

# ■ CAPTAIN TOMADAY SOFT DIP ■

SOFT DIP SCREEN

CAPTAIN TOMADAY	
DIFFICULTY	LEVEL4
CONTINUE	WITH
DEMO SOUND	WITH
LEVEL DISP	WITH
CREDIT DISP	WITH
INSTRUCTION	WITH
WIN COUNT	3

## 【SETTING】

- ① Use Joystick to move cursor to the desired items.
- ② Press A or B button to change the setting.

【 DIFFICULTY 】	DIFFICULTY SETTING
	LEVEL1 ⇨ 2 ⇨ 3 ⇨ 4 ⇨ 5 ⇨ 6 ⇨ 7 ⇨ 8
【 CONTINUE 】	WITH OR WITHOUT CONTINUE PLAY
	WITH ⇨ WITHOUT
【 DEMO SOUND 】	WITH OR WITHOUT DEMO SOUND
	WITH ⇨ WITHOUT
【 LEVEL DISPLAY 】	WITH OR WITHOUT LEVEL DISPLAY
	WITHOUT ⇨ WITH
【 CREDIT DISPLAY 】	WITH OR WITHOUT CREDIT DISPLAY
	WITH ⇨ WITHOUT
【 HOW TO PLAY 】	WITH OR WITHOUT HOW TO PLAY SCREEN
	WITH ⇨ WITHOUT

---

---


## SETTING UP THE SOFT DIP ON THE MULTI VIDEO SYSTEM

---

---


1. TURN POWER ON.
2. PUSH THE TEST BUTTON INSIDE THE CABINET.
3. THE FOLLOWING SCREEN WILL APPEAR.

**MOVE LEFT JOYSTICK UP/DOWN TO MOVE THE POINTER TO "SETTING UP THE SOFT DIP". PRESS "A" BUTTON TO SET.**



HARDWARE TEST  
SETTING UP THE HARD DIP  
SETTING UP THE SOFT DIP  
BOOKKEEPING  
SETTING UP THE CODE NUMBER  
SETTING UP THE CALENDAR  
EXIT

THE FOLLOWING SCREEN WILL BE DISPLAYED:



CABINET SET UP  
SLOT 1 (GAME TITLE)  
SLOT 2 (GAME TITLE)  
SLOT 3 (GAME TITLE)  
SLOT 4 (GAME TITLE)  
SLOT 5 (GAME TITLE)  
SLOT 6 (GAME TITLE)

4. SELECT THE GAME TITLE YOU WANT AND PRESS "A" BUTTON TO VIEW THE SOFT DIP SETTING OF EACH INDIVIDUAL GAME.