

SECTION EF & EC

CONTENTS

<p>PREPARATION.....3</p> <p style="padding-left: 20px;">Special Service Tools3</p> <p>PRECAUTIONS4</p> <p>ENGINE AND EMISSION CONTROL OVERALL SYSTEM.....5</p> <p style="padding-left: 20px;">ECCS Component Parts Location.....5</p> <p style="padding-left: 20px;">System Diagram7</p> <p style="padding-left: 20px;">System Chart9</p> <p style="padding-left: 20px;">Vacuum Hose Drawing10</p> <p style="padding-left: 20px;">Circuit Diagram12</p> <p>ENGINE AND EMISSION CONTROL PARTS DESCRIPTION.....13</p> <p style="padding-left: 20px;">Engine Control Module (ECM)-ECCS Control Module13</p> <p style="padding-left: 20px;">Camshaft Position Sensor (CMPS)13</p> <p style="padding-left: 20px;">Mass Air Flow Sensor (MAFS)13</p> <p style="padding-left: 20px;">Engine Coolant Temperature Sensor (ECTS)13</p> <p style="padding-left: 20px;">Throttle Position Sensor (TPS) & Soft/Hard Closed Throttle Position (CTP) Switch14</p> <p style="padding-left: 20px;">Fuel Injector14</p> <p style="padding-left: 20px;">Pressure Regulator15</p> <p style="padding-left: 20px;">Heated Oxygen Sensor (HO2S).....15</p> <p style="padding-left: 20px;">Fuel Pump15</p> <p style="padding-left: 20px;">Fuel Damper15</p> <p style="padding-left: 20px;">Power Transistor Unit & Ignition Coil16</p> <p style="padding-left: 20px;">Idle Air Control Valve (IACV)-Air Regulator.....16</p> <p style="padding-left: 20px;">Idle Air Adjusting (IAA) Unit16</p> <p style="padding-left: 20px;">Idle Air Control Valve (IACV)-Auxiliary Air Control (AAC) Valve16</p> <p style="padding-left: 20px;">Power Steering Oil Pressure Switch17</p> <p style="padding-left: 20px;">Vehicle Speed Sensor (VSS)17</p> <p style="padding-left: 20px;">Knock Sensor (KS)17</p> <p style="padding-left: 20px;">Exhaust Gas Recirculation (EGR) Valve.....17</p> <p style="padding-left: 20px;">EGR Control (EGRC)-Solenoid Valve18</p> <p style="padding-left: 20px;">Pressure Regulator Vacuum Relief (PRVR) Control Solenoid Valve18</p> <p style="padding-left: 20px;">Wastegate Valve Control Solenoid Valve.....18</p>	<p style="padding-left: 20px;">Fuel Filter.....18</p> <p style="padding-left: 20px;">Data Link Connector for CONSULT18</p> <p style="padding-left: 20px;">EGR Temperature Sensor19</p> <p style="padding-left: 20px;">Valve Timing Control Solenoid Valve.....19</p> <p style="padding-left: 20px;">Carbon Canister.....19</p> <p style="padding-left: 20px;">Fuel Temperature Sensor19</p> <p style="padding-left: 20px;">Boost Pressure Sensor.....19</p> <p>ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION20</p> <p style="padding-left: 20px;">Multiport Fuel Injection (MFI) System20</p> <p style="padding-left: 20px;">Electronic Ignition (EI) System22</p> <p style="padding-left: 20px;">Idle Air Control (IAC) System23</p> <p style="padding-left: 20px;">Fuel Pump Control.....24</p> <p style="padding-left: 20px;">Exhaust Gas Recirculation (EGR) System.....25</p> <p style="padding-left: 20px;">Fuel Pressure Regulator Control.....26</p> <p style="padding-left: 20px;">Air Conditioning Cut Control.....26</p> <p style="padding-left: 20px;">Valve Timing Control.....27</p> <p style="padding-left: 20px;">Cooling Fan Control.....29</p> <p style="padding-left: 20px;">Wastegate Valve Control30</p> <p style="padding-left: 20px;">Fail-safe System31</p> <p style="padding-left: 20px;">Direct Ignition System.....33</p> <p>IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION35</p> <p>TROUBLE DIAGNOSES41</p> <p style="padding-left: 20px;">Contents.....41</p> <p>MULTIPORT FUEL INJECTION SYSTEM INSPECTION.....189</p> <p style="padding-left: 20px;">Releasing Fuel Pressure189</p> <p style="padding-left: 20px;">Fuel Pressure Check.....189</p> <p style="padding-left: 20px;">Injector Removal and Installation190</p> <p>EVAPORATIVE EMISSION SYSTEM191</p> <p style="padding-left: 20px;">Description191</p> <p style="padding-left: 20px;">Inspection.....191</p> <p>CRANKCASE EMISSION CONTROL SYSTEM.....193</p> <p style="padding-left: 20px;">Description193</p>
---	---

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS (Cont'd)

Inspection.....	193	General Specifications.....	194
SERVICE DATA AND SPECIFICATIONS (SDS)	194	Inspection and Adjustment	194

For assistance with wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

Note: Refer to Foldout page for "ECCS WIRING DIAGRAM".

PREPARATION

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description	
① KV109D0010 (J36777-1) Ignition timing adapter coil ② KV10114200 (J-36777-4) Adapter harness	<p>NT054</p>	Measuring ignition timing GI MA EM LC EF & EC
KV10114400 (J-38365) Heated oxygen sen- sor wrench	<p>NT636</p> <p>a: 22 mm (0.87 in)</p>	Loosening or tightening heated oxygen sensor FE CL MT AT PD FA RA BR ST RS BT HA EL IDX


PRECAUTIONS

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

INJECTOR

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors.




ECM

- Do not disassemble ECCS control module (ECM).
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECCS will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following: (Such wireless equipment may adversely affect electronic control systems depending on its installation location.)
- 1) Keep the antenna as far away as possible from the ECM.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



ECCS PARTS HANDLING

- Handle air flow meter carefully to avoid damage.
- Do not disassemble air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.




WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS** section of this service manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS.

ECCS HARNESS HANDLING

- Securely connect ECCS harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECCS harness at least 10 cm (3.9 in) away from adjacent harnesses. This prevents an ECCS system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECCS parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

ECCS Component Parts Location

NON-TURBOCHARGER MODEL



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)


TURBOCHARGER MODEL



ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Diagram


NON-TURBOCHARGER MODEL



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM


System Chart



* Turbocharger model only

Vacuum Hose Drawing


NON-TURBOCHARGER MODEL



ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Vacuum Hose Drawing (Cont'd)

TURBOCHARGER MODEL





- ① PRVR control solenoid valve to Vacuum tank collector
- ② PRVR control solenoid valve to Intake manifold collector
- ③ PRVR control solenoid valve to Fuel vacuum gallery
- ④ Fuel pressure regulator to Fuel vacuum gallery
- ⑤ Fuel damper to Balance tube
- ⑥ EGRC-solenoid valve to Rear side vacuum gallery
- ⑦ Rear side vacuum gallery to Right side vacuum gallery
- ⑧ EGRC-solenoid valve to Right side vacuum gallery
- ⑨ Throttle body to EGRC-solenoid valve
- ⑩ EGRC-solenoid valve to Right side air gallery through 3-way connector
- ⑪ Air duct to Right side air gallery
- ⑫ Right side recirculation valve to Intake manifold collector
- ⑬ Right side wastegate valve control solenoid valve to Air pipe through 3-way connector
- ⑭ Right side wastegate valve control solenoid valve to Suction pipe
- ⑮ Right side wastegate valve actuator to Air pipe through 3-way connector
- ⑯ Air pipe to 3-way connector (For right side wastegate valve control)
- ⑰ Left side wastegate valve control solenoid valve to Air pipe through 3-way connector
- ⑱ Left side wastegate valve control solenoid valve to Suction pipe
- ⑲ PRVR control solenoid valve
- ⑳ Rear vacuum gallery
- ㉑ Recirculation valve
- ㉒ Boost pressure gallery
- ㉓ Recirculation valve
- ㉔ Boost pressure sensor
- ㉕ Front side
- ① Right vacuum gallery
- ② Right wastegate valve control solenoid valve
- ③ Wastegate valve actuator
- ④ EGRC-solenoid valve
- ⑤ Fuel vacuum gallery
- ⑥ PRVR control solenoid valve
- ⑦ Wastegate valve actuator
- ⑧ Boost pressure sensor
- ⑨ Left side wastegate valve control solenoid valve
- ⑩ Boost pressure sensor
- ⑪ Air pipe to 3-way connector
- ⑫ Left side recirculation valve to Intake manifold collector
- ⑬ Canister purge line
- ⑭ Boost pressure sensor to Left side air pipe through boost pressure gallery
- ⑮ Boost pressure sensor to Boost pressure gallery through boost pressure gallery
- ⑯ Boost pressure sensor to Right side air pipe through boost pressure gallery

GI
MA
EM
LG
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram





SEC220B

Engine Control Module (ECM)-ECCS Control Module


The ECM consists of a microcomputer, an inspection lamp, a diagnostic test mode selector, and connectors for signal input and output and for power supply. The module controls the engine.

GI

MA

EM

LC



SEF971E

Camshaft Position Sensor (CMPS)


The camshaft position sensor is a basic component of the ECCS. It monitors engine speed and piston position, and sends signals to the ECM to control fuel injection, ignition timing and other functions. The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 6 slits for 120° signal. Light Emitting Diodes (LED) and photo diodes are built in the wave-forming circuit.

EF & EC

FE

CL

MT



SEF326I


The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

AT

PD

FA

RA



SEC221B

Mass Air Flow Sensor (MAFS)

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss.


BR

ST

RS

Therefore, the ECM must supply more electric current to the hot film as air flow increases. This maintains the temperature of the hot film. The ECM detects the air flow by means of this current change.

BT



MEF870F

Engine Coolant Temperature Sensor (ECTS)


The engine coolant temperature sensor, located on the top of water inlet housing, detects engine coolant temperature and transmits a signal to the ECM.

HA

EL



The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

IDX




Throttle Position Sensor (TPS) & Soft/Hard Closed Throttle Position (CTP) Switch

The throttle position sensor responds to accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM. Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This system is called "soft closed throttle position switch". It controls engine operation such as fuel cut. On the other hand, "hard closed throttle position switch", which is built into the throttle position sensor unit, is used for engine control when soft closed throttle position switch is malfunctioning.



Fuel Injector

The fuel injector is a small, elaborate solenoid valve. As the ECM sends injection signals to the injector, the coil in the injector pulls the needle valve back and fuel is released into the intake manifold through the nozzle. The injected fuel is controlled by the ECM in terms of injection pulse duration.



Pressure Regulator


The pressure regulator maintains the fuel pressure at 299.1 kPa (3.05 kg/cm², 43.4 psi). Since the injected fuel amount depends on injection pulse duration, it is necessary to maintain the pressure at the above value.

GI

MA

EM

LC



Heated Oxygen Sensor (HO2S)


The heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

EF & EC

FE

CL

MT




AT

PD

FA

RA



Fuel Pump


The fuel pump is an in-tank type with a fuel damper. Both the pump and damper are located in the fuel tank.

BR

ST

RS

BT




Fuel Damper

The fuel damper, which consists of a diaphragm, reduces fuel pressure pulsation in the fuel feed line between the fuel filter and injectors.

HA



EL

IDX



Power Transistor Unit & Ignition Coil


The ignition signal from the ECM is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type.



Idle Air Control Valve (IACV)-Air Regulator

The IACV-air regulator provides an air by-pass when the engine is cold for a fast idle during warm-up.


A bimetal, heater and rotary shutter are built into the IACV-air regulator. When the bimetal temperature is low, the air by-pass port opens. As the engine starts and electric current flows through a heater, the bimetal begins to turn the shutter to close the by-pass port. The air passage remains closed until the engine stops and the bimetal temperature drops.



Idle Air Adjusting (IAA) Unit


The IAA unit is made up of the IACV-AAC valve, IACV-FICD solenoid valve and idle adjust screw. It receives the signal from the ECM and controls the idle speed at the preset value.

The IACV-FICD solenoid valve compensates for changes in idle speed caused by the operation of the air compressor.



Idle Air Control Valve (IACV)-Auxiliary Air Control (AAC) Valve


The ECM actuates the IACV-AAC valve by an ON/OFF pulse. The longer that ON duty is left on, the larger the amount of air that will flow through the IACV-AAC valve.



Power Steering Oil Pressure Switch

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects the power steering load, sending the load signal to the ECM. The ECM then sends the idle-up signal to the IACV-AAC valve.

GI
MA
EM
LC




Vehicle Speed Sensor (VSS)

The vehicle speed sensor provides a vehicle speed signal to the ECM.

The speed sensor consists of a reed switch, which is installed in the speedometer unit and transforms vehicle speed into a pulse signal.

EF & EC
FE
CL
MT




Knock Sensor (KS)

The knock sensor is attached to the cylinder block and senses engine knocking conditions.

A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is sent to the ECM.


AT
PD
FA
RA



Exhaust Gas Recirculation (EGR) Valve

The EGR valve controls the quantity of exhaust gas to be diverted to the intake manifold through vertical movement of a taper valve connected to the diaphragm. Vacuum is applied to the diaphragm in response to the opening of the throttle valve.

BR
ST
RS
BT
HA
EL
IDX




EGR Control (EGRC)-Solenoid Valve

The solenoid valve responds to the ON/OFF signal from the ECM. When it is off, a vacuum signal from the throttle body is fed into the EGR valve. When the ECM sends an ON signal, the coil pulls the plunger downward and cuts the vacuum signal.


Pressure Regulator Vacuum Relief (PRVR) Control Solenoid Valve

The solenoid valve responds to the ON/OFF signal from the ECM. When it is off, a vacuum signal from the intake manifold is fed into the pressure regulator. When the ECM sends an ON signal, the coil pulls the plunger downward and cuts the vacuum signal.




Wastegate Valve Control Solenoid Valve

The solenoid valve responds to the ON/OFF signal from the ECM. When it is ON, a vacuum signal from the suction pipe or compressor outlet is fed into the wastegate valve actuator. The actuator is hard to open at this time. When the control module sends an OFF signal, the coil pulls the plunger upward and cuts the route to the suction pipe.




Fuel Filter

The specially designed fuel filter has a metal case in order to withstand high fuel pressure.



Data Link Connector for CONSULT

The data link connector for CONSULT is located above the hood release handle.




EGR Temperature Sensor

The EGR temperature sensor monitors the exhaust gas temperature and transmits a signal to the ECM. The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electric resistance of the thermistor decreases in response to the temperature rise.

CI
MA
EM

LC



Valve Timing Control Solenoid Valve


The valve timing control solenoids are installed at the rear end of the intake camshafts, and control oil pressure which regulates the position of the intake camshafts.

EF & EC

FE

CL

WT



Carbon Canister


The carbon canister is filled with active charcoal to absorb evaporative gases produced in the fuel tank. These absorbed gases are then delivered to the intake manifold by manifold vacuum for combustion purposes.

AT

PD

FA

RA



Fuel Temperature Sensor


The fuel temperature sensor, built into the fuel tube, senses fuel temperature. When the fuel temperature is higher than specified, the ECM (ECCS control module) turns the PRVR control solenoid valve ON and raises fuel pressure.

BR

ST

RS

BT



Boost Pressure Sensor

The boost pressure sensor detects boost pressure at the upstream of the throttle body. The pressure signal is transmitted to the ECM.


HA

EL

IDX

Multiport Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL LINE



*Turbocharger only

BASIC MULTIPOINT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector, or the length of time the valve remains open, is determined by the ECM. The basic amount of fuel injected is a program value mapped in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

The amount of fuel injection is compensated for to improve engine performance. This will be made under various operating conditions as listed below.


(Fuel increase)

- 1) During warm-up
- 2) When starting the engine
- 3) During acceleration
- 4) Hot-engine operation

(Fuel decrease)

- 1) During deceleration
- 2) During high boost pressure

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION



Multiport Fuel Injection (MFI) System (Cont'd) MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system is used for precise control of the mixture ratio to the stoichiometric point, so that the three way catalyst can reduce CO, HC and NOx emissions. This system uses an heated oxygen sensor in the exhaust manifold to check the air-fuel ratio. The ECM adjusts the injection pulse width according to the sensor voltage so the mixture ratio will be within the range of the stoichiometric air-fuel ratio.


This stage refers to the closed loop control condition. The open loop control condition refers to that under which the ECM detects any of the following conditions and feedback control stops in order to maintain stabilized fuel combustion.

- 1) Deceleration
- 2) High-load, high-speed operation
- 3) Engine idling
- 4) Malfunction of heated oxygen sensor or its circuit
- 5) Insufficient activation of heated oxygen sensor at low engine coolant temperature
- 6) Engine starting
- 7) Heated oxygen sensor high output voltage

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor. This feedback signal is then sent to the ECM to control the amount of fuel injection to provide a basic mixture ratio as close to the stoichiometric mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing errors (e.g., mass air flow sensor hot wire) and changes during operation (injector clogging, etc.) of ECCS parts which directly affect the mixture ratio.

Accordingly, a difference between the basic and stoichiometric mixture ratios is monitored in this system. It is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.



FUEL INJECTION TIMING

Two types of systems are used — sequential multipoint fuel injection system and simultaneous multipoint fuel injection system.

- 1) Simultaneous multipoint fuel injection system
Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM. The six injectors will then receive the signals two times for each engine cycle. This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.
- 2) Sequential multipoint fuel injection system
Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.



FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or high-speed operation.

G1
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Electronic Ignition (EI) System

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM in order to maintain the best air-fuel ratio in response to every running condition of the engine.

The ignition timing data is stored in the ECM. This data forms the map shown below.

The ECM detects information such as the injection pulse width and camshaft position sensor signal which varies every moment. Then responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, T_p : 1.50 msec

A °BTDC

In addition to this,

- 1) At starting
- 2) During warm-up
- 3) At idle
- 4) At low battery voltage


the ignition timing is revised by the ECM according to the other data stored in the ECM.

The retard system, actuated by the knock sensor, is designed only for emergencies. The basic ignition timing is pre-programmed within the anti-knocking zone, even if recommended fuel is used under dry conditions. Consequently, the retard system does not operate under normal driving conditions.

However, if engine knocking occurs, the knock sensor monitors the condition and the signal is transmitted to the ECM (ECCS control module). After receiving it, the ECM retards the ignition timing to eliminate the knocking condition.

Idle Air Control (IAC) System

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as noise and vibration transmitted to the vehicle interior, fuel consumption, and engine load.

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Fuel Pump Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

Fuel pump and IACV-air regulator ON-OFF control

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine start-up. If the ECM receives a 1° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to activate. If the 1° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second
Engine running and cranking	Operates
When engine is stopped	Stops in 1.5 seconds
Except as shown above	Stops

Fuel pump voltage control


The fuel pump is controlled by the fuel pump control unit adjusting the voltage supplied to the fuel pump.

Conditions	Supplied voltage	
	Turbocharger model	Non-turbocharger model
<ul style="list-style-type: none"> • 1 second after ignition switch is turned ON • Engine cranking • 30 (*NA)/5 (**TC) seconds after engine start [above 50°C (122°F)] • Engine coolant temperature below 0°C (32°F) • Engine is running under heavy load conditions 	Battery voltage	Battery voltage
<ul style="list-style-type: none"> • Engine is running under middle load conditions 	Approx. 7V	Battery voltage
<ul style="list-style-type: none"> • Except the above 	Approx. 6V	Approx. 8V

*NA: Non-turbocharger model **TC: Turbocharger model

Exhaust Gas Recirculation (EGR) System

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

This system cuts and controls vacuum applied to EGR valve and canister to suit engine operating conditions.

This cut-and-control operation is accomplished through the ECM. When the ECM detects any of the following conditions, current flows through the solenoid valve in the EGR control vacuum line.

This causes the port vacuum to be discharged into the atmosphere so that the EGR valve remains closed.

- 1) Low engine coolant temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling
- 5) Excessively high engine coolant temperature

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


Fuel Pressure Regulator Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

The fuel “pressure-up” control system briefly increases fuel pressure for improved starting performance of a hot engine. Under normal operating conditions, manifold vacuum is applied to the fuel pressure regulator. When starting the engine, however, the ECM allows current to flow through the ON/OFF solenoid valve in the control vacuum line, opening this line to the atmosphere. As a result, atmospheric pressure is applied, restricting the fuel return line so as to increase fuel pressure.



Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

This system improves acceleration when the air conditioner is used.

Valve Timing Control


INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The valve timing control system is utilized to increase engine performance. Intake valve opening and closing time is controlled, according to the engine operating conditions, by the ECM. Engine coolant temperature signals, engine speed,

amount of intake air, throttle position and gear position are used to determine intake valve timing. The intake camshaft pulley position is regulated by oil pressure, which is controlled by the valve timing control solenoid valve.




MEF434EA

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION


Valve Timing Control (Cont'd)

OPERATION

Engine operating condition	Valve timing control solenoid valve	Intake valve opening and closing time	Valve overlap	Engine torque curve
Idling, high speed	OFF	Retard	Decreased	Ⓘ
Low to medium speed	ON	Advance	Increased	Ⓚ



SEF009I




SEF010I

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Cooling Fan Control

INPUT/OUTPUT SIGNAL LINE



The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The non-turbocharger model has 2-step control [ON/OFF]. The turbocharger model has [ON/OFF] and [LOW/HIGH] speed control.

OPERATION

[Non-turbocharger model]

Air conditioner switch is "OFF"

Engine coolant temperature °C (°F)	Cooling fan
Below 104 (219)	OFF
Above 105 (221)	ON

Air conditioner switch is "ON"

Vehicle speed km/h (MPH)	Engine coolant temperature °C (°F)	Cooling fan
Below 39 (24)	Below 94 (201)	OFF
	Above 95 (203)	ON
Above 40 (25)	Below 104 (219)	OFF
	Above 105 (221)	ON

[Turbocharger model]

Air conditioner switch is "OFF"

Engine coolant temperature °C (°F)	Cooling fan
Below 104 (219)	OFF
Above 105 (221)	ON (HIGH)


Air conditioner switch is "ON"

Vehicle speed km/h (MPH)	Engine coolant temperature °C (°F)	Cooling fan
Below 39 (24)	Below 89 (192)	OFF
	Between 90 (194) and 99 (210)	LOW
	Above 100 (212)	HIGH
Above 40 (25)	Below 104 (219)	OFF
	Above 105 (221)	HIGH

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Wastegate Valve Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

The wastegate valve control solenoid valve changes the source vacuum which activates the actuator. This results in a suitable turbocharger-pressure.

When knock signs are detected, which means a low octane fuel is being used, the solenoid valve turns OFF, and turbocharger pressure becomes low.


OPERATION

Engine conditions	Wastegate valve control solenoid valves	Wastegate valve actuators	Turbocharger pressure
<ul style="list-style-type: none"> • Engine running or cranking • Throttle position sensor output voltage: more than 0.1V • Judged fuel quality: hi octane (Detecting no sign of knock) • Engine coolant temperature is less than 55°C (131°F) 	ON	Lead to suction pipe or turbocharger compressor outlet	HIGH
<ul style="list-style-type: none"> • Except the above 	OFF	Lead to turbocharger compressor outlet	LOW

Fail-safe System

CPU MALFUNCTION OF ECM

Input/output signal line



Outline

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit.

In general, engine starting was difficult under the previously mentioned conditions. But with the provisions in this fail-safe system, it is possible to start the engine.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fail-safe System (Cont'd)

Fail-safe system activating condition when ECM is malfunctioning

The fail-safe mode operation starts when the computing function of the ECM is judged to be malfunctioning.

When the fail-safe system activates, i.e. if a malfunction condition is detected in the CPU of the ECM, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.

Engine control, with fail-safe system, operates when ECM is malfunctioning

When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, engine idle speed, EGR operation, and so on are controlled under certain limitations.

Cancellation of fail-safe system when ECM is malfunctioning

Activation of the fail-safe system is canceled each time the ignition switch is turned OFF. The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from OFF to ON.

MASS AIR FLOW SENSOR MALFUNCTION

If the mass air flow sensor output voltage is above or below the specified value, the ECM senses a mass air flow sensor malfunction. In case of a malfunction, the throttle position sensor substitutes for the mass air flow sensor.

Although the mass air flow sensor is malfunctioning, it is possible to start the engine and drive the vehicle. But engine speed will not rise more than 2,400 rpm in order to inform the driver of fail-safe system operation while driving.

Operation

Engine condition	Starter switch	Fail-safe system	Fail-safe functioning
Stopped	ANY	Does not operate	—
Cranking	ON	Operates	Engine will be started by a pre-determined injection pulse on ECM.
Running	OFF		Engine speed will not rise above 2,400 rpm

ENGINE COOLANT TEMPERATURE SENSOR MALFUNCTION


When engine coolant temperature sensor output voltage is below or above the specified value, engine coolant temperature signal is fixed at the preset value as follows:

Engine condition	Engine coolant temperature preset value °C (°F)
Start	20 (68)
Running	80 (176)

FUEL TEMPERATURE SENSOR MALFUNCTION

When fuel temperature sensor output voltage is below or above the specified value, fuel temperature signal is fixed at the preset value as follows:

Engine condition	Fuel temperature preset value °C (°F)
Start	20 (68)
Running	80 (176)



Direct Ignition System

CHECKING IDLE SPEED AND IGNITION TIMING

Idle speed

- **Method (With pulse type tachometer)**

Clamp loop wire as shown.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL


IDX



Ignition timing


- **Method A (Without SST)**

1. Remove No. 1 ignition coil.



2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.

3. Check ignition timing.




4. For above procedures, enlarge suitable high-tension wire end with insulating tape as shown.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION


Direct Ignition System (Cont'd)

- **Method B (With SST)**


1. Disconnect connector of No. 1 ignition coil.



2. Connect SST and clamp wire with timing light as shown.
3. Check ignition timing.



Align direction marks on SST and timing light clamp if aligning mark is punched.



IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION

PREPARATION

1. Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system
(Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - EGR valve operation
 - Throttle valve

2. On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
3. On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while gear shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA







EL

IDX





Overall inspection sequence



IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION






IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION






GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION






IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



M

①

- 1) Disconnect engine coolant temperature sensor harness connector.
- 2) Connect a resistor (2.5 kΩ) between terminals of engine coolant temperature sensor harness connector.

N

Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge.

O

Race engine two or three times under no-load, then run engine at idle speed.

Check "CO" %.

Idle CO: 0.2 - 8%

After checking CO%,

- 1) Disconnect the resistor from terminals of engine coolant temperature sensor.
- 2) Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.

NG

Connect heated oxygen sensor harness connector to heated oxygen sensor.

Check fuel pressure regulator.

Check mass air flow sensor.

Check injector.
Clean or replace if necessary.

Check engine coolant temperature sensor.

Check ECM function* by substituting another known good ECM.

*: ECM may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES




Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	EF & EC- 43	GI
On-board Diagnostic System	EF & EC- 47	
On-board Diagnostic System — Diagnostic Test Mode I	EF & EC- 49	
On-board Diagnostic System — Diagnostic Test Mode II (Self-diagnostic results)	EF & EC- 50	MA
On-board Diagnostic System — Diagnostic Test Mode II (Heated oxygen sensor monitor)	EF & EC- 53	
Consult	EF & EC- 54	EM
Diagnostic Procedure	EF & EC- 62	
Basic Inspection	EF & EC- 64	
Diagnostic Procedure 1 — High Idling after Warm-up	EF & EC- 67	LC
Diagnostic Procedure 2 — Hunting	EF & EC- 68	
Diagnostic Procedure 3 — Unstable Idle	EF & EC- 70	
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold	EF & EC- 74	EF & EC
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot	EF & EC- 76	FE
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions	EF & EC- 78	
Diagnostic Procedure 7 — Hesitation when the Engine is Hot	EF & EC- 80	CL
Diagnostic Procedure 8 — Hesitation when the Engine is Cold	EF & EC- 80	
Diagnostic Procedure 9 — Hesitation under Normal Conditions	EF & EC- 81	
Diagnostic Procedure 10 — Engine Stalls when Turning	EF & EC- 83	MT
Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot	EF & EC- 85	
Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold	EF & EC- 87	
Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily	EF & EC- 89	AT
Diagnostic Procedure 14 — Engine Stalls after Decelerating	EF & EC- 92	
Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising	EF & EC- 97	PD
Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy	EF & EC- 99	
Diagnostic Procedure 17 — Lack of Power and Stumble	EF & EC-101	
Diagnostic Procedure 18 — Knock	EF & EC-102	FA
Diagnostic Procedure 19 — Surge	EF & EC-103	
Diagnostic Procedure 20 — Backfire through the Intake	EF & EC-105	
Diagnostic Procedure 21 — Backfire through the Exhaust	EF & EC-105	RA
Diagnostic Procedure 22		
MAIN POWER SUPPLY AND GROUND CIRCUIT	EF & EC-106	
Diagnostic Procedure 23		BR
CAMSHAFT POSITION SENSOR	EF & EC-108	
Diagnostic Procedure 24		
MASS AIR FLOW SENSOR	EF & EC-111	ST
Diagnostic Procedure 25		
ENGINE COOLANT TEMPERATURE SENSOR	EF & EC-114	RS
Diagnostic Procedure 26		
VEHICLE SPEED SENSOR	EF & EC-116	
Diagnostic Procedure 27		BT
IGNITION SIGNAL	EF & EC-119	
Diagnostic Procedure 28		
BOOST PRESSURE SENSOR	EF & EC-122	HA
Diagnostic Procedure 29		
ENGINE CONTROL MODULE	EF & EC-124	EL
Diagnostic Procedure 30		
EGR FUNCTION	EF & EC-125	
Diagnostic Procedure 31		IDX
HEATED OXYGEN SENSOR	EF & EC-129	

TROUBLE DIAGNOSES

Contents (Cont'd)

Diagnostic Procedure 32	
KNOCK SENSOR	EF & EC-132
Diagnostic Procedure 33	
EGR TEMPERATURE SENSOR	EF & EC-134
Diagnostic Procedure 34	
FUEL TEMPERATURE SENSOR	EF & EC-136
Diagnostic Procedure 35	
THROTTLE POSITION SENSOR	EF & EC-138
Diagnostic Procedure 36	
INJECTOR LEAK	EF & EC-141
Diagnostic Procedure 37	
INJECTOR CIRCUIT	EF & EC-143
Diagnostic Procedure 38	
CLOSED THROTTLE POSITION SWITCH	EF & EC-145
Diagnostic Procedure 39	
START SIGNAL	EF & EC-147
Diagnostic Procedure 40	
POWER STEERING OIL PRESSURE SWITCH	EF & EC-149
Diagnostic Procedure 41	
NEUTRAL POSITION SWITCH & A/T CONTROL UNIT (NEUTRAL POSITION SIGNAL) CIRCUIT	EF & EC-151
Diagnostic Procedure 42	
FUEL PUMP	EF & EC-153
Diagnostic Procedure 43	
IACV-AIR REGULATOR	EF & EC-156
Diagnostic Procedure 44	
IACV-AAC VALVE	EF & EC-159
Diagnostic Procedure 45	
IACV-FICD SOLENOID VALVE	EF & EC-161
Diagnostic Procedure 46	
PRVR CONTROL SOLENOID VALVE	EF & EC-163
Diagnostic Procedure 47	
VTC SOLENOID VALVE	EF & EC-165
Diagnostic Procedure 48	
COOLING FAN CONTROL	EF & EC-167
Diagnostic Procedure 49	
WASTEGATE VALVE CONTROL SOLENOID VALVE	EF & EC-174
Electrical Components Inspection	EF & EC-176



How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



*1: If the on-board diagnostic system cannot be performed, check main power supply and ground circuit. (See Diagnostic Procedure 22.)

*2: If the trouble is not duplicated, see INTERMITTENT PROBLEM SIMULATION (EF & EC-46).

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

KEY POINTS

- WHAT** Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SEF907L

DIAGNOSTIC WORKSHEET

There are many kinds of operating conditions that lead to malfunctions on engine components.

A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, feelings for a problem depend on each customer. It is important to fully understand the symptoms or under what conditions a customer complains.

Make good use of a worksheet like below in order to utilize all the complaints for trouble-shooting.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Worksheet sample

Customer name MR/MS		Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Symptoms	<input type="checkbox"/> Startability	<input type="checkbox"/> Impossible to start <input type="checkbox"/> No combustion <input type="checkbox"/> Partial combustion <input type="checkbox"/> Partial combustion affected by throttle position <input type="checkbox"/> Partial combustion NOT affected by throttle position <input type="checkbox"/> Possible but hard to start <input type="checkbox"/> Others []	
	<input type="checkbox"/> Idling	<input type="checkbox"/> No fast idle <input type="checkbox"/> Unstable <input type="checkbox"/> High idle <input type="checkbox"/> Low idle <input type="checkbox"/> Others []	
	<input type="checkbox"/> Driveability	<input type="checkbox"/> Stumble <input type="checkbox"/> Surge <input type="checkbox"/> Knock <input type="checkbox"/> Lack of power <input type="checkbox"/> Intake backfire <input type="checkbox"/> Exhaust backfire <input type="checkbox"/> Others []	
	<input type="checkbox"/> Engine stall	<input type="checkbox"/> At the time of start <input type="checkbox"/> While idling <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating <input type="checkbox"/> Just after stopping <input type="checkbox"/> While loading	
Incident occurrence		<input type="checkbox"/> Just after delivery <input type="checkbox"/> Recently <input type="checkbox"/> In the morning <input type="checkbox"/> At night <input type="checkbox"/> In the daytime	
Frequency		<input type="checkbox"/> All the time <input type="checkbox"/> Under certain conditions <input type="checkbox"/> Sometimes	
Weather conditions		<input type="checkbox"/> Not affected	
		Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Raining <input type="checkbox"/> Snowing <input type="checkbox"/> Others []
		Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Humid °F
Engine conditions		<input type="checkbox"/> Cold <input type="checkbox"/> During warm-up <input type="checkbox"/> After warm-up Engine speed <div style="text-align: center;"> </div>	
Road conditions		<input type="checkbox"/> In town <input type="checkbox"/> In suburbs <input type="checkbox"/> Highway <input type="checkbox"/> Off road (up/down)	
Driving conditions		<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH) Vehicle speed <div style="text-align: center;"> </div>	
Malfunction indicator lamp		<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on	


TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

INTERMITTENT PROBLEM SIMULATION


In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under Service procedure and note the result.



	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Camshaft position sensor	Advanced	Rotate distributor counterclockwise.
			Retarded	Rotate distributor clockwise.
3	Mixture ratio feedback control	Heated oxygen sensor	Suspended	Disconnect heated oxygen sensor harness connector.
		ECM	Operation check	Perform on-board diagnostic system (Diagnostic Test Mode II) at 2,000 rpm.
4	Idle speed	IACV-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electrical connection (Electric continuity)	Harness connectors and wires	Poor electrical connection or improper wiring	Tap or wiggle.
				Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	ECM	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioner, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Rotate throttle position sensor body.
10	Ignition spark position	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition coil adapter (SST).

TROUBLE DIAGNOSES






On-board Diagnostic System

MALFUNCTION INDICATOR LAMP

A malfunction indicator lamp has been adopted on the combination meter.

ON-BOARD DIAGNOSTIC SYSTEM FUNCTION

Condition		Diagnostic Test Mode	
		Diagnostic Test Mode I	Diagnostic Test Mode II
Ignition switch in "ON" position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	HEATED OXYGEN SENSOR MONITOR

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TROUBLE DIAGNOSES

On-board Diagnostic System (Cont'd) HOW TO SWITCH DIAGNOSTIC TEST MODES



- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 1 second. The diagnosis will automatically return to Diagnostic Test Mode I.

TROUBLE DIAGNOSES

On-board Diagnostic System — Diagnostic Test Mode I

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MALFUNCTION INDICATOR LAMP in the instrument panel stays "ON".

If either remain "OFF", check the bulb in the MALFUNCTION INDICATOR LAMP.

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MALFUNCTION INDICATOR LAMP	Condition
ON	When the following malfunction (malfunction indicator lamp item) is detected or the ECM's CPU is malfunctioning.
OFF	OK

Diagnostic trouble code No.	Malfunction
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
26	Boost pressure sensor (Turbocharger model)
31	ECM (ECCS control module)
32	EGR function
33	Heated oxygen sensor circuit (Left side)
35	EGR temperature sensor circuit
43	Throttle position sensor circuit
45	Injector leak
51	Injector circuit
53	Heated oxygen sensor circuit (Right side)

- These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS.
- The MALFUNCTION INDICATOR LAMP will turn off when normal condition is detected. At this time, the Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS memory must be cleared as the contents remain stored.


GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSES

On-board Diagnostic System — Diagnostic Test Mode II (Self-diagnostic results)

DESCRIPTION













In this mode, a diagnostic trouble code is indicated by the number of flashes from the MALFUNCTION INDICATOR LAMP as shown below:




Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits. For example, the MALFUNCTION INDICATOR LAMP flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the mass air flow sensor. In this way, all the problems are classified by their diagnostic trouble code numbers.

The diagnostic results will remain in ECM memory.

Display diagnostic trouble code table

Diagnostic trouble code No.	Detected items
11	Camshaft position sensor circuit
12 	Mass air flow sensor circuit
13 	Engine coolant temperature sensor circuit
14 	Vehicle speed sensor circuit
21	Ignition signal circuit
26 	Boost pressure sensor (Turbocharger model)
31 	ECM
32 	EGR function
33 	Heated oxygen sensor circuit (Left side)
34	Knock sensor circuit
35 	EGR temperature sensor circuit
42	Fuel temperature sensor circuit
43 	Throttle position sensor circuit
45 	Injector leak
51 	Injector circuit
53 	Heated oxygen sensor circuit (Right side)
54	Signal circuit from A/T control unit to ECM (A/T only)
55	No malfunction in the above circuits

 : Malfunction indicator lamp item

TROUBLE DIAGNOSES

On-board Diagnostic System — Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)

Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
*11	Camshaft position sensor circuit	<ul style="list-style-type: none"> • Either 1° or 120° signal is not entered for the first few seconds during engine cranking. • Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace camshaft position sensor.)
12	Mass air flow sensor circuit	<ul style="list-style-type: none"> • The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
13	Engine coolant temperature sensor circuit	<ul style="list-style-type: none"> • The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> • The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (reed switch)
*21	Ignition signal circuit	<ul style="list-style-type: none"> • The ignition signal in the primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> • Harness and connector • Power transistor unit
26	Boost pressure sensor (Turbocharger model)	<ul style="list-style-type: none"> • The boost pressure sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Boost pressure leaks • Boost pressure sensor
31	ECM	<ul style="list-style-type: none"> • ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
32	EGR function	<ul style="list-style-type: none"> • EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> • EGR valve • EGRC-solenoid valve
33	Heated oxygen sensor circuit (Left side)	<ul style="list-style-type: none"> • The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Heated oxygen sensor • Fuel pressure • Injectors • Intake air leaks
53	Heated oxygen sensor circuit (Right side)		
34	Knock sensor circuit	<ul style="list-style-type: none"> • The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Knock sensor
35	EGR temperature sensor circuit	<ul style="list-style-type: none"> • The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • EGR temperature sensor
42	Fuel temperature sensor circuit	<ul style="list-style-type: none"> • The fuel temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Fuel temperature sensor
43	Throttle position sensor circuit	<ul style="list-style-type: none"> • The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor

*: Check items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

TROUBLE DIAGNOSES

On-board Diagnostic System — Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)

Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
45	Injector leak	<ul style="list-style-type: none">• Fuel leaks from injector.	<ul style="list-style-type: none">• Injector
51	Injector circuit	<ul style="list-style-type: none">• The injector circuit is open.	<ul style="list-style-type: none">• Harness and connector• Injector
54	Signal circuit from A/T control unit to ECM (A/T only)	<ul style="list-style-type: none">• The A/T communication line is open or shorted.	<ul style="list-style-type: none">• Harness and connector

HOW TO ERASE DIAGNOSTIC TEST MODE II (SELF-DIAGNOSTIC RESULTS)

The diagnostic trouble code is erased from the backup memory on the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- **When the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.**
- **Before starting on-board diagnostic system, do not erase the stored memory before beginning on-board diagnostic system.**

On-board Diagnostic System — Diagnostic Test Mode II (Heated oxygen sensor monitor)

DESCRIPTION

In this mode, the MALFUNCTION INDICATOR LAMP displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor.


MALFUNCTION INDICATOR LAMP	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

If two heated oxygen sensors (right side and left side) are fitted on the engine, the left side heated oxygen sensor monitor operates first, when selecting this mode.

HOW TO CHANGE MONITOR FROM LEFT SIDE (Right side) TO RIGHT SIDE (Left side)


1. Turn diagnostic test mode selector on ECM fully clockwise.
 2. Wait at least 2 seconds.
 3. Turn diagnostic test mode selector on ECM fully counterclockwise.
- These procedures should be carried out when the engine is running.



HOW TO CHECK HEATED OXYGEN SENSOR

1. Set Diagnostic Test Mode II. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure MALFUNCTION INDICATOR LAMP goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.



TROUBLE DIAGNOSES




Consult

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located in left dash side panel.)



3. Turn on ignition switch.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to the inspection sheet as follows:

For further information, see the CONSULT Operation Manual.

TROUBLE DIAGNOSES

Consult (Cont'd)

ECCS COMPONENT PARTS APPLICATION

ECCS COMPONENT PARTS		DIAGNOSTIC TEST MODE				
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
INPUT	Camshaft position sensor		X	X		
	Mass air flow sensor		X	X		
	Engine coolant temperature sensor		X	X	X	
	Heated oxygen sensors		X	X		X
	Vehicle speed sensor		X	X		X
	Throttle position sensor	X	X	X		X
	Boost pressure sensor		X			
	Fuel temperature sensor		X	X		
	EGR temperature sensor		X	X		
	Knock sensor		X			
	Ignition switch (start signal)			X		X
	Air conditioner switch			X		
	Neutral position switch			X		
	Power steering oil pressure switch			X		X
	Battery			X		
A/T signal		X				
OUTPUT	Injectors		X	X	X	X
	Power transistors (ignition timing)		X (Ignition signal)	X	X	X
	IACV-AAC valve	X		X	X	X
	IACV-FICD solenoid valve			X	X	X
	Valve timing control solenoid valve			X	X	X
	PRVR control solenoid valve			X	X	X
	EGRC-solenoid valve			X	X	X
	Wastegate valve control solenoid valve			X		
	Air conditioner relay			X		
	Fuel pump relay	X		X	X	X
Cooling fan			X	X	X	

X: Applicable

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Consult (Cont'd)

FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
ECM part number	ECM part number can be read.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> • IGN SW "ON" • ENG NOT RUNNING • ACC PEDAL NOT PRESSED 	When adjusting throttle position sensor initial position.
IGNITION TIMING ADJUSTMENT*	<ul style="list-style-type: none"> • IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.	When adjusting initial ignition timing.
IACV-AAC/V ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> • ENGINE WARMED UP • NO-LOAD 	When adjusting idle speed.
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> • FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line.

*: The ignition timing feedback control is not adopted on model 300ZX, so it is not necessary to perform IGNITION TIMING ADJUSTMENT.

TROUBLE DIAGNOSES

Consult (Cont'd)

SELF-DIAGNOSTIC RESULTS MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CAMSHAFT POSITION SEN*	<ul style="list-style-type: none"> • Either 1° or 120° signal is not entered for the first few seconds during engine cranking. • Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace camshaft position sensor.)
MASS AIR FLOW SEN	<ul style="list-style-type: none"> • The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
COOLANT TEMP SEN	<ul style="list-style-type: none"> • The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
VEHICLE SPEED SEN	<ul style="list-style-type: none"> • The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (reed switch)
IGN SIGNAL—PRIMARY*	<ul style="list-style-type: none"> • The ignition signal in primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> • Harness and connector • Power transistor unit
TURBO PRESS SENSOR	<ul style="list-style-type: none"> • The boost pressure sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Boost pressure sensor • Boost pressure leaks
ECM	<ul style="list-style-type: none"> • ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
EGR SYSTEM	<ul style="list-style-type: none"> • EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> • EGR valve • EGRC-solenoid valve
OXYGEN SEN OXYGEN SEN-R	<ul style="list-style-type: none"> • The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Heated oxygen sensor • Fuel pressure • Injectors • Intake air leaks
KNOCK SENSOR	<ul style="list-style-type: none"> • The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Knock sensor
EGR TEMP SENSOR	<ul style="list-style-type: none"> • The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • EGR temperature sensor
FUEL TEMP SENSOR	<ul style="list-style-type: none"> • The fuel temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Fuel temperature sensor
THROTTLE POSI SEN	<ul style="list-style-type: none"> • The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor
INJECTOR FUEL LEAK	<ul style="list-style-type: none"> • Fuel leaks from injector. 	<ul style="list-style-type: none"> • Injector
INJECTOR OPEN	<ul style="list-style-type: none"> • The injector circuit is open. 	<ul style="list-style-type: none"> • Injector
A/T COMM LINE	<ul style="list-style-type: none"> • The A/T communication line is open or shorted. 	<ul style="list-style-type: none"> • Harness and connector

*: Check items causing a malfunction of camshaft position sensor circuit first, if both "CAMSHAFT POSITION SENSOR" and "IGN SIGNAL—PRIMARY" are displayed at the same time.

TROUBLE DIAGNOSES

Consult (Cont'd)

DATA MONITOR MODE

Remarks: • Specification data are reference values.

• Specification data are out-put/in-put values which are detected or supplied by ECM at the connector.

*: Specification data may not be directly related to their components signals/values/operations.

ie. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing being not adjusted to the specification data. This IGN TIMING monitors the calculated data by ECM according to the input signals from camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CMPS●RPM (POS)	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.	<ul style="list-style-type: none"> Harness and connector Camshaft position sensor
CMPS●RPM (REF)				
MAS AIR/FL SE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine A/C switch "OFF" Shift lever "N" No-load 	Idle	0.8 - 1.5V	<ul style="list-style-type: none"> Harness and connector Mass air flow sensor
		2,000 rpm	1.4 - 1.8V	
COOLAN TEMP/S	<ul style="list-style-type: none"> Engine: After warming up 		More than 70°C (158°F)	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor
O2 SEN	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V	<ul style="list-style-type: none"> Harness and connector Heated oxygen sensor Intake air leaks Injectors
O2 SEN-R			LEAN ↔ RICH	
M/R F/C MNT			Changes more than 5 times during 10 seconds.	
M/R F/C MNT-R				
VHCL SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value	<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor
BATTERY VOLT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 		11 - 14V	<ul style="list-style-type: none"> Battery ECM power supply circuit
THRTL POS SEN	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Throttle valve fully closed	0.4 - 0.5V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment
		Throttle valve fully opened	Approx. 4.0V	
FUEL TEMP SEN	<ul style="list-style-type: none"> Engine: After warming up 		20 - 60°C (68 - 140°F)	<ul style="list-style-type: none"> Harness and connector Fuel temp. sensor
EGR TEMP SEN	<ul style="list-style-type: none"> Engine: After warming up 		Less than 4.5V	<ul style="list-style-type: none"> Harness and connector EGR temperature sensor
START SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON → START 		OFF → ON	<ul style="list-style-type: none"> Harness and connector Start switch
CLOSED TH/POS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	A/C switch "OFF"	OFF	<ul style="list-style-type: none"> Harness and connector Air conditioner switch
		A/C switch "ON"	ON	
NEUT POSI SW	<ul style="list-style-type: none"> Ignition switch: ON 	Shift lever "P" or "N"	ON	<ul style="list-style-type: none"> Harness and connector Neutral position switch
		Except above	OFF	
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF	<ul style="list-style-type: none"> Harness and connector Power steering oil pressure switch
		The steering wheel is turned	ON	
INJ PULSE	<ul style="list-style-type: none"> Engine: After warming up A/C switch "OFF" Shift lever "N" No-load 	Idle	2.0 - 3.0 msec.	<ul style="list-style-type: none"> Harness and connector Injector Mass air flow sensor Intake air system
INJ PULSE-R		2,000 rpm	2.0 - 3.0 msec.	

TROUBLE DIAGNOSES

Consult (Cont'd)

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
IGN TIMING	ditto	Idle	15° BTDC	<ul style="list-style-type: none"> • Harness and connector • Camshaft position sensor
		2,000 rpm	More than 25° BTDC	
IACV-AAC/V	ditto	Idle	15 - 40%	<ul style="list-style-type: none"> • Harness and connector • IACV-AAC valve
		2,000 rpm	—	

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL INJECTION TEST	<ul style="list-style-type: none"> • Engine: Return to the original trouble condition • Change the amount of fuel injection with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> • Harness and connector • Fuel injectors • Heated oxygen sensor
IACV-AAC/V OPENING TEST	<ul style="list-style-type: none"> • Engine: After warming up, idle the engine. • Change the IACV-AAC valve opening percent with the CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> • Harness and connector • IACV-AAC valve
ENG COOLANT TEMP TEST	<ul style="list-style-type: none"> • Engine: Return to the original trouble condition • Change the engine coolant temperature with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor • Fuel injectors
IGN TIMING TEST	<ul style="list-style-type: none"> • Engine: Return to the original trouble condition • Timing light: Set • Retard the ignition timing with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> • Adjust initial ignition timing
POWER BALANCE TEST	<ul style="list-style-type: none"> • Engine: After warming up, idle the engine. • A/C switch "OFF" • Shift lever "N" • Cut off each injector signal one at a time with the CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> • Harness and connector • Compression • Injectors • Power transistor • Spark plugs • Ignition coils
COOLING FAN TEST	<ul style="list-style-type: none"> • Ignition switch: ON • Turn the cooling fan "ON" and "OFF" with the CONSULT. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> • Harness and connector • Cooling fan motor
FICD SOLV TEST	<ul style="list-style-type: none"> • Engine: After warming up, idle the engine. • A/C switch "OFF" • Shift lever "N" • Turn the IACV-FICD solenoid valve "ON" with the CONSULT. 	Engine speed will increase momentarily by approx. 200 rpm.	<ul style="list-style-type: none"> • Harness and connector • IACV-FICD solenoid valve
FUEL PUMP RLY TEST	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) • Turn the fuel pump relay "ON" and "OFF" with the CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> • Harness and connector • Fuel pump relay
EGRC SOLENOID VALVE TEST	<ul style="list-style-type: none"> • Ignition switch: ON • Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound. 	Each solenoid valve makes an operating sound.	<ul style="list-style-type: none"> • Harness and connector • Solenoid valve
PRVR CONT SOLV TEST			
VALVE TIM SOL TEST			
SELF-LEARN CONT TEST	<ul style="list-style-type: none"> • In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		

TROUBLE DIAGNOSES

Consult (Cont'd)






FUNCTION TEST MODE

TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
SELF-DIAG RESULTS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Displays the results of on-board diagnostic system. 	—		Objective system
CLOSED THROTTLE POSI (CLOSED THROTTLE POSITION SWITCH CIRCUIT)	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Closed throttle position switch circuit is tested when throttle is opened and closed fully. ("CLOSED THROTTLE POSI" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> Harness and connector Throttle position sensor (Closed throttle position switch) Throttle position sensor (Closed throttle position switch) adjustment Throttle linkage Verify operation in DATA MONITOR mode.
		Throttle valve: closed	ON	
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode.
NEUTRAL POSI SW CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Neutral position switch circuit is tested when shift lever is manipulated. 	OUT OF N/P-RANGE	OFF	<ul style="list-style-type: none"> Harness and connector Neutral position switch/Inhibitor switch Linkage + Inhibitor switch adjustment
		IN N-RANGE	ON	
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) EGR control S/V circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector EGRC-solenoid valve
PRVR CONT S/V CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) PRVR CONT S/V circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector PRVR control solenoid valve
VALVE TIMING S/V CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Valve timing S/V circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector Valve timing solenoid valve
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Cooling fan circuit is tested by checking cooling fan operation. 	The cooling fan rotates and stops every 3 seconds.		<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay

TROUBLE DIAGNOSES

Consult (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON → START Start signal circuit is tested when engine is started by operating the starter. Battery voltage and water temperature before cranking, and average battery voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed. 	Start signal: OFF → ON		<ul style="list-style-type: none"> Harness and connector Ignition switch 	GI MA EM
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine running) Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> Harness and connector Power steering oil pressure switch Power steering oil pump 	LC
		Neutral position	OFF		EF & EC
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor Electric speedometer 	FE
IGN TIMING ADJ	<ul style="list-style-type: none"> After warming up, idle the engine. Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> Adjust ignition timing (by moving camshaft position sensor or distributor) Camshaft position sensor drive mechanism 	CL MT
MIXTURE RATIO TEST	<ul style="list-style-type: none"> Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the O₂ sensor output at 2,000 rpm under non-loaded state. 	<ul style="list-style-type: none"> O₂ SEN COUNT: More than 5 times during 10 seconds (O₂ SEN-R COUNT: More than 5 times during 10 seconds) 		<ul style="list-style-type: none"> INJECTION SYS (Injector, fuel pressure regulator, harness or connector) IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) VACUUM SYS (Intake air leaks) O₂ sensor circuit O₂ sensor operation Fuel pressure high or low Mass air flow sensor 	AT PD FA
POWER BALANCE	<ul style="list-style-type: none"> After warming up, idle the engine. Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multiport fuel injection system is used.) 	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.		<ul style="list-style-type: none"> Injector circuit (Injector, harness or connector) Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) Compression Valve timing 	RA BR ST
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> After warming up, idle the engine. IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% (102 steps) and at 20% (25 steps).		<ul style="list-style-type: none"> Harness and connector IACV-AAC valve Air passage restriction between air inlet and IACV-AAC valve IAS (Idle adjusting screw) adjustment 	RS BT HA
IACV-FICD S/V SYSTEM	<ul style="list-style-type: none"> After warming up, idle the engine. A/C switch: OFF Light switch: OFF FICD system is tested by detecting change in engine speed when IACV-FICD solenoid valve is ON and OFF. 	Difference in engine speed is greater than 50 rpm between IACV-FICD solenoid valve "ON" and "OFF".		<ul style="list-style-type: none"> Harness and connector IACV-FICD solenoid valve Air passage 	EL IDX



Diagnostic Procedure

CAUTION:

1. Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM. Because battery voltage is applied to ECM even if ignition switch is turned off.

2. When connecting ECM harness connector, tighten securing bolt until red projection is in line with connector face.

3. When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.


5. Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. (See page EF & EC-176.)

6. After performing this "Diagnostic Procedure", perform diagnostic test mode II (Self-diagnostic results) and driving test.

TROUBLE DIAGNOSES

Diagnostic Procedure (Cont'd)

7. When measuring ECM signals with a circuit tester, never bring the two tester probes into contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



GI

MA

EM

LG

**EF &
EC**

FE

CL

MT

AT

PD

FA

RA

BR

ST





RS

BT

HA

EL

IDX



Basic Inspection

1

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for proper connections
 - Vacuum hoses for splits, kinks, and proper connections
 - Wiring for proper connections, pinches, and cuts

2

CONNECT CONSULT TO THE VEHICLE
 Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. (Refer to page EF & EC-54.)

3

DOES ENGINE START?

No → Go to **6**

4

CHECK IGNITION TIMING.
 Warm up engine sufficiently and check ignition timing at idle using timing light. (Refer to page EF & EC-35.)
Ignition timing: 15°±2° BTDC
(in "N" position for AT model)

NG → Adjust ignition timing by turning camshaft position sensor.

OK
 (Go to **A** on next page.)

TROUBLE DIAGNOSES


Basic Inspection (Cont'd)

5 ■ IGN TIMING ADJ ■ □

IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.

START

SEF555N



6 ■ THRTL POS SEN ADJ ■ □

*** ADJ MONITOR ***


THRTL POS SEN 0.46V

===== MONITOR =====

CKPS•RPM (POS) 950rpm

CLOSED TH/POS ON

MEF567G



5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine speed fall to;

Non-turbocharger
M/T: 650±50 rpm
A/T: 720±50 rpm
[in "N" position]?

Turbocharger
M/T: 650±50 rpm (U.S.A.)
700±50 rpm (Canada)
A/T: 700±50 rpm
[in "N" position]?

OR

When disconnecting throttle position sensor harness connector, does engine speed fall to:

Non-turbocharger
M/T: 650±50 rpm
A/T: 720±50 rpm
[in "N" position]?

Turbocharger
M/T: 650±50 rpm (U.S.A.)
700±50 rpm (Canada)
A/T: 700±50 rpm
[in "N" position]?

No → Adjust engine speed by turning idle adjusting screw.

6

CHECK THROTTLE POSITION SENSOR IDLE POSITION.

1. Perform "THRTL POS SEN. ADJ." in "WORK SUPPORT" mode.

2. Check that output voltage of throttle position sensor is 0.4 to 0.5V. (Throttle valve fully closes.) and "CLOSED TH/POS" stays "ON".

OR

Measure output voltage of throttle position sensor using voltmeter, and check that it is 0.4 to 0.5V. (Throttle valve fully closed.)

NG → 1. Adjust output voltage by rotating throttle position sensor body.
2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "CLOSED TH/POS" stays "ON".

OK

(Go to ⑧ on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)

7


☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON


RECORD

SEF248M


7




A/C



ST





N

SEF150I

8

■ SELF-DIAG RESULTS ■


FAILURE DETECTED TIME

ENGINE TEMP SENSOR 0

ERASE
PRINT

SEF151I

8



CHECK

SEF051P

⑧

7

CHECK SWITCH INPUT SIGNAL.

Select the following switches in "DATA MONITOR" mode,

- Start signal,
- Idle position,
- Air conditioner signal,
- Neutral position (Parking) switch,

and check the switches' ON-OFF operation.

OR

Remove ECM from front floor panel and check the above switches' ON-OFF operation using voltmeter at each ECM terminal.

Switch	Condition	Voltage (V)
Start signal	IGN ON →	0 → Battery
	IGN START	voltage
Idle position	—	—
A/C signal	A/C OFF →	Battery voltage
	A/C ON (Engine running)	
Park/Neutral position switch	Shift lever is "N" or "P" position → Except "N" and "P"	0 → 8.0 - 9.0

NG → Repair or replace the malfunctioning switch or its circuit.

OK

8

READ SELF-DIAGNOSTIC RESULTS.

- Perform "SELF-DIAG RESULTS" mode.
- Read out self-diagnostic results.
- Is a failure detected?

OR

- Set "Self-diagnostic results mode" in Diagnostic Test Mode II. (Refer to page EF & EC-50.)
- Count the number of malfunction indicator lamp flashes and read out the diagnostic trouble codes.
- Are the diagnostic trouble codes being output?


Yes → Go to the relevant inspection procedure.

No → INSPECTION END

TROUBLE DIAGNOSES

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Diagnostic Procedure 1 — High Idling after Warm-up



1

CHECK IACV-AIR REGULATOR.
When pinching the IACV-air regulator hose, does the engine speed drop?

Yes → Check IACV-air regulator and circuit.



2


CHECK INTAKE AIR LEAK.

1. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.

2. Clear the self-learning control coefficient by touching "CLEAR".

3. Does the engine speed drop?

Yes → Discover air leak location and repair.



OR

1. Disconnect heated oxygen sensor harness connectors.

2. After racing engine at 1,500 rpm under no load for about 30 seconds, does the engine speed drop?


3

CHECK THROTTLE LINKAGE.

1. Check that throttle linkage moves smoothly.

2. Confirm that throttle valve both fully opens and fully closes.


NG → Repair throttle linkage or sticking of throttle valve.



OK → INSPECTION END


TROUBLE DIAGNOSES

Diagnostic Procedure 2 — Hunting



1
CHECK HEATED OXYGEN SENSORS.
 When disconnecting heated oxygen sensor harness connectors, is the hunting fixed?

Yes → Check heated oxygen sensor(s). (See page EF & EC-129.)




2
PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
 2. Is there any cylinder which does not produce a momentary engine speed drop?

OR


When disconnecting each ignition coil harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**.



3
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.




NG → Repair or replace spark plug(s).



OK
 (Go to **A** on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 2 — Hunting (Cont'd)



GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Diagnostic Procedure 3 — Unstable Idle




1

CHECK EGR VALVE.
Check EGR valve for sticking.

NG → Repair or replace.

OK ↓



2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.


2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 6.

OR

⊗ When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes ↓



3

CHECK INJECTOR.


1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)

2. Turn ignition switch ON. (Do not start engine.)

3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes ↓



4

CHECK IGNITION SPARK.

1. Disconnect ignition coil assembly from collector.


2. Connect a known good spark plug to the ignition coil assembly.

3. Place end of spark plug against a suitable ground and crank engine.

4. Check for spark.

NG → Check ignition coil, power transistor unit and their circuits. (See page EF & EC-119.)


OK ↓



(Go to A on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 3 — Unstable Idle (Cont'd)



5

CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).



6

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.
2. Install fuel pressure gauge and check fuel pressure.
At idle approx. 255 kPa (2.6 kg/cm², 37 psi)

OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)
2. Install fuel pressure gauge and check fuel pressure.

NG → Check fuel pump and circuit.

OK

(Go to Ⓑ on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES




Diagnostic Procedure 3 — Unstable Idle (Cont'd)

7

■ ACTIVE TEST ■		<input type="checkbox"/>
IACV-FICD SOL/V OFF		
=== MONITOR ===		
CMPS-RPM (POS)	762rpm	
COOLAN TEMP/S	177°F	
CLOSED TH/POS	ON	
AIR COND SIG	OFF	
IACV-AAC/V	18%	




ON ON/OFF OFF

SEF644N



TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle (Cont'd)



9

CHECK IDLE ADJ. SCREW CLOGGING.

- Perform "IGN TIMING ADJ" in "WORK SUPPORT" mode.
- Can you set engine speed as follows by turning idle adjusting screw?
 - Non-turbocharger
 - M/T: 650±50 rpm
 - A/T: 720±50 rpm [in "N" position]
 - Turbocharger
 - M/T: 650±50 rpm (U.S.A.)
 - 700±50 rpm (Canada)
 - A/T: 700±50 rpm [in "N" position]

OR

- Disconnect throttle position sensor harness connector.
- Can you set engine speed as follows by turning idle speed adjusting screw?
 - Non-turbocharger
 - M/T: 650±50 rpm
 - A/T: 720±50 rpm [in "N" position]
 - Turbocharger
 - M/T: 650±50 rpm (U.S.A.)
 - 700±50 rpm (Canada)
 - A/T: 700±50 rpm [in "N" position]

No → Check for IAS clogging or throttle valve clogging.

10

CHECK COMPRESSION PRESSURE.

- Check compression pressure.
 - Standard: kPa (kg/cm², psi)/300 rpm
1,285 (13.1, 186)
 - Minimum: kPa (kg/cm², psi)/300 rpm
981 (10.0, 142)
 - Difference between each cylinder:
kPa (kg/cm², psi)/300 rpm
98 (1.0, 14)

NG → Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

CHECK ECM HARNESS CONNECTOR.
Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

Reconnect ECM harness connector and retest.

Trouble is not fixed.







TRY A KNOWN GOOD ECM*.

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.



CI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold



TROUBLE DIAGNOSES

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot




1

CHECK FUEL PRESSURE.
 1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?


No

Check fuel pump and circuit. (See page EF & EC-153.)

Yes




2

CHECK FUEL VAPOR.
 1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode.
 2. After touching "ON", can you start the engine?


Yes

Check fuel properties.

OR

 1. Disconnect fuel pressure regulator vacuum hose and plug hose.
 2. Can you start engine?

No




3

CHECK INJECTOR.
 1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
 2. Turn ignition switch ON. (Do not start engine.)
 3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No

Check injector(s) and circuit(s).

Yes



4


CHECK IGNITION SPARK.
 1. Disconnect ignition coil assembly from collector.
 2. Connect a known good spark plug to the ignition coil assembly.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

NG

Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)


OK

(Go to Ⓐ on next page.)



TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

**EF &
EC**

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions



1
CHECK BATTERY AND STARTER.
 Check battery and starter operation.
 (Refer to EL section.)

NG → Repair or replace.


OK



2
CHECK FUEL PRESSURE.
 1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. (See page EF & EC-153.)


Yes



3
CHECK INJECTOR FOR LEAKAGE.
 When pressing accelerator pedal fully, can you start the engine?

Yes → Check injector(s) for leakage.


No



4
CHECK INJECTOR.
 1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
 2. Turn ignition switch ON. (Do not start engine.)
 3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injectors and circuits.

Yes



5
CHECK IGNITION SPARK.
 1. Disconnect ignition coil assembly from collector.
 2. Connect a known good spark plug to the ignition coil assembly.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.




NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)

OK

(Go to Ⓐ on next page.)


TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)




*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Diagnostic Procedure 7 — Hesitation when the Engine is Hot



- 1**
- CHECK FUEL VAPOR.**
1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode.
 2. After touching "ON", perform cruise test.
 3. Does the hesitation disappear?
- OR
1. Disconnect fuel pressure regulator vacuum hose and plug hose.
 2. Perform cruise test.
 3. Does the hesitation disappear?


Yes → Check fuel properties.



- 2**
- CHECK CANISTER PURGE.**
1. Disconnect canister purge line hose and plug hose.
 2. Perform cruise test.
 3. Does the hesitation disappear?

Yes → Check purge and vacuum lines.

No → INSPECTION END



Diagnostic Procedure 8 — Hesitation when the Engine is Cold



- 1**
- CHECK SPARK PLUGS.**
Remove spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).


OK → (A)

TROUBLE DIAGNOSES




Diagnostic Procedure 8 — Hesitation when the Engine is Cold (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






Diagnostic Procedure 9 — Hesitation under Normal Conditions




TROUBLE DIAGNOSES

Diagnostic Procedure 9 — Hesitation under Normal Conditions (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 10 — Engine Stalls when Turning




1
CHECK FUEL LEVEL.
Check to see that there is enough fuel in tank.

NG → Fill fuel tank with fuel.




2
PERFORM POWER BALANCE TEST.
1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?
OR
When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.




3
CHECK INJECTOR.
1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Turn ignition switch ON. (Do not start engine.)
3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).



4
CHECK IGNITION SPARK.
1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)



OK
↓
(Go to Ⓐ on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)

5


■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE.
CRANK A FEW TIMES AFTER ENGINE STALL.

START








SEF204J



*: ECM may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot



1

CHECK FUEL VAPOR.

1. Select "PRVR CONT SOL VALVE" in "ACTIVE TEST" mode.

2. After touching "ON", perform cruise test.

3. Does the engine stall disappear?

OR

1. Disconnect fuel pressure regulator vacuum hose and plug hose.

2. Perform cruise test.

3. Does the engine stall disappear?

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

3

CHECK INJECTOR.

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)

2. Turn ignition switch ON. (Do not start engine.)

3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

(Go to ④ on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)




4

CHECK IGNITION SPARK.

1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and their circuits. (See page EF & EC-119.)



5

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.
2. Install fuel pressure gauge and check fuel pressure.
At idle approx. 255 kPa (2.6 kg/cm², 37 psi)
The moment throttle valve is fully open: approx. 304 kPa (3.1 kg/cm², 44 psi)

OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)
2. Install fuel pressure gauge and check fuel pressure.

NG → Check fuel pressure regulator diaphragm.

CHECK ECM HARNESS CONNECTOR.
 Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

Reconnect ECM harness connector and retest.

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.
 Refer to page EF & EC-106.

NG → Repair or replace.

TRY A KNOWN GOOD ECM*.






CHECK TIMING BELT FOR PROPER INSTALLATION.

NG → Replace timing belt.

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold



1

CHECK IACV-AIR REGULATOR AND IACV-AAC VALVE.
When the engine is cold, can you start the engine when pressing accelerator pedal fully?

NG → Check IACV-AAC valve, IACV-air regulator and circuits. (See pages EF & EC-156 - 159.)

OK ↓

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

NG → Go to **6**.

OK ↓

3

CHECK INJECTOR.

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)

2. Turn ignition switch ON. (Do not start engine.)

3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

NG → Check injector(s) and circuit(s).

OK ↓

4

CHECK IGNITION SPARK.

1. Disconnect ignition coil assembly from collector.

2. Connect a known good spark plug to the ignition coil assembly.

3. Place end of spark plug against a suitable ground and crank engine.

4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)


OK ↓

(Go to **A** on next page.)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)




5

CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).

OK →



6

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.

2. Install fuel pressure gauge and check fuel pressure.
At idle approx. 255 kPa (2.6 kg/cm², 37 psi)
The moment throttle valve is fully open: approx. 304 kPa (3.1 kg/cm², 44 psi)

OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)

2. Install fuel pressure gauge and check fuel pressure.

NG → Check fuel pressure regulator diaphragm.

OK →

CHECK ECM HARNESS CONNECTOR.
Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

OK →

Reconnect ECM harness connector and retest.

Trouble is not fixed.

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.
Refer to page EF & EC-106.

NG → Repair or replace.

OK →

TRY A KNOWN GOOD ECM*.

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST






RS

BT

HA

EL

IDX



1

CHECK OVERALL FUNCTION.

- Start engine and warm it up sufficiently.
- Check idle speed.

Non-turbocharger

MT: 700±50 rpm

AT: 770±50 rpm

[in "N" position]

Turbocharger

MT: 700±50 rpm (U.S.A.)

750±50 rpm (Canada)

AT: 750±50 rpm

[in "N" position]

3. Perform "IACV-AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.

No → Check IACV-AAC valve and circuit. (See page EF & EC-159.)

OR

1. Select "IACV-AAC/V OPENING" in "ACTIVE TEST" mode.

2. When touching "Qu" and "Qd", does the engine speed change according to the percent of IACV-AAC valve opening?

OR

When disconnecting IACV-AAC valve harness connector, does the engine speed drop?

Yes

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?





No → Go to **5**.

Yes

(Go to **A** on next page.)


TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

**EF &
EC**

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Diagnostic Procedure 14 — Engine Stalls after Decelerating

1 ■ IACV-AAC/V SYSTEM ■

LET ENGINE IDLE
THEN
TOUCH START
(A/C SW·LIGHT SW OFF)

NEXT
START

SEF474M

1 ■ ACTIVE TEST ■

IACV-AAC/V OPENING 50%



== == MONITOR == ==

CMPS·RPM(POS)	850rpm
MAS AIR/FL SE	1.24V
COOLAN TEMP/S	179°F

Qu
Up
DWN
Qd

SEF649N

1

SEF146I

1

CHECK OVERALL FUNCTION.

1. Start engine and warm it up sufficiently.
2. Check idle speed.
 - Non-turbocharger**
 - MT: 700±50 rpm
 - AT: 770±50 rpm
 - [in "N" position]
 - Turbocharger**
 - MT: 700±50 rpm (U.S.A.)
 - 750±50 rpm (Canada)
 - AT: 750±50 rpm
 - [in "N" position]
3. Perform "IACV-AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.

OR

1. Select "IACV-AAC/V OPENING" in "ACTIVE TEST" mode.
2. When touching "Qu" and "Qd", does the engine speed change according to the percent of IACV-AAC valve opening?

OR



- When disconnecting IACV-AAC valve harness connector, does the engine speed drop?

No → Check IACV-AAC valve and circuit. (See page EF & EC-159.)

Yes
↓
(Go to Ⓐ on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



2

CHECK IDLE ADJ. SCREW CLOGGING.



1. Perform "IGN TIMING ADJ" in "WORK SUPPORT" mode.
2. Can you set engine speed as follows by turning idle adjusting screw?

Non-turbocharger

M/T: 650±50 rpm

A/T: 720±50 rpm

[in "N" position]

Turbocharger

M/T: 650±50 rpm (U.S.A.)

700±50 rpm (Canada)

A/T: 700±50 rpm

[in "N" position]

OR



1. Disconnect throttle position sensor harness connector.
2. Can you set engine speed as follows by turning idle speed adjusting screw?

Non-turbocharger

M/T: 650±50 rpm

A/T: 720±50 rpm

[in "N" position]

Turbocharger

M/T: 650±50 rpm (U.S.A.)

700±50 rpm (Canada)

A/T: 700±50 rpm

[in "N" position]

No

Check for IAS clogging or throttle body clogging.

Yes

(Go to ⑧ on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT






HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)

6

■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE.
CRANK A FEW TIMES AFTER ENGINE STALL.

START



SEF204J

6

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.

2. Install fuel pressure gauge and check fuel pressure.

At idle approx. 255 kPa (2.6 kg/cm², 37 psi)
The moment throttle valve is fully open: approx. 304 kPa (3.1 kg/cm², 44 psi)

OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)

2. Install fuel pressure gauge and check fuel pressure.

NG → Check fuel pressure regulator diaphragm.

OK →

7

☆ MONITOR ☆ NO FAIL

CMPS•RPM (POS) 2087rpm
M/R F/C MNT LEAN
M/R F/C MNT-R RICH

RECORD

SEF652N

7

CHECK HEATED OXYGEN SENSOR.

1. See "M/R F/C MNT (right and left sides)" in "DATA MONITOR" mode.

2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently.), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

OR


1. Set "Heated oxygen sensor monitor" in Diagnostic Test Mode II. (See page EF & EC-53.)

2. Maintaining engine at 2,000 rpm under no load, check that malfunction indicator lamp goes ON and OFF more than 5 times during 10 seconds.

NG → Replace heated oxygen sensor(s).

OK →

7



SEF051P

OK

(Go to ① on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL





IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising

1

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No

Go to **4**.

OR



When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

2

CHECK INJECTOR.

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)
2. Turn ignition switch ON. (Do not start engine.)
3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No

Check injector(s) and circuit(s).

Yes

3

CHECK IGNITION SPARK.

1. Disconnect ignition coil assembly from collector.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG

Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)

OK

(Go to **A** on next page.)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 15 — Engine Stalls when Accelerating or Cruising (Cont'd)

4

■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE.
CRANK A FEW TIMES AFTER ENGINE STALL.

START



SEF204J

4

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.

2. Install fuel pressure gauge and check fuel pressure.

At idle approx. 255 kPa (2.6 kg/cm², 37 psi)

The moment throttle valve is fully open: approx. 304 kPa (3.1 kg/cm², 44 psi)


OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)

2. Install fuel pressure gauge and check fuel pressure.

NG → Check fuel pump, circuit and fuel pressure regulator.

OK →



5

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes → Discover air leak location and repair.

No →

CHECK ECM HARNESS CONNECTOR.

Check the ECM pin terminals for damage or poor connection of ECM harness connector.

NG → Repair or replace.

OK →

Reconnect ECM harness connector and retest.

Trouble is not fixed. →

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Refer to page EF & EC-106.

Yes → Repair or replace.

No →






TRY A KNOWN GOOD ECM*.

INSPECTION END

*: ECM may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



1

CHECK BATTERY AND ALTERNATOR.
Check battery and alternator condition.
(Refer to "BATTERY" and "CHARGING SYSTEM" in EL section.)

NG → Repair or replace.

OK ↓

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.

Yes ↓

3

CHECK INJECTOR.

1. Remove camshaft position sensor from engine. (Harness connector should remain connected.)

2. Turn ignition switch ON. (Do not start engine.)

3. When rotating camshaft position sensor shaft, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes ↓

4

CHECK IGNITION SPARK.

1. Disconnect ignition coil assembly from collector.

2. Connect a known good spark plug to the ignition coil assembly.

3. Place end of spark plug against a suitable ground and crank engine.

4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. (See page EF & EC-119.)

OK ↓

(Go to Ⓐ on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)

5


■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE.
CRANK A FEW TIMES AFTER ENGINE STALL.

START



SEF204J



*: ECM may be the cause of a problem, but this is rarely the case.

CI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 17 — Lack of Power and Stumble

1

■ FUEL PRES RELEASE ■

FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE.
CRANK A FEW TIMES AFTER ENGINE STALL.

START

SEF204J

1

CHECK FUEL PRESSURE.

1. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode in order to release fuel pressure to zero.

2. Install fuel pressure gauge and check fuel pressure.

At idle approx. 255 kPa (2.6 kg/cm², 37 psi)

The moment throttle valve is fully open: approx. 304 kPa (3.1 kg/cm², 44 psi)

OR

1. Release fuel pressure to zero. (Refer to page EF & EC-189.)

2. Install fuel pressure gauge and check fuel pressure.

NG →

Check fuel pressure regulator diaphragm.

OK ↓

2

SEF664N

2

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes →

Discover air leak location and repair.

No ↓

CHECK TIMING BELT FOR PROPER INSTALLATION.





NG →

Replace timing belt.

OK ↓

INSPECTION END

Diagnostic Procedure 18 — Knock



1

CHECK FOR INTAKE AIR LEAK.
When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes → Discover air leak location and repair.

No ↓

2

CHECK EGR OPERATION.
1. Apply vacuum directly to the EGR valve using a handy vacuum pump.
2. Check to see that the engine runs rough or dies.

No → Check EGR valve for sticking.

Yes ↓

3

CHECK EGRC-SOLENOID VALVE.

1. Select "EGRC. SOL/V" in "ACTIVE TEST" mode.
2. Turn EGRC-solenoid valve ON and OFF.
3. Check operating sound.

OR

1. Disconnect EGRC-solenoid valve harness connector.
2. Supply EGRC-solenoid valve terminals with battery current and check operating sound.

NG → Check solenoid valve and circuit.

OK ↓

4

CHECK VACUUM HOSES.
Check the following vacuum hoses for clogging, cracks and poor connection.
a) Vacuum hose between EGR valve and EGRC-solenoid valve.
b) Vacuum hose between EGRC-solenoid valve and throttle body port.
c) Vacuum hose between EGRC-solenoid valve and air duct.



NG → Repair or replace.

OK ↓

(Go to Ⓐ on next page.)






TROUBLE DIAGNOSES

Diagnostic Procedure 18 — Knock (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 19 — Surge




TROUBLE DIAGNOSES



Diagnostic Procedure 19 — Surge (Cont'd)




*: ECM may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 20 — Backfire through the Intake



Diagnostic Procedure 21 — Backfire through the Exhaust




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 22 (Cont'd)



INSPECTION START

CHECK POWER SUPPLY.

- 1) Turn ignition switch "ON".
- A** 2) Check voltage between ECM pin terminal 16 and ground.
Voltage: Approximately 0.8 - 1.0V
- B** 3) Check voltage between ECM pin terminals 109, 49, 59 and ground.
Voltage: Battery voltage

C

Check the following items.

- 1) ECCS relay
Refer to "Electrical Components Inspection". (See page EF & EC-187.)
- 2) "G" fusible link
- 3) Harness continuity between ECCS relay and battery ⊕ terminal
Continuity should exist.
- 4) Harness continuity between ECCS relay and ECM pin terminal 16
Continuity should exist.

OK

D

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM pin terminals 10, 20, 50, 60, 107, 108, 116 and ground.
Continuity should exist.

NG

- 1) Check if engine ground terminal connectors (F28, F11 and F39) make contact with engine body properly.
- 2) Repair harness or connectors.

OK

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 23

CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)









Harness layout



TROUBLE DIAGNOSES



Diagnostic Procedure 23 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 23 (Cont'd)






Diagnostic Procedure 24

MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12)  (MALFUNCTION INDICATOR LAMP ITEM)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX









Harness layout





TROUBLE DIAGNOSES

Diagnostic Procedure 24 (Cont'd)



TROUBLE DIAGNOSES


Diagnostic Procedure 24 (Cont'd)





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 25

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13) (MALFUNCTION INDICATOR LAMP ITEM)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)



INSPECTION START

A

CHECK INPUT SIGNAL.

- 1) Start engine.
- 2) Read "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT.

Engine coolant temperature should gradually rise and reach more than 70°C (158°F) after engine warm-up.

OR

- 2) Make sure that voltage between ECM terminal ② and ground changes during engine warm-up.

Cold → Hot:
Approximately 5 - 0V

B

CHECK HARNESS CONTINUITY BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM.

- 1) Stop engine.
- 2) Disconnect engine coolant temperature sensor harness connector.
- 3) Disconnect ECM harness connector.
- 4) Check harness continuity between ECM terminal ② and terminal ①. **Continuity should exist.** If NG, repair harness or connectors.

CHECK COMPONENT (Engine coolant temperature sensor). Refer to "Electrical Components Inspection". (See page EF & EC-181.)

C

CHECK GROUND CIRCUIT.

- 1) Stop engine.
- 2) Disconnect engine coolant temperature sensor harness connector.
- 3) Disconnect ECM harness connector.
- 4) Check harness continuity between ECM terminal ③ and terminal ①. **Continuity should exist.**

Repair harness or connectors.

Reinstall any part removed.

- 1) Erase the diagnostic test mode II (Self-diagnostic results) memory. (Refer to EF & EC-52.)
- 2) Perform test drive and then perform diagnostic test mode II (Self-diagnostic results) again. (Refer to EF & EC-50.)

- 1) Perform ECM input/output signal inspection test.
- 2) If NG, recheck the ECM pin terminals for damage. Check the connection at the ECM harness connector.


INSPECTION END

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 26

VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14) (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)

A

■ VEHICLE SPEED SEN CKT ■

AFTER TOUCH START.
DRIVE VEHICLE
AT 10km/h (6mph) OR
MORE WITHIN 15sec.

NEXT START

SEF479M

A

☆ MONITOR ☆ NO FAIL

VHCL SPEED SE 0mph

RECORD

SEF480M

A

ECM CONNECTOR

53

Ω

DISCONNECT

DISCONNECT

OFF

MEF674C

B

ECM CONNECTOR

53

Ω


DISCONNECT

DISCONNECT

OFF

a b c d e f
g h i j k l


MEF677F




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)




- ①
- 1) Start engine and warm it up sufficiently.
 - 2) Shift to a suitable gear position and maintain the following test drive conditions for at least 5 seconds.
Drive conditions
 - (1) Engine speed:
Non-turbocharger model
2,200±200 rpm
Turbocharger model
2,050±250 rpm
 - (2) Intake manifold vacuum:
Non-turbocharger model
-28.0±5.3 kPa (-210±40 mmHg,
-8.27±1.57 inHg)
Turbocharger model
-39.3±6.0 kPa (-295±45 mmHg,
-11.61±1.77 inHg)
 - (3) Vehicle speed
5 km/h (3 MPH) or more






TROUBLE DIAGNOSES

Diagnostic Procedure 27

IGNITION SIGNAL (Diagnostic trouble code No. 21)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.


- 1) Turn ignition switch "ON".
- 2) Check voltage between terminal ② and ground.

Voltage:
Approx. Battery voltage


B

Check the following items.

- 1) Ignition coil relay
Refer to "Electrical Components Inspection".
(See page EF & EC-187.)
- 2) "G" fusible link
- 3) Harness continuity between ignition coil relay and ignition coils.
Continuity should exist.
- 4) Harness continuity between ignition coil relay and battery ⊕ terminal.
Continuity should exist.



OK



C

CHECK OUTPUT SIGNAL.


- 1) Start engine.
- 2) With logic probe make sure that pulse signal exists between terminal ③ and ground.

Pulse signal should exist.

D

Check the following items.

- 1) Power transistor unit
Refer to "Electrical Components Inspection".
(See page EF & EC-182.)
- 2) Harness continuity between terminal ③ and power transistor terminals ① (No. 1 cylinder), ② (No. 2 cylinder), ⑥ (No. 6 cylinder).
Continuity should exist.
- 3) Harness continuity between power transistor terminals and ECM terminals.
① - ① ⑪ - ①
② - ① ⑫ - ②
③ - ③ ⑬ - ③
Continuity should exist.





OK

A

TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 28

BOOST PRESSURE SENSOR (Diagnostic trouble code No. 26) (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 28 (Cont'd)



INSPECTION START


A

CHECK POWER SUPPLY.

- 1) Disconnect boost pressure sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal ③ and ground.

Voltage: Approximately 5V

NG → Repair harness or connectors.




B

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Loosen and retighten ground screws.
- 3) Check harness continuity between terminal ④ and engine ground.

Continuity should exist.

NG → Repair harness or connectors.



C

CHECK INPUT SIGNAL CIRCUIT.

- 1) Disconnect ECM harness connector.
- 2) Check harness continuity between ECM terminal ⑦ and terminal ⑤.

Continuity should exist.

NG → Repair harness or connectors.

CHECK COMPONENT
(Boost pressure sensor).
Refer to "Electrical Components Inspection".
(See page EF & EC-188.)

NG → Replace boost pressure sensor.

Reinstall any part removed.

- 1) Erase the diagnostic test mode II (Self-diagnostic results) memory. (Refer to EF & EC-52.)
- 2) Perform test drive and then perform diagnostic test mode II (Self-diagnostic results) again. (Refer to EF & EC-50.)

NG →

- 1) Perform ECM input/output signal inspection test.
- 2) If NG, recheck the ECM pin terminals for damage or the connection of ECM harness connector.


INSPECTION END

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 29


ECM (ECCS CONTROL MODULE) (Diagnostic trouble code No. 31)  (MALFUNCTION INDICATOR LAMP ITEM)






TROUBLE DIAGNOSES

Diagnostic Procedure 30

EGR FUNCTION (Diagnostic trouble code No. 32) (MALFUNCTION INDICATOR LAMP ITEM)









Harness layout



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 30 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 30 (Cont'd)



G

■ EGRC SOL/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS ?

NEXT NO YES

SEF481M

G

■ ACTIVE TEST ■


EGRC SOL/V ON

=== MONITOR ===

CMPS·RPM (POS) 750rpm

ON ON/OFF OFF

MEF681F



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 30 (Cont'd)


H ROAD TEST

Test conditions

Drive vehicle under the following conditions with suitable gear position.

- (1) Engine speed:
 Non-turbocharger model
 2,650 ± 150 rpm
 Turbocharger model
 2,150 ± 150 rpm
- (2) Intake manifold vacuum:
 Non-turbocharger model
 -40.0 kPa
 (-300 mmHg, -11.81 inHg)
 Turbocharger model
 -33.3 kPa
 (-250 mmHg, -9.84 inHg)

Driving mode




- ① Start engine and warm it up sufficiently.
 ② Turn off ignition switch and keep it off until malfunction indicator lamp goes off.
 ③ Start engine and make sure that air conditioning switch and rear defogger are turned "OFF" during test drive.
 ④ Keep engine running for at least for 30 seconds.
 ⑤ Shift to suitable gear position and drive in "Test condition" for a total of 50 seconds or more.

Note: If engine stalls or ignition switch is turned off within step ⑤, return to step ②.

SEF667NA

I



SEF051P

Ⓑ

H

Perform test drive under the following conditions:

- 1) Warm up engine sufficiently.
- 2) Use test driving modes indicated in figure H.

I

Make sure malfunction indicator lamp does not come "ON" during test drive.

Comes

"ON"

Perform diagnostic test mode II (Self-diagnostic results) and find diagnostic trouble code. According to displayed Diagnostic trouble code No., perform electronic control system inspection.


Does not come "ON"

INSPECTION END





TROUBLE DIAGNOSES

Diagnostic Procedure 31

HEATED OXYGEN SENSOR (Diagnostic trouble code No. 33 and 53) (MALFUNCTION INDICATOR LAMP ITEM)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 31 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
1) Turn ignition switch "ON".
2) Check voltage between terminal ① and ground.
Voltage: Battery voltage

B
CHECK HARNESS CONTINUITY BETWEEN HEATED OXYGEN SENSOR AND FUSE.
1) Turn ignition switch "OFF".
2) Disconnect heated oxygen sensor harness connector.
3) Disconnect "ENG CONT" fuse.
4) Check harness continuity between terminal ① and the fuse.
Continuity should exist.
If NG, repair harness or connectors.

OK

C
CHECK OVERALL FUNCTION.
1) Start engine and warm it up sufficiently.
2) Perform "MIXTURE RATIO TEST" in "FUNCTION TEST" mode with CONSULT.
OR
2) Make sure that "M/R F/C MNT(R)" in "DATA MONITOR" mode indicates "RICH" and "LEAN" periodically more than 5 times during 10 seconds at 2,000 rpm.
OR
2) Make sure that malfunction indicator lamp goes on and off periodically more than 5 times during 10 seconds at 2,000 rpm in on-board diagnostic system (Diagnostic Test Mode II). (Refer to EF & EC-53.)

D
CHECK HARNESS CONTINUITY BETWEEN HEATED OXYGEN SENSOR AND ECM.
1) Stop engine.
2) Disconnect heated oxygen sensor harness connector.
3) Disconnect ECM harness connector.
4) Check harness continuity between ECM terminals and heated oxygen sensor terminals.
Right side: ② - ①
Left side: ⑤ - ①
Continuity should exist.
If NG, repair harness or connectors.

OK




①

OK

Replace heated oxygen sensor.

TROUBLE DIAGNOSES

Diagnostic Procedure 31 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL




IDX

Diagnostic Procedure 32

KNOCK SENSOR (Diagnostic trouble code No. 34)






Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 32 (Cont'd)




CI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 33

EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35) (MALFUNCTION INDICATOR LAMP ITEM)




Harness layout






TROUBLE DIAGNOSES






Diagnostic Procedure 33 (Cont'd)



INSPECTION START





OK



OK

Reinstall any part removed.



OK


INSPECTION END

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
JDX



TROUBLE DIAGNOSES

Diagnostic Procedure 34

FUEL TEMPERATURE SENSOR (Diagnostic trouble code No. 42)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 34 (Cont'd)



CI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 35

THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43) (MALFUNCTION INDICATOR LAMP ITEM)









Harness layout



TROUBLE DIAGNOSES




Diagnostic Procedure 35 (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 35 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



B ROAD TEST

Test conditions
Drive vehicle under the following conditions with suitable gear position.

(1) Engine speed:
Non-turbocharger 2,150 ± 350 rpm
Turbocharger 2,150 ± 450 rpm

(2) Intake manifold vacuum:
Non-turbocharger -43.3 ± 10.0 kPa (-325 ± 75 mmHg, -12.80 ± 2.95 inHg)
Turbocharger -33.3 ± 13.3 kPa (-250 ± 100 mmHg, -9.84 ± 3.94 inHg)

Driving mode

(A): More than 13 minutes
(B): More than 20 minutes at idle speed
(C): 10 seconds at test condition
(D): 2 minutes at idle speed

Test condition
Engine running
Ignition switch: OFF


Until malfunction indicator lamp goes off.

- Start engine and warm it up sufficiently.
- Turn off ignition switch and keep it off until malfunction indicator lamp goes off.
- Start engine and keep it running for more than 13 minutes.
- Turn off ignition switch and keep it off until malfunction indicator lamp goes off.
- Repeat steps ③ through ④ for a total of 3 times.
- Start engine and keep it at idle for more than 20 minutes.
If engine stalls or ignition turns off within 13 minutes after engine is started, return to step ②. If over 13 minutes, restart step ⑥.
- Shift to suitable gear position and drive in "Test condition" for at least 10 seconds.
If the following conditions occur during step ⑦, return to step ⑥.
 - Engine races over 4,000 rpm or hardly accelerates for more than 10 seconds.
 - Engine stalls or ignition is turns off.
- Keep engine at idle speed for more than 2 minutes.

SEF668NA



Diagnostic Procedure 36

INJECTOR LEAK (Diagnostic trouble code No. 45) (MALFUNCTION INDICATOR LAMP ITEM)



TROUBLE DIAGNOSES


Diagnostic Procedure 36 (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 37

INJECTOR CIRCUIT (Diagnostic trouble code No. 51) (MALFUNCTION INDICATOR LAMP ITEM)







Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 37 (Cont'd)





Diagnostic Procedure 38

CLOSED THROTTLE POSITION SWITCH (Idle position) (Not self-diagnostic item)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 38 (Cont'd)



INSPECTION START

A

CHECK INPUT SIGNAL.

- 1) Turn ignition switch "ON".
- 2) Check voltage between ECM terminal ⑤ and ground.

Voltage:

Throttle valve fully closed:
9.0 - 10.0V

Throttle valve fully open:
0V

OK

INSPECTION END

B

CHECK HARNESS CONTINUITY BETWEEN ECM AND CLOSED THROTTLE POSITION SWITCH.

- 1) Turn ignition switch "OFF".
- 2) Disconnect closed throttle position switch harness connector.
- 3) Disconnect ECM harness connector.
- 4) Check harness continuity between ECM terminals ⑤, ⑦ and terminals ①, ②.

Continuity should exist.

If NG, repair harness or connectors.

OK

Check if closed throttle position switch (throttle position sensor body) is installed in proper position. (See page EF & EC-185.)

OK

CHECK COMPONENT (closed throttle position switch). Refer to "Electrical Components Inspection". (See page EF & EC-185.)

TROUBLE DIAGNOSES

Diagnostic Procedure 39

START SIGNAL (Not self-diagnostic item)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 39 (Cont'd)

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE. SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY.

NEXT START

SEF191L



A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLOSED TH/POS	O N
AIR COND SIG	OFF
NEUT POSI SW	O N

RECORD

SEF485M



INSPECTION START

A

CHECK OVERALL FUNCTION.

1) Turn ignition switch "ON".

2) Perform "START SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

1) Turn ignition switch "ON".

2) Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT.

IGN "ON"	OFF
IGN "START"	ON

OR

1) Check voltage between ECM terminal ④ and ground.

When cranking:
Battery voltage

Except above:
0V

OK

INSPECTION END

B

Check the following items.

- 1) "G" fusible link
- 2) "7.5A" fuse
- 3) Ignition switch
- 4) Harness continuity between ECM and ignition switch
Continuity should exist.
- 5) Harness continuity between battery ⊕ terminal and ignition switch
Continuity should exist.

Diagnostic Procedure 40

POWER STEERING OIL PRESSURE SWITCH (Not self-diagnostic item)

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT




HA

EL

IDX



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 40 (Cont'd)

A

■ PW/ST SIGNAL CIRCUIT ■

HOLD STEERING WHEEL
IN A FULL
LOCKED POSITION
THEN
TOUCH START

NEXT START

SEF200L

A

☆ MONITOR ☆ NO FAIL

PW/ST SIGNAL OFF

RECORD

SEF591I

A

ECM CONNECTOR H.S. CONNECT

34

V

ON

MEF693C

B

DISCONNECT H.S. OFF

ECM CONNECTOR TS DISCONNECT

34 a b

Ω

MEF694C

C

DISCONNECT TS OFF

a b

Ω

SEF481I

INSPECTION START

A

CHECK OVERALL FUNCTION.

1) Turn ignition switch "ON".
2) Perform "PW/ST SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

OK → INSPECTION END

1) Start engine.
2) Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT.

Steering is neutral position: OFF
Steering is turned: ON

OR

1) Start engine.
2) Check voltage between ECM terminal ④ and ground with tester.

Voltage:
Steering is neutral position: Approx. 5V
Steering is turned: Approx. 0V

NG

B

CHECK HARNESS CONTINUITY BETWEEN POWER STEERING OIL PRESSURE SWITCH AND ECM.

1) Turn ignition switch "OFF".
2) Disconnect ECM harness connector and power steering oil pressure switch harness connector.
3) Check harness continuity between ECM terminal ④ and ⑤.

Continuity should exist.

NG → Repair or replace harness or connectors.

OK

C


CHECK GROUND CIRCUIT.
Check harness continuity between terminal ⑥ and ground.
Continuity should exist.

NG → Repair or replace harness or connectors.



OK → CHECK COMPONENT.
(Power steering oil pressure switch)
Refer to "Electrical Components Inspection".
(See page EF & EC-187.)

Diagnostic Procedure 41

NEUTRAL POSITION SWITCH & A/T CONTROL UNIT (NEUTRAL POSITION SIGNAL) CIRCUIT (Not self-diagnostic item)









Harness layout



GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 41 (Cont'd)







Diagnostic Procedure 42

FUEL PUMP (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 42 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Turn ignition switch "ON".
- 2) Check voltage between fuel pump connector terminal ① and ground.

Battery voltage indication should appear for 5 seconds after turning ignition switch "ON".

NG


B

Check the following items.

- 1) "G" fusible link
- 2) Harness continuity between
 - battery ⊕ terminal and fuel pump relay
 - fuel pump relay and fuel pump
 - fuel pump relay and ECM terminal ⑩

Continuity should exist.

OK



C

CHECK COMPONENT (Fuel pump relay).

Perform "FUEL PUMP CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

— OR —

Perform "FUEL PUMP RELAY TEST" in "ACTIVE TEST" mode with CONSULT and check for operating sound.

— OR —

Refer to "Electrical Components Inspection". (See page EF & EC-187.)

OK

Ⓐ

C

■ FUEL PUMP CIRCUIT ■

PINCH FUEL FEED HOSE WITH FINGERS. IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?

OR

DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

SEF633L

C

■ ACTIVE TEST ■ □

FUEL PUMP RELAY ON

== MONITOR ==



CMPS•RPM (POS) 0rpm

ON ON/OFF OFF

MEF686F

TROUBLE DIAGNOSES

Diagnostic Procedure 42 (Cont'd)



D

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Loosen and retighten ground screws.
- 3) Start engine.
- 4) Check voltage between fuel pump terminal ① and ground under the following conditions.

Idling	Approx. 3 - 6V
For 30 seconds after starting engine	Battery voltage

OK

INSPECTION END

E

Check the following items. Harness continuity between

- fuel pump and fuel pump control module
- fuel pump control module and ECM terminal 104

Continuity should exist.

OK

CHECK COMPONENT (Fuel pump).

Refer to "Electrical Components Inspection". (See page EF & EC-182.)

NG


Replace fuel pump control module.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 43

IACV-AIR REGULATOR (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 43 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Start engine.
 2) Check voltage between IACV-air regulator terminal (a) and ground.
Voltage: Battery voltage

B
 Check the following items.
 1) Harness continuity between
 • IACV-air regulator and fuel pump relay
 • fuel pump relay and battery ⊕ terminal
 • fuel pump relay and ECM terminal (18)
Continuity should exist.
 2) "G" fusible link



OK

OK

C
CHECK COMPONENT (Fuel pump relay).
 Perform "FUEL PUMP CIRCUIT" in "FUNCTION TEST" mode with CONSULT.
 — OR —
 Perform "FUEL PUMP RELAY TEST" in "ACTIVE TEST" mode with CONSULT and check for operating sound.
 — OR —
 Refer to "Electrical Components Inspection". (See page EF & EC-187.)

C
 ■ FUEL PUMP CIRCUIT ■
 PINCH FUEL FEED HOSE WITH FINGERS. IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?
 OR
 DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?



ⓐ

C
 ■ ACTIVE TEST ■
 FUEL PUMP RELAY ON
 === MONITOR ===
 CMPS•RPM (POS) 0rpm

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 43 (Cont'd)





Diagnostic Procedure 44

IACV-AAC VALVE (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 44 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.


- 1) Turn ignition switch "ON".
- 2) Check voltage between IACV-AAC valve terminal (a) and ground.

Voltage: Battery voltage.

B

Check the following items.

- 1) "G" fusible link
- 2) Ignition switch
- 3) "10A" fuses
- 4) Harness continuity between terminals:
 - IACV-AAC valve and ignition switch
 - Ignition switch and battery ⊕ terminal.




C

CHECK HARNESS CONTINUITY BETWEEN IACV-AAC VALVE AND ECM.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector and IACV-AAC valve harness connector.
- 3) Check harness continuity between terminal (b) and ECM terminal (4).

Continuity should exist.

Repair or replace harness or connectors.




D

CHECK COMPONENT (IACV-AAC valve).


- 1) Reconnect ECM harness connector and IACV-AAC valve harness connector.
- 2) Start engine and let it idle.
- 3) Perform "IACV-AAC/V SYSTEM" in "FUNCTION TEST" mode with CONSULT.

Repair or replace IACV-AAC valve.



OR

- 3) Select "IACV-AAC/V OPENING" in "ACTIVE TEST" mode with CONSULT.
- 4) When touching "Qu" and "Qd", check that engine speed changes according to the IACV-AAC valve opening percentage.



OR


- 3) Disconnect IACV-AAC valve harness connector.
- 4) Make sure that idle speed drops.

INSPECTION END



TROUBLE DIAGNOSES

Diagnostic Procedure 45

IACV-FICD SOLENOID VALVE (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 45 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Turn ignition switch "ON".
 2) Check voltage between IACV-FICD solenoid valve terminal (a) and ground.
Voltage: Battery voltage.


B
 Check the following items.
 1) "G" fusible link
 2) "10A" fuses
 3) Ignition switch
 4) Harness continuity between terminals:
 • IACV-FICD solenoid valve and ignition switch
 • Ignition switch and battery ⊕ terminal.
Continuity should exist.



OK

C
CHECK HARNESS CONTINUITY BETWEEN IACV-FICD SOLENOID VALVE AND ECM.
 1) Turn ignition switch "OFF".
 2) Disconnect ECM harness connector and IACV-FICD solenoid valve harness connector.
 3) Check harness continuity between IACV-FICD solenoid valve terminal (b) and ECM terminal (33).
Continuity should exist.


NG
 Repair or replace harness or connectors.




OK

D
CHECK COMPONENT (IACV-FICD solenoid valve).
 1) Reconnect ECM harness connector and IACV-FICD solenoid valve harness connector.
 2) Start engine and let it idle.
 3) Perform "IACV-FICD SV SYSTEM" in "FUNCTION TEST" mode with CONSULT.
 — OR —
 3) Perform "IACV-FICD SOL/V TEST" in "ACTIVE TEST" mode with CONSULT.
 — OR —
 Refer to "Electrical Components Inspection".
 (See page EF & EC-186.)

NG
 Repair or replace IACV-FICD solenoid valve.



OK




INSPECTION END




Diagnostic Procedure 46

PRVR CONTROL SOLENOID VALVE (Not self-diagnostic item)

GI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX









Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 46 (Cont'd)






TROUBLE DIAGNOSES

Diagnostic Procedure 47

VTC SOLENOID VALVE (Not self-diagnostic item)




Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 47 (Cont'd)







TROUBLE DIAGNOSES

Diagnostic Procedure 48

COOLING FAN CONTROL (Not self-diagnostic item)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)



Non-turbocharger models

INSPECTION START

A

CHECK OVERALL FUNCTION.

1) Turn ignition switch "ON".
2) Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

1) Turn ignition switch "ON".
2) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

OR

1) Start engine.
2) Set temperature lever at full cold position.
3) Turn air conditioner switch "ON".
4) Turn blower fan switch "ON".
5) Run engine at idle for a few minutes with air conditioner operating.
6) Make sure that cooling fan operates.

OK → INSPECTION END

NG

1) Turn air conditioner switch and blower fan switch "OFF".

B

CHECK POWER SUPPLY.

1) Turn ignition switch "OFF".
2) Disconnect cooling fan relay.
3) Turn ignition switch "ON".
4) Check voltage between terminals ②, ③ and ground.

Voltage: Battery voltage

NG →

Check the following.



- "L" fusible link
- "R" fusible link
- 10A fuse
- Harness continuity between battery and cooling fan relay
- Harness continuity between fuse and cooling fan relay

If NG, repair harness or connectors.

OK → **A**

TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)




Turbocharger models

INSPECTION START

E CHECK COOLING FAN LOW SPEED OPERATION.


1) Turn ignition switch "ON".
2) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

NG Check cooling fan low speed control circuit. (Go to PROCEDURE A.)



OR


1) Start engine.
2) Set temperature lever at full cold position.
3) Turn air conditioner switch "ON".
4) Turn blower fan switch "ON".
5) Run engine at idle for a few minutes with air conditioner operating.
6) Make sure that cooling fan operates at low speed.



F CHECK COOLING FAN HIGH SPEED OPERATION.


1) Turn ignition switch "OFF".
2) Turn ignition switch "ON".
3) Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

NG Check cooling fan high speed control circuit. (Go to PROCEDURE B.)



OR

2) Turn ignition switch "ON".
3) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.



OR




2) Turn air conditioner switch and blower fan switch "OFF".
3) Disconnect engine coolant temperature sensor harness connector.
4) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
5) Restart engine and make sure that cooling fan operates at higher speed than low speed.

OK

INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)



PROCEDURE A

INSPECTION START

G

CHECK POWER SUPPLY.

- 1) Turn ignition switch "OFF".
- 2) Disconnect cooling fan relay.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ②, ③ and ground.

Voltage: Battery voltage.

NG →

Check the following.

- "L" fusible link
- "R" fusible link
- 10A fuse
- Harness continuity between battery and cooling fan relay
- Harness continuity between fuse and cooling fan relay

If NG, repair harness or connectors.

OK ↓

H

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect cooling fan motor harness connector.
- 3) Check harness continuity between terminal ④ and terminal ⑤, terminal ⑥ and ground.

Continuity should exist.

NG →

Repair harness or connectors.

OK ↓

I

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Disconnect ECM harness connector.
- 2) Check harness continuity between ECM terminal ⑯ and terminal ①.

Continuity should exist.

NG →

Check the following.

- Harness connectors (F23, E10)
- Harness continuity between ECM and cooling fan relay

If NG, repair harness or connectors.

OK ↓

CHECK COMPONENT
(Cooling fan relay).
Refer to "Electrical Components Inspection".
(See page EF & EC-187.)

NG →

Replace cooling fan relay.




OK ↓

⑧

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)





PROCEDURE B

INSPECTION START



TROUBLE DIAGNOSES

Diagnostic Procedure 48 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 49

WASTEGATE VALVE CONTROL SOLENOID VALVE (Not self-diagnostic item): Turbocharger model only







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 49 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL


IDX




Electrical Components Inspection

ECM INPUT/OUTPUT SIGNAL INSPECTION

1. ECM is located behind front passenger side floor board. For this inspection, remove the front passenger side floor board.



2. Remove ECM harness protector.



3. Perform all voltage measurements with the connectors connected. Extend tester probe as shown to perform tests easily.

ECM HARNESS CONNECTOR TERMINAL LAYOUT

10	102	103	104	105	×	107	108	1	2	3	4	5	6	7	×	9	10	21	22	23	×	25	26	27	28	29	30	41	42	43	44	45	46	47	48	49	50	
109	110	111	112	113	114	115	116	11	12	13	14	15	16	×	18	19	20	31	32	33	34	35	36	37	38	39	40	51	×	53	54	55	56	57	58	59	60	

MEF541G

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM inspection table

*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
1 2 3 11 12 13	Ignition signal	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	Approx. 0.1V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Engine speed is 2,000 rpm.	Approx. 0.14V
4	IACV-AAC valve	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Racing condition	Voltage briefly decreases from battery voltage (11 - 14V).
6	Cooling fan sub-relay (Turbocharger model)	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Cooling fan is operating.	Approx. 0V
7	Tachometer	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	1.0 - 1.5V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Engine speed is 2,000 rpm	2.3 - 2.8V
9	Air conditioner relay	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Air conditioner switch "OFF"	BATTERY VOLTAGE (11 - 14V)
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Air conditioner switch "ON"	Approx. 0V
16	ECM power source (Self-shutoff)	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	0.8 - 1.0V
		<input type="checkbox"/> Engine is not running. <input type="checkbox"/> For a few seconds after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
18	Fuel pump relay	<input type="checkbox"/> Ignition switch "ON" <input type="checkbox"/> For a few seconds after turning ignition switch "ON"	0.7 - 0.9V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Ignition switch "ON" <input type="checkbox"/> A few seconds after turning ignition switch "ON" and thereafter	BATTERY VOLTAGE (11 - 14V)
19	Cooling fan relay	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Cooling fan is operating.	Approx. 0V
23	Knock sensor	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	Approx. 2.5V
25	Wastegate valve control solenoid valves (Turbocharger model)	<input type="checkbox"/> Ignition switch "ON" <input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	BATTERY VOLTAGE (11 - 14V)
		<input type="checkbox"/> Engine is racing. <input type="checkbox"/> Engine speed is up to 3,000 rpm	Approx. 0.2V

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
27	Mass air flow sensor	<input type="checkbox"/> Engine is running. (Warm-up condition) <input type="checkbox"/> Idle speed	0.8 - 1.5V
		<input type="checkbox"/> Engine is running. (Warm-up condition) <input type="checkbox"/> Engine speed is 2,000 rpm.	1.0 - 1.6V
28	Engine coolant temperature sensor	<input type="checkbox"/> Engine is running.	0 - 5.0V Output voltage varies with engine coolant temperature.
29	Right side heated oxygen sensor	<input type="checkbox"/> Engine is running.	0 ↔ Approx. 1.0V
55	Left side heated oxygen sensor	<input type="checkbox"/> After warming up sufficiently and engine speed is 2,000 rpm.	
33	IACV-FICD solenoid valve	<input type="checkbox"/> Engine is running. <input type="checkbox"/> A/C compressor is not operating.	BATTERY VOLTAGE (11 - 14V)
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> A/C compressor is operating.	0 - 1.0V
34	Power steering oil pressure switch	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Steering wheel is in the "straight ahead" position.	Approx. 5V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Steering wheel is turned.	Approx. 0V
35	Fuel pump voltage control (Turbocharger model)	<input type="checkbox"/> Ignition switch "ON" <input type="checkbox"/> Engine stopped	0V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	1 - 2V
		<input type="checkbox"/> Engine is racing.	4 - 5V
36	Fuel temperature sensor	<input type="checkbox"/> Engine is running.	0 - 5.0V Output voltage varies with fuel temperature.
37	Boost pressure sensor (Turbocharger model)	<input type="checkbox"/> Engine is running. <input type="checkbox"/> Idle speed	Approx. 2.7V
		<input type="checkbox"/> Engine is running. <input type="checkbox"/> Engine is racing from idle to 4,500 rpm.	Approx. 3.1V
38	Throttle position sensor	<input type="checkbox"/> Ignition switch "ON"	0.4 - 4.0V Output voltage varies with throttle valve opening angle.
39	EGR temperature sensor	<input type="checkbox"/> Engine is running. (Warm-up condition) <input type="checkbox"/> Idle speed	Less than 4.5V
		<input type="checkbox"/> Engine is running. (Warm-up condition) <input type="checkbox"/> EGR system is operating.	0 - 1.0V
41 51	Camshaft position sensor (Reference signal)	<input type="checkbox"/> Engine is running. Do not run engine at high speed under no-load.	0.8 - 1.8V Output voltage varies slightly with engine speed.
42	Camshaft position sensor (Position signal)	<input type="checkbox"/> Engine is running. Do not run engine at high speed under no-load.	2.5 - 2.7V Output voltage varies slightly with engine speed.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
43	Start signal	Ignition switch "ON"	Approx. 0V
		Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)
44	Neutral position switch (M/T model) A/T control unit (A/T model)	Ignition switch "ON" └ Gear position is "Neutral position" (M/T model). └ Gear position is "N" or "P" position (A/T model).	Approx. 0V
		Ignition switch "ON" └ Except the above conditions	Approx. 5V
45	Ignition switch	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)
46	Air conditioner switch	Engine is running. └ Air conditioner switch "OFF"	BATTERY VOLTAGE (11 - 14V)
		Engine is running. └ Air conditioner switch "ON"	0.5 - 0.7V
48	Power source for sensors	Ignition switch "ON" └ Engine stopped	Approximately 5.0V
49 59	Battery source	Ignition switch "ON" └ Engine stopped	BATTERY VOLTAGE (11 - 14V)
54	Closed throttle position switch (Idle position)	Ignition switch "ON" └ Accelerator pedal is fully released (engine running).	8.0 - 10.0V
		Ignition switch "ON" └ Accelerator pedal is depressed (engine running).	0V
57	Power source for closed throttle position switch	Ignition switch "ON" └ Engine running	BATTERY VOLTAGE (11 - 14V)
58	Power supply	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101 103 105 110 112 114	Injectors	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
102	EGRC-solenoid valve	Engine is running. (Warm-up condition) └ Idle speed	Approx. 0V
		Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
104	Fuel pump voltage control	Ignition switch "ON" └ Engine stopped	0V
		Engine is running. (Warm-up condition) └ Idle speed	1 - 2V

CI
 MA
 EM
 LC
EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)


*Data are reference values.

TERMI- NAL NO.	ITEM	CONDITION	*DATA
111	PRVR control solenoid valve	<div style="border: 1px solid black; padding: 2px;">Stop and restart engine after warming it up.</div> <input type="checkbox"/> Fuel temperature is above 75°C (167°F)	0 - 1.0V (For 30 seconds after engine is start.) <hr/> BATTERY VOLTAGE (30 seconds after engine is start.)
		<div style="border: 1px solid black; padding: 2px;">Stop and restart engine after warming it up.</div> <input type="checkbox"/> Fuel temperature is below 75°C (167°F)	BATTERY VOLTAGE (11 - 14V)
113	Valve timing control solenoid valves	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <input type="checkbox"/> Idle speed	BATTERY VOLTAGE (11 - 14V)
		<div style="border: 1px solid black; padding: 2px;">Engine is racing.</div> (Jack-up drive wheels and shift selector lever to 1st position.) <input type="checkbox"/> Engine speed is below 2,000 rpm.	0.2 - 0.5V
115	Heated oxygen sensor heater	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <input type="checkbox"/> Engine speed is below 2,800 rpm.	Approx. 0V
		<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <input type="checkbox"/> Engine speed is above 2,800 rpm.	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

CAMSHAFT POSITION SENSOR




1. Remove camshaft position sensor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON".
3. Rotate camshaft position sensor shaft slowly by hand and check voltage between terminals ①, ② and ground.

Terminal	Voltage
② (120° signal)	Voltage fluctuates between 5V and 0V.
① (1° signal)	

If NG, replace camshaft position sensor.

After this inspection, diagnostic trouble code No. 11 might be displayed though the camshaft position sensor is functioning properly. In this case erase the stored memory.




MASS AIR FLOW SENSOR

1. Fold back mass air flow sensor harness connector rubber as shown in the figure if the harness connector is connected.
2. Turn ignition switch "ON".
3. Start engine and warm it up sufficiently.
4. Check voltage between terminal ① and ground.

Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Approximately 0.8
Idle (Engine is warm-up sufficiently.)	Approximately 0.8 - 1.5

5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.




ENGINE COOLANT TEMPERATURE SENSOR

1. Disconnect engine coolant temperature sensor harness connector.
2. Check resistance as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

If NG, replace engine coolant temperature sensor.

EF & EC-181



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)


IGNITION COIL



1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.

Terminal	Resistance
① - ②	Approximately 0.7Ω

If NG, replace ignition coil.




POWER TRANSISTOR

1. Disconnect power transistor harness connector.
2. Check power transistor continuity between terminals as shown in the figure.

Terminal combination	Tester polarity	Resistance	Tester polarity	Resistance
③	⊕	Not ∞ or 0	⊖	∞
①	⊖	Not ∞ or 0	⊕	∞
③	⊕	Not ∞ or 0	⊖	Not ∞ or 0
②	⊖	Not ∞ or 0	⊕	Not ∞ or 0
①	⊕	∞	⊖	Not ∞ or 0
②	⊖	∞	⊕	Not ∞ or 0

If NG, replace power transistor.




FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals (a) and (c).

Resistance: Approximately 0.2 - 5.0Ω

If NG, replace fuel pump.



VEHICLE SPEED SENSOR

1. Jack up rear wheels. Use stands to support vehicle.
2. Disconnect vehicle speed sensor harness connector.
3. Check continuity between terminals (a) and (b) while rotating rear wheel by hand.

Continuity should come and go.

If NG replace vehicle speed sensor.


TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

EGRC-SOLENOID VALVE

PRVR CONTROL SOLENOID VALVE

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




WASTEGATE VALVE CONTROL SOLENOID VALVE

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals (a) and (b)	Yes
No supply	No

If NG, replace solenoid valve.




EGR VALVE

Apply vacuum to EGR vacuum port with a hand vacuum pump.

EGR valve spring should lift.

If NG, replace EGR valve.



COOLING FAN MOTOR

1. Disconnect cooling fan motor harness connector.
2. Supply cooling fan motor terminals with battery voltage and check operation.


Non-turbocharger model

Cooling fan motor should operate.

If NG, replace cooling fan motor.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)




Turbocharger model

Cooling fan motor operation	Terminals	
	⊕	⊖
Low speed	③	②
High speed	① and ③	②

Cooling fan motor should operate.

If NG, replace cooling fan motor.



HEATED OXYGEN SENSOR


Refer to "Diagnostic Procedure 30".
(See page EF & EC-129.)

HEATED OXYGEN SENSOR HEATER

Check resistance between terminals ① and ③.

Resistance: 3 - 1,000Ω

If NG, replace heated oxygen sensor.



EGR TEMPERATURE SENSOR


Check resistance change and resistance value at 100°C (212°F).

- **Resistance should decrease in response to temperature increase.**

Resistance: 100°C (212°F)

85.3±8.53 kΩ

If NG, replace EGR temperature sensor.




WIDE OPEN THROTTLE POSITION SWITCH

1. Disconnect throttle position switch harness connector.
2. Check continuity between terminals ③ and ②.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

If NG, replace throttle position switch.



THROTTLE POSITION SENSOR

1. Disconnect throttle position sensor harness connector.
2. Make sure that resistance between terminals ② and ③ changes when opening throttle valve manually.

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

If NG, replace throttle position sensor.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

CLOSED THROTTLE POSITION SWITCH (Idle position)

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between terminals ① and ②.

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

If NG, replace closed throttle position switch.

Adjustment

If throttle position sensor or throttle position switch is replaced or removed, it is necessary to install it in the proper position, by following the procedure as shown below:

1. Install throttle position sensor body in throttle body. Do not tighten bolts.
2. Connect throttle position sensor and throttle position switch harness connector.
3. Start engine and warm it up sufficiently.
4. Disconnect throttle position switch harness connector.
5. Check closed throttle position switch OFF → ON speed with circuit tester, closing throttle valve manually.

Closed throttle position switch OFF → ON speed:

Non-turbocharger

MT: 900±150 rpm



AT: 970±150 rpm

Turbocharger

MT: 900±150 rpm (U.S.A.)

950±150 rpm (Canada)

AT: 950±150 rpm [in "N" position]




IACV-AAC VALVE

- Check IACV-AAC valve resistance.

Resistance:

Approximately 10Ω




- Check plunger for seizing or sticking.
- Check for broken spring.

TROUBLE DIAGNOSES


Electrical Components Inspection (Cont'd)

IACV-FICD SOLENOID VALVE

- Check for clicking sound when applying 12V direct current to terminals.




- Check plunger for seizing or sticking.
- Check for broken spring.




IACV-AIR REGULATOR

- Check IACV-air regulator resistance.
Resistance:
Approximately 70 - 80Ω
- Check IACV-air regulator for clogging.




KNOCK SENSOR

1. Disconnect knock sensor sub-harness connector.
2. Check continuity between terminal Ⓐ and ground.
Continuity should exist.



INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.
Resistance: 10 - 14Ω
If NG, replace injector.



TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

VALVE TIMING CONTROL SOLENOID VALVE

Check valve timing control solenoid valve for normal operation by supplying it with battery voltage between terminals ① and ②. If NG, replace solenoid valve.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




NEUTRAL POSITION SWITCH

Check continuity between terminals ① and ②.

Conditions	Continuity
Shift to Neutral position	Yes
Shift to other position	No

If NG, replace neutral position switch.



INHIBITOR SWITCH

Check continuity between terminals ① and ②, ③.


Conditions	Continuity between terminals ① and ②	Continuity between terminals ① and ③
Shift to "P" position	Yes	No
Shift to "N" position	No	Yes
Shift to positions other than "P" and "N"	No	No

ECCS RELAY, FUEL PUMP RELAY, COOLING FAN RELAY, COOLING FAN SUB-RELAY AND IGNITION COIL RELAY

Check continuity between terminals ③ and ⑤.

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.



POWER STEERING OIL PRESSURE SWITCH


1. Disconnect power steering oil pressure switch harness connector.
2. Check resistance between terminals.
Resistance: Approximately 2 - 3Ω

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

FUEL TEMPERATURE SENSOR

1. Disconnect fuel temperature sensor harness connector.
2. Check resistance between terminal and ground as shown in the figure.




Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

If NG, replace fuel inhibitor switch.



BOOST PRESSURE SENSOR

Check voltage between terminals.



+	-	Engine condition	Voltage (V)
c	a	Idle	Approx. 5.2
c	b	Idle - 4,500 rpm	Approx. 2.7
c	b	Above 4,500 rpm	Approx. 3.1

MULTIPOINT FUEL INJECTION SYSTEM INSPECTION



Releasing Fuel Pressure

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.



Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.




1. Remove fuel pump relay or disconnect fuel pump connector.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch off and reconnect fuel pump relay or fuel pump connector.

Fuel Pressure Check

- a. When reconnecting fuel line, always use new clamps.
- b. Make sure that clamp screw does not contact adjacent parts.
- c. Use a torque driver to tighten clamps.
- d. Use Pressure Gauge to check fuel pressure.
- e. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.

1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.



5. Read the indication of fuel pressure gauge.

At idling:

When fuel pressure regulator valve vacuum hose is connected.

Approximately 250.1 kPa
(2.55 kg/cm², 36.3 psi)


When fuel pressure regulator valve vacuum hose is disconnected.

Approximately 299.1 kPa
(3.05 kg/cm², 43.4 psi)

MULTIPOINT FUEL INJECTION SYSTEM INSPECTION

Fuel Pressure Check (Cont'd)

6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.



9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.

Injector Removal and Installation

1. Release fuel pressure to zero.
2. Drain coolant from radiator drain cock.
3. Remove or disconnect the following:
 - Related harnesses, wires and tubes
 - Intake manifold collectorFor details, refer to EM section.
4. Remove injectors with fuel tube assembly.
5. Remove injectors from fuel tube assembly.
6. Install injectors as follows:
 - 1) Clean exterior of injector tail piece.
 - 2) Use new O-rings.


CAUTION:

After properly connecting injectors to fuel tube assembly, check connections for fuel leakage.

7. Assemble injectors with fuel tube assembly to intake manifold.

EVAPORATIVE EMISSION SYSTEM

Description




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from sealed fuel tank is led into the canister when the engine is off. The fuel vapor is then stored in the canister. The canister retains the fuel vapor until the canister is purged by air.

When the engine is running, the air is drawn through the bottom of the canister. The fuel vapor will then be led to the intake manifold. When the engine runs at idle, the purge control valve is closed. Only a small amount of vapor flows into the intake manifold through the constant purge orifice.

As the engine speed increases and the throttle vacuum rises, the purge control valve opens. The vapor is sucked through both main purge and constant purge orifices.



Inspection

CARBON CANISTER

Check carbon canister as follows:

1. Blow air in port (A) and ensure that there is no leakage.
2.
 - Apply vacuum to port (A).
 - Cover port (D) with hand.
 - Blow air in port (C) and ensure free flow out of port (B).


EVAPORATIVE EMISSION SYSTEM

Inspection (Cont'd)

FUEL CHECK VALVE


Check valve operation

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
2. Blow air through connector on canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.




Rollover valve operation

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.



FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.



CRANKCASE EMISSION CONTROL SYSTEM

Description

This system returns blow-by gas to both the intake manifold and air inlet tubes.

The positive crankcase ventilation (PCV) valves are provided to conduct crankcase blow-by gas to the intake manifold.



During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valves.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from air inlet tubes into crankcase through a hose. The hose connects the air inlet tubes and the rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the PCV valves. Flow then goes through the hose connection in the reverse direction.


Under any condition, some of the flow goes through the hose connection to the air inlet tubes. This will occur on vehicles with an excessively high blow-by.



Inspection

PCV (Positive Crankcase Ventilation)

With engine running at idle, remove ventilation hose from PCV valve; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

PRESSURE REGULATOR	
Regulated pressure kPa (kg/cm ² , psi)	299.1 (3.05, 43.4)

Inspection and Adjustment

	Turbocharger	Non-turbocharger
Idle speed*1 rpm		
No-load*2		
M/T		
U.S.A.	700±50	700±50
Canada	750±50	
A/T	750±50	770±50
Air conditioner: ON	850±50	800±50
Ignition timing degree	15±2 BTDC	
Throttle position sensor idle position V	0.4 - 0.5	

*1: Feedback controlled and needs no adjustments

*2: Under the following conditions:

- Air conditioner switch: OFF
- Steering wheel: Kept straight
- Electric load: OFF (Lights, heater, fan & rear defogger)
- Cooling fan: OFF

IGNITION COIL

Primary voltage V	12
Primary resistance [at 20°C (68°F)] Ω	Approximately 0.7
Secondary resistance [at 20°C (68°F)] kΩ	Approximately 8

ENGINE COOLANT TEMPERATURE SENSOR AND FUEL TEMPERATURE SENSOR

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

BOOST PRESSURE SENSOR

Engine condition	Voltage (V)
Idle - 4,500 rpm	Approximately 2.7
Above 4,500 rpm	Approximately 3.1

FUEL PUMP

Resistance Ω	Approximately 0.2 - 5.0
--------------	-------------------------

EGR TEMPERATURE SENSOR

Resistance [at 100°C (212°F)] kΩ	85.3±8.53
----------------------------------	-----------

HEATED OXYGEN SENSOR HEATER

Resistance Ω	3 - 1,000
--------------	-----------

IACV-AAC VALVE

Resistance Ω	Approximately 10
--------------	------------------

INJECTOR

Resistance Ω	10 - 14
--------------	---------

THROTTLE POSITION SENSOR

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

IACV-AIR REGULATOR

Resistance Ω	70 - 80
--------------	---------

POWER STEERING OIL PRESSURE SWITCH

Resistance Ω	Approximately 2 - 3
--------------	---------------------