

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION **LC**

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS

PRECAUTIONS	2	ENGINE COOLING SYSTEM	8
Supplemental Restraint System (SRS) "AIR BAG".....	2	Cooling Circuit	8
Liquid Gasket Application Procedure	2	System Check.....	8
PREPARATION	3	Water Pump.....	9
Special Service Tools	3	Thermostat.....	10
ENGINE LUBRICATION SYSTEM	4	Cooling Fan (Crankshaft driven)	11
Lubrication Circuit.....	4	Cooling Fan (Motor driven).....	11
Oil Pressure Check.....	5	Radiator	12
Oil Filter Bracket (Turbocharger model)	5	Overheating Cause Analysis	17
Oil Pump	5	SERVICE DATA AND SPECIFICATIONS (SDS)	18
Oil Cooler (Turbocharger model).....	7	Engine Lubrication System.....	18
		Engine Cooling System	18



PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.









Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.


PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge	 <p>PF1/4x19/in</p> <p>NT558</p>	GI MA EM Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi)
ST25052000 (J25695-2) Hose	 <p>PS1/4x19/in</p> <p>PS1/8x28/in</p> <p>NT559</p>	EC Adapting oil pressure gauge to cylinder block LC
WS39930000 (—) Tube presser	 <p>NT052</p>	FE Pressing the tube of liquid gasket CL
EG17650301 (J33984-A) Radiator cap tester adapter	 <p>NT564</p>	MT Adapting radiator cap tester to radiator filler neck AT a: 28 mm (1.10 in) dia. b: 31.4 mm (1.236 in) dia. c: 41.3 mm (1.626 in) dia.
KV99103510 (—) Radiator plate pliers A	 <p>NT224</p>	PD Installing radiator upper and lower tanks FA RA
KV99103520 (—) Radiator plate pliers B	 <p>NT225</p>	BR Removing radiator upper and lower tanks ST RS

Lubrication Circuit





Non-turbocharger model

Turbocharger model



ENGINE LUBRICATION SYSTEM



Oil Pressure Check

WARNING:


- Be careful not to burn yourself, as the engine and oil may be hot.
 - Oil pressure check should be done in "Neutral position".
1. Check oil level.
 2. Remove oil pressure switch.

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000	353 - 451 (3.6 - 4.6, 51 - 65)


If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.



Oil Filter Bracket (Turbocharger model)

- Check oil cooler check valve for valve opening pressure.
Opening pressure:
324 - 363 kPa (3.3 - 3.7 kg/cm², 47 - 53 psi)



Oil Pump



REMOVAL

1. Drain oil.
2. Remove oil pan. Refer to EM section ("Removal", "OIL PAN").
3. Remove oil pump assembly.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd) DISASSEMBLY AND ASSEMBLY

SEC. 150



- Always replace with new oil seal and gasket.
- When assembling, apply engine oil to inner and outer gears.
- Be sure that O-ring is properly installed.

OIL PUMP INSPECTION

Using a feeler gauge, straightedge and micrometers, check the following clearances:

Standard clearance:

Turbocharger model

Unit: mm (in)



Body to outer gear clearance ①	0.110 - 0.200 (0.0043 - 0.0079)
Inner gear to crescent clearance ②	0.223 - 0.333 (0.0088 - 0.0131)
Outer gear to crescent clearance ③	0.210 - 0.320 (0.0083 - 0.0126)
Housing to inner gear clearance ⑥	0.050 - 0.090 (0.0020 - 0.0035)
Housing to outer gear clearance ⑦	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of body clearance ⑧	0.045 - 0.091 (0.0018 - 0.0036)

Non-turbocharger model

Unit: mm (in)


Body to outer gear clearance ④	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance ⑤	Less than 0.18 (0.0071)
Body to inner gear clearance ⑥	0.050 - 0.090 (0.0020 - 0.0035)
Body to outer gear clearance ⑦	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of body clearance ⑧	0.045 - 0.091 (0.0018 - 0.0036)

If any clearance exceeds the limit, replace gear set or entire oil pump assembly.



ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




REGULATOR VALVE INSPECTION

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
4. Check regulator valve to oil pump body clearance.

Clearance:

⑨: 0.040 - 0.080 mm (0.0016 - 0.0031 in)

If it exceeds the limit, replace oil pump assembly.




OIL PRESSURE RELIEF VALVE INSPECTION

Inspect oil pressure relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove valve by prying it out with a suitable tool.



Install a new valve by tapping it in place.

Oil Cooler (Turbocharger model)



ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the radiator cap when the engine is hot; serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap and carefully remove it by turning it a quarter turn to allow built-up pressure to escape and then turn the cap all the way off.

CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.


CHECKING COOLING SYSTEM FOR LEAKS

To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.



ENGINE COOLING SYSTEM


System Check (Cont'd)

CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.


Radiator cap relief pressure:

108 - 127 kPa (1.1 - 1.3 kg/cm², 16 - 18 psi)



Water Pump

SEC. 210



REMOVAL AND INSTALLATION


CAUTION:

- When removing water pump assembly, be careful not to get coolant on timing belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.

1. Drain coolant from drain cocks on both sides of cylinder block and radiator.
2. Remove the following parts:
 - Under cover
 - Radiator
 - Drive belts
 - Cooling fan and coupling
 - Water inlet and outlet
 - Crank pulley
 - Timing belt cover
3. Remove water pump.
4. After repairing or replacing water pump, install any parts removed in reverse order of removal.

ENGINE COOLING SYSTEM

Thermostat (Cont'd)



4. After repairing or replacing thermostat, install thermostat with jiggle valve facing upward.
 - After installation, run engine for a few minutes, and check for leaks.
 - Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

INSPECTION

1. Check valve seating condition at ordinary room temperatures. It should seat tightly.
2. Check valve opening temperature and maximum valve lift.


		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 10/90 (0.39/194)

3. Then check if valve is 5°C (9°F) below valve opening temperature.




Cooling Fan (Crankshaft driven)

DISASSEMBLY AND ASSEMBLY



INSPECTION

Check fan coupling for rough operation, oil leakage or bent bimetal.



Cooling Fan (Motor driven)

This cooling fan is controlled by ECM (ECCS control module). For details, refer to EC section ("Cooling Fan", "TROUBLE DIAGNOSIS FOR DTC P1900").

ENGINE COOLING SYSTEM

Radiator

REMOVAL AND INSTALLATION


1. Drain coolant from radiator drain cock.
2. Remove under cover.
3. Disconnect radiator upper and lower hoses.
4. Remove A/T oil cooler hoses. (A/T model only)
5. Remove radiator lower shroud.
6. Remove radiator.
7. After repairing or replacing radiator, install any part removed in reverse order of removal.

When filling radiator with coolant, refer to MA section ("Changing Engine Coolant").

SEC. 214

Non-turbocharger model

Turbocharger model




MLC065AA

ENGINE COOLING SYSTEM


Radiator (Cont'd)

SEC. 214


Non-turbocharger model




Turbocharger model



A/T model only



MLC083A



DISASSEMBLY


1. Remove tank with Tool.

ENGINE COOLING SYSTEM

Radiator (Cont'd)


- Grip the crimped edge and bend it upwards so that Tool slips off.

Do not bend excessively.




- In areas where Tool cannot be used, use a screwdriver to bend the edge up.

Be careful not to damage tank.




2. Make sure the edge stands straight up.
3. Remove oil cooler from tank.




ASSEMBLY

1. Install oil cooler.

Pay attention to direction of conical washer.





2. Clean contact portion of tank.





ENGINE COOLING SYSTEM

Radiator (Cont'd)


Push it in with fingers.
Be careful not to twist sealing rubber.



3. Caulk tank in specified sequence with Tool.



• Use pliers in the locations where Tool cannot be used.



4. Make sure that the rim is completely crimped down.
Standard height "H":
9.5 - 9.9 mm (0.374 - 0.390 in)
5. Confirm that there is no leakage.
Refer to Inspection.

ENGINE COOLING SYSTEM

Radiator (Cont'd)

INSPECTION

Apply pressure with Tool.


Specified pressure value:

157 kPa (1.6 kg/cm², 23 psi)

WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp.

Attach a hose to the oil cooler as well.



ENGINE COOLING SYSTEM

Overheating Cause Analysis

	Symptom	Check items				
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	GI	
		Thermostat stuck closed	—		MA	
		Damaged fins	Dust contamination or paper clogging		—	EM
			Mechanical damage			LC
	Reduced air flow	Fan coupling does not operate.	—	—	EC	
		Cooling fan does not operate.			FE	
		High resistance to fan rotation			CL	
		Damaged fan blades			MT	
	Damaged radiator shroud	—	—	—	AT	
	Improper coolant mixture ratio	—	—	—	PD	
	Poor coolant quality	—	—	—	FA	
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	RA	
				Cracked hose	BR	
			Water pump	Poor sealing	ST	
				Radiator cap	Loose	RS
Poor sealing		BT				
Radiator		O-ring for damage, deterioration or improper fitting	—	HA		
		Cracked radiator tank		EL		
		Cracked radiator core		IDX		
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration	RA			
		Cylinder head gasket deterioration	BR			
—	Overload on engine	Abusive driving	High engine rpm under no load	ST		
			Driving in low gear for extended time	RS		
			Driving at extremely high speed	BT		
		Powertrain system malfunction	—	HA		
		Installed improper size wheels and tires		EL		
		Dragging brakes		IDX		
Improper ignition timing.	—	—	—			
Blocked or restricted air flow	Blocked bumper	—	—	—		
	Blocked radiator grille	Installed car brassiere	—	BT		
		Mud contamination or paper clogging		HA		
	Blocked radiator	—	—	—		
	Blocked condenser	—	—	—		
Installed large fog lamp	—	—	—	—		
Except cooling system parts malfunction	—	—	—	—		
				—		

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure check

Engine speed	Approximate discharge
rpm	pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,000	353 - 451 (3.6 - 4.6, 51 - 65)

Regulator valve inspection

Unit: mm (in)

Regulator valve to oil pump body clearance	0.040 - 0.080 (0.0016 - 0.0031)
--	---------------------------------

Oil pump

Turbocharger model

Unit: mm (in)

Body to outer gear clearance	0.110 - 0.200 (0.0043 - 0.0079)
Inner gear to crescent clearance	0.223 - 0.333 (0.0088 - 0.0131)
Outer gear to crescent clearance	0.210 - 0.320 (0.0083 - 0.0126)
Housing to inner gear side clearance	0.050 - 0.090 (0.0020 - 0.0035)
Housing to outer gear side clearance	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

Non-turbocharger model

Unit: mm (in)

Body to outer gear clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance	Less than 0.18 (0.0071)
Body to inner gear clearance	0.050 - 0.090 (0.0020 - 0.0035)
Body to outer gear clearance	0.050 - 0.110 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

Engine Cooling System

Thermostat

		Standard
Valve opening temperature	°C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 10/90 (0.39/194)

Radiator

Unit: kPa (kg/cm², psi)

Cap relief pressure	108 - 127 (1.1 - 1.3, 16 - 18)
Leakage test pressure	157 (1.6, 23)