

ENGINE MECHANICAL

SECTION **EM**



CONTENTS

PRECAUTIONS	2	Camshaft End Play.....	33
Parts Requiring Angular Tightening	2	Camshaft Sprocket Runout	33
Liquid Gasket Application Procedure.....	2	Valve Guide Clearance.....	33
PREPARATION	3	Valve Guide Replacement.....	34
Special Service Tools.....	3	Valve Seats.....	35
Commercial Service Tools	6	Replacing Valve Seat For Service Parts.....	35
OUTER COMPONENT PARTS	7	Valve Dimensions	36
Except A/T Models For California.....	7	Valve Spring.....	36
A/T Models For California.....	8	Valve Lifter And Valve Shim	36
COMPRESSION PRESSURE	11	Assembly.....	37
Measurement of Compression Pressure	11	Valve Clearance.....	37
OIL PAN	12	ENGINE REMOVAL	40
Removal.....	12	Removal.....	41
Installation.....	14	Installation.....	42
TIMING CHAIN	17	CYLINDER BLOCK	43
Liquid gasket application places	18	Disassembly.....	44
Removal.....	19	Piston And Crankshaft.....	44
Upper Timing Chain.....	19	Inspection.....	45
Lower Timing Chain.....	22	Piston And Piston Pin Clearance	45
Inspection.....	22	Piston Ring Side Clearance	45
Installation.....	22	Piston Ring End Gap.....	45
Lower Timing Chain.....	22	Connecting Rod Bend And Torsion	46
Upper Timing Chain.....	23	Cylinder Block Distortion	46
OIL SEAL REPLACEMENT	26	Piston-To-Bore Clearance	46
Valve Oil Seal	26	Crankshaft	47
Front Oil Seal.....	26	Bearing Clearance.....	48
Rear Oil Seal	27	Connecting Rod Bushing Clearance (Small	
ACCEL-DRUM UNIT	28	end).....	50
Adjustment	28	Replacement of Connecting Rod Bushing	
CYLINDER HEAD	30	(Small end)	51
Removal and Installation	31	Flywheel/Drive Plate Runout.....	51
Disassembly.....	31	Assembly.....	51
Inspection.....	31	Piston.....	51
Cylinder Head Distortion	31	Crankshaft	52
Camshaft Visual Check	32	Replacing Pilot Bushing	53
Camshaft Runout.....	32	SERVICE DATA AND SPECIFICATIONS (SDS)	54
Camshaft Cam Height.....	32	General Specifications	54
Camshaft Journal Clearance.....	32	Inspection and Adjustment.....	54

PRECAUTIONS

Parts Requiring Angular Tightening

- Use an angle wrench for the final tightening of the following engine parts:
 - (1) Cylinder head bolts
 - (2) Main bearing cap bolts
 - (3) Connecting rod cap nuts
- Do not use a torque value for final tightening.
- The torque value for these parts is for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.









Liquid Gasket Application Procedure

- a. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- b. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
- c. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- d. Assembly should be done within 5 minutes after coating.
- e. Wait at least 30 minutes before refilling engine oil and engine coolant.

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.






Tool number (Kent-Moore No.) Tool name	Description	GI MA
ST0501S000 (—) Engine stand assembly ① ST05011000 (—) Engine stand ② ST05012000 (—) Base	Disassembling and assembling  NT042	EM LC EC
KV10114300 (—) Engine sub-attachment	 NT239	FE CL MT
KV10106500 (—) Engine stand shaft	 NT028	AT FA
KV10109250 (J-26336-B) Valve spring compressor ① KV10109210 (—) Compressor ② KV10109220 (—) Adapter	Disassembling and assembling valve components 	RA BR ST
or (J-39773) Valve spring compressor kit	NT021	RS
KV10116300 (J-38955) Valve oil seal drift	  NT602	BT HA EL ID

Installing valve oil seal

- a: 25 (0.98) dia.
- b: 14.4 (0.567) dia.
- c: 11.8 (0.465) dia.
- d: 10 (0.39) dia.
- e: 11 (0.43)
- f: 9 (0.35)
- Unit: mm (in)





PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
KV10110300 (—) Piston pin press stand assembly ① KV10110310 (—) Cap ② KV10110330 (—) Spacer ③ ST13030020 (—) Press stand ④ ST13030030 (—) Spring ⑤ KV10110340 (—) Drift ⑥ KV10110320 (—) Center shaft	 <p style="text-align: right;">Disassembling and assembling piston with connecting rod</p> <p style="text-align: center;">NT036</p>
EM03470000 (J8037) Piston ring compressor	 <p style="text-align: right;">Installing piston assembly into cylinder bore</p> <p style="text-align: center;">NT044</p>
(J36467) Valve oil seal remover	 <p style="text-align: right;">Displacement valve oil seal</p> <p style="text-align: center;">NT034</p>
KV10111100 (J37228) Seal cutter	 <p style="text-align: right;">Removing oil pan</p> <p style="text-align: center;">NT046</p>
WS39930000 (—) Tube presser	 <p style="text-align: right;">Pressing the tube of liquid gasket</p> <p style="text-align: center;">NT052</p>
ST16610001 (J23907) Pilot bushing puller	 <p style="text-align: right;">Removing crankshaft pilot bushing</p> <p style="text-align: center;">NT045</p>

PREPARATION





Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
ST10120000 (J-24239-01) Cylinder head bolt wrench	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Loosening and tightening cylinder head bolt</p> <p>a: 13 (0.51) dia. b: 12 (0.47) c: 10 (0.39) Unit: mm (in)</p> </div> </div> <p style="margin-top: 10px;">NT583</p>
KV10115150 (J-38972) Lifter stopper set ① KV10115110 (J-38972-1) Camshaft pliers ② KV10115120 (J-38972-2) Lifter stopper	<div style="display: flex; align-items: center;">  </div> <p style="margin-top: 10px;">NT041</p> <p style="margin-top: 10px;">Changing shims</p>
KV10112100 (—) Angle wrench	<div style="display: flex; align-items: center;">  </div> <p style="margin-top: 10px;">NT014</p> <p style="margin-top: 10px;">Tightening bolts for bearing cap, cylinder head, etc.</p>
(J36471-A) Front (heated) oxygen sensor wrench	<div style="display: flex; align-items: center;">  </div> <p style="margin-top: 10px;">NT379</p> <p style="margin-top: 10px;">Loosening or tightening front (heated) oxygen sensor</p>

GI
 MA
EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

PREPARATION


Commercial Service Tools

Tool name	Description
Spark plug wrench	 <p>16 mm (0.63 in)</p> <p>NT047</p> <p>Removing and installing spark plug</p>
Pulley holder	 <p>NT035</p> <p>Holding camshaft pulley while tightening or loosening camshaft bolt</p>
Valve seat cutter set	 <p>NT048</p> <p>Finishing valve seat dimensions</p>
Piston ring expander	 <p>NT030</p> <p>Removing and installing piston ring</p>
Valve guide drift	 <p>NT015</p> <p>Removing and installing valve guide</p> <p>Intake & Exhaust: a: 10.5 mm (0.413 in) dia. b: 6.6 mm (0.260 in) dia.</p>
Valve guide reamer	 <p>NT016</p> <p>Reaming valve guide ① or hole for oversize valve guide ②</p> <p>Intake & Exhaust: d₁: 7 mm (0.28 in) dia. d₂: 11.175 mm (0.4400 in) dia.</p>

OUTER COMPONENT PARTS

EXCEPT A/T MODELS FOR CALIFORNIA

SEC. 140-147-148-163




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AEM180

OUTER COMPONENT PARTS


A/T MODELS FOR CALIFORNIA

SEC. 140•147•148•163



OUTER COMPONENT PARTS

SEC. 140 • 208 • 210 • 275



- : N·m (kg-m, in-lb)
- : N·m (kg-m, ft-lb)
- ★ : Refer to "Tightening Procedure"


AEM182

CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


OUTER COMPONENT PARTS

Tightening Procedure


A Intake manifold




B Intake manifold collector




C Exhaust manifold— Except California models



C Exhaust manifold— California models



D Throttle body





Throttle body bolts Tightening procedure

- 1) Tighten all bolts to 9 to 11 N·m
(0.9 to 1.1 kg-m, 6.5 to 8.0 ft-lb).
- 2) Tighten all bolts to 18 to 22 N·m
(1.8 to 2.2 kg-m, 13 to 16 ft-lb).

AEM189

COMPRESSION PRESSURE



Measurement of Compression Pressure

1. Warm up engine.
2. Turn ignition switch off.
3. Release fuel pressure.
Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
4. Remove all spark plugs.
5. Disconnect distributor center cable.

6. Attach a compression tester to No. 1 cylinder.
 7. Depress accelerator pedal fully to keep throttle valve wide open.
 8. Crank engine and record highest gauge indication.
 9. Repeat the measurement on each cylinder as shown above.
- **Always use a fully-charged battery to obtain specified engine speed.**

Compression pressure: kPa (kg/cm², psi)/rpm

Standard

1,226 (12.5, 178)/300

Minimum

1,030 (10.5, 149)/300


Difference limit between cylinders

98 (1.0, 14)/300

10. If compression in one or more cylinders is low:
 - a. Pour a small amount of engine oil into cylinders through spark plug holes.
 - b. Retest compression.
- **If adding oil helps compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
 - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to SDS.) If valve or valve seat is damaged excessively, replace.**
 - **If compression stays low in two cylinders that are next to each other:**
 - a. **The cylinder head gasket may be leaking, or**
 - b. **Both cylinders may have valve component damage. Inspect and repair as necessary.**

OIL PAN

SEC. 110



- : N·m (kg·m, in·lb)
- : N·m (kg·m, ft·lb)
- : Apply liquid gasket.

⑤ 29 - 39
(3.0 - 4.0,
22 - 29)


M6: 6.4 - 7.5 (0.65 - 0.76, 56.4 - 66.0)
M8, M10: 16 - 19 (1.6 - 1.9, 12 - 14)

- ① Aluminum oil pan
- ② Rear cover plate
- ③ Steel oil pan
- ④ Baffle plate
- ⑤ Drain plug


AEM193

Removal

1. Remove engine under cover.
2. Drain engine oil.




3. Remove steel oil pan bolts.




4. Remove steel oil pan.
 - a. Insert Tool between aluminum oil pan and steel oil pan.
 - Be careful not to damage aluminum mating surface.
 - Do not insert screwdriver or oil pan flange will be damaged.

OIL PAN


Removal (Cont'd)




- b. Slide Tool by tapping on the side of the Tool with a hammer.
- c. Remove steel oil pan.




- 5. Remove baffle plate.
- 6. Remove oil strainer.



- 7. Remove front tube.
- 8. Set a suitable transmission jack under transaxle and hoist engine with engine slinger.
- 9. Remove center member.



- 10. Remove compressor gussets.



- 11. Remove rear cover plate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX


OIL PAN

Removal (Cont'd)



12. Remove aluminum oil pan nuts and bolts.


- Remove in reverse order as shown.




13. Remove aluminum oil pan.

a. Insert Tool between cylinder block and aluminum oil pan.


- Be careful not to damage aluminum mating surface.
- Do not insert screwdriver, or oil pan flange will be damaged.



b. Slide Tool by tapping on the side of the Tool with a hammer.



c. Remove aluminum oil pan.



Installation






1. Install aluminum oil pan.

a. Use a scraper to remove all traces of liquid gasket from mating surfaces.

- Also remove traces of liquid gasket from mating surfaces of cylinder block, front cover and steel oil pan.

OIL PAN

Installation (Cont'd)



b. Apply a continuous bead of liquid gasket to mating surface of aluminum oil pan.

- Use Genuine Liquid Gasket or equivalent.

- Apply to groove on mating surface.

- Allow 7 mm (0.28 in) clearance around bolt holes.

- For areas marked with "★", apply liquid gasket around the outer side of the bolt hole.

- Be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).

- Attaching should be done within 5 minutes after coating.

c. Install aluminum oil pan.

- Tighten nuts and bolts in numerical order.

2. Install compressor gussets.

3. Install center member.

4. Install front tube.

5. Install oil strainer baffle plate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT






HA

EL

IDX

OIL PAN

Installation (Cont'd)



6. Install steel oil pan.
 - a. Use a scraper to remove all traces of liquid gasket from mating surfaces.
 - Also remove traces of liquid gasket from mating surface of aluminum oil pan.

- b. Apply a continuous bead of liquid gasket to mating surface of steel oil pan.

- Use Genuine Liquid Gasket or equivalent.


- Apply to groove on mating surface.
- Allow 7 mm (0.28 in) clearance around bolt holes.

- Be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
- Attaching should be done within 5 minutes after coating.

- c. Install steel oil pan.
 - Tighten bolts in numerical order shown.
 - Wait at least 30 minutes before refilling engine oil.

TIMING CHAIN

SEC. 111-120-130-135







GI
MA
EM
LG
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AEM194

TIMING CHAIN


Liquid gasket application places



TIMING CHAIN

CAUTION:

- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing camshafts, chain tensioners, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to bolt threads and seat surfaces when installing cylinder head, camshaft sprockets, crankshaft pulley, and camshaft brackets.
- Before disconnecting fuel hose, release fuel pressure. Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").




Removal

UPPER TIMING CHAIN


1. Drain coolant from drain plug on water pipe and radiator drain cock. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
2. Remove vacuum hoses, fuel hoses, wires, harness and connectors and so on.
3. Remove the following parts:
 - Generator and bracket
 - Air duct
 - Upper radiator hose
 - Cooling fan assembly
 - Front exhaust tube
4. Remove the following:
 - Intake manifold collector supports
 - Intake manifold
 - Exhaust manifold with warm-up three way catalyst

Refer to EM-8.





TIMING CHAIN


Removal (Cont'd)




5. Set No. 1 piston at TDC on its compression stroke.
6. Remove distributor.
7. Set a suitable transmission jack under aluminum oil pan and remove front engine mounting.



8. Remove rocker cover.




9. Remove cam sprocket.



- The stoppers on camshaft sprocket cover prevent upper timing chain from disengaging idler sprocket.


TIMING CHAIN

Removal (Cont'd)



10. Remove camshaft brackets and camshafts.

- These parts must be reassembled in their original positions.



11. Loosen cylinder head bolts in numerical order.


- Removing in incorrect order could result in a warped or cracked cylinder head.

- Loosen cylinder head bolts in two or three steps.


12. Remove camshaft sprocket cover.

13. Remove upper chain tensioner and upper chain guides.


14. Remove upper timing chain.



15. Remove idler sprocket bolt.



- The stoppers on front cover prevent lower timing chain from disengaging crankshaft sprocket.



16. Remove cylinder head and cylinder head gasket.

TIMING CHAIN

Removal (Cont'd)



LOWER TIMING CHAIN

1. Remove upper timing chain.

Refer to EM-19.

2. Remove oil pan.


Refer to EM-12.



3. Remove crankshaft pulley.

4. Remove front cover.


- Inspect for oil leakage at front oil seal. Replace seal if oil leak is present.



5. Remove the following parts:

- Oil pump drive spacer
- Lower timing chain tensioner
- Tension arm
- Lower timing chain guide

6. Remove lower timing chain and idler sprocket.



Inspection

Check for cracks and excessive wear at roller links. Replace chain if necessary.


Installation

LOWER TIMING CHAIN

1. Install crankshaft sprocket and oil pump drive spacer.





- Make sure that mating marks on crankshaft sprocket face front of engine.

2. Position crankshaft so that No. 1 piston is set at TDC.



TIMING CHAIN

Installation (Cont'd)



3. Install idler sprocket and lower timing chain.

- **Fit lower timing chain on the sprockets, aligning mating marks.**
4. Install tension arm and chain guide.
5. Install lower timing chain tensioner.

6. Install front cover.

- **Apply a continuous bead of liquid gasket to front cover. Refer to EM-18.**
 - **Be sure to install new front oil seal in the right direction. Refer to EM-26.**
7. Install the following parts:
- Crankshaft pulley
 - Oil strainer
 - Oil pan
 - New cylinder head gasket

8. When installing front cover, install cylinder head and cylinder head bolts.

- **Apply new engine oil to bolt threads and seat surfaces.**
 - **Be sure to install washers between bolts and cylinder head.**
9. Slightly tighten the cylinder head bolts.
- **This is necessary to avoid damaging cylinder head gasket.**

UPPER TIMING CHAIN

1. Install lower timing chain.
Refer to EM-22.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

TIMING CHAIN


Installation (Cont'd)





2. Install upper timing chain, chain tensioner and chain guide.
 - **Set upper timing chain on the idler sprocket, aligning mating marks.**



3. Install cam sprocket cover.
 - **Apply a continuous bead of liquid gasket to camshaft sprocket cover. Refer to EM-18.**
 - **Be careful not to damage cylinder head gasket.**
 - **Be careful upper timing chain does not slip or jump off idler sprocket.**







4. Tighten cylinder head bolts using the following procedure:
 - a. **Tighten all bolts to 29 N·m (3.0 kg·m, 22 ft·lb).**
 - b. **Tighten all bolts to 79 N·m (8.1 kg·m, 59 ft·lb).**
 - c. **Loosen all bolts completely.**
 - d. **Tighten all bolts to 25 to 34 N·m (2.5 to 3.5 kg·m, 18 to 25 ft·lb).**
 - e. **Turn all bolts 86 to 91 degrees clockwise. If an angle wrench is not available, mark all cylinder head bolts on the side facing engine front. Then, turn each cylinder head bolt 86 to 91 degrees clockwise.**



5. Install camshafts and camshaft brackets using the following procedure:
 - a. **Set camshafts and camshaft brackets.**
 - b. **Tighten all bolts to 2 N·m (0.2 kg·m, 17 in·lb).**
 - c. **Tighten all bolts to 9.0 to 11.8 N·m (0.92 to 1.2 kg·m, 79.9 to 104.2 in·lb).**

TIMING CHAIN

Installation (Cont'd)



6. Install camshaft sprockets.
7. Install chain guide between both camshaft sprockets.

8. Install distributor.
 - Make sure that No. 1 piston is set at TDC and that distributor rotor is set at No. 1 cylinder spark position.

9. Install rocker cover gasket.
 - Apply liquid gasket to rocker cover rubber gasket, cylinder head and camshaft sprocket cover. Refer to EM-18.
10. Install rocker cover using the following procedure:
 - a. Tighten nuts ①-⑤-⑥-④ in that order to 4 N-m (0.4 kg-m, 35 in-lb).
 - b. Tighten nuts ① to ⑪ in numerical order to 8 to 11 N-m (0.8 to 1.1 kg-m, 69 to 95 in-lb).
11. Install all spark plugs with high-tension cords.
12. Install vacuum hoses, fuel tubes, wires, harness and connectors and so on.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

OIL SEAL REPLACEMENT





Valve Oil Seal

1. Remove rocker cover.
2. Remove camshaft. Refer to EM-19.
3. Remove valve spring and valve oil seal with Tool or suitable tool.


Piston must be set at TDC to prevent valve from falling.

4. Apply engine oil to new valve oil seal and install it with Tool.




Front Oil Seal






1. Remove radiator shroud and crankshaft pulley.
 2. Remove front oil seal.
- **Be careful not to scratch front cover.**



3. Install new oil seal in the direction shown.
- Apply engine oil to new oil seal and install it using a suitable tool.



OIL SEAL REPLACEMENT



Rear Oil Seal

1. Remove drive plate or flywheel.
2. Remove rear oil seal retainer.
3. Remove traces of liquid gasket using scraper.

4. Remove rear oil seal from rear oil seal retainer.
Be careful not to scratch rear oil seal retainer.

5. Install new oil seal in the direction shown.
 - Apply engine oil to new oil seal and install it using a suitable tool.

6. Apply a continuous bead of liquid gasket to rear oil seal retainer.
 - Apply around inner side of bolt holes.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

ACCEL-DRUM UNIT



Adjustment


Adjust accel-drum unit after any of the following parts are installed:

- Accel-drum unit
- Throttle body
- Rod (Always replace with a new one after removal.)


1. Install accel-drum unit and throttle body.
2. Apply grease all over the inside of the rod couplings.

Use genuine Nissan grease or equivalent.

3. Attach each coupling to ball links on throttle body and accel-drum unit.



4. Loosen lock nut.
5. Loosen adjusting screw.





6. Manually turn accel-drum until throttle valve is fully open.

- Check that stopper lever is not touching adjusting screw. If it is, loosen adjusting screw to maintain clearance between the two.

ACCEL-DRUM UNIT

Adjustment (Cont'd)

7. Turn adjusting screw until it touches stopper lever.
8. Release accel-drum.



9. Turn adjusting screw 3 rotations clockwise.
10. Tighten lock nut to specification.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

CYLINDER HEAD

SEC. 111-130

Refer to "Installation" in "TIMING CHAIN".



Liquid gasket
Refer to "Liquid gasket application places" in "TIMING CHAIN".

Refer to "Installation" in "TIMING CHAIN".

Refer to "Installation" in "TIMING CHAIN".

Liquid gasket
Refer to "Liquid gasket application places" in "TIMING CHAIN".

Cylinder head gasket

- ① Oil filler cap
- ② Rocker cover
- ③ Camshaft bracket
- ④ Intake camshaft
- ⑤ Exhaust camshaft

- ⑥ Shim
- ⑦ Valve lifter
- ⑧ Valve cotter
- ⑨ Spring retainer
- ⑩ Valve spring

- ⑪ Spring seat
- ⑫ Intake valve
- ⑬ Exhaust valve
- ⑭ Cylinder head
- ⑮ Cylinder head bolt

SEM149EA



CYLINDER HEAD

CAUTION:

- When installing camshafts, chain tensioners, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- When tightening cylinder head bolts, camshaft sprocket bolts, crankshaft pulley bolt and camshaft bracket bolts, lubricate bolt threads and seat surfaces with new engine oil.
- Attach tags to valve lifters so as not to mix them up.

Removal and Installation

- Removal and installation procedures are the same as those for timing chain. Refer to EM-19.



Disassembly

1. Remove valve components with Tool.
2. Remove valve oil seal with a suitable tool.

CAUTION:

Keep parts in order so that they can be installed in their original positions during assembly.

Inspection

CYLINDER HEAD DISTORTION

Clean surface of cylinder head.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder head surface.

Check along six positions shown in figure.

Head surface flatness:

Standard: Less than 0.03 mm (0.0012 in)

Limit: 0.1 mm (0.004 in)

If beyond the specified limit, replace it or resurface it.

Resurfacing limit:

The limit for cylinder head resurfacing is determined by the cylinder block resurfacing.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

A + B = 0.2 mm (0.008 in)

After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.


Nominal cylinder head height:

126.3 - 126.5 mm (4.972 - 4.980 in)

CYLINDER HEAD

Inspection (Cont'd) CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.



CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):


Standard

Less than 0.02 mm (0.0008 in)

Limit

0.04 mm (0.0016 in)

2. If it exceeds the limit, replace camshaft.



CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

Standard cam height:

Intake

42.415 - 42.605 mm (1.6699 - 1.6774 in)

Exhaust

For California

42.415 - 42.605 mm (1.6699 - 1.6774 in)

Except for California


42.815 - 43.005 mm (1.6856 - 1.6931 in)

Cam wear limit:

Intake & Exhaust

0.2 mm (0.008 in)

2. If wear is beyond the limit, replace camshaft.



CAMSHAFT JOURNAL CLEARANCE

1. Install camshaft bracket and tighten bolts to the specified torque. Refer to EM-24.
2. Measure inner diameter of camshaft bearing.

Standard inner diameter:

#1, #6 journal


24.000 - 24.025 mm (0.9449 - 0.9459 in)

#2 to #5 journals

28.000 - 28.025 mm (1.1024 - 1.1033 in)

CYLINDER HEAD

Inspection (Cont'd)



3. Measure outer diameter of camshaft journal.

Standard outer diameter:

#1, #6 journal

23.935 - 23.955 mm (0.9423 - 0.9431 in)

#2 to #5 journals


27.935 - 27.955 mm (1.0998 - 1.1006 in)

4. If clearance exceeds the limit, replace camshaft and/or cylinder head.

Camshaft journal clearance:

Standard 0.045 - 0.090 mm (0.0018 - 0.0035 in)

Limit 0.12 mm (0.0047 in)



CAMSHAFT END PLAY

1. Install camshaft in cylinder head. Refer to EM-24.
2. Measure camshaft end play.


Camshaft end play:

Standard

0.07 - 0.15 mm (0.0028 - 0.0059 in)

Limit

0.20 mm (0.0079 in)




CAMSHAFT SPROCKET RUNOUT

1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.

Runout (Total indicator reading):

Limit 0.12 mm (0.0047 in)

3. If it exceeds the limit, replace camshaft sprocket.



VALVE GUIDE CLEARANCE

1. Measure valve deflection as shown in figure. (Valve and valve guide mostly wear in this direction.)

Valve intake and exhaust deflection limit (Dial gauge reading):

0.2 mm (0.008 in)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

CYLINDER HEAD

Inspection (Cont'd)



2. If it exceeds the limit, check valve to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.

Valve to valve guide clearance:


Unit: mm (in)

	Standard	Limit
Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.08 (0.0031)
Exhaust	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)


- c. If it exceeds the limit, replace valve or valve guide.

VALVE GUIDE REPLACEMENT

1. To remove valve guide, heat cylinder head to 120 to 140°C (248 to 284°F).



2. Drive out valve guide with a press [less than 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.




3. Ream cylinder head valve guide hole.

Valve guide hole diameter (for service parts):


Intake & Exhaust

11.175 - 11.196 mm (0.4400 - 0.4408 in)



CYLINDER HEAD


Inspection (Cont'd)



- Heat cylinder head to 120 to 140°C (230 to 266°F) and press service valve guide onto cylinder head.

Projection "L":

13.3 - 13.9 mm (0.524 - 0.547 in)




- Ream valve guide.

Finished size:

Intake & Exhaust


7.000 - 7.018 mm (0.2756 - 0.2763 in)



VALVE SEATS

Check valve seats for pitting at contact surface. Resurface or replace if excessively worn.

- **Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.**
- **Use both hands to cut uniformly.**



REPLACING VALVE SEAT FOR SERVICE PARTS

- Bore out old seat until it collapses. Set machine depth stop so that boring cannot contact bottom face of seat recess in cylinder head.

- Ream cylinder head recess.


Reaming bore for service valve seat

Oversize [0.5 mm (0.020 in)]:

Intake 38.000 - 38.016 mm (1.4961 - 1.4967 in)

Exhaust 32.700 - 32.716 mm (1.2874 - 1.2880 in)

Use the valve guide center for reaming to ensure valve seat will have the correct fit.




- Heat cylinder head to 120 to 140°C (248 to 284°F).
- Press fit valve seat until it seats on the bottom.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CYLINDER HEAD

Inspection (Cont'd)



5. Cut or grind valve seat using suitable tool to the specified dimensions. Refer to SDS (EM-57).
6. After cutting, lap valve seat with abrasive compound.
7. Check valve seating condition.

Seat face angle " α ":

44°53' - 45°07'


Contacting width " W ":

Intake

1.48 - 1.63 mm (0.0583 - 0.0642 in)

Exhaust

1.8 - 2.0 mm (0.071 - 0.079 in)




VALVE DIMENSIONS

Check dimensions of each valve. For dimensions, refer to SDS (EM-54).

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.



VALVE SPRING


Squareness

1. Measure dimension " S ".

Out-of-square " S ":

Less than 2.0 mm (0.079 in)

2. If it exceeds the limit, replace spring.



Pressure

Check valve spring pressure at specified spring height.

Pressure:


Standard

471.7 N (48.1 kg, 106.1 lb) at 26.06 mm (1.0260 in)

Limit

More than 421.31 N (42.96 kg, 94.73 lb) at 26.06 mm (1.0260 in)

If it exceeds the limit, replace spring.




VALVE LIFTER AND VALVE SHIM

1. Check contact and sliding surfaces for wear or scratches.

CYLINDER HEAD

Inspection (Cont'd)



2. Check diameter of valve lifter and valve lifter guide bore.

Valve lifter diameter:

33.960 - 33.975 mm (1.3370 - 1.3376 in)



Lifter guide bore diameter:

34.000 - 34.021 mm (1.3386 - 1.3394 in)

Valve lifter to valve lifter guide clearance:

0.025 - 0.061 mm (0.0010 - 0.0024 in)


If it exceeds the standard diameter or clearance, replace valve lifter or cylinder head.



Assembly

Install valve component parts.

- Always use new valve oil seal. Refer to EM-26.
- Before installing valve oil seal, install valve spring seat.
- Install outer valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side.
- After installing valve components, tap valve stem tip with plastic hammer to assure a proper fit.




Valve Clearance

CHECKING

Check valve clearance while engine is warm but not running.

1. Remove rocker cover and all spark plugs.
2. Set No. 1 cylinder at TDC on its compression stroke.
 - Align pointer with TDC mark on crankshaft pulley.
 - Check that valve lifters on No. 1 cylinder are loose and valve lifters on No. 4 are tight.If not, turn crankshaft one revolution (360°) and align as above.



3. Check only those valves shown in the figure.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

CYLINDER HEAD

Valve Clearance (Cont'd)



- Using a feeler gauge, measure clearance between valve lifter and camshaft.
- Record any valve clearance measurements which are out of specification. They will be used later to determine the required replacement adjusting shim.


Valve clearance (Hot):

Intake

0.31 - 0.39 mm (0.012 - 0.015 in)

Exhaust

0.33 - 0.41 mm (0.013 - 0.016 in)



4. Turn crankshaft one revolution (360°) and align mark on crankshaft pulley with pointer.
5. Check those valves shown in the figure.
 - Use the same procedure mentioned in step 4.
6. If all valve clearances are within specification, install the following parts:
 - Rocker cover
 - All spark plugs

ADJUSTING


Adjust valve clearance while engine is cold.

1. Turn crankshaft to position cam lobe on camshaft of valve that must be adjusted upward.
2. Place Tool (A) around camshaft as shown in figure.
3. Rotate Tool (A) so that lifter is pushed down.

Before placing Tool (A), rotate notch toward center of cylinder head (see figure). This will simplify shim removal later.

CAUTION:

Be careful not to damage cam surface with Tool (A).




4. Place Tool (B) between camshaft and valve lifter to retain valve lifter.


CAUTION:

- Tool (B) must be placed as close to camshaft bracket as possible.
- Be careful not to damage cam surface with Tool (B).

5. Remove Tool (A).




6. Remove adjusting shim using a small screwdriver and a magnetic finger.



CYLINDER HEAD

Valve Clearance (Cont'd)



7. Determine replacement adjusting shim size as follows:
 - a. Using a micrometer, determine thickness of removed shim.
 - b. Calculate thickness of new adjusting shim so valve clearance comes within specified values.


R = Thickness of removed shim

N = Thickness of new shim

M = Measured valve clearance

Intake: $N = R + [M - 0.35 \text{ mm (0.0138 in)}]$


Exhaust: $N = R + [M - 0.37 \text{ mm (0.0146 in)}]$



Shims are available in thicknesses from 1.96 mm (0.0772 in) to 2.68 mm (0.1055 in), in steps of 0.02 mm (0.0008 in).

- c. Select new shim with thickness as close as possible to calculated value.

Refer to SDS (EM-56).




8. Install new shim using a suitable tool.

Install with the surface on which the thickness is stamped facing down.

9. Place Tool (A) as mentioned in steps 2 and 3.
10. Remove Tool (B).
11. Remove Tool (A).
12. Recheck valve clearance.
Refer to EM-37.

ENGINE REMOVAL

SEC. 112




ENGINE REMOVAL

WARNING:

- Position vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled; otherwise, you may burn yourself and/or fire may break out in fuel line.
- Before disconnecting fuel hose, release fuel pressure. Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
- Before removing front axle from transaxle, place safety stands under designated front supporting points. Refer to GI section for lifting points and towing.
- Be sure to hoist engine and transaxle in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.


CAUTION:

- When lifting engine, be sure to clear surrounding parts. Use special care for accelerator wire casing, brake lines and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- In removing drive shaft, be careful not to damage grease seal of transaxle.
- Before separating engine and transaxle, remove crankshaft position sensor (OBD) from the assembly.
- Always be extra careful not to damage edge of crankshaft position sensor (OBD), or ring gear teeth.



Removal


1. Remove engine undercover and hood.
2. Drain coolant from drain plug on water pipe, and radiator.
3. Remove vacuum hoses, fuel hoses, wires, harnesses and connectors and so on.
4. Remove front exhaust tube and drive shafts.
5. Remove drive belts.
6. Remove generator, compressor and power steering oil pump from engine.
7. Set a suitable transmission jack under transaxle. Hoist engine with engine slinger.
8. Remove RH and LH engine mountings and center member.
9. Remove front and rear engine mountings.



ENGINE REMOVAL

Removal (Cont'd)

10. Remove engine with transaxle as shown.




Installation

Installation is in the reverse order of removal.

CYLINDER BLOCK

SEC. 110-120



Refer to "Assembly".

- : Apply new engine oil.
- : Apply liquid gasket.
- : N-m (kg-m, in-lb)
- : N-m (kg-m, ft-lb)

- ① Piston rings
- ② Piston
- ③ Piston pin
- ④ Snap ring
- ⑤ Connecting rod
- ⑥ Connecting rod bearing
- ⑦ Oil jet

- ⑧ Crankshaft
- ⑨ Main bearing cap
- ⑩ Pilot bushing (M/T)
- ⑪ Rear plate (M/T)
- ⑫ Flywheel (M/T)
- ⑬ Dust cover (A/T)
- ⑭ Pilot converter (A/T)


- ⑮ Rear plate (A/T)
- ⑯ Drive plate (A/T)
- ⑰ Drive plate reinforcement
- ⑱ Main bearing
- ⑲ Rear oil seal
- ⑳ Rear oil seal retainer
- ㉑ Cylinder block

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CYLINDER BLOCK

CAUTION:


- When installing sliding parts such as bearings and pistons, apply new engine oil on the sliding surfaces.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When installing connecting rod nuts and main bearing cap bolts, apply new engine oil to threads and seating surfaces.
- Do not allow any magnetic materials to contact the ring gear teeth of flywheel or drive plate.



Disassembly

PISTON AND CRANKSHAFT

1. Place engine on a work stand.
2. Remove timing chains.
Refer to EM-19.





3. Remove pistons with connecting rods.

- To disassemble piston and connecting rod, first remove snap rings. Heat piston to 60 to 70°C (140 to 158°F) then use piston pin press to remove pin.

CAUTION:


- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- When replacing piston rings, if there is no punchmark, install with either side up.



4. Remove main bearing cap and crankshaft.

- Before removing main bearing cap, measure crankshaft end play. Refer to EM-52.
- Bolts should be loosened in two or three steps.


CYLINDER BLOCK




Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".
Standard diameter "dp":
20.987 - 20.999 mm (0.8263 - 0.8267 in)



2. Measure outer diameter of piston pin "Dp".
Standard diameter "Dp":
20.989 - 21.001 mm (0.8263 - 0.8268 in)
3. Calculate interference fit of piston pin to piston.
Dp - dp: -0.004 to 0 mm (-0.0002 to 0 in)
 If it exceeds the above value, replace piston assembly with pin.



PISTON RING SIDE CLEARANCE


Side clearance:

- Top ring**
0.040 - 0.080 mm (0.0016 - 0.0031 in)
- 2nd ring**
0.030 - 0.070 mm (0.0012 - 0.0028 in)

Max. limit of side clearance:

0.1 mm (0.004 in)

If out of specification, replace piston ring. If clearance exceeds maximum limit with new ring, replace piston.



PISTON RING END GAP

End gap:

- Top ring**
0.28 - 0.52 mm (0.0110 - 0.0205 in)
- 2nd ring**
0.45 - 0.69 mm (0.0177 - 0.0272 in)
- Oil ring**
0.20 - 0.69 mm (0.0079 - 0.0272 in)

Max. limit of ring gap:

1.0 mm (0.039 in)

If out of specification, replace piston ring. If gap exceeds maximum limit with new ring, rebore cylinder and use oversized piston and piston rings.

Refer to SDS (EM-60).

When replacing the piston, check the cylinder block surface for scratches or seizure.

If scratches or seizure is found, hone or replace the cylinder block.

CYLINDER BLOCK

Inspection (Cont'd)

CONNECTING ROD BEND AND TORSION


Bend:

Limit 0.15 mm (0.0059 in)
per 100 mm (3.94 in) length



Torsion:

Limit 0.30 mm (0.0118 in)
per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.



Measuring points



CYLINDER BLOCK DISTORTION

Clean upper surface of cylinder block.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder block surface.

Check along six positions shown in figure.

Block surface flatness:

Standard: Less than 0.03 mm (0.0012 in)

Limit: 0.1 mm (0.004 in)

If out of specification, resurface it.

Resurfacing limit:

The limit for cylinder block resurfacing is determined by the cylinder head resurfacing.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$

Nominal cylinder block height
from crankshaft center:

246.95 - 247.05 mm (9.7224 - 9.7264 in)

If necessary, replace cylinder block.

PISTON-TO-BORE CLEARANCE

- Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Standard inner diameter:

89.000 - 89.030 mm (3.5039 - 3.5051 in)

Wear limit:

0.2 mm (0.008 in)

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.


Out-of-round (X - Y) standard:

Less than 0.015 mm (0.0006 in)

Taper (A - B) standard:



Less than 0.01 mm (0.0004 in)

- Check for scratches and seizure. If seizure is found, hone it.



CYLINDER BLOCK

Inspection (Cont'd)



- If cylinder block and piston are replaced, match piston grade with grade number on cylinder block surface.

3. Measure piston skirt diameter.
Piston diameter "A":
Refer to SDS (EM-60).
Measuring point "a" (Distance from the top):
52 mm (2.05 in)
4. Check that piston-to-bore clearance is within specification.
Piston-to-bore clearance "B":
0.020 - 0.040 mm (0.0008 - 0.0016 in)

5. Determine piston oversize according to amount of cylinder wear.

Oversize pistons are available for service. Refer to SDS (EM-60).

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation: $D = A + B - C$ where,

D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

7. Install main bearing caps and tighten to the specified torque. This will prevent distortion of cylinder bores.

8. Cut cylinder bores.


- **When any cylinder needs boring, all other cylinders must also be bored.**

- **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**

- 9.hone cylinders to obtain specified piston-to-bore clearance.

10. Measure finished cylinder bore for out-of-round and taper.

- **Measurement should be done after cylinder bore cools down.**



CRANKSHAFT

- Check crankshaft main and pin journals for score, wear or cracks.

- With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):

Less than 0.005 mm (0.0002 in)



Taper (A - B):

Less than 0.002 mm (0.0001 in)

CYLINDER BLOCK

Inspection (Cont'd)

- Measure crankshaft runout.
Runout (Total indicator reading):
Less than 0.04 mm (0.0016 in)




BEARING CLEARANCE

- Use Method A or Method B. Method A is preferred because it is more accurate.

Method A (Using bore gauge & micrometer)

Main bearing


1. Set main bearings in their proper positions on cylinder block and main bearing cap.



2. Install main bearing cap to cylinder block.

Tighten all bolts in correct order in two or three stages. Refer to EM-52.

3. Measure inner diameter "A" of each main bearing.



4. Measure outer diameter "Dm" of each crankshaft main journal.

5. Calculate main bearing clearance.

Main bearing clearance = $A - Dm$

Standard:

0.020 - 0.047 mm (0.0008 - 0.0019 in)

Limit: 0.1 mm (0.004 in)


If it exceeds the limit, replace bearing.

If clearance cannot be adjusted using any standard bearing grade, grind crankshaft main journal and use undersized bearing.

When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.



"L": 0.1 mm (0.004 in)

Refer to EM-61 for grinding crankshaft and available service parts.



CYLINDER BLOCK

Inspection (Cont'd)



- If crankshaft is replaced, select thickness of main bearings as follows:
 - a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.

- b. Grade number of each crankshaft main journal is punched on crankshaft. These numbers are punched in either Arabic or Roman numerals.

- c. Select main bearing with suitable thickness according to the following table.

Main bearing grade number:


Crankshaft main journal grade number	Cylinder block main journal grade number		
	0	1	2
0	0	1	2
1	1	2	3
2	2	3	4

For example:

Cylinder block main journal grade number: 1

Crankshaft main journal grade number: 2

Main bearing grade number = 1 + 2 = 3



Connecting rod bearing (Big end)


1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of each bearing.

CYLINDER BLOCK

Inspection (Cont'd)




4. Measure outer diameter "Dp" of each crankshaft pin journal.
5. Calculate connecting rod bearing clearance.

Connecting rod bearing clearance = C - Dp
Standard: 0.010 - 0.035 mm (0.0004 - 0.0014 in)

Limit: 0.09 mm (0.0035 in)

If it exceeds the limit, replace bearing.

If clearance cannot be adjusted using any standard bearing grade, grind crankshaft pin journal and use undersized bearing. Refer to step 5 on EM-48 for fillet roll remarks and EM-61 for grinding crankshaft and available service parts.




- If crankshaft is replaced with a new one, select connecting rod bearings according to the following table.

Connecting rod bearing grade number:

These numbers are punched in either Arabic or Roman numerals.


Crankshaft pin journal grade number	Connecting rod bearing grade number
0	0
1	1
2	2



Method B (Using plastigage)


CAUTION:

- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- If incorrect bearing clearance exists, use a thicker or undersized main bearing to ensure specified clearance.



CONNECTING ROD BUSHING CLEARANCE (Small end)

1. Measure inner diameter "C" of bushing.



2. Measure outer diameter "Dp" of piston pin.
3. Calculate connecting rod bushing clearance.

C - Dp =
0.005 - 0.017 mm (0.0002 - 0.0007 in) (Standard)
0.023 mm (0.0009 in) (Limit)

If it exceeds the limit, replace connecting rod assembly and/or piston set with pin.

CYLINDER BLOCK

Inspection (Cont'd)

REPLACEMENT OF CONNECTING ROD BUSHING (Small end)



1. Drive in small end bushing until it is flush with end surface of rod.

Be sure to align the oil holes.

2. Ream the bushing so that clearance with piston pin is within specification.

Clearance between small end bushing and piston pin:

0.005 - 0.017 mm (0.0002 - 0.0007 in)



FLYWHEEL/DRIVE PLATE RUNOUT

Runout (Total indicator reading):

Flywheel (M/T model)


Less than 0.15 mm (0.0059 in)

Drive plate (A/T model)

Less than 0.15 mm (0.0059 in)

CAUTION:


Do not allow any magnetic materials to contact the ring gear teeth.



Assembly


PISTON

1. Install new snap ring on one side of piston pin hole.



2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.

- **Align the direction of piston and connecting rod.**
- **Numbers stamped on connecting rod and cap correspond to each cylinder.**
- **After assembly, make sure connecting rod swings smoothly.**




3. Set piston rings as shown.

CAUTION:


- **When piston rings are not being replaced, make sure that piston rings are mounted in their original positions.**
- **Install new piston rings either side up if there is no punchmark.**

CYLINDER BLOCK

Assembly (Cont'd)




- Align piston rings so that end gaps are positioned as shown.



CRANKSHAFT


- Set main bearings in their proper positions on cylinder block and main bearing cap.

- Confirm that correct main bearings are used. Refer to EM-47.



- Install crankshaft and main bearing cap and tighten bolts to the specified torque.

- Apply new engine oil to bolt threads and seat surfaces.
- Prior to tightening bearing cap bolts, shift crankshaft back and forth to properly seat the bearing cap.
- Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward sequentially.
- After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.



- Measure crankshaft end play.

Crankshaft end play:


Standard

0.05 - 0.18 mm (0.0020 - 0.0071 in)

Limit

0.3 mm (0.012 in)

If beyond the limit, replace bearing with a new one.








- Install connecting rod bearings in connecting rods and connecting rod caps.

- Confirm that correct bearings are used. Refer to EM-49.
- Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.

CYLINDER BLOCK

Assembly (Cont'd)



5. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - Be careful not to scratch cylinder wall with connecting rod.
 - Arrange so that front mark on piston head faces toward engine front.

- b. Install connecting rod bearing caps.

Apply new engine oil to threads and seat surfaces.

Tighten connecting rod bearing cap nuts in the following procedure:
 - (1) Tighten to 14 to 16 N-m (1.4 to 1.6 kg-m, 10 to 12 ft-lb).
 - (2) Turn all nuts 60 to 65 degrees clockwise. If an angle wrench is not available, mark all connecting rod bearing cap nuts on the side facing engine front. Then, turn each nut 60 to 65 degrees clockwise.

6. Measure connecting rod side clearance.

Connecting rod side clearance:

Standard
0.2 - 0.4 mm (0.008 - 0.016 in)

Limit
0.6 mm (0.024 in)

If beyond the limit, replace connecting rod and/or crankshaft.

REPLACING PILOT BUSHING

1. Remove pilot bushing (M/T) or pilot converter (A/T).
2. Install pilot bushing (M/T) or pilot converter (A/T).

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Cylinder arrangement	In-line 4	
Displacement	cm ³ (cu in)	2,389 (145.78)
Bore and stroke	mm (in)	89 x 96 (3.50 x 3.78)
Valve arrangement	DOHC	
Firing order	1-3-4-2	
Number of piston rings		
Compression	2	
Oil	1	
Number of main bearings	5	
Compression ratio	9.2	

COMPRESSION PRESSURE

Unit: kPa (kg/cm², psi)/300 rpm


Compression pressure	
Standard	1,226 (12.5, 178)
Minimum	1,030 (10.5, 149)
Differential limit between cylinders	98 (1.0, 14)

Inspection and Adjustment

CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Head surface distortion	Less than 0.03 (0.0012)	0.1 (0.004)




Nominal cylinder head height:
H = 126.3 - 126.5 (4.972 - 4.980)
Limit:
0.2 (0.008)*

SEM956C

* Total amount of cylinder head resurfacing plus cylinder block resurfacing

VALVE

Unit: mm (in)



SEM188

Valve head diameter "D"

Intake	36.5 - 36.7 (1.437 - 1.445)
Exhaust	31.2 - 31.4 (1.228 - 1.236)

Valve length "L"

Intake	101.02 - 101.62 (3.9772 - 4.0008)
Exhaust	98.52 - 99.72 (3.8787 - 3.9260)

Valve stem diameter "d"

Intake	6.965 - 6.980 (0.2742 - 0.2748)
Exhaust	6.945 - 6.960 (0.2734 - 0.2740)

Valve seat angle "α"

Intake	45°15' - 45°45'
Exhaust	

Valve margin "T"

Intake	0.95 - 1.25 (0.0374 - 0.0492)
Exhaust	1.15 - 1.45 (0.0453 - 0.0571)

Valve margin "T" limit

More than 0.5 (0.020)

Valve stem end surface grinding limit

Less than 0.2 (0.008)

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

VALVE SPRING

Free height	mm (in)	45.79 (1.8028)
Pressure N (kg, lb) at height mm (in)		471.7 (48.1, 106.1) at 26.06 (1.0260)
		421.31 (42.96, 94.73) at 26.06 (1.0260)
Out-of-square	mm (in)	Less than 2.0 (0.079)


VALVE LIFTER

Unit: mm (in)

Valve lifter outer diameter	33.960 - 33.975 (1.3370 - 1.3376)
Lifter guide inner diameter	34.000 - 34.021 (1.3386 - 1.3394)
Clearance between lifter and filter guide	0.025 - 0.061 (0.0010 - 0.0024)

VALVE GUIDE

Unit: mm (in)



		SEM301D	
		Standard	Service
Valve guide	Outer diameter	11.023 - 11.034 (0.4340 - 0.4344)	11.223 - 11.234 (0.4418 - 0.4423)
	Intake & Exhaust		
Valve guide	Inner diameter (Finished size)	7.000 - 7.018 (0.2756 - 0.2763)	7.000 - 7.018 (0.2756 - 0.2763)
	Intake & Exhaust		
Cylinder head valve guide hole diameter	Intake & Exhaust	10.975 - 10.996 (0.4321 - 0.4329)	11.175 - 11.196 (0.4400 - 0.4408)
	Intake & Exhaust		
Interference fit of valve guide		0.027 - 0.059 (0.0011 - 0.0023)	
		Standard	Limit
Stem to guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.08 (0.0031)
	Exhaust	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)
Valve deflection limit		0.2 (0.008)	
Projection length "L"		13.3 - 13.9 (0.524 - 0.547)	

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)


VALVE CLEARANCE ADJUSTMENT

Unit: mm (in)

Valve clearance (Hot)	
Intake	0.31 - 0.39 (0.012 - 0.015)
Exhaust	0.33 - 0.41 (0.013 - 0.016)

Available shims

Thickness mm (in)	Identification mark
1.96 (0.0772)	196
1.98 (0.0780)	198
2.00 (0.0787)	200
2.02 (0.0795)	202
2.04 (0.0803)	204
2.06 (0.0811)	206
2.08 (0.0819)	208
2.10 (0.0827)	210
2.12 (0.0835)	212
2.14 (0.0843)	214
2.16 (0.0850)	216
2.18 (0.0858)	218
2.20 (0.0866)	220
2.22 (0.0874)	222
2.24 (0.0882)	224
2.26 (0.0890)	226
2.28 (0.0898)	228
2.30 (0.0906)	230
2.32 (0.0913)	232
2.34 (0.0921)	234
2.36 (0.0929)	236
2.38 (0.0937)	238
2.40 (0.0945)	240
2.42 (0.0953)	242
2.44 (0.0961)	244
2.46 (0.0969)	246
2.48 (0.0976)	248
2.50 (0.0984)	250
2.52 (0.0992)	252
2.54 (0.1000)	254
2.56 (0.1008)	256
2.58 (0.1016)	258
2.60 (0.1024)	260
2.62 (0.1031)	262
2.64 (0.1039)	264
2.66 (0.1047)	266
2.68 (0.1055)	268




SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

VALVE SEAT

Unit: mm (in)



SEM179E


		Standard	Service
Cylinder head seat recess diameter (D)	In.	37.500 - 37.516 (1.4764 - 1.4770)	38.000 - 38.016 (1.4961 - 1.4967)
	Ex.	32.200 - 32.216 (1.2677 - 1.2683)	32.700 - 32.716 (1.2874 - 1.2880)
Valve seat interference fit	In.	0.064 - 0.096 (0.0025 - 0.0038)	
	Ex.	0.064 - 0.096 (0.0025 - 0.0038)	
Valve seat outer diameter (d)	In.	37.580 - 37.596 (1.4795 - 1.4802)	38.080 - 38.096 (1.4992 - 1.4998)
	Ex.	32.280 - 32.296 (1.2709 - 1.2715)	32.780 - 32.796 (1.2905 - 1.2912)
Depth (H)	In.	6.1 - 6.3 (0.240 - 0.248)	
	Ex.	6.1 - 6.3 (0.240 - 0.248)	
Height (h ₁)		5.9 - 6.0 (0.232 - 0.236)	
Height (h ₂)	In.	0.44 - 0.64 (0.0173 - 0.0252)	
	Ex.	0.53 - 0.73 (0.0209 - 0.0287)	

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CYLINDER BLOCK

Unit: mm (in)



SEM447C

			Standard	Limit
Distortion			Less than 0.03 (0.0012)	0.1 (0.004)
Cylinder bore	Inner diameter	Grade 1	89.000 - 89.010 (3.5039 - 3.5043)	0.2 (0.008)
		Grade 2	89.010 - 89.020 (3.5043 - 3.5047)	
		Grade 3	89.020 - 89.030 (3.5047 - 3.5051)	
	Out-of-round (X - Y)		Less than 0.015 (0.0006)	—
Taper (A - B)		Less than 0.010 (0.0004)	—	
Difference in inner diameter between cylinders			Less than 0.03 (0.0012)	0.2 (0.008)
Nominal cylinder block height : H (From crankshaft center)			246.95 - 247.05 (9.7224 - 9.7264)	0.2 (0.008)*



* Total amount of cylinder head resurfacing plus cylinder block resurfacing

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)



SEM568A

EM120

		Standard	Limit
Cam height (A)	Intake	42.415 - 42.605 (1.6699 - 1.6774)	—
	Exhaust	42.815 - 43.005 (1.6856 - 1.6931) 42.415 - 42.605 (1.6699 - 1.6774)*2	—
Wear limit of cam height		—	0.2 (0.008)
Camshaft journal to bearing clearance		0.045 - 0.090 (0.0018 - 0.0035)	0.12 (0.0047)
Inner diameter of camshaft bearing	#1, #6 journal	24.000 - 24.025 (0.9449 - 0.9459)	—
	#2 to #5 journal	28.000 - 28.025 (1.1024 - 1.1033)	—
Outer diameter of camshaft journal (D)	#1, #6 journal	23.935 - 23.955 (0.9423 - 0.9431)	—
	#2 to #5 journal	27.935 - 27.955 (1.0998 - 1.1006)	—
Camshaft runout*1		Less than 0.02 (0.0008)	0.04 (0.0016)
Camshaft end play		0.07 - 0.15 (0.0028 - 0.0059)	0.20 (0.0079)
Valve timing (Degree on crankshaft)	a	248 232*2	—
	b	240	—
	c	-1	—
	d	61	—
	e	4	—
	f	64 48*2	—

*1: Total indicator reading

*2: For California


SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

PISTON, PISTON RING AND PISTON PIN

CONNECTING ROD


Unit: mm (in)



Unit: mm (in)

SEM444C

Piston skirt diameter (A)	Standard	Grade No. 1	88.970 - 88.980 (3.5027 - 3.5031)
		Grade No. 2	88.980 - 88.990 (3.5031 - 3.5035)
Grade No. 3	88.990 - 89.000 (3.5035 - 3.5039)		
Service (Oversize)	0.5 (0.020)	89.470 - 89.500 (3.5224 - 3.5236)	
	1.0 (0.039)	89.970 - 90.000 (3.5421 - 3.5433)	
Dimension (a)		Approximately 52 (2.05)	
Piston pin hole diameter (d)		20.987 - 20.999 (0.8263 - 0.8267)	
Piston-to-cylinder bore clearance		0.020 - 0.040 (0.0008 - 0.0016)	



SEM180E

	Standard	Limit
Center distance (S)	164.95 - 165.05 (6.4941 - 6.4980)	—
Bend [per 100 mm (3.94 in)]	—	0.15 (0.0059)
Torsion [per 100 mm (3.94 in)]	—	0.30 (0.0118)
Piston pin bushing inner diameter (d)*	21.000 - 21.012 (0.8268 - 0.8272)	—
Connecting rod big end inner diameter (D)*	53.000 - 53.013 (2.0866 - 2.0871)	—
Side clearance	0.2 - 0.4 (0.008 - 0.016)	0.6 (0.024)

* Without bearing

Piston pin

Unit: mm (in)

	Standard	Limit
Piston pin outer diameter	20.989 - 21.001 (0.8263 - 0.8268)	—
Interference fit of piston pin to piston pin hole	-0.004 to 0 (-0.0002 to 0)	—
Piston pin to connecting rod bearing clearance	0.005 - 0.017 (0.0002 - 0.0007)	0.023 (0.0009)

Piston ring

Unit: mm (in)


		Standard	Limit
Side clearance	Top	0.040 - 0.080 (0.0016 - 0.0031)	0.1 (0.004)
	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.1 (0.004)
Ring gap	Top	0.28 - 0.52 (0.0110 - 0.0205)	1.0 (0.039)
	2nd	0.45 - 0.69 (0.0177 - 0.0272)	1.0 (0.039)
	Oil (rail ring)	0.20 - 0.69 (0.0079 - 0.0272)	1.0 (0.039)

SERVICE DATA AND SPECIFICATIONS (SDS)


Inspection and Adjustment (Cont'd)

CRANKSHAFT

Unit: mm (in)



Out-of-round (X - Y)
Taper (A - B)



SEM394

EM715

Main journal diameter (Dm)	Grade	No. 0	59.967 - 59.975 (2.3609 - 2.3612)	
		No. 1	59.959 - 59.967 (2.3606 - 2.3609)	
		No. 2	59.951 - 59.959 (2.3603 - 2.3606)	
Pin journal diameter (Dp)	Grade	No. 0	49.968 - 49.974 (1.9672 - 1.9675)	
		No. 1	49.962 - 49.968 (1.9670 - 1.9672)	
		No. 2	49.956 - 49.962 (1.9668 - 1.9670)	
Center distance (r)		47.97 - 48.05 (1.8886 - 1.8917)		
		Standard	Limit	
Taper of journal and pin (A - B)		Less than 0.002 (0.0001)	—	
Out-of-round of journal and pin (X - Y)		Less than 0.005 (0.0002)	—	
Runout [TIR]*		Less than 0.04 (0.0016)	—	
Free end play		0.05 - 0.18 (0.0020 - 0.0071)	0.3 (0.012)	
Fillet roll		More than 0.1 (0.004)		

* Total indicator reading

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

BEARING CLEARANCE

Unit: mm (in)

	Standard	Limit
Main bearing clearance	0.020 - 0.047 (0.0008 - 0.0019)	0.1 (0.004)
Connecting rod bearing clearance	0.010 - 0.035 (0.0004 - 0.0014)	0.09 (0.0035)

AVAILABLE MAIN BEARING

Standard

Unit: mm (in)

Grade number	Thickness	Identification color
0	1.821 - 1.825 (0.0717 - 0.0719)	Black
1	1.825 - 1.829 (0.0719 - 0.0720)	Brown
2	1.829 - 1.833 (0.0720 - 0.0722)	Green
3	1.833 - 1.837 (0.0722 - 0.0723)	Yellow
4	1.837 - 1.841 (0.0723 - 0.0725)	Blue

Undersize (service)

Unit: mm (in)

	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	1.952 - 1.960 (0.0769 - 0.0772)	Grind so that bearing clearance is the specified value.

AVAILABLE CONNECTING ROD BEARING

Standard

Unit: mm (in)

Grade number	Thickness	Identification color
0	1.505 - 1.508 (0.0593 - 0.0594)	—
1	1.508 - 1.511 (0.0594 - 0.0595)	Brown
2	1.511 - 1.514 (0.0595 - 0.0596)	Green

Undersize (service)

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.08 (0.0031)	1.540 - 1.548 (0.0606 - 0.0609)	Grind so that bearing clearance is the specified value.
0.12 (0.0047)	1.560 - 1.568 (0.0614 - 0.0617)	
0.25 (0.0098)	1.625 - 1.633 (0.0640 - 0.0643)	

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Camshaft sprocket runout [TIR]*	Less than 0.12 (0.0047)
Flywheel runout [TIR]*	Less than 0.15 (0.0059)
Drive plate runout [TIR]*	Less than 0.15 (0.0059)

* Total indicator reading