

SECTION **INL**

INTERIOR LIGHTING SYSTEM

BASIC INSPECTION	3	STEP LAMP CIRCUIT	18
DIAGNOSIS AND REPAIR WORKFLOW	3	Description	18
Work Flow	3	Component Function Check	18
Diagnosis Procedure	18		
FUNCTION DIAGNOSIS	6	TRUNK ROOM LAMP CIRCUIT	20
INTERIOR ROOM LAMP CONTROL SYSTEM 6	Description	20
System Diagram	6	Component Function Check	20
System Description	6	Diagnosis Procedure	20
Component Parts Location	6		
Component Description	7		
ILLUMINATION CONTROL SYSTEM	9	PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	22
System Diagram	9	Description	22
System Description	9	Component Function Check	22
Component Parts Location	9	Diagnosis Procedure	22
Component Description	10		
DIAGNOSIS SYSTEM (BCM)	11	INTERIOR ROOM LAMP CONTROL SYSTEM	24
CONSULT-III Function	11	Wiring Diagram	24
COMPONENT DIAGNOSIS	13		
POWER SUPPLY AND GROUND CIRCUIT	13	ILLUMINATION	35
BCM	13	Wiring Diagram	35
BCM : Inspection Procedure	13		
BCM : Special Repair Requirement	13		
INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT	14	ECU DIAGNOSIS	48
Description	14	BCM (BODY CONTROL MODULE)	48
Component Function Check	14	Description	48
Diagnosis Procedure	14		
INTERIOR ROOM LAMP CONTROL CIRCUIT 16	SYMPTOM DIAGNOSIS	49
Description	16	INTERIOR LIGHTING SYSTEM SYMPTOMS ...49	
Component Function Check	16	Symptom Table	49
Diagnosis Procedure	16		
PRECAUTION	50		
PRECAUTIONS	50		
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	50		
General precautions for service operations	50		
ON-VEHICLE REPAIR	51		
INTERIOR ROOM LAMP	51		

A
B
C
D
E

F
G
H
I
J

INL

M
N
O

P

Removal and Installation	51	SERVICE DATA AND SPECIFICATIONS (SDS)	55
ILLUMINATION	54	SERVICE DATA AND SPECIFICATIONS (SDS)	55
Removal and Installation	54	Bulb Specifications	55

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:0000000000994333

OVERALL SEQUENCE



JPLIA0089GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2..

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3..

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4..

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5..

NO >> GO TO 6..

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9..

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7..

NO >> GO TO 8..

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9..

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9..

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 11..

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Verified that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 5..
NO >> GO TO 11..

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END
NO >> GO TO 3..

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram



System Description

INFOID:0000000000994335

OUTLINE


- Interior room lamps* are controlled by interior room lamp timer control function of BCM.
*:Room map lamp and personal lamp (when lamp switch is in DOOR position).
- Trunk room lamp is controlled by trunk room lamp control function of BCM.
- Step lamp is controlled by step lamp control function of BCM.

Component Parts Location

INFOID:0000000000994336

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >



ALLIA0051GB

1. BCM M17, M18, M19, M20, M21 (view with instrument panel removed)
2. Front door switch LH, B8 and RH, B18
3. Rear door switch LH, B108 and RH, B116
4. Trunk lamp switch and trunk release solenoid B28
5. Main power window and door lock/unlock switch D7 and D8
6. Key slot M40

INL

INFOID:0000000000994337

Component Description

M

N

O

P

SWITCH OPERATION

When a door is opened, the door switch closes to send a ground signal to the BCM. When the trunk is opened, the trunk lamp switch and trunk release solenoid closes sending a ground signal to the BCM.

ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in DOOR position and when all conditions below are met, BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with Intelligent Key, main power window and door lock/unlock switch, or front door lock assembly (key cylinder switch)].
 - When a door opens → closes and the Intelligent Key is not inserted in the key slot.
- Timer control is canceled under the following conditions.
- When the front door LH is locked [with Intelligent Key, main power window and door lock/unlock switch, or front door lock assembly (key cylinder switch)].
 - A door is opened (door switch turns ON).
 - Intelligent Key is inserted into the key slot.

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

Interior lamp operational settings can be changed with the function setting of CONSULT-III.

INTERIOR LAMP BATTERY SAVER CONTROL

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 30 minutes after the ignition switch is turned OFF.

The BCM controls the interior lamps listed below

- Step lamp
- Front room/map lamp
- Personal lamp rear
- Vanity mirror lamp
- Trunk room lamp

After the battery saver system turns the lamps OFF, the lamps will illuminate again when

- a signal is received from an Intelligent Key or main power window and door lock/unlock switch, or when the front door LH lock assembly (key cylinder switch) is locked or unlocked
- a door is opened or closed
- the Intelligent Key is removed from or inserted into the key slot.


The Interior lamp battery saver control time period can be changed with the function setting of CONSULT-III.

ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

ILLUMINATION CONTROL SYSTEM

System Diagram




System Description

The illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input requesting the illumination lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the illumination lamps, which then illuminate.

Component Parts Location

INFOID:0000000000994340



ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

1. IPDM E/R E17, E18
2. BCM M16, M17, M18, M19 (view with instrument panel removed)
3. Combination Switch M28
4. Combination Meter M24

Component Description

INFOID:000000000994341

ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input requesting the illumination lamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the tail lamp relay coil which, when energized, directs power

BATTERY SAVER CONTROL

When the lighting switch (combination switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 30 minutes unless the lighting switch position is changed. If the lighting switch position is changed, then the illumination lamps are turned off after a 30 second delay. When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

CONSULT-III Function

INFOID:0000000000994342

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

WORK SUPPORT

Display Item List

Service item	Setting item	Setting
ROOM LAMP TIMER SET	MODE 2	7.5 sec.
	MODE 3*	15 sec.
	MODE 4	30 sec.
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function
	OFF	Without the interior room lamp timer function
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.
	MODE 2*	1 sec.
	MODE 3	2 sec.
	MODE 4	3 sec.
	MODE 5	0 sec.
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.
	MODE 2	1 sec.
	MODE 3	2 sec.
	MODE 4*	3 sec.
	MODE 5	0 sec.
ROOM LAMP TIMER LOGIC SET	ON* (MODE 1)	Interior room lamp timer activates with synchronizing all doors.
	OFF (MODE 2)	Interior room lamp timer activates with synchronizing the driver door only.

* : Initial setting

DATA MONITOR

Display Item List

Monitor item		Contents
IGN ON SW	"ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
KEY ON SW	"ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key switch signal.
DOOR SW-DR	"ON/OFF"	Displays status of the front door LH as judged from the front door switch LH signal. (Door is open: ON/Door is closed: OFF)

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

Monitor item		Contents
DOOR SW-AS	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from front door switch RH signal.
DOOR SW-RR	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch RH signal.
DOOR SW-RL	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch LH signal.
BACK DOOR SW	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from back door switch signal.
KEY CYL LK-SW	"ON/OFF"	Displays "Door locked (ON)" status, determined from key cylinder lock switch in front door LH.
KEY CYL UN-SW	"ON/OFF"	Displays "Door unlocked (OFF)" status, determined from key cylinder lock switch in front door LH.
CDL LOCK SW	"ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF)" status, determined from locking detection switch in front door LH.
CDL UNLOCK SW	"ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in front door RH.
KEYLESS LOCK	"ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
KEYLESS UNLOCK	"ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.

ACTIVE TEST

Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition keyhole illumination can be operated by ON-OFF operation.
STEP LAMP TEST	Step lamp can be operated by ON-OFF operation.
LUGGAGE LAMP TEST	Trunk room lamp can be operated by ON-OFF operation.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Inspection Procedure

INFOID:000000000994343

POWER SUPPLY AND GROUND CIRCUIT INSPECTION FOR BCM

For information about power and ground circuit inspection for the BCM, refer to [BCS-33, "Diagnosis Procedure".](#)

BCM : Special Repair Requirement

INFOID:000000000994344

1. REQUIRED WORK WHEN REPLACING BCM

Initialize IVIS with CONSULT-III. For the details of initialization, refer to CONSULT-III operation manual NATS-IVIS/NVIS.

A

B

C

D

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

Description

INFOID:0000000000994345

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

Component Function Check

INFOID:0000000000994346

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

(B) CONSULT-III ACTIVE TEST

1. Turn ignition switch ON.
2. Turn each interior room lamp ON.
 - Map lamp
 - Personal lamp
 - Step lamp
 - Vanity mirror lamp
 - Trunk room lamp
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF.

OFF : Interior room lamp OFF

ON : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-14, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000000994347

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

(B) CONSULT-III ACTIVE TEST

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. With operating the test item, check voltage between BCM harness connector and ground.

Terminals		Test item	Voltage
(+)	(-)		
BCM		Ground	BATTERY SAVER
Connector	Terminal		OFF
M17	4		0 V
			ON
			Battery voltage

Is the measurement value normal?

YES >> GO TO 2..

NO >> Replace BCM.

2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - BCM M17
 - Map lamp
 - Personal lamp
 - Vanity mirror lamp (LH)
 - Vanity mirror lamp (RH)
 - Trunk room lamp
 - Step lamp (LH)
 - Step lamp (RH)

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

3. Check continuity between BCM harness connector and each interior room lamp harness connector.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M17	4	Front room/map lamp (LH)	R13	1
		Front room/map lamp (RH)	R14	1
		Personal lamp rear (LH)	R12	1
		Personal lamp rear (RH)	R11	1
		Vanity mirror lamp (LH)	R3	2
		Vanity mirror lamp (RH)	R4	2
		Trunk room lamp	B36	1
		Step lamp (LH)	D11	1
		Step lamp (RH)	D109	1

Does continuity exist?

YES >> GO TO 3..

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	4		No

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check that each interior room lamp has no internal short circuit.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000000994348

Controls each interior room lamp (ground side) by PWM signal.

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:0000000000994349

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb
- Personal lamp bulb

1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

(H)CONSULT-III ACTIVE TEST

1. Switch the map lamp switch to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

ON : Interior room lamp gradual brightening

OFF : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-16, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000000994350

1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove all the bulbs of map lamp and personal lamp.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		INT LAMP	
M17	19		ON	Yes
			OFF	No

Is the measurement value normal?

YES >> GO TO 2..

Fixed ON>>GO TO 3..

Fixed OFF>>Replace BCM.

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector, map lamp harness connector, and personal lamp harness connector.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

BCM		Map lamp/personal lamp			Continuity
Connector	Terminal	Connector		Terminal	
M17	19	Front room/map lamp (LH)	R13	8	Yes
		Front room/map lamp (RH)	R14	4	
		Personal lamp rear (LH)	R12	2	
		Personal lamp rear (RH)	R11	2	

Does continuity exist?

YES >> Replace the map lamp or the personal lamp.

NO >> Repair the harnesses or connectors.

3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, map lamp connector and personal lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	19		No

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

STEP LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000000994351

Controls the step lamp (ground side) to turn the step lamp ON and OFF.

Component Function Check

INFOID:0000000000994352

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Step lamp bulb

1.CHECK STEP LAMP OPRATION

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test items, check that step lamp turns ON/OFF.

ON : Step lamp ON

OFF : Step lamp OFF

Does the step lamp turn ON/OFF?

YES >> Step lamp circuit is operating.

NO >> Refer to [INL-18, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000000994353

1.CHECK STEP LAMP OUTPUT

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove the step lamp bulbs.
3. Turn ignition switch ON.
4. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		STEP LAMP TEST	
M17	7		ON	Yes
			OFF	No

Is the measurement value normal?

YES >> GO TO 2..

Fixed ON>>GO TO 3..

Fixed OFF>>Replace BCM.

2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and step lamp connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M17	7	LH	D11	2	Yes
		RH	D109	2	

STEP LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

Does continuity exist?

YES >> Replace step lamp.

NO >> Repair harnesses or connectors.

3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	7		No

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

TRUNK ROOM LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

TRUNK ROOM LAMP CIRCUIT

Description

INFOID:0000000000994354

Controls the trunk room lamp (ground side) to turn the trunk room lamp ON and OFF.

Component Function Check

INFOID:0000000000994355

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Trunk room lamp bulb

1. CHECK TRUNK ROOM LAMP OPRATION

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch ON.
2. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that trunk room lamp turns ON/OFF.

ON : Trunk room lamp ON

OFF : Trunk room lamp OFF

Does the trunk room lamp turn ON/OFF?

YES >> Trunk room lamp circuit is normal.

NO >> Refer to [INL-18, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000000994356

1. CHECK TRUNK ROOM LAMP OUTPUT

(H)CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove trunk room lamp bulb.
3. Turn ignition switch ON.
4. Select "LUGGAGE LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		LUGGAGE LAMP TEST	
M111	110		ON	Yes
			OFF	No

Is the measurement value normal?

YES >> GO TO 2..

Fixed ON>>GO TO 3..

Fixed OFF>>Replace BCM.

2. CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and trunk room lamp harness connector.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M111	110	B36	2	Yes

Does continuity exist?

YES >> Replace trunk room lamp.

TRUNK ROOM LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

NO >> Repair harnesses or connectors.

3.CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and trunk room lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M111	110		No

Does continuity exist?

YES >> Repair harnesses or connectors.

NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< COMPONENT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Description

INFOID:0000000000994357

Provides the power supply and the ground to control the push-button ignition switch illumination.

Component Function Check

INFOID:0000000000994358

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF

ON : Push-button ignition switch illumination ON

OFF : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-22, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000000994359

1.CHECK ILLUMINATION CONTROL SWITCHING OPERATION

1. Turn the ignition switch ON.
2. With operating the lighting switch, check that the push-button ignition switch illumination turns ON/OFF

Condition	Push-button ignition switch illumination
• Ignition switch ON • Lighting switch 1ST	ON
• Ignition switch OFF • Lighting switch OFF • Driver door LOCK	OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> GO TO 2..

NO >> GO TO 3..

2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	14	M38	2	Yes

Does the continuity exist?

YES >> Replace BCM.

NO >> Repair the harness or the connector.

3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

(CONSULT-III ACTIVE TEST

1. Turn the ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLGENT KEY) active test item.
3. With operating the test item, check voltage between BCM harness connector and ground.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< COMPONENT DIAGNOSIS >

Terminals		Test item	Voltage
(+)	(-)		
BCM		Ground	ENGINE SW ILLUMI
Connector	Terminal		ON 5 V
M18	41		OFF 0 V

Is the measurement value normal?

- YES >> GO TO 4..
NO >> GO TO 5..

4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	41	M38	3	Yes

Does the continuity exist?

- YES >> Replace push-button ignition switch.
NO >> Repair the harness or the connector.

5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector and the push-button ignition switch connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Ground	Continuity
Connector	Terminal		
M18	41		No

Does the continuity exist?

- YES >> Repair the harness or the connector.
NO >> Replace BCM.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram



INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >




ALJWA0005GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


INTERIOR ROOM LAMP CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	—

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4N	G/Y	—
7N	Y/R	—


Terminal No.	Color of Wire	Signal Name
4N	G/Y	—
7N	Y/R	—

Terminal No.	Color of Wire	Signal Name
8	P/W	—
9	B	—

Terminal No.	Color of Wire	Signal Name
10	Y	—
11	P/W	—

Terminal No.	Color of Wire	Signal Name
15	B	—

Terminal No.	Color of Wire	Signal Name
17J	SB	—
22J	R/B	—
23J	P/W	—
25J	Y/G	—
26J	V/W	—






Terminal No.	Color of Wire	Signal Name
4N	G/Y	—
7N	Y/R	—

ALJIA0038GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	R/B	—
11	R/W	—

Terminal No.	Color of Wire	Signal Name
8	B	—
9	—	—

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16

Terminal No.	Color of Wire	Signal Name
2	L/B	—
4	P/W	—
9	L/R	—
10	Y/G	—
13	R/W	—

Terminal No.	Color of Wire	Signal Name
1	3	—
2	—	—

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12

Terminal No.	Color of Wire	Signal Name
4	P/W	ROOM_LAMP_BAT_SAVER
7	R/W	STEP_LAMP_OUTPUT
11	Y/R	BAT_BCM_FUSE
13	B	GND1
19	Y	ROOM_LAMP_OUTPUT

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
ALJIA0039GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
32	R/B	AS_DOOR_SW
34	L/R	DOOR_KEYC_UNLOCK_SW
40	Y/G	PW_K-LINE
56	L/B	DOOR_KEYC_LOCK_SW
58	SB	DR_DOOR_SW




Terminal No.	Color of Wire	Signal Name
78	P	CAN-L
79	L	CAN-H
80	R/L	FOB SLOT ILLUMINATION



79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60
93	92	91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	74
58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39
59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40


Terminal No.	Color of Wire	Signal Name
110	V/W	TRUNK LAMP_OUTPUT



Terminal No.	Color of Wire	Signal Name
110	V/W	TRUNK LAMP_OUTPUT
111	W	KEY SLOT



Terminal No.	Color of Wire	Signal Name
110	V/W	KEY SLOT
111	W	JOINT CONNECTOR-M02



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12

Terminal No.	Color of Wire	Signal Name
110	V/W	KEY SLOT
111	W	JOINT CONNECTOR-M02



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name

<tbl_r cells="3"


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


A B C D E F G H I J K L M N O P

Terminal No.	Color of Wire	Signal Name
17J	SB	—
22J	R/B	—
23J	P	—
25J	Y/G	—
26J	V/W	—

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	—



Connector No.	B28
Connector Name	TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID
Connector Color	WHITE



Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y/G	—
2	B	—



Terminal No.	Color of Wire	Signal Name
2	R/B	DOOR SW(RL)

ALJIA0041GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	B36
Connector Name	TRUNK ROOM LAMP
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	—
2	V/W	—

Terminal No.	Color of Wire	Signal Name
10	R/B	—
11	R/W	—

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—

Terminal No.	Color of Wire	Signal Name
2	R/B	DOOR SW (AS)
—	—	—



Terminal No.	Color of Wire	Signal Name
1	B	—
2	P	DOOR SW (AS)

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	R/W	DOOR SW (RR)
8	P	—
9	W	—
10	W	—
11	W	—
15	B	—




INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	R9
Connector Name	VANITY MIRROR LAMP RH
Connector Color	WHITE



Connector No.	R10
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	R9
Connector Name	VANITY MIRROR LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND	1	W	—
2	P	ROOM_LAMP_BAT_SAVER	2	W	—
3	W	—	3	W	—
4	—	—	4	W	—
5	—	—	5	W	—
6	—	—	6	W	—
7	—	—	7	W	—


Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND	1	W	—
2	P	ROOM_LAMP_BAT_SAVER	2	W	—
3	W	—	3	W	—
4	—	—	4	W	—
5	—	—	5	W	—
6	—	—	6	W	—
7	—	—	7	W	—

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	—	1	W	—
2	W	—	2	W	—
3	W	—	3	W	—
4	—	—	4	W	—
5	W	—	5	W	—
6	W	—	6	W	—
7	W	—	7	W	—
8	—	—	8	R	—


Connector No.	R14
Connector Name	PERSONAL LAMP REAR LH
Connector Color	—




Connector No.	R13
Connector Name	FRONT ROOM/MAP LAMP LH
Connector Color	—



Connector No.	R12
Connector Name	PERSONAL LAMP REAR RH
Connector Color	—



Connector No.	R14
Connector Name	FRONT ROOM/MAP LAMP RH
Connector Color	—



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	—	1	W	—
2	W	—	2	W	—
3	W	—	3	W	—
4	—	—	4	R	—
5	W	—	5	W	—
6	W	—	6	W	—
7	W	—	7	W	—
8	—	—	8	R	—

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	—	1	W	—
2	W	—	2	W	—
3	W	—	3	W	—
4	—	—	4	R	—
5	W	—	5	W	—
6	W	—	6	W	—
7	W	—	7	W	—
8	—	—	8	R	—


ALJIA0043GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	R15
Connector Name	FRONT ROOM/MAP LAMP SWITCH
Connector Color	—



Connector No.	R50
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	R51
Connector Name	FRONT ROOM/MAP LAMP
Connector Color	—



Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	R	—
5	W	—
6	W	—
7	W	—
8	R	—

Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	R	—
5	W	—
6	W	—
7	W	—
8	R	—

Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	W	—
5	W	—
6	W	—
7	W	—
8	R	—

Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	W	—
5	W	—
6	W	—
7	W	—
8	R	—

Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	W	—
5	W	—
6	W	—
7	W	—
8	R	—

Terminal No.	Color of Wire	Signal Name
1	W	—
2	W	—
3	W	—
4	W	—
5	W	—
6	W	—
7	W	—
8	R	—


ALJIA0044GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< COMPONENT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z


Connector No.	D7 (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)	Connector No.	D7 (WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM)
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH	Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE	Connector Color	WHITE



Connector No.	D2	Connector No.	D7 (WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM)
Connector Name	WIRE TO WIRE	Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE	Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	—
4	P/W	—
9	L/R	—
10	Y/G	—
13	R/W	—



Terminal No.	Color of Wire	Signal Name
4	L/B	LOCK
6	L/R	UNLOCK
14	Y/G	COM

Terminal No.	Color of Wire	Signal Name
4	L/B	LOCK
6	L/R	UNLOCK
14	Y/G	COM
17	—	—
18	—	—
19	—	—

Terminal No.	Color of Wire	Signal Name
6	GRR	UNLOCK

Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—
3	—	—
4	—	—
5	—	—
6	—	—

Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—
3	—	—
4	—	—
5	—	—
6	—	—

Terminal No.	Color of Wire	Signal Name
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW
6	L/B	DOOR_KEY/C_LOCK_SW

Terminal No.	Color of Wire	Signal Name
1	P/N	—
2	R/M	—

ALJIA0045GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D109
Connector Name	STEP LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
6	P/W	—	1	P/W	—
11	R/W	—	2	R/W	—

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
6	P/W	—	1	P/W	—
11	R/W	—	2	R/W	—

ALJIA0046GB


ILLUMINATION

< COMPONENT DIAGNOSIS >

ILLUMINATION


Wiring Diagram

INFOID:0000000000994361



ILLUMINATION

< COMPONENT DIAGNOSIS >




ALJWA0007GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

◆ : WITH CVT

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



INL


ALJWA0008GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

ILLUMINATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8G	P	—
15G	L	—
82G	W/B	—

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1N	W/L	—
7N	Y/R	—
		—

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12M	P	—
		—
		—



Terminal No.	Color of Wire	Signal Name
12M	P	—
		—
		—


ALJIA0047GB

ILLUMINATION

< COMPONENT DIAGNOSIS >


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17J	SB	—

Terminal No.	Color of Wire	Signal Name
17J	SB	—



Terminal No.	Color of Wire	Signal Name
17J	SB	—
14	R/Y	—

Terminal No.	Color of Wire	Signal Name
5	R/L	—
14	R/Y	—

Terminal No.	Color of Wire	Signal Name
5	R/L	—
14	R/Y	—

Terminal No.	Color of Wire	Signal Name
11	Y/R	BAT_BCM_FUSE
13	B	GND1

Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L
14	R/Y	LOW_SIDE_PUSH_L/E_D_OUTPUT


Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L
14	R/Y	LOW_SIDE_PUSH_L/E_D_OUTPUT

ALJIA0048GB



ILLUMINATION

< COMPONENT DIAGNOSIS >

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Connector No.	M19
Connector Name	BCM (Body Control Module)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W/L	BATT
2	O	IGN
3	B	GND
4	B	GND
5	R/Y	ILL_OUTPUT
9	GRW	SWILL_PWR
10	O/L	GND(SATELLITE SW)
21	L	CAN-H
22	P	CAN-L
23	B	GND

Terminal No.	Color of Wire	Signal Name
2	G/Y	OUTPUT_4
5	LGR	OUTPUT_3
7	R/G	INPUT_3
8	LGB	OUTPUT_5
9	R/B	INPUT_2
10	P/B	INPUT_4
11	R/N	INPUT_1
12	L/N	OUTPUT_1
13	R/Y	INPUT_5
14	G/B	OUTPUT_2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Connector No.	M25
Connector Name	METER MODE SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	O/L	GND(SATELLITE SW)
7	GRW	SWILL_PWR

ALJIA0049GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

K


M

Z

O

P

Connector No.	M29	Connector No.	M37
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)	Connector Name	FRONT AIR CONTROL
Connector Color	YELLOW	Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
23	R/L	TAIL/ILL_RLY

Terminal No.	Color of Wire	Signal Name
26	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
16	R/L	ILL_+
36	R/Y	ILL_-

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	17
16	17	18
17	18	19
18	19	20

	
--	--

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	17
16	17	18

	
--	--

Terminal No.	Color of Wire	Signal Name
8	R/Y	ILL_CONT_OUT
9	R/L	TAIL/ILL_RLY



Terminal No.	Color of Wire	Signal Name
13	R/Y	ILL_-
14	R/L	ILL_+

ALJIA0050GB


ILLUMINATION

< COMPONENT DIAGNOSIS >

Connector No.	M43 (BOSE AUDIO WITHOUT NAVIGATION SYSTEM)
Connector Name	AUDIO UNIT
Connector Color	WHITE



Connector No.	M47
Connector Name	AV CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	—	—
9	—	—

Terminal No.	Color of Wire	Signal Name
9	R/L	ILL
18	R/Y	ILL_CONT


Terminal No.	Color of Wire	Signal Name
3	R/L	TAIL/ILL_RLY
4	R/Y	ILL_CONT_OUT

Connector No.	M65
Connector Name	A/T DEVICE
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
1	R/L	TAIL/ILL_RLY
2	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
3	R/L	TAIL/ILL_RLY
4	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
3	R/L	TAIL/ILL_RLY
4	R/Y	ILL_CONT_OUT



Terminal No.	Color of Wire	Signal Name
8	R/L	TAIL/ILL_RLY
11	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
8	R/L	TAIL/ILL_RLY
11	R/Y	ILL_CONT_OUT

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

K

M

Z


O

P


Connector No.	M72
Connector Name	TCS OFF SWITCH (WITH TCS)
Connector Color	GRAY



Connector No.	M72
Connector Name	VDC OFF SWITCH (WITH VDC)
Connector Color	GRAY



Connector No.	M72
Connector Name	TAIL/ILL RLY
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R/L	TAIL/ILL RLY
4	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
3	R/L	TAIL/ILL RLY
4	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
19	P	ILL
20	Y	ILL

Terminal No.	Color of Wire	Signal Name
1	—	LOW_SIDE_PUSH_L_E
2	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
1	—	LOW_SIDE_PUSH_L_E
2	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	—	TAIL/ILL_RLY
6	—	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
1	—	LOW_SIDE_PUSH_L_E
2	R/Y	ILL_CONT_OUT


Terminal No.	Color of Wire	Signal Name
1	—	LOW_SIDE_PUSH_L_E
2	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	—	TAIL/ILL_RLY
6	—	ILL_CONT_OUT


ILLUMINATION

< COMPONENT DIAGNOSIS >

Connector No.	M202
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	Color



Connector No.	E6
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R/L	TAIL/RLY
6	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
9P	R/L	—

Terminal No.	Color of Wire	Signal Name
39	P	CAN-L
40	L	CAN-H
41	B	S-GND


Connector No.	E18
Connector Name	IDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R/L	TAIL/ILLUMI
12	B	P-GND

Terminal No.	Color of Wire	Signal Name
39	P	CAN-L
40	L	CAN-H

Terminal No.	Color of Wire	Signal Name
1	L	—
2	L	—








ILLUMINATION

< COMPONENT DIAGNOSIS >

A B C D E F G H I J K L

INL
M
Z
O
P



ALJIA0054GB


ILLUMINATION

< COMPONENT DIAGNOSIS >

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R10
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	L	—
14	Y	—

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	Y	—
6	L	—

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	Y	—
6	L	—

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	Y	—
6	L	—

Terminal No.	Color of Wire	Signal Name
8	R/L	TAIL/ILL_RLY
15	R/Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
1	L	TAIL/ILL_RLY
2	Y	ILL_CONT_OUT

Terminal No.	Color of Wire	Signal Name
5	Y	—
6	L	—

ALJIA0056GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

INL


M

N

O

P

Connector No.	D5
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
8	R/Y	ILL_CONT_OUT
9	R/L	TAIL/ILL_FLY

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Description

INFOID:000000000994362

REFERENCE VALUES FOR BCM

For BCM reference values, refer to [BCS-38, "Reference Value"](#).

TERMINAL LAYOUT FOR BCM

For the terminal layout for the BCM, refer to [BCS-41, "Terminal Layout"](#).

PHYSICAL VALUES FOR BCM

For physical values for the BCM, refer to [BCS-42, "Physical Values"](#).

WIRING DIAGRAM - BCM

For the BCM wiring diagram, refer to [BCS-61, "Wiring Diagram"](#).

FAIL SAFE - BCM

For BCM fail safe information, refer to [BCS-69, "Fail_Safe"](#).

DTC INSPECTION PRIORITY CHART - BCM

For the BCM DTC inspection priority chart, refer to [BCS-71, "DTC_Inspection_Priority_Chart"](#).

DTC INDEX - BCM

For the BCM DTC index, refer to [BCS-72, "DTC_Index"](#).

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000000994363

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none">• Map lamp• Personal lamp• Trunk room lamp• Step lamp• Vanity mirror lamp	<ul style="list-style-type: none">• Harness between BCM and each interior room lamp• BCM	Interior room lamp power supply circuit Refer to INL-14 .
<ul style="list-style-type: none">• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)• Interior room lamp does not turn OFF even though the door is closed.	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and each interior room lamp• BCM	Door switch circuit Refer to BCS-38 . Interior room lamp control circuit Refer to INL-16 .
Interior room lamp timer does not activate. (It turns ON/OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-11 .
Step lamps do not turn ON. (The map lamp and the personal lamp turn ON.)	<ul style="list-style-type: none">• Harness between BCM and each step lamp• BCM	Step lamp circuit Refer to INL-18 .
Step lamps (driver side and passenger side) do not turn OFF. (The map lamp and the personal lamp turn OFF.)	<ul style="list-style-type: none">• Harness between BCM and trunk room lamp switch• Harness between BCM and trunk room lamp• BCM	Trunk room lamp switch circuit Refer to BCS-38 .
<ul style="list-style-type: none">• Trunk room lamp does not turn ON. (The bulb is normal.)• Trunk room lamp does not turn OFF.	<ul style="list-style-type: none">• Harness between BCM and trunk room lamp• BCM	Trunk room lamp circuit Refer to INL-20 .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to INL-11 .

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000000994364

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

General precautions for service operations

INFOID:0000000000994365

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts which may get in the way with cloth.
- When removing parts with a screw driver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If an non-reuseable part is removed, replace it with a new one.
- After re-assembly has been completed, make sure each part functions correctly.
- Never work with wet hands.
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps or remove sealant residue.


< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR**INTERIOR ROOM LAMP****Removal and Installation**

INFOID:0000000000994366

MAP LAMP**Removal**


1. Disconnect the negative battery cable.
2. Release the metal clips and drop front edge of map lamp (1) away from headlining. Slide map lamp forward in vehicle to clear pawls at rear.
3. Disconnect the connectors, then remove map lamp.

**Installation**

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery cable.
2. Using a suitable tool (3), remove map lamp lens (2) RH/LH.
3. Pull bulb (1) straight out to remove.

Map lamp bulb : 12V - 8W**VANITY MIRROR LAMP**


INL

RemovalThe vanity mirror lamp is replaced as part of the sunvisor assembly. Refer to [INT-19, "Removal and Installation"](#).**Installation**

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery cable.
2. Using a suitable tool (1), remove the vanity mirror lamp lens (2) RH/LH.
3. Pull bulb (3) straight out to remove.

Vanity mirror lamp bulb : 12V - 2W


INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

GLOVE BOX LAMP

Removal

1. Disconnect the negative battery cable.
2. Remove the lower instrument glove box assembly (1). Refer to [IP-11, "Removal and Installation"](#).
3. Rotate glove box lamp socket (3) counterclockwise to remove.



Installation

Installation is in the reverse order of removal.


Bulb Replacement

1. Disconnect the negative battery cable.
2. Remove glove box lamp socket (3).
3. Pull bulb (2) straight out to remove.

Glove box lamp bulb : 12V - 3.4W

STEP LAMP

Removal



- | | | |
|------------------------|------------------|--------------------------|
| 1. Step lamp connector | 2. Door finisher | 3. Step lamp lens/socket |
| 4. Step lamp bulb | ➡ Vehicle front | |
1. Disconnect the negative battery cable.
 2. Insert a suitable tool between door finisher (2) and step lamp lens/socket (1) to release the pawls.
 3. Disconnect the step lamp connector, then remove step lamp.

Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery cable.
2. Remove the step lamp lens/socket.

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >


- Pull the bulb straight out to remove.

Step lamp bulb : 12V - 5W

PERSONAL LAMP

Removal

The personal lamp (RH/LH) (1) is replaced as part of the headlining assembly. Refer to [INT-19, "Removal and Installation"](#).



Installation

Installation is in the reverse order of removal.

Bulb Replacement

- Disconnect the negative battery cable.
- Using a suitable tool, release the pawls and remove personal lamp lens (3)
- Pull bulb (2) straight out to remove.

Personal lamp bulb : 12V - 8W

A
B
C
D
E
F
G
H
I
J
K
L
INL
M
N
O
P

ILLUMINATION

< ON-VEHICLE REPAIR >

ILLUMINATION


Removal and Installation

INFOID:0000000000994367

TRUNK ROOM LAMP

Removal

1. Disconnect the negative battery cable.
2. Release the tab (A), then swing open the lens.
3. Remove the bulb (3).
4. Release the tab (B), then pull trunk room lamp (2) away from body opening.
5. Disconnect the connector (1) and remove trunk room lamp.



Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery cable.
2. Release the tab (A), then swing open the lens.
3. Pull bulb (3) straight out to remove.

Trunk room lamp bulb : 12V - 3.4W

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:0000000000994368

Item	Type	Wattage (W)	Bulb No.*
Map lamp	Wedge	8	B5Y
Push-button ignition switch illumination	LED	-	-
Vanity mirror lamp	Cylinder	2	-
Glove box lamp	Wedge	3.4	658
Step lamp	Wedge	5	-
Personal lamp	Wedge	8	B5Y
Trunk room lamp	Wedge	3.4	158

* Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P