

TM
SECTION
TRANSAXLE & TRANSMISSION

A
B
C

TM

CONTENTS

E

| | | | |
|---|---|--|---|
| 6MT: RS6F52A | Inspection20 | | F |
| FUNCTION DIAGNOSIS 9 | CONTROL LINKAGE21 | | |
| M/T SYSTEM 9 | Exploded View21 | | G |
| System Diagram9 | Removal and Installation21 | | |
| System Description 10 | Adjustment22 | | |
| SYMPTOM DIAGNOSIS11 | AIR BREATHER HOSE23 | | H |
| NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING11 | Exploded View23 | | |
| NVH Troubleshooting Chart 11 | Removal and Installation23 | | |
| PRECAUTION12 | REMOVAL AND INSTALLATION25 | | I |
| PRECAUTIONS12 | TRANSAXLE ASSEMBLY25 | | |
| Service Notice or Precautions 12 | Exploded View25 | | J |
| PREPARATION13 | Removal and Installation25 | | |
| PREPARATION13 | DISASSEMBLY AND ASSEMBLY28 | | K |
| Special Service Tools 13 | TRANSAXLE ASSEMBLY28 | | |
| Commercial Service Tools 15 | Exploded View28 | | L |
| ON-VEHICLE MAINTENANCE17 | Disassembly32 | | |
| M/T OIL17 | Assembly39 | | |
| Draining 17 | Adjustment49 | | M |
| Refilling 17 | INPUT SHAFT AND GEAR57 | | |
| Inspection 17 | Exploded View57 | | N |
| ON-VEHICLE REPAIR18 | Disassembly57 | | |
| SIDE OIL SEAL18 | Assembly58 | | O |
| Removal and Installation 18 | Inspection62 | | |
| BACK-UP LAMP SWITCH19 | MAINSHAFT AND GEAR64 | | |
| Removal and Installation 19 | Exploded View64 | | P |
| Inspection 19 | Disassembly64 | | |
| PARK/NEUTRAL POSITION SWITCH20 | Assembly65 | | |
| Removal and Installation 20 | Inspection69 | | |
| | REVERSE IDLER SHAFT AND GEAR72 | | |
| | Exploded View72 | | |
| | Disassembly72 | | |
| | Assembly72 | | |
| | Inspection72 | | |

| | | | |
|--|-----------|---|--------------|
| FINAL DRIVE | 74 | System Description | 98 |
| Exploded View | 74 | Component Parts Location | 99 |
| Disassembly | 74 | Component Description | 100 |
| Assembly | 74 | | |
| Inspection | 76 | | |
| SHIFT FORK AND FORK ROD | 78 | LOCK-UP AND SELECT CONTROL SYSTEM | ..102 |
| Exploded View | 78 | System Diagram | 102 |
| Disassembly | 78 | System Description | 102 |
| Assembly | 78 | Component Parts Location | 102 |
| Inspection | 79 | Component Description | 103 |
| SERVICE DATA AND SPECIFICATIONS | | SHIFT MECHANISM | 105 |
| (SDS) | 81 | System Diagram | 105 |
| SERVICE DATA AND SPECIFICATIONS | | System Description | 105 |
| (SDS) | 81 | Component Parts Location | 106 |
| General Specifications | 81 | Component Description | 107 |
| End Play | 82 | SHIFT LOCK SYSTEM | 108 |
| Baulk Ring Clearance | 82 | System Diagram | 108 |
| Dimension | 83 | System Description | 108 |
| Differential Side Bearing Preload | 83 | Component Parts Location | 108 |
| Differential Side Gear Clearance | 83 | Component Description | 108 |
| CVT: RE0F09B | | ON BOARD DIAGNOSTIC (OBD) SYSTEM ... | 110 |
| BASIC INSPECTION | 84 | Diagnosis Description | 110 |
| DIAGNOSIS AND REPAIR WORKFLOW | 84 | DIAGNOSIS SYSTEM (TCM) | 112 |
| Work Flow | 84 | CONSULT-III Function (TRANSMISSION) | 112 |
| Diagnostic Work Sheet | 85 | Diagnostic Tool Function | 117 |
| INSPECTION AND ADJUSTMENT | 87 | COMPONENT DIAGNOSIS | 118 |
| ADDITIONAL SERVICE WHEN REPLACING | | U1000 CAN COMM CIRCUIT | 118 |
| CONTROL UNIT | 87 | Description | 118 |
| ADDITIONAL SERVICE WHEN REPLACING | | DTC Logic | 118 |
| CONTROL UNIT : Precaution for TCM and CVT | | Diagnosis Procedure | 118 |
| Assembly Replacement | 87 | P0615 START SIGNAL | 119 |
| FUNCTION DIAGNOSIS | 88 | Description | 119 |
| CVT SYSTEM | 88 | DTC Logic | 119 |
| System Diagram | 88 | Diagnosis Procedure | 119 |
| Component Parts Location | 88 | P0703 STOP LAMP SWITCH | 121 |
| MECHANICAL SYSTEM | 90 | Description | 121 |
| Cross-Sectional View | 90 | DTC Logic | 121 |
| System Diagram | 90 | Diagnosis Procedure | 121 |
| System Description | 91 | Component Inspection | 121 |
| Component Parts Location | 91 | P0705 PARK/NEUTRAL POSITION SWITCH. | 123 |
| Component Description | 92 | Description | 123 |
| HYDRAULIC CONTROL SYSTEM | 94 | DTC Logic | 123 |
| System Diagram | 94 | Diagnosis Procedure | 123 |
| System Description | 94 | Component Inspection | 124 |
| Component Parts Location | 95 | P0710 CVT FLUID TEMPERATURE SENSOR | ..126 |
| Component Description | 96 | Description | 126 |
| CONTROL SYSTEM | 98 | DTC Logic | 126 |
| System Diagram | 98 | Diagnosis Procedure | 126 |
| | | Component Inspection | 127 |

| | | | | |
|---|-----|---|-----|----|
| P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR) | 128 | Component Inspection | 148 | A |
| Description | 128 | P0826 MANUAL MODE SWITCH | 149 | B |
| DTC Logic | 128 | Description | 149 | |
| Diagnosis Procedure | 128 | DTC Logic | 149 | |
| P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR) | 130 | Diagnosis Procedure | 149 | |
| Description | 130 | Component Inspection | 151 | C |
| DTC Logic | 130 | P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR) | 152 | |
| Diagnosis Procedure | 130 | Description | 152 | |
| P0725 ENGINE SPEED SIGNAL | 133 | DTC Logic | 152 | TM |
| Description | 133 | Diagnosis Procedure | 152 | |
| DTC Logic | 133 | P0841 PRESSURE SENSOR FUNCTION | 154 | E |
| Diagnosis Procedure | 133 | Description | 154 | |
| P0730 BELT DAMAGE | 135 | DTC Logic | 154 | |
| Description | 135 | Diagnosis Procedure | 154 | F |
| DTC Logic | 135 | P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR) | 156 | G |
| Diagnosis Procedure | 135 | Description | 156 | |
| P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE | 137 | DTC Logic | 156 | |
| Description | 137 | Diagnosis Procedure | 156 | H |
| DTC Logic | 137 | P0868 SECONDARY PRESSURE DOWN | 158 | I |
| Diagnosis Procedure | 137 | Description | 158 | |
| Component Inspection | 138 | DTC Logic | 158 | |
| P0744 A/T TCC S/V FUNCTION (LOCK -UP) .. | 139 | Diagnosis Procedure | 158 | J |
| Description | 139 | P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY) | 160 | K |
| DTC Logic | 139 | Description | 160 | |
| Diagnosis Procedure | 139 | DTC Logic | 160 | |
| P0745 LINE PRESSURE SOLENOID VALVE. | 141 | Diagnosis Procedure | 160 | L |
| Description | 141 | P1705 THROTTLE POSITION SENSOR | 162 | M |
| DTC Logic | 141 | Description | 162 | |
| Diagnosis Procedure | 141 | DTC Logic | 162 | |
| Component Inspection | 142 | Diagnosis Procedure | 162 | |
| P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE) | 143 | P1722 ESTM VEHICLE SPEED SIGNAL | 164 | N |
| Description | 143 | Description | 164 | |
| DTC Logic | 143 | DTC Logic | 164 | |
| Diagnosis Procedure | 143 | Diagnosis Procedure | 164 | |
| P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE) | 145 | P1723 CVT SPEED SENSOR FUNCTION | 166 | O |
| Description | 145 | Description | 166 | |
| DTC Logic | 145 | DTC Logic | 166 | |
| Diagnosis Procedure | 145 | Diagnosis Procedure | 166 | |
| P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE) | 147 | P1726 ELECTRIC THROTTLE CONTROL SYSTEM | 168 | P |
| Description | 147 | Description | 168 | |
| DTC Logic | 147 | DTC Logic | 168 | |
| Diagnosis Procedure | 147 | Diagnosis Procedure | 168 | |
| | | P1740 LOCK-UP SELECT SOLENOID VALVE | 169 | |
| | | Description | 169 | |
| | | DTC Logic | 169 | |

| | | | |
|--|------------|--|------------|
| Diagnosis Procedure | 169 | ON-VEHICLE MAINTENANCE | 214 |
| Component Inspection | 170 | CVT FLUID | 214 |
| P1745 LINE PRESSURE CONTROL | 171 | Inspection | 214 |
| Description | 171 | Changing | 215 |
| DTC Logic | 171 | FLUID FLOOR CLEANING | 216 |
| Diagnosis Procedure | 171 | Cleaning | 216 |
| P1777 STEP MOTOR | 172 | STALL TEST | 219 |
| Description | 172 | Inspection and Judgment | 219 |
| DTC Logic | 172 | LINE PRESSURE TEST | 221 |
| Diagnosis Procedure | 172 | Inspection and Judgment | 221 |
| Component Inspection | 173 | ROAD TEST | 223 |
| P1778 STEP MOTOR - FUNCTION | 175 | Description | 223 |
| Description | 175 | Check before Engine Is Started | 223 |
| DTC Logic | 175 | Check at Idle | 224 |
| Diagnosis Procedure | 175 | Cruise Test | 225 |
| SHIFT LOCK SYSTEM | 177 | CVT POSITION | 227 |
| Description | 177 | Inspection and Adjustment | 227 |
| Wiring Diagram | 177 | ON-VEHICLE REPAIR | 228 |
| Diagnosis Procedure | 178 | TRANSMISSION CONTROL MODULE | 228 |
| ECU DIAGNOSIS | 181 | Exploded View | 228 |
| TCM | 181 | Removal and Installation | 228 |
| Reference Value | 181 | CONTROL DEVICE | 229 |
| Wiring Diagram — CVT CONTROL SYSTEM — .. | 186 | Exploded View | 229 |
| Fail-safe | 193 | Removal and Installation | 229 |
| DTC Inspection Priority Chart | 194 | CONTROL CABLE | 230 |
| DTC Index | 194 | Exploded View | 230 |
| SYMPTOM DIAGNOSIS | 196 | Removal and Installation | 230 |
| SYSTEM SYMPTOM | 196 | AIR BREATHER HOSE | 231 |
| Symptom Table | 196 | Exploded View | 231 |
| PRECAUTION | 207 | Removal and Installation | 231 |
| PRECAUTIONS | 207 | DIFFERENTIAL SIDE OIL SEAL | 232 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 207 | Exploded View | 232 |
| Precaution for Procedure without Cowl Top Cover .. | 207 | Removal and Installation | 232 |
| Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect | 207 | REMOVAL AND INSTALLATION | 233 |
| Precaution for On Board Diagnosis (OBD) System of CVT and Engine | 208 | TRANSAXLE ASSEMBLY | 233 |
| Precaution for TCM and CVT Assembly Replace- ment | 208 | Exploded View | 233 |
| Removal and Installation Procedure for CVT Unit Connector | 208 | Removal and Installation | 233 |
| Precaution | 209 | Inspection | 234 |
| Service Notice or Precaution | 210 | SERVICE DATA AND SPECIFICATIONS (SDS) | 235 |
| PREPARATION | 212 | SERVICE DATA AND SPECIFICATIONS (SDS) | 235 |
| PREPARATION | 212 | General Specification | 235 |
| Special Service Tool | 212 | Vehicle Speed When Shifting Gears | 235 |
| Commercial Service Tool | 212 | Stall Speed | 235 |
| | | Line Pressure | 235 |

| | | | | |
|--|---------------|--|------------|----|
| Solenoid Valves | 235 | System Description | 262 | |
| CVT Fluid Temperature Sensor | 236 | Component Parts Location | 262 | A |
| Primary Speed Sensor | 236 | Component Description | 262 | |
| Secondary Speed Sensor | 236 | | | |
| Removal and Installation | 236 | ON BOARD DIAGNOSTIC (OBD) SYSTEM .. | 264 | B |
| CVT: RE0F10A | | Diagnosis Description | 264 | |
| BASIC INSPECTION | 237 | DIAGNOSIS SYSTEM (TCM) | 266 | C |
| DIAGNOSIS AND REPAIR WORKFLOW | 237 | CONSULT-III Function (TRANSMISSION) | 266 | |
| Work Flow | 237 | Diagnostic Tool Function | 271 | |
| Diagnostic Work Sheet | 238 | COMPONENT DIAGNOSIS | 272 | TM |
| INSPECTION AND ADJUSTMENT | 240 | U1000 CAN COMM CIRCUIT | 272 | |
| ADDITIONAL SERVICE WHEN REPLACING | | Description | 272 | E |
| CONTROL UNIT | 240 | DTC Logic | 272 | |
| ADDITIONAL SERVICE WHEN REPLACING | | Diagnosis Procedure | 272 | |
| CONTROL UNIT : Service After Replacing TCM | | U1010 CONTROL UNIT (CAN) | 273 | F |
| and Transaxle Assembly | 240 | Description | 273 | |
| FUNCTION DIAGNOSIS | 242 | DTC Logic | 273 | |
| CVT SYSTEM | 242 | Diagnosis Procedure | 273 | G |
| System Diagram | 242 | P0703 STOP LAMP SWITCH | 274 | |
| Component Parts Location | 242 | Description | 274 | H |
| MECHANICAL SYSTEM | 244 | DTC Logic | 274 | |
| Cross-Sectional View | 244 | Diagnosis Procedure | 274 | |
| System Diagram | 244 | Component Inspection | 274 | I |
| System Description | 245 | P0705 PARK/NEUTRAL POSITION SWITCH. 276 | | |
| Component Parts Location | 245 | Description | 276 | J |
| Component Description | 246 | DTC Logic | 276 | |
| HYDRAULIC CONTROL SYSTEM | 248 | Diagnosis Procedure | 277 | |
| System Diagram | 248 | Component Inspection | 277 | |
| System Description | 248 | P0710 CVT FLUID TEMPERATURE SENSOR | 279 | K |
| Component Parts Location | 249 | Description | 279 | |
| Component Description | 250 | DTC Logic | 279 | |
| CONTROL SYSTEM | 252 | Diagnosis Procedure | 279 | L |
| System Diagram | 252 | Component Inspection | 280 | |
| System Description | 252 | P0715 INPUT SPEED SENSOR (PRI SPEED | | M |
| Component Parts Location | 253 | SENSOR) | 281 | |
| Component Description | 254 | Description | 281 | |
| LOCK-UP AND SELECT CONTROL SYSTEM | .. 256 | DTC Logic | 281 | |
| System Diagram | 256 | Diagnosis Procedure | 281 | N |
| System Description | 256 | P0720 VEHICLE SPEED SENSOR CVT (SEC- | | O |
| Component Parts Location | 256 | ONDARY SPEED SENSOR) | 284 | |
| Component Description | 257 | Description | 284 | |
| SHIFT MECHANISM | 259 | DTC Logic | 284 | |
| System Diagram | 259 | Diagnosis Procedure | 284 | P |
| System Description | 259 | P0725 ENGINE SPEED SIGNAL | 287 | |
| Component Parts Location | 260 | Description | 287 | |
| Component Description | 261 | DTC Logic | 287 | |
| SHIFT LOCK SYSTEM | 262 | Diagnosis Procedure | 287 | |
| System Diagram | 262 | P0730 BELT DAMAGE | 289 | |
| | | Description | 289 | |

| | | | |
|---|------------|--|------------|
| DTC Logic | 289 | P0845 TRANSMISSION FLUID PRESSURE | |
| Diagnosis Procedure | 289 | SENSOR B (PRI PRESSURE SENSOR) | 310 |
| P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE | 291 | Description | 310 |
| Description | 291 | DTC Logic | 310 |
| DTC Logic | 291 | Diagnosis Procedure | 310 |
| Diagnosis Procedure | 291 | P0868 SECONDARY PRESSURE DOWN | 312 |
| Component Inspection | 292 | Description | 312 |
| P0744 A/T TCC S/V FUNCTION (LOCK -UP). 293 | | DTC Logic | 312 |
| Description | 293 | Diagnosis Procedure | 312 |
| DTC Logic | 293 | P1701 TRANSMISSION CONTROL MODULE | |
| Diagnosis Procedure | 293 | (POWER SUPPLY) | 314 |
| P0745 LINE PRESSURE SOLENOID VALVE. 295 | | Description | 314 |
| Description | 295 | DTC Logic | 314 |
| DTC Logic | 295 | Diagnosis Procedure | 314 |
| Diagnosis Procedure | 295 | P1705 THROTTLE POSITION SENSOR | 316 |
| Component Inspection | 296 | Description | 316 |
| P0746 PRESSURE CONTROL SOLENOID A | | DTC Logic | 316 |
| PERFORMANCE (LINE PRESSURE SOLENOID VALVE) | 297 | Diagnosis Procedure | 316 |
| Description | 297 | P1722 ESTM VEHICLE SPEED SIGNAL | 318 |
| DTC Logic | 297 | Description | 318 |
| Diagnosis Procedure | 297 | DTC Logic | 318 |
| P0776 PRESSURE CONTROL SOLENOID B | | Diagnosis Procedure | 318 |
| PERFORMANCE (SEC PRESSURE SOLENOID VALVE) | 299 | P1723 CVT SPEED SENSOR FUNCTION | 320 |
| Description | 299 | Description | 320 |
| DTC Logic | 299 | DTC Logic | 320 |
| Diagnosis Procedure | 299 | Diagnosis Procedure | 320 |
| P0778 PRESSURE CONTROL SOLENOID B | | P1726 ELECTRIC THROTTLE CONTROL | |
| ELECTRICAL (SEC PRESSURE SOLENOID VALVE) | 301 | SYSTEM | 322 |
| Description | 301 | Description | 322 |
| DTC Logic | 301 | DTC Logic | 322 |
| Diagnosis Procedure | 301 | Diagnosis Procedure | 322 |
| Component Inspection | 302 | P1740 LOCK-UP SELECT SOLENOID VALVE | 323 |
| P0826 MANUAL MODE SWITCH | 303 | Description | 323 |
| Description | 303 | DTC Logic | 323 |
| DTC Logic | 303 | Diagnosis Procedure | 323 |
| Diagnosis Procedure | 303 | Component Inspection | 324 |
| Component Inspection | 305 | P1745 LINE PRESSURE CONTROL | 325 |
| P0840 TRANSMISSION FLUID PRESSURE | | Description | 325 |
| SENSOR A (SEC PRESSURE SENSOR) | 306 | DTC Logic | 325 |
| Description | 306 | Diagnosis Procedure | 325 |
| DTC Logic | 306 | P1777 STEP MOTOR | 326 |
| Diagnosis Procedure | 306 | Description | 326 |
| P0841 PRESSURE SENSOR FUNCTION | 308 | DTC Logic | 326 |
| Description | 308 | Diagnosis Procedure | 326 |
| DTC Logic | 308 | Component Inspection | 327 |
| Diagnosis Procedure | 308 | P1778 STEP MOTOR - FUNCTION | 329 |
| P0845 TRANSMISSION FLUID PRESSURE | | Description | 329 |
| SENSOR B (PRI PRESSURE SENSOR) | 310 | DTC Logic | 329 |
| Description | 310 | Diagnosis Procedure | 329 |
| DTC Logic | 310 | | |
| Diagnosis Procedure | 310 | | |
| P0868 SECONDARY PRESSURE DOWN | 312 | | |
| Description | 312 | | |
| DTC Logic | 312 | | |
| Diagnosis Procedure | 312 | | |
| P1701 TRANSMISSION CONTROL MODULE | | | |
| (POWER SUPPLY) | 314 | | |
| Description | 314 | | |
| DTC Logic | 314 | | |
| Diagnosis Procedure | 314 | | |
| P1705 THROTTLE POSITION SENSOR | 316 | | |
| Description | 316 | | |
| DTC Logic | 316 | | |
| Diagnosis Procedure | 316 | | |
| P1722 ESTM VEHICLE SPEED SIGNAL | 318 | | |
| Description | 318 | | |
| DTC Logic | 318 | | |
| Diagnosis Procedure | 318 | | |
| P1723 CVT SPEED SENSOR FUNCTION | 320 | | |
| Description | 320 | | |
| DTC Logic | 320 | | |
| Diagnosis Procedure | 320 | | |
| P1726 ELECTRIC THROTTLE CONTROL | | | |
| SYSTEM | 322 | | |
| Description | 322 | | |
| DTC Logic | 322 | | |
| Diagnosis Procedure | 322 | | |
| P1740 LOCK-UP SELECT SOLENOID VALVE | 323 | | |
| Description | 323 | | |
| DTC Logic | 323 | | |
| Diagnosis Procedure | 323 | | |
| Component Inspection | 324 | | |
| P1745 LINE PRESSURE CONTROL | 325 | | |
| Description | 325 | | |
| DTC Logic | 325 | | |
| Diagnosis Procedure | 325 | | |
| P1777 STEP MOTOR | 326 | | |
| Description | 326 | | |
| DTC Logic | 326 | | |
| Diagnosis Procedure | 326 | | |
| Component Inspection | 327 | | |
| P1778 STEP MOTOR - FUNCTION | 329 | | |
| Description | 329 | | |
| DTC Logic | 329 | | |
| Diagnosis Procedure | 329 | | |

| | | | | |
|--|------------|---|------------|----|
| SHIFT LOCK SYSTEM | 331 | Cruise Test | 379 | |
| Description | 331 | CVT POSITION | 381 | A |
| Wiring Diagram | 331 | Inspection and Adjustment | 381 | |
| Diagnosis Procedure | 332 | ON-VEHICLE REPAIR | 382 | B |
| ECU DIAGNOSIS | 335 | TRANSMISSION CONTROL MODULE | 382 | C |
| TCM | 335 | Exploded View | 382 | |
| Reference Value | 335 | Removal and Installation | 382 | |
| Wiring Diagram — CVT CONTROL SYSTEM — .. | 339 | CONTROL DEVICE | 383 | TM |
| Fail-safe | 347 | Exploded View | 383 | |
| DTC Inspection Priority Chart | 348 | Removal and Installation | 383 | |
| DTC Index | 348 | Inspection and Adjustment | 384 | |
| SYMPTOM DIAGNOSIS | 350 | CONTROL CABLE | 385 | E |
| SYSTEM SYMPTOM | 350 | Exploded View | 385 | |
| Symptom Table | 350 | Removal and Installation | 385 | |
| PRECAUTION | 362 | DIFFERENTIAL SIDE OIL SEAL | 386 | F |
| PRECAUTIONS | 362 | Exploded View | 386 | |
| Precaution for Supplemental Restraint System | | Removal and Installation | 386 | G |
| (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- | | AIR BREATHING HOSE | 387 | |
| SIONER" | 362 | Exploded View | 387 | |
| Precaution for Procedure without Cowl Top Cover. | 362 | Removal and Installation | 387 | H |
| Precaution Necessary for Steering Wheel Rota- | | OIL PAN | 388 | |
| tion After Battery Disconnect | 362 | Exploded View | 388 | I |
| Precaution for On Board Diagnosis (OBD) System | | Removal and Installation | 388 | |
| of CVT and Engine | 363 | PARK/NEUTRAL POSITION (PNP) SWITCH . | 389 | J |
| Precaution for TCM and CVT Assembly Replace- | | Exploded View | 389 | |
| ment | 363 | Removal and Installation | 389 | |
| Removal and Installation Procedure for CVT Unit | | PRIMARY SPEED SENSOR | 390 | K |
| Connector | 363 | Exploded View | 390 | |
| Precaution | 364 | Removal and Installation | 390 | |
| Service Notice or Precaution | 365 | SECONDARY SPEED SENSOR | 391 | L |
| PREPARATION | 367 | Exploded View | 391 | |
| PREPARATION | 367 | Removal and Installation | 391 | |
| Special Service Tool | 367 | OIL PUMP FITTING BOLT | 392 | M |
| Commercial Service Tool | 367 | Exploded View | 392 | |
| ON-VEHICLE MAINTENANCE | 368 | Removal and Installation | 392 | |
| CVT FLUID | 368 | REMOVAL AND INSTALLATION | 393 | N |
| Inspection | 368 | TRANSAXLE ASSEMBLY | 393 | O |
| Changing | 369 | Exploded View | 393 | |
| CVT FLUID COOLER SYSTEM | 370 | Removal and Installation | 393 | |
| Cleaning | 370 | Inspection | 394 | P |
| STALL TEST | 373 | DISASSEMBLY AND ASSEMBLY | 396 | |
| Inspection and Judgment | 373 | TORQUE CONVERTER AND CONVERTER | | |
| LINE PRESSURE TEST | 375 | HOUSING OIL SEAL | 396 | |
| Inspection and Judgment | 375 | Exploded View | 396 | |
| ROAD TEST | 377 | Disassembly | 396 | |
| Description | 377 | Assembly | 396 | |
| Check before Engine Is Started | 377 | | | |
| Check at Idle | 378 | | | |

SERVICE DATA AND SPECIFICATIONS**(SDS)**397**SERVICE DATA AND SPECIFICATIONS****(SDS)** 397

General Specification397

Vehicle Speed When Shifting Gears397

Stall Speed 397

Line Pressure 397

Solenoid Valves 397

CVT Fluid Temperature Sensor 398

Primary Speed Sensor 398

Secondary Speed Sensor 398

Removal and Installation 398


FUNCTION DIAGNOSIS

M/T SYSTEM

System Diagram

INFOID:000000000991868

CROSS-SECTIONAL VIEW



- | | | |
|--------------------------------|------------------------------|-------------------------------|
| 1. Transaxle case | 2. 3rd input gear | 3. 3rd-4th synchronizer hub |
| 4. 3rd-4th coupling sleeve | 5. 4th input gear | 6. 5th input gear |
| 7. 5th-6th synchronizer hub | 8. 5th-6th coupling sleeve | 9. 6th input gear |
| 10. Input shaft rear bearing | 11. Mainshaft rear bearing | 12. 6th main gear |
| 13. 5th main gear | 14. 4th main gear | 15. 3rd main gear |
| 16. 2nd main gear | 17. 1st-2nd synchronizer hub | 18. 1st-2nd coupling sleeve |
| 19. 1st main gear | 20. Reverse main gear | 21. Differential side bearing |
| 22. Differential case assembly | 23. Final gear | 24. Speedometer drive gear |
| 25. Mainshaft front bearing | 26. Mainshaft | 27. Input shaft |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

- | | | |
|--------------------------------|-----------------------------|-------------------------------|
| 28. Input shaft front bearing | 29. Clutch housing | 30. Reverse idler shaft |
| 31. Reverse idler gear (Front) | 32. Reverse coupling sleeve | 33. Reverse idler gear (Rear) |

System Description


INFOID:000000000991869

DOUBLE-CONE SYNCHRONIZER

Double-cone synchronizer is adopted for 3rd gear to reduce operating force of the shift lever.

TRIPLE-CONE SYNCHRONIZER


Triple-cone synchronizer are adopted for 1st and 2nd gears to reduce operating force of the shift lever.



REVERSE GEAR NOISE PREVENTION FUNCTION (SYNCHRONIZING METHOD)

Reverse gear can be matched smoothly in a structure by setting synchronizer hub (1) of reverse idler gear (Rear), reverse coupling sleeve (2), reverse baulk ring (3), and reverse insert spring (4) to reverse idler gears, and letting reverse gear be synchronized.

- 5 : Reverse idler gear (Rear)
- 6 : Reverse idler gear (Front)



NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[6MT: RS6F52A]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000000991870

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

| Reference page | | MA-11 | | | TM-28 | | | TM-21 | TM-32 | TM-28 | | | | |
|-------------------------------------|---------------------------------|-------------------------|------------------|--------------------------|------------------|----------------------------|--------------------------|------------------------------|---|-------------------|------------------------|---------------------------|------------------------------|-------------------------|
| SUSPECTED PARTS (Possible cause) | | OIL (Oil level is low.) | OIL (Wrong oil.) | OIL (Oil level is high.) | GASKET (Damaged) | OIL SEAL (Worn or damaged) | O-RING (Worn or damaged) | SHIFT CONTROL LINKAGE (Worn) | CHECK PLUG RETURN SPRING AND CHECK BALL (Worn or damaged) | SHIFT FORK (Worn) | GEAR (Worn or damaged) | BEARING (Worn or damaged) | BAULK RING (Worn or damaged) | INSERT SPRING (Damaged) |
| Symptoms | Noise | 1 | 2 | | | | | | | | 3 | 3 | | |
| | Oil leakage | | 3 | 1 | 2 | 2 | | | | | | | | |
| | Hard to shift or will not shift | | 1 | 1 | | | | 2 | | | | | 3 | 3 |
| | Jumps out of gear | | | | | | | 1 | 2 | 3 | 3 | | | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Service Notice or Precautions

INFOID:000000000991871

- Do not reuse transaxle oil, once it has been drained.
- Check oil level or replace oil with vehicle on level surface.
- During removal or installation, keep inside of transaxle clear of dust or dirt.
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts they are applied.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Be careful not to damage sliding surfaces and mating surfaces.

PREPARATION

< PREPARATION >

[6MT: RS6F52A]






PREPARATION

PREPARATION

Special Service Tools

INFOID:000000000991872

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|--|
| KV381054S0 (J-34286) Puller  ZZA0601D | <ul style="list-style-type: none"> • Removing differential side bearing outer race • Removing mainshaft front bearing |
| ST33400001 (J-26082) Drift  ZZA0814D | Installing differential side oil seal (clutch housing side) a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia. |
| ST35321000 (—) Drift  ZZA1000D | <ul style="list-style-type: none"> • Installing input shaft oil seal • Installing reverse main gear • Installing 1st main gear bushing • Installing 1st-2nd synchronizer hub assembly • Installing 2nd main gear bushing • Installing 3rd main gear a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia. |
| KV40105320 (—) Drift  ZZA0898D | Installing differential side bearing outer race (clutch housing side) a: 88 mm (3.46 in) dia. |
| ST33200000 (J-26082) Drift  ZZA1002D | <ul style="list-style-type: none"> • Installing mainshaft front bearing • Installing 6th input gear bushing • Installing 4th main gear • Installing 5th main gear • Installing 6th main gear a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia. |
| ST30720000 (J-25405) Drift  ZZA0811D | <ul style="list-style-type: none"> • Installing differential side oil seal (transaxle case side) • Installing differential side bearing outer race (transaxle case side) • Installing mainshaft rear bearing • Installing differential side bearing a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia. |

A

B

C

TM

E

F

G

H

I

J

K

L

M

N






O

P

PREPARATION

< PREPARATION >






[6MT: RS6F52A]

| Tool number (Kent-Moore No.) Tool name | | Description |
|--|---|---|
| ST33061000 (J-8107-2) Drift |  <p style="text-align: center;">ZZA1000D</p> | <ul style="list-style-type: none"> • Installing bore plug • Removing differential side bearing (transaxle case side) • Removing differential side bearing (clutch housing side) <p>a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.</p> |
| ST33052000 (—) Drift |  <p style="text-align: center;">ZZA1023D</p> | <ul style="list-style-type: none"> • Removing input shaft rear bearing • Removing 5th input gear bushing, 4th input gear, 4th input gear bushing, 3rd-4th synchronizer hub assembly, and 3rd input gear • Installing input shaft front bearing • Removing mainshaft rear bearing • Removing 6th main gear • Removing 4th main gear and 5th main gear <p>a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.</p> |
| KV40105020 (—) Drift |  <p style="text-align: center;">ZZA1133D</p> | <ul style="list-style-type: none"> • Removing 5th input gear and 5th-6th synchronizer hub assembly • Removing 3rd main gear, 2nd main gear, 2nd main gear bushing, 1st-2nd synchronizer hub assembly, 1st main gear, 1st main gear bushing, and reverse main gear <p>a: 39.7 mm (1.563 in) dia. b: 35 mm (1.38 in) dia. c: 15 mm (0.59 in)</p> |
| ST30031000 (J-22912-01) Puller |  <p style="text-align: center;">ZZA0537D</p> | Measuring wear of inner baulk ring |
| KV40105710 (—) Press stand |  <p style="text-align: center;">ZZA1058D</p> | <ul style="list-style-type: none"> • Installing 3rd-4th synchronizer hub assembly • Installing 4th input gear bushing • Installing 5th input gear bushing • Installing 5th-6th synchronizer hub assembly • Installing 2nd main gear bushing • Installing 3rd main gear <p>a: 46 mm (1.81 in) dia. b: 41 mm (1.61 in)</p> |
| ST30901000 (J-26010-01) Drift |  <p style="text-align: center;">ZZA0978D</p> | <ul style="list-style-type: none"> • Installing input shaft rear bearing • Installing 4th main gear • Installing 5th main gear • Installing 6th main gear • Installing mainshaft rear bearing <p>a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.</p> |

PREPARATION

< PREPARATION >

[6MT: RS6F52A]

| Tool number (Kent-Moore No.) Tool name | Description |
|---|---|
| ST30032000 (J-26010-01) Drift  <p style="text-align: right; font-size: small;">ZZA0978D</p> | Installing input shaft front bearing a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia. |
| ST38220000 (—) Press stand  <p style="text-align: right; font-size: small;">ZZA1058D</p> | <ul style="list-style-type: none"> • Installing reverse main gear • Installing 1st main gear bushing • Installing 1st-2nd synchronizer hub assembly a: 63 mm (2.48 in) dia. b: 65 mm (2.56 in) |
| KV40101630 (J-35870) Drift  <p style="text-align: right; font-size: small;">ZZA1003D</p> | Installing reverse main gear a: 68 mm (2.68 in) dia. b: 60 mm (2.36 in) dia. |
| KV38102510 (—) Drift  <p style="text-align: right; font-size: small;">ZZA0838D</p> | <ul style="list-style-type: none"> • Installing 1st main gear bushing • Installing 1st-2nd synchronizer hub assembly • Installing differential side bearing (transaxle case side) • Installing differential side bearing (clutch housing side) a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia. |
| (J-39713) Preload adapter  <p style="text-align: right; font-size: small;">NT087</p> | Measuring end play of side gear |

Commercial Service Tools






INFOID:000000000991873

A
 B
 C
 TM
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P

PREPARATION

< PREPARATION >

[6MT: RS6F52A]

| Tool name | Description |
|---|---|
| <p>Pin punch</p> <div style="text-align: center;">  <p>NT410</p> </div> | <p>Removing and installing retaining pin a: 4.5 mm (0.177 in) dia.</p> |
| <p>Pin punch</p> <div style="text-align: center;">  <p>NT410</p> </div> | <p>Removing and installing retaining pin of selector lever a: 5.5 mm (0.217 in) dia.</p> |
| <p>Pin punch</p> <div style="text-align: center;">  <p>NT410</p> </div> | <p>Removing and installing retaining pin of each shifter lever a: 7.5 mm (0.295 in) dia.</p> |
| <p>Drift</p> <div style="text-align: center;">  <p>S-NT063</p> </div> | <p>Installing striking rod oil seal and shifter lever oil seal a: 24.5 mm (0.965 in) dia.</p> |
| <p>Puller</p> <div style="text-align: center;">  <p>ZZA0537D</p> </div> | <p>Removing each bearing, gear, and bushing</p> |
| <p>Puller</p> <div style="text-align: center;">  <p>NT077</p> </div> | <p>Removing each bearing, gear, and bushing</p> |
| <p>Power tool</p> <div style="text-align: center;">  <p>PBIC0190E</p> </div> | <p>Loosening bolts and nuts</p> |

ON-VEHICLE MAINTENANCE

M/T OIL

Draining

INFOID:000000000991874

1. Start engine and let it run to warm up transaxle oil.
2. Stop engine and remove the drain plug to drain the oil.
3. Install the drain plug with a new gasket to the transaxle case. Tighten the drain plug to the specified torque. Refer to [TM-28, "Exploded View"](#).

CAUTION:

Do not reuse gasket.

Refilling

INFOID:000000000991875

1. Remove the plug and fill transaxle with new oil.

Oil grade and capacity: Refer to [MA-11, "Fluids and Lubricants"](#).

2. After refilling oil, measure oil level to check if it is within the specification using suitable gauge as shown.

CAUTION:

Do not start engine while checking oil level.


Oil level "L": 55.0 - 61.0 mm (2.17 - 2.40 in)

3. Install the plug with a new O-ring to the clutch housing.

CAUTION:

Do not reuse O-ring.

4. Tighten plug to the specified torque. Refer to [TM-28, "Exploded View"](#).



Inspection

INFOID:000000000991876

LEAKAGE

- Make sure that oil is not leaking from transaxle or around it.


LEVEL

- Remove the plug.
- Measure oil level to check if it is within the specification using a suitable gauge as shown.

CAUTION:

Do not start engine while checking oil level.

Oil level "L": 55.0 - 61.0 mm (2.17 - 2.40 in)



- Install the plug with a new O-ring to the clutch housing.

CAUTION:

Do not reuse O-ring.

- Tighten plug to the specified torque. Refer to [TM-28, "Exploded View"](#).

ON-VEHICLE REPAIR

SIDE OIL SEAL

Removal and Installation


INFOID:000000000991877

REMOVAL

1. Remove the drive shaft. Refer to [FAX-9. "Removal and Installation \(Left Side\)"](#), [FAX-10. "Removal and Installation \(Right Side\)"](#).
2. Remove oil seal using suitable tool.

CAUTION:

Do not damage the transaxle case surface when removing oil seal.



INSTALLATION

1. Drive the oil seal straight in until it protrudes from the case end equal to dimension "A" shown using Tool.


Dimension "A" : Within 0.5 mm (0.020 in) of flush with the case.

Tool number : ST30720000 (J-25405)

CAUTION:

- Apply multi-purpose grease onto oil seal lip.
- Do not reuse oil seal.

2. Install the drive shaft. Refer to [FAX-9. "Removal and Installation \(Left Side\)"](#), [FAX-10. "Removal and Installation \(Right Side\)"](#).
3. Check the transaxle fluid level. Refer to [TM-17. "Inspection"](#).



BACK-UP LAMP SWITCH

< ON-VEHICLE REPAIR >

[6MT: RS6F52A]

BACK-UP LAMP SWITCH

Removal and Installation

INFOID:000000000991878


For removal and installation of back-up lamp switch, refer to [TM-28, "Exploded View"](#).

Inspection

INFOID:000000000991879

- Check continuity.

| Gear position | Continuity |
|----------------|------------|
| Reverse | Yes |
| Except reverse | No |



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PARK/NEUTRAL POSITION SWITCH

< ON-VEHICLE REPAIR >

[6MT: RS6F52A]

PARK/NEUTRAL POSITION SWITCH

Removal and Installation

INFOID:000000000991880


For removal and installation of park/neutral position switch, refer to [TM-28, "Exploded View"](#).

Inspection

INFOID:000000000991881

- Check continuity.

| Gear position | Continuity |
|----------------|------------|
| Neutral | Yes |
| Except neutral | No |



CONTROL LINKAGE


< ON-VEHICLE REPAIR >

[6MT: RS6F52A]

CONTROL LINKAGE

Exploded View

INFOID:000000000991882



- | | | |
|-----------------------|------------------|----------------------------|
| 1. Control lever knob | 2. Control lever | 3. Control device assembly |
| 4. Retainer grommet | 5. Select cable | 6. Shift cable |
| 7. Lock plate | 8. Cable bracket | |

Removal and Installation

INFOID:000000000991883

REMOVAL

1. Shift control lever to the neutral position.
2. Remove the air filter assembly. Refer to [EM-18, "Removal and Installation"](#).
3. Remove the shift cable from the CVT shift lever and cable bracket.
4. Remove the select cable from the CVT select lever and cable bracket.
5. Remove the center console. Refer to [IP-16, "Disassembly and Assembly"](#).
6. Remove the shift cable from the control device assembly.
7. Remove the select cable from the control device assembly.
8. Remove the bracket covering the retainer grommet.
9. Remove the retainer grommet bolts and retainer grommet.

CONTROL LINKAGE

< ON-VEHICLE REPAIR >

[6MT: RS6F52A]

10. Remove the shift cable and select cable from the vehicle.
11. Remove the control device assembly bolts and the control device assembly.

INSTALLATION

Installation is in the reverse order of removal.


- After assembly, make sure control lever automatically returns to Neutral when it is moved to 1st, 2nd, or Reverse.
- When control lever is shifted to each position, make sure there is no binding or disconnection at each connection.

Adjustment


INFOID:000000000991884

SELECT CABLE ADJUSTMENT

1. Remove the select cable eye end (1) from the select lever (2) of the control device.
2. Slide the lock (A) on the select cable eye end (1) away from the cable end.
3. Turn the select cable eye end (1) over and push the stopper (B) to release the adjustment.




4. Install the select cable eye end (1) to the select lever (2) of the control device




5. Hold the shift lever with the gap between the reverse gate stopper and the shifter base at the specified distance (A).

Distance "A" : 6.3 – 7.0 mm (0.25 – 0.28 in)



6. Push the stopper (B) into the cable eye end housing (1).
7. Slide the lock (A) over the stopper (B).
8. Check for smooth gear select operation.



AIR BREATHER HOSE

< ON-VEHICLE REPAIR >


[6MT: RS6F52A]

AIR BREATHER HOSE

Exploded View


INFOID:000000000991885

QR engine models



- | | | |
|---------|----------------------|--|
| 1. Clip | 2. Air cleaner case | 3. Transaxle assembly |
| 4. Clip | 5. Air breather hose | A. Set paint mark and clip at front side |
- ←: Front

VQ engine models



- | | | |
|----------------------|-----------------------|--|
| 1. Air cleaner case | 2. Transaxle assembly | 3. Clip |
| 4. Air breather hose | 5. Clip | A. Set paint mark and clip at front side |
- ←: Front

Removal and Installation

INFOID:000000000991886

Refer to the figure for air breather hose removal and installation information.

CAUTION:

- Install air breather hose with paint mark and clip facing front.
- Install air breather hose onto air breather tube until overlap area reaches the spool.
- Install air breather hose to air cleaner case by fully inserting the clip.

AIR BREATHER HOSE

< ON-VEHICLE REPAIR >

[6MT: RS6F52A]

-
- **Make sure there are no pinched or restricted areas on air breather hose caused by bending or winding when installing it.**

TRANSAXLE ASSEMBLY

< REMOVAL AND INSTALLATION >


[6MT: RS6F52A]

REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000000991887



1. Transaxle assembly

2. LH engine mounting bracket

A. Refer to [TM-25, "Removal and Installation"](#)

Removal and Installation

INFOID:000000000991888

CAUTION:

If transaxle assembly is removed from the vehicle, always replace CSC (Concentric Slave Cylinder). Inserted CSC returns to the original position when removing transaxle assembly. Dust on clutch disc sliding parts may damage CSC seal and may cause clutch fluid leakage.

REMOVAL

1. Remove the engine and transaxle as an assembly. Refer to [EM-72, "Removal and Installation"](#) (QR25DE), [EM-199, "Removal and Installation"](#) (VQ35DE).

CAUTION:

Do not depress clutch pedal during removal procedure.

2. Disconnect the electrical connectors from the following:
 - Back-up lamp switch
 - Park/neutral position switch
3. Remove the harness from the transaxle.
4. Remove the starter motor. Refer to [STR-19, "Removal and Installation"](#) (QR25DE), [STR-37, "Removal and Installation"](#) (VQ35DE).
5. Remove the transaxle to engine and engine to transaxle bolts.

TRANSAXLE ASSEMBLY

[6MT: RS6F52A]

< REMOVAL AND INSTALLATION >

6. Separate the transaxle from the engine.
7. If necessary remove the following:
 - Air breather hose
 - Switches
 - LH engine mount
 - Brackets

INSTALLATION

Installation is in the reverse order of removal.


- If transaxle is removed from the vehicle, always replace CSC. Refer to [CL-12, "Removal and Installation"](#).
- When installing the transaxle assembly to the engine, install the bolts following the standard below.

CAUTION:

When installing transaxle assembly do not bring transaxle input shaft into contact with clutch cover.

QR engine models

| Bolt No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
|--|------------------------------|-----------|------------------------------|-----------|-----------|------------------------------|-----------|-----------|-----------|-----------|
| Bolt length "ℓ" mm (in) | 40 (1.57) | 82 (3.23) | 47 (1.85) | 47 (1.85) | 52 (2.05) | 40 (1.57) | 40 (1.57) | 40 (1.57) | 30 (1.18) | 30 (1.18) |
| Tightening torque N·m (kg - m, ft- lb) | 30 - 40 (3.1 - 4.1, 22 - 29) | | 70 - 80 (7.1 - 8.1, 52 - 59) | | | 30 - 40 (3.1 - 4.1, 22 - 29) | | | | |




VQ engine models

| Bolt No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
|--|------------------------------|------------|------------|-----------|-----------|------------------------------|-----------|-----------|-----------|-----------|
| Bolt length "ℓ" mm (in) | 52 (2.17) | 113 (2.76) | 113 (4.72) | 52 (1.77) | 52 (1.57) | 52 (1.38) | 40 (1.57) | 40 (1.57) | 40 (1.57) | 40 (1.57) |
| Tightening torque N·m (kg - m, ft- lb) | 70 - 80 (7.1 - 8.1, 52 - 59) | | | | | 30 - 40 (3.1 - 4.1, 22 - 29) | | | | |

TRANSAXLE ASSEMBLY

< REMOVAL AND INSTALLATION >

[6MT: RS6F52A]



- Bleed the air from the clutch hydraulic system. Refer to [CL-6, "Air Bleeding Procedure"](#).
- After installation, check oil level, and check for leaks and loose mechanisms. Refer to [TM-17, "Inspection"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


DISASSEMBLY AND ASSEMBLY

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000000991889

CASE AND HOUSING



- | | | |
|-------------------------------|----------------------------|--|
| 1. Differential side oil seal | 2. Clutch housing | 3. Input shaft oil seal |
| 4. Oil channel | 5. Oil gutter A | 6. Back-up lamp switch |
| 7. Plunger | 8. Gasket | 9. Plug |
| 10. Bore plug | 11. Striking rod oil seal | 12. Transaxle case |
| 13. Oil gutter B | 14. Air breather tube | 15. Park/Neutral position (PNP) switch |
| 16. Shifter lever oil seal | 17. Drain plug | 18. Magnet |
| 19. O-ring | 20. Plug (With ABS models) | 21. Speedometer pinion gear (Without ABS models) |

Apply Genuine Silicone RTV or an equivalent. Refer to [GI-15. "Recommended Chemical Products and Sealants"](#).


Refer to [GI-4. "Components"](#) for symbols not described on the above.

SHAFT AND GEAR

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]



- | | | |
|------------------------------|---|---------------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. 3rd needle bearing |
| 4. 3rd input gear | 5. 3rd inner baulk ring | 6. 3rd synchronizer cone |
| 7. 3rd outer baulk ring | 8. 3rd-4th spread spring | 9. 3rd-4th shifting insert |
| 10. 3rd-4th synchronizer hub | 11. 4th baulk ring | 12. 3rd-4th coupling sleeve |
| 13. 4th input gear bushing | 14. 4th needle bearing | 15. 4th input gear |
| 16. Thrust washer | 17. 5th input gear bushing | 18. 5th needle bearing |
| 19. 5th input gear | 20. 5th baulk ring | 21. 5th-6th spread spring |
| 22. 5th-6th shifting insert | 23. 5th-6th synchronizer hub | 24. 5th-6th coupling sleeve |
| 25. 6th baulk ring | 26. 6th input gear | 27. 6th needle bearing |
| 28. 6th input gear bushing | 29. Snap ring | 30. Input shaft rear bearing |
| 31. Oil channel | 32. Input shaft rear bearing adjusting shim | 33. Retaining pin |
| 34. Reverse idler shaft | 35. Thrust needle bearing | 36. Reverse idler gear needle bearing |
| 37. Reverse insert spring | 38. Reverse idler gear (Front) | 39. Reverse baulk ring |
| 40. Reverse coupling sleeve | 41. Reverse idler gear (Rear) | 42. Reverse idler gear adjusting shim |

■: Replace the parts as a set.

Refer to [GI-4, "Components"](#) for symbols not described on the above.


- Apply gear oil to gears, shafts, synchronizers, and bearings when assembly.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]



- | | | |
|----------------------------------|-------------------------------|---|
| 1. Mainshaft front bearing | 2. Mainshaft bearing retainer | 3. Mainshaft |
| 4. Reverse main gear | 5. 1st main gear | 6. 1st main gear bushing |
| 7. 1st needle bearing | 8. 1st inner baulk ring | 9. 1st synchronizer cone |
| 10. 1st outer baulk ring | 11. 1st-2nd spread spring | 12. 1st-2nd shifting insert |
| 13. 1st-2nd synchronizer hub | 14. 2nd outer baulk ring | 15. 2nd synchronizer cone |
| 16. 2nd inner baulk ring | 17. 1st-2nd coupling sleeve | 18. 2nd main gear bushing |
| 19. 2nd needle bearing | 20. 2nd main gear | 21. 3rd main gear |
| 22. 3rd-4th mainshaft spacer | 23. 4th main adjusting shim | 24. 4th main gear |
| 25. 5th main gear | 26. 5th-6th mainshaft spacer | 27. 6th main gear |
| 28. 6th main gear adjusting shim | 29. Mainshaft rear bearing | 30. Mainshaft C-ring |
| 31. C-ring holder | 32. Snap ring | 33. Mainshaft rear bearing adjusting shim |

■: Replace the parts as a set.

Refer to [GI-4. "Components"](#) for symbols not described on the above.


- Apply gear oil to gears, shafts, synchronizers, and bearings when assembly.

SHIFT FORK AND FORK ROD

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]



- | | | |
|------------------------|--------------------------------|--------------------------|
| 1. Clutch housing | 2. Retaining pin | 3. Reverse shift fork |
| 4. Reverse fork rod | 5. Return spring | 6. Striking rod assembly |
| 7. Striking rod shim | 8. Striking rod adjusting shim | 9. Shifter lever A |
| 10. Shifter lever B | 11. Guide bolt | 12. Selector lever |
| 13. Transaxle case | 14. 3rd-4th shift fork | 15. 3rd-4th fork rod |
| 16. 1st-2nd shift fork | 17. 1st-2nd fork rod | 18. 5th-6th shift fork |
| 19. 5th-6th fork rod | | |

Refer to [GI-4, "Components"](#) for the symbols in the figure.


FINAL DRIVE

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]




- | | | |
|---|--|--|
| 1. Differential side bearing outer race (clutch housing side) | 2. Differential side bearing (clutch housing side) | 3. Speedometer drive gear |
| 4. Differential case | 5. Final gear | 6. Differential side bearing (transaxle case side) |
| 7. Differential side bearing outer race (transaxle case side) | 8. Differential side bearing adjusting shim | 9. Pinion mate shaft |
| 10. Side gear | 11. Side gear thrust washer | 12. Pinion mate gear |
| 13. Pinion mate thrust washer | 14. Retaining pin | |

Refer to [GI-4, "Components"](#) for the symbols in the figure.

Disassembly

INFOID:000000000991890

1. Remove drain plug and gasket from clutch housing.
2. Remove plug mounting bolt and then plug (with ABS models) or speedometer pinion gear (without ABS models) and O-ring from clutch housing.




TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


3. Remove plug and gasket from transaxle case.




4. Remove park/neutral position (PNP) switch (1) from transaxle case.
5. Remove back-up lamp switch (2) and plunger from transaxle case.
CAUTION:
Be careful not to lose plunger.
6. Remove air breather tube (3) from transaxle case.




7. Remove guide bolt from transaxle case.



8. Remove retaining pin using a pin punch and then remove selector lever from transaxle case.



9. Remove transaxle case mounting bolts.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

10. Remove bore plug from transaxle case.


CAUTION:

- Be careful not to damage transaxle case.
- Access bore plug from cutout (A) of transaxle case when removing.



11. Remove transaxle case following the procedures below.

a. Expand snap ring at mainshaft rear bearing accessing from the bore plug hole. Then pull up transaxle case from clutch housing until snap ring comes off.




b. With shifter lever A (1) held in the position shown in the figure, remove transaxle case from clutch housing.

CAUTION:

Do not drop each adjusting shim.


NOTE:

Make sure to hold shifter lever A in the position shown in the figure. Otherwise transaxle case cannot be removed from clutch housing.



12. Remove oil gutter A (1) and oil gutter B (2) from transaxle case.

A : Tab of oil gutter




TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

13. Remove snap ring from transaxle case.




14. Remove retaining pin using a pin punch and then remove shifter lever A and shifter lever B from transaxle case.



15. Remove differential side bearing outer race from transaxle case using the puller and then remove differential side bearing adjusting shim from transaxle case.

CAUTION:


Be careful not to damage transaxle case.



16. Remove differential side oil seal from transaxle case.

CAUTION:


Be careful not to damage transaxle case.



17. Remove shifter lever oil seal (1) and striking rod oil seal (2) from transaxle case.

CAUTION:

Be careful not to damage transaxle case.




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

18. Remove striking rod shim (1), striking rod adjusting shim (2), mainshaft rear bearing adjusting shim (3), input shaft rear bearing adjusting shim (4), and reverse idler gear adjusting shim (5).




19. Remove retaining pin of reverse shift fork (1) using a pin punch.

2 : Reverse fork rod




20. Rotate striking lever of striking rod assembly as shown in the figure. Then rotate reverse fork rod to a position where bracket of reverse fork rod does not interfere with striking lever of striking rod assembly.

21. Pull out reverse shift fork and reverse fork rod.




22. Remove retaining pin of 5th-6th shift fork (1) using a pin punch.

2 : 5th-6th fork rod



23. Remove retaining pin of 3rd-4th shift fork (1) using a pin punch.

24. Pull out 3rd-4th fork rod (2).




TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

25. Pull out 5th-6th shift fork (1) and 5th-6th fork rod (2).




26. Pull out 3rd-4th shift fork (1).




27. Remove retaining pin of 1st-2nd shift fork (1) using a pin punch.

28. Pull out 1st-2nd shift fork and 1st-2nd fork rod (2).



29. Remove striking rod assembly (1).




30. Remove gear components from clutch housing in the following procedure.

a. Remove a set of input shaft assembly, main shaft assembly, and reverse idler gear assembly by tapping the tip of input shaft from the back of the clutch housing with a plastic hammer.

CAUTION:

Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.

b. Remove final drive assembly.



A
B
C
TM

E
F
G

H
I
J
K

L
M
N


O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

31. Remove magnet from clutch housing.




32. Remove mainshaft bearing retainer and then mainshaft front bearing from clutch housing using the puller.

CAUTION:

Be careful not to damage clutch housing, mainshaft front bearing, and oil channel.


33. Remove oil channel from clutch housing.



34. Remove differential side bearing outer race from clutch housing using the puller.

CAUTION:


Be careful not to damage clutch housing and differential side bearing outer race.



35. Remove input shaft oil seal from clutch housing.

CAUTION:


Be careful not to damage clutch housing.



36. Remove differential side oil seal from clutch housing.

CAUTION:

Be careful not to damage clutch housing.



TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

INFOID:00000000991891


Assembly

1. Install differential side oil seal (1) to clutch housing using the drift (A) [SST: ST33400001 (J-26082)].

Dimension "H" : -0.5 - 0.5 mm (-0.020 - 0.020 in)

CAUTION:

- Do not reuse differential side oil seal.
- When installing, do not incline differential side oil seal.
- Be careful not to damage clutch housing.




2. Install input shaft oil seal (1) to clutch housing using the drift (A) [SST: ST35321000 (—)].

Dimension "H" : 1.1 - 2.1 mm (0.043 - 0.083 in)

CAUTION:

- Do not reuse input shaft oil seal.
- When installing, do not incline input shaft oil seal.
- Be careful not to damage clutch housing.




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


3. Install differential side bearing outer race to clutch housing using the drifts.



4. Install oil channel (1) on mainshaft side.

CAUTION:


When installing oil channel, fit the rib (A) of oil channel into the processed area of the spot facing (B).



5. Install mainshaft front bearing to clutch housing using the drift.

CAUTION:

Be careful with the orientation of mainshaft front bearing.




6. Install mainshaft bearing retainer (1) to clutch housing and tighten mounting bolt to the specified torque.

2 : Mainshaft front bearing


3 : Oil channel

CAUTION:

Install with punched surface facing up.



7. Install magnet to clutch housing.




TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


8. Install final drive assembly into clutch housing.




9. Install input shaft assembly, mainshaft assembly, and reverse idler gear assembly into clutch housing.

CAUTION:

- Wrap a tape, etc. to the spline of input shaft so as not to damage the input shaft oil seal.
- Be careful with the orientation of reverse idler shaft.




10. Install striking rod assembly (1) into clutch housing.



CAUTION:

- Check that return spring is securely seated in the groove on return pin.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

11. Install 1st-2nd shift fork (1) and 1st-2nd fork rod (2) and then install retaining pin to 1st-2nd shift fork.

CAUTION:


- Do not reuse retaining pin.
- Be careful with the orientation of 1st-2nd shift fork and 1st-2nd fork rod.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of 1st-2nd shift fork.



12. Install 3rd-4th shift fork (1) to 3rd-4th coupling sleeve.

CAUTION:


- Be careful with the orientation of 3rd-4th shift fork.



13. Install 5th-6th shift fork (1) and 5th-6th fork rod (2) and then install retaining pin to 5th-6th shift fork.

CAUTION:


- Do not reuse retaining pin.
- Be careful with the orientation of 5th-6th shift fork and 5th-6th fork rod.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of 5th-6th shift fork.



14. Install 3rd-4th fork rod (2) and then install retaining pin to 3rd-4th shift fork (1).

CAUTION:


- Do not reuse retaining pin.
- Be careful with the orientation of 3rd-4th fork rod.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of 3rd-4th shift fork.



15. Install reverse shift fork (1) and reverse fork rod (2).

CAUTION:

- Be careful with the orientation of reverse shift fork and reverse fork rod.




TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

16. Rotate striking lever of striking rod assembly as shown in the figure. Then rotate reverse fork rod to a position where bracket of reverse fork rod does not interfere with striking lever of striking rod assembly.




17. Install retaining pin to reverse shift fork (1).

2 : Reverse fork rod

CAUTION:

- Do not reuse retaining pin.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of reverse shift fork.




18. Install selected differential side bearing adjusting shim(s) and differential side bearing outer race.
- For selection of adjusting shim(s), refer to [TM-49, "Adjustment"](#).
19. Install selected reverse idler gear adjusting shim onto reverse idler gear assembly.
- For selection of adjusting shim, refer to [TM-49, "Adjustment"](#).
20. Install selected input shaft rear bearing adjusting shim onto input shaft.
- For selection of adjusting shim, refer to [TM-49, "Adjustment"](#).
21. Install selected striking rod adjusting shim onto striking rod assembly.
- For selection of adjusting shim, refer to [TM-49, "Adjustment"](#).
22. Install shifter lever oil seal (1) and striking rod oil seal (2) to transaxle case using a suitable drift.

Dimension "H" : 0 - 1.0 mm (0 - 0.039 in)

CAUTION:

- Do not reuse shifter lever oil seal and striking rod oil seal.
- When installing, do not incline shifter lever oil seal and striking rod oil seal.
- Be careful not to damage transaxle case.



TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

23. Install differential side oil seal (1) to transaxle case using the drift (A) [SST: ST30720000 (J-25405)].

Dimension "H" : -0.5 - 0.5 mm (-0.020 - 0.020 in)

CAUTION:


- Do not reuse differential side oil seal.
- When installing, do not incline differential side oil seal.
- Be careful not to damage transaxle case.



24. Install shifter lever B (1) and shifter lever A (2) to transaxle case.

CAUTION:


Be careful with the orientation of shifter lever B and shifter lever A.



25. Install retaining pin to shifter lever A.

CAUTION:

- Do not reuse retaining pin.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of shifter lever A.



26. Install transaxle case following the procedures below.
- a. Install selected mainshaft rear bearing adjusting shim into transaxle case.
- For selection of adjusting shim, refer to [TM-49. "Adjustment"](#).

TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- b. Install oil gutter A (1) and oil gutter B (2) to transaxle case.

CAUTION:


Insert the tab (A) of oil gutter A and oil gutter B into transaxle case.



- c. Temporarily install snap ring of mainshaft rear bearing into transaxle case.

CAUTION:

Do not reuse snap ring.




- d. Apply recommended sealant to mating surface of clutch housing as shown in the figure.

• Use Genuine Silicone RTV or an equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).

CAUTION:

- Remove old sealant adhering to the mounting surfaces. Also remove any moisture, oil, or foreign material adhering to both mounting surfaces.
- Apply sealant so as not to break the bead.
- The width of sealant bead is 1 - 2 mm (0.04 - 0.08 in).
- The height of sealant bead is 0.4 - 1 mm (0.016 - 0.04 in).
- The overlap length of both ends of sealant bead is 3 - 5 mm (0.12 - 0.20 in).




- e. With shifter lever A (1) held in the position shown in the figure, temporarily assemble transaxle case to clutch housing.

CAUTION:

Be careful not to damage striking rod oil seal.

NOTE:

Make sure to hold shifter lever A in the position shown in the figure. Otherwise transaxle case cannot be installed to clutch housing.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

- f. While rotating shifter lever A (1) in the direction of the arrow in the figure, assemble transaxle case to clutch housing.

2 : Shifter lever B




- g. Accessing from the bore plug hole, expand snap ring at mainshaft rear bearing so that the ring catches the periphery of mainshaft rear bearing.
- h. Temporarily tighten transaxle case mounting bolts.



- i. Shift the shifter lever A (1) to 2nd gear position.

NOTE:

- The 2nd gear position is attained when shifter lever A is in the position shown in the figure.




TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- When transaxle is shifted to the 2nd gear position, mainshaft assembly is lifted.
- j. Seat snap ring in the groove on mainshaft rear bearing. If snap ring is not seated in the groove on mainshaft rear bearing, remove transaxle case and repeat the procedure from step d.




- k. Tighten transaxle case mounting bolts to the specified torque.



- l. Shift the shifter lever A (1) to neutral position.

NOTE:

The neutral position is attained when shifter lever A is in the position shown in the figure.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

27. Install bore plug to transaxle case using the drift.

CAUTION:


Do not reuse bore plug.



28. Install selector lever to transaxle case and then install retaining pin to selector lever.

CAUTION:

- Do not reuse retaining pin.
- Assemble retaining pin from the direction shown by the arrow in the figure until it becomes flush with the end surface of selector lever.



29. Install guide bolt following the procedures below.


- Shift the shifter lever A and selector lever to neutral position.
- Visually confirm from the guide bolt mounting hole (C) that the lever is securely set to neutral position (A). If it is not in the neutral position, repeat the procedure from step a.

1 : Guide bolt

CAUTION:

The guide groove (D) of striking rod assembly will be damaged when assembling guide bolt with the lever is in except neutral position (B).

- Check continuity between terminals of park/neutral position (PNP) switch to confirm it in the neutral position. If it is not in the neutral position, remove park/neutral position (PNP) switch and repeat the procedure from step a. Refer to [TM-20, "Inspection"](#).



TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- d. Install guide bolt to transaxle case and then tighten guide bolt to the specified torque.

CAUTION:

Do not reuse guide bolt.



30. Apply recommended sealant to threads of park/neutral position (PNP) switch (1). Then install it to transaxle case and tighten to the specified torque.

• Use Genuine Silicone RTV or an equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Remove old sealant and oil adhering to threads.

31. Install plunger to transaxle case.

32. Apply recommended sealant to threads of back-up lamp switch (2). Then install it to transaxle case and tighten to the specified torque.

• Use Genuine Silicone RTV or an equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Remove old sealant and oil adhering to threads.

33. Install air breather tube (3) to transaxle case.

CAUTION:



• Do not reuse air breather tube.

• Assemble air breather tube until its collar element contacts with transaxle case.

34. Install gasket onto plug and then install them into transaxle case. Tighten plug to the specified torque.

CAUTION:

Do not reuse gasket.



35. Install gasket onto drain plug and then install them into transaxle case. Tighten drain plug to the specified torque.

CAUTION:


Do not reuse gasket.

36. Install O-ring onto plug (with ABS models) or speedometer pinion gear (without ABS models) and then install it into clutch housing. Tighten mounting bolt to the specified torque.

CAUTION:

• Do not reuse O-ring.

• After oil is filled, tighten mounting bolt to specified torque.



Adjustment

INFOID:000000000991892

DIFFERENTIAL SIDE BEARING PRELOAD

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.

CAUTION:

Up to 2 adjusting shims can be selected.

- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to satisfy specification of preload for differential side bearing.

Preload : Refer to [TM-83, "Differential Side Bearing Preload"](#).


Dimension "L" = (L1 - L2) + Preload

L : Thickness of adjusting shim

L1 : Distance between transaxle case end face and mounting face of adjusting shim

L2 : Distance between differential side bearing outer race and clutch housing end face



- Using a depth micrometer and straightedge, measure dimension "L1" between transaxle case end face and mounting face of adjusting shim.
- Install differential side bearing outer race onto differential side bearing on final gear side. Holding lightly differential side bearing outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).




- Using a depth micrometer and straightedge as shown in the figure, measure dimension "L2" between differential side bearing outer race and clutch housing end face.

CAUTION:

"L2": Measure at 4 point by approximately 90 degrees and use the average value.



- Install selected differential side bearing adjusting shim and then install differential side bearing outer race using the drift.



REVERSE IDLER GEAR END PLAY

TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- When adjusting reverse idler gear end play, select adjusting shim for reverse idler gear. To select adjusting shim (1), measure clearance between transaxle case (2) and reverse idler gear (Rear) (3).

CAUTION:

Only 1 adjusting shim can be selected.

- Calculate dimension "Q" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for reverse idler gear.

End play : Refer to [TM-82, "End Play"](#).



Dimension "Q" = (Q1 - Q2) - End play

Q : Thickness of adjusting shim

Q1 : Distance between transaxle case end face and mounting face of adjusting shim

Q2 : Distance between clutch housing end face and end face of reverse idler gear (Rear)

- Using a depth micrometer and straightedge, measure dimension "Q1" between transaxle case end face and mounting face of adjusting shim.




- Using a depth micrometer and straightedge as shown in the figure, measure dimension "Q2" between clutch housing (1) end face and end face of reverse idler gear (Rear) (2).

CAUTION:

"Q2": Measure at 4 point by approximately 90 degrees and use the average value.

- Install selected reverse idler gear adjusting shim onto reverse idler gear (Rear).



INPUT SHAFT END PLAY

- When adjusting input shaft end play, select adjusting shim for input shaft rear bearing. To select adjusting shim, measure clearance between transaxle case and input shaft rear bearing.

CAUTION:


Only 1 adjusting shim can be selected.

- Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.

End play : Refer to [TM-82, "End Play"](#).

Dimension "O" = (O1 - O2) - End play

O : Thickness of adjusting shim



TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


O1 : Distance between transaxle case end face and mounting face of adjusting shim

O2 : Distance between clutch housing end face and end face of input shaft rear bearing

- Using a depth micrometer and straightedge, measure dimension "O1" between transaxle case end face and mounting face of adjusting shim.

CAUTION:

"O1": Measure at 4 point by approximately 90 degrees and use the average value.




- Using a depth micrometer and straightedge as shown in the figure, measure dimension "O2" between clutch housing end face and end face of input shaft rear bearing.

CAUTION:

"O2": Measure at 4 point by approximately 90 degrees and use the average value.

- Install selected input shaft rear bearing adjusting shim onto input shaft.



STRIKING ROD END PLAY

- When adjusting striking rod end play, select adjusting shim (1) for striking rod (2). To select adjusting shim, measure clearance between transaxle case (3) and striking rod shim (4).

CAUTION:

Only 1 adjusting shim can be selected.

- Calculate dimension "R" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for striking rod.


End play : Refer to [TM-82, "End Play"](#).

Dimension "R" = (R1 - R2) - End play

R : Thickness of adjusting shim

R1 : Distance between transaxle case end face and mounting face of adjusting shim


R2 : Distance between clutch housing end face and end face of striking rod shim



- Using a depth micrometer (A) and straightedge (B), measure dimension "R1" between transaxle case (1) end face and mounting face of adjusting shim.

CAUTION:

"R1": Measure at 4 point by approximately 90 degrees and use the average value.



TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

2. Using a depth micrometer (A) and straightedge (B) as shown in the figure, measure dimension "R2" between clutch housing (1) end face and end face of striking rod shim (2).

CAUTION:

- "R2": Measure at 4 point by approximately 90 degrees and use the average value.
- When measuring, be careful for the inclination of striking rod assembly and striking rod shim.

3. Install selected striking rod adjusting shim onto striking rod assembly.



MAINSHAFT END PLAY


- When adjusting mainshaft end play, select adjusting shim (1) for mainshaft rear bearing (2). To select adjusting shim, measure clearance "M" between transaxle case (3) and dummy adjusting shim (4) on mainshaft rear bearing.

- 5 : Snap ring
- 6 : Mainshaft

CAUTION:

Only 1 adjusting shim can be selected.

- Calculate dimension "P" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for mainshaft rear bearing.



End play : Refer to [TM-82, "End Play"](#).

Dimension "P" = (M + N) - End play

P : Thickness of adjusting shim

M : Distance between dummy adjusting shim on mainshaft rear bearing end face and transaxle case end face


N* : Thickness of dummy adjusting shim

*: Refer to the latest parts information to use a dummy adjusting shim of which part number is the thinnest in thickness.

1. Install transaxle case following the procedures below.
 - a. Temporarily install snap ring of mainshaft rear bearing into transaxle case.

CAUTION:

Do not reuse snap ring.




TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- b. Install dummy adjusting shim (1) to mainshaft assembly.




- c. With shifter lever A (1) held in the position shown in the figure, temporarily assemble transaxle case to clutch housing.

CAUTION:

Be careful not to damage striking rod oil seal.


NOTE:

Make sure to hold shifter lever A in the position shown in the figure. Otherwise transaxle case cannot be installed to clutch housing.




- d. While rotating shifter lever A (1) in the direction of the arrow shown in the figure, assemble transaxle case to clutch housing.

2 : Shifter lever B



- e. Accessing from the bore plug hole, expand snap ring at mainshaft rear bearing so that the ring catches the periphery of mainshaft rear bearing.

- f. Temporarily tighten transaxle case mounting bolts.



2. Shift the shifter lever A to 2nd gear position.


NOTE:

TRANSAXLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- The 2nd gear position is attained when shifter lever A (1) is in the position shown in the figure.




- When transaxle is shifted to the 2nd gear position, mainshaft assembly (1) is lifted.




3. Seat snap ring in the groove on mainshaft rear bearing. If snap ring is not seated in the groove on mainshaft rear bearing, remove transaxle case and repeat the procedure 1 from step c.
4. Shift the shifter lever A to 1st gear position, and then shift it to 2nd gear position. Repeat 3 times.

NOTE:

- The mainshaft rear bearing position will be stabilized by shifting between 1st gear position and 2nd gear position alternately.
- The 1st gear position is attained when shifter lever A (1) is in the position shown in the figure.



- When transaxle is shifted to the 1st gear position, mainshaft assembly (1) is declined.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


TRANSAXLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

5. Set the dial indicator (A) to dummy adjusting shim (1) through the bore plug mounting hole.

- 2 : Mainshaft rear bearing
3 : Snap ring



6. Shift the shifter lever A (1) to 2nd gear position (A), and then rotate it in the direction of the arrow (C) in the figure until it stops. Using this position as the reference point, measure the amount of movement when shifting shifter lever A to 1st gear position (B) and rotating it in the direction of the arrow (D) in the figure until it stops. This measurement is the "M" dimension.
7. When measurement "M" is 0 - 0.06 mm (0 - 0.0024 in), adjustment terminates, and the dummy adjusting shim becomes regular adjusting shim. Select adjusting shim from the computed expressions when measurement "M" is over 0.06 mm (0.0024 in).



INPUT SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

INPUT SHAFT AND GEAR

Exploded View

INFOID:000000000991893

Refer to [TM-28, "Exploded View"](#).


Disassembly

INFOID:000000000991894

1. Before disassembling, measure end play for 3rd, 4th, 5th, and 6th input gears.


End play standard value : Refer to [TM-82, "End Play"](#).

2. Remove oil channel.




3. Press out input shaft rear bearing using the drift and a puller.

4. Remove snap ring.




5. Press out 6th input gear, 6th needle bearing, 6th input gear bushing, 5th-6th synchronizer hub assembly, and 5th input gear using the drift (A) [SST: ST33052000 (-)] and a puller (B).

6. Remove 5th needle bearing.



7. Press out 5th input gear bushing, thrust washer, 4th input gear, 4th needle bearing, 4th input gear bushing, 3rd-4th synchronizer hub assembly, and 3rd input gear using the drift and a puller.

8. Remove 3rd needle bearing.




INPUT SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

9. Press out input shaft front bearing using a puller.




Assembly

INFOID:000000000991895


1. Install 3rd needle bearing to input shaft.
2. Install 3rd input gear, 3rd inner baulk ring, 3rd synchronizer cone, and 3rd outer baulk ring to input shaft.
CAUTION:
Replace 3rd inner baulk ring, 3rd synchronizer cone, and 3rd outer baulk ring as a set.
3. Install 3rd-4th spread spring, 3rd-4th shifting insert, and 3rd-4th synchronizer hub onto 3rd-4th coupling sleeve.

CAUTION:


- Be careful with orientation of 3rd-4th synchronizer hub.
- Do not reuse 3rd-4th synchronizer hub and 3rd-4th coupling sleeve.
- Replace 3rd-4th synchronizer hub and 3rd-4th coupling sleeve as a set.



- Be careful with orientation of 3rd-4th coupling sleeve.



- Be sure not to hook center projection of 2 spread springs on same shifting insert.



INPUT SHAFT AND GEAR


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


4. Press in 3rd-4th synchronizer hub assembly using the press stand.

CAUTION:

Align grooves of 3rd-4th shifting insert and 3rd outer baulk ring.



5. Press in 4th input gear bushing using the press stand.
6. Install 4th baulk ring.
7. Install 4th needle bearing and 4th input gear to input shaft.




8. Select thrust washer so that dimension "C2" satisfies the standard value below. Then install thrust washer onto input shaft.

Standard value for dimension "C2"


: Refer to [TM-83, "Dimension"](#).

CAUTION:

Only one thrust washer can be selected.



9. Press in 5th input gear bushing using the press stand.
CAUTION:
Do not reuse 5th input gear bushing.
10. Install 5th needle bearing and 5th input gear to input shaft.
11. Install 5th baulk ring.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

INPUT SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


12. Install 5th-6th synchronizer hub, 5th-6th spread spring, and 5th-6th shifting insert onto 5th-6th coupling sleeve.

CAUTION:

- Be careful with orientation of 5th-6th synchronizer hub.


A : Front side
B : Rear side

- Do not reuse 5th-6th synchronizer hub and 5th-6th coupling sleeve.
- Replace 5th-6th synchronizer hub and 5th-6th coupling sleeve as a set.




- Be careful with orientation of 5th-6th coupling sleeve.

A : 5th input gear side
B : 6th input gear side




- Be sure not to hook center projection of 2 spread springs on same shifting insert.



13. Press in 5th-6th synchronizer hub assembly using the press stand.

CAUTION:

- Align grooves of 5th-6th shifting insert and 5th baulk ring.




INPUT SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

14. Install 6th needle bearing, 6th input gear, 6th baulk ring onto 6th input gear bushing and then press in 6th bushing onto input shaft using the drift [SST: ST33200000 (J-26082)].




15. Install snap ring onto input shaft and make sure that end play (gap between snap ring and groove) of 6th input gear bushing satisfies the standard value.

End play standard value : Refer to [TM-82, "End Play"](#).

- If measurement is outside the standard range, select snap ring.

CAUTION:


Do not reuse snap ring.



16. Press in input shaft rear bearing using the drift [SST: ST30901000 (J-26010-01)].

CAUTION:

Install input shaft rear bearing with its brown surface facing the 6th input gear side.




17. Press in input shaft front bearing using the drifts.

A: Drift [SST: ST33052000 (—)]


B: Drift [SST: ST30032000 (J-26010-01)]

18. Install oil channel onto input shaft.



19. Check end play of 3rd, 4th, 5th, and 6th input gears.

End play standard value : Refer to [TM-82, "End Play"](#).



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

INPUT SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]


INFOID:00000000991896

Inspection

INPUT SHAFT AND GEAR

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, etc. of shaft
- Excessive wear, damage, peeling, etc. of gears




SYNCHRONIZER

Synchronizer Hub and Coupling Sleeve

Check items below. If necessary, replace them with new ones.


- Damage and excessive wear of contact surfaces of coupling sleeve, synchronizer hub and shifting insert
- Coupling sleeve and synchronizer hub must move smoothly.



Baulk Ring and Spread Spring

Check items below. If necessary, replace them with new ones.

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk Ring Clearance for Single Cone Synchronizer (4th, 5th, and 6th)

- Push baulk ring on the cone and measure the clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).



Baulk Ring Clearance for Double Cone Synchronizer (3rd)

INPUT SHAFT AND GEAR


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- Check the clearance between outer baulk ring, synchronizer cone, and inner baulk ring as follows.

CAUTION:

The clearances “A” and “B” are controlled with outer baulk ring, synchronizer cone, and inner baulk ring as a set. Replace them as a set if the clearances are outside the limit value.




1. Measure the clearance “A” at 2 points or more diagonally opposite using a dial indicator. And then calculate mean value.

Clearance “A”

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).




2. Measure the clearance “B” at 2 points or more diagonally opposite using a feeler gauge. And then calculate mean value.

Clearance “B”

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).


Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).



BEARING

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MAINSHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

MAINSHAFT AND GEAR

Exploded View

INFOID:000000000991897


Refer to [TM-28, "Exploded View"](#).

Disassembly


INFOID:000000000991898

1. Before disassembling, measure the end play of 1st and 2nd main gears.


End play standard value : Refer to [TM-82, "End Play"](#).




2. Remove snap ring.
3. Remove C-ring holder and then remove mainshaft C-ring.



4. Press out mainshaft rear bearing, 6th main gear adjusting shim, and 6th main gear using the drift and a puller.
5. Remove 5th-6th mainshaft spacer.



6. Press out 4th main gear and 5th main gear using the drift and a puller.
7. Remove 4th main gear adjusting shim.
8. Remove 3rd-4th mainshaft spacer.




MAINSHAFT AND GEAR


[6MT: RS6F52A]

< DISASSEMBLY AND ASSEMBLY >

9. Press out 3rd main gear and 2nd main gear using the drift (A) [SST: KV40105020 (—)] and a puller (B).
10. Remove 2nd needle bearing.




11. Press out 2nd main gear bushing, 1st-2nd synchronizer hub assembly, 1st main gear, 1st needle bearing, 1st main gear bushing, and reverse main gear using the drift [SST: KV40105020 (—)].



INFOID:000000000991899


Assembly

1. Press in reverse main gear using the drifts and the press stand.



CAUTION:

- Be careful with orientation of reverse main gear.
- Do not reuse reverse main gear.




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MAINSHAFT AND GEAR

[6MT: RS6F52A]

< DISASSEMBLY AND ASSEMBLY >


2. Press in 1st main gear bushing using the drifts and the press stand.
3. Install 1st needle bearing and then 1st main gear.




4. Install 1st-2nd spread spring, 1st-2nd shifting insert, and 1st-2nd synchronizer hub onto 1st-2nd coupling sleeve.

CAUTION:


- Be careful with orientation of 1st-2nd synchronizer hub.
- Do not reuse 1st-2nd synchronizer hub and 1st-2nd coupling sleeve.
- Replace 1st-2nd synchronizer hub and 1st-2nd coupling sleeve as a set.



- Be careful with orientation of 1st-2nd coupling sleeve.



- Be sure not to hook center projection of 2 spread springs on same 1st-2nd shifting insert.



MAINSHAFT AND GEAR


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

5. Install 1st inner baulk ring, 1st synchronizer cone, and 1st outer baulk ring onto mainshaft and then press in 1st-2nd synchronizer hub assembly onto mainshaft using the drifts and the press stand.

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side must have been removed.
- Be careful with orientation of coupling sleeve.
- Replace 1st inner baulk ring, 1st synchronizer cone, and 1st outer baulk ring as a set.




6. Press in 2nd main gear bushing using the drift and the press stand.
7. Install 2nd outer baulk ring, 2nd synchronizer cone, and 2nd inner baulk ring.

CAUTION:

Replace 2nd outer baulk ring, 2nd synchronizer cone, and 2nd inner baulk ring as a set.

8. Install 2nd needle bearing and 2nd main gear.




9. Press in 3rd main gear using the drift and the press stand.

CAUTION:

- Be careful with orientation of 3rd main gear.
- Do not reuse 3rd main gear.

10. Install 3rd-4th mainshaft spacer.




11. Select 4th main gear adjusting shim so that dimension "C1" satisfies the standard value below and install 4th main gear adjusting shim onto mainshaft.

Standard value for dimension "C1" : Refer to [TM-83](#), "[Dimension](#)".

CAUTION:

Only one adjusting shim can be selected.



MAINSHAFT AND GEAR


[6MT: RS6F52A]

< DISASSEMBLY AND ASSEMBLY >

12. Press in 4th main gear using the drifts.

CAUTION:

- Be careful with orientation of 4th main gear.
- Do not reuse 4th main gear.




13. Press in 5th main gear using the drifts.

CAUTION:

- Be careful with orientation of 5th main gear.
- Do not reuse 5th main gear.

14. Install 5th-6th mainshaft spacer.




15. Press in 6th main gear using the drifts.

A: Drift [SST: ST33200000 (J-26082)]

B: Drift [SST: ST30901000 (J-26010-01)]

CAUTION:

Do not reuse 6th main gear.



16. Select 6th main gear adjusting shim and then install it onto mainshaft.

- Calculate thickness "S" of 6th main gear adjusting shim following the procedure below so that end play dimension between 6th main gear and mainshaft rear bearing becomes the dimension shown below.

End play : Refer to [TM-82, "End Play"](#).

Dimension "S" = (S₁ - S₂) - End play

S : Thickness of adjusting shim


S₁ : Dimension from mainshaft standard face to mainshaft rear bearing press-fit end face

S₂ : Dimension from mainshaft standard face to 6th main gear end face

CAUTION:

Only one adjusting shim can be selected.

- Measure dimension "S₁" and "S₂" using a height gauge (A) and pick tester (B).
- Install selected 6th main gear adjusting shim to mainshaft.



MAINSHAFT AND GEAR


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

17. Press in mainshaft rear bearing using the drifts.

A: Drift [SST: ST30720000 (J-25405)]


B: Drift [SST: ST30901000 (J-26010-01)]



18. Install mainshaft C-ring onto mainshaft and check that end play of mainshaft rear bearing satisfies the standard value.

End play standard value : Refer to [TM-82, "End Play"](#).


- If measurement is outside the standard range, reselect mainshaft C-ring.



19. Install C-ring holder and then install snap ring.


CAUTION:

Do not reuse snap ring.



20. Check end play of 1st and 2nd main gears.

End play standard value : Refer to [TM-82, "End Play"](#).



Inspection

MAINSHAFT AND GEAR

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


MAINSHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.




SYNCHRONIZER

Synchronizer Hub and Coupling Sleeve

Check items below. If necessary, replace them with new ones.


- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly.



Baulk Ring and Spread Spring

Check items below. If necessary, replace them with new ones.

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk Ring Clearance for Triple Cone Synchronizer (1st and 2nd)

- Check the clearance between outer baulk ring, synchronizer cone, and inner baulk ring as follows.

CAUTION:

The clearances "A", "B", and "C" are controlled with outer baulk ring, synchronizer cone, and inner baulk ring as a set. Replace them as a set if the clearances are outside the limit value.



MAINSHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

1. Measure the clearance "A" at 2 points or more diagonally opposite using a feeler gauge (B) when pressing outer baulk ring (1), synchronizer cone (2), and inner baulk ring (3) toward gear taper cone (C). And then calculate mean value.

Clearance "A"

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).




JPDIC0034ZZ

2. Measure the clearance "B" at 2 points or more diagonally opposite using a feeler gauge. And then calculate mean value.

Clearance "B"

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).




PCIB1360E

3. Measure the clearance "C" at 2 points or more diagonally opposite using a feeler gauge (A) when pressing outer baulk ring (1), synchronizer cone (2), and inner baulk ring (3) toward gear taper cone (B). And then calculate mean value.

Clearance "C"

Standard value : Refer to [TM-82, "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82, "Baulk Ring Clearance"](#).




JPDIC0035ZZ

BEARING

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing



MTF0041D

REVERSE IDLER SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

REVERSE IDLER SHAFT AND GEAR

Exploded View

INFOID:000000000991901

Refer to [TM-28, "Exploded View"](#).

Disassembly

INFOID:000000000991902

1. Remove reverse idler gear (Rear), reverse coupling sleeve, and reverse insert spring simultaneously.
2. Remove reverse idler gear needle bearing.
3. Remove thrust needle bearing.
4. Remove reverse baulk ring.
5. Remove reverse idler gear (Front).
6. Remove reverse idler gear needle bearing.
7. Remove thrust needle bearing.
8. Remove retaining pin from reverse idler shaft.

Assembly

INFOID:000000000991903

Note the following, and assemble in the reverse order of disassembly.


CAUTION:

- Be careful with orientation of reverse insert spring.



: Front

- Do not reuse retaining pin.




Inspection

INFOID:000000000991904

REVERSE IDLER SHAFT AND GEAR

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.



SYNCHRONIZER

Synchronizer Hub and Coupling Sleeve


REVERSE IDLER SHAFT AND GEAR

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub of reverse idler gear (Rear), and insert spring.
- Coupling sleeve and synchronizer hub of reverse idler gear (Rear) must move smoothly.




A
B
C

TM

Baulk Ring

Check items below. If necessary, replace them with new ones.

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



E
F
G

H


Baulk Ring Clearance for Single Cone Synchronizer (Reverse)

- Push baulk ring on the cone and measure the clearance between baulk ring and cone. If the measurement is below limit, replace it with a new one.

Clearance

Standard value : Refer to [TM-82. "Baulk Ring Clearance"](#).

Limit value : Refer to [TM-82. "Baulk Ring Clearance"](#).



I
J
K

L

BEARING

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing.

M

N

O

P

FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

FINAL DRIVE

Exploded View


INFOID:000000000991905

Refer to [TM-28, "Exploded View"](#).


Disassembly

INFOID:000000000991906


1. Remove final gear mounting bolts and then separate the final gear from differential case.
2. Remove differential side bearing (clutch housing side) using the drift (A) [SST: ST33061000 (J-8107-2)] and pullers (B).



3. Remove differential side bearing (transaxle case side) using the drift and pullers.
4. Remove speedometer drive gear.




5. Remove retaining pin from differential case using a pin punch and then remove pinion mate shaft.
6. Rotate pinion mate gears and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from differential case.



Assembly

INFOID:000000000991907

1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.
2. Install side gear thrust washers and side gears into differential case.
3. While rotating pinion mate thrust washers and pinion mate gears, aligning them diagonally, install them into differential case.



FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

4. Insert pinion mate shaft into differential case.


CAUTION:

Be sure not to damage pinion mate thrust washers.



5. Measure end play of side gears following the procedure below. Then select side gear thrust washer.

- a. Put differential case vertically so that its side gear to be measured faces upward.
- b. Place the preload adapter and a dial indicator onto side gears.




- c. Move side gears up and down to measure the clearance and select thrust washer so that it satisfies the standard value.

Allowable Clearance between side gear and differential case with thrust washer : Refer to [TM-83, "Differential Side Gear Clearance"](#).

CAUTION:


- There should be no resistance and gears should rotate freely.
- Place differential case upside down. Measure the end play for opposite side-gears likewise securely.
- Only one thrust washer can be selected.



6. Install retaining pin into pinion mate shaft using a pin punch.

CAUTION:

Do not reuse retaining pin.




A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

7. Press in differential side bearing (transaxle case side) to differential case using the drifts.




8. Align and install speedometer drive gear onto differential case.




9. Press in differential side bearing (clutch housing side) to differential case using the drifts.

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: KV38102510 (—)]



10. Install final gear into differential case and tighten final gear mounting bolts to the specified torque.



Inspection

INSPECTION BEFORE DISASSEMBLY


INFOID:000000000991908

FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- Check the clearance between side gear and differential case as follows.
1. Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.




2. Put differential case vertically so that side gear to be measured faces upward.
3. Place the drift and a dial indicator onto side gear. Move side gear up and down, and measure the clearance.

Allowable Clearance between side gear and differential case with thrust washer : Refer to [TM-83, "Differential Side Gear Clearance"](#).

CAUTION:

There should be no resistance and gears should rotate freely.


4. If not within specification, adjust the clearance by changing side gear thrust washer thickness.
5. Turn differential case upside down and measure the clearance between side gear and differential case on the other side in the same way.



INSPECTION AFTER DISASSEMBLY

Gear, Washer, Shaft, And Case

- Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case. If necessary, replace with a new one.




Bearing

- Check for bearing damage and rough rotation. If necessary, replace with a new one.

CAUTION:

When replacing tapered roller bearing, replace outer and inner races as a set.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SHIFT FORK AND FORK ROD

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

SHIFT FORK AND FORK ROD

Exploded View


INFOID:000000000991909

Refer to [TM-28, "Exploded View"](#).

Disassembly

INFOID:000000000991910

1. Remove return spring to striking rod assembly.




Assembly

INFOID:000000000991911


1. Temporarily install return spring to striking rod assembly.

CAUTION:

Be careful with the orientation of return spring.




2. Attach one end of the return spring to striking interlock of striking rod assembly while holding return spring.



CAUTION:

- When installing, check that return spring is securely seated in the groove of striking interlock of striking rod assembly.



SHIFT FORK AND FORK ROD

< DISASSEMBLY AND ASSEMBLY >


[6MT: RS6F52A]

Inspection

INFOID:00000000991912


STRIKING ROD ASSEMBLY AND RETURN SPRING

- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.



FORK ROD AND SHIFT FORK

- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.



SHIFT FORK

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


SHIFT FORK AND FORK ROD

< DISASSEMBLY AND ASSEMBLY >

[6MT: RS6F52A]

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below.

| Item | One-side wear specification | Sliding width of new part |
|---------|-----------------------------|--|
| 1st-2nd | 0.2 mm (0.008 in) | 7.80 - 7.93 mm (0.3071 - 0.3122 in) |
| 3rd-4th | 0.2 mm (0.008 in) | 7.80 - 7.93 mm (0.3071 - 0.3122 in) |
| 5th-6th | 0.2 mm (0.008 in) | 6.10 - 6.23 mm (0.2402 - 0.2453 in) |
| Reverse | 0.2 mm (0.008 in) | 12.80 - 12.93 mm (0.5039 - 0.5091 in) |



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[6MT: RS6F52A]


SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:000000000991913

TRANSAXLE

| | | | | |
|--------------------------|--------------------------|--|-----------------------------|----|
| Engine type | | QR25DE | VQ35DE | |
| Transaxle model | | RS6F52A | | |
| Model code number | | JA60A | JA60B | |
| Number of speed | | 6 | | |
| Synchromesh type | | Warner | | |
| Shift pattern | |  PCIB1769E | | |
| Gear ratio | 1st | 3.500 | 3.154 | |
| | 2nd | 1.950 | | |
| | 3rd | 1.393 | | |
| | 4th | 1.056 | | |
| | 5th | 0.810 | | |
| | 6th | 0.673 | 0.630 | |
| | Reverse | 3.375 | 3.002 | |
| Number of teeth | Input gear | 1st | 14 | 13 |
| | | 2nd | 20 | |
| | | 3rd | 28 | |
| | | 4th | 36 | |
| | | 5th | 42 | |
| | | 6th | 49 | 46 |
| | | Reverse | 14 | 13 |
| | Main gear | 1st | 49 | 41 |
| | | 2nd | 39 | |
| | | 3rd | 39 | |
| | | 4th | 38 | |
| | | 5th | 34 | |
| | | 6th | 33 | 29 |
| | | Reverse | 38 | |
| | Reverse idler gear | Front | 37 | |
| Rear | | 38 | | |
| Oil level | mm (in) | 61.0 - 67.0 (2.402 - 2.638) | 66.5 - 71.5 (2.618 - 2.815) | |
| Oil capacity (Reference) | ℓ (US pt, Imp pt) | 1.7 (3-5/8, 3) | | |
| Remarks | Reverse synchronizer | Installed | | |
| | Double-cone synchronizer | 3rd | | |
| | Triple-cone synchronizer | 1st and 2nd | | |

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[6MT: RS6F52A]

FINAL GEAR

| | | | |
|-------------------|----------------------------|---------|--------|
| Engine type | | QR25DE | VQ35DE |
| Transaxle model | | RS6F52A | |
| Model code number | | JA60A | JA60B |
| Final gear ratio | | 3.813 | 4.133 |
| Number of teeth | Final gear/Pinion | 61/16 | 62/15 |
| | Side gear/Pinion mate gear | 14/10 | |

End Play

INFOID:000000000991914

Unit: mm (in)



| Items | Standard value |
|------------------------|--------------------------------|
| 1st main gear | 0.20 - 0.30 (0.0079 - 0.0118) |
| 2nd main gear | 0.06 - 0.16 (0.0024 - 0.0063) |
| 6th main gear | 0 - 0.1 (0 - 0.004) |
| 3rd input gear | 0.18 - 0.31 (0.0071 - 0.0122) |
| 4th input gear | 0.20 - 0.30 (0.0079 - 0.0118) |
| 5th input gear | 0.06 - 0.16 (0.0024 - 0.0063) |
| 6th input gear | 0.06 - 0.16 (0.0024 - 0.0063) |
| Reverse idler gear | 0.04 - 0.10 (0.0016 - 0.0039) |
| 6th input gear bushing | 0 - 0.1 (0 - 0.004) |
| Input shaft | 0 - 0.06 (0 - 0.0024) |
| Mainshaft | 0 - 0.06 (0 - 0.0024) |
| Mainshaft C-ring | 0 - 0.06 (0 - 0.0024) |
| Striking rod | 0.05 - 0.152 (0.0020 - 0.0060) |

Baulk Ring Clearance

INFOID:000000000991915

Unit: mm (in)

| Measurement point | Standard value | Limit value |
|---|---|---|
| 3rd (Double-cone synchronizer) | Clearance between synchronizer cone and inner baulk ring end face "A" | 0.6 - 0.8 (0.024 - 0.031) 0.2 (0.008) |
| | Clearance between outer baulk ring pawl and synchronizer cone "B" | 0.6 - 1.1 (0.024 - 0.043) 0.2 (0.008) |
| 1st and 2nd (Triple-cone synchronizer) | Clearance between synchronizer cone and clutch gear end face "A" | 0.6 - 1.2 (0.024 - 0.047) 0.3 (0.012) |
| | Clearance between outer baulk ring pawl and synchronizer cone "B" | 0.6 - 1.1 (0.024 - 0.043) 0.2 (0.008) |
| | Clearance between inner baulk ring and clutch gear end face "C" | 0.7 - 1.1 (0.028 - 0.043) 0.3 (0.012) |
| 4th | | 0.9 - 1.45 (0.035 - 0.057) 0.7 (0.028) |



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)



[6MT: RS6F52A]

| Measurement point | Standard value | Limit value |
|-------------------|----------------------------|-------------|
| 5th | 0.95 - 1.4 (0.037 - 0.055) | 0.7 (0.028) |
| 6th | 0.95 - 1.4 (0.037 - 0.055) | 0.7 (0.028) |
| Reverse | 0.95 - 1.4 (0.037 - 0.055) | 0.7 (0.028) |

Dimension

INFOID:000000000991916

Unit: mm (in)

| Measurement point | Standard value |
|---|---------------------------------|
| Mainshaft: Dimension "C1"  <p style="text-align: center;">SCIA1009E</p> | 173.85 - 173.95 (6.844 - 6.848) |
| Input shaft: Dimension "C2"  <p style="text-align: center;">SCIA1008E</p> | 154.7 - 154.8 (6.091 - 6.094) |

Differential Side Bearing Preload

INFOID:000000000991917

Unit: mm (in)

| | |
|---------------------------------------|-------------------------------|
| Differential side bearing preload: L* | 0.15 - 0.21 (0.0059 - 0.0083) |
|---------------------------------------|-------------------------------|

*: Install shims which are "deflection of differential case" + "L" in thickness.

Differential Side Gear Clearance

INFOID:000000000991918

Unit: mm (in)

| | |
|--|---------------------------|
| Allowable clearance between side gear and differential case with thrust washer | 0.1 - 0.2 (0.004 - 0.008) |
|--|---------------------------|

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow


INFOID:000000000991919

INTRODUCTION

The TCM receives a signal from the vehicle speed sensor, PNP switch and provides shift control or lock-up control via CVT solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the CVT system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the CVT system. The CVT system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose an error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the errors. A road test with CONSULT-III (or GST) or a circuit tester connected should be performed. Follow the "DETAILED FLOW".



Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Work Sheet" as shown on the example (Refer to [TM-85](#)) should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.



DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using diagnosis worksheet. Refer to [TM-85, "Diagnostic Work Sheet"](#).

>> GO TO 2..

2. CHECK SYMPTOM 1

Check the following items based on the information obtained from the customer.

- Fail-safe. Refer to [TM-193, "Fail-safe"](#).
- CVT fluid inspection. Refer to [TM-214, "Inspection"](#).
- Line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CVT: RE0F09B]

- Stall test. Refer to [TM-219. "Inspection and Judgment"](#).

>> GO TO 3..

3.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC.
 - Erase DTC. Refer to [TM-110. "Diagnosis Description"](#).

Is any DTC detected?

- YES >> GO TO 4..
NO >> GO TO 5..

4.PERFORM DIAGNOSTIC PROCEDURE

Perform "Diagnostic Procedure" for the displayed DTC.

>> GO TO 5..

5.CHECK SYMPTOM 2

Try to confirm the symptom described by the customer.

Is any malfunction present?

- YES >> GO TO 6..
NO >> **INSPECTION END**

6.RODE TEST

1. Perform "RODE TEST". Refer to [TM-223. "Description"](#).

>> GO TO 7..

7.CHECK SYMPTOM 3

Try to confirm the symptom described by the customer.

Is any malfunction present?

- YES >> GO TO 2..
NO >> **INSPECTION END**

Diagnostic Work Sheet

INFOID:000000000991920

INFORMATION FROM CUSTOMER

KEY POINTS

- **WHAT**..... Vehicle & CVT model
- **WHEN**..... Date, Frequencies
- **WHERE**..... Road conditions
- **HOW**..... Operating conditions, Symptoms

| | | |
|---------------------|--|-----------------|
| Customer name MR/MS | Model & Year | VIN |
| Trans. Model | Engine | Mileage |
| malfunction Date | Manuf. Date | In Service Date |
| Frequency | <input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day) | |

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[CVT: RE0F09B]

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Precaution for TCM and CVT Assembly Replacement

INFOID:000000000991921

CAUTION:

- Check if new data (Unit ID) are entered correctly after replacing CVT assembly and erasing data in TCM. (Connect CONSULT-III, and then turn ignition switch OFF.)
- When replacing CVT assembly or TCM, refer to the pattern table below and erase the EEPROM in the TCM if necessary.

EEPROM ERASING PATTERNS

| CVT assembly | TCM | Erasing EEPROM in TCM | Remarks |
|--------------|--------------|-----------------------|--|
| Replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. (CVT assembly must be replaced first.) |
| Not replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. |
| Replaced | Not replaced | Required | Required because data has been written in the EEPROM in the TCM and because the TCM cannot write data from the ROM assembly in the transmission. |

METHOD FOR ERASING THE EEPROM IN THE TCM

1. Turn ignition switch ON. Confirm that CONSULT-III is turned ON.
2. Move selector lever to "R" position.
3. Select "SELF-DIAG RESULTS".
4. Press the brake pedal and turn the brake switch ON.
5. Press the accelerator pedal (0.5/8 - 4/8 throttle) not to exceed the half, and hold it in the half or less open position. (This will set the closed throttle position signal to OFF and the wide open throttle position signal to OFF.)
6. Touch "ERASE" on CONSULT-III, and then touch "YES".
7. Wait 3 seconds and then release the accelerator pedal.
8. Turn ignition switch OFF.

METHOD FOR WRITING DATA FROM THE ROM ASSEMBLY IN THE TRANSAXLE

In the following procedure, the TCM reads data from the ROM assembly and writes it to the EEPROM in the TCM.

1. Erase the EEPROM in the TCM.
2. Move selector lever to "P" position.
3. Turn ignition switch ON.

CHECK METHOD

- Standard: About 2 seconds after the ignition switch ON, the CVT indicator lamp lights up for 2 seconds.
- Non-standard: Even after the ignition switch ON, the CVT indicator lamp does not light up after 2 seconds or illuminates immediately.

CAUTION:

Perform in the "P" or "N" position.

Action for Non-standard


- Replace the CVT assembly.
- Replace the TCM.

FUNCTION DIAGNOSIS

CVT SYSTEM

System Diagram

INFOID:000000000991922




Component Parts Location

INFOID:000000000991923

CVT SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



1. Control device assembly (Manual mode select switch and manual mode position select switch)
2. Accelerator pedal position (APP) sensor
3. Secondary speed sensor
4. CVT unit harness connector
5. TCM
6. Battery
7. Shift position indicator

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MECHANICAL SYSTEM


< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

MECHANICAL SYSTEM

Cross-Sectional View

INFOID:000000000991924



SCIA7859E

- | | | |
|--------------------------|----------------------|--------------------|
| 1. Converter housing | 2. Oil pump | 3. Forward clutch |
| 4. Reverse brake | 5. Planetary carrier | 6. Primary pulley |
| 7. Steel belt | 8. Sun gear | 9. Side cover |
| 10. Internal gear | 11. Secondary pulley | 12. Final gear |
| 13. Differential case | 14. Idler gear | 15. Reduction gear |
| 16. Taper roller bearing | 17. Output gear | 18. Parking gear |
| 19. Input shaft | 20. Torque converter | |


System Diagram

INFOID:000000000991925

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

System Description

INFOID:000000000991926

Transmits the power from the engine to the drive wheel.


Component Parts Location

INFOID:000000000991927

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



AW11A0001ZZ

- | | | |
|---|--|---------------------------|
| 1. Control device assembly (Manual mode select switch and manual mode position select switch) | 2. Accelerator pedal position (APP) sensor | 3. Secondary speed sensor |
| 4. CVT unit harness connector | 5. TCM | 6. Battery |
| 7. Shift position indicator | | |

Component Description

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >


[CVT: RE0F09B]

| Item | Function | A |
|------------------|--|-----------|
| Torque converter | The torque converter is the device that increases the engine torque as well as the conventional A/T and transmits it to the transaxle. | B |
| Oil pump | It is a parachoid type oil pump with the flow control valve directly controlled by the engine. Discharged oil from oil pump is transmitted to the control valve. It is used as the oil of primary and secondary pulley operation and the oil of clutch operation and the lubricant for each part. | C |
| Planetary gear | Perform the transmission of drive power and the switching of forward/backward movement. | TM |
| Forward clutch | | |
| Reverse brake | | |
| Primary pulley | It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the steel belt (the steel star wheels are placed continuously and the belt is guided with the multilayer steel rings on both sides). The groove width changes according to wrapping radius of steel belt and pulley from low status to over-drive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley. | E |
| Secondary pulley | | F |
| Steel belt | The drive power from the secondary pulley returns the deceleration gears [primary deceleration (output gear/idler gear pair) and secondary deceleration (reduction gear/final gear pair)]. It is transmitted from differential to drive wheel. | G |
| Output gear | | H |
| Idler gear | | I |
| Reduction gear | | J |
| Final gear | | K |
| Differential | | L |
| Manual shaft | | M |
| Parking rod | The parking rod rotates the parking pole and the parking pole engages with the parking gear when the manual shaft is in P position. As a result the parking gear and the output axis are fixed. | N |
| Parking pawl | | O |
| Parking gear | | P |

HYDRAULIC CONTROL SYSTEM

System Diagram

INFOID:000000000991929



System Description

INFOID:000000000991930

The hydraulic control mechanism consists of the oil pump directly driven by the engine, the hydraulic control valve that controls line pressure and transmission, and the input signal line.

LINE PRESSURE AND SECONDARY PRESSURE CONTROL


- When an input torque signal equivalent to the engine drive force is sent from the ECM to the TCM, the TCM controls the line pressure solenoid valve and secondary pressure solenoid valve.

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving state. Secondary pressure is controlled by decreasing line pressure.



Nomal Control

Optimize the line pressure and secondary pressure, depending on driving conditions, on the basis of the throttle position, the engine speed, the primary pulley (input) revolution speed, the secondary pulley (output) revolution speed, the brake signal, the PNP switch signal, the lock-up signal, the voltage, the target gear ratio, the fluid temperature, and the fluid pressure.

Feedback Control

When controlling the normal fluid pressure or the selected fluid pressure, the secondary pressure can be set more accurately by using the fluid pressure sensor to detect the secondary pressure and controlling the feedback.


Component Parts Location

INFOID:000000000991931

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



AW11A0001ZZ

- | | | |
|---|--|---------------------------|
| 1. Control device assembly (Manual mode select switch and manual mode position select switch) | 2. Accelerator pedal position (APP) sensor | 3. Secondary speed sensor |
| 4. CVT unit harness connector | 5. TCM | 6. Battery |
| 7. Shift position indicator | | |

Component Description

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

TRANSAXLE ASSEMBLY

| Name | Function |
|-----------------------------------|--|
| Torque converter regulator valve | Optimizes the supply pressure for the torque converter depending on driving conditions. |
| Pressure regulator valve | Optimizes the discharge pressure from the oil pump depending on driving conditions. |
| TCC control valve | <ul style="list-style-type: none"> Activates or deactivate the lock-up. Lock-up smoothly by opening lock-up operation excessively. |
| TCC solenoid valve | TM-137 |
| Shift control valve | Controls flow-in/out of line pressure from the primary pulley depending on the stroke difference between the stepping motor and the primary pulley. |
| Secondary valve | Controls the line pressure from the secondary pulley depending on operating conditions. |
| Clutch regulator valve | Adjusts the clutch operating pressure depending on operating conditions. |
| Secondary pressure solenoid valve | TM-147 |
| Line pressure solenoid valve | TM-141 |
| Step motor | TM-172 |
| Manual valve | Transmits the clutch operating pressure to each circuit in accordance with the selected position. |
| Select control valve | Engages forward clutch, reverse brake smoothly depending on select operation. |
| Select switch valve | Switches torque converter clutch solenoid valve control pressure use to torque converter clutch control valve or select control valve. |
| Lockup select solenoid valve | TM-169 |
| Primary speed sensor | TM-128 |
| Secondary speed sensor | TM-130 |
| PNP switch | TM-123 |
| Primary pulley | TM-92 |
| Secondary pulley | |
| Forward clutch | |
| Torque converter | |

EXCEPT TRANSAXLE ASSEMBLY


| Name | Function |
|-----------------------------------|---|
| TCM | Judges the vehicle driving status according to the signal from each sensor and controls the non-step transmission mechanism properly. |
| Accelerator pedal position sensor | TM-162 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL SYSTEM

System Diagram

INFOID:000000000991933



System Description

INFOID:000000000991934

The function of the TCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, and lock-up operation.
- Send required output signals to the step motor and the respective solenoids.

CONTROL SYSTEM OUTLINE

The CVT senses vehicle operating conditions through various sensors. It always controls the optimum shift position and reduces shifting and lock-up shocks.

| SENSORS (or SIGNAL) | | TCM | | ACTUATORS |
|--|---|--|---|--|
| PNP switch Accelerator pedal position signal Closed throttle position signal Engine speed signal CVT fluid temperature sensor Vehicle speed signal Manual mode signal Stop lamp switch signal Primary speed sensor Secondary speed sensor Primary pressure sensor Secondary pressure sensor | ⇒ | Shift control Line pressure control Primary pressure control Secondary pressure control Lock-up control Engine brake control Vehicle speed control Fail-safe control Self-diagnosis CONSULT-III communication line Duet-EA control CAN system On board diagnosis | ⇒ | Step motor Torque converter clutch solenoid valve Lock-up select solenoid valve Line pressure solenoid valve Secondary pressure solenoid valve Manual mode indicator Shift position indicator CVT indicator lamp Starter relay |

INPUT/OUTPUT SIGNAL OF TCM

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

| | Control item | Fluid pressure control | Select control | Shift control | Lock-up control | CAN communication control | Fail-safe function ^(*2) |
|--------|---|------------------------|----------------|---------------|-----------------|---------------------------|------------------------------------|
| Input | PNP switch | X | X | X | X | X | X |
| | Accelerator pedal position signal ^(*1) | X | X | X | X | X | X |
| | Closed throttle position signal ^(*1) | X | | X | X | X | |
| | Engine speed signal ^(*1) | X | X | | X | X | X |
| | CVT fluid temperature sensor | X | X | X | X | | X |
| | Manual mode signal ^(*1) | X | | X | X | X | X |
| | Stop lamp switch signal ^(*1) | X | | X | X | X | |
| | Primary speed sensor | X | | X | X | X | X |
| | Secondary speed sensor | X | X | X | X | X | X |
| | Primary pressure sensor | X | | X | | | |
| | Secondary pressure sensor | X | | X | | | X |
| | TCM power supply voltage signal | X | X | X | X | X | X |
| Output | Step motor | | | X | | | X |
| | TCC solenoid valve | | X | | X | | X |
| | Lock-up select solenoid valve | | X | | X | | X |
| | Line pressure solenoid valve | X | X | X | | | X |
| | Secondary pressure solenoid valve | X | | X | | | X |

*1: Input by CAN communications.

*2: If these input and output signals are different, the TCM triggers the fail-safe function.

Component Parts Location


INFOID:000000000991935

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



AW11A0001ZZ

- | | | |
|---|--|---------------------------|
| 1. Control device assembly (Manual mode select switch and manual mode position select switch) | 2. Accelerator pedal position (APP) sensor | 3. Secondary speed sensor |
| 4. CVT unit harness connector | 5. TCM | 6. Battery |
| 7. Shift position indicator | | |

Component Description

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

TRANSAXLE ASSEMBLY

| Name | Function |
|-----------------------------------|------------------------|
| PNP switch | TM-123 |
| CVT fluid temperature sensor | TM-126 |
| Primary speed sensor | TM-128 |
| Secondary speed sensor | TM-130 |
| Primary pressure sensor | TM-130 |
| Secondary pressure sensor | TM-152 |
| Step motor | TM-172 |
| TCC solenoid valve | TM-137 |
| Lock-up select solenoid valve | TM-169 |
| Line pressure solenoid valve | TM-141 |
| Secondary pressure solenoid valve | TM-147 |

EXCEPT TRANSAXLE ASSEMBLY

| Name | Function |
|------------------|---|
| TCM | Optimally controls continuously variable transmission system by judging driving conditions based on signals from each sensor. |
| Stop lamp switch | TM-121 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

LOCK-UP AND SELECT CONTROL SYSTEM


System Diagram



System Description

INFOID:000000000991938

- The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.
- The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM. The torque converter clutch control valve engages or releases the torque converter clutch piston.
- When shifting between “N” (“P”) ↔ “D” (“R”), torque converter clutch solenoid controls engagement power of forward clutch and reverse brake.
- The lock-up applied gear range was expanded by locking up the torque converter at a lower vehicle speed than conventional CVT models.



TORQUE CONVERTER CLUTCH AND SELECT CONTROL VALVE CONTROL

Lock-up Released

In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid and the lock-up apply pressure is drained.

In this way, the torque converter clutch piston is not coupled.

Lock-up Applied

In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid and lock-up apply pressure is generated.

In this way, the torque converter clutch piston is pressed and coupled.

Select Control

When shifting between “N” (“P”) ↔ “D” (“R”), optimize the operating pressure on the basis of the throttle position, the engine speed, and the secondary pulley (output) revolution speed to lessen the shift shock.


Component Parts Location

INFOID:000000000991939

LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]



- | | | |
|---|--|---------------------------|
| 1. Control device assembly (Manual mode select switch and manual mode position select switch) | 2. Accelerator pedal position (APP) sensor | 3. Secondary speed sensor |
| 4. CVT unit harness connector | 5. TCM | 6. Battery |
| 7. Shift position indicator | | |

Component Description

INFOID:000000000991940

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

TRANSAXLE ASSEMBLY

| Name | Function | |
|----------------------------------|------------------------|-----------------------|
| Torque converter regulator valve | | |
| TCC control valve | | |
| Select control valve | | TM-96 |
| Select switch valve | | |
| Manual valve | | |
| TCC solenoid valve | TM-137 | |
| Lock-up select solenoid valve | TM-169 | |
| Primary speed sensor | TM-128 | |
| Secondary speed sensor | TM-130 | |
| CVT fluid temperature sensor | TM-126 | |
| PNP switch | TM-123 | |
| Forward clutch | TM-96 | |
| Reverse brake | | |
| Torque converter | | |

EXCEPT TRANSAXLE ASSEMBLY

| Name | Function |
|-----------------------------------|------------------------|
| TCM | TM-96 |
| Accelerator pedal position sensor | TM-162 |


SHIFT MECHANISM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

SHIFT MECHANISM

System Diagram



NOTE:

The gear ratio is set for every position separately.


System Description

INFOID:000000000991942

In order to select the gear ratio which can obtain the driving force in accordance with driver's intention and the vehicle condition, TCM monitors the driving conditions, such as the vehicle speed and the throttle position and selects the optimum gear ratio, and determines the gear change steps to the gear ratio. Then send the command to the step motor, and control the flow-in/flow-out of line pressure from the primary pulley to determine the position of the moving-pulley and control the gear ratio.


“D” POSITION

Shifting over all the ranges of gear ratios from the lowest to the highest.



“M” POSITION

When the selector lever is put in the manual shift gate side, the fixed changing gear line is set. By moving the selector lever to + side or - side, the manual mode switch is changed over, and shift change like M/T becomes possible following the changing gear set line step by step.



DOWNHILL ENGINE BRAKE CONTROL (AUTO ENGINE BRAKE CONTROL)

When downhill is detected with the accelerator pedal released, the engine brake will be strengthened up by downshifting so as not to accelerate the vehicle more than necessary.

ACCELERATION CONTROL

SHIFT MECHANISM


< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

According to vehicle speed and a change of accelerator pedal angle, driver's request for acceleration and driving scene are judged. This function assists improvement in acceleration feeling by making the engine speed proportionate to the vehicle speed. And a shift map which can gain a larger driving force is available for compatibility of mileage with driveability.

Component Parts Location

INFOID:000000000991943



AWIIA0001ZZ

SHIFT MECHANISM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

- | | | | |
|---|--|---------------------------|---|
| 1. Control device assembly (Manual mode select switch and manual mode position select switch) | 2. Accelerator pedal position (APP) sensor | 3. Secondary speed sensor | A |
| 4. CVT unit harness connector | 5. TCM | 6. Battery | B |
| 7. Shift position indicator | | | |

Component Description

INFOID:000000000991944

TRANSAXLE ASSEMBLY

| Item | Functoin | TM |
|----------------------|------------------------|----|
| PNP switch | TM-123 | |
| Primary speed sensor | TM-128 | |
| Secndry speed sensor | TM-130 | E |
| Step motor | TM-172 | |
| Shift control valve | TM-96 | F |
| Primary pulley | TM-92 | |
| Secondary pulley | TM-92 | |

EXCEPT TRANSAXLE ASSEMBLY

| Item | Functoin | H |
|------|-----------------------|---|
| TCM | TM-96 | |

TM

E

F

G

H

I

J

K

L

M

N

O

P


SHIFT LOCK SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

SHIFT LOCK SYSTEM

System Diagram




System Description

INFOID:000000000991946

The selector lever cannot be shifted from "P" position to any other position unless the ignition switch is in the ON position and the brake pedal is depressed.

Component Parts Location

INFOID:000000000991947



- | | | |
|---|--|--|
| 1. BCM (view with instrument panel removed) | 2. Steering column | 3. Stop lamp switch |
| 4. Shift lock release button | 5. Detention switch (for manual shift) | 6. Shift lock solenoid/Detent switch (key) |
| 7. CVT device connector | | |

Component Description

INFOID:000000000991948

SHIFT LOCK SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

| Component | | Function |
|------------------|---------------------------|--|
| CVT device | Shift lock solenoid | TM-108. "System Description" |
| | Lock plate | The lock plate restricts the position pin stroke by selector button operation according to the shift lock unit status. |
| | Position pin | The position pin, linking with the selector button, restricts the selector lever movement. |
| | Shift lock release button | Pressing the shift lock release button cancels the shift lock forcibly. |
| Stop lamp switch | | TM-121. "Description" |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:000000000991949

DESCRIPTION

The CVT system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory, and the TCM memory.

The second is the TCM original self-diagnosis performed by the TCM. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

OBD-II FUNCTION

The ECM provides emission-related on board diagnostic (OBD-II) functions for the CVT system. One function is to receive a signal from the TCM used with OBD-related parts of the CVT system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in "One or Two Trip Detection Logic" when a malfunction is sensed in relation to CVT system parts.

ONE OR TWO TRIP DETECTION LOGIC OF OBD-II

One Trip Detection Logic

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

Two Trip Detection Logic

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — 1st trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — 2nd trip

The "trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II DIAGNOSTIC TROUBLE CODE (DTC)

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

( with **CONSULT-III** or ( **GST**) CONSULT-III or GST (Generic Scan Tool) Examples: P0705, P0720 etc.

These DTC are prescribed by SAE J2012.

(CONSULT-III also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**

CONSULT-III can identify them as shown below, therefore, CONSULT-III (if available) is recommended.

- DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT-III. Time data indicates how many times the vehicle was driven after the last detection of a DTC.
- If the DTC is being detected currently, the time data will be "0".
- If a 1st trip DTC is stored in the ECM, the time data will be "1".

Freeze Frame Data and 1st Trip Freeze Frame Data

- The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-III or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-III screen, not on the GST. For details, refer to [EC-130, "CONSULT-III Function"](#).

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data, and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items | |
|----------|----------------------------|--|
| 1 | Freeze frame data | Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175 |
| 2 | | Except the above items (Includes CVT related items) |
| 3 | 1st trip freeze frame data | |

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

How to Erase DTC

- The diagnostic trouble code can be erased by CONSULT-III, GST or ECM DIAGNOSTIC TEST MODE as described following.
 - **If the battery cable is disconnected, the diagnostic trouble code will be lost within 24 hours.**
 - **When you erase the DTC, using CONSULT-III or GST is easier and quicker than switching the mode selector on the ECM.**
- The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-502. "DTC Index"](#).
 - **Diagnostic trouble codes (DTC)**
 - **1st trip diagnostic trouble codes (1st trip DTC)**
 - **Freeze frame data**
 - **1st trip freeze frame data**
 - **System readiness test (SRT) codes**
 - **Test values**

How to Erase DTC (With CONSULT-III)

The emission related diagnostic information in the TCM and ECM can be erased by selecting "ALL Erase" in the "Description" of "FINAL CHECK" mode with CONSULT-III.

How to Erase DTC (With GST)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Select Mode 4 with GST (Generic Scan Tool). For details, refer to [EC-140. "Diagnosis Tool Function"](#).

MALFUNCTION INDICATOR LAMP (MIL)

Description

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [MWI-11, "WARNING LAMPS/INDICATOR LAMPS : System Diagram"](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



DIAGNOSIS SYSTEM (TCM)

CONSULT-III Function (TRANSMISSION)

INFOID:000000000991950

CONSULT-III can display each diagnostic item using the diagnostic test modes shown below.

FUNCTION

| Diagnostic test mode | Function |
|--------------------------------|---|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III. |
| Self-diagnostic results | Self-diagnostic results can be read and erased quickly. |
| Data monitor | Input/Output data in the TCM can be read. |
| CAN diagnostic support monitor | The results of transmit/receive diagnosis of CAN communication can be read. |
| CALIB data | Characteristic information for TCM and CVT assembly can be read. Do not use, but displayed. |
| Function test | Performed by CONSULT-III instead of a technician to determine whether each system is "OK" or "NG". |
| ECU part number | TCM part number can be read. |

WORK SUPPORT MODE

Display Item List

| Item name | Description |
|-------------------------|---|
| ENGINE BRAKE ADJ. | The engine brake level setting can be canceled. |
| CONFORM CVTF DETERIORTN | The CVT fluid deterioration level can be checked. |

Engine Brake Adjustment

“ENGINE BRAKE LEVEL”

0 :Initial set value (Engine brake level control is activated)

OFF :Engine brake level control is deactivated.

CAUTION:

Mode of “+1” “0” “-1” “-2” “OFF” can be selected by pressing the “UP” “DOWN” on CONSULT-III screen. However, do not select mode other than “0” and “OFF”. If the “+1” or “-1” or “-2” is selected, that might cause the irregular driveability.

Check CVT Fluid Deterioration Date

“CVTF DETERIORATION DATE”

More than 210000 :It is necessary to change CVT fluid.

Less than 210000 :It is not necessary to change CVT fluid.

CAUTION:

Touch “CLEAR” after changing CVT fluid, and then erase “CVTF DETERIORATION DATE”.

SELF-DIAGNOSTIC RESULT MODE

After performing self-diagnosis, place check marks for results on the [TM-85. "Diagnostic Work Sheet"](#). Reference pages are provided following the items.

Display Items List

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

X: Applicable —: Not applicable

| Items (CONSULT-III screen terms) | Malfunction is detected when... | TCM self-diagnosis | OBD-II (DTC) | Reference page |
|----------------------------------|---|---------------------------------|--|------------------------|
| | | "TRANSMISSION" with CONSULT-III | MIL*, "ENGINE" with CONSULT-III or GST | |
| CAN COMM CIRCUIT | When TCM is not transmitting or receiving CAN communication signal for 2 seconds or more. | U1000 | U1000 | TM-118 |
| STARTER RELAY/CIRC | If this signal is ON other than in "P" or "N" position, this is judged to be a malfunction. (And if it is OFF in "P" or "N" position, this is judged to be a malfunction too.) | P0615 | — | TM-119 |
| BRAKE SW/CIRC | When the brake switch does not switch to ON or OFF. | P0703 | — | TM-121 |
| PNP SW/CIRC | <ul style="list-style-type: none"> PNP switch 1-4 signals input with impossible pattern. PNP switch 3 monitor terminal open or short circuit. | P0705 | P0705 | TM-123 |
| ATF TEMP SEN/CIRC | During running, the CVT fluid temperature sensor signal voltage is excessively high or low. | P0710 | P0710 | TM-126 |
| INPUT SPD SEN/CIRC | <ul style="list-style-type: none"> Input speed sensor (primary speed sensor) signal is not input due to an open circuit. An unexpected signal is input when vehicle is being driven. | P0715 | P0715 | TM-128 |
| VEH SPD SEN/CIR AT | <ul style="list-style-type: none"> Signal from vehicle speed sensor CVT [Output speed sensor (Secondary speed sensor)] not input due to open or short circuit. Unexpected signal input during running. | P0720 | P0720 | TM-130 |
| ENGINE SPEED SIG | TCM does not receive the CAN communication signal from the ECM. | P0725 | — | TM-133 |
| BELT DAMG | Unexpected gear ratio detected. | P0730 | — | TM-135 |
| TCC SOLENOID/CIRC | Normal voltage not applied to solenoid due to open or short circuit. | P0740 | P0740 | TM-137 |
| A/T TCC S/V FNCTN | <ul style="list-style-type: none"> CVT cannot perform lock-up even if electrical circuit is good. TCM detects as irregular by comparing difference value with slip rotation. There is a great difference between engine speed and primary speed when TCM lock-up signal is on. | P0744 | P0744 | TM-139 |
| L/PRESS SOL/CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to open or short circuit. TCM detects as irregular by comparing target value with monitor value. | P0745 | P0745 | TM-141 |
| PRS CNT SOL/A FCTN | Unexpected gear ratio was detected in the LOW side due to excessively low line pressure. | P0746 | P0746 | TM-143 |
| PRS CNT SOL/B FCTN | Secondary pressure is too high or too low compared with the commanded value while driving. | P0776 | P0776 | TM-145 |
| PRS CNT SOL/B CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. | P0778 | P0778 | TM-147 |
| MANUAL MODE SWITCH | When an impossible pattern of switch signals is detected, a malfunction is detected. | P0826 | — | TM-149 |
| TR PRS SENS/A CIRC | Signal voltage of the transmission fluid pressure sensor A (secondary pressure sensor) is too high or too low while driving. | P0840 | P0840 | TM-152 |
| PRESS SEN/FNCTN | Correlation between the values of the transmission fluid pressure sensor A (secondary pressure sensor) and the transmission fluid pressure sensor B (primary pressure sensor) is out of specification. | P0841 | — | TM-154 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

| Items (CONSULT-III screen terms) | Malfunction is detected when... | TCM self-diagnosis | OBD-II (DTC) | Reference page |
|---|--|---------------------------------|--|------------------------|
| | | "TRANSMISSION" with CONSULT-III | MIL*, "ENGINE" with CONSULT-III or GST | |
| TR PRS SENS/B CIRC | Signal voltage of the transmission fluid pressure sensor B (primary pressure sensor) is too high or too low while driving. | P0845 | P0845 | TM-156 |
| SEC/PRESS DOWN | Secondary fluid pressure is too low compared with the commanded value while driving. | P0868 | — | TM-158 |
| TCM-POWER SUPPLY | <ul style="list-style-type: none"> When the power supply to the TCM is cut OFF, for example because the battery is removed, and the self-diagnosis memory function stops. This is not a malfunction message (Whenever shutting OFF a power supply to the TCM, this message appears on the screen). | P1701 | — | TM-160 |
| TP SEN/CIRC A/T | TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM. | P1705 | — | TM-162 |
| ESTM VEH SPD SIG | <ul style="list-style-type: none"> CAN communication with the ABS actuator and the electric unit (control unit) is malfunctioning. There is a great difference between the vehicle speed signal from the ABS actuator and the electric unit (control unit), and the vehicle speed sensor signal. | P1722 | — | TM-164 |
| CVT SPD SEN/ FNCTN | <p>A rotation sensor error is detected because the gear does not change in accordance with the position of the stepping motor.</p> <p>CAUTION: One of the "P0720 VEH SPD SEN/CIR AT", the "P0715 INPUT SPD SEN/CIRC" or the "P0725 ENGINE SPEED SIG" is displayed with the DTC at the same time.</p> | P1723 | — | TM-166 |
| ELEC TH CONTROL | The electronically controlled throttle for ECM is malfunctioning. | P1726 | — | TM-168 |
| LU-SLCT SOL/ CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. | P1740 | P1740 | TM-169 |
| L/PRESS CONTROL | TCM detects the unexpected line pressure. | P1745 | — | TM-171 |
| STEP MOTR CIRC | Each coil of the step motor is not energized properly due to an open or a short. | P1777 | P1777 | TM-172 |
| STEP MOTR/FNC | There is a great difference between the number of steps for the stepping motor and for the actual gear ratio. | P1778 | P1778 | TM-175 |
| NO DTC IS DETECTED: FURTHER TESTING MAY BE REQUIRED | No NG item has been detected. | X | X | — |

*: Refer to [TM-110, "Diagnosis Description"](#).

DATA MONITOR MODE

Display Items List

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

X: Standard, —: Not applicable, ▼: Option

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|------------------------|-----------------------------|-------------------|--------------------------------|--|
| | ECU IN- PUT SIG- NALS | MAIN SIG- NALS | SELEC- TION FROM MENU | |
| VSP SENSOR (km/h) | X | — | ▼ | Output speed sensor (secondary speed sensor) |
| ESTM VSP SIG (km/h) | X | — | ▼ | — |
| PRI SPEED SEN (rpm) | X | — | ▼ | — |
| ENG SPEED SIG (rpm) | X | — | ▼ | — |
| SEC HYDR SEN (V) | X | — | ▼ | — |
| PRI HYDR SEN (V) | X | — | ▼ | — |
| ATF TEMP SEN (V) | X | — | ▼ | CVT fluid temperature sensor |
| VIGN SEN (V) | X | — | ▼ | — |
| VEHICLE SPEED (km/h) | — | X | ▼ | Vehicle speed recognized by the TCM. |
| PRI SPEED (rpm) | — | X | ▼ | Primary pulley speed |
| SEC SPEED (rpm) | — | — | ▼ | Secondary pulley speed |
| ENG SPEED (rpm) | — | X | ▼ | — |
| SLIP REV (rpm) | — | X | ▼ | Difference between engine speed and primary pulley speed. |
| GEAR RATIO | — | X | ▼ | — |
| G SPEED (G) | — | — | ▼ | — |
| ACC PEDAL OPEN (0.0/8) | X | X | ▼ | Degree of opening for accelerator recognized by the TCM. For fail-safe operation, the specific value used for control is displayed. |
| TRQ RTO | — | — | ▼ | — |
| SEC PRESS (MPa) | — | X | ▼ | — |
| PRI PRESS (MPa) | — | X | ▼ | — |
| ATF TEMP | — | X | ▼ | — |
| DSR REV (rpm) | — | — | ▼ | — |
| DGEAR RATIO | — | — | ▼ | — |
| DSTM STEP (step) | — | — | ▼ | — |
| STM STEP (step) | — | X | ▼ | — |
| LU PRS (MPa) | — | — | ▼ | — |
| LINE PRS (MPa) | — | — | ▼ | — |
| TGT SEC PRESS (MPa) | — | — | ▼ | — |
| ISOLT1 (A) | — | X | ▼ | Torque converter clutch solenoid valve output current |
| ISOLT2 (A) | — | X | ▼ | Pressure control solenoid valve A (line pressure solenoid valve) output current |
| ISOLT3 (A) | — | X | ▼ | Pressure control solenoid valve B (secondary pressure solenoid valve) output current |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|-------------------------|------------------------|--------------|---------------------|---|
| | ECU INPUT SIGNALS | MAIN SIGNALS | SELECTION FROM MENU | |
| SOLMON1 (A) | X | X | ▼ | Torque converter clutch solenoid valve monitor current |
| SOLMON2 (A) | X | X | ▼ | Pressure control solenoid valve A (line pressure solenoid valve) monitor current |
| SOLMON3 (A) | X | X | ▼ | Pressure control solenoid valve B (secondary pressure solenoid valve) monitor current |
| INH SW3M (ON/OFF) | X | — | ▼ | PNP switch 3 ON-OFF status monitor |
| INH SW4 (ON/OFF) | X | — | ▼ | PNP switch 4 ON-OFF status |
| INH SW3 (ON/OFF) | X | — | ▼ | PNP switch 3 ON-OFF status |
| INH SW2 (ON/OFF) | X | — | ▼ | PNP switch 2 ON-OFF status |
| INH SW1 (ON/OFF) | X | — | ▼ | PNP switch 1 ON-OFF status |
| BRAKE SW (ON/OFF) | X | X | ▼ | Stop lamp switch (Signal input with CAN communications) |
| FULL SW (ON/OFF) | X | X | ▼ | Signal input with CAN communications |
| IDLE SW (ON/OFF) | X | X | ▼ | |
| SPORT MODE SW (ON/OFF) | X | X | ▼ | |
| STRDWSW (ON/OFF) | X | — | ▼ | Not mounted but displayed. |
| STRUPSW (ON/OFF) | X | — | ▼ | |
| DOWNLVR (ON/OFF) | X | — | ▼ | |
| UPLVR (ON/OFF) | X | — | ▼ | — |
| NONMMODE (ON/OFF) | X | — | ▼ | — |
| MMODE (ON/OFF) | X | — | ▼ | — |
| INDLRNG (ON/OFF) | — | — | ▼ | Not mounted but displayed. |
| INDDRNG (ON/OFF) | — | — | ▼ | "D" position indicator output |
| INDNRNG (ON/OFF) | — | — | ▼ | "N" position indicator output |
| INDRNG (ON/OFF) | — | — | ▼ | "R" position indicator output |
| INDPRNG (ON/OFF) | — | — | ▼ | "P" position indicator output |
| CVT LAMP (ON/OFF) | — | — | ▼ | — |
| SPORT MODE IND (ON/OFF) | — | — | ▼ | Not mounted but displayed. |
| MMODE IND (ON/OFF) | — | — | ▼ | — |
| SMCOIL D (ON/OFF) | — | — | ▼ | Step motor coil "D" energizing status |
| SMCOIL C (ON/OFF) | — | — | ▼ | Step motor coil "C" energizing status |
| SMCOIL B (ON/OFF) | — | — | ▼ | Step motor coil "B" energizing status |
| SMCOIL A (ON/OFF) | — | — | ▼ | Step motor coil "A" energizing status |
| LUSEL SOL OUT (ON/OFF) | — | — | ▼ | — |
| REV LAMP (ON/OFF) | — | X | ▼ | — |
| STRTR RLY OUT (ON/OFF) | — | — | ▼ | Starter relay |

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F09B]

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|------------------------|------------------------|--------------|---------------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | SELECTION FROM MENU | |
| LUSEL SOL MON (ON/OFF) | — | — | ▼ | — |
| STRTR RLY MON (ON/OFF) | — | — | ▼ | Starter relay |
| VDC ON (ON/OFF) | X | — | ▼ | — |
| TCS ON (ON/OFF) | X | — | ▼ | — |
| ABS ON (ON/OFF) | X | — | ▼ | — |
| ACC ON (ON/OFF) | X | — | ▼ | Not mounted but displayed. |
| RANGE | — | X | ▼ | Indicates position is recognized by TCM. Indicates a specific value required for control when fail-safe function is activated. |
| M GEAR POS | — | X | ▼ | — |
| Voltage (V) | — | — | ▼ | Displays the value measured by the voltage probe. |
| Frequency (Hz) | — | — | ▼ | The value measured by the pulse probe is displayed. |
| DUTY-HI (high) (%) | — | — | ▼ | |
| DUTY-LOW (low) (%) | — | — | ▼ | |
| PLS WIDTH-HI (ms) | — | — | ▼ | |
| PLS WIDTH-LOW (ms) | — | — | ▼ | |

Diagnostic Tool Function

INFOID:000000000991951

OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

Refer to [EC-118. "Diagnosis Description"](#).

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000000991952

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000000991953

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "U1000 CAN COMM CIRCUIT" with CONSULT-III is detected when TCM cannot communicate to other control units.

Possible Cause

- Harness or connectors
(CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, touch "ERASE" on "SELF-DIAG RESULTS" and then perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and wait for at least 6 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure "WITH CONSULT-III".

Is "U1000 CAN COMM CIRCUIT" detected?

- YES >> Go to [TM-118, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#)

Diagnosis Procedure

INFOID:000000000991954

1. CHECK CAN COMMUNICATION CIRCUIT

With CONSULT-III

1. Turn ignition switch ON and start engine.
2. Select "SELF-DIAG RESULTS".

Is any malfunction of the "U1000 CAN COMM CIRCUIT" indicated?

- YES >> Go to LAN section. Refer to [LAN-25, "CAN System Specification Chart"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P0615 START SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0615 START SIGNAL

Description

INFOID:000000000991955

- TCM controls starter relay in IPDM E/R.
- TCM switches starter relay ON at “P” or “N” position and allows to crank engine.
- Then it prohibits cranking other than at “P” or “N” position.

DTC Logic

INFOID:000000000991956

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0615 STARTER RELAY/CIRC” with CONSULT-III is detected when starter relay switched ON other than at “P” or “N” position. (Or when switched OFF at “P” or “N” position).

Possible Cause

- Harness or connectors
(Starter relay and TCM circuit is open or shorted.)
- Starter relay

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Perform “SELF-DIAG RESULTS”. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is “P0615 STARTER RELAY/CIRC” detected?

- YES >> Go to [TM-119, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991957

1. CHECK STARTER RELAY SIGNAL

1. Turn ignition switch ON.
2. Check voltage between the TCM connector terminal and ground.

| TCM connector | | Ground | Condition | Data (Approx.) |
|---------------|----------|--------|---|-----------------|
| Connector | Terminal | | | |
| F16 | 20 | Ground | Selector lever in “N” and “P” positions | Battery voltage |
| | | | Selector lever in other positions | 0 V |

Is the inspection result normal?

- YES >> GO TO 2..
NO >> GO TO 4..

2. CHECK HARNESS BETWEEN TCM AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect TCM connector and IPDM E/R harness connector.
3. Check continuity between TCM connector terminals and IPDM E/R harness connector terminal.

P0615 START SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| TCM connector | | IPDM E/R harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 20 | F10 | 72 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Repair or replace damaged parts.

3.CHECK STARTER RELAY

Starter relay. Refer to [PG-60, "Description"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#)

P0703 STOP LAMP SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0703 STOP LAMP SWITCH

Description

INFOID:000000000991958

ON, OFF status of the stop lamp switch is sent via the CAN communication from the BCM to TCM using the signal.

DTC Logic

INFOID:000000000991959

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0703 BRAKE SW/CIRC" with CONSULT-III is detected when the stop lamp switch does not switch to ON and OFF.
- The stop lamp switch does not switch to ON, OFF.

Possible Cause

- Harness or connectors
(Stop lamp switch, and BCM circuit are open or shorted.)
(CAN communication line is open or shorted.)
- Stop lamp switch

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine.
3. Start vehicle for at least 3 consecutive seconds.
4. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P0703 BRAKE SW/CIRC" detected?

- YES >> Go to [TM-123, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991960

1.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [TM-121, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and BCM.
 - 10A fuse (No.7, located in fuse block).
- NO >> Repair or replace the stop lamp switch. Refer to [BR-16, "Exploded View"](#).

Component Inspection

INFOID:000000000991961

1.CHECK STOP LAMP SWITCH

Check continuity between stop lamp switch connector terminals.

| Stop lamp switch | | Condition | Continuity |
|------------------|----------|-----------|------------|
| Connector | Terminal | | |
| | | | |

P0703 STOP LAMP SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| | | | | |
|-----|---|---|-------------------------------|-------------|
| E38 | 1 | 2 | When brake pedal is depressed | Existed |
| | | | When brake pedal is released | Not existed |

Check stop lamp switch after adjusting brake pedal — refer to [BR-12. "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and BCM.
 - 10A fuse (No.7, located in fuse block).
- NO >> Repair or replace the stop lamp switch. Refer to [BR-16. "Exploded View"](#).

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0705 PARK/NEUTRAL POSITION SWITCH

Description

INFOID:000000000991962

- The PNP switch is included in the control valve assembly.
- The PNP switch includes 4 transmission position switches.
- TCM judges the selector lever position by the PNP switch signal.

| Shift position | PNP switch 1 | PNP switch 2 | PNP switch 3 | PNP switch 4 | PNP switch 3 (monitor) |
|----------------|--------------|--------------|--------------|--------------|------------------------|
| P | OFF | OFF | OFF | OFF | OFF |
| R | ON | OFF | OFF | ON | OFF |
| N | ON | ON | OFF | OFF | OFF |
| D | ON | ON | ON | ON | ON |

DTC Logic

INFOID:000000000991963

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0705 PNP SW/CIRC" with CONSULT-III is detected under the following conditions.
 - When TCM does not receive the correct voltage signal from the PNP switches 1, 2, 3 and 4 based on the gear position.
 - When the signal from monitor terminal of PNP switch 3 is different from PNP switch 3.

Possible Cause

- Harness or connectors
(PNP switches 1, 2, 3, 4 and TCM circuit is open or shorted.)
- PNP switches 1, 2, 3, 4
- PNP switch 3 monitor terminal is open or shorted

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

| | |
|----------------|-----------------------------|
| VEHICLE SPEED | : More than 10 km/h (6 MPH) |
| ENG SPEED | : More than 450 rpm |
| ACC PEDAL OPEN | : More than 1.0/8 |

With GST

Follow the procedure "With CONSULT-III".

Is "P0705 PNP SW/CIRC" detected?

- YES >> Go to [TM-123, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991964

1. CHECK HARNESS BETWEEN TCM AND PNP SWITCH

1. Turn ignition switch OFF.

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 1 | F46 | 5 | Existed |
| | 2 | | 14 | Existed |
| | 3 | | 15 | Existed |
| | 4 | | 18 | Existed |
| | 11 | | 4 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- OK >> GO TO 2..
 NG >> Repair or replace damaged parts.

2. DETECT MALFUNCTIONING ITEM

Check PNP switch. Refer to [TM-124, "Component Inspection"](#).

Is the inspection result normal?

- OK >> GO TO 3..
 NG >> Repair or replace damaged parts.

3. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
 NG >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000991965

1. CHECK PNP SWITCH

Change selector lever to various positions to check the continuity between terminals on the PNP switch and ground.

| SW No. | Shift position | PNP SW | | Continuity |
|--------------|-----------------|-----------|----------|-------------|
| | | Connector | Terminal | |
| SW 1 | "R", "N", "D" | F46 | 4 | Existed |
| | Other positions | | | Not existed |
| SW 2 | "N", "D" | | 5 | Existed |
| | Other positions | | | Not existed |
| SW 3 | "D" | | 14 | Existed |
| | Other positions | | | Not existed |
| SW 4 | "R", "D" | | 15 | Existed |
| | Other positions | | | Not existed |
| SW 3 Monitor | "D" | | 18 | Existed |
| | Other positions | | | Not existed |

Is the inspection result normal?

- YES >> **INSPECTION END**
 NO >> GO TO 2

2. CHECK CVT POSITION

Check continuity with control cable disconnected. (Refer to step 1 above.)

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Is the inspection result normal?

YES >> Adjust CVT position. Refer to [TM-227, "Inspection and Adjustment"](#).

NO >> Replace transaxle assembly. Refer to [TM-233, "Exploded View"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P0710 CVT FLUID TEMPERATURE SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0710 CVT FLUID TEMPERATURE SENSOR

Description

INFOID:000000000991966

The CVT fluid temperature sensor detects the CVT fluid temperature and sends a signal to the TCM.

DTC Logic

INFOID:000000000991967

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0710 ATF TEMP SEN/CIRC" with CONSULT-III is detected when TCM receives an excessively low or high voltage from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 10 minutes (Total).

| | |
|----------------|---------------------------|
| VEHICLE SPEED | : 10 km/h (6 MPH) or more |
| ENG SPEED | : 450 rpm more than |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |

With GST

Follow the procedure "With CONSULT-III".

Is "P0710 ATF TEMP SEN/CIRC" detected?

- YES >> Go to [TM-126, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991968

1. CHECK CVT FLUID TEMPERATURE SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the TCM connector.
3. Check resistance between TCM connector terminals.

| CVT fluid temperature sensor | | | Temperature °C (°F) | Resistance (Approx.) |
|------------------------------|----------|----------|---------------------|----------------------|
| Connector | Terminal | Terminal | | |
| F16 | 13 | 25 | 20 (68) | 6.5 kΩ |
| | | | 80 (176) | 0.9 kΩ |

Is the inspection result normal?

- YES >> GO TO 4..
NO >> GO TO 2..

2. CHECK CVT FLUID TEMPERATURE SENSOR

P0710 CVT FLUID TEMPERATURE SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Check CVT fluid temperature sensor. Refer to [TM-127, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

3. CHECK HARNESS BETWEEN TCM AND CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect the TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 13 | F46 | 17 | Exsited |
| | 25 | | 19 | Exsited |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

OK >> GO TO 4..

NG >> Repair or replace damaged parts.

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000991969

CVT FLUID TEMPERATURE SENSOR

1. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminals.

| CVT fluid temperature sensor | | | Temperature °C (°F) | Resistance (Approx.) |
|------------------------------|----------|----------|---------------------|----------------------|
| Connector | Terminal | Terminal | | |
| F46 | 17 | 19 | 20 (68) | 6.5 kΩ |
| | | | 80 (176) | 0.9 kΩ |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Replace transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

Description

INFOID:000000000991970

The input speed sensor (primary speed sensor) detects the primary pulley revolution speed and sends a signal to the TCM.

DTC Logic

INFOID:000000000991971

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0715 INPUT SPD SEN/CIRC" with CONSULT-III is detected when TCM does not receive the proper signal from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Input speed sensor (Primary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|------------------|--|
| VEHICLE SPEED | : 10 km/h (6 MPH) or more |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| ENG SPEED | : 450 rpm or more |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-III".

Is "P0715 INPUT SPD SEN/CIRC" detected?

- YES >> Go to [TM-128, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991972

1. CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)

1. Start engine.
2. Check voltage between TCM connector terminals.

| TCM connector | | Data (Approx.) |
|---------------|----------------------------|----------------|
| Connector | Terminal | |
| F16 | 25 26 | 5.0 V |

3. Check the pulse with CONSULT-III or oscilloscope, when vehicle cruises.

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| TCM connector | | Condition | Data (Approx.) |
|---------------|----------|--|----------------|
| Connector | Terminal | | |
| F16 | 33 | When running at 20 km/h (12 MPH) in "M1" position with the closed throttle position signal OFF, use the CONSULT-III pulse frequency measuring function. CAUTION: Connect the data link connector to the vehicle-side diagnosis connector. | 660 Hz |

Is the inspection result normal?

OK >> GO TO 5..

NG - 1 >> Battery voltage is not supplied: GO TO 2..

NG - 2 >> Battery voltage is supplied, but there is a malfunction in the frequency: GO TO 3..

2. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (SENSOR POWER AND SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F46 | 19 | Existed |
| | 26 | | 20 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR [INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)]

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 33 | F46 | 22 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THE TCM SHORT

Replace same type TCM, perform self-diagnosis check. Erase self-diagnostic results and then drive the vehicle [10 km/h (6 MPH) or more], perform self-diagnosis check. Refer to [TM-128, "DTC Logic"](#).

Is the "P0715 INPUT SPD SEN/CIRC" detected again?

YES >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

5. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

Description

INFOID:000000000991973

The vehicle speed sensor CVT [output speed sensor (secondary speed sensor)] detects the revolution of the CVT output shaft and emits a pulse signal. The pulse signal is sent to the TCM, which converts it into vehicle speed.

DTC Logic

INFOID:000000000991974

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0720 VEH SPD SEN/CIR AT" with CONSULT-III is detected TCM does not receive the proper signal from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Output speed sensor (Secondary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 12 consecutive seconds.

| | |
|----------------------|--|
| ACC PEDAL OPEN RANGE | : More than 1.0/8 |
| Driving location | : "D" position |
| | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected,

With GST

Follow the procedure "With CONSULT-III".

Is "P0720 VEH SPD SEN/CIR AT" detected?

- YES >> Go to [TM-130, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991975

1. CHECK SECONDARY SPEED SENSOR

With CONSULT-III

1. Start engine.
2. Check power supply to output speed sensor (secondary speed sensor) by voltage between TCM connector terminals.

| TCM connector | | Data (Approx.) |
|---------------|----------|----------------|
| Connector | Terminal | |
| | | |

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| | | | |
|-----|----|---|-----------------|
| F16 | 45 | 7 | Battery voltage |
| | 48 | | |

3. If OK, check the pulse when vehicle cruises.

| TCM connector | | Condition | Data (Approx.) |
|---------------|----------|--|----------------|
| Connector | Terminal | | |
| F16 | 34 | When running at 20 km/h (12 MPH) in "D" position, use the CONSULT-III pulse frequency measuring function. CAUTION: Connect the data link connector to the vehicle-side diagnosis connector. | 400 Hz |

Is the inspection result normal?

- YES >> GO TO 7..
- NO >> GO TO 2..

2. CHECK POWER AND SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect the output speed sensor (secondary speed sensor) harness connector.
3. Turn ignition switch ON.
4. Check voltage between output speed sensor (secondary speed sensor) harness connector terminals.

| Output speed sensor (Secondary speed sensor) harness connector | | | Data (Approx.) |
|--|----------|----------|-----------------|
| Connector | Terminal | Terminal | |
| F23 | 1 | 3 | Battery voltage |

5. Check voltage between output speed sensor (secondary speed sensor) harness connector terminal and ground.

| Output speed sensor (Secondary speed sensor) harness connector | | Ground | Data (Approx.) |
|--|----------|--------|-----------------|
| Connector | Terminal | | |
| F23 | 3 | | Battery voltage |

6. If OK, check harness for short to ground and short to power.
7. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 3..
- NO - 1 >> Battery voltage is not supplied between terminals 1 and 3, terminals 3 and ground: GO TO 5..
- NO - 2 >> Battery voltage is not supplied between terminals 1 and 3 only: GO TO 6..

3. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 34 | F23 | 2 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THE TCM SHORT

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Replace same type TCM, perform self-diagnosis check. Erase self-diagnostic results and then drive the vehicle [more than 40 km/h (25 MPH)], perform self-diagnosis check. Refer to [TM-130, "DTC Logic"](#).

Is "P0720 VEH SPD SEN/CIR AT" detected again?

YES >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

5. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) (POWER)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminals and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 46 | F23 | 3 | Existed |
| | 48 | | | |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> 10 A fuse (No. 34, located in the IPDM E/R) or ignition switch are malfunctioning.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) (SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 7 | F23 | 1 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 7..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

P0725 ENGINE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0725 ENGINE SPEED SIGNAL

Description

INFOID:000000000991976

The engine speed signal is sent from the ECM to the TCM.

DTC Logic

INFOID:000000000991977

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0725 ENGINE SPEED SIG” with CONSULT-III is detected when TCM does not receive the engine speed signal (input by CAN communication) from ECM.

Possible Cause

Harness or connectors
(The ECM to the TCM circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

④ With CONSULT-III

1. Turn ignition switch ON.
2. Select “DATA MONITOR”.
3. Start engine and maintain the following conditions for at least 10 consecutive seconds.

PRI SPEED SEN : More than 1000 rpm

“P0725 ENGINE SPEED SIG” detected?

- YES >> Go to [TM-133, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991978

1. CHECK DTC WITH ECM

④ With CONSULT-III

1. Turn ignition switch ON.
2. Select “SELF-DIAG RESULTS” mode for “ENGINE” with CONSULT-III. Refer to [EC-130, "CONSULT-III Function"](#).

Is the inspection result normal?

- OK >> GO TO 2..
NG >> Check the DTC detected item. Refer to [EC-130, "CONSULT-III Function"](#).

2. CHECK DTC WITH TCM

④ With CONSULT-III

1. Turn ignition switch ON.
2. Select “SELF-DIAG RESULTS” mode for “TRANSMISSION” with CONSULT-III. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is the inspection result normal?

- OK >> GO TO 3..
NG >> Check the DTC detected item. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

3. CHECK INPUT SIGNALS

④ With CONSULT-III

1. Start engine.

P0725 ENGINE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

2. Select "DATA MONITOR".
3. While monitoring "ENG SPEED SIG", check for engine speed change corresponding to "ACC PEDAL OPEN".

| Item name | Condition | Display value |
|----------------|--|---|
| ENG SPEED SIG | Engine running | Closely matches the tachometer reading. |
| ACC PEDAL OPEN | Released accelerator pedal – Fully depressed accelerator pedal | 0.0/8 – 8.0/8 |

Is the inspection result normal?

- OK >> GO TO 4..
- NG >> Check ignition signal circuit. Refer to [EC-442. "Description"](#).

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-181. "Reference Value"](#).

Is the inspection result normal?

- OK >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).
- NG >> Replace the TCM. Refer to [TM-228. "Exploded View"](#).

P0730 BELT DAMAGE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0730 BELT DAMAGE

Description

INFOID:000000000991979

TCM selects the gear ratio using the engine load (throttle position), the primary pulley revolution speed, and the secondary pulley revolution speed as input signal. Then it changes the operating pressure of the primary pulley and the secondary pulley and changes the groove width of the pulley.

DTC Logic

INFOID:000000000991980

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- TCM calculates the actual gear ratio with input speed sensor (primary speed sensor) and output speed sensor (secondary speed sensor).
- Diagnostic trouble code "P0730 BELT DAMG" with CONSULT-III is detected, when TCM receives an unexpected gear ratio signal.

Possible Cause

Transaxle assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 30 consecutive seconds.

TEST START FROM 0 km/h (0 MPH)

CONSTANT ACCELERATION : Keep 30 sec or more

VEHICLE SPEED : 10 km/h (6 MPH) or more

ACC PEDAL OPEN : More than 1.0/8

RANGE : "D" position

ENG SPEED : 450 rpm or more

Is "P0730 BELT DAMG" detected?

YES >> Go to [TM-135, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991981

1. CHECK DTC

Perform [TM-135, "DTC Logic"](#).

Are any DTC displayed?

YES - 1>> DTC except for "P0730 BELT DAMG" is displayed: Go to Check the DTC detected item. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

YES - 2>> DTC for "P0730 BELT DAMG" is displayed: Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P0730 BELT DAMAGE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

NO >> Check intermittent incident. Refer to [G1-39. "Intermittent Incident"](#).

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Description

INFOID:000000000991982

- The torque converter clutch solenoid valve is activated by the TCM in response to signals sent from the vehicle speed and accelerator pedal position sensors. Lock-up piston operation will then be controlled.
- Lock-up operation, however, is prohibited when CVT fluid temperature is too low.
- When the accelerator pedal is depressed (less than 2.0/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

DTC Logic

INFOID:000000000991983

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P0740 TCC SOLENOID/CIRC” with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.

Possible Cause

- Torque converter clutch solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Wait at least 10 consecutive seconds.
3. Perform “SELF-DIAG RESULTS”. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure “With CONSULT-III”.

Is “P0740 TCC SOLENOID/CIRC” detected?

- YES >> Go to [TM-137, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991984

1. CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 38 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 38 | F46 | 12 | Existed |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 3..
NO >> Repair or replace damaged parts.

3.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-138, "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 4..
NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000991985

TORQUE CONVERTER CLUTCH SOLENOID VALVE

1.TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 12 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> **INSPECTION END**
NO >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

Description

INFOID:000000000991986

This malfunction is detected when the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted), but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

DTC Logic

INFOID:000000000991987

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0744 A/T TCC S/V FNCTN" with CONSULT-III is detected under the following conditions.
 - When CVT cannot perform lock-up even if electrical circuit is good.
 - When TCM compares difference value with slip revolution and detects an irregularity.

Possible Cause

- Torque converter clutch solenoid valve
- Hydraulic control circuit

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following condition for at least 30 seconds.

| | |
|----------------------|--|
| ACC PEDAL OPEN RANGE | : More than 1.0/8 |
| VEHICLE SPEED | : "D" position |
| | : Constant speed of more than 40 km/h (25 MPH) |

4. If DTC is detected

With GST

Follow the procedure "With CONSULT-III".

Is "P0744 A/T TCC S/V FNCTN" detected?

- YES >> Go to [TM-139, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991988

1.CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts. Refer to [TM-221, "Inspection and Judgment"](#).

2.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-138, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3..
NO >> Repair or replace damaged parts.

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

3.CHECK LOCK-UP SELECT SOLENOID VALVE

Check lock-up select solenoid valve. Refer to [TM-170, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-130, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-128, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6..

NO >> Repair or replace damaged parts.

6.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

P0745 LINE PRESSURE SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0745 LINE PRESSURE SOLENOID VALVE

Description

INFOID:000000000991989

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000991990

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0745 L/PRESS SOL/CIRC" with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Harness or connectors (Solenoid circuit is open or shorted.)
- Pressure control solenoid valve A (Line pressure solenoid valve)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and wait at least 5 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)".](#)

With GST

Follow the procedure "With CONSULT-III".

Is "P0745 L/PRESS SOL/CIRC" detected?

- YES >> Go to [TM-141, "Diagnosis Procedure".](#)
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident".](#)

Diagnosis Procedure

INFOID:000000000991991

1. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 40 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> GO TO 2..

2. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-138, "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View".](#)

P0745 LINE PRESSURE SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

3. CHECK HARNESS BETWEEN TCM AND PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector and TCM connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 40 | F46 | 2 | Existed |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 4..
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000991992

PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 2 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> **INSPECTION END**
NO >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

Description

INFOID:000000000991993

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000991994

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0746 PRS CNT SOL/A FCTN" with CONSULT-III is detected under the following conditions.
- Unexpected gear ratio was detected in the LOW side due to excessively low line pressure.

Possible Cause

- Line pressure control system
- Output speed sensor (Secondary speed sensor)
- Input speed sensor (Primary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 10 consecutive seconds. Test start from 0 km/h (0 MPH).

| | |
|------------------|--|
| ATF TEMP SEN | : 1.0 – 2.0 V |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| VEHICLE SPEED | : 10 km/h (6 MPH) More than |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-III".

Is "P0746 PRS CNT SOL/A FCTN" detected?

- YES >> Go to [TM-143, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991995

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
- NO >> Repair or replace damaged parts. Refer to [TM-221, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Check pressure control solenoid valve A (line pressure solenoid valve). Refer to [TM-142, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-130, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-128, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

Description

INFOID:000000000991996

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000991997

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0776 PRS CNT SOL/B FCTN" with CONSULT-III is detected when secondary pressure is too high or too low compared with the commanded value while driving.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve system)
- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Line pressure control system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 30 consecutive seconds.

| | |
|------------------|--|
| ATF TEMP SEN | : 1.0 – 2.0 V |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| VEHICLE SPEED | : 10 km/h (6 MPH) More than |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-III".

Is "P0776 PRS CNT SOL/B FCTN" detected?

- YES >> Go to [TM-145, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000991998

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts. Refer to [TM-221, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Check pressure control solenoid valve B (Secondary pressure solenoid valve). Refer to [TM-148. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-142. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-152. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-181. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228. "Exploded View"](#).

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

Description

INFOID:000000000991999

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992000

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0778 PRS CNT SOL/B CIRC" with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
4. Perform "SELF-DIAG RESULTS". Refer to [TM-112. "CONSULT-III Function \(TRANSMISSION\)".](#)

With GST

Follow the procedure "With CONSULT-III".

Is "P0778 PRS CNT SOL/B CIRC" detected?

- YES >> Go to [TM-147. "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992001

1. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 39 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> GO TO 2..

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve B (secondary pressure solenoid valve). Refer to [TM-148. "Component Inspection"](#).

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Repair or replace damaged parts.

3.CHECK HARNESS BETWEEN TCM AND PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 39 | F46 | 3 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000992002

PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1.PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 3 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> **INSPECTION END**
- NO >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P0826 MANUAL MODE SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0826 MANUAL MODE SWITCH

Description

INFOID:000000000992003

Manual mode switch is installed in CVT control device. The manual mode switch sends shift up and shift down switch signals to TCM.

TCM sends the switch signals to combination meter via CAN communication line. Then manual mode switch position is indicated on the CVT position indicator.

DTC Logic

INFOID:000000000992004

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0826 MANUAL MODE SWITCH" with CONSULT-III is detected when TCM monitors Manual mode, Non manual mode, Up or Down switch signal, and then detects irregular with impossible input pattern for 1 second or more.

Possible Cause

- Harness or connectors
(These switches circuit is open or shorted.)
(TCM, and combination meter circuit are open or shorted.)
(CAN communication line is open or shorted.)
- Manual mode select switch (Built into CVT control device)
- Manual mode position select switch (Built into CVT control device)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine.
4. Drive vehicle for at least 2 consecutive seconds.

MMODE : ON

Is "P0826 MANUAL MODE SWITCH" detected?

- YES >> Go to [TM-149, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992005

1. CHECK MANUAL MODE SWITCH SIGNALS

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Read out ON/OFF switching action of the "MMODE", "NON M-MODE", "UPLVR", "DOWNLVR".

| Item name | Condition | Display value |
|-----------|--------------------------------------|---------------|
| MMODE | Manual shift gate position (neutral) | ON |
| | Other than the above | OFF |

P0826 MANUAL MODE SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

| Item name | Condition | Display value |
|-----------|--|---------------|
| NON MMODE | Manual shift gate position (neutral, +side, -side) | OFF |
| | Other than the above | ON |
| UPLVR | Selector lever: + side | ON |
| | Other than the above | OFF |
| DOWNLVR | Selector lever: - side | ON |
| | Other than the above | OFF |

⊗ Without CONSULT-III

Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ↔ 6th gear).

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2.CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [TM-151, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK SELF-DIAGNOSTIC RESULTS (COMBINATION METER)

Perform self-diagnosis check. Refer to [MWI-16, "CONSULT-III Function \(METER\)"](#).

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 4..

4.CHECK MANUAL MODE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect CVT device connector and combination meter connector.
3. Check continuity between CVT device harness connector terminals and combination meter harness connector terminals.

| CVT device harness connector | | Combination meter harness connector | | Continuity |
|------------------------------|----------|-------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M23 | 1 | M24 | 40 | Existed |
| | 2 | | 38 | Existed |
| | 3 | | 39 | Existed |
| | 5 | | 37 | Existed |

4. Check continuity between CVT device harness connector terminal and ground.

| CVT device harness connector | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M23 | 4 | | Existed |

5. If OK, check harness for short to ground and short to power.

6. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

P0826 MANUAL MODE SWITCH

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000992006

MANUAL MODE SWITCH

1. MANUAL MODE SWITCH

Check continuity between CVT device harness connector terminals.

| Item | Position | CVT device harness connector | | | Continuity |
|------------------------------------|----------|------------------------------|----------|----------|------------|
| | | Connector | Terminal | Terminal | |
| Manual mode select switch | Auto | M23 | 4 | 5 | Existed |
| | Manual | | 1 | 4 | Existed |
| Manual mode position select switch | Up | | 3 | 4 | Existed |
| | Down | | 2 | 4 | Existed |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

Description

INFOID:000000000992007

The transmission fluid pressure sensor A (secondary pressure sensor) detects secondary pressure of CVT and sends TCM the signal.

DTC Logic

INFOID:000000000992008

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0840 TR PRS SENS/A CIRC" with CONSULT-III is detected when TCM detects an improper voltage drop when it receives the sensor signal.

Possible Cause

- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Harness or connectors
(Switch circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓜ WITH CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of line temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and wait for at least 5 consecutive seconds.

Ⓜ With GST

Follow the procedure "WITH CONSULT-III".

Is "P0840 TR PRS SENS/A CIRC" detected?

YES >> Go to [TM-152, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992009

1. CHECK INPUT SIGNAL

1. Start engine.
2. Check voltage between TCM connector terminal and ground.

| TCM connector | | Ground | Condition | Data (Approx.) |
|---------------|----------|--------|-------------------|----------------|
| Connector | Terminal | | | |
| F16 | 15 | | "N" position idle | 1.0 V |

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR)

1. Turn ignition switch OFF.

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 15 | F46 | 23 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (SENSOR POWER AND SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F46 | 19 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK SENSOR POWER AND SENSOR GROUND

1. Turn ignition switch ON.
2. Disconnect CVT unit harness connector.
3. Check voltage between CVT unit harness connector terminals.

| CVT unit harness connector | | | Data (Approx.) |
|----------------------------|----------|----------|----------------|
| Connector | Terminal | Terminal | |
| F46 | 19 | 20 | 5.0 V |

4. Reinstall any part removed.

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

NO >> GO TO 5..

5. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

P0841 PRESSURE SENSOR FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0841 PRESSURE SENSOR FUNCTION

Description

INFOID:000000000992010

Using the engine load (throttle position), the primary pulley revolution speed, and the secondary pulley revolution speed as input signal, TCM changes the operating pressure of the primary pulley and the secondary pulley and changes the groove width of the pulley to control the gear ratio.

DTC Logic

INFOID:000000000992011

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0841 PRESS SEN/FNCTN" with CONSULT-III is detected when correlation between the values of the secondary pressure sensor and the primary pressure sensor is out of specification.

Possible Cause

- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Transmission fluid pressure sensor B (Primary pressure sensor)
- Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 12 consecutive seconds.

VEHICLE SPEED : 40 km/h (25 MPH) More than
RANGE : "D" position

Is "P0841 PRESS SEN/FNCTN" detected?

- YES >> Go to [TM-154, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992012

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts. Refer to [TM-221, "Inspection and Judgment"](#).

2. CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-152, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 3..
NO >> Repair or replace damaged parts.

3. CHECK TRANSMISSION FLUID PRESSURE SENSOR B (PRIMARY PRESSURE SENSOR) SYSTEM

P0841 PRESSURE SENSOR FUNCTION

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

Check transmission fluid pressure sensor B (primary pressure sensor) system. Refer to [TM-156, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-142, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK SECONDARY PRESSURE SOLENOID VALVE

Check secondary pressure solenoid valve. Refer to [TM-148, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6..

NO >> Repair or replace damaged parts.

6.CHECK STEP MOTOR

Step motor. Refer to [TM-173, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7..

NO >> Repair or replace damaged parts.

7.CHECK TCM

Check input /output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

Description

INFOID:000000000992013

The transmission fluid pressure sensor B (primary pressure sensor) detects primary pressure of CVT and sends TCM the signal.

DTC Logic

INFOID:000000000992014

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0845 TR PRS SENS/B CIRC" with CONSULT-III is detected under the following conditions.
 - When TCM detects an improper voltage drop when it receives the sensor signal.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Transmission fluid pressure sensor B (Primary pressure sensor)
- Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of line temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and wait for at least 5 consecutive seconds.

With GST

Follow the procedure "WITH CONSULT-III".

Is "P0845 TR PRS SENS/B CIRC" detected?

YES >> Go to [TM-156, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992015

1. CHECK INPUT SIGNAL

1. Start engine.
2. Check voltage between TCM connector terminal and ground.

| TCM connector | | Ground | Condition | Data (Approx.) |
|---------------|----------|--------|-------------------|----------------|
| Connector | Terminal | | | |
| F16 | 14 | | "N" position idle | 0.7 – 3.5 V |

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TRANSMISSION FLUID PRESSURE SENSOR B (PRIMARY

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

PRESSURE SENSOR)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 14 | F46 | 25 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (SENSOR POWER AND SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F46 | 19 | Existed |
| | 26 | | 20 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK SENSOR POWER AND SENSOR GROUND

1. Turn ignition switch ON.
2. Disconnect CVT unit harness connector.
3. Check voltage between CVT unit harness connector terminals.

| CVT unit harness connector | | | Data (Approx.) |
|----------------------------|----------|----------|----------------|
| Connector | Terminal | Terminal | |
| F46 | 19 | 20 | 5.0 V |

4. Reinstall any part removed.

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

NO >> GO TO 5..

5. CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

P0868 SECONDARY PRESSURE DOWN

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P0868 SECONDARY PRESSURE DOWN

Description

INFOID:000000000992016

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992017

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0868 SEC/PRESS DOWN" with CONSULT-III is detected when secondary fluid pressure is too low compared with the commanded value while driving.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve) system
- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Line pressure control system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 10 consecutive seconds.

VEHICLE SPEED (accelerate slowly) : 0 → 50 km/h (31 MPH)

ACC PEDAL OPEN : 0.5/8 – 1.0/8

RANGE : "D" position

Is "P0868 SEC/PRESS DOWN" detected?

YES >> Go to [TM-158, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992018

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-221, "Inspection and Judgment"](#).

Is the inspection result normal?

YES >> GO TO 2..

NO >> Repair or replace damaged parts. Refer to [TM-221, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve B (Secondary pressure solenoid valve). Refer to [TM-148, "Component Inspection"](#).

P0868 SECONDARY PRESSURE DOWN

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-142, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-152, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check input/output signal. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228, "Exploded View"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

Description

INFOID:000000000992019

When the power supply to the TCM is cut OFF, for example because the battery is removed, and the self-diagnosis memory function stops, malfunction is detected.

NOTE:

Since "P1701 TCM-POWER SUPPLY" will be indicated when replacing TCM, perform diagnosis after erasing "SELF-DIAG RESULTS"

DTC Logic

INFOID:000000000992020

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1701 TCM-POWER SUPPLY" with CONSULT-III is detected when TCM does not receive the voltage signal from the battery power supply.
- This is not a malfunction message. (Whenever shutting OFF a power supply to the TCM, this message appears on the screen.)

Possible Cause

Harness or connectors

(Battery or ignition switch and TCM circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Wait for at least 2 consecutive seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P1701 TCM-POWER SUPPLY" detected?

YES >> Go to [TM-160, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992021

1.CHECK TCM POWER SOURCE

Check voltage between TCM connector terminals and ground.

| Name | TCM connector | | Condition | Data (Approx.) |
|-------------------------------|---------------|---------------------|---------------------|-----------------|
| | Connector | Terminal | | |
| Power supply | F16 | 46 | Ignition switch ON | Battery voltage |
| | | 48 | Ignition switch OFF | 0 V |
| | | | Ignition switch ON | Battery voltage |
| | | Ignition switch OFF | 0 V | |
| Power supply (memory back-up) | F16 | 45 | Always | Battery voltage |
| | | 47 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2..

2.DETECT MALFUNCTIONING ITEM

Check the following.

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

- Harness for short or open between battery and TCM connector terminal 45, 47
- Harness for short or open between ignition switch and TCM connector terminal 46, 48
- 10 A fuse (No. 34, located in the IPDM E/R)
- 10 A fuse (No. 11, located in the J/B)
- Ignition switch. Refer to [PG-5](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK TCM GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM connector terminals and ground.

| TCM Connector | | Ground | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| F16 | 5 | | Existed |
| | 42 | | Existed |

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK TCM

1. Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

P1705 THROTTLE POSITION SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1705 THROTTLE POSITION SENSOR

Description

INFOID:000000000992022

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000000992023

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1705 TP SEN/CIRC A/T" with CONSULT-III is detected when TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.

Possible Cause

- ECM
- Harness or connectors
(CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Depress accelerator pedal fully and release it, then wait for 5 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P1705 TP SEN/CIRC A/T" detected?

- YES >> Go to [TM-162, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992024

1. CHECK INPUT SIGNAL

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Read out the value of "ACC PEDAL OPEN".

| Item name | Condition | Display value (Approx.) |
|----------------|--|-------------------------|
| ACC PEDAL OPEN | Release accelerator pedal. | 0.0/8 |
| | ↓ Fully depressed accelerator pedal | ↓ 8.0/8 |

OK or NG

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
NG >> GO TO 2..

2. CHECK DTC WITH ECM

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-130, "CONSULT-III Function"](#).

OK or NG

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P1705 THROTTLE POSITION SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

NG >> Check the DTC Detected Item. Go to [EC-130. "CONSULT-III Function"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P1722 ESTM VEHICLE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1722 ESTM VEHICLE SPEED SIGNAL

Description

INFOID:000000000992025

The vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) to TCM by CAN communication line.

DTC Logic

INFOID:000000000992026

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1722 ESTM VEH SPD SIG" with CONSULT-III is detected when TCM does not receive the proper vehicle speed signal (input by CAN communication) from ABS actuator and electric unit (control unit).

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

ACC PEDAL OPEN : 1.0/8 or less
VEHICLE SPEED : 30 km/h (19 MPH) or more

Is "P1722 ESTM VEH SPD SIG" detected?

- YES >> Go to [TM-164, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992027

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "SELF-DIAG RESULTS". Refer to [BRC-71, "CONSULT-III Function \(ABS\)"](#) (TCS/ABS models), [BRC-138, "CONSULT-III Function \(ABS\)"](#) (VDC/TCS/ABS models).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts.

2. CHECK INPUT SIGNALS

With CONSULT-III

1. Start engine.
2. Select "DATA MONITOR".
3. Drive vehicle and read out the value of "VEHICLE SPEED" and "ESTM VSP SIG".

| Item name | Condition | Display value |
|---------------|----------------|--|
| ESTM VSP SIG | During driving | Approximately matches the speedometer reading. |
| VEHICLE SPEED | | |

P1722 ESTM VEHICLE SPEED SIGNAL

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

4. Check if there is a great difference between the two values.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 3..

3.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P1723 CVT SPEED SENSOR FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1723 CVT SPEED SENSOR FUNCTION

Description

INFOID:000000000992028

The vehicle speed sensor CVT [output speed sensor (secondary speed sensor)] detects the revolution of parking gear and generates a pulse signal. The pulse signal is sent to the TCM, which converts it into vehicle speed.

The input speed sensor (primary speed sensor) detects the primary pulley revolution speed and sends a signal to the TCM.

DTC Logic

INFOID:000000000992029

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1723 CVT SPD SEN/FNCTN" with CONSULT-III is detected when there is a great difference between the vehicle speed signal and the secondary speed sensor signal.

CAUTION:

One of the "P0720 VEH SPD SEN/CIR AT", the "P0715 INPUT SPD SEN/CIRC" or the "P0725 ENGINE SPEED SIG" is displayed with the DTC at the same time.

NOTE:

When the vehicle is driven fixed in 2nd gear, a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Output speed sensor (Secondary speed sensor)
- Input speed sensor (Primary speed sensor)
- Engine speed signal system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|------------------|--|
| VEHICLE SPEED SE | : 10 km/h (6 MPH) or more |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| ENG SPEED | : 450 rpm or more |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

Is "P1723 CVT SPD SEN/FNCTN" detected?

YES >> Go to [TM-166, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992030

1. CHECK STEP MOTOR FUNCTION

Perform the self-diagnosis check. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

P1723 CVT SPEED SENSOR FUNCTION

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

Is a malfunction in the step motor function indicated in the results?

- YES >> Repair or replace damaged parts. (Check the step motor function. Refer to [TM-175, "DTC Logic"](#).)
- NO >> GO TO 2..

2.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-130, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 3..
- NG >> Repair or replace damaged parts.

3.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-128, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 4..
- NG >> Repair or replace damaged parts.

4.CHECK ENGINE SPEED SIGNAL SYSTEM

Check engine speed signal system. Refer to [TM-133, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 5..
- NG >> Repair or replace damaged parts. Refer to [EC-442, "Description"](#).

5.CHECK TCM

Check TCM input/output signals.

Is the inspection result normal?

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NG >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1726 ELECTRIC THROTTLE CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1726 ELECTRIC THROTTLE CONTROL SYSTEM

Description

INFOID:000000000992031

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000000992032

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1726 ELEC TH CONTROL" with CONSULT-III is detected when the electronically controlled throttle for ECM is malfunctioning.

Possible Cause

Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and let it idle for 5 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-112. "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P1726 ELEC TH CONTROL" detected?

- YES >> Go to [TM-168. "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992033

1. CHECK DTC WITH ECM

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-130. "CONSULT-III Function"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Check the DTC Detected Item. Go to [EC-130. "CONSULT-III Function"](#).

2. CHECK TCM

Check TCM input/output signals. Refer to [TM-181. "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).
NO >> Replace TCM. Refer to [TM-228. "Exploded View"](#).

P1740 LOCK-UP SELECT SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1740 LOCK-UP SELECT SOLENOID VALVE

Description

INFOID:000000000992034

- Lock-up select solenoid valve controls lock-up clutch pressure or forward clutch pressure (reverse brake pressure).
- When controlling lock-up clutch, the valve is turned OFF. When controlling forward clutch, it is turned ON.

DTC Logic

INFOID:000000000992035

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1740 LU-SLCT SOL/CIRC" with CONSULT-III is detected under the following conditions.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Lock-up select solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

RANGE : "D" position and "N" position

(At each time, wait for 5 seconds.)

With GST

Follow the procedure "With CONSULT-III".

Is "P1740 LU-SLCT SOL/CIRC" detected?

YES >> Go to [TM-169, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992036

1. CHECK LOCK-UP SELECT SOLENOID VALVE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 37 | | 6 – 19 Ω |

Is the inspection result normal?

YES >> GO TO .4.

NO >> GO TO 2..

2. CHECK LOCK-UP SELECT SOLENOID VALVE

P1740 LOCK-UP SELECT SOLENOID VALVE

[CVT: RE0F09B]

< COMPONENT DIAGNOSIS >

Check lock-up select solenoid valve.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Replace the transaxle assembly. Refer to [TM-233. "Removal and Installation"](#).

3.CHECK HARNESS BETWEEN TCM AND LOCK-UP SELECT SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 37 | F46 | 13 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-181. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-228. "Exploded View"](#).

Component Inspection

INFOID:000000000992037

LOCK-UP SELECT SOLENOID VALVE

1.LOCK-UP SELECT SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 13 | | 6 – 19 Ω |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Replace the transaxle assembly. Refer to [TM-233. "Exploded View"](#).

P1745 LINE PRESSURE CONTROL

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1745 LINE PRESSURE CONTROL

Description

INFOID:000000000992038

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992039

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1745 L/PRESS CONTROL" with CONSULT-III is detected when TCM detects the unexpected line pressure.

Possible Cause

TCM

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓜ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

Is "P1745 L/PRESS CONTROL" detected?

- YES >> Go to [TM-171, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992040

1. CHECK DTC

Ⓜ With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS".
3. Erase self-diagnostic results. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).
4. Turn ignition switch OFF, and wait for 10 seconds or more.
5. Start engine.
6. Perform "SELF-DIAG RESULTS". Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is the "P1745 L/PRESS CONTROL" displayed?

- YES >> Replace TCM. Refer to [TM-228, "Exploded View"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P1777 STEP MOTOR

Description

INFOID:000000000992041

The step motor changes the step with turning 4 coils ON/OFF according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.

DTC Logic

INFOID:000000000992042

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1777 STEP MOTR CIRC” with CONSULT-III is detected under the following conditions.
- When operating step motor ON and OFF, there is no proper change in the voltage of TCM terminal which corresponds to it.

Possible Cause

- Step motor
- Harness or connectors
(Step motor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

 **With CONSULT-III**

1. Turn ignition switch ON.
2. Drive vehicle for at least 5 consecutive seconds.
3. Perform “SELF-DIAG RESULTS”. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

 **With GST**

Follow the procedure “With CONSULT-III”.

Is “P1777 STEP MOTR CIRC” detected?

- YES >> Go to [TM-172, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992043

1. CHECK INPUT SIGNALS

 **With CONSULT-III**

1. Start engine.
2. Select “DATA MONITOR”.
3. Start vehicle and read out the value of “STM STEP”, “SMCOIL A”, “SMCOIL B”, “SMCOIL C”, and “SMCOIL D”.

| Item name | Condition | Display value (Approx.) |
|-----------|----------------|-------------------------|
| STM STEP | During driving | -20 step – 190 step |
| SMCOIL A | | Changes ON↔OFF. |
| SMCOIL B | | |
| SMCOIL C | | |
| SMCOIL D | | |

Is the inspection result normal?

- YES >> GO TO 4..

P1777 STEP MOTOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

NO >> GO TO 2..

2.CHECK HARNESS BETWEEN TCM AND STEP MOTOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector and TCM connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 27 | F46 | 9 | Existed |
| | 28 | | 8 | |
| | 29 | | 7 | |
| | 30 | | 6 | |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between body ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK STEP MOTOR

Check step motor. Refer to [TM-173, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-181, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-228, "Exploded View"](#).

Component Inspection

INFOID:000000000992044

STEP MOTOR

1.STEP MOTOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminals and ground.

| CVT unit harness connector | | | Resistance (Approx.) |
|----------------------------|----------|----------|----------------------|
| Connector | Terminal | Terminal | |
| F46 | 6 | 7 | 30 Ω |
| | 8 | 9 | |

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 6 | Ground | 15 Ω |
| | 7 | | |
| | 8 | | |
| | 9 | | |

Is the inspection result normal?

P1777 STEP MOTOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

YES >> **INSPECTION END**

NO >> Transaxle assembly. Refer to [TM-233, "Exploded View"](#).

P1778 STEP MOTOR - FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

P1778 STEP MOTOR - FUNCTION

Description

INFOID:000000000992045

- The step motor's 4 aspects of ON/OFF change according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.
- This diagnosis item is detected when electrical system is OK, but mechanical system is NG.
- This diagnosis item is detected when the state of the changing the speed mechanism in unit does not operate normally.

DTC Logic

INFOID:000000000992046

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1778 STEP MOTR/FNC" with CONSULT-III is detected under the following conditions.
 - When not changing the pulley ratio according to the instruction of TCM.

Possible Cause

Step motor

DTC CONFIRMATION PROCEDURE

CAUTION:

- Always drive vehicle at a safe speed.
- Before starting "DTC CONFIRMATION PROCEDURE", confirm "Hi" or "Mid" or "Low" fixation by "PRI SPEED" and "VEHICLE SPEED" on "DATA MONITOR MODE".
- If hi-gear fixation occurred, go to [TM-175. "Diagnosis Procedure"](#).

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 30 consecutive seconds.

TEST START FROM 0 km/h (0 MPH)

CONSTANT ACCELERATION : Keep 30 sec or more

VEHICLE SPEED : 10 km/h (6 MPH) or more

ACC PEDAL OPEN : More than 1.0/8

RANGE : "D" position

ENG SPEED : 450 rpm or more

With GST

Follow the procedure "With CONSULT-III".

Is "P1778 STEP MOTR/FNC" detected?

YES >> Go to [TM-175. "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992047

1. CHECK STEP MOTOR

P1778 STEP MOTOR - FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

Ⓟ With CONSULT-III

It is monitoring whether "GEAR RATIO: 2.37 – 0.43" changes similarly to "STM STEP: –20 – 190" by "DATA MONITOR" mode. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).

ⓧ Without CONSULT-III

Inspect the engine speed (rise and descend), vehicle speed, throttle position, and check shift change. Refer to [TM-235, "Vehicle Speed When Shifting Gears"](#).

OK or NG

OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NG >> Replace the transaxle assembly. Refer to [TM-233, "Exploded View"](#).

SHIFT LOCK SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

SHIFT LOCK SYSTEM

Description


INFOID:000000000992048

The selector lever cannot be shifted from "P" position to any other position unless the ignition switch is in the ON position and the brake pedal is depressed.

Wiring Diagram

INFOID:000000000992049

CVT SHIFT LOCK SYSTEM (VQ35DE)



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


SHIFT LOCK SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]


CVT SHIFT LOCK SYSTEM (VQ35DE) CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | | | | | |
|--------------|-----|---------------|-----|-------------|---|
| Terminal No. | 56G | Color of wire | R/W | Signal Name | - |
|--------------|-----|---------------|-----|-------------|---|

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| | | | | | |
|--------------|----|---------------|-----|-------------|---------------|
| Terminal No. | 84 | Color of wire | Y/R | Signal Name | AT_DEVICE_OUT |
| | 87 | G/B | | | SHIFT_P |

| | |
|-----------------|------------|
| Connector No. | M23 |
| Connector Name | CVT DEVICE |
| Connector Color | WHITE |



| | | | | | |
|--------------|---|---------------|-----|-------------|------------------|
| Terminal No. | 1 | Color of wire | LGR | Signal Name | MT-MODE |
| | 2 | BR | | | M-DOWN |
| | 3 | W | | | M-UP |
| | 4 | B | | | GND |
| | 5 | G | | | AT-MODE |
| | 6 | RW | | | S/LOCK_SOL_GND |
| | 7 | B | | | S/LOCK_SOL_INPUT |
| | 8 | Y/R | | | DETENT_KEY_SW |
| | 9 | G/B | | | DETENT_KEY_SW |

| | |
|-----------------|--------------|
| Connector No. | E30 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



SHIFT LOCK SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F09B]

- Selector lever can be moved from "P" position with ignition key in ON position and brake pedal released.

1. CHECK POWER SOURCE

1. Disconnect CVT device harness connector.
2. Turn ignition switch ON (Do not start engine).
3. Check voltage between CVT device harness connector M23 terminal 6 and ground.

Voltage:


Brake pedal depressed: Battery voltage

Brake pedal released: 0V

OK or NG

OK >> GO TO 4.

NG >> GO TO 2.



2. CHECK POWER SOURCE AT STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Turn ignition switch ON (Do not start engine).
4. Check voltage between stop lamp switch harness connector E38 terminal 3 and ground.

Voltage:


Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check the following items for damage, repair or replace damaged parts:

- 10A fuse [No. 3, located in the fuse block (J/B)].
- Harness for open between ignition switch and stop lamp switch harness connector.
- Ignition switch, refer to XX POWER SUPPLY ROUTING CIRCUIT.



3. CHECK STOP LAMP SWITCH


1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector E38.
3. Check continuity between stop lamp switch terminals 3 and 4.

| Condition | Continuity |
|-----------------------------------|------------|
| Manually depress stop lamp switch | YES |
| Stop lamp switch released | NO |

OK or NG

OK >> Adjust stop lamp switch. Refer to XX BRAKE PEDAL - ADJUSTMENT.

NG >> Replace stop lamp switch.



4. CHECK GROUND CIRCUIT

SHIFT LOCK SYSTEM

[CVT: RE0F09B]


< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between CVT device harness connector M23 terminal 6 and ground.

Continuity should exist.

OK or NG

- OK >> Replace shift lock solenoid and park position switch assembly.
- NG >> Repair open circuit in harness or connectors.



ECU DIAGNOSIS

TCM

Reference Value

INFOID:000000000992051

VALUES ON THE DIAGNOSIS TOOL

| Item name | Condition | Display value (Approx.) |
|----------------|--|---|
| VSP SENSOR | During driving | Approximately matches the speedometer reading. |
| ESTM VSP SIG | During driving | Approximately matches the speedometer reading. |
| PRI SPEED SEN | During driving (lock-up ON) | Approximately matches the engine speed. |
| ENG SPEED SIG | Engine running | Closely matches the tachometer reading. |
| SEC HYDR SEN | "N" position idle | 0.8 - 1.0 V |
| PRI HYDR SEN | "N" position idle | 0.7 - 3.5 V |
| ATF TEMP SEN | When CVT fluid temperature is 20°C (68°F). | 1.8 - 2.0 V |
| | When CVT fluid temperature is 80°C (176°F). | 0.6 - 1.0 V |
| VIGN SEN | Ignition switch: ON | Battery voltage |
| VEHICLE SPEED | During driving | Approximately matches the speedometer reading. |
| PRI SPEED | During driving (lock-up ON) | Approximately matches the engine speed. |
| SEC SPEED | During driving | 45 X Approximately matches the speedometer reading. |
| ENG SPEED | Engine running | Closely matches the tachometer reading. |
| GEAR RATIO | During driving | 2.37 - 0.43 |
| ACC PEDAL OPEN | Released accelerator pedal - Fully depressed accelerator pedal | 0.0/8 - 8.0/8 |
| SEC PRESS | "N" position idle | 0.5 - 0.9 MPa |
| PRI PRESS | "N" position idle | 0.3 - 0.9 MPa |
| STM STEP | During driving | -20 step – 190 step |
| ISOLT1 | Lock-up OFF | 0.0 A |
| | Lock-up ON | 0.7 A |
| ISOLT2 | Release your foot from the accelerator pedal. | 0.8 A |
| | Press the accelerator pedal all the way down. | 0.0 A |
| ISOLT3 | Secondary pressure low - Secondary pressure high. | 0.8 - 0.0 A |
| SOLMON1 | Lock-up OFF | 0.0 A |
| | Lock-up ON | 0.6 - 0.7 A |
| SOLMON2 | "N" position idle | 0.8 A |
| | When stalled | 0.3 - 0.6 A |
| SOLMON3 | "N" position idle | 0.6 - 0.7 A |
| | When stalled | 0.4 - 0.6 A |
| INH SW3M | Selector lever in "D" position | ON |
| | Selector lever in "P", "R" and "N" positions | OFF |
| INH SW4 | Selector lever in "R" and "D" positions | ON |
| | Selector lever in "P" and "N" positions | OFF |

TCM

< ECU DIAGNOSIS >

[CVT: RE0F09B]

| Item name | Condition | Display value (Approx.) |
|---------------|--|-------------------------|
| INH SW3 | Selector lever in "D" position | ON |
| | Selector lever in "P", "R" and "N" positions | OFF |
| INH SW2 | Selector lever in "N" and "D" positions | ON |
| | Selector lever in "P" and "R" positions | OFF |
| INH SW1 | Selector lever in "R", "N" and "D" positions | ON |
| | Selector lever in "P" position | OFF |
| BRAKE SW | Depressed brake pedal | ON |
| | Released brake pedal | OFF |
| FULL SW | Fully depressed accelerator pedal | ON |
| | Released accelerator pedal | OFF |
| IDLE SW | Released accelerator pedal | ON |
| | Fully depressed accelerator pedal | OFF |
| DOWNLVR | Selector lever: - side | ON |
| | Other than the above | OFF |
| UPLVR | Selector lever: + side | ON |
| | Other than the above | OFF |
| NONMMODE | Manual shift gate position (neutral, +side, -side) | OFF |
| | Other than the above | ON |
| MMODE | Manual shift gate position (neutral) | ON |
| | Other than the above | OFF |
| INDDRNG | Selector lever in "D" position | ON |
| | Selector lever in other positions | OFF |
| INDNRNG | Selector lever in "N" position | ON |
| | Selector lever in other positions | OFF |
| INDRRNG | Selector lever in "R" position | ON |
| | Selector lever in other positions | OFF |
| INDPRNG | Selector lever in "P" position | ON |
| | Selector lever in other positions | OFF |
| SMCOIL D | During driving | Changes ON ⇔ OFF. |
| SMCOIL C | During driving | Changes ON ⇔ OFF. |
| SMCOIL B | During driving | Changes ON ⇔ OFF. |
| SMCOIL A | During driving | Changes ON ⇔ OFF. |
| LUSEL SOL OUT | Selector lever in "P" and "N" positions | ON |
| | Wait at least for 5 seconds with the selector lever in "R" and "D" positions | OFF |
| STRTR RLY OUT | Selector lever in "P" and "N" positions | ON |
| | Selector lever in other positions | OFF |
| STRTR RLY MON | Selector lever in "P" and "N" positions | ON |
| | Selector lever in other positions | OFF |
| VDC ON | VDC operate | ON |
| | Other conditions | OFF |
| TCS ON | TCS operate | ON |
| | Other conditions | OFF |
| ABS ON | ABS operate | ON |
| | Other conditions | OFF |


TCM

< ECU DIAGNOSIS >

[CVT: RE0F09B]

| Item name | Condition | Display value (Approx.) |
|------------|---|-------------------------|
| RANGE | Selector lever in "N" and "P" position. | N·P |
| | Selector lever in "R" position. | R |
| | Selector lever in "D" position. | D |
| M GEAR POS | During driving | 1, 2, 3, 4, 5, 6 |

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|--------|------------------------|--------------|--------------------------------------|--------------------------|
| + | - | Signal name | Input/Output | | |
| 1 (P/B) | Ground | PNP switch 2 | Output | Selector lever in "N", "D" positions | 0 V |
| | | | | Selector lever in other positions | 10.0 V – Battery voltage |
| 2 (P/L) | Ground | PNP switch 3 | Output | Selector lever in "D" position | 0 V |
| | | | | Selector lever in other positions | 8.0 V – Battery voltage |
| 3 (G/O) | Ground | PNP switch 4 | Output | Selector lever in "R", "D" positions | 0 V |
| | | | | Selector lever in other positions | 10.0 V – Battery voltage |
| 4 (GR) | Ground | PNP switch 3 (monitor) | Output | Selector lever in "D" position | 0 V |
| | | | | Selector lever in other positions | 8.0 V – Battery voltage |
| 5 (B) | Ground | Ground | Output | Always | 0 V |
| 6 (O) | Ground | K-LINE | Inout/Output | — | — |
| 7 (W) | Ground | Sensor ground | Input | Always | 0 V |
| 8 (G/W) | — | CLOCK | — | — | — |
| 9 (L/R) | — | CHIP SELECT | — | — | — |
| 10 (BR/R) | — | DATA I/O | — | — | — |

TCM

< ECU DIAGNOSIS >

[CVT: RE0F09B]

| Terminal No. | | Description | | Condition | | Value (Approx.) |
|--------------|--------|--|--------------|--|--|-----------------|
| + | - | Signal name | Input/Output | | | |
| 11 (BR/W) | Ground | PNP switch 1 | Output | Ignition switch ON | Selector lever in "R", "N", "D" positions | 0 V |
| | | | | | Selector lever in other position | Battery voltage |
| 13 (V) | Ground | CVT fluid temperature sensor | Output | Ignition switch ON | When CVT fluid temperature is 20°C (68°F) | 2.0 V |
| | | | | | When CVT fluid temperature is 80°C (176°F) | 1.0 V |
| 14 (R/W) | Ground | Transmission fluid pressure sensor B (Primary pressure sensor) | Input | "N" position idle | | 0.7 – 3.5 V |
| 15 (V/W) | Ground | Transmission fluid pressure sensor A (Secondary pressure sensor) | Input | | | 1.0 V |
| 19 (SB) | Ground | Back-up lamp relay | Input | Ignition switch ON | Selector lever in "R" position | 0 V |
| | | | | | Selector lever in other positions | Battery voltage |
| 20 (R/B) | Ground | Starter relay | Input | Ignition switch ON | Selector lever in "N", "P" positions | Battery voltage |
| | | | | | Selector lever in other positions | 0 V |
| 25 (W/R) | Ground | Sensor ground | Input | Always | | 0 V |
| 26 (L/O) | Ground | Sensor power | Input | Ignition switch ON | — | 5.0 V |
| | | | | Ignition switch OFF | — | 0 V |
| 27 (R/G) | Ground | Step motor D | Input | Within 2 seconds after ignition switch ON, the time measurement by using the pulse width measurement function (Hi level) of CONSULT-III.*1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. | | 10.0 msec |
| 28 (R) | Ground | Step motor C | Input | | | 30.0 msec |
| 29 (O/B) | Ground | Step motor B | Input | | | 10.0 msec |
| 30 (G/R) | Ground | Step motor A | Input | | | 30.0 msec |
| 31 (P) | — | CAN-L | Inout/Output | — | | — |
| 32 (L) | — | CAN-H | Inout/Output | — | | — |
| 33 (LG) | Ground | Input speed sensor (Primary speed sensor) | Input | When driving ["M1" position, 20 km/h (12 MPH)] | | 660 Hz |
| 34 (LG/R) | Ground | Output speed sensor (Secondary speed sensor) | Input | When driving ["D" position, 20 km/h (12 MPH)] | | 400 Hz |
| 37 (L/B) | Ground | Lock-up select solenoid valve | Output | Ignition switch ON | Selector lever in "P", "N" positions | Battery voltage |
| | | | | | Wait at least for 5 seconds with the selector lever in "R", "D" positions. | 0 V |
| 38 (L/W) | Ground | Torque converter clutch solenoid valve | Output | When vehicle cruises in "D" position | When CVT performs lock-up | 6.0 V |
| | | | | | When CVT does not perform lock-up | 1.0 V |

TCM

< ECU DIAGNOSIS >

[CVT: RE0F09B]


| Terminal No. | | Description | | Condition | | Value (Approx.) |
|--------------|--------|---|--------------|------------------------|---|-----------------|
| + | - | Signal name | Input/Output | | | |
| 39 (W/B) | Ground | Pressure control solenoid valve B (Secondary pressure solenoid valve) | Output | "P", "N" position idle | Release your foot from the accelerator pedal. | 5.0 – 7.0 V |
| | | | | | Press the accelerator pedal all the way down. | 3.0 – 4.0 V |
| 40 (R/Y) | Ground | Pressure control solenoid valve A (Line pressure solenoid valve) | Output | | Release your foot from the accelerator pedal. | 5.0 – 7.0 V |
| | | | | | Press the accelerator pedal all the way down. | 1.0 – 3.0 V |
| 42 (B) | Ground | Ground | Output | Always | | 0 V |
| 45 (L/R) | Ground | Power supply (memory back-up) | Input | Always | | Battery voltage |
| 46 (Y) | Ground | Power supply | Input | Ignition switch ON | — | Battery voltage |
| | | | | Ignition switch OFF | — | 0 V |
| 47 (L/R) | Ground | Power supply (memory back-up) | Input | Always | | Battery voltage |
| 48 (Y) | Ground | Power supply | Input | Ignition switch ON | — | Battery voltage |
| | | | | Ignition switch OFF | — | 0 V |

*1: A circuit tester cannot be used to test this item.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


Wiring Diagram — CVT CONTROL SYSTEM —

INFOID:00000000992052



ALDWA0004GE


--- : DATA LINE



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


ALDWA0005GE

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | GND |
| 5 | B | GND |
| 6 | L | CAN-H |
| 7 | O | K-LINE |
| 8 | G | IGN_SW |
| 14 | P | CAN-L |
| 16 | Y/R | BATT |

| | |
|-----------------|---------------------------|
| Connector No. | M21 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 132 | R | ST_CONT_USM |


| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 78 | P | CAN-L |
| 79 | L | CAN-H |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|---------------|
| 1 | W/L | BAT |
| 2 | O | IGN |
| 3 | B | GND |
| 14 | V/Y | ACC |
| 21 | L | CAN-H |
| 22 | P | CAN-L |
| 23 | B | GND |
| 37 | G | NOT M RANGE |
| 38 | BR | AT SHIFT DOWN |
| 39 | W | AT SHIFT UP |
| 40 | LG/R | M RANGE |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |




| | |
|-----------------|------------|
| Connector No. | M23 |
| Connector Name | CVT DEVICE |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG/R | MT_MODE |
| 2 | BR | M_DOWN |
| 3 | W | M_UP |
| 4 | B | GND |
| 5 | G | AT_MODE |

ALDIA0009GB

| | |
|-----------------|--------------|
| Connector No. | E3 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | G/B | - |
| 6 | L/R | - |
| 8 | P | - |
| 14 | B | - |
| 15 | O | - |

| | |
|-----------------|------------------|
| Connector No. | E6 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1P | SB | - |
| 4P | G/R | - |
| 6P | Y | - |
| 8P | Y/R | - |
| 12P | L/R | - |

| | |
|-----------------|-------|
| Connector No. | E10 |
| Connector Name | ECM |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 97 | P | CAN-L |
| 98 | L | CAN-H |

| | |
|-----------------|--|
| Connector No. | E17 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 41 | B | S-GND |
| 46 | R | START_CONT |

| | |
|-----------------|---------------------|
| Connector No. | E21 |
| Connector Name | JOINT CONNECTOR-E03 |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 2 | L | - |
| 3 | L | - |

| | |
|-----------------|---------------------|
| Connector No. | E22 |
| Connector Name | JOINT CONNECTOR-E04 |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 2 | P | - |
| 3 | P | - |

| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y/R | - |
| 2 | R/G | - |
| 3 | G/R | - |
| 4 | R/W | - |

| | |
|-----------------|--------------------|
| Connector No. | E34 |
| Connector Name | BACK-UP LAMP RELAY |
| Connector Color | BLUE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O/B | - |
| 2 | G/B | - |
| 3 | P/B | - |
| 5 | O | - |

| | |
|-----------------|--------------|
| Connector No. | E30 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 8G | P | - |
| 13G | O | - |
| 15G | L | - |
| 51G | L | - |
| 54G | P | - |

| | |
|-----------------|----------------|
| Connector No. | E49 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | BROWN |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 51 | O | - |
| 52 | O/B | - |

| | |
|-----------------|----------------|
| Connector No. | E47 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 45 | O | - |

| | |
|-----------------|----------------|
| Connector No. | E46 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 31 | O | - |

ALDIA0011GB


A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

| | |
|-----------------|----------------|
| Connector No. | E50 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 56 | O | — |

| | |
|-----------------|--------------|
| Connector No. | F1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | — |
| 4 | G/B | — |
| 6 | L/R | — |
| 8 | P | — |
| 14 | B | — |
| 15 | O | — |

| | |
|-----------------|--|
| Connector No. | F10 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 53 | 54 | 55 | 56 | 57 | 58 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 |
| 47 | 48 | 49 | 50 | 51 | 52 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 58 | Y | AT_ECU |
| 72 | R/B | NPSW |
| 74 | Y | START_IG-EGI |
| 80 | B/W | STARTER_MOTOR |

| | |
|-----------------|-----------------------------------|
| Connector No. | F16 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK |



| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 47 | 48 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 45 | 46 |
| 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 43 | 44 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 41 | 42 |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P/B | R_RANGE_SW |
| 2 | P/L | N_RANGE_SW |
| 3 | G/O | D_RANGE_SW |
| 4 | GR | L_RANGE_SW |
| 5 | B | GND |
| 6 | O | K-LINE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 7 | W | SENSOR_GND |
| 8 | G/W | CLOCK (SEL2) |
| 9 | L/R | CHIP_SELECT (SEL1) |
| 10 | BR/R | DATA_I/O (SEL3) |
| 11 | BR/W | P_RANGE_SW |
| 13 | V | ATF_TEMP_SENS |
| 14 | LG | PRI_OIL_PRESS_SENS |
| 15 | V/W | SEC_OIL_PRESS_SE NS |
| 19 | G/B | REV LAMP RLY |
| 20 | — | — |
| 25 | W/R | SENSOR_GND |
| 26 | L/O | SENS_POWER_SOURCE |
| 27 | R/G | S/M-D |
| 28 | R | S/M-C |
| 29 | O/B | S/M-B |
| 30 | G/R | S/M-A |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 31 | P | CAN-L |
| 32 | L | CAN-H |
| 33 | LG | PRI_SPEED_SENSOR |
| 34 | LG/R | SEC_SPEED_SENSOR |
| 37 | L/B | L/U&SEL-ON/OFF_SOL |
| 38 | L/W | L/U&SEL-LINER_SOL |
| 39 | W/B | SEC-LINER-SOL |
| 40 | R/Y | PL_LINER_SOL |
| 42 | B | GND |
| 45 | L/R | BATT |
| 46 | Y | VIGN |
| 47 | L/R | BATT |
| 48 | Y | VIGN |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------------------|
| 1 | L/R | CHIP SELECT |
| 2 | R/Y | PL LINEAR SOL |
| 3 | W/B | SEC LINEAR SOL |
| 4 | BR/W | INH SW 1 |
| 5 | P/B | INH SW 2 |
| 6 | G/R | S/M-COIL A |
| 7 | O/B | S/M-COIL B |
| 8 | R/Y | S/M-COIL C |
| 9 | R/G | S/M-COIL D |
| 11 | G/W | CLOCK |
| 12 | G | L/U&SELECT-LINEAR SOL |
| 13 | L/W | L/U&SELECT-ON/OFF SOL |
| 14 | P/L | INH SW 3 |
| 15 | G/O | INH SW 4 |
| 16 | BR/R | DATA I/O |
| 17 | V | ATF TEMP SENSOR |
| 18 | GR | INH SW 3 M |
| 19 | W/R | SENSOR GND |
| 20 | L/O | SENSOR POWER SOURCE |
| 22 | LG | PRI SPEED SENSOR |
| 23 | V/W | SEC OIL PRESSURE SENSOR |
| 25 | LG | PRI OIL PRESSURE SENSOR |

| | |
|-----------------|----------|
| Connector No. | F46 |
| Connector Name | CVT UNIT |
| Connector Color | BLACK |




| | |
|-----------------|------------------------|
| Connector No. | F23 |
| Connector Name | SECONDARY SPEED SENSOR |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|------------------|
| 1 | W | SENSOR_GND |
| 2 | LG/R | SEC_SPEED_SENSOR |
| 3 | Y | VIGN |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | Y | - |
| 3 | L/R | - |
| 4 | L/R | - |
| 5 | L/R | - |
| 6 | Y | - |
| 7 | Y | - |
| 8 | B | - |
| 9 | B | - |
| 10 | B | - |

| | |
|-----------------|---------------------|
| Connector No. | F73 |
| Connector Name | JOINT CONNECTOR-F05 |
| Connector Color | BLACK |



Fail-safe

The TCM has an electrical fail-safe mode. This mode makes it possible to operate even if there is an error in a main electronic control input/output signal circuit.

FAIL-SAFE FUNCTION

If any malfunction occurs in a sensor or solenoid, this function controls the CVT to make driving possible.

Output Speed Sensor (Secondary Speed Sensor)

The shift pattern is changed in accordance with throttle position when an unexpected signal is sent from the output speed sensor (secondary speed sensor) to the TCM. The manual mode position is inhibited, and the transaxle is put in “D”.

Input Speed Sensor (Primary Speed Sensor)

The shift pattern is changed in accordance with throttle position and secondary speed (vehicle speed) when an unexpected signal is sent from the input speed sensor (primary speed sensor) to the TCM. The manual mode position is inhibited, and the transaxle is put in “D”.

PNP Switch

If an unexpected signal is sent from the PNP switch to the TCM, the transaxle is put in “D”.

Manual Mode Switch

If an unexpected signal is sent from the manual mode switch to the TCM, the transaxle is put in “D”.

CVT Fluid Temperature Sensor

If an unexpected signal is sent from the CVT fluid temperature sensor to the TCM, the gear ratio in use before receiving the unexpected signal is maintained or the gear ratio is controlled to keep engine speed under 2,800 rpm.

Transmission Fluid Pressure Sensor A (Secondary Pressure Sensor)

- If an unexpected signal is sent from the transmission fluid pressure sensor A (secondary pressure sensor) to the TCM, the secondary pressure feedback control is stopped and the offset value obtained before the non-standard condition occurs is used to control line pressure.
- If transmission fluid pressure sensor A (secondary pressure sensor) error signal is input to TCM, secondary pressure feedback control stops, but line pressure is controlled normally.

Pressure Control Solenoid A (Line Pressure Solenoid)

If an unexpected signal is sent from the solenoid to the TCM, the pressure control solenoid A (line pressure solenoid) is turned OFF to achieve the maximum fluid pressure.

Pressure Control Solenoid B (Secondary Pressure Solenoid)

If an unexpected signal is sent from the solenoid to the TCM, the pressure control solenoid B (secondary pressure solenoid) is turned OFF to achieve the maximum fluid pressure.

Torque Converter Clutch Solenoid

If an unexpected signal is sent from the solenoid to the TCM, the torque converter clutch solenoid is turned OFF to cancel the lock-up.

Step Motor

If an unexpected signal is sent from the step motor to the TCM, the step motor coil phases “A” through “D” are all turned OFF to hold the gear ratio used right before the non-standard condition occurred.

CVT Lock-up Select Solenoid

If an unexpected signal is sent from the solenoid to the TCM, the CVT lock-up select solenoid is turned OFF to cancel the lock-up.

TCM Power Supply (Memory Back-up)

Transaxle assembly is protected by limiting the engine torque when the memory back-up power supply (for controlling) from the battery is not supplied to TCM. Normal status is restored when turning the ignition switch OFF to ON after the normal power supply.

DTC Inspection Priority Chart

INFOID:000000000992054

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

NOTE:

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [TM-118](#).

| Priority | Detected items (DTC) |
|----------|------------------------------|
| 1 | U1000 CAN communication line |
| 2 | Except above |

DTC Index

INFOID:000000000992055

TCM

< ECU DIAGNOSIS >

[CVT: RE0F09B]

NOTE:

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [TM-118](#).

| DTC | | Items (CONSULT-III screen terms) | Reference page |
|---------------------|------------------------------------|-------------------------------------|------------------------|
| OBD-II | Except OBD-II | | |
| CONSULT-III GST* | CONSULT-III only “TRANSMISSION” | | |
| — | P0615 | STARTER RELAY/CIRC | TM-119 |
| — | P0703 | BRAKE SW/CIRC | TM-121 |
| P0705 | P0705 | PNP SW/CIRC | TM-123 |
| P0710 | P0710 | ATF TEMP SEN/CIRC | TM-126 |
| P0715 | P0715 | INPUT SPD SEN/CIRC | TM-128 |
| P0720 | P0720 | VEH SPD SEN/CIR AT | TM-130 |
| — | P0725 | ENGINE SPEED SIG | TM-133 |
| — | P0730 | BELT DAMG | TM-135 |
| P0740 | P0740 | TCC SOLENOID/CIRC | TM-137 |
| P0744 | P0744 | A/T TCC S/V FNCTN | TM-139 |
| P0745 | P0745 | L/PRESS SOL/CIRC | TM-141 |
| P0746 | P0746 | PRS CNT SOL/A FCTN | TM-143 |
| P0776 | P0776 | PRS CNT SOL/B FCTN | TM-145 |
| P0778 | P0778 | PRS CNT SOL/B CIRC | TM-147 |
| — | P0826 | MANUAL MODE SWITCH | TM-149 |
| P0840 | P0840 | TR PRS SENS/A CIRC | TM-152 |
| — | P0841 | PRESS SEN/FNCTN | TM-154 |
| P0845 | P0845 | TR PRS SENS/B CIRC | TM-156 |
| — | P0868 | SEC/PRESS DOWN | TM-158 |
| — | P1701 | TCM-POWER SUPPLY | TM-160 |
| — | P1705 | TP SEN/CIRC A/T | TM-162 |
| — | P1722 | ESTM VEH SPD SIG | TM-164 |
| — | P1723 | CVT SPD SEN/FNCTN | TM-166 |
| — | P1726 | ELEC TH CONTROL | TM-168 |
| P1740 | P1740 | LU-SLCT SOL/CIRC | TM-169 |
| — | P1745 | L/PRESS CONTROL | TM-171 |
| P1777 | P1777 | STEP MOTR CIRC | TM-172 |
| P1778 | P1778 | STEP MOTR/FNC | TM-175 |
| U1000 | U1000 | CAN COMM CIRCUIT | TM-118 |

*: These numbers are prescribed by SAE J2012.

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

SYMPTOM DIAGNOSIS

SYSTEM SYMPTOM

Symptom Table

INFOID:000000000992056

The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------------|-----------------------------------|-------------|---|------------------------|
| 1 | Shift Shock | Large shock. ("N" → "D" position) | ON vehicle | 1. Engine idle speed | EC-28 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. Accelerator pedal position sensor | TM-162 |
| | | | | 4. CVT position | TM-227 |
| | | | | 5. CVT fluid temperature sensor | TM-126 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. CVT fluid level and state | TM-214 |
| | | | | 8. Line pressure test | TM-221 |
| | | | | 9. Torque converter clutch solenoid valve | TM-137 |
| | | | | 10. Lock-up select solenoid valve | TM-169 |
| | | | | 11. PNP switch | TM-123 |
| | | | OFF vehicle | 12. Forward clutch | TM-233 |
| | | | | 13. Control valve | |
| 2 | Shift Shock | Large shock. ("N" → "R" position) | ON vehicle | 1. Engine idle speed | EC-28 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. Accelerator pedal position sensor | TM-162 |
| | | | | 4. CVT position | TM-227 |
| | | | | 5. CVT fluid temperature sensor | TM-126 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. CVT fluid level and state | TM-214 |
| | | | | 8. Line pressure test | TM-221 |
| | | | | 9. Torque converter clutch solenoid valve | TM-137 |
| | | | | 10. Lock-up select solenoid valve | TM-169 |
| | | | | 11. PNP switch | TM-123 |
| | | | OFF vehicle | 12. Reverse brake | TM-233 |
| | | | | 13. Control valve | |
| 3 | Shift Shock | Shock is too large for lock-up. | ON vehicle | 1. CVT position | TM-227 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. CAN communication line | TM-118 |
| | | | | 4. CVT fluid level and state | TM-214 |
| | | | OFF vehicle | 5. Torque converter | TM-233 |
| | | | | 6. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|--------------------------------------|------------------------|
| 4 | Slips/Will Not Engage | Vehicle cannot be started from "D" position. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. CVT position | TM-227 |
| | | | | 3. CAN communication line | TM-118 |
| | | | | 4. Line pressure test | TM-221 |
| | | | | 5. Stall test | TM-219 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | | 10. CVT fluid temperature sensor | TM-126 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Oil pump assembly | TM-233 |
| | | | | 14. Forward clutch | |
| | | | | 15. Control valve | |
| | | | | 16. Parking components | |
| 5 | Slips/Will Not Engage | Vehicle cannot be started from "R" position. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. CVT position | TM-227 |
| | | | | 3. CAN communication line | TM-118 |
| | | | | 4. Line pressure test | TM-221 |
| | | | | 5. Stall test | TM-219 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | | 10. CVT fluid temperature sensor | TM-126 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Oil pump assembly | TM-233 |
| | | | | 14. Reverse brake | |
| | | | | 15. Control valve | |
| | | | | 16. Parking components | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|----------------------------------|-------------------|-------------|---|------------------------|
| 6 | Slips/Will Not Engage | Does not lock-up. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Engine speed signal | TM-133 |
| | | | | 4. Primary speed sensor | TM-128 |
| | | | | 5. Torque converter clutch solenoid valve | TM-137 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Stall test | TM-219 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. PNP switch | TM-123 |
| | | | | 10. Lock-up select solenoid valve | TM-169 |
| | | | | 11. CVT fluid temperature sensor | TM-126 |
| | | | | 12. Secondary speed sensor | TM-130 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-233 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |
| 7 | Does not hold lock-up condition. | | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Engine speed signal | TM-133 |
| | | | | 4. Primary speed sensor | TM-128 |
| | | | | 5. Torque converter clutch solenoid valve | TM-137 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Stall test | TM-219 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. PNP switch | TM-123 |
| | | | | 10. Lock-up select solenoid valve | TM-169 |
| | | | | 11. CVT fluid temperature sensor | TM-126 |
| | | | | 12. Secondary speed sensor | TM-130 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-233 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|---|------------------------|
| 8 | | Lock-up is not released. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Engine speed signal | TM-133 |
| | | | | 4. Primary speed sensor | TM-128 |
| | | | | 5. Torque converter clutch solenoid valve | TM-137 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Stall test | TM-219 |
| | | | OFF vehicle | 8. Torque converter | TM-233 |
| | | | | 9. Oil pump assembly | |
| | | | | 10. Control valve | |
| 9 | Slips/Will Not Engage | With selector lever in "D" position, acceleration is extremely poor. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Stall test | TM-219 |
| | | | | 4. Accelerator pedal position sensor | TM-162 |
| | | | | 5. CAN communication line | TM-118 |
| | | | | 6. PNP switch | TM-123 |
| | | | | 7. CVT position | TM-227 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. Primary speed sensor | TM-128 |
| | | | | 10. Secondary speed sensor | TM-130 |
| | | | | 11. Accelerator pedal position sensor | TM-162 |
| | | | | 12. Primary pressure sensor | TM-156 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | | 14. CVT fluid temperature sensor | TM-126 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-233 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Forward clutch | |
| | | | | 19. Control valve | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|---|------------------------|
| 10 | Slips/Will Not Engage | With selector lever in "R" position, acceleration is extremely poor. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Stall test | TM-219 |
| | | | | 4. Accelerator pedal position sensor | TM-162 |
| | | | | 5. CAN communication line | TM-118 |
| | | | | 6. PNP switch | TM-123 |
| | | | | 7. CVT position | TM-227 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. Primary speed sensor | TM-128 |
| | | | | 10. Secondary speed sensor | TM-130 |
| | | | | 11. Accelerator pedal position sensor | TM-162 |
| | | | | 12. Primary pressure sensor | TM-156 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | | 14. CVT fluid temperature sensor | TM-126 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-233 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Reverse brake | |
| | | | | 19. Control valve | |
| 11 | Slips at lock-up. | | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Engine speed signal | TM-133 |
| | | | | 4. Primary speed sensor | TM-128 |
| | | | | 5. Torque converter clutch solenoid valve | TM-137 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Stall test | TM-219 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. PNP switch | TM-123 |
| | | | | 10. Lock-up select solenoid valve | TM-169 |
| | | | | 11. CVT fluid temperature sensor | TM-126 |
| | | | | 12. Secondary speed sensor | TM-130 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-233 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|--------------------------------------|-------------|---------------------------------------|------------------------|
| 12 | Other | No creep at all. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Accelerator pedal position sensor | TM-162 |
| | | | | 4. PNP switch | TM-123 |
| | | | | 5. CAN communication line | TM-118 |
| | | | | 6. Stall test | TM-219 |
| | | | | 7. CVT position | TM-227 |
| | | | | 8. Step motor | TM-172 |
| | | | | 9. Primary speed sensor | TM-128 |
| | | | | 10. Secondary speed sensor | TM-130 |
| | | | | 11. Accelerator pedal position sensor | TM-162 |
| | | | | 12. CVT fluid temperature sensor | TM-126 |
| | | | | 13. Primary pressure sensor | TM-156 |
| | | | | 14. Secondary pressure sensor | TM-152 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-233 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Gear system | |
| | | | | 19. Forward clutch | |
| | | | | 20. Reverse brake | |
| | | | | 21. Control valve | |
| 13 | Other | Vehicle cannot run in all positions. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. PNP switch | TM-123 |
| | | | | 4. Stall test | TM-219 |
| | | | | 5. CVT position | TM-227 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | | 10. CVT fluid temperature sensor | TM-126 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-233 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Forward clutch | |
| | | | | 17. Reverse brake | |
| | | | | 18. Control valve | |
| | | | | 19. Parking components | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|---|-------------|--------------------------------------|------------------------|
| 14 | Other | With selector lever in "D" position, driving is not possible. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. PNP switch | TM-123 |
| | | | | 4. Stall test | TM-219 |
| | | | | 5. CVT position | TM-227 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | | 10. CVT fluid temperature sensor | TM-126 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-233 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Forward clutch | |
| | | | | 17. Control valve | |
| | | | | 18. Parking components | |
| 15 | Other | With selector lever in "R" position, driving is not possible. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. PNP switch | TM-123 |
| | | | | 4. Stall test | TM-219 |
| | | | | 5. CVT position | TM-227 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | | 10. CVT fluid temperature sensor | TM-126 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-233 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Reverse brake | |
| | | | | 17. Control valve | |
| | | | | 18. Parking components | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|--------------------------------|-------------|---|------------------------|
| 16 | Other | Judder occurs during lock-up. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. Primary speed sensor | TM-128 |
| | | | | 4. Secondary speed sensor | TM-130 |
| | | | | 5. Accelerator pedal position sensor | TM-162 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Torque converter clutch solenoid valve | TM-137 |
| | | | OFF vehicle | 8. Torque converter | TM-233 |
| | | | | 9. Control valve | |
| 17 | Other | Strange noise in "D" position. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. CAN communication line | TM-118 |
| | | | OFF vehicle | 4. Torque converter | TM-233 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Forward clutch | |
| | | | | 8. Control valve | |
| | | | | 9. Bearing | |
| 18 | Other | Strange noise in "R" position. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. CAN communication line | TM-118 |
| | | | OFF vehicle | 4. Torque converter | TM-233 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Reverse brake | |
| | | | | 8. Control valve | |
| 19 | Other | Strange noise in "N" position. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. CAN communication line | TM-118 |
| | | | OFF vehicle | 4. Torque converter | TM-233 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Control valve | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|--|-------------|--------------------------------------|------------------------|
| 20 | | Vehicle does not decelerate by engine brake. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. CVT position | TM-227 |
| | | | | 3. CAN communication line | TM-118 |
| | | | | 4. Step motor | TM-172 |
| | | | | 5. Primary speed sensor | TM-128 |
| | | | | 6. Secondary speed sensor | TM-130 |
| | | | | 7. Line pressure test | TM-221 |
| | | | | 8. Engine speed signal | TM-133 |
| | | | | 9. Accelerator pedal position sensor | TM-162 |
| | | | OFF vehicle | 10. Control valve | TM-233 |
| 21 | Other | Maximum speed low. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Line pressure test | TM-221 |
| | | | | 3. Accelerator pedal position sensor | TM-162 |
| | | | | 4. CAN communication line | TM-118 |
| | | | | 5. Stall test | TM-219 |
| | | | | 6. Step motor | TM-172 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Primary pressure sensor | TM-156 |
| | | | | 10. Secondary pressure sensor | TM-152 |
| | | | | 11. CVT fluid temperature sensor | TM-126 |
| | | | OFF vehicle | 12. Torque converter | TM-233 |
| | | | | 13. Oil pump assembly | |
| | | | | 14. Gear system | |
| | | | | 15. Forward clutch | |
| | | | | 16. Control valve | |
| 22 | | With selector lever in "P" position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled. | ON vehicle | 1. PNP switch | TM-123 |
| | | | | 2. CVT position | TM-227 |
| | | | OFF vehicle | 3. Parking components | TM-233 |
| 23 | | Vehicle runs with CVT in "P" position. | ON vehicle | 1. PNP switch | TM-123 |
| | | | | 2. CVT fluid level and state | TM-214 |
| | | | | 3. CVT position | TM-227 |
| | | | OFF vehicle | 4. Parking components | TM-233 |
| | | | | 5. Gear system | |
| | | | | 6. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|---|-------------|---|------------------------|
| 24 | | Vehicle runs with CVT in "N" position. | ON vehicle | 1. PNP switch | TM-123 |
| | | | | 2. CVT fluid level and state | TM-214 |
| | | | | 3. CVT position | TM-227 |
| | | | OFF vehicle | 4. Gear system | TM-233 |
| | | | | 5. Forward clutch | |
| | | | | 6. Reverse brake | |
| | | | | 7. Control valve | |
| 25 | | Engine stall. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. Primary speed sensor | TM-128 |
| | | | | 4. Torque converter clutch solenoid valve | TM-137 |
| | | | | 5. CAN communication line | TM-118 |
| | | | | 6. Stall test | TM-219 |
| | | | | 7. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 8. Torque converter | TM-233 |
| | | | | 9. Control valve | |
| 26 | Other | Engine stalls when selector lever shifted "N" → "D" or "R". | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Engine speed signal | TM-133 |
| | | | | 3. Primary speed sensor | TM-128 |
| | | | | 4. Torque converter clutch solenoid valve | TM-137 |
| | | | | 5. CAN communication line | TM-118 |
| | | | | 6. Stall test | TM-219 |
| | | | OFF vehicle | 7. Torque converter | TM-233 |
| | | | | 8. Control valve | |
| 27 | | Engine speed does not return to idle. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. Accelerator pedal position sensor | TM-162 |
| | | | | 3. Secondary speed sensor | TM-130 |
| | | | | 4. CAN communication line | TM-118 |
| | | | OFF vehicle | 5. Control valve | TM-233 |
| 28 | | CVT does not shift. | ON vehicle | 1. CVT fluid level and state | TM-214 |
| | | | | 2. CVT position | TM-227 |
| | | | | 3. Line pressure test | TM-221 |
| | | | | 4. Engine speed signal | TM-133 |
| | | | | 5. Accelerator pedal position sensor | TM-162 |
| | | | | 6. CAN communication line | TM-118 |
| | | | | 7. Primary speed sensor | TM-128 |
| | | | | 8. Secondary speed sensor | TM-130 |
| | | | | 9. Step motor | TM-172 |
| | | | OFF vehicle | 10. Control valve | TM-233 |
| | | | | 11. Oil pump assembly | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F09B]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page | |
|-----|-------|---|---|--------------------------------|--------------------------------|-----------------------------|
| 29 | Other | Engine does not start in "N" or "P" position. | ON vehicle | 1. Ignition switch and starter | PG-5, STR-3 | |
| | | | | 2. CVT position | TM-227 | |
| | | | | 3. PNP switch | TM-123 | |
| 30 | | Other | Engine starts in positions other than "N" or "P". | ON vehicle | 1. Ignition switch and starter | PG-5, STR-3 |
| | | | | | 2. CVT position | TM-227 |
| | | | | | 3. PNP switch | TM-123 |

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000000992057

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Procedure without Cowl Top Cover

INFOID:000000000992058

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000000992059

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NVIS/IVIS (NISSAN/INFINITI VEHICLE IMMOBILIZER SYSTEM - NATS).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-II to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NVIS/IVIS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

PRECAUTIONS

[CVT: RE0F09B]

< PRECAUTION >

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-II.

Precaution for On Board Diagnosis (OBD) System of CVT and Engine

INFOID:000000000992060

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EVAP system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Precaution for TCM and CVT Assembly Replacement

INFOID:000000000992061

CAUTION:

- Check if new data (Unit ID) are entered correctly after replacing CVT assembly and erasing data in TCM. (Connect CONSULT-III, and then turn ignition switch OFF.)
- When replacing CVT assembly or TCM, refer to the pattern table below and erase the EEPROM in the TCM if necessary.

EEPROM ERASING PATTERNS

| CVT assembly | TCM | Erasing EEPROM in TCM | Remarks |
|--------------|--------------|-----------------------|--|
| Replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. (CVT assembly must be replaced first.) |
| Not replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. |
| Replaced | Not replaced | Required | Required because data has been written in the EEPROM in the TCM and because the TCM cannot write data from the ROM assembly in the transmission. |

Removal and Installation Procedure for CVT Unit Connector

INFOID:000000000992062


REMOVAL

PRECAUTIONS

[CVT: RE0F09B]


< PRECAUTION >

Rotate bayonet ring counterclockwise, pull out CVT unit harness connector upward and remove it.




INSTALLATION

1. Align CVT unit harness connector terminal body marking with bayonet ring marking, insert CVT unit harness connector, and then rotate bayonet ring clockwise.




2. Rotate bayonet ring clockwise until CVT unit harness connector terminal body marking is aligned with the bayonet ring marking (linear slit) as shown.



CAUTION:

- Securely align Δ marking on CVT unit harness connector terminal body with bayonet ring slit. Then, be careful not to make a half fit condition as shown in the figure.
- Do not mistake the slit of bayonet ring for other dent portion.



Precaution

INFOID:000000000992063

NOTE:


If any malfunction occurs in the RE0F09A model transaxle, replace the entire transaxle assembly.

PRECAUTIONS


[CVT: RE0F09B]

< PRECAUTION >


- Before connecting or disconnecting the TCM harness connector, turn ignition switch OFF and disconnect negative battery cable. Because battery voltage is applied to TCM even if ignition switch is turned OFF.




- When connecting or disconnecting pin connectors into or from TCM, take care not to damage pin terminals (bend or break).
When connecting pin connectors make sure that there are not any bends or breaks on TCM pin terminal.



- Before replacing TCM, perform TCM input/output signal inspection and make sure whether TCM functions properly or not. [TM-181, "Reference Value"](#).



- After performing each TROUBLE DIAGNOSIS, perform "DTC Confirmation Procedure".
If the repair is completed the DTC should not be displayed in the "DTC Confirmation Procedure".
- Always use the specified brand of CVT fluid. Refer to [TM-235, "General Specification"](#).
- Use lint-free paper, not cloth rags, during work.
- After replacing the CVT fluid, dispose of the waste oil using the methods prescribed by law, ordinance, etc.



Service Notice or Precaution

INFOID:000000000992064

CVT FLUID COOLER SERVICE

If CVT fluid contains friction material (clutches, brakes, etc.), or if a CVT is replaced, inspect and clean the CVT fluid cooler mounted in the radiator or replace the radiator. Flush cooler lines using cleaning solvent and compressed air after repair. For CVT fluid cooler cleaning procedure, refer to [TM-216, "Cleaning"](#). For radiator replacement, refer to [CO-36, "Removal and Installation"](#).

OBD-II SELF-DIAGNOSIS

PRECAUTIONS

[CVT: RE0F09B]

< PRECAUTION >

- CVT self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the malfunction indicator lamp (MIL). Refer to the table on [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#) for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

Always perform the procedure on [TM-110, "Diagnosis Description"](#) to complete the repair and avoid unnecessary blinking of the MIL.

For details of OBD-II, refer to [EC-118, "Diagnosis Description"](#).

- **Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-58](#).**

PREPARATION

< PREPARATION >

[CVT: RE0F09B]



PREPARATION

PREPARATION

Special Service Tool


INFOID:000000000992065

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|---|---|
| <p>— (OTC3492) Oil pressure gauge set</p>  <p style="text-align: right;">SCIA7531E</p> | <p>Measuring line pressure</p> |
| <p>— (J-47244) Drift a: 65.83 mm (2.59 in) dia. b: 53.85 mm (2.12 in) dia.</p>  <p style="text-align: right;">SCIA5777E</p> | <p>Installing differential side oil seal</p> <ul style="list-style-type: none"> • Transaxle case side (left) |
| <p>ST33400001 (J-47005) Drift a: 69.85 mm (2.75 in) dia. b: 49.53 mm (1.95 in) dia.</p>  <p style="text-align: right;">SCIA5777E</p> | <p>Installing differential side oil seal</p> <ul style="list-style-type: none"> • Converter housing side (right) |

Commercial Service Tool

INFOID:000000000992066

| Tool number Tool name | Description |
|--|---|
| <p>31197CA000 Drive plate location guide a: 14 mm (0.55 in) dia.</p>  <p style="text-align: right;">SCIA2013E</p> | <p>Installing transaxle assembly</p> |
| <p>31093CA000 Slinger</p>  <p style="text-align: right;">SCIA2014E</p> | <p>Removing and installing transaxle assembly</p> |

PREPARATION

< PREPARATION >

[CVT: RE0F09B]

| Tool number Tool name | Description | A |
|---|--|--------------|
| 31092CA000 Slinger <div data-bbox="727 262 820 457" style="text-align: center;"> </div> <div data-bbox="852 443 922 464" style="text-align: right;"> <small>SCIA2015E</small> </div> | Removing and installing transaxle assembly | B C |
| Power tool <div data-bbox="625 520 896 693" style="text-align: center;"> </div> <div data-bbox="852 695 922 716" style="text-align: right;"> <small>PBIC0190E</small> </div> | Loosening nuts and bolts | TM E F |

TM

E

F

G

H

I

J

K

L

M

N

O

P

ON-VEHICLE MAINTENANCE

CVT FLUID


Inspection

INFOID:000000000992067


CHECKING CVT FLUID

Fluid level should be checked with the fluid warmed up to 50 to 80°C (122 to 176°F). The fluid level check procedure is as follows:

1. Check for fluid leakage.
2. With the engine warmed up, drive the vehicle in an urban area. When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).
3. Park the vehicle on a level surface.
4. Apply parking brake firmly.
5. With engine at idle, while depressing brake pedal, move shift selector throughout the entire shift range.




6. Pull out the CVT fluid level gauge from the CVT fluid charging pipe after pressing the tab on the CVT fluid level gauge to release the lock.



7. Wipe fluid off the CVT fluid level gauge. Insert the CVT fluid level gauge rotating 180° from the originally installed position, then securely push the CVT fluid level gauge until it meets the top end of the CVT fluid charging pipe.

CAUTION:


When wiping away the CVT fluid level gauge, always use lint-free paper, not a cloth rag.



8. Place the selector lever in "P" or "N" and make sure the fluid level is within the specified range.

CAUTION:

When reinstalling CVT fluid level gauge, insert it into the CVT fluid charging pipe and rotate it to the original installation position until it is securely locked.



CVT FLUID CONDITION


CVT FLUID

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

Check CVT fluid condition.

- If CVT fluid is very dark or smells burned, check operation of CVT. Flush cooling system after repair of CVT.
- If CVT fluid contains frictional material (clutches, brakes, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of CVT. Refer to [CO-36. "Removal and Installation"](#) and [TM-216. "Cleaning"](#).




ATA0022D

| Fluid status | Conceivable cause | Required operation |
|---------------------------------------|--|---|
| Varnished (viscous varnish state) | Clutch, brake scorched | Replace the CVT fluid and check the CVT main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.) |
| Milky white or cloudy | Water in the fluid | Replace the CVT fluid and check for places where water is getting in. |
| Large amount of metal powder mixed in | Unusual wear of sliding parts within CVT | Replace the CVT fluid and check for improper operation of the CVT. |

Changing

INFOID:000000000992068

1. Warm up CVT fluid by driving the vehicle for 10 minutes.
 - ⇐: Vehicle front
 - Radiator (2)
 - CVT fluid cooler hose (inlet side) (3)
 - Transaxle assembly (4)
2. Drain CVT fluid from CVT fluid cooler hose (outlet side) (1) and refill with new CVT fluid at CVT fluid charging pipe with the engine running at idle speed.
3. Refill until new CVT fluid comes out from CVT fluid cooler hose (outlet side) (1).
About 30 to 50% extra fluid will be required for this procedure.



SCIA6088E

CVT fluid:

Genuine NISSAN CVT Fluid NS-2

Fluid capacity:

Approx. 10.2 ℓ (10-6/8 US qt, 9 Imp qt)

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-2. Do not mix with other fluid.
 - Using CVT fluid other than Genuine NISSAN CVT Fluid NS-2 will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the warranty.
 - When filling CVT fluid, take care not to scatter heat generating parts such as exhaust.
 - Delete CVT fluid deterioration date with CONSULT-III after changing CVT fluid. Refer to [TM-112. "CONSULT-III Function \(TRANSMISSION\)"](#).
4. Check fluid level and condition. Refer to [TM-214. "Inspection"](#).

FLUID FLOOR CLEANING

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

FLUID FLOOR CLEANING

Cleaning

INFOID:00000000992069

Whenever an automatic transaxle is repaired, overhauled, or replaced, the CVT fluid cooler mounted in the radiator must be inspected and cleaned.

Metal debris and friction material, if present, can be trapped or become deposit in the CVT fluid cooler. This debris can contaminate the newly serviced CVT or, in severe cases, can block or restrict the flow of CVT fluid. In either case, malfunction of the newly serviced CVT may occur.

Debris, if present, may deposit as CVT fluid enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


CVT FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any CVT fluid that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.



7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and end of the cooler outlet hose.

9. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining CVT fluid.

10. Repeat steps 5 through 9 three additional times.

11. Position an oil pan under the banjo bolts that connect the CVT fluid cooler steel lines to the transaxle.


12. Remove the banjo bolts.

13. Flush each steel line from the cooler side back toward the transaxle by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.

14. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through each steel line from the cooler side back toward the transaxle for 10 seconds to force out any remaining CVT fluid.

15. Ensure all debris is removed from the steel cooler lines.

16. Ensure all debris is removed from the banjo bolts and fittings.



FLUID FLOOR CLEANING

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

17. Perform "CVT FLUID COOLER DIAGNOSIS PROCEDURE".

CVT FLUID COOLER DIAGNOSIS PROCEDURE

NOTE:



Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.


CAUTION:

- **Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.**
- **Spray Transmission Cooler Cleaner only with adequate ventilation.**
- **Avoid contact with eyes and skin.**
- **Do not breath vapors or spray mist.**

4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.
5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.




6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose to force any remaining CVT fluid into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform "CVT FLUID COOLER INSPECTION PROCEDURE".



CVT FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
 - a. If small metal debris less than 1 mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the CVT fluid cooler/radiator can be re-used and the procedure is ended.




FLUID CLOOR CLEANING

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

- b. If one or more pieces of debris are found that are over 1 mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the fluid cooler is not serviceable. The radiator/ fluid cooler must be replaced and the inspection procedure is ended.



CVT FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.

STALL TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]


STALL TEST

Inspection and Judgment


INFOID:000000000992070

INSPECTION


1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of CVT fluid. Replenish if necessary.



3. Securely engage the parking brake so that the tires do not turn.
4. Install a tachometer where it can be seen by driver during test.
 - It is good practice to mark the point of specified engine rpm on indicator.
5. Start engine, apply foot brake, and place selector lever in "D" position.



6. While holding down the foot brake, gradually press down the accelerator pedal.
7. Quickly read off the stall speed, and then quickly remove your foot from the accelerator pedal.
CAUTION:
Do not hold down the accelerator pedal for more than 5 seconds during this test.



Stall speed: 2,700 – 3,250 rpm

8. Move the selector lever to the "N" position.
9. Cool down the CVT fluid.
CAUTION:
Run the engine at idle for at least 1 minute.
10. Repeat steps 6 through 9 with selector lever in "R" position.

JUDGMENT

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

STALL TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

| | Selector lever position | | Expected problem location |
|----------------|-------------------------|-----|--|
| | "D" | "R" | |
| Stall rotation | H | O | <ul style="list-style-type: none">• Forward clutch |
| | O | H | <ul style="list-style-type: none">• Reverse brake |
| | L | L | <ul style="list-style-type: none">• Engine and torque converter one-way clutch |
| | H | H | <ul style="list-style-type: none">• Line pressure low• Primary pulley• Secondary pulley• Steel belt |

O: Stall speed within standard value position.

H: Stall speed is higher than standard value.

L: Stall speed is lower than standard value.

LINE PRESSURE TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]


LINE PRESSURE TEST

Inspection and Judgment

INFOID:000000000992071

INSPECTION

Line Pressure Test Port



Line Pressure Test Procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the CVT fluid reaches in the range of 50 to 80°C (122 to 176°F), then inspect the amount of CVT fluid and replenish if necessary.

NOTE:


The CVT fluid temperature rises in the range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.

3. After warming up CVT, remove the oil pressure detection plug and install the oil pressure gauge [special service tool: — (OTC3492)].

CAUTION:

When using the oil pressure gauge, be sure to use the O-ring attached to the oil pressure detection plug.

4. Securely engage the parking brake so that the tires do not turn.



5. Start the engine, and then measure the line pressure at both idle and the stall speed.

CAUTION:


- Keep the brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to "STALL TEST".

6. After the measurements are complete, install the oil pressure detection plug and tighten to the specified torque below.

 : 7.5 N·m (0.77 kg·m, 66 in-lb)

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid to O-ring.



Line Pressure

LINE PRESSURE TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

| Engine speed | Line pressure kPa (kg/cm ² , psi) |
|--------------|--|
| | “R”, “D” positions |
| At idle | 750 (7.65, 108.8) |
| At stall | 5,700 (58.14, 826.5)* ¹ |

*1: Reference values

JUDGMENT

| Judgment | Possible cause |
|-------------|---|
| Idle speed | <p>Low for all positions (“P”, “R”, “N”, “D”)</p> <p>Possible causes include malfunctions in the pressure supply system and low oil pump output. For example</p> <ul style="list-style-type: none"> • Oil pump wear • Pressure regulator valve or plug sticking or spring fatigue • Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak • Engine idle speed too low |
| | <p>Only low for a specific position</p> <p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p> |
| | <p>High</p> <p>Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • CVT fluid temperature sensor malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (sticking in OFF state, filter clog, cut line) • Pressure regulator valve or plug sticking |
| Stall speed | <p>Line pressure does not rise higher than the line pressure for idle.</p> <p>Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • TCM malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (shorting, sticking in ON state) • Pressure regulator valve or plug sticking |
| | <p>The pressure rises, but does not enter the standard position.</p> <p>Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (sticking, filter clog) • Pressure regulator valve or plug sticking |
| | <p>Only low for a specific position</p> <p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p> |


ROAD TEST

Description

INFOID:000000000992072

DESCRIPTION

- The purpose of the test is to determine overall performance of CVT and analyze causes of problems.
- The road test consists of the following three parts:
 1. "Check Before Engine Is Started" [TM-223](#).
 2. "Check at Idle" [TM-224](#).
 3. "Cruise Test" [TM-225](#).



- Before road test, familiarize yourself with all test procedures and items to check.
- Perform tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test.



CONSULT-III SETTING PROCEDURE

- Using CONSULT-III, perform a cruise test and record the result.
 - Print the result and ensure that shifts and lock-ups take place as per Shift Schedule.
1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
 2. Touch "MAIN SIGNALS" to set recording condition.
 3. See "Numerical Display", "Bar chart Display" or "Line Graph Display".
 4. Touch "START".
 5. When performing cruise test. Refer to [TM-225, "Cruise Test"](#).
 6. After finishing cruise test part, touch "RECORD".
 7. Touch "STORE".
 8. Touch "BACK".
 9. Touch "DISPLAY".
 10. Touch "PRINT".
 11. Check the monitor data printed out.

Check before Engine Is Started

INFOID:000000000992073

1. CHECK CVT INDICATOR LAMP

1. Park vehicle on flat surface.
2. Move selector lever to "P" position.
3. Turn ignition switch OFF. Wait at least 5 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Does shift position indicator come on for about 2 seconds?

- YES >>
1. Turn ignition switch OFF.
 2. Perform self-diagnosis and note NG items.
Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).
 3. Go to [TM-224, "Check at Idle"](#).

ROAD TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F09B]

NO >> Stop "Road Test". Refer to [TM-196. "Symptom Table"](#).

Check at Idle

INFOID:000000000992074

1.CHECK STARTING THE ENGINE

1. Park vehicle on flat surface.
2. Move selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Turn ignition switch to "START" position.

Is engine started?

YES >> GO TO 2..

NO >> Stop "Road Test". Refer to [TM-196. "Symptom Table"](#).

2.CHECK STARTING THE ENGINE

1. Turn ignition switch ON.
2. Move selector lever to "D", "M" or "R" position.
3. Turn ignition switch to "START" position.

Is engine started?

YES >> Stop "Road Test". Refer to [TM-196. "Symptom Table"](#).

NO >> GO TO 3..

3.CHECK "P" POSITION FUNCTION

1. Move selector lever to "P" position.
2. Turn ignition switch OFF.
3. Release parking brake.
4. Push vehicle forward or backward.
5. Apply parking brake.

Does vehicle move when it is pushed forward or backward?

YES >> Refer to [TM-196. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 4..

4.CHECK "N" POSITION FUNCTION

1. Start engine.
2. Move selector lever to "N" position.
3. Release parking brake.

Does vehicle move forward or backward?

YES >> Refer to [TM-196. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 5..

5.CHECK SHIFT SHOCK

1. Apply foot brake.
2. Move selector lever to "R" position.

Is there large shock when changing from "N" to "R" position?

YES >> Refer to [TM-196. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 6..

6.CHECK "R" POSITION FUNCTION

Release foot brake for several seconds.

Does vehicle creep backward when foot brake is released?

YES >> GO TO 7..

NO >> Refer to [TM-196. "Symptom Table"](#). Continue "Road Test".

7.CHECK "D" POSITION FUNCTION

Move selector lever to "D" position and check if vehicle creeps forward.

Does vehicle creep forward in all positions?

YES >> Go to [TM-225. "Cruise Test"](#).

NO >> Stop "Road Test". Refer to [TM-196. "Symptom Table"](#).

Cruise Test

1. CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 1

1. Drive vehicle for approximately 10 minutes to warm engine oil and CVT fluid up to operating temperature.


CVT fluid operating temperature: 50 – 80°C (122 – 176°F)

2. Park vehicle on flat surface.
3. Move selector lever to “P” position.
4. Start engine.
5. Move selector lever to “D” position.
6. Accelerate vehicle to 2/8-way throttle depressing accelerator pedal constantly.

 **Read vehicle speed and engine speed. Refer to [TM-235, "Vehicle Speed When Shifting Gears"](#).**

OK or NG

- OK >> GO TO 2..
 NG >> Refer to [TM-196, "Symptom Table"](#). Continue “Road Test”.


**2. CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 2**

1. Park vehicle on flat surface.
2. Move selector lever to “D” position.
3. Accelerate vehicle to full depression depressing accelerator pedal constantly.

 **Read vehicle speed and engine speed. Refer to [TM-235, "Vehicle Speed When Shifting Gears"](#).**

OK or NG

- OK >> GO TO 3..
 NG >> Refer to [TM-196, "Symptom Table"](#). Continue “Road Test”.

**3. CHECK MANUAL MODE FUNCTION**

Move to manual mode from “D” position.

Does it switch to manual mode?

- YES >> GO TO 4..
 NO >> Refer to [TM-196, "Symptom Table"](#). Continue “Road Test”.

4. CHECK SHIFT-UP FUNCTION

During manual mode driving, is upshift from M1 → M2 → M3 → M4 → M5 → M6 performed?

 **Read the gear position. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).**

Is upshifting correctly performed?

- YES >> GO TO 5..
 NO >> Refer to [TM-196, "Symptom Table"](#). Continue “Road Test”.

5. CHECK SHIFT-DOWN FUNCTION

During manual mode driving, is downshift from M6 → M5 → M4 → M3 → M2 → M1 performed?

 **Read the gear position. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).**

Is downshifting correctly performed?

- YES >> GO TO 6..
 NO >> Refer to [TM-196, "Symptom Table"](#). Continue “Road Test”.

6. CHECK ENGINE BRAKE FUNCTION

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

- YES >> 1. Stop the vehicle.
2. Perform self-diagnosis. Refer to [TM-112, "CONSULT-III Function \(TRANSMISSION\)"](#).
- NO >> Refer to [TM-196, "Symptom Table"](#). then continue trouble diagnosis.


CVT POSITION

Inspection and Adjustment

INFOID:000000000992076

INSPECTION

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check that the actual position of the selector lever matches the position shown by the shift position indicator and the manual lever on the transaxle.
5. The method of operating the selector lever to individual positions correctly should be as shown.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when selector lever is placed in the "R" position. Confirm the back-up lamps do not illuminate when the selector lever is pushed toward the "R" position when in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions.
9. Make sure transaxle is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



ADJUSTMENT

CAUTION:**Apply parking brake before adjustment.**

1. Loosen the control cable nut.
2. Place the manual lever and the selector lever in "P" position.
3. Tighten control cable nut to specified torque.

Control cable nut: Refer to [TM-230, "Exploded View"](#).

CAUTION:

Secure the manual lever when tightening control cable nut. Make sure the manual lever stays in the "P" position.

4. Check the operation of the CVT.

TRANSMISSION CONTROL MODULE

< ON-VEHICLE REPAIR >


[CVT: RE0F09B]

ON-VEHICLE REPAIR

TRANSMISSION CONTROL MODULE

Exploded View

INFOID:000000000992077



1. TCM
⇐: Front

2. Bracket


3. Battery

Removal and Installation

INFOID:000000000992078

REMOVAL

1. Disconnect the battery negative terminal. Refer to [PG-66, "Removal and Installation"](#).
2. Remove the fresh air intake tube (upper) [EM-24, "Removal and Installation"](#).
3. Disconnect the TCM harness connector.
4. Remove the TCM (1) from the bracket (2).
 - ⇐: Front
 - Battery (3)




INSTALLATION

Installation is in the reverse order of removal.

CONTROL DEVICE

Exploded View

INFOID:000000000992079



- | | | |
|----------------------------------|----------------------------|---------------|
| 1. Control lever knob | 2. Lock pin | 3. Knob cover |
| 4. Control device selector plate | 5. Control device assembly | |

Removal and Installation

INFOID:000000000992080

REMOVAL

1. Remove the center console assembly. Refer to [IP-16, "Disassembly and Assembly"](#).
2. Disconnect the control cable from the control device assembly.
3. Disconnect the CVT device harness connector from the control device assembly.
4. Remove the control device assembly bolts and the control device assembly.

INSTALLATION

Installation is in the reverse order of removal.

- When installing the control cable to the control device assembly, make sure that the control cable is fully pressed in with the ribbed surface facing upward.
- After installation is completed, adjust and check CVT position. Refer to [TM-227, "Inspection and Adjustment"](#).

CONTROL CABLE


< ON-VEHICLE REPAIR >

[CVT: RE0F09B]

CONTROL CABLE

Exploded View

INFOID:000000000992081



- | | | |
|---------------------|----------------------------|-------------------------|
| 1. Control lever | 2. Control device assembly | 3. Control cable socket |
| 4. Retainer grommet | 5. Control cable | 6. Bracket |
| 7. Lock plate | 8. Manual lever | |

Removal and Installation

INFOID:000000000992082

REMOVAL

1. Shift control lever to "P".
2. Remove the air filter assembly. Refer to [EM-24, "Removal and Installation"](#).
3. Remove the control cable nut and control cable from the manual lever.
4. Remove the lock plate and the control cable from the bracket.
5. Remove the center console. Refer to [IP-16, "Disassembly and Assembly"](#).
6. Remove the bracket covering the retainer grommet.
7. Remove the retainer grommet bolts and the retainer grommet.
8. Remove the control cable from the control device assembly.
9. Remove the control cable from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.

- When installing the control cable to the control device assembly, make sure that the control cable socket is fully pressed into the control device assembly, and the control cable end is fully pressed in with the ribbed surface facing upward.
- After installation is complete, adjust and check the CVT position. Refer to [TM-227, "Inspection and Adjustment"](#).

AIR BREATHER HOSE


< ON-VEHICLE REPAIR >

[CVT: RE0F09B]

AIR BREATHER HOSE

Exploded View

INFOID:000000000992083



- | | | |
|----------------|----------------------|-----------------------|
| 1. Air cleaner | 2. Air breather hose | 3. Transaxle assembly |
| 4. Heater pipe | 5. Clip | A. Paint mark |
| ←: Front | | |

Removal and Installation

INFOID:000000000992084

CAUTION:

- Install air breather hose with paint mark facing front.
- Insert air breather hose onto air breather tube until overlap area reaches the spool.
- Install air breather hose to heater pipe and air cleaner case by fully inserting the clip.
- Make sure there are no pinched or restricted areas on air breather hose caused by bending or winding when installing it.

DIFFERENTIAL SIDE OIL SEAL


< ON-VEHICLE REPAIR >

[CVT: RE0F09B]

DIFFERENTIAL SIDE OIL SEAL

Exploded View

INFOID:000000000992085



1. Transaxle assembly

2. Differential side oil seal



:NISSAN CVT Fluid NS-2

Removal and Installation

INFOID:000000000992086


REMOVAL

1. Remove drive shaft assembly. Refer to [FAX-9, "Removal and Installation \(Left Side\)"](#) and [FAX-10, "Removal and Installation \(Right Side\)"](#).

2. Remove the differential side oil seal using suitable tool

CAUTION:

Do not scratch transaxle case or converter housing.



INSTALLATION

1. Drive the new differential side oil seal into the transaxle case side (B) and converter housing side (C) until it is flush using suitable tool.


Dimension A : 0 ± 0.5 (0 ± 0.02)

CAUTION:

- Do not reuse differential side oil seals.
- Apply specified NISSAN CVT fluid to side oil seals.

2. Install drive shaft assembly. Refer to [FAX-9, "Removal and Installation \(Left Side\)"](#) and [FAX-10, "Removal and Installation \(Right Side\)"](#).

3. Check CVT fluid level. Refer to [TM-214, "Inspection"](#).



TRANSAXLE ASSEMBLY

< REMOVAL AND INSTALLATION >


[CVT: RE0F09B]

REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000000992087



- | | | |
|----------------------------|-----------------------|--|
| 1. Rear gusset | 2. Air breather hose | 3. CVT fluid level gauge |
| 4. CVT fluid charging pipe | 5. O-ring | 6. Copper washer |
| 7. Fluid cooler tube | 8. Transaxle assembly | A. Refer to TM-233, "Removal and Installation" . |

Removal and Installation

INFOID:000000000992088

REMOVAL

- Remove the engine and transaxle as an assembly. Refer to [EM-72, "Removal and Installation"](#).
NOTE:
Using paint, put matching marks on the drive plate and torque converter when removing the torque converter to drive plate nuts.
- Disconnect the electrical connectors from the following:
 - CVT unit harness connector. Refer to [TM-208, "Removal and Installation Procedure for CVT Unit Connector"](#).
 - Secondary speed sensor

TRANSAXLE ASSEMBLY

[CVT: RE0F09B]

< REMOVAL AND INSTALLATION >

3. Remove the harness from the transaxle.
4. Remove the transaxle to engine and engine to transaxle bolts.
5. Remove the CVT fluid charging pipe.
6. Separate the transaxle from the engine.
7. If necessary, remove the following from the CVT:
 - Fluid cooler tube
 - Air breather hose
 - Brackets


INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When replacing an engine or transaxle you must make sure any dowels are installed correctly during re-assembly
- Improper alignment caused by missing dowels may cause vibration, oil leaks or breakage of drive train components.
- Do not reuse O-rings.
- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the nuts for the torque converter while securing the crankshaft pulley bolt, be sure to confirm the tightening torque of the crankshaft pulley bolt. Refer to [EM-51, "Removal and Installation"](#).
- After converter is installed to drive plate, rotate crankshaft several turns to check that CVT rotates freely without binding.
- When installing the CVT to the engine, align the matching mark on the drive plate with the matching mark on the torque converter.
- When installing CVT assembly to the engine assembly, attach the bolts in accordance with the following standard.

| | | | | |
|--|--------------|-----------|------------|-----------------|
| Bolt No. | 1 | 2 | 3 | 4 |
| Number of bolts | 1 | 2 | 2 | 4 |
| Bolt length "ℓ" mm (in) | 55 (2.17) | 34 (1.54) | 108 (4.25) | 45 (1.77) |
| Tightening torque N·m (kg·m, ft·lb) | 75 (7.7, 55) | | | 43 (4.4, 32) |



- When installing the drive plate to torque converter nuts, tighten them temporarily. then tighten the nuts to the specified torque.
- After completing installation, check for fluid leakage, fluid level, and the positions of CVT. Refer to [TM-214, "Inspection"](#) and [TM-227, "Inspection and Adjustment"](#).
- When replacing the CVT assembly, erase EEP ROM in TCM.


Inspection

INFOID:000000000992089

Installation and Inspection of Torque Converter

- After inserting the torque converter to the CVT, be sure to check distance "A" to ensure it is within specifications.

Distance "A" : 14.0 mm (0.55 in) or more



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F09B]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:000000000992090

| | | |
|-------------------------|-------------------|-------------------------------------|
| Applied model | | VQ35DE engine |
| | | 2WD |
| CVT model | | RE0F09B |
| CVT assembly | Model code number | 1XE0A |
| Transmission gear ratio | D position | Variable |
| | Reverse | 1.766 |
| | Final drive | 5.173 |
| Recommended fluid | | NISSAN CVT Fluid NS-2*1 |
| Fluid capacity | | 10.2 liter (10-6/8 US qt, 9 Imp qt) |

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-2. Do not mix with other fluid.
- Using CVT fluid other than Genuine NISSAN CVT Fluid NS-2 will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the warranty.

*1: Refer to [MA-11, "Fluids and Lubricants"](#).

Vehicle Speed When Shifting Gears

INFOID:000000000992091

Numerical value data are reference values.

| Engine type | Throttle position | Shift pattern | Engine speed (rpm) | |
|-------------|-------------------|---------------|---------------------|---------------------|
| | | | At 40 km/h (25 MPH) | At 60 km/h (37 MPH) |
| VQ35DE | 8/8 | "D" position | 2,900 – 4,100 | 3,900 – 5,600 |
| | 2/8 | | 900 – 2,000 | 1,000 – 2,000 |

CAUTION:

Lock-up clutch is engaged when vehicle speed is approximately 18 km/h (11 MPH) to 90 km/h (56 MPH).

Stall Speed

INFOID:000000000992092

| | |
|-------------|-------------------|
| Stall speed | 2,700 – 3,250 rpm |
|-------------|-------------------|

Line Pressure

INFOID:000000000992093

| Engine speed | Line pressure kPa (kg/cm ² , psi) |
|--------------|--|
| | "R", "D" positions |
| At idle | 750 (7.65, 108.8) |
| At stall | 5,700 (58.14, 826.5)*1 |

*1: Reference values

Solenoid Valves

INFOID:000000000992094

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F09B]

| Name | Resistance (Approx.) | Terminal |
|---|----------------------|----------|
| Pressure control solenoid valve B (secondary pressure solenoid valve) | 3.0 – 9.0 Ω | 3 |
| Pressure control solenoid valve A (line pressure solenoid valve) | | 2 |
| Torque converter clutch solenoid valve | | 12 |
| Lock-up select solenoid valve | 6 – 19 Ω | 13 |

CVT Fluid Temperature Sensor

INFOID:000000000992095

| Name | Condition | CONSULT-III "DATA MONITOR" (Approx.) | Resistance (Approx.) |
|--------------|--------------|--------------------------------------|----------------------|
| ATF TEMP SEN | 20°C (68°F) | 1.8 – 2.0 V | 6.5 kΩ |
| | 80°C (176°F) | 0.6 – 1.0 V | 0.9 kΩ |

Primary Speed Sensor

INFOID:000000000992096

| Name | Condition | Data (Approx.) |
|----------------------|--|----------------|
| Primary speed sensor | When driving ["M1" position, 20 km/h (12 MPH)] | 660 Hz |

Secondary Speed Sensor

INFOID:000000000992097

| Name | Condition | Data (Approx.) |
|------------------------|---|----------------|
| Secondary speed sensor | When driving ["D" position, 20 km/h (12 MPH)] | 400 Hz |

Removal and Installation

INFOID:000000000992098

| | |
|--|---------------------------|
| Distance between end of converter housing and torque converter | 14.0 mm (0.55 in) or more |
|--|---------------------------|

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow


INFOID:000000000992099

INTRODUCTION

The TCM receives a signal from the vehicle speed sensor, PNP switch and provides shift control or lock-up control via CVT solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the CVT system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the CVT system. The CVT system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose an error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the errors. A road test with CONSULT-III (or GST) or a circuit tester connected should be performed. Follow the "DETAILED FLOW".



Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Work Sheet" as shown on the example (Refer to [TM-238](#)) should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.



DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using diagnosis worksheet. Refer to [TM-238, "Diagnostic Work Sheet"](#).

>> GO TO 2..

2. CHECK SYMPTOM 1

Check the following items based on the information obtained from the customer.

- Fail-safe. Refer to [TM-347, "Fail-safe"](#).
- CVT fluid inspection. Refer to [TM-368, "Inspection"](#).
- Line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

DIAGNOSIS AND REPAIR WORKFLOW

[CVT: RE0F10A]

< BASIC INSPECTION >

- Stall test. Refer to [TM-373. "Inspection and Judgment"](#).

>> GO TO 3..

3.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC.
 - Erase DTC. Refer to [TM-264. "Diagnosis Description"](#).

Is any DTC detected?

YES >> GO TO 4..

NO >> GO TO 5..

4.PERFORM DIAGNOSTIC PROCEDURE

Perform "Diagnostic Procedure" for the displayed DTC.

>> GO TO 5..

5.CHECK SYMPTOM 2

Try to confirm the symptom described by the customer.

Is any malfunction present?

YES >> GO TO 6..

NO >> **INSPECTION END**

6.RODE TEST

1. Perform "RODE TEST". Refer to [TM-377. "Description"](#).

>> GO TO 7..

7.CHECK SYMPTOM 3

Try to confirm the symptom described by the customer.

Is any malfunction present?

YES >> GO TO 2..

NO >> **INSPECTION END**

Diagnostic Work Sheet

INFOID:000000000992100

INFORMATION FROM CUSTOMER

KEY POINTS

- **WHAT**..... Vehicle & CVT model
- **WHEN**..... Date, Frequencies
- **WHERE**..... Road conditions
- **HOW**..... Operating conditions, Symptoms

| | | |
|---------------------|--|-----------------|
| Customer name MR/MS | Model & Year | VIN |
| Trans. Model | Engine | Mileage |
| malfunction Date | Manuf. Date | In Service Date |
| Frequency | <input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day) | |

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CVT: RE0F10A]

| | | |
|----------------------------------|--|----------------------------------|
| Symptoms | <input type="checkbox"/> Vehicle does not move. (<input type="checkbox"/> Any position <input type="checkbox"/> Particular position) | |
| | <input type="checkbox"/> No shift | |
| | <input type="checkbox"/> Lock-up malfunction | |
| | <input type="checkbox"/> Shift shock or slip (<input type="checkbox"/> N → D <input type="checkbox"/> N → R <input type="checkbox"/> Lock-up <input type="checkbox"/> Any drive position) | |
| | <input type="checkbox"/> Noise or vibration | |
| | <input type="checkbox"/> No pattern select | |
| | <input type="checkbox"/> Others () | |
| Malfunction indicator lamp (MIL) | <input type="checkbox"/> Continuously lit | <input type="checkbox"/> Not lit |

A
B
C
TM

DIAGNOSTIC WORKSHEET

| | | | |
|--|---|---|---|
| 1 | <input type="checkbox"/> Read the item on cautions concerning fail-safe and understand the customer's complaint. | | TM-347 |
| 2 | <input type="checkbox"/> CVT fluid inspection, stall test and line pressure test | | |
| | | <input type="checkbox"/> CVT fluid inspection | TM-368 |
| | | <input type="checkbox"/> Leak (Repair leak location.) | |
| | | <input type="checkbox"/> State | |
| | | <input type="checkbox"/> Amount | |
| <input type="checkbox"/> Stall test | | TM-373, TM-375 | |
| <input type="checkbox"/> Torque converter one-way clutch | <input type="checkbox"/> Engine | | |
| <input type="checkbox"/> Reverse brake | <input type="checkbox"/> Line pressure low | | |
| | <input type="checkbox"/> Forward clutch | <input type="checkbox"/> Primary pulley | |
| | <input type="checkbox"/> Steel belt | <input type="checkbox"/> Secondary pulley | |
| | <input type="checkbox"/> Line pressure inspection - Suspected part: | | |
| 3 | <input type="checkbox"/> Perform self-diagnosis. | | TM-266 |
| | Enter checks for detected items. | | |
| 4 | <input type="checkbox"/> Perform road test. | | TM-377 |
| | 4-1. | Check before engine is started | TM-377 |
| | 4-2. | Check at idle | TM-378 |
| | 4-3. | Cruise test | TM-379 |
| 5 | <input type="checkbox"/> Inspect each system for items found to be NG in the self-diagnosis and repair or replace the malfunctioning parts. | | |
| 6 | <input type="checkbox"/> Perform all road tests and enter the checks again for the required items. | | TM-377 |
| 7 | <input type="checkbox"/> For any remaining NG items, perform the "diagnosis procedure" and repair or replace the malfunctioning parts. | | |
| 8 | <input type="checkbox"/> Erase the results of the self-diagnosis from the TCM and the ECM. | | TM-264, TM-266 |

E
F
G
H
I
J
K
L
M
N
O
P

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Service After Replacing TCM and Transaxle Assembly

INFOID:000000000992101

SERVICE AFTER REPLACING TCM AND TRANSAXLE ASSEMBLY

Perform the applicable service in the following sheet when replacing TCM or transaxle assembly.

CAUTION:

- **Do not start the engine until the service is completed.**
- **“TCM- POWER SUPPLY [P1701]” may be indicated soon after replacing TCM or transaxle assembly (after erasing the memory at the pattern B). Restart the self-diagnosis after erasing the self-diagnosis result. Check that no error is detected.**

| TCM | CVT assembly | Service pattern |
|--------------------------|------------------------------|-----------------|
| Replace the new unit. | Do not replace the unit. | "PATTERN A" |
| Do not replace the unit. | Replace the new or old unit. | "PATTERN B" |
| Replace the old unit. | Do not replace the unit. | |
| | Replace the new or old unit. | |
| Replace the new unit. | Replace the new or old unit. | "PATTERN C" |

NOTE:

Old unit means that the unit has been already used for another vehicle.

PATTERN A

1. Shift the selector lever to “P” position after replacing TCM. Turn the ignition switch ON.
2. Check that the shift position indicator in the combination meter turns ON (It indicates approximately 1 or 2 seconds after turning the ignition switch ON.)
 - Check the following items if the shift position indicator does not turn ON. Repair or replace the shift position indicator if necessary.
 - The harness between TCM and ROM ASSY in the transaxle assembly is open or short.
 - Cable disconnected, loosen, or bent from the connector housing.

PATTERN B

1. Turn the ignition switch ON after replacing each part.
2. Start engine.

CAUTION:
Do not start the driving.
3. Select “DATA MONITOR”.
4. Warm up the transaxle assembly until “ATF TEMP” indicates 48 (approximately 20°C) or more. Turn the ignition switch OFF.
5. Turn the ignition switch ON.

CAUTION:
Do not start engine.
6. Select “SELF-DIAG RESULTS”.
7. Shift the selector lever to “R” position.
8. Depress slightly the accelerator pedal (Pedal angle: 2/8) while depressing the brake pedal.
9. Perform “ERASE”.
10. Shift the selector lever to “R” position after replacing TCM. Turn the ignition switch OFF.
11. Wait approximately 10 minutes after turning the ignition switch OFF.
12. Turn the ignition switch ON while shifting the selector lever to “R” position.

CAUTION:
Do not start engine.
13. Select “Special function”.
14. Check that the value on “CALIBRATION DATA” is same as the data after erasing "Calibration Data".

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[CVT: RE0F10A]

- Restart the procedure from step 3 if the values are not same.

15. Shift the selector lever to “P” position.

16. Check that the shift position indicator in the combination meter turns ON (It indicates approximately 1 or 2 seconds after shifting the selector lever to “P” position.)

- Check the following items if the shift position indicator does not turn ON. Repair or replace the shift position indicator if necessary.
 - The harness between TCM and ROM ASSY in the transaxle assembly is open or short.
 - Cable disconnected, loosen, or bent from the connector housing.
 - Power supply and ground of TCM. Refer to [TM-314](#).

Calibration Data

Data after deletion

| Item name | Display value | Item name | Display value |
|---------------|---------------|-------------|---------------|
| UNIT CLB ID 1 | 0000 | GAIN PL | 256 |
| UNIT CLB ID 2 | 0000 | OFFSET PL | 40 |
| UNIT CLB ID 3 | 0000 | OFFSET2 PL | 0 |
| UNIT CLB ID 4 | 0000 | MAP NO SEC | 32 |
| UNIT CLB ID 5 | 0000 | GAIN SEC | 256 |
| UNIT CLB ID 6 | 0000 | OFFSET SEC | 40 |
| MAP NO LU | 33 | OFFSET2 SEC | 0 |
| GAIN LU | 256 | MAP NO SL | 32 |
| OFFSET LU | 40 | GAIN SL | 256 |
| OFFSET2 LU | 0 | OFFSET SL | 40 |
| MAP NO PL | 32 | OFFSET2 SL | 0 |

PATTERN C

1. Replace the transaxle assembly first, and then replace TCM.
2. Perform the service of “PATTERN A”.
(Perform the service of “PATTERN B” if TCM is replaced first.)


A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

FUNCTION DIAGNOSIS

CVT SYSTEM

System Diagram

INFOID:000000000992102




Component Parts Location

INFOID:000000000992103

CVT SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



- | | | |
|----------------------------|--|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position (APP) sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MECHANICAL SYSTEM


< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

MECHANICAL SYSTEM

Cross-Sectional View

INFOID:000000000992104



SCIA7792J

- | | | |
|--------------------------|----------------------|--------------------|
| 1. Converter housing | 2. Driven sprocket | 3. Chain |
| 4. Reverse brake | 5. Oil pump | 6. Forward clutch |
| 7. Planetary carrier | 8. Primary pulley | 9. Sun gear |
| 10. Steel belt | 11. Side cover | 12. Internal gear |
| 13. Parking gear | 14. Secondary pulley | 15. Final gear |
| 16. Differential case | 17. Idler gear | 18. Reduction gear |
| 19. Taper roller bearing | 20. Output gear | 21. Drive sprocket |
| 22. Input shaft | 23. Torque converter | |


System Diagram

INFOID:000000000992105

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



System Description

INFOID:000000000992106

Transmits the power from the engine to the drive wheel.

Component Parts Location


INFOID:000000000992107

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



AW11A0002ZZ

- | | | |
|----------------------------|--------------------------------------|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

Component Description

INFOID:000000000992108

MECHANICAL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]


| Item | Function |
|------------------|--|
| Torque converter | The torque converter is the device that increases the engine torque as well as the conventional A/T and transmits it to the transaxle. |
| Oil pump | The efficiency of pump discharge rate at low-rpm and the optimization at high-rpm have been increased through the oil pump drive chain by adopting a vane-type oil pump controlled by the engine. Discharged oil from oil pump is transmitted to the control valve. It is used as the oil of primary and secondary pulley operation and the oil of clutch operation and the lubricant for each part. |
| Planetary gear | Perform the transmission of drive power and the switching of forward/backward movement. |
| Forward clutch | |
| Reverse brake | |
| Primary pulley | It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the steel belt (the steel star wheels are placed continuously and the belt is guided with the multilayer steel rings on both sides). The groove width changes according to wrapping radius of steel belt and pulley from low status to over-drive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley. |
| Secondary pulley | |
| Steel belt | |
| Output gear | The drive power from the secondary pulley returns the deceleration gears [primary deceleration (output gear/idler gear pair) and secondary deceleration (reduction gear/final gear pair)]. It is transmitted from differential to drive wheel. |
| Idler gear | |
| Reduction gear | |
| Final gear | |
| Differential | |
| Manual shaft | The parking rod rotates the parking pole and the parking pole engages with the parking gear when the manual shaft is in P position. As a result the parking gear and the output axis are fixed. |
| Parking rod | |
| Parking pawl | |
| Parking gear | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

HYDRAULIC CONTROL SYSTEM

System Diagram

INFOID:000000000992109



SCIA8216E

System Description

INFOID:000000000992110

The hydraulic control mechanism consists of the oil pump directly driven by the engine, the hydraulic control valve that controls line pressure and transmission, and the input signal line.

LINE PRESSURE AND SECONDARY PRESSURE CONTROL


- When an input torque signal equivalent to the engine drive force is sent from the ECM to the TCM, the TCM controls the line pressure solenoid valve and secondary pressure solenoid valve.

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving state. Secondary pressure is controlled by decreasing line pressure.



Normal Control

Optimize the line pressure and secondary pressure, depending on driving conditions, on the basis of the throttle position, the engine speed, the primary pulley (input) revolution speed, the secondary pulley (output) revolution speed, the brake signal, the PNP switch signal, the lock-up signal, the voltage, the target gear ratio, the fluid temperature, and the fluid pressure.

Feedback Control

When controlling the normal fluid pressure or the selected fluid pressure, the secondary pressure can be set more accurately by using the fluid pressure sensor to detect the secondary pressure and controlling the feedback.


Component Parts Location

INFOID:000000000992111

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



- | | | |
|----------------------------|--------------------------------------|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

Component Description

INFOID:000000000992112

TRANSAXLE ASSEMBLY

HYDRAULIC CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Name | Function |
|-----------------------------------|--|
| Torque converter regulator valve | Optimizes the supply pressure for the torque converter depending on driving conditions. |
| Pressure regulator valve | Optimizes the discharge pressure from the oil pump depending on driving conditions. |
| TCC control valve | <ul style="list-style-type: none"> Activates or deactivate the lock-up. Lock-up smoothly by opening lock-up operation excessively. |
| TCC solenoid valve | TM-293 |
| Shift control valve | Controls flow-in/out of line pressure from the primary pulley depending on the stroke difference between the stepping motor and the primary pulley. |
| Secondary valve | Controls the line pressure from the secondary pulley depending on operating conditions. |
| Clutch regulator valve | Adjusts the clutch operating pressure depending on operating conditions. |
| Secondary pressure solenoid valve | TM-301 |
| Line pressure solenoid valve | TM-295 |
| Step motor | TM-326 |
| Manual valve | Transmits the clutch operating pressure to each circuit in accordance with the selected position. |
| Select control valve | Engages forward clutch, reverse brake smoothly depending on select operation. |
| Select switch valve | Switches torque converter clutch solenoid valve control pressure use to torque converter clutch control valve or select control valve. |
| Lock-up select solenoid valve | TM-323 |
| Primary speed sensor | TM-281 |
| Secondary speed sensor | TM-284 |
| PNP switch | TM-281 |
| Primary pulley | TM-246 |
| Secondary pulley | |
| Forward clutch | |
| Torque converter | |


EXCEPT TRANSAXLE ASSEMBLY

| Name | Function |
|-----------------------------------|---|
| TCM | Judges the vehicle driving status according to the signal from each sensor and controls the non-step transmission mechanism properly. |
| Accelerator pedal position sensor | TM-316 |

CONTROL SYSTEM

System Diagram

INFOID:000000000992113



System Description

INFOID:000000000992114

The function of the TCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, and lock-up operation.
- Send required output signals to the step motor and the respective solenoids.

CONTROL SYSTEM OUTLINE

The CVT senses vehicle operating conditions through various sensors. It always controls the optimum shift position and reduces shifting and lock-up shocks.

| SENSORS (or SIGNAL) | | TCM | | ACTUATORS |
|--|---|--|---|--|
| PNP switch Accelerator pedal position signal Closed throttle position signal Engine speed signal CVT fluid temperature sensor Vehicle speed signal Manual mode signal Stop lamp switch signal Primary speed sensor Secondary speed sensor Primary pressure sensor Secondary pressure sensor | ⇒ | Shift control Line pressure control Primary pressure control Secondary pressure control Lock-up control Engine brake control Vehicle speed control Fail-safe control Self-diagnosis CONSULT-III communication line Duet-EA control CAN system On board diagnosis | ⇒ | Step motor Torque converter clutch solenoid valve Lock-up select solenoid valve Line pressure solenoid valve Secondary pressure solenoid valve Manual mode indicator Shift position indicator CVT indicator lamp Starter relay |

*: Without manual mode.

INPUT/OUTPUT SIGNAL OF TCM

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Control item | | Fluid pressure control | Select control | Shift control | Lock-up control | CAN communication control | Fail-safe function ^(*2) |
|--------------|---|------------------------|----------------|---------------|-----------------|---------------------------|------------------------------------|
| Input | PNP switch | X | X | X | X | X | X |
| | Accelerator pedal position signal ^(*1) | X | X | X | X | X | X |
| | Closed throttle position signal ^(*1) | X | | X | X | X | |
| | Engine speed signal ^(*1) | X | X | | X | X | X |
| | CVT fluid temperature sensor | X | X | X | X | | X |
| | Manual mode signal ^(*1) | X | | X | X | X | X |
| | Stop lamp switch signal ^(*1) | X | | X | X | X | |
| | Primary speed sensor | X | | X | X | X | X |
| | Secondary speed sensor | X | X | X | X | X | X |
| | Primary pressure sensor | X | | X | | | |
| | Secondary pressure sensor | X | | X | | | X |
| Output | Step motor | | | X | | | X |
| | TCC solenoid valve | | X | | X | | X |
| | Lock-up select solenoid valve | | X | | X | | X |
| | Line pressure solenoid valve | X | X | X | | | X |
| | Secondary pressure solenoid valve | X | | X | | | X |

*1: Input by CAN communications.

*2: If these input and output signals are different, the TCM triggers the fail-safe function.


Component Parts Location

INFOID:000000000992115

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



AW11A0002ZZ

- | | | |
|----------------------------|--------------------------------------|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

Component Description

INFOID:000000000992116

TRANSAXLE ASSEMBLY

CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Name | Function |
|-----------------------------------|------------------------|
| PNP switch | TM-276 |
| CVT fluid temperature sensor | TM-279 |
| Primary speed sensor | TM-281 |
| Secondary speed sensor | TM-284 |
| Primary pressure sensor | TM-310 |
| Secondary pressure sensor | TM-306 |
| Step motor | TM-326 |
| TCC solenoid valve | TM-291 |
| Lock-up select solenoid valve | TM-323 |
| Line pressure solenoid valve | TM-295 |
| Secondary pressure solenoid valve | TM-299 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

EXCEPT TRANSAXLE ASSEMBLY

| Name | Function |
|------------------|---|
| TCM | Optimally controls continuously variable transmission system by judging driving conditions based on signals from each sensor. |
| Stop lamp switch | TM-274 |


LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

LOCK-UP AND SELECT CONTROL SYSTEM


System Diagram



System Description

INFOID:000000000992118

- The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.
- The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM. The torque converter clutch control valve engages or releases the torque converter clutch piston.
- When shifting between “N” (“P”) ↔ “D” (“R”), torque converter clutch solenoid controls engagement power of forward clutch and reverse brake.
- The lock-up applied gear range was expanded by locking up the torque converter at a lower vehicle speed than conventional CVT models.



TORQUE CONVERTER CLUTCH AND SELECT CONTROL VALVE CONTROL

Lock-up Released

In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid and the lock-up apply pressure is drained.

In this way, the torque converter clutch piston is not coupled.

Lock-up Applied

In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid and lock-up apply pressure is generated.

In this way, the torque converter clutch piston is pressed and coupled.

Select Control

When shifting between “N” (“P”) ↔ “D” (“R”), optimize the operating pressure on the basis of the throttle position, the engine speed, and the secondary pulley (output) revolution speed to lessen the shift shock.


Component Parts Location

INFOID:000000000992119

LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]



- | | | |
|----------------------------|--------------------------------------|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

Component Description

INFOID:000000000992120

TRANSAXLE ASSEMBLY

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

LOCK-UP AND SELECT CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Name | Function | |
|----------------------------------|------------------------|------------------------|
| Torque converter regulator valve | | |
| TCC control valve | | |
| Select control valve | | TM-250 |
| Select switch valve | | |
| Manual valve | | |
| TCC solenoid valve | TM-291 | |
| Lock-up select solenoid valve | TM-323 | |
| Primary speed sensor | TM-281 | |
| Secondary speed sensor | TM-284 | |
| CVT fluid temperature sensor | TM-279 | |
| PNP switch | TM-276 | |
| Forward clutch | TM-246 | |
| Reverse brake | | |
| Torque converter | | |

EXCEPT TRANSAXLE ASSEMBLY

| Name | Function |
|-----------------------------------|------------------------|
| TCM | TM-254 |
| Accelerator pedal position sensor | TM-316 |


SHIFT MECHANISM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

SHIFT MECHANISM

System Diagram



NOTE:

The gear ratio is set for every position separately.


System Description

INFOID:000000000992122

In order to select the gear ratio which can obtain the driving force in accordance with driver's intention and the vehicle condition, TCM monitors the driving conditions, such as the vehicle speed and the throttle position and selects the optimum gear ratio, and determines the gear change steps to the gear ratio. Then send the command to the step motor, and control the flow-in/flow-out of line pressure from the primary pulley to determine the position of the moving-pulley and control the gear ratio.


“D” POSITION

Shifting over all the ranges of gear ratios from the lowest to the highest.



“M” POSITION

When the selector lever is put in the manual shift gate side, the fixed changing gear line is set. By moving the selector lever to + side or - side, the manual mode switch is changed over, and shift change like M/T becomes possible following the changing gear set line step by step.



DOWNHILL ENGINE BRAKE CONTROL (AUTO ENGINE BRAKE CONTROL)

When downhill is detected with the accelerator pedal released, the engine brake will be strengthened up by downshifting so as not to accelerate the vehicle more than necessary.

ACCELERATION CONTROL

SHIFT MECHANISM


< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

According to vehicle speed and a change of accelerator pedal angle, driver's request for acceleration and driving scene are judged. This function assists improvement in acceleration feeling by making the engine speed proportionate to the vehicle speed. And a shift map which can gain a larger driving force is available for compatibility of mileage with driveability.

Component Parts Location

INFOID:000000000992123



AWIIA0002ZZ

SHIFT MECHANISM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

- | | | |
|----------------------------|--------------------------------------|-------------------------------|
| 1. Control device assembly | 2. Accelerator pedal position sensor | 3. CVT unit harness connector |
| 4. Primary speed sensor | 5. Secondary speed sensor | 6. PNP switch |
| 7. TCM | 8. Battery | 9. Shift position indicator |

Component Description

INFOID:000000000992124

TRANSAXLE ASSEMBLY

| Item | Functoin |
|------------------------|------------------------|
| PNP switch | TM-276 |
| Primary speed sensor | TM-281 |
| Secondary speed sensor | TM-284 |
| Step motor | TM-326 |
| Shift control valve | TM-250 |
| Primary pulley | TM-246 |
| Secondary pulley | TM-246 |

EXCEPT TRANSAXLE ASSEMBLY

| Item | Functoin |
|------|------------------------|
| TCM | TM-254 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


SHIFT LOCK SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

SHIFT LOCK SYSTEM

System Diagram




System Description

INFOID:000000000992126

The selector lever cannot be shifted from "P" position to any other position unless the ignition switch is in the ON position and the brake pedal is depressed.

Component Parts Location

INFOID:000000000992127



- | | | |
|---|--|--|
| 1. BCM (view with instrument panel removed) | 2. Steering column | 3. Stop lamp switch |
| 4. Shift lock release button | 5. Detention switch (for manual shift) | 6. Shift lock solenoid/Detent switch (key) |
| 7. CVT device connector | | |

Component Description

INFOID:000000000992128

SHIFT LOCK SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Component | | Function |
|------------|---------------------------|--|
| CVT device | Shift lock solenoid | TM-262, "System Description" |
| | Lock plate | The lock plate restricts the position pin stroke by selector button operation according to the shift lock unit status. |
| | Position pin | The position pin, linking with the selector button, restricts the selector lever movement. |
| | Shift lock release button | Pressing the shift lock release button cancels the shift lock forcibly. |

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:000000000992129

DESCRIPTION

The CVT system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory, and the TCM memory.

The second is the TCM original self-diagnosis performed by the TCM. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

OBD-II FUNCTION

The ECM provides emission-related on board diagnostic (OBD-II) functions for the CVT system. One function is to receive a signal from the TCM used with OBD-related parts of the CVT system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in "One or Two Trip Detection Logic" when a malfunction is sensed in relation to CVT system parts.

ONE OR TWO TRIP DETECTION LOGIC OF OBD-II

One Trip Detection Logic

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

Two Trip Detection Logic

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — 1st trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — 2nd trip

The "trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II DIAGNOSTIC TROUBLE CODE (DTC)

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

( with **CONSULT-III** or ( **GST**) CONSULT-III or GST (Generic Scan Tool) Examples: P0705, P0720 etc.

These DTC are prescribed by SAE J2012.

(CONSULT-III also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**
CONSULT-III can identify them as shown below, therefore, CONSULT-III (if available) is recommended.

- DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT-III. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

- If the DTC is being detected currently, the time data will be "0".

- If a 1st trip DTC is stored in the ECM, the time data will be "1t".

Freeze Frame Data and 1st Trip Freeze Frame Data

- The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-III or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-III screen, not on the GST. For details, refer to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data, and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items | |
|----------|----------------------------|--|
| 1 | Freeze frame data | Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175 |
| 2 | | Except the above items (Includes CVT related items) |
| 3 | 1st trip freeze frame data | |

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

How to Erase DTC

- The diagnostic trouble code can be erased by CONSULT-III, GST or ECM DIAGNOSTIC TEST MODE as described following.
 - **If the battery cable is disconnected, the diagnostic trouble code will be lost within 24 hours.**
 - **When you erase the DTC, using CONSULT-III or GST is easier and quicker than switching the mode selector on the ECM.**
- The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-632. "CONSULT-III Function"](#) (for california), [EC-1488. "DTC Index"](#) (except for california).
 - **Diagnostic trouble codes (DTC)**
 - **1st trip diagnostic trouble codes (1st trip DTC)**
 - **Freeze frame data**
 - **1st trip freeze frame data**
 - **System readiness test (SRT) codes**
 - **Test values**

How to Erase DTC (With CONSULT-III)

The emission related diagnostic information in the TCM and ECM can be erased by selecting "ALL Erase" in the "Description" of "FINAL CHECK" mode with CONSULT-III.

How to Erase DTC (With GST)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Select Mode 4 with GST (Generic Scan Tool). For details, refer to [EC-632. "CONSULT-III Function"](#) (for california), [EC-1141. "CONSULT-III Function"](#) (except for california).

MALFUNCTION INDICATOR LAMP (MIL)

Description

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [MWI-11. "WARNING LAMPS/INDICATOR LAMPS : System Diagram"](#) (for california), [MWI-11. "WARNING LAMPS/INDICATOR LAMPS : System Diagram"](#) (except for california).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



DIAGNOSIS SYSTEM (TCM)

CONSULT-III Function (TRANSMISSION)

INFOID:000000000992130

CONSULT-III can display each diagnostic item using the diagnostic test modes shown below.

FUNCTION

| Diagnostic test mode | Function |
|--------------------------------|---|
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III. |
| Self-diagnostic results | Self-diagnostic results can be read and erased quickly. |
| Data monitor | Input/Output data in the TCM can be read. |
| CAN diagnostic support monitor | The results of transmit/receive diagnosis of CAN communication can be read. |
| CALIB data | Characteristic information for TCM and CVT assembly can be read. Do not use, but displayed. |
| Function test | Performed by CONSULT-III instead of a technician to determine whether each system is "OK" or "NG". |
| ECU part number | TCM part number can be read. |

WORK SUPPORT MODE

Display Item List

| Item name | Description |
|-------------------------|---|
| ENGINE BRAKE ADJ. | The engine brake level setting can be canceled. |
| CONFORM CVTF DETERIORTN | The CVT fluid deterioration level can be checked. |

Engine Brake Adjustment

"ENGINE BRAKE LEVEL"

- 0:** Initial set value (Engine brake level control is activated)
- OFF:** Engine brake level control is deactivated.

CAUTION:

Mode of "+1" "0" "-1" "-2" "OFF" can be selected by pressing the "UP" "DOWN" on CONSULT-III screen. However, do not select mode other than "0" and "OFF". If the "+1" or "-1" or "-2" is selected, that might cause the irregular driveability.

Check CVT Fluid Deterioration Date

"CVTF DETERIORATION DATE"

More than 210000:

It is necessary to change CVT fluid.

Less than 210000:

It is not necessary to change CVT fluid.

CAUTION:

Touch "CLEAR" after changing CVT fluid, and then erase "CVTF DETERIORATION DATE".

SELF-DIAGNOSTIC RESULT MODE

After performing self-diagnosis, place check marks for results on the [TM-238, "Diagnostic Work Sheet"](#). Reference pages are provided following the items.

Display Items List

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

X: Applicable —: Not applicable

| Items (CONSULT-III screen terms) | Malfunction is detected when... | TCM self-diagnosis | OBD-II (DTC) | Reference page |
|----------------------------------|---|---------------------------------|---|------------------------|
| | | "TRANSMISSION" with CONSULT-III | MIL*1, "ENGINE" with CONSULT-III or GST | |
| CAN COMM CIRCUIT | When TCM is not transmitting or receiving CAN communication signal for 2 seconds or more. | U1000 | U1000 | TM-272 |
| CONTROL UNIT (CAN) | When detecting error during the initial diagnosis of CAN controller to TCM. | U1010 | U1010 | TM-273 |
| BRAKE SW/CIRC | When the brake switch does not switch to ON or OFF. | P0703 | — | TM-274 |
| PNP SW/CIRC | TCM does not receive the correct voltage signal (based on the gear position) from the switch. | P0705 | P0705 | TM-276 |
| ATF TEMP SEN/CIRC | During running, the CVT fluid temperature sensor signal voltage is excessively high or low. | P0710 | P0710 | TM-279 |
| INPUT SPD SEN/CIRC | <ul style="list-style-type: none"> Input speed sensor (primary speed sensor) signal is not input due to an open circuit. An unexpected signal is input when vehicle is being driven. | P0715 | P0715 | TM-281 |
| VEH SPD SEN/CIR AT | <ul style="list-style-type: none"> Signal from vehicle speed sensor CVT [Output speed sensor (Secondary speed sensor)] not input due to open or short circuit. Unexpected signal input during running. | P0720 | P0720 | TM-284 |
| ENGINE SPEED SIG | <ul style="list-style-type: none"> TCM does not receive the CAN communication signal from the ECM. Engine speed is too low while driving. | P0725 | — | TM-287 |
| BELT DAMG | Unexpected gear ratio detected. | P0730 | — | TM-289 |
| TCC SOLENOID/CIRC | Normal voltage not applied to solenoid due to open or short circuit. | P0740 | P0740 | TM-291 |
| A/T TCC S/V FNCTN | <ul style="list-style-type: none"> CVT cannot perform lock-up even if electrical circuit is good. TCM detects as irregular by comparing difference value with slip rotation. There is big difference engine speed and primary speed when TCM lock-up signal is on. | P0744 | P0744 | TM-293 |
| L/PRESS SOL/CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to open or short circuit. TCM detects as irregular by comparing target value with monitor value. | P0745 | P0745 | TM-295 |
| PRS CNT SOL/A FCTN | Unexpected gear ratio was detected in the LOW side due to excessively low line pressure. | P0746 | P0746 | TM-297 |
| PRS CNT SOL/B FCTN | Secondary pressure is too high or too low compared with the commanded value while driving. | P0776 | P0776 | TM-299 |
| PRS CNT SOL/B CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. | P0778 | P0778 | TM-301 |
| MANUAL MODE SWITCH | When an impossible pattern of switch signals is detected, a malfunction is detected. | P0826 | — | TM-303 |
| TR PRS SENS/A CIRC | Signal voltage of the transmission fluid pressure sensor A (secondary pressure sensor) is too high or too low while driving. | P0840 | P0840 | TM-306 |
| PRESS SEN/FNCTN | Correlation between the values of the transmission fluid pressure sensor A (secondary pressure sensor) and the transmission fluid pressure sensor B (primary pressure sensor) is out of specification. | P0841 | — | TM-308 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Items (CONSULT-III screen terms) | Malfunction is detected when... | TCM self-diagnosis | OBD-II (DTC) | Reference page |
|---|--|---------------------------------|---|------------------------|
| | | "TRANSMISSION" with CONSULT-III | MIL*1, "ENGINE" with CONSULT-III or GST | |
| TR PRS SENS/B CIRC | Signal voltage of the transmission fluid pressure sensor B (primary pressure sensor) is too high or too low while driving. | P0845 | P0845 | TM-310 |
| SEC/PRESS DOWN | Secondary fluid pressure is too low compared with the commanded value while driving. | P0868 | — | TM-312 |
| TCM-POWER SUPPLY | <ul style="list-style-type: none"> When the power supply to the TCM is cut OFF, for example because the battery is removed, and the self-diagnosis memory function stops. This is not a malfunction message (Whenever shutting OFF a power supply to the TCM, this message appears on the screen). | P1701 | — | TM-314 |
| TP SEN/CIRC A/T | TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM. | P1705 | — | TM-316 |
| ESTM VEH SPD SIG ² | <ul style="list-style-type: none"> CAN communication with the ABS actuator and the electric unit (control unit) is malfunctioning. There is a great difference between the vehicle speed signal from the ABS actuator and the electric unit (control unit), and the vehicle speed sensor signal. | P1722 | — | TM-318 |
| CVT SPD SEN/FNCTN | <p>A rotation sensor error is detected because the gear does not change in accordance with the position of the stepping motor.</p> <p>CAUTION: One of the "P0720 VEH SPD SEN/CIR AT", the "P0715 INPUT SPD SEN/CIRC" or the "P0725 ENGINE SPEED SIG" is displayed with the DTC at the same time.</p> | P1723 | — | TM-320 |
| ELEC TH CONTROL | The electronically controlled throttle for ECM is malfunctioning. | P1726 | — | TM-322 |
| LU-SLCT SOL/CIRC | <ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. | P1740 | P1740 | TM-323 |
| L/PRESS CONTROL | TCM detects the unexpected line pressure. | P1745 | — | TM-325 |
| STEP MOTR CIRC | Each coil of the step motor is not energized properly due to an open or a short. | P1777 | P1777 | TM-326 |
| STEP MOTR/FNC | There is a great difference between the number of steps for the stepping motor and for the actual gear ratio. | P1778 | P1778 | TM-329 |
| NO DTC IS DETECTED: FURTHER TESTING MAY BE REQUIRED | No NG item has been detected. | X | X | — |

*1: Refer to [TM-264, "Diagnosis Description"](#).

*2: Models without ABS does not indicate.

DATA MONITOR MODE

Display Items List

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

X: Standard, —: Not applicable, ▼: Option

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|------------------------|-----------------------------|-------------------|--------------------------------|--|
| | ECU IN- PUT SIG- NALS | MAIN SIG- NALS | SELEC- TION FROM MENU | |
| VSP SENSOR (km/h) | X | — | ▼ | Output speed sensor (secondary speed sensor) |
| ESTM VSP SIG (km/h) | X | — | ▼ | Models without ABS dose not indicate. |
| PRI SPEED SEN (rpm) | X | — | ▼ | — |
| ENG SPEED SIG (rpm) | X | — | ▼ | — |
| SEC HYDR SEN (V) | X | — | ▼ | — |
| PRI HYDR SEN (V) | X | — | ▼ | — |
| ATF TEMP SEN (V) | X | — | ▼ | CVT fluid temperature sensor |
| VIGN SEN (V) | X | — | ▼ | — |
| VEHICLE SPEED (km/h) | — | X | ▼ | Vehicle speed recognized by the TCM. |
| PRI SPEED (rpm) | — | X | ▼ | Primary pulley speed |
| SEC SPEED (rpm) | — | — | ▼ | Secondary pulley speed |
| ENG SPEED (rpm) | — | X | ▼ | — |
| SLIP REV (rpm) | — | X | ▼ | Difference between engine speed and primary pulley speed. |
| GEAR RATIO | — | X | ▼ | — |
| G SPEED (G) | — | — | ▼ | — |
| ACC PEDAL OPEN (0.0/8) | X | X | ▼ | Degree of opening for accelerator recognized by the TCM. For fail-safe operation, the specific value used for control is displayed. |
| TRQ RTO | — | — | ▼ | — |
| SEC PRESS (MPa) | — | X | ▼ | — |
| PRI PRESS (MPa) | — | X | ▼ | — |
| ATF TEMP | — | X | ▼ | — |
| DSR REV (rpm) | — | — | ▼ | — |
| DGEAR RATIO | — | — | ▼ | — |
| DSTM STEP (step) | — | — | ▼ | — |
| STM STEP (step) | — | X | ▼ | — |
| LU PRS (MPa) | — | — | ▼ | — |
| LINE PRS (MPa) | — | — | ▼ | — |
| TGT SEC PRESS (MPa) | — | — | ▼ | — |
| ISOLT1 (A) | — | X | ▼ | Torque converter clutch solenoid valve output current |
| ISOLT2 (A) | — | X | ▼ | Pressure control solenoid valve A (line pressure solenoid valve) output current |
| ISOLT3 (A) | — | X | ▼ | Pressure control solenoid valve B (secondary pressure solenoid valve) output current |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|-------------------------|------------------------|---------------|----------------------|---|
| | ECU IN-PUT SIG-NALS | MAIN SIG-NALS | SELEC-TION FROM MENU | |
| SOLMON1 (A) | X | X | ▼ | Torque converter clutch solenoid valve monitor current |
| SOLMON2 (A) | X | X | ▼ | Pressure control solenoid valve A (line pressure solenoid valve) monitor current |
| SOLMON3 (A) | X | X | ▼ | Pressure control solenoid valve B (secondary pressure solenoid valve) monitor current |
| P POSITION SW (ON/OFF) | X | — | ▼ | — |
| R POSITION SW (ON/OFF) | X | — | ▼ | — |
| N POSITION SW (ON/OFF) | X | — | ▼ | — |
| D POSITION SW (ON/OFF) | X | — | ▼ | — |
| L POSITION SW (ON/OFF) | X | — | ▼ | — |
| BRAKE SW (ON/OFF) | X | X | ▼ | Stop lamp switch (Signal input with CAN communications) |
| FULL SW (ON/OFF) | X | X | ▼ | Signal input with CAN communications |
| IDLE SW (ON/OFF) | X | X | ▼ | |
| SPORT MODE SW (ON/OFF) | X | X | ▼ | |
| STRDWSW (ON/OFF) | X | — | ▼ | |
| STRUPSW (ON/OFF) | X | — | ▼ | Not mounted but displayed. |
| DOWNLVR (ON/OFF) | X | — | ▼ | |
| UPLVR (ON/OFF) | X | — | ▼ | |
| NONMMODE (ON/OFF) | X | — | ▼ | |
| MMODE (ON/OFF) | X | — | ▼ | |
| INDLRNG (ON/OFF) | — | — | ▼ | — |
| INDDRNG (ON/OFF) | — | — | ▼ | "D" position indicator output |
| INDNRNG (ON/OFF) | — | — | ▼ | "N" position indicator output |
| INDRRNG (ON/OFF) | — | — | ▼ | "R" position indicator output |
| INDPRNG (ON/OFF) | — | — | ▼ | "P" position indicator output |
| CVT LAMP (ON/OFF) | — | — | ▼ | — |
| SPORT MODE IND (ON/OFF) | — | — | ▼ | — |
| MMODE IND (ON/OFF) | — | — | ▼ | — |
| SMCOIL D (ON/OFF) | — | — | ▼ | Step motor coil "D" energizing status |
| SMCOIL C (ON/OFF) | — | — | ▼ | Step motor coil "C" energizing status |
| SMCOIL B (ON/OFF) | — | — | ▼ | Step motor coil "B" energizing status |
| SMCOIL A (ON/OFF) | — | — | ▼ | Step motor coil "A" energizing status |
| LUSEL SOL OUT (ON/OFF) | — | — | ▼ | — |
| REV LAMP (ON/OFF) | — | X | ▼ | — |
| LUSEL SOL MON (ON/OFF) | — | — | ▼ | — |

DIAGNOSIS SYSTEM (TCM)

< FUNCTION DIAGNOSIS >

[CVT: RE0F10A]

| Monitored item (Unit) | Monitor item selection | | | Remarks |
|-----------------------|-----------------------------|-------------------|--------------------------------|--|
| | ECU IN- PUT SIG- NALS | MAIN SIG- NALS | SELEC- TION FROM MENU | |
| VDC ON (ON/OFF) | X | — | ▼ | — |
| TCS ON (ON/OFF) | X | — | ▼ | — |
| ABS ON (ON/OFF) | X | — | ▼ | Models without ABS dose not indicate. |
| ACC ON (ON/OFF) | X | — | ▼ | Not mounted but displayed. |
| RANGE | — | X | ▼ | Indicates position is recognized by TCM. Indicates a specific value required for control when fail-safe function is activated. |
| M GEAR POS | — | X | ▼ | — |
| Voltage (V) | — | — | ▼ | Displays the value measured by the voltage probe. |
| Frequency (Hz) | — | — | ▼ | The value measured by the pulse probe is displayed. |
| DUTY-HI (high) (%) | — | — | ▼ | |
| DUTY-LOW (low) (%) | — | — | ▼ | |
| PLS WIDTH-HI (ms) | — | — | ▼ | |
| PLS WIDTH-LOW (ms) | — | — | ▼ | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

Diagnostic Tool Function

INFOID:000000000992131

OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

Refer to [EC-641, "Diagnosis Tool Function"](#) (for california), [EC-1150, "Diagnosis Tool Function"](#) (except for california)

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000000992132

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000000992133

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "U1000 CAN COMM CIRCUIT" with CONSULT-III is detected when TCM cannot communicate to other control units.

Possible Cause

- Harness or connectors
(CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, touch "ERASE" on "SELF-DIAG RESULTS" and then perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and wait for at least 6 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure "WITH CONSULT-III".

Is "U1000 CAN COMM CIRCUIT" detected?

- YES >> Go to [TM-272, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992134

1. CHECK CAN COMMUNICATION CIRCUIT

With CONSULT-III

1. Turn ignition switch ON and start engine.
2. Select "SELF-DIAG RESULTS".

Is any malfunction of the "U1000 CAN COMM CIRCUIT" indicated?

- YES >> Go to LAN section. Refer to [LAN-25, "CAN System Specification Chart"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000000992135

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000000992136

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “U1010 CONTROL UNIT(CAN)” with CONSULT-III is detected when TCM cannot communicate to other control units.

Possible Cause

- Harness or connectors
(CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, touch “ERASE” on “SELF-DIAG RESULTS” and then perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and wait for at least 6 seconds.
3. Perform “SELF-DIAG RESULTS”.

With GST

Follow the procedure “WITH CONSULT-III”.

Is “U1010 CONTROL UNIT(CAN)” detected?

- YES >> Go to [TM-273, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992137

1. CHECK CAN COMMUNICATION CIRCUIT

With CONSULT-III

1. Turn ignition switch ON and start engine.
2. Select “SELF-DIAG RESULTS”.

Is any malfunction of the “U1010 CONTROL UNIT(CAN)” indicated?

- YES >> Print out CONSULT-III screen, go to LAN section. Refer to [LAN-25, "CAN System Specification Chart"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P0703 STOP LAMP SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0703 STOP LAMP SWITCH

Description

INFOID:000000000992138

ON, OFF status of the stop lamp switch is sent via the CAN communication from the BCM to TCM using the signal.

DTC Logic

INFOID:000000000992139

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0703 BRAKE SW/CIRC" with CONSULT-III is detected when the stop lamp switch does not switch to ON and OFF.
- The stop lamp switch does not switch to ON, OFF.

Possible Cause

- Harness or connectors
(Stop lamp switch, and BCM circuit are open or shorted.)
(CAN communication line is open or shorted.)
- Stop lamp switch

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine.
3. Start vehicle for at least 3 consecutive seconds.
4. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P0703 BRAKE SW/CIRC" detected?

- YES >> Go to [TM-274, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992140

1.CHECK STOP LAMP SWITCH

Check stop lamp switch.

Is the inspection result normal?

- YES >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and BCM.
 - 10A fuse (No.7, located in fuse block).
- NO >> Repair or replace the stop lamp switch.

Component Inspection

INFOID:000000000992141

1.CHECK STOP LAMP SWITCH

Check continuity between stop lamp switch connector terminals.

| Stop lamp switch | | Condition | Continuity |
|------------------|----------|-----------|------------|
| Connector | Terminal | | |
| | | | |

P0703 STOP LAMP SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| | | | | |
|-----|---|---|-------------------------------|-------------|
| E38 | 1 | 2 | When brake pedal is depressed | Existed |
| | | | When brake pedal is released | Not existed |

Check stop lamp switch after adjusting brake pedal — refer to [BR-16](#).

Is the inspection result normal?

- YES >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and BCM.
 - 10A fuse (No.7, located in fuse block).
- NO >> Repair or replace the stop lamp switch.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0705 PARK/NEUTRAL POSITION SWITCH

Description

INFOID:000000000992142

- The PNP switch assembly includes a transaxle range switch.
- The transaxle range switch detects the selector lever position and sends a signal to the TCM.

| Item name | Condition | Display value |
|---------------|---|---------------|
| P POSITION SW | Selector lever in "P" position | ON |
| | When setting selector lever to other positions. | OFF |
| R POSITION SW | Selector lever in "R" position | ON |
| | When setting selector lever to other positions. | OFF |
| N POSITION SW | Selector lever in "N" position | ON |
| | When setting selector lever to other positions. | OFF |
| D POSITION SW | Selector lever in "D" position | ON |
| | When setting selector lever to other positions. | OFF |
| RANGE | Selector lever in "N" or "P" position | N·P |
| | Selector lever in "R" position | R |
| | Selector lever in "D" position | D |

DTC Logic

INFOID:000000000992143

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0705 PNP SW/CIRC" with CONSULT-III is detected when TCM does not receive the correct voltage signal from the switch based on the gear position.

Possible Cause

- Harness or connectors
(PNP switches circuit is open or shorted.)
- PNP switch

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

| | |
|----------------|-----------------------------|
| VEHICLE SPEED | : More than 10 km/h (6 MPH) |
| ENG SPEED | : More than 450 rpm |
| ACC PEDAL OPEN | : More than 1.0/8 |

With GST

Follow the procedure "With CONSULT-III".

Is "P0705 PNP SW/CIRC" detected?

- YES >> Go to [TM-277, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Diagnosis Procedure

INFOID:000000000992144

1. CHECK HARNESS BETWEEN TCM AND PNP SWITCH

1. Turn ignition switch OFF.
2. Disconnect TCM connector and PNP switch connector.
3. Check continuity between TCM connector terminals and PNP switch connector terminals.

| TCM connector | | PNP switch connector | | Continuity |
|---------------|----------|----------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 1 | F25 | 5 | Existed |
| | 2 | | 6 | Existed |
| | 3 | | 7 | Existed |
| | 4 | | 8 | Existed |
| | 11 | | 4 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- OK >> GO TO 2..
 NG >> Repair or replace damaged parts.

2. DETECT MALFUNCTIONING ITEM

Check the following items..

- Harness for short or open between ignition switch and PNP switch.
- 10A fuse (No.4, located in the J/B).
- Ignition switch.

Is the inspection result normal?

- OK >> GO TO 3..
 NG >> Repair or replace damaged parts.

3. CHECK PNP SWITCH

Check PNP switch. Refer to [TM-277, "Component Inspection"](#).

Is the inspection result normal?

- OK >> GO TO 4..
 NG >> Repair or replace damaged parts.

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
 NG >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992145

1. CHECK PNP SWITCH

Change selector lever to various positions to check the continuity between terminals on the PNP switch and ground.

| Selector lever position | PNP switch connector | | | Continuity |
|-------------------------|----------------------|----------|----------|------------|
| | Connector | Terminal | Terminal | |

P0705 PARK/NEUTRAL POSITION SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| | | | | |
|---|-----|---|---------|---------|
| P | F25 | 1 | 2 | Existed |
| | | 3 | 4 | Existed |
| 3 | | 5 | Existed | |
| 1 | | 2 | Existed | |
| 3 | | 6 | Existed | |
| 3 | | 7 | Existed | |
| L | | 3 | 8 | Existed |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> GO TO 2..

2.CHECK CVT POSITION

1. Disconnect control cable.
2. Check PNP switch. (Refer to step 1 above.)

Is the inspection result normal?

YES >> Adjust CVT position. Refer to [TM-384, "Inspection and Adjustment"](#).

NO >> GO TO 3..

3.CHECK CVT POSITION

1. Remove PNP switch from CVT. Refer to [TM-389, "Removal and Installation"](#).
2. Check PNP switch. (Refer to step 1 above.)

Is the inspection result normal?

YES >> Adjust PNP switch. Refer to [TM-381, "Inspection and Adjustment"](#).

NO >> Replace PNP switch. Refer to [TM-389, "Removal and Installation"](#).

P0710 CVT FLUID TEMPERATURE SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0710 CVT FLUID TEMPERATURE SENSOR

Description

INFOID:000000000992146

The CVT fluid temperature sensor detects the CVT fluid temperature and sends a signal to the TCM.

DTC Logic

INFOID:000000000992147

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0710 ATF TEMP SEN/CIRC" with CONSULT-III is detected when TCM receives an excessively low or high voltage from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 10 minutes (Total).

| | |
|----------------|---------------------------|
| VEHICLE SPEED | : 10 km/h (6 MPH) or more |
| ENG SPEED | : 450 rpm more than |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |

With GST

Follow the procedure "With CONSULT-III".

Is "P0710 ATF TEMP SEN/CIRC" detected?

- YES >> Go to [TM-279, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992148

1. CHECK CVT FLUID TEMPERATURE SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the TCM connector.
3. Check resistance between TCM connector terminals.

| CVT fluid temperature sensor | | | Temperature °C (°F) | Resistance (Approx.) |
|------------------------------|----------|----|---------------------|----------------------|
| Connector | Terminal | | | |
| F16 | 13 | 25 | 20 (68) | 6.5 kΩ |
| | | | 80 (176) | 0.9 kΩ |

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> GO TO 2..

2. CHECK CVT FLUID TEMPERATURE SENSOR

P0710 CVT FLUID TEMPERATURE SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Check CVT fluid temperature sensor. Refer to [TM-280, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

3. CHECK HARNESS BETWEEN TCM AND CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect the TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 13 | F46 | 17 | Existed |
| | 25 | | 19 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

OK >> GO TO 4..

NG >> Repair or replace damaged parts.

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992149

CVT FLUID TEMPERATURE SENSOR

1. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminals.

| CVT fluid temperature sensor | | | Temperature °C (°F) | Resistance (Approx.) |
|------------------------------|----------|----|---------------------|----------------------|
| Connector | Terminal | | | |
| F46 | 17 | 19 | 20 (68) | 6.5 kΩ |
| | | | | 80 (176) |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Replace the transaxle assembly. Refer to [TM-382, "Exploded View"](#).

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

Description

INFOID:000000000992150

The input speed sensor (primary speed sensor) detects the primary pulley revolution speed and sends a signal to the TCM.

DTC Logic

INFOID:000000000992151

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0715 INPUT SPD SEN/CIRC" with CONSULT-III is detected when TCM does not receive the proper signal from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Input speed sensor (Primary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|------------------|--|
| VEHICLE SPEED | : 10 km/h (6 MPH) or more |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| ENG SPEED | : 450 rpm or more |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-II".

Is "P0715 INPUT SPD SEN/CIRC" detected?

- YES >> Go to [TM-281, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992152

1. CHECK PRIMARY SPEED SENSOR

With CONSULT-III

1. Start engine.
2. Check power supply to input speed sensor (primary speed sensor) by voltage between TCM connector terminals.

| TCM connector | | | Data (Approx.) |
|---------------|----------|----------|----------------|
| Connector | Terminal | Terminal | |
| | | | |

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| | | | |
|-----|----|----|-----------------|
| F16 | 25 | 45 | Battery voltage |
| | | 48 | |

3. If OK, check the pulse when vehicle cruises.

| TCM connector | | Condition | Data (Approx.) |
|---------------|----------|---|----------------|
| Connector | Terminal | | |
| F16 | 33 | When running at 20 km/h (12 MPH) in "M1" position, use the CONSULT-III pulse frequency measuring function. CAUTION: Connect the data link connector to the vehicle-side diagnosis connector. | 610 Hz |

Is the inspection result normal?

YES >> GO TO 7..

NO >> GO TO 2..

2. CHECK POWER AND SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect the input speed sensor (primary speed sensor) harness connector.
3. Turn ignition switch ON.
4. Check voltage between input speed sensor (primary speed sensor) harness connector terminals.

| Input speed sensor (primary speed sensor) harness connector | | | Data (Approx.) |
|---|----------|----------|-----------------|
| Connector | Terminal | Terminal | |
| F8 | 1 | 3 | Battery voltage |

5. Check voltage between input speed sensor (primary speed sensor) harness connector terminal and ground.

| Input speed sensor (primary speed sensor) harness connector | | Ground | Data (Approx.) |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| F8 | 3 | | Battery voltage |

6. If OK, check harness for short to ground and short to power.

7. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO - 1 >> Battery voltage is not supplied between terminals 1 and 3, terminal 3 and ground: GO TO 5..

NO - 2 >> Battery voltage is not supplied between terminals 1 and 3 only: GO TO 6..

3. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and input speed sensor (primary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and input speed sensor (primary speed sensor) harness connector terminal.

| TCM connector | | Input speed sensor (primary speed sensor) harness connector | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 33 | F8 | 2 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

P0715 INPUT SPEED SENSOR (PRI SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

4. CHECK THE TCM SHORT

Replace same type TCM, perform self-diagnosis check. Erase self-diagnostic results and then drive the vehicle [more than 40 km/h (25 MPH)], perform self-diagnosis check. Refer to [TM-281, "DTC Logic"](#).

Is "P0720 VEH SPD SEN/CIR AT" detected again?

YES >> Replace the primary speed sensor. Refer to [TM-390, "Removal and Installation"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

5. CHECK HARNESS BETWEEN TCM AND INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) (POWER)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and input speed sensor (primary speed sensor) harness connector.
3. Check continuity between TCM connector terminals and input speed sensor (primary speed sensor) harness connector terminal.

| TCM connector | | Input speed sensor (primary speed sensor) harness connector | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 46 | F8 | 3 | Existed |
| | 48 | | | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> 10 A fuse (No. 34, located in the IPDM E/R) or ignition switch are malfunctioning.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) (SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and input speed sensor (primary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and input speed sensor (primary speed sensor) harness connector terminal.

| TCM connector | | Input speed sensor (primary speed sensor) harness connector | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F8 | 1 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 7..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382, "Exploded View"](#).

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

Description

INFOID:000000000992153

The vehicle speed sensor CVT [output speed sensor (secondary speed sensor)] detects the revolution of the CVT output shaft and emits a pulse signal. The pulse signal is sent to the TCM, which converts it into vehicle speed.

DTC Logic

INFOID:000000000992154

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0720 VEH SPD SEN/CIR AT" with CONSULT-III is detected TCM does not receive the proper signal from the sensor.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Output speed sensor (Secondary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DCT DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 12 consecutive seconds.

| | |
|------------------|--|
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

4. If DTC is detected,

With GST

Follow the procedure "With CONSULT-III".

Is "P0720 VEH SPD SEN/CIR AT" detected?

- YES >> Go to [TM-284, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992155

1. CHECK SECONDARY SPEED SENSOR

With CONSULT-III

1. Start engine.
2. Check power supply to output speed sensor (secondary speed sensor) by voltage between TCM connector terminals.

| TCM connector | | | Data (Approx.) |
|---------------|----------|----------|----------------|
| Connector | Terminal | Terminal | |
| | | | |

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| | | | |
|-----|----|---|-----------------|
| F16 | 46 | 7 | Battery voltage |
| | 48 | | |

3. If OK, check the pulse when vehicle cruises.

| TCM connector | | Condition | Data (Approx.) |
|---------------|----------|--|----------------|
| Connector | Terminal | | |
| F16 | 34 | When running at 20 km/h (12 MPH) in "D" position, use the CONSULT-III pulse frequency measuring function. CAUTION: Connect the data link connector to the vehicle-side diagnosis connector. | 480 Hz |

Is the inspection result normal?

- YES >> GO TO 7..
- NO >> GO TO 2..

2. CHECK POWER AND SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect the output speed sensor (secondary speed sensor) harness connector.
3. Turn ignition switch ON.
4. Check voltage between output speed sensor (secondary speed sensor) harness connector terminals.

| Output speed sensor (Secondary speed sensor) harness connector | | | Data (Approx.) |
|--|-----------|----------|-----------------|
| Connector | Connector | Terminal | |
| F23 | 1 | 3 | Battery voltage |

5. Check voltage between output speed sensor (secondary speed sensor) harness connector terminal and ground.

| Output speed sensor (Secondary speed sensor) harness connector | | Ground | Data (Approx.) |
|--|----------|--------|-----------------|
| Connector | Terminal | | |
| F23 | 3 | | Battery voltage |

6. If OK, check harness for short to ground and short to power.
7. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 3..
- NO - 1 >> Battery voltage is not supplied between terminals 1 and 3, terminals 3 and ground: GO TO 5..
- NO - 2 >> Battery voltage is not supplied between terminals 1 and 3 only: GO TO 6..

3. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 34 | F23 | 2 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THE TCM SHORT

P0720 VEHICLE SPEED SENSOR CVT (SECONDARY SPEED SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Replace same type TCM, perform self-diagnosis check. Erase self-diagnostic results and then drive the vehicle [more than 40 km/h (25 MPH)], perform self-diagnosis check. Refer to [TM-284, "DTC Logic"](#).

Is "P0720 VEH SPD SEN/CIR AT" detected again?

YES >> Replace the secondary speed sensor. Refer to [TM-391, "Removal and Installation"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

5. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) (POWER)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminals and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 46 | F23 | 3 | Existed |
| | 48 | | | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> 10 A fuse (No. 34, located in the IPDM E/R) or ignition switch are malfunctioning.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HARNESS BETWEEN TCM AND OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) (SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and output speed sensor (secondary speed sensor) harness connector.
3. Check continuity between TCM connector terminal and output speed sensor (secondary speed sensor) harness connector terminal.

| TCM connector | | Output speed sensor (Secondary speed sensor) harness connector | | Continuity |
|---------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 7 | F23 | 1 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 7..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382, "Exploded View"](#).

P0725 ENGINE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0725 ENGINE SPEED SIGNAL

Description

INFOID:000000000992156

The engine speed signal is sent from the ECM to the TCM.

DTC Logic

INFOID:000000000992157

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0725 ENGINE SPEED SIG" with CONSULT-III is detected when TCM does not receive the engine speed signal (input by CAN communication) from ECM.

Possible Cause

Harness or connectors
(The ECM to the TCM circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 10 consecutive seconds.

PRI SPEED SEN : More than 1000 rpm

Is "P0725 ENGINE SPEED SIG" detected?

- YES >> Go to [TM-287, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992158

1. CHECK DTC WITH ECM

With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

Is the inspection result normal?

- OK >> GO TO 2..
NG >> Check the DTC detected item. Refer to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

2. CHECK DTC WITH TCM

With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "TRANSMISSION" with CONSULT-III. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is the inspection result normal?

- OK >> GO TO 3..
NG >> Check the DTC detected item. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

3. CHECK INPUT SIGNALS

With CONSULT-III

P0725 ENGINE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

1. Start engine.
2. Select "DATA MONITOR".
3. While monitoring "ENG SPEED SIG", check for engine speed change corresponding to "ACC PEDAL OPEN".

| Item name | Condition | Display value |
|----------------|--|---|
| ENG SPEED SIG | Engine running | Closely matches the tachometer reading. |
| ACC PEDAL OPEN | Released accelerator pedal – Fully depressed accelerator pedal | 0.0/8 – 8.0/8 |

Is the inspection result normal?

OK >> GO TO 4..

NG >> Check ignition signal circuit. Refer to [EC-967. "Description"](#) (for california), [EC-1439. "Description"](#) (except for california).

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

OK >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NG >> Replace the TCM. Refer to [TM-382. "Exploded View"](#).

P0730 BELT DAMAGE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0730 BELT DAMAGE

Description

INFOID:000000000992159

TCM selects the gear ratio using the engine load (throttle position), the primary pulley revolution speed, and the secondary pulley revolution speed as input signal. Then it changes the operating pressure of the primary pulley and the secondary pulley and changes the groove width of the pulley.

DTC Logic

INFOID:000000000992160

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- TCM calculates the actual gear ratio with input speed sensor (primary speed sensor) and output speed sensor (secondary speed sensor).
- Diagnostic trouble code "P0730 BELT DAMG" with CONSULT-III is detected, when TCM receives an unexpected gear ratio signal.

Possible Cause

Transaxle assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 30 consecutive seconds.

TEST START FROM 0 km/h (0 MPH)

CONSTANT ACCELERATION : Keep 30 sec or more

VEHICLE SPEED : 10 km/h (6 MPH) or more

ACC PEDAL OPEN : More than 1.0/8

RANGE : "D" position

ENG SPEED : 450 rpm or more

Is "P0730 BELT DAMG" detected?

YES >> Go to [TM-289, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992161

1. CHECK DTC

Perform [TM-289, "DTC Logic"](#).

Are any DTC displayed?

YES - 1>> DTC except for "P0730 BELT DAMG" is displayed: Go to Check the DTC detected item. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

YES - 2>> DTC for "P0730 BELT DAMG" is displayed: Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

P0730 BELT DAMAGE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

NO >> Check intermittent incident. Refer to [G1-39. "Intermittent Incident"](#).

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Description

INFOID:000000000992162

- The torque converter clutch solenoid valve is activated by the TCM in response to signals sent from the vehicle speed and accelerator pedal position sensors. Lock-up piston operation will then be controlled.
- Lock-up operation, however, is prohibited when CVT fluid temperature is too low.
- When the accelerator pedal is depressed (less than 2.0/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

DTC Logic

INFOID:000000000992163

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0740 TCC SOLENOID/CIRC" with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.

Possible Cause

- Torque converter clutch solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Wait at least 10 consecutive seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure "With CONSULT-III".

Is "P0740 TCC SOLENOID/CIRC" detected?

- YES >> Go to [TM-291, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992164

1. CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 38 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 38 | F46 | 12 | Existed |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 3..
NO >> Repair or replace damaged parts.

3.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-292, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4..
NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992165

TORQUE CONVERTER CLUTCH SOLENOID VALVE

1.TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 12 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> **INSPECTION END**
NO >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

Description

INFOID:000000000992166

This malfunction is detected when the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted), but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

DTC Logic

INFOID:000000000992167

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0744 A/T TCC S/V FNCTN" with CONSULT-III is detected under the following conditions.
 - When CVT cannot perform lock-up even if electrical circuit is good.
 - When TCM compares difference value with slip revolution and detects an irregularity.

Possible Cause

- Torque converter clutch solenoid valve
- Hydraulic control circuit

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following condition for at least 30 seconds.

| | |
|----------------|--|
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| Vehicle speed | : Constant speed of more than 40 km/h (25 MPH) |

4. If DTC is detected

With GST

Follow the procedure "With CONSULT-III".

Is "P0744 A/T TCC S/V FNCTN" detected?

- YES >> Go to [TM-293, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992168

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
- NO >> Repair or replace damaged parts. Refer to [TM-375, "Inspection and Judgment"](#).

2. CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-292, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Repair or replace damaged parts.

P0744 A/T TCC S/V FUNCTION (LOCK -UP)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

3.CHECK LOCK-UP SELECT SOLENOID VALVE

Check lock-up select solenoid valve. Refer to [TM-324, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-284, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-281, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6..

NO >> Repair or replace damaged parts.

6.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

P0745 LINE PRESSURE SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0745 LINE PRESSURE SOLENOID VALVE

Description

INFOID:000000000992169

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992170

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0745 L/PRESS SOL/CIRC" with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve A (Line pressure solenoid valve)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DCT DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and wait at least 5 seconds.
3. Perform "SELF-DIAG RESULTS" [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure "With CONSULT-III".

Is "P0745 L/PRESS SOL/CIRC" detected?

- YES >> Go to [TM-295, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992171

1. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 40 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> GO TO 2..

2. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-296, "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Replace the transaxle assembly. Refer to [TM-382, "Exploded View"](#).

P0745 LINE PRESSURE SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

3. CHECK HARNESS BETWEEN TCM AND PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector and TCM connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 40 | F46 | 2 | Existed |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992172

PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 2 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

Description

INFOID:000000000992173

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992174

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0746 PRS CNT SOL/A FCTN" with CONSULT-III is detected under the following conditions.
- Unexpected gear ratio was detected in the LOW side due to excessively low line pressure.

Possible Cause

- Line pressure control system
- Output speed sensor (Secondary speed sensor)
- Input speed sensor (Primary speed sensor)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 10 consecutive seconds. Test start from 0 km/h (0 MPH).

| | |
|------------------|--|
| ATF TEMP SEN | : 1.0 – 2.0 V |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| VEHICLE SPEED | : 10 km/h (6 MPH) More than |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-III".

Is "P0746 PRS CNT SOL/A FCTN" detected?

- YES >> Go to [TM-297, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992175

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
- NO >> Repair or replace damaged parts. Refer to [TM-375, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

P0746 PRESSURE CONTROL SOLENOID A PERFORMANCE (LINE PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Check pressure control solenoid valve A (line pressure solenoid valve). Refer to [TM-296, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-284, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-281, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

Description

INFOID:000000000992176

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992177

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0776 PRS CNT SOL/B FCTN" with CONSULT-III is detected when secondary pressure is too high or too low compared with the commanded value while driving.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve system)
- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Line pressure control system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 30 consecutive seconds.

| | |
|------------------|--|
| ATF TEMP SEN | : 1.0 – 2.0 V |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| VEHICLE SPEED | : 10 km/h (6 MPH) More than |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

With GST

Follow the procedure "With CONSULT-III".

Is "P0776 PRS CNT SOL/B FCTN" detected?

- YES >> Go to [TM-299, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992178

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts. Refer to [TM-375, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

P0776 PRESSURE CONTROL SOLENOID B PERFORMANCE (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Check pressure control solenoid valve B (Secondary pressure solenoid valve). Refer to [TM-302. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-296. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-306. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382. "Exploded View"](#).

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

Description

INFOID:000000000992179

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992180

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0778 PRS CNT SOL/B CIRC" with CONSULT-III is detected under the following conditions.
 - TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Start engine.
3. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
4. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

With GST

Follow the procedure "With CONSULT-III".

Is "P0778 PRS CNT SOL/B CIRC" detected?

- YES >> Go to [TM-301, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992181

1. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 39 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> GO TO 2..

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve B (secondary pressure solenoid valve). Refer to [TM-302, "Component Inspection"](#).

P0778 PRESSURE CONTROL SOLENOID B ELECTRICAL (SEC PRESSURE SOLENOID VALVE)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Is the inspection result normal?

- YES >> GO TO 3..
- NO >> Repair or replace damaged parts.

3.CHECK HARNESS BETWEEN TCM AND PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 39 | F46 | 3 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

- YES >> GO TO 4..
- NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992182

PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1.PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 3 | | 3.0 – 9.0 Ω |

Is the inspection result normal?

- YES >> **INSPECTION END**
- NO >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

P0826 MANUAL MODE SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0826 MANUAL MODE SWITCH

Description

INFOID:000000000992183

Manual mode switch is installed in CVT control device. The manual mode switch sends shift up and shift down switch signals to TCM.

TCM sends the switch signals to combination meter via CAN communication line. Then manual mode switch position is indicated on the CVT position indicator.

DTC Logic

INFOID:000000000992184

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0826 MANUAL MODE SWITCH" with CONSULT-III is detected when TCM monitors Manual mode, Non manual mode, Up or Down switch signal, and then detects irregular with impossible input pattern for 1 second or more.

Possible Cause

- Harness or connectors
(These switches circuit is open or shorted.)
(TCM, and combination meter circuit are open or shorted.)
(CAN communication line is open or shorted.)
- Manual mode select switch (Built into CVT control device)
- Manual mode position select switch (Built into CVT control device)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine.
4. Drive vehicle for at least 2 consecutive seconds.

MMODE : ON

Is "P0826 MANUAL MODE SWITCH" detected?

- YES >> Go to [TM-303, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992185

1. CHECK MANUAL MODE SWITCH SIGNALS

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Read out ON/OFF switching action of the "MMODE", "NON M-MODE", "UPLVR", "DOWNLVR".

| Item name | Condition | Display value |
|-----------|--------------------------------------|---------------|
| MMODE | Manual shift gate position (neutral) | ON |
| | Other than the above | OFF |

P0826 MANUAL MODE SWITCH

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

| Item name | Condition | Display value |
|-----------|--|---------------|
| NONMMODE | Manual shift gate position (neutral, +side, -side) | OFF |
| | Other than the above | ON |
| UPLVR | Selector lever: + side | ON |
| | Other than the above | OFF |
| DOWNLVR | Selector lever: - side | ON |
| | Other than the above | OFF |

⊗ Without CONSULT-III

Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ↔ 6th gear).

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2.CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [TM-305, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK SELF-DIAGNOSTIC RESULTS (COMBINATION METER)

Perform self-diagnosis check. Refer to [MWI-16, "CONSULT-III Function \(METER\)"](#).

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 4..

4.CHECK MANUAL MODE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect CVT device connector and combination meter connector.
3. Check continuity between CVT device harness connector terminals and combination meter harness connector terminals.

| CVT device harness connector | | Combination meter harness connector | | Continuity |
|------------------------------|----------|-------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M23 | 1 | M24 | 40 | Existed |
| | 2 | | 38 | Existed |
| | 3 | | 39 | Existed |
| | 5 | | 37 | Existed |

4. Check continuity between CVT device harness connector terminal and ground.

| CVT device harness connector | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M23 | 4 | | Existed |

5. If OK, check harness for short to ground and short to power.

6. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

P0826 MANUAL MODE SWITCH

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382. "Exploded View"](#).

Component Inspection

INFOID:000000000992186

MANUAL MODE SWITCH

1. MANUAL MODE SWITCH

Check continuity between CVT device harness connector terminals.

| Item | Position | CVT device harness connector | | | Continuity |
|------------------------------------|----------|------------------------------|----------|----------|------------|
| | | Connector | Terminal | Terminal | |
| Manual mode select switch | Auto | M23 | 4 | 5 | Existed |
| | Manual | | 1 | 4 | |
| Manual mode position select switch | Up | | 3 | 4 | |
| | Down | | 2 | 4 | |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Repair or replace damaged parts.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

Description

INFOID:000000000992187

The transmission fluid pressure sensor A (secondary pressure sensor) detects secondary pressure of CVT and sends TCM the signal.

DTC Logic

INFOID:000000000992188

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0840 TR PRS SENS/A CIRC" with CONSULT-III is detected when TCM detects an improper voltage drop when it receives the sensor signal.

Possible Cause

- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Harness or connectors
(Switch circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of line temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and wait for at least 5 consecutive seconds.

Ⓟ With GST

Follow the procedure "WITH CONSULT-III".

Is "P0840 TR PRS SENS/A CIRC" detected?

YES >> Go to [TM-306, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992189

1. CHECK INPUT SIGNAL

1. Start engine.
2. Check voltage between TCM connector terminal and ground.

| TCM connector | | Ground | Condition | Data (Approx.) |
|---------------|----------|--------|------------------|----------------|
| Connector | Terminal | | | |
| F16 | 15 | | "N"position idle | 1.0 V |

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR)

1. Turn ignition switch OFF.

P0840 TRANSMISSION FLUID PRESSURE SENSOR A (SEC PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 15 | F46 | 23 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (SENSOR POWER AND SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F46 | 19 | Existed |
| | 26 | | 20 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK SENSOR POWER AND SENSOR GROUND

1. Turn ignition switch ON.
2. Disconnect CVT unit harness connector.
3. Check voltage between TCM connector terminals.

| CVT unit harness connector | | | Data (Approx.) |
|----------------------------|----------|----|----------------|
| Connector | Terminal | | |
| F46 | 19 | 20 | 5.0 V |

4. Reinstall any part removed.

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-393. "Exploded View"](#).

NO >> GO TO 5..

5. CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382. "Exploded View"](#).

P0841 PRESSURE SENSOR FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0841 PRESSURE SENSOR FUNCTION

Description

INFOID:000000000992190

Using the engine load (throttle position), the primary pulley revolution speed, and the secondary pulley revolution speed as input signal, TCM changes the operating pressure of the primary pulley and the secondary pulley and changes the groove width of the pulley to control the gear ratio.

DTC Logic

INFOID:000000000992191

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0841 PRESS SEN/FNCTN" with CONSULT-III is detected when correlation between the values of the secondary pressure sensor and the primary pressure sensor is out of specification.

Possible Cause

- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Transmission fluid pressure sensor B (Primary pressure sensor)
- Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 12 consecutive seconds.

VEHICLE SPEED : 40 km/h (25 MPH) More than
RANGE : "D" position

Is "P0841 PRESS SEN/FNCTN" detected?

- YES >> Go to [TM-308, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992192

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts. Refer to [TM-375, "Inspection and Judgment"](#).

2. CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-306, "Description"](#).

Is the inspection result normal?

- YES >> GO TO 3..
NO >> Repair or replace damaged parts.

3. CHECK TRANSMISSION FLUID PRESSURE SENSOR B (PRIMARY PRESSURE SENSOR) SYSTEM

P0841 PRESSURE SENSOR FUNCTION

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Check transmission fluid pressure sensor B (primary pressure sensor) system. Refer to [TM-310. "Description"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-296. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK SECONDARY PRESSURE SOLENOID VALVE

Check secondary pressure solenoid valve. Refer to [TM-302. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6..

NO >> Repair or replace damaged parts.

6.CHECK STEP MOTOR

Step motor. Refer to [TM-327. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7..

NO >> Repair or replace damaged parts.

7.CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382. "Exploded View"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

Description

INFOID:000000000992193

The transmission fluid pressure sensor B (primary pressure sensor) detects primary pressure of CVT and sends TCM the signal.

DTC Logic

INFOID:000000000992194

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0845 TR PRS SENS/B CIRC" with CONSULT-III is detected under the following conditions.
 - When TCM detects an improper voltage drop when it receives the sensor signal.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Transmission fluid pressure sensor B (Primary pressure sensor)
- Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of line temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and wait for at least 5 consecutive seconds.

With GST

Follow the procedure "WITH CONSULT-III".

"P0845 TR PRS SENS/B CIRC" detected?

YES >> Go to [TM-310, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992195

1. CHECK INPUT SIGNAL

1. Start engine.
2. Check voltage between TCM connector terminal and ground.

| TCM connector | | Ground | Condition | Data (Approx.) |
|---------------|----------|--------|-------------------|----------------|
| Connector | Terminal | | | |
| F16 | 14 | | "N" position idle | 0.7 – 3.5 V |

Is the inspection result normal?

YES >> GO TO 5..

NO >> GO TO 2..

2. CHECK HARNESS BETWEEN TCM AND TRANSMISSION FLUID PRESSURE SENSOR B (PRIMARY

P0845 TRANSMISSION FLUID PRESSURE SENSOR B (PRI PRESSURE SENSOR)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

PRESSURE SENSOR)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 14 | F46 | 25 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS BETWEEN TCM AND CVT UNIT HARNESS CONNECTOR (SENSOR POWER AND SENSOR GROUND)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit harness connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 25 | F46 | 19 | Existed |
| | 26 | | 20 | Existed |

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK SENSOR POWER AND SENSOR GROUND

1. Turn ignition switch ON.
2. Disconnect CVT unit harness connector.
3. Check voltage between CVT unit harness connector terminals.

| CVT unit harness connector | | | Data (Approx.) |
|----------------------------|----------|----|----------------|
| Connector | Terminal | | |
| F46 | 19 | 20 | 5.0 V |

4. Reinstall any part removed.

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

NO >> GO TO 5..

5. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382, "Exploded View"](#).

P0868 SECONDARY PRESSURE DOWN

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P0868 SECONDARY PRESSURE DOWN

Description

INFOID:000000000992196

The pressure control solenoid valve B (secondary pressure solenoid valve) regulates the secondary pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992197

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0868 SEC/PRESS DOWN" with CONSULT-III is detected when secondary fluid pressure is too low compared with the commanded value while driving.

Possible Cause

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Pressure control solenoid valve B (Secondary pressure solenoid valve) system
- Transmission fluid pressure sensor A (Secondary pressure sensor)
- Line pressure control system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DCT DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 10 consecutive seconds.

VEHICLE SPEED (accelerate slowly) : 0 → 50 km/h (31 MPH)

ACC PEDAL OPEN : 0.5/8 – 1.0/8

RANGE : "D" position

"P0868 SEC/PRESS DOWN"

YES >> Go to [TM-312, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992198

1. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-375, "Inspection and Judgment"](#).

Is the inspection result normal?

YES >> GO TO 2..

NO >> Repair or replace damaged parts. Refer to [TM-375, "Inspection and Judgment"](#).

2. CHECK PRESSURE CONTROL SOLENOID VALVE B (SECONDARY PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve B (Secondary pressure solenoid valve). Refer to [TM-302, "Component Inspection"](#).

P0868 SECONDARY PRESSURE DOWN

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK PRESSURE CONTROL SOLENOID VALVE A (LINE PRESSURE SOLENOID VALVE)

Check pressure control solenoid valve A (Line pressure solenoid valve). Refer to [TM-296. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TRANSMISSION FLUID PRESSURE SENSOR A (SECONDARY PRESSURE SENSOR) SYSTEM

Check transmission fluid pressure sensor A (secondary pressure sensor) system. Refer to [TM-306. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5..

NO >> Repair or replace damaged parts.

5.CHECK TCM

Check input/output signal. Refer to [TM-335. "Reference Value"](#)

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382. "Exploded View"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

Description

INFOID:000000000992199

When the power supply to the TCM is cut OFF, for example because the battery is removed, and the self-diagnosis memory function stops, malfunction is detected.

NOTE:

Since "P1701 TCM-POWER SUPPLY" will be indicated when replacing TCM, perform diagnosis after erasing "SELF-DIAG RESULTS"

DTC Logic

INFOID:000000000992200

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1701 TCM-POWER SUPPLY" with CONSULT-III is detected when TCM does not receive the voltage signal from the battery power supply.
- This is not a malfunction message. (Whenever shutting OFF a power supply to the TCM, this message appears on the screen.)

Possible Cause

Harness or connectors

(Battery or ignition switch and TCM circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Wait for at least 2 consecutive seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is "P1701 TCM-POWER SUPPLY" detected?

YES >> Go to [TM-314, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992201

1.CHECK TCM POWER SOURCE

Check voltage between TCM connector terminals and ground.

| Name | TCM connector | | Condition | Data (Approx.) |
|-------------------------------|---------------|---------------------|---------------------|-----------------|
| | Connector | Terminal | | |
| Power supply | F16 | 46 | Ignition switch ON | Battery voltage |
| | | 48 | Ignition switch OFF | 0 V |
| | | | Ignition switch ON | Battery voltage |
| | | Ignition switch OFF | 0 V | |
| Power supply (memory back-up) | F16 | 45 | Always | Battery voltage |
| | | 47 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2..

2.DETECT MALFUNCTIONING ITEM

Check the following.

P1701 TRANSMISSION CONTROL MODULE (POWER SUPPLY)

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

- Harness for short or open between battery and TCM connector terminal 45, 47
- Harness for short or open between ignition switch and TCM connector terminal 46, 48
- 10 A fuse (No. 34, located in the IPDM E/R)
- 10 A fuse (No. 11, located in the J/B)
- Ignition switch. Refer to [PG-5](#).

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair or replace damaged parts.

3.CHECK TCM GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM connector terminals and ground.

| TCM connector | | Ground | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| F16 | 5 | | Existed |
| | 42 | | Existed |

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK TCM

1. Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382. "Exploded View"](#).

P1705 THROTTLE POSITION SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1705 THROTTLE POSITION SENSOR

Description

INFOID:000000000992202

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000000992203

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1705 TP SEN/CIRC A/T" with CONSULT-III is detected when TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.

Possible Cause

- ECM
- Harness or connectors
(CAN communication line is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Depress accelerator pedal fully and release it, then wait for 5 seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

"P1705 TP SEN/CIRC A/T"

- YES >> Go to [TM-316, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992204

1. CHECK INPUT SIGNAL

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Read out the value of "ACC PEDAL OPEN".

| Item name | Condition | Display value (Approx.) |
|----------------|--|-------------------------|
| ACC PEDAL OPEN | Release accelerator pedal. | 0.0/8 |
| | ↓ Fully depressed accelerator pedal | ↓ 8.0/8 |

OK or NG

- OK >> Intermittent incident.
NG >> GO TO 2..

2. CHECK DTC WITH ECM

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

OK or NG

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P1705 THROTTLE POSITION SENSOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

NG >> Check the DTC Detected Item. Go to [EC-632. "CONSULT-III Function"](#) (for california), [EC-1141. "CONSULT-III Function"](#) (except for california).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P1722 ESTM VEHICLE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1722 ESTM VEHICLE SPEED SIGNAL

Description

INFOID:000000000992205

The vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) to TCM by CAN communication line.

DTC Logic

INFOID:000000000992206

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1722 ESTM VEH SPD SIG” with CONSULT-III is detected when TCM does not receive the proper vehicle speed signal (input by CAN communication) from ABS actuator and electric unit (control unit).

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select “DATA MONITOR”.
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

ACC PEDAL OPEN : 1.0/8 or less
VEHICLE SPEED : 30 km/h (19 MPH) or more

Is “P1722 ESTM VEH SPD SIG” detected?

- YES >> Go to [TM-318, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992207

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform “SELF-DIAG RESULTS”. Refer to [BRC-12, "CONSULT-III Function \(ABS\)"](#).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Repair or replace damaged parts.

2. CHECK INPUT SIGNALS

With CONSULT-III

1. Start engine.
2. Select “DATA MONITOR”.
3. Drive vehicle and read out the value of “VEHICLE SPEED” and “ESTM VSP SIG”.

| Item name | Condition | Display value |
|---------------|----------------|--|
| ESTM VSP SIG | During driving | Approximately matches the speedometer reading. |
| VEHICLE SPEED | | |

4. Check if there is a great difference between the two values.

P1722 ESTM VEHICLE SPEED SIGNAL

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> GO TO 3..

3.CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382. "Exploded View"](#).

A
B
C
E
F
G
H
I
J
K
L
M
N
O
P

TM

P1723 CVT SPEED SENSOR FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1723 CVT SPEED SENSOR FUNCTION

Description

INFOID:000000000992208

The vehicle speed sensor CVT [output speed sensor (secondary speed sensor)] detects the revolution of parking gear and generates a pulse signal. The pulse signal is sent to the TCM, which converts it into vehicle speed.

The input speed sensor (primary speed sensor) detects the primary pulley revolution speed and sends a signal to the TCM.

DTC Logic

INFOID:000000000992209

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1723 CVT SPD SEN/FNCTN" with CONSULT-III is detected when there is a great difference between the vehicle speed signal and the secondary speed sensor signal.

CAUTION:

One of the "P0720 VEH SPD SEN/CIR AT", the "P0715 INPUT SPD SEN/CIRC" or the "P0725 ENGINE SPEED SIG" is displayed with the DTC at the same time.

NOTE:

When the vehicle is driven fixed in 2nd gear, a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.

Possible Cause

- Harness or connectors
(Sensor circuit is open or shorted.)
- Output speed sensor (Secondary speed sensor)
- Input speed sensor (Primary speed sensor)
- Engine speed signal system

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

| | |
|------------------|--|
| VEHICLE SPEED | : 10 km/h (6 MPH) or more |
| ACC PEDAL OPEN | : More than 1.0/8 |
| RANGE | : "D" position |
| ENG SPEED | : 450 rpm or more |
| Driving location | : Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test. |

"P1723 CVT SPD SEN/FNCTN"

YES >> Go to [TM-320, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992210

1. CHECK STEP MOTOR FUNCTION

Perform the self-diagnosis check. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

P1723 CVT SPEED SENSOR FUNCTION

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Is a malfunction in the step motor function indicated in the results?

- YES >> Repair or replace damaged parts. (Check the step motor function. Refer to [TM-329, "DTC Logic"](#).)
- NO >> GO TO 2..

2.CHECK OUTPUT SPEED SENSOR (SECONDARY SPEED SENSOR) SYSTEM

Check output speed sensor (secondary speed sensor) system. Refer to [TM-284, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 3..
- NG >> Repair or replace damaged parts.

3.CHECK INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) SYSTEM

Check input speed sensor (primary speed sensor) system. Refer to [TM-281, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 4..
- NG >> Repair or replace damaged parts.

4.CHECK ENGINE SPEED SIGNAL SYSTEM

Check engine speed signal system. Refer to [TM-287, "DTC Logic"](#).

Is the inspection result normal?

- OK >> GO TO 5..
- NG >> Repair or replace damaged parts. Refer to [EC-967, "Description"](#) (for california), [EC-1439, "Description"](#) (except for california).

5.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

- OK >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NG >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P1726 ELECTRIC THROTTLE CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1726 ELECTRIC THROTTLE CONTROL SYSTEM

Description

INFOID:000000000992211

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor etc. The actuator sends a signal to the ECM, and ECM sends the signal to TCM with CAN communication.

DTC Logic

INFOID:000000000992212

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1726 ELEC TH CONTROL" with CONSULT-III is detected when the electronically controlled throttle for ECM is malfunctioning.

Possible Cause

Harness or connectors
(Sensor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Start engine and let it idle for 5 seconds.
3. Perform "SELF-DIAG RESULTS".

"P1726 ELEC TH CONTROL" detected?

- YES >> Go to [TM-322, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992213

1. CHECK DTC WITH ECM

Ⓟ With CONSULT-III

1. Turn ignition switch ON.
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-III. Refer to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

Is the inspection result normal?

- YES >> GO TO 2..
NO >> Check the DTC Detected Item. Go to [EC-632, "CONSULT-III Function"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california)..

2. CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
NO >> Replace TCM. Refer to [TM-382, "Exploded View"](#).

P1740 LOCK-UP SELECT SOLENOID VALVE

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1740 LOCK-UP SELECT SOLENOID VALVE

Description

INFOID:000000000992214

- Lock-up select solenoid valve controls lock-up clutch pressure or forward clutch pressure (reverse brake pressure).
- When controlling lock-up clutch, the valve is turned OFF. When controlling forward clutch, it is turned ON.

DTC Logic

INFOID:000000000992215

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1740 LU-SLCT SOL/CIRC" with CONSULT-III is detected under the following conditions.
 - When TCM compares target value with monitor value and detects an irregularity.

Possible Cause

- Lock-up select solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1.CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

RANGE : "D" position and "N" positions

(At each time, wait for 5 seconds.)

With GST

Follow the procedure "With CONSULT-III".

Is ""

YES >> Go to [TM-323, "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992216

1.CHECK LOCK-UP SELECT SOLENOID VALVE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check resistance between TCM connector terminal and ground.

| TCM connector | | Ground | Resistance (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F16 | 37 | | 17 – 38 Ω |

Is the inspection result normal?

YES >> GO TO .4.

NO >> GO TO 2..

2.CHECK LOCK-UP SELECT SOLENOID VALVE

P1740 LOCK-UP SELECT SOLENOID VALVE

[CVT: RE0F10A]

< COMPONENT DIAGNOSIS >

Check lock-up select solenoid valve.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Replace the transaxle assembly. Refer to [TM-393. "Exploded View"](#).

3.CHECK HARNESS BETWEEN TCM AND LOCK-UP SELECT SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM connector terminal and CVT unit harness connector terminal.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 37 | F46 | 13 | Existed |

4. If OK, check harness for short to ground and short to power.

5. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-335. "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> Replace TCM. Refer to [TM-382. "Exploded View"](#).

Component Inspection

INFOID:000000000992217

LOCK-UP SELECT SOLENOID VALVE

1.LOCK-UP SELECT SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminal and ground.

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 13 | | 17 – 38 Ω |

Is the inspection result normal?

YES >> **INSPECTION END**

NO >> Replace the transaxle assembly. Refer to [TM-393. "Exploded View"](#).

P1745 LINE PRESSURE CONTROL

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1745 LINE PRESSURE CONTROL

Description

INFOID:000000000992218

The pressure control solenoid valve A (line pressure solenoid valve) regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

DTC Logic

INFOID:000000000992219

DTC DETECTION LOGIC

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1745 L/PRESS CONTROL” with CONSULT-III is detected when TCM detects the unexpected line pressure.

Possible Cause

TCM

DTC CONFIRMATION PROCEDURE

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

Ⓜ With CONSULT-III

1. Turn ignition switch ON.
2. Select “DATA MONITOR”.
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

“P1745 L/PRESS CONTROL”

- YES >> Go to [TM-325, "Diagnosis Procedure"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992220

1. CHECK DTC

Ⓜ With CONSULT-III

1. Turn ignition switch ON.
2. Select “SELF-DIAG RESULTS”.
3. Erase self-diagnostic results. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).
4. Turn ignition switch OFF, and wait for 10 seconds or more.
5. Start engine.
6. Confirm self-diagnostic results again. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

Is the “P1745 L/PRESS CONTROL” displayed?

- YES >> Replace TCM. Refer to [TM-382, "Exploded View"](#).
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

P1777 STEP MOTOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1777 STEP MOTOR

Description

INFOID:000000000992221

The step motor changes the step with turning 4 coils ON/OFF according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled

DTC Logic

INFOID:000000000992222

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1777 STEP MOTR CIRC" with CONSULT-III is detected under the following conditions.
- When operating step motor ON and OFF, there is no proper change in the voltage of TCM terminal which corresponds to it.

Possible Cause

- Step motor
- Harness or connectors
(Step motor circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

④ With CONSULT-III

1. Turn ignition switch ON.
2. Drive vehicle for at least 5 consecutive seconds.
3. Perform "SELF-DIAG RESULTS". Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).

⑤ With GST

Follow the procedure "With CONSULT-III".

"P1777 STEP MOTR CIRC"

- YES >> Go to [TM-326, "Diagnosis Procedure"](#).
- NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992223

1. CHECK INPUT SIGNALS

④ With CONSULT-III

1. Start engine.
2. Select "DATA MONITOR".
3. Start vehicle and read out the value of "STM STEP", "SMCOIL A", "SMCOIL B", "SMCOIL C", and "SMCOIL D".

| Item name | Condition | Display value (Approx.) |
|-----------|----------------|-------------------------|
| STM STEP | During driving | 0 step – 177 step |
| SMCOIL A | | Changes ON↔OFF. |
| SMCOIL B | | |
| SMCOIL C | | |
| SMCOIL D | | |

Is the inspection result normal?

- YES >> GO TO 4..

P1777 STEP MOTOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

NO >> GO TO 2..

2.CHECK HARNESS BETWEEN TCM AND STEP MOTOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector and TCM connector.
3. Check continuity between TCM connector terminals and CVT unit harness connector terminals.

| TCM connector | | CVT unit harness connector | | Continuity |
|---------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F16 | 27 | F46 | 9 | Existed |
| | 28 | | 8 | Existed |
| | 29 | | 7 | Existed |
| | 30 | | 6 | Existed |

4. If OK, check harness for short to ground and short to power.
5. If OK, check continuity between body ground and CVT assembly.
6. Reinstall any part removed.

Is the inspection result normal?

YES >> GO TO 3..

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK STEP MOTOR

Check step motor. Refer to [TM-327, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4..

NO >> Repair or replace damaged parts.

4.CHECK TCM

Check TCM input/output signals. Refer to [TM-335, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace the TCM. Refer to [TM-382, "Exploded View"](#).

Component Inspection

INFOID:000000000992224

STEP MOTOR

1.STEP MOTOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit harness connector.
3. Check resistance between CVT unit harness connector terminals and ground.

| CVT unit harness connector | | | Resistance (Approx.) |
|----------------------------|----------|----------|----------------------|
| Connector | Terminal | Terminal | |
| F46 | 6 | 7 | 30 Ω |
| | 8 | 9 | |

| CVT unit harness connector | | Ground | Resistance (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F46 | 6 | Ground | 15 Ω |
| | 7 | | |
| | 8 | | |
| | 9 | | |

Is the inspection result normal?

P1777 STEP MOTOR

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

YES >> **INSPECTION END**

NO >> Replace the transaxle assembly. Refer to [TM-393, "Exploded View"](#).

P1778 STEP MOTOR - FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

P1778 STEP MOTOR - FUNCTION

Description

INFOID:000000000992225

- The step motor's 4 aspects of ON/OFF change according to the signal from TCM. As a result, the flow of line pressure to primary pulley is changed and pulley ratio is controlled.
- This diagnosis item is detected when electrical system is OK, but mechanical system is NG.
- This diagnosis item is detected when the state of the changing the speed mechanism in unit does not operate normally.

DTC Logic

INFOID:000000000992226

DTC DETECTION LOGIC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1778 STEP MOTR/FNC" with CONSULT-III is detected under the following conditions.
 - When not changing the pulley ratio according to the instruction of TCM.

Possible Cause

Step motor

DTC CONFIRMATION PROCEDURE

CAUTION:

- Always drive vehicle at a safe speed.
- Before starting "DTC CONFIRMATION PROCEDURE", confirm "Hi" or "Mid" or "Low" fixation by "PRI SPEED" and "VEHICLE SPEED" on "DATA MONITOR MODE".
- If hi-gear fixation occurred, go to [TM-329. "Diagnosis Procedure"](#).

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

1. CHECK DTC DETECTION

With CONSULT-III

1. Turn ignition switch ON.
2. Select "DATA MONITOR".
3. Make sure that output voltage of CVT fluid temperature sensor is within the range below.

ATF TEMP SEN : 1.0 – 2.0 V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid)

4. Start engine and maintain the following conditions for at least 30 consecutive seconds.

TEST START FROM 0 km/h (0 MPH)

CONSTANT ACCELERATION : Keep 30 sec or more

VEHICLE SPEED : 10 km/h (6 MPH) or more

ACC PEDAL OPEN : More than 1.0/8

RANGE : "D" position

ENG SPEED : 450 rpm or more

With GST.

Follow the procedure "With CONSULT-III".

"P1778 STEP MOTR/FNC"

YES >> Go to [TM-329. "Diagnosis Procedure"](#).

NO >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000000992227

1. CHECK STEP MOTOR

P1778 STEP MOTOR - FUNCTION

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

Ⓟ With CONSULT-III

It is monitoring whether "GEAR RATIO: 2.34 – 0.39" changes similarly to "STM STEP: 0 – 177" by "DATA MONITOR" mode. Refer to [TM-266. "CONSULT-III Function \(TRANSMISSION\)"](#).

ⓧ Without CONSULT-III

Inspect the engine speed (rise and descend), vehicle speed, throttle position, and check shift change. Refer to [TM-397. "Vehicle Speed When Shifting Gears"](#).

OK or NG

OK >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NG >> Replace the transaxle assembly. Refer to [TM-393. "Exploded View"](#).

SHIFT LOCK SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

SHIFT LOCK SYSTEM

Description


INFOID:000000000992228

The selector lever cannot be shifted from "P" position to any other position unless the ignition switch is in the ON position and the brake pedal is depressed.

Wiring Diagram

INFOID:000000000992229

CVT SHIFT LOCK SYSTEM (QR25DE)



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SHIFT LOCK SYSTEM

< COMPONENT DIAGNOSIS >

[CVT: RE0F10A]

- Selector lever can be moved from "P" position with ignition key in ON position and brake pedal released.

1. CHECK POWER SOURCE

1. Disconnect CVT device harness connector.
2. Turn ignition switch ON (Do not start engine).
3. Check voltage between CVT device harness connector M23 terminal 6 and ground.

Voltage:


Brake pedal depressed: Battery voltage

Brake pedal released: 0V

OK or NG

OK >> GO TO 4.

NG >> GO TO 2.



2. CHECK POWER SOURCE AT STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Turn ignition switch ON (Do not start engine).
4. Check voltage between stop lamp switch harness connector E38 terminal 3 and ground.

Voltage:


Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check the following items for damage, repair or replace damaged parts:

- 10A fuse [No. 3, located in the fuse block (J/B)].
- Harness for open between ignition switch and stop lamp switch harness connector.
- Ignition switch, refer to XX POWER SUPPLY ROUTING CIRCUIT.



3. CHECK STOP LAMP SWITCH


1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector E38.
3. Check continuity between stop lamp switch terminals 3 and 4.

| Condition | Continuity |
|-----------------------------------|------------|
| Manually depress stop lamp switch | YES |
| Stop lamp switch released | NO |

OK or NG

OK >> Adjust stop lamp switch. Refer to XX BRAKE PEDAL - ADJUSTMENT.

NG >> Replace stop lamp switch.



4. CHECK GROUND CIRCUIT

SHIFT LOCK SYSTEM

[CVT: RE0F10A]


< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between CVT device harness connector M23 terminal 6 and ground.

Continuity should exist.

OK or NG

- OK >> Replace shift lock solenoid and park position switch assembly.
- NG >> Repair open circuit in harness or connectors.



ECU DIAGNOSIS

TCM

Reference Value

INFOID:000000000992231

VALUES ON THE DIAGNOSIS TOOL

| Item name | Condition | Display value (Approx.) |
|----------------|--|---|
| VSP SENSOR | During driving | Approximately matches the speedometer reading. |
| ESTM VSP SIG* | During driving | Approximately matches the speedometer reading. |
| PRI SPEED SEN | During driving (lock-up ON) | Approximately matches the engine speed. |
| ENG SPEED SIG | Engine running | Closely matches the tachometer reading. |
| SEC HYDR SEN | "N" position idle | 1.0 V |
| PRI HYDR SEN | "N" position idle | 0.7 - 3.5 V |
| ATF TEMP SEN | When CVT fluid temperature is 20°C (68°F) | 2.0 V |
| | When CVT fluid temperature is 80°C (176°F) | 1.0 V |
| VIGN SEN | Ignition switch: ON | Battery voltage |
| VEHICLE SPEED | During driving | Approximately matches the speedometer reading. |
| PRI SPEED | During driving (lock-up ON) | Approximately matches the engine speed. |
| SEC SPEED | During driving | 45 X Approximately matches the speedometer reading. |
| ENG SPEED | Engine running | Closely matches the tachometer reading. |
| GEAR RATIO | During driving | 2.34 - 0.39 |
| ACC PEDAL OPEN | Released accelerator pedal - Fully depressed accelerator pedal | 0.0/8 - 8.0/8 |
| SEC PRESS | "N" position idle | 1.3 MPa |
| PRI PRESS | "N" position idle | 0.6 - 0.8 MPa |
| STM STEP | During driving | 0 step – 177 step |
| ISOLT1 | Lock-up "OFF" | 0.0 A |
| | Lock-up "ON" | 0.7 A |
| ISOLT2 | Release your foot from the accelerator pedal. | 0.8 A |
| | Press the accelerator pedal all the way down. | 0.0 A |
| ISOLT3 | Secondary pressure low - Secondary pressure high | 0.8 - 0.0 A |
| SOLMON1 | Lock-up "OFF" | 0.0 A |
| | Lock-up "ON" | 0.7 A |
| SOLMON2 | "N" position idle | 0.8 A |
| | When stalled | 0.3 - 0.6 A |
| SOLMON3 | "N" position idle | 0.6 - 0.7 A |
| | When stalled | 0.4 - 0.6 A |
| P POSITION SW | Selector lever in "P" position | ON |
| | When setting selector lever to other positions. | OFF |
| R POSITION SW | Selector lever in "R" position | ON |
| | When setting selector lever to other positions. | OFF |
| N POSITION SW | Selector lever in "N" position | ON |
| | When setting selector lever to other positions. | OFF |

TCM


< ECU DIAGNOSIS >

[CVT: RE0F10A]

| Item name | Condition | Display value (Approx.) |
|---------------|---|-------------------------|
| D POSITION SW | Selector lever in "D" position | ON |
| | When setting selector lever to other positions. | OFF |
| BRAKE SW | Depressed brake pedal | ON |
| | Released brake pedal | OFF |
| FULL SW | Fully depressed accelerator pedal | ON |
| | Released accelerator pedal | OFF |
| IDLE SW | Released accelerator pedal | ON |
| | Fully depressed accelerator pedal | OFF |
| INDDRNG | Selector lever in "D" position | ON |
| | When setting selector lever to other positions. | OFF |
| INDNRNG | Selector lever in "N" position | ON |
| | When setting selector lever to other positions. | OFF |
| INDRRNG | Selector lever in "R" position | ON |
| | When setting selector lever to other positions. | OFF |
| INDPRNG | Selector lever in "P" position | ON |
| | When setting selector lever to other positions. | OFF |
| SMCOIL D | During driving | Changes ON ⇔ OFF. |
| SMCOIL C | During driving | Changes ON ⇔ OFF. |
| SMCOIL B | During driving | Changes ON ⇔ OFF. |
| SMCOIL A | During driving | Changes ON ⇔ OFF. |
| LUSEL SOL OUT | Selector lever in "P", "N" positions | ON |
| | Wait at least for 5 seconds with the selector lever in "R", "D" position | OFF |
| LUSEL SOL MON | Selector lever in "P", "N" positions | ON |
| | Wait at least for 5 seconds with the selector lever in "R", "D" or position | OFF |
| ABS ON* | ABS operate | ON |
| | Other conditions | OFF |
| RANGE | Selector lever in "N" or "P" position | N-P |
| | Selector lever in "R" position | R |
| | Selector lever in "D" position | D |
| DOWNLVR | Selector lever: - side | ON |
| | Other than the above | OFF |
| UPLVR | Selector lever: + side | ON |
| | Other than the above | OFF |
| NONMMODE | Manual shift gate position (neutral, +side, -side) | OFF |
| | Other than the above | ON |
| MMODE | Manual shift gate position (neutral) | ON |
| | Other than the above | OFF |
| M GEAR POS | During driving | 1, 2, 3, 4, 5, 6 |

*: Models without ABS does not indicate.

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|--------|------------------------------|--------------|--|---|
| + | - | Signal name | Input/Output | | |
| 1 (P/B) | Ground | R RANGE SW | Output | Ignition switch ON | Battery voltage |
| | | | | Selector lever in "R" position | 0 V |
| 2 (P/L) | Ground | N RANGE SW | Output | Ignition switch ON | Battery voltage |
| | | | | Selector lever in "N" position | 0 V |
| 3 (G/O) | Ground | D RANGE SW | Output | Ignition switch ON | Battery voltage |
| | | | | Selector lever in "D" positions | 0 V |
| 4 (GR) | Ground | L RANGE SW | Output | Ignition switch ON | Battery voltage |
| | | | | Selector lever in "L" position | 0 V |
| 5 (B) | Ground | Ground | Output | Always | 0 V |
| 6 (O) | Ground | K-LINE | Input/Output | — | — |
| 7 (W) | Ground | Sensor ground | Input | Always | 0 V |
| 8 (G/W) | — | CLOCK | — | — | — |
| 9 (L/R) | — | CHIP SELECT | — | — | — |
| 10 (BR/R) | — | DATA I/O | — | — | — |
| 11 (BR/W) | Ground | P RANGE SW | Output | Ignition switch ON | Battery voltage |
| | | | | Selector lever in "P" position | 0 V |
| 13 (V) | Ground | CVT fluid temperature sensor | Output | Ignition switch ON | When CVT fluid temperature is 20°C (68°F) |
| | | | | When CVT fluid temperature is 80°C (176°F) | 2.0 V |
| | | | | | 1.0 V |

TCM

< ECU DIAGNOSIS >

[CVT: RE0F10A]

| Terminal No. | | Description | | Condition | | Value (Approx.) |
|--------------|--------|---|--------------|---|--|-----------------|
| + | - | Signal name | Input/Output | | | |
| 14 (LG) | Ground | Transmission fluid pressure sensor B (Primary pressure sensor) | Input | "N" position idle | | 0.7 – 3.5 V |
| 15 (V/W) | Ground | Transmission fluid pressure sensor A (Secondary pressure sensor) | Input | | | 1.0 V |
| 25 (W/R) | Ground | Sensor ground | Input | Always | | 0 V |
| 26 (L/O) | Ground | Sensor power | Input | Ignition switch ON | — | 5.0 V |
| | | | | Ignition switch OFF | — | 0 V |
| 27 (R/G) | Ground | Step motor D | Input | Within 2 seconds after ignition switch ON, the time measurement by using the pulse width measurement function (Hi level) of CONSULT-III.* ¹ CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. | | 10.0 msec |
| 28 (R) | Ground | Step motor C | Input | | | 30.0 msec |
| 29 (O/B) | Ground | Step motor B | Input | | | 10.0 msec |
| 30 (G/R) | Ground | Step motor A | Input | | | 30.0 msec |
| 31 (P) | — | CAN-L | Input/Output | — | | — |
| 32 (L) | — | CAN-H | Input/Output | — | | — |
| 33 (LG/W) | Ground | Input speed sensor (Primary speed sensor) | Input | When driving ["M1" position, 20 km/h (12 MPH)] | | 610 Hz |
| 34 (LG/R) | Ground | Output speed sensor (Secondary speed sensor) | Input | When driving ["D" position, 20 km/h (12 MPH)] | | 480 Hz |
| 37 (L/W) | Ground | Lock-up select solenoid valve | Output | Ignition switch ON | Selector lever in "P" or "N" positions | Battery voltage |
| | | | | | Wait at least for 5 seconds with the selector lever in "R" or "D" positions. | 0 V |
| 38 (G) | Ground | Torque converter clutch solenoid valve | Output | When vehicle cruises in "D" position | When CVT performs lock-up | 6.0 V |
| | | | | | When CVT does not perform lock-up | 1.0 V |
| 39 (W/B) | Ground | Pressure control solenoid valve B (Secondary pressure solenoid valve) | Output | "P" or "N" position idle | Release your foot from the accelerator pedal. | 5.0 – 7.0 V |
| | | | | | Press the accelerator pedal all the way down. | 3.0 – 4.0 V |
| 40 (R/Y) | Ground | Pressure control solenoid valve A (Line pressure solenoid valve) | Output | | Release your foot from the accelerator pedal. | 5.0 – 7.0 V |
| | | | | | Press the accelerator pedal all the way down. | 1.0 – 3.0 V |
| 42 (B) | Ground | Ground | Output | Always | | 0 V |
| 45 (L/R) | Ground | Power supply (memory back-up) | Input | Always | | Battery voltage |
| 46 (Y) | Ground | Power supply | Input | Ignition switch ON | — | Battery voltage |
| | | | | Ignition switch OFF | — | 0 V |
| 47 (L/R) | Ground | Power supply (memory back-up) | Input | Always | | Battery voltage |


< ECU DIAGNOSIS >

| Terminal No. | | Description | | Condition | | Value (Approx.) |
|--------------|--------|--------------|--------------|---------------------|---|-----------------|
| + | - | Signal name | Input/Output | | | |
| 48 (Y) | Ground | Power supply | Input | Ignition switch ON | — | Battery voltage |
| | | | | Ignition switch OFF | — | 0 V |

*1: A circuit tester cannot be used to test this item.

Wiring Diagram — CVT CONTROL SYSTEM —

INFOID:000000000992232




ALDWA0001GE

A
B
C

TM

E
F
G
H
I
J
K
L
M
N
O
P


--- : DATA LINE



ALDWA0002GE


CVT CONTROL SYSTEM (QR25DE) CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 8G | P | - |
| 13G | O | - |
| 15G | L | - |
| 51G | L | - |
| 52G | P | - |

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 2N | G | - |

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 3Q | O/L | - |
| 6Q | Y/R | - |

| | |
|-----------------|------------------|
| Connector No. | M5 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 12M | P | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------------|
| 26 | O/L | STOP_LAMP_HIGH_SW |

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B | GND |
| 5 | B | GND |
| 6 | L | CAN-H |
| 7 | O | K-LINE |
| 8 | G | IGN_SW |
| 14 | P | CAN-L |
| 16 | Y/R | BATT |

| | |
|-----------------|---------------------------|
| Connector No. | M21 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 132 | R | ST_CONT_USM |


| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 78 | P | CAN-L |
| 79 | L | CAN-H |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|---------------|
| 1 | W/L | BAT |
| 2 | O | IGN |
| 3 | B | GND |
| 14 | V/Y | ACC |
| 21 | L | CAN-H |
| 22 | P | CAN-L |
| 23 | B | GND |
| 37 | G | NOT M RANGE |
| 38 | BR | AT SHIFT DOWN |
| 39 | W | AT SHIFT UP |
| 40 | LG/R | M RANGE |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |




| | |
|-----------------|------------|
| Connector No. | M23 |
| Connector Name | CVT DEVICE |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG/R | MT_MODE |
| 2 | BR | M_DOWN |
| 3 | W | M_UP |
| 4 | B | GND |
| 5 | G | AT_MODE |

| | |
|-----------------|-------|
| Connector No. | E10 |
| Connector Name | ECM |
| Connector Color | BLACK |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 97 | P | CAN-L |
| 98 | L | CAN-H |

| | |
|-----------------|------------------|
| Connector No. | E6 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1P | SB | - |
| 4P | G/R | - |
| 6P | Y | - |
| 8P | Y/R | - |
| 12P | L/R | - |

| | |
|-----------------|--------------|
| Connector No. | E3 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | G/B | - |
| 6 | L/R | - |
| 8 | P | - |
| 14 | B | - |
| 15 | O | - |

| | |
|-----------------|---------------------|
| Connector No. | E22 |
| Connector Name | JOINT CONNECTOR-E04 |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 2 | P | - |
| 3 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | E21 |
| Connector Name | JOINT CONNECTOR-E03 |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 2 | L | - |
| 3 | L | - |

| | |
|-----------------|--|
| Connector No. | E17 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 41 | B | S-GND |
| 46 | R | START_CONT |

ALDIA0003GB


| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y/R | - |
| 2 | R/G | - |
| 3 | G/R | - |
| 4 | R/W | - |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 8G | P | - |
| 13G | O | - |
| 15G | L | - |
| 51G | L | - |
| 52G | P | - |

| | |
|-----------------|--------------|
| Connector No. | E30 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|--------------|
| Connector No. | F1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|----------------|
| Connector No. | E50 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| | |
|-----------------|----------------|
| Connector No. | E46 |
| Connector Name | JUNCTION BLOCK |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 4 | G/B | - |
| 6 | L/R | - |
| 8 | P | - |
| 14 | B | - |
| 15 | O | - |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 56 | O | - |


| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 31 | O | - |

| | |
|-----------------|----------------------|
| Connector No. | F8 |
| Connector Name | PRIMARY SPEED SENSOR |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|------------------|
| 1 | W/R | SENSOR_GND |
| 2 | LG/W | PRI_SPEED_SENSOR |
| 3 | Y | VIGN |

| | |
|-----------------|--|
| Connector No. | F10 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|---------------|
| 58 | Y | AT_ECU |
| 72 | R/B | NPSW |
| 74 | Y | START_I_G_EGI |
| 80 | B/W | STARTER_MOTOR |

| | |
|-----------------|-----------------------------------|
| Connector No. | F16 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | P/B | R RANGE SW |
| 2 | P/L | N RANGE SW |
| 3 | G/O | D RANGE SW |
| 4 | GR | L RANGE SW |
| 5 | B | GND |
| 6 | O | K-LINE |
| 7 | W | SENSOR GND |
| 8 | GW | CLOCK (SEL2) |
| 9 | L/R | CHIP SELECT (SEL1) |
| 10 | BR/R | DATA I/O (SEL3) |
| 11 | BR/W | P RANGE SW |
| 13 | V | ATF TEMP SENS |
| 14 | LG | PRI OIL PRESS SENS |
| 15 | V/W | SEC OIL PRESS SENS |
| 25 | W/R | SENSOR GND |
| 26 | L/O | SENS POWER SOURCE |
| 27 | R/G | S/M-D |

| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-----------------------|
| 28 | R | S/M-C |
| 29 | O/B | S/M-B |
| 30 | G/R | S/M-A |
| 31 | P | CAN-L |
| 32 | L | CAN-H |
| 33 | LG/W | PRI SPEED SENSOR |
| 34 | LG/R | SEC SPEED SENSOR |
| 37 | L/W | L/U&SELECT-ON/OFF SOL |
| 38 | G | L/U&SELECT-LINER SOL |
| 39 | W/B | SEC LINER SOL |
| 40 | R/Y | PL LINER SOL |
| 42 | B | GND |
| 45 | L/R | BATT |
| 46 | Y | VIGN |
| 47 | L/R | BATT |
| 48 | Y | VIGN |


ALDIA0005GB

| | |
|-----------------|------------------------|
| Connector No. | F23 |
| Connector Name | SECONDARY SPEED SENSOR |
| Connector Color | WHITE |




| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|------------------|
| 1 | W | SENSOR_GND |
| 2 | LG/R | SEC_SPEED_SENSOR |
| 3 | Y | VIGN |

| | |
|-----------------|------------------------------------|
| Connector No. | F25 |
| Connector Name | PARK/NEUTRAL POSITION (PNP) SWITCH |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | IGN_P_N |
| 2 | R/B | P_N_OUTPUT |
| 3 | O | IGN |
| 4 | BR/W | P_OUTPUT |
| 5 | P/B | R_OUTPUT |
| 6 | P/L | N_OUTPUT |
| 7 | G/O | D_OUTPUT |
| 8 | G/R | L_OUTPUT |


| | |
|-----------------|----------|
| Connector No. | F46 |
| Connector Name | CVT UNIT |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | L/R | CHIP_SELECT_(SEL1) |
| 2 | R/Y | PL_LINEAR_SOL |
| 3 | W/B | SEC_LINEAR_SOL |
| 6 | G/R | S/M-A |


| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------------------|
| 7 | O/B | S/M-B |
| 8 | R/Y | S/M-C |
| 9 | R/G | S/M-D |
| 11 | G/W | CLOCK_(SEL2) |
| 12 | G | L/U&SELECT-LINEAR_SOL |
| 13 | L/W | L/U&SELECT-ON/OFF_SOL |
| 16 | BR/R | DATA_I/O_(SEL3) |
| 17 | V | ATF_TEMP_SENSOR |
| 19 | W/R | SENSOR_GND |
| 20 | L/O | SENSOR_POWER_SOURCE |
| 23 | V/W | SEC_OIL_PRESSURE_SENSOR |
| 25 | LG | PRI_OIL_PRESSURE_SENSOR |

| | |
|-----------------|---------------------|
| Connector No. | F48 |
| Connector Name | JOINT-CONNECTOR-F02 |
| Connector Color | BLACK |



| Terminal No. | Color of wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L/R | - |
| 2 | L/R | - |
| 3 | Y | - |
| 4 | Y | - |
| 5 | Y | - |
| 6 | L/R | - |
| 9 | Y | - |
| 10 | Y | - |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P



Fail-safe

The TCM has an electrical fail-safe mode. This mode makes it possible to operate even if there is an error in a main electronic control input/output signal circuit.

FAIL-SAFE FUNCTION

If any malfunction occurs in a sensor or solenoid, this function controls the CVT to make driving possible.

Output Speed Sensor (Secondary Speed Sensor)

ALDIA0056GB

INFOID:000000000992233

The shift pattern is changed in accordance with throttle position when an unexpected signal is sent from the output speed sensor (secondary speed sensor) to the TCM. The manual mode position is inhibited, and the transaxle is put in “D”.

Input Speed Sensor (Primary Speed Sensor)

The shift pattern is changed in accordance with throttle position and secondary speed (vehicle speed) when an unexpected signal is sent from the input speed sensor (primary speed sensor) to the TCM. The manual mode position is inhibited, and the transaxle is put in “D”.

PNP Switch

If an unexpected signal is sent from the PNP switch to the TCM, the transaxle is put in “D”.

Manual Mode Switch

If an unexpected signal is sent from the manual mode switch to the TCM, the transaxle is put in “D”.

CVT Fluid Temperature Sensor

If an unexpected signal is sent from the CVT fluid temperature sensor to the TCM, the gear ratio in use before receiving the unexpected signal is maintained or the gear ratio is controlled to keep engine speed under 3,400 rpm.

Transmission Fluid Pressure Sensor A (Secondary Pressure Sensor)

- If an unexpected signal is sent from the transmission fluid pressure sensor A (secondary pressure sensor) to the TCM, the secondary pressure feedback control is stopped and the offset value obtained before the non-standard condition occurs is used to control line pressure.
- If transmission fluid pressure sensor A (secondary pressure sensor) error signal is input to TCM, secondary pressure feedback control stops, but line pressure is controlled normally.

Pressure Control Solenoid A (Line Pressure Solenoid)

If an unexpected signal is sent from the solenoid to the TCM, the pressure control solenoid A (line pressure solenoid) is turned OFF to achieve the maximum fluid pressure.

Pressure Control Solenoid B (Secondary Pressure Solenoid)

If an unexpected signal is sent from the solenoid to the TCM, the pressure control solenoid B (secondary pressure solenoid) is turned OFF to achieve the maximum fluid pressure.

Torque Converter Clutch Solenoid

If an unexpected signal is sent from the solenoid to the TCM, the torque converter clutch solenoid is turned OFF to cancel the lock-up.

Step Motor

If an unexpected signal is sent from the step motor to the TCM, the step motor coil phases “A” through “D” are all turned OFF to hold the gear ratio used right before the non-standard condition occurred.

CVT Lock-up Select Solenoid

If an unexpected signal is sent from the solenoid to the TCM, the CVT lock-up select solenoid is turned OFF to cancel the lock-up.

TCM Power Supply (Memory Back-up)

Transaxle assembly is protected by limiting the engine torque when the memory back-up power supply (for controlling) from the battery is not supplied to TCM. Normal statues is restored when turning the ignition switch OFF to ON after the normal power supply.

DTC Inspection Priority Chart

INFOID:000000000992234

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

NOTE:

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [TM-272](#).

| Priority | Detected items (DTC) |
|----------|------------------------------|
| 1 | U1000 CAN communication line |
| 2 | Except above |

DTC Index

INFOID:000000000992235

TCM

< ECU DIAGNOSIS >

[CVT: RE0F10A]

NOTE:

If DTC “U1000 CAN COMM CIRCUIT” is displayed with other DTCs, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [TM-272](#).

| DTC | | Items (CONSULT-III screen terms) | Reference page |
|----------------------|------------------------------------|-------------------------------------|------------------------|
| OBD-II | Except OBD-II | | |
| CONSULT-III GST*1 | CONSULT-III only “TRANSMISSION” | | |
| — | P0703 | BRAKE SW/CIRC | TM-274 |
| P0705 | P0705 | PNP SW/CIRC | TM-276 |
| P0710 | P0710 | ATF TEMP SEN/CIRC | TM-279 |
| P0715 | P0715 | INPUT SPD SEN/CIRC | TM-281 |
| P0720 | P0720 | VEH SPD SEN/CIR AT | TM-284 |
| — | P0725 | ENGINE SPEED SIG | TM-287 |
| — | P0730 | BELT DAMG | TM-289 |
| P0740 | P0740 | TCC SOLENOID/CIRC | TM-291 |
| P0744 | P0744 | A/T TCC S/V FNCTN | TM-293 |
| P0745 | P0745 | L/PRESS SOL/CIRC | TM-295 |
| P0746 | P0746 | PRS CNT SOL/A FCTN | TM-297 |
| P0776 | P0776 | PRS CNT SOL/B FCTN | TM-299 |
| P0778 | P0778 | PRS CNT SOL/B CIRC | TM-301 |
| — | P0826 | MANUAL MODE SWITCH | TM-303 |
| P0840 | P0840 | TR PRS SENS/A CIRC | TM-306 |
| — | P0841 | PRESS SEN/FNCTN | TM-308 |
| P0845 | P0845 | TR PRS SENS/B CIRC | TM-310 |
| — | P0868 | SEC/PRESS DOWN | TM-312 |
| — | P1701 | TCM-POWER SUPPLY | TM-314 |
| — | P1705 | TP SEN/CIRC A/T | TM-316 |
| — | P1722*2 | ESTM VEH SPD SIG | TM-318 |
| — | P1723 | CVT SPD SEN/FNCTN | TM-320 |
| — | P1726 | ELEC TH CONTROL | TM-322 |
| P1740 | P1740 | LU-SLCT SOL/CIRC | TM-323 |
| — | P1745 | L/PRESS CONTROL | TM-325 |
| P1777 | P1777 | STEP MOTR CIRC | TM-326 |
| P1778 | P1778 | STEP MOTR/FNC | TM-329 |
| U1000 | U1000 | CAN COMM CIRCUIT | TM-272 |
| U1010 | U1010 | CONTROL UNIT(CAN) | TM-273 |

*1: These numbers are prescribed by SAE J2012.

*2: Models without ABS does not indicate.

SYMPTOM DIAGNOSIS

SYSTEM SYMPTOM

Symptom Table

INFOID:000000000992236

The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------------|-------------------------------------|------------------|---|--|
| 1 | | Large shock. ("N"→ "D" position) | ON vehicle | 1. Engine idle speed | EC-536 (For califor- nia), EC-1051 (Ex- cept for california) |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. Accelerator pedal position sensor | TM-316 |
| | | | | 4. CVT position | TM-381 |
| | | | | 5. CVT fluid temperature sensor | TM-279 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. CVT fluid level and state | TM-368 |
| | | | | 8. Line pressure test | TM-375 |
| | | | | 9. Torque converter clutch solenoid valve | TM-291 |
| | | | | 10. Lock-up select solenoid valve | TM-323 |
| | | | | 11. PNP switch | TM-276 |
| | | | OFF vehi- cle | 12. Forward clutch | TM-393 |
| | | | | 13. Control valve | |
| 2 | Shift Shock | Large shock. ("N"→ "R" position) | ON vehicle | 1. Engine idle speed | EC-536 (For califor- nia), EC-1051 (Ex- cept for california) |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. Accelerator pedal position sensor | TM-316 |
| | | | | 4. CVT position | TM-381 |
| | | | | 5. CVT fluid temperature sensor | TM-279 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. CVT fluid level and state | TM-368 |
| | | | | 8. Line pressure test | TM-375 |
| | | | | 9. Torque converter clutch solenoid valve | TM-291 |
| | | | | 10. Lock-up select solenoid valve | TM-323 |
| | | | | 11. PNP switch | TM-276 |
| | | | OFF vehi- cle | 12. Reverse brake | TM-393 |
| | | | | 13. Control valve | |
| 3 | | Shock is too large for lock-up. | ON vehicle | 1. CVT position | TM-381 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. CAN communication line | TM-272 |
| | | | | 4. CVT fluid level and state | TM-368 |
| | | | OFF vehi- cle | 5. Torque converter | TM-393 |
| | | | | 6. Control valve | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|--------------------------------------|------------------------|
| 4 | Slips/Will Not Engage | Vehicle cannot be started from "D" position. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. CVT position | TM-381 |
| | | | | 3. CAN communication line | TM-272 |
| | | | | 4. Line pressure test | TM-375 |
| | | | | 5. Stall test | TM-373 |
| | | | | 6. Step motor | TM-326 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Accelerator pedal position sensor | TM-316 |
| | | | | 10. CVT fluid temperature sensor | TM-279 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Oil pump assembly | TM-393 |
| | | | | 14. Forward clutch | |
| | | | | 15. Control valve | |
| | | | | 16. Parking components | |
| 5 | Slips/Will Not Engage | Vehicle cannot be started from "R" position. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. CVT position | TM-381 |
| | | | | 3. CAN communication line | TM-272 |
| | | | | 4. Line pressure test | TM-375 |
| | | | | 5. Stall test | TM-373 |
| | | | | 6. Step motor | TM-326 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Accelerator pedal position sensor | TM-316 |
| | | | | 10. CVT fluid temperature sensor | TM-279 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Oil pump assembly | TM-393 |
| | | | | 14. Reverse brake | |
| | | | | 15. Control valve | |
| | | | | 16. Parking components | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|----------------------------------|-------------|---|------------------------|
| 6 | Slips/Will Not Engage | Does not lock-up. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Engine speed signal | TM-287 |
| | | | | 4. Primary speed sensor | TM-281 |
| | | | | 5. Torque converter clutch solenoid valve | TM-291 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Stall test | TM-373 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. PNP switch | TM-276 |
| | | | | 10. Lock-up select solenoid valve | TM-323 |
| | | | | 11. CVT fluid temperature sensor | TM-279 |
| | | | | 12. Secondary speed sensor | TM-284 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-393 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |
| 7 | Slips/Will Not Engage | Does not hold lock-up condition. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Engine speed signal | TM-287 |
| | | | | 4. Primary speed sensor | TM-281 |
| | | | | 5. Torque converter clutch solenoid valve | TM-291 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Stall test | TM-373 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. PNP switch | TM-276 |
| | | | | 10. Lock-up select solenoid valve | TM-323 |
| | | | | 11. CVT fluid temperature sensor | TM-279 |
| | | | | 12. Secondary speed sensor | TM-284 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-393 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|---|------------------------|
| 8 | | Lock-up is not released. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Engine speed signal | TM-287 |
| | | | | 4. Primary speed sensor | TM-281 |
| | | | | 5. Torque converter clutch solenoid valve | TM-291 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Stall test | TM-373 |
| | | | OFF vehicle | 8. Torque converter | TM-393 |
| | | | | 9. Oil pump assembly | |
| | | | | 10. Control valve | |
| 9 | Slips/Will Not Engage | With selector lever in "D" position, acceleration is extremely poor. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Stall test | TM-373 |
| | | | | 4. Accelerator pedal position sensor | TM-316 |
| | | | | 5. CAN communication line | TM-272 |
| | | | | 6. PNP switch | TM-276 |
| | | | | 7. CVT position | TM-381 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. Primary speed sensor | TM-281 |
| | | | | 10. Secondary speed sensor | TM-284 |
| | | | | 11. Accelerator pedal position sensor | TM-316 |
| | | | | 12. Primary pressure sensor | TM-156 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | | 14. CVT fluid temperature sensor | TM-279 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-393 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Forward clutch | |
| | | | | 19. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-----------------------|--|-------------|---|------------------------|
| 10 | Slips/Will Not Engage | With selector lever in "R" position, acceleration is extremely poor. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Stall test | TM-373 |
| | | | | 4. Accelerator pedal position sensor | TM-316 |
| | | | | 5. CAN communication line | TM-272 |
| | | | | 6. PNP switch | TM-276 |
| | | | | 7. CVT position | TM-381 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. Primary speed sensor | TM-281 |
| | | | | 10. Secondary speed sensor | TM-284 |
| | | | | 11. Accelerator pedal position sensor | TM-316 |
| | | | | 12. Primary pressure sensor | TM-156 |
| | | | | 13. Secondary pressure sensor | TM-156 |
| | | | | 14. CVT fluid temperature sensor | TM-279 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-393 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Reverse brake | |
| | | | | 19. Control valve | |
| 11 | Slips at lock-up. | | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Engine speed signal | TM-287 |
| | | | | 4. Primary speed sensor | TM-281 |
| | | | | 5. Torque converter clutch solenoid valve | TM-291 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Stall test | TM-373 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. PNP switch | TM-276 |
| | | | | 10. Lock-up select solenoid valve | TM-323 |
| | | | | 11. CVT fluid temperature sensor | TM-279 |
| | | | | 12. Secondary speed sensor | TM-284 |
| | | | | 13. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 14. Torque converter | TM-393 |
| | | | | 15. Oil pump assembly | |
| | | | | 16. Control valve | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|--------------------------------------|-------------|---------------------------------------|------------------------|
| 12 | Other | No creep at all. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. Accelerator pedal position sensor | TM-316 |
| | | | | 4. PNP switch | TM-276 |
| | | | | 5. CAN communication line | TM-272 |
| | | | | 6. Stall test | TM-373 |
| | | | | 7. CVT position | TM-381 |
| | | | | 8. Step motor | TM-326 |
| | | | | 9. Primary speed sensor | TM-281 |
| | | | | 10. Secondary speed sensor | TM-284 |
| | | | | 11. Accelerator pedal position sensor | TM-316 |
| | | | | 12. CVT fluid temperature sensor | TM-279 |
| | | | | 13. Primary pressure sensor | TM-156 |
| | | | | 14. Secondary pressure sensor | TM-152 |
| | | | | 15. Power supply | TM-160 |
| | | | OFF vehicle | 16. Torque converter | TM-393 |
| | | | | 17. Oil pump assembly | |
| | | | | 18. Gear system | |
| | | | | 19. Forward clutch | |
| | | | | 20. Reverse brake | |
| | | | | 21. Control valve | |
| 13 | Other | Vehicle cannot run in all positions. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. PNP switch | TM-276 |
| | | | | 4. Stall test | TM-373 |
| | | | | 5. CVT position | TM-381 |
| | | | | 6. Step motor | TM-326 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Accelerator pedal position sensor | TM-316 |
| | | | | 10. CVT fluid temperature sensor | TM-279 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-393 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Forward clutch | |
| | | | | 17. Reverse brake | |
| | | | | 18. Control valve | |
| | | | | 19. Parking components | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|---|-------------|--------------------------------------|------------------------|
| 14 | Other | With selector lever in "D" position, driving is not possible. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. PNP switch | TM-276 |
| | | | | 4. Stall test | TM-373 |
| | | | | 5. CVT position | TM-381 |
| | | | | 6. Step motor | TM-326 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Accelerator pedal position sensor | TM-316 |
| | | | | 10. CVT fluid temperature sensor | TM-279 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-393 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Forward clutch | |
| | | | | 17. Control valve | |
| | | | | 18. Parking components | |
| 15 | Other | With selector lever in "R" position, driving is not possible. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Line pressure test | TM-375 |
| | | | | 3. PNP switch | TM-276 |
| | | | | 4. Stall test | TM-373 |
| | | | | 5. CVT position | TM-381 |
| | | | | 6. Step motor | TM-326 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Accelerator pedal position sensor | TM-316 |
| | | | | 10. CVT fluid temperature sensor | TM-279 |
| | | | | 11. Secondary pressure sensor | TM-152 |
| | | | | 12. Power supply | TM-160 |
| | | | OFF vehicle | 13. Torque converter | TM-393 |
| | | | | 14. Oil pump assembly | |
| | | | | 15. Gear system | |
| | | | | 16. Reverse brake | |
| | | | | 17. Control valve | |
| | | | | 18. Parking components | |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|--------------------------------|-------------|---|------------------------|
| 16 | Other | Judder occurs during lock-up. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. Primary speed sensor | TM-281 |
| | | | | 4. Secondary speed sensor | TM-284 |
| | | | | 5. Accelerator pedal position sensor | TM-316 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Torque converter clutch solenoid valve | TM-291 |
| | | | OFF vehicle | 8. Torque converter | TM-393 |
| | | | | 9. Control valve | |
| 17 | Other | Strange noise in "D" position. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. CAN communication line | TM-272 |
| | | | OFF vehicle | 4. Torque converter | TM-393 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Forward clutch | |
| | | | | 8. Control valve | |
| | | | | 9. Bearing | |
| 18 | Other | Strange noise in "R" position. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. CAN communication line | TM-272 |
| | | | OFF vehicle | 4. Torque converter | TM-393 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Reverse brake | |
| | | | | 8. Control valve | |
| | | | | | |
| 19 | Other | Strange noise in "N" position. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. CAN communication line | TM-272 |
| | | | OFF vehicle | 4. Torque converter | TM-393 |
| | | | | 5. Oil pump assembly | |
| | | | | 6. Gear system | |
| | | | | 7. Control valve | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page | | |
|-----|-------|--|--|--------------------------------------|------------------------------|------------------------|---|
| 20 | | Vehicle does not decelerate by engine brake. | ON vehicle | 1. CVT fluid level and state | TM-368 | A | |
| | | | | 2. CVT position | TM-381 | B | |
| | | | | 3. CAN communication line | TM-272 | | |
| | | | | 4. Step motor | TM-326 | | |
| | | | | 5. Primary speed sensor | TM-281 | C | |
| | | | | 6. Secondary speed sensor | TM-284 | | |
| | | | | 7. Line pressure test | TM-375 | | |
| | | | | 8. Engine speed signal | TM-287 | TM | |
| | | | | 9. Accelerator pedal position sensor | TM-316 | | |
| | | | | OFF vehicle | 10. Control valve | TM-393 | E |
| 21 | Other | Maximum speed low. | ON vehicle | 1. CVT fluid level and state | TM-368 | | |
| | | | | 2. Line pressure test | TM-375 | F | |
| | | | | 3. Accelerator pedal position sensor | TM-316 | | |
| | | | | 4. CAN communication line | TM-272 | | |
| | | | | 5. Stall test | TM-373 | G | |
| | | | | 6. Step motor | TM-326 | | |
| | | | | 7. Primary speed sensor | TM-281 | H | |
| | | | | 8. Secondary speed sensor | TM-284 | | |
| | | | | 9. Primary pressure sensor | TM-156 | | |
| | | | | 10. Secondary pressure sensor | TM-152 | I | |
| | | | | 11. CVT fluid temperature sensor | TM-279 | | |
| | | | | OFF vehicle | 12. Torque converter | TM-393 | J |
| | | | | | 13. Oil pump assembly | | |
| | | | | | 14. Gear system | | |
| | | | | | 15. Forward clutch | | K |
| | | | | | 16. Control valve | | |
| 22 | | With selector lever in "P" position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled. | ON vehicle | 1. PNP switch | TM-276 | L | |
| | | | | 2. CVT position | TM-381 | | |
| | | | | OFF vehicle | 3. Parking components | TM-393 | M |
| 23 | | | Vehicle runs with CVT in "P" position. | ON vehicle | 1. PNP switch | TM-276 | N |
| | | | | | 2. CVT fluid level and state | TM-368 | |
| | | | | | 3. CVT position | TM-381 | |
| | | | | OFF vehicle | 4. Parking components | TM-393 | O |
| | | | | | 5. Gear system | | |
| | | | | | 6. Control valve | | P |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|---|-------------|---|------------------------|
| 24 | | Vehicle runs with CVT in "N" position. | ON vehicle | 1. PNP switch | TM-276 |
| | | | | 2. CVT fluid level and state | TM-368 |
| | | | | 3. CVT position | TM-381 |
| | | | OFF vehicle | 4. Gear system | TM-393 |
| | | | | 5. Forward clutch | |
| | | | | 6. Reverse brake | |
| | | | | 7. Control valve | |
| 25 | | Engine stall. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. Primary speed sensor | TM-281 |
| | | | | 4. Torque converter clutch solenoid valve | TM-291 |
| | | | | 5. CAN communication line | TM-272 |
| | | | | 6. Stall test | TM-373 |
| | | | | 7. Secondary pressure sensor | TM-152 |
| | | | OFF vehicle | 8. Torque converter | TM-393 |
| | | | | 9. Control valve | |
| 26 | Other | Engine stalls when selector lever shifted "N" → "D" or "R". | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Engine speed signal | TM-287 |
| | | | | 3. Primary speed sensor | TM-281 |
| | | | | 4. Torque converter clutch solenoid valve | TM-291 |
| | | | | 5. CAN communication line | TM-272 |
| | | | | 6. Stall test | TM-373 |
| | | | OFF vehicle | 7. Torque converter | TM-393 |
| | | | | 8. Control valve | |
| 27 | | Engine speed does not return to idle. | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. Accelerator pedal position sensor | TM-316 |
| | | | | 3. Secondary speed sensor | TM-284 |
| | | | | 4. CAN communication line | TM-272 |
| | | | OFF vehicle | 5. Control valve | TM-393 |
| 28 | | CVT does not shift | ON vehicle | 1. CVT fluid level and state | TM-368 |
| | | | | 2. CVT position | TM-381 |
| | | | | 3. Line pressure test | TM-375 |
| | | | | 4. Engine speed signal | TM-287 |
| | | | | 5. Accelerator pedal position sensor | TM-316 |
| | | | | 6. CAN communication line | TM-272 |
| | | | | 7. Primary speed sensor | TM-281 |
| | | | | 8. Secondary speed sensor | TM-284 |
| | | | | 9. Step motor | TM-326 |
| | | | OFF vehicle | 10. Control valve | TM-393 |
| | | | | 11. Oil pump assembly | |

SYSTEM SYMPTOM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10A]

| No. | Item | Symptom | Condition | Diagnostic Item | Reference page |
|-----|-------|---|------------|--------------------------------|---|
| 29 | Other | Engine does not start in "N" or "P" position. | ON vehicle | 1. Ignition switch and starter | STR-3 , STR-21 |
| | | | | 2. CVT position | TM-381 |
| | | | | 3. PNP switch | TM-276 |
| 30 | | Engine starts in positions other than "N" or "P". | ON vehicle | 1. Ignition switch and starter | STR-3 , STR-21 |
| | | | | 2. CVT position | TM-381 |
| | | | | 3. PNP switch | TM-276 |

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000000992237

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Procedure without Cowl Top Cover

INFOID:000000000992238

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000000992239

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NVIS/IVIS (NISSAN/INFINITI VEHICLE IMMOBILIZER SYSTEM - NATS).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-II to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NVIS/IVIS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

PRECAUTIONS

[CVT: RE0F10A]

< PRECAUTION >

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-II.

Precaution for On Board Diagnosis (OBD) System of CVT and Engine

INFOID:000000000992240

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EVAP system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Precaution for TCM and CVT Assembly Replacement

INFOID:000000000992241

CAUTION:

- Check if new data (Unit ID) are entered correctly after replacing CVT assembly and erasing data in TCM. (Connect CONSULT-III, and then turn ignition switch OFF.)
- When replacing CVT assembly or TCM, refer to the pattern table below and erase the EEPROM in the TCM if necessary.

EEPROM ERASING PATTERNS

| CVT assembly | TCM | Erasing EEPROM in TCM | Remarks |
|--------------|--------------|-----------------------|--|
| Replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. (CVT assembly must be replaced first.) |
| Not replaced | Replaced | Not required | Not required because the EEPROM in the TCM is in the default state. |
| Replaced | Not replaced | Required | Required because data has been written in the EEPROM in the TCM and because the TCM cannot write data from the ROM assembly in the transmission. |

Removal and Installation Procedure for CVT Unit Connector

INFOID:000000000992242


REMOVAL

PRECAUTIONS

[CVT: RE0F10A]


< PRECAUTION >

Rotate bayonet ring (1) counterclockwise, pull out CVT unit harness connector (2) upward and remove it.




INSTALLATION

1. Align Δ marking on CVT unit harness connector terminal body with \square marking on bayonet ring, insert CVT unit harness connector, and then rotate bayonet ring clockwise.




2. Rotate bayonet ring clockwise until Δ marking on CVT unit harness connector terminal body is aligned with the slit on bayonet ring as shown in the figure (correctly fitting condition), install CVT unit harness connector to CVT unit harness connector terminal body.



CAUTION:

- Securely align Δ marking on CVT unit harness connector terminal body with bayonet ring slit. Then, be careful not to make a half fit condition as shown in the figure.
- Do not mistake the slit of bayonet ring for other dent portion.



Precaution

INFOID:000000000992243

NOTE:


If any malfunction occurs in the RE0F09A model transaxle, replace the entire transaxle assembly.

PRECAUTIONS


[CVT: RE0F10A]

< PRECAUTION >


- Before connecting or disconnecting the TCM harness connector, turn ignition switch OFF and disconnect negative battery cable. Because battery voltage is applied to TCM even if ignition switch is turned OFF.




- When connecting or disconnecting pin connectors into or from TCM, take care not to damage pin terminals (bend or break).
When connecting pin connectors make sure that there are not any bends or breaks on TCM pin terminal.



- Before replacing TCM, perform TCM input/output signal inspection and make sure whether TCM functions properly or not. [TM-335. "Reference Value"](#).



- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure”.
If the repair is completed the DTC should not be displayed in the “DTC Confirmation Procedure”.
- Always use the specified brand of CVT fluid. Refer to [MA-11. "Fluids and Lubricants"](#).
- Use lint-free paper, not cloth rags, during work.
- After replacing the CVT fluid, dispose of the waste oil using the methods prescribed by law, ordinance, etc.



Service Notice or Precaution

INFOID:000000000992244

CVT FLUID COOLER SERVICE

If CVT fluid contains friction material (clutches, brakes, etc.), or if a CVT is replaced, inspect and clean the CVT fluid cooler mounted in the radiator or replace the radiator. Flush cooler lines using cleaning solvent and compressed air after repair. For CVT fluid cooler cleaning procedure, refer to [TM-370. "Cleaning"](#). For radiator replacement, refer to [CO-15. "Removal and Installation"](#).

OBD-II SELF-DIAGNOSIS

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

[CVT: RE0F10A]

- CVT self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the malfunction indicator lamp (MIL). Refer to the table on [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#) for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.

Always perform the procedure on [TM-264, "Diagnosis Description"](#) to complete the repair and avoid unnecessary blinking of the MIL.

For details of OBD-II, refer to [EC-619, "Diagnosis Description"](#) (for california), [EC-1141, "CONSULT-III Function"](#) (except for california).

- **Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-58](#).**

PREPARATION

< PREPARATION >

[CVT: RE0F10A]

PREPARATION

PREPARATION

Special Service Tool


INFOID:000000000992245

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|---|
| — (OTC3492) Oil pressure gauge set | Measuring line pressure |
| KV38100300 (—) Drift | Installing differential side oil seal a: ϕ 54 mm (2.13 in) b: ϕ 32 mm (1.26 in) |



SCIA7531E




ZZA1046D

Commercial Service Tool

INFOID:000000000992246

| Tool number Tool name | Description |
|--------------------------|--------------------------|
| Power tool | Loosening nuts and bolts |



PBIC0190E

ON-VEHICLE MAINTENANCE

CVT FLUID


Inspection

INFOID:000000000992247


CHECKING CVT FLUID

Fluid level should be checked with the fluid warmed up to 50 to 80°C (122 to 176°F). The fluid level check procedure is as follows:

1. Check for fluid leakage.
2. With the engine warmed up, drive the vehicle in an urban area. When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).
3. Park the vehicle on a level surface.
4. Apply parking brake firmly.
5. With engine at idle, while depressing brake pedal, move shift selector throughout the entire shift range.




6. Pull out the CVT fluid level gauge from the CVT fluid charging pipe after pressing the tab on the CVT fluid level gauge to release the lock.



7. Wipe fluid off the CVT fluid level gauge. Insert the CVT fluid level gauge rotating 180° from the originally installed position, then securely push the CVT fluid level gauge until it meets the top end of the CVT fluid charging pipe.

CAUTION:


When wiping away the CVT fluid level gauge, always use lint-free paper, not a cloth rag.



8. Place the selector lever in "P" or "N" and make sure the fluid level is within the specified range.

CAUTION:

When reinstalling CVT fluid level gauge, insert it into the CVT fluid charging pipe and rotate it to the original installation position until it is securely locked.



CVT FLUID CONDITION


CVT FLUID

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

Check CVT fluid condition.

- If CVT fluid is very dark or smells burned, check operation of CVT. Flush cooling system after repair of CVT.
- If CVT fluid contains frictional material (clutches, brakes, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of CVT. Refer to [CO-15. "Removal and Installation"](#) and [TM-370. "Cleaning"](#).



| Fluid status | Conceivable cause | Required operation |
|---------------------------------------|---|---|
| Varnished (viscous varnish state) | CVT fluid become degraded due to high temperatures. | Replace the CVT fluid and check the CVT main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.) |
| Milky white or cloudy | Water in the fluid | Replace the CVT fluid and check for places where water is getting in. |
| Large amount of metal powder mixed in | Unusual wear of sliding parts within CVT | Replace the CVT fluid and check for improper operation of the CVT. |

Changing

INFOID:000000000992248

1. Remove drain plug, and then drain CVT fluid from oil pan.
2. Install drain plug to oil pan.

CAUTION:

Do not reuse drain plug gasket.

 **34.3 N·m (3.5 kg·m, 25 ft·lb)**

3. Fill CVT fluid from CVT fluid charging pipe to the specified level.
4. With the engine warmed up, drive the vehicle in an urban area. When ambient temperature is 20°C (68°F), it takes about 10 minutes for the CVT fluid to warm up to 50 to 80°C (122 to 176°F).
5. Check CVT fluid level and condition.
6. Repeat steps 1 to 5 if CVT fluid has been contaminated.

CVT fluid:

Genuine NISSAN CVT Fluid NS-2

Fluid capacity:

Approx. 8.3 ℓ (7-1/4 Imp qt)

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-2. Do not mix with other fluid.
- Using CVT fluid other than Genuine NISSAN CVT Fluid NS-2 will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the warranty.
- When filling CVT fluid, take care not to scatter heat generating parts such as exhaust.
- Sufficiently shake the container of CVT fluid before using.
- Delete CVT fluid deterioration date with CONSULT-III after changing CVT fluid.

CVT FLUID COOLER SYSTEM

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

CVT FLUID COOLER SYSTEM

Cleaning

INFOID:000000000992249

Whenever an automatic transaxle is repaired, overhauled, or replaced, the CVT fluid cooler mounted in the radiator must be inspected and cleaned.

Metal debris and friction material, if present, can be trapped or become deposit in the CVT fluid cooler. This debris can contaminate the newly serviced CVT or, in severe cases, can block or restrict the flow of CVT fluid. In either case, malfunction of the newly serviced CVT may occur.

Debris, if present, may deposit as CVT fluid enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


CVT FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any CVT fluid that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.



7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and end of the cooler outlet hose.

9. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining CVT fluid.

10. Repeat steps 5 through 9 three additional times.

11. Position an oil pan under the banjo bolts that connect the CVT fluid cooler steel lines to the transaxle.


12. Remove the banjo bolts.

13. Flush each steel line from the cooler side back toward the transaxle by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.

14. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through each steel line from the cooler side back toward the transaxle for 10 seconds to force out any remaining CVT fluid.

15. Ensure all debris is removed from the steel cooler lines.

16. Ensure all debris is removed from the banjo bolts and fittings.



CVT FLUID COOLER SYSTEM

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

17. Perform "CVT FLUID COOLER DIAGNOSIS PROCEDURE".

CVT FLUID COOLER DIAGNOSIS PROCEDURE

NOTE:



Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.


CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.
5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.




6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose to force any remaining CVT fluid into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform "CVT FLUID COOLER INSPECTION PROCEDURE".



CVT FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
 - a. If small metal debris less than 1 mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the CVT fluid cooler/radiator can be re-used and the procedure is ended.




CVT FLUID COOLER SYSTEM

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

- b. If one or more pieces of debris are found that are over 1 mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the fluid cooler is not serviceable. The radiator/ fluid cooler must be replaced and the inspection procedure is ended.



CVT FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.


STALL TEST

Inspection and Judgment


INFOID:000000000992250

INSPECTION

1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of CVT fluid. Replenish if necessary.




3. Securely engage the parking brake so that the tires do not turn.
4. Install a tachometer where it can be seen by driver during test.
 - It is good practice to mark the point of specified engine rpm on indicator.
5. Start engine, apply foot brake, and place selector lever in “D” position.



6. While holding down the foot brake, gradually press down the accelerator pedal.
7. Quickly read off the stall speed, and then quickly remove your foot from the accelerator pedal.

CAUTION:
Do not hold down the accelerator pedal for more than 5 seconds during this test.



Stall speed: 2,500 – 3,000 rpm

8. Move the selector lever to the “N” position.
9. Cool down the CVT fluid.

CAUTION:
Run the engine at idle for at least 1 minute.
10. Repeat steps 6 through 9 with selector lever in “R” position.

JUDGMENT

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

STALL TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

| | Selector lever position | | Expected problem location |
|----------------|-------------------------|-----|--|
| | "D" | "R" | |
| Stall rotation | H | O | <ul style="list-style-type: none">• Forward clutch |
| | O | H | <ul style="list-style-type: none">• Reverse brake |
| | L | L | <ul style="list-style-type: none">• Engine and torque converter one-way clutch |
| | H | H | <ul style="list-style-type: none">• Line pressure low• Primary pulley• Secondary pulley• Steel belt |

O: Stall speed within standard value position.

H: Stall speed is higher than standard value.

L: Stall speed is lower than standard value.

LINE PRESSURE TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]


LINE PRESSURE TEST

Inspection and Judgment

INFOID:000000000992251

INSPECTION

Line Pressure Test Port (A)



Line Pressure Test Procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the CVT fluid reaches in the range of 50 to 80°C (122 to 176°F), then inspect the amount of CVT fluid and replenish if necessary.

NOTE:


The CVT fluid temperature rises in the range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.

3. After warming up CVT, remove the oil pressure detection plug and install the oil pressure gauge [special service tool: — (OTC3492)].

CAUTION:

When using the oil pressure gauge, be sure to use the O-ring attached to the oil pressure detection plug.

4. Securely engage the parking brake so that the tires do not turn.



5. Start the engine, and then measure the line pressure at both idle and the stall speed.

CAUTION:


- Keep the brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to "STALL TEST".

6. After the measurements are complete, install the oil pressure detection plug and tighten to the specified torque below.

 : 7.5 N·m (0.77 kg-m, 66 in-lb)

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid to O-ring.



Line Pressure

LINE PRESSURE TEST

< ON-VEHICLE MAINTENANCE >

[CVT: RE0F10A]

| Engine speed | Line pressure kPa (kg/cm ² , psi) |
|--------------|--|
| | “R”, “D” positions |
| At idle | 750 (7.65, 108.8) |
| At stall | 5,700 (58.14, 826.5)* ² |

*1: Without manual mode

*2: Reference values

JUDGMENT

| Judgment | Possible cause |
|-------------|---|
| Idle speed | <p>Low for all positions (“P”, “R”, “N”, “D”)</p> <p>Possible causes include malfunctions in the pressure supply system and low oil pump output. For example</p> <ul style="list-style-type: none"> • Oil pump wear • Pressure regulator valve or plug sticking or spring fatigue • Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak • Engine idle speed too low |
| | <p>Only low for a specific position</p> <p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p> |
| | <p>High</p> <p>Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • CVT fluid temperature sensor malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (sticking in OFF state, filter clog, cut line) • Pressure regulator valve or plug sticking |
| Stall speed | <p>Line pressure does not rise higher than the line pressure for idle.</p> <p>Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • TCM malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (shorting, sticking in ON state) • Pressure regulator valve or plug sticking |
| | <p>The pressure rises, but does not enter the standard position.</p> <p>Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> • Accelerator pedal position signal malfunction • Pressure control solenoid A (line pressure solenoid) malfunction (sticking, filter clog) • Pressure regulator valve or plug sticking |
| | <p>Only low for a specific position</p> <p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p> |


ROAD TEST

Description

INFOID:000000000992252

DESCRIPTION

- The purpose of the test is to determine overall performance of CVT and analyze causes of problems.
- The road test consists of the following three parts:
 1. "Check Before Engine Is Started" [TM-377](#).
 2. "Check at Idle" [TM-378](#).
 3. "Cruise Test" [TM-379](#).



- Before road test, familiarize yourself with all test procedures and items to check.
- Perform tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test.



CONSULT-III SETTING PROCEDURE

- Using CONSULT-III, perform a cruise test and record the result.
 - Print the result and ensure that shifts and lock-ups take place as per Shift Schedule.
1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
 2. Touch "MAIN SIGNALS" to set recording condition.
 3. See "Numerical Display", "Bar chart Display" or "Line Graph Display".
 4. Touch "START".
 5. When performing cruise test. Refer to [TM-379, "Cruise Test"](#).
 6. After finishing cruise test part, touch "RECORD".
 7. Touch "STORE".
 8. Touch "BACK".
 9. Touch "DISPLAY".
 10. Touch "PRINT".
 11. Check the monitor data printed out.

Check before Engine Is Started

INFOID:000000000992253

1. CHECK CVT INDICATOR LAMP

1. Park vehicle on flat surface.
2. Move selector lever to "P" position.
3. Turn ignition switch OFF. Wait at least 5 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Does shift position indicator come on for about 2 seconds?

- YES >>
1. Turn ignition switch OFF.
 2. Perform self-diagnosis and note NG items.
Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).
 3. Go to [TM-378, "Check at Idle"](#).

ROAD TEST

[CVT: RE0F10A]

< ON-VEHICLE MAINTENANCE >

NO >> Stop "Road Test". Refer to [TM-350. "Symptom Table"](#).

Check at Idle

INFOID:000000000992254

1.CHECK STARTING THE ENGINE

1. Park vehicle on flat surface.
2. Move selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Turn ignition switch to "START" position.

Is engine started?

YES >> GO TO 2..

NO >> Stop "Road Test". Refer to [TM-350. "Symptom Table"](#).

2.CHECK STARTING THE ENGINE

1. Turn ignition switch ON.
2. Move selector lever to "D", "M" or "R" position.
3. Turn ignition switch to "START" position.

Is engine started?

YES >> Stop "Road Test". Refer to [TM-350. "Symptom Table"](#).

NO >> GO TO 3..

3.CHECK "P" POSITION FUNCTION

1. Move selector lever to "P" position.
2. Turn ignition switch OFF.
3. Release parking brake.
4. Push vehicle forward or backward.
5. Apply parking brake.

Does vehicle move when it is pushed forward or backward?

YES >> Refer to [TM-350. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 4..

4.CHECK "N" POSITION FUNCTION

1. Start engine.
2. Move selector lever to "N" position.
3. Release parking brake.

Does vehicle move forward or backward?

YES >> Refer to [TM-350. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 5..

5.CHECK SHIFT SHOCK

1. Apply foot brake.
2. Move selector lever to "R" position.

Is there large shock when changing from "N" to "R" position?

YES >> Refer to [TM-350. "Symptom Table"](#). Continue "Road Test".

NO >> GO TO 6..

6.CHECK "R" POSITION FUNCTION

Release foot brake for several seconds.

Does vehicle creep backward when foot brake is released?

YES >> GO TO 7..

NO >> Refer to [TM-350. "Symptom Table"](#). Continue "Road Test".

7.CHECK "D" POSITION FUNCTION

Move selector lever to "D" position and check if vehicle creeps forward.

Does vehicle creep forward in all positions?

YES >> Go to [TM-379. "Cruise Test"](#).

NO >> Stop "Road Test". Refer to [TM-350. "Symptom Table"](#).

Cruise Test

1. CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 1

1. Drive vehicle for approximately 10 minutes to warm engine oil and CVT fluid up to operating temperature.


CVT fluid operating temperature: 50 – 80°C (122 – 176°F)

2. Park vehicle on flat surface.
3. Move selector lever to “P” position.
4. Start engine.
5. Move selector lever to “D” position.
6. Accelerate vehicle to 2/8-way throttle depressing accelerator pedal constantly.

 **Read vehicle speed and engine speed. Refer to [TM-397](#), "[Vehicle Speed When Shifting Gears](#)".**

OK or NG

- OK >> GO TO 2..
 NG >> Refer to [TM-350](#), "[Symptom Table](#)". Continue “Road Test”.


**2. CHECK VEHICLE SPEED WHEN SHIFTING GEARS — PART 2**

1. Park vehicle on flat surface.
2. Move selector lever to “D” position.
3. Accelerate vehicle to full depression depressing accelerator pedal constantly.

 **Read vehicle speed and engine speed. Refer to [TM-397](#), "[Vehicle Speed When Shifting Gears](#)".**

OK or NG

- OK >> GO TO 3..
 NG >> Refer to [TM-350](#), "[Symptom Table](#)". Continue “Road Test”.

**3. CHECK MANUAL MODE FUNCTION**

Move to manual mode from “D” position.

Does it switch to manual mode?

- YES >> GO TO 4..
 NO >> Refer to [TM-350](#), "[Symptom Table](#)". Continue “Road Test”.

4. CHECK SHIFT-UP FUNCTION

During manual mode driving, is upshift from M1 → M2 → M3 → M4 → M5 → M6 performed?

 **Read the gear position. Refer to [TM-266](#), "[CONSULT-III Function \(TRANSMISSION\)](#)".**

Is upshifting correctly performed?

- YES >> GO TO 5..
 NO >> Refer to [TM-350](#), "[Symptom Table](#)". Continue “Road Test”.

5. CHECK SHIFT-DOWN FUNCTION

During manual mode driving, is downshift from M6 → M5 → M4 → M3 → M2 → M1 performed?

 **Read the gear position. Refer to [TM-266](#), "[CONSULT-III Function \(TRANSMISSION\)](#)".**

Is downshifting correctly performed?

- YES >> GO TO 6..
 NO >> Refer to [TM-350](#), "[Symptom Table](#)". Continue “Road Test”.

6. CHECK ENGINE BRAKE FUNCTION

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

- YES >> 1. Stop the vehicle.
2. Perform self-diagnosis. Refer to [TM-266, "CONSULT-III Function \(TRANSMISSION\)"](#).
- NO >> Refer to [TM-350, "Symptom Table"](#). then continue trouble diagnosis.


CVT POSITION

Inspection and Adjustment

INFOID:000000000992256

INSPECTION

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check that the actual position of the selector lever matches the position shown by the shift position indicator and the manual lever on the transaxle.
5. The method of operating the selector lever to individual positions correctly should be as shown.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when selector lever is placed in the "R" position. Confirm the back-up lamps do not illuminate when the selector lever is pushed toward the "R" position when in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions.
9. Make sure transaxle is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



ADJUSTMENT

CAUTION:**Apply parking brake before adjustment.**

1. Loosen the control cable nut.
2. Place the manual lever and the selector lever in "P" position.
3. Tighten control cable nut to specified torque.

Control cable nut: Refer to [TM-385, "Exploded View"](#).

CAUTION:

Secure the manual lever when tightening control cable nut. Make sure the manual lever stays in the "P" position.

4. Check the operation of the CVT.

TRANSMISSION CONTROL MODULE

< ON-VEHICLE REPAIR >


[CVT: RE0F10A]

ON-VEHICLE REPAIR

TRANSMISSION CONTROL MODULE

Exploded View

INFOID:00000000099257



1. TCM
⇐: Front

2. Bracket


3. Battery

Removal and Installation

INFOID:00000000099258

REMOVAL

1. Disconnect the battery negative terminal.
2. Remove the fresh air intake tube (upper).
3. Disconnect the TCM harness connector.
4. Remove the TCM (1) from the bracket (2).
 - ⇐: Front
 - Battery (3)




INSTALLATION

Installation is in the reverse order of removal.

CONTROL DEVICE

Exploded View

INFOID:000000000992259



- | | | |
|----------------------------------|----------------------------|---------------|
| 1. Control lever knob | 2. Lock pin | 3. Knob cover |
| 4. Control device selector plate | 5. Control device assembly | |

Removal and Installation

INFOID:000000000992260

REMOVAL

1. Remove the center console assembly. Refer to [IP-11, "Removal and Installation"](#).
2. Disconnect the control cable from the control device assembly.
3. Disconnect the CVT device harness connector from the control device assembly.
4. Remove the control device assembly bolts and the control device assembly.

INSTALLATION


Installation is in the reverse order of removal.

- When installing the control cable to the control device assembly, make sure that the control cable is fully pressed in with the ribbed surface facing upward.
- After installation is completed, adjust and check CVT position. Refer to [TM-381, "Inspection and Adjustment"](#).

Inspection and Adjustment

INSPECTION

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check that the actual position of the selector lever matches the position shown by the shift position indicator and the manual lever on the transaxle.
5. The method of operating the selector lever to individual positions correctly should be as shown.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when selector lever is placed in the "R" position. Confirm the back-up lamps do not illuminate when the selector lever is pushed toward the "R" position when in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions.
9. Make sure transaxle is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



ADJUSTMENT

CAUTION:

Apply parking brake before adjustment.

1. Loosen the control cable nut.
2. Place the manual lever and the selector lever in "P" position.
3. Tighten control cable nut to specified torque.

Control cable nut: Refer to [TM-385, "Exploded View"](#).

CAUTION:

Secure the manual lever when tightening control cable nut. Make sure the manual lever stays in the "P" position.

4. Check the operation of the CVT. Refer to [TM-384, "Inspection and Adjustment"](#).

CONTROL CABLE


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

CONTROL CABLE

Exploded View

INFOID:000000000992262



- | | | |
|---------------------|----------------------------|-------------------------|
| 1. Control lever | 2. Control device assembly | 3. Control cable socket |
| 4. Retainer grommet | 5. Control cable | 6. Bracket |
| 7. Lock plate | 8. Manual lever | |

Removal and Installation

INFOID:000000000992263

REMOVAL

1. Shift control lever to "P".
2. Remove the air filter assembly. Refer to [EM-24, "Removal and Installation"](#).
3. Remove the control cable nut and control cable from the manual lever.
4. Remove the lock plate and the control cable from the bracket.
5. Remove the center console. Refer to [IP-11, "Removal and Installation"](#).
6. Remove the bracket covering the retainer grommet.
7. Remove the retainer grommet bolts and the retainer grommet.
8. Remove the control cable from the control device assembly.
9. Remove the control cable from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.

- When installing the control cable to the control device assembly, make sure that the control cable socket is fully pressed into the control device assembly, and the control cable end is fully pressed in with the ribbed surface facing upward.
- After installation is complete, adjust and check the CVT position. Refer to [TM-384, "Inspection and Adjustment"](#).

DIFFERENTIAL SIDE OIL SEAL


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

DIFFERENTIAL SIDE OIL SEAL

Exploded View

INFOID:000000000992264



1. CVT assembly

2. Differential side oil seal



:NISSAN CVT Fluid NS-2

Removal and Installation

INFOID:000000000992265


REMOVAL

1. Remove drive shaft assembly. Refer to [FAX-9, "Removal and Installation \(Left Side\)"](#) and [FAX-10, "Removal and Installation \(Right Side\)"](#).

2. Remove the differential side oil seal using suitable tool

CAUTION:

Do not scratch transaxle case or converter housing.



INSTALLATION

1. Drive the new differential side oil seal into the transaxle case side (B) and converter housing side (C) until it is flush using suitable tool.


Dimension A : 0 ± 0.5 mm (0 ± 0.020 in)

CAUTION:

- Do not reuse differential side oil seals.
- Apply specified NISSAN CVT fluid to side oil seals.

2. Install drive shaft assembly. Refer to [FAX-9, "Removal and Installation \(Left Side\)"](#) and [FAX-10, "Removal and Installation \(Right Side\)"](#).

3. Check CVT fluid level. Refer to [TM-368, "Inspection"](#).



AIR BREATHER HOSE


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

AIR BREATHER HOSE

Exploded View

INFOID:000000000992266



- | | | |
|----------------------|-----------------|---------------|
| 1. Air breather hose | 2. Clip | 3. Bracket |
| 4. Air breather tube | 5. CVT assembly | A. Paint mark |
- ←: Front

Removal and Installation

INFOID:000000000992267

Refer to the figure for removal and installation.

CAUTION:

- Install air breather hose with paint mark facing upward.
- Insert air breather hose a minimum of 17mm (0.67 in) onto air breather tube (to end of air breather tubes radius end).
- Install air breather hose to bracket by fully inserting the clip.
- Make sure there are no pinched or restricted areas on air breather hose caused by bending or winding when installing it.

OIL PAN


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

OIL PAN

Exploded View

INFOID:000000000992268



- | | | |
|-----------------|----------------------|---------------|
| 1. CVT assembly | 2. Oil pan gasket | 3. Oil pan |
| 4. Magnet | 5. Drain plug gasket | 6. Drain plug |

Removal and Installation

INFOID:000000000992269

Refer to the figure for removal and installation.

CAUTION:

- Check for foreign materials in the oil pan to help determine the cause of any malfunction. If the CVT fluid is very dark, smells burned, or contains foreign particles, frictional material (clutches) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves to stick and can inhibit pump pressure.
- Completely remove all moisture, oil, old gasket and any foreign material from the gasket mounting surface of the CVT case and oil pan.
- Do not reuse oil pan gasket and oil pan bolts.
- After installation is complete, fill CVT with recommended CVT fluid and check for CVT fluid leakage and CVT fluid level. Refer to [TM-369, "Changing"](#) and [TM-368, "Inspection"](#).

PARK/NEUTRAL POSITION (PNP) SWITCH


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

PARK/NEUTRAL POSITION (PNP) SWITCH

Exploded View

INFOID:000000000992270



1. Washer
2. Manual lever
3. PNP switch
4. CVT assembly

Removal and Installation

INFOID:000000000992271

Refer to the figure for removal and installation.

NOTE:

- Align PNP switch position when installing.
- After installation of PNP switch, check the continuity of PNP switch.
- After installation is complete, adjust and check CVT position. Refer to [TM-381, "Inspection and Adjustment"](#).

PRIMARY SPEED SENSOR


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

PRIMARY SPEED SENSOR

Exploded View

INFOID:000000000992272



1. CVT assembly

2. O-ring

3. Primary speed sensor

 : Nissan CVT Fluid NS-2

Removal and Installation

INFOID:000000000992273

Refer to the figure for removal and installation.

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid to O-ring.
- After installation is complete, check for CVT fluid leakage and CVT fluid level. Refer to [TM-368](#), "[Inspection](#)".

SECONDARY SPEED SENSOR


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

SECONDARY SPEED SENSOR

Exploded View

INFOID:000000000992274



1. CVT assembly
 2. Shim
 3. O-ring
 4. Secondary Speed Sensor
- : Nissan CVT Fluid NS-2

Removal and Installation

INFOID:000000000992275

Refer to the figure for removal and installation.

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid to O-ring.
- Insert the shim.
- After installation is complete, check for CVT fluid leakage and CVT fluid level Refer to [TM-368](#), "[Inspection](#)".

OIL PUMP FITTING BOLT


< ON-VEHICLE REPAIR >

[CVT: RE0F10A]

OIL PUMP FITTING BOLT

Exploded View

INFOID:000000000992276



1. Oil pump fitting bolt

2. O-ring

3. CVT assembly

 : Nissan CVT Fluid NS-2

Removal and Installation

INFOID:000000000992277

Refer to the figure for removal and installation.

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid to O-ring.
- After installation is complete, check for CVT fluid leakage and CVT fluid level. Refer to [TM-368](#), "[Inspection](#)".

TRANSAXLE ASSEMBLY

< REMOVAL AND INSTALLATION >


[CVT: RE0F10A]

REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000000992278



- | | | |
|--|--------------------------|----------------------------|
| 1. Air breather hose | 2. CVT fluid level gauge | 3. CVT fluid charging pipe |
| 4. O-ring | 5. Copper washer | 6. Fluid cooler tube |
| 7. Fluid cooler tube | 8. CVT assembly | |
| A. Refer to TM-393 . "Removal and Installation". | | |

Removal and Installation

INFOID:000000000992279

REMOVAL


1. Remove the engine and transaxle as an assembly. Refer to [EM-72](#). "Removal and Installation".
NOTE:
Using paint, put matching marks on the drive plate and torque converter when removing the torque converter to drive plate nuts.

TRANSAXLE ASSEMBLY

[CVT: RE0F10A]

< REMOVAL AND INSTALLATION >

2. Disconnect the electrical connectors from the following:
 - Primary speed sensor (1)
 - Secondary speed sensor (3)
 - CVT unit connector (2)
 - PNP switch (4)
3. Remove the harness from the CVT.
4. Remove the CVT to engine and engine to CVT bolts.
5. Separate the CVT from the engine.
6. If necessary, remove the following from the CVT:
 - Primary speed sensor
 - Secondary speed sensor
 - PNP switch
 - CVT fluid charging pipe
 - Water tube and hoses
 - Air breather hose
 - Any necessary brackets




INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

- When installing fluid cooler tube align the tube against the rib as shown.
- When replacing an engine or transaxle you must make sure any dowels are installed correctly during re-assembly.
- Improper alignment caused by missing dowels may cause vibration, oil leaks or breakage of drivetrain components.
- Do not reuse O-rings.
- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the nuts for the torque converter while securing the crankshaft pulley bolt, be sure to confirm the tightening torque of the crankshaft pulley bolt. Refer to [EM-51, "Removal and Installation"](#).
- After converter is installed to drive plate, rotate crankshaft several turns to check that CVT rotates freely without binding.
- When installing the CVT to the engine, align the matching mark on the drive plate with the matching mark on the torque converter.
- When installing the CVT to the engine, attach the bolts in accordance with the following standard.



| Bolt No. | A | B | C | D | E | F |
|--|--------------|--------------|--------------|--------------|--------------|--------------|
| Number of bolts | 1 | 3 | 2 | 2 | 1 | 2 |
| Bolt length "ℓ" mm (in) | 45 (1.77) | 45 (1.77) | 45 (1.77) | 35 (1.38) | 45 (1.77) | 45 (1.77) |
| Tightening torque N·m (kg·m, ft·lb) | 35 (3.6, 26) | 75 (7.7, 55) | 43 (4.4, 32) | 43 (4.4, 32) | 48 (4.9, 35) | 48 (4.9, 35) |



- When installing the drive plate to torque converter nuts, tighten them temporarily. then tighten the nuts to the specified torque.
- After completing installation, check for fluid leakage, fluid level, and the positions of CVT. Refer to [TM-368, "Inspection"](#) and [TM-381, "Inspection and Adjustment"](#).
- When replacing the CVT assembly, erase EEP ROM in TCM.

Inspection

Installation and Inspection of Torque Converter

INFOID:000000000992280


TRANSAXLE ASSEMBLY

< REMOVAL AND INSTALLATION >

[CVT: RE0F10A]

- After installing the torque converter to the CVT, be sure to check distance "A" to ensure it is within specifications.

Distance "A" : 14.4 mm (0.567 in)



A
B
C

TM

E
F
G
H
I
J
K
L
M
N
O
P

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

< DISASSEMBLY AND ASSEMBLY >


[CVT: RE0F10A]

DISASSEMBLY AND ASSEMBLY

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

Exploded View

INFOID:000000000992281



1. CVT assembly

2. Converter housing oil seal

3. Torque converter

 : Apply CVT Fluid. Refer to [MA-11, "Fluids and Lubricants"](#).

Disassembly

INFOID:000000000992282

1. Remove torque converter.
2. Remove the converter housing oil seal using suitable tool.

CAUTION:

Do not scratch converter housing.

Assembly

INFOID:000000000992283

1. Drive the converter housing oil seal (1) in evenly using suitable tool as shown.

• CVT (2)

CAUTION:

- **Do not reuse converter housing oil seal.**
- **Apply CVT fluid to converter housing oil seal.**

2. Install the torque converter.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F10A]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:000000000992284

| | | |
|-------------------------|-------------------|---------------------------------------|
| Applied model | | QR25DE engine |
| | | 2WD |
| CVT model | | RE0F10A |
| CVT assembly | Model code number | 1XF5A |
| Transmission gear ratio | D range | 2.349 – 0.394 |
| | Reverse | 1.750 |
| | Final drive | 5.798 |
| Recommended fluid | | NISSAN CVT Fluid NS-2*1 |
| Fluid capacity | | 8.3 liter (8-3/4 US qt, 7-1/4 Imp qt) |

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-2. Do not mix with other fluid.
- Using CVT fluid other than Genuine NISSAN CVT Fluid NS-2 will deteriorate in driveability and CVT durability, and may damage the CVT, which is not covered by the warranty.

*1: Refer to [MA-11, "Fluids and Lubricants"](#).

Vehicle Speed When Shifting Gears

INFOID:000000000992285

Numerical value data are reference values.

| Engine type | Throttle position | Shift pattern | Engine speed (rpm) | |
|-------------|-------------------|---------------|---------------------|---------------------|
| | | | At 40 km/h (25 MPH) | At 60 km/h (37 MPH) |
| QR25DE | 8/8 | "D" position | 3,400 – 4,200 | 4,300 – 5,100 |
| | 2/8 | "D" position | 1,400 – 2,200 | 1,600 – 2,400 |

*: Without manual mode

CAUTION:

Lock-up clutch is engaged when vehicle speed is approximately 18 km/h (11 MPH) to 90 km/h (56 MPH).

Stall Speed

INFOID:000000000992286

| | |
|-------------|-------------------|
| Stall speed | 2,500 – 3,000 rpm |
|-------------|-------------------|

Line Pressure

INFOID:000000000992287

| Engine speed | Line pressure kPa (kg/cm ² , psi) |
|--------------|--|
| | "R" or "D" positions |
| At idle | 750 (7.65, 108.8) |
| At stall | 5,700 (58.14, 826.5)*1 |

*1: Reference values

Solenoid Valves

INFOID:000000000992288

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F10A]

| Name | Resistance (Approx.) | Terminal |
|---|----------------------|----------|
| Pressure control solenoid valve B (secondary pressure solenoid valve) | 3.0 – 7.0 Ω | 3 |
| Pressure control solenoid valve A (line pressure solenoid valve) | | 2 |
| Torque converter clutch solenoid valve | | 12 |
| Lock-up select solenoid valve | 17.0 – 38.0 Ω | 13 |

CVT Fluid Temperature Sensor

INFOID:000000000992289

| Name | Condition | CONSULT-II "DATA MONITOR" (Approx.) | Resistance (Approx.) |
|--------------|--------------|-------------------------------------|----------------------|
| ATF TEMP SEN | 20°C (68°F) | 2.0 V | 6.5 kΩ |
| | 80°C (176°F) | 1.0 V | 0.9 kΩ |

Primary Speed Sensor

INFOID:000000000992290

| Name | Condition | Data (Approx.) |
|----------------------|--|----------------|
| Primary speed sensor | When driving ["M1" position, 20 km/h (12 MPH)] | 610 Hz |

Secondary Speed Sensor

INFOID:000000000992291

| Name | Condition | Data (Approx.) |
|------------------------|---|----------------|
| Secondary speed sensor | When driving ["D" position, 20 km/h (12 MPH)] | 480 Hz |

Removal and Installation

INFOID:000000000992292

| | |
|--|--------------------|
| Distance between end of converter housing and torque converter | 14.4 mm (0.567 in) |
|--|--------------------|