

SECTION **AV**

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

<b>BASE AUDIO</b>	Diagnosis Procedure .....	23	F
<b>BASIC INSPECTION</b> .....	<b>COMMUNICATION SIGNAL CIRCUIT</b> .....	25	G
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>SATELLITE RADIO TUNER</b> .....	25	H
Work Flow .....	SATELLITE RADIO TUNER : Description .....	25	I
<b>FUNCTION DIAGNOSIS</b> .....	SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	25	J
<b>AUDIO SYSTEM</b> .....	<b>SOUND SIGNAL CIRCUIT</b> .....	27	K
System Diagram .....	<b>SATELLITE RADIO TUNER</b> .....	27	L
System Description .....	SATELLITE RADIO TUNER : Description .....	27	M
Component Parts Location .....	SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	27	AV
Component Description .....	<b>ECU DIAGNOSIS</b> .....	29	O
<b>DIAGNOSIS SYSTEM (AUDIO UNIT)</b> .....	<b>AUDIO UNIT</b> .....	29	P
Diagnosis Description .....	Reference Value .....	29	
<b>COMPONENT DIAGNOSIS</b> .....	Wiring Diagram .....	32	
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	<b>SATELLITE RADIO TUNER</b> .....	39	
<b>AUDIO UNIT</b> .....	Reference Value .....	39	
AUDIO UNIT : Diagnosis Procedure .....	Wiring Diagram .....	40	
<b>SATELLITE RADIO TUNER</b> .....	<b>SYMPTOM DIAGNOSIS</b> .....	41	
SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	<b>AUDIO SYSTEM</b> .....	41	
<b>FRONT DOOR SPEAKER</b> .....	<b>AUDIO UNIT</b> .....	41	
Description .....	AUDIO UNIT : Symptom Table .....	41	
Diagnosis Procedure .....	<b>CD</b> .....	41	
<b>TWEETER</b> .....	CD : Symptom Table .....	41	
Description .....	<b>SATELLITE RADIO TUNER</b> .....	41	
Diagnosis Procedure .....	SATELLITE RADIO TUNER : Symptom Table .....	41	
<b>REAR SPEAKER</b> .....	<b>NORMAL OPERATING CONDITION</b> .....	42	
Description .....	Description .....	42	
Diagnosis Procedure .....	<b>PRECAUTION</b> .....	43	
<b>STEERING SWITCH</b> .....			
Description .....			

<b>PRECAUTIONS</b> .....	<b>43</b>	<b>AUDIO UNIT</b> .....	<b>65</b>
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	43	AUDIO UNIT : Diagnosis Procedure .....	65
<b>PREPARATION</b> .....	<b>44</b>	<b>BOSE SPEAKER AMP</b> .....	<b>65</b>
<b>PREPARATION</b> .....	<b>44</b>	BOSE SPEAKER AMP : Diagnosis Procedure .....	65
Commercial Service Tools .....	44	<b>SATELLITE RADIO TUNER</b> .....	<b>66</b>
<b>ON-VEHICLE REPAIR</b> .....	<b>45</b>	SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	66
<b>AUDIO UNIT</b> .....	<b>45</b>	<b>BLUETOOTH CONTROL UNIT</b> .....	<b>67</b>
Removal and Installation .....	45	BLUETOOTH CONTROL UNIT : Diagnosis Pro- cedure .....	67
<b>TWEETER</b> .....	<b>46</b>	<b>MICROPHONE</b> .....	<b>68</b>
Removal and Installation .....	46	MICROPHONE : Diagnosis Procedure .....	68
<b>FRONT DOOR SPEAKER</b> .....	<b>47</b>	<b>FRONT DOOR SPEAKER</b> .....	<b>70</b>
Removal and Installation .....	47	Description .....	70
<b>REAR SPEAKER</b> .....	<b>48</b>	Diagnosis Procedure .....	70
Removal and Installation .....	48	<b>TWEETER</b> .....	<b>73</b>
<b>AUDIO ANTENNA</b> .....	<b>49</b>	Description .....	73
Location of Antennas .....	49	Diagnosis Procedure .....	73
Roof Antenna .....	49	<b>CENTER SPEAKER</b> .....	<b>76</b>
Window Antenna Repair .....	50	Description .....	76
<b>STEERING SWITCH</b> .....	<b>53</b>	Diagnosis Procedure .....	76
Removal and Installation .....	53	<b>REAR DOOR SPEAKER</b> .....	<b>78</b>
<b>BOSE AUDIO WITHOUT NAVIGATION</b>		Description .....	78
<b>BASIC INSPECTION</b> .....	<b>54</b>	Diagnosis Procedure .....	78
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>54</b>	<b>WOOFER</b> .....	<b>81</b>
Work Flow .....	54	Description .....	81
<b>FUNCTION DIAGNOSIS</b> .....	<b>56</b>	Diagnosis Procedure .....	81
<b>AUDIO SYSTEM</b> .....	<b>56</b>	<b>AMP ON SIGNAL CIRCUIT</b> .....	<b>84</b>
System Diagram .....	56	Description .....	84
System Description .....	56	Diagnosis Procedure .....	84
Component Parts Location .....	57	<b>STEERING SWITCH</b> .....	<b>85</b>
Component Description .....	58	Description .....	85
<b>HANDS-FREE PHONE SYSTEM</b> .....	<b>59</b>	Diagnosis Procedure .....	85
System Diagram .....	59	Component Inspection .....	87
System Description .....	59	<b>COMMUNICATION SIGNAL CIRCUIT</b> .....	<b>88</b>
Component Parts Location .....	59	<b>SATELLITE RADIO TUNER</b> .....	<b>88</b>
Component Description .....	60	SATELLITE RADIO TUNER : Description .....	88
<b>DIAGNOSIS SYSTEM (AUDIO UNIT)</b> .....	<b>61</b>	SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	88
Diagnosis Description .....	61	<b>SOUND SIGNAL CIRCUIT</b> .....	<b>90</b>
<b>DIAGNOSIS SYSTEM (BLUETOOTH CON- CONTROL UNIT)</b> .....	<b>64</b>	<b>SATELLITE RADIO TUNER</b> .....	<b>90</b>
Diagnosis Description .....	64	SATELLITE RADIO TUNER : Description .....	90
Work Flow .....	64	SATELLITE RADIO TUNER : Diagnosis Proce- dure .....	90
<b>COMPONENT DIAGNOSIS</b> .....	<b>65</b>	<b>MICROPHONE SIGNAL CIRCUIT</b> .....	<b>92</b>
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	<b>65</b>	Description .....	92
		Diagnosis Procedure .....	92

<b>ECU DIAGNOSIS</b> .....	<b>94</b>	<b>STEERING SWITCH</b> .....	<b>135</b>	A
<b>AUDIO UNIT</b> .....	<b>94</b>	Removal and Installation .....	135	
Reference Value .....	94	<b>MICROPHONE</b> .....	<b>136</b>	B
Wiring Diagram .....	100	Removal and Installation .....	136	
<b>BOSE SPEAKER AMP</b> .....	<b>115</b>	<b>TEL ANTENNA</b> .....	<b>137</b>	C
Reference Value .....	115	Removal and Installation .....	137	
<b>SATELLITE RADIO TUNER</b> .....	<b>118</b>	<b>TEL ADAPTER UNIT</b> .....	<b>138</b>	D
Reference Value .....	118	Removal and Installation .....	138	
<b>BLUETOOTH CONTROL UNIT</b> .....	<b>120</b>	<b>BOSE AUDIO WITH NAVIGATION</b>		
Reference Value .....	120	<b>BASIC INSPECTION</b> .....	<b>139</b>	E
<b>SYMPTOM DIAGNOSIS</b> .....	<b>122</b>	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>139</b>	
<b>AUDIO SYSTEM</b> .....	<b>122</b>	Work Flow .....	139	F
Symptom Table .....	122	<b>INSPECTION AND ADJUSTMENT</b> .....	<b>141</b>	
<b>NORMAL OPERATING CONDITION</b> .....	<b>123</b>	<b>REAR VIEW MONITOR GUIDING LINE ADJUSTMENT</b> .....	<b>141</b>	G
Description .....	123	REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Description .....	141	
<b>PRECAUTION</b> .....	<b>124</b>	REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Special Repair Requirement .....	141	H
<b>PRECAUTIONS</b> .....	<b>124</b>	<b>FUNCTION DIAGNOSIS</b> .....	<b>143</b>	
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	124	<b>MULTI AV SYSTEM</b> .....	<b>143</b>	I
<b>PREPARATION</b> .....	<b>125</b>	System Diagram .....	143	
<b>PREPARATION</b> .....	<b>125</b>	System Description .....	143	J
Commercial Service Tools .....	125	Component Parts Location .....	145	
<b>ON-VEHICLE REPAIR</b> .....	<b>126</b>	Component Description .....	147	K
<b>AUDIO UNIT</b> .....	<b>126</b>	<b>NAVIGATION SYSTEM</b> .....	<b>149</b>	
Removal and Installation .....	126	System Diagram .....	149	L
<b>BOSE AMP.</b> .....	<b>127</b>	System Description .....	149	
Removal and Installation .....	127	Component Parts Location .....	151	M
<b>TWEETER</b> .....	<b>128</b>	Component Description .....	151	
Removal and Installation .....	128	<b>REAR VIEW MONITOR SYSTEM</b> .....	<b>152</b>	
<b>CENTER SPEAKER</b> .....	<b>129</b>	System Diagram .....	152	
Removal and Installation .....	129	System Description .....	152	
<b>FRONT DOOR SPEAKER</b> .....	<b>130</b>	Component Parts Location .....	152	
Removal and Installation .....	130	Component Description .....	152	
<b>REAR DOOR SPEAKER</b> .....	<b>131</b>	<b>AUDIO SYSTEM</b> .....	<b>153</b>	AV
Removal and Installation .....	131	System Diagram .....	153	
<b>REAR SPEAKER</b> .....	<b>132</b>	System Description .....	153	O
Removal and Installation .....	132	Component Parts Location .....	153	
<b>SATELLITE RADIO TUNER</b> .....	<b>133</b>	Component Description .....	154	
Removal and Installation .....	133	<b>HANDS-FREE PHONE SYSTEM</b> .....	<b>155</b>	P
<b>AUDIO ANTENNA</b> .....	<b>134</b>	System Diagram .....	155	
Roof Antenna .....	134	System Description .....	155	
		Component Parts Location .....	155	
		Component Description .....	156	
		<b>DIAGNOSIS SYSTEM (AV CONTROL UNIT)</b> .....	<b>157</b>	
		Diagnosis Description .....	157	
		CONSULT - III Function (MULTI AV) .....	164	

<b>COMPONENT DIAGNOSIS</b> .....	166	Description .....	179
<b>U1000 CAN COMM CIRCUIT</b> .....	166	DTC Logic .....	179
Description .....	166	Diagnosis Procedure .....	179
DTC Logic .....	166	<b>U1212 DVD-ROM DATA FORWARD</b> .....	180
Diagnosis Procedure .....	166	Description .....	180
<b>U1010 CONTROL UNIT (CAN)</b> .....	167	DTC Logic .....	180
Description .....	167	Diagnosis Procedure .....	180
DTC Logic .....	167	<b>U1213 DVD-ROM DATA</b> .....	181
Diagnosis Procedure .....	167	Description .....	181
<b>U1200 AV CONTROL UNIT</b> .....	168	DTC Logic .....	181
Description .....	168	Diagnosis Procedure .....	181
DTC Logic .....	168	<b>U1214 DVD-ROM TIMEOUT</b> .....	182
<b>U1201 AV CONTROL UNIT</b> .....	169	Description .....	182
Description .....	169	DTC Logic .....	182
DTC Logic .....	169	Diagnosis Procedure .....	182
<b>U1204 GPS COMM</b> .....	170	<b>U1215 DVD-ROM LOAD</b> .....	183
Description .....	170	Description .....	183
DTC Logic .....	170	DTC Logic .....	183
<b>U1205 GPS ROM</b> .....	171	Diagnosis Procedure .....	183
Description .....	171	<b>U1216 AV CONTROL UNIT</b> .....	184
DTC Logic .....	171	Description .....	184
<b>U1206 GPS RAM</b> .....	172	DTC Logic .....	184
Description .....	172	<b>U1217 AV CONTROL UNIT</b> .....	185
DTC Logic .....	172	Description .....	185
<b>U1207 GPS RTC</b> .....	173	DTC Logic .....	185
Description .....	173	<b>U1220 AV CONTROL UNIT</b> .....	186
DTC Logic .....	173	Description .....	186
<b>U1208 DVD-ROM COMM</b> .....	174	DTC Logic .....	186
Description .....	174	<b>U1244 GPS ANTENNA</b> .....	187
DTC Logic .....	174	Description .....	187
Diagnosis Procedure .....	174	DTC Logic .....	187
<b>U1209 DVD-ROM READ</b> .....	175	Diagnosis Procedure .....	187
Description .....	175	<b>U124C CD CHANGER</b> .....	188
DTC Logic .....	175	Description .....	188
Diagnosis Procedure .....	175	DTC Logic .....	188
<b>U120A DVD-ROM DISC</b> .....	176	Diagnosis Procedure .....	188
Description .....	176	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ...	190
DTC Logic .....	176	<b>AV CONTROL UNIT</b> .....	190
Diagnosis Procedure .....	176	AV CONTROL UNIT : Diagnosis Procedure .....	190
<b>U120C DVD-ROM MECHA DETECT</b> .....	177	<b>REAR VIEW CAMERA CONTROL UNIT</b> .....	190
Description .....	177	REAR VIEW CAMERA CONTROL UNIT : Diagno-	
DTC Logic .....	177	sis Procedure .....	190
Diagnosis Procedure .....	177	<b>REAR VIEW CAMERA</b> .....	191
<b>U120D DVD-ROM DRIVE MECHA</b> .....	178	REAR VIEW CAMERA : Diagnosis Procedure ....	191
Description .....	178	<b>BOSE SPEAKER AMP</b> .....	192
DTC Logic .....	178	BOSE SPEAKER AMP : Diagnosis Procedure ....	192
Diagnosis Procedure .....	178	<b>CD CHANGER</b> .....	193
<b>U1210 DVD-ROM SEEK</b> .....	179	CD CHANGER : Diagnosis Procedure .....	193

<b>MICROPHONE</b> .....	<b>194</b>	<b>BOSE SPEAKER AMP</b> .....	<b>243</b>	A
MICROPHONE : Diagnosis Procedure .....	194	Reference Value .....	243	
<b>FRONT DOOR SPEAKER</b> .....	<b>196</b>	<b>REAR VIEW CAMERA CONTROL UNIT</b> .....	<b>246</b>	B
Description .....	196	Reference Value .....	246	
Diagnosis Procedure .....	196	<b>CD CHANGER</b> .....	<b>247</b>	C
<b>TWEETER</b> .....	<b>199</b>	Reference Value .....	247	
Description .....	199	<b>SYMPTOM DIAGNOSIS</b> .....	<b>249</b>	
Diagnosis Procedure .....	199	<b>MULTI AV SYSTEM</b> .....	<b>249</b>	D
<b>CENTER SPEAKER</b> .....	<b>202</b>	Symptom Table .....	249	
Description .....	202	<b>NORMAL OPERATING CONDITION</b> .....	<b>250</b>	E
Diagnosis Procedure .....	202	Description .....	250	
<b>REAR DOOR SPEAKER</b> .....	<b>204</b>	<b>PRECAUTION</b> .....	<b>258</b>	F
Description .....	204	<b>PRECAUTIONS</b> .....	<b>258</b>	
Diagnosis Procedure .....	204	Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	258	G
<b>WOOFER</b> .....	<b>207</b>	Precaution for Trouble Diagnosis .....	258	
Description .....	207	Precaution for Harness Repair .....	258	
Diagnosis Procedure .....	207	<b>PREPARATION</b> .....	<b>259</b>	H
<b>AMP ON SIGNAL CIRCUIT</b> .....	<b>210</b>	<b>PREPARATION</b> .....	<b>259</b>	
Description .....	210	Commercial Service Tools .....	259	I
Diagnosis Procedure .....	210	<b>ON-VEHICLE REPAIR</b> .....	<b>260</b>	
<b>STEERING SWITCH</b> .....	<b>211</b>	<b>AV CONTROL UNIT</b> .....	<b>260</b>	J
Description .....	211	Removal and Installation .....	260	
Diagnosis Procedure .....	211	<b>BOSE AMP.</b> .....	<b>261</b>	K
Component Inspection .....	212	Removal and Installation .....	261	
<b>MICROPHONE SIGNAL CIRCUIT</b> .....	<b>213</b>	<b>CD CHANGER</b> .....	<b>262</b>	L
Description .....	213	Removal and Installation .....	262	
Diagnosis Procedure .....	213	<b>TWEETER</b> .....	<b>263</b>	M
<b>CAMERA IMAGE SIGNAL CIRCUIT (REAR VIEW CAMERA TO CAMERA CONTROL UNIT)</b> .....	<b>215</b>	Removal and Installation .....	263	
Description .....	215	<b>CENTER SPEAKER</b> .....	<b>264</b>	
Diagnosis Procedure .....	215	Removal and Installation .....	264	
<b>CAMERA ON SIGNAL CIRCUIT</b> .....	<b>216</b>	<b>FRONT DOOR SPEAKER</b> .....	<b>265</b>	AV
Description .....	216	Removal and Installation .....	265	
Diagnosis Procedure .....	216	<b>REAR DOOR SPEAKER</b> .....	<b>266</b>	O
<b>CAMERA IMAGE SIGNAL CIRCUIT (CAM- ERA CONTROL UNIT TO AV CONTROL UNIT)</b> .....	<b>217</b>	Removal and Installation .....	266	
Description .....	217	<b>REAR SPEAKER</b> .....	<b>267</b>	P
Diagnosis Procedure .....	217	Removal and Installation .....	267	
<b>REVERSE SIGNAL CIRCUIT</b> .....	<b>218</b>	<b>AUDIO ANTENNA</b> .....	<b>268</b>	
Description .....	218	Roof Antenna .....	268	
Diagnosis Procedure .....	218	<b>GPS ANTENNA</b> .....	<b>269</b>	
<b>ECU DIAGNOSIS</b> .....	<b>219</b>	Removal and Installation .....	269	
<b>AV CONTROL UNIT</b> .....	<b>219</b>	<b>STEERING SWITCH</b> .....	<b>270</b>	
Reference Value .....	219	Removal and Installation .....	270	
Wiring Diagram .....	224			
DTC Index .....	241			

---

<b>MICROPHONE</b> .....	<b>271</b>	<b>REAR VIEW MONITOR</b> .....	<b>274</b>
Removal and Installation .....	271	Removal and Installation .....	274
<b>TEL ANTENNA</b> .....	<b>272</b>	Adjustment .....	274
Removal and Installation .....	272	<b>CAMERA CONTROL UNIT</b> .....	<b>275</b>
<b>TEL ADAPTER UNIT</b> .....	<b>273</b>	Removal and Installation .....	275
Removal and Installation .....	273		


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000001502535

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

---

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

## 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

## 5.FINAL CHECK

---

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.


NO >> GO TO 2



FUNCTION DIAGNOSIS

AUDIO SYSTEM

System Diagram



System Description

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Window antenna
- Roof antenna (audio)
- Steering switches
- Front door speakers
- Tweeters
- Rear speakers

When the audio system is on, radio signals are received by the window antenna and roof antenna. The audio unit then sends audio signals to the front door speakers, front tweeters and rear speakers.

Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Roof antenna (satellite)
- Satellite radio tuner

When the satellite radio system is on, radio signals are supplied to the satellite radio tuner from the satellite antenna. The satellite radio tuner then sends audio signals to the audio unit.

Refer to Owner's Manual for satellite radio system operating instructions.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P


# AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

## Component Parts Location

INFOID:000000001502538



AWNIA0074GB

- |                             |   |                        |
|-----------------------------|---|------------------------|
| 1. Tweeter LH M51           | 2. Steering wheel audio control switches                            | 3. Tweeter RH M52      |
| 4. Audio unit M43, M45, M81 | 5. Front door speaker<br>LH D3<br>RH D103                           | 6. Rear speaker RH B44 |
| 7. Rear speaker LH B26      | 8. Satellite radio tuner B123, B129 (with<br>satellite radio tuner) |                        |

## Component Description

INFOID:000000001502539

Part name	Description
Audio unit	Controls audio system and satellite radio system functions
Steering switches	<ul style="list-style-type: none"> <li>Each audio operation can be operated</li> <li>Steering switch signal (operation signal) is output to AV control unit</li> </ul>

# AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

Part name	Description	
Front door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high, mid and low range sounds</li></ul>	A
Tweeters	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high range sounds</li></ul>	B
Rear speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high, mid and low range sounds</li></ul>	C
Satellite radio tuner	<ul style="list-style-type: none"><li>• Receives radio signals from satellite antenna</li><li>• Sends audio signals to audio unit</li></ul>	
Satellite antenna	Audio signal (satellite radio) is received and output to audio unit.	D

E

F

G

H

I

J

K

L

M

AV

O

P

## DIAGNOSIS SYSTEM (AUDIO UNIT)

### Diagnosis Description


INFOID:000000001502540

Self-diagnosis mode can check the following items.


- Audio unit hardware/software versions
- Continuity of each speaker channel
- Continuity of each audio unit switch

### OPERATION PROCEDURE

1. Turn ignition switch to the ACC position.
2. Turn the audio unit off.
3. While pressing the "AUDIO" button, turn the volume control dial clockwise or counterclockwise 30 clicks or more. When the self-diagnosis mode is started, a short beep will be heard.




4. Initially, all display segments will be illuminated.



### Version Check

1. Press the "AUDIO" switch to enter version diagnostics. "Software" (audio software version) is displayed.




# DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

2. Press the "AUDIO" switch again to display the "Hardware" (audio hardware version).



A  
B  
C  
D

3. Press the "AUDIO" switch again to display the "CD Mech" (CD mechanism version).



E  
F  
G

4. Press the "AUDIO" switch again to display the "SDARS" (satellite radio version).



H  
I  
J

## Channel Check Diagnostics

When all segments are illuminated, press the "TUNE" up switch to enter channel check diagnostics. The self-diagnostic function will then send a tone to each channel (FL, RL, RR, FR) for 1 second.



L  
M

AV

## Button Check Diagnostics


O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

When all segments are illuminated, press the "TUNE" down switch to enter button check diagnostics. When each audio unit switch is pressed, a tone will sound and the switch name will be displayed.



# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

#### AUDIO UNIT : Diagnosis Procedure

INFOID:000000001502541

#### 1.CHECK FUSES

Check that the following fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	24
	7	Ignition switch ACC or ON	19


Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

#### 2.POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M43.
2. Check voltage between the audio unit connector M43 and ground.



Unit	Terminal No.			OFF	ACC	ON
	(+)		(-)			
	Connector	Terminal				
Audio unit	M43	19	Ground	Battery voltage	Battery voltage	Battery voltage
		7	Ground	0V	Battery voltage	Battery voltage

Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 3.GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair audio unit case ground.

### SATELLITE RADIO TUNER

#### SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001502542

#### 1.CHECK FUSES

Check that the following fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
Satellite radio tuner (factory installed)	32	Battery power	24
	36	Ignition switch ACC or ON	19

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT


< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## 2. POWER SUPPLY CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123.
3. Check voltage between the satellite radio tuner (factory installed) and ground.

Unit	Terminal No.		OFF	ACC	ON
	(+)				
	Connector	Terminal			
Satellite radio tuner (factory installed)	B123	32	Battery voltage	Battery voltage	Battery voltage
		36	Ground	0V	Battery voltage



Are the voltage results as specified?

- YES >> GO TO 3  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

## 3. GROUND CIRCUIT CHECK

Inspect satellite radio tuner (factory installed) case ground.

Does case ground pass inspection?

- YES >> Inspection End.  
 NO >> Repair satellite radio tuner (factory installed) case ground.



# FRONT DOOR SPEAKER

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## FRONT DOOR SPEAKER

### Description

INFOID:000000001502543

The audio unit sends audio signals to the front door speakers using the front door speaker circuits.

### Diagnosis Procedure

INFOID:000000001502544


#### 1. HARNESS CHECK

1. Disconnect audio unit connector M43 (A) and suspect speaker connector (B).
2. Check continuity between audio unit harness connector M43 (A) terminal and suspect speaker harness connector (B) terminal.

Terminals				Continuity
Audio unit		Speaker		
Connector	Terminal	Connector	Terminal	
A: M43	2	B: D3	1	Yes
	3		2	
	11	B: D103	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) terminal and ground.

Terminals				Continuity
Audio unit		—		
Connector	Terminal			
A: M43	2	Ground		No
	3			
	11			
	12			



Are continuity results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. FRONT SPEAKER SIGNAL CHECK

1. Connect audio unit connector and front speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# FRONT DOOR SPEAKER

[BASE AUDIO]


< COMPONENT DIAGNOSIS >

4. Check the signal between audio unit harness connector terminals with CONSULT-III or oscilloscope.

Terminals				Condi- tion	Reference signal
(+) (+)		(-) (-)			
Con- nec- tor	Termi- nal	Con- nec- tor	Termi- nal		
M43	2	M43	3	Receive audio signal	
	11		12		

Is the audio signal voltage as specified?

- YES >> Replace speaker. Refer to [AV-47. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-45. "Removal and Installation"](#).



TWEETER

Description

INFOID:000000001502545

The audio unit sends audio signals to the tweeters using the tweeter circuits.

Diagnosis Procedure

INFOID:000000001502546


1. HARNESS CHECK

1. Disconnect audio unit connector M43 (A) and suspect tweeter connector (B).
2. Check continuity between audio unit harness connector M43 (A) and suspect tweeter harness connector (B).

Terminals				Continuity
Audio unit		Tweeter		
Connector	Terminal	Connector	Terminal	
A: M43	2	B: M51	1	Yes
	3		2	
	11	B: M52	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.

Terminals				Continuity
Audio unit		—		
Connector	Terminal			
A: M43	2	Ground		No
	3			
	11			
	12			



Are the continuity results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

2. TWEETER SIGNAL CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# TWEETER

## < COMPONENT DIAGNOSIS >


[BASE AUDIO]

1. Connect audio unit connector and tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT-III or oscilloscope.

Terminals				Condi- tion	Reference signal
(+)		(-)			
Con- nec- tor	Termi- nal	Con- nec- tor	Termi- nal		
M43	2	M43	3	Receive audio signal	
	11	M43	12		

Is the audio signal voltage as specified?

- YES >> Replace tweeter. Refer to [AV-47. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-45. "Removal and Installation"](#).



# REAR SPEAKER

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## REAR SPEAKER

### Description

INFOID:000000001502547

The audio unit sends audio signals to the rear speakers using the rear speaker circuits.

### Diagnosis Procedure

INFOID:000000001502548

#### 1. HARNESS CHECK

1. Disconnect audio unit connector M43 (A) and suspect speaker connector.
2. Check continuity between audio unit harness connector M43 (A) and suspect speaker harness connector (B).

Terminals				Continuity
Audio unit		Speaker		
Connector	Terminal	Connector	Terminal	
A: M43	4	B: B26	1	Yes
	5		2	
	13	B: B44	1	
	14		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.


Terminals				Continuity
Audio unit		—		
Connector	Terminal			
A: M43	4	Ground		No
	5			
	13			
	14			

Are the continuity results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

#### 2. REAR SPEAKER SIGNAL CHECK



AWNIA0033ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# REAR SPEAKER

[BASE AUDIO]

## < COMPONENT DIAGNOSIS >


1. Connect audio unit connector and rear speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT-III or oscilloscope.

Terminals				Condi- tion	Reference signal
(+) (+)		(-) (-)			
Con- nector	Termi- nal	Con- nector	Terminal		
M43	4	M43	5	Receive audio signal	
	13		14		

SKIA0177E

Is the audio signal voltage as specified?

- YES >> Replace rear speaker. Refer to [AV-48, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).



AVNIA0034ZZ

# STEERING SWITCH

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## STEERING SWITCH

### Description

INFOID:000000001502549

When one of the steering wheel audio control switches is pushed, the resistance in steering switch circuit changes depending on which button is pushed.


### Diagnosis Procedure

INFOID:000000001502550

#### 1. CHECK STEERING SWITCH RESISTANCE

1. Disconnect steering switch connector M88.
2. Check resistance between steering switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
15	17	Seek (down)	Depress (station) down switch.	165
		Volume (down)	Depress volume down switch.	487
14	17	Seek (up)	Depress (station) up switch.	165
		Source	Depress source switch.	0
		Volume (up)	Depress volume up switch.	487



Do the steering switches check OK?


YES >> GO TO 2

NO >> Replace steering switch. Refer to [AV-53. "Removal and Installation"](#).

#### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M43 (A) and spiral cable connector M30 (B).
3. Check continuity between spiral cable harness connector M30 (B) and audio unit harness connector M43 (A).

Terminals				Continuity
Spiral cable		Audio Unit		
Connector	Terminal	Connector	Terminal	
B: M30	24	A: M43	6	Yes
	31		16	
	33		15	



4. Check continuity between audio unit connector M43 (A) and ground.

Terminals			Continuity
Audio unit		—	
Connector	Terminal		
A: M43	6	Ground	No
	15		
	16		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness.

#### 3. SPIRAL CABLE CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV


# STEERING SWITCH

[BASE AUDIO]

## < COMPONENT DIAGNOSIS >

1. Disconnect spiral cable connector M88 (B).
2. Check continuity between spiral cable harness connector M30 (A) and M88 (B).

Terminals				Continuity
Spiral cable				
Connector	Terminal	Connector	Terminal	
A: M30	24	B: M88	14	Yes
	31		15	
	33		17	



### Does the spiral cable check OK?

- YES >> Inspection End.  
 NO >> Replace spiral cable. Refer to [SRS-6. "Removal and Installation"](#).



## COMMUNICATION SIGNAL CIRCUIT

### SATELLITE RADIO TUNER

#### SATELLITE RADIO TUNER : Description

INFOID:000000001502551

Communication signals are exchanged between the audio unit and satellite radio tuner using the communication circuits.

#### SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001502552

### 1. CHECK HARNESS - 1

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 and audio unit connector M45.
3. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 28 and audio unit harness connector M45 (B) terminal 38.


**Continuity should exist.**

4. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 28 and ground.

**Continuity should not exist.**

Are continuity results as specified?

- YES >> GO TO 2  
 NO >> Repair harness or connector.



### 2. CHECK HARNESS - 2

1. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 29 and audio unit harness connector M45 (B) terminal 39.


**Continuity should exist.**

2. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 29 and ground.

**Continuity should not exist.**

Are continuity results as specified?

- YES >> GO TO 3  
 NO >> Repair harness or connector.



### 3. CHECK HARNESS - 3

1. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 30 and audio unit harness connector M45 (B) terminal 40.


**Continuity should exist.**

2. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 30 and ground.

**Continuity should not exist.**

Are continuity results as specified?

- YES >> GO TO 4  
 NO >> Repair harness or connector.



### 4. CHECK REQ1 SIGNAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P



# COMMUNICATION SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

1. Connect satellite radio tuner (factory installed) connector and audio unit connector.
2. Turn ignition switch to ACC
3. Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 28 and ground with CONSULT-III or oscilloscope.

## 28 - Ground



Are voltage readings as specified?



YES >> GO TO 5

NO >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).

## 5. CHECK TXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 29 and ground with CONSULT-III or oscilloscope.

## 29 - Ground



Are the voltage readings as specified?



YES >> GO TO 6

NO >> Replace satellite radio tuner.

## 6. CHECK RXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 30 and ground with CONSULT-III or oscilloscope.

## 30 - Ground



Are the voltage readings as specified?

YES >> Replace satellite radio tuner.

NO >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).

# SOUND SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## SOUND SIGNAL CIRCUIT SATELLITE RADIO TUNER

### SATELLITE RADIO TUNER : Description

INFOID:000000001502553

Left and right channel audio signals are supplied from the satellite radio tuner to the audio unit through the sound signal circuits.


### SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001502554

#### LEFT CHANNEL

#### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 (A) and audio unit connector M45 (B).
3. Check continuity between satellite radio tuner (factory installed) and audio unit.



Terminals				Continuity
Satellite radio tuner		Audio unit		
Connector	Terminal	Connector	Terminal	
A: B123	21	B: M45	31	Yes
	22		32	

4. Check continuity between satellite radio tuner (factory installed) and ground.

Terminals				Continuity
Satellite radio tuner		—		
Connector	Terminal			
A: B123	21	Ground		No
	22			

Are continuity results as specified?



YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK LEFT CHANNEL AUDIO SIGNAL

1. Connect satellite radio tuner (factory installed) and audio unit.
2. Turn ignition switch ON.
3. Check signal between satellite radio tuner (factory installed) connector B123 terminals 21 and 22 with CONSULT-III or oscilloscope.

21 - 22



Are voltage readings as specified?

YES >> Replace audio unit. Refer to [AV-45. "Removal and Installation"](#).

NO >> Replace satellite radio tuner. Refer to [AV-133. "Removal and Installation"](#).

#### RIGHT CHANNEL

# SOUND SIGNAL CIRCUIT


< COMPONENT DIAGNOSIS >

[BASE AUDIO]

## 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 (A) and audio unit connector M45 (B).
3. Check continuity between satellite radio tuner (factory installed) and audio unit.

Terminals				Continuity
Satellite radio tuner		Audio unit		
Connector	Terminal	Connector	Terminal	
A: B123	23	B: M45	33	Yes
	24		34	



4. Check continuity between satellite radio tuner (factory installed) and ground.

Terminals			Continuity
Satellite radio tuner		—	
Connector	Terminal		
A: B123	23	Ground	No
	24		

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.


## 2. CHECK RIGHT CHANNEL AUDIO SIGNAL

1. Connect satellite radio tuner (factory installed) and audio unit.
2. Turn ignition switch ON.
3. Check signal between satellite radio tuner (factory installed) connector B123 terminals 23 and 24 with CONSULT-III or oscilloscope.

**23 - 24**



SKIB3609E



Are voltage readings as specified?

YES >> Replace audio unit. Refer to [AV-45. "Removal and Installation"](#).

NO >> Replace satellite radio tuner. Refer to [AV-133. "Removal and Installation"](#).

# AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]


## ECU DIAGNOSIS

### AUDIO UNIT

#### Reference Value

INFOID:000000001502555

#### TERMINAL LAYOUT






#### PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/output	Condition		Reference value	Example of symptom
+	-			Ignition switch	Operation		
2 (W)	3 (B)	Audio sound signal front LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from front door speaker LH or tweeter LH.
4 (O/B)	5 (W/R)	Audio sound signal rear LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from rear speaker LH.
6 (W/G)	Ground	Remote control A	Input	ON	Press SOURCE switch	Approx. 0.0V	Steering wheel audio controls do not function
					Press SEEK UP switch	Approx. 0.75V	
					Press VOL UP switch	Approx. 2.0V	
					Except for above	Approx. 5.0V	
7 (V/Y)	Ground	ACC signal	Input	ON	Ignition switch ACC or ON	Battery voltage	System does not work properly.
11 (G/W)	12 (BR)	Audio sound signal front RH	Output	ON	Receive audio signal	 SKIA0177E	No sound from front door speaker RH or tweeter RH.

# AUDIO UNIT

< ECU DIAGNOSIS >



[BASE AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
13 (L)	14 (B/W)	Audio sound signal rear RH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear speaker RH.
15 (L/B)	-	Remote control ground	Input	-	-	-	Steering wheel au- dio controls do not function
16 (GR/L)	Ground	Remote control B	Input	ON	Press SEEK DOWN switch	Approx. 0.75V	Steering wheel au- dio controls do not function
					Press VOL DOWN switch	Approx. 2.0V	
					Except for above	Approx. 5.0V	
19 (Y/R)	Ground	Battery pow- er	Input	-	-	Battery voltage	System will not work properly.
32 (Y/L)	31 (W/L)	Audio left channel sound signal from satel- lite radio tuner	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from sat- ellite radio tuner left channel.
34 (BR/L)	33 (Y/G)	Audio right channel sound signal from satel- lite radio tuner	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from sat- ellite radio tuner right channel.
35	-	Shield ground (au- dio signal)	-	-	-	0V	-
36	-	Shield ground (da- ta)	-	-	-	0V	-

# AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
38 (R)	Ground	Satellite ra- dio tuner re- quest to audio unit	Input	ON	Turn audio unit ON	5V	Satellite radio tun- er does not oper- ate properly.
39 (G)	Ground	Audio RX	Input		Operate audio volume		Satellite radio tun- er audio informa- tion does not display properly.
40 (B)	Ground	Audio TX	Output		Operate audio volume		Satellite radio tun- er audio informa- tion does not display properly.
75 (B)	Ground	Amp power supply	Output	ON	Turn audio unit ON	Battery voltage	-
76 (B)	Ground	Main anten- na	Input	ON	Turn audio unit ON	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


# AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

## Wiring Diagram

INFOID:000000001502556





ALNWA0041GE



BASE AUDIO CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	V/Y	-
2	Y/G	-
3	SHIELD	-
4	W/L	-
5	R	-
18	BR/L	-
19	Y/L	-
20	B	-
21	SHIELD	-
22	G	-
25	Y/R	-

Terminal No.	Color of Wire	Signal Name
64G	Y/R	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
80J	B/W	-
82J	L	-
96J	O/B	-
97J	W/R	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS >


[BASE AUDIO]

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	W/G	AUDIO_STRG_SW_REMOTE_A
31	GR/L	AUDIO_STRG_SW_REMOTE_B
33	L/B	AUDIO_STRG_SW_GND

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-


Connector No.	M45
Connector Name	AUDIO UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
31	W/L	SAT LH INPUT (-)
32	Y/L	SAT LH INPUT (+)
33	Y/G	SAT RH INPUT (-)
34	BR/L	SAT RH INPUT (+)
35	SHIELD	EARTH
36	SHIELD	DAT EARTH
37	-	-
38	R	RFQ1 (SAT TO COMBI)
39	G	RX (SAT TO COMBI)
40	B	TX (COMBI TO SAT)
41	-	-
42	-	-

Terminal No.	Color of Wire	Signal Name
6	W/G	STRG_SW_A
7	V/Y	ACC
8	R/Y	ILL_CONT_OUT
9	R/L	TAIL/ILL_RLY
10	-	-
11	G/W	FR SP RH (+)
12	BR	FR SP RH (-)
13	L	RR SP RH (+)
14	B/W	RR SP RH (-)
15	L/B	STRG_SW_GND
16	GR/L	STRG_SW_B
17	-	-
18	-	-
19	Y/R	BAT
20	-	-

Connector No.	M43
Connector Name	AUDIO UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	W	FR SP LH (+)
3	B	FR SP LH (-)
4	O/B	RR SP LH (+)
5	W/R	RR SP LH (-)

ALNIA0028GB

# AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

Connector No.	M81
Connector Name	AUDIO UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
75	B	AMP POWER SUPPLY
76	B	MAIN ANTENNA
77	-	-

Connector No.	M52
Connector Name	TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	BR	-

Connector No.	M51
Connector Name	TWEETER LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	M93
Connector Name	ROOF ANTENNA (AUDIO)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M88
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
14	W	REMOTE A
15	L	REMOTE B
17	BR	GND

Connector No.	M87
Connector Name	WINDOW ANTENNA
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-


ALNIA0160GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

Terminal No.	Color of Wire	Signal Name
80J	B/W	-
82J	L	-
96J	O/B	-
97J	W/R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
64G	Y/R	-

Connector No.	B44
Connector Name	REAR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B/W	-

Connector No.	B26
Connector Name	REAR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	W/R	-


# AUDIO UNIT

< ECU DIAGNOSIS >


[BASE AUDIO]

Terminal No.	Color of Wire	Signal Name
21	W/L	SAT_LCH (-)
22	Y/L	SAT_LCH (+)
23	Y/G	SAT_RCH (-)
24	BR/L	SAT_RCH (+)
25	SHIELD	EARTH (SIG)
26	SHIELD	DATA
27	-	-
28	R/L	EC1 (SAT-COMBI)
29	R/W	TXD (SAT_COMBI)
30	B	RXD (COMBI_SAT)
31	-	-
32	Y/R	BAT
33	-	-
34	-	-
35	-	-
36	GR/W	ACC

Connector No.	B123
Connector Name	SATELLITE RADIO TUNER OR PRE-WIRING FOR SATELLITE RADIO TUNER
Connector Color	WHITE



Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/W	-
2	Y/G	-
3	SHIELD	-
4	W/L	-
5	R/L	-
18	BR/L	-
19	Y/L	-
20	B	-
21	SHIELD	-
22	R/W	-
25	Y/R	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B132
Connector Name	ROOF ANTENNA (SATELLITE)
Connector Color	GRAY (WITH SIRIUS SATELLITE RADIO) BROWN (WITH XM SATELLITE RADIO)



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-

Connector No.	B129
Connector Name	SATELLITE RADIO TUNER OR PRE-WIRING FOR SATELLITE RADIO TUNER
Connector Color	BROWN (WITH SIRIUS SATELLITE RADIO) VIOLET (WITH XM SATELLITE RADIO)



Terminal No.	Color of Wire	Signal Name
37	B	ANTENNA SIGNAL

ALNIA0161GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

Connector No.	D103
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	BR	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

Connector No.	D3
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

# SATELLITE RADIO TUNER

< ECU DIAGNOSIS >


[BASE AUDIO]

## SATELLITE RADIO TUNER

Reference Value

INFOID:000000001502557

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Voltage (approx.)
+	-			Ignition switch	Operation	
22 (Y/L)	21 (W/L)	Audio signal LH	Output	ON	Receive audio signal.	<p>SKIB3609E</p>
24 (BR/L)	23 (Y/G)	Audio signal RH	Output	ON	Receive audio signal.	<p>SKIB3609E</p>
25	-	Shield	-	-	-	-
26	-	Data ground	-	ON	-	Approx. 0 V
28 (R/L)	Ground	REQ1 (SAT-AUDIO)	Output	ON	Set to the satellite radio mode	<p>SKIB3825E</p>
29 (R/W)	Ground	Communication signal (SAT-AUDIO)	Output	ON	Set to the satellite radio mode	<p>SKIB3824E</p>


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BASE AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Voltage (approx.)
+	-			Ignition switch	Operation	
30 (B)	Ground	Communication signal (AUDIO-SAT)	Input	ON	Set to the satellite radio mode	 <p style="text-align: right; font-size: small;">SKIB3826E</p>
32 (Y/R)	Ground	Battery power supply	Input	OFF	-	Battery voltage
36 (GR/W)		ACC power supply		ACC		
37 (B)	-	Antenna signal	-	-	-	-

## Wiring Diagram

INFOID:000000001502558

Refer to [AV-32, "Wiring Diagram"](#).



# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

## SYMPTOM DIAGNOSIS

### AUDIO SYSTEM

#### AUDIO UNIT

#### AUDIO UNIT : Symptom Table

INFOID:000000001502559

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"><li>Audio unit power circuit</li><li>Audio unit</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-15</a></li><li><a href="#">AV-45</a></li></ul>
Steering switch does not operate	<ul style="list-style-type: none"><li>Steering switch</li><li>Audio unit</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-23</a></li><li><a href="#">AV-45</a></li></ul>
All speakers do not sound	<ul style="list-style-type: none"><li>Audio unit power circuit</li><li>Audio unit</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-15</a></li><li><a href="#">AV-45</a></li></ul>
One or several speakers do not sound	<ul style="list-style-type: none"><li>Front door speaker</li><li>Tweeter</li><li>Rear speaker</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-17</a></li><li><a href="#">AV-19</a></li><li><a href="#">AV-21</a></li></ul>

### CD

#### CD : Symptom Table

INFOID:000000001502560

Symptom	Possible cause	Reference page
CD cannot be inserted.	Audio unit	<a href="#">AV-45</a>
CD cannot be ejected.		
The CD cannot be played.		
The sound skips, stops suddenly, or is distorted.		

### SATELLITE RADIO TUNER

#### SATELLITE RADIO TUNER : Symptom Table

INFOID:000000001502561

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"><li>Satellite radio tuner power or ground circuit</li><li>Satellite radio tuner communication circuit</li><li>Satellite radio tuner</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-15</a></li><li><a href="#">AV-25</a></li><li><a href="#">AV-133</a></li></ul>
Right or left channel does not sound	<ul style="list-style-type: none"><li>Satellite radio tuner right channel audio signal circuit</li><li>Satellite radio tuner left channel audio signal circuit</li><li>Satellite radio tuner</li></ul>	<ul style="list-style-type: none"><li><a href="#">AV-27</a></li><li><a href="#">AV-27</a></li><li><a href="#">AV-133</a></li></ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000001502562

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

### NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"><li>• Ignition components</li></ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"><li>• Fuel pump condenser</li></ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"><li>• Relay malfunction, audio unit malfunction</li></ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"><li>• Motor case ground</li><li>• Motor</li></ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"><li>• Rear defogger coil malfunction</li><li>• Open circuit in printed heater</li><li>• Poor ground of antenna feeder line</li></ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"><li>• Ground wire of body parts</li><li>• Ground due to improper part installation</li><li>• Wiring connections or a short circuit</li></ul>

# PRECAUTION

## PRECAUTIONS

### Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001502563

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000001502564


Tool name	Description
<p data-bbox="175 516 285 541">Power tool</p>  <p data-bbox="850 632 919 646">PBIC0191E</p>	<p data-bbox="1005 411 1256 438">Loosening bolts and nuts</p>

**ON-VEHICLE REPAIR****AUDIO UNIT****Removal and Installation**

INFOID:000000001502565

**REMOVAL**

1. Disconnect the 12-volt battery negative terminal.
2. Remove the cluster lid D. Refer to [IP-11, "Removal and Installation"](#).
3. Remove the cluster lid D screws (A), then remove the audio unit screws (B) and the audio unit (1).

**INSTALLATION**

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


## TWEETER

### Removal and Installation

INFOID:000000001502566

#### REMOVAL

1. Remove the front pillar finisher. Refer to [INT-18, "Removal and Installation"](#).
2. Remove tweeter speaker grille. Refer to [IP-11, "Removal and Installation"](#).
3. Remove the tweeter speaker screws (A), disconnect the tweeter speaker connector and remove the tweeter speaker (1).



ALNIA0180GB

#### INSTALLATION

Installation is in the reverse order of removal.

# FRONT DOOR SPEAKER

< ON-VEHICLE REPAIR >

[BASE AUDIO]


## FRONT DOOR SPEAKER

### Removal and Installation

INFOID:000000001502567

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-11, "Removal and Installation"](#).
2. Remove the front door speaker screws (A), then disconnect the front door speaker connector and remove the front door speaker (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


## REAR SPEAKER

### Removal and Installation

INFOID:000000001502568

#### REMOVAL

1. Remove the rear parcel shelf finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the rear speaker screws (A), then disconnect the rear speaker connector and remove the rear speaker (1).



#### INSTALLATION


Installation is in the reverse order of removal.



## AUDIO ANTENNA

### Location of Antennas

INFOID:000000001502569



- |                                 |                       |                                   |
|---------------------------------|-----------------------|-----------------------------------|
| 1. Audio unit harness connector | 2. Audio unit harness | 3. Audio unit                     |
| 4. Roof antenna rod             | 5. Roof antenna base  | 6. Antenna feeder (to audio unit) |
| 7. Satellite feeder             | 8. Window antenna     | 9. Satellite radio tuner          |

### Roof Antenna

INFOID:000000001502570

#### REMOVAL AND INSTALLATION

##### Removal

1. Remove the rear parcel shelf finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the rear assist grips. Refer to [INT-18, "Removal and Installation"](#).
3. Pull down headlining (rear) and obtain space work between roof and headlining.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# AUDIO ANTENNA

< ON-VEHICLE REPAIR >

[BASE AUDIO]

4. Remove the roof antenna nut (A), then disconnect the antenna feeder connector (B) and remove the antenna feeder (1) from the roof.
5. Detach the antenna feeder harness wire clips, then disconnect the antenna feeder harness wire end and feed the antenna feeder harness through the roof to remove the roof antenna base.



Installation


Installation is in the reverse order of removal.

## Window Antenna Repair


INFOID:000000001502571

### ELEMENT CHECK

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.



- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.




# AUDIO ANTENNA


< ON-VEHICLE REPAIR >

[BASE AUDIO]

- If an element is broken, no continuity will exist.



- To locate a break, move probe along element. Tester indication will change abruptly when probe passes the broken point.




## REPAIR EQUIPMENT

- Conductive silver composition (DuPont No. 4817 or equivalent)
- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

## REPAIRING PROCEDURE

- Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
- Apply a small amount of conductive silver composition to tip of drawing pen. Shake silver composition container before use.
- Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO ANTENNA


## < ON-VEHICLE REPAIR >

[BASE AUDIO]

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited. Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.




## STEERING SWITCH

### Removal and Installation

INFOID:000000001502572

#### REMOVAL

1. Remove the driver airbag module. Refer to [SRS-4. "Removal and Installation"](#).
2. Remove the steering wheel switch assembly screws (A), then remove the steering wheel switches (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000001502573

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

# DIAGNOSIS AND REPAIR WORKFLOW

[BOSE AUDIO WITHOUT NAVIGATION]

< BASIC INSPECTION >

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

## 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

## 5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

## FUNCTION DIAGNOSIS

### AUDIO SYSTEM

#### System Diagram



#### System Description

INFOID:000000001502575

#### AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- BOSE speaker amp.
- Window antenna
- Roof antenna (audio)
- Steering switches
- Front door speakers
- Tweeters
- Center speaker
- Rear door speakers
- Woofers

When the audio system is on, radio signals are received by the roof antenna (audio) and the window antenna. The audio unit then sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers, tweeters, center speaker, rear door speakers and woofers.

Refer to Owner's Manual for audio system operating instructions.

#### SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Roof antenna (satellite)
- Satellite radio tuner

When the satellite radio system is on, radio signals are supplied to the satellite radio tuner from the satellite antenna. The satellite radio tuner then sends audio signals to the audio unit.

Refer to Owner's Manual for satellite radio system operating instructions.

#### SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system goes up and down automatically in proportion to the vehicle speed. The control level can be selected by the customer. Refer to Owner's Manual for operating instructions.




# AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## Component Parts Location

INFOID:000000001502576



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

- |                                  |  |                        |
|----------------------------------|--|------------------------|
| 1. Tweeter LH M51                | 2. Steering wheel audio control switches | 3. Tweeter RH M52      |
| 4. Audio unit M43, M44, M45, M81 | 5. Combination meter M24                 | 6. Center speaker M151 |

AWNIA0089GB

# AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

- |   |   |  |
|---|---|--|
| 7. Front door speaker<br>LH D3<br>RH D103   | 8. Rear subwoofer RH B124   | 9. Rear subwoofer LH B120  |
| 10. Rear door speaker<br>LH D202<br>RH D302 | 11. Satellite radio tuner B123, B129<br>(viewed under parcel shelf near rear<br>speaker LH) | 12. Bluetooth control unit B125, B126<br>(viewed under parcel shelf near rear<br>speaker LH) |
| 13. Microphone R7                           | 14. BOSE speaker amp B121, B122<br>(view with rear seat back removed)                       |  |

## Component Description

INFOID:000000001502577

Part name	Description
Audio unit	Controls audio system and satellite radio system functions
BOSE speaker amp.	Receives power (amp ON) and audio signals from audio unit, and outputs audio signals to each speaker.
Steering switches	<ul style="list-style-type: none"><li>• Each audio operation can be operated</li><li>• Steering switch signal (operation signal) is output to audio unit</li></ul>
Front door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Tweeters	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high range sounds</li></ul>
Center speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high range sounds</li></ul>
Rear door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Woofers	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs low range sounds</li></ul>
Satellite radio tuner	<ul style="list-style-type: none"><li>• Receives radio signals from satellite antenna</li><li>• Sends audio signals to audio unit</li></ul>
Satellite antenna	Audio signal (satellite radio) is received and output to audio unit.


# HANDS-FREE PHONE SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## HANDS-FREE PHONE SYSTEM

### System Diagram



### System Description

Refer to the owner's manual for Bluetooth telephone system operating instructions.

#### NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth telephone system.

Bluetooth telephone system allows users who have a Bluetooth cellular telephone to make a wireless connection between their cellular telephone and the Bluetooth control unit. Hands-free cellular telephone calls can be sent and received. Personal memos can be created using the Nissan Voice Recognition system. Some Bluetooth cellular telephones may not be recognized by the Bluetooth control unit. When a cellular telephone or the Bluetooth control unit is replaced, the telephone must be paired with the Bluetooth control unit. Different cellular telephones may have different pairing procedures. Refer to the cellular telephone operating manual.

#### BLUETOOTH CONTROL UNIT

When the ignition switch is turned to ACC or ON, the Bluetooth control unit will power up. During power up, the Bluetooth control unit is initialized and performs various self checks. Initialization may take up to 10 seconds. If a phone is present in the vehicle and paired with the Bluetooth control unit, Nissan Voice Recognition will then become active. Bluetooth telephone functions can be turned off using the Nissan Voice Recognition system.

#### STEERING WHEEL AUDIO CONTROL SWITCHES

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes depending on which button is pushed. The Bluetooth control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate Self Diagnosis of the Bluetooth telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

#### MICROPHONE

The microphone is located in the roof console assembly. The microphone sends a signal to the Bluetooth control unit. The microphone can be actively tested during self-diagnosis.

#### AUDIO UNIT

The audio unit receives signals from the Bluetooth control unit and sends audio signals to the speakers.

### Component Parts Location

Refer to [AV-57, "Component Parts Location"](#).

# HANDS-FREE PHONE SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< FUNCTION DIAGNOSIS >

## Component Description

INFOID:000000001502581

Part name	Description
Audio unit	<ul style="list-style-type: none"><li>• Receives telephone voice signal from Bluetooth control unit</li><li>• Sends telephone voice and voice guidance signals to BOSE speaker amp.</li></ul>
BOSE speaker amp.	Inputs power (amp ON) and sound signal from audio unit, and outputs sound signal to each speaker.
Front door speaker	Receives telephone voice and voice guidance signals from BOSE speaker amp.
Tweeter	
Center speaker	
Steering switches	<ul style="list-style-type: none"><li>• Start a voice recognition session</li><li>• Answer and end telephone calls</li><li>• Adjust the volume level</li></ul>
Microphone	Sends voice signals to Bluetooth control unit
Bluetooth control unit	Controls hands-free phone functions
Bluetooth antenna	Sends telephone voice signal to bluetooth control unit

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[BOSE AUDIO WITHOUT NAVIGATION]

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (AUDIO UNIT)

### Diagnosis Description


INFOID:000000001502582

Self-diagnosis mode can check the following items.


- Audio unit hardware/software versions
- Continuity of each speaker channel
- Continuity of each audio unit switch

### OPERATION PROCEDURE

1. Turn ignition switch to the ACC position.
2. Turn the audio unit off.
3. While pressing the “AUDIO” button, turn the volume control dial clockwise or counterclockwise 30 clicks or more. When the self-diagnosis mode is started, a short beep will be heard.




4. Initially, all display segments will be illuminated.



### Version Check

1. Press the “AUDIO” switch to enter version diagnostics. “Software” (audio software version) is displayed.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[BOSE AUDIO WITHOUT NAVIGATION]

< FUNCTION DIAGNOSIS >

2. Press the "AUDIO" switch again to display the "Hardware" (audio hardware version).



3. Press the "AUDIO" switch again to display the "CD Mech" (CD mechanism version).




4. Press the "AUDIO" switch again to display the "SDARS" (satellite radio version).



## Channel Check Diagnostics

When all segments are illuminated, press the "TUNE" up switch to enter channel check diagnostics. The self-diagnostic function will then send a tone to each channel (FL, RL, RR, FR) for 1 second.




## Button Check Diagnostics

# DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

When all segments are illuminated, press the "TUNE" down switch to enter button check diagnostics. When each audio unit switch is pressed, a tone will sound and the switch name will be displayed.



- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

AV

# DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

### Diagnosis Description

INFOID:000000001502583


The Bluetooth control unit has two diagnostic checks. The first diagnostic check is performed automatically every ignition cycle during control unit initialization. The second diagnostic check is performed by the technician using the steering wheel audio control switches prior to trouble diagnosis.

### BLUETOOTH CONTROL UNIT INITIALIZATION CHECKS


- Internal control unit failure
- Bluetooth antenna connection open or shorted
- Steering wheel audio control switches (SEND/END) stuck closed
- Vehicle speed pulse count
- Microphone connection test (with playback to operator)
- Bluetooth inquiry check

### OPERATION PROCEDURE

1. Turn ignition switch to ACC or ON.
2. Wait for the Bluetooth system to complete initialization. This may take up to 10 seconds.
3. Press and hold the steering wheel audio control switch SEND button for at least 5 seconds. The Bluetooth system will begin to play a verbal prompt.



4. While the prompt is playing, press and hold the steering wheel audio control switch END button until you hear the “Diagnostics mode” prompt. The Bluetooth system will sound a 5 second beep.
5. While the beep is sounding, press and hold the steering wheel audio control switch END button again until you hear prompts.
6. The Bluetooth system has now entered into the diagnostic mode. Results of the diagnostic checks will be verbalized to the technician. Refer to [AV-64, "Work Flow"](#).
7. After the failure records are reported, an interactive microphone test will be performed. Follow the voice prompt. If the microphone test fails refer to [AV-64, "Work Flow"](#).
8. Self-diagnosis mode is complete when the voice prompt says “All diagnostic functions completed”.



### Work Flow

INFOID:000000001502584

Failure Message	Action
“Internal failure”	Replace Bluetooth control unit. Refer to <a href="#">AV-138, "Removal and Installation"</a> .
“Bluetooth antenna open”	1. Inspect harness connection.
“Bluetooth antenna shorted”	2. Replace Bluetooth antenna. Refer to <a href="#">AV-137, "Removal and Installation"</a> .
“Phone/Send for Hands Free System is stuck”	Check steering wheel audio control switches. Refer to <a href="#">AV-85, "Diagnosis Procedure"</a> .
“Phone/End for the Hands Free System is stuck”	
“Microphone test” (failed interactive test)	1. Inspect harness between Bluetooth control unit and microphone. 2. Replace microphone. Refer to <a href="#">AV-136, "Removal and Installation"</a> .



# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

#### AUDIO UNIT : Diagnosis Procedure

INFOID:000000001502585

#### 1.CHECK FUSE

Check that the following fuses of the audio unit are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	24
	7	Ignition switch ACC or ON	19

Are the fuses OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

#### 2.AUDIO UNIT POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector.
2. Check voltage between the audio unit and ground.

Unit	Terminal No.			OFF	ACC	ON
	(+)		(-)			
	Connector	Terminal				
Audio unit	M43	19	Ground	Battery voltage	Battery voltage	Battery voltage
		7	Ground	0V	Battery voltage	Battery voltage



Are the voltage readings as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 3.GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair audio unit case ground.

### BOSE SPEAKER AMP

#### BOSE SPEAKER AMP : Diagnosis Procedure

INFOID:000000001502586

#### 1.CHECK FUSE

Check for blown fuses.

Unit	Terminals	Signal name	Fuse No.
BOSE speaker amp.	50	Battery power	25
	51		26

Are the fuses OK?

YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2.CHECK POWER SUPPLY CIRCUIT


# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp connector.
3. Check voltage between BOSE speaker amp harness connector and ground.

Unit	Terminal No.		(-)	Voltage (approx.)
	(+)			
	Connector	Terminal		
BOSE speaker amp	B122	50	Ground	Battery voltage
		51		




### Is battery voltage present?

- YES >> GO TO 3  
 NO >> Check harness between BOSE speaker amp and fuse.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp connector.
3. Check continuity between BOSE speaker amp harness connector and ground.

Unit	Terminal No.		(-)	Continuity
	(+)			
	Connector	Terminal		
BOSE speaker amp	B122	47	Ground	Yes
		52		



### Does continuity exist?

- YES >> Inspection End.  
 NO >> Repair harness or connector.

## SATELLITE RADIO TUNER

### SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001502567

## 1.CHECK FUSES

Check that the following fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
Satellite radio tuner (factory installed)	32	Battery power	24
	36	Ignition switch ACC or ON	19

### Are the fuses OK?

- YES >> GO TO 2  
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.


## 2.POWER SUPPLY CIRCUIT CHECK

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123.
3. Check voltage between the satellite radio tuner (factory installed) and ground.



Unit	Terminal No.			OFF	ACC	ON
	(+)		(-)			
	Connector	Terminal				
Satellite radiotuner (factory installed)	B123	32	Ground	Battery voltage	Battery voltage	Battery voltage
		36	Ground	0V	Battery voltage	Battery voltage

Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 3. GROUND CIRCUIT CHECK

Inspect satellite radio tuner (factory installed) case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair satellite radio tuner (factory installed) case ground.

## BLUETOOTH CONTROL UNIT

### BLUETOOTH CONTROL UNIT : Diagnosis Procedure

INFOID:000000001502588

#### 1. CHECK FUSE

Check that the following fuses of the Bluetooth control unit are not blown.

Power source	Fuse No.
Battery	24
Ignition switch ACC or ON	19
Ignition switch ON or START	3

Are the fuses OK?


YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between Bluetooth control unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Battery power supply	B126	1	OFF	Battery voltage
ACC power supply		2	ACC	
Ignition signal		3	ON	



Are the voltage results as specified?

YES >> GO TO 3

NO >> Check harness between Bluetooth control unit and fuse.

# POWER SUPPLY AND GROUND CIRCUIT


[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector B126.
3. Check continuity between Bluetooth control unit harness connector and ground.

Unit	Terminal No.		Continuity
	(+)		
	Connector	Terminal	
Ground	B126	4	Ground
		24	



Does continuity exist?

- YES >> Inspection End.  
 NO >> Repair harness or connector.

## MICROPHONE


### MICROPHONE : Diagnosis Procedure

INFOID:000000001502589

## 1. CHECK POWER SUPPLY CIRCUIT (MICROPHONE SIDE)

Check voltage between microphone harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Microphone VCC signal	R7	4	ON	5V



Is proper voltage present?

- YES >> GO TO 4  
 NO >> GO TO 2


## 2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit and microphone connectors.
3. Check continuity between microphone harness connector R7 (A) terminal 4 and Bluetooth control unit harness connector B126 (B) terminal 29.

Signal name	Continuity
Microphone VCC signal	Continuity should exist.

4. Check continuity between microphone harness connector R7 (A) terminal 4 and ground.

Signal name	Continuity
Microphone VCC signal	Continuity should not exist.



Are continuity results as specified?

- YES >> GO TO 3  
 NO >> Repair harness or connector.

## 3. CHECK POWER SUPPLY CIRCUIT (BLUETOOTH CONTROL UNIT SIDE)

# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >


1. Connect Bluetooth control unit connector.
2. Turn ignition switch ON.
3. Check voltage between Bluetooth control unit harness connector and ground.

Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
B126	29	ON	5V

Is proper voltage present?

YES >> Inspection End.

NO >> Replace Bluetooth control unit. Refer to [AV-138](#).  
["Removal and Installation"](#).



## 4.CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit and microphone connectors.
3. Check continuity between microphone harness connector R7 terminal 2 and Bluetooth control unit harness connector B126 terminal 8.

Signal name	Continuity
Microphone ground	Continuity should exist.

Is continuity present?

YES >> Inspection End.

NO >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## FRONT DOOR SPEAKER

### Description

INFOID:000000001502590

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502591

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B121 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connector B121 (A) and suspect speaker harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B121	58	D3	1	Yes
	59		2	
	71	D103	1	
	72		2	


3. Check continuity between BOSE speaker amp. harness connector B121 (A) and ground.

Terminals			Continuity
A		B	
Connector	Terminal		
B121	58	Ground	No
	59		
	71		
	72		

Are continuity test results as specified?

- YES >> GO TO 2  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

#### 2. FRONT SPEAKER SIGNAL CHECK




# FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B121 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B121 terminals with CONSULT-III or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B121	58	59	Receive audio signal	
	71	72		



Is audio signal voltage as specified?

YES >> Replace suspect speaker. Refer to [AV-130. "Removal and Installation"](#).

NO >> GO TO 3

## 3. HARNESS CHECK

1. Disconnect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M43 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between audio unit harness connector M43 (A) and ground.


Terminals			Continuity
A		—	
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are continuity test results as specified?

YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. FRONT SPEAKER SIGNAL CHECK




# FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >


1. Connect audio unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-127, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-126, "Removal and Installation"](#).



WKIA5352E



# TWEETER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## TWEETER

### Description

INFOID:000000001502592

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the tweeters using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502593

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B122 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connector B122 (A) and suspect tweeter harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B122	41	M51	1	Yes
	42		2	
	44	M52	1	
	43		2	

3. Check continuity between BOSE speaker amp. harness connector B122 (A) and ground.


Terminals				Continuity
A		—		
Connector	Terminal			
B122	41	Ground		No
	42			
	44			
	43			

Are continuity test results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. TWEETER SIGNAL CHECK



ALNIA0137ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B122 and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B122 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B122	41	42	Receive audio signal	
	44	43		

SKIA0177E

Are the audio signal voltage readings as specified?

YES >> Replace suspect tweeter. Refer to [AV-128, "Removal and Installation"](#).

NO >> GO TO 3

### 3. HARNESS CHECK

1. Disconnect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M43 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between audio unit harness connector M43 (A) and ground.


Terminals			Continuity
A		—	
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are continuity test results as specified?


YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

### 4. TWEETER SIGNAL CHECK



ALNIA0138ZZ




ALNIA0136ZZ

# TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >


1. Connect audio unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-127, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-126, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# CENTER SPEAKER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## CENTER SPEAKER

### Description

INFOID:000000001502594

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the center speaker using the audio signal circuits.


### Diagnosis Procedure

INFOID:000000001502595

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B121 and center speaker connector M151.
2. Check continuity between BOSE speaker amp. harness connector B121 (A) and center speaker harness connector M151 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B121	69	M151	1	Yes
	70		2	



3. Check continuity between BOSE speaker amp. harness connector B121 (A) and ground.

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B121	69	Ground	—	No
	70		—	

Are continuity test results as specified?


YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. CENTER SPEAKER SIGNAL CHECK

1. Connect BOSE speaker amp. connector B121 and center speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B121 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B121	69	70	Receive audio signal	



Is the audio signal voltage reading as specified?

YES >> Replace center speaker. Refer to [AV-129. "Removal and Installation"](#).

NO >> GO TO 3

# CENTER SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## 3. HARNESS CHECK

1. Disconnect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M43 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between audio unit harness connector M43 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
M43	2	Ground		No
	3			
	11			
	12			


Are continuity test results as specified?

YES >> GO TO 4

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. CENTER SPEAKER SIGNAL CHECK



1. Connect audio unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-127, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-126, "Removal and Installation"](#).



# REAR DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## REAR DOOR SPEAKER

### Description

INFOID:000000001502596

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502597


#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors B121, B122 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connectors B121 (A) and B122 (B) and suspect speaker harness connector (C).

Terminals				Continuity
Connector	Terminal	Connector	Terminal	
A: B121	55	C: D202	2	Yes
	68		1	
B: B122	49	C: D302	2	
	54		1	

3. Check continuity between BOSE speaker amp. harness connectors B121 (A) and B122 (B) and ground.

Connector	Terminal	-	Continuity
A: B121	55	Ground	No
	68		
B: B122	49		
	54		



Are the continuity test results as specified?

- YES >> GO TO 2  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

#### 2. REAR DOOR SPEAKER SIGNAL CHECK

# REAR DOOR SPEAKER


[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors B121 (A) and B122 (B) terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
A: B121	68	55	Receive audio signal	
B: B122	54	49		

SKIA0177E



Are audio signal voltage readings as specified?

- YES >> Replace suspect speaker. Refer to [AV-131. "Removal and Installation"](#).
- NO >> GO TO 3

## 3. HARNESS CHECK

1. Disconnect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M43 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	4	B121	64	Yes
	5		63	
	13		66	
	14		65	


3. Check continuity between audio unit harness connector M43 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
M43	4	Ground		No
	5			
	13			
	14			

Are the continuity test results as specified?

- YES >> GO TO 4
- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. REAR DOOR SPEAKER SIGNAL CHECK




# REAR DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]


< COMPONENT DIAGNOSIS >

1. Connect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	4	5	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-127, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-126, "Removal and Installation"](#).





# WOOFER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## WOOFER

### Description

INFOID:000000001502598

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the woofers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502599


#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B122 and suspect rear subwoofer connector.
2. Check continuity between BOSE speaker amp. harness connector B122 (A) and suspect rear subwoofer harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B122	53	B120	1	Yes
	48		2	
	45	B124	1	
	46		2	

3. Check continuity between BOSE speaker amp. harness connector B122 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
B122	53	Ground		No
	48			
	45			
	46			



ALNIA0145ZZ

Are the continuity test results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. REAR SUBWOOFER SIGNAL CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# WOOFER

## < COMPONENT DIAGNOSIS >

## [BOSE AUDIO WITHOUT NAVIGATION]

1. Connect BOSE speaker amp. connector B122 and suspect rear subwoofer connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B122 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B122	53	48	Receive audio signal	
	45	46		

SKIA0177E

Is the audio signal voltage as specified?

YES >> Replace suspect rear subwoofer. Refer to [AV-132, "Removal and Installation"](#).

NO >> GO TO 3

### 3. HARNESS CHECK

1. Disconnect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M43 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	4	B121	64	Yes
	5		63	
	13		66	
	14		65	

3. Check continuity between audio unit harness connector M43 (A) terminal and ground.



Terminals			Continuity
A		—	
Connector	Terminal		
M43	4	Ground	No
	5		
	13		
	14		

Are continuity test results as specified?

YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

### 4. REAR SUBWOOFER SIGNAL CHECK




# WOOFER

[BOSE AUDIO WITHOUT NAVIGATION]


## < COMPONENT DIAGNOSIS >

1. Connect audio unit connector M43 and BOSE speaker amp. connector B121.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	4	5	Receive audio signal	 <small>SKIA0177E</small>
	13	14		

Is the audio signal voltage as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-127, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-126, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AMP ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## AMP ON SIGNAL CIRCUIT

### Description

INFOID:000000001502600

When the audio system is turned on, a voltage signal is supplied from the audio unit to the BOSE speaker amp. When this signal is received, the BOSE speaker amp. will turn on.

### Diagnosis Procedure

INFOID:000000001502601


#### 1. CHECK AMP ON SIGNAL (BOSE SPEAKER AMP)

1. Turn audio system ON.
2. Check voltage between BOSE speaker amp. harness connector B121 terminal 60 and ground.

**60 - Ground : More than approx. 6.5V**

Is voltage greater than 6.5V?

- YES >> Inspection End.  
NO >> GO TO 2




#### 2. CHECK AMP ON SIGNAL (AUDIO UNIT)

Check voltage between audio unit harness connector M43 terminal 1 and ground.

**1 - Ground : More than approx. 6.5V**

Is voltage greater than 6.5V?

- YES >> Repair harness or connector.  
NO >> Replace audio unit. Refer to [AV-126. "Removal and Installation"](#).



# STEERING SWITCH

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## STEERING SWITCH

### Description

INFOID:000000001502602

When one of the steering wheel audio control switches is pushed, the resistance in the steering switch circuit changes depending on which button is pushed.


### Diagnosis Procedure

INFOID:000000001502603

#### WITH BLUETOOTH

#### 1.CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector B126 and spiral cable connector M30.
3. Check continuity between Bluetooth control unit connector B126 (A) terminals and spiral cable connector M30 (B) terminals.



Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B126	12	M30	24	Yes
	13		31	
	14		33	

4. Check continuity between Bluetooth control unit B126 (A) and ground.


Terminals				Continuity
A				
Connector	Terminal			
B126	12	Ground		No
	13			
	14			

Are the continuity test results as specified?

- YES >> GO TO 2  
 NO >> Repair harness.

#### 2.CHECK HARNESS

1. Disconnect audio unit connector.
2. Check continuity between audio unit connector M43 (A) terminals and Bluetooth control unit connector B126 (B) terminals.



Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M43	6	B126	17	Yes
	15		19	
	16		18	

Are the continuity test results as specified?

- YES >> GO TO 3  
 NO >> Repair harness.

#### 3.SPIRAL CABLE CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P


# STEERING SWITCH

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Disconnect spiral cable connector M88.
2. Check continuity between spiral cable harness connector M30 and M88.

Terminals				Continuity
Spiral cable				
Connector	Terminal	Connector	Terminal	
M30	24	M88	14	Yes
	31		15	
	33		17	



Are the continuity test results as specified?

YES >> GO TO 4

NO >> Replace spiral cable. Refer to [SRS-6. "Removal and Installation"](#).

## 4. CHECK STEERING SWITCH

Check steering switch. Refer to [AV-87. "Component Inspection"](#).

Does the steering switch pass inspection?

YES >> Replace Bluetooth control unit. Refer to [AV-138. "Removal and Installation"](#)

NO >> Replace steering switch. Refer to [AV-135. "Removal and Installation"](#).

WITHOUT BLUETOOTH

## 1. CHECK STEERING SWITCH

Check steering switch. Refer to [AV-87. "Component Inspection"](#).

Does the steering switch pass inspection?


YES >> GO TO 2

NO >> Replace steering switch. Refer to [AV-53. "Removal and Installation"](#).

## 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M43 and spiral cable connector M30.
3. Check continuity between spiral cable harness connector M30 (B) and audio unit harness connector M43 (A).

Terminals				Continuity
B		A		
Connector	Terminal	Connector	Terminal	
M30	24	M43	6	Yes
	31		16	
	33		15	



4. Check continuity between audio unit connector M43 (A) and ground.

Terminals			Continuity
A			
Connector	Terminal		
M43	6	Ground	No
	15		
	16		

Are the continuity test results as specified?

YES >> GO TO 3

# STEERING SWITCH

[BOSE AUDIO WITHOUT NAVIGATION]


## < COMPONENT DIAGNOSIS >

NO >> Repair harness.

### 3. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M88.
2. Check continuity between spiral cable harness connector M30 and M88.

Terminals				Continuity
Spiral cable				
Connector	Terminal	Connector	Terminal	
M30	24	M88	14	Yes
	31		15	
	33		17	



Are the continuity test results as specified?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SRS-6, "Removal and Installation"](#).

## Component Inspection

INFOID:000000001502604

### WITH BLUETOOTH

Measure the resistance between the steering switch connector terminals 14 to 17 and 15 to 17.


Standard

#### Between terminals 14 and 17

- switch ON : 0 Ω
- SEEK UP switch ON : 108 – 112 Ω
- SEEK DOWN switch ON : 323 – 337 Ω

#### Between terminals 15 and 17

- VOL DOWN switch ON : 0 Ω
- VOL UP switch ON : 108 – 112 Ω
- switch ON : 323 – 337 Ω
- SOURCE switch ON : 990 – 1030 Ω



### WITHOUT BLUETOOTH

Measure the resistance between the steering switch connector terminals 14 to 17 and 15 to 17.


Standard

#### Between terminals 14 and 17

- SOURCE switch ON : 0 Ω
- SEEK UP switch ON : 162 – 168 Ω
- VOLUME UP switch ON : 639 – 665 Ω

#### Between terminals 15 and 17

- SEEK DOWN switch ON : 162 – 168 Ω
- VOL DOWN switch ON : 639 – 665 Ω



# COMMUNICATION SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## COMMUNICATION SIGNAL CIRCUIT

### SATELLITE RADIO TUNER

#### SATELLITE RADIO TUNER : Description

INFOID:000000001502605

Communication signals are exchanged between the audio unit and satellite radio tuner using the communication circuits.

#### SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001502606

#### 1. CHECK HARNESS - 1

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 and audio unit connector M45.
3. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 28 and audio unit harness connector M45 (B) terminal 38.

**Continuity should exist.**

4. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 28 and ground.

**Continuity should not exist.**

Are continuity test results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK HARNESS - 2

1. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 29 and audio unit harness connector M45 (B) terminal 39.

**Continuity should exist.**

2. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 29 and ground.

**Continuity should not exist.**

Are continuity test results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

#### 3. CHECK HARNESS - 3

1. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 30 and audio unit harness connector M45 (B) terminal 40.

**Continuity should exist.**

2. Check continuity between satellite radio tuner (factory installed) harness connector B123 (A) terminal 30 and ground.




**Continuity should not exist.**

Are the continuity test results as specified?

YES >> GO TO 4

NO >> Repair harness or connector.

#### 4. CHECK REQ1 SIGNAL







# COMMUNICATION SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect satellite radio tuner (factory installed) connector and audio unit connector.
2. Turn ignition switch to ACC
3. Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 28 and ground with CONSULT-III or oscilloscope.

### 28 - Ground



Are the voltage readings as specified?



YES >> GO TO 5

NO >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).

## 5. CHECK TXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 29 and ground with CONSULT-III or oscilloscope.

### 29 - Ground



Are the voltage readings as specified?



YES >> GO TO 6

NO >> Replace satellite radio tuner. Refer to [AV-133, "Removal and Installation"](#).

## 6. CHECK RXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector B123 terminal 30 and ground with CONSULT-III or oscilloscope.

### 30 - Ground



Are the voltage readings as specified?

YES >> Replace satellite radio tuner. Refer to [AV-133, "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# SOUND SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## SOUND SIGNAL CIRCUIT SATELLITE RADIO TUNER

### SATELLITE RADIO TUNER : Description

INFOID:000000001502607

Left and right channel audio signals are supplied from the satellite radio tuner to the audio unit through the sound signal circuits.

### SATELLITE RADIO TUNER : Diagnosis Procedure


INFOID:000000001502608

#### LEFT CHANNEL

#### 1.CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 (A) and audio unit connector M45 (B).
3. Check continuity between satellite radio tuner (factory installed) and audio unit.

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B123	21	M45	31	Yes
	22		32	



4. Check continuity between satellite radio tuner (factory installed)(A) and ground.

Terminals			Continuity
A		—	
Connector	Terminal		
B123	21	Ground	No
	22		


Are continuity test results as specified?

- YES >> GO TO 2  
NO >> Repair harness or connector.


#### 2.CHECK LEFT CHANNEL AUDIO SIGNAL

1. Connect satellite radio tuner (factory installed) and audio unit.
2. Turn ignition switch ON.
3. Check signal between satellite radio tuner (factory installed) connector B123 terminals 21 and 22 with CONSULT-III or oscilloscope.

21 - 22



SKIB3609E



WKIA4548E

Are the voltage readings as specified?

- YES >> Replace audio unit. Refer to [AV-45. "Removal and Installation"](#).  
NO >> Replace satellite radio tuner. Refer to [AV-133. "Removal and Installation"](#).

#### RIGHT CHANNEL

# SOUND SIGNAL CIRCUIT


[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

## 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector B123 (A) and audio unit connector M45 (B).
3. Check continuity between satellite radio tuner (factory installed) and audio unit.

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B123	23	M45	33	Yes
	24		34	



4. Check continuity between satellite radio tuner (factory installed)(A) and ground.

Terminals			Continuity
A		—	
Connector	Terminal		
B123	23	Ground	No
	24		

Are continuity test results as specified?



YES >> GO TO 2

NO >> Repair harness or connector.

## 2. CHECK RIGHT CHANNEL AUDIO SIGNAL

1. Connect satellite radio tuner (factory installed) and audio unit.
2. Turn ignition switch ON.
3. Check signal between satellite radio tuner (factory installed) connector B123 terminals 23 and 24 with CONSULT-III or oscilloscope.

**23 - 24**



Are voltage readings as specified?

YES >> Replace audio unit. Refer to [AV-45, "Removal and Installation"](#).

NO >> Replace satellite radio tuner. Refer to [AV-133, "Removal and Installation"](#).

# MICROPHONE SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## MICROPHONE SIGNAL CIRCUIT

### Description

INFOID:000000001502609


Voice signals are transmitted from the microphone to the Bluetooth control unit using the microphone signal circuits.

### Diagnosis Procedure

INFOID:000000001502610

#### 1. CHECK HARNESS BETWEEN BLUETOOTH CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector and microphone connector.
3. Check continuity between Bluetooth control unit harness connector B126 (A) and microphone harness connector R7 (B).



Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B126	7	R7	1	Yes
	8		2	
	29		4	

4. Check continuity between Bluetooth control unit harness connector B126 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
B126	7	Ground		No
	8			
	29			

Are the continuity test results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK MICROPHONE POWER SUPPLY


1. Connect Bluetooth control unit connector and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R7 terminal 4 and ground.

**4 - Ground : Approx. 5V**

Is voltage reading approx. 5 volts?

YES >> GO TO 3

NO >> Replace Bluetooth control unit. Refer to [AV-138](#), "Removal and Installation".



#### 3. CHECK MICROPHONE SIGNAL

# MICROPHONE SIGNAL CIRCUIT



[BOSE AUDIO WITHOUT NAVIGATION]

< COMPONENT DIAGNOSIS >

Check signal between Bluetooth control unit harness connector B126 terminals 7 and 8.

7 - 8:

When giving a voice



Are voltage readings as specified?

- YES >> Replace Bluetooth control unit. Refer to [AV-138. "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-136. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]


## ECU DIAGNOSIS

### AUDIO UNIT

Reference Value

INFOID:000000001502611

#### TERMINAL LAYOUT







#### PHYSICAL VALUES - WITH BLUETOOTH

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
1 (B/P)	Ground	Amp. ON signal	Output	ON	-	More than approx. 6.5V	Amp. does not work properly.
2 (G)	3 (R)	Audio sound signal front LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from front door speaker LH or tweeter LH.
4 (GR/V)	5 (W/L)	Audio sound signal rear LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from rear door speaker LH or subwoofer LH.
6 (W/G)	Ground	Remote control A	Input	ON	Press SEEK DOWN switch.	0.7 V	Steering wheel au- dio controls do not function
					Press SEEK UP switch.	1.3 V	
					Press  switch.	2.0 V	
					Except for above.	3.3 V	
7 (V/Y)	Ground	ACC signal	Input	ON	Ignition switch ACC or ON	Battery voltage	System does not work properly.
10	-	Shield	-	-	-	Approx. 0V	Interference and distortion heard from speakers.

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
11 (B)	12 (W)	Audio sound signal front RH	Output	ON	Receive audio signal	 SKIA0177E	No sound from front door speaker RH or tweeter RH.
13 (V)	14 (LG)	Audio sound signal rear RH	Output	ON	Receive audio signal	 SKIA0177E	No sound from rear door speaker RH or subwoofer RH.
15 (L/B)	-	Remote control ground	Input	-	-	-	Steering wheel au- dio controls do not function
16 (GR/L)	Ground	Remote control B	Input	ON	Press SOURCE switch.	0 V	Steering wheel au- dio controls do not function
					Press  switch.	0.7 V	
					Press VOL UP switch.	1.3 V	
					Press VOL DOWN switch	2 V	
					Except for above.	3.3 V	
18 (V/W)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 PKIA1935E	Speed sensitive volume inopera- tive.
19 (Y/R)	Ground	Battery pow- er	Input	-	-	Battery voltage	System will not work properly.
20	-	Shield	-	-	-	Approx. 0V	Interference and distortion heard from speakers.
21	-	M-CAN +	-	-	-	-	-
22	-	M-CAN -	-	-	-	-	-
23	-	Shield	-	-	-	Approx. 0V	-
25	-	Tel. Shield	-	-	-	Approx. 0V	-
26 (BR)	27 (Y)	Telephone audio in	-	-	-	-	-
28 (R/W)	Ground	Telephone ON signal	Input	ON	-	-	-





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
32 (Y/L)	31 (W/L)	Audio left channel sound signal from satel- lite radio tuner	Input	ON	Receive audio signal	 SKIA0177E	No sound from sat- ellite radio tuner left channel.
34 (BR/L)	33 (Y/G)	Audio right channel sound signal from satel- lite radio tuner	Input	ON	Receive audio signal	 SKIA0177E	No sound from sat- ellite radio tuner right channel.
35	-	Shield ground (au- dio signal)	-	-	-	0V	-
36	-	Shield ground (da- ta)	-	-	-	0V	-
38 (R)	Ground	Satellite ra- dio tuner re- quest to audio unit	Input	ON	Turn audio unit ON	5V	Satellite radio tuner does not opera- te properly.
39 (G)	Ground	Audio RX	Input		Operate audio volume	 SKIA4403E	Satellite radio tuner audio informa- tion does not display properly.
40 (B)	Ground	Audio TX	Output		Operate audio volume	 SKIA4402E	Satellite radio tuner audio informa- tion does not display properly.
75 (B)	Ground	Amp power supply	Output	ON	Turn audio unit ON	Battery voltage	-
76 (B)	Ground	Main anten- na	Input	ON	Turn audio unit ON	-	-





PHYSICAL VALUES - WITHOUT BLUETOOTH



# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]




Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
1 (B/P)	Ground	Amp. ON signal	Output	ON	-	More than approx. 6.5V	Amp. does not work properly.
2 (G)	3 (R)	Audio sound signal front LH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speaker LH or tweeter LH.
4 (GR/V)	5 (W/L)	Audio sound signal rear LH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear door speaker LH or subwoofer LH.
6 (W/G)	Ground	Remote control A	Input	ON	Press SOURCE switch.	0.0 V	Steering wheel au- dio controls do not function
					Press SEEK UP switch.	0.75 V	
					Press VOL UP switch.	2.0 V	
					Except for above.	5.0 V	
7 (V/Y)	Ground	ACC signal	Input	ON	Ignition switch ACC or ON	Battery voltage	System does not work properly.
10	-	Shield	-	-	-	Approx. 0V	Interference and distortion heard from speakers.
11 (B)	12 (W)	Audio sound signal front RH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speaker RH or tweeter RH.
13 (V)	14 (LG)	Audio sound signal rear RH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear door speaker RH or subwoofer RH.
15 (L/B)	-	Remote control ground	Input	-	-	-	Steering wheel au- dio controls do not function

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS >



[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
16 (GR/L)	Ground	Remote control B	Input	ON	Press SEEK DOWN switch.	0.75 V	Steering wheel audio controls do not function
					Press VOL DOWN switch.	2.0 V	
					Except for above.	5.0 V	
18 (V/W)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>	Speed sensitive volume inoperative.
19 (Y/R)	Ground	Battery power	Input	-	-	Battery voltage	System will not work properly.
20	-	Shield	-	-	-	Approx. 0V	Interference and distortion heard from speakers.
21	-	M-CAN +	-	-	-	-	-
22	-	M-CAN -	-	-	-	-	-
23	-	Shield	-	-	-	Approx. 0V	-
25	-	Tel. Shield	-	-	-	Approx. 0V	-
26 (BR)	27 (Y)	Telephone audio in	-	-	-	-	-
28 (R/W)	Ground	Telephone ON signal	Input	ON	-	-	-
32 (Y/L)	31 (W/L)	Audio left channel sound signal from satellite radio tuner	Input	ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>	No sound from satellite radio tuner left channel.
34 (BR/L)	33 (Y/G)	Audio right channel sound signal from satellite radio tuner	Input	ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>	No sound from satellite radio tuner right channel.
35	-	Shield ground (audio signal)	-	-	-	0V	-
36	-	Shield ground (data)	-	-	-	0V	-

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value	Example of symp- tom
+	-			Ignition switch	Operation		
38 (R)	Ground	Satellite ra- dio tuner re- quest to audio unit	Input	ON	Turn audio unit ON	5V	Satellite radio tun- er does not oper- ate properly.
39 (G)	Ground	Audio RX	Input		Operate audio volume		Satellite radio tun- er audio informa- tion does not display properly.
40 (B)	Ground	Audio TX	Output		Operate audio volume		Satellite radio tun- er audio informa- tion does not display properly.
75 (B)	Ground	Amp power supply	Output	ON	Turn audio unit ON	Battery voltage	-
76 (B)	Ground	Main anten- na	Input	ON	Turn audio unit ON	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


# AUDIO UNIT

## [BOSE AUDIO WITHOUT NAVIGATION]

< ECU DIAGNOSIS >

### Wiring Diagram

INFOID:000000001502612




ALNWA0035GE

# AUDIO UNIT

[BOSE AUDIO WITHOUT NAVIGATION]

< ECU DIAGNOSIS >

BB : WITH BLUETOOTH  
 NB : WITHOUT BLUETOOTH



ALNWA0033GE


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# AUDIO UNIT

[BOSE AUDIO WITHOUT NAVIGATION]


< ECU DIAGNOSIS >



ALNWA0024GE


## BOSE AUDIO WITHOUT NAVIGATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
53G	B/R	-
54G	BR	-
64G	Y/R	-


Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V/Y	-
2	Y/G	-
3	SHIELD	-
4	W/L	-
5	R	-
6	L	-
7	B/W	-
8	V/Y	-
9	GR/L	-
10	L/B	-


Terminal No.	Color of Wire	Signal Name
11	Y	-
12	B/R	-
13	R/B	-
14	SHIELD	-
15	R/L	-
16	Y/R	-
18	BR/L	-
19	Y/L	-
20	B	-
21	SHIELD	-
22	G	-
23	SHIELD	-
24	G	-
25	Y/R	-
26	W/G	-
27	BR	-
28	SHIELD	-
29	BR/W	-
30	V/W	-
31	R/W	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6Q	Y/R	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	G	-
5N	V/Y	-

ALNIA0174GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]


Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
2	R/B	-
3	R/L	-
4	SHIELD	-
7	Y/R	-
13	BRW	-


Terminal No.	Color of Wire	Signal Name
18J	BR/R	-
19J	R/G	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	G	-
13	LG	-
14	SHIELD	-
15	W/L	-
18	GR/L	-
19	L/B	-
21	W	-
22	SHIELD	-
23	R	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	V	-
3	SHIELD	-
4	GR/V	-
6	W/G	-
8	B/P	-
10	B	-
11	SHIELD	-

ALNIA0113GB



# AUDIO UNIT

## [BOSE AUDIO WITHOUT NAVIGATION]

< ECU DIAGNOSIS >

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-

Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR/R	-
4	GR/L	-
5	GW	-
6	B/Y	-
7	W	-
9	B/R	-
10	O/B	-
11	R/G	-
12	B/P	-
13	BR	-
14	L/O	-
15	B	-
16	LG	-

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	BROWN

7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8



Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY

24	25	26	27
31	32	33	34



Terminal No.	Color of Wire	Signal Name
24	W/G	AUDIO_STRG_SW_REMOTE_A
31	GR/L	AUDIO_STRG_SW_REMOTE_B
33	L/B	AUDIO_STRG_SW_GND

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
31	V/W	8P/R OUT

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4		
5	6	7	8	9	10



Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

ALNIA0114GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]


Connector No.	M44
Connector Name	AUDIO UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	L	M-CAN +
22	P	M-CAN -
23	SHIELD	-
24	-	-
25	SHIELD	-
26	BR	TEL I/F +
27	Y	TEL I/F -
28	R/W	TEL ON

Terminal No.	Color of Wire	Signal Name
6	W/G	STRG_SW_A
7	V/Y	ACC
8	R/Y	ILL-
9	R/L	ILL+
10	SHIELD	-
11	B	FR SP RH (+)
12	W	FR SP RH (-)
13	V	RR SP RH (+)
14	LG	RR SP RH (-)
15	L/B	STRG_SW_GND
16	GR/L	STRG_SW_B
17	-	-
18	V/W	SPEED SIGNAL
19	Y/R	BAT
20	SHIELD	-

Connector No.	M43
Connector Name	AUDIO UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/P	AMP_ON
2	G	FR SP LH (+)
3	R	FR SP LH (-)
4	GR/V	RR SP LH (+)
5	W/L	RR SP LH (-)


Connector No.	M50
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

Terminal No.	Color of Wire	Signal Name
31	W/L	SAT LH INPUT (-)
32	Y/L	SAT LH INPUT (+)
33	Y/G	SAT RH INPUT (-)
34	BR/L	SAT RH INPUT (+)
35	SHIELD	EARTH
36	SHIELD	DAT EARTH
37	-	-
38	R	RFQ1 (SAT TO COMBI)
39	G	RX (SAT TO COMBI)
40	B	TX (COMBI TO SAT)
41	-	-
42	-	-

Connector No.	M45
Connector Name	AUDIO UNIT
Connector Color	WHITE



ALNIA0115GB

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	M81
Connector Name	AUDIO UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
75	B	AMP SUPPLY
76	B	MAIN ANTENNA
77	-	-

Connector No.	M52
Connector Name	TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/O	-
2	GR/L	-

Connector No.	M51
Connector Name	TWEETER LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B/Y	-

Connector No.	M150
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

Connector No.	M88
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
14	W	REMOTE A
15	L	REMOTE B
17	BR	GND

Connector No.	M87
Connector Name	WINDOW ANTENNA
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M151
Connector Name	CENTER SPEAKER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

ALNIA0162GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


# AUDIO UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITHOUT NAVIGATION]

Terminal No.	Color of Wire	Signal Name
18J	W/R	-
19J	O/B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
53G	B/R	-
54G	BR	-
64G	Y/R	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	W/R	-


ALNIA0078GB

# AUDIO UNIT


< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/W	-
2	Y/G	-
3	SHIELD	-
4	W/L	-
5	R/L	-
6	L	-



Connector No.	B102
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	P	-
8	V/Y	-
9	GR/L	-
10	L/B	-
11	Y	-
12	B/R	-
13	R/B	-
14	SHIELD	-
15	R/L	-
16	Y/B	-
18	BR/L	-
19	Y/L	-

Terminal No.	Color of Wire	Signal Name
20	B	-
21	SHIELD	-
22	R/W	-
23	SHIELD	-
24	G/W	-
25	Y/R	-
26	W/G	-
27	BR	-
28	SHIELD	-
29	BR/W	-
30	V/W	-
31	R/W	-

Terminal No.	Color of Wire	Signal Name
2	LG	-
3	SHIELD	-
4	BR	-
6	W/G	-
8	B/G	-
10	W/L	-
11	SHIELD	-
12	W/R	-

Terminal No.	Color of Wire	Signal Name
13	V	-
14	SHIELD	-
15	Y	-
18	GR/L	-
19	L/B	-
21	GR/V	-
22	SHIELD	-
23	B/R	-

ALNIA0175GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]


Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
5	B/W	-

Terminal No.	Color of Wire	Signal Name
7	W	-
9	B/R	-
10	O/B	-
11	R/G	-
12	B/P	-
13	BR	-
14	L/O	-
15	B	-
16	LG	-


Connector No.	B103
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR/B	-
4	GR/L	-
5	G/W	-
6	B/Y	-

Terminal No.	Color of Wire	Signal Name
55	BR/B	RR DOOR LH - OUT
58	W	FR DOOR LH + OUT
59	B	FR DOOR LH - OUT
60	B/G	AMP ON
63	Y	RR LH - IN
64	BR	RR LH + IN
65	V	RR RH - IN
66	LG	RR RH + IN
68	R/G	RR DOOR LH + OUT
69	B/P	INST CTR TWDR +
70	O/B	INST CTR TWDR - OUT
71	G/W	FR DOOR RH + OUT
72	BR	FR DOOR RH - OUT
73	W/L	FR RH + IN
74	GR/V	FR RH - IN
75	W/R	FR LH + IN
76	B/R	FR LH - IN

Connector No.	B121
Connector Name	BOSE SPEAKER AMP
Connector Color	BROWN



Connector No.	B120
Connector Name	REAR SPEAKER SUBWOOFER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	G/B	-


ALNIA0176GB

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	B122
Connector Name	BOSE SPEAKER AMP
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
41	LG	FR TWDR LH + OUT
42	B/Y	FR TWDR LH - OUT
43	GR/L	FR TWDR RH - OUT
44	L/O	FR TWDR RH + OUT
45	BR/W	RH WOOFER + OUT
46	BR	RH WOOFER - OUT
47	B/W	GND
48	G/B	LH WOOFER - OUT
49	B/W	RR DOOR RH - OUT
50	BR	BAT
51	B/R	BAT
52	B/W	GND
53	W/B	LH WOOFER + OUT
54	L	RR DOOR RH + OUT



Connector No.	B124
Connector Name	REAR SUBWOOFER RH
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
1	BR/W	-
2	BR	-

Connector No.	B123
Connector Name	SATELLITE RADIO TUNER OR PRE-WIRING FOR SATELLITE RADIO TUNER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	W/L	SAT_LCH (-)
22	Y/L	SAT_LCH (+)
23	Y/G	SAT_RCH (-)
24	BR/L	SAT_RCH (+)
25	SHIELD	EARTH (SIG)
26	SHIELD	DATA
27	-	-
28	R/L	REQ1 (SAT - COMBI)
29	R/W	TXD (SAT_COMBI)
30	B	RXD (COMBI_SAT)
31	-	-
32	Y/R	BAT
33	-	-
34	-	-
35	-	-
36	GR/W	ACC

Connector No.	B125
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
35	L	M-CAN+_1
36	P	M-CAN-_2
37	SHIELD	M-CAN_SHIELD_1
39	Y/R	M-CAN_JUMPER_1
40	Y/R	M-CAN+_2
41	SB	M-CAN_JUMPER_1
42	SB	M-CAN-_2

ALNIA0081GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	B126
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y/B	BAT
2	V/Y	ACC
3	G/W	IGN
4	B/W	GND
6	-	SHIELD

Terminal No.	Color of Wire	Signal Name
7	B/R	MIC_IN_+
8	R/B	MIC_IN_-
9	BR	AUDIO_OUT(+)
10	Y	AUDIO_OUT(-)
11	G/O	MUTE_CONTROL
12	W/G	LAD_IN1
13	GR/L	LAD_IN2
14	L/B	LAD_GND
15	BR/W	IND1
17	W/G	LAD_OUT_1
18	GR/L	LAD_OUT_2
19	L/B	LAD_GND
24	B/W	CONT5
28	V/W	SPEED SIGNAL
29	R/L	MIC_POWER

Connector No.	B129
Connector Name	SATELLITE RADIO TUNER OR PRE-WIRING FOR SATELLITE RADIO TUNER
Connector Color	BROWN (WITH SIRIUS SATELLITE TUNER) VIOLET (WITH XM SATELLITE RADIO)




Terminal No.	Color of Wire	Signal Name
37	B	ANTENNA SIGNAL

Connector No.	B132
Connector Name	ROOF ANTENNA (SATELLITE)
Connector Color	GRAY (WITH SIRIUS SATELLITE TUNER) BROWN (WITH XM SATELLITE RADIO)



Terminal No.	Color of Wire	Signal Name
1	GR	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-

Connector No.	D3
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

ALNIA0163GB




# AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	O/B	-
5	W/R	-

Connector No.	D103
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	BR	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
5	B/W	-

Connector No.	D202
Connector Name	REAR DOOR SPEAKER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	W/R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

ALNIA0116GB

# AUDIO UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITHOUT NAVIGATION]

Connector No.	D302
Connector Name	REAR DOOR SPEAKER RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L	-
2	B/W	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	B	-
4	SHIELD	-
7	B/Y	-
13	BR	-

Connector No.	R7
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	SIG
2	R	GND
4	B	VCC

Connector No.	R8
Connector Name	BLUETOOTH ON INDICATOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	IND
2	B/Y	BAT

ALNIA0084GB

# BOSE SPEAKER AMP

[BOSE AUDIO WITHOUT NAVIGATION]


< ECU DIAGNOSIS >

## BOSE SPEAKER AMP

Reference Value

INFOID:000000001502613

### TERMINAL LAYOUT



### PHYSICAL VALUES







Terminal (wire color)		Item	Signal input/output	Condition		Reference value	Example of symptom
+	-			Ignition switch	Operation		
41 (LG)	42 (B/Y)	Tweeter LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from tweeter LH.
44 (L/O)	43 (GR/L)	Tweeter RH	Output	ON	Receive audio signal	 SKIA0177E	No sound from tweeter RH.
45 (BR/W)	46 (BR)	Woofer RH	Output	ON	Receive audio signal	 SKIA0177E	No sound from woofer RH.
47 (B/W)	Ground	Ground	-	ON	-	-	-
50 (BR)	Ground	Battery	Input	-	-	Battery voltage	System does not work properly.
51(B/R)							
52 (B/W)	Ground	Ground	-	ON	-	-	-
53 (W/B)	48 (G/B)	Woofer LH	Output	ON	Receive audio signal	 SKIA0177E	No sound from woofer LH.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# BOSE SPEAKER AMP

< ECU DIAGNOSIS >




[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value	Example of symptom
+	-			Ignition switch	Operation		
54 (L)	49 (B/W)	Rear door speaker RH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear speaker RH.
58 (W)	59 (B)	Front door speaker LH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speak- er LH.
60 (B/G)	Ground	Amp. ON sig- nal	Input	ON	-	More than approx. 6.5V	System does not work properly.
64 (BR)	63 (Y)	Audio sound signal rear LH	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear door speak- er LH.
66 (LG)	65 (V)	Audio sound signal rear RH	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear door speak- er RH.
68 (R/G)	55 (BR/B)	Rear door speaker LH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from rear speaker LH.
69 (B/P)	70 (O/B)	Center speak- er	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from center speaker.

# BOSE SPEAKER AMP

< ECU DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value	Example of symptom
+	-			Ignition switch	Operation		
71 (G/W)	72 (BR)	Front door speaker RH	Output	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speak- er RH.
73 (W/L)	74 (GR/V)	Audio sound signal front RH	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speak- er RH or tweeter RH.
75 (W/R)	76 (B/R)	Audio sound signal front LH	Input	ON	Receive audio signal	 <small>SKIA0177E</small>	No sound from front door speak- er LH or tweeter LH.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# SATELLITE RADIO TUNER

< ECU DIAGNOSIS >


[BOSE AUDIO WITHOUT NAVIGATION]

## SATELLITE RADIO TUNER

Reference Value

INFOID:000000001502614

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Voltage (approx.)
+	-			Ignition switch	Operation	
22 (Y/L)	21 (W/L)	Audio signal LH	Output	ON	Receive audio signal.	<p>SKIB3609E</p>
24 (BR/L)	23 (Y/G)	Audio signal RH	Output	ON	Receive audio signal.	<p>SKIB3609E</p>
25	-	Shield	-	-	-	-
26	-	Data ground	-	ON	-	Approx. 0 V
28 (R/L)	Ground	REQ1 (SAT-AUDIO)	Output	ON	Set to the satellite radio mode	<p>SKIB3825E</p>
29 (R/W)	Ground	Communication signal (SAT-AUDIO)	Output	ON	Set to the satellite radio mode	<p>SKIB3824E</p>

# SATELLITE RADIO TUNER

[BOSE AUDIO WITHOUT NAVIGATION]

< ECU DIAGNOSIS >

Terminal (Wire color)		Item	Signal input/ output	Condition		Voltage (approx.)
+	-			Ignition switch	Operation	
30 (B)	Ground	Communication signal (AUDIO-SAT)	Input	ON	Set to the satellite radio mode	
32 (Y/R)	Ground	Battery power supply	Input	OFF	-	Battery voltage
36 (GR/W)		ACC power supply		ACC		
37	-	Antenna signal		-	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITHOUT NAVIGATION]

## BLUETOOTH CONTROL UNIT

Reference Value

INFOID:000000001502615

### TERMINAL LAYOUT



### PHYSICAL VALUES


Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)	Example of symp- tom
+	-			Ignition switch	Operation		
1 (Y/B)	Ground	Battery power	Input	-	-	Battery voltage	System does not work properly.
2 (V/Y)	Ground	ACC power	Input	ACC/ ON	-	Battery voltage	System does not work properly.
3 (G/W)	Ground	IGN power	Input	ON/ START	-	Battery voltage	System does not work properly.
4 (B/W)	-	Ground	-	-	-	-	-
6	-	Shield	-	-	-	-	-
7 (B/R)	8 (R/B)	Mic-in signal	Input	-	-	-	Microphone inoperative.
9 (BR)	10 (Y)	Audio out	Output	ACC/ ON	Bluetooth control unit sends audio signal	 SKIB3609E	Audio can not be heard.
11 (G/O)	-	Mute	Output	-	-	-	Mute inoperative.
12 (W/G)	Ground	Remote control switch 1	Input	ACC/ ON	Press SEEK DOWN switch.	0.7 V	Steering wheel audio control switches do not function.
					Press SEEK UP switch.	1.3 V	
					Pressing  switch.	2.0 V	
					Except for above.	3.3 V	



# BLUETOOTH CONTROL UNIT

[BOSE AUDIO WITHOUT NAVIGATION]

< ECU DIAGNOSIS >

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)	Example of symp- tom
+	-			Ignition switch	Operation		
13 (GR/L)	Ground	Remote control switch 2	Input	ACC/ ON	Press SOURCE switch.	0 V	Steering wheel au- dio control switches do not function.
					Press  switch.	0.7 V	
					Press VOL UP switch.	1.3 V	
					Press VOL DOWN switch	2 V	
					Except for above.	3.3 V	
14 (L/B)	-	Remote control ground	Input	-	-	-	Steering wheel au- dio control switches do not function.
17 (W/G)	Ground	Steering switch 1	Output	ACC/ ON	Press SEEK DOWN switch.	0.7 V	Steering wheel au- dio controls do not function.
					Press SEEK UP switch.	1.3 V	
					Pressing  switch.	2.0 V	
					Except for above.	3.3 V	
18 (GR/L)	Ground	Steering switch 2	Output	ACC/ ON	Press SOURCE switch.	0 V	Steering wheel au- dio controls do not function.
					Press  switch.	0.7 V	
					Press VOL UP switch.	1.3 V	
					Press VOL DOWN switch	2 V	
					Except for above.	3.3 V	
19 (L/B)	Ground	Steering switch ground	Output	-	-	-	Steering wheel au- dio controls do not function.
24 (B/W)	-	Ground	-	-	-	-	-
28 (V/W)	-	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)		-
29 (R/L)	Ground	Microphone power	Output	-	-	-	Microphone inoper- ative.
35 (L)	-	M-CAN (+)	-	-	-	-	-
36 (P)	-	M-CAN (-)	-	-	-	-	-
37	-	Shield ground	-	-	-	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

AV

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## SYMPTOM DIAGNOSIS

### AUDIO SYSTEM

#### Symptom Table

INFOID:000000001502616

#### AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>Audio unit power circuit</li> <li>Audio unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-65</a></li> <li><a href="#">AV-126</a></li> </ul>
Steering switch does not operate	<ul style="list-style-type: none"> <li>Steering switch</li> <li>Audio unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-85</a></li> <li><a href="#">AV-126</a></li> </ul>
All speakers do not sound	<ul style="list-style-type: none"> <li>Audio unit</li> <li>Audio unit power circuit</li> <li>BOSE speaker amp. ON signal</li> <li>BOSE speaker amp. ground circuit</li> <li>BOSE speaker amp.</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-126</a></li> <li><a href="#">AV-65</a></li> <li><a href="#">AV-84</a></li> <li><a href="#">AV-65</a></li> <li><a href="#">AV-127</a></li> </ul>
One or several speakers do not sound	<ul style="list-style-type: none"> <li>Front door speaker</li> <li>Tweeter</li> <li>Center speaker</li> <li>Rear door speaker</li> <li>Woofers</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-70</a></li> <li><a href="#">AV-73</a></li> <li><a href="#">AV-76</a></li> <li><a href="#">AV-78</a></li> <li><a href="#">AV-81</a></li> </ul>

#### CD

Symptom	Possible cause	Reference page
CD cannot be inserted.	Audio unit	<a href="#">AV-126</a>
CD cannot be ejected.		
The CD cannot be played.		
The sound skips, stops suddenly, or is distorted.		

#### SATELLITE RADIO

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>Satellite radio tuner power or ground circuit</li> <li>Satellite radio tuner communication circuit</li> <li>Satellite radio tuner</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-66</a></li> <li><a href="#">AV-88</a></li> <li><a href="#">AV-133</a></li> </ul>
Right or left channel does not sound	<ul style="list-style-type: none"> <li>Satellite radio tuner right channel audio signal circuit</li> <li>Satellite radio tuner left channel audio signal circuit</li> <li>Satellite radio tuner</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-90</a></li> <li><a href="#">AV-90</a></li> <li><a href="#">AV-133</a></li> </ul>

#### HANDS-FREE PHONE

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>Bluetooth control unit power and ground circuit</li> <li>Bluetooth control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-67</a></li> <li><a href="#">AV-138</a></li> </ul>
Steering switch does not operate	<ul style="list-style-type: none"> <li>Steering switch</li> <li>Bluetooth control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-85</a></li> <li><a href="#">AV-138</a></li> </ul>
Voice activated control does not operate	<ul style="list-style-type: none"> <li>Microphone</li> <li>Steering switch</li> <li>Bluetooth control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-92</a></li> <li><a href="#">AV-85</a></li> <li><a href="#">AV-138</a></li> </ul>

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000001502617

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

### NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## PRECAUTION

### PRECAUTIONS

#### Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001502618

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# PREPARATION

< PREPARATION >


[BOSE AUDIO WITHOUT NAVIGATION]

## PREPARATION

### PREPARATION

#### Commercial Service Tools

INFOID:000000001502619

Tool name	Description
<p>Power tool</p>  <p>PBIC0191E</p>	<p>Loosening bolts and nuts</p>

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

## ON-VEHICLE REPAIR

### AUDIO UNIT

#### Removal and Installation

INFOID:000000001502620

For removal and installation, refer to [AV-45, "Removal and Installation"](#).

# BOSE AMP.

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]


## BOSE AMP.

### Removal and Installation

INFOID:000000001502621

#### REMOVAL

1. Disconnect the 12-volt battery negative terminal.
2. Remove the rear seat back. Refer to [SE-20, "Removal and Installation"](#).
3. Remove the bose speaker amp. screws (A), then disconnect the bose speaker amp. connectors (B), and remove the bose speaker amplifier (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

**TWEETER**

**Removal and Installation**

*INFOID:000000001502622*

For removal and installation, refer to [AV-46. "Removal and Installation"](#).



# CENTER SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]


## CENTER SPEAKER

### Removal and Installation

INFOID:000000001502623

#### REMOVAL

1. Remove the center speaker grille. Refer to [JP-11, "Removal and Installation"](#).
2. Remove the center speaker screws (A), then pull out the center speaker (1), disconnect the connector and remove the center speaker (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

## FRONT DOOR SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]

---

### FRONT DOOR SPEAKER

#### Removal and Installation

INFOID:000000001502624

For removal and installation, refer to [AV-47, "Removal and Installation"](#).

# REAR DOOR SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]


## REAR DOOR SPEAKER

### Removal and Installation

INFOID:000000001502625

#### REMOVAL

1. Remove the rear door finisher. Refer to [INT-11. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A), then disconnect the rear door speaker connector and remove the rear door speaker (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REAR SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]

---

### REAR SPEAKER

#### Removal and Installation

INFOID:000000001502626

For removal and installation, refer to [AV-48, "Removal and Installation"](#).

# SATELLITE RADIO TUNER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]

## SATELLITE RADIO TUNER

### Removal and Installation


INFOID:000000001502627

#### REMOVAL

1. Disconnect the 12-volt battery negative terminal.
2. Remove the rear parcel shelf finisher. Refer to [INT-15, "Removal and Installation"](#).
3. Remove the satellite radio tuner unit screws (A), disconnect the satellite tuner harness connectors and remove the satellite radio tuner (1).

**NOTE:**

Bluetooth control unit (2) is removed with the satellite radio tuner unit (if equipped).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## AUDIO ANTENNA

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]

---

### AUDIO ANTENNA

#### Roof Antenna

INFOID:000000001502628

#### REMOVAL and INSTALLATION

For removal and installation, refer to [AV-49. "Roof Antenna"](#).

# STEERING SWITCH

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITHOUT NAVIGATION]

## STEERING SWITCH

### Removal and Installation

INFOID:000000001502629

For removal and installation, refer to [AV-53. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

< ON-VEHICLE REPAIR >


### MICROPHONE

#### Removal and Installation

INFOID:000000001502630

#### REMOVAL

1. Remove the map lamp. Refer to [INL-50. "Removal and Installation"](#).
2. Remove the Bluetooth microphone (2).
  - Map lamp (1)



#### INSTALLATION

Installation is in the reverse order of removal.




## TEL ANTENNA

### Removal and Installation

INFOID:000000001502631

#### REMOVAL

1. Remove the rear parcel shelf finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the Bluetooth antenna screw (A), fold down the rear seat, disconnect the Bluetooth antenna connector and remove the Bluetooth antenna (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

**TEL ADAPTER UNIT****Removal and Installation**

INFOID:000000001502632

**REMOVAL**

1. Disconnect the 12-volt battery negative terminal.
2. Remove the rear parcel shelf finisher. Refer to [INT-15, "Removal and Installation"](#).
3. Remove the Bluetooth control (tel adaptor) unit screws (A), disconnect the Bluetooth control (tel adaptor) unit connectors and remove the Bluetooth control (tel adaptor) unit (2).
  - Satellite radio tuner (1)

**INSTALLATION**

Installation is in the reverse order of removal.


**BASIC INSPECTION**

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001502633

OVERALL SEQUENCE



- Reference 1... Refer to [AV-164, "CONSULT - III Function \(MULTI AV\)"](#).
- Reference 2... Refer to [AV-249, "Symptom Table"](#).

DETAILED FLOW

**1. CHECK SYMPTOM**

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

>> GO TO 2

**2. SELF-DIAGNOSIS (CONSULT-III)**

1. Connect CONSULT-III and perform "SELF-DIAGNOSIS" for "MULTI AV".  
**NOTE:**  
Skip to step 4 of the diagnosis procedure if "MULTI AV" is not displayed.
2. Check if any DTC No. is displayed in the self-diagnosis results.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

[BOSE AUDIO WITH NAVIGATION]

< BASIC INSPECTION >

Is any DTC No. displayed?

YES >> GO TO 3

NO >> GO TO 4

## 3.CHECK SELF-DIAGNOSIS RESULTS (CONSULT-III)

1. Check the DTC No. indicated in the self-diagnosis results.
2. Perform the relevant diagnosis referring to the DTC No. list. Refer to [AV-241, "DTC Index"](#).

**NOTE:**

Start with the diagnosis for the CAN communication system if "CAN COMM CIRCUIT [U1000] or CONTROL UNIT (CAN) [U1010]" is displayed.

>> GO TO 5

## 4.PERFORM DIAGNOSIS BY SYMPTOM

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [AV-249, "Symptom Table"](#).

>> GO TO 5

## 5.REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the identified malfunctioning parts.

**NOTE:**

Erase the stored self-diagnosis results after repairing or replacing the relevant components if any DTC No. has been indicated in the self-diagnosis results.

>> GO TO 6

## 6.CHECK AFTER REPAIR

1. Perform self-diagnosis for "MULTI AV" with CONSULT-III after repairing or replacing the malfunctioning parts.
2. Check if any DTC No. is displayed in the self-diagnosis results.

Is any DTC No. displayed?

YES >> GO TO 3

NO >> GO TO 7

## 7.FINAL CHECK

Perform the operation check to confirm that the malfunction symptom is solved or that any other symptoms are present.

Are any symptoms present?

YES >> GO TO 4

NO >> Inspection End.

## INSPECTION AND ADJUSTMENT

### REAR VIEW MONITOR GUIDING LINE ADJUSTMENT

#### REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Description

INFOID:000000001502634

This mode is used to modify the side distance guidelines if they are dislocated from the rear view monitor image, because of variations of body/camera mounting conditions.


#### REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Special Repair Requirement

INFOID:000000001502635


1. Create a correction line to modify the screen.  
 Draw lines on the rearward of the vehicle passing through the following points: 200 mm (7.87 inch) from both sides of the vehicle, and
  - \*1: 0.5 m (1.5 feet)
  - \*2: 1 m (3 feet)
  - \*3: 2 m (7 feet)
  - \*4: 3 m (10 feet)
 and from the rear end of the bumper
2. With the ignition switch OFF, connect CONSULT-III, then turn ignition switch ON. Select "REARVIEW CAMERA".

**CAUTION:**

**Stop engine for safety when correcting side distance guideline.**



3. Shift the selector lever to R position.



4. Touch "SELCT GUIDELINE PATTERN" under "WORK SUPPORT" menu.
5. Touch "UP" or "DOWN", and select the guide line, "PATTERN NO. 0" or "PATTERN NO. 1", which is the closest to the corrected line.
6. Touch "SAVE", and confirm the guide line.
7. Touch "END".
8. Touch "ADJ GUIDELINE POSITION" under the "WORK SUPPORT" menu.
9. Adjust the guide line touching "X UP", "X DOWN", "Y UP" or "Y DOWN" so that the corrected line can fit the guide line.
10. Touch "SAVE", and confirm the guide line.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV

## INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[BOSE AUDIO WITH NAVIGATION]


---

11. Touch "END" to finish correcting.

FUNCTION DIAGNOSIS

MULTI AV SYSTEM

System Diagram



System Description

INFOID:000000001502637

The multi AV system consists of the following systems.

- Navigation system
- Audio system
- Rear view monitor
- Hands-free phone system

Refer to the following table for multi AV system descriptions.

System	Reference page
Navigation system	<a href="#">AV-149</a>
Audio system	<a href="#">AV-153</a>
Rear view monitor system	<a href="#">AV-152</a>
Hands-free phone system	<a href="#">AV-155</a>

VOICE RECOGNITION

The multi AV system uses voice recognition to control functions of the following systems:


- Navigation system

# MULTI AV SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


- Hands-free phone system



## TOUCH PANEL

The multi AV system uses a touch panel display to control functions of the following systems:

- Audio system
- Navigation system
- Hands-free phone system





Component Parts Location

INFOID:000000001502638

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

# MULTI AV SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]




AWNIA0090GB

# MULTI AV SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]



AWNIA0091GB

- |                            |  |   |
|----------------------------|--|---|
| 1. Tweeter LH M51          | 2. Steering wheel audio control switches   | 3. CD changer M42   |
| 4. Tweeter RH M52          | 5. AV control unit M46, M47, M48, M81, M90, M91                                  | 6. Center speaker M151  |
| 7. Combination meter M24   | 8. Front door speaker LH D3<br>RH D103   | 9. Rear subwoofer RH B124   |
| 10. Rear subwoofer LH B120 | 11. Rear door speaker LH D202<br>RH D302   | 12. BOSE speaker amp. B121, B122 (view with rear seat back removed) |
| 13. Microphone R7          | 14. Rear view camera control unit B31 (view with trunk side finisher LH removed) | 15. Rear view camera B35  |

## Component Description

INFOID:000000001502639

Part name	Description
AV control unit	<ul style="list-style-type: none"> <li>Integrates DVD-ROM drive allowing map data to be stored</li> <li>The AV control unit includes the navigation, audio, hands-free phone, satellite radio and display functions</li> </ul>
BOSE speaker amp.	Receives power (amp ON) and audio signals from AV control unit, and outputs audio signals to each speaker.
CD changer	Outputs audio signals to AV control unit.
Front door speaker	<ul style="list-style-type: none"> <li>Outputs audio signal from BOSE speaker amp.</li> <li>Outputs high, mid and low range sounds</li> </ul>
Tweeter	<ul style="list-style-type: none"> <li>Outputs audio signal from BOSE speaker amp.</li> <li>Outputs high range sound</li> </ul>
Center speaker	<ul style="list-style-type: none"> <li>Outputs audio signal from BOSE speaker amp.</li> <li>Outputs high, mid and low range sounds</li> </ul>
Rear door speaker	<ul style="list-style-type: none"> <li>Outputs audio signal from BOSE speaker amp.</li> <li>Outputs high, mid and low range sounds</li> </ul>
Woofer	<ul style="list-style-type: none"> <li>Outputs audio signal from BOSE speaker amp.</li> <li>Outputs low range sound</li> </ul>
Rear view camera control unit	<ul style="list-style-type: none"> <li>Camera image signal is input from rear view camera, and camera image is indicated on the display</li> <li>Power (camera ON signal) is sent to rear view camera</li> <li>Controlled by AV communication sent from AV control unit</li> <li>AV control unit recognizes the presence of camera system with camera connection recognition signal</li> </ul>
Rear view camera	<ul style="list-style-type: none"> <li>Receives camera ON signal from rear view camera control unit</li> <li>Sends image signal to rear view camera control unit</li> </ul>

## MULTI AV SYSTEM


< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Part name	Description
Steering switches	<ul style="list-style-type: none"><li>• Operations for audio, hands-free phone and navigation are possible</li><li>• Steering switch signal (operation signal) is output to AV control unit</li></ul>
Microphone	Voice signals are received and sent to AV control unit.
GPS antenna	GPS signal is received and sent to AV control unit.
Satellite radio antenna	Satellite radio signal is received and sent to AV control unit.

NAVIGATION SYSTEM

System Diagram



System Description


INFOID:000000001502641

**NOTE:**

Refer to NAVI System Owner's Manual for system operation.


The navigation system periodically calculates the vehicle's current position according to the following three signals: Travel distance of the vehicle as determined by the vehicle speed sensor, turning angle of the vehicle as determined by the gyroscope (angular velocity sensor), and the direction of vehicle travel as determined by the GPS antenna (GPS information).

The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the map DVD-ROM, which is stored in the DVD-ROM drive (map-matching), and indicated on the screen with a current-location mark.



By comparing the vehicle position detection results found by the GPS and by map-matching, more accurate vehicle position data can be used.

The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.



TRAVEL DISTANCE

Travel distance calculations are based on the vehicle speed input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance fine adjustment function has been adopted.

TRAVEL DIRECTION

Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). As the gyroscope and GPS antenna have both merit and demerit, input signals

# NAVIGATION SYSTEM

## < FUNCTION DIAGNOSIS >

## [BOSE AUDIO WITH NAVIGATION]

from them are prioritized in each situation. However, this order of priority may change in accordance with more detailed travel conditions so that the travel direction is detected more accurately.

Type	Advantage	Disadvantage
Gyroscope (angular velocity sensor)	<ul style="list-style-type: none"> <li>Can detect the vehicle's turning angle quite accurately.</li> </ul>	<ul style="list-style-type: none"> <li>Direction errors may accumulate when the vehicle is driven for long distances without stopping.</li> </ul>
GPS antenna (GPS information)	<ul style="list-style-type: none"> <li>Can detect the vehicle's travel direction (North/South/East/West).</li> </ul>	<ul style="list-style-type: none"> <li>Correct direction cannot be detected when the vehicle speed is low.</li> </ul>

### MAP-MATCHING

Map-matching is a function that repositions the vehicle on the road map when a new location is judged to be the most accurate. This is done by comparing the current vehicle position, calculated by the method described in the position detection principle, with the road map data around the vehicle, read from the map DVD-ROM stored in the DVD-ROM drive.

Therefore, the vehicle position may not be corrected after the vehicle is driven over a certain distance or time in which GPS information is hard to receive. In this case, the current-location mark on the display must be corrected manually.



#### CAUTION:

**The road map data is based on data stored in the map DVD-ROM.**

- In map-matching, alternative routes to reach the destination will be shown and prioritized, after the road on which the vehicle is currently driven has been judged and the current-location mark has been repositioned.

If there is an error in distance and/or direction, the alternative routes will be shown in different order of priority, and the wrong road can be avoided.


If two roads are running in parallel, they are of the same priority. Therefore, the current-location mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.



- Map-matching does not function correctly when the road on which the vehicle is driving is new and not recorded in the map DVD-ROM, or when the road pattern stored in the map data and the actual road pattern are different due to repair.

When driving on a road not present in the map, the map-matching function may find another road and position the current-location mark on it. Then, when the correct road is detected, the current-location mark may leap to it.

- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the map DVD-ROM is limited. Therefore, when there is an excessive gap between the current vehicle position and the position on the map, correction by map-matching is not possible.




### GPS (GLOBAL POSITIONING SYSTEM)

# NAVIGATION SYSTEM

## < FUNCTION DIAGNOSIS >

## [BOSE AUDIO WITH NAVIGATION]

GPS (Global Positioning System) has been developed and controlled by the US Department of Defense. The system utilizes GPS satellite (NAVSTAR), sending out radio waves while flying on an orbit around the earth at the height of approx. 21,000 km (13,000 miles). The GPS receiver calculates the vehicle's position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves received from four or more GPS satellites (three-dimensional positioning). If radio waves were received only from three GPS satellites, the GPS receiver calculates the vehicle's position in two dimensions (latitude/longitude), utilizing the altitude data calculated previously by using radio waves from four or more GPS satellites (two-dimensional positioning).



Accuracy of the GPS will deteriorate under the following conditions.

- In two-dimensional positioning, the GPS accuracy will deteriorate when the altitude of the vehicle position changes.
- There may be an error of approximately 10 m (30 ft.) in position detected by three-dimensional positioning, which is more accurate than two-dimensional positioning. The accuracy can be even lower depending on the arrangement of the GPS satellites utilized for the positioning.
- Position detection is not possible when the vehicle is in an area where radio waves from the GPS satellite do not reach, such as in a tunnel, parking lot in a building, and under an elevated highway. Radio waves from the GPS satellites may not be received when some object is located over the GPS antenna.
- Position correction by GPS is not available while the vehicle is stopped.

## Component Parts Location

INFOID:000000001502642

Refer to [AV-145. "Component Parts Location"](#).

## Component Description

INFOID:000000001502643

Part name	Description
AV control unit	<ul style="list-style-type: none"> <li>• Controls each operation of the navigation system</li> <li>• DVD-ROM drive is built in</li> <li>• Voice guidance signal is output to BOSE speaker amp.</li> </ul>
BOSE speaker amp.	Voice guidance signal is input from AV control unit, and it is output to speakers.
Tweeter	Voice guidance signal from BOSE speaker amp. is output.
Steering switches	<ul style="list-style-type: none"> <li>• Each operation of navigation system can be performed</li> <li>• Switch operating signal is output to AV control unit</li> </ul>
Microphone	Sends voice signals to AV control unit
GPS antenna	GPS signal is received and is output to AV control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


# REAR VIEW MONITOR SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## REAR VIEW MONITOR SYSTEM

### System Diagram



### System Description

INFOID:000000001502645

When the selector is in the R position, the display shows a view to the rear of the vehicle. Lines which indicate the vehicle clearance and distances are also displayed.

#### AV COMMUNICATION LINE

The rear view camera control unit is connected to the AV control unit using an AV communication line. This line is used to transmit and receive data.

### Component Parts Location

INFOID:000000001502646

Refer to [AV-145, "Component Parts Location"](#).

### Component Description


INFOID:000000001502647

Part name	Description
AV control unit	Camera image signal is sent from rear view camera control unit
Rear view camera control unit	<ul style="list-style-type: none"> <li>Receives reverse signal from back-up lamp relay</li> <li>Receives rear view camera image signal</li> <li>Sends camera ON signal to rear view camera</li> <li>Sends image signal to AV control unit</li> </ul>
Rear view camera	<ul style="list-style-type: none"> <li>Receives camera ON signal from rear view camera control unit</li> <li>Sends image signal to rear view camera control unit</li> </ul>



## AUDIO SYSTEM

### System Diagram



### System Description

INFOID:000000001502649

#### AUDIO SYSTEM

The audio system consists of the following components

- AV control unit (audio unit)
- BOSE speaker amp.
- Window antenna
- Roof antenna (audio)
- Steering switches
- Front door speakers
- Tweeters
- Center speaker
- Rear door speakers
- Woofers
- CD changer

When the audio system is on, radio signals are received by the window antenna and roof antenna. The audio unit then sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers, tweeters, center speaker, rear door speakers and woofers. Refer to Owner's Manual for audio system operating instructions.

#### SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Roof antenna (satellite)
- Satellite radio tuner

When the satellite radio system is on, radio signals are supplied to the satellite radio tuner from the satellite antenna. The satellite radio tuner then sends audio signals to the audio unit.

Refer to Owner's Manual for satellite radio system operating instructions.

#### SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system goes up and down automatically in proportion to the vehicle speed. The control level can be selected by the customer. Refer to Owner's Manual for operating instructions.

### Component Parts Location

INFOID:000000001502650

Refer to [AV-145. "Component Parts Location"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## Component Description

INFOID:000000001502651

Part name	Description
AV control unit	<ul style="list-style-type: none"><li>• Controls audio system and satellite radio system functions</li><li>• Audio information is displayed on display screen</li></ul>
BOSE speaker amp.	Receives power (amp ON) and audio signals from AV control unit, and outputs audio signals to each speaker.
CD changer	Sends audio signals to AV control unit
Front door speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Tweeter	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high range sound</li></ul>
Center speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Rear door speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Woofers	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs low range sound</li></ul>
Steering switches	<ul style="list-style-type: none"><li>• Each audio operation can be operated</li><li>• Steering switch signal (operation signal) is output to AV control unit</li></ul>
Satellite antenna	Audio signal (satellite radio) is received and output to AV control unit.


# HANDS-FREE PHONE SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## HANDS-FREE PHONE SYSTEM

### System Diagram



### System Description

Refer to the owner's manual for Bluetooth telephone system operating instructions.

#### NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth telephone system.

Bluetooth telephone system allows users who have a Bluetooth cellular telephone to make a wireless connection between their cellular telephone and the AV control unit. Hands-free cellular telephone calls can be sent and received. Personal memos can be created using the Nissan Voice Recognition system. Some Bluetooth cellular telephones may not be recognized by the AV control unit. When a cellular telephone or the AV control unit is replaced, the telephone must be paired with the AV control unit. Different cellular telephones may have different pairing procedures. Refer to the cellular telephone operating manual.

#### AV CONTROL UNIT

When the ignition switch is turned to ACC or ON, the AV control unit will power up. During power up, the AV control unit is initialized and performs various self checks. Initialization may take up to 10 seconds. During this time the Bluetooth ON indicator will flash until initialization is complete. If a phone is present in the vehicle and paired with the AV control unit, Nissan Voice Recognition will then become active and the Bluetooth ON indicator will remain on. Bluetooth telephone functions can be turned off using the Nissan Voice Recognition system.

#### STEERING WHEEL AUDIO CONTROL SWITCHES

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes depending on which button is pushed. The AV control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate Self-Diagnosis of the Bluetooth telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

#### MICROPHONE

The microphone is located in the roof console assembly. The microphone sends a signal to the AV control unit. The microphone can be actively tested during self-diagnosis.

#### BLUETOOTH ON INDICATOR

The Bluetooth ON indicator is located in the overhead console. The indicator will flash during power up while the AV control unit is initializing. This process may take up to 10 seconds. If a phone is present in the vehicle and paired with the AV control unit, the indicator will remain on to indicate that the system is ready for voice commands. The indicator flashes during self-diagnosis.

### Component Parts Location

Refer to [AV-145, "Component Parts Location"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# HANDS-FREE PHONE SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## Component Description

INFOID:000000001502655

Part name	Description
AV control unit	<ul style="list-style-type: none"><li>• Controls hands-free phone functions</li><li>• Displays hands-free phone information on display screen</li></ul>
BOSE speaker amp.	Inputs power (amp ON) and sound signal from AV control unit, and outputs sound signal to each speaker.
Front door speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Tweeter	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high range sound</li></ul>
Center speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Rear door speaker	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs high, mid and low range sounds</li></ul>
Woofer	<ul style="list-style-type: none"><li>• Outputs audio signal from BOSE speaker amp.</li><li>• Outputs low range sound</li></ul>
Steering switches	<ul style="list-style-type: none"><li>• Start a voice recognition session</li><li>• Answer and end telephone calls</li><li>• Adjust the volume level</li></ul>
Microphone	Sends voice signals to AV control unit

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## DIAGNOSIS SYSTEM (AV CONTROL UNIT)

### Diagnosis Description

INFOID:000000001502656

### DESCRIPTION


- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnosis that requires operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the History of Errors of the multi AV system.

### DIAGNOSIS ITEM

Mode		Description	
Self-diagnosis		<ul style="list-style-type: none"> <li>• AV control unit diagnosis (DVD-ROM drive will not be diagnosed when no map DVD-ROM is in it.</li> <li>• Analyzes connection between the AV control unit, CD changer, satellite radio antenna and GPS antenna.</li> </ul>	
CONFIRMATION/ ADJUSTMENT	Display diagnosis	Color spectrum bar	Color tone of the screen can be checked by the display of a color bar.
		Gradation bar	Shading of the screen can be checked by the display of a gray scale.
		Touch panel	<ul style="list-style-type: none"> <li>• Touch panel response can be checked.</li> <li>• Touch panel calibration can be performed.</li> </ul>
	Vehicle signals		The following vehicle signals are analyzed: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.
	Speaker test		Connection can be checked by sending a test tone to each speaker.
	Navigation		XM NavTraffic subscription status can be checked.
	Error history		Diagnosis results previously stored in the memory are displayed in this mode.
	Vehicle CAN diagnosis		The transmitting/receiving of CAN communication can be monitored.
	Handsfree phone	Handsfree volume adjustment	Volume of hands-free phone can be adjusted.
		Voice microphone test	Hands-free phone microphone can be tested.
		Delete handsfree memory	Hands-free phone memory can be deleted.
	Bluetooth	Confirm / Change Passkey	Bluetooth passkey can be changed.
		Confirm / Change Device Key	Bluetooth device name can be changed.
XM SAT		Traffic channel information can be reviewed and changed.	

### OPERATION PROCEDURE

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "SETUP" button, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)




# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]

< FUNCTION DIAGNOSIS >

- The initial trouble diagnosis screen will be displayed, and items “Self-Diagnosis” and “Confirmation/Adjustment” can be selected.




## SELF-DIAGNOSIS

- Perform self-diagnosis by selecting “Self-diagnosis”.
  - Self-diagnosis subdivision screen is displayed, and the self-diagnosis mode starts.
  - A bar graph visible on the center of the self-diagnosis subdivision screen indicates progress of the trouble diagnosis.


**NOTE:**

Self-diagnosis requires approximately 10 seconds to complete.



- Diagnosis results are displayed after the self-diagnosis is completed. The unit names and the connection lines are color-coded according to the diagnostic results.


Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction <sup>Note</sup>	Red	Green



Note:

- Only the control unit (AV control unit) is displayed in red.
- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > yellow > gray.

- Select a switch on the “SELF DIAGNOSIS” screen and comments for the diagnosis results will be shown.






Self-Diagnosis Results

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p>System Diagnosis &gt; Connection Conf... Back</p> <p>CD Changer</p> <p>SAT Antenna Control unit</p> <p>GPS Antenna</p> <p>Red</p> <p>ALNIA0090GB</p>	<p>AV control unit malfunction is detected</p>	<p>Replace the AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a>.</p>
 <p>System Diagnosis &gt; Connection Conf... Back</p> <p>CD Changer</p> <p>SAT Antenna Control unit</p> <p>GPS Antenna</p> <p>Gray - - - - : Yellow</p> <p>ALNIA0091GB</p>	<p>GPS antenna connection malfunction is detected</p>	<p>GPS antenna</p>
 <p>System Diagnosis &gt; Connection Conf... Back</p> <p>CD Changer</p> <p>SAT Antenna Control unit</p> <p>GPS Antenna</p> <p>Gray - - - - : Yellow</p> <p>ALNIA0092GB</p>	<p>Poor connection is detected in satellite antenna</p>	<ul style="list-style-type: none"> <li>Satellite antenna feeder</li> <li>Satellite antenna</li> </ul>



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p>System Diagnosis &gt; Connection Conf... Back</p> <p>CD Changer</p> <p>SAT Antenna Control unit</p> <p>GPS Antenna</p> <p>■ : Gray - - - : Gray</p> <p>ALNIA0093GB</p>	<p>No diagnosis due to internal malfunction of CD changer</p>	<p>Replace the CD changer. Refer to <a href="#">AV-262</a>, "Removal and Installation".</p>
 <p>System Diagnosis &gt; Connection Conf... Back</p> <p>CD Changer</p> <p>SAT Antenna Control unit</p> <p>GPS Antenna</p> <p>■ : Gray - - - : Yellow</p> <p>ALNIA0094GB</p>	<ul style="list-style-type: none"> <li>• CD changer power supply and ground circuits</li> <li>• A malfunction is detected in communication circuit between AV control unit and CD changer (REQ1 signal or communication signal)</li> <li>• A malfunction is detected in communication signal between AV control unit and CD changer (REQ1 signal or communication signal)</li> </ul>	<ul style="list-style-type: none"> <li>• CD changer power supply and ground circuits</li> <li>• Communication line between AV control unit and CD changer (REQ1 signal or communication signal)</li> </ul>

## CONFIRMATION/ADJUSTMENT MODE

1. Start the diagnosis function and select "Confirmation/Adjustment". The confirmation/adjustment mode indicates where each item can be checked or adjusted.
2. Select each button on the "Confirmation/Adjustment Mode" screen to display the relevant trouble diagnosis screen. Press the "BACK" button to return to the initial Confirmation/Adjustment Mode screen.






# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< FUNCTION DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

## Display Diagnosis



## Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



Diagnosis item	Display	Vehicle status	Remarks
Vehicle speed	ON	Vehicle speed > 0 km/h	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h	
	-	Ignition switch in ACC position	
Parking brake	ON	Parking brake is applied.	
	OFF	Parking brake is released.	

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Diagnosis item	Dis-play	Vehicle status	Remarks
Lights	ON	Light switch ON	Block the light beam from the auto light optical sensor.
	OFF	Light switch OFF	
Ignition	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
Reverse	ON	Selector lever in R position	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Selector lever in any position other than R	
	—	Ignition switch in ACC position	


### Speaker Test

Select "SPEAKER TEST" to display the speaker diagnosis screen. Press "START" to generate a test tone in speakers. Press "End" to stop the test tones.

**NOTE:**


The speakers are tested in the following order:

Front left tweeter > front center > front right tweeter > front right > rear right > woofer > rear left > front left



### Navigation

The XM NavTraffic subscription status can be checked.



### Error History

The error record displays the time and place of the most recent occurrence of that error. However, take note of the following points.

- If there is a malfunction with the GPS antenna circuit board in the AV control unit, the correct date and time of occurrence may not be able to be displayed.
- Place of the error occurrence is represented by the position of the current location mark at the time an error occurred. If current location mark has deviated from the correct position, then the place of the error occurrence cannot be located correctly.

### Vehicle CAN Diagnosis


# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

## [BOSE AUDIO WITH NAVIGATION]

### < FUNCTION DIAGNOSIS >


- CAN communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.

Items	Display (Current)	Malfunction counter (Past)
Rx (ECM)	OK / UNKWN	OK / 0 - 39
Rx (Cluster)	OK / UNKWN	OK / 0 - 39
Rx (HEV)	OK / UNKWN	OK / 0-39



### Handsfree Phone


The hands-free phone reception volume adjustment, microphone test and memory erase functions are available.



### Bluetooth


#### Passkey confirmation/change

- The passkey of Bluetooth can be confirmed and changed.
- The passkey can be changed by four digits within 0 to 9.



#### Device name confirmation/change

- The device name of Bluetooth can be confirmed and changed.
- The device name can be changed by sixteen digits within A to Z (small character can be used) and - (hyphen).



### XM SAT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

## < FUNCTION DIAGNOSIS >

## [BOSE AUDIO WITH NAVIGATION]

- Change Channel
- Any necessary channels required to receive traffic information from the satellite radio system can be set.

The screenshot shows the 'System Diagnosis > Traffic Info. CH' screen. At the top, there is a title bar with a back arrow and the text 'System Diagnosis > Traffic Info. CH'. Below the title bar, the number '255' is displayed in a large font, followed by a 'Delete' button. Below the number, there is a numeric keypad with buttons for digits 1 through 9, 0, and an 'Enter' button. The screen is labeled 'ALNIA0103ZZ' at the bottom right.

- Change Application ID
- Any application ID's required to receive traffic information from the satellite radio system can be set.

The screenshot shows the 'System Diagnosis > Traffic Info. APPID' screen. At the top, there is a title bar with a back arrow and the text 'System Diagnosis > Traffic Info. APPID'. Below the title bar, the number '8' is displayed in a large font, followed by a 'Delete' button. Below the number, there is a numeric keypad with buttons for digits 1 through 9, 0, and an 'Enter' button. The screen is labeled 'ALNIA0104ZZ' at the bottom right.

- Change EXT ID
- Any EXT ID's required to receive traffic information from the satellite radio system can be set.

The screenshot shows the 'System Diagnosis > Traffic Info. EXTID' screen. At the top, there is a title bar with a back arrow and the text 'System Diagnosis > Traffic Info. EXTID'. Below the title bar, the number '5' is displayed in a large font, followed by a 'Delete' button. Below the number, there is a numeric keypad with buttons for digits 1 through 9, 0, and an 'Enter' button. The screen is labeled 'ALNIA0105ZZ' at the bottom right.

## CONSULT - III Function (MULTI AV)

INFOID:000000001502657

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

MULTI AV diagnosis mode	Description
SELF-DIAG RESULTS	Displays AV control unit self-diagnosis results.
DATA MONITOR	Displays AV control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
AV COMM MONITOR	Allows the technician to monitor the status of the Multi AV system communication signals.
ECU PART NUMBER	The part number of AV control unit can be checked.

### SELF-DIAG RESULTS

Display Item List  
Refer to [AV-241, "DTC Index"](#).

### DATA MONITOR

Display Item List

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Display item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
VHCL SPD SIG [ON/OFF]	X	X	Displays "ON" when vehicle speed > 0 km/h. Displays "OFF" when vehicle speed = 0 km/h.
PKB SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of parking brake switch.
ILLUM SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of lighting switch.
IGN SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of ignition switch.
REV SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of back-up lamp switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## COMPONENT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000001502658

Refer to [LAN-7, "System Description"](#).

#### DTC Logic

INFOID:000000001502659

#### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1000	CAN COMM CIRCUIT [U1000]	When AV control unit is not transmitting or receiving CAN communication signals for 2 seconds or more.

#### Diagnosis Procedure

INFOID:000000001502660

Symptom: Displays "CAN COMM CIRCUIT [U1000]" as a self-diagnosis result of AV control unit.

#### 1. CHECK CAN COMMUNICATION

Select "SELF-DIAG RESULTS" mode for "MULTI AV" with CONSULT-III.

>> Go to "LAN system". Refer to [LAN-10, "Condition of Error Detection"](#).

# U1010 CONTROL UNIT (CAN)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000001502661

Refer to [LAN-7, "System Description"](#).

### DTC Logic

INFOID:000000001502662

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1010	CONTROL UNIT (CAN) [U1010]	When a malfunction is detected during initial diagnosis for CAN controller of each control unit.

### Diagnosis Procedure

INFOID:000000001502663

Symptom: Displays "CONTROL UNIT (CAN) [U1010]" as a self-diagnosis result of AV control unit.

#### 1. CHECK CAN COMMUNICATION

Select "SELF-DIAG RESULTS" mode for "MULTI AV" with CONSULT-III.

>> Go to "LAN system". Refer to [LAN-10, "Condition of Error Detection"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1200 AV CONTROL UNIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1200 AV CONTROL UNIT

### Description

INFOID:000000001502664

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502665

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1200	Cont Unit FLASH-ROM [U1200]	An internal malfunction is detected in AV control unit (FLASH-ROM).	Replace AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a> .



# U1201 AV CONTROL UNIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1201 AV CONTROL UNIT

### Description

INFOID:000000001502666

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502667

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1201	GYRO NO CONN [U1201]	An internal malfunction is detected in AV control unit (gyrocompass disconnection).	Replace AV control unit. Refer to <a href="#">AV-260, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1204 GPS COMM

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1204 GPS COMM

### Description

INFOID:000000001502668

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502669

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1204	GPS COMM [U1204]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a> .

U1205 GPS ROM

Description

INFOID:000000001502670

Refer to [AV-143, "System Description"](#).

DTC Logic

INFOID:000000001502671

DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1205	GPS ROM [U1205]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to <a href="#">AV-260, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# U1206 GPS RAM

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1206 GPS RAM

### Description

INFOID:000000001502672

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502673

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1206	GPS RAM [U1206]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a> .

# U1207 GPS RTC

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1207 GPS RTC

### Description

INFOID:000000001502674

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502675

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1207	GPS RTC [U1207]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to <a href="#">AV-260, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1208 DVD-ROM COMM

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1208 DVD-ROM COMM

### Description

INFOID:000000001502676

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502677

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1208	DVD-ROM COMM [U1208]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502678

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- OK >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).
- NG >> Replace DVD-ROM map.

# U1209 DVD-ROM READ

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1209 DVD-ROM READ

### Description

INFOID:000000001502679

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502680

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1209	DVD-ROM READ [U1209]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502681

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).
- NO >> Replace DVD-ROM map.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U120A DVD-ROM DISC

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U120A DVD-ROM DISC

### Description

INFOID:000000001502682

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502683

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U120A	DVD-ROM DISC [U120A]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502684

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

YES >> Replace AV control unit. Refer to [AV-260. "Removal and Installation"](#).

NO >> Replace DVD-ROM map.



# U120C DVD-ROM MECHA DETECT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U120C DVD-ROM MECHA DETECT

### Description

INFOID:000000001502685

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502686

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U120C	DVD-ROM MECHA DETECT [U120C]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502687

#### 1.CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).
- NO >> Replace DVD-ROM map.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U120D DVD-ROM DRIVE MECHA

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U120D DVD-ROM DRIVE MECHA

### Description

INFOID:000000001502688

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502689

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U120D	DVD-ROM MECHA [U120D]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502690

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).

NO >> Replace DVD-ROM map.

# U1210 DVD-ROM SEEK

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1210 DVD-ROM SEEK

### Description

INFOID:000000001502691

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502692

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1210	DVD-ROM SEEK [U1210]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502693

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).

NO >> Replace DVD-ROM map.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1212 DVD-ROM DATA FORWARD

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1212 DVD-ROM DATA FORWARD

### Description

INFOID:000000001502694

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502695

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1212	DVD-ROM DATA FORWARD [U1212]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502696

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- YES >> Replace AV control unit. Refer to [AV-260. "Removal and Installation"](#).
- NO >> Replace DVD-ROM map.

# U1213 DVD-ROM DATA

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1213 DVD-ROM DATA

### Description

INFOID:000000001502697

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502698

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1213	DVD-ROM DATA [U1213]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502699

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).
- NO >> Replace DVD-ROM map.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1214 DVD-ROM TIMEOUT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1214 DVD-ROM TIMEOUT

### Description

INFOID:000000001502700

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502701

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1214	DVD-ROM TIMEOUT [U1214]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502702

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

- YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).
- NO >> Replace DVD-ROM map.

# U1215 DVD-ROM LOAD

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1215 DVD-ROM LOAD

### Description

INFOID:000000001502703

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502704

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1215	DVD-ROM LOAD [U1215]	An internal malfunction is detected in AV control unit (DVD-ROM).

### Diagnosis Procedure

INFOID:000000001502705

#### 1. CHECK DVD-ROM

Check DVD-ROM for dirt, scratches and warpage.

Is the DVD-ROM clean and undamaged?

YES >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).

NO >> Replace DVD-ROM map.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1216 AV CONTROL UNIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1216 AV CONTROL UNIT

### Description

INFOID:000000001502706

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502707

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1216	CAN CONT [U1216]	An internal malfunction is detected in AV control unit (CAN controller).	Replace AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a> .



# U1217 AV CONTROL UNIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1217 AV CONTROL UNIT

### Description

INFOID:000000001502708

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502709

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1217	BLUETOOTH CONN [U1217]	An internal malfunction is detected in AV control unit (Bluetooth module connection malfunction).	Replace AV control unit. Refer to <a href="#">AV-260, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1220 AV CONTROL UNIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1220 AV CONTROL UNIT

### Description

INFOID:000000001502710

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502711

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition	Action to take
U1220	XM SERIAL COMM [U1220]	An internal malfunction is detected in AV control unit (satellite radio tuner communication malfunction).	Replace AV control unit. Refer to <a href="#">AV-260. "Removal and Installation"</a> .

# U1244 GPS ANTENNA

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U1244 GPS ANTENNA

### Description

INFOID:000000001502712

Refer to [AV-143, "System Description"](#).

### DTC Logic

INFOID:000000001502713

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U1244	GPS ANTENNA CONN [U1244]	GPS antenna connection malfunction is detected.

### Diagnosis Procedure

INFOID:000000001502714

#### 1. GPS ANTENNA CHECK

Inspect GPS antenna and antenna feeder for damage or poor connection.

Is the GPS antenna and feeder clean and undamaged?

YES >> GO TO 2

NO >> Repair or replace malfunctioning parts.

#### 2. CHECK AV CONTROL UNIT VOLTAGE


- Turn ignition switch ON.
- Check voltage between AV control unit connector M90 terminal 73 and ground.

**73 - Ground : Approx. 5V**

Is the voltage reading as specified?

YES >> Replace GPS antenna. Refer to [AV-269, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U124C CD CHANGER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## U124C CD CHANGER

### Description

INFOID:000000001502715

Refer to [AV-143. "System Description"](#).

### DTC Logic

INFOID:000000001502716

### DTC DETECTION LOGIC

DTC	CONSULT-III display	Detection condition
U124C	N-BUS CD CHG CONN [U124C]	<ul style="list-style-type: none"><li>• A malfunction is detected in CD changer power supply and ground circuits</li><li>• Malfunction occurs in request signal circuit. (Between CD changer and AV control unit)</li><li>• Malfunction occurs in communication signal circuit. (Between CD changer and AV control unit)</li></ul>

### Diagnosis Procedure

INFOID:000000001502717

#### 1. CHECK CD CHANGER POWER SUPPLY AND GROUND CIRCUIT

Check CD changer power supply and ground circuit. Refer to [AV-193. "CD CHANGER : Diagnosis Procedure"](#).

Do power and ground check OK?

YES >> GO TO 2

NO >> Repair power supply or ground circuit.

#### 2. CHECK COMMUNICATION CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect CD changer connector M42 and AV control unit connector M48.
3. Check continuity between CD changer harness connector M42 (A) terminals 8, 9 and 10 and AV control unit harness connector M48 (B) terminals 69, 70 and 72.


**8 - 72 : Continuity should exist.**

**9 - 69 : Continuity should exist.**

**10 - 70 : Continuity should exist.**

4. Check continuity between CD changer harness connector M42 (A) terminals 8, 9, 10 and ground.

**8, 9, 10 - Ground : Continuity should not exist.**



Are the continuity test results as specified?



YES >> GO TO 3

NO >> Repair harness or connector.

#### 3. CHECK REQUEST SIGNAL

1. Connect CD changer connector and AV control unit connector.
2. Turn ignition switch ON.
3. Check signal between CD changer harness connector M42 terminal 8 and ground.

**8 - Ground**



# U124C CD CHANGER

[BOSE AUDIO WITH NAVIGATION]

< COMPONENT DIAGNOSIS >

Are the voltage readings as specified?



YES >> GO TO 4

NO >> Replace CD changer. Refer to [AV-262, "Removal and Installation"](#).

## 4. CHECK COMMUNICATION SIGNAL

Check signal between CD changer harness connector M42 terminal 9 and ground.

**9 - Ground**



Are the voltage readings as specified?



YES >> GO TO 5

NO >> Replace CD changer. Refer to [AV-262, "Removal and Installation"](#).

## 5. CHECK COMMUNICATION SIGNAL

Check signal between CD changer harness connector M42 terminal 10 and ground.

**10 - Ground**



Are the voltage readings as specified?

YES >> Inspection End.

NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## POWER SUPPLY AND GROUND CIRCUIT

### AV CONTROL UNIT

#### AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000001502718

### 1.CHECK FUSE

Check that the following fuses of the AV control unit are not blown.

Unit	Terminals	Signal name	Fuse No.
AV control unit	20	Battery power	24
	7	Ignition switch ACC or ON	19
	10	Ignition switch ON or START	3

Are the fuses OK?


YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

### 2.CHECK POWER SUPPLY CIRCUIT

Check voltage between AV control unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Battery power supply	M47	20	OFF	Battery voltage
ACC power supply		7	ACC	
Ignition signal		10	ON	



Are the voltage tests as specified?

YES >> GO TO 3

NO >> Check harness between AV control unit and fuse.

### 3.CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect AV control unit connectors.
3. Check continuity between AV control unit harness connector M47 terminal 19 and ground.

Signal name	Continuity
Ground	Continuity should exist.

Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.



## REAR VIEW CAMERA CONTROL UNIT

#### REAR VIEW CAMERA CONTROL UNIT : Diagnosis Procedure

INFOID:000000001502719

### 1.CHECK FUSE

Check that the following fuses of the rear view camera control unit are not blown.

Unit	Terminals	Signal name	Fuse No.
Rear view camera control unit	1	Battery power	24
	2	Ignition switch ACC or ON	19

# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

### Are the fuses OK?

YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

## 2.CHECK POWER SUPPLY CIRCUIT


Check voltage between rear view camera control unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Battery power supply	B31	1	OFF	Battery voltage
ACC power supply		2	ACC	

### Are the voltage readings as specified?

YES >> GO TO 3

NO >> Check harness between rear view camera control unit and fuse.



## 3.CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector.
3. Check continuity between rear view camera control unit harness connector B31 terminal 3 and ground.

Signal name	Continuity
Ground	Continuity should exist.

### Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.



## REAR VIEW CAMERA

### REAR VIEW CAMERA : Diagnosis Procedure

INFOID:0000000011502720

## 1.CHECK POWER SUPPLY CIRCUIT (REAR VIEW CAMERA SIDE)


Check voltage between rear view camera harness connector and ground.

Signal name	Connector No.	Terminal No.	Transmission position	Value (Approx.)
Camera ON signal	B35	1	Reverse	6V

### Is voltage reading approximately 6 volts?

YES >> GO TO 4

NO >> GO TO 2



## 2.CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect rear view camera and rear view camera control unit connectors.

# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

- Check continuity between rear view camera harness connector B35 (A) terminal 1 and rear view camera control unit harness connector B31 (B) terminal 8.

Signal name	Continuity
Camera ON signal	Continuity should exist.

- Check continuity between rear view camera harness connector B35 (A) terminal 1 and ground.

Signal name	Continuity
Camera ON signal	Continuity should not exist.

Are continuity test results as specified?

- YES >> GO TO 3  
 NO >> Repair harness or connector.

### 3.CHECK POWER SUPPLY CIRCUIT (CAMERA CONTROL UNIT SIDE)

- Connect rear view camera control unit harness connector.
- Turn ignition switch ON.
- Check voltage between rear view camera control unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Transmission position	Value (Approx.)
Camera ON signal	B31	8	Reverse	6V

Is voltage reading approximately 6 volts?

- YES >> Inspection End.  
 NO >> Replace rear view camera control unit. Refer to [AV-275](#).  
["Removal and Installation"](#).

### 4.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect rear view camera harness connector.
- Check continuity between rear view camera harness connector B35 terminal 2 and ground.

Signal name	Continuity
Ground	Continuity should exist.

Does continuity exist?

- YES >> Inspection End.  
 NO >> Repair harness or connector.

## BOSE SPEAKER AMP

### BOSE SPEAKER AMP : Diagnosis Procedure




INFOID:000000001502721

#### 1.CHECK FUSE

Check that the following fuses of the BOSE speaker amp. are not blown.

Unit	Terminals	Signal name	Fuse No.
BOSE speaker amp.	50	Battery power	25
	51		26

Are the fuses OK?





# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]


## < COMPONENT DIAGNOSIS >

- YES >> GO TO 2  
 NO >> Be sure to eliminate cause of malfunction before installing new fuse.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp connector.
3. Check voltage between BOSE speaker amp harness connector and ground.

Unit	Terminal No.		Voltage (approx.)
	(+)		
	Connector	Terminal	
BOSE speaker amp	B122	50	Ground
		51	




Are the voltage readings as specified?

- YES >> GO TO 3  
 NO >> Check harness between BOSE speaker amp. and fuse.

### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp connector.
3. Check continuity between BOSE speaker amp harness connector and ground.

Unit	Terminal No.		Continuity
	(+)		
	Connector	Terminal	
BOSE speaker amp	B122	47	Ground
		52	



Are continuity test results as specified?

- YES >> Inspection End.  
 NO >> Repair harness or connector.

## CD CHANGER

### CD CHANGER : Diagnosis Procedure

INFOID:000000001502722

#### 1.CHECK FUSE

Check that the following fuses of the CD changer are not blown.

Unit	Terminals	Signal name	Fuse No.
CD changer	12	Battery power	24
	16	Ignition switch ACC or ON	19

Are the fuses OK?

- YES >> GO TO 2  
 NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2.CHECK POWER SUPPLY CIRCUIT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

Check voltage between CD changer harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Battery power supply	M42	12	OFF	Battery voltage
ACC power supply		16	ACC	

Are the voltage readings as specified?

YES >> Inspection End.

NO >> Check harness between CD changer and fuse.

## MICROPHONE

### MICROPHONE : Diagnosis Procedure

INFOID:000000001502723

#### 1. CHECK POWER SUPPLY CIRCUIT (MICROPHONE SIDE)

Check voltage between microphone harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Microphone VCC signal	R7	4	ON	5V

Is proper voltage present?

YES >> GO TO 4

NO >> GO TO 2

#### 2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

- Turn ignition switch OFF.
- Disconnect microphone and AV control unit harness connectors.
- Check continuity between microphone harness connector R7 (A) terminal 4 and AV control unit harness connector M46 (B) terminal 46.

Signal name	Continuity
Microphone VCC signal	Continuity should exist.

- Check continuity between microphone harness connector R7 (A) terminal 4 and ground.

Signal name	Continuity
Microphone VCC signal	Continuity should not exist.




Are the continuity test results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

#### 3. CHECK POWER SUPPLY CIRCUIT (AV CONTROL UNIT SIDE)

- Connect AV control unit harness connector.
- Turn ignition switch to ACC.



# POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]


## < COMPONENT DIAGNOSIS >

- Check voltage between AV control unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Value (Approx.)
Microphone VCC signal	M46	46	ACC	5V

Is voltage approximately 5 volts?

- YES >> Inspection End.  
 NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).




## 4.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect microphone harness connector R7 and AV control unit harness connector M46.
- Check continuity between microphone harness connector R7 (A) terminal 2 and AV control unit harness connector M46 (B) terminal 47.

Signal name	Continuity
Ground	Continuity should exist.

Does continuity exist?

- YES >> Inspection End.  
 NO >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT DOOR SPEAKER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## FRONT DOOR SPEAKER

### Description

INFOID:000000001502724

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502725

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B121 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connector B121 (A) and suspect speaker harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B121	58	D3	1	Yes
	59		2	
	71	D103	1	
	72		2	

3. Check continuity between BOSE speaker amp. harness connector B121 (A) and ground.

Terminals			Continuity
A		—	
Connector	Terminal		
B121	58	Ground	No
	59		
	71		
	72		


Are continuity test results as specified?

YES >> GO TO 2

NO >> • Check connector housings for disconnected or loose terminals.

- Repair harness or connector.

#### 2. FRONT DOOR SPEAKER SIGNAL CHECK



ALNIA0134ZZ


# FRONT DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B121 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B121 terminals with CONSULT-III or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B121	58	59	Receive audio signal	
	71	72		



Is audio signal voltage as specified?

YES >> Replace suspect speaker. Refer to [AV-265. "Removal and Installation"](#).

NO >> GO TO 3

## 3. HARNESS CHECK

1. Disconnect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M47 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M47	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between AV control unit harness connector M47 (A) and ground.


Terminals			Continuity
A		—	
Connector	Terminal		
M47	2	Ground	No
	3		
	11		
	12		

Are continuity test results as specified?

YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. FRONT DOOR SPEAKER SIGNAL CHECK



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# FRONT DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M47	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-261, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



# TWEETER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## TWEETER

### Description

INFOID:000000001502726

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the tweeters using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502727

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B122 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connector B122 (A) and suspect tweeter harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B122	41	M51	1	Yes
	42		2	
	44	M52	1	
	43		2	

3. Check continuity between BOSE speaker amp. harness connector B122 (A) and ground.


Terminals				Continuity
A		—		
Connector	Terminal			
B122	41	Ground		No
	42			
	44			
	43			

Are continuity test results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. TWEETER SIGNAL CHECK



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# TWEETER

## < COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

1. Connect BOSE speaker amp. connector B122 and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B122 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B122	41	42	Receive audio signal	
	44	43		

SKIA0177E

Are voltage readings as specified?

YES >> Replace suspect tweeter. Refer to [AV-263, "Removal and Installation"](#).

NO >> GO TO 3

### 3. HARNESS CHECK

1. Disconnect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Check continuity between AV control unit harness connector (A) M47 and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M47	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between AV control unit harness connector B121 (A) and ground.



Terminals			Continuity
A		—	
Connector	Terminal		
M47	2	Ground	No
	3		
	11		
	12		

Are continuity test results as specified?

YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

### 4. TWEETER SIGNAL CHECK






# TWEETER

## < COMPONENT DIAGNOSIS >

## [BOSE AUDIO WITH NAVIGATION]


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M47	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-261, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# CENTER SPEAKER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## CENTER SPEAKER

### Description

INFOID:000000001502728

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the center speaker using the audio signal circuits.


### Diagnosis Procedure

INFOID:000000001502729

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B121 and center speaker connector M151.
2. Check continuity between BOSE speaker amp. harness connector B121 (A) and center speaker harness connector M151 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B121	69	M151	1	Yes
	70		2	



3. Check continuity between BOSE speaker amp. harness connector B121 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
B121	69	Ground		No
	70			

Are continuity test results as specified?


YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. CENTER SPEAKER SIGNAL CHECK

1. Connect BOSE speaker amp. connector B121 and center speaker connector M151.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B121 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B121	69	70	Receive audio signal	<p style="text-align: right;">SKIA0177E</p>



Is the audio signal voltage as specified?

YES >> Replace center speaker. Refer to [AV-264. "Removal and Installation"](#).

NO >> GO TO 3

# CENTER SPEAKER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## 3. HARNESS CHECK

1. Disconnect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Check continuity between audio unit harness connector M47 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
M47	2	B121	75	Yes
	3		76	
	11		73	
	12		74	

3. Check continuity between AV control unit harness connector M47 (A) and ground.

Terminals				Continuity
A		—		
Connector	Terminal			
M47	2	Ground		No
	3			
	11			
	12			

Are continuity test results as specified?

YES >> GO TO 4

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. CENTER SPEAKER SIGNAL CHECK



1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M47 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M47	2	3	Receive audio signal	
	11	12		

SKIA0177E

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-261, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# REAR DOOR SPEAKER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## REAR DOOR SPEAKER

### Description

INFOID:000000001502730

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502731


#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors B121, B122 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connectors B121 (A) and B122 (B) and suspect speaker harness connector (C).

Terminals				Continuity
Connector	Terminal	Connector	Terminal	
A: B121	55	C: D202	2	Yes
	68		1	
B: B122	49	C: D302	2	
	54		1	

3. Check continuity between BOSE speaker amp. harness connectors B121 (A) and B122 (B) and ground.

Terminals			Continuity
BOSE speaker amp.		—	
Connector	Terminal		
A: B121	68	Ground	No
	55		
B: B122	49		
	54		



ALNIA0141ZZ

Are the continuity test results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. REAR DOOR SPEAKER SIGNAL CHECK

# REAR DOOR SPEAKER


[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors B121, B122 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors (A) B121 and (B) B122 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
A: B121	68	55	Receive audio signal	
B: B122	54	49		

SKIA0177E




Is the audio signal voltage readings as specified?

- YES >> Replace suspect speaker. Refer to [AV-266. "Removal and Installation"](#).
- NO >> GO TO 3.

## 3. HARNESS CHECK

1. Disconnect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Check continuity between AV control unit harness connector M47 (A) and BOSE speaker amp. harness connector B121 (B).

Terminals				Continuity
AV control unit		BOSE speaker amp.		
Connector	Terminal	Connector	Terminal	
M47	5	B121	64	Yes
	6		63	
	14		66	
	15		65	



3. Check continuity between AV control unit harness connector M47 (A) and ground.

Terminals			Continuity
AV control unit		Ground	
Connector	Terminal		
M47	5	Ground	No
	6		
	14		
	15		

Are continuity test results as specified?

- YES >> GO TO 4
- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 4. REAR DOOR SPEAKER SIGNAL CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# REAR DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]


< COMPONENT DIAGNOSIS >

1. Connect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M47 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M47	5	6	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	14	15		

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-261, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



# WOOFER

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## WOOFER

### Description

INFOID:000000001502732

The audio unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the woofers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000001502733

#### 1. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B122 and suspect rear subwoofer connector.
2. Check continuity between BOSE speaker amp. harness connector B122 (A) and suspect rear subwoofer harness connector (B).

Terminals				Continuity
A		B		
Connector	Terminal	Connector	Terminal	
B122	53	B120	1	Yes
	48		2	
	45	B124	1	
	46		2	

3. Check continuity between BOSE speaker amp. harness connector B122 (A) and ground.


Terminals				Continuity
A		—		
Connector	Terminal			
B122	53	Ground		No
	48			
	45			
	46			

Are the continuity test results as specified?

YES >> GO TO 2

- NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

#### 2. REAR SUBWOOFER SIGNAL CHECK




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# WOOFER

## < COMPONENT DIAGNOSIS >

## [BOSE AUDIO WITH NAVIGATION]

1. Connect BOSE speaker amp. connector B122 and suspect rear subwoofer connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B122 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B122	53	48	Receive audio signal	
	45	46		

SKIA0177E

Is the audio signal voltage as specified?

YES >> Replace suspect rear subwoofer. Refer to [AV-132](#), "[Removal and Installation](#)".

NO >> GO TO 3

### 3. HARNESS CHECK

1. Disconnect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Check continuity between AV control unit harness connector M47 (A) and BOSE speaker amp. harness connector B121 (B).

A		B.		Continuity
Connector	Terminal	Connector	Terminal	
M47	5	B121	64	Yes
	6		63	
	14		66	
	15		65	

3. Check continuity between AV control unit harness connector M47 (A) and ground.



A		—	Continuity
Connector	Terminal		
M47	5	Ground	No
	6		
	14		
	15		

Are continuity test results as specified?

YES >> GO TO 4

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

### 4. REAR SUBWOOFER SIGNAL CHECK






# WOOFER

## < COMPONENT DIAGNOSIS >


## [BOSE AUDIO WITH NAVIGATION]

1. Connect AV control unit connector M47 and BOSE speaker amp. connector B121.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M47 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M47	5	6	Receive audio signal	
	14	15		

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-261, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AMP ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## AMP ON SIGNAL CIRCUIT

### Description

INFOID:000000001502734

When the audio system is turned on, a voltage signal is supplied from the AV control unit to the BOSE speaker amp. When this signal is received, the BOSE speaker amp. will turn on.

### Diagnosis Procedure

INFOID:000000001502735


#### 1. CHECK AMP ON SIGNAL (BOSE SPEAKER AMP)

1. Turn audio system ON.
2. Check voltage between BOSE speaker amp. harness connector B121 terminal 60 and ground.

**60 - Ground : More than approx. 6.5V**

Is voltage greater than 6.5V?

- YES >> Inspection End.  
NO >> GO TO 2




#### 2. CHECK AMP ON SIGNAL (AV CONTROL UNIT)

Check voltage between AV control unit harness connector M47 terminal 16 and ground.

**16 - Ground : More than approx. 6.5V**

Is voltage approximately 6.5 volts?

- YES >> Repair harness or connector.  
NO >> Replace AV control unit. Refer to [AV-260, "Removal and Installation"](#).



# STEERING SWITCH

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## STEERING SWITCH

### Description

INFOID:000000001502736

When one of the steering wheel audio control switches is pushed, the resistance in the steering switch circuit changes depending on which button is pushed.


### Diagnosis Procedure

INFOID:000000001502737

#### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M46 and spiral cable connector M30.
3. Check continuity between AV control unit connector M46 terminals 25, 26, and 27 and spiral cable connector M30 terminals 24, 31, and 33.

Terminals				Continuity
AV control unit		Spiral cable		
Connector	Terminal	Connector	Terminal	
M46	25	M30	24	Yes
	26		33	
	27		31	



4. Check continuity between AV control unit connector M46 and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal		
M46	25	Ground	No
	26		
	27		


Are the continuity test results as specified?

- YES >> GO TO 2  
 NO >> Repair harness.

#### 2. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M88.
2. Check continuity between spiral cable harness connector M30 and M88.

Terminals				Continuity
Spiral cable				
Connector	Terminal	Connector	Terminal	
M30	24	M88	14	Yes
	31		15	
	33		17	



Are the continuity test results as specified?

- YES >> GO TO 3.  
 NO >> Replace spiral cable. Refer to [SRS-6, "Removal and Installation"](#).

#### 3. CHECK STEERING SWITCH

Check steering switch. Refer to [AV-212, "Component Inspection"](#).

Does the steering switch pass inspection?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# STEERING SWITCH

[BOSE AUDIO WITH NAVIGATION]

## < COMPONENT DIAGNOSIS >

- YES >> Inspection End.
- NO >> Replace steering switch. Refer to [AV-270, "Removal and Installation"](#).

## Component Inspection

INFOID:000000001502738

Measure the resistance between the steering switch connector terminals 14 to 17 and 15 to 17.


Standard

### Between terminals 14 and 17

- ENTER switch ON** : 2003 – 2043  $\Omega$
- switch ON** : 716 – 730  $\Omega$
- MENU DOWN switch ON** : 318 – 324  $\Omega$
- MENU UP switch ON** : 120 – 122  $\Omega$
- SOURCE switch ON** : 0  $\Omega$

### Between terminals 15 and 17

- switch ON** : 716 – 730  $\Omega$
- switch ON** : 318 – 324  $\Omega$
- VOL UP switch ON** : 120 – 122  $\Omega$
- VOL DOWN switch ON** : 0  $\Omega$



# MICROPHONE SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## MICROPHONE SIGNAL CIRCUIT

### Description

INFOID:000000001502739

Power is supplied to the microphone from the AV control unit. The microphone transmits voice signals to the AV control unit.

### Diagnosis Procedure

INFOID:000000001502740

#### 1. CHECK CONTINUITY BETWEEN AV CONTROL UNIT AND MICROPHONE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M46 and microphone connector R7.
3. Check continuity between AV control unit harness connector M46 (A) terminals 45, 46, 47 and microphone harness connector R7 (B) terminals 1, 2, 4.


**45 - 1 : Continuity should exist.**

**47 - 2 : Continuity should exist.**

**46 - 4 : Continuity should exist.**

4. Check continuity between AV control unit harness connector M46 (A) terminals 45, 46, 47 and ground.

**45, 46, 47 - Ground : Continuity should not exist.**



Is inspection result OK?

YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK MICROPHONE VCC VOLTAGE


1. Connect AV control unit connector.
2. Turn ignition switch ON.
3. Check voltage between AV control unit harness connector M46 terminals 46 and 47.

**46 - 47 : Approx. 5V**

Is inspection result OK?

YES >> GO TO 3



NO >> Replace AV control unit. Refer to [AV-260. "Removal and Installation"](#).



#### 3. CHECK MICROPHONE SIGNAL

1. Connect microphone connector.
2. Check signal between AV control unit harness connector M46 terminals 45 and 47.

**45 - 47 :**



Is inspection result OK?

YES >> Replace AV control unit. Refer to [AV-260. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

## MICROPHONE SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

---

NO >> Replace microphone. Refer to [AV-271, "Removal and Installation"](#).

# CAMERA IMAGE SIGNAL CIRCUIT (REAR VIEW CAMERA TO CAMERA CONTROL UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## CAMERA IMAGE SIGNAL CIRCUIT (REAR VIEW CAMERA TO CAMERA CONTROL UNIT)

### Description

INFOID:000000001502741

Rear view camera images are transmitted to the rear view camera control unit using the camera image signal circuits.

### Diagnosis Procedure

INFOID:000000001502742

#### 1. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY


1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector and rear view camera connector.
3. Check continuity between rear view camera control unit harness connector B31 (A) terminals 9, 10 and rear view camera harness connector B35 (B) terminals 3, 4.

**9 - 4** : Continuity should exist.

**10 - 3** : Continuity should exist.

4. Check continuity between rear view camera control unit harness connector B31 (A) terminals 9, 10 and ground.

**9, 10 - Ground** : Continuity should not exist.



Is inspection result OK?



YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK CAMERA IMAGE SIGNAL

1. Connect rear view camera control unit connector and rear view camera connector.
2. Turn ignition switch ON.
3. Check signal between rear view camera control unit harness connector B31 terminals 10 and 9.

**10 - 9** :



Is inspection result OK?

YES >> Replace rear view camera control unit. Refer to [AV-275, "Removal and Installation"](#).

NO >> Replace rear view camera. Refer to [AV-274, "Removal and Installation"](#).

# CAMERA ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## CAMERA ON SIGNAL CIRCUIT

### Description

INFOID:000000001502743

When the selector lever is placed in the R position, the rear view camera control unit sends a camera ON signal to the rear view camera.

### Diagnosis Procedure

INFOID:000000001502744

#### 1. CHECK CAMERA ON SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector and rear view camera connector.
3. Check continuity between rear view camera control unit harness connector B31 (A) terminal 8 and rear view camera harness connector B35 (B) terminal 1.

**8 - 1 : Continuity should exist.**

4. Check continuity between rear view camera control unit harness connector B31 (B) terminal 8 and ground.

**8 - Ground : Continuity should not exist.**

Is inspection result OK?

YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK CAMERA ON SIGNAL VOLTAGE



1. Connect rear view camera control unit connector and rear view camera connector.
2. Turn ignition switch ON.
3. Check voltage between rear view camera control unit harness connector B31 terminal 8 and ground.

**8 - Ground : Approx. 6V**

Is inspection result OK?

YES >> Replace rear view camera. Refer to [AV-274, "Removal and Installation"](#).

NO >> Replace rear view camera control unit. Refer to [AV-275, "Removal and Installation"](#).





# CAMERA IMAGE SIGNAL CIRCUIT (CAMERA CONTROL UNIT TO AV CONTROL UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## CAMERA IMAGE SIGNAL CIRCUIT (CAMERA CONTROL UNIT TO AV CONTROL UNIT)

### Description

INFOID:000000001502745

Rear view camera image signals are transmitted from the rear view camera control unit to the AV control unit using the image signal circuits.

### Diagnosis Procedure

INFOID:000000001502746

#### 1. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY


1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector B31 and AV control unit connector M46.
3. Check continuity between rear view camera control unit harness connector B31 (A) terminals 11, 12 and AV control unit harness connector M46 (B) terminals 34, 55.

**11 - 55** : Continuity should exist.

**12 - 34** : Continuity should exist.

4. Check continuity between rear view camera control unit harness connector B31 (A) terminals 11, 12 and ground.

**11, 12 - Ground** : Continuity should not exist.



Is inspection result OK?



YES >> GO TO 2

NO >> Repair harness or connector.

#### 2. CHECK CAMERA IMAGE SIGNAL

1. Connect rear view camera control unit connector and AV control unit connector.
2. Turn ignition switch ON.
3. Check signal between rear view camera control unit harness connector B31 terminals 12 and 11.

**12 - 11** :



Is inspection result OK?

YES >> Replace AV control unit. Refer to [AV-260. "Removal and Installation"](#).

NO >> Replace rear view camera control unit. Refer to [AV-275. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REVERSE SIGNAL CIRCUIT

### Description

INFOID:000000001502747

A reverse signal is supplied from the back-up lamp relay to the rear view camera control unit. When this signal is received, the display shows a view to the rear of the vehicle.

### Diagnosis Procedure

INFOID:000000001502748

#### 1. BACK-UP LAMP INSPECTION

1. Turn ignition switch ON.
2. Shift selector lever to R position.

Does back-up lamp illuminate?

- YES >> GO TO 2  
 NO >> Check back-up lamp system. Refer to [EXL-4, "Work Flow"](#).

#### 2. CHECK REVERSE POSITION INPUT SIGNAL

 **With CONSULT-III**

Select "DATA MONITOR" of "REARVIEW CAMERA". Operate ignition switch with "R POSI SIG" of "DATA MONITOR" and check operate status.


 **Without CONSULT-III**

1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector.
3. Turn ignition switch ON.
4. Shift selector lever to R position.
5. Check voltage between rear view camera control unit harness connector B31 terminal 4 and ground.

**Battery voltage should exist.**

Does battery voltage exist?

- YES >> Inspection End.  
 NO >> Check harness for open or short between rear view camera control unit and back-up lamp relay.



# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## ECU DIAGNOSIS

### AV CONTROL UNIT

Reference Value


INFOID:000000001502749

#### VALUES ON THE DIAGNOSIS TOOL

CONSULT-III data monitor item

Display Item	Display	Vehicle status	Remarks
VHCL SPD SIG	ON	Vehicle speed > 0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	Vehicle speed = 0 km/h (0 MPH)	
PKB SIG	ON	Parking brake is applied.	
	OFF	Parking brake is released.	
ILLUM SIG	ON	Block the light beam from the auto light optical sensor when the light SW is ON .	—
	OFF	Expose the auto light optical sensor to light when the light SW is OFF or ON.	
IGN SIG	ON	Ignition switch ON	
	OFF	Ignition switch in ACC position	
REV SIG	ON	Selector lever in R position	Changes in indication may be delayed. This is normal.
	OFF	Selector lever in any position other than R	

#### TERMINAL LAYOUT







#### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
1 (G/R)	Ground	Parking brake signal	Input	Ignition switch ON	Parking brake ON	0V
					Parking brake OFF	Battery voltage
2 (G)	3 (R)	Sound signal front LH	Output	Ignition switch ON	—	<p>SKIB3609E</p>
4	—	Shield	—	—	—	—

# AV CONTROL UNIT

< ECU DIAGNOSIS >



[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
5 (GR/V)	6 (W/L)	Sound signal rear LH	Output	Ignition switch ON	—	 <small>SKIB3609E</small>
7 (V/Y)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
8 (V/W)	Ground	Vehicle speed (8-pulse) signal	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	 <small>SKIA6649J</small>
9 (R/L)	Ground	Illumination signal	Input	OFF	Lighting switch is OFF.	0V
					Lighting switch is ON.	Battery voltage
10 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
11 (B)	12 (W)	Sound signal front RH	Output	Ignition switch ON	—	 <small>SKIB3609E</small>
13	—	Shield	—	—	—	—
14 (V)	15 (LG)	Sound signal rear RH	Output	Ignition switch ON	—	 <small>SKIB3609E</small>
16 (B/P)	Ground	Amp. ON signal	Output	Ignition switch ON	—	Battery voltage
17 (P/B)	Ground	Reverse signal	Input	Ignition switch ON	R position	Battery voltage
18 (R/Y)	Ground	Illumination control	Input	OFF	—	Refer to <a href="#">INL-9, "System Description"</a> .
19 (B)	Ground	Ground	—	Ignition switch ON	—	0V

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]






Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
20 (Y/R)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
24 (L)	—	CAN-H	Input/ Output	—	—	—
25 (W/G)	26 (L/B)	Steering switch signal 1	Input	Ignition switch ON	Keep pressing SOURCE switch.	0V
					Keep pressing MENU UP switch.	1V
					Keep pressing MENU DOWN switch.	2V
					Keep pressing  switch	3V
					Keep pressing ENTER switch.	4V
					Except for above.	5V
26 (L/B)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0V
27 (GR/L)	26 (L/B)	Steering switch signal 2	Input	Ignition switch ON	Keep pressing VOL DOWN switch.	0V
					Keep pressing VOL UP switch.	1V
					Keep pressing  switch.	2V
					Keep pressing  switch.	3V
					Except for above.	5V
28	—	Shield	—	—	—	—
31 (W/R)	Ground	AUX sound signal RH	Input	Ignition switch ON	When AUX mode is select- ed	 <small>SKIB3609E</small>
32 (W)	Ground	AUX ground	—	Ignition switch ON	—	0V
33 (W/L)	Ground	AUX sound signal LH	Input	Ignition switch ON	When AUX mode is select- ed	 <small>SKIB3609E</small>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AV CONTROL UNIT

< ECU DIAGNOSIS >




[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
34 (W)	Ground	Camera image signal	Input	Ignition switch ON	Rear view camera image displayed	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
35	—	Shield	—	—	—	—
44 (P)	—	CAN-L	Input/ Output	—	—	—
45 (B/R)	Ground	Microphone signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">PKIB5037J</p>
46 (R/L)	Ground	Microphone VCC	Output	Ignition switch ON	—	5V
47 (R/B)	Ground	Microphone ground	—	Ignition switch ON	—	0V
48	—	Shield	—	—	—	—
53 (V/G)	Ground	Camera-connection rec- ognition signal	Input	Ignition switch ON	Connected to camera con- trol unit connector	0V
					Not connected to camera control unit connector	5V
55 (R)	Ground	Camera image signal	Input	Ignition switch ON	Rear view camera image displayed	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
62 (Y/L)	61 (W/L)	CD changer sound sig- nal LH	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
64 (Y/G)	63 (BR/L)	CD changer sound sig- nal RH	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
65	—	Shield	—	—	—	—
66	—	Shield	—	—	—	—
69 (B)	Ground	Communication signal (CD→CONT)	Input	Ignition switch ON	—	
70 (G)	Ground	Communication signal (CONT→CD)	Input	Ignition switch ON	—	
72 (R)	Ground	Request signal (CD→CONT)	Output	Ignition switch ON	—	
73 (B)	—	GPS signal	Input	Ignition switch ACC	Not connected to GPS an- tenna connector	5V
74 (B)	—	Shield	—	—	—	—
75 (B)	Ground	Antenna amp. supply	Output	Ignition switch ACC	—	Battery voltage
76 (B)	—	Main antenna	Input	—	—	—
78 (B)	Ground	Satellite antenna signal	Input	Ignition switch ACC	Not connected to satellite antenna connector	5V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV


# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## Wiring Diagram

INFOID:000000001502750



ALNWA0034GE






# AV CONTROL UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]



# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]



ALNWA0027GE


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

< ECU DIAGNOSIS >

### BOSE AUDIO WITH NAVIGATION SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




# AV CONTROL UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR/R	-
4	GR/L	-
5	G/W	-
6	B/Y	-
7	W	-
9	B/R	-
10	O/B	-
11	R/G	-
12	B/P	-
13	BR	-
14	L/O	-
15	B	-
16	LG	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	V	-
3	SHIELD	-
4	GR/V	-
8	B/P	-
10	B	-
11	SHIELD	-
12	G	-
13	LG	-
14	SHIELD	-
15	W/L	-
21	W	-
22	SHIELD	-
23	R	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/R	-
2	R/B	-
3	R/L	-
4	SHIELD	-

Connector No.	M22
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	O	K-LINE

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-

ALNIA0118GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# AV CONTROL UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
31	V/W	8P/R OUT

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
24	W/G	AUDIO_STRG_SW_REMOTE_A
31	GR/L	AUDIO_STRG_SW_REMOTE_B
33	L/B	AUDIO_STRG_SW_GND

Connector No.	M41
Connector Name	AUX JACK
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/R	AUX_OUT_R
2	W	AUX_GND
3	-	-
4	W/L	AUX_OUT_L

Connector No.	M42
Connector Name	CD CHANGER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/L	N-BUS L-
2	Y/L	N-BUS L+
3	BR/L	N-BUS R-
4	Y/G	N-BUS R+
5	SHIELD	-
6	-	DATA_GND
7	-	-
8	R	REQ
9	B	RX
10	G	TX
12	Y/R	B+
13	R/Y	ILL-
14	R/L	ILL+
16	V/Y	ACC

ALNIA0119GB

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	M46
Connector Name	AV CONTROL UNIT
Connector Color	WHITE



21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60

Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	-	-
24	L	V-CAN_H
25	W/G	STRG_SW_SIG_1
26	L/B	STRG_SW_GND
27	GR/L	STRG_SW_SIG_2
28	SHIELD	-

Connector No.	M47
Connector Name	AV CONTROL UNIT
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	
10	11	12	13	14	15	16	17	18	20

Terminal No.	Color of Wire	Signal Name
1	G/R	PKB
2	G	FR_LH +
3	R	FR_LH -
4	SHIELD	-
5	GR/V	RR_LH +
6	W/L	RR_LH -

Terminal No.	Color of Wire	Signal Name
29	-	-
30	-	-
31	W/R	AUX_IN_R
32	W	AUX_GND
33	W/L	AUX_IN_L
34	W	COMP_IN +
35	SHIELD	-
36	-	-
37	-	-
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-
43	-	-
44	P	V-CAN_L

Terminal No.	Color of Wire	Signal Name
45	B/R	MIC_IN+
46	R/L	MIC_+B
47	R/B	MIC_GND
48	SHIELD	-
49	-	-
50	-	-
51	-	-
52	-	-
53	V/G	RV_CAM_SIG
54	-	-
55	R	COMP_IN-
56	-	-
57	-	-
58	-	-
59	-	-
60	-	-

Terminal No.	Color of Wire	Signal Name
7	V/Y	ACC
8	V/W	SPEED (8P)
9	R/L	ILL
10	G	IGN
11	B	FR_RH +
12	W	FR_RH -
13	SHIELD	-
14	V	RR_RH +
15	LG	RR_RH -
16	B/P	AMP_ON
17	P/B	RV
18	R/Y	ILL_CONT
19	B	GND
20	Y/R	B+

ALNIA0120GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	M51
Connector Name	TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B/Y	-

Connector No.	M50
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

Connector No.	M48
Connector Name	AV CONTROL UNIT
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
61	W/L	N-BUS_L -
62	Y/L	N-BUS_L +
63	BR/L	N-BUS_R -
64	Y/G	N-BUS_R +
65	SHIELD	-
66	-	DATA_GND
67	-	-
68	-	-
69	B	RX
70	G	TX
71	-	-
72	R	REQ2

Connector No.	M64
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	M63
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
8	B	-
10	GR	-

Connector No.	M52
Connector Name	TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/O	-
2	GR/L	-

ALNIA0039GB




# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	M88
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
14	W	REMOTE A
15	L	REMOTE B
17	BR	GND

Connector No.	M87
Connector Name	WINDOW ANTENNA
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M81
Connector Name	AV CONTROL UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
75	B	AMP SUPPLY
76	B	MAIN ANTENNA
77	-	-

Connector No.	M92
Connector Name	ROOF ANTENNA (SATELLITE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M91
Connector Name	AV CONTROL UNIT
Connector Color	VIOLET



Terminal No.	Color of Wire	Signal Name
78	B	-

Connector No.	M90
Connector Name	AV CONTROL UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
73	B	-
74	B	-

ALNIA0121GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	M151
Connector Name	CENTER SPEAKER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

Connector No.	M150
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/P	-
2	O/B	-

Connector No.	M93
Connector Name	ROOF ANTENNA (AUDIO)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	E34
Connector Name	BACK-UP LAMP RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	Y	-
3	P/B	-
5	O	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	E46
Connector Name	JUNCTION BLOCK
Connector Color	WHITE



51	30	29	28	27	26	25		
40	39	38	37	36	35	34	33	32

Terminal No.	28	Color of Wire	O/B	Signal Name	-
--------------	----	---------------	-----	-------------	---

Connector No.	E45
Connector Name	JUNCTION BLOCK
Connector Color	WHITE



17	16	15	14	13		
24	23	22	21	20	19	18

Terminal No.	13	Color of Wire	GR	Signal Name	-
--------------	----	---------------	----	-------------	---


Connector No.	E35
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



1
---

Terminal No.	1	Color of Wire	G/R	Signal Name	-
--------------	---	---------------	-----	-------------	---


Connector No.	E49
Connector Name	JUNCTION BLOCK
Connector Color	BROWN



54	53	52	51
----	----	----	----

Terminal No.	53	Color of Wire	G/R	Signal Name	-
--------------	----	---------------	-----	-------------	---


Connector No.	E47
Connector Name	JUNCTION BLOCK
Connector Color	WHITE



42	41		
46	45	44	43

Terminal No.	41	Color of Wire	G/R	Signal Name	-
--------------	----	---------------	-----	-------------	---

Connector No.	E66
Connector Name	HIGH VOLTAGE ECU
Connector Color	BLACK



168	167	166	165	164	163	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61
174	173	172	171	170	169	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96	95
180	179	178	177	176	175	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113	112
186	185	184	183	182	181	162	161	160	159	158	157	156	155	154	153	152	151	150	149	148	147	146

Terminal No.	82	Color of Wire	G/B	Signal Name	BL
--------------	----	---------------	-----	-------------	----

ALNIA0123GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/B	-
5	W/R	-

Terminal No.	Color of Wire	Signal Name
10J	GR	-
18J	BR/B	-
19J	R/G	-
84J	P/B	-
85J	SHIELD	-
86J	V/G	-
87J	R	-
88J	W	-
90J	V	-
91J	O	-
92J	Y	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B22
Connector Name	JOINT CONNECTOR-B07
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P/B	-
2	P/B	-
4	P/B	-
5	P/B	-
6	P/B	-

Connector No.	B20
Connector Name	JOINT CONNECTOR-B05
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR	-
3	GR	-
5	GR	-
6	B	-

Connector No.	B10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
15	P/B	-

ALNIA0177GB


# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Terminal No.	Color of Wire	Signal Name
1	Y	B +
2	V	ACC
3	B	GND
4	P/B	REV
5	V/G	CONTROL 1
6	O	DDL (K-LINE)
8	GR	CAMERA ON
9	L	CAMERA -
10	P	CAMERA +
11	R	COMP -
12	W	COMP +

Connector No.	B31
Connector Name	REAR VIEW CAMERA CONTROL UNIT
Connector Color	WHITE



Connector No.	B24
Connector Name	JOINT CONNECTOR-B09
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-
3	B	-
4	B	-

Terminal No.	Color of Wire	Signal Name
2	LG	-
3	SHIELD	-
4	BR	-
8	B/G	-
10	W/L	-
11	SHIELD	-
12	W/R	-
13	V	-
14	SHIELD	-
15	Y	-
21	GR/V	-
22	SHIELD	-
23	B/R	-

Connector No.	B102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B35
Connector Name	REAR VIEW CAMERA CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	CAMERA ON
2	B	GND
3	P	COMP +
4	L	COMP -

ALNIA0069GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3
4	5	6
7	8	



Terminal No.	Color of Wire	Signal Name
1	L	-
5	B/W	-

Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR/B	-
4	GR/L	-
5	G/W	-
6	B/Y	-
7	W	-
9	B/R	-
10	O/B	-
11	R/G	-
12	B/P	-
13	BR	-
14	L/O	-
15	B	-
16	LG	-

Connector No.	B103
Connector Name	WIRE TO WIRE
Connector Color	BROWN

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					



Terminal No.	Color of Wire	Signal Name
55	BR/B	RR DOOR LH - OUT
58	W	FR TWDR LH + OUT
59	B	FR TWDR LH - OUT
60	B/G	AMP ON
63	Y	RR LH - IN
64	BR	RR LH + IN
65	V	RR RH - IN
66	LG	RR RH + IN
68	R/G	RR DOOR LH + OUT
69	B/P	INST CTR TWDR + OUT
70	O/B	INST CTR TWDR - OUT
71	G/W	FR DOOR RH + OUT
72	BR	FR DOOR RH - OUT
73	W/L	FR RH + IN
74	GR/V	FR RH - IN
75	W/R	FR LH + IN
76	B/R	FR LH - IN

Connector No.	B121
Connector Name	BOSE SPEAKER AMP
Connector Color	BROWN

77	76	75	74	73	72	71	70	69	68
67	66	65	64	63	62	61	60	59	58



Connector No.	B120
Connector Name	REAR SPEAKER SUBWOOFER LH
Connector Color	WHITE

2	1
---	---



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	G/B	-

ALNIA0178GB

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	B124
Connector Name	REAR SUBWOOFER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BRW	-
2	BR	-

Terminal No.	Color of Wire	Signal Name
41	LG	FR TWDR LH + OUT
42	B/Y	FR TWDR LH - OUT
43	GR/L	FR TWDR RH - OUT
44	L/O	FR TWDR RH + OUT
45	BRW	RH WOOFER + OUT
46	BR	RH WOOFER - OUT
47	B/L	GND
48	G/B	LH WOOFER - OUT
49	B/W	RR DOOR RH - OUT
50	BR	BAT
51	B/R	BAT
52	B	GND
53	W/B	LH WOOFER +OUT
54	L	RR DOOR RH + OUT

Connector No.	B122
Connector Name	BOSE SPEAKER AMP
Connector Color	BROWN



Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	G/W	-
9	BR	-

Connector No.	D3
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	W	-
15	B	-

ALNIA0179GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AV CONTROL UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

Connector No.	D202
Connector Name	REAR DOOR SPEAKER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/B	-
2	W/R	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	O/B	-
5	W/R	-

Connector No.	D103
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	BR	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	B	-
4	SHIELD	-


Connector No.	D302
Connector Name	REAR DOOR SPEAKER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B/W	-

Terminal No.	Color of Wire	Signal Name
1	W	SIG
2	R	GND
4	B	VCC

Connector No.	R7
Connector Name	MICROPHONE
Connector Color	WHITE



ALNIA0124GB



# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## DTC Index

INFOID:000000001502751

CONSULT-III display	Malfunction	Reference page
CAN COMM CIRCUIT [U1000]	When AV control unit is not transmitting or receiving CAN communication signals for 2 seconds or more.	<a href="#">AV-166</a>
CONTROL UNIT (CAN) [U1010]	When a malfunction is detected during initial diagnosis for CAN controller of each control unit.	<a href="#">AV-167</a>
Cont Unit FLASH-ROM [U1200]	An internal malfunction is detected in AV control unit (FLASH-ROM).	<a href="#">AV-260</a>
GYRO NO CONN [U1201]	An internal malfunction is detected in AV control unit (gyrocompass disconnection).	<a href="#">AV-260</a>
GPS COMM [U1204]	An internal malfunction is detected in AV control unit (GPS malfunction).	<a href="#">AV-260</a>
GPS ROM [U1205]	An internal malfunction is detected in AV control unit (GPS malfunction).	<a href="#">AV-260</a>
GPS RAM [U1206]	An internal malfunction is detected in AV control unit (GPS malfunction).	<a href="#">AV-260</a>
GPS RTC [U1207]	An internal malfunction is detected in AV control unit (GPS malfunction).	<a href="#">AV-260</a>
DVD-ROM COMM [U1208]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-174</a>
DVD-ROM READ [U1209]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-175</a>
DVD-ROM DISC [U120A]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-176</a>
DVD-ROM MECHA DETECT [U120C]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-177</a>
DVD-ROM MECHA [U120D]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-178</a>
DVD-ROM SEEK [U1210]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-179</a>
DVD-ROM DATA FORWARD [U1212]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-180</a>
DVD-ROM DATA [U1213]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-181</a>
DVD-ROM TIMEOUT [U1214]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-182</a>
DVD-ROM LOAD [U1215]	An internal malfunction is detected in AV control unit (DVD-ROM).	<a href="#">AV-183</a>
CAN CONT [U1216]	An internal malfunction is detected in AV control unit (CAN controller).	<a href="#">AV-260</a>
BLUETOOTH CONN [U1217]	An internal malfunction is detected in AV control unit (Bluetooth module connection malfunction).	<a href="#">AV-260</a>
XM SERIAL COMM [U1220]	An internal malfunction is detected in AV control unit (satellite radio tuner communication malfunction).	<a href="#">AV-260</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AV CONTROL UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

CONSULT-III display	Malfunction	Reference page
GPS ANTENNA CONN [U1244]	GPS antenna connection malfunction is detected.	<a href="#">AV-187</a>
N-BUS CD CHG CONN [U124C]	<ul style="list-style-type: none"><li>• A malfunction is detected in CD changer power supply and ground circuits</li><li>• Malfunction occurs in request signal circuit. (Between CD changer and AV control unit)</li><li>• Malfunction occurs in communication signal circuit. (Between CD changer and AV control unit)</li></ul>	<a href="#">AV-188</a>

# BOSE SPEAKER AMP

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

## BOSE SPEAKER AMP

Reference Value

INFOID:000000001502752

### TERMINAL LAYOUT



### PHYSICAL VALUES







Terminal (Wire color)		Description		Condition	Reference value (Approx.)
+	-	Signal name	Input/Output		
41 (LG)	42 (B/Y)	Sound signal front tweeter LH	Output	Ignition switch ON	 SKIB3609E
44 (L/O)	43 (GR/L)	Sound signal front tweeter RH	Output	Ignition switch ON	 SKIB3609E
45 (BR/W)	46 (BR)	Sound signal woofer RH	Output	Ignition switch ON	 SKIB3609E
47 (B/L)	Ground	GND	—	Ignition switch ON	0V
50 (BR)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
51 (B/R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
52 (B)	Ground	GND	—	Ignition switch ON	0V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# BOSE SPEAKER AMP

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition	Reference value (Approx.)
+	-	Signal name	Input/Output		
53 (W/B)	48 (G/B)	Sound signal woofer LH	Output	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>
54 (L)	49 (B/W)	Sound signal rear door RH	Output	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>
58 (W)	59 (B)	Sound signal front door speaker LH	Output	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>
60 (B/G)	Ground	Amp. ON signal	Input	Ignition switch ACC	Battery voltage
64 (BR)	63 (Y)	Sound signal rear LH	Input	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>
66 (LG)	65 (V)	Sound signal rear RH	Input	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>
68 (R/G)	55 (BR/B)	Sound signal rear door LH	Output	Ignition switch ON	 <p style="text-align: right;">SKIB3609E</p>

# BOSE SPEAKER AMP

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition	Reference value (Approx.)
+	-	Signal name	Input/Output		
69 (B/P)	70 (O/B)	Sound signal center speaker	Output	Ignition switch ON	
71 (G/W)	72 (BR)	Sound signal front door speaker RH	Output	Ignition switch ON	
73 (W/L)	74 (GR/V)	Sound signal front RH	Input	Ignition switch ON	
75 (W/R)	76 (B/R)	Sound signal front LH	Input	Ignition switch ON	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# REAR VIEW CAMERA CONTROL UNIT

[BOSE AUDIO WITH NAVIGATION]


< ECU DIAGNOSIS >

## REAR VIEW CAMERA CONTROL UNIT

Reference Value

INFOID:000000001502753

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
		Signal name	Input/ Output	Ignition switch	Operation	
1 (Y)	Ground	Battery power	Input	OFF	—	Battery voltage
2 (V)	Ground	ACC power	Input	ACC	—	Battery voltage
3 (B)	Ground	Ground	—	ON	—	0V
4 (P/B)	Ground	Reverse signal input	Input	ON	A/T selector lever R position	Battery voltage
					A/T selector lever in other than R position	0V
5 (V/G)	Ground	AV Control	Output	ON	—	0V
6 (O)	Ground	DDL	Output	—	—	—
8 (GR)	Ground	Camera power output	Output	ON	A/T selector lever R position	6V
9 (L)	Ground	Camera image input (-)	Input	ON	—	0V
10 (P)	Ground	Camera image input (+)	Input	ON	A/T selector lever R position	 SKIA4894E
11 (R)	Ground	Composite image output (-)	Output	ON	A/T selector lever R position	 SKIA4896E
12 (W)	Ground	Composite image output (+)	Output	ON	A/T selector lever R position	 SKIA4896E

# CD CHANGER

< ECU DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

## CD CHANGER

Reference Value

INFOID:000000001502754

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
2 (Y/L)	1 (W/L)	CD changer sound signal LH	Output	Ignition switch ON	When CD change mode is selected	<p>SKIB3609E</p>
4 (Y/G)	3 (BR/L)	CD changer sound signal RH	Output	Ignition switch ON	When CD change mode is selected	<p>SKIB3609E</p>
5	—	Shield	—	—	—	—
6	—	Shield	—	—	—	—
8 (R)	Ground	Request signal (CD→CONT)	Output	Ignition switch ON	When CD change mode is selected	<p>SKIA9299J</p>
9 (B)	Ground	Communication signal (CONT→CD)	Input	Ignition switch ON	When CD change mode is selected	<p>SKIA9300J</p>


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# CD CHANGER

< ECU DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
10 (G)	Ground	Communication signal (CD→CONT)	Output	Ignition switch ON	When CD change mode is selected	 <p style="text-align: right; font-size: small;">SKIA9301J</p>
12 (Y/R)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
13 (R/Y)	Ground	Illumination (-)	Input	OFF	—	Refer to <a href="#">JNL-9, "System Description"</a> .
14 (R/L)	Ground	Illumination (+)	Input	OFF	Lighting switch is OFF.	0V
					Lighting switch is ON.	Battery voltage
16 (V/Y)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage



# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## SYMPTOM DIAGNOSIS

### MULTI AV SYSTEM

#### Symptom Table

INFOID:000000001502755

#### NAVIGATION SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>AV control unit power and ground circuit</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-190</a></li> <li><a href="#">AV-260</a></li> </ul>
Steering switch does not operate	<ul style="list-style-type: none"> <li>Steering switch</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-211</a></li> <li><a href="#">AV-260</a></li> </ul>
Voice activated control does not operate	<ul style="list-style-type: none"> <li>Microphone</li> <li>Steering switch</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-213</a></li> <li><a href="#">AV-211</a></li> <li><a href="#">AV-260</a></li> </ul>

#### HANDS-FREE PHONE SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>AV control unit power and ground circuit</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-190</a></li> <li><a href="#">AV-260</a></li> </ul>
Steering switch does not operate	<ul style="list-style-type: none"> <li>Steering switch</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-211</a></li> <li><a href="#">AV-260</a></li> </ul>
Voice activated control does not operate	<ul style="list-style-type: none"> <li>Microphone</li> <li>Steering switch</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-213</a></li> <li><a href="#">AV-211</a></li> <li><a href="#">AV-260</a></li> </ul>

#### REAR VIEW MONITOR

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>Rear view camera control unit power and ground circuit</li> <li>Reverse signal circuit</li> <li>Camera ON signal circuit</li> <li>Camera image signal circuit (rear view camera to rear view camera control unit)</li> <li>Camera image signal circuit (rear view camera control unit to AV control unit)</li> <li>Rear view camera control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-190</a></li> <li><a href="#">AV-218</a></li> <li><a href="#">AV-216</a></li> <li><a href="#">AV-215</a></li> <li><a href="#">AV-217</a></li> <li><a href="#">AV-275</a></li> </ul>

#### AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>AV control unit power and ground circuit</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-190</a></li> <li><a href="#">AV-260</a></li> </ul>
Steering switch does not operate	<ul style="list-style-type: none"> <li>Steering switch</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-211</a></li> <li><a href="#">AV-260</a></li> </ul>
All speakers do not sound	<ul style="list-style-type: none"> <li>AV control unit power and ground circuit</li> <li>BOSE speaker amp. ON signal</li> <li>BOSE speaker amp. power and ground circuit</li> <li>BOSE speaker amp.</li> <li>AV control unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-190</a></li> <li><a href="#">AV-210</a></li> <li><a href="#">AV-192</a></li> <li><a href="#">AV-261</a></li> <li><a href="#">AV-260</a></li> </ul>
One or several speakers do not sound	<ul style="list-style-type: none"> <li>Front door speaker</li> <li>Tweeter</li> <li>Center speaker</li> <li>Rear door speaker</li> <li>Rear subwoofer</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-196</a></li> <li><a href="#">AV-199</a></li> <li><a href="#">AV-202</a></li> <li><a href="#">AV-204</a></li> <li><a href="#">AV-207</a></li> </ul>

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000001502756

#### AUDIO SYSTEM

The majority of the audio troubles are the result of outside causes (bad CD, electromagnetic interference, etc.).

#### Noise

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

#### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> <li>• Ignition components</li> </ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> <li>• Fuel pump condenser</li> </ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> <li>• Relay malfunction, audio unit malfunction</li> </ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> <li>• Motor case ground</li> <li>• Motor</li> </ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> <li>• Rear defogger coil malfunction</li> <li>• Open circuit in printed heater</li> <li>• Poor ground of antenna feeder line</li> </ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> <li>• Ground wire of body parts</li> <li>• Ground due to improper part installation</li> <li>• Wiring connections or a short circuit</li> </ul>

#### NAVIGATION SYSTEM

##### Basic Operation

Symptom	Cause	Remedy
No image is shown.	Display brightness adjustment is set fully to DARK side.	Adjust the display brightness.
No guide sound is heard. Audio guide volume is too low or too high.	Volume control is set to OFF, MIN or MAX.	Adjust the audio guide volume.
	Audio guidance is not available while the vehicle is driving on a dark pink route.	System is not malfunctioning.
Screen is too dark. Motion of the image is too slow.	Temperature inside the vehicle is low.	Wait until the temperature inside the vehicle reaches the proper temperature.
Small black or bright spots appear on the screen.	Symptom peculiar to a liquid crystal display (display unit).	System is not malfunctioning.

##### Vehicle Mark

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Symptom	Cause	Remedy	
Map screen and BIRDVIEW™ Name of the place vary with the screen.	Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ.	System is not malfunctioning.	A
	The same place name, street name, etc. may not be displayed every time on account of the data processing.		B
Vehicle mark is not positioned correctly.	Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF.	Drive the vehicle for a while in the GPS satellite signal receiving condition.	C
Screen will not switch to nighttime mode after the lighting switch is turned ON.	The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screen may be inhibited by the automatic illumination adjustment function.	Perform screen dimming and select the nighttime screen by "SWITCH SCREENS".	D
Map screen will not scroll in accordance with the vehicle travel.	Current location is not displayed.	Press "MAP" button to display the current location.	E
Vehicle mark will not be shown.	Current location is not displayed.	Press "MAP" button to display the current location.	F
Accuracy indicator (GPS satellite mark) on the map screen stays gray.	GPS satellite signal is intercepted because the vehicle is in or behind a building.	Move the vehicle out to an open space.	G
	GPS satellite signal cannot be received because an obstacle is placed on top of the instrument panel.	Do not place anything on top of the meter display (instrument panel).	H
	GPS satellites are not visible from current location.	Wait until GPS satellites are visible by moving the vehicle.	I
Vehicle location accuracy is low.	Accuracy indicator (GPS satellite mark) on the map screen stays gray.	Current location is not determined.	J
	Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle.	Drive the vehicle for a while [for approx. 30 minutes at approx. 30 km/h (19 MPH)] and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by CONFIRMATION/ADJUSTMENT mode of diagnosis function.	K
	Map data has error or omission. (Vehicle mark is always deviated to the same position.)	As a rule, an updated map DVD-ROM will be released once a year.	L

## Destination, Passing Points and Menu Items Cannot be Selected/Set

Symptom	Cause	Remedy	
Destination cannot be set.	Destination to be set is on an expressway.	Set the destination on an ordinary road.	M
Passing point is not searched when re-searching the route.	The vehicle has already passed the passing point, or the system judged so.	To include the passing points that have been passed into the route again, set the route again.	AV
Route information will not be displayed.	Route searching has not been done.	Set the destination and perform route searching.	O
	Vehicle mark is not on the recommended route.	Drive on the recommended route.	P
	Route guide is turned OFF.	Turn route guide ON.	
	Route information is not available on the dark pink route.	System is not malfunctioning.	
After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road.	Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.)	Drive on the recommended route.	

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Symptom	Cause	Remedy
Automatic route searching is not possible.	Vehicle is driving on a highway (gray route), or no recommended route is available.	Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched.
Performed automatic detour search (or detour search). However, the result is the same as that of the previous search.	Performed search with every conditions considered. However, the result is the same as that of the previous search.	System is not malfunctioning.
Passing points cannot be set.	More than five passing points were set.	Passing points can be set up to five. To stop at more than five points, perform sharing in several steps.
When setting the route, the starting point cannot be selected.	The current vehicle location is always set as the starting point of a route.	System is not malfunctioning.
Some menu items cannot be selected.	The vehicle is being driven.	Stop the vehicle at a safe place and then operate the system.

### Voice Guide

Symptom	Cause	Remedy
Voice guide will not operate.	Note: Voice guide is only available at intersections that satisfy certain conditions (indicated by ● on the map). Therefore, guidance may not be given even when the route on the map changes direction.	System is not malfunctioning.
	The vehicle is not on the recommended route.	Return to the recommended route or re-search the route.
	Voice guide is turned OFF.	Turn voice guide ON.
	Route guide is turned OFF.	Turn route guide ON.
Voice guide does not match the actual road pattern.	Voice guide may vary with the direction to which the vehicle is turn and the connection of the road to other roads.	Drive in conformity to the actual traffic rules.

### Route Search

Symptom	Cause	Remedy
No route is shown.	No road to be searched is found around the destination.	Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads.
	Starting point and the destination are too close.	Set the destination at more distant point.
	Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current location or the destination.	Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF.
Indicated route is intermittent.	In some areas, highways (gray routes) are not used for the search <sup>(Note)</sup> Therefore, the route to the current location or the passing points may be intermittent.	System is not malfunctioning.
When the vehicle has passed the recommended route, it is deleted from the screen.	A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.)	System is not malfunctioning.

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


Symptom	Cause	Remedy
Detouring route is recommended.	In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended.	Set the route closer to the basic route (gray route).
	A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination.	Slightly move the starting point or the destination, or set the passing point on the route of your choice.
	In the area where highways (gray routes) are used for the search, left turn has priority around the current location and the destination (passing points). For this reason, the recommended route may be detouring.	System is not malfunctioning.
Landmarks on the map do not match the actual ones.	This can be happen due to omission or error in the map data.	As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available.
Recommended route is far from the starting point, passing points, and destination.	Starting point, passing points, and destination of the route guide were set far from the desired points because route searching data around these area were not stored.	Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route.

**NOTE:**

Except for the ordinance-designated cities. (Malfunctioning areas may be changed in the updated map disc.)

**Examples of Current-Location Mark Displacement**

Vehicle's travel amount is calculated by reading its travel distance and turning angle. Therefore, if the vehicle is driven in the following manner, an error will occur in the vehicle's current location display. If correct location has not been restored after driving the vehicle for a while, perform location correction.









A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >





[BOSE AUDIO WITH NAVIGATION]

Cause (condition)	-: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Road configuration	<p>Y-intersections</p>  <p style="text-align: center; font-size: small;">ELK0192D</p>	<p>At a Y intersection or similar gradual division of roads, an error in the direction of travel deduced by the sensor may result in the current-location mark appearing on the wrong road.</p>	<p>If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.</p>
	<p>Spiral roads</p>  <p style="text-align: center; font-size: small;">ELK0193D</p>	<p>When driving on a large, continuous spiral road (such as loop bridge), turning angle error is accumulated and the vehicle mark may deviate from the correct location.</p>	
	<p>Straight roads</p>  <p style="text-align: center; font-size: small;">ELK0194D</p>	<p>When driving on a long, straight road and slow curve without stopping, map-matching does not work effectively enough and distance errors may accumulate. As a result, the vehicle mark may deviate from the correct location when the vehicle is turned at a corner.</p>	
	<p>Zigzag roads</p>  <p style="text-align: center; font-size: small;">ELK0195D</p>	<p>When driving on a zigzag road, the map may be matched to other roads in the similar direction nearby at every turn, and the vehicle mark may deviate from the correct location.</p>	
	<p>Roads laid out in a grid pattern</p>  <p style="text-align: center; font-size: small;">ELK0196D</p>	<p>When driving where roads are laid out in a grid pattern, or where many roads are running in the similar direction nearby, the map may be matched to them by mistake and the vehicle mark may deviate from the correct location.</p>	
	<p>Parallel roads</p>  <p style="text-align: center; font-size: small;">ELK0197D</p>	<p>When two roads are running in parallel (such as highway and sideways), the map may be matched to the other road by mistake and the vehicle mark may deviate from the correct location.</p>	

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]



	Cause (condition)    -: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Place	In a parking lot  SEL709V	When driving in a parking lot, or other location where there are no roads on the map, matching may place the vehicle mark on a nearby road. When the vehicle returns to the road, the vehicle mark may have deviated from the correct location. When driving in circle or turning the steering wheel repeatedly, direction errors accumulate, and the vehicle mark may deviate from the correct location.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
	Turntable  SEL710V	When the ignition switch is OFF, the navigation system cannot get the signal from the gyroscope (angular speed sensor). Therefore, the displayed direction may be wrong and the correct road may not be easily returned to after rotating the vehicle on a turntable with the ignition OFF.	
	Slippery roads	On snow, wet roads, gravel, or other roads where tires may slip easily, accumulated mileage errors may cause the vehicle mark to deviate from the correct road.	
	Slopes	When parking in sloped garages, when travelling on banked roads, or in other cases where the vehicle turns when tilted, an error in the turning angle will occur, and the vehicle mark may deviate from the road.	
Map data	Road not displayed on the map screen  SEL699V	When driving on new roads or other roads not displayed on the map screen, map matching does not function correctly and matches the location to a nearby road. When the vehicle returns to a road which is on the map, the vehicle mark may deviate from the correct road.	
	Different road pattern (Changed due to repair)  ELK0201D	If the road pattern stored in the map data and the actual road pattern are different, map matching does not function correctly and matches the location to a nearby road. The vehicle mark may deviate from the correct road.	
Vehicle	Use of tire chains	When tire chains are used, the mileage is not correctly detected, and the vehicle mark may deviate from the correct road.	Drive the vehicle for a while. If the distance still deviates, adjust it by using the distance adjustment function. (If the tire chain is removed, recover the original value.)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Cause (condition)	-: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Precautions for driving	Just after the engine is started	If the vehicle is driven just after the engine is started when the gyroscope (angular speed sensor) correction is not completed, the vehicle can lose its direction and may have deviated from the correct location.	Wait for a short while before driving after starting the engine.
	Continuous driving without stopping	When driving long distances without stopping, direction errors may accumulate, and the current-location mark may deviate from the correct road.	Stop and adjust the orientation.
	Abusive driving	Spinning the wheels or engaging in other kinds of abusive driving may result in the system being unable perform correct detection, and may cause the vehicle mark to deviate from the correct road.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
How to correct location	Position correction accuracy 	If the accuracy of location settings is poor, accuracy may be reduced when the correct road cannot be found, particularly in places where there are many roads.	Enter in the road displayed on the screen with an accuracy of approx. 1mm. Caution: Whenever possible, use detailed map for the correction.
	Direction when location is corrected 	If the accuracy of location settings during correction is poor, accuracy may be reduced afterwards.	Perform direction correction.

### Location Correction by Map-Matching is Slow

- The map-matching function needs to refer to the data of the surrounding area. It is necessary to drive some distance for the function to work.
- Because map-matching operates on this principle, when there are many roads running in similar directions in the surrounding area, no matching determination may be made. The location may not be corrected until some special feature is found.

### Name of Road is Not Displayed

The current road name may not be displayed if there are no road names displayed on the map screen.

### Contents of Display Differ for Birdview™ and the (Flat) Map Screen

Difference of the BIRDVIEW™ screen from the flat map screen are as follows.

- The current place name displays names which are primarily in the direction of vehicle travel.
- The amount of time before the vehicle travel or turn angle is updated on the screen is longer than for the (flat) map display.
- The conditions for display of place names, roads, and other data are different for nearby areas and for more distant areas.
- Some thinning of the character data is done to prevent the display becoming too complex. In some cases and in some locations, the display contents may differ.
- The same place name, street name, etc. may be displayed multiple times.

### Vehicle Mark Shows a Position Which is Completely Wrong

In the following cases, the vehicle mark may appear on completely different position in the map depending on the GPS satellite signal receiving conditions. In this case, perform location correction and direction correction.

- When location correction has not been done
- If the receiving conditions of the GPS satellite signal is poor, if the vehicle mark becomes out of place, it may move to a completely different location and not come back if location correction is not done. The position will be corrected if the GPS signal can be received.
- When the vehicle has traveled by ferry, or when the vehicle has been being towed



## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

- Because calculation of the current location cannot be done when traveling with the ignition off, for example when traveling by ferry or when being towed, the location before travel is displayed. If the precise location can be detected with GPS, the location will be corrected.

A

### Vehicle Mark Jumps

In the following cases, the vehicle mark may appear to jump as a result of automatic correction of the current location.

B

- When map matching has been done
  - If the current location and the vehicle mark are different when map matching is done, the vehicle mark may seem to jump. At this time, the location may be “corrected” to the wrong road or to a location which is not on a road.
- When GPS location correction has been done
  - If the current location and the vehicle mark are different when the location is corrected using GPS measurements, the vehicle mark may seem to jump. At this time, the location may be “corrected” to a location which is not on a road.

C

D

### Vehicle Mark is in a River or Sea

The navigation system moves the vehicle mark with no distinction between land and rivers or sea. If the vehicle mark is somehow out of place, it may appear that the vehicle is driving in a river or the sea.

E

### Vehicle Mark Automatically Rotates

The system wrongly memorizes the rotating status as stopping when the ignition switch is turned ON with the turntable rotating. That causes the vehicle mark to rotate when the vehicle is stopped.

F

### When Driving on Same Road, Sometimes Vehicle Mark is in Right Place and Sometimes it is in Wrong Place

The conditions of the GPS antenna (GPS data) and gyroscope (angular speed sensor) change gradually. Depending on the road traveled and the operation of the steering wheel, the location detection results will be different. Therefore, even on a road on which the location has never been wrong, conditions may cause the vehicle mark to deviate.

G

H

I

J

K

L

M

AV

O

P

PRECAUTION

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001502757

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Trouble Diagnosis

INFOID:000000001502758

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair


INFOID:000000001502759

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)




# PREPARATION

## PREPARATION

### Commercial Service Tools

INFOID:000000001502760

Tool name	Description
<p>Power tool</p>  <p>PBIC0191E</p>	<p>Loosening bolts and nuts</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

AV

## ON-VEHICLE REPAIR


### AV CONTROL UNIT

#### Removal and Installation


INFOID:000000001502761

#### REMOVAL

1. Disconnect the 12-volt battery negative terminal.
2. Remove cluster lid C. Refer to [IP-11, "Removal and Installation"](#).
3. Remove cluster lid D lower finisher. Refer to [IP-11, "Removal and Installation"](#).
4. Remove navigation audio unit upper and lower screws (A).



5. Remove the navigation audio unit bracket screws (A) and remove the navigation audio unit bracket (1).



6. Pull out the navigation audio unit assembly, disconnect the navigation audio unit assembly connectors.

#### INSTALLATION

Installation is in the reverse order of removal.

**BOSE AMP.**

**Removal and Installation**

INFOID:000000001502762

For removal and installation, refer to [AV-127. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV
- O
- P


## CD CHANGER

### Removal and Installation


INFOID:000000001502763

#### REMOVAL


1. Remove Cluster D lower finisher. Refer to [IP-11. "Removal and Installation"](#).
2. Put selector lever in the drive (D) position.
3. Using a suitable tool remove the CD changer finisher (1), then disconnect the power socket, AUX jack connectors and remove the CD changer finisher (1).



4. Remove the CD changer screws (A), pull out the unit, then disconnect the CD changer connector and remove the CD changer (1).



5. Remove the CD changer bracket screws (A).
  - CD changer brackets (1)
  - CD changer (2)



#### INSTALLATION

Installation is in the reverse order of removal.

---

## TWEETER

### Removal and Installation

INFOID:000000001502764

For removal and installation, refer to [AV-128. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV
- O
- P

## CENTER SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITH NAVIGATION]

---

### CENTER SPEAKER

#### Removal and Installation

INFOID:000000001502765

For removal and installation, refer to [AV-129. "Removal and Installation"](#).



# FRONT DOOR SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITH NAVIGATION]

## FRONT DOOR SPEAKER

### Removal and Installation

INFOID:000000001502766

For removal and installation, refer to [AV-47. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

## REAR DOOR SPEAKER

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITH NAVIGATION]

---

### REAR DOOR SPEAKER

#### Removal and Installation

INFOID:000000001502767

For removal and installation, refer to [AV-131, "Removal and Installation"](#).

---

REAR SPEAKER

Removal and Installation

INFOID:000000001502768

For removal and installation, refer to [AV-48. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV
- O
- P

## AUDIO ANTENNA

### Roof Antenna

INFOID:000000001502769

#### REMOVAL and INSTALLATION

For removal and installation, refer to [AV-49. "Roof Antenna"](#).


## GPS ANTENNA

## Removal and Installation

INFOID:000000001502770

## REMOVAL

1. Remove the combination meter. Refer to [IP-11. "Removal and Installation"](#).
2. Remove the navigation audio unit. Refer to Navigation audio unit.
3. Remove the GPS navigation antenna screw (A), then fish the GPS navigation antenna connector and harness (1), through the combination meter instrument panel opening and remove the GPS antenna.



## INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## STEERING SWITCH

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITH NAVIGATION]

---

### STEERING SWITCH

#### Removal and Installation

INFOID:000000001502771

For removal and installation, refer to [AV-53, "Removal and Installation"](#).

MICROPHONE

Removal and Installation

INFOID:000000001502772

For removal and installation, refer to [AV-136. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV
- O
- P

## TEL ANTENNA

### Removal and Installation

INFOID:000000001502773

For removal and installation, refer to [AV-137, "Removal and Installation"](#).



---

TEL ADAPTER UNIT

Removal and Installation

INFOID:000000001502774

For removal and installation, refer to [AV-138. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV
- O
- P


## REAR VIEW MONITOR

### Removal and Installation

INFOID:000000001502775

#### REMOVAL

1. Remove the license plate finisher. Refer to [EXT-24. "Removal and Installation"](#).
2. Remove trunk lid finisher. Refer to Trunk lid finisher.
3. Disconnect the rear view monitor connector (B), press the rear view monitor tab (A) and remove the rear view monitor (1).



#### INSTALLATION

Installation is in the reverse order of removal.

#### Adjustment

INFOID:000000001502776

#### REAR VIEW MONITOR

For adjustment on the rear view monitor, refer to [AV-141. "REAR VIEW MONITOR GUIDING LINE ADJUSTMENT : Special Repair Requirement"](#).

# CAMERA CONTROL UNIT

< ON-VEHICLE REPAIR >

[BOSE AUDIO WITH NAVIGATION]


## CAMERA CONTROL UNIT

### Removal and Installation

INFOID:000000001502777

#### REMOVAL

1. Disconnect the 12-volt battery negative terminal.
2. Remove the trunk side finisher. Refer to [INT-22, "Removal and Installation"](#).
3. Disconnect the rear view monitor control unit connector (A), then remove the rear view monitor screws (B) and remove the rear view monitor control unit (1).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV