

# SECTION **PWC**

## POWER WINDOW CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P

### CONTENTS

<b>LH ONLY WINDOW ANTI-PINCH</b>	
<b>BASIC INSPECTION</b> .....	5
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	5
Work Flow .....	5
<b>INSPECTION AND ADJUSTMENT</b> .....	8
<b>BASIC INSPECTION</b> .....	8
BASIC INSPECTION : Special Repair Requirement .....	8
<b>FUNCTION DIAGNOSIS</b> .....	9
<b>POWER WINDOW SYSTEM</b> .....	9
System Diagram .....	9
System Description .....	9
Component Parts Location .....	11
Component Description .....	11
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	13
<b>COMMON ITEM</b> .....	13
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	13
<b>RETAINED PWR</b> .....	13
RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR) .....	13
<b>COMPONENT DIAGNOSIS</b> .....	14
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	14
<b>POWER WINDOW MAIN SWITCH</b> .....	14
POWER WINDOW MAIN SWITCH : Description .....	14
POWER WINDOW MAIN SWITCH : Component Function Check .....	14
POWER WINDOW MAIN SWITCH : Diagnosis Procedure .....	14
POWER WINDOW MAIN SWITCH : Component Inspection .....	17
POWER WINDOW MAIN SWITCH : Special Repair Requirement .....	19
<b>FRONT POWER WINDOW SWITCH</b> .....	19
FRONT POWER WINDOW SWITCH : Description .....	19
FRONT POWER WINDOW SWITCH : Component Function Check .....	19
FRONT POWER WINDOW SWITCH : Diagnosis Procedure .....	19
<b>REAR POWER WINDOW SWITCH</b> .....	21
REAR POWER WINDOW SWITCH : Description .....	21
REAR POWER WINDOW SWITCH : Component Function Check .....	21
REAR POWER WINDOW SWITCH : Diagnosis Procedure .....	22
REAR POWER WINDOW SWITCH : Component Inspection .....	23
<b>POWER WINDOW MOTOR</b> .....	25
<b>DRIVER SIDE</b> .....	25
DRIVER SIDE : Description .....	25
DRIVER SIDE : Component Function Check .....	25
DRIVER SIDE : Diagnosis Procedure .....	25
DRIVER SIDE : Component Inspection .....	26
DRIVER SIDE : Special Repair Requirement .....	26
<b>PASSENGER SIDE</b> .....	26
PASSENGER SIDE : Description .....	27
PASSENGER SIDE : Component Function Check .....	27
PASSENGER SIDE : Diagnosis Procedure .....	27
PASSENGER SIDE : Component Inspection .....	28
<b>REAR LH</b> .....	28
REAR LH : Description .....	28
REAR LH : Component Function Check .....	28
REAR LH : Diagnosis Procedure .....	28
REAR LH : Component Inspection .....	29
<b>REAR RH</b> .....	30

REAR RH : Description .....	30	<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE) .....</b>	<b>55</b>
REAR RH : Component Function Check .....	30	Diagnosis Procedure .....	55
REAR RH : Diagnosis Procedure .....	30	<b>POWER WINDOW RETAINED POWER OP- ERATION DOES NOT OPERATE PROPERLY</b>	<b>... 56</b>
REAR RH : Component Inspection .....	31	Diagnosis Procedure .....	56
<b>ENCODER .....</b>	<b>32</b>	<b>POWER WINDOW LOCK SWITCH DOES NOT FUNCTION .....</b>	<b>57</b>
<b>DRIVER SIDE .....</b>	<b>32</b>	Diagnosis Procedure .....	57
DRIVER SIDE : Description .....	32	<b>PRECAUTION .....</b>	<b>58</b>
DRIVER SIDE : Component Function Check .....	32	<b>PRECAUTIONS .....</b>	<b>58</b>
DRIVER SIDE : Diagnosis Procedure .....	32	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	58
DRIVER SIDE : Special Repair Requirement .....	34	<b>ON-VEHICLE MAINTENANCE .....</b>	<b>59</b>
<b>DOOR SWITCH .....</b>	<b>35</b>	<b>PRE-INSPECTION FOR DIAGNOSTIC .....</b>	<b>59</b>
Description .....	35	Basic Inspection .....	59
Component Function Check .....	35	<b>ON-VEHICLE REPAIR .....</b>	<b>60</b>
Diagnosis Procedure .....	35	<b>POWER WINDOW MAIN SWITCH .....</b>	<b>60</b>
Component Inspection .....	36	Removal and Installation .....	60
<b>POWER WINDOW LOCK SWITCH .....</b>	<b>37</b>	<b>LH&amp;RH FRONT WINDOW ANTI-PINCH</b>	
Description .....	37	<b>BASIC INSPECTION .....</b>	<b>61</b>
Component Function Check .....	37	<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>61</b>
Special Repair Requirement .....	37	Work Flow .....	61
<b>ECU DIAGNOSIS .....</b>	<b>38</b>	<b>INSPECTION AND ADJUSTMENT .....</b>	<b>64</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>38</b>	<b>ADDITIONAL SERVICE WHEN REMOVING BAT- TERY NEGATIVE TERMINAL .....</b>	<b>64</b>
Reference Value .....	38	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description ...	64
<b>POWER WINDOW MAIN SWITCH .....</b>	<b>39</b>	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Re- pair Requirement .....	64
Reference Value .....	39	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>64</b>
Wiring Diagram .....	41	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	64
Fail Safe .....	47	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement ...	64
<b>SYMPTOM DIAGNOSIS .....</b>	<b>49</b>	<b>FUNCTION DIAGNOSIS .....</b>	<b>66</b>
<b>NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH .....</b>	<b>49</b>	<b>POWER WINDOW SYSTEM .....</b>	<b>66</b>
Diagnosis Procedure .....	49	System Diagram .....	66
<b>DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE .....</b>	<b>50</b>	System Description .....	66
Diagnosis Procedure .....	50	Component Parts Location .....	68
<b>FRONT PASSENGER SIDE POWER WIN- DOW ALONE DOES NOT OPERATE .....</b>	<b>51</b>	Component Description .....	69
Diagnosis Procedure .....	51		
<b>REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE .....</b>	<b>52</b>		
Diagnosis Procedure .....	52		
<b>REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE .....</b>	<b>53</b>		
Diagnosis Procedure .....	53		
<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE) .....</b>	<b>54</b>		
Diagnosis Procedure .....	54		

<b>DIAGNOSIS SYSTEM (BCM)</b> .....	<b>70</b>	<b>REAR LH</b> .....	<b>84</b>	
<b>COMMON ITEM</b> .....	<b>70</b>	REAR LH : Description .....	84	A
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	70	REAR LH : Component Function Check .....	84	
<b>RETAINED PWR</b> .....	<b>70</b>	REAR LH : Diagnosis Procedure .....	85	B
RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR) .....	70	REAR LH : Component Inspection .....	86	
<b>COMPONENT DIAGNOSIS</b> .....	<b>71</b>	<b>REAR RH</b> .....	<b>86</b>	C
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	<b>71</b>	REAR RH : Description .....	86	
<b>POWER WINDOW MAIN SWITCH</b> .....	<b>71</b>	REAR RH : Component Function Check .....	86	D
POWER WINDOW MAIN SWITCH : Description....	71	REAR RH : Diagnosis Procedure .....	86	
POWER WINDOW MAIN SWITCH : Component Function Check .....	71	REAR RH : Component Inspection .....	87	
POWER WINDOW MAIN SWITCH : Diagnosis Procedure .....	71	<b>ENCODER</b> .....	<b>88</b>	
POWER WINDOW MAIN SWITCH : Component Inspection .....	74	<b>DRIVER SIDE</b> .....	<b>88</b>	E
POWER WINDOW MAIN SWITCH : Special Re- pair Requirement .....	75	DRIVER SIDE : Description .....	88	
<b>FRONT POWER WINDOW SWITCH</b> .....	<b>75</b>	DRIVER SIDE : Component Function Check .....	88	
FRONT POWER WINDOW SWITCH : Descrip- tion .....	76	DRIVER SIDE : Diagnosis Procedure .....	88	
FRONT POWER WINDOW SWITCH : Compo- nent Function Check .....	76	<b>PASSENGER SIDE</b> .....	<b>90</b>	F
FRONT POWER WINDOW SWITCH : Diagnosis Procedure .....	76	PASSENGER SIDE : Description .....	90	
FRONT POWER WINDOW SWITCH : Special Repair Requirement .....	77	PASSENGER SIDE : Component Function Check .....	90	G
<b>REAR POWER WINDOW SWITCH</b> .....	<b>77</b>	PASSENGER SIDE : Diagnosis Procedure .....	91	
REAR POWER WINDOW SWITCH : Description... 77		<b>DOOR SWITCH</b> .....	<b>94</b>	H
REAR POWER WINDOW SWITCH : Component Function Check .....	78	Description .....	94	
REAR POWER WINDOW SWITCH : Diagnosis Procedure .....	78	Component Function Check .....	94	
REAR POWER WINDOW SWITCH : Component Inspection .....	79	Diagnosis Procedure .....	94	I
<b>POWER WINDOW MOTOR</b> .....	<b>81</b>	Component Inspection .....	95	
<b>DRIVER SIDE</b> .....	<b>81</b>	<b>DOOR KEY CYLINDER SWITCH</b> .....	<b>96</b>	J
DRIVER SIDE : Description .....	81	Description .....	96	
DRIVER SIDE : Component Function Check .....	81	Component Function Check .....	96	
DRIVER SIDE : Diagnosis Procedure .....	81	Diagnosis Procedure .....	96	
DRIVER SIDE : Component Inspection .....	82	Component Inspection .....	97	
DRIVER SIDE : Special Repair Requirement .....	82	Special Repair Requirement .....	98	
<b>PASSENGER SIDE</b> .....	<b>82</b>	<b>POWER WINDOW SERIAL LINK</b> .....	<b>99</b>	PWC
PASSENGER SIDE : Description .....	82	<b>POWER WINDOW MAIN SWITCH</b> .....	<b>99</b>	L
PASSENGER SIDE : Component Function Check .....	83	POWER WINDOW MAIN SWITCH : Description ....	99	
PASSENGER SIDE : Diagnosis Procedure .....	83	POWER WINDOW MAIN SWITCH : Component Function Check .....	99	M
PASSENGER SIDE : Component Inspection .....	84	POWER WINDOW MAIN SWITCH : Diagnosis Procedure .....	99	
PASSENGER SIDE : Special Repair Requirement .....	84	<b>FRONT POWER WINDOW SWITCH</b> .....	<b>100</b>	N
		FRONT POWER WINDOW SWITCH : Descrip- tion .....	100	
		FRONT POWER WINDOW SWITCH : Compo- nent Function Check .....	100	O
		FRONT POWER WINDOW SWITCH : Diagnosis Procedure .....	101	
		<b>POWER WINDOW LOCK SWITCH</b> .....	<b>103</b>	P
		Description .....	103	
		Component Function Check .....	103	
		Special Repair Requirement .....	103	
		<b>ECU DIAGNOSIS</b> .....	<b>104</b>	

<b>BCM (BODY CONTROL MODULE)</b> .....	104	<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)</b> .....	132
Reference Value .....	104	Diagnosis Procedure .....	132
<b>POWER WINDOW MAIN SWITCH</b> .....	105	<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PAS- SENGER SIDE)</b> .....	133
Reference Value .....	105	Diagnosis Procedure .....	133
Wiring Diagram .....	107	<b>POWER WINDOW RETAINED POWER OP- ERATION DOES NOT OPERATE PROPERLY</b>	..134
Fail Safe .....	113	Diagnosis Procedure .....	134
<b>FRONT POWER WINDOW SWITCH</b> .....	115	<b>DOES NOT OPERATE BY KEY CYLINDER SWITCH</b> .....	135
Reference Value .....	115	Diagnosis Procedure .....	135
Wiring Diagram .....	117	<b>KEYLESS POWER WINDOW DOWN DOES NOT OPERATE</b> .....	136
Fail Safe .....	123	Diagnosis Procedure .....	136
<b>SYMPTOM DIAGNOSIS</b> .....	125	<b>POWER WINDOW LOCK SWITCH DOES NOT FUNCTION</b> .....	137
<b>NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH</b> .....	125	Diagnosis Procedure .....	137
Diagnosis Procedure .....	125	<b>PRECAUTION</b> .....	138
<b>DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE</b> .....	126	<b>PRECAUTIONS</b> .....	138
Diagnosis Procedure .....	126	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	138
<b>FRONT PASSENGER SIDE POWER WIN- DOW ALONE DOES NOT OPERATE</b> .....	127	<b>ON-VEHICLE MAINTENANCE</b> .....	139
Diagnosis Procedure .....	127	<b>PRE-INSPECTION FOR DIAGNOSTIC</b> .....	139
<b>REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE</b> .....	128	Basic Inspection .....	139
Diagnosis Procedure .....	128	<b>ON-VEHICLE REPAIR</b> .....	140
<b>REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE</b> .....	129	<b>POWER WINDOW MAIN SWITCH</b> .....	140
Diagnosis Procedure .....	129	Removal and Installation .....	140
<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)</b> .....	130		
Diagnosis Procedure .....	130		
<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)</b> .....	131		
Diagnosis Procedure .....	131		

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH ONLY WINDOW ANTI-PINCH]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000003071128

#### OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH ONLY WINDOW ANTI-PINCH]

DETAILED FLOW

## 1. INTERVIEW FOR MALFUNCTION

---

Interview the symptom to the customer.

>> GO TO 2

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH ONLY WINDOW ANTI-PINCH]

NO >> GO TO 11

## 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH ONLY WINDOW ANTI-PINCH]

---

## INSPECTION AND ADJUSTMENT

### BASIC INSPECTION

BASIC INSPECTION : Special Repair Requirement

INFOID:000000003071129

### BASIC INSPECTION

#### 1. INSPECTION START

---

1. Check the service history.
2. Check the following parts.
  - Fuse/circuit breaker blown.
  - Poor connection, open or short circuit of harness connector.
  - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace the malfunctioning parts.




FUNCTION DIAGNOSIS

POWER WINDOW SYSTEM

System Diagram

INFOID:0000000003071130

FRONT POWER WINDOW LH ANTI-PINCH SYSTEM



ALMIA0059GB

System Description

INFOID:0000000003071131

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT/OUTPUT SIGNAL CHART

PWC

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Encoder	Encoder pulse signal	Power window control	Front power window motor
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

POWER WINDOW OPERATION

- Power window system is operable during the retained power operation timer after turning ignition switch ON and OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Front & rear power window switches can open/close the corresponding windows.

POWER WINDOW AUTO-OPERATION (FRONT LH)

# POWER WINDOW SYSTEM

## < FUNCTION DIAGNOSIS >

## [LH ONLY WINDOW ANTI-PINCH]

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating.
- Main power window and door lock/unlock switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

### RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF

#### Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes (45 seconds).

### POWER WINDOW LOCK

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch.

### ANTI-PINCH OPERATION (FRONT LH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to main power window and door lock/unlock switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm or 2 seconds after it detects encoder pulse signal frequency change.

### OPERATION CONDITION

- When door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

#### **NOTE:**

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.


# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## Component Parts Location

INFOID:000000003071132



- |   |   |  |
|---|---|--|
| 1. BCM M16, M17, M18, M19                               | 2. Front power window motor LH D9, RH D104          | 3. Rear power window motor LH D204, RH D304  |
| 4. Main power window and door lock/unlock switch D7, D8 | 5. Power window and door lock/unlock switch RH D105 | 6. Rear power window switch LH D203, RH D303 |
| 7. Front door lock assembly LH                          | 8. Front door switch LH B8, RH B108                 |  |

ALCIA0039ZZ

## Component Description

INFOID:000000003071133

### FRONT POWER WINDOW LH ANTI-PINCH SYSTEM

Component	Function
BCM	<ul style="list-style-type: none"> <li>Supplies power supply to power window switch.</li> <li>Controls retained power.</li> </ul>
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> <li>Directly controls all power window motor of all doors.</li> <li>Controls anti-pinch operation of front power window LH.</li> </ul>
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> <li>Controls front power window motor RH.</li> </ul>
Rear power window switch	<ul style="list-style-type: none"> <li>Controls rear power window motors LH and RH.</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PWC

L

M

N

O

P

# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Component	Function
Front power window motor LH	<ul style="list-style-type: none"><li>• Integrates the ENCODER POWER and WINDOW MOTOR.</li><li>• Starts operating with signals from main power window and door lock/unlock switch.</li><li>• Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.</li></ul>
Front power window motor RH	Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch & rear power window switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000003071134

#### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to <a href="#">BCS-81, "DTC Index"</a> .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	This function is not used even though it is displayed.

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

**NOTE:**

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	×		
RAP system	RETAINED PWR		×	

### RETAINED PWR

#### RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR)

INFOID:000000003071135

#### Data monitor

PWC

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### POWER WINDOW MAIN SWITCH

#### POWER WINDOW MAIN SWITCH : Description

INFOID:000000003071136

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

#### POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000003071137

#### Main Power Window And Door Lock/unlock Switch

#### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Does power window motor operate with main power window and door lock/unlock switch operation?

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.

NO >> Refer to [PWC-14, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

#### POWER WINDOW MAIN SWITCH : Diagnosis Procedure


INFOID:000000003071138

#### Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

#### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors (A and B) and ground.

Terminal (+)		Terminal (-)	Voltage (V) (Approx.)
Main power window and door lock/unlock switch connector	Terminal		
D7 (A)	10	Ground	Battery voltage
D8 (B)	19		



Is the measurement value within the specification?


YES >> GO TO 3

NO >> GO TO 2

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector (A) and main power window and door lock/unlock switch connectors (B and C).

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M16 (A)	3	D7 (B)	10	Yes
	2	D8 (C)	19	



4. Check continuity between BCM connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

BCM connector	Terminal	Ground	Continuity
M16 (A)	3		Ground
	2		

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.


### 3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect main power window and door lock/unlock switch.
- Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	17		Ground

Is the inspection result normal?


- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-19. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).
- NO >> Repair or replace harness.



### 4. CHECK BCM OUTPUT SIGNAL

- Connect BCM.
- Turn ignition switch ON.
- Check voltage between BCM connector and ground.

Terminals		(-)	Voltage (V) (Approx.)
(+)			
BCM connector	Terminal	Ground	Battery voltage
M16	3		
	2		




Is the measurement value within the specification?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6
- NO >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).

### 5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

- Connect main power window and door lock/unlock switch.
- Turn ignition switch ON.
- Check voltage between main power window and door lock/unlock switch and ground.



# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Terminal		Window condition	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?


YES >> GO TO 7

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-19, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

## 6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch and ground.

Terminal		Window condition	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	7	UP	Battery voltage
		DOWN	0
	5	UP	0
		DOWN	Battery voltage



Is the measurement value within the specification?


YES >> GO TO 8

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-19, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

## 7. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7 (A)	1	D203 (B)	2	Yes
	3		3	



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.



# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	1		No
	3		


Is the inspection result normal?

YES >> GO TO 9

NO >> Repair or replace harness.

### 8. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

- Turn ignition switch OFF.
- Disconnect main power window and door lock/unlock switch and rear power window switch RH.
- Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch RH connector (B).



Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7 (A)	5	D303 (B)	3	Yes
	7		2	

- Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	5		No
	7		

Is the inspection result normal?

YES >> GO TO 9

NO >> Repair or replace harness.

### 9. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-17. "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-19. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

## POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000003071139

### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC


# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >


1. Check main power window and door lock/unlock switch.

Terminal	Main power window and door lock/unlock switch condition	Continuity
10	1 Rear LH	UP
10	7 Rear RH	
10	8 Front RH	
1	3 Rear LH	NEUTRAL
5	7 Rear RH	
8	11 Front RH	
10	3 Rear LH	DOWN
10	5 Rear RH	
10	11 Front RH	




2. Check continuity between main power window and door lock/unlock switch (power window lock switch) (Lock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
3	Rear LH	UP
5	Rear RH	
11	Front RH	
1	Rear LH	NEUTRAL
3	Rear RH	
5	Front RH	
7	Rear LH	DOWN
8	Rear RH	
11	Front RH	



3. Check continuity between main power window and door lock/unlock switch (power window lock switch) (Unlock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
3	Rear LH	UP
5	Rear RH	
11	Front RH	
1	Rear LH	NEUTRAL
3	Rear RH	
5	Front RH	
7	Rear LH	DOWN
8	Rear RH	
11	Front RH	



# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

### Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch is OK.
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-75. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

## POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000003071140

### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

### Is the inspection result normal?

- YES >> GO TO 2
- NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

### 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

### Is the inspection result normal?

- YES >> Inspection end.
- NO >> Refer to [PWC-88. "DRIVER SIDE : Component Function Check"](#).

## FRONT POWER WINDOW SWITCH

### FRONT POWER WINDOW SWITCH : Description

INFOID:000000003071141

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

### FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000003071142

Power Window And Door Lock/unlock Switch RH

### 1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Does front power window motor RH operate with power window and door lock/unlock switch RH operation?

### Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
- NO >> Refer to [PWC-19. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

### FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000003071143

Power Window And Door Lock/Unlock Switch RH Power Supply Circuit Check


### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between power window and door lock/unlock switch RH connector and ground.

Terminal		Terminal	Voltage (V) (Approx.)
(+)	(-)		
Power window and door lock/unlock switch RH connector			
D105	8	Ground	Battery voltage

### Is the measurement value within the specification?

- YES >> GO TO 3



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

NO >> GO TO 2

## 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and power window and door lock/unlock switch RH.
3. Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M16 (A)	3	D105 (B)	8	Yes

4. Check continuity between BCM connector (A) and ground.

BCM connector	Terminal	Ground	Continuity
M16 (A)	3		No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

## 3. CHECK HARNESS CONTINUITY (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and power window and door lock/unlock switch RH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
D7 (A)	11	D105 (B)	11	Yes
	8		12	

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.



Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	8		No
	11		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace harness.

## 4. CHECK BCM OUTPUT SIGNAL




# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between power window and door lock/unlock switch RH connector and ground.

Terminal		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	
D105	8	Battery voltage



Is the measurement value within the specification?

- YES >> GO TO 5  
 NO >> Repair or replace harness.

## 5. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-79, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?


- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).  
 NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60, "Removal and Installation"](#).

## COMPONENT INSPECTION

### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Terminal	Power window switch condition	Continuity
8	6	UP
12	7	
12	7	
6	11	NEUTRAL
8	7	
6	11	DOWN



Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH is OK.  
 NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60, "Removal and Installation"](#).

## REAR POWER WINDOW SWITCH

### REAR POWER WINDOW SWITCH : Description

INFOID:000000003071144

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

### REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000003071145

#### Rear Power Window Switch

### 1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Does rear power window motor operate with rear power window switch operation?

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.  
 NO >> Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## REAR POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000003071146

### Rear Power Window Switch Power Supply Circuit Check

#### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear power window switch connector and ground.

Terminal		Terminal	(-)	Condition	Voltage (V) (Approx.)
(+)					
Rear power window switch connector		1	Ground	Ignition switch ON	Battery voltage
LH	D203				
RH	D303				




Is the measurement value within the specification?

- YES >> GO TO 2 (Rear power window switch LH)  
 YES >> GO TO 3 (Rear power window switch RH)  
 NO >> GO TO 4

#### 2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7 (A)	1	D203 (B)	2	Yes
	3		3	



4. Check continuity between main power window and door lock/unlock switchh connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	1	Ground	No
	3		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).  
 NO >> Repair or replace harness.


#### 3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

# POWER SUPPLY AND GROUND CIRCUIT

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch RH connector (B).



Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7 (A)	5	D303 (B)	3	Yes
	7		2	

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.


Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	5		No
	7		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).  
 NO >> Repair or replace harness.

## 4. CHECK HARNESS CONTINUITY

1. Disconnect BCM and rear power window switch.
2. Check continuity between BCM connector (A) and rear power window switch connector (B).



BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M16 (A)	3	LH	D203 (B)	1	Yes
		RH	D303 (B)		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M16	3		No

Is the inspection result normal?

- YES >> GO TO 5  
 NO >> Repair or replace harness.

## 5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-79. "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).  
 NO >> Replace rear power window switch. Refer to [PWC-60. "Removal and Installation"](#).

## REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000003071147

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW SWITCH


# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Check rear power window switch.

Terminal		Power window switch condition	Continuity
1	5	UP	Yes
3	4		
3	4	NEUTRAL	
2	5		
1	4	DOWN	
2	5		



Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-60. "Removal and Installation"](#).



# POWER WINDOW MOTOR

[LH ONLY WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## POWER WINDOW MOTOR DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003071148

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch.

### DRIVER SIDE : Component Function Check

INFOID:000000003071149

#### 1. CHECK FRONT POWER WINDOW MOTOR LH CIRCUIT

Does front power window motor LH operate with the main power window and door lock/unlock switch?

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-25. "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure


INFOID:000000003071150

#### Front Power Window Motor LH Circuit Check

##### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector and ground.

Terminal (+)		Terminal (-)	Main power window and door lock/unlock switch condition	Voltage (V) (Approx.)
Front power window motor LH connector	Terminal			
D9	2	Ground	UP	Battery voltage
			DOWN	0
	1		UP	0
			DOWN	Battery voltage



Is the measurement value within the specification?


YES >> GO TO 2

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-19. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

##### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	16	D9 (B)	2	Yes
	12		1	



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal		Ground	Continuity
	D7 (A)	16		
12				

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

## 3. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-82, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-26, "DRIVER SIDE : Special Repair Requirement"](#).

## DRIVER SIDE : Component Inspection

INFOID:000000003071151

### COMPONENT INSPECTION

#### 1. CHECK FRONT POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to power window motor?

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-26, "DRIVER SIDE : Special Repair Requirement"](#).

## DRIVER SIDE : Special Repair Requirement

INFOID:000000003071152

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

#### 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [PWC-32, "DRIVER SIDE : Component Function Check"](#).

## PASSENGER SIDE

# POWER WINDOW MOTOR

[LH ONLY WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## PASSENGER SIDE : Description

INFOID:000000003071153

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

## PASSENGER SIDE : Component Function Check

INFOID:000000003071154

### 1. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Does front power window motor RH operate with main power window and door lock/unlock switch or power window and door lock/unlock switch?

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Refer to [PWC-27. "PASSENGER SIDE : Diagnosis Procedure"](#).

## PASSENGER SIDE : Diagnosis Procedure


INFOID:000000003071155

### Front Power Window Motor RH Circuit Check

#### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

1. Disconnect front power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor RH connector and ground.

Terminal (+)		Terminal (-)	Front power window motor RH condition	Voltage (V) (Approx.)
Front power window motor RH connector	Terminal			
D104	1	Ground	UP	Battery voltage
			DOWN	0
	2		UP	0
			DOWN	Battery voltage




Is the measurement value within the specification?

- YES >> GO TO 2
- NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60. "Removal and Installation"](#).

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

Power window and door lock/unlock-switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105 (A)	6	D104 (B)	1	Yes
	7		2	



4. Check continuity between power window and door lock/unlock switch connector (A) and ground.

# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105 (A)	6		Ground
	7		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

## 3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-28, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace front power window motor RH. Refer to [PWC-60, "Removal and Installation"](#).

## PASSENGER SIDE : Component Inspection

INFOID:000000003071156

### COMPONENT INSPECTION

#### COMPONENT INSPECTION

## 1. CHECK FRONT POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to front power window motor RH?

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#).

## REAR LH

### REAR LH : Description

INFOID:000000003071157

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch LH.

### REAR LH : Component Function Check

INFOID:000000003071158

## 1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Does rear power window motor LH operate with main power window and door lock/unlock switch or rear power window switch LH?

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-28, "REAR LH : Diagnosis Procedure"](#).

### REAR LH : Diagnosis Procedure

INFOID:000000003071159

Rear Power Window Motor LH Circuit Check


## 1. CHECK REAR POWER WINDOW SWITCH LH OUTPUT SIGNAL

# POWER WINDOW MOTOR

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Disconnect rear power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor LH connector and ground.



Terminal (+)		Terminal (-)	Window condition	Voltage (V) (Approx.)
Rear power window motor LH connector	Terminal			
D204	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage


Is the measurement value within the specification?

YES >> GO TO 2

NO >> Check rear power window switch LH. Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

## 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector (A) and rear power window motor LH connector (B).



Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203 (A)	5	D204 (B)	1	Yes
	4		3	

4. Check continuity between rear power window switch LH connector (A) and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203 (A)	5	Ground	No
	4		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

## 3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-29, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace rear power window motor LH. Refer to [GW-24, "Removal and Installation"](#).

## REAR LH : Component Inspection

INFOID:000000003071160

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to rear power window motor LH?

# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Replace rear power window motor LH. Refer to [GW-24, "Removal and Installation"](#).

## REAR RH

### REAR RH : Description

INFOID:000000003071161

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

### REAR RH : Component Function Check

INFOID:000000003071162

#### 1. CHECK POWER WINDOW MOTOR CIRCUIT

Does rear power window motor RH operate with operating main power window and door lock/unlock switch or rear power window switch RH?

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Refer to [PWC-30, "REAR RH : Diagnosis Procedure"](#).

### REAR RH : Diagnosis Procedure


INFOID:000000003071163

#### Rear Power Window Motor RH Circuit Check

##### 1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Disconnect rear power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor RH connector and ground.

Terminal		Rear power window switch RH condition	Voltage (V) (Approx.)
(+)	(-)		
Rear power window motor RH connector D304	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage



Is the measurement value within the specification?

YES >> GO TO 2

NO >> Check rear power window switch RH. Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

##### 2. CHECK HARNESS CONTINUITY

# POWER WINDOW MOTOR

[LH ONLY WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector (A) and rear power window motor RH connector (B).

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303 (A)	5	D304 (B)	1	Yes
	4		3	

4. Check continuity between rear power window switch RH connector (A) and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303 (A)	5		No
	4		

Is the inspection result normal?

- YES >> GO TO 3  
 NO >> Repair or replace harness.

### 3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.  
 Refer to [PWC-31, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).  
 NO >> Replace rear power window motor RH. Refer to [GW-24, "Removal and Installation"](#).

## REAR RH : Component Inspection

INFOID:000000003071164

### COMPONENT INSPECTION


#### 1. CHECK REAR POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to rear power window motor RH?

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Power window motor is OK.  
 NO >> Replace rear power window motor RH. Refer to [GW-24, "Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## ENCODER DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003071165

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

### DRIVER SIDE : Component Function Check

INFOID:000000003071166

## 1. CHECK ENCODER OPERATION

Does front door glass LH perform AUTO open/close operation normally with main power window and door lock/unlock switch?

Is the inspection result normal?

- YES >> Encoder operation is OK.
- NO >> Refer to [PWC-88, "DRIVER SIDE : Diagnosis Procedure"](#).


### DRIVER SIDE : Diagnosis Procedure

INFOID:000000003071167


#### Encoder Circuit Check

## 1. CHECK ENCODER OPERATION

1. Connect front power window motor LH.
2. Turn ignition switch ON.
3. Check signal between main power window and door lock/unlock switch connector and ground with oscilloscope.



Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	
D7	9 13	Ground  Refer to following signal



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> GO TO 2

## 2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY




# ENCODER

## < COMPONENT DIAGNOSIS >

## [LH ONLY WINDOW ANTI-PINCH]

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector and ground.

Terminal			Voltage (V) (Approx.)
(+)		(-)	
Front power window motor LH connector	Terminal		
D9	4	Ground	10




Is the measurement value within the specification?

- YES >> GO TO 4  
NO >> GO TO 3

### 3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	15	D9 (B)	4	Yes



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	15		No


Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-34, "DRIVER SIDE : Special Repair Requirement"](#).  
NO >> Repair or replace harness.

### 4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	6		Yes



Is the inspection result normal?

- YES >> GO TO 6  
NO >> GO TO 5

### 5. CHECK HARNESS CONTINUITY 2

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ENCODER

## < COMPONENT DIAGNOSIS >

## [LH ONLY WINDOW ANTI-PINCH]

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	2	D9 (B)	6	Yes

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-34, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness.

### 6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	9	D9 (B)	3	Yes
	13		5	

3. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	9		No
	13		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-26, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness.

## DRIVER SIDE : Special Repair Requirement

INFOID:000000003071168

### 1. PERFORM INITIALIZATION PROCEDURE



Perform initialization procedure.

Refer to [PWC-8, "BASIC INSPECTION : Special Repair Requirement"](#)

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).



# DOOR SWITCH

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## DOOR SWITCH

### Description

INFOID:000000003071169

Detects door open/close condition and transmits the signal to BCM.

### Component Function Check

INFOID:000000003071170

#### 1. CHECK FRONT DOOR SWITCH INPUT SIGNAL

Check ("DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-III. Refer to [PWC-13. "RETAINED PWR : CONSULT-III Function \(BCM - RETAINED PWR\)"](#).

Monitor item	Condition
DOOR SW-DR	OPEN : ON
	CLOSE : OFF
DOOR SW-AS	OPEN : ON
	CLOSE : OFF

#### Is the inspection result normal?

- YES >> Front door switch circuit is OK.
- NO >> Refer to [PWC-35. "Diagnosis Procedure"](#).


### Diagnosis Procedure

INFOID:000000003071171

#### 1. CHECK HARNESS CONTINUITY

Check voltage between BCM connector and ground.

Terminals		Door condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	32	Front door RH	OPEN 0
			CLOSE Battery voltage
	58	Front door LH	OPEN 0
			CLOSE Battery voltage




#### Is the measurement value within the specification?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).
- NO >> GO TO 2

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front door switch.
3. Check continuity between BCM connector (A) and front door switch connector (B).

BCM connector	Terminal	Front door switch connector	Terminal	Continuity
M18 (A)	32	RH: B108 (B)	2	Yes
	58	LH: B8 (B)		



4. Check continuity between BCM connector (A) and ground.

# DOOR SWITCH

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

BCM connector	Terminal	Ground	Continuity
M18	32		Ground
	58		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

## 3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Terminal (+)		Terminal (-)	Voltage (V) (Approx.)
BCM connector	Terminal		
M18	32	Ground	Battery voltage
	58		

Is the measurement value within the specification?

- YES >> GO TO 4
- NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

## 4. CHECK FRONT DOOR SWITCH

Check front door switch.  
Refer to [PWC-36, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace front door switch.

## Component Inspection

INFOID:000000003071172



### 1. CHECK FRONT DOOR SWITCH

Check front door switches.

Terminal		Door switch	Continuity
Door switches			
2	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

- YES >> Front door switch is OK.
- NO >> Replace front door switch.



# POWER WINDOW LOCK SWITCH

< COMPONENT DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## POWER WINDOW LOCK SWITCH

### Description

INFOID:000000003071173

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

### Component Function Check

INFOID:000000003071174

#### 1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

##### Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, [PWC-8, "BASIC INSPECTION : Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

### Special Repair Requirement

INFOID:000000003071175

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-8, "BASIC INSPECTION : Special Repair Requirement"](#).

##### Is the inspection result normal?

- YES >> Inspection end.
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000003071176

#### VALUES ON THE DIAGNOSIS TOOL

##### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
DOOR SW-DR	Front door LH closed	OFF
	Front door LH opened	ON
DOOR SW-AS	Front door RH closed	OFF
	Front door RH opened	ON

#### TERMINAL LAYOUT

Refer to [BCS-50, "Terminal Layout"](#).

#### PHYSICAL VALUES

Refer to [BCS-51, "Physical Values"](#).

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


[LH ONLY WINDOW ANTI-PINCH]

## POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000003071177

### TERMINAL LAYOUT



### PHYSICAL VALUES

#### MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
1 (G/B)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage
2 (W/B)	Ground	Encoder ground	—	—	0
3 (G/O)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage
5 (G/R)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
6 (GR/R)	Ground	Door key cylinder switch UNLOCK signal	Input	Key position (Neutral → Unlocked)	5 → 0
7 (G/W)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (R/B)	11	Front power window motor RH UP signal	Output	When front RH switch in power window main switch is operated UP.	Battery voltage
9 (G/W)	2	Encoder pulse signal 2	Input	When power window mo- tor operates.	

JMKIA0070GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
10 (L/W)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When driver side or passenger side door is opened during retained power operation.	0
11 (R/W)	8	Front power window motor RH DOWN signal	Output	When front RH switch in power window main switch is operated DOWN.	Battery voltage
12 (L/B)	16	Front power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage
13 (G/Y)	2	Encoder pulse signal 1	Input	When power window motor operates.	
15 (G/R)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
16 (L/R)	12	Front power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
17 (B)	Ground	Ground	—	—	0
19 (R/Y)	Ground	Battery power supply	Input	—	Battery voltage

JMKIA0070GB



# POWER WINDOW MAIN SWITCH


[LH ONLY WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

## Wiring Diagram

INFOID:000000003071178

### POWER WINDOW SYSTEM-WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH



AWKWA0206GI

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P




# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM CONNECTORS-WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	82G	Color of Wire	W/B	Signal Name	—
--------------	-----	---------------	-----	-------------	---

Terminal No.	7N	Color of Wire	Y/R	Signal Name	—
--------------	----	---------------	-----	-------------	---

Terminal No.	17J	Color of Wire	SB	Signal Name	—
93J	L/W	—	—	—	
94J	G/B	—	—	—	
95J	G/O	—	—	—	

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	7	Color of Wire	R/Y	Signal Name	—
8	B	—	—	—	
10	G/R	—	—	—	
11	G/O	—	—	—	
12	L/W	—	—	—	
16	R/W	—	—	—	

Terminal No.	1	Color of Wire	L/W	Signal Name	—
3	G/R	—	—	—	
7	G/B	—	—	—	
10	R/B	—	—	—	

Terminal No.	2	Color of Wire	G/W	Signal Name	—
3	G/B	—	—	—	
6	R/B	—	—	—	


AWKIA0533GB

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L/W	—
3	R/B	—
5	B	—
10	R/W	—

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_FL
2	R/Y	P/W_POWER_SUPPL Y_PERM
3	L/W	POWER_WINDOW_ POWER_SUPPLY (RAP)

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	Y/R	BAT_BCM_FUSE
13	B	GND1
15	Y/L	ACC_LED

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
32	R/B	AS_DOOR_SW
42	R	S/L_LOCK_LED
58	SB	DR_DOOR_SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
81	LG	IGN_ON_LED

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	—

ALKIA0183GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17J	SB	---
93J	L/W	---
94J	G/B	---
95J	G/O	---

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G/B	---
4	G/O	---
6	B	---
8	L/W	---

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	SB	DOOR SW(DR)

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	---
3	G/R	---
7	G/B	---
10	R/G	---

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/W	---
4	G/R	---
6	B	---
8	L/W	---


AWKIA0534GB

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	R/G	DOOR SW (AS)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G/W	—
3	G/B	—
6	R/B	—
7	R/Y	—
8	B	—
10	G/R	—
11	G/O	—
12	L/W	—
16	R/W	—

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/B	RL_UP
2	W/B	ENCODER_GND
3	G/O	RL_DOWN
5	G/R	RR_DOWN
7	G/W	RR_UP
8	R/B	AS_UP
9	G/W	ENCODER_SIG2
10	L/W	IGN
11	R/W	AS_DOWN
12	L/B	DR_DOWN
13	G/Y	ENCODER_SIG1
15	G/R	ENCODER_POWER
16	L/R	DR_UP

Connector No.	D8
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	GND
19	R/Y	BAT

AWKIA0535GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/W	—
3	R/B	—
5	B	—
10	R/W	—

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—
3	G/W	—
4	G/R	—
5	G/Y	—
6	W/B	—

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/B	—
4	G/O	—
6	B	—
8	L/W	—

Terminal No.	Color of Wire	Signal Name
3	B	GND
6	L/B	DOWN
7	L/R	UP
8	L/W	IGN
11	R/W	DOWN
12	R/B	UP

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE




AWKIA0536GB

# POWER WINDOW MAIN SWITCH

[LH ONLY WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G/W	—
4	G/R	—
6	B	—
8	L/W	—

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/B	UP
3	G/O	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/W	UP
3	G/R	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

ALKIA0187GB

INFOID:000000003071179

## Fail Safe

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.



## SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

### Diagnosis Procedure

INFOID:000000003071180

#### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.  
Refer to [BCS-41, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check main power window and door lock/unlock switch power supply and ground circuit.  
Refer to [PWC-14, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.  
Refer to [PWC-14, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

---

## DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071181

#### 1. CHECK FRONT POWER WINDOW MOTOR LH

---

Check front power window motor LH.

Refer to [PWC-25, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071182

#### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-19, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-27, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

---

## REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071183

#### 1. CHECK REAR POWER WINDOW SWITCH LH

---

Check rear power window switch LH.

Refer to [PWC-21, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW MOTOR LH

---

Check rear power window motor LH.

Refer to [PWC-28, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071184

#### 1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-21, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-30, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003071185

#### 1. PERFORM INITIALIZATION PROCEDURE

---

Perform initialization procedure.

Refer to [PWC-19, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK DOOR WINDOW SLIDING PART

---

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK ENCODER CIRCUIT

---

Check encoder circuit.

Refer to [PWC-14, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003071186

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-19, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK ENCODER

Check encoder.

Refer to [PWC-14, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

### Diagnosis Procedure

INFOID:000000003071187

#### 1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [PWC-35, "Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).



# POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH ONLY WINDOW ANTI-PINCH]

## POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

### Diagnosis Procedure

INFOID:000000003071188

#### 1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-60, "Removal and Installation"](#). After that, [PWC-19, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003071189

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# PRE-INSPECTION FOR DIAGNOSTIC

< ON-VEHICLE MAINTENANCE >

[LH ONLY WINDOW ANTI-PINCH]

## ON-VEHICLE MAINTENANCE

### PRE-INSPECTION FOR DIAGNOSTIC

#### Basic Inspection

INFOID:000000003071190

#### BASIC INSPECTION

##### 1.INSPECTION START

1. Check the service history.
2. Check the following parts.
  - Fuse/circuit breaker blown.
  - Poor connection, open or short circuit of harness connector.
  - Battery voltage.

##### Is the inspection result normal?

- YES >> Inspection end.  
NO >> Repair or replace the malfunctioning parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

< ON-VEHICLE REPAIR >

[LH ONLY WINDOW ANTI-PINCH]

## ON-VEHICLE REPAIR


### POWER WINDOW MAIN SWITCH

#### Removal and Installation

INFOID:000000003071191

#### REMOVAL

1. Remove the power window main switch finisher (2).  
Refer to [INT-11. "Removal and Installation"](#).
2. Power window main switch (1) is removed from power window main switch finisher (2) using flat-head screw driver (A) etc.


 : Pawl

#### CAUTION:

**Do not fold the pawl of power window main switch finisher.**

#### NOTE:

The same procedure is also performed for front power window and door lock/unlock switch RH and rear power window switch (LH & RH).



#### INSTALLATION

Install in the reverse order of removal.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH&RH FRONT WINDOW ANTI-PINCH]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000003071192

#### OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH&RH FRONT WINDOW ANTI-PINCH]

DETAILED FLOW

## 1. INTERVIEW FOR MALFUNCTION

---

Interview the symptom to the customer.

>> GO TO 2

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH&RH FRONT WINDOW ANTI-PINCH]

NO >> GO TO 11

## 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LH&RH FRONT WINDOW ANTI-PINCH]

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000003071193

Initial setting is necessary when battery terminal is disconnected.

#### **CAUTION:**

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000003071194

### INITIALIZATION PROCEDURE

1. Disconnect battery negative terminal or main power window and door lock/unlock switch. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 3 seconds or more.
5. Inspect anti-pinch function.

### CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
  - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
  - Check that glass does not rise when operating the power window main switch while lowering.

#### **CAUTION:**

- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-113, "Fail Safe"](#).
- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function
3. Retained power operation when ignition switch is OFF.

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000003071195

Initial setting is necessary when replacing main power window and door lock/unlock switch.

#### **CAUTION:**

The following specified operations are not performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function
- Retained power operation

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000003071196

### INITIALIZATION PROCEDURE

1. Disconnect battery negative terminal or main power window and door lock/unlock switch. Reconnect it after a minute or more.



# INSPECTION AND ADJUSTMENT

## < BASIC INSPECTION >

## [LH&RH FRONT WINDOW ANTI-PINCH]

2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open) A
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 3 seconds or more. B
5. Inspect anti-pinch function.

### CHECK ANTI-PINCH FUNCTION

1. Fully open the door window. C
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.
  - Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops. D
  - Check that glass does not rise when operating the main power window and door lock/unlock switch while lowering.

#### **CAUTION:**

- Do not check with hands and other part of body because they may be pinched. Do not get pinched. E
  - Check that AUTO-UP operates before inspection when system initialization is performed.
  - It may switch to fail-safe mode if open/close operation is performed continuously. Perform initial setting in that situation. Refer to [PWC-113, "Fail Safe"](#). F
  - Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
  - Finish initial setting. Otherwise, next operation cannot be done.
1. Auto-up operation G
  2. Anti-pinch function H
  3. Retained power operation when ignition switch is OFF. I

PWC

L

M

N

O

P

# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]


## FUNCTION DIAGNOSIS

### POWER WINDOW SYSTEM

#### System Diagram

INFOID:000000003071197

#### FRONT WINDOW ANTI-PINCH SYSTEM



#### System Description

INFOID:000000003071198

#### POWER WINDOW MAIN SWITCH INPUT/OUTPUT SIGNAL CHART

Item	Input signal to main power window and door lock/unlock switch	Main power window and door lock/unlock switch function	Actuator
Key cylinder switch	LOCK/UNLOCK signal (more than 1.5 seconds over)	Power window control	Front power window motor
Encoder	Encoder pulse signal		
Main power window and door lock/unlock switch	Front power window motor LH UP/DOWN signal		
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal		
BCM	RAP signal		
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor

#### POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT/OUTPUT SIGNAL CHART

# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Item	Input signal to front power window switch	Front power window switch function	Actuator
Power window and door lock/unlock switch RH	Front power window motor RH UP/DOWN signal	Power window control	Front power window motor RH
Encoder	Encoder pulse signal		
BCM	RAP signal		

## POWER WINDOW OPERATION

- Power window system is operable during the retained power operation timer after turning ignition switch ON and OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Power window and door lock unlock switch RH & rear power window switches LH and RH can open/close the corresponding windows.

## POWER WINDOW AUTO-OPERATION (FRONT LH & RH)

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch & power window and door lock/unlock switch RH turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

## RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF

### Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes. (45 seconds)

## POWER WINDOW LOCK

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch.

## ANTI-PINCH OPERATION (FRONT LH & RH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm or 2 seconds after it detects encoder pulse signal frequency change.

## OPERATION CONDITION

- When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

### NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

## KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for more than 1 second to OPEN or CLOSE front power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL when operating.

## OPERATION CONDITION

- Ignition switch OFF

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW SYSTEM

## < FUNCTION DIAGNOSIS >

## [LH&RH FRONT WINDOW ANTI-PINCH]

- Hold door key cylinder to LOCK position for more than 1 second to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for more than 1 second to perform OPEN operation of the door glass.

### KEYLESS POWER WINDOW DOWN OPERATION (FRONT LH & RH)

Front power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3(NOTE) seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

#### NOTE:

Keyless power window down operation mode can be changed by "PW DOWN SET" mode in "WORK SUPPORT". Refer to [SEC-21. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)


#### NOTE:

Use CONSULT-III to change settings.

MODE 1 (3sec) / MODE 2 (OFF) / MODE 3 (5sec)

## Component Parts Location

INFOID:000000003071199



ALCIA0039ZZ

# POWER WINDOW SYSTEM

## [LH&RH FRONT WINDOW ANTI-PINCH]

### < FUNCTION DIAGNOSIS >

- |  |   |  |
|--|---|--|
| 1. BCM M16, M17, M18, M19 (view with instrument panel removed) | 2. Front power window motor LH D9, RH D104          | 3. Rear power window motor LH D204, RH D304  |
| 4. Main power window and door lock/unlock switch D7, D8        | 5. Power window and door lock/unlock switch RH D105 | 6. Rear power window switch LH D203, RH D303 |
| 7. Front door lock assembly LH (key cylinder switch) D10       | 8. Front door switch LH B8, RH B108                 |  |

### Component Description

INFOID:000000003071200

### FRONT WINDOW ANTI-PINCH SYSTEM

Component	Function
BCM	<ul style="list-style-type: none"> <li>Supplies power supply to power window switch.</li> <li>Controls retained power.</li> </ul>
Main power window and door lock/unlock switch	<ul style="list-style-type: none"> <li>Directly controls all power window motor of all doors.</li> <li>Controls anti-pinch operation of front power window LH.</li> </ul>
Power window and door lock/unlock switch RH	<ul style="list-style-type: none"> <li>Controls front power window motor RH.</li> <li>Controls anti-pinch operation of front power window RH.</li> </ul>
Rear power window switch	<ul style="list-style-type: none"> <li>Controls rear power window motors LH and RH.</li> </ul>
Front power window motor LH	<ul style="list-style-type: none"> <li>Integrates the ENCODER POWER and WINDOW MOTOR.</li> <li>Starts operating with signals from main power window and door lock/unlock switch.</li> <li>Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch.</li> </ul>
Front power window motor RH	Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH.
Rear power window motor	Starts operating with signals from main power window and door lock/unlock switch & rear power window switch.
Front door lock assembly LH (key cylinder switch)	Transmits operation condition of key cylinder switch to power window main switch.
Front door switch LH or RH	Detects door open/close condition and transmits to BCM.

PWC

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000003071201

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to <a href="#">BCS-81, "DTC Index"</a> .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	This function is not used even though it is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	×		
RAP system	RETAINED PWR		×	

### RETAINED PWR

RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR)

INFOID:000000003071202

### Data monitor

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### POWER WINDOW MAIN SWITCH

#### POWER WINDOW MAIN SWITCH : Description

INFOID:000000003071203

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

#### POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000003071204

#### Main Power Window And Door Lock/Unlock Switch

#### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Does power window motor operate with main power window and door lock/unlock switch operation?

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.  
 NO >> Refer to [PWC-71, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

#### POWER WINDOW MAIN SWITCH : Diagnosis Procedure


INFOID:000000003071205

#### Main Power Window And Door Lock/Unlock Switch Power Supply Circuit Check

#### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors (A and B) and ground.

Terminal (+)		Terminal (-)	Voltage (V) (Approx.)
Main power window and door lock/unlock switch connector	Terminal		
D7 (A)	10	Ground	Battery voltage
D8 (B)	19		




Is the measurement value within the specification?

- YES >> GO TO 3  
 NO >> GO TO 2

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector (A) and main power window and door lock/unlock switch connectors (B and C).

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M16 (A)	3	D7 (B)	10	Yes
	2	D8 (C)	19	



4. Check continuity between BCM connector (A) and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

BCM connector	Terminal	Ground	Continuity
M16	3		Ground
	2		

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.


## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D8	17		Ground

Is the inspection result normal?


- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-140, "Removal and Installation"](#). After that, refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).
- NO >> Repair or replace harness.



## 4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector and ground.

Terminals		(-)	Voltage (V) (Approx.)
(+) BCM connector			
M16	3	Ground	Battery voltage
	2		




Is the measurement value within the specification?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6
- NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

## 5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector and ground.





# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Terminal		Window condition	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?


YES >> GO TO 7

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-140, "Removal and Installation"](#). After that, refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

## 6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

- Turn ignition switch ON.
- Check voltage between main power window and door lock/unlock switch connector and ground.

Terminal		Window condition	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	7	UP	Battery voltage
		DOWN	0
	5	UP	0
		DOWN	Battery voltage



Is the measurement value within the specification?


YES >> GO TO 8

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-140, "Removal and Installation"](#). After that, refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

## 7. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

- Turn ignition switch OFF.
- Disconnect rear power window switch LH.
- Check continuity between main power window and door lock/unlock switch connector and rear power window switch LH connector.

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7 (A)	1	D203 (B)	2	Yes
	3		3	



- Check continuity between main power window and door lock/unlock switch connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	1		Ground
	3		


Is the inspection result normal?

YES >> GO TO 9

NO >> Repair or replace harness.

## 8. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

- Turn ignition switch OFF.
- Disconnect rear power window switch RH.
- Check continuity between main power window and door lock/unlock switch connector and rear power window switch RH connector.



Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7 (A)	5	D303 (B)	3	Yes
	7		2	

- Check continuity between main power window and door lock/unlock switch connector and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	5		Ground
	7		

Is the inspection result normal?

YES >> GO TO 9

NO >> Repair or replace harness.

## 9. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-74, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. After that, refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).


## POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000003071206

### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

- Check main power window and door lock/unlock switch.

Terminal	Main power window and door lock/unlock switch condition	Continuity
10	1	UP
10	7	
1	3	NEUTRAL
5	7	
10	3	DOWN
10	5	




# POWER SUPPLY AND GROUND CIRCUIT

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >


2. Check continuity between main power window and door lock/unlock switch condition. (Lock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
3	Rear LH	UP
5	Rear RH	
1	Rear LH	NEUTRAL
3	Rear RH	
5	Rear LH	DOWN
7	Rear RH	



3. Check continuity between main power window and door lock/unlock switch condition. (Unlock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
3	Rear LH	UP
5	Rear RH	
1	Rear LH	NEUTRAL
3	Rear RH	
5	Rear LH	DOWN
7	Rear RH	



Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch is OK.  
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-75, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

PWC

## POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000003071207

### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2  
 NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

### 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection end.  
 NO >> Refer to [PWC-88, "DRIVER SIDE : Component Function Check"](#).

## FRONT POWER WINDOW SWITCH

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## FRONT POWER WINDOW SWITCH : Description

INFOID:000000003071208

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

## FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000003071209

Power Window And Door Lock/Unlock Switch RH

### 1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Does front power window motor RH operate with power window and door lock/unlock switch RH operation?

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.  
 NO >> Refer to [PWC-76. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

## FRONT POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000003071210

Power Window And Door Lock/Unlock Switch RH Power Supply Circuit Check

### 1. CHECK POWER SUPPLY CIRCUIT

Check voltage between power window and door lock/unlock switch RH connector and ground.

Terminal (+)		Terminal (-)	Voltage (V) (Approx.)
Power window and door lock/unlock switch RH connector	Terminal		
D105	10	Ground	Battery voltage




Is the measurement value within the specification?

- YES >> GO TO 3  
 NO >> GO TO 2

### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and power window and door lock/unlock switch RH.
3. Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M16 (A)	2	D105 (B)	10	Yes



4. Check continuity between BCM connector (A) and ground.

BCM connector	Terminal	Ground	Continuity
M16 (A)	2	Ground	No

Is the inspection result normal?

- YES >> GO TO 4  
 NO >> Repair or replace harness.

### 3. CHECK GROUND CIRCUIT

# POWER SUPPLY AND GROUND CIRCUIT

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector and ground.

Power window and door lock/unlock switch RH	Terminal	Ground	Continuity
D105	11		Yes

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-77, "FRONT POWER WINDOW SWITCH : Special Repair Requirement"](#).

NO >> Repair or replace harness.

## 4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector and ground.

Terminals		(-)	Voltage (V) (Approx.)
(+)	Terminal		
BCM connector	2	Ground	Battery voltage
M16	2		

Is the measurement value within the specification?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-77, "FRONT POWER WINDOW SWITCH : Special Repair Requirement"](#).

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

## FRONT POWER WINDOW SWITCH : Special Repair Requirement

INFOID:000000003071211

## 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

## 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.


NO >> Refer to [PWC-90, "PASSENGER SIDE : Component Function Check"](#).

## REAR POWER WINDOW SWITCH


### REAR POWER WINDOW SWITCH : Description

INFOID:000000003071212

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.



ALKIA0304ZZ



ALKIA0304ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000003071213

Rear Power Window Switch

### 1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Does rear power window motor operate with rear power window switch operation?

Is the inspection result normal?

YES >> Rear power window switch power supply and ground circuit are OK.

NO >> Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

## REAR POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000003071214

Rear Power Window Switch Power Supply Circuit Check

### 1. CHECK POWER SUPPLY CIRCUIT

Check voltage between rear power window switch connector and ground.

Terminal		Terminal	Condition	Voltage (V) (Approx.)
(+)	(-)			
Rear power window switch connector		1	Ignition switch ON	Battery voltage
LH	D203			
RH	D303			



Is the measurement value within the specification?

YES >> GO TO 2 (Rear power window switch LH)


YES >> GO TO 3 (Rear power window switch RH)

NO >> GO TO 4

### 2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

- Turn ignition switch OFF.
- Disconnect main power window and door lock/unlock switch and rear power window switch LH.
- Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D7 (A)	1	D203 (B)	2	Yes
	3		3	



- Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	1	Ground	No
	3		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace harness.


### 3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

# POWER SUPPLY AND GROUND CIRCUIT

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch RH connector (B).



Main power window and door lock/unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D7 (A)	5	D303 (B)	3	Yes
	7		2	

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	5	Ground	No
	7		


Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace harness.

## 4. CHECK HARNESS CONTINUITY

1. Disconnect BCM and rear power window switch.
2. Check continuity between BCM connector (A) and rear power window switch connector (B).



BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M16 (A)	3	LH	D203 (B)	1	Yes
		RH	D303 (B)		

3. Check continuity between BCM connector (A) and ground.

BCM connector	Terminal	Ground	Continuity
M16 (A)	3	Ground	No

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace harness.

## 5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-79, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-60, "Removal and Installation"](#).

## REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000003071215

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW SWITCH


# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Check rear power window switch.

Terminal		Power window switch condition	Continuity
1	5	UP	Yes
3	4		
3	4	NEUTRAL	
5	2		
1	4	DOWN	
5	2		



Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-60. "Removal and Installation"](#).



# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## POWER WINDOW MOTOR DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003071216

Door glass moves UP/DOWN by receiving the signal from power window main switch.

### DRIVER SIDE : Component Function Check

INFOID:000000003071217

#### 1. CHECK POWER WINDOW MOTOR CIRCUIT

Does front power window motor LH operate with operating main power window and door lock/unlock switch?  
Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Refer to [PWC-81, "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure


INFOID:000000003071218

#### Front Power Window Motor LH Circuit Check

##### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector and ground.

Terminal (+)		Terminal (-)	Main power window and door lock/unlock switch condition	Voltage (V) (Approx.)
Power window motor LH connector	Terminal			
D9	2	Ground	UP	Battery voltage
			DOWN	0
	1		UP	0
			DOWN	Battery voltage




Is the measurement value within the specification?

- YES >> GO TO 2
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-75, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

##### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor connector LH (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	8	D9 (B)	2	Yes
	11		1	



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	8		Ground
	11		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

### 3. CHECK POWER WINDOW MOTOR

Check front power window motor LH.

Refer to [PWC-82, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-82, "DRIVER SIDE : Special Repair Requirement"](#).

## DRIVER SIDE : Component Inspection

INFOID:000000003071219

### COMPONENT INSPECTION

#### 1. CHECK FRONT POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to power window motor?

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-82, "DRIVER SIDE : Special Repair Requirement"](#).

## DRIVER SIDE : Special Repair Requirement

INFOID:000000003071220

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

#### 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-88, "DRIVER SIDE : Component Function Check"](#).

## PASSENGER SIDE

### PASSENGER SIDE : Description

INFOID:000000003071221

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## PASSENGER SIDE : Component Function Check

INFOID:000000003071223

### 1. CHECK POWER WINDOW MOTOR CIRCUIT

Does power window motor operate with operating main power window and door lock/unlock switch or power window and door lock/unlock switch RH?

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Refer to [PWC-83, "PASSENGER SIDE : Diagnosis Procedure"](#).

## PASSENGER SIDE : Diagnosis Procedure


INFOID:000000003071223

### Front Power Window Motor RH Circuit Check

#### 1. CHECK FRONT POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Disconnect front power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor RH connector and ground.

Terminal		(-)	Front power window motor RH condition	Voltage (V) (Approx.)
(+)	Terminal			
D104	2	Ground	UP	Battery voltage
			DOWN	0
	1		UP	0
			DOWN	Battery voltage




Is the measurement value within the specification?

- YES >> GO TO 2
- NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-77, "FRONT POWER WINDOW SWITCH : Special Repair Requirement"](#).

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105 (A)	8	D104 (B)	2	Yes
	9		1	



4. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105 (A)	8	Ground	No
	9		

Is the inspection result normal?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

- YES >> GO TO 3
- NO >> Repair or replace harness.

### 3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-84, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace front power window motor RH. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-84, "PASSENGER SIDE : Special Repair Requirement"](#).

## PASSENGER SIDE : Component Inspection

INFOID:000000003071224

### COMPONENT INSPECTION

#### 1. CHECK FRONT POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to front power window motor RH?

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

- YES >> Front power window motor RH is OK.
- NO >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-84, "PASSENGER SIDE : Special Repair Requirement"](#).

## PASSENGER SIDE : Special Repair Requirement

INFOID:000000003071225

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

#### 2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [PWC-90, "PASSENGER SIDE : Component Function Check"](#).

## REAR LH

### REAR LH : Description

INFOID:000000003071226

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

### REAR LH : Component Function Check

INFOID:000000003071227

#### 1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Does rear power window motor LH operate with main power window and door lock/unlock switch or rear power window switch LH?

Is the inspection result normal?

# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

- YES >> Rear power window motor LH is OK.
- NO >> Refer to [PWC-85, "REAR LH : Diagnosis Procedure"](#).


### REAR LH : Diagnosis Procedure

INFOID:000000003071228

#### Power Window Motor Circuit Check

### 1. CHECK REAR POWER WINDOW SWITCH OUTPUT SIGNAL

1. Disconnect rear power window motor LH connector.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor LH connector and ground.




Terminal (+)		Terminal (-)	Window condition	Voltage (V) (Approx.)
Rear power window motor LH connector	Terminal			
D204	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the measurement value within the specification?

- YES >> GO TO 2
- NO >> Check rear power window switch LH. Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector (A) and rear power window motor LH connector (B).



Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D203 (A)	5	D204 (B)	1	Yes
	4		3	

4. Check continuity between rear power window switch LH connector (A) and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D203 (A)	5	Ground	No
	4		

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

### 3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.  
Refer to [PWC-86, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace rear power window motor LH. Refer to [GW-24, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## REAR LH : Component Inspection

INFOID:000000003071229

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to rear power window motor LH?

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Replace rear power window motor LH. Refer to [GW-24. "Removal and Installation"](#).

## REAR RH

### REAR RH : Description

INFOID:000000003071230

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

### REAR RH : Component Function Check

INFOID:000000003071231

#### 1. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

Does rear power window motor RH operate with operating main power window and door lock/unlock switch or rear power window switch RH?

Is the inspection result normal?

YES >> Rear power window motor RH is OK.

NO >> Refer to [PWC-86. "REAR RH : Diagnosis Procedure"](#).

### REAR RH : Diagnosis Procedure

INFOID:000000003071232

#### Rear Power Window Motor RH Circuit Check

##### 1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Disconnect rear power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor RH connector and ground.


Terminal		Rear power window switch RH condition	Voltage (V) (Approx.)
(+)	(-)		
Rear power window motor RH connector  D304	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?

YES >> GO TO 2

NO >> Check rear power window switch RH. Refer to [PWC-78. "REAR POWER WINDOW SWITCH : Component Function Check"](#).

##### 2. CHECK HARNESS CONTINUITY




# POWER WINDOW MOTOR

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector (A) and rear power window motor RH connector (B).

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D303 (A)	5	D304 (B)	1	Yes
	4		3	



4. Check continuity between rear power window switch RH connector (A) and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D303 (A)	5	Ground	No
	4		

Is the inspection result normal?

- YES >> GO TO 3  
 NO >> Repair or replace harness.

### 3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.  
 Refer to [PWC-87, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).  
 NO >> Replace rear power window motor RH. Refer to [GW-24, "Removal and Installation"](#).

## REAR RH : Component Inspection

INFOID:000000003071233

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to rear power window motor RH?

Terminal		Motor condition
(+)	(-)	
3	1	DOWN
1	3	UP

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.  
 NO >> Replace rear power window motor RH. Refer to [GW-24, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ENCODER

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## ENCODER DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003071234

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

### DRIVER SIDE : Component Function Check

INFOID:000000003071235

#### 1. CHECK ENCODER OPERATION

Does front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch?

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-88, "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure



INFOID:000000003071236

#### Encoder Circuit Check

#### 1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Ground
D7	9	
	13	Refer to following signal



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 2

#### 2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY




# ENCODER

## [LH&RH FRONT WINDOW ANTI-PINCH]

### < COMPONENT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector and ground.

Terminal (+)		Terminal (-)	Voltage (V) (Approx.)
Front power window motor LH connector	Terminal		
D9	4	Ground	10




Is the measurement value within the specification?

- YES >> GO TO 4  
NO >> GO TO 3

### 3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	15	D9 (B)	4	Yes



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	15		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-75. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).  
NO >> Repair or replace harness.

### 4. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	6		Yes

Is the inspection result normal?

- YES >> GO TO 6  
NO >> GO TO 5

### 5. CHECK HARNESS CONTINUITY 2



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ENCODER

## < COMPONENT DIAGNOSIS >

## [LH&RH FRONT WINDOW ANTI-PINCH]

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	2	D9 (B)	6	Yes

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-75, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

NO >> Repair or replace harness.

### 6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D7 (A)	9	D9 (B)	3	Yes
	13		5	

3. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	9	Ground	No
	13		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#). After that, refer to [PWC-82, "DRIVER SIDE : Special Repair Requirement"](#).

NO >> Repair or replace harness.

## PASSENGER SIDE

### PASSENGER SIDE : Description

INFOID:000000003071237

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

### PASSENGER SIDE : Component Function Check

INFOID:000000003071238


#### 1. CHECK ENCODER OPERATION

Does front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH?


Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-91, "PASSENGER SIDE : Diagnosis Procedure"](#).



ALKIA0299ZZ



ALKIA0300ZZ

# ENCODER

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]



## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000003071239

### 1. CHECK ENCODER SIGNAL

1. Connect front power window motor RH.
2. Turn ignition switch ON.
3. Check signal between power window and door lock/unlock switch RH connector and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	Ground
D105	12	
	15	Refer to following signal




Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).  
 NO >> GO TO 2

### 2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor RH connector and ground.

Terminal		Voltage (V) (Approx.)
(+)	(-)	
Front power window motor RH connector	Terminal	10
D105	4	




Is the measurement value within the specification?

- YES >> GO TO 4  
 NO >> GO TO 3

### 3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH and front power window motor RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PWC

# ENCODER

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105 (A)	4	D104 (B)	4	Yes

4. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105 (A)	4		No

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-77. "FRONT POWER WINDOW SWITCH : Special Repair Requirement"](#).

NO >> Repair or replace harness.

## 4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Check continuity between front power window motor RH connector and ground.

Front power window motor RH connector	Terminal	Ground	Continuity
D104	6		Yes

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 5

## 5. CHECK HARNESS CONTINUITY 2

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).



Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105 (A)	3	D104 (B)	6	Yes

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-77. "FRONT POWER WINDOW SWITCH : Special Repair Requirement"](#).

NO >> Repair or replace harness.

## 6. CHECK HARNESS CONTINUITY 3




# ENCODER

## [LH&RH FRONT WINDOW ANTI-PINCH]

### < COMPONENT DIAGNOSIS >

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D105 (A)	12	D104 (B)	5	Yes
	15		3	



3. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D105 (A)	12	Ground	No
	15		

Is the inspection result normal?

- YES >> Replace front power window motor RH. Refer to [GW-18. "Removal and Installation"](#). After that, refer to [PWC-84. "PASSENGER SIDE : Special Repair Requirement"](#).
- NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DOOR SWITCH

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## DOOR SWITCH

### Description

INFOID:000000003071240

Detects door open/close condition and transmits the signal to BCM.

### Component Function Check

INFOID:000000003071241

#### 1. CHECK FRONT DOOR SWITCH INPUT SIGNAL

Check ("DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-III. Refer to [PWC-70. "RETAINED PWR : CONSULT-III Function \(BCM - RETAINED PWR\)"](#).

Monitor item	Condition	
DOOR SW-DR	OPEN	: ON
	CLOSE	: OFF
DOOR SW-AS	OPEN	: ON
	CLOSE	: OFF

Is the inspection result normal?

- YES >> Front door switch circuit is OK.  
 NO >> Refer to [PWC-94. "Diagnosis Procedure"](#).


### Diagnosis Procedure

INFOID:000000003071242

#### 1. CHECK HARNESS CONTINUITY

Check voltage between BCM connector and ground.

Terminals		Door condition	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	32	Front door RH	OPEN: 0 CLOSE: Battery voltage
		Front door LH	OPEN: 0 CLOSE: Battery voltage
	58		Ground




Is the measurement value within the specification?

- YES >> Replace BCM. Refer to [BCS-85. "Removal and Installation"](#).  
 NO >> GO TO 2

#### 2. CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and front door switch.
- Check continuity between BCM connector (A) and front door switch connector (B).

BCM connector	Terminal	Front door switch connector	Terminal	Continuity
M18 (A)	32	RH: B108 (B)	2	Yes
	58	LH: B8 (B)		



- Check continuity between BCM connector (A) and ground.

# DOOR SWITCH

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

BCM connector	Terminal	Ground	Continuity
M18 (A)	32		Ground
	58		


Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

## 3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Terminal		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	Battery voltage
M18	32	
	58	



Is the measurement value within the specification?

- YES >> GO TO 4
- NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).

## 4. CHECK FRONT DOOR SWITCH

Check front door switch.  
Refer to [PWC-95, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace front door switch.

## Component Inspection

INFOID:000000003071243


### 1. CHECK FRONT DOOR SWITCH

Check front door switches.

Terminal		Door switch	Continuity
Door switches			
2	Ground part of door switch	Pressed	No
		Released	Yes

Is the inspection result normal?

- YES >> Front door switch is OK.
- NO >> Replace front door switch.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DOOR KEY CYLINDER SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## DOOR KEY CYLINDER SWITCH

### Description

INFOID:000000003071244

Main power window and door lock/unlock switch detects condition of the door key cylinder and transmits to BCM as the LOCK or UNLOCK signals.

### Component Function Check

INFOID:000000003071245

## 1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check ("KEY CYL LK-SW", "KEY CYL UN-SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [SEC-20. "COMMON ITEM : CONSULT-III Function"](#).

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

- YES >> Key cylinder switch is OK.  
 NO >> Refer to [PWC-96. "Diagnosis Procedure"](#).


### Diagnosis Procedure

INFOID:000000003071246

## 1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch ON.
- Check voltage between main power window and door lock/unlock switch connector and ground.

Terminals		Key position	Voltage (V) (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal		
D7	4	Lock	0
		Neutral/Unlock	5
	6	Unlock	0
		Neutral/Lock	5



Is the measurement value within the specification?

- YES >> Replace main power window and door lock/unlock switch. After that, refer to [PWC-75. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).  
 NO >> GO TO 2

## 2. CHECK DOOR KEY CYLINDER SIGNAL CIRCUIT




# DOOR KEY CYLINDER SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]

## < COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front door lock assembly LH (key cylinder switch).
3. Check continuity between main power window and door lock/unlock switch connector (A) and front door lock assembly LH (key cylinder switch) connector (B).



Main power window and door lock/unlock switch connector	Terminal	Front door lock assembly LH (key cylinder switch) connector	Terminal	Continuity
D7 (A)	4	D10 (B)	6	Yes
	6		5	

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D7 (A)	4	Ground	No
	6		

Is the inspection result normal?

- YES >> GO TO 3  
 NO >> Repair or replace harness.


### 3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH (key cylinder switch) connector and ground.

Front door lock assembly LH (key cylinder switch) connector	Terminal	Ground	Continuity
D10	4	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4  
 NO >> Repair or replace harness.



### 4. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [PWC-97, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).  
 NO >> Replace front door lock assembly LH (door key cylinder switch). After that, refer to [PWC-98, "Special Repair Requirement"](#).

## Component Inspection

INFOID:000000003071247

### COMPONENT INSPECTION

#### 1. CHECK DOOR KEY CYLINDER SWITCH


# DOOR KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Check front door lock assembly LH (key cylinder switch).

Terminal		Key position	Continuity
Front door lock assembly LH (key cylinder switch) connector			
5	4	Unlock	Yes
		Neutral/Lock	No
6		Lock	Yes
		Neutral/Unlock	No



Is the inspection result normal?

YES >> Key cylinder switch is OK.

NO >> Replace front door lock assembly LH (key cylinder switch). After that, refer to [PWC-98, "Special Repair Requirement"](#).

## Special Repair Requirement

INFOID:000000003071248

### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# POWER WINDOW SERIAL LINK

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

## POWER WINDOW SERIAL LINK

### POWER WINDOW MAIN SWITCH

#### POWER WINDOW MAIN SWITCH : Description

INFOID:000000003071249

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

#### POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000003071250

##### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [SEC-20, "COMMON ITEM : CONSULT-III Function"](#).

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-99, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

#### POWER WINDOW MAIN SWITCH : Diagnosis Procedure


INFOID:000000003071251



##### Power Window Serial Link Check

##### 1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Remove Intelligent Key, and close front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".



# POWER WINDOW SERIAL LINK

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

Terminal (+)		Terminal (-)	Signal (Reference value)
BCM connector	Terminal		
M18	40	Ground	<p>PIIA1297E</p>


Is the inspection result normal?

- YES >> Power window serial link is OK.  
 NO >> GO TO 2

## 2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM and main power window and door lock/unlock switch.
- Check continuity between BCM connector (A) and main power window and door lock/unlock switch connector (B).

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M18 (A)	40	D7 (B)	14	Yes



- Check continuity between BCM connector (A) and ground.

BCM connector	Terminal	Ground	Continuity
M18 (A)	40		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-75. "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

- NO >> Repair or replace harness.

## FRONT POWER WINDOW SWITCH

### FRONT POWER WINDOW SWITCH : Description

INFOID:000000003071252

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

### FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000003071253

#### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

# POWER WINDOW SERIAL LINK

[LH&RH FRONT WINDOW ANTI-PINCH]

< COMPONENT DIAGNOSIS >

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [SEC-20, "COMMON ITEM : CONSULT-III Function"](#).

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-101, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).


## FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000003071254

### Power Window Serial Link Check

#### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

- Remove Intelligent Key, and close the front door LH and RH.
- Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
- Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".



Terminal (+)		Terminal (-)	Signal (Reference value)
BCM connector	Terminal		
M18	40	Ground	

Is the inspection result normal?


YES >> Power window serial link is OK.

NO >> GO TO 2

#### 2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M18 (A)	40	D105 (B)	16	Yes



- Check continuity between BCM connector (A) and ground.

## POWER WINDOW SERIAL LINK

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

BCM connector	Terminal	Ground	Continuity
M18 (A)	40		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60, "Removal and Installation"](#). After that, refer to [PWC-75, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).
- NO >> Repair or replace harness.

# POWER WINDOW LOCK SWITCH

< COMPONENT DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## POWER WINDOW LOCK SWITCH

### Description

INFOID:000000003071255

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

### Component Function Check

INFOID:000000003071256

#### 1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-60. "Removal and Installation"](#). After that, refer to [PWC-103. "Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

### Special Repair Requirement

INFOID:000000003071257

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)

[LH&RH FRONT WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000003071258

#### VALUES ON THE DIAGNOSIS TOOL

##### CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
DOOR SW-DR	Front door LH closed	OFF
	Front door LH opened	ON
DOOR SW-AS	Front door RH closed	OFF
	Front door RH opened	ON
KEY CYL LK-SW	Other than front door key cylinder LH LOCK position	OFF
	Front door key cylinder LH LOCK position	ON
KEY CYL UN-SW	Other than front door key cylinder LH UNLOCK position	OFF
	Front door key cylinder LH UNLOCK position	ON
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	OFF

#### TERMINAL LAYOUT

Refer to [BCS-50, "Terminal Layout"](#).

#### PHYSICAL VALUES

Refer to [BCS-51, "Physical Values"](#).



# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

## POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000003071259

TERMINAL LAYOUT



PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
1 (G/B)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage
2 (W/B)	Ground	Encoder ground	—	—	0
3 (G/O)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage
4 (L/B)	Ground	Door key cylinder switch LH LOCK signal	Input	Key position (Neutral → Locked)	5 → 0
5 (G/R)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
6 (L/R)	Ground	Door key cylinder switch LH UNLOCK signal	Input	Key position (Neutral → Unlocked)	5 → 0
7 (G/W)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (L/R)	11	Front door power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
9 (G/W)	2	Encoder pulse signal 2	Input	When power window motor operates.	

JMKIA0070GB



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

## [LH&RH FRONT WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
10 (L/W)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When front LH or RH door is opened during retained power operation.	0
11 (L/B)	8	Front door power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage
13 (G/Y)	2	Encoder pulse signal 1	Input	When power window motor operates.	 <p style="text-align: right; font-size: small;">JMKIA0070GB</p>
14 (Y/G)	Ground	Power window serial link	Input/ Output	IGN SW ON or power window timer operating.	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p>
15 (G/R)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
17 (B)	Ground	Ground	—	—	0
19 (R/Y)	Ground	Battery power supply	Input	—	Battery voltage

# POWER WINDOW MAIN SWITCH


[LH&RH FRONT WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

## Wiring Diagram

INFOID:000000003071260

### POWER WINDOW SYSTEM-WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC


# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM CONNECTORS-WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	82G	Color of Wire	W/B	Signal Name	—
--------------	-----	---------------	-----	-------------	---

Terminal No.	7N	Color of Wire	Y/R	Signal Name	—
--------------	----	---------------	-----	-------------	---

Terminal No.	17J	Color of Wire	SB	Signal Name	—
93J	L/W	—	—	—	—
94J	G/B	—	—	—	—
95J	G/O	—	—	—	—

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	B	Signal Name	—
10	G/R	—	—	—	—
11	G/O	—	—	—	—
12	L/W	—	—	—	—

Terminal No.	1	Color of Wire	L/W	Signal Name	—
3	G/R	—	—	—	—
7	G/B	—	—	—	—
10	R/B	—	—	—	—

Terminal No.	2	Color of Wire	G/W	Signal Name	—
3	G/B	—	—	—	—
7	R/W	—	—	—	—


AWKIA0560GB

# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	Y/G	—

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R/Y	—
5	B	—
8	Y/G	—

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L
2	R/Y	P/W_POWER_SUPPL_Y_PERM
3	L/W	POWER_WINDOW_POWER_SUPPLY (RAP)

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	Y/R	BAT_BCM_FUSE
13	B	GND1
15	Y/L	ACC_LED

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
32	R/B	AS_DOOR_SW
40	Y/G	PW_K-LINE
42	R	S/L_LOCK_LED
58	SB	DR_DOOR_SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
81	LG	IGN_ON_LED

ALKIA0189GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	—

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	R/B	DOOR SW (AS)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/W	—
3	G/B	—
7	R/Y	—
8	B	—
10	G/R	—
11	G/O	—
12	L/W	—

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	Y/G	—

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/B	RL_UP
2	W/B	ENCODER_GND
3	G/O	RL_DOWN
4	L/B	LOCK
5	G/R	RR_DOWN
6	L/R	UNLOCK
7	G/W	RR_UP
8	L/R	AS_UP
9	G/W	ENCODER_SIG2
10	L/W	IGN
11	L/B	AS_DOWN
13	G/Y	ENCODER_SIG1
14	Y/G	COM
15	G/R	ENCODER_POWER

Connector No.	D8
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	GND
19	R/Y	BAT

AWKIA0562GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R/Y	—
5	B	—
8	Y/G	—

Connector No.	D10
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW_
6	L/B	DOOR_KEY/C_LOCK_SW


Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—
3	G/W	—
4	G/R	—
5	G/Y	—
6	W/B	—

Terminal No.	Color of Wire	Signal Name
3	W/B	GND
4	G/R	ENCODER POWER
8	L/R	UP
9	L/B	DOWN
10	R/Y	BATT
11	B	GND
12	G/Y	ENCODER SIG1
15	G/W	ENCODER SIG2
16	Y/G	COM

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—
3	G/W	—
4	G/R	—
5	G/Y	—
6	W/B	—

AWKIA0563GB




# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/B	UP
3	G/O	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/B	—
4	G/O	—
6	B	—
8	L/W	—

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/W	UP
3	G/R	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/W	—
4	G/R	—
6	B	—
8	L/W	—

## Fail Safe

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

ALKIA0193GB

INFOID:000000003071261

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER WINDOW MAIN SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

# FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS >


[LH&RH FRONT WINDOW ANTI-PINCH]

## FRONT POWER WINDOW SWITCH

Reference Value

INFOID:000000003071262

### TERMINAL LAYOUT



### PHYSICAL VALUES

#### POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
3 (W/B)	Ground	Encoder ground	—	—	0
4 (G/R)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	10
8 (L/R)	9	Power window motor UP signal	Output	When power window motor is UP at operated.	Battery voltage
9 (L/B)	8	Power window motor DOWN signal	Output	When power window motor is DOWN at operated.	Battery voltage
10 (R/Y)	Ground	Battery power supply	Input	—	Battery voltage
11 (B)	Ground	Ground	—	—	0
12 (G/Y)	3	Encoder pulse signal 1	Input	When power window motor operates.	

JMKIA0070GB



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# FRONT POWER WINDOW SWITCH

**[LH&RH FRONT WINDOW ANTI-PINCH]**

< ECU DIAGNOSIS >

Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
15 (G/W)	3	Encoder pulse signal 2	Input	When power window motor operates.	 <p style="text-align: right; font-size: small;">JMkia0070GB</p>
16 (Y/G)	Ground	Power window serial link	Input/ Output	IGN SW ON or power window timer operating.	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p>

# FRONT POWER WINDOW SWITCH


[LH&RH FRONT WINDOW ANTI-PINCH]

< ECU DIAGNOSIS >

## Wiring Diagram

INFOID:000000003304475

### POWER WINDOW SYSTEM-WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH



AWKWA0201GI

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PWC


# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM CONNECTORS-WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH


Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	82G	Color of Wire	W/B	Signal Name	—
--------------	-----	---------------	-----	-------------	---

Terminal No.	7N	Color of Wire	Y/R	Signal Name	—
--------------	----	---------------	-----	-------------	---

Terminal No.	17J	Color of Wire	SB	Signal Name	—
Terminal No.	93J	Color of Wire	L/W	Signal Name	—
Terminal No.	94J	Color of Wire	G/B	Signal Name	—
Terminal No.	95J	Color of Wire	G/O	Signal Name	—

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	B	Signal Name	—
Terminal No.	10	Color of Wire	G/R	Signal Name	—
Terminal No.	11	Color of Wire	G/O	Signal Name	—
Terminal No.	12	Color of Wire	L/W	Signal Name	—

Terminal No.	1	Color of Wire	L/W	Signal Name	—
Terminal No.	3	Color of Wire	G/R	Signal Name	—
Terminal No.	7	Color of Wire	G/B	Signal Name	—
Terminal No.	10	Color of Wire	R/B	Signal Name	—

Terminal No.	2	Color of Wire	G/W	Signal Name	—
Terminal No.	3	Color of Wire	G/B	Signal Name	—
Terminal No.	7	Color of Wire	R/W	Signal Name	—


AWKIA0560GB

# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	Y/G	—

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R/Y	—
5	B	—
8	Y/G	—

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W/B	BAT_POWER_F/L
2	R/Y	P/W_POWER_SUPPL_Y_PERM
3	L/W	POWER_WINDOW_POWER_SUPPLY (RAP)

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	Y/R	BAT_BCM_FUSE
13	B	GND1
15	Y/L	ACC_LED

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
32	R/B	AS_DOOR_SW
40	Y/G	PW_K-LINE
42	R	S/L_LOCK_LED
58	SB	DR_DOOR_SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
81	LG	IGN_ON_LED

ALKIA0189GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	—

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE






# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	R/B	DOOR SW (AS)

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G/W	—
3	G/B	—
7	R/Y	—
8	B	—
10	G/R	—
11	G/O	—
12	L/W	—

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	Y/G	—

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/B	RL_UP
2	W/B	ENCODER_GND
3	G/O	RL_DOWN
4	L/B	LOCK
5	G/R	RR_DOWN
6	L/R	UNLOCK
7	G/W	RR_UP
8	L/R	AS_UP
9	G/W	ENCODER_SIG2
10	L/W	IGN
11	L/B	AS_DOWN
13	G/Y	ENCODER_SIG1
14	Y/G	COM
15	G/R	ENCODER_POWER

Connector No.	D8
Connector Name	MAIN POWER WINDOW AND LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	GND
19	R/Y	BAT

AWKIA0562GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R/Y	—
5	B	—
8	Y/G	—

Connector No.	D10
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	GND
5	L/R	DOOR_KEY/C_UNLOCK_SW_
6	L/B	DOOR_KEY/C_LOCK_SW_

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—
3	G/W	—
4	G/R	—
5	G/Y	—
6	W/B	—

Terminal No.	Color of Wire	Signal Name
3	W/B	GND
4	G/R	ENCODER POWER
8	L/R	UP
9	L/B	DOWN
10	R/Y	BATT
11	B	GND
12	G/Y	ENCODER SIG1
15	G/W	ENCODER SIG2
16	Y/G	COM

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	L/R	—
3	G/W	—
4	G/R	—
5	G/Y	—
6	W/B	—


AWKIA0563GB

# FRONT POWER WINDOW SWITCH

[LH&RH FRONT WINDOW ANTI-PINCH]


< ECU DIAGNOSIS >

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D203
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/B	UP
3	G/O	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/B	—
4	G/O	—
6	B	—
8	L/W	—

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L/R	UP
2	—	—
3	L/B	DOWN
4	—	—
5	—	—
6	—	—

Connector No.	D303
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	IGN
2	G/W	UP
3	G/R	DOWN
4	L/B	DOWN
5	L/R	UP
6	—	—
7	B	GND
8	—	—

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G/W	—
4	G/R	—
6	B	—
8	L/W	—

## Fail Safe

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

ALKIA0193GB

INFOID:0000000003071264

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

## SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

### Diagnosis Procedure

INFOID:000000003071265

#### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.  
Refer to [BCS-41, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.  
Refer to [PWC-71, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.  
Refer to [PWC-71, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.  
Refer to [PWC-71, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

---

## DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071266

#### 1. CHECK FRONT POWER WINDOW MOTOR LH

---

Check front power window motor LH.

Refer to [PWC-81, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071267

#### 1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-76, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-100, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-83, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

---

## REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071268

#### 1. CHECK REAR POWER WINDOW SWITCH LH

---

Check rear power window switch LH.

Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW MOTOR LH

---

Check rear power window motor LH.

Refer to [PWC-84, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).



# REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071269

#### 1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-78, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-86, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

# ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003071270

#### 1. PERFORM INITIALIZATION PROCEDURE

---

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK DOOR WINDOW SLIDING PART

---

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK ENCODER CIRCUIT

---

Check encoder circuit.

Refer to [PWC-88, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

**ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)**  
< SYMPTOM DIAGNOSIS > **[LH&RH FRONT WINDOW ANTI-PINCH]**

**ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)**

Diagnosis Procedure

INFOID:000000003071271

**1. PERFORM INITIALIZATION PROCEDURE**

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

**2. CHECK DOOR WINDOW SLIDING PART**

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

**3. CHECK ENCODER CIRCUIT**

Check encoder circuit.

Refer to [PWC-90, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003071272

#### 1. PERFORM INITIALIZATION PROCEDURE

---

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK ENCODER

---

Check encoder.

Refer to [PWC-88, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PASSENGER SIDE)

### Diagnosis Procedure

INFOID:000000003071273

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK ENCODER

Check encoder.

Refer to [PWC-90, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

### Diagnosis Procedure

INFOID:000000003071274

#### 1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [PWC-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

# DOES NOT OPERATE BY KEY CYLINDER SWITCH

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## DOES NOT OPERATE BY KEY CYLINDER SWITCH

### Diagnosis Procedure

INFOID:000000003071275

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-64, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check front door lock assembly LH (key cylinder switch).

Refer to [PWC-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

---

## KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003071276

#### 1. CHECK INTELLIGENT KEY FUNCTION

---

Check Intelligent Key function.

Refer to [DLK-112, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-85, "Removal and Installation"](#).



# POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH&RH FRONT WINDOW ANTI-PINCH]

## POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

### Diagnosis Procedure

INFOID:000000003071277

#### 1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-60, "Removal and Installation"](#). After that, [PWC-75, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003071278

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# PRE-INSPECTION FOR DIAGNOSTIC

< ON-VEHICLE MAINTENANCE >

[LH&RH FRONT WINDOW ANTI-PINCH]

## ON-VEHICLE MAINTENANCE

### PRE-INSPECTION FOR DIAGNOSTIC

#### Basic Inspection

INFOID:000000003071279

#### BASIC INSPECTION

##### 1. INSPECTION START

1. Check the service history.
2. Check the following parts.
  - Fuse/fusible link blown.
  - Poor connection, open or short circuit of harness connector.
  - Battery voltage.

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace the malfunctioning parts.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

< ON-VEHICLE REPAIR >

[LH&RH FRONT WINDOW ANTI-PINCH]

## ON-VEHICLE REPAIR


### POWER WINDOW MAIN SWITCH

#### Removal and Installation

INFOID:000000003071280

#### REMOVAL

1. Remove the power window main switch finisher (2).  
Refer to [INT-11. "Removal and Installation"](#).
2. Power window main switch (1) is removed from power window main switch finisher (2) using flat-head screw driver (A) etc.


 : Pawl

#### CAUTION:

**Do not fold the pawl of power window main switch finisher.**

#### NOTE:

The same procedure is also performed for power window and door lock/unlock switch RH and rear power window switch (LH & RH).



#### INSTALLATION

Install in the reverse order of removal.