

# SECTION **PWC**

## POWER WINDOW CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

### CONTENTS

<p><b>BASIC INSPECTION</b> ..... 4</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> ..... 4</p> <p style="padding-left: 20px;">WorkFlow .....4</p> <p><b>INSPECTION AND ADJUSTMENT</b> ..... 5</p> <p><b>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL</b> .....5</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description .....5</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement .....5</p> <p><b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....5</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....5</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....6</p> <p><b>FUNCTION DIAGNOSIS</b> ..... 7</p> <p><b>POWER WINDOW SYSTEM</b> ..... 7</p> <p style="padding-left: 20px;">System Diagram .....7</p> <p style="padding-left: 20px;">System Description .....7</p> <p style="padding-left: 20px;">Component Parts Location .....9</p> <p style="padding-left: 20px;">Component Description .....9</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> .....11</p> <p><b>COMMON ITEM</b> .....11</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) ..... 11</p> <p><b>RETAINED PWR</b> .....12</p> <p style="padding-left: 20px;">RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR) ..... 12</p> <p><b>COMPONENT DIAGNOSIS</b> .....13</p> <p><b>POWER SUPPLY AND GROUND CIRCUIT</b> .....13</p>	<p><b>BCM</b> .....13</p> <p style="padding-left: 20px;">BCM : Diagnosis Procedure .....13</p> <p><b>POWER WINDOW MAIN SWITCH</b> .....13</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Diagnosis Procedure .....13</p> <p><b>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)</b> .....14</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure .....14</p> <p><b>REAR POWER WINDOW SWITCH</b> .....15</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Diagnosis Procedure .....15</p> <p><b>REAR POWER WINDOW SWITCH</b> .....17</p> <p style="padding-left: 20px;">Description .....17</p> <p style="padding-left: 20px;">Component Function Check .....17</p> <p style="padding-left: 20px;">Diagnosis Procedure .....17</p> <p style="padding-left: 20px;">Component Inspection .....18</p> <p><b>POWER WINDOW MOTOR</b> .....19</p> <p><b>DRIVER SIDE</b> .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Description .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Function Check .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Diagnosis Procedure .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Inspection .....20</p> <p><b>PASSENGER SIDE</b> .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Description .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Function Check .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Diagnosis Procedure .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Inspection .....21</p> <p><b>REAR LH</b> .....22</p> <p style="padding-left: 20px;">REAR LH : Description .....22</p> <p style="padding-left: 20px;">REAR LH : Component Function Check .....22</p> <p style="padding-left: 20px;">REAR LH : Diagnosis Procedure .....22</p> <p style="padding-left: 20px;">REAR LH : Component Inspection .....23</p>
---	--

PWC

<b>REAR RH</b> .....	<b>23</b>	<b>NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH</b> .....	<b>97</b>
REAR RH : Description .....	23	Diagnosis Procedure .....	97
REAR RH : Component Function Check .....	23	<b>DRIVER SIDE POWER WINDOW DOES NOT OPERATE</b> .....	<b>98</b>
REAR RH : Diagnosis Procedure .....	24	Diagnosis Procedure .....	98
REAR RH : Component Inspection .....	25	<b>FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE</b> .....	<b>99</b>
<b>DOOR SWITCH</b> .....	<b>26</b>	<b>POWER WINDOW MAIN SWITCH IS OPERATED... POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure</b> .....	<b>99</b>
Description .....	26	<b>WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED</b> .....	<b>99</b>
Component Function Check .....	26	WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED : Diagnosis Procedure .....	99
Diagnosis Procedure .....	26	<b>REAR LH SIDE POWER WINDOW DOES NOT OPERATE</b> .....	<b>100</b>
Component Inspection .....	27	<b>WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH</b> .....	<b>100</b>
<b>ENCODER CIRCUIT</b> .....	<b>28</b>	WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH : Diagnosis Procedure .....	100
<b>DRIVER SIDE</b> .....	<b>28</b>	<b>WITH REAR POWER WINDOW SWITCH LH ONLY</b> .....	<b>100</b>
DRIVER SIDE : Description .....	28	WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure .....	100
DRIVER SIDE : Component Function Check .....	28	<b>REAR RH SIDE POWER WINDOW DOES NOT OPERATE</b> .....	<b>101</b>
DRIVER SIDE : Diagnosis Procedure .....	28	<b>WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH</b> .....	<b>101</b>
<b>PASSENGER SIDE</b> .....	<b>30</b>	WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Diagnosis Procedure .....	101
PASSENGER SIDE : Description .....	30	<b>WITH REAR POWER WINDOW SWITCH RH ONLY</b> .....	<b>101</b>
PASSENGER SIDE : Component Function Check .....	30	WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure .....	101
PASSENGER SIDE : Diagnosis Procedure .....	30	<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)</b> .....	<b>102</b>
<b>DOOR KEY CYLINDER SWITCH</b> .....	<b>33</b>	Diagnosis Procedure .....	102
Description .....	33	<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)</b> .....	<b>103</b>
Component Function Check .....	33	Diagnosis Procedure .....	103
Diagnosis Procedure .....	33	<b>POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY</b> .....	<b>104</b>
Component Inspection .....	34	Diagnosis Procedure .....	104
<b>POWER WINDOW SERIAL LINK</b> .....	<b>35</b>		
Description .....	35		
Component Function Check .....	35		
Diagnosis Procedure .....	35		
<b>POWER WINDOW SYSTEM</b> .....	<b>37</b>		
Wiring Diagram - POWER WINDOW SYSTEM - ...	37		
<b>ECU DIAGNOSIS</b> .....	<b>43</b>		
<b>BCM (BODY CONTROL MODULE)</b> .....	<b>43</b>		
Reference Value .....	43		
Wiring Diagram - BCM - .....	67		
Fail-safe .....	73		
DTC Inspection Priority Chart .....	75		
DTC Index .....	77		
<b>POWER WINDOW MAIN SWITCH</b> .....	<b>79</b>		
Reference Value .....	79		
Wiring Diagram - POWER WINDOW SYSTEM - ...	81		
Fail Safe .....	86		
<b>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)</b> .....	<b>88</b>		
Reference Value .....	88		
Wiring Diagram - POWER WINDOW SYSTEM - ...	90		
Fail Safe .....	95		
<b>SYMPTOM DIAGNOSIS</b> .....	<b>97</b>		

<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)</b> .....	105	Diagnosis Procedure .....	105	
<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PASSENGER SIDE)</b> .....	106	Diagnosis Procedure .....	106	
<b>DOES NOT OPERATE BY KEY CYLINDER SWITCH</b> .....	107	Diagnosis Procedure .....	107	
<b>KEYLESS POWER WINDOW DOWN DOES NOT OPERATE</b> .....	108	Diagnosis Procedure .....	108	
<b>POWER WINDOW LOCK SWITCH DOES NOT FUNCTION</b> .....	109	Diagnosis Procedure .....	109	
		<b>POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE</b> .....	110	
		Diagnosis Procedure .....	110	
		<b>PRECAUTION</b> .....	111	
		<b>PRECAUTIONS</b> .....	111	
		Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	111	
		Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....	111	
		<b>ON-VEHICLE REPAIR</b> .....	112	
		<b>POWER WINDOW MAIN SWITCH</b> .....	112	
		Exploded View .....	112	
		Removal and Installation .....	112	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

**PWC**

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

WorkFlow

INFOID:000000003573452

DETAILED FLOW

#### 1.OBTAIN INFORMATION ABOUT SYMPTOM

---

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

#### 2.REPRODUCE THE MALFUNCTION INFORMATION

---

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

#### 3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

---

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

#### 4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

---

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

#### 5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

---

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

#### 6.FINAL CHECK

---

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 3.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000003573453

When the negative terminal of battery is disconnected, the initialization is necessary.

If any of the following operations are performed, the initialization is necessary as well as when the negative terminal of battery is disconnected.

- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000003573454

#### INITIALIZATION PROCEDURE

1. Disconnect battery negative terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.
5. Initializing procedure is completely.
6. Inspect anti-pinch function.

#### CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
  2. Place a piece of wood near fully closed position.
  3. Close door glass completely with AUTO-UP.
- Check that glass lowers for approximately 150 mm (5.9 in) or 2 seconds without pinching piece of wood and stops.
  - Check that glass does not rise when operating the power window main switch while lowering.

#### **CAUTION:**

- **Perform initial setting when auto-up operation or anti-pinch function does not operate normally.**
- **Check that AUTO-UP operates before inspection when system initialization is performed.**
- **Do not check with hands and other body parts because they may be pinched. Do not get pinched.**
- **It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-86, "Fail Safe"](#)**
- **Finish initial setting. Otherwise, next operation cannot be done.**

1. Auto-up operation
2. Anti-pinch function

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000003729875

When the control unit is replace, the initialization is necessary.

If any of the following operations are performed, the initialization is necessary as well as when the control unit is disconnected.

- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or the battery fuse is blown.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# INSPECTION AND ADJUSTMENT

## < BASIC INSPECTION >

---

- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Disconnection and connection of battery negative terminal.
- Removal and installation of glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000003729876

### INITIALIZATION PROCEDURE

1. Disconnect battery negative terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.
5. Initializing procedure is completely.
6. Inspect anti-pinch function.

### CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
  2. Place a piece of wood near fully closed position.
  3. Close door glass completely with AUTO-UP.
- Check that glass lowers for approximately 150 mm (5.9 in) or 2 seconds without pinching piece of wood and stops.
  - Check that glass does not rise when operating the power window main switch while lowering.

#### **CAUTION:**

- **Perform initial setting when auto-up operation or anti-pinch function does not operate normally.**
  - **Check that AUTO-UP operates before inspection when system initialization is performed.**
  - **Do not check with hands and other body parts because they may be pinched. Do not get pinched.**
  - **It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-86, "Fail Safe"](#)**
  - **Finish initial setting. Otherwise, next operation cannot be done.**
1. Auto-up operation
  2. Anti-pinch function

# POWER WINDOW SYSTEM


< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS

### POWER WINDOW SYSTEM

#### System Diagram

INFOID:000000003573457



#### System Description

INFOID:000000003573458

##### POWER WINDOW OPERATION

- Power window system is operable during the retained power operation timer after turning ignition switch OFF.
- Power window main switch can open/close all windows.
- Front & rear power window switch can open/close the corresponding windows.

##### POWER WINDOW AUTO-OPERATION (FRONT SIDE)

- AUTO UP/DOWN operation can be performed when power window main switch turns to AUTO.
- Encoder continues detecting the movement of power window motor and output to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Auto function is inoperable in case encoder is malfunctioning.

##### RETAINED POWER OPERATION

Retained power operation is an additional power supply function that enables power window system to operate for 45 seconds even when ignition switch is turned OFF.

##### RETAINED POWER FUNCTION CANCEL CONDITIONS

- Front door CLOSE (door switch OFF) → OPEN (door switch ON).
- When ignition switch is ON again.
- When timer time passes. (45 seconds)

##### POWER WINDOW LOCK

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PWC

L  
M  
N  
O  
P

# POWER WINDOW SYSTEM

## < FUNCTION DIAGNOSIS >

---

### ANTI-PINCH SYSTEM (FRONT SIDE)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.9 in) or 2 seconds when detected.
- Encoder continues detecting the movement of front power window motor and transmits to power window main switch as the encoder pulse signal while front power window motor is operating.
- Resistance is applied to the front power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window main switch controls to lower the window glass for 150 mm (5.9 in) or 2 seconds after it detects encoder pulse signal frequency change.

### OPERATION CONDITION

- When front door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

### NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

### DOOR KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for 1.5 seconds or more to OPEN or CLOSE all power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL during operating.

### OPERATION CONDITION

- Ignition switch OFF.
- Hold door key cylinder to LOCK position for 1.5 seconds or more to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for 1.5 seconds or more to perform OPEN operation of the door glass.

### KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3\* seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed.

- The unlock button is kept pressed more than 15 seconds.
- The ignition switch is turned ON while the power window opening is operated.
- The unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Keyless power window down operation mode can be changed by "PW DOWN SET" mode in "WORK SUPPORT". Refer to [DLK-49. "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

### NOTE:

Use CONSULT-III to change settings.

MODE 1 (3 sec) / MODE 2 (OFF) / MODE 3 (5 sec)




# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000003573459



- |                                       |  |   |
|---------------------------------------|--|---|
| 1. BCM<br>M118, M119, M122, M123      | 2. Front power window motor (driver side)<br>D10 | 3. Rear power window motor LH<br>D52      |
| 4. Power window main switch<br>D8, D9 | 5. Rear power window switch LH<br>D54            | 6. Front door switch (driver side)<br>B16 |
| A. Dash side lower (passenger side)   | B. View with front door finisher removed.        | C. View with rear door finisher removed.  |

## Component Description

INFOID:000000003573460

Component	Function
BCM	<ul style="list-style-type: none"> <li>Supplies the power to power window switch</li> <li>Controls retained power function</li> </ul>
Power window main switch	<ul style="list-style-type: none"> <li>Directly controls all power window motor of all doors</li> <li>Controls anti-pinch operation of power window</li> </ul>
Front power window switch (passenger side)	<ul style="list-style-type: none"> <li>Controls power window motor of front passenger side door</li> <li>Controls anti-pinch operation of power window</li> </ul>
Rear power window switch (LH & RH)	Controls power window motor of rear right and left doors
Front power window motor (driver side)	<ul style="list-style-type: none"> <li>Integrates the encoder and power window motor</li> <li>Starts operating with signals from power window main switch</li> <li>Outputs front power window motor (driver side) rotation as a pulse signal to power window main switch</li> </ul>
Front power window motor (passenger side)	<ul style="list-style-type: none"> <li>Integrates the encoder and power window motor</li> <li>Starts operating with signals from power window main switch &amp; front power window switch (passenger side)</li> <li>Outputs front power window motor (passenger side) rotation as a pulse signal to front power window switch (passenger side)</li> </ul>

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

## POWER WINDOW SYSTEM

### < FUNCTION DIAGNOSIS >

Component	Function
Rear power window motor (LH & RH)	Starts operating with signals from power window main switch & rear power window switch (LH & RH)
Front door switch (front side)	Door open/close condition and input to BCM

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:0000000003703253

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER		×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*			
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
—	TRUNK*		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD) AND IGN COUNTER

Freeze Frame Data

# DIAGNOSIS SYSTEM (BCM)

## < FUNCTION DIAGNOSIS >

The BCM records the following condition at the moment a particular DTC is detected.

- Vehicle Speed
- Odd Trip Meter
- Vehicle Condition (BCM detected condition)

CONSULT screen terms	Description
SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
LOCK>ACC	While turning power supply position from "LOCK" to "ACC"
ACC>ON	While turning power supply position from "ACC" to "IGN"
RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
ACC>OFF	While turning power supply position from "ACC" to "OFF"
OFF>LOCK	While turning power supply position from "OFF" to "LOCK"
OFF>ACC	While turning power supply position from "OFF" to "ACC"
ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
ACC	Power supply position is "ACC" (Ignition switch ACC)
ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)

### IGN Counter

IGN counter indicates the number of times that ignition switch is turned ON after DTC is detected.

- The number is 0 when a malfunction is detected now.
- The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.
- The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

### RETAINED PWR

### RETAINED PWR : CONSULT-III Function (BCM - RETAINED PWR)

INFOID:000000003573462

### Data monitor

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of driver side door switch.
DOOR SW-AS	Indicates [ON/OFF] condition of passenger side door switch.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM

#### BCM : Diagnosis Procedure

INFOID:000000003573463

#### 1.CHECK FUSE AND FUSIBLE LINK

- 1.Turn ignition switch OFF.
- 2.Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	K (40A)
11		10 (10A)

#### Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (Approx.)
BCM			
Connector	Terminal	Ground	Battery voltage
M118	1		
M119	11		

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Existed
M119	13		

#### Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness or connector.

### POWER WINDOW MAIN SWITCH

#### POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000003573464

#### 1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition OFF.
2. Disconnect power window main switch connector.
3. Turn ignition switch ON.
4. Check voltage between power window main switch harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Power window main switch			
Connector	Terminal	Ground	Battery voltage
D8	10		
D9	19		

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

### 2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D9	17		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

### 3.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and power window main switch harness connector.

BCM		Power window main switch		Continuity
Connector	Terminal	Connector	Terminal	
M118	2	D9	19	Existed
	3	D8	10	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M118	2		Not existed
	3		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-84. "Removal and Installation"](#).

NO >> Repair or replace harness.

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

### FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000003573465

#### 1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window switch (passenger side) harness connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Front power window switch (passenger side)			
Connector	Terminal	Ground	Battery voltage
D38	10		

Is the inspection result normal?

YES >> INSPECTION END.

NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front power window switch (passenger side) harness connector.

BCM		Front power window switch (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M118	2	D38	10	Existed

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M118	2		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-84, "Removal and Installation"](#).

NO >> Repair or replace harness.

## REAR POWER WINDOW SWITCH

### REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:0000000003573466

### 1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect rear power window switch connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Rear power window switch			
Connector	Terminal	Ground	Battery voltage
LH	D54		
RH	D74		

Is the inspection result normal?

YES >> INSPECTION END.

NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear power window switch harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

BCM		Rear power window switch		Continuity
Connector	Terminal	Connector	Terminal	
M118	3	LH	D54	Existed
		RH	D74	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M118	3		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-84, "Removal and Installation"](#).

NO >> Repair or replace harness.



# REAR POWER WINDOW SWITCH

< COMPONENT DIAGNOSIS >

## REAR POWER WINDOW SWITCH

### Description

INFOID:000000003573467

Rear power window motor will be operated if rear power window switch is operated.

### Component Function Check

INFOID:000000003573468

### 1. CHECK REAR POWER WINDOW SWITCH FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch is OK.
- NO >> Refer to [PWC-17, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003573469

### 1. CHECK REAR POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window switch connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector and ground.

(+)		Terminal	(-)	Condition	Voltage (V) (Approx.)
Rear power window switch					
Connector					
LH	D54	2	Ground	UP	Battery voltage
		3		DOWN	0
RH	D74			2	UP
		DOWN			Battery voltage
		3		UP	Battery voltage
				DOWN	0
			UP	0	
			DOWN	Battery voltage	

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

### 2. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-18, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace rear power window switch. Refer to [PWC-112, "Removal and Installation"](#).

### 3. CHECK REAR POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and rear power window switch harness connector.

# REAR POWER WINDOW SWITCH

## < COMPONENT DIAGNOSIS >

Power window main switch		Rear power window switch			Continuity
Connector	Terminal	Connector		Terminal	
D8	1	LH	D54	2	Existed
	3			3	
	5	RH	D74	3	
	7			2	

4. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	1		Not existed
	3		
	5		
	7		

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-112, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000003573470

### 1. CHECK REAR POWER WINDOW SWITCH

- Turn ignition switch OFF.
- Disconnect rear power window switch connector.
- Check rear power window switch.

Rear power window switch	Terminal		Rear power window switch condition	Continuity
•D54 (LH) •D74 (RH)	1	5	UP	Existed
	3	4		
	3	4	NEUTRAL	
	2	5		
	1	4	DOWN	
	2	5		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear power window switch. Refer to [PWC-112, "Removal and Installation"](#).

# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

## POWER WINDOW MOTOR DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003573471

Door glass moves UP/DOWN by receiving the signal from power window main switch.

### DRIVER SIDE : Component Function Check

INFOID:000000003573472

#### 1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE) OPERATION

Check front power window motor (driver side) operation with power window main switch.

Is the inspection result normal?

- YES >> Front power window motor (driver side) is OK.  
 NO >> Refer to [PWC-19, "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000003573473

#### 1. CHECK POWER WINDOW MOTOR (DRIVER SIDE) INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect front power window motor (driver side) connector.
- Turn ignition switch ON.
- Check voltage between power window motor (driver side) harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D10	1	Ground	Power window main switch UP	Battery voltage
			Power window main switch DOWN	0
	2		Power window main switch UP	0
			Power window main switch DOWN	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2. CHECK POWER WINDOW MOTOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect power window main switch connector.
- Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	8	D10	2	Existed
	11		1	

- Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	8		Not existed
	11		

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-112, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

### 3.CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

Check front power window motor (driver side).

Refer to [PWC-20, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power window motor (driver side). Refer to [GW-20, "Removal and Installation"](#).

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## DRIVER SIDE : Component Inspection

INFOID:000000003573474

### 1.CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

1. Turn ignition switch OFF.
2. Disconnect front power window motor (driver side) connector.
3. Check motor operate by connecting the battery voltage directly to front power window motor (driver side) connector.

Front power window motor (driver side)			Motor condition
Connector	Terminal		
	(+)	(-)	
D10	1	2	DOWN
	2	1	UP

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front power window motor (driver side). Refer to [GW-20, "Removal and Installation"](#).

## PASSENGER SIDE

### PASSENGER SIDE : Description

INFOID:000000003573475

Door glass moves UP/DOWN by receiving the signal from power window main switch or front power window switch (passenger side).

### PASSENGER SIDE : Component Function Check

INFOID:000000003573476

### 1. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) OPERATION

Check front power window motor (passenger side) operation with power window main switch or front power window switch (passenger side).

Is the inspection result normal?

YES >> Power window motor (passenger side) is OK.

NO >> Refer to [PWC-20, "PASSENGER SIDE : Diagnosis Procedure"](#).

### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000003573477

### 1.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window motor (passenger side) harness connector and ground.

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

(+)		(-)	Condition	Voltage (V) (Approx.)
Front power window motor (passenger side)				
Connector	Terminal			
D40	1	Ground	UP	0
			DOWN	Battery voltage
	2		UP	Battery voltage
			DOWN	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

### 2.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) CIRCUIT

- Turn ignition switch OFF.
- Disconnect front power window switch (passenger side) connector.
- Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D38	9	D40	1	Existed
	8		2	

- Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D38	9		Not existed
	8		

Is the inspection result normal?

YES >> Replace front power window switch (passenger side). [PWC-112, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 3.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check front power window motor (passenger side).

Refer to [PWC-21, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace front power window motor (passenger side). Refer to [GW-20, "Removal and Installation"](#).

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## PASSENGER SIDE : Component Inspection

INFOID:0000000003573478

### 1.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

- Turn ignition switch OFF.
- Disconnect front power window motor (passenger side) connector.
- Check motor operate by connecting the battery voltage directly to front power window motor (passenger side) connector.

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

Front power window motor (passenger side)			Motor condition
Connector	Terminal		
	(+)	(-)	
D40	1	2	DOWN
	2	1	UP

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front power window motor (passenger side). Refer to [GW-20. "Removal and Installation"](#).

## REAR LH

### REAR LH : Description

INFOID:000000003573479

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

### REAR LH : Component Function Check

INFOID:000000003573480

#### 1.CHECK REAR POWER WINDOW MOTOR LH OPERATION

Check rear power window motor LH operation with power window main switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-22. "REAR LH : Diagnosis Procedure"](#)

### REAR LH : Diagnosis Procedure

INFOID:000000003573481

#### 1.CHECK REAR POWER WINDOW MOTOR LH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH harness connector and ground.

(+) Rear power window motor LH		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D52	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector.
3. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D54	4	D52	3	Existed
	5		1	

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

4. Check continuity between rear power window switch LH harness connector and ground.

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D54	4		Not existed
	5		

Is the inspection result normal?

- YES >> Replace rear power window switch LH. Refer to [PWC-112, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-23, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Replace rear power window motor LH. Refer to [GW-26, "Removal and Installation"](#).

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## REAR LH : Component Inspection

INFOID:000000003573482

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW MOTOR LH

- Turn ignition switch OFF.
- Disconnect rear power window motor LH connector.
- Check motor operate by connecting the battery voltage directly to rear power window motor LH connector.

Rear power window motor LH			Motor condition
Connector	Terminal		
	(+)	(-)	
D52	3	1	DOWN
	1	3	UP

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace rear power window motor LH. Refer to [GW-26, "Removal and Installation"](#).

## REAR RH

### REAR RH : Description

INFOID:000000003573483

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch RH.

### REAR RH : Component Function Check

INFOID:000000003573484

#### 1. CHECK REAR POWER WINDOW MOTOR RH OPERATION

Check rear power window motor RH operation with power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.  
 NO >> Refer to [PWC-24, "REAR RH : Diagnosis Procedure"](#).

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

### REAR RH : Diagnosis Procedure

INFOID:000000003573485

#### 1. CHECK REAR POWER WINDOW MOTOR RH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
D72	1	Ground	UP	Battery voltage
			DOWN	0
	3		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector.
3. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D74	4	D72	3	Existed
	5		1	

4. Check continuity between rear power window switch RH harness connector and ground.

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D74	4		Not existed
	5		

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-112, "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.  
Refer to [PWC-25, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace rear power window motor RH. Refer to [GW-26, "Removal and Installation"](#).

#### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END



# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

REAR RH : Component Inspection

INFOID:000000003573486

## COMPONENT INSPECTION

### 1. CHECK REAR POWER WINDOW MOTOR RH

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Check motor operation by connecting the battery voltage directly to rear power window motor RH connector.

Rear power window motor RH		Motor condition	
Connector	Terminal		
	(+)	(-)	
D72	3	1	DOWN
	1	3	UP

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear power window motor RH. Refer to [GW-26, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DOOR SWITCH

< COMPONENT DIAGNOSIS >

## DOOR SWITCH

### Description

INFOID:000000003573487

Detects door open/closed condition.

### Component Function Check

INFOID:000000003573488

### 1.CHECK FUNCTION

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in "Data Monitor" mode with CONSULT-III.

Monitor item	Door condition	Display
DOOR SW-DR	CLOSE → OPEN	OFF → ON
DOOR SW-AS		

Is the inspection result normal?


- YES >> Door switch is OK.  
 NO >> Refer to [PWC-26, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003573489

### 1.CHECK FRONT DOOR SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect malfunction front door switch connector.
- Check signal between malfunction front door switch harness connector and ground with oscilloscope.

(+)			(-)	Voltage (V) (Approx.)
Front door switch				
Connector		Terminal	Ground	
Driver side	B16	2		
Passenger side	B216			

JPMIA0011GB

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

### 2.CHECK DOOR SWITCH CIRCUIT

- Disconnect BCM connector.
- Check continuity between BCM harness connector and malfunction door switch harness connector.

BCM		Front door switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	124	B216	2	Exists
	150	B16		

- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	124		Not exist
	150		

# DOOR SWITCH

## < COMPONENT DIAGNOSIS >

### Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-84, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 3.CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [PWC-27, "Component Inspection"](#).

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunction front door switch. Refer to [DLK-257, "Removal and Installation"](#).

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000003573490

### 1.CHECK FRONT DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunction front door switch connector.
3. Check malfunction front door switch.

(+) Front door switch			(-)	Condition	Continuity
Connector	Terminal				
Driver side	B16	2	Ground part of door switch	Door switch pressed	Not exist
				Door switch released	Exists
Passenger side	B216	2		Door switch pressed	Not exist
				Door switch released	Exists

### Is the inspection result normal?

YES >> Front door switch is OK.

NO >> Replace malfunction front door switch. Refer to [DLK-257, "Removal and Installation"](#).

PWC

# ENCODER CIRCUIT

< COMPONENT DIAGNOSIS >

## ENCODER CIRCUIT DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000003573491

Detects condition of the front power window motor (driver side) operation and transmits to power window main switch as pulse signal.

### DRIVER SIDE : Component Function Check

INFOID:000000003573492

#### 1. CHECK ENCODER OPERATION

Check front driver side door glass perform AUTO open/close operation normally with power window main switch.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-28, "DRIVER SIDE : Diagnosis Procedure"](#)

### DRIVER SIDE : Diagnosis Procedure


INFOID:000000003573493

#### Encoder Circuit Check

##### 1. CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window main switch harness connector and ground with oscilloscope.

Power window main switch		Ground	Signal (Reference value)
Connector	Terminal		Refer to following signal
D8	9		
	13		



Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-112, "Removal and Installation"](#).

NO >> GO TO 2.

##### 2. CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window motor (driver side) connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	9	D10	3	Existed
	13		5	

4. Check continuity between power window main switch harness connector and ground.

# ENCODER CIRCUIT

## < COMPONENT DIAGNOSIS >

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	9		Not existed
	13		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK ENCODER POWER SUPPLY

1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (driver side) harness connector and ground.

Front power window motor (driver side)		Ground	Voltage (V) (Approx.)
Connector	Terminal		
D10	4		Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	2	D10	6	Existed

3. Check continuity between front power window motor (driver side) harness connector and ground.

Front power window motor (driver side)		Ground	Continuity
Connector	Terminal		
D10	6		Not existed

Is the inspection result normal?

YES >> Replace front power window motor. Refer to [GW-20, "Removal and Installation"](#)

NO >> Repair or replace harness or connector.

### 5.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	15	D10	4	Existed

3. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	15		Not existed

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-112, "Removal and Installation"](#).

# ENCODER CIRCUIT

## < COMPONENT DIAGNOSIS >

NO >> Repair or replace harness.

### PASSENGER SIDE

#### PASSENGER SIDE : Description

INFOID:000000003573494

Detects condition of the front power window motor (passenger side) operation and transmits to front power window switch (passenger side) as pulse signal.

#### PASSENGER SIDE : Component Function Check

INFOID:000000003573495

### 1.CHECK ENCODER OPERATION

Check front driver side door glass perform AUTO open/close operation normally with front power window switch (passenger side).

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-30. "PASSENGER SIDE : Diagnosis Procedure"](#)


#### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000003573496

### 1.CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between front power window switch (passenger side) harness connector and ground with oscilloscope.

Front power window switch (passenger side)		Ground	Signal (Reference value)
Connector	Terminal		
D38	12		Refer to following signal
	15		



Is the inspection result normal?

YES >> Replace front power window switch (passenger side). Refer to [PWC-112. "Removal and Installation"](#).

NO >> GO TO 2.

### 2.CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector and front power window motor (passenger side) connector.
3. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D38	12	D40	5	Existed
	15		3	

4. Check continuity between front power window switch (passenger side) harness connector and ground.

# ENCODER CIRCUIT

## < COMPONENT DIAGNOSIS >

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D38	12		
	15		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

### 3.CHECK ENCODER POWER SUPPLY

1. Connect front power window switch (passenger side) connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (passenger side) harness connector and ground.

Front power window motor (passenger side)		Ground	Voltage (V) (Approx.)
Connector	Terminal		
D40	4		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D38	3	D40	6	Existed

3. Check continuity between front power window motor (passenger side) harness connector and ground.

Front power window motor (passenger side)		Ground	Continuity
Connector	Terminal		
D40	6		

Is the inspection result normal?

YES >> Replace front power window motor (passenger side). Refer to [GW-20. "Removal and Installation"](#)

NO >> Repair or replace harness or connector.

### 5.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D38	4	D40	4	Existed

3. Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D38	4		

Is the inspection result normal?

## ENCODER CIRCUIT

### < COMPONENT DIAGNOSIS >

---

- YES >> Replace front power window switch (passenger side). Refer to [PWC-112. "Removal and Installation"](#).
- NO >> Repair or replace harness or connector.



# DOOR KEY CYLINDER SWITCH

< COMPONENT DIAGNOSIS >

## DOOR KEY CYLINDER SWITCH

### Description

INFOID:000000003573497

Power window main switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signals.

### Component Function Check

INFOID:000000003573498

### 1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check ("KEY CYL LK-SW", "KEY CYL UN-SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-48. "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

Monitor item	Condition
KEY CYL LK-SW	Lock : ON
	Neutral / Unlock : OFF
KEY CYL UN-SW	Unlock : ON
	Neutral / Lock : OFF

Is the inspection result normal?

- YES >> Door key cylinder switch is OK.
- NO >> Refer to [PWC-33. "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:000000003573499

### 1. CHECK DOOR KEY CYLINDER SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) (key cylinder switch) connect.
3. Turn ignition switch ON.
4. Check voltage between front door lock assembly (driver side) (key cylinder switch) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Front door lock assembly (driver side) (key cylinder switch)			
Connector	Terminal	Ground	5
D15	5		
	6		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

### 2. CHECK DOOR KEY CYLINDER SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front door lock assembly (driver side) (key cylinder switch) harness connector.

Power window main switch		Front door lock assembly (driver side) (key cylinder switch)		Continuity
Connector	Terminal	Connector	Terminal	
D8	4	D15	6	Existed
	6		5	

4. Check continuity between power window main switch harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DOOR KEY CYLINDER SWITCH

## < COMPONENT DIAGNOSIS >

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	4		
	6		Not existed

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-112, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

### 3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) (key cylinder switch) harness connector and ground.

Front door lock assembly (driver side) (key cylinder switch)		Ground	Continuity
Connector	Terminal		
D15	4		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4.CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly (driver side) (key cylinder switch). Refer to [PWC-34, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Replace front door lock assembly (driver side) (key cylinder switch). Refer to [PWC-34, "Component Inspection"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-38, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000003573500

### COMPONENT INSPECTION

#### 1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) (key cylinder switch) connector.
3. Check front door lock assembly (driver side) (key cylinder switch).

Front door lock assembly (driver side) (key cylinder switch)			Key position	Continuity
Connector	Terminal			
D15	5	4	Unlock	Existed
			Neutral / Lock	Not existed
	6		Lock	Existed
			Neutral / Unlock	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace front door lock assembly (driver side) (key cylinder switch). Refer to [DLK-244, "DOOR LOCK : Removal and Installation"](#).

# POWER WINDOW SERIAL LINK

< COMPONENT DIAGNOSIS >

## POWER WINDOW SERIAL LINK

### Description

INFOID:000000003573501

Power window main switch, front power window switch (passenger side), and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to power window main switch, front power window (passenger side).

- Keyless power window down signal

The signal mentioned below is transmitted from power window main switch to front power window switch (passenger side).

- Passenger side door window operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

### Component Function Check

INFOID:000000003573502

#### 1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT-III. Refer to [DLK-48, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?


- YES >> Power window serial link is OK.  
 NO >> Refer to [PWC-35, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003573503

#### 1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Close doors of driver side and passenger side.
2. Check signal between BCM harness connector and ground with oscilloscope when door lock and unlock switch (driver side and passenger side) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 seconds just after door lock and unlock switch (driver side and passenger side) is turned to "LOCK" or "UNLOCK".

(+)		(-)	Signal (Reference value)
BCM			
Connector	Terminal		
M123	132	Ground	 <p style="text-align: right;">JPMIA0013GB</p>

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 3.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW SERIAL LINK

< COMPONENT DIAGNOSIS >

## 2. CHECK BCM OUTPUT SIGNAL

Check power window serial link ("PW REMOTO DOWN SET") in "ACTIVE TEST" mode with CONSULT-III.

Test item		Description	
POWER WINDOW DOWN	ON	Driver side window and passenger side window	OPEN

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace BCM. Refer to [BCS-84. "Removal and Installation"](#).

## 3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect power window main switch connector and front power window switch (passenger side) connector.
4. Check continuity between BCM connector and power window main switch connector.

BCM		Power window switch			Continuity
Connector	Terminal	Connector		Terminal	
M123	132	Driver side	D8	14	Existed
		Passenger side	D38	16	

5. Check continuity between BCM connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	132		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-84. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-38. "Intermittent Incident"](#).

>> INSPECTION END


POWER WINDOW SYSTEM

< COMPONENT DIAGNOSIS >

POWER WINDOW SYSTEM

Wiring Diagram - POWER WINDOW SYSTEM -

INFOID:000000003757462



2007/10/26

JCKWM1093GI

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# POWER WINDOW SYSTEM

## < COMPONENT DIAGNOSIS >


### POWER WINDOW SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
85	V	-
98	GR	-
100	Y	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8




Terminal No.	Color of Wire	Signal Name [Specification]
11	W	-
12	GR	-
13	Y	-
18	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
7	LG	-
8	R	-
9	W	-
87	GR	-

Connector No.	B216
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8



Terminal No.	Color of Wire	Signal Name [Specification]
11	W	-
12	R	-
13	LG	-
18	B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
3	V	-
7	GR	-
8	W	-
9	O	-
10	BR	-
13	B	-
14	SB	-
15	Y	-

# POWER WINDOW SYSTEM

< COMPONENT DIAGNOSIS >

## POWER WINDOW SYSTEM

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	GR	-
4	V	-
5	O	-
6	Y	-
7	BR	-
8	L	-
9	O	-
10	SB	-
11	G	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED08FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	Y	-
6	V	-


I3	P
I4	V
I5	B

Connector No.	D9
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
18	Y	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
9	V	-
14	B	-
15	Y	-

Connector No.	D10
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	B	-
5	P	-
6	R	-

Connector No.	D40
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	GR	-
5	P	-
6	LG	-

Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	GR	-
8	L	-
9	G	-
10	Y	-
11	B	-
15	O	-
16	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

JCKWM1095G1

# POWER WINDOW SYSTEM

## < COMPONENT DIAGNOSIS >

### POWER WINDOW SYSTEM

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NSB



Terminal No.	Color of Wire	Signal Name [Specification]
11	V	-
12	R	-
13	W	-
18	B	-

Connector No.	D54
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS06FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	V	-
3	R	-
4	L	-
5	G	-
7	B	-

Connector No.	D32
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	RS06FG



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NSB




Terminal No.	Color of Wire	Signal Name [Specification]
11	V	-
12	R	-
13	Y	-
18	B	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2




Terminal No.	Color of Wire	Signal Name [Specification]
7A	R	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TR06FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
9I	W	-

Connector No.	D74
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS06FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	R	-
4	L	-
5	G	-
7	B	-

Connector No.	D72
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	RS06FG



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
3	L	-









JCKW11096G1



# POWER WINDOW SYSTEM

## < COMPONENT DIAGNOSIS >

### POWER WINDOW SYSTEM

<table border="1"> <tr><td>Connector No.</td><td>M5</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS15</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>3</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>R</td><td>-</td></tr> <tr><td>8</td><td>W</td><td>-</td></tr> <tr><td>9</td><td>G</td><td>-</td></tr> <tr><td>10</td><td>L</td><td>-</td></tr> <tr><td>13</td><td>B</td><td>-</td></tr> <tr><td>14</td><td>O</td><td>-</td></tr> <tr><td>15</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M5	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS15	Terminal No.	Color of Wire	Signal Name [Specification]	3	V	-	7	R	-	8	W	-	9	G	-	10	L	-	13	B	-	14	O	-	15	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M6</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH60MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>91</td><td>W</td><td>-</td></tr> </table>	Connector No.	M6	Connector Name	WIRE TO WIRE	Connector Type	TH60MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	91	W	-	<table border="1"> <tr><td>Connector No.</td><td>M7</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH60MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>85</td><td>LG</td><td>-</td></tr> <tr><td>98</td><td>W</td><td>-</td></tr> <tr><td>99</td><td>R</td><td>-</td></tr> <tr><td>100</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M7	Connector Name	WIRE TO WIRE	Connector Type	TH60MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	85	LG	-	98	W	-	99	R	-	100	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M117</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH60MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>7</td><td>W</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> <tr><td>9</td><td>L</td><td>-</td></tr> <tr><td>97</td><td>LG</td><td>-</td></tr> </table>	Connector No.	M117	Connector Name	WIRE TO WIRE	Connector Type	TH60MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	7	W	-	8	G	-	9	L	-	97	LG	-
Connector No.	M5																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS15																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
3	V	-																																																																																								
7	R	-																																																																																								
8	W	-																																																																																								
9	G	-																																																																																								
10	L	-																																																																																								
13	B	-																																																																																								
14	O	-																																																																																								
15	Y	-																																																																																								
Connector No.	M6																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH60MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
91	W	-																																																																																								
Connector No.	M7																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH60MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
85	LG	-																																																																																								
98	W	-																																																																																								
99	R	-																																																																																								
100	Y	-																																																																																								
Connector No.	M117																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH60MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
7	W	-																																																																																								
8	G	-																																																																																								
9	L	-																																																																																								
97	LG	-																																																																																								
<table border="1"> <tr><td>Connector No.</td><td>M118</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>M03FB-LC</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>1</td><td>W</td><td>BAT (F/L)</td></tr> <tr><td>2</td><td>Y</td><td>POWER WINDOW POWER SUPPLY (BAT)</td></tr> <tr><td>3</td><td>O</td><td>POWER WINDOW POWER SUPPLY (RAP)</td></tr> </table>	Connector No.	M118	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	M03FB-LC	Terminal No.	Color of Wire	Signal Name [Specification]	1	W	BAT (F/L)	2	Y	POWER WINDOW POWER SUPPLY (BAT)	3	O	POWER WINDOW POWER SUPPLY (RAP)	<table border="1"> <tr><td>Connector No.</td><td>M119</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>11</td><td>R</td><td>BAT (FUSE)</td></tr> <tr><td>13</td><td>B</td><td>GND</td></tr> </table>	Connector No.	M119	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	NS10FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	11	R	BAT (FUSE)	13	B	GND	<table border="1"> <tr><td>Connector No.</td><td>M122</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FB-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>63</td><td>Y</td><td>KEYLESS TUNER SIGNAL</td></tr> <tr><td>109</td><td>LG</td><td>KEYLESS ENTRY RECEIVER POWER SUPPLY</td></tr> </table>	Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FB-NH	Terminal No.	Color of Wire	Signal Name [Specification]	63	Y	KEYLESS TUNER SIGNAL	109	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	<table border="1"> <tr><td>Connector No.</td><td>M123</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FG-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>124</td><td>LG</td><td>PASSENGER DOOR SW</td></tr> <tr><td>132</td><td>V</td><td>POWER WINDOW SW COMM</td></tr> <tr><td>137</td><td>O</td><td>RECEIVER SENSOR GND</td></tr> <tr><td>150</td><td>LG</td><td>DRIVER DOOR SW</td></tr> </table>	Connector No.	M123	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FG-NH	Terminal No.	Color of Wire	Signal Name [Specification]	124	LG	PASSENGER DOOR SW	132	V	POWER WINDOW SW COMM	137	O	RECEIVER SENSOR GND	150	LG	DRIVER DOOR SW																		
Connector No.	M118																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	M03FB-LC																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
1	W	BAT (F/L)																																																																																								
2	Y	POWER WINDOW POWER SUPPLY (BAT)																																																																																								
3	O	POWER WINDOW POWER SUPPLY (RAP)																																																																																								
Connector No.	M119																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	NS10FW-CS																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
11	R	BAT (FUSE)																																																																																								
13	B	GND																																																																																								
Connector No.	M122																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FB-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
63	Y	KEYLESS TUNER SIGNAL																																																																																								
109	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY																																																																																								
Connector No.	M123																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FG-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
124	LG	PASSENGER DOOR SW																																																																																								
132	V	POWER WINDOW SW COMM																																																																																								
137	O	RECEIVER SENSOR GND																																																																																								
150	LG	DRIVER DOOR SW																																																																																								

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC


JCKWM1097GI

# POWER WINDOW SYSTEM

## < COMPONENT DIAGNOSIS >

**POWER WINDOW SYSTEM**

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	THRMW-C515



Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	-
14	B	-
15	Y	-

JCKWM1098Gf

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000003773244

#### VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V	A
	Dark outside of the vehicle	Close to 0 V	
REQ SW -DR	Driver door request switch is not pressed	Off	B
	Driver door request switch is pressed	On	
REQ SW -AS	Passenger door request switch is not pressed	Off	C
	Passenger door request switch is pressed	On	
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	D
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off	D
REQ SW -BD/TR	Back door request switch is not pressed	Off	E
	Back door request switch is pressed	On	
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off	F
	Push-button ignition switch (push switch) is pressed	On	
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off	G
	Ignition switch in ON position	On	
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	G
BRAKE SW 1	The brake pedal is not depressed	On	H
	The brake pedal is depressed	Off	
DETE/CANCL SW	Selector lever in P position	Off	I
	Selector lever in any position other than P	On	
SFT PN/N SW	Selector lever in any position other than P and N	Off	J
	Selector lever in P or N position	On	
S/L -LOCK	Steering is locked	Off	J
	Steering is unlocked	On	
S/L -UNLOCK	Steering is unlocked	Off	PWC
	Steering is locked	On	
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off	L
	Ignition switch in ON position	On	
UNLK SEN -DR	Driver door is unlocked	Off	M
	Driver door is locked	On	
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off	N
	Push-button ignition switch (push-switch) is pressed	On	
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off	N
	Ignition switch in ON position	On	
DETE SW -IPDM	Selector lever in P position	Off	O
	Selector lever in any position other than P	On	
SFT PN -IPDM	Selector lever in any position other than P and N	Off	P
	Selector lever in P or N position	On	
SFT P -MET	Selector lever in any position other than P	Off	
	Selector lever in P position	On	
SFT N -MET	Selector lever in any position other than N	Off	
	Selector lever in N position	On	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L UNLK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L RELAY-REQ	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Ignition switch in ACC or ON position	Reset
	Ignition switch in OFF position	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	DONE
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	DONE
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	DONE
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	DONE

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet	A
	The key ID that the key slot receives accords with the first key ID registered to BCM.	DONE	B
TP 4	The ID of fourth key is not registered to BCM	Yet	C
	The ID of fourth key is registered to BCM	DONE	
TP 3	The ID of third key is not registered to BCM	Yet	D
	The ID of third key is registered to BCM	DONE	
TP 2	The ID of second key is not registered to BCM	Yet	E
	The ID of second key is registered to BCM	DONE	
TP 1	The ID of first key is not registered to BCM	Yet	F
	The ID of first key is registered to BCM	DONE	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	G
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	H
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	I
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	J
ID REGST FL1	ID of front LH tire transmitter is registered	DONE	K
	ID of front LH tire transmitter is not registered	Yet	
ID REGST FR1	ID of front RH tire transmitter is registered	DONE	L
	ID of front RH tire transmitter is not registered	Yet	
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE	M
	ID of rear RH tire transmitter is not registered	Yet	
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE	N
	ID of rear LH tire transmitter is not registered	Yet	
WARNING LAMP	Tire pressure indicator OFF	Off	O
	Tire pressure indicator ON	On	
BUZZER	Tire pressure warning alarm is not sounding	Off	P
	Tire pressure warning alarm is sounding	On	

PWC

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >  
 TERMINAL LAYOUT




PHYSICAL VALUES



# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	Battery voltage
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)	Battery voltage
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<p><b>NOTE:</b> When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right;"><small>JSNIA0010GB</small></p>
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON	Battery voltage
					ACC	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: right;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
18 (O)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 <p style="text-align: right;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: right;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
23 (G)	Ground	Back door opening	Output	Back door	OPEN (Back door opener actuator is activated)	Battery voltage
					Other than OPEN (Back door opener actuator is not activated)	0 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 <p style="text-align: right;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
26 (G)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
34 (SB)	Ground	Luggage room antenna 1 (-)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
35 (V)	Ground	Luggage room antenna 1 (+)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
38 (B)	Ground	Rear bumper antenna (-)	Output	When the back door request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Rear bumper antenna (+)	Output	When the back door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
					When Intelligent Key is not in the antenna detection area	
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
61 (W)	Ground	Back door opener request switch	Input	Back door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	<p style="text-align: center;">1.0 V</p>
64 (V)	Ground	Request switch buzzer	Output	Request switch buzzer	Sounding	0 V
					Not sounding	Battery voltage
65 (O)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	<p style="text-align: center;">1.0 V</p>
					Not in stop position	0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
66 (R)	Ground	Back door switch	Input	Back door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				ON (Door open)	0 V
67 (GR)	Ground	Back door opener switch	Input	Back door opener switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				Pressed	0 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				ON (Door open)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				ON (Door open)	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
75 (GR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area	
				When the passenger door request switch is operated with ignition switch OFF	
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	
				When the driver door request switch is operated with ignition switch OFF	
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area	
				When the driver door request switch is operated with ignition switch OFF	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
78 (Y)	Ground	Room antenna (-) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment  JMkia0062GB
					When Intelligent Key is not in the passenger compart- ment  JMkia0063GB
79 (BR)	Ground	Room antenna (+) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment  JMkia0062GB
					When Intelligent Key is not in the passenger compart- ment  JMkia0063GB
80 (GR)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (Built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC 0 V
				ON	Battery voltage



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
83 (Y)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting	 <p style="text-align: right; font-size: small;">JMkia0064GB</p>	
				When operating either button on the key	 <p style="text-align: right; font-size: small;">JMkia0065GB</p>	
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Rear washer switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
90 (P)	Ground	CAN-L	Input/ Output	—	—	
91 (L)	Ground	CAN-H	Input/ Output	—	—	

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 <p style="text-align: center;">6.5 V</p> <p style="text-align: right; font-size: small;">JPMIA0015GB</p>
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	Control device (Detention switch) power supply	Output	—	Battery voltage	
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p style="text-align: center;">1.0 V</p> <p style="text-align: right; font-size: small;">JPMIA0016GB</p>
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p style="text-align: center;">1.0 V</p> <p style="text-align: right; font-size: small;">JPMIA0016GB</p>
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage
106 (W)	Ground	Steering wheel lock unit power supply	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Turn signal switch LH	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch LO	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front washer switch ON	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >







Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right;">1.4 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>
					Rear wiper switch INT (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>
					Any of the conditions below with all switch OFF	 <p style="text-align: right;">1.3 V</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 1.4 V
					Lighting switch PASS	 1.3 V
					Lighting switch 2ND	 1.3 V
					Front wiper switch INT	 1.3 V
					Front wiper switch HI	 1.3 V
					ON	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	OFF	 1.1 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage
					LOCK or UNLOCK	
					For 15 seconds after UNLOCK	Battery voltage
					15 seconds or later after UNLOCK	0 V
113* (P)	Ground	Optical sensor signal	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
				When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Fuse check [Stop lamp switch, ICC brake hold relay (With ICC)]	Input	—	Battery voltage	
118 (P)	Ground	Stop lamp switch (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	Battery voltage
		Stop lamp switch and ICC brake hold relay (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF	0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON	Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	
					UNLOCK status (Unlock switch sensor ON)	0 V
					1.1 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot	Battery voltage	
				When the key is not inserted into key slot	0 V	
122 (V)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0 V
				ACC or ON	Battery voltage	
123 (W)	Ground	IGN feedback signal	Input	Ignition switch	OFF or ACC	0 V
				ON	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (Door open)	0 V
132 (V)	Ground	Power window switch communication	Input/ Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p>	
					Ignition switch OFF or ACC	Battery voltage
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button igni- tion switch illumina- tion	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	<p><b>NOTE:</b> The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMIA0159GB</p>
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
139 (L)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	Standby state  OCC3881D
				When receiving the signal from the transmitter  OCC3880D	
140 (GR)	Ground	Selector lever P/N position signal	Input	Selector lever	P or N position Battery voltage
				Except P and N positions	0 V
141 (G)	Ground	Security indicator signal	Output	Security indicator	ON 0 V
				Blinking  JPMIA0014GB 11.3 V	
				OFF	Battery voltage
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF 0 V
				Lighting switch 1ST	 JPMIA0031GB 10.7 V
				Lighting switch HI	
				Lighting switch 2ND	
Turn signal switch RH					
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4) 0 V
				Front wiper switch HI (Wiper intermittent dial 4)	 JPMIA0032GB 10.7 V
				Rear wiper switch INT (Wiper intermittent dial 4)	
				Any of the conditions below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	
					Front washer switch ON (Wiper intermittent dial 4)	<p style="text-align: right;">JPMIA0033GB</p>	
					Rear wiper switch ON (Wiper intermittent dial 4)		
					Rear washer switch ON (Wiper intermittent dial 4)		
					Any of the conditions below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>		
					10.7 V		
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Front wiper switch INT	<p style="text-align: right;">JPMIA0034GB</p>	
					Front wiper switch LO		
					Lighting switch AUTO		
					10.7 V		
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Front fog lamp switch ON	<p style="text-align: right;">JPMIA0035GB</p>	
					Lighting switch 2ND		
					Lighting switch PASS		
					Turn signal switch LH		
					10.7 V		
149 (W)	Ground	Tire pressure warn- ing check switch	Input	Ignition switch ON	<p style="text-align: right;">JPMIA0011GB</p>	11.8 V	
150 (LG)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	<p style="text-align: right;">JPMIA0011GB</p>	11.8 V
					ON (Door open)	0 V	
151 (G)	Ground	Rear window defog- ger relay	Output	Rear window de- fogger	Active	0 V	
					Not activated	Battery voltage	

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

**NOTE:**

\*: With auto light system

## Wiring Diagram - BCM -

INFOID:000000003773245




(IC) : With ICC  
 (SO) : With sonar system  
 (AV) : With around view monitor  
 (OA) : Without around view monitor

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





\*: This connector is not shown in "Harness Layout".

JCMWM1399G

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

- ◁ NV ▷ : With NAVI
- ◁ ON ▷ : Without NAVI
- ◁ RF ▷ : With sunroof
- ◁ PM ▷ : With automatic drive positioner
- ◁ OP ▷ : Without automatic drive positioner




JCMWM1400G1

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



JCMWM1402GI

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P




# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
23	G	BACK DOOR OPEN OUTPUT
25	G	TURN SIGNAL LH (REAR)
26	G	REAR WIPER OUTPUT

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(TRAP)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANTI-
35	V	LUGGAGE ROOM ANTI+
38	B	REAR BUMPER ANTI-
39	W	REAR BUMPER ANTI+
47	Y	IGN RELAY IPDM E/R CONT
52	SB	STARTER RELAY CONT
61	W	BACK DOOR OPENER REQUEST SW
64	V	REQUEST SW BUZZER
65	O	REAR WIPER STOP POSITION
66	R	BACK DOOR SW
67	GR	BACK DOOR OPENER SW

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSINGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (R/USE)
13	B	GND
14	W	PUSH-BUTTON IGNITION SW ILL GND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)

68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

18	O	TURN SIGNAL LH (FRONT)
19	V	ROOM LAMP TIMER CONTROL

JCMWM1403G



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## BCM (BODY CONTROL MODULE)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	GR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANTI-
79	BR	ROOM ANTI+
80	GR	IMMOBI ANTENNA CONTROL
81	W	IMMOBI ANTENNA SIGNAL
82	R	IGN RELAY (F/B) CONT

83	Y	KEYLESS TIMER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	Y	ON IND
94	V	PUDDLE LAMP CONT
95	O	ACC RELAY CONT
96	GR	A-T DEVICE POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	W	S/L POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	IGN F/B
109	Y	COMBI SW INPUT 4
110	G	COMBI SW INPUT 2
111	Y	HAZARD SW
		S/L COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name [Specification]
113	P	OPTICAL SENSOR
116	SB	FUSE CHECK
118	P	STOP LAMP SW
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
122	V	ACC F/B
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	V	POWER WINDOW SW COMM
133	W	PUSH-BUTTON IGNITION SW ILL POWER
134	GR	LOCK IND

137	O	RECEIVER SENSOR GND
138	Y	RECEIVER SENSOR POWER SUPPLY
139	L	TIRE PRESS RECEIVER SIGNAL
140	GR	SHIFT N/P
141	G	SECURITY INDICATOR OUTPUT
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	TIRE PRESS WARNING CHECK SW
150	LG	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## Fail-safe

**FAIL-SAFE CONTROL BY DTC**  
BCM performs fail-safe control when any DTC is detected.

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals have been received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (battery voltage)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> <li>• Status 1               <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (battery voltage)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2               <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position               <ul style="list-style-type: none"> <li>- Power position: IGN</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- Interlock/PNP switch signal (CAN): OFF</li> </ul> </li> <li>• Status 2               <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (battery voltage)</li> <li>- PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>• BCM steering lock control status</li> <li>• Steering lock condition No. 1 signal status</li> <li>• Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (Battery voltage)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When any of the following conditions is fulfilled <ul style="list-style-type: none"> <li>• Steering lock unit status signal (CAN) is received normally</li> <li>• The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions is fulfilled <ul style="list-style-type: none"> <li>• Steering condition No. 1 signal: LOCK (0V)</li> <li>• Steering condition No. 2 signal: LOCK (Battery voltage)</li> </ul>

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### DTC Inspection Priority Chart

INFOID:000000003773247

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
3	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Priority	DTC
4	<ul style="list-style-type: none"> <li>• B2013: ID DISCORD BCM-S/L</li> <li>• B2014: CHAIN OF S/L-BCM</li> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP SW</li> <li>• B2605: PNP SW</li> <li>• B2606: S/L RELAY</li> <li>• B2607: S/L RELAY</li> <li>• B2608: STARTER RELAY</li> <li>• B2609: S/L STATUS</li> <li>• B260A: IGNITION RELAY</li> <li>• B260B: STEERING LOCK UNIT</li> <li>• B260C: STEERING LOCK UNIT</li> <li>• B260D: STEERING LOCK UNIT</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2612: S/L STATUS</li> <li>• B2614: ACC RELAY CIRC</li> <li>• B2615: BLOWER RELAY CIRC</li> <li>• B2616: IGN RELAY CIRC</li> <li>• B2617: STARTER RELAY CIRC</li> <li>• B2618: BCM</li> <li>• B2619: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B26E1: ENG STATE NO RECIV</li> <li>• B26E9: S/L STATUS</li> <li>• B26EA: KEY REGISTRATION</li> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• U0415: VEHICLE SPEED SIG</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1712: [CHECKSUM ERR] FL</li> <li>• C1713: [CHECKSUM ERR] FR</li> <li>• C1714: [CHECKSUM ERR] RR</li> <li>• C1715: [CHECKSUM ERR] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1720: [CODE ERR] FL</li> <li>• C1721: [CODE ERR] FR</li> <li>• C1722: [CODE ERR] RR</li> <li>• C1723: [CODE ERR] RL</li> <li>• C1724: [BATT VOLT LOW] FL</li> <li>• C1725: [BATT VOLT LOW] FR</li> <li>• C1726: [BATT VOLT LOW] RR</li> <li>• C1727: [BATT VOLT LOW] RL</li> <li>• C1734: CONTROL UNIT</li> </ul>
6	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2622: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## DTC Index

INFOID:000000003773248

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data and IGN Counter, refer to [BCS-16, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	<a href="#">BCS-37</a>
U1010: CONTROL UNIT (CAN)	—	—	—	—	<a href="#">BCS-38</a>
U0415: VEHICLE SPEED SIG	—	—	—	—	<a href="#">BCS-39</a>
B2013: ID DISCORD BCM-S/L	×	×	—	—	<a href="#">SEC-48</a>
B2014: CHAIN OF S/L-BCM	×	×	—	—	<a href="#">SEC-49</a>
B2190: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-42</a>
B2191: DIFFERENCE OF KEY	×	—	—	—	<a href="#">SEC-45</a>
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-46</a>
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-47</a>
B2553: IGNITION RELAY	—	×	—	—	<a href="#">PCS-49</a>
B2555: STOP LAMP	—	×	—	—	<a href="#">SEC-52</a>
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-54</a>
B2557: VEHICLE SPEED	×	×	×	—	<a href="#">SEC-56</a>
B2560: STARTER CONT RELAY	×	×	×	—	<a href="#">SEC-57</a>
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-40</a>
B2601: SHIFT POSITION	×	×	×	—	<a href="#">SEC-58</a>
B2602: SHIFT POSITION	×	×	×	—	<a href="#">SEC-61</a>
B2603: SHIFT POSI STATUS	×	×	×	—	<a href="#">SEC-63</a>
B2604: PNP SW	×	×	×	—	<a href="#">SEC-66</a>
B2605: PNP SW	×	×	×	—	<a href="#">SEC-68</a>
B2606: S/L RELAY	×	×	×	—	<a href="#">SEC-70</a>
B2607: S/L RELAY	×	×	×	—	<a href="#">SEC-71</a>
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-73</a>
B2609: S/L STATUS	×	×	×	—	<a href="#">SEC-75</a>
B260A: IGNITION RELAY	×	×	×	—	<a href="#">PCS-51</a>
B260B: STEERING LOCK UNIT	—	×	×	—	<a href="#">SEC-79</a>
B260C: STEERING LOCK UNIT	—	×	×	—	<a href="#">SEC-80</a>
B260D: STEERING LOCK UNIT	—	×	×	—	<a href="#">SEC-81</a>
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-82</a>
B2612: S/L STATUS	×	×	×	—	<a href="#">SEC-86</a>
B2614: ACC RELAY CIRC	—	×	×	—	<a href="#">PCS-53</a>
B2615: BLOWER RELAY CIRC	—	×	×	—	<a href="#">PCS-57</a>
B2616: IGN RELAY CIRC	—	×	×	—	<a href="#">PCS-59</a>
B2617: STARTER RELAY CIRC	×	×	×	—	<a href="#">SEC-90</a>

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2618: BCM	×	×	×	—	<a href="#">PCS-61</a>
B2619: BCM	×	×	×	—	<a href="#">SEC-92</a>
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-93</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-96</a>
B2621: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-56</a>
B2622: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-58</a>
B2623: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-60</a>
B26E1: ENG STATE NO RES	×	×	×	—	<a href="#">SEC-83</a>
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-84</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-85</a>
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-16</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	<a href="#">WT-18</a>
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	
C1712: [CHECKSUM ERR] FL	—	—	—	×	<a href="#">WT-21</a>
C1713: [CHECKSUM ERR] FR	—	—	—	×	
C1714: [CHECKSUM ERR] RR	—	—	—	×	
C1715: [CHECKSUM ERR] RL	—	—	—	×	
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-24</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1720: [CODE ERR] FL	—	—	—	×	<a href="#">WT-26</a>
C1721: [CODE ERR] FR	—	—	—	×	
C1722: [CODE ERR] RR	—	—	—	×	
C1723: [CODE ERR] RL	—	—	—	×	
C1724: [BATT VOLT LOW] FL	—	—	—	×	<a href="#">WT-29</a>
C1725: [BATT VOLT LOW] FR	—	—	—	×	
C1726: [BATT VOLT LOW] RR	—	—	—	×	
C1727: [BATT VOLT LOW] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-32</a>
C1734: CONTROL UNIT	—	—	—	×	<a href="#">WT-33</a>

# POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS >

## POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000003573510

### TERMINAL LAYOUT



### PHYSICAL VALUES

#### POWER WINDOW MAIN SWITCH

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is UP at operated	Battery voltage
2 (R)	Ground	Encoder ground	—	—	0
3 (GR)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is DOWN at operated	Battery voltage
4 (V)	Ground	Door key cylinder switch LH LOCK signal	Input	Key position (Neutral → Locked)	5 → 0
5 (O)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is DOWN at operated	Battery voltage
6 (Y)	Ground	Door key cylinder switch LH UNLOCK signal	Input	Key position (Neutral → Unlocked)	5 → 0
7 (BR)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is UP at operated	Battery voltage
8 (L)	Ground	Front power window motor (driver side) UP signal	Output	When front LH switch in power window main switch is UP at operated	Battery voltage
9 (O)	Ground	Encoder pulse signal 2	Input	When front power window motor (driver side) operates	



JMKIA0070GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
10 (SB)	Ground	Retained power signal	Input	Ignition switch ON	Battery voltage
				Within 45 seconds after ignition switch is turned to OFF	Battery voltage
				When driver side or passenger side door is opened during retained power operation	0
11 (G)	Ground	Front power window motor (driver side) DOWN signal	Output	When front LH switch in power window main switch is DOWN at operated	Battery voltage
13 (P)	Ground	Encoder pulse signal 1	Input	When front power window motor (driver side) operates.	 <p style="text-align: right; font-size: small;">JMKIA0070GB</p>
14 (V)	Ground	Power window serial link	Input/ Output	Ignition switch ON or power window timer operating	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p>
15 (B)	Ground	Encoder power supply	Output	Ignition switch ON	Battery voltage
17 (B)	Ground	Ground	—	—	0
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage






# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM

Connector No.	B1	Connector No.	B201
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4	Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
85	V	-	7	LG	-
98	GR	-	8	R	-
100	Y	-	9	W	-
			87	GR	-

Connector No.	B18	Connector No.	D1
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8	Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
11	W	-	15	V	-
12	GR	-	16	GR	-
13	Y	-	17	W	-
18	B	-	18	B	-

Connector No.	B16	Connector No.	B218
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	Connector Name	WIRE TO WIRE
Connector Type	A03FW	Connector Type	TK10FW-NS8



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-	10	W	-

Connector No.	B216	Connector No.	B218
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	Connector Name	WIRE TO WIRE
Connector Type	A03FW	Connector Type	TK10FW-NS8



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-	11	W	-
			12	R	-
			13	LG	-
			18	B	-


JCKWM1094Gf

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM

Connector No.	D08
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	GR	-
4	V	-
5	O	-
6	Y	-
7	BR	-
8	L	-
9	O	-
10	SB	-
11	G	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0FCY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	Y	-
6	V	-


I3	P
I4	V
I5	B

Connector No.	D09
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
18	Y	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
9	V	-
14	B	-
15	Y	-

Connector No.	D10
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	B	-
5	P	-
6	R	-

Connector No.	D40
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	GR	-
5	P	-
6	LG	-

Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	GR	-
8	L	-
9	G	-
10	Y	-
11	B	-
15	O	-
16	V	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P





























PWC

JCKWM1095G1

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM









Connector No.	D51	Connector No.	D71	Connector No.	D54	Connector No.	D32	Connector No.	D72	Connector No.	D74	Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Name	REAR POWER WINDOW MOTOR LH	Connector Name	REAR POWER WINDOW MOTOR LH	Connector Name	REAR POWER WINDOW SWITCH RH	Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Type	TK10MW-NSB	Connector Type	TK10MW-NSB	Connector Type	NS06FW-CS	Connector Type	RS06FG	Connector Type	RS06FG	Connector Type	NS06FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	
															
Terminal No.	11	Terminal No.	11	Terminal No.	1	Terminal No.	1	Terminal No.	1	Terminal No.	1	Terminal No.	1	Terminal No.	1
Color of Wire	V	Color of Wire	V	Color of Wire	Y	Color of Wire	G	Color of Wire	L	Color of Wire	G	Color of Wire	W	Color of Wire	L
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Terminal No.	12	Terminal No.	12	Terminal No.	2	Terminal No.	3	Terminal No.	3	Terminal No.	2	Terminal No.	2	Terminal No.	2
Color of Wire	R	Color of Wire	R	Color of Wire	R	Color of Wire	L	Color of Wire	L	Color of Wire	V	Color of Wire	V	Color of Wire	R
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Terminal No.	13	Terminal No.	13	Terminal No.	3	Terminal No.	4	Terminal No.	4	Terminal No.	3	Terminal No.	3	Terminal No.	3
Color of Wire	Y	Color of Wire	Y	Color of Wire	L	Color of Wire	Y	Color of Wire	Y	Color of Wire	R	Color of Wire	R	Color of Wire	R
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Terminal No.	18	Terminal No.	18	Terminal No.	5	Terminal No.	5	Terminal No.	5	Terminal No.	4	Terminal No.	4	Terminal No.	4
Color of Wire	B	Color of Wire	B	Color of Wire	G	Color of Wire	G	Color of Wire	G	Color of Wire	L	Color of Wire	L	Color of Wire	L
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Terminal No.	18	Terminal No.	18	Terminal No.	7	Terminal No.	7	Terminal No.	7	Terminal No.	5	Terminal No.	5	Terminal No.	5
Color of Wire	B	Color of Wire	B	Color of Wire	B	Color of Wire	B	Color of Wire	B	Color of Wire	G	Color of Wire	G	Color of Wire	G
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Terminal No.	7A	Terminal No.	7A	Terminal No.	9I	Terminal No.	9I	Terminal No.	9I	Terminal No.	9I	Terminal No.	9I	Terminal No.	9I
Color of Wire	R	Color of Wire	R	Color of Wire	W	Color of Wire	W	Color of Wire	W	Color of Wire	W	Color of Wire	W	Color of Wire	W
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
Connector No.	M1	Connector No.	M1	Connector No.	E106	Connector No.	D74	Connector No.	D72	Connector No.	D74	Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Name	FUSE BLOCK (J/B)	Connector Name	FUSE BLOCK (J/B)	Connector Name	WIRE TO WIRE	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Name	REAR POWER WINDOW MOTOR RH	Connector Name	REAR POWER WINDOW SWITCH RH	Terminal No.	Color of Wire	Signal Name [Specification]	
Connector Type	NS06FW-M2	Connector Type	NS06FW-M2	Connector Type	TR06FW-CS16-TM4	Connector Type	NS06FW-CS	Connector Type	RS06FG	Connector Type	NS06FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	
															

JCKWWM1096G1

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM

<table border="1"> <tr><td>Connector No.</td><td>M5</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS15</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>3</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>R</td><td>-</td></tr> <tr><td>8</td><td>W</td><td>-</td></tr> <tr><td>9</td><td>G</td><td>-</td></tr> <tr><td>10</td><td>L</td><td>-</td></tr> <tr><td>13</td><td>B</td><td>-</td></tr> <tr><td>14</td><td>O</td><td>-</td></tr> <tr><td>15</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M5	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS15	Terminal No.	Color of Wire	Signal Name [Specification]	3	V	-	7	R	-	8	W	-	9	G	-	10	L	-	13	B	-	14	O	-	15	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M6</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>91</td><td>W</td><td>-</td></tr> </table>	Connector No.	M6	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	91	W	-	<table border="1"> <tr><td>Connector No.</td><td>M7</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>85</td><td>LG</td><td>-</td></tr> <tr><td>98</td><td>W</td><td>-</td></tr> <tr><td>99</td><td>R</td><td>-</td></tr> <tr><td>100</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M7	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	85	LG	-	98	W	-	99	R	-	100	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M117</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>7</td><td>W</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> <tr><td>9</td><td>L</td><td>-</td></tr> <tr><td>97</td><td>LG</td><td>-</td></tr> </table>	Connector No.	M117	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	7	W	-	8	G	-	9	L	-	97	LG	-
Connector No.	M5																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS15																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
3	V	-																																																																																								
7	R	-																																																																																								
8	W	-																																																																																								
9	G	-																																																																																								
10	L	-																																																																																								
13	B	-																																																																																								
14	O	-																																																																																								
15	Y	-																																																																																								
Connector No.	M6																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
91	W	-																																																																																								
Connector No.	M7																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
85	LG	-																																																																																								
98	W	-																																																																																								
99	R	-																																																																																								
100	Y	-																																																																																								
Connector No.	M117																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
7	W	-																																																																																								
8	G	-																																																																																								
9	L	-																																																																																								
97	LG	-																																																																																								
<table border="1"> <tr><td>Connector No.</td><td>M118</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>M03FB-LC</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>1</td><td>W</td><td>BAT (F/L)</td></tr> <tr><td>2</td><td>Y</td><td>POWER WINDOW POWER SUPPLY (BAT)</td></tr> <tr><td>3</td><td>O</td><td>POWER WINDOW POWER SUPPLY (RAP)</td></tr> </table>	Connector No.	M118	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	M03FB-LC	Terminal No.	Color of Wire	Signal Name [Specification]	1	W	BAT (F/L)	2	Y	POWER WINDOW POWER SUPPLY (BAT)	3	O	POWER WINDOW POWER SUPPLY (RAP)	<table border="1"> <tr><td>Connector No.</td><td>M119</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>11</td><td>R</td><td>BAT (FUSE)</td></tr> <tr><td>13</td><td>B</td><td>GND</td></tr> </table>	Connector No.	M119	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	NS10FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	11	R	BAT (FUSE)	13	B	GND	<table border="1"> <tr><td>Connector No.</td><td>M122</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FB-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>63</td><td>Y</td><td>KEYLESS TUNER SIGNAL</td></tr> <tr><td>109</td><td>LG</td><td>KEYLESS ENTRY RECEIVER POWER SUPPLY</td></tr> </table>	Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FB-NH	Terminal No.	Color of Wire	Signal Name [Specification]	63	Y	KEYLESS TUNER SIGNAL	109	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	<table border="1"> <tr><td>Connector No.</td><td>M123</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FG-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>124</td><td>LG</td><td>PASSENGER DOOR SW</td></tr> <tr><td>132</td><td>V</td><td>POWER WINDOW SW COMM</td></tr> <tr><td>137</td><td>O</td><td>RECEIVER SENSOR GND</td></tr> <tr><td>150</td><td>LG</td><td>DRIVER DOOR SW</td></tr> </table>	Connector No.	M123	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FG-NH	Terminal No.	Color of Wire	Signal Name [Specification]	124	LG	PASSENGER DOOR SW	132	V	POWER WINDOW SW COMM	137	O	RECEIVER SENSOR GND	150	LG	DRIVER DOOR SW																		
Connector No.	M118																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	M03FB-LC																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
1	W	BAT (F/L)																																																																																								
2	Y	POWER WINDOW POWER SUPPLY (BAT)																																																																																								
3	O	POWER WINDOW POWER SUPPLY (RAP)																																																																																								
Connector No.	M119																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	NS10FW-CS																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
11	R	BAT (FUSE)																																																																																								
13	B	GND																																																																																								
Connector No.	M122																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FB-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
63	Y	KEYLESS TUNER SIGNAL																																																																																								
109	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY																																																																																								
Connector No.	M123																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FG-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
124	LG	PASSENGER DOOR SW																																																																																								
132	V	POWER WINDOW SW COMM																																																																																								
137	O	RECEIVER SENSOR GND																																																																																								
150	LG	DRIVER DOOR SW																																																																																								


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

JCKWM1097GI

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >



JCKWM1098Gf

INFOID:000000003573513

## Fail Safe

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

# POWER WINDOW MAIN SWITCH

## < ECU DIAGNOSIS >

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or front power window motor.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)


< ECU DIAGNOSIS >

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Reference Value

INFOID:000000003573514

### TERMINAL LAYOUT



### PHYSICAL VALUES

#### FRONT POWER WINDOW SWITCH (PASSENGER SIDE)



Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
3 (LG)	Ground	Encoder ground	—	—	0
4 (GR)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	Battery voltage
8 (L)	9	Power window motor UP signal	Output	When power window motor is UP at operated.	Battery voltage
9 (G)	8	Power window motor DOWN signal	Output	When power window motor is DOWN at operated.	Battery voltage
10 (Y)	Ground	Battery power supply	Input	—	Battery voltage
11 (B)	Ground	Ground	—	—	0
12 (P)	3	Encoder pulse signal 1	Input	When power window motor operates.	

JMKIA0070GB



# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

Terminal No.		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
15 (O)	3	Encoder pulse signal 2	Input	When power window motor operates.	 <p style="text-align: right; font-size: small;">JMKIA0070GB</p>
16 (V)	Ground	Power window serial link	Input/ Output	Ignition switch ON or power window timer operating.	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


PWC

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

## Wiring Diagram - POWER WINDOW SYSTEM -

INFOID:000000003733367





JCKWM1093GI

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >



## POWER WINDOW SYSTEM

Connector No.	B1	Connector No.	B201
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4	Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
85	V	-	7	LG	-
96	W	-	8	R	-
98	GR	-	9	W	-
100	Y	-	97	GR	-

Connector No.	B16	Connector No.	B18
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	Connector Name	WIRE TO WIRE
Connector Type	A03FW	Connector Type	TK10FW-NS8


Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	V	-	11	W	-
			12	GR	-
			13	Y	-
			18	B	-

Connector No.	B218	Connector No.	D1
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	Connector Name	WIRE TO WIRE
Connector Type	A03FW	Connector Type	TH40FW-CS15


Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
11	W	-	3	V	-
12	GR	-	7	GR	-
13	Y	-	8	W	-
18	B	-	9	O	-
			10	BR	-
			13	B	-
			14	SB	-
			15	Y	-

Connector No.	B216	Terminal No.	11
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)	Color of Wire	W
Connector Type	A03FW	Signal Name [Specification]	-




Terminal No.	Color of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B218	Terminal No.	12
Connector Name	WIRE TO WIRE	Color of Wire	R
Connector Type	TK10FW-NS8	Signal Name [Specification]	-



Terminal No.	Color of Wire	Signal Name [Specification]
12	R	-
13	LG	-
18	B	-

Connector No.	B218	Terminal No.	18
Connector Name	WIRE TO WIRE	Color of Wire	B
Connector Type	TK10FW-NS8	Signal Name [Specification]	-



Terminal No.	Color of Wire	Signal Name [Specification]
18	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PWC

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM

Connector No.	D08
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	GR	-
4	V	-
5	O	-
6	Y	-
7	BR	-
8	L	-
9	O	-
10	SB	-
11	G	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0FCY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	Y	-
6	V	-


13	P	-
14	V	-
15	B	-

Connector No.	D09
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS09FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
19	Y	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
9	V	-
14	B	-
15	Y	-

Connector No.	D10
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS09FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	B	-
5	P	-
6	R	-

Connector No.	D40
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS09FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	O	-
4	GR	-
5	P	-
6	LG	-

Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	GR	-
8	L	-
9	G	-
10	Y	-
11	B	-
15	O	-
16	V	-

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM

<table border="1"> <tr><td>Connector No.</td><td>D51</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TK10MW-NSS</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>11</td><td>V</td><td>-</td></tr> <tr><td>12</td><td>R</td><td>-</td></tr> <tr><td>13</td><td>Y</td><td>-</td></tr> <tr><td>18</td><td>B</td><td>-</td></tr> </tbody> </table>	Connector No.	D51	Connector Name	WIRE TO WIRE	Connector Type	TK10MW-NSS	Terminal No.	Color of Wire	Signal Name [Specification]	11	V	-	12	R	-	13	Y	-	18	B	-	<table border="1"> <tr><td>Connector No.</td><td>D54</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH LH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> <tr><td>3</td><td>L</td><td>-</td></tr> <tr><td>4</td><td>L</td><td>-</td></tr> <tr><td>5</td><td>G</td><td>-</td></tr> <tr><td>7</td><td>B</td><td>-</td></tr> </tbody> </table>	Connector No.	D54	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Type	NS08FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	1	Y	-	2	R	-	3	L	-	4	L	-	5	G	-	7	B	-	<table border="1"> <tr><td>Connector No.</td><td>D72</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW MOTOR LH</td></tr> <tr><td>Connector Type</td><td>RS06FG</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>3</td><td>L</td><td>-</td></tr> </tbody> </table>	Connector No.	D72	Connector Name	REAR POWER WINDOW MOTOR LH	Connector Type	RS06FG	Terminal No.	Color of Wire	Signal Name [Specification]	1	G	-	3	L	-	<table border="1"> <tr><td>Connector No.</td><td>D74</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td></tr> <tr><td>3</td><td>R</td><td>-</td></tr> <tr><td>4</td><td>L</td><td>-</td></tr> <tr><td>5</td><td>G</td><td>-</td></tr> <tr><td>7</td><td>B</td><td>-</td></tr> </tbody> </table>	Connector No.	D74	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	1	W	-	2	V	-	3	R	-	4	L	-	5	G	-	7	B	-	<table border="1"> <tr><td>Connector No.</td><td>D72</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW MOTOR RH</td></tr> <tr><td>Connector Type</td><td>RS06FG</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>3</td><td>L</td><td>-</td></tr> </tbody> </table>	Connector No.	D72	Connector Name	REAR POWER WINDOW MOTOR RH	Connector Type	RS06FG	Terminal No.	Color of Wire	Signal Name [Specification]	1	G	-	3	L	-	<table border="1"> <tr><td>Connector No.</td><td>M1</td></tr> <tr><td>Connector Name</td><td>FUSE BLOK (J/B)</td></tr> <tr><td>Connector Type</td><td>NS08FW-M2</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>7A</td><td>R</td><td>-</td></tr> </tbody> </table>	Connector No.	M1	Connector Name	FUSE BLOK (J/B)	Connector Type	NS08FW-M2	Terminal No.	Color of Wire	Signal Name [Specification]	7A	R	-	<table border="1"> <tr><td>Connector No.</td><td>E106</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TR08FW-CS16-TM4</td></tr> </table> <table border="1"> <thead> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> </thead> <tbody> <tr><td>91</td><td>W</td><td>-</td></tr> </tbody> </table>	Connector No.	E106	Connector Name	WIRE TO WIRE	Connector Type	TR08FW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	91	W	-
Connector No.	D51																																																																																																																																						
Connector Name	WIRE TO WIRE																																																																																																																																						
Connector Type	TK10MW-NSS																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
11	V	-																																																																																																																																					
12	R	-																																																																																																																																					
13	Y	-																																																																																																																																					
18	B	-																																																																																																																																					
Connector No.	D54																																																																																																																																						
Connector Name	REAR POWER WINDOW SWITCH LH																																																																																																																																						
Connector Type	NS08FW-CS																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
1	Y	-																																																																																																																																					
2	R	-																																																																																																																																					
3	L	-																																																																																																																																					
4	L	-																																																																																																																																					
5	G	-																																																																																																																																					
7	B	-																																																																																																																																					
Connector No.	D72																																																																																																																																						
Connector Name	REAR POWER WINDOW MOTOR LH																																																																																																																																						
Connector Type	RS06FG																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
1	G	-																																																																																																																																					
3	L	-																																																																																																																																					
Connector No.	D74																																																																																																																																						
Connector Name	REAR POWER WINDOW SWITCH RH																																																																																																																																						
Connector Type	NS08FW-CS																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
1	W	-																																																																																																																																					
2	V	-																																																																																																																																					
3	R	-																																																																																																																																					
4	L	-																																																																																																																																					
5	G	-																																																																																																																																					
7	B	-																																																																																																																																					
Connector No.	D72																																																																																																																																						
Connector Name	REAR POWER WINDOW MOTOR RH																																																																																																																																						
Connector Type	RS06FG																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
1	G	-																																																																																																																																					
3	L	-																																																																																																																																					
Connector No.	M1																																																																																																																																						
Connector Name	FUSE BLOK (J/B)																																																																																																																																						
Connector Type	NS08FW-M2																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
7A	R	-																																																																																																																																					
Connector No.	E106																																																																																																																																						
Connector Name	WIRE TO WIRE																																																																																																																																						
Connector Type	TR08FW-CS16-TM4																																																																																																																																						
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																																					
91	W	-																																																																																																																																					

JCKWM1096Gf









A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PWC

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM

<table border="1"> <tr><td>Connector No.</td><td>M5</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS15</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>3</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>R</td><td>-</td></tr> <tr><td>8</td><td>W</td><td>-</td></tr> <tr><td>9</td><td>G</td><td>-</td></tr> <tr><td>10</td><td>L</td><td>-</td></tr> <tr><td>13</td><td>B</td><td>-</td></tr> <tr><td>14</td><td>O</td><td>-</td></tr> <tr><td>15</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M5	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS15	Terminal No.	Color of Wire	Signal Name [Specification]	3	V	-	7	R	-	8	W	-	9	G	-	10	L	-	13	B	-	14	O	-	15	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M6</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>91</td><td>W</td><td>-</td></tr> </table>	Connector No.	M6	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	91	W	-	<table border="1"> <tr><td>Connector No.</td><td>M7</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS18-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>85</td><td>LG</td><td>-</td></tr> <tr><td>98</td><td>W</td><td>-</td></tr> <tr><td>99</td><td>R</td><td>-</td></tr> <tr><td>100</td><td>Y</td><td>-</td></tr> </table>	Connector No.	M7	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS18-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	85	LG	-	98	W	-	99	R	-	100	Y	-	<table border="1"> <tr><td>Connector No.</td><td>M117</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH40MW-CS16-TM4</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>7</td><td>W</td><td>-</td></tr> <tr><td>8</td><td>G</td><td>-</td></tr> <tr><td>9</td><td>L</td><td>-</td></tr> <tr><td>87</td><td>LG</td><td>-</td></tr> </table>	Connector No.	M117	Connector Name	WIRE TO WIRE	Connector Type	TH40MW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	7	W	-	8	G	-	9	L	-	87	LG	-
Connector No.	M5																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS15																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
3	V	-																																																																																								
7	R	-																																																																																								
8	W	-																																																																																								
9	G	-																																																																																								
10	L	-																																																																																								
13	B	-																																																																																								
14	O	-																																																																																								
15	Y	-																																																																																								
Connector No.	M6																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
91	W	-																																																																																								
Connector No.	M7																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS18-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
85	LG	-																																																																																								
98	W	-																																																																																								
99	R	-																																																																																								
100	Y	-																																																																																								
Connector No.	M117																																																																																									
Connector Name	WIRE TO WIRE																																																																																									
Connector Type	TH40MW-CS16-TM4																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
7	W	-																																																																																								
8	G	-																																																																																								
9	L	-																																																																																								
87	LG	-																																																																																								
<table border="1"> <tr><td>Connector No.</td><td>M118</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>M03IFB-LC</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>1</td><td>W</td><td>BAT (F/L)</td></tr> <tr><td>2</td><td>Y</td><td>POWER WINDOW POWER SUPPLY (IGAT)</td></tr> <tr><td>3</td><td>O</td><td>POWER WINDOW POWER SUPPLY (IRAP)</td></tr> </table>	Connector No.	M118	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	M03IFB-LC	Terminal No.	Color of Wire	Signal Name [Specification]	1	W	BAT (F/L)	2	Y	POWER WINDOW POWER SUPPLY (IGAT)	3	O	POWER WINDOW POWER SUPPLY (IRAP)	<table border="1"> <tr><td>Connector No.</td><td>M119</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>NS16FW-CS</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>11</td><td>R</td><td>BAT (FUSE)</td></tr> <tr><td>13</td><td>B</td><td>GND</td></tr> </table>	Connector No.	M119	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	NS16FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	11	R	BAT (FUSE)	13	B	GND	<table border="1"> <tr><td>Connector No.</td><td>M122</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FB-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>83</td><td>Y</td><td>KEYLESS TUNER SIGNAL</td></tr> <tr><td>103</td><td>LG</td><td>KEYLESS ENTRY RECEIVER POWER SUPPLY</td></tr> </table>	Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FB-NH	Terminal No.	Color of Wire	Signal Name [Specification]	83	Y	KEYLESS TUNER SIGNAL	103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	<table border="1"> <tr><td>Connector No.</td><td>M123</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH40FG-NH</td></tr> </table>  <table border="1"> <tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name [Specification]</th></tr> <tr><td>124</td><td>LG</td><td>PASSENGER DOOR SW</td></tr> <tr><td>132</td><td>V</td><td>POWER WINDOW SW COMM</td></tr> <tr><td>137</td><td>O</td><td>RECEIVER / SENSOR GND</td></tr> <tr><td>150</td><td>LG</td><td>DRIVER DOOR SW</td></tr> </table>	Connector No.	M123	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH40FG-NH	Terminal No.	Color of Wire	Signal Name [Specification]	124	LG	PASSENGER DOOR SW	132	V	POWER WINDOW SW COMM	137	O	RECEIVER / SENSOR GND	150	LG	DRIVER DOOR SW																		
Connector No.	M118																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	M03IFB-LC																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
1	W	BAT (F/L)																																																																																								
2	Y	POWER WINDOW POWER SUPPLY (IGAT)																																																																																								
3	O	POWER WINDOW POWER SUPPLY (IRAP)																																																																																								
Connector No.	M119																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	NS16FW-CS																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
11	R	BAT (FUSE)																																																																																								
13	B	GND																																																																																								
Connector No.	M122																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FB-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
83	Y	KEYLESS TUNER SIGNAL																																																																																								
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY																																																																																								
Connector No.	M123																																																																																									
Connector Name	BCM (BODY CONTROL MODULE)																																																																																									
Connector Type	TH40FG-NH																																																																																									
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																								
124	LG	PASSENGER DOOR SW																																																																																								
132	V	POWER WINDOW SW COMM																																																																																								
137	O	RECEIVER / SENSOR GND																																																																																								
150	LG	DRIVER DOOR SW																																																																																								


JCKW11097G1

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC



JCKWM1098Gf

## Fail Safe

INFOID:000000003573516

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

### < ECU DIAGNOSIS >

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in front power window motor.



# NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

### Diagnosis Procedure

INFOID:000000003573517

#### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.  
Refer to [PWC-13, "BCM : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK POWER WINDOW MAIN SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window main switch power supply and ground circuit.  
Refer to [PWC-13, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DRIVER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## DRIVER SIDE POWER WINDOW DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003573518

#### 1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

---

Check power window motor.

Refer to [PWC-19, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

# FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE POWER WINDOW MAIN SWITCH IS OPERATED

POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure INFOID:000000003671434

### 1. REPLACE FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Replace front power window switch (passenger side).

Refer to [PWC-112, "Removal and Installation"](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

## WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW  
SWITCH ARE OPERATED : Diagnosis Procedure INFOID:000000003671435

### 1. CHECK POWER WINDOW SWITCH SERIAL LINK CIRCUIT

Check power window switch serial link circuit.

Refer to [PWC-35, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CHECK PASSENGER SIDE POWER WINDOW MOTOR CIRCUIT

Check passenger side power window motor circuit.

Refer to [PWC-20, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## REAR LH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

### REAR LH SIDE POWER WINDOW DOES NOT OPERATE WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW  
SWITCH LH : Diagnosis Procedure

INFOID:000000003573522

#### 1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-17, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-22, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

### WITH REAR POWER WINDOW SWITCH LH ONLY

WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure

INFOID:000000003573523

#### 1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-15, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-17, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

# REAR RH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW DOES NOT OPERATE  
WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Diagnosis Procedure

INFOID:000000003573524

## 1.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.  
Refer to [PWC-17, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

## 2.CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.  
Refer to [PWC-23, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

## 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).
- NO >> GO TO 1.

WITH REAR POWER WINDOW SWITCH RH ONLY

WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure

INFOID:000000003573525

## 1.CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.  
Refer to [PWC-15, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

## 2.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.  
Refer to [PWC-17, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

## 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).
- NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

## ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003573526

#### 1.PERFORM INITIALIZATION PROCEDURE

---

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-5. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

#### 2.CHECK ENCODER CIRCUIT

---

Check encoder circuit.

Refer to [PWC-28. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).

NO >> GO TO 1.

# ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

## ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

### Diagnosis Procedure

INFOID:000000003573527

#### 1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-5. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

#### 2.CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-30. "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

---

## POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

### Diagnosis Procedure

INFOID:000000003573528

#### 1.CHECK DOOR SWITCH

---

Check door switch.

Refer to [PWC-26, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.



# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000003573529

#### 1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-5. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 2.

#### 2.CHECK ENCODER

Check encoder.

Refer to [PWC-28. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38. "Intermittent Incident"](#).  
NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

---

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (PASSENGER SIDE)

### Diagnosis Procedure

INFOID:000000003573530

#### 1.PERFORM INITIALIZATION PROCEDURE

---

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-5, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END  
NO >> GO TO 2.

#### 2.CHECK ENCODER

---

Check encoder.

Refer to [PWC-28, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).  
NO >> GO TO 1.

# DOES NOT OPERATE BY KEY CYLINDER SWITCH

< SYMPTOM DIAGNOSIS >

---

## DOES NOT OPERATE BY KEY CYLINDER SWITCH

### Diagnosis Procedure

INFOID:000000003573531

---

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-5, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

---

#### 2. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check front door lock assembly LH (key cylinder switch).

Refer to [PWC-33, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

---

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000003573532

#### 1. CHECK INTELLIGENT KEY FUNCTION

---

Check Intelligent Key function.

Refer to [DLK-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM. Refer to [BCS-84, "Removal and Installation"](#).

#### 2. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-38, "Intermittent Incident"](#).

NO >> GO TO 1.

# POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

---

## POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000003573533

### 1. REPLACE POWER WINDOW MAIN SWITCH

---

Replace power window main switch.

>> Refer to [PWC-112. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

---

## POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE

### Diagnosis Procedure

INFOID:000000003761724

#### 1. REPLACE POWER WINDOW MAIN SWITCH

---

Replace power window main switch.

>> Refer to [PWC-112. "Removal and Installation"](#).

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003751409

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000003751395

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH


< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### POWER WINDOW MAIN SWITCH

Exploded View

INFOID:000000003573537



1. Pull handle cover
2. Power window main switch
3. Power window main switch finisher

#### NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power switch (LH & RH).

Refer to removal and installation procedure. Refer to [PWC-112. "Removal and Installation"](#).

### Removal and Installation

INFOID:000000003573538

#### REMOVAL


1. Remove the power window main switch finisher (2).  
Refer to [GW-20. "Exploded View"](#) and [GW-20. "Removal and Installation"](#).
2. Power window main switch (1) is removed from power window main switch finisher (2) using flat-head screw driver (A) etc.

#### CAUTION:

**Do not fold the pawl of power window main switch finisher.**

#### NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power window switch (LH & RH).



#### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Power window main switch is exchanged or is detached it is necessary to do the initialization procedure.

Refer to [PWC-5. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).