

A
LU
C
D
E
F
G
H
I
J
K
L
M

SECTION LU

ENGINE LUBRICATION SYSTEM

CONTENTS

VQ35DE			
PRECAUTIONS	3	REMOVAL	
Precautions for Liquid Gasket	3	INSTALLATION	
LIQUID GASKET APPLICATION PROCEDURE...	3	INSPECTION AFTER INSTALLATION	
PREPARATION	4	Disassembly and Assembly	
Special Service Tools	4	DISASSEMBLY	
Commercial Service Tools	4	INSPECTION AFTER DISASSEMBLY	
LUBRICATION SYSTEM	5	ASSEMBLY	
Lubrication Circuit	5	SERVICE DATA AND SPECIFICATIONS (SDS)	
System Drawing	6	Standard and Limit	
ENGINE OIL	7	ENGINE OIL PRESSURE	
Inspection	7	OIL PUMP	
ENGINE OIL LEVEL	7	REGULATOR VALVE	
ENGINE OIL APPEARANCE	7	ENGINE OIL CAPACITY (APPROXIMATE)	
ENGINE OIL LEAKAGE	7		
OIL PRESSURE CHECK	8	VK45DE	
Changing Engine Oil	9	PRECAUTIONS	21
OIL FILTER	10	Precautions for Liquid Gasket	21
Removal and Installation	10	LIQUID GASKET APPLICATION PROCEDURE..	21
REMOVAL	10	PREPARATION	22
INSTALLATION	10	Special Service Tools	22
INSPECTION AFTER INSTALLATION	10	Commercial Service Tools	22
OIL FILTER BRACKET (AWD)	12	LUBRICATION SYSTEM	23
Removal and Installation	12	Lubrication Circuit	23
REMOVAL	12	System Drawing	24
INSTALLATION	12	ENGINE OIL	25
INSPECTION AFTER INSTALLATION	12	Inspection	25
OIL COOLER	14	ENGINE OIL LEVEL	25
Removal and Installation	14	ENGINE OIL APPEARANCE	25
2WD MODEL	14	ENGINE OIL LEAKAGE	25
AWD MODEL	15	OIL PRESSURE CHECK	25
REMOVAL	15	Changing Engine Oil	26
INSPECTION AFTER REMOVAL	15	OIL FILTER	28
INSTALLATION	16	Removal and Installation	28
INSPECTION AFTER INSTALLATION	16	REMOVAL	28
OIL PUMP	17	INSTALLATION	28
Removal and Installation	17	INSPECTION AFTER INSTALLATION	28

OIL COOLER	29	INSPECTION AFTER INSTALLATION	32
Removal and Installation	29	Disassembly and Assembly	32
REMOVAL	29	DISASSEMBLY	32
INSPECTION AFTER REMOVAL	29	INSPECTION AFTER DISASSEMBLY	32
INSTALLATION	30	ASSEMBLY	33
INSPECTION AFTER INSTALLATION	30	SERVICE DATA AND SPECIFICATIONS (SDS)	34
OIL PUMP	31	Standard and Limit	34
Removal and Installation	31	OIL PRESSURE	34
REMOVAL	31	ENGINE OIL CAPACITY (APPROXIMATE)	34
INSTALLATION	31	OIL PUMP	34
		REGULATOR VALVE	34

PRECAUTIONS

PF0:00001


Precautions for Liquid Gasket LIQUID GASKET APPLICATION PROCEDURE

ABS005ZE

1. Remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the liquid gasket application surface, mounting bolts, and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
3. Attach liquid gasket tube to tube presser [SST: WS39930000 (–)].

Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.



A
LU
C
D
E
F
G
H
I
J
K
L
M

PREPARATION

[VQ35DE]





PREPARATION

PFP:00002

Special Service Tools



ABS004SQ

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description
ST25051001 (J-25695-1) Oil pressure gauge	 NT050	Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg-cm² , 356 psi)
ST25052000 (J-25695-2) Hose	 S-NT559	Adapting oil pressure gauge to upper oil pan
KV10115801 (J-38956) Oil filter wrench	 S-NT375	Removing and installing oil filter a: 64.3 mm (2.531 in)
WS39930000 (—) Tube presser	 NT052	Pressing tube of liquid gasket

Commercial Service Tools

ABS004SR


Tool name		Description
Deep socket	 PBIC2072E	Removing and installing oil pressure switch (2WD model) a: 26 mm (1.02 in)
Power tools	 PBIC0190E	Loosening nuts and bolts

LUBRICATION SYSTEM

PFP:15010

Lubrication Circuit

ABS004SS



A

LU

C

D

E

F

G

H

I

J

K

L


M

LUBRICATION SYSTEM

[VQ35DE]

System Drawing

ABS004ST



PBIC2071E

ENGINE OIL

PFM:KLA92


Inspection ENGINE OIL LEVEL

ABS004SU

NOTE:


Before starting engine, check engine oil level. If engine is already started, stop it and allow 10 minutes before checking.

1. Put vehicle horizontally.
2. Pull out oil level gauge and wipe it clean.
3. Insert oil level gauge and make sure engine oil level is within the range shown in the figure.
4. If it is out of range, adjust it.



NOTE:

When checking engine oil level, insert oil level gauge with its tip aligned with oil level gauge guide on cylinder head. (In figure, air cleaner case and air duct are removed.)



ENGINE OIL APPEARANCE

- Check engine oil for white turbidity or heavy contamination.
- If engine oil is milky, it is highly probable that it is contaminated with engine coolant. Repair the broken parts.

ENGINE OIL LEAKAGE

Check for engine oil leakage around the following areas:



- Oil pan
- Oil pan drain plug
- Oil pressure switch
- Oil filter
- Oil cooler
- Water pump cover
- Chain tensioner cover
- Intake valve timing control cover and intake valve timing control solenoid valve
- Mating surface between cylinder block and cylinder head
- Mating surface between cylinder head and rocker cover
- Mating surface between front timing chain case and rear timing chain case
- Mating surface between rear timing chain case and cylinder block and cylinder head
- Crankshaft oil seal (front and rear)

A
LU
C
D
E
F
G
H
I
J
K
L
M


OIL PRESSURE CHECK

WARNING:

- Be careful not to burn yourself, as engine oil may be hot.
 - Put selector lever in the Park “P” position.
1. Check engine oil level. Refer to [LU-7, "ENGINE OIL LEVEL"](#).
 2. Remove front engine undercover with power tool.
 3. Disconnect oil pressure switch harness connector.
 4. Remove oil pressure switch.



5. Install oil pressure gauge (SST) and hose (SST).



6. Start engine and warm it up to normal operating temperature.
7. Check engine oil pressure with engine running under no-load.

NOTE:

When engine oil temperature is low, engine oil pressure becomes high.

Engine oil pressure [Engine oil temperature at 80 °C (176 °F)]

Engine speed (rpm)	Approximate discharge pressure [kPa (kg/cm ² , psi)]
Idle speed	More than 98 (1.0, 14)
2,000	More than 294 (3.0, 43)

If difference is extreme, check engine oil passage and oil pump for engine oil leaks.

8. After the inspections, install oil pressure switch as follows:
 - a. Remove old liquid gasket adhering to oil pressure switch and the mating surface.
 - b. Apply liquid gasket and tighten oil pressure switch to specification.

Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) .

Oil pressure switch:

 : 14.8 N·m (1.5 kg-m, 11 ft-lb)

Changing Engine Oil

ABS004SV

WARNING:

- Be careful not to burn yourself, as engine oil may be hot.
 - Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
1. Remove front engine undercover with power tool.
 2. Warm up engine, and check for engine oil leakage from engine components. Refer to [LU-7, "ENGINE OIL LEAKAGE"](#) .
 3. Stop engine and wait for 10 minutes.
 4. Remove drain plug and oil filler cap.
 5. Drain engine oil.
 6. Install drain plug with new washer. Refer to [EM-30, "OIL PAN AND OIL STRAINER"](#) .

CAUTION:

Be sure to clean drain plug and install with new washer.

Oil pan drain plug:

 : 34.3 N·m (3.5 kg-m, 25 ft-lb)

7. Refill with new engine oil.
Engine oil specification and viscosity:
 Refer to [MA-12, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .
Engine oil capacity (Approximate):

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	4.7 (5, 4-1/8)
	Without oil filter change	4.4 (4-5/8, 3-7/8)
Dry engine (Overhaul)		5.4 (5-3/4, 4-3/4)

CAUTION:

- The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
 - Always use oil level gauge to determine the proper amount of engine oil in engine.
8. Warm up engine and check area around drain plug and oil filter for engine oil leakage.
 9. Stop engine and wait for 10 minutes.
 10. Check the engine oil level. Refer to [LU-7, "ENGINE OIL LEVEL"](#) .

OIL FILTER



Removal and Installation

REMOVAL

1. Remove front engine undercover with power tool.
2. Using oil filter wrench (SST), remove oil filter.


CAUTION:

- Oil filter is provided with a relief valve.
Use genuine NISSAN oil filter or equivalent.
- Be careful not to get burned when engine and engine oil are hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Do not allow engine oil to adhere to drive belts.
- Completely wipe off any engine oil that adhere to engine and vehicle.



INSTALLATION


1. Remove foreign materials adhering to oil filter installation surface.
2. Apply engine oil to the oil seal contact surface of new oil filter.



3. Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn. Or tighten to specification.

Oil filter:

 : 17.7 N·m (1.8 kg-m, 13 ft-lb)



INSPECTION AFTER INSTALLATION

1. Start engine, and check there is no leak of engine oil.
2. Stop engine and wait for 10 minutes.

3. Check the engine oil level and add engine oil. Refer to [LU-7, "ENGINE OIL"](#).

A

LU

C

D

E

F

G

H

I

J

K

L


M

OIL FILTER BRACKET (AWD)

PFP:15238

Removal and Installation

ABS007ZS



- | | | |
|---------------|------------------------|---------------------------|
| 1. Oil filter | 2. Connector bolt | 3. Oil cooler |
| 4. O-ring | 5. Relief valve | 6. Oil filter bracket |
| 7. Gasket | 8. Oil pressure switch | 9. Oil temperature sensor |
| 10. Washer | 11. Oil pan (upper) | |

REMOVAL

WARNING:

Be careful not to burn yourself, as engine oil may be hot.

1. Remove front engine undercover with power tool.
2. Using oil filter wrench [SST: KV10115801 (J-38956)], remove oil filter. Refer to [LU-10, "OIL FILTER"](#).
3. Remove oil cooler connector bolt, and then oil cooler.
4. Disconnect oil temperature sensor and oil pressure switch harness connector.
5. Remove oil filter bracket from oil pan (upper).
6. Remove oil temperature sensor and oil pressure switch from oil filter bracket.

INSTALLATION

Note to the following, and install in the reverse order of removal.

- Install oil pressure switch and oil temperature sensor as follows:
 - Remove old liquid gasket adhering to oil pressure switch and oil filter bracket.
 - Apply liquid gasket and install oil pressure switch, and then oil temperature sensor with a new washer. **Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).**
- Align cutout on oil cooler with protrusion on oil filter bracket. Refer to [LU-16, "INSTALLATION"](#).

INSPECTION AFTER INSTALLATION

1. Check the engine oil level and add engine oil. Refer to [LU-7, "ENGINE OIL"](#).

OIL FILTER BRACKET (AWD)

[VQ35DE]

2. Start engine, and check there is no leak of engine oil.
3. Stop engine and wait for 10 minutes.
4. Check the engine oil level again. Refer to [LU-7, "ENGINE OIL"](#)

A

LU

C

D

E

F

G

H

I

J

K


L

M

OIL COOLER

Removal and Installation 2WD MODEL

SEC. 150•211•213




PBIC2403E

- | | | |
|----------------|-------------------|-------------------------------|
| 1. Oil filter | 2. Connector bolt | 3. Oil cooler |
| 4. O-ring | 5. Relief valve | 6. Oil pan (upper) right side |
| 7. Water hose | 8. Water hose | 9. Water pipe |
| 10. Water hose | | |

AWD MODEL

SEC. 150•211•213



- | | | |
|----------------|-------------------|-----------------------|
| 1. Oil filter | 2. Connector bolt | 3. Oil cooler |
| 4. O-ring | 5. Relief valve | 6. Oil filter bracket |
| 7. Water hose | 8. Water hose | 9. Water pipe |
| 10. Water hose | | |

REMOVAL

WARNING:

Be careful not to burn yourself, as engine oil and engine coolant may be hot.

- Remove front engine undercover with power tool.
- Disconnect water hoses from oil cooler pinching water hoses near oil cooler to prevent engine coolant from spilling out.
 - Remaining engine coolant in piping will come out. Use a tray to collect it.

CAUTION:

Do not spill engine coolant on drive belt.

- Using oil filter wrench [SST: KV10115801 (J-38956)], remove oil filter. Refer to [LU-10, "OIL FILTER"](#).
- Remove connector bolt, and remove oil cooler.

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

Relief Valve


Inspect relief valve for movement, cracks and breaks by pushing ball. If replacement is necessary, remove relief valve by prying it out with a suitable tool. Install a new relief valve in place by tapping it.

INSTALLATION

Note to the following, and install in the reverse order of removal.


2WD Model

Align cutout on oil cooler with protrusion on oil pan (upper).



AWD Model

Align cutout on oil cooler with protrusion on oil filter bracket.



INSPECTION AFTER INSTALLATION


1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [LU-7, "ENGINE OIL"](#) and Refer to [CO-11, "ENGINE COOLANT"](#) .
2. Start engine, and check there is no leaks of engine oil or engine coolant.
3. Stop engine and wait for 10 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-7, "ENGINE OIL"](#) and Refer to [CO-11, "ENGINE COOLANT"](#) .

OIL PUMP

PF15010

Removal and Installation

ABS004SY



- | | | |
|--------------------|-------------------------|---------------------------|
| 1. Oil pump body | 2. Oil pump outer rotor | 3. Oil pump inner rotor |
| 4. Oil pump cover | 5. Regulator valve plug | 6. Regulator valve spring |
| 7. Regulator valve | | |

CAUTION:

Before installation, apply new engine oil to the parts as instructed in the figure.

REMOVAL

1. Remove oil pan (lower and upper) and oil strainer. Refer to [EM-30, "OIL PAN AND OIL STRAINER"](#).
2. Remove front timing chain case and timing chain (primary). Refer to [EM-63, "TIMING CHAIN"](#).
3. Remove oil pump assembly.

INSTALLATION

Note to the following, and install in the reverse order of removal.

- When installing, align crankshaft flat faces with oil pump inner rotor flat faces.

INSPECTION AFTER INSTALLATION

1. After warming up engine, check for engine oil leakage.
2. Check the engine oil level and add engine oil. Refer to [LU-7, "ENGINE OIL"](#).

Disassembly and Assembly

DISASSEMBLY

1. Remove oil pump cover.
2. Remove oil pump inner rotor and oil pump outer rotor from oil pump body.
3. After removing regulator valve plug, remove regulator valve spring and regulator valve.

ABS004SZ

INSPECTION AFTER DISASSEMBLY


Oil Pump Clearance

- Measure clearance with feeler gauge.
Clearance between oil pump outer rotor and oil pump body (position "1")

Standard : 0.114 - 0.260 mm (0.0045 - 0.0102 in)

Tip clearance between oil pump inner rotor and oil pump outer rotor (position "2")

Standard : Below 0.180 mm (0.0071in)




- Measure clearance with feeler gauge and straightedge.
Side clearance between oil pump inner rotor and oil pump body (position "3")

Standard : 0.030 - 0.070 mm (0.0012 - 0.0028 in)

Side clearance between oil pump outer rotor and oil pump body (position "4")


Standard : 0.050 - 0.110 mm (0.0020 - 0.0043 in)



Calculate the clearance between oil pump inner rotor and oil pump body as follows.

- Measure the inner diameter of oil pump body with inside micrometer (Position "5")
- Measure the outer diameter of protruded portion of oil pump inner rotor (Position "6")
- (Clearance) = (Inner diameter of oil pump body) – (Outer diameter of oil pump inner rotor)

Standard : 0.045 - 0.091 mm (0.0018 - 0.0036 in)




Regulator Valve Clearance

(Clearance) = (Regulator valve hole diameter) – (Outer diameter of regulator valve)

Standard : 0.040 - 0.097 mm (0.0016 - 0.0038 in)

CAUTION:


- Coat regulator valve with new engine oil.
- Make sure it falls smoothly into the regulator valve hole by its own weight.



ASSEMBLY

Note to the following, and install in the reverse order of removal.

- Install oil pump inner rotor with the groove faced to the oil pump cover side.



A
LU
C
D
E
F
G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

[VQ35DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit ENGINE OIL PRESSURE

ABS004T0

Engine speed (rpm)	Approximate discharge pressure [kPa (kg/cm ² , psi)]
Idle speed	More than 98 (1.0, 14)
2,000	More than 294 (3.0, 43)

OIL PUMP

Unit: mm (in)

Oil pump body to oil pump outer rotor radial clearance	0.114 - 0.260 (0.0045 - 0.0102)
Oil pump inner rotor to oil pump outer rotor tip clearance	Below 0.180 (0.0071)
Oil pump body to oil pump inner rotor axial clearance	0.030 - 0.070 (0.0012 - 0.0028)
Oil pump body to oil pump outer rotor axial clearance	0.050 - 0.110 (0.0020 - 0.0043)
Oil pump inner rotor to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

REGULATOR VALVE

Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	4.7 (5, 4-1/8)
	Without oil filter change	4.4 (4-5/8, 3-7/8)
Dry engine (Overhaul)		5.4 (5-3/4, 4-3/4)

PRECAUTIONS

PF0:00001


Precautions for Liquid Gasket LIQUID GASKET APPLICATION PROCEDURE

ABS006IZ

1. Remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the liquid gasket application surface, mounting bolts, and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
3. Attach liquid gasket tube to tube presser [SST: WS39930000 (—)].

Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.



A
LU
C
D
E
F
G
H
I
J
K
L
M

PREPARATION

[VK45DE]

PREPARATION

PF0:00002

Special Service Tools

ABS006J0

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST25051001 (J25695-1) Oil pressure gauge	Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg/cm² , 356 psi)
ST25052000 (J25695-2) Hose	Adapting oil pressure gauge to cylinder block
KV10115801 (J38956) Oil filter wrench	Removing and installing oil filter a: 64.3 (2.531 in)
WS39930000 (—) Tube presser	Pressing the tube of liquid gasket

Commercial Service Tools

ABS006J1


Tool name	Description
Power tool	Loosening bolts and nuts
Deep socket	Removing and installing oil pressure switch a: 24 mm (0.94 in)

LUBRICATION SYSTEM

PF15010

Lubrication Circuit

ABS006J2



A

LU

C

D

E

F

G

H

I

J

K


L

M

ENGINE OIL**Inspection
ENGINE OIL LEVEL****NOTE:**

Before starting engine, put vehicle horizontally and check the engine oil level. If the engine is already started, stop it and allow 15 minutes before checking.

1. Pull out oil level gauge and wipe it clean.
2. Insert oil level gauge and make sure the engine oil level is within the range shown in the figure.
3. If it is out of range, adjust it.

**ENGINE OIL APPEARANCE**

- Check engine oil for white turbidity or heavy contamination.
- If engine oil becomes turbid and white, it is highly probable that it is contaminated with engine coolant. Repair or replace damaged parts.

ENGINE OIL LEAKAGE

Check for oil leakage around the following area.

- Oil pan
- Oil pan drain plug
- Oil pressure switch
- Oil filter
- Oil cooler
- Intake valve timing control cover
- Intake valve timing control solenoid valve
- Front cover
- Chain tensioner cover
- Mating surface between cylinder block and cylinder head
- Mating surface between cylinder head and rocker cover
- Crankshaft oil seals (front and rear)


OIL PRESSURE CHECK**WARNING:**

- Be careful not to burn yourself, as engine oil may be hot.
 - Oil pressure check should be done in "Parking position".
1. Check engine oil level. Refer to [LU-25, "ENGINE OIL LEVEL"](#).
 2. Remove front engine undercover with power tool.


ENGINE OIL

[VK45DE]

3. Disconnect oil pressure switch harness connector.
4. Remove oil pressure switch.



5. Install oil pressure gauge and hose (SST).



6. Start engine and warm it up to normal operating temperature.
7. Check oil pressure with engine running under no-load.

NOTE:

When engine oil temperature is low, engine oil pressure becomes high.

Engine oil pressure [Engine oil temperature at 80°C (176°F)]

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 98 (1.0, 14)
2,000	More than 294 (3.0, 43)

If difference is extreme, check oil passage and oil pump for oil leaks.

8. After the inspections, install oil pressure switch as follows:
 - a. Remove old liquid gasket adhering to oil presser switch and engine.
 - b. Apply liquid gasket and tighten oil pressure switch to specification.
Use Genuine Thread Sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) .

 : 14.8 N·m (1.5 kg·m, 11 ft·lb)


Changing Engine Oil

ABS006J5

WARNING:

- Be careful not to burn yourself, as engine oil may be hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Remove front engine undercover with power tool.
2. Warm up engine, put vehicle horizontally and check for oil leakage from engine components. Refer to [LU-25, "ENGINE OIL LEAKAGE"](#) .
3. Stop engine and wait for 15 minutes.
4. Loosen oil filler cap, and then remove drain plug.



5. Drain engine oil.
6. Install drain plug with new washer. Refer to [EM-181, "OIL PAN AND OIL STRAINER"](#) .

CAUTION:

Be sure to clean drain plug and install with new washer.

Oil pan drain plug:

 : **34.3 N·m (3.5 kg·m, 25 ft·lb)**

7. Refill with new engine oil.
Engine oil specification and viscosity:
 Refer to [MA-12, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .

Engine oil capacity (Approximate):

		Unit: ℓ (US qt, Imp qt)
Drain and refill	With oil filter change	6.4 (6-3/4, 5-5/8)
	without oil filter change	5.8 (6-1/8, 5-1/8)
Dry engine (engine overhaul)		7.2 (7-5/8, 6-3/8)

CAUTION:

- **The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.**
 - **Always use the oil level gauge to determine when the proper amount of engine oil is in the engine.**
8. Warm up engine and check area around drain plug and oil filter for oil leakage.
 9. Stop engine and wait for 15 minutes.
 10. Check the engine oil level. Refer to [LU-25, "ENGINE OIL LEVEL"](#) .

A
LU
C
D
E
F
G
H
I
J
K
L
M

OIL FILTER


Removal and Installation

REMOVAL

1. Remove front engine undercover with power tool.
2. Using the oil filter wrench (SST), remove the oil filter.


CAUTION:

- Oil filter is provided with relief valve.
Use Genuine Nissan Oil Filter or equivalent.
- Be careful not to get burned when engine and engine oil may be hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Do not allow engine oil to adhere to drive belts.
- Completely wipe off any engine oil that adhere to engine and vehicle.



INSTALLATION


1. Remove foreign materials adhering to oil filter installation surface.
2. Apply engine oil to the oil seal circumference of the new oil filter.



3. Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn. Or tighten to specification.

Oil filter:

 :17.7 N·m (1.8 kg-m, 13 ft-lb)




INSPECTION AFTER INSTALLATION

1. After warming up engine, check for engine oil leakage.
2. Stop engine and wait for 15 minutes.
3. Check the engine oil level and add engine oil. Refer to [LU-25, "ENGINE OIL"](#) .

OIL COOLER

Removal and Installation



- | | | |
|------------------------|-------------------|-----------------|
| 1. Oil filter | 2. Connector bolt | 3. Water hose |
| 4. Water pipe | 5. Oil cooler | 6. O-ring |
| 7. Oil pan (left side) | 8. Water hose | 9. Relief valve |

WARNING:

Be careful not to get burn yourself, as engine oil and engine coolant are hot.

REMOVAL

1. Remove front engine undercover with power tool.
2. Remove oil filter. Refer to [LU-28, "OIL FILTER"](#).

CAUTION:

Do not spill engine oil on drive belts.

3. Disconnect water hoses from oil cooler, while pinching hoses near oil cooler to prevent engine coolant from spilling.

CAUTION:

- Perform this step when engine is cold.
- Do not spill engine coolant on the drive belt.

4. Remove connector bolt, and remove oil cooler.

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.


Relief Valve

Check relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove relief valve by prying it out with suitable tool. Install a new valve in place by tapping it.

INSTALLATION

Note to the following, and install in the reverse order of removal.

- Make sure that no foreign objects are adhering to the installation planes of oil cooler or oil pan.
- Tighten connector bolt after aligning stopper on the oil pan side with protrusion of oil cooler.



INSPECTION AFTER INSTALLATION


1. Make sure level of engine oil and engine coolant, and add engine oil and engine coolant. Refer to [LU-25, "ENGINE OIL"](#) and [CO-36, "ENGINE COOLANT"](#) .
2. Start engine, and make sure there is no leak of engine oil or engine coolant.
3. Stop engine and wait for 15 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-25, "ENGINE OIL"](#) and [CO-36, "ENGINE COOLANT"](#) .

OIL PUMP

PFP:15010

Removal and Installation

ABS006J7



- | | | |
|---------------------------|--------------------------|-------------------------|
| 1. Oil pump body | 2. Oil pump outer rotor | 3. Oil pump inner rotor |
| 4. Oil pump cover | 5. Oil pump drive spacer | 6. Regulator valve |
| 7. Regulator valve spring | 8. Regulator valve plug | |


REMOVAL

- Remove front cover. Refer to [EM-196, "TIMING CHAIN"](#) .
- Remove the oil pump drive spacer.

- Set bolts in the two bolt holes [M6 × pitch 1.0 mm (0.04 in)] on the front surface. Using suitable puller, pull oil pump drive spacer off from crankshaft.

NOTE:


The dimension between the centers of the two bolt holes is 33 mm (1.30 in).
 In the figure, a commercial steering puller is used.



- Remove oil pump.

INSTALLATION

- Install the oil pump.
- Install oil pump drive spacer as follows:
 - Insert oil pump drive spacer according to the directions of crankshaft key and the two flat surfaces of oil pump inner rotor.
 - If the positional relationship does not allow the insertion, rotate oil pump inner rotor with a finger to allow spacer.
 - After confirming that the position of each part is in correct condition to allow for spacer, force fit spacer by lightly tapping with plastic hammer until it contacts and does not go further.



- Install in the reverse order of removal after this step.

INSPECTION AFTER INSTALLATION

- After warming up engine, check for engine oil leakage.
- Check the engine oil level, and add engine oil. Refer to [LU-25, "ENGINE OIL"](#).

Disassembly and Assembly

DISASSEMBLY

ABS006J8

1. Remove oil pump cover.
2. Remove oil pump inner rotor and oil pump outer rotor from oil pump body.
3. After removing regulator valve plug, remove regulator valve spring and regulator valve.

INSPECTION AFTER DISASSEMBLY


Oil Pump Clearance

- Measure clearance with feeler gauge.
 - Clearance between oil pump outer rotor and oil pump body (Position 1)

Standard : 0.114 - 0.200 mm (0.0045 - 0.0079 in)

- Tip clearance between oil pump inner rotor and oil pump outer rotor (Position 2)

Standard : Below 0.180 mm (0.0071 in)




- Measure clearance with feeler gauge and straightedge.
 - Side clearance between oil pump inner rotor and oil pump body (Position 3)

Standard : 0.030 - 0.070 mm (0.0012 - 0.0028 in)

- Side clearance between oil pump outer rotor and oil pump body (Position 4)


Standard : 0.030 - 0.090 mm (0.0012 - 0.0035 in)



- Calculate the clearance between oil pump inner rotor and oil pump body as follows:


OIL PUMP INNER ROTOR OUTER DIAMETER

- Measure the outer diameter of protruded portion of oil pump inner rotor. (Position 5)



OIL PUMP BODY INNER DIAMETER

- Measure the inner diameter of oil pump body with inside micrometer. (Position 6)



OIL PUMP INNER DIAMETER TO OIL PUMP BODY CLEARANCE

- (Clearance) = (Oil pump body inner diameter) – (Oil pump inner rotor outer diameter)

Standard : 0.045 - 0.091 mm (0.0018 - 0.0036 in)

- If measured/calculated values are out of the standard, replace oil pump assembly.

Regulator Valve Clearance


(Clearance) = D1 (Valve hole diameter) – D2 (Regulator valve outer diameter of valve)

Standard : 0.040 - 0.097 mm (0.0016 - 0.0038 in)

- If out of the standard, replace oil pump assembly.

CAUTION:


- Coat regulator valve with engine oil.
- Make sure that it falls smoothly into regulator valve hole by its own weight.



ASSEMBLY

Note to the following, and assemble in the reverse order of disassembly.

- Install oil pump inner rotor and oil pump outer rotor with the punched marks on the oil pump cover side.



A
LU
C
D
E
F
G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

[VK45DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit OIL PRESSURE

ABS006J9

Engine speed rpm	Approximate discharge oil pressure* kPa (kg/cm ² , psi)
Idle speed 2,000	More than 98 (1.0, 14) More than 294 (3.0, 43)

*: Engine oil temperature at 80°C (176°F)

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	6.4 (6-3/4, 5-5/8)
	Without oil filter change	5.8 (6-1/8, 5-1/8)
Dry engine (engine overhaul)		7.2 (7-5/8, 6-3/8)

OIL PUMP

Unit: mm (in)

Oil pump body to oil pump outer rotor radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Oil pump inner rotor to oil pump outer rotor tip clearance	Below 0.180 (0.0071)
Oil pump body to oil pump inner rotor axial clearance	0.030 - 0.070 (0.0012 - 0.0028)
Oil pump body to oil pump outer rotor axial clearance	0.030 - 0.090 (0.0012 - 0.0035)
Oil pump inner rotor to oil pump body clearance	0.045 - 0.091 (0.0018 - 0.0036)

REGULATOR VALVE

Unit: mm (in)

Regulator valve to oil pump body clearance	0.040 - 0.097 (0.0016 - 0.0038)
--	---------------------------------