

A
B
C

SECTION RFD

REAR FINAL DRIVE

RFD

CONTENTS

<p>PRECAUTIONS 2</p> <p style="padding-left: 20px;">Precautions 2</p> <p>PREPARATION 3</p> <p style="padding-left: 20px;">Special Service Tools 3</p> <p style="padding-left: 20px;">Commercial Service Tools 5</p> <p>NOISE, VIBRATION AND HARSHNESS (NVH)</p> <p>TROUBLESHOOTING 6</p> <p style="padding-left: 20px;">NVH Troubleshooting Chart 6</p> <p>FRONT OIL SEAL 7</p> <p style="padding-left: 20px;">Removal and Installation 7</p> <p style="padding-left: 40px;">REMOVAL 7</p> <p style="padding-left: 40px;">INSTALLATION 7</p> <p>SIDE OIL SEAL 9</p> <p style="padding-left: 20px;">Removal and Installation 9</p> <p style="padding-left: 40px;">REMOVAL 9</p> <p style="padding-left: 40px;">INSTALLATION 10</p> <p>REAR FINAL DRIVE ASSEMBLY 11</p> <p style="padding-left: 20px;">Removal and Installation 11</p> <p style="padding-left: 40px;">REMOVAL 11</p> <p style="padding-left: 40px;">INSTALLATION 11</p> <p style="padding-left: 20px;">Components 12</p> <p style="padding-left: 40px;">R200 2-PINION 12</p> <p style="padding-left: 20px;">Pre-Inspection 13</p> <p style="padding-left: 40px;">TOTAL PRELOAD 13</p> <p style="padding-left: 40px;">DRIVE GEAR TO DRIVE PINION BACKLASH... 13</p> <p style="padding-left: 40px;">DRIVE GEAR RUNOUT 13</p> <p style="padding-left: 40px;">COMPANION FLANGE RUNOUT 14</p> <p style="padding-left: 40px;">TOOTH CONTACT 14</p> <p style="padding-left: 20px;">Disassembly and Assembly 14</p> <p style="padding-left: 40px;">REMOVAL OF DIFFERENTIAL CASE ASSEM-</p>	<p style="padding-left: 40px;">BLY 14</p> <p style="padding-left: 20px;">REMOVAL OF DRIVE PINION ASSEMBLY 15</p> <p style="padding-left: 20px;">DISASSEMBLY OF DIFFERENTIAL CASE ASSEMBLY 17</p> <p style="padding-left: 20px;">INSPECTION 18</p> <p style="padding-left: 20px;">ADJUSTMENT OF DIFFERENTIAL CASE 19</p> <p style="padding-left: 20px;">SIDE BEARING PRELOAD 20</p> <p style="padding-left: 20px;">PINION GEAR HEIGHT 21</p> <p style="padding-left: 20px;">TOOTH CONTACT 24</p> <p style="padding-left: 20px;">ASSEMBLY OF DIFFERENTIAL CASE ASSEMBLY 25</p> <p style="padding-left: 20px;">INSTALLATION OF DRIVE PINION ASSEMBLY.. 26</p> <p style="padding-left: 20px;">INSTALLATION OF DIFFERENTIAL CASE ASSEMBLY 28</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS) 31</p> <p style="padding-left: 20px;">General Specifications 31</p> <p style="padding-left: 20px;">Drive Gear Runout 31</p> <p style="padding-left: 20px;">Side Gear Adjustment 31</p> <p style="padding-left: 40px;">AVAILABLE SIDE GEAR THRUST WASHERS... 31</p> <p style="padding-left: 20px;">Drive Pinion Height Adjustment 31</p> <p style="padding-left: 40px;">AVAILABLE PINION HEIGHT ADJUSTING WASHERS 31</p> <p style="padding-left: 20px;">Drive Pinion Preload Adjustment 31</p> <p style="padding-left: 20px;">Side Bearing Preload Adjustment 32</p> <p style="padding-left: 40px;">SIDE BEARING ADJUSTING WASHERS 32</p> <p style="padding-left: 20px;">Total Preload Adjustment 32</p> <p style="padding-left: 20px;">Companion Flange 32</p>
---	--

E

F

G

H

I

J

K

L

M

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions

ADS000K2

CAUTION:

- Before starting diagnosis of the vehicle, understand symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior removal or disassembly. When matching marks are required, be sure they do not interfere with the function of the parts they are applied to.
- Carry out an overhaul in a clean work place, Using a dust proof room is recommended.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. If a malfunction is detected, replace it with a new one.
- Normally replace lock pins, oil seals, and bearings with new ones every times they are removed.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage the sliding surfaces and mating surface.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent entering of lint.
- During assembly, observe the specified tightening torque, and new differential gear oil, Vaseline, or multi-purpose grease, as specified for each vehicle, when necessary.

PREPARATION

PREPARATION

PFP:00002

Special Service Tools








ADS000JM

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




Tool number (Kent-Moore No.) Tool name	Description
ST30720000 (J-25405) a: 77 mm (3.03 in) dia. b: 55 mm (2.17 in) dia. Drift	Installing front oil seal
KV38100200 (J-26233) a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia. Drift	Installing side oil seal
KV38107900 (J-39352) Protector	Installing side flange
KV38100800 (J-25604-01) a: 541 mm (21.30 in) b: 200 mm (7.87 in) Attachment	Fixing unit assembly
ST3306S001 (-) 1.ST33051001 (J-22888-20) 2.ST33061000 (J-8107-2) a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia. Differential side bearing puller set	Removing and installing side bearing
ST30613000 (J-25742-3) a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia. Drift	Installing pinion front bearing outer race
KV38100300 (J-25523) a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32 mm (1.26 in) dia. Drift	Installing side bearing

A
 B
 C
RFD
 E
 F
 G
 H
 I
 J
 K
 L
 M

PREPARATION


Tool number (Kent-Moore No.) Tool name	Description
KV40104000 (-) a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia. Drive pinion flange wrench <div style="text-align: center;">  <p style="text-align: center;">NT659</p> </div>	Removing and installing drive pinion lock nut
ST36230000 (J-25840-A) Sliding hammer <div style="text-align: center;">  <p style="text-align: center;">ZZA0803D</p> </div>	Removing side flange
KV40104100 (-) Axle stand <div style="text-align: center;">  <p style="text-align: center;">ZZA0804D</p> </div>	Removing side flange (VQ35DE engine)
KV40101000 (-) Axle stand <div style="text-align: center;">  <p style="text-align: center;">NT159</p> </div>	Removing side flange (VK45DE engine)
HT72400000 (-) Sliding hammer <div style="text-align: center;">  <p style="text-align: center;">S-NT125</p> </div>	Removing differential case assembly
ST3090S000 (-) 1. ST30031000 (J-22912-01) Puller 2. ST30901000 (-) Base Equivalent tool (J-26010-01) a : 90 mm (3.54 in) dia. b : 80 mm (3.15 in) dia. c : 50 mm (1.97 in) dia. d : 79 mm (3.11 in) dia. e : 45 mm (1.77 in) dia. f : 35 mm (1.38 in) dia. Drive pinion rear inner race puller set <div style="text-align: center;">  <p style="text-align: center;">S-NT640</p> </div>	Removing and installing drive pinion rear bearing inner race
ST30611000 (J-25742-1) Drift <div style="text-align: center;">  <p style="text-align: center;">S-NT090</p> </div>	Installing pinion rear bearing outer race (Use with ST30613000)

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description	
ST3127S000 (J-25765-A) 1. GG91030000 Torque wrench (J-25765) 2. HT62940000 (-) Socket adapter (1/2") 3. HT62900000 (-) Socket adapter (3/8") Preload gauge	 NT124	A B C
ST33290001 (J-34286) Side bearing outer race puller	 NT713	RFD E
Differential shim selection (J-34309)	 NT134	F G H

Commercial Service Tools

ADS000JN

Tool name	Description	
Power tool	 PBIC0190E	I J K L M

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

ADS000J0

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Differential	Noise	Possible cause and suspected parts	Reference page
x			Rough gear tooth	Refer to RFD-18, "INSPECTION" .
x			Improper gear contact	Refer to RFD-24, "TOOTH CONTACT" .
x			Tooth surfaces worn	Refer to RFD-18, "INSPECTION" .
x			Incorrect backlash	Refer to RFD-13, "Pre-Inspection" .
x			Companion flange excessive runout	—
x			Improper gear oil	Refer to JA-32, "Checking Differential Gear Oil" .
x			Propeller shaft	NVH in PR section.
x			Axle and suspension	NVH in FAX, RAX, FSU and RSU sections.
x			Tires	NVH in WT section.
x			Road wheel	NVH in WT section.
x			Drive shaft	NVH in RAX section.
x			Brakes	NVH in BR section.
x			Steering	NVH in PS section.

x: Applicable

FRONT OIL SEAL

FRONT OIL SEAL

PFP:38189

Removal and Installation


ADS000JP

REMOVAL

1. Remove the rear propeller shaft. Refer to [PR-7, "Removal and Installation"](#).
2. Put a matching mark on the end of the drive pinion corresponding to the C position matching mark on the final drive companion flange.

CAUTION:


- For matching mark, use paint. Never damage drive pinion.
- The matching mark C on the final drive companion flange indicates the maximum vertical runout position.



3. Using the drive pinion flange wrench, remove drive pinion lock nut.


Tool number : KV40104000 (-)

4. Remove the companion flange using the puller.



5. Remove front oil seal using the side bearing outer race puller,

Tool number : ST33290001 (J-34286)




INSTALLATION

1. Apply multi-purpose grease to sealing lips of oil seal. Press front oil seal into carrier with tool.

Tool number : ST30720000 (J-25405)

NOTE:


- When installing the oil seal, be careful not to get it inclined.
- Discard the old oil seal. Always replace with new one.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

FRONT OIL SEAL

- Align the matching mark of drive pinion with the matching mark C of companion flange, then install the companion flange.



- Apply oil on the screw part of drive pinion and the seating surface of drive pinion lock nut.
- Install drive pinion lock nut with tool.

Tool number : KV40104000 (-)

 : 147 - 323 N·m (15 - 32 kg-m, 109 - 238 ft-lb)

CAUTION:

The drive pinion lock nut is not reusable. Never reuse drive pinion nut.

- Install rear propeller shaft. Refer to [PR-7, "Removal and Installation"](#) .

SIDE OIL SEAL

SIDE OIL SEAL



PPF:33142

Removal and Installation REMOVAL


ADS000JQ

1. Remove side flange with the following procedure for press-fitting.
 - a. Remove ABS rear wheel sensor. Refer to [BRC-57, "WHEEL SENSORS"](#) .
 - b. Remove drive shaft and axle assembly. Refer to [RAX-9, "REAR DRIVE SHAFT"](#) and [RAX-5, "WHEEL HUB"](#) .
 - c. Install axle stand to side flange, and then, pull out the side flange with using a sliding hammer.

Engine model	Toll number A	Tool number B
VQ35DE	KV40104100 (-)	ST36230000 (J-25840-A)
VK45DE	KV40101000 (-)	



2. Remove side oil seal using a flat-bladed screwdriver.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

SIDE OIL SEAL


INSTALLATION

1. Apply multi-purpose grease to sealing lips of side oil seal.
2. Using the drift, press-fit side oil seal so that its surface comes face to face with the end surface of the case.

Tool number : KV38100200 (J-26233)

CAUTION:

- When installing the side oil seal be careful not to get it inclined.
- Discard the old side oil seal. Always replace them with new ones.




3. Install the side flange with the following procedure.

- a. Attach the protector to side oil seal.

Tool number : KV38107900 (J-39352)

- b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.



- c. Put suitable drift on the center of side flange, then drive it until sound changes.


NOTE:

When installation is completed, driving sound of the side flange turns into a sound which seems to affect the whole final drive.

4. Confirm that the dimension of the side flange installation (Measurement A) in the illustration comes into the following.

Measurement A : Approx. 326 - 328 mm (12.83 - 12.91 in)

5. Install the drive shaft and axle assembly. Refer to [RAX-9, "REAR DRIVE SHAFT"](#) and [RAX-5, "WHEEL HUB"](#).
6. Align the installing position of the ABS rear wheel sensor. Refer to [BRC-57, "WHEEL SENSORS"](#).



REAR FINAL DRIVE ASSEMBLY


PF38300

REAR FINAL DRIVE ASSEMBLY

Removal and Installation

ADS000JR

SEC. 370 • 380 • 431



REMOVAL

1. Remove exhaust center tube. Refer to [EX-3. "EXHAUST SYSTEM"](#) .
2. Remove rear propeller shaft from the final drive. Refer to [PR-6. "REAR PROPELLER SHAFT"](#) .
3. Remove rear drive shaft from final drive, then suspend it by wire etc.
4. Remove breather hose from the final drive.
5. Remove ABS rear wheel sensor. Refer to [BRC-57. "WHEEL SENSORS"](#) .
6. Set transmission jack to rear final drive assembly, and then remove mounting bolts and nut connecting to the suspension member.

CAUTION:

Do not place a transmission jack on the rear cover (aluminum case).


7. Remove the rear final drive assembly.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

After installation, check the final drive oil level. Refer to [MA-32. "Checking Differential Gear Oil"](#) .




REAR FINAL DRIVE ASSEMBLY

ADS000JS

Components R200 2-PINION

SEC.380



PDIA0371E

REAR FINAL DRIVE ASSEMBLY

- | | | |
|-----------------------------------|---|------------------------|
| 1. Drive pinion lock nut | 2. Companion flange (Rebro joint type) | 3. Front oil seal |
| 4. Pinion front bearing | 5. Pinion bearing adjusting spacer (Collapsible spacer) | 6. Pinion rear bearing |
| 7. Pinion height adjusting washer | 8. Drive pinion | 9. Side oil seal |
| 10. Drive gear | 11. Pinion mate shaft | 12. Look pin |
| 13. Pinion mate gear | 14. Pinion mate thrust washer | 15. Side gear |
| 16. Side gear thrust washer | 17. Differential case | 18. Side bearing |
| 19. Side bearing adjusting washer | 20. Bearing cap | 21. Rear cover |
| 22. Filler plug | 23. Drain plug | 24. Gear carrier |
| 25. Circlip | 26. Gasket | |

A
B
C
RFD

Pre-Inspection

ADS000JT

Before disassembling final drive, drain off oil from the gear and remove the rear cover. Then, perform the following inspection.


TOTAL PRELOAD

1. Turn drive pinion in both directions several times to set bearing rollers.
2. Check total preload with tool.

Tool number : ST3127S000 (J-25765-A)

Total preload (With oil seal)

: 2.84 - 3.75 N·m (0.29 - 0.38 kg·m, 26 - 33 in·lb)




DRIVE GEAR TO DRIVE PINION BACKLASH

Check drive gear to drive pinion backlash with a dial gauge at several points.

Drive gear to drive pinion backlash


: 0.10 - 0.15 mm (0.0039 - 0.0059 in)



DRIVE GEAR RUNOUT

Check runout of drive gear with a dial gauge.

Drive gear runout limit : 0.05 mm (0.0020 in)



E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY

COMPANION FLANGE RUNOUT


1. Fit a dial gauge onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
2. Rotate the companion flange to check for runout.

Runout limit : 0.13 mm (0.0051 in)

3. Fit a test indicator to the inner side of the companion flange (socket diameter).
4. Rotate the companion flange to check for runout.

Runout limit : 0.13 mm (0.0051 in)

5. If the runout value is outside the repair limit, follow the procedure below to adjust.
 - a. Check for runout while changing the phase between companion flange and drive pinion gear by 90° step, and search for the point where the runout is the minimum.
 - b. If the runout value is still outside of the limit after the phase has been changed, replace the companion flange.
 - c. If the runout value still outside of the limit after the companion flange has been replaced, check pinion bearing and drive pinion assembly.



TOOTH CONTACT


Check tooth contact. Refer to [RFD-24, "TOOTH CONTACT"](#) .

Disassembly and Assembly


REMOVAL OF DIFFERENTIAL CASE ASSEMBLY

1. Using two 45 mm (1.77 in) spacers, mount carrier on tool.

Tool number : KV38100800 (J-25604-01)




2. For proper reinstallation, paint matching marks on one side of the bearing cap.
Bearing caps are line-board during manufacture. Replace them in their proper positions.




REAR FINAL DRIVE ASSEMBLY

3. Remove bearing caps.




4. Lift differential case assembly out with tool.

Tool number : HT72400000 (-)




- Keep the side bearing outer races together with inner race. Do not mix them up. Also, keep side bearing adjusting washers together with bearings.



REMOVAL OF DRIVE PINION ASSEMBLY

1. Put matching marks on companion flange and drive pinion with paint.
2. Loosen drive pinion lock nut with tool.


Tool number : KV40104000 (-)




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY


3. Remove companion flange using the suitable puller .



4. Take out drive pinion (together with rear bearing inner race, pinion bearing adjusting spacer).
5. Remove front oil seal. Refer to [RFD-7, "FRONT OIL SEAL"](#) .
6. Remove pinion front bearing inner race.
7. Remove side oil seal. Refer to [RFD-9, "SIDE OIL SEAL"](#) .




8. Remove pinion bearing outer races with a brass drift.



9. Remove pinion rear bearing inner race and drive pinion height adjusting washer with tool.

Tool number : ST30031000 (J-22912-01)



REAR FINAL DRIVE ASSEMBLY

DISASSEMBLY OF DIFFERENTIAL CASE ASSEMBLY

1. Remove side bearing inner race.
To prevent damage to bearing, engage puller jaws in groove.


Tool number

A : ST33051001 (J-22888-20)


B : ST33061000 (J-8107-2)

CAUTION:


- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing except it is replaced.



- Be careful not to confuse left-hand and right-hand parts.
Keep bearing and bearing race for each side together.




2. Loosen drive gear mounting bolts in a crisscross fashion.
3. Tap drive gear off the differential case with a soft hammer.
 - Tap evenly all around to keep drive gear from binding.




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY


4. Drive out pinion mate shaft lock pin with punch from drive gear side.




5. Remove the pinion mate shaft.



6. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from the differential case.



7. Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft and thrust washers.



INSPECTION

- Clean up the disassembled parts. Then, inspect if the parts are wear or damaged. If so, follow the measures below.

Content	Measures
Drive gear and drive pinion	<ul style="list-style-type: none"> ● If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary. ● If the gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with a new gears.
Bearing	<ul style="list-style-type: none"> ● If found any chipped (by friction), pitted, worn, rusted, scratched mark, or unusual noise from the bearing, replace with a new bearing assembly (as a new set).

REAR FINAL DRIVE ASSEMBLY


Content	Measures
Side gear thrust washer and pinion mate thrust washer	<ul style="list-style-type: none"> ● Replace with a new one if found any cracks or damage on the surface of the tooth. ● Replace with a new one if found any worn or chipped mark on the contact sides of the thrust washer.
Side gear and pinion mate thrust washer	<ul style="list-style-type: none"> ● Replace with a new one if found that it is chipped (by friction), damaged, or unusual worn.
Oil seal	<ul style="list-style-type: none"> ● Oil seals must be replaced with a new one whenever disassembled.
Differential case	<ul style="list-style-type: none"> ● Replace with a new one if found any wear or cracks on the contact sides of the differential case.
Companion flange	<ul style="list-style-type: none"> ● Replace with a new one if found any chipped marks (about 0.10mm, 0.0039in) or other damage on the contact sides of the lips of the companion flange.

A
B
C
RFD

ADJUSTMENT OF DIFFERENTIAL CASE

Thrust Washer Selection

1. Apply gear oil to contact surfaces of each gear, thrust washers and differential case.
2. Install the removed thrust washer or same thickness washer to side gear.




E
F
G
H

3. Install the side gears, thrust washers, pinion mate gears, thrust washers into differential case.


CAUTION:

Install the circlip equipped side gear to the side retainer side.



I
J
K
L

4. Fit pinion mate shaft to differential case so that it meets lock pin holes.




M

REAR FINAL DRIVE ASSEMBLY

- Adjust clearance between rear face of side gear and thrust washer by selecting side gear thrust washer. Refer to [RFD-31, "AVAILABLE PINION HEIGHT ADJUSTING WASHERS"](#). Use two feeler gauges to prevent leaning of side gear as showing figure.

Clearance between side gear thrust washer and differential case


: 0.20 mm (0.0079 in) or less




SIDE BEARING PRELOAD

A selection of carrier side bearing adjusting washers is required for successful completion of this procedure.


- Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
- Place the differential case, with side bearings and bearing races installed, into gear carrier.



- Insert left and right original side bearing adjusting washers in place between side bearings and carrier.



- Install the side bearing caps in their correct locations and torque the bearing cap retaining bolts.
- Turn the carrier several times to seat the bearings.




REAR FINAL DRIVE ASSEMBLY

6. Measure the turning torque of the carrier at the drive gear retaining bolts with a spring gauge, J-8129.

Specification


**: 34.2 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb)
of pulling force at the drive gear bolt**



7. If the turning torque is not within the specifications, correct the torque as follows:


- If the turning torque is less than the specified range, install washers of greater thickness.
- If the turning torque is greater than the specification, install thinner washers.
- See the SDS section for washer dimensions and part numbers.

8. Record the total amount of washer thickness required for the correct carrier side bearing preload.




9. Remove the carrier from the final drive housing. Save the selected washers for later use during the assembly of the final drive unit.

Tool number : HT72400000 (-)




PINION GEAR HEIGHT

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the differential shim selector tool, J-34309.



- Pinion front bearing; make sure the J-34309-3 pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the pinion front bearing pilot, J-34309-5, to secure the bearing in its proper position.
- Pinion rear bearing; the pinion rear bearing pilot, J-34309-8, is used to center the pinion rear bearing only. The pinion rear bearing locking seat, J-34309-4, is used to lock the bearing to the assembly.
- Installation of J-34309-9 and J-34309-16; place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-




A
B
C
RFD
E
F
G
H
I
J
K
L
M


REAR FINAL DRIVE ASSEMBLY

34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).


3. Install the pinion rear bearing inner race into the final drive housing. Then place the pinion preload shim selector tool, J-34309-1, gauge screw assembly.



4. Assemble the pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in the final drive housing. Make sure that the pinion height gauge plate, J-34309-16, will turn a full 360 degrees. Tighten the two sections together by hand.




5. Turn the assembly several times to seat the bearings.



6. Measure the turning torque at the end of the J-34309-2 gauge anvil using torque wrench J-25765A.

Turning torque specification


: 1.0 - 1.3 N·m (0.11 - 0.13 kg·m, 9 - 11 in·lb)



REAR FINAL DRIVE ASSEMBLY

- Place the J-34309-11 "R200A" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:
Make sure all machined surfaces are clean.




A
B
C

RFD


Pinion Height Adjusting Washer Selection

- Now, position the side bearing discs, J-25269-4, and arbor firmly into the side bearing bores. Install the bearing caps and tighten the cap bolts to proper torque.




E
F
G

- Select the correct standard pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and your J-34309-101 feeler gauge. Measure the distance between the J-34309-11 pinion height adapter including the standard gauge and the arbor.



H
I
J
K


- Write down your exact measurement (the value of feeler gauge).



L
M

REAR FINAL DRIVE ASSEMBLY


4. Correct the pinion height washer size by referring to the “pinion head number”.



There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the “pinion head height number”. It refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.

Pinion head height number	Add or remove from the standard pinion height washer thickness measurement
- 6	Add 0.06 mm (0.0024 in)
- 5	Add 0.05 mm (0.0020 in)
- 4	Add 0.04 mm (0.0016 in)
- 3	Add 0.03 mm (0.0012 in)
- 2	Add 0.02 mm (0.0008 in)
- 1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

5. Select the correct pinion height adjusting washer as follows. Refer to [RFD-31, "AVAILABLE PINION HEIGHT ADJUSTING WASHERS"](#).
6. Remove the J-34309 differential shim selector tool from the final drive housing. Then disassemble to retrieve the pinion bearings.




TOOTH CONTACT

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion.


Hypoid gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

REAR FINAL DRIVE ASSEMBLY


1. Thoroughly clean drive gear and drive pinion teeth.
2. Lightly apply a mixture of powdered ferric oxide and oil or the equivalent. Apply it to 3 or 4 teeth of drive gear drive side.



3. Hold companion flange steady by hand and rotate the drive gear in both directions.




Usually the pattern will be correct if washers are correctly calculated and the backlash is correct. However, in rare cases, trial and error processes may be employed to obtain a correct pattern. The tooth pattern is the best indication of how well a differential has been set up.



To correct, increase thickness of pinion height adjusting washer in order to bring drive pinion close to drive gear.

To correct, reduce thickness of pinion height adjusting washer in order to make drive pinion go away from drive gear.



When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.


SDIA1796E

ASSEMBLY OF DIFFERENTIAL CASE ASSEMBLY

1. Install pinion mate shaft lock pin with a punch. Make sure lock pin is flush with case.

CAUTION:

Do not reuse the lock pin. Always replace the lock pin with a new one.



A
B
C
RFD
E
F
G
H
I
J
K
L
M


REAR FINAL DRIVE ASSEMBLY

- Place differential case on drive gear.
- Apply genuine medium strength locking sealant or equivalent. Refer to [GI-48, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) to drive gear bolts, and install them.

CAUTION:


Do not reuse the bolts. Always replace the bolts with a new one.

- Tighten bolts in a crisscross fashion.
- After tightening the bolt to the specified torque, turn the bolt 31 to 36 more degrees.



- Press-fit side bearing inner race on differential case with tool.


Tool number **A : KV38100300 (J-25523)**
 B : ST33061000 (J-8107-2)



INSTALLATION OF DRIVE PINION ASSEMBLY

- Press-fit front and rear bearing outer races with tools.

Tool number **A : Suitable tool**
 B : ST30611000 (J-25742-1)
 C : ST30613000 (J-25742-3)




- Select drive pinion height adjusting washer. Refer to [RFD-31, "AVAILABLE PINION HEIGHT ADJUSTING WASHERS"](#)


REAR FINAL DRIVE ASSEMBLY

3. Install selected drive pinion height adjusting washer in drive pinion. Using hydraulic press and tool, press-fit pinion rear bearing inner race into it.


Tool number : ST30901000 (-)



4. Apply multi-purpose grease to pinion rear bearing inner race and pinion front bearing inner race.



5. Set drive pinion assembly (as shown in figure) in gear carrier and install drive pinion, with press and suitable tool. Stop when drive pinion touches bearing.



6. Install front oil seal with tool. Refer to [RFD-7, "Removal and Installation"](#).

Tool number : ST30720000 (J-25405)


7. Install companion flange, and tighten drive pinion lock nut to minimum.

Ascertain that threaded portion of drive pinion and drive pinion lock nut are free from oil.

Tool number : KV40104000 (-)

CAUTION:

The drive pinion lock nut is not reusable. Never reuse drive pinion lock nut.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY


8. Tighten the drive pinion lock nut by very small degrees until the specified preload is achieved, when checking the preload, turn drive pinion in both directions several times.

Tool number

: ST3127S000 (J-25765-A)

Drive pinion bearing preload


: 2.65 - 3.23 N-m (0.27 - 0.32 kg-m, 24 - 28 in-lb)




- If pinion bearing preload is too small, tighten the drive pinion lock nut more.
- If pinion bearing preload is too great, replace pinion bearing adjusting spacer.

INSTALLATION OF DIFFERENTIAL CASE ASSEMBLY


1. Select side bearing adjusting washer. Refer to [RFD-32, "SIDE BEARING ADJUSTING WASHERS"](#).
2. Install differential case assembly with side bearing outer races into gear carrier.



3. Insert original left and right side bearing adjusting washers in place between side bearings and carrier.



4. Align matching mark on bearing cap with that on gear carrier.
5. Install the side bearing cap.



6. Install side oil seal. Refer to [RFD-9, "Removal and Installation"](#).


Tool number : KV38100200 (J-26233)

REAR FINAL DRIVE ASSEMBLY

7. Measure drive gear-to-drive pinion backlash with a dial gauge at several point.

Drive gear to drive pinion backlash


: 0.10 - 0.15 mm (0.0039 - 0.0059 in)



- If backlash is too small, adjustment of washer thickness is required. Decrease thickness of left shim and increase thickness of right by the same amount. If backlash is too great, reverse the above procedure.
- Never change the total amount of washers as it will change the bearing preload.

8. Check total preload with tool.

Tool number : ST3127S000 (J-25765-A)



When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.

Total preload : 2.84 - 3.75 N·m (0.29 - 0.38 kg·m, 26 - 33 in·lb)


- If preload is too great, remove the same amount of washer to each side.
- If preload is too small, add the same amount of washer to each side.

Never add or remove a different number of washers for each side. Difference in number of washers will change drive gear to drive pinion backlash.

9. Recheck drive gear to drive pinion backlash. Increase or decrease in thickness of shims will cause change to drive gear to pinion backlash.
- Check whether the backlash varies excessively in different places. Foreign matter may be caught between the drive gear and the differential case causing the trouble.
 - The backlash can vary greatly even when the drive gear runout is within a specified range. In that case, replace the hypoid gear set or differential case.
10. Check runout of drive gear with a dial gauge.

Drive gear runout limit : 0.05 mm (0.0020 in)

11. Check tooth contact.
Refer to [RFD-24, "TOOTH CONTACT"](#) .



A
B
C

RFD

E

F

G

H

I

J


K

L

M

REAR FINAL DRIVE ASSEMBLY

12. Install rear cover. Apply liquid sealant to rear cover side and install gear carrier.



SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PPF:00030

General Specifications

ADS000JV

Applied model	VQ35DE engine		VK45DE engine
	5A/T		
	2WD	AWD	
Final drive model	R200 (2-pinion)		
Gear ratio	3.357	3.692	
Number of teeth (Drive gear/Drive pinion)	47/14	48/13	
Oil capacity (Approx.) ℓ (US qt, Imp qt)	1.4 (3, 2-1/2)		

Drive Gear Runout

ADS000JV

Unit: mm (in)

Type	R200
Drive gear runout limit	0.05 (0.0020)

Side Gear Adjustment

ADS000JX

Unit: mm (in)

Type	R200
Clearance limit between side gear thrust washer and differential case	0.20 (0.0079) or less

AVAILABLE SIDE GEAR THRUST WASHERS

Unit: mm (in)

Type	R200	
	Thickness	Part number*
Thrust washer	0.75 (0.0295)	38424 0C000
	0.78 (0.0307)	38424 0C001
	0.81 (0.0319)	38424 0C002
	0.84 (0.0331)	38424 0C003
	0.87 (0.0343)	38424 0C004
	0.90 (0.0350)	38424 0C005
	0.93 (0.0366)	38424 0C006

*: Always check with the Parts Department for the latest parts information.

Drive Pinion Height Adjustment

ADS000JY

AVAILABLE PINION HEIGHT ADJUSTING WASHERS

Unit: mm (in)

Type	R200			
	Thickness	Part number*	Thickness	Part number*
Adjusting washer	3.05 (0.1201)	38154 0C000	3.17 (0.1248)	38154 0C004
	3.08 (0.1213)	38154 0C001	3.20 (0.1260)	38154 0C005
	3.11 (0.1224)	38154 0C002	3.23 (0.1272)	38154 0C006
	3.14 (0.1236)	38154 0C003	3.26 (0.1283)	38154 0C007

*: Always check with the Parts Department for the latest parts information.

Drive Pinion Preload Adjustment

ADS000JZ

Type	R200
Drive pinion preload	2.65 – 3.23 N·m (0.27 – 0.32 kg-m, 24 – 28 in-lb)

SERVICE DATA AND SPECIFICATIONS (SDS)

Side Bearing Preload Adjustment

ADS000K0

Type	R200
Side bearing preload <Reference>	0.20 – 0.52 N·m (0.02 – 0.05 kg-m, 2 – 4 in-lb)
Torque by spring gauge	34.2 – 39.2 N (3.5 – 4.0 kg, 7.7 – 8.8 lb)

SIDE BEARING ADJUSTING WASHERS

Unit: mm (in)

Type	R200			
	Thickness	Part number*	Thickness	Part number*
Adjusting washer	2.00 (0.0787)	38453 N3100	2.35 (0.0925)	38453 N3107
	2.05 (0.0807)	38453 N3101	2.40 (0.0945)	38453 N3108
	2.10 (0.0827)	38453 N3102	2.45 (0.0965)	38453 N3109
	2.15 (0.0846)	38453 N3103	2.50 (0.0984)	38453 N3110
	2.20 (0.0866)	38453 N3104	2.55 (0.1004)	38453 N3111
	2.25 (0.0886)	38453 N3105	2.60 (0.1024)	38453 N3112
	2.30 (0.0906)	38453 N3106	2.65 (0.1043)	38453 N3113

*: Always check with the Parts Department for the latest parts information.

Total Preload Adjustment

ADS000K1

Type	R200
Total preload (with oil seal)	2.84 – 3.75 N·m (0.29 – 0.38 kg-m, 26 – 33 in-lb)
Drive gear to drive pinion backlash	0.10 – 0.15 mm (0.0039 – 0.0059 in)

Companion Flange

ADS0000C

Type	R200
Runout limit	0.13 mm (0.0051 in)