

**SECTION** **LT**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

**CONTENTS**

<b>PRECAUTIONS</b> .....	<b>5</b>	Sides) .....	<b>26</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	5	Headlamp Low Beam Does Not Illuminate (One Side) .....	29
General Precautions for Service Operations .....	6	Headlamp RH Low Beam and High Beam Does Not Illuminate .....	30
<b>HEADLAMP - XENON TYPE -</b> .....	<b>7</b>	Headlamp LH Low Beam and High Beam Does Not Illuminate .....	31
Component Parts and Harness Connector Location...	7	Headlamps Do Not Turn OFF .....	32
System Description .....	7	General Information for Xenon Headlamp Trouble Diagnosis .....	34
OUTLINE .....	7	Caution: .....	34
HEADLAMP OPERATION .....	8	Xenon Headlamp Trouble Diagnosis .....	34
COMBINATION SWITCH READING FUNCTION...	9	Aiming Adjustment .....	35
EXTERIOR LAMP BATTERY SAVER CONTROL...	9	PREPARATION BEFORE ADJUSTING .....	35
AUTO LIGHT OPERATION (IF EQUIPPED) .....	9	LOW BEAM AND HIGH BEAM .....	35
VEHICLE SECURITY SYSTEM .....	9	ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE) .....	36
XENON HEADLAMP .....	9	Bulb Replacement .....	36
CAN Communication System Description .....	9	HEADLAMP HIGH/LOW BEAM .....	36
CAN Communication Unit .....	9	DAYTIME/PARKING LAMP .....	37
Schematic .....	10	FRONT TURN SIGNAL LAMP .....	37
Wiring Diagram — H/LAMP — .....	11	FRONT SIDE MARKER LAMP .....	37
Terminals and Reference Values for BCM .....	15	Removal and Installation .....	37
Terminals and Reference Values for IPDM E/R .....	15	REMOVAL .....	37
How to Proceed With Trouble Diagnosis .....	16	INSTALLATION .....	38
Preliminary Check .....	16	Disassembly and Assembly .....	38
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	16	DISASSEMBLY .....	38
CONSULT-II Functions (BCM) .....	18	ASSEMBLY .....	38
CONSULT-II BASIC OPERATION .....	18	<b>DAYTIME LIGHT SYSTEM</b> .....	<b>39</b>
WORK SUPPORT .....	19	Component Parts and Harness Connector Location..	39
DATA MONITOR .....	19	System Description .....	39
ACTIVE TEST .....	20	OUTLINE .....	39
CONSULT-II Functions (IPDM E/R) .....	20	DAYTIME LIGHT OPERATION .....	40
CONSULT-II BASIC OPERATION .....	21	COMBINATION SWITCH READING FUNCTION..	40
DATA MONITOR .....	22	AUTO LIGHT OPERATION .....	40
ACTIVE TEST .....	23	CAN Communication System Description .....	40
Headlamp Does Not Change To High Beam (Both Sides) .....	23	CAN Communication Unit .....	40
Headlamp Does Not Change To High Beam (One Side) .....	25	Schematic .....	41
High Beam Indicator Lamp Does Not Illuminate ...	26	Wiring Diagram — DTRL — .....	42
Headlamp Low Beam Does Not Illuminate (Both		Terminals and Reference Values for BCM .....	46

How to Proceed With Trouble Diagnosis .....	46	System Description .....	79
Preliminary Check .....	47	OUTLINE .....	79
CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	47	FRONT FOG LAMP OPERATION .....	80
INSPECTION PARKING BRAKE SWITCH CIR- CUIT .....	48	COMBINATION SWITCH READING FUNCTION .....	80
CONSULT-II Functions (BCM) .....	49	EXTERIOR LAMP BATTERY SAVER CONTROL .....	80
CONSULT-II BASIC OPERATION .....	49	CAN Communication System Description .....	80
DATA MONITOR .....	50	CAN Communication Unit .....	80
ACTIVE TEST .....	51	Wiring Diagram — F/FOG — .....	81
Daytime Light Control Does Not Operate Properly .....	52	Terminals and Reference Values for BCM .....	83
Aiming Adjustment .....	54	Terminals and Reference Values for IPDM E/R .....	83
Bulb Replacement .....	54	How to Proceed With Trouble Diagnosis .....	84
Removal and Installation .....	54	Preliminary Check .....	84
Disassembly and Assembly .....	54	CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	84
<b>AUTO LIGHT SYSTEM .....</b>	<b>55</b>	CONSULT-II Functions (BCM) .....	85
Component Parts and Harness Connector Location .....	55	CONSULT-II Functions (IPDM E/R) .....	85
System Description .....	55	Front Fog Lamp Does Not Illuminate (Both Sides) .....	86
OUTLINE .....	55	Front Fog Lamp Does Not Illuminate (One Side) .....	88
COMBINATION SWITCH READING FUNCTION .....	56	Aiming Adjustment .....	89
EXTERIOR LAMP BATTERY SAVER CONTROL .....	56	Bulb Replacement .....	90
DELAY TIMER FUNCTION .....	56	Removal and Installation .....	90
CAN Communication System Description .....	56	REMOVAL .....	90
CAN Communication Unit .....	56	INSTALLATION .....	90
Major Components and Functions .....	56	<b>TURN SIGNAL AND HAZARD WARNING LAMPS...91</b>	
Schematic .....	57	Component Parts and Harness Connector Location .....	91
Wiring Diagram — AUTO/L — .....	58	System Description .....	91
Terminals and Reference Values for BCM .....	61	TURN SIGNAL OPERATION .....	91
Terminals and Reference Values for IPDM E/R .....	62	HAZARD LAMP OPERATION .....	92
How to Proceed With Trouble Diagnosis .....	62	REMOTE CONTROL ENTRY SYSTEM OPER- ATION .....	93
Preliminary Check .....	63	COMBINATION SWITCH READING FUNCTION .....	94
SETTING CHANGE FUNCTIONS .....	63	CAN Communication System Description .....	94
CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	63	CAN Communication Unit .....	94
CONSULT-II Functions (BCM) .....	65	Schematic .....	95
CONSULT-II BASIC OPERATION .....	65	Wiring Diagram — TURN — .....	96
WORK SUPPORT .....	66	Terminals and Reference Values for BCM .....	99
DATA MONITOR .....	66	How to Proceed With Trouble Diagnosis .....	100
ACTIVE TEST .....	67	Preliminary Check .....	100
CONSULT-II Functions (IPDM E/R) .....	68	CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	100
CONSULT-II BASIC OPERATION .....	68	CONSULT-II Functions (BCM) .....	102
DATA MONITOR .....	69	CONSULT-II BASIC OPERATION .....	102
ACTIVE TEST .....	69	DATA MONITOR .....	103
Symptom Chart .....	70	ACTIVE TEST .....	103
Lighting Switch Inspection .....	70	Turn Signal Lamp Does Not Operate .....	103
Optical sensor System Inspection .....	71	Rear Turn Signal Lamp Does Not Operate .....	105
Removal and Installation of Optical Sensor .....	73	Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operate .....	107
REMOVAL .....	73	Turn Signal Indicator Lamp Does Not Operate .....	108
INSTALLATION .....	73	Bulb Replacement (Front Turn Signal Lamp) .....	108
<b>HEADLAMP AIMING CONTROL .....</b>	<b>74</b>	Bulb Replacement (Rear Turn Signal Lamp) .....	108
Schematic .....	74	Removal and Installation of Front Turn Signal Lamp .....	108
Wiring Diagram — H/AIM — .....	75	Removal and Installation of Rear Turn Signal Lamp .....	108
Removal and Installation .....	78	Removal and Installation of Rear Combination Lamp Control Unit .....	109
REMOVAL .....	78	REMOVAL .....	109
INSTALLATION .....	78	INSTALLATION .....	109
Switch Circuit Inspection .....	78		
<b>FRONT FOG LAMP .....</b>	<b>79</b>		
Component Parts and Harness Connector Location .....	79		

<b>LIGHTING AND TURN SIGNAL SWITCH</b> .....	<b>110</b>	CONSULT-II Functions (IPDM E/R) .....	140	
Removal and Installation .....	110	Parking, License Plate and Side Marker Lamps Do		A
REMOVAL .....	110	Not Illuminate .....	140	
INSTALLATION .....	110	Tail Lamp Does Not Operate .....	146	
<b>HAZARD SWITCH</b> .....	<b>111</b>	Parking, License Plate, Side Marker and Tail Lamps		B
Removal and Installation .....	111	Do Not Turn OFF (After Approx. 10 Minutes) .....	147	
REMOVAL .....	111	License Plate Lamp .....	147	
INSTALLATION .....	111	BULB REPLACEMENT, REMOVAL AND		C
<b>COMBINATION SWITCH</b> .....	<b>112</b>	INSTALLATION .....	147	
Wiring Diagram — COMBSW — .....	112	Front Parking Lamp .....	148	
Combination Switch Reading Function .....	113	BULB REPLACEMENT .....	148	D
CONSULT-II Functions (BCM) .....	113	REMOVAL AND INSTALLATION .....	148	
CONSULT-II BASIC OPERATION .....	113	Tail Lamp .....	148	
DATA MONITOR .....	114	BULB REPLACEMENT .....	148	E
Combination Switch Inspection .....	115	REMOVAL AND INSTALLATION .....	148	
Removal and Installation .....	117	Front Side Marker Lamp .....	148	
<b>STOP LAMP</b> .....	<b>118</b>	BULB REPLACEMENT .....	148	F
Component Parts and Harness Connector Location	118	REMOVAL AND INSTALLATION .....	148	
System Description .....	118	Rear Side Marker Lamp .....	148	
Schematic .....	119	BULB REPLACEMENT .....	148	G
Wiring Diagram — STOP/L — .....	120	REMOVAL AND INSTALLATION .....	148	
Stop Lamp Does Not Operate .....	123	Rear Combination Lamp Control Unit .....	148	
High-Mounted Stop Lamp .....	125	REMOVAL AND INSTALLATION .....	148	H
BULB REPLACEMENT, REMOVAL AND		<b>REAR COMBINATION LAMP</b> .....	<b>149</b>	
INSTALLATION .....	125	Bulb Replacement .....	149	I
Stop Lamp .....	125	REAR FENDER SIDE (REAR SIDE MARKER		J
BULB REPLACEMENT .....	125	LAMP BULB) .....	149	
REMOVAL AND INSTALLATION .....	125	BACK DOOR SIDE (BACK-UP LAMP) .....	149	
Rear Combination Lamp Control Unit .....	125	Removal and Installation .....	149	
REMOVAL AND INSTALLATION .....	125	REMOVAL .....	149	
<b>STEP LAMP</b> .....	<b>126</b>	INSTALLATION .....	150	
Front Door Step Lamp .....	126	<b>VANITY MIRROR LAMP</b> .....	<b>151</b>	
BULB REPLACEMENT, REMOVAL AND		Bulb Replacement .....	151	
INSTALLATION .....	126	<b>MAP LAMP</b> .....	<b>152</b>	
Rear Door Step Lamp .....	126	Bulb Replacement .....	152	
BULB REPLACEMENT, REMOVAL AND		Removal and Installation .....	152	
INSTALLATION .....	126	REMOVAL .....	152	
<b>BACK-UP LAMP</b> .....	<b>127</b>	INSTALLATION .....	152	
Wiring Diagram — BACK/L — .....	127	<b>PERSONAL LAMP</b> .....	<b>153</b>	
Bulb Replacement .....	128	Bulb Replacement .....	153	
Removal and Installation .....	128	Removal and Installation .....	153	
<b>PARKING, LICENSE PLATE AND TAIL LAMPS</b> ..	<b>129</b>	REMOVAL .....	153	
Component Parts and Harness Connector Location	129	INSTALLATION .....	153	
System Description .....	129	<b>LUGGAGE ROOM LAMP</b> .....	<b>154</b>	
OUT LINE .....	129	Bulb Replacement .....	154	
OPERATION BY LIGHTING SWITCH .....	130	Removal and Installation .....	154	
COMBINATION SWITCH READING FUNCTION	131	REMOVAL .....	154	
EXTERIOR LAMP BATTERY SAVER CONTROL	131	INSTALLATION .....	154	
CAN Communication System Description .....	131	<b>IGNITION KEY HOLE ILLUMINATION</b> .....	<b>155</b>	
CAN Communication Unit .....	131	Bulb Replacement, Removal and Installation .....	155	
Schematic .....	132	<b>GLOVE BOX LAMP</b> .....	<b>156</b>	
Wiring Diagram — TAIL/L — .....	133	Bulb Replacement, Removal and Installation .....	156	
Terminals and Reference Values for BCM .....	138	<b>ASHTRAY ILLUMINATION</b> .....	<b>157</b>	
Terminals and Reference Values for IPDM E/R ..	138	Bulb Replacement and Removal and Installation ..	157	
How to Proceed With Trouble Diagnosis .....	139	<b>CIGARETTE LIGHTER ILLUMINATION</b> .....	<b>158</b>	
Preliminary Check .....	139	Bulb Replacement and Removal and Installation ..	158	
CHECK POWER SUPPLY AND GROUND CIR-		<b>INTERIOR ROOM LAMP</b> .....	<b>159</b>	
CUIT .....	139	Component Parts and Harness Connector Location	159	
CONSULT-II Functions (BCM) .....	140	System Description .....	159	

POWER SUPPLY AND GROUND .....	160	INTERIOR ROOM LAMP .....	187
SWITCH OPERATION .....	161	MAP LAMP .....	187
ROOM LAMP TIMER OPERATION .....	162	PERSONAL LAMP .....	187
INTERIOR LAMP BATTERY SAVER CONTROL	163	Removal and Installation .....	188
Schematic .....	165	INTERIOR ROOM LAMP .....	188
Wiring Diagram — ROOM/L — .....	167	MAP LAMP .....	188
Terminals and Reference Values for BCM .....	175	PERSONAL LAMP .....	188
How to Proceed With Trouble Diagnosis .....	176	<b>ILLUMINATION .....</b>	<b>189</b>
Preliminary Check .....	176	System Description .....	189
CHECK FOR POWER SUPPLY AND GROUND		ILLUMINATION OPERATION BY LIGHTING	
CIRCUIT .....	176	SWITCH .....	189
CONSULT-II Functions (BCM) .....	177	EXTERIOR LAMP BATTERY SAVER CONTROL	190
CONSULT-II BASIC OPERATION .....	177	CAN Communication System Description .....	190
WORK SUPPORT .....	178	CAN Communication Unit .....	191
DATA MONITOR .....	178	Schematic .....	192
ACTIVE TEST .....	179	Wiring Diagram — ILL — .....	194
Interior Room Lamp Control Does Not Operate ..	180	Removal and Installation .....	202
Map Lamp Control Does Not Operate .....	181	ILLUMINATION CONTROL SWITCH .....	202
Personal Lamp Control Does Not Operate .....	183	GLOVE BOX LAMP .....	202
Ignition Key Hole Illumination Control Does Not		FRONT DOOR INSIDE ILLUMINATION .....	202
Operate .....	184	<b>BULB SPECIFICATIONS .....</b>	<b>203</b>
All Step Lamps Do Not Operate .....	186	Headlamp .....	203
All Interior Room Lamps Do Not Operate .....	187	Exterior Lamp .....	203
Bulb Replacement .....	187	Interior Lamp/Illumination .....	203

# PRECAUTIONS

## PRECAUTIONS

PPF:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS007KP

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


LT

# PRECAUTIONS

## General Precautions for Service Operations

AKS004ZU

- Never work with wet hands.
- Xenon headlamp includes high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.




# HEADLAMP - XENON TYPE -

## HEADLAMP - XENON TYPE -

PFP:26010

### Component Parts and Harness Connector Location

AKS007M9



## System Description

AKS007MA

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, the BCM (body control module) receives input signal requesting the headlamps (and tail lamps) illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the headlamp high and headlamp low relay coils. These relays, when energized, direct power to the respective headlamps, which then illuminate. If voltage is applied to a high beam solenoid, the bulb shade will move, even a xenon head lamp bulb comes out, and a high beam and a low beam are changed.

## OUTLINE

Power is supplied at all times

- to headlamp high relay, located in IPDM E/R,
- to headlamp low relay, located in IPDM E/R, and
- to ignition relay, located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 15A fuse [No. 22, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8.

## HEADLAMP - XENON TYPE -

---

With ignition switch in ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct
- through 15A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 7.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds M35, M45 and M85,
- to IPDM E/R terminals 38 and 60
- through grounds E21, E50 and E51,
- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85.

### HEADLAMP OPERATION

#### Low Beam Operation

With the lighting switch in the 2ND position, the BCM receives input signal requesting the headlamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls the headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 6,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 6.

Ground is supplied

- to front combination lamp RH terminal 7
- through grounds E21, E50 and E51,
- to front combination lamp LH terminal 7
- through grounds E21, E50 and E51.

With power and ground supplied, low beam headlamps illuminate.

#### High Beam Operation/Flash-to-Pass Operation

With the lighting switch in the 2ND position and placed in the HIGH or PASS position, the BCM receives input signal requesting the headlamp high beams to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls the headlamp high relay coil and low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 6,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 6,
- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 5,
- through 10A fuse (No. 74, located in IPDM E/R)
- through IPDM E/R terminal 28

# HEADLAMP - XENON TYPE -

- to front combination lamp LH terminal 5.

Ground is supplied

- to front combination lamp RH terminal 7
- through grounds E21, E50 and E51,
- to front combination lamp LH terminal 7
- through grounds E21, E50 and E51.

With power and ground supplied, the high beam headlamps illuminate.

If voltage is applied to a high beam solenoid, the bulb shade will move, even a xenon head lamp bulb comes out, and a high beam and a low beam are changed.

The unified meter and A/C amp. that received the high beam request signal by BCM across the CAN communication makes a high beam indicator lamp turn on in combination meter.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3. "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamps are turned OFF.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION (IF EQUIPPED)

Refer to [LT-55. "System Description"](#) in "AUTO LIGHT SYSTEM".

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-186. "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

## XENON HEADLAMP

Xenon type lamps are used for to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to strong lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Followings are some advantages of the xenon type headlamp.

- The light produced by the headlamps is white color similar to sunlight that is easy to the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- Retroreflected luminance increases and the contrast enhances on the wet road in the rain. That makes visibility go up more than the increase of the light volume.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

## CAN Communication System Description

AKS007MB

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS0080S

Refer to [LAN-30. "CAN Communication Unit"](#) .

# HEADLAMP - XENON TYPE -

## Schematic

AKS007MD



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).




TKWM0601E

# HEADLAMP - XENON TYPE -

## Wiring Diagram — H/LAMP —

AKS007ME

### LT-H/LAMP-01





REFER TO THE FOLLOWING.

- E211 -SUPER MULTIPLE JUNCTION (SMJ)
- M1, M2 -FUSE BLOCK-JUNCTION BOX (J/B)
- M3, M4 -ELECTRICAL UNITS

TKWM0815E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-02





REFER TO THE FOLLOWING.

E21 -SUPER MULTIPLE JUNCTION (SMJ)

TKWM0603E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-03






TKWM0604E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-04

▬ : DATA LINE



REFER TO THE FOLLOWING.





(M1) - FUSE BLOCK - JUNCTION BOX (J/B)

TKWM0605E

# HEADLAMP - XENON TYPE -

## Terminals and Reference Values for BCM

AKS007MF

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3468E</p>
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3469E</p>
4	PU/W	Combination switch input 3			
5	Y/R	Combination switch input 2			
6	SB	Combination switch input 1			
11	LG/R	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3470E</p>
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3471E</p>
34	W/B	Combination switch output 3			
35	W/G	Combination switch output 2			
36	W/R	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	R	CAN - L	—	—	—
42	L/R	Battery power supply	OFF	—	Battery voltage
49	B	Ground	ON	—	Approx. 0V
52	B	Ground	ON	—	Approx. 0V
55	G	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS007MG

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
20	LG	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage
28	SB	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage

# HEADLAMP - XENON TYPE -

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
30	GY	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF
					ON
38	B	Ground	ON	—	Approx. 0V
48	L	CAN – H	—	—	—
49	R	CAN – L	—	—	—
60	B	Ground	ON	—	Approx. 0V

## How to Proceed With Trouble Diagnosis

AKS007MH

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-7, "System Description"](#) .
3. Perform Preliminary Check. Refer to [LT-16, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

AKS007MI

### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86

Refer to [LT-11, "Wiring Diagram — H/LAMP —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# HEADLAMP - XENON TYPE -


## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M3	11 (LG/R)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.




## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M4	49 (B)	Ground	Yes
	52 (B)		

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

AKS007MJ

## CONSULT-II Functions (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# HEADLAMP - XENON TYPE -

4. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



A  
B  
C  
D  
E  
F  
G

## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

H  
I

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

LT

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

L  
M

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.

## HEADLAMP - XENON TYPE -

Monitor item	Contents
AUTO LIGHT SW <sup>NOTE 1</sup> "ON/OFF"	Displays status of lighting switch as judged from lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR "ON/OFF"	Displays status of driver door as judged from driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of passenger door as judged from passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR "ON/OFF"	Displays status of rear door as judged from rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL "ON/OFF"	Displays status of rear door as judged from rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW "ON/OFF"	Displays status of back door as judged from back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
ENGINE RUN <sup>NOTE 2</sup> "ON/OFF"	Displays status (Engine running: ON/Others: OFF) as judged from engine status signal.
PKB SW <sup>NOTE 2</sup> "ON/OFF"	Displays status (Parking brake switch: ON/Others: OFF) as judged from parking brake switch signal.
CARGO LAMP SW <sup>NOTE 3</sup> "OFF"	—
OPTICAL SENSOR <sup>NOTE 1</sup> "0 - 5V"	Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

1. Vehicles without auto light system display this item, but cannot be monitored.
2. Vehicles without daytime light system display this item, but cannot be monitored.
3. This item is displayed, but cannot be monitored.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows front fog lamp relay to operate by switching ON-OFF.
DTRL <sup>NOTE 1</sup>	Allows daytime light lamp operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE 2</sup>	—
CARGO LAMP <sup>NOTE 2</sup>	—

**NOTE:**

1. Vehicles without daytime light lamp system display this item, but cannot be tested.
2. This item is displayed, but cannot be tested.

### CONSULT-II Functions (IPDM E/R)

AKS007MK

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

# HEADLAMP - XENON TYPE -


Check Item, Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-21, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CON-SULT-II CONVERTER to data link connector, then turn ignition switch ON.




2. Touch "START (NISSAN BASED VHCL)".



3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



4. Select the desired part to be diagnosed on "SELECT DIAG MODE" screen.



# HEADLAMP - XENON TYPE -

## DATA MONITOR

### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE " screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, display may not be correct.

# HEADLAMP - XENON TYPE -

## ACTIVE TEST

### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option (Headlamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay output		Allows front fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

## Headlamp Does Not Change To High Beam (Both Sides)

AKS007ML

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓟ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is HIGH BEAM position : HI BEAM SW ON**

ⓧ Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7585E

### 2. HEADLAMP ACTIVE TEST

Ⓟ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operation.

**Headlamp high beam should operate (Headlamp high beam repeats ON-OFF every 1 second).**

ⓧ Without CONSULT-II

1. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
2. Make sure headlamp high beam operation.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
HI			
LO	FOG		
MODE	BACK	LIGHT	COPY

SKIA5774E

# HEADLAMP - XENON TYPE -

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HIGH BEAM position.

**When lighting switch is HIGH BEAM position : HL LO REQ ON  
: HL HI REQ ON**

DATA MONITOR			
MONITOR			
HL LO REQ		ON	ON
HL HI REQ		ON	ON
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7638E


### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

## 4. CHECK HEADLAMP INPUT SIGNAL

### With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground (Headlamp high beam repeats ON-OFF every 1 second).



Terminal			(-)	Voltage
(+)				
Connector	Terminal (Wire color)		Ground	Battery voltage
RH	E24	5 (BR)		
LH	E44	5 (SB)		

### Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
4. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal			(-)	Voltage
(+)				
Connector	Terminal (Wire color)		Ground	Battery voltage
RH	E24	5 (BR)		
LH	E44	5 (SB)		

### OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.

# HEADLAMP - XENON TYPE -


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and front combination lamp RH harness connector E24 terminal 5 (BR).

**27 (BR) – 5 (BR) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 (SB) and front combination lamp LH harness connector E44 terminal 5 (SB).

**28 (SB) – 5 (SB) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.


## 6. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E44 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**



OK or NG


- OK >> Replace front combination lamp.
- NG >> Repair harness or connector.

## Headlamp Does Not Change To High Beam (One Side)

AKS007MM

### 1. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned HIGH BEAM position.
5. Check voltage between front combination lamp RH or LH harness connector and ground.



Terminal (+)			(-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	5 (BR)	Ground	Battery voltage
LH	E44	5 (SB)		

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

# HEADLAMP - XENON TYPE -


## 2. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and front combination lamp RH harness connector E24 terminal 5 (BR).

**27 (BR) – 5 (BR) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 (SB) and front combination lamp LH harness connector E44 terminal 5 (SB).

**28 (SB) – 5 (SB) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.


## 3. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E44 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**



OK or NG

- OK >> Replace front combination lamp.
- NG >> Repair harness or connector.

## High Beam Indicator Lamp Does Not Illuminate

### 1. CHECK BULB

Check bulb of high beam indicator lamp.

OK or NG

- OK >> Replace combination meter.
- NG >> Replace indicator bulb.

AKS007MN

## Headlamp Low Beam Does Not Illuminate (Both Sides)

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

☒ Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#).



# HEADLAMP - XENON TYPE -

## 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II


1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST" ITEM screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operation.

**Headlamp low beam should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
2. Make sure headlamp low beam operation.

**Headlamp low beam should operate.**



OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.


## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND position : HL LO REQ ON**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## 4. CHECK HEADLAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.



Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	6 (LG)	Ground	Battery voltage
LH	E44	6 (GY)		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
4. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	6 (LG)	Ground	Battery voltage
LH	E44	6 (GY)		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (LG) and front combination lamp RH harness connector E24 terminal 6 (LG).

**20 (LG) – 6 (LG) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 (GY) and front combination lamp LH harness connector E44 terminal 6 (GY).

**30 (GY) – 6 (GY) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.

# HEADLAMP - XENON TYPE -

## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E24 terminal 7 (B) and ground.


**7 (B) – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E44 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connectors, ballasts (HID control unit), and xenon bulbs. Refer to [LT-34, "Xenon Headlamp Trouble Diagnosis"](#) .
- NG >> Repair harness or connector.



## Headlamp Low Beam Does Not Illuminate (One Side)

AKS007MP

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-34, "Xenon Headlamp Trouble Diagnosis"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.


### 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned 2ND position.
5. Check voltage between front combination lamp RH or LH harness connector and ground.

Terminal (+)			(-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	6 (LG)	Ground	Battery voltage
LH	E44	6 (GY)		

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# HEADLAMP - XENON TYPE -


## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (LG) and front combination lamp RH harness connector E24 terminal 6 (LG).

**20 (LG) – 6 (LG) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 (GY) and front combination lamp LH harness connector E44 terminal 6 (GY).

**30 (GY) – 6 (GY) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
NG >> Repair harness or connector.

## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 7 (B) and ground.


**7 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E44 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connector.  
NG >> Repair harness or connector.



## Headlamp RH Low Beam and High Beam Does Not Illuminate

AKS007MQ

### 1. CHECK BULB

Inspect ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-34, "Xenon Headlamp Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 2.  
NG >> Replace malfunctioning part.


### 2. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH connector.
3. Check continuity between front combination lamp RH harness connector E24 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.




# HEADLAMP - XENON TYPE -

## 3. CHECK HEADLAMP CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and front combination lamp RH harness connector E24 terminal 5 (BR).

**27 (BR) – 5 (BR) : Continuity should exist.**




3. Check continuity between IPDM E/R harness connector E7 terminal 20 (LG) and front combination lamp RH harness connector E24 terminal 6 (LG).

**20 (LG) – 6 (LG) : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.



## Headlamp LH Low Beam and High Beam Does Not Illuminate

### 1. CHECK BULB

Inspect ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-34, "Xenon Headlamp Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.


### 2. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Disconnect front combination lamp LH connector.
3. Check continuity between front combination lamp LH harness connector E44 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.




# HEADLAMP - XENON TYPE -

## 3. CHECK HEADLAMP CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E7 terminal 28 (SB) and front combination lamp LH harness connector E44 terminal 5 (SB).

**28 (SB) – 5 (SB) : Continuity should exist.**



3. Check continuity between IPDM E/R harness connector E7 terminal 30 (GY) and front combination lamp LH harness connector E44 terminal 6 (GY).

**30 (GY) – 6 (GY) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.

## Headlamps Do Not Turn OFF

### 1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure is headlamp turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is OFF : HEAD LAMP SW 1 OFF position : HEAD LAMP SW 2 OFF**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Check combination switch (lighting switch). Refer to [LT-115](#), "[Combination Switch Inspection](#)".

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	OFF		
HEAD LAMP SW2	OFF		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

# HEADLAMP - XENON TYPE -

## 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" by CONSULT-II, and perform self-diagnosis for "BCM".

### Display of self-diagnosis results

NO DTC>> Replace IPDM E/R.

CAN COMM CIRCUIT>> Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT (U1000)			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

---

## General Information for Xenon Headlamp Trouble Diagnosis

AKS00CHH

In most cases, malfunction of xenon headlamp - "does not illuminate", "flickers" or "dark" - is caused by a malfunctioning xenon bulb. A malfunctioning HID control unit or lamp housing, however, may be a cause. Be sure to perform trouble diagnosis following the steps described below.

### Caution:

AKS00CHI

- Installation or removal of connector must be done with lighting switch OFF.
- Disconnect the battery cable from the negative terminal or remove power fuse.
- When the lamp is illuminated (when lighting switch is ON), never touch harness, HID control unit, inside of lamp, or lamp metal parts.
- To check illumination, temporarily install lamp in vehicle. Be sure to connect power at vehicle side connector.
- If error can be traced directly to electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, dislocated terminals, and improper connections.
- Never work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling HID control unit or harnesses (bulb socket harness, ECM harness) is prohibited.
- Immediately after illumination, light intensity and color will fluctuate, but there is nothing wrong.
- When bulb has come to end of its life, brightness will drop significantly, it will flash repeatedly, or light color will turn reddish.

## Xenon Headlamp Trouble Diagnosis

AKS00CHJ

### 1. CHECK 1: XENON HEADLAMP LIGHTING

---

Install normal xenon bulb to corresponding xenon bulb headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace xenon bulb.
- NG >> GO TO 2.

### 2. CHECK 2: XENON HEADLAMP LIGHTING

---

Install normal HID control unit to corresponding xenon headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace HID control unit.
- NG >> GO TO 3.

### 3. CHECK 3: XENON HEADLAMP LIGHTING

---

Install normal xenon lamp housing assembly to corresponding xenon headlamp, and check if lamp lights up.


#### OK or NG

- OK >> Replace xenon headlamp housing assembly. [Malfunction in starter (boosting circuit) in xenon headlamp housing]
- NG >> INSPECTION END

# HEADLAMP - XENON TYPE -

## Aiming Adjustment

AKS00CHK



### PREPARATION BEFORE ADJUSTING

For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on level ground.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.


### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.

#### CAUTION:

Be sure aiming switch is set to "0" when performing aiming adjustment.

2. Use adjusting screws to perform aiming adjustment.




PKIB3650E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)




If the vehicle front body has been repaired and/or headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

### Bulb Replacement HEADLAMP HIGH/LOW BEAM

AKS00CHL

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove air cleaner case (LH) or radiator reservoir tank (RH). Refer to [EM-17, "Removal and Installation"](#), [EM-176, "Removal and Installation"](#), [CO-14, "Removal and Installation"](#), [CO-41, "Removal and Installation"](#).
4. Turn plastic cap counterclockwise and unlock it.
5. Turn bulb socket counterclockwise and unlock it.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.



#### NOTE:

After installation, perform aiming adjustment. Refer to [LT-35, "Aiming Adjustment"](#).


**Headlamp high/low beam (Xenon) : 12V - 35W (D2S)**

# HEADLAMP - XENON TYPE -

## DAYTIME/PARKING LAMP

1. Turn lighting switch OFF.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from its socket.
4. Installation is the reverse order of removal.


**Daytime/Parking lamp (Clearance lamp) : 12V - 21/5W lamp)**



## FRONT TURN SIGNAL LAMP

1. Turn lighting switch OFF.
2. Turn bulb socket counterclockwise with suitable tool and unlock it.
3. Remove bulb from its socket.
4. Installation is the reverse order of removal.

**Front turn signal lamp : 12V - 21W (amber)**




## FRONT SIDE MARKER LAMP

1. Turn lighting switch OFF.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from its socket.
4. Installation is the reverse order of removal.

**Front side marker lamp : 12V - 3.8W**

### CAUTION:


**After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.**



## Removal and Installation

### REMOVAL

1. Disconnect the battery cable from the negative terminal or remove power fuse.
2. Remove front bumper. Refer to [EI-14, "Removal and Installation"](#) in "EI" section.
3. Remove headlamp mounting bolts and nut.
4. Remove plastics bumper bracket, then pull headlamp toward vehicle front, disconnect connector, and remove headlamp.



# HEADLAMP - XENON TYPE -

## INSTALLATION

Installation is the reverse order of removal.


**Headlamp mounting bolt**  : 6.1 N·m (0.62 kg-m, 54 in-lb)

### NOTE:

After installation, perform aiming adjustment. Refer to [LT-35, "Aiming Adjustment"](#).

## Disassembly and Assembly

AKS00CHN



- |                              |                                     |  |
|------------------------------|-------------------------------------|--|
| 1. Headlamp housing assembly | 2. Side marker lamp bulb            | 3. Side marker lamp bulb socket        |
| 4. Plastic cap               | 5. Seal packing                     | 6. Screw                               |
| 7. HID control unit          | 8. Daytime/Parking lamp bulb socket | 9. Daytime/Parking lamp bulb           |
| 10. Retaining spring         | 11. Front turn signal lamp bulb     | 12. Front turn signal lamp bulb socket |
| 13. Xenon bulb               | 14. Xenon bulb socket               | 15. Seal packing                       |

## DISASSEMBLY

1. Turn plastic cap counterclockwise and unlock it.
2. Turn xenon bulb socket counterclockwise, and unlock it.
3. Unlock retaining spring, and remove xenon bulb.
4. Disconnect HID control unit connector, and remove HID control unit screws.
5. Turn daytime/parking lamp bulb socket counterclockwise and unlock it.
6. Remove daytime/parking lamp bulb from its socket.
7. Turn front turn signal lamp bulb socket counterclockwise and unlock it.
8. Remove front turn signal lamp bulb from its socket.
9. Turn front side marker lamp bulb socket counterclockwise and unlock it.
10. Remove front side marker lamp bulb from its socket.

## ASSEMBLY

Assembly is the reverse order of disassembly.

**HID control unit mounting screw**  : 3.2 N·m (0.33 kg-m, 28 in-lb)

### CAUTION:

- When HID control unit is removed, reinstall it securely and avoid any looseness.
- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.


# DAYTIME LIGHT SYSTEM

## DAYTIME LIGHT SYSTEM

PPF:284B2

### Component Parts and Harness Connector Location

AKS007MZ



## System Description

AKS007N0

Daytime light system turns ON daytime light lamps while driving. Daytime light lamps are not turned ON if engine is activated with parking brake ON. Take off parking brake to turn ON daytime light lamps. The lamps turn OFF when the lighting switch is in the 2ND position or AUTO position (headlamp is ON) and when the lighting switch is in the PASSING position (daytime light lamps are not turned OFF only by parking brake itself).

The parking brake signal and engine run/stop signal are sent to BCM (body control module) by CAN communication line, and control daytime light system.

## OUTLINE

Power is supplied at all times

- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8,
- through 15A fuse [No. 22, located in fuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter M, located in fuse, fusible link and relay box)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

---

- to BCM terminal 55,
- through 10A fuse (No. 36, located in fuse, fusible link and relay box)
- to daytime light relay terminals 2 and 5.

When ignition switch is in ON or START position, power is supplied

- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 7,
- through 15A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85,
- to BCM terminals 49 and 52
- through grounds M35, M45 and M85.

## DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light relay terminal 1
- to combination meter terminal 10,
- through daytime light relay terminal 3
- to clearance lamp RH and LH terminal 1.

Ground is supplied

- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85,
- to clearance lamp RH and LH terminal 3
- through grounds E21, E50 and E51.

With power and grounds supplied, the daytime light lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## AUTO LIGHT OPERATION

Refer to [LT-55, "System Description"](#) in "AUTO LIGHT SYSTEM".

## CAN Communication System Description

AKS007N1

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS0080T

Refer to [LAN-30, "CAN Communication Unit"](#) .

# DAYTIME LIGHT SYSTEM

## Schematic

AKS007N3



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# DAYTIME LIGHT SYSTEM

## Wiring Diagram — DTRL —

AKS007N4






REFER TO THE FOLLOWING.  
 (E211), (F102) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2046E

# DAYTIME LIGHT SYSTEM

LT-DTRL-02




REFER TO THE FOLLOWING.

- (E21) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4), (M90) -ELECTRICAL UNITS

TKWM0816E

# DAYTIME LIGHT SYSTEM

LT-DTRL-03




REFER TO PG-POWER.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)  
 (E7), (E8), (E9)

NEXT PAGE



PRE-CEDED PAGE



REFER TO THE FOLLOWING.  
 (E21) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM0609E

# DAYTIME LIGHT SYSTEM







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

## Terminals and Reference Values for BCM

AKS00CHO

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p>PKIB3468E</p>
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p>PKIB3469E</p>
4	PU/W	Combination switch input 3			
5	Y/R	Combination switch input 2			
6	SB	Combination switch input 1			
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p>PKIB3470E</p>
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p>PKIB3471E</p>
34	W/B	Combination switch output 3			
35	W/G	Combination switch output 2			
36	W/R	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	R	CAN – L	—	—	—
42	L/R	Battery power supply	OFF	—	Battery voltage
49	B	Ground	ON	—	Approx. 0V
52	B	Ground	ON	—	Approx. 0V
55	G	Battery power supply	OFF	—	Battery voltage

## How to Proceed With Trouble Diagnosis

AKS007N6

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-39, "System Description"](#).
3. Perform Preliminary Check. Refer to [LT-47, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Does daytime light lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# DAYTIME LIGHT SYSTEM

AKS007N7

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
Daytime light relay	Battery	36

Refer to [LT-42, "Wiring Diagram — DTRL —"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		(-)	Ignition switch position	
Connector	Terminal (Wire color)		OFF	ON
M3	38 (W/L)	Ground	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

### 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M4	49 (B)	Ground	Yes
	52 (B)		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# DAYTIME LIGHT SYSTEM

## INSPECTION PARKING BRAKE SWITCH CIRCUIT

### 1. CHECK BRAKE INDICATOR

1. Turn ignition switch ON.
2. When a parking brake is made ON/OFF, it checks whether brake indicator lamp of combination meter lights up / puts out the light.

OK or NG

- OK >> INSPECTION END  
NG >> GO TO 2.


### 2. CHECK PARKING BRAKE SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector E207 terminal 1 (L) and ground.

**1 (L) – Ground : Battery voltage.**

OK or NG

- OK >> Replace parking brake switch.  
NG >> GO TO 3.




### 3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M20 terminal 23 (PU/W) and parking brake switch harness connector E207 terminal 1 (L).

**1 (L) – 23 (PU/W) : Continuity should exist.**

OK or NG

- OK >> Replace combination meter.  
NG >> Repair harness or connector.



# DAYTIME LIGHT SYSTEM

## CONSULT-II Functions (BCM)

AKS007NB

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# DAYTIME LIGHT SYSTEM

4. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item		Contents
IGN ON SW	"ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW	"ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW	"ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1	"ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2	"ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST	"ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW <sup>NOTE 1</sup>	"ON/OFF"	Displays status of lighting switch as judged from lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR	"ON/OFF"	Displays status of driver door as judged from driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF"	Displays status of passenger door as judged from passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF"	Displays status of rear door as judged from rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF"	Displays status of rear door as judged from rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)

# DAYTIME LIGHT SYSTEM

Monitor item		Contents
BACK DOOR SW	"ON/OFF"	Displays status of back door as judged from back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R	"ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
ENGINE RUN <sup>NOTE 2</sup>	"ON/OFF"	Displays status (Engine running: ON/Others: OFF) as judged from engine status signal.
PKB SW <sup>NOTE 2</sup>	"ON/OFF"	Displays status (Parking brake switch: ON/Others: OFF) as judged from parking brake switch signal.
CARGO LAMP SW <sup>NOTE 3</sup>	"OFF"	—
OPTICAL SENSOR <sup>NOTE 1</sup>	"0 - 5V"	Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

1. Vehicles without auto light system display this item, but cannot be monitored.
2. Vehicles without daytime light system display this item, but cannot be monitored.
3. This item is displayed, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows front fog lamp relay to operate by switching ON-OFF
DTRL <sup>NOTE 1</sup>	Allows daytime light lamp operate by switching ON-OFF
CORNERING LAMP <sup>NOTE 2</sup>	—
CARGO LAMP <sup>NOTE 2</sup>	—

**NOTE:**

1. Vehicles without daytime light lamp system display this item, but cannot be tested.
2. This item is displayed, but cannot be tested.

# DAYTIME LIGHT SYSTEM

AKS007N9

## Daytime Light Control Does Not Operate Properly

### 1. CHECK DAYTIME LIGHT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime light relay.
3. Check voltage between daytime light relay harness connector E15 terminal 2 (BR) and ground.


**2 (BR) – Ground : Battery voltage.**

4. Check voltage between daytime light relay harness connector E15 terminal 5 (BR) and ground.

**5 (BR) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 2.  
NG >> Repair harness or connector.




### 2. CHECK DAYTIME LIGHT RELAY

Apply battery voltage to between daytime light relay terminal 1, 2 and check continuity between terminal 3 and 5.

**3 – 5 : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Replace daytime light relay.



### 3. CHECK DAYTIME LIGHT RELAY CIRCUIT

1. Disconnect clearance lamp RH and LH connector.
2. Check continuity between daytime light relay connector E15 terminal 3 (G) and clearance lamp RH harness connector E23 terminal 1 (G).


**3 (G) – 1 (G) : Continuity should exist.**

3. Check continuity between daytime light relay connector E15 terminal 3 (G) and clearance lamp LH harness connector E43 terminal 1 (G).

**3 (G) – 1 (G) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.



# DAYTIME LIGHT SYSTEM

## 4. CHECK GROUND

1. Check continuity between clearance lamp RH harness connector E23 terminal 3 (B) and ground.


**3 (B) – Ground : Continuity should exist.**

2. Check continuity between clearance lamp LH harness connector E43 terminal 3 (B) and ground.

**3 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.



## 5. CHECK BULB

Inspect bulbs of lamp which do not illuminate.

OK or NG

- OK >> GO TO 6.  
NG >> Replace bulb.


## 6. CHECK DAYTIME RELAY CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between daytime lamp relay harness connector E15 terminal 1 (L) and combination meter harness connector M20 terminal 10 (L/W).

**1 (L) – 10 (L/W) : Continuity should exist.**

OK or NG

- OK >> GO TO 7.  
NG >> Repair harness or connector.



## 7. CHECK INPUT SIGNAL

1. Connect combination meter connector.
2. Start engine running.
3. Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "ENGINE RUN" turns ON-OFF linked with operation of engine running or stop.

**Engine running : ENGINE RUN ON**

**Engine stop : ENGINE RUN OFF**


4. Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "PKB SW" turns ON-OFF linked with operation of parking brake switch.

**Parking brake ON : PKR SW ON**

**Parking brake OFF : PKR SW OFF**

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).  
NG >> GO TO 8.



# DAYTIME LIGHT SYSTEM

## 8. CHECKING CAN COMMUNICATIONS

Select "BCM" by CONSULT-II, and perform self-diagnosis for "BCM".

### Displayed self-diagnosis results

NO DTC>> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

CAN COMM CIRCUIT>> Check BCM CAN communication system.  
Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

### Aiming Adjustment

AKS007NA

Refer to [LT-35, "Aiming Adjustment"](#) in "HEADLAMP -XENON TYPE-".

### Bulb Replacement

AKS007NB

Refer to [LT-36, "Bulb Replacement"](#) in "HEADLAMP -XENON TYPE-".

### Removal and Installation

AKS007NC

Refer to [LT-37, "Removal and Installation"](#) in "HEADLAMP -XENON TYPE-".

### Disassembly and Assembly

AKS007ND

Refer to [LT-38, "Disassembly and Assembly"](#) in "HEADLAMP -XENON TYPE-".


# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PF28491

### Component Parts and Harness Connector Location

AKS007ER



PKIB3474E

## System Description

AKS007ES

Automatically turns ON/OFF parking lamps and the headlamps in accordance with ambient light. Timing for when the lamps turn ON/OFF can be selected using four modes.

### OUTLINE

The auto light control system has an optical sensor inside it that detects outside brightness. When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking lamps and the headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [LT-63. "SETTING CHANGE FUNCTIONS"](#).

Optical sensor control mode can be changed by the function setting of CONSULT-II or display.

Optical sensor, power is supplied

- from BCM (body control module) terminal 17
- to optical sensor terminal 1.

Optical sensor, ground is supplied

- to optical sensor terminal 3
- through BCM terminal 18.

# AUTO LIGHT SYSTEM

When ignition switch is turn to ON position, and  
When outside brightness is darker than prescribed level, input is supplied

- from BCM terminal 14
- to optical sensor terminal 2

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-55, "System Description"](#).

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the AUTO position, and the ignition switch is turned from ON or ACC to OFF, and one of the front door is opened, the battery saver control feature is activated. Under this condition, the headlamp remain illuminated for 5 minutes, then the headlamp are turned OFF. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## DELAY TIMER FUNCTION

Delay timer function carries out a function that BCM activates the timer and controls lights out of headlamps by door switch signal and lightning switch signal when turning the Ignition switch OFF while it is ON and headlamps are ON by the auto light function.

Timer types are a 5-minute timer and a 45-second timer

- When opening any door (door switch is ON), the 5-minute timer starts and then headlamps go out five minutes later
- When all the doors are closed (from door switch ON to OFF), the 45-second timer starts and then headlamps go out forty-five seconds later. If any door is opened (door switch ON) while the 45-second timer is in operation, the 5-minute timer starts again
- The timer stops when turning on the ignition switch or turning off the auto light switch under the above conditions.

Delay timer control mode can be changed by the function setting of CONSULT-II or display.

## CAN Communication System Description

AKS007ET

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

AKS0080U

Refer to [LAN-30, "CAN Communication Unit"](#).

## Major Components and Functions


AKS007EV

Components	Functions
BCM	● Turns on/off circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), driver door switch, passenger door switch, rear door switch, and ignition switch (ON, OFF).
Optical sensor	● Converts outside brightness (lux) to voltage, and sends it to BCM. (Detects brightness of 50 to 1,300 lux)

# AUTO LIGHT SYSTEM

## Schematic

AKS007EW



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT



TKWM0611E

# AUTO LIGHT SYSTEM

## Wiring Diagram — AUTO/L —

AKS007EX

LT-AUTO/L-01




REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) , (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3) , (M4) -ELECTRICAL UNITS

TKWM0817E

# AUTO LIGHT SYSTEM

LT-AUTO/L-02





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

REFER TO THE FOLLOWING.  
 (B1), (B201) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M3), (B14) -ELECTRICAL UNITS

TKWM1073E

# AUTO LIGHT SYSTEM

LT-AUTO/L-03







REFER TO THE FOLLOWING.  
E211 -SUPER MULTIPLE  
JUNCTION (SMJ)

TKWM0614E

# AUTO LIGHT SYSTEM

## Terminals and Reference Values for BCM

AKS007XO

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3468E</p>	
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3469E</p>	
4	PU/W	Combination switch input 3				
5	Y/R	Combination switch input 2				
6	SB	Combination switch input 1				
11	LG/R	Ignition switch (ACC)	ACC	—	Battery voltage	
12	P/B	Front door switch (Passenger side) signal	OFF	Front door switch (Passenger side)	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
13	P/L	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
14	P	Optical sensor signal	ON	When optical sensor is illuminated	3.1 V or more <sup>Note</sup>	
				When optical sensor is not illuminated	0.6 V or less	
17	Y/G	Optical sensor power supply	ON	—	Approx. 5V	
18	B	Sensor ground	ON	—	Approx. 0V	
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3470E</p>	
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3471E</p>	
34	W/B	Combination switch output 3				
35	W/G	Combination switch output 2				
36	W/R	Combination switch output 1				
38	W/L	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN – H	—	—	—	
40	R	CAN – L	—	—	—	
42	L/R	Battery power supply	OFF	—	Battery voltage	
49	B	Ground	ON	—	Approx. 0V	
52	B	Ground	ON	—	Approx. 0V	
55	G	Battery power supply	OFF	—	Battery voltage	
58	L	Back door closure motor (Door switch)	OFF	Back door switch	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage

# AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
62	W	Front door switch (Driver side) signal	OFF	Front door switch (Driver side)	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
63	P	Rear door switch LH signal	OFF	Rear door switch LH	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage

**NOTE:**

Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy standard.

## Terminals and Reference Values for IPDM E/R

AKS00714

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
20	LG	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
22	R	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	Approx. 0V
					ON	Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage
28	SB	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage
30	GY	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	—	Approx. 0V
48	L	CAN – H	—	—	—	—
49	R	CAN – L	—	—	—	—
60	B	Ground	ON	—	—	Approx. 0V

## How to Proceed With Trouble Diagnosis

AKS007F0

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-55, "System Description"](#) .
3. Perform Preliminary Check. Refer to [LT-63, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction. Refer to [LT-70, "Symptom Chart"](#) .
5. Does auto light system operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# AUTO LIGHT SYSTEM

AKS007F1

## Preliminary Check SETTING CHANGE FUNCTIONS

- Sensitivity of auto light system can be adjusted using CONSULT-II. Refer to [LT-66, "WORK SUPPORT"](#).

## CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71
		72
		74
		76
		86

Refer to [LT-58, "Wiring Diagram — AUTO/L —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		Terminal (-)	Ignition switch position		
Connector	Terminal (Wire color)		OFF	ACC	ON
M3	11 (LG/R)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



PKIB5197E

# AUTO LIGHT SYSTEM

## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M4	49 (B)	Ground	Yes
	52 (B)		

OK or NG

OK >> INSPECTION END

NG >> Check ground circuit harness.



# AUTO LIGHT SYSTEM

## CONSULT-II Functions (BCM)

AKS00715

- CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# AUTO LIGHT SYSTEM

4. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "CUSTOM A/LIGHT SETTING" or "ILL DELAY SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "NORMAL" or "MODE 2 - 4" of setting to be changed (CUSTOM A/LIGHT SETTING), Touch "MODE1-8" of setting to be changed (ILL DELAY SET).
6. Touch "SETTING CHANGE".
7. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
8. Touch "END".

### Work Support Setting Item

- Sensitivity of auto light can be selected and set from four modes.

Work item	Description
CUSTOMA/LIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. <ul style="list-style-type: none"> <li>● MODE 1 (Normal)/ MODE 2 (sensitive)/MODE 3 (Desensitized)/MODE4 (Insensitive)</li> </ul>
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. <ul style="list-style-type: none"> <li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)</li> </ul>

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW                      "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW                      "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW                      "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.

# AUTO LIGHT SYSTEM

Monitor item	Contents
HEAD LAMP SW 1	"ON/OFF" Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2	"ON/OFF" Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST	"ON/OFF" Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW <sup>NOTE 1</sup>	"ON/OFF" Displays status of lighting switch as judged from lighting switch signal. (AUTO position: ON/ Other than AUTO position: OFF)
PASSING SW	"ON/OFF" Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF" Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR	"ON/OFF" Displays status of driver door as judged from driver door switch signal. (Door is open: ON/ Door is closed: OFF)
DOOR SW - AS	"ON/OFF" Displays status of passenger door as judged from passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF" Displays status of rear door as judged from rear door switch (RH) signal. (Door is open: ON/ Door is closed: OFF)
DOOR SW - RL	"ON/OFF" Displays status of rear door as judged from rear door switch (LH) signal. (Door is open: ON/ Door is closed: OFF)
BACK DOOR SW	"ON/OFF" Displays status of back door as judged from back door switch signal. (Door is open: ON/ Door is closed: OFF)
TURN SIGNAL R	"ON/OFF" Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
ENGINE RUN <sup>NOTE 2</sup>	"ON/OFF" Displays status (Engine running: ON/Others: OFF) as judged from engine status signal.
PKB SW <sup>NOTE 2</sup>	"ON/OFF" Displays status (Parking brake switch: ON/Others: OFF) as judged from parking brake switch signal.
CARGO LAMP SW <sup>NOTE 3</sup>	—
OPTICAL SENSOR <sup>NOTE 1</sup>	"0 - 5V" Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

1. Vehicles without auto light system display this item, but cannot be monitored.
2. Vehicles without daytime light system display this item, but cannot be monitored.
3. This item is displayed, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
DTRL <sup>NOTE 1</sup>	Allows day time light lamp operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE 2</sup>	—
CARGO LAMP <sup>NOTE 2</sup>	—

# AUTO LIGHT SYSTEM

**NOTE:**

1. Vehicles without daytime light lamp system display this item, but cannot be tested.
2. This item is displayed, but cannot be tested.

## CONSULT-II Functions (IPDM E/R)

AKS00716

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


Check Item, Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-21, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

### CONSULT-II BASIC OPERATION


**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not displayed, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# AUTO LIGHT SYSTEM

- Select the desired part to be diagnosed on "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

- Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "START".
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, the display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested, and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option (Head lamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

# AUTO LIGHT SYSTEM

## Symptom Chart

AKS007F3

Trouble phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Parking lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-66, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-70, "Lighting Switch Inspection"</a> .</li> <li>● Refer to <a href="#">LT-71, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM.</p>
<p>Parking lamps illuminate when outside of the vehicle becomes dark, but headlamps stay off. (Lighting switch 1ST position and 2ND position operate normally.)</p>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-66, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-71, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM.</p>
<p>Auto light adjustment system will not operate. (Lighting switch AUTO, 1ST position and 2ND position operate normally.)</p>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-71, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>
<p>Auto light adjustment system of combination meter will not operate.</p>	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> </ul>
<p>Shut off delay feature will not operate.</p>	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> <li>● Refer to <a href="#">BL-42, "Check Door Switch"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>

## Lighting Switch Inspection

AKS007F4

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

 With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is AUTO : AUTO LIGHT SW ON position**


 Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#) .

OK or NG

OK >> INSPECTION END

NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#) .



# AUTO LIGHT SYSTEM

## Optical sensor System Inspection

AKS007F5

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "OPTICAL SENSOR", check difference in the voltage when auto light sensor is illuminated and not illuminated.

**Illuminated**

**OPTICAL SENSOR : 3.1V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6V or less**

#### CAUTION:

Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.

② Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector M3 terminal 14 (P) and ground.

**Illuminated**

**OPTICAL SENSOR : 3.1V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6V or less**

#### CAUTION:

Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.


OK or NG

OK >> INSPECTION END

NG >> GO TO 2.

DATA MONITOR	
MONITOR	
OPTICAL SENSOR	0.75V
RECORD	
MODE	BACK
LIGHT	COPY

PKIA7596E



### 2. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M3 terminal 17 (Y/G) and optical sensor harness connector M37 terminal 1 (Y/G).

**17 (Y/G) – 1 (Y/G) : Continuity should exist.**


4. Check continuity (short circuit) between BCM harness connector M3 terminal 17 (Y/G) and ground.

**17 (Y/G) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# AUTO LIGHT SYSTEM

## 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M3 terminal 14 (P) and optical sensor harness connector M37 terminal 2 (P).

**14 (P) – 2 (P) : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M3 terminal 14 (P) and ground.

**14 (P) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M3 terminal 18 (B) and optical sensor harness connector M37 terminal 3 (B).

**18 (B) – 3 (B) : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M3 terminal 18 (B) and ground.

**18 (B) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



## 5. CHECK OPTICAL SENSOR VOLTAGE


1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M3 terminal 17 (Y/G) and ground.

**17 (Y/G) – Ground : Approx. 5V**

OK or NG

OK >> Replace optical sensor.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).




# AUTO LIGHT SYSTEM

## Removal and Installation of Optical Sensor

AKS007F6

### REMOVAL

1. Insert a screwdriver or similar tool and remove front defroster grill (LH). Refer to [IP-15, "\(V\) Front Defroster Grille \(RH/LH\)"](#) in "IP" section.
2. Disconnect optical sensor connector.
3. Remove optical sensor.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# HEADLAMP AIMING CONTROL

## HEADLAMP AIMING CONTROL

PFP:26010

### Schematic

AKS00717



TKWH0337E




# HEADLAMP AIMING CONTROL

## Wiring Diagram — H/AIM —

AKS007CF

LT-H/AIM-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4) -ELECTRICAL UNITS


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP AIMING CONTROL

LT-H/AIM-02


▬ : DATA LINE

REFER TO PG-POWER.



PRE-  
CEDING  
PAGE

▶ NEXT PAGE




REFER TO THE FOLLOWING.

(E21) -SUPER MULTIPLE JUNCTION (SMJ)


TKWM1074E

# HEADLAMP AIMING CONTROL

LT-H/AIM-03



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(E211) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B)


TKWM0618E

# HEADLAMP AIMING CONTROL

## Removal and Installation

### REMOVAL

1. Remove combination meter. Refer to [DI-25, "Removal and Installation of Combination Meter"](#) in "DI" section.
2. Remove screws for removing headlamp aiming switch from meter housing.
3. Remove screws and then remove headlamp aiming switch.




### INSTALLATION

Installation is the reverse order of removal.

### Switch Circuit Inspection

Using a circuit tester, check resistance between the headlamp aiming switch connector terminals in each operation status of the aiming switch.




# FRONT FOG LAMP

## FRONT FOG LAMP

PPF:26150

### Component Parts and Harness Connector Location

AKS00705



PKIB3475E

### System Description

AKS007C1

Control of the front fog lamps is dependent upon the position of the combination switch (lighting switch). The lighting switch must be in the 2ND position or AUTO position (headlamp is ON) for front fog lamp operation. When the lighting switch is placed in the fog lamp position the BCM (body control module) receives input signal requesting the front fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the front fog lamp relay coil. When activated, this relay directs power to the front fog lamps.

### OUTLINE

Power is supplied at all times

- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R, and
- to ignition relay, located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R.

Power is also supplied at all times

- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 15A fuse [No. 22, located in fuse block (J/B)]
- to BCM terminal 42.

When ignition switch is in ON or START position, power is supplied

- through 15A fuse [No. 1, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

---

- to BCM terminal 38.

When ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds M35, M45 and M85,
- to IPDM E/R terminals 38 and 60
- through grounds E21, E50 and E51.

## FRONT FOG LAMP OPERATION

The front fog lamp switch is built into combination switch. The lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and the front fog lamp switch must be ON for front fog lamp operation.

With the front fog lamp switch in the ON position, the CPU located in the IPDM E/R grounds the coil side of the front fog lamp relay. The front fog lamp relay then directs power

- through IPDM E/R terminal 37
- to front fog lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front fog lamp RH terminal 1.

Ground is supplied

- to front fog lamp LH terminal 2
- through grounds E21, E50 and E51,
- to front fog lamp RH terminal 2
- through grounds E21, E50 and E51.

With power and grounds supplied, front fog lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3. "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), the front fog lamp switch is ON, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the front fog lamps (and headlamps) remain illuminated for 5 minutes, then the front fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

AKS007CJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

AKS0080V

Refer to [LAN-30. "CAN Communication Unit"](#) .




# FRONT FOG LAMP

## Wiring Diagram — F/FOG —

AKS007CL

LT-F/FOG-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4) -ELECTRICAL UNITS





TKWM0819E



# FRONT FOG LAMP

## Terminals and Reference Values for BCM

AKS007XP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3468E</p>
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3469E</p>
4	PU/W	Combination switch input 3			
5	Y/R	Combination switch input 2			
6	SB	Combination switch input 1			
11	LG/R	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3470E</p>
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3471E</p>
34	W/B	Combination switch output 3			
35	W/G	Combination switch output 2			
36	W/R	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	R	CAN - L	—	—	—
42	L/R	Battery power supply	OFF	—	Battery voltage
49	B	Ground	ON	—	Approx. 0V
52	B	Ground	ON	—	Approx. 0V
55	G	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS007CN

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	W	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and front fog lamp switch must be ON.	OFF	Approx. 0V
					ON	Battery voltage
37	SB	Front fog lamp (LH)	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and front fog lamp switch must be ON.	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
48	L	CAN - H	—	—	—	

# FRONT FOG LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
49	R	CAN – L	—	—	—
60	B	Ground	ON	—	Approx. 0V

## How to Proceed With Trouble Diagnosis

AKS007CO

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-79, "System Description"](#) .
3. Perform Preliminary Check. Refer to [LT-84, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS007CP

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-81, "Wiring Diagram — F/FOG —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# FRONT FOG LAMP


## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M3	11 (LG/R)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.




## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Continuity
Connector	Terminal (Wire color)	
M4	49 (B)	Ground Yes
	52 (B)	

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

Refer to [LT-18, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP.

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-20, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP.

# FRONT FOG LAMP

AKS00719

## Front Fog Lamp Does Not Illuminate (Both Sides)

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is FOG : FR FOG SW ON position**

⊗ Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
FR FOG SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

### 2. FRONT FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure front fog lamp operation.

**Front fog lamp should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-24, "Auto Active Test"](#) .
2. Make sure front fog lamp operation.

**Front fog lamp should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is FOG : FR FOG REQ ON position**

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
MODE	BACK	LIGHT	COPY

SKIA5774E

DATA MONITOR			
MONITOR			
FR FOG REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5898E

# FRONT FOG LAMP

## 4. CHECK FRONT FOG LAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When front fog lamp is operating, check voltage between front fog lamp RH and LH harness connector and ground.

Terminal			(-)	Voltage
(+)		Terminal (Wire color)		
Connector				Ground
RH	E102	1 (W)		
LH	E45	1 (SB)		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connector.
3. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
4. When front fog lamp is operating, check voltage between front fog lamp RH and LH harness connector and ground.

Terminal			(-)	Voltage
(+)		Terminal (Wire color)		
Connector				Ground
RH	E102	1 (W)		
LH	E45	1 (SB)		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.

## 5. CHECK FRONT FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 (W) and front fog lamp RH harness connector E102 terminal 1 (W).



**36 (W) – 1 (W) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 (SB) and front fog lamp LH harness connector E45 terminal 1 (SB).

**37 (SB) – 1 (SB) : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.



# FRONT FOG LAMP

## 6. CHECK FRONT FOG LAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front fog lamp RH harness connector E102 terminal 2 (B) and ground.


**2 (B) – Ground : Continuity should exist.**

3. Check continuity between front fog lamp LH harness connector E45 terminal 2 (B) and ground.

**2 (B) – Ground : Continuity should exist.**

### OK or NG

- OK >> Check front fog lamp bulbs.  
NG >> Repair harness or connector.



## Front Fog Lamp Does Not Illuminate (One Side)

AKS0071A

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

### OK or NG

- OK >> GO TO 2.  
NG >> Replace front fog lamp bulb.

## 2. CHECK FRONT FOG LAMP CIRCUIT

1. Disconnect IPDM E/R connector and front fog lamp RH or LH connector.
2. Check continuity between IPDM E/R harness connector E8 terminal 36 (W) and front fog lamp RH harness connector E102 terminal 1 (W).


**36 (W) – 1 (W) : Continuity should exist.**

3. Check continuity between IPDM E/R harness connector E8 terminal 37 (SB) and front fog lamp LH harness connector E45 terminal 1 (SB).

**37 (SB) – 1 (SB) : Continuity should exist.**

### OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.



## 3. CHECK FRONT FOG LAMP GROUND

1. Check continuity between front fog lamp RH harness connector E102 terminal 2 (B) and ground.


**2 (B) – Ground : Continuity should exist.**

2. Check continuity between front fog lamp LH harness connector E45 terminal 2 (B) and ground.

**2 (B) – Ground : Continuity should exist.**

### OK or NG

- OK >> Replace IPDM E/R.  
NG >> Repair harness or connector.



# FRONT FOG LAMP


## Aiming Adjustment

AKS007CT


Front fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.


Adjust aiming in the vertical direction by turning adjusting screw.



1. Set the distance between the screen and the center of front fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is 100 mm (3.94 in) below the height of front fog lamp centers as shown at left.
  - When performing adjustment, if necessary, cover headlamps and opposite front fog lamp.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

## Bulb Replacement


AKS007CU

1. Remove left side fender protector (front). Refer to [EI-24, "Removal and Installation"](#), [EI-14, "Removal and Installation"](#) in "EI" section.
2. Disconnect fog lamp connector.
3. Turn bulb socket counterclockwise and unlock it.

**Front fog lamp : 12 V - 51 W (HB4 halogen)**

### CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Never leave bulb out of front fog lamp reflector for a long time because dust, moisture smoke, etc. May affect the performance of front fog lamp. When replacing bulb, be sure to replace it with new one.




## Removal and Installation

### REMOVAL

AKS007CV

1. Remove front bumper fascia. Refer to [EI-14, "Removal and Installation"](#) in "EI" section.
2. Remove front fog lamp mounting bolt.
3. Pull out front fog lamp from vehicle and disconnect fog lamp connector.



### INSTALLATION

Installation is the reverse order of removal.

**Front fog lamp mounting bolt**  : 5.5 N-m (0.55 kg-m, 48 in-lb)


# TURN SIGNAL AND HAZARD WARNING LAMPS

## TURN SIGNAL AND HAZARD WARNING LAMPS

PPF:26120

### Component Parts and Harness Connector Location

AKS00706



### System Description

#### TURN SIGNAL OPERATION

AKS007CW

Power is supplied at all times

- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 1.

When ignition switch is in ON or START position, power is supplied

- through 15A fuse [No. 1, located in fuse block (J/B)]
- to BCM (body control module) terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 7.

When ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds M35, M45 and M85,
- to rear combination lamp control unit terminal 7
- through grounds E21, E50 and E51,
- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85.

#### LH Turn Signal Lamp

When the turn signal switch is moved to the left position, BCM output turn signal from BCM terminal 45, interpreting it as turn signal is ON.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

Connected from BCM terminal 45 to front combination lamp LH terminal 4.

Turn signal lamp turns ON

- through front combination lamp LH terminal 8
- to grounds E21, E50 and E51.

Connected from BCM terminal 45 to rear combination lamp control unit terminal 4.

Rear turn signal (LED) turns ON

- through rear combination lamp control unit terminal 11
- to rear combination lamp LH terminal 3,
- through rear combination lamp LH terminal 4
- to rear combination lamp control unit terminal 10.

BCM sends signal to the unified meter and A/C amp. through CAN communication lines, and turns ON turn signal indicator lamp with combination meter.

When rear turn signal lamp (LED) does not turn ON, rear combination lamp control unit sends signal to combination meter. And then unified meter and A/C amp. ends turn LED burnout status signal to BCM through CAN communication lines for speeding up turn signal blinking.

## RH Turn Signal Lamp

When the turn signal switch is moved to right position, BCM output turn signal from BCM terminal 46, interpreting it as turn signal is ON.

Connected from BCM terminal 46 to front combination lamp RH terminal 4.

Turn signal lamp turns ON

- through front combination lamp RH terminal 8
- to grounds E21, E50 and E51.

Connected from BCM terminal 46 to rear combination lamp control unit terminal 5.

Rear turn signal (LED) turns ON

- through rear combination lamp control unit terminal 9
- to rear combination lamp RH terminal 3,
- through rear combination lamp RH terminal 4
- to rear combination lamp control unit terminal 8.

BCM sends signal to the unified meter and A/C amp. through CAN communication lines, and turns ON turn signal indicator lamp with combination meter.

When rear turn signal lamp (LED) does not turn ON, rear combination lamp control unit sends signal to combination meter. And then unified meter and A/C amp. ends turn LED burnout status signal to BCM through CAN communication lines for speeding up turn signal blinking.

## HAZARD LAMP OPERATION

Power is supplied at all times

- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8,
- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 1.

Ground is supplied

- through BCM terminals 49 and 52
- to grounds M35, M45 and M85,
- through rear combination lamp control unit terminal 7
- to grounds E21, E50 and E51,
- through combination meter terminals 5, 6 and 15
- to grounds M35, M45 and M85.

When hazard switch is depressed, ground is supplied

- to hazard switch terminal 2
- through BCM terminal 29,

# TURN SIGNAL AND HAZARD WARNING LAMPS

- to grounds M35, M45 and M85
- through hazard switch terminal 1.

When the hazard switch is depressed, BCM output turn signal from BCM terminals 45 and 46, interpreting it as turn signal is ON.

Connected from BCM terminal 45 and 46 to front combination lamp terminal 4.

Turn signal lamp turns ON

- through front combination lamp terminal 8
- to grounds E21, E50 and E51.

Connected from BCM terminals 45 and 46 to rear combination lamp control unit terminals 4 and 5.

Rear turn signal (LED) turns ON

- through rear combination lamp control unit terminal 11
- to rear combination lamp LH terminal 3,
- through rear combination lamp LH terminal 4
- to rear combination lamp control unit terminal 10,
- through rear combination lamp control unit terminal 9
- to rear combination lamp RH terminal 3,
- through rear combination lamp RH terminal 4
- to rear combination lamp control unit terminal 8.

BCM sends signal to the unified meter and A/C amp. through CAN communication lines, and turns ON turn signal indicator lamp with combination meter.

When rear turn signal lamp (LED) does not turn ON, rear combination lamp control unit sends signal to combination meter. And then unified meter and A/C amp. ends turn LED burnout status signal to BCM through CAN communication lines for speeding up turn signal blinking.

## REMOTE CONTROL ENTRY SYSTEM OPERATION

Power is supplied at all times

- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8,
- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 1.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds M35, M45 and M85,
- to rear combination lamp control unit terminal 7
- through grounds E21, E50 and E51,
- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85.

When the remote control entry system is triggered by input from key fob, BCM output turn signal from BCM terminals 45 and 46, interpreting it as turn signal is ON.

Connected from BCM terminals 45 and 46 to front combination lamp terminal 4.

Turn signal lamp turns ON

- through front combination lamp terminal 8
- to grounds E21, E50 and E51.

Connected from BCM terminals 45 and 46 to rear combination lamp control unit terminals 4 and 5.

Rear turn signal (LED) turns ON

- through rear combination lamp control unit terminal 11
- to rear combination lamp LH terminal 3,
- through rear combination lamp LH terminal 4
- to rear combination lamp control unit terminal 10,
- through rear combination lamp control unit terminal 9

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

- to rear combination lamp RH terminal 3,
- through rear combination lamp RH terminal 4
- to rear combination lamp control unit terminal 8.

BCM sends signal to the unified meter and A/C amp. through the CAN communication lines, and turns ON turn signal indicator lamp with combination meter.

With power and input supplied, BCM controls the flashing of hazard warning lamps when key fob is used to activate remote control entry system.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CAN Communication System Description

AKS007CX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS0080W

Refer to [LAN-30, "CAN Communication Unit"](#) .

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Schematic

AKS007CZ



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT




TKWM0621E

# TURN SIGNAL AND HAZARD WARNING LAMPS

AKS007D0

## Wiring Diagram — TURN —

LT-TURN-01




REFER TO THE FOLLOWING.

- (E211) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) , (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3) , (M4) -ELECTRICAL UNITS

TKWM0820E


# TURN SIGNAL AND HAZARD WARNING LAMPS



**LT-TURN-02**  
REFER TO PG-POWER.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT







REFER TO THE FOLLOWING.  
 (E211), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (E201) -FUSE BLOCK-JUNCTION BOX (J/B)  
 (M4) -ELECTRICAL UNITS

TKWWM1075E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M3) - ELECTRICAL UNITS

TKWM0624E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Terminals and Reference Values for BCM

AKS0071B

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3468E</p>	
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3469E</p>	
4	PU/W	Combination switch input 3				
5	Y/R	Combination switch input 2				
6	SB	Combination switch input 1				
11	LG/R	Ignition switch (ACC)	ACC	—	Battery voltage	
29	G/Y	Hazard switch signal	OFF	Hazard switch	ON	Approx. 0V
					OFF	Battery voltage
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3470E</p>	
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3471E</p>	
34	W/B	Combination switch output 3				
35	W/G	Combination switch output 2				
36	W/R	Combination switch output 1				
38	W/L	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN – H	—	—	—	
40	R	CAN – L	—	—	—	
42	L/R	Battery power supply	OFF	—	Battery voltage	
45	G/W	Flasher output (left)	ON	Combination switch	Turn left ON	<p style="text-align: right;">SKIA3009J</p>
46	BR/W	Flasher output (right)	ON	Combination switch	Turn right ON	<p style="text-align: right;">SKIA3009J</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
49	B	Ground	ON	—	Approx. 0V
52	B	Ground	ON	—	Approx. 0V
55	G	Battery power supply	OFF	—	Battery voltage

## How to Proceed With Trouble Diagnosis

AKS007D2

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-91, "System Description"](#).
3. Perform preliminary check. Refer to [LT-100, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS007D3

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
Rear combination lamp control unit	Battery	20

Refer to [LT-96, "Wiring Diagram — TURN —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

# TURN SIGNAL AND HAZARD WARNING LAMPS


## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M3	11 (LG/R)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage	Battery voltage

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness or connector.




## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M4	49 (B)	Ground	Yes
	52 (B)		

**OK or NG**

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

AKS007D4

## CONSULT-II Functions (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


BCM diagnosis part	Diagnosis mode	Description
FLASHER	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.




2. Touch "START (NISSAN BASED VHCL)".



3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



4. Touch "FLASHER" on "SELECT TEST ITEM" screen.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## DATA MONITOR

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELET MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
HAZARD SW "ON/OFF"	Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.
BRAKE SW "ON/OFF"	Displays "Stop lamp switch ON (ON)/Stop lamp switch OFF (OFF)" status, determined from stop lamp switch signal.

## ACTIVE TEST

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
FLASHER	Turn signal lamp (right or left) can be operated by any ON-OFF operations.

## Turn Signal Lamp Does Not Operate

AKS007D5

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is TURN RH position : TURN SIGNAL R ON**

**When lighting switch is TURN LH position : TURN SIGNAL L ON**

☒ Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
TURN SIGNAL R	ON		
TURN SIGNAL L	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7600E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 2. ACTIVE TEST

☑ With CONSULT-II


1. Select "FLASHER" during active test. Refer to [LT-103, "ACTIVE TEST"](#).
2. Make sure "FLASHER RIGHT" and "FLASHER LEFT" operate.

☒ Without CONSULT-II

GO TO 3.

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.



## 3. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and front combination lamp LH and RH connectors.
3. Check continuity between BCM harness connector M4 terminal 45 (G/W) and front combination lamp LH harness connector E44 terminal 4 (G).


**45 (G/W) – 4 (G) : Continuity should exist.**

4. Check continuity between BCM harness connector M4 terminal 46 (BR/W) and front combination lamp RH harness connector E24 terminal 4 (PU).

**46 (BR/W) – 4 (PU) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.



## 4. CHECK GROUND

1. Check continuity between front combination lamp LH harness connector E44 terminal 8 (B) and ground.


**8 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 5. CHECK TURN SIGNAL LAMPS SHORT CIRCUIT

1. Disconnect rear combination lamp unit connector.
2. Check continuity (short circuit) between front combination lamp LH harness connector E44 terminal 4 (G) and ground.

**4 (G) – Ground : Continuity should not exist.**


3. Check continuity (short circuit) between front combination lamp RH harness connector E24 terminal 4 (PU) and ground.

**4 (PU) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



## 6. CHECK BULB

Check bulb standard of each turn signal lamp is correct.

OK or NG

OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Replace turn signal lamp bulb.

## Rear Turn Signal Lamp Does Not Operate

AKS007IF

### 1. CHECK TAIL LAMPS AND STOP LAMPS

Make sure tail lamps and stop lamps is illuminated.

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.

### 2. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminal 45 (G/W) and rear combination lamp control unit harness connector B65 terminal 4 (OR).

**45 (G/W) – 4 (OR) : Continuity should exist.**


3. Check continuity between BCM harness connector M4 terminal 46 (BR/W) and rear combination lamp control unit harness connector B65 terminal 5 (PU).

**46 (BR/W) – 5 (PU) : Continuity should exist.**

OK or NG

OK >> Replace rear combination lamp control unit.

NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. CHECK POWER SUPPLY CIRCUIT


1. Disconnect rear combination lamp control unit connector.
2. Check voltage between rear combination lamp control unit harness connector B65 terminal 1 (GY) and ground.

**1 (GY) – Ground : Battery voltage.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK GROUND CIRCUIT


- Check continuity between rear combination lamp control unit harness connector B65 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



## 5. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect rear combination lamp RH and LH connector.
2. Check continuity between rear combination lamp control unit harness connector B65 terminal 11 (W) and rear combination lamp LH harness connector B57 terminal 3 (W).

**11 (W) – 3 (W) : Continuity should exist.**

3. Check continuity between rear combination lamp control unit harness connector B65 terminal 10 (BR) and rear combination lamp LH harness connector B57 terminal 4 (BR).

**10 (BR) – 4 (BR) : Continuity should exist.**

4. Check continuity between rear combination lamp control unit harness connector B65 terminal 9 (LG) and rear combination lamp RH harness connector B219 terminal 3 (LG).

**9 (LG) – 3 (LG) : Continuity should exist.**


5. Check continuity between rear combination lamp control unit harness connector B65 terminal 8 (Y) and rear combination lamp RH harness connector B219 terminal 4 (Y).

**8 (Y) – 4 (Y) : Continuity should exist.**

OK or NG

OK >> Replace rear combination lamp control unit or rear combination lamp, and then check if turn signal lamps is illuminated.

NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operate

AKS007D6

### 1. CHECK BULB

Make sure bulb standard of each turn signal lamp is correct.

OK or NG


- OK >> GO TO 2.
- NG >> Replace bulb.

### 2. CHECK HAZARD SWITCH INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor to make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.


**When hazard switch is ON position : HAZARD SW ON**



② Without CONSULT-II

Check voltage between BCM harness connector M3 terminal 29 (G/Y) and ground.

Terminal (+)		Terminal (-)	Condition	Voltage
Connector	Terminal (Wire color)			
M3	29 (G/Y)	Ground	Hazard switch is ON	Approx. 0V
			Hazard switch is OFF	Battery voltage



OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.


### 3. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity BCM harness connector M3 terminal 29 (G/Y) and hazard switch harness connector M51 terminal 2 (G/Y).

**29 (G/Y) – 2 (G/Y) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS


## 4. CHECK GROUND

Check continuity hazard switch harness connector M51 terminal 1 (B) and ground.

**1 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.




## 5. CHECK HAZARD SWITCH

Check continuity hazard switch.

Terminal		Condition	Continuity
Hazard switch			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No

OK or NG

- OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16. "Removal and Installation of BCM"](#) .
- NG >> Replace hazard switch.



## Turn Signal Indicator Lamp Does Not Operate

### 1. CHECK BULB

Check bulb of turn signal indicator lamp in combination meter.

OK or NG

- OK >> Replace combination meter.
- NG >> Replace indicator bulb.

### Bulb Replacement (Front Turn Signal Lamp)

AKS007D8

Refer to [LT-36. "Bulb Replacement"](#) in "HEADLAMP -XENON TYPE-".

### Bulb Replacement (Rear Turn Signal Lamp)

AKS007D9

Refer to [LT-149. "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

### Removal and Installation of Front Turn Signal Lamp

AKS007DA

Refer to [LT-37. "Removal and Installation"](#) in "HEADLAMP -XENON TYPE-".

### Removal and Installation of Rear Turn Signal Lamp

AKS007DB

Refer to [LT-149. "Removal and Installation"](#) in "REAR COMBINATION LAMP".


# TURN SIGNAL AND HAZARD WARNING LAMPS

## Removal and Installation of Rear Combination Lamp Control Unit

AKS007NX

### REMOVAL

1. Remove luggage side finisher assembly (left). Refer to [EI-43](#), "[Removal and Installation](#)" in "EI" section.
2. Remove nuts (2), and remove rear combination lamp control unit.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PFP:25540

### Removal and Installation

AKS007DC

#### REMOVAL

1. Remove steering column cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. While pressing pawls in direction as shown in the figure, pull lighting and turn signal switch toward driver door and disconnect from the base.



#### INSTALLATION

Installation is the reverse order of removal.

# HAZARD SWITCH

## HAZARD SWITCH


PFP:25290

### Removal and Installation

AKS007DD

#### REMOVAL

1. Remove A/T console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Disconnect hazard switch connector.
3. Remove screws and remove ashtray assembly from A/T console finisher.
4. Press pawl on reverse side and remove hazard switch.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# COMBINATION SWITCH




PFP:25567

## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

AKS007G4

## LT-COMBSW-01



REFER TO THE FOLLOWING.

- (E21) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M3), (M4) -ELECTRICAL UNITS

TKWM0814E

# COMBINATION SWITCH

## Combination Switch Reading Function

AKS007G5

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) in "BCS" section.

## CONSULT-II Functions (BCM)

AKS007G6

- CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
COMB SW	DATA MONITOR	Displays BCM input data in real time.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


- With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



- Touch "START (NISSAN BASED VHCL)".




- Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# COMBINATION SWITCH

4. Touch "COMB SW".



## DATA MONITOR

### Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the signals will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
TURN SIGNAL R "ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays "Auto light switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR FOG SW "ON/OFF"	Displays "Front fog lamp switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR WIPER HI "ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT "ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WASHER SW "ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME "1 - 7"	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
RR WIPER ON "ON/OFF"	Displays "rear Wiper (ON)/Other (OFF)" status as judged from wiper switch signal.
RR WIPER INT "ON/OFF"	Displays "rear Wiper INT (ON)/Other (OFF)" status as judged from wiper switch signal.
RR WASHER SW "ON/OFF"	Displays "rear Washer Switch (ON)/Other (OFF)" status as judged from wiper switch signal.

# COMBINATION SWITCH

## Combination Switch Inspection

AKS007G7

### 1. SYSTEM CHECK

1. Referring to table below, check which system malfunctioning switch belongs to.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	LIGHT SW 1ST
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> Check the system to which malfunctioning switch belongs, and GO TO 2.

### 2. SYSTEM CHECK

Ⓜ With CONSULT-II

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START", and confirm that other switches in malfunctioning system operate normally.

Example: When the auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR			
MONITOR			
TURN SIGNAL R	OFF		
TURN SIGNAL L	OFF		
HIBEAM SW	OFF		
HEAD LAMP SW1	OFF		
HEAD LAMP SW2	OFF		
LIGHT SW 1ST	OFF		
PASSING SW	OFF		
AUTO LIGHT SW	OFF		
FR FOG SW	OFF		
		Page Down	
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7602E

ⓧ Without CONSULT-II

Operating combination switch, and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that FRONT WIPER LOW and FRONT WIPER INT in System 3, to which the auto light switch belongs, operate normally.

#### Check results


- Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.  
Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. HARNESS INSPECTION


1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM harness connector of the suspect system and the corresponding combination switch connector terminals.

Suspect system	Terminal				Continuity	
	BCM		Combination switch			
	Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
1	M3	Input 1	6 (SB)	M17	6 (SB)	Yes
		Output 1	36 (W/R)		1 (W/R)	
2		Input 2	5 (Y/R)		7 (Y/R)	
		Output 2	35 (W/G)		2 (W/G)	
3		Input 3	4 (PU/W)		10 (PU/W)	
		Output 3	34 (W/B)		3 (W/B)	
4		Input 4	3 (L/B)		9 (L/B)	
		Output 4	33 (G)		4 (G)	
5		Input 5	2 (GY)		8 (GY)	
		Output 5	32 (GY/R)		5 (GY/R)	



4. Check for continuity between each terminal of BCM harness connector in suspect malfunctioning system and ground.

Suspect system	Terminal				Continuity
	BCM		Ground		
	Connector	Terminal (Wire color)			
1	M3	Input 1	6 (SB)	Ground	No
		Output 1	36 (W/R)		
2		Input 2	5 (Y/R)		
		Output 2	35 (W/G)		
3		Input 3	4 (PU/W)		
		Output 3	34 (W/B)		
4		Input 4	3 (L/B)		
		Output 4	33 (G)		
5		Input 5	2 (GY)		
		Output 5	32 (GY/R)		



OK or NG

OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH

## 4. BCM OUTPUT TERMINAL INSPECTION


1. Turn lighting switch and wiper switch into ON.
2. Set wiper dial position 4.
3. Connect BCM and combination switch connectors, and check BCM output terminal voltage waveform of suspect malfunctioning system.

Suspect system	Terminal		(-)
	Combination switch (+)		
	Connector	Terminal (Wire color)	
1	M17	1 (W/R)	Ground
2		2 (W/G)	
3		3 (W/B)	
4		4 (G)	
5		5 (GY/R)	

OK or NG

OK >> Open circuit in combination switch, GO TO 5.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).



## 5. COMBINATION SWITCH INSPECTION

Referring to table below, perform combination switch inspection.

Procedure									
1	2		3	4		5	6		7
Replace lighting switch	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END
		NG	Replace wiper switch		NG	Replace switch base		NG	Confirm symptom again

>> INSPECTION END

## Removal and Installation

For details, refer to [LT-110, "LIGHTING AND TURN SIGNAL SWITCH"](#).


# STOP LAMP

## STOP LAMP

PFP:26550

### Component Parts and Harness Connector Location

AKS007IG



## System Description


AKS007IH

The current that flows by Rear combination lamp control unit is controlled, and a stop lamp (LED) is made to turn on.

# STOP LAMP

## Schematic

AKS007II



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



TKWM0625E

# STOP LAMP

## Wiring Diagram — STOP/L —

AKS007DL

### LT-STOP/L-01





REFER TO THE FOLLOWING.  
 (E211), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (E201) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM1076E

# STOP LAMP

LT-STOP/L-02




(B5) (D101)  
W W




(B57) (B219)  
W W



(B65)  
W




(B80)  
W



(B216)  
GY



(D102)  
W



(D103)  
GY





REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWH0227E

# STOP LAMP

## LT-STOP/L-03



REFER TO THE FOLLOWING.

(M1) -FUSE BLOCK-JUNCTION BOX (J/B)

(M3) -ELECTRICAL UNITS

TKWM0628E

# STOP LAMP

AKS007J

## Stop Lamp Does Not Operate

### 1. CHECK TAIL LAMP AND TURN SIGNAL LAMP

Make sure tail lamps and turn signal lamps is illuminated.

OK or NG

- OK >> GO TO 2.
- NG >> GO TO 6.

### 2. CHECK FUSE

Check fuse No.20 is blow out.

OK or NG

- OK >> GO TO 3.
- NG >> If fuse is blow out, be sure to eliminate cause of problem before installing new fuse.


### 3. CHECK INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between rear combination lamp control unit harness connector and ground.

Terminal (+)		(-)	Condition	Voltage
Connector	Terminal (Wire color)			
B65	3 (P)	Ground	Stop lamp switch is ON. (Depressed)	Battery voltage
			Stop lamp switch is OFF. (Released)	Approx. 0

OK or NG

- OK >> Replace rear combination lamp control unit.
- NG >> GO TO 4.




### 4. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch connector.
2. Check voltage between stop lamp switch harness connector E210 terminal 1 (GY) and ground.

**1 (GY) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.



# STOP LAMP


## 5. CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect rear combination lamp control unit connector.
2. Check continuity between stop lamp switch harness connector E210 terminal 2 (P) and rear combination lamp control unit harness connector B65 terminal 3 (P).

**2 (P) – 3 (P) : Continuity should exist.**

OK or NG

- OK >> Replace stop lamp switch.  
NG >> Repair harness or connector.




## 6. CHECK POWER SUPPLY CIRCUIT

1. Disconnect rear combination lamp control unit connector.
2. Check voltage between rear combination lamp control unit harness connector B65 terminal 1 (GY) and ground.

**1 (GY) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 7.  
NG >> Repair harness or connector.




## 7. CHECK GROUND CIRCUIT

Check continuity between rear combination lamp control unit harness connector B65 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 8.  
NG >> Repair harness or connector.



# STOP LAMP

## 8. CHECK STOP LAMPS CIRCUIT

1. Disconnect rear combination lamp RH and LH connector.
2. Check continuity between rear combination lamp control unit harness connector B65 terminal 11 (W) and rear combination lamp LH harness connector B57 terminal 3 (W).

**11 (W) – 3 (W) : Continuity should exist.**

3. Check continuity between rear combination lamp control unit harness connector B65 terminal 10 (BR) and rear combination lamp LH harness connector B57 terminal 4 (BR).


**10 (BR) – 4 (BR) : Continuity should exist.**

4. Check continuity between rear combination lamp control unit harness connector B65 terminal 9 (LG) and rear combination lamp RH harness connector B219 terminal 3 (LG).

**9 (LG) – 3 (LG) : Continuity should exist.**

5. Check continuity between rear combination lamp control unit harness connector B65 terminal 8 (Y) and rear combination lamp RH harness connector B219 terminal 4 (Y).

**8 (Y) – 4 (Y) : Continuity should exist.**



### OK or NG

OK >> Replace rear combination lamp control unit or rear combination lamp, and then check if turn signal lamps is illuminated.

NG >> Repair harness or connector.

## High-Mounted Stop Lamp


### BULB REPLACEMENT, REMOVAL AND INSTALLATION

1. Remove cap from back door finisher and remove nuts. Refer to [EI-45, "Removal and Installation"](#) in "EI" section.
2. Disconnect high-mounted stop lamp connector.
3. Remove washer tube from high-mounted stop lamp, and remove high-mounted stop lamp from the rear air spoiler.
4. Remove seal packing from the rear air spoiler.
5. Installation is the reverse order of removal.

**High-mounted stop lamp : LED**

### CAUTION:

Seal packing cannot be reused.



## Stop Lamp

### BULB REPLACEMENT

Refer to [LT-149, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

### REMOVAL AND INSTALLATION

Refer to [LT-149, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

## Rear Combination Lamp Control Unit

### REMOVAL AND INSTALLATION

Refer to [LT-109, "Removal and Installation of Rear Combination Lamp Control Unit"](#) in "TURN SIGNAL AND HAZARD WARNING LAMPS".

# STEP LAMP

## STEP LAMP

PFP:26420


### Front Door Step Lamp BULB REPLACEMENT, REMOVAL AND INSTALLATION

AKS007DO

1. Remove door finisher. Refer to [EI-34, "Removal and Installation"](#) in "EI" section.
2. Insert a screwdriver in lens and remove lens.
3. Remove bulb.

**Step lamp : 12V - 5W**

4. Installation is the reverse order of removal.




### Rear Door Step Lamp BULB REPLACEMENT, REMOVAL AND INSTALLATION

AKS007DP

1. Remove door finisher. Refer to [EI-34, "Removal and Installation"](#) in "EI" section.
2. Insert a screwdriver in lens and remove lens.
3. Remove bulb.

**Step lamp : 12V - 5W**

4. Installation is the reverse order of removal.



# BACK-UP LAMP

PPF:26550










## BACK-UP LAMP

### Wiring Diagram — BACK/L —

AKS007DQ

## LT-BACK/L-01

▬ : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM1370E

# BACK-UP LAMP

---

## **Bulb Replacement**

AKS007DR

Refer to [LT-149, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

## **Removal and Installation**

AKS007DS


Refer to [LT-149, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

## PARKING, LICENSE PLATE AND TAIL LAMPS

PPF:26550

### Component Parts and Harness Connector Location

AKS00707



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

### System Description

AKS007DT

Control of the parking, license plate, side marker and tail lamp operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST position, the BCM (body control module) receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the parking, license plate, side marker and tail lamps, which then illuminate.

The current that flows by Rear combination lamp control unit is controlled, and a tail lamp (LED) is made to turn ON.

### OUT LINE

Power is supplied at all times

- through 10A fuse (No. 71, located in IPDM E/R)
- to tail lamp relay, located in IPDM E/R, and
- to CPU located in IPDM E/R,

## PARKING, LICENSE PLATE AND TAIL LAMPS

---

- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R.

Power is also supplied at all times

- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 15A fuse [No. 22, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 1,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8, and
- to unified meter and A/C amp. terminal 21.

With ignition switch in ON or START position, power is supplied

- through ignition relay, located in IPDM E/R, from battery direct,
- through 15A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 7,
- through 10A fuse [No. 12, located in fuse block (J/B)]
- to unified meter and A/C amp. terminal 22.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds M35, M45 and M85,
- to IPDM E/R terminals 38 and 60
- through grounds E21, E50 and E51,
- to rear combination lamp control unit terminal 7
- through grounds E21, E50 and E51,
- to combination meter terminals 5, 6 and 15
- through grounds M35, M45 and M85,
- to unified meter and A/C amp. terminals 29 and 30
- through grounds M35, M45 and M85.

### OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls the tail lamp relay coil, which when energized, directs power.

- through IPDM E/R terminal 22
- to front side marker lamp LH terminal 1
- to clearance lamp LH terminal 2
- to license plate lamp LH terminal 1
- to rear combination lamp LH terminal 1
- to rear combination lamp control unit terminal 2
- to front side marker lamp RH terminal 1
- to clearance lamp RH terminal 2
- to license plate lamp RH terminal 1, and
- to rear combination lamp RH terminal 1.

# PARKING, LICENSE PLATE AND TAIL LAMPS

Ground is supplied at all times

- to front side marker lamp LH terminal 2
- through grounds E21, E50 and E51,
- to clearance lamp LH terminal 3
- through grounds E21, E50 and E51,
- to license plate lamp LH terminal 2
- through grounds B15 and B45,
- to rear combination lamp LH terminal 2
- through grounds B15 and B45,
- to front side marker lamp RH terminal 2
- through grounds E21, E50 and E51,
- to clearance lamp RH terminal 3
- through grounds E21, E50 and E51,
- to license plate lamp RH terminal 2
- through grounds B15 and B45,
- to rear combination lamp RH terminal 2
- through grounds B203 and B210,
- to rear combination lamp control unit terminal 7
- through grounds E21, E50 and E51.

With power and ground supplied, the parking, license plate, side marker and tail lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the parking, license, side marker and tail lamps remain illuminated for 5 minutes, then the parking, license plate, side marker and tail lamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

AKS007DU

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS0080X

Refer to [LAN-30, "CAN Communication Unit"](#) .

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

AKS007DW





\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —

AKS007DX

### LT-TAIL/L-01





REFER TO THE FOLLOWING.  
 E211 -SUPER MULTIPLE JUNCTION (SMJ)  
 M1, M2 -FUSE BLOCK-JUNCTION BOX (J/B)  
 M3, M4 -ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02




REFER TO THE FOLLOWING.  
 E211 -SUPER MULTIPLE JUNCTION (SMJ)

TKWM0632E

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-03

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




REFER TO THE FOLLOWING.  
 (E21) -SUPER MULTIPLE JUNCTION (SMJ)

LT

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-04




REFER TO PG-POWER.

PRE-  
CEDING  
PAGE

L/OR  
G  
NEXT  
PAGE



PRE-  
CEDING  
PAGE



REFER TO THE FOLLOWING.  
 (B1), (B201) -SUPER MULTIPLE  
 JUNCTION (SMJ)  
 (E201) -FUSE BLOCK-JUNCTION  
 BOX (J/B)

TKWM1081E

# PARKING, LICENSE PLATE AND TAIL LAMPS



REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2431E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

AKS00CJ0

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	GY	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3468E</p>
3	L/B	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3469E</p>
4	PU/W	Combination switch input 3			
5	Y/R	Combination switch input 2			
6	SB	Combination switch input 1			
11	LG/R	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY/R	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3470E</p>
33	G	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3471E</p>
34	W/B	Combination switch output 3			
35	W/G	Combination switch output 2			
36	W/R	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	R	CAN – L	—	—	—
42	L/R	Battery power supply	OFF	—	Battery voltage
49	B	Ground	ON	—	Approx. 0V
52	B	Ground	ON	—	Approx. 0V
55	G	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS007IM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
22	R	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
48	L	CAN – H	—	—	—	
49	R	CAN – L	—	—	—	
60	B	Ground	ON	—	Approx. 0V	

# PARKING, LICENSE PLATE AND TAIL LAMPS

## How to Proceed With Trouble Diagnosis

AKS007E0

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-129, "System Description"](#) .
3. Perform Preliminary Check. Refer to [LT-139, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Do parking, license plate, side marker and tail lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS007E1

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71
Rear combination lamp control unit	Battery	20

Refer to [LT-133, "Wiring Diagram — TAIL/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
Connector	Terminal (Wire color)	Ground	OFF	ACC	ON
	M3		11 (LG/R)	Approx. 0V	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (L/R)		Battery voltage	Battery voltage	Battery voltage
	55 (G)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



PKIB5197E

# PARKING, LICENSE PLATE AND TAIL LAMPS


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M4	49 (B)	Ground	Yes
	52 (B)		

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



AKS007E2

### CONSULT-II Functions (BCM)

Refer to [LT-18, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP.

### CONSULT-II Functions (IPDM E/R)

Refer to [LT-20, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP.

AKS00CM4

## Parking, License Plate and Side Marker Lamps Do Not Illuminate

AKS00710

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓜ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "LIGHT SW 1 ST" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is 1ST : LIGHT SW 1 ST ON position**

ⓧ Without CONSULT-II

Refer to [LT-115, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.  
 NG >> Check combination switch (lighting switch). Refer to [LT-115, "Combination Switch Inspection"](#).



PKIA7607E


# PARKING, LICENSE PLATE AND TAIL LAMPS

## 2. ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure parking, license plate and side marker lamp operation.

**Parking, license plate and side marker lamp should operate.**



☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
2. Make sure parking, license plate and side marker lamp operation.

**Parking, license plate and side marker lamp should operate.**


OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 4.

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "TAIL & CLR REQ" turns ON when lighting switch is in 1ST position.

**When lighting switch is 1ST : TAIL & CLR REQ ON position**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK INPUT SIGNAL


☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker, clearance lamp, license plate lamp and rear combination lamp connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. When parking, license plate and side marker is operating, check voltage between front side marker lamp, clearance lamp, license plate lamp, rear combination lamp harness connector and ground.


☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker, clearance lamp, license plate lamp and rear combination lamp connectors.
3. Start auto active test. Refer to [PG-24, "Auto Active Test"](#).
4. When parking, license plate and side marker is operating, check voltage between front side marker lamp, clearance lamp, license plate lamp, rear combination lamp harness connector and ground.


Terminal			(-)	Voltage
Front side marker lamp (+)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	E22	1 (R)		
LH	E42			



Terminal			(-)	Voltage
Clearance lamp (+) (Parking)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	E23	2 (R)		
LH	E43			



Terminal			(-)	Voltage
License plate lamp (+)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	D111	1 (R)		
LH	D110			




# PARKING, LICENSE PLATE AND TAIL LAMPS

Terminal			(-)	Voltage
Rear combination lamp (+) (Side marker)				
Connector		Terminal (Wire color)		
RH	B219	1 (R)		
LH	B57			

**OK or NG**

- OK >> GO TO 6.
- NG >> GO TO 5.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK PARKING, LICENSE PLATE AND SIDE MARKER LAMPS CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

Terminal					Continuity
IPDM E/R		Front side marker lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R)	RH	E22	1 (R)	Yes
		LH	E42		




4. Check continuity between IPDM E/R harness connector and clearance lamp harness connector.

Terminal					Continuity
IPDM E/R		Clearance lamp (Parking)			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R)	RH	E23	2 (R)	Yes
		LH	E43		




5. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

Terminal					Continuity
IPDM E/R		License plate lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R)	RH	D111	1 (R)	Yes
		LH	D110		



6. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

Terminal					Continuity
IPDM E/R		Rear combination lamp (Side marker)			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R)	RH	B219	1 (R)	Yes
		LH	B57		



OK or NG


- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 6. CHECK GROUND


1. Turn ignition switch OFF.
2. Check continuity between front side marker lamp harness connector and ground.

Terminal		Continuity
Front side marker lamp		
Connector		Ground
Terminal (Wire color)		
RH	E22	2 (B)
LH	E42	




3. Check continuity between clearance lamp harness connector and ground.

Terminal		Continuity
Clearance lamp (Parking)		
Connector		Ground
Terminal (Wire color)		
RH	E23	3 (B)
LH	E43	




4. Check continuity between license plate lamp harness connector and ground.

Terminal		Continuity
License plate lamp		
Connector		Ground
Terminal (Wire color)		
RH	D111	2 (B)
LH	D110	



5. Check continuity between rear combination lamp harness connector and ground.

Terminal		Continuity
Rear combination lamp (Side marker)		
Connector		Ground
Terminal (Wire color)		
RH	B219	2 (B)
LH	B57	



OK or NG

- OK >> Check bulb.  
 NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

AKS0071N

## Tail Lamp Does Not Operate

### 1. CHECK STOP LAMP AND TURN SIGNAL LAMP

Make sure stop lamps and turn signal lamps is illuminated.


OK or NG

- OK >> GO TO 2.
- NG >> GO TO 3.

### 2. CHECK INPUT SIGNAL

Check voltage between rear combination lamp control unit harness connector B65 terminal 2 (R) and ground.

Terminal (+)		(-)	Condition	Voltage
Connector	Terminal (Wire color)			
B65	2 (R)	Ground	Lighting switch 1ST position is ON	Battery voltage
			Lighting switch 1ST position is OFF	Approx. 0V



OK or NG

- OK >> Replace rear combination lamp control unit.
- NG >> Repair harness or connector.


### 3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between rear combination lamp control unit harness connector B65 terminal 1 (GY) and ground.

**1 (GY) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.




### 4. CHECK GROUND CIRCUIT

1. Disconnect rear combination lamp control unit connector.
2. Check continuity between rear combination lamp control unit harness connector B65 terminal 7 (B) and ground.

**7 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.



# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect rear combination lamp RH and LH connector.
2. Check continuity between rear combination lamp control unit harness connector B65 terminal 11 (W) and rear combination lamp LH harness connector B57 terminal 3 (W).

**11 (W) – 3 (W) : Continuity should exist.**

3. Check continuity between rear combination lamp control unit harness connector B65 terminal 10 (BR) and rear combination lamp LH harness connector B57 terminal 4 (BR).


**10 (BR) – 4 (BR) : Continuity should exist.**

4. Check continuity between rear combination lamp control unit harness connector B65 terminal 9 (LG) and rear combination lamp RH harness connector B219 terminal 3 (LG).

**9 (LG) – 3 (LG) : Continuity should exist.**

5. Check continuity between rear combination lamp control unit harness connector B65 terminal 8 (Y) and rear combination lamp RH harness connector B219 terminal 4 (Y).

**8 (Y) – 4 (Y) : Continuity should exist.**



### OK or NG

- OK >> Replace rear combination lamp control unit or rear combination lamp, and then check if turn signal lamps is illuminated.
- NG >> Repair harness or connector.

## Parking, License Plate, Side Marker and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

AKS007E4

### 1. CHECK IPDM E/R

1. Turn ignition switch ON. Turn combination switch (lighting switch) to the OFF position. Turn ignition switch OFF.
2. Verify that parking, license plate, and tail lamps turn on and off after approximately 10 minutes.


### OK or NG

- OK >> Ignition relay malfunction. Refer to [PG-19, "Function of Detecting Ignition Relay Malfunction"](#).
- NG >> INSPECTION END

## License Plate Lamp BULB REPLACEMENT, REMOVAL AND INSTALLATION

AKS007E5

1. Remove screws and remove license plate lamp from back door.
2. Disconnect license plate lamp connector.




## PARKING, LICENSE PLATE AND TAIL LAMPS

3. Insert a flat head or suitable tool and remove housing.
4. Remove bulb from it's socket.

**License plate lamp** : 12V - 5W

5. Installation is the reverse order of removal.



### Front Parking Lamp BULB REPLACEMENT

AKS007E6

For bulb replacement, refer to [LT-36, "Bulb Replacement"](#) in "HEADLAMP-XENON TYPE-".

#### REMOVAL AND INSTALLATION

For front parking lamp removal and installation procedures, refer to [LT-37, "Removal and Installation"](#) in "HEAD LAMP -XENON TYPE-".

### Tail Lamp BULB REPLACEMENT

AKS007E7

For bulb replacement, refer to [LT-149, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

#### REMOVAL AND INSTALLATION

For tail lamp removal and installation procedures, refer to [LT-149, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

### Front Side Marker Lamp BULB REPLACEMENT

AKS007E8

For bulb replacement, refer to [LT-36, "Bulb Replacement"](#) in "HEADLAMP-XENON TYPE-".

#### REMOVAL AND INSTALLATION

For head lamp removal and installation procedures, refer to [LT-37, "Removal and Installation"](#) in "HEAD LAMP-XENON TYPE-".

### Rear Side Marker Lamp BULB REPLACEMENT

AKS007E9

For bulb replacement, refer to [LT-149, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

#### REMOVAL AND INSTALLATION

For rear side marker lamp removal and installation procedures, refer to [LT-149, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

### Rear Combination Lamp Control Unit REMOVAL AND INSTALLATION

AKS00703

Refer to [LT-109, "Removal and Installation of Rear Combination Lamp Control Unit"](#) in "TURN SIGNAL AND HAZARD WARNING LAMPS".

# REAR COMBINATION LAMP

## REAR COMBINATION LAMP


PPF:26554

### Bulb Replacement

#### REAR FENDER SIDE (REAR SIDE MARKER LAMP BULB)


AKS007FP

1. Remove rear combination lamp.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.



#### BACK DOOR SIDE (BACK-UP LAMP)

1. Remove rear combination lamp.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.



**Stop/tail lamp and rear turn signal lamp (rear fender side) : LED (Replace together with rear combination lamp assembly.)**

**Rear side marker lamp (rear fender side) : 12V - 3.8W**


**Back-up lamp (back door side) : 12V - 18W**

## Removal and Installation

### REMOVAL

#### Rear Fender Side


1. Remove bumper side cover A. Refer to [EI-17, "Removal and Installation"](#) in "EI" section.
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting bolts.
4. Pull rear combination lamp toward side of the vehicle and remove from the vehicle.



# REAR COMBINATION LAMP

## Trunk Lid Side

1. Remove back door finisher. Refer to [EI-45, "Removal and Installation"](#) in "EI" section.
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting nuts.
4. Remove rear combination lamp from back door.
5. Remove seal packing from back door.



## INSTALLATION

Installation is the reverse order of removal.

- Installation a new seal packing to the rear combination lamp.

### **CAUTION:**

**Seal packing cannot be reused.**

**Rear combination lamp (trunk lid side) mounting nut**  : 5.5 N·m (0.56 kg-m, 49 in-lb)

**Rear combination lamp (rear fender side) mounting nut**  : 3.2 N·m (0.33 kg-m, 28 in-lb)

# VANITY MIRROR LAMP

## VANITY MIRROR LAMP

PFP:96400


### Bulb Replacement

AKS007EC

1. Insert a thin screwdriver in the lens end and remove lens.
2. Remove bulb together with substrate.

**Vanity mirror lamp : 12V - 1.32W**

3. Installation is the reverse order of removal.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# MAP LAMP

## MAP LAMP

PFP:26430


### Bulb Replacement

AKS007ED

1. Remove lens using clip driver or suitable tool.
2. Remove bulb.

**Map lamp : 12V - 8 W**

3. Installation is the reverse order of removal.




### Removal and Installation

#### REMOVAL

AKS007EE

1. Insert a clip driver or suitable tool back of map lamp and pull down it to disengage pawl.
2. Pull down map lamp in direction shown by the arrow in the figure.
3. Disconnect map lamp connector and remove map lamp.



#### INSTALLATION

Installation is the reverse order of removal.

# PERSONAL LAMP

## PERSONAL LAMP

PPF:26415


### Bulb Replacement

AKS007FT

1. Remove personal lamp. Refer to [LT-153, "Removal and Installation"](#).
2. Remove screw from personal lamp.
3. Insert a screwdriver or similar tool and remove lens.
4. Remove bulb.

**Personal lamp : 12V - 8W**

5. Installation is the reverse order of removal.




### Removal and Installation

#### REMOVAL

AKS007FU

1. Use a clip driver or similar tool to press metal clip, and remove personal lamp.
2. Disconnect personal lamp connector.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# LUGGAGE ROOM LAMP

## LUGGAGE ROOM LAMP

PFP:26410


### Bulb Replacement

AKS007FV

1. Remove luggage room lamp. Refer to [LT-154, "Removal and Installation"](#).
2. Remove screw from luggage room lamp.
3. Insert a suitable tool and remove lens.
4. Remove bulb.

**Luggage room lamp : 12V - 8W**

5. Installation is the reverse order of removal.




### Removal and Installation

#### REMOVAL

AKS007FW

1. Use a clip driver or similar tool to press metal clip, and remove luggage room lamp.
2. Disconnect luggage room lamp connector.



#### INSTALLATION

Installation is the reverse order of removal.

# IGNITION KEY HOLE ILLUMINATION

## IGNITION KEY HOLE ILLUMINATION

PF:48476


### Bulb Replacement, Removal and Installation

AKS007FR

1. Remove combination meter. Refer to [DI-25, "Removal and Installation of Combination Meter"](#) in "DI" section.
2. Remove screw and remove NATS antenna amp.
3. Pull out ring and turn bulb socket to left to release lock.

**Ignition key hole illumination : 12V - 0.8W**

4. Installation is the reverse order of removal.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# GLOVE BOX LAMP

## GLOVE BOX LAMP

PFP:68520


### Bulb Replacement, Removal and Installation

AKS007FS

1. Remove instrument passenger lower panel. Refer to [IP-18](#), "[INSTRUMENT PASSENGER LOWER PANEL](#)" in "IP" section.
2. Turn bulb socket left to release lock and remove it.

**Glove box lamp : 12V - 1.4W**

3. Installation is the reverse order of removal.



# ASHTRAY ILLUMINATION

## ASHTRAY ILLUMINATION


PFP:25860

### Bulb Replacement and Removal and Installation

AKS007NZ

1. Remove A/T console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Remove instrument ashtray and hazard switch. Refer to [IP-16, "A/T CONSOLE FINISHER"](#) in "IP" section.
3. Use a screwdriver to undo ashtray finisher hooks.
4. Turn bulb socket on circuit board to left to undo lock. Remove bulb socket.
5. Installation is the reverse order of removal.

**Ashtray and cigarette  
lighter illumination** : 12V - 1.4W



A

B

C

D

E

F

G

H

I

J

LT

L

M

# CIGARETTE LIGHTER ILLUMINATION

---

## CIGARETTE LIGHTER ILLUMINATION

PFP:25331

### Bulb Replacement and Removal and Installation

AKS00700

Refer to [LT-157, "Bulb Replacement and Removal and Installation"](#) in "ASHTRAY ILLUMINATION".


# INTERIOR ROOM LAMP

## INTERIOR ROOM LAMP

PF26410

### Component Parts and Harness Connector Location

AKS00708



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

### System Description

AKS007F7

When the room lamp and personal lamp switch is in DOOR position, room lamp and personal lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from keyfob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch.

## INTERIOR ROOM LAMP

When the room lamp and personal lamp turns ON, there is a gradual brightening over 1 second. When room lamp and personal lamp turns OFF, there is a gradual dimming over 1 second.

The room lamp and personal lamp timer is controlled by the BCM (body control module).

Room lamp and personal lamp timer control settings can be changed with CONSULT-II.

Ignition keyhole illumination turns ON at time when driver door is opened (door switch ON) or removed keyfob from key cylinder. Illumination turns OFF when driver door is closed (door switch OFF).

Step lamp turns ON at time when driver door or passenger door is opened (door switch ON). Lamp turns OFF when the driver, passenger doors are closed (all door switches OFF).

### POWER SUPPLY AND GROUND

Power is supplied at all times (without Intelligent Key system)

- through 15A fuse [No. 22, located in fuse block (J/B)]
- to key switch terminal 2, and
- to BCM terminal 42,
- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8.

Power is supplied at all times (with Intelligent Key system)

- through 10A fuse (No.38, located in fuse, fusible link and relay box)
- to key switch and ignition knob switch terminal 1,
- through 15A fuse [No.22, located in fuse block (J/B)]
- to BCM terminal 42,
- to key switch and ignition knob switch terminal 3,
- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 8.

When key plate inserted to key switch, power is supplied (without Intelligent Key system)

- through key switch terminal 1
- to BCM terminal 37.

When inserted key plate to key switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37.

When moved ignition knob switch, power is supplied (with Intelligent Key system)

- through ignition knob switch terminal 2
- to intelligent key unit terminal 27.

With ignition switch in the ON or START position, power is supplied

- through 15A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminals 49 and 52
- through grounds terminals M35, M45 and M85.

When driver side door is opened, ground is supplied

- through case ground of front door switch (driver side)
- through front door switch (driver side) terminal 1
- to BCM terminal 62.

When passenger side door is opened, ground is supplied

- through case ground of front door switch (passenger side)
- through front door switch (passenger side) terminal 1
- to BCM terminal 12.

# INTERIOR ROOM LAMP

When rear door LH is opened, ground is supplied

- through case ground of rear door switch LH
- through rear door switch LH terminal 1
- to BCM terminal 63, and
- to personal lamp LH terminal 1.

A

When rear door RH is opened, ground is supplied

- through case ground of rear door switch RH
- through rear door switch RH terminal 1
- to BCM terminal 13, and
- to personal lamp RH terminal 1.

B

C

When driver side door is unlocked by door lock and unlock switch, BCM receives a ground signal

- through grounds terminals M35, M45 and M85
- to power window main switch (door lock and unlock switch) terminal 17 or front power window switch (passenger side) (door lock and unlock switch) terminal 11
- from power window main switch (door lock and unlock switch) terminal 14 or front power window switch (passenger side) (door lock and unlock switch) terminal 16
- to BCM terminal 22.

D

E

F

When front driver side door is unlocked by driver side door lock assembly (key cylinder switch), BCM receives a ground signal

- through grounds M35, M45 and M85
- to front door lock assembly (driver side) (key cylinder switch) terminal 5
- from front door lock assembly (driver side) (key cylinder switch) terminal 6
- to power window main switch (door lock and unlock switch) terminal 6
- from power window main switch (door lock and unlock switch) terminal 14
- to BCM terminal 22.

G

H

I

When a signal, or combination of signals is received by BCM, ground is supplied

- to interior room lamp terminal 1 (without DVD player),
- to map lamp terminal 2,
- to front door inside handle illumination terminal 2, and
- to rear door inside handle illumination terminal 2
- through BCM terminal 48.

J

LT

With power and supplied, interior lamp illuminates.

L

## SWITCH OPERATION

When driver door switch is ON (door is opened), ground is supplied

- through BCM terminal 1
- to ignition keyhole illumination terminal 2.

M

And power is supplied

- from BCM terminal 41
- to ignition keyhole illumination terminal 1.

When any door switch is ON (door is opened), ground is supplied

- through BCM terminal 47
- to front step lamp (driver side and passenger side) and rear step lamp (LH and RH) terminals 2
- through rear door switch (LH or RH) terminal 1
- to personal lamp (LH or RH) terminals 1.

And power is supplied

- from BCM terminal 41
- to front step lamp (driver side and passenger side) and rear step lamp (LH and RH) terminals 1, and
- to personal lamp (LH and RH) terminals 2

When map lamp switch is ON, ground is supplied

# INTERIOR ROOM LAMP

---

- through grounds M35, M45 and M85
- to map lamp terminal 1.

And power is supplied

- from BCM terminal 41
- to map lamp terminal 3.

When interior room lamp switch is ON, ground supplied (without DVD player)

- through grounds M35, M45 and M85
- to interior room lamp terminal 3.

And power is supplied (without DVD player)

- from BCM terminal 41
- to interior room lamp terminal 2.

When personal lamp LH or RH switch is ON, ground supplied

- through grounds M35, M45 and M85
- to personal lamp LH or RH terminal 3.

And power is supplied

- from BCM terminal 41
- to personal lamp LH or RH terminal 2.

When vanity mirror lamp (driver side or passenger side) is ON, ground is supplied

- through grounds M35, M45 and M85
- to vanity mirror lamp (driver side or passenger side) terminal 2.

And power is supplied

- from BCM terminal 41
- to vanity mirror lamp (driver side or passenger side) terminal 1.

When luggage room lamp (back door side) is ON, ground is supplied

- through grounds B15 and B45
- to luggage room lamp (back door side) terminal 3.

And power is supplied

- from BCM terminal 41
- to luggage room lamp (back door side) terminals 2.

## ROOM LAMP TIMER OPERATION

### Without Intelligent Key System

When the interior room lamp and map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for interior room lamp and map lamp ON/OFF. In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- to 15A fuse [No. 22, located infuse block (J/B)]
- through key switch terminal 2.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

Ground is supplied

- from BCM terminal 22
- to power window main switch (door lock and unlock switch) terminal 14.

At the time that driver door are opened, BCM detects that driver door is unlocked. It determines that interior room lamp and map lamp timer operation conditions are met, and turns interior room lamp and map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON),

Power is supplied

- through key switch terminal 1
- to BCM terminal 37.

# INTERIOR ROOM LAMP

When the key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that interior room lamp and map lamp timer conditions are met, and turns interior room lamp and map lamp ON for 30 seconds.

When driver door opens → closes, and key is not inserted in key switch (key switch OFF), BCM terminal 62 changes between 0V (door open) → 12V (door closed). BCM determines that conditions for interior room lamp and map lamp operation are met and turns interior room lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked keyfob or power window main switch (door lock and unlock switch), door key cylinder switch].
- Driver door is opened (driver door switch turns ON).
- Ignition switch ON.

## With Intelligent Key System

When the interior room lamp and map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 second) for interior room lamp and map lamp ON/OFF. In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- to 15A fuse [No. 22, located in fuse and fuse block (J/B)]
- through key switch and ignition knob switch terminal 3.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37. And not turned ignition knob switch, power will not be supplied to Intelligent Key unit.

Ground is supplied

- from BCM terminal 22
- to power window main switch (door lock and unlock switch) terminal 14.

At the time that driver door are opened, BCM detects that driver door is unlocked. It determines that interior room lamp and map lamp timer operation conditions are met, and turns interior room lamp and map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), or turned ignition knob switch,

Power is supplied

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37,
- through key switch and ignition knob switch terminal 2
- to intelligent key unit terminal 27.

When the key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. And turned ignition knob switch, power supply to Intelligent Key unit is terminated. BCM detects that key has been removed, determines that interior room lamp and map lamp timer conditions are met, and turns interior room lamp and map lamp ON for 30 seconds.

When driver door opens → closes, and key is not inserted in key switch (or not turned ignition knob switch), BCM terminal 62 changes between 0V (door open) → 12V (door closed). BCM determines that conditions for interior room lamp and map lamp operation are met and turns interior room lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked keyfob, power window main switch (door lock and unlock switch) or door key cylinder switch].
- Driver door is opened (driver door switch turns ON).
- Ignition switch ON.

## INTERIOR LAMP BATTERY SAVER CONTROL

If interior lamp is left "ON", it will not be turned out even when door is closed.

BCM turns off interior lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior lamps listed below:

- Luggage room lamp
- Vanity mirror lamp
- Map lamp
- Interior room lamp
- Personal lamp

After lamps turn OFF by battery saver system, lamps illuminate again when

## INTERIOR ROOM LAMP

---


- signal from keyfob, or power window main switch (door lock and unlock switch) or key cylinder is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder, or turned ignition knob switch.

Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

# INTERIOR ROOM LAMP

## Schematic


AKS007F9



TKWH0228E

# INTERIOR ROOM LAMP

(OD) : Without DVD player






TKWM0823E

# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —

AKS007FA

LT-ROOM/L-01





REFER TO THE FOLLOWING.

- E211 -SUPER MULTIPLE JUNCTION (SMJ)
- M1, M2 -FUSE BLOCK-JUNCTION BOX (J/B)
- M3, M4, M34 -ELECTRICAL UNITS

TKWM2047E

# INTERIOR ROOM LAMP





REFER TO THE FOLLOWING.  
 (B1), (D1), (D31) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M3), (M4) -ELECTRICAL  
 UNITS

TKWM1078E

# INTERIOR ROOM LAMP

LT-ROOM/L-03





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

LT-ROOM/L-04






TKWH0231E



# INTERIOR ROOM LAMP


LT-ROOM/L-06

Ⓞ : WITHOUT DVD PLAYER



# INTERIOR ROOM LAMP

LT-ROOM/L-07






1	
2	(B26), (B36), (B46), (B206)
3	W, W, W, W

REFER TO THE FOLLOWING.  
 (B1), (B201) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M3), (B14) -ELECTRICAL UNITS

TKWM1079E

# INTERIOR ROOM LAMP

LT-ROOM/L-08



REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M3) -ELECTRICAL UNITS

TKWH0235E

# INTERIOR ROOM LAMP

## Terminals and Reference Values for BCM

AKS007FB

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
1	PU	Ignition keyhole illumination signal	OFF	Door is locked. (SW OFF)		Battery voltage
				Door is unlocked. (SW ON)		Approx. 0V
12	P/B	Front door switch AS signal	OFF	Front door switch AS	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
13	P/L	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
22	OR	Power window switch serial link	—	—		
37	B/W	Key-in detection switch signal	OFF	Vehicle key is removed.		Approx. 0V
				Vehicle key is inserted.		Battery voltage
38	W/L	Ignition power supply	ON	—		Battery voltage
39	L	CAN – H	—	—		—
40	R	CAN – L	—	—		—
41	R/B	Battery saver output signal	OFF	30 minutes after ignition switch is turned to OFF		Approx. 0V
			ON	—		Battery voltage
42	L/R	Battery power supply	OFF	—		Battery voltage
47	Y/R	Step lamp signal	OFF	Any door is open (ON)		Approx. 0V
				All doors are closed (OFF)		Battery voltage
48	PU/W	Interior room lamp, map lamp, front door inside handle and rear door inside handle illumination output signal	OFF	Interior door switch: DOOR position	Any door switch ON (open)	Approx. 0V
					Any door switch OFF (closed)	Battery voltage
49	B	Ground	ON	—		Approx. 0V
52	B	Ground	ON	—		Approx. 0V
55	G	Battery power supply	OFF	—		Battery voltage
58	L	Back door switch signal (Auto close motor)	OFF	Back door switch	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
62	W	Front door switch DR signal	OFF	Front door switch DR	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
63	P	Rear door switch LH signal	OFF	Rear door switch LH	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

AKS007FC

## How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-159, "System Description"](#) .
3. Perform Preliminary Check. Refer to [LT-176, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does interior room lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS007FD

### CHECK FOR POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	M
		22
	Ignition switch ON or START position	1

Refer to [LT-167, "Wiring Diagram — ROOM/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

Terminal		Ignition switch position	
(+)		(-)	
Connector	Terminal (Wire color)	OFF	ON
M4	42 (L/R)	Battery voltage	Battery voltage
	55 (G)	Battery voltage	Battery voltage
M3	38 (W/L)	Approx. 0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

#### 3. CHECK GROUND CIRCUIT



Check continuity between BCM and ground.

Terminal		Continuity	
Connector	Terminal (Wire color)	Ground	
M4	49 (B)	Ground	Yes
	52 (B)		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## CONSULT-II Functions (BCM)

AKS007FE

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


BCM diagnosis part	Diagnosis mode	Description
INT LAMP	WORK SUPPORT	Changes setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# INTERIOR ROOM LAMP

4. Touch "INT LAMP" on "SELECT TEST ITEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "SET I/L D- UNLCK INTCON" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED " will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds glowing function interior room lamps and ignition keyhole illumination can be selected when driver door is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned on.	MODE 1 – 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned off.	MODE 1 – 7

Reference between "MODE" and "TIME" for "TURN ON/OFF"

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

## DATA MONITOR

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

All signals	Monitors all the signals.
Selection from menu	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
KEY ON SW "ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from key switch signal.

## INTERIOR ROOM LAMP

Monitor item	Contents
DOOR SW - DR "ON/OFF"	Displays status of driver door as judged from driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from passenger door switch signal.
DOOR SW - RR "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch RH signal.
DOOR SW - RL "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch LH signal.
BACK DOOR SW "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from back door switch signal.
KEY CYL LK - SW "ON/OFF"	Displays "Door locked (ON) status, determined from key cylinder lock switch in driver door.
KEY CYL UN - SW "ON/OFF"	Displays "Door unlocked (OFF) status, determined from key cylinder lock switch in driver door.
CDL LOCK SW "ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF) status, determined from locking detection switch in driver door.
CDL UNLOCK SW "ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in passenger door.
I- KEY LOCK <sup>NOTE</sup> "ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
I- KEY UNLOCK <sup>NOTE</sup> "ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.

**NOTE:**

Vehicle with intelligent key system display this item.

### ACTIVE TEST

#### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

#### Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition key hole illumination can be operated by ON-OFF operation.
STEP LAMP TEST	All step lamp can be operated by ON-OFF operation.
LUGGAGE LAMP TEST <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.

# INTERIOR ROOM LAMP

AKS007FF

## Interior Room Lamp Control Does Not Operate

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-178, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E

### 2. ACTIVE TEST

- Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
- When interior room lamp switch is in DOOR position, use active test to make sure interior room lamp operates.

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA7641E


### 3. CHECK INTERIOR ROOM LAMP INPUT

- Turn ignition switch OFF.
- Check voltage between interior room lamp harness connector R53 terminal 1 (PU) and ground.

**1 (PU) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.




### 4. CHECK INTERIOR ROOM LAMP

- Disconnect interior room lamp connector.
- Check continuity between interior room lamp.

Terminal		Condition	Continuity
Interior room lamp			
1	2	Interior room lamp switch is DOOR.	Yes
		Interior room lamp switch is OFF or ON.	No

OK or NG

- OK >> GO TO 5.
- NG >> Replace Interior room lamp.



# INTERIOR ROOM LAMP


## 5. CHECK INTERIOR ROOM LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminal 41 (R/B) and interior room lamp harness connector R53 terminal 2 (R).

**41 (R/B) – 2 (R) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if interior room lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK INTERIOR ROOM LAMP CIRCUIT

1. Disconnect BCM connector and interior room lamp connector.
2. Check continuity between BCM harness connector M4 terminal 48 (PU/W) and interior room lamp harness connector R53 terminal 1 (PU).

**48 (PU/W) – 1 (PU) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if interior room lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



## Map Lamp Control Does Not Operate

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-178, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK LIGHT COPY

### 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. When map lamp switch is in DOOR position, use active test to make sure map lamp operates.

**Map lamp should operate.**

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK LIGHT COPY

# INTERIOR ROOM LAMP


## 3. CHECK MAP LAMP INPUT

1. Turn ignition switch OFF.
2. Check voltage between map lamp harness connector R52 terminal 2 (PU) and ground.

**2 (PU) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 6.  
NG >> GO TO 4.




## 4. CHECK MAP LAMP

1. Disconnect map lamp connector.
2. Check continuity between map lamp.

Terminal		Condition	Continuity
Map lamp			
2	3	Map lamp switch is DOOR.	Yes
		Map lamp switch is OFF.	No

OK or NG

- OK >> GO TO 5.  
NG >> Replace Map lamp.




## 5. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminal 41 (R/B) and map lamp harness connector R52 terminal 3 (R).

**41 (R/B) – 3 (R) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector and map lamp connector.
2. Check continuity between BCM harness connector M4 terminal 48 (PU/W) and map lamp harness connector R52 terminal 2 (PU).

**48 (PU/W) – 2 (PU) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## Personal Lamp Control Does Not Operate

AKS007FG

### 1. CHECK REAR DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switch "DOOR SW-RR" and "DOOR SW-RL" turn ON-OFF linked with rear door (RH and LH) operation.

#### OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning rear door switch.


DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
CDL LOCK SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIA7640E

### 2. CHECK PERSONAL LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect personal lamp connector.
3. Open rear door.
4. Check continuity between personal lamp harness connector and ground.

Terminal			Ground	Continuity
Personal lamp				
Connector		Terminal (Wire color)	Ground	Yes
RH	R55	1 (L)		
LH	R54	1 (P)		




#### OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

### 3. CHECK PERSONAL LAMP INPUT

Check voltage between personal lamp harness connector and ground.

Terminal			Ground	Voltage
Personal lamp (+)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	R55	2 (R)		
LH	R54			



#### OK or NG


- OK >> Replace personal lamp. Refer to [LT-153, "Removal and Installation"](#).
- NG >> GO TO 4.

# INTERIOR ROOM LAMP

## 4. CHECK PERSONAL LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M4 terminal 41 (R/B) and personal lamp harness connector.

Terminal				Continuity	
BCM		Personal lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
M4	41 (R/B)	RH	R55	2 (R)	Yes
		LH	R54		



**OK or NG**

- OK >> Replace BCM if personal lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
- NG >> Repair harness or connector.

## Ignition Key Hole Illumination Control Does Not Operate

AKS007FH

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-178, "Display Item List"](#) for switches and their functions.

**OK or NG**

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK LIGHT COPY

PKIB3532E

### 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP".
2. Select "IGN ILLUM" active test to make sure lamp operates.

**Ignition key hole illumination should operate.**

**OK or NG**

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
- NG >> GO TO 3.

ACTIVE TEST	
IGN ILLUM	ON
OFF	
MODE	BACK LIGHT COPY

PKIA7642E

# INTERIOR ROOM LAMP


## 3. CHECK IGNITION KEY HOLE ILLUMINATION INPUT

1. Turn ignition switch OFF.
2. Check voltage between ignition key hole illumination harness connector M24 terminal 1 (R/B) and ground.

**1 (R/B) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 4.  
NG >> GO TO 6.




## 4. CHECK IGNITION KEY HOLE ILLUMINATION BULB

1. Disconnect ignition key hole illumination connector.
2. Check continuity between ignition key hole illumination terminals 1 and 2.

**1 – 2 : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Replace ignition key hole illumination. Refer to [LT-155, "Bulb Replacement, Removal and Installation"](#).




## 5. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M3 terminal 1 (PU) and ignition key hole illumination harness connector M24 terminal 2 (PU).

**1 (PU) – 2 (PU) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector and ignition key hole illumination connector.
2. Check continuity between BCM harness connector M4 terminal 41 (R/B) and ignition key hole illumination harness connector M24 terminal 1 (R/B).

**41 (R/B) – 1 (R/B) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

AKS007FI

## All Step Lamps Do Not Operate

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed below turn ON-OFF linked with switch operation.

Switch name	CONSULT screen
Driver side door switch	DOOR SW - DR
Passenger side door switch	DOOR SW - AS
Rear RH side door switch	DOOR SW - RR
Rear LH side door switch	DOOR SW - RL

OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E


### 2. CHECK STEP LAMP INPUT

- Turn ignition switch OFF.
- Check voltage between front door driver side step lamp harness connector D9 terminal 1 (R) and ground.

**1 (R) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 4.




### 3. CHECK STEP LAMP CIRCUIT

- Disconnect BCM connector and front door driver side step lamp connector.
- Check continuity between BCM harness connector M4 terminal 47 (Y/R) and front door driver side step lamp harness connector D9 terminal 2 (SB).

**47 (Y/R) – 2 (SB) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## 4. CHECK STEP LAMP CIRCUIT


1. Disconnect BCM connector and front door driver side step lamp connector.
2. Check continuity between BCM harness connector M4 terminal 41 (R/B) and front door driver side step lamp harness connector D9 terminal 1 (R).

**41 (R/B) – 1 (R) : Continuity should exist.**

### OK or NG

OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Repair harness or connector.



## All Interior Room Lamps Do Not Operate

AKS007FJ

### 1. CHECK POWER SUPPLY CIRCUIT


1. All interior room lamps switch are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M4 terminal 41 (R/B) and ground.

**41 (R/B) – Ground : Battery voltage.**

### OK or NG

OK >> Repair harness or connector. In a case of making a short circuit, be sure to disconnect cable from the negative terminal repairing harness, and then reconnect.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).




## Bulb Replacement INTERIOR ROOM LAMP

AKS007FK

1. Remove interior room lamp. Refer to [LT-188, "Removal and Installation"](#).
2. Insert a suitable tool and remove lens.
3. Remove bulb.

**Interior room lamp :12V - 10W**

4. Installation is the reverse order of removal.



## MAP LAMP

Refer to [LT-152, "Bulb Replacement"](#) in "MAPLAMP".

## PERSONAL LAMP

Refer to [LT-153, "Bulb Replacement"](#) in "PERSONAL LAMP".


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

## Removal and Installation INTERIOR ROOM LAMP

AKS007FL

1. Use a suitable tool to press metal clip and remove room lamp.
2. Disconnect interior room lamp connector.



## MAP LAMP

Refer to [LT-152, "Removal and Installation"](#) in "MAP LAMP".

## PERSONAL LAMP

Refer to [LT-153, "Removal and Installation"](#) in "PERSONAL LAMP".

**ILLUMINATION****System Description**

AKS007EI

Control of illumination lamps operation is dependent upon position of lighting switch (combination switch). When lighting switch is placed in the 1ST or 2ND position (or if auto light system is activated), BCM (body control module) receives input signal requesting illumination lamps to illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls tail lamp relay coil. This relay, when energized, directs power to illumination lamps, which then illuminate.

Power is supplied at all times

- through 10A fuse (No. 71, located in IPDM E/R)
- to tail lamp relay, located in IPDM E/R, and
- to CPU located in IPDM E/R.

Power is also supplied at all times

- through 50A fusible link (letter M, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 15A fuse [No. 22 located in fuse block (J/B)]
- to BCM terminal 42,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse [No. 19 located in fuse block (J/B)]
- to unified meter and A/C amp. terminal 21, and
- to combination meter terminal 8.

With ignition switch in ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct,
- through 15A fuse [No. 1 located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 12, located in fuse block (J/B)]
- to unified meter and A/C amp. terminal 22,
- through 10A fuse [No. 14 located in fuse block (J/B)]
- to combination meter terminal 7.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 and 52
- to unified meter and A/C amp. terminals 29 and 30, and
- to combination meter terminals 5, 6, and 15
- through grounds M35, M45, and M85,
- to IPDM E/R terminals 38 and 60
- through grounds E21, E50, and E51.

**ILLUMINATION OPERATION BY LIGHTING SWITCH**

With lighting switch in the 1ST or 2ND position (or if auto light system is activated), BCM receives input signal requesting illumination lamps to illuminate. This input signal is communicated to IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls tail lamp relay coil, which, when energized, directs power

- through IPDM E/R terminal 22
- to glove box lamp terminal 1
- to A/T device (illumination) terminal 11
- to snow mode switch (illumination) terminal 5
- to VDC off switch (illumination) terminal 3

# ILLUMINATION

---

- to clock (illumination) terminal 3
- to hazard switch (illumination) terminal 3
- to heated seat switch (driver side) (illumination) terminal 5
- to heated seat switch (passenger side) (illumination) terminal 5
- to LDW switch (illumination) terminal 5
- to door mirror remote control switch (illumination) terminal 16
- to A/C and AV switch (illumination) terminal 3
- to NAVI control unit (illumination) terminal 25
- to DVD player (illumination) terminal 12
- to front cigarette lighter socket terminal 2
- to rear power window switch LH (illumination) terminal 6 (without interruption detection function for rear door window), and
- to rear power window switch RH (illumination) terminal 6 (without interruption detection function for rear door window).

## Illumination control

- through combination meter terminal 19
- to A/T device (illumination) terminal 12
- to snow mode switch (illumination) terminal 6
- to VDC off switch (illumination) terminal 4
- to clock (illumination) terminal 4
- to hazard switch (illumination) terminal 4
- to heated seat switch (driver side) (illumination) terminal 6
- to heated seat switch (passenger side) (illumination) terminal 6
- to door mirror remote control switch terminal 15
- to LDW switch (illumination) terminal 4,
- to A/C and AV switch (illumination) terminal 4
- to NAVI control unit (illumination) terminal 30, and
- to DVD player (illumination) terminal 10.

## Ground is supplied at all times

- to glove box lamp terminal 2, and
- to front cigarette lighter socket terminal 3
- through grounds M35, M45 and M85,
- to rear power window switch LH (illumination) terminal 7 (without interruption detection function for rear door window), and
- to rear power window switch RH (illumination) terminal 7 (without interruption detection function for rear door window)
- through grounds B15 and B45.

With power and ground supplied, illumination lamps illuminate.

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the lighting switch is in the 1ST or 2ND position (or if auto light system is activated), and ignition switch is turned from ON or ACC to OFF, battery saver control function is activated.

Under this condition, illumination lamps remain illuminated for 5 minutes, then illumination lamps are turned off.

When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps are turned off by battery saver control, and illumination lamps illuminate again.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

AKS007EJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2

# ILLUMINATION

---

communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## **CAN Communication Unit**

AKS0080Y


Refer to [LAN-30, "CAN Communication Unit"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# ILLUMINATION

## Schematic

AKS007EL




\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

TKWM0670E

# ILLUMINATION

(OF) : Without interruption detection function for rear door window

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M




TKWM2050E



# ILLUMINATION

LT-ILL-02




▬ : DATA LINE

REFER TO PG-POWER.

IPDM E/R  
(INTELLIGENT  
POWER  
DISTRIBUTION  
MODULE  
ENGINE ROOM)  
E7, E8,  
E9

REFER TO THE FOLLOWING.




E211 -SUPER MULTIPLE  
JUNCTION (SMJ)



TKWM1082E

# ILLUMINATION

LT-ILL-03





REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2432E

# ILLUMINATION

LT-ILL-04





\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM0675E

# ILLUMINATION

LT-ILL-05





REFER TO THE FOLLOWING.  
 (E211) -SUPER MULTIPLE  
 JUNCTION (SMJ)

TKWM2051E

# ILLUMINATION

LT-ILL-06


◊DM◊ : WITH MEMORY MIRROR  
 ◊OM◊ : WITHOUT MEMORY MIRROR




(M18) BR  
 (M19) W



(M51) W



(M68) W  
 (M69) BR





(M96) GY

TKWM2052E

# ILLUMINATION

LT-ILL-07



REFER TO THE FOLLOWING.


(B201) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2053E

# ILLUMINATION

LT-ILL-08

⊡ : WITHOUT INTERRUPTION DETECTION FUNCTION FOR REAR DOOR WINDOW



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(B5)  
W

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(B21), (B31)  
W W

6	7			
1	5	4	3	2

(D55), (D75)  
W W

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

TKWM1083E

# ILLUMINATION

---

AKS007EN

## **Removal and Installation** **ILLUMINATION CONTROL SWITCH**

Refer to [DI-27, "Removal and Installation of Odo/Trip Meter and Illumination Control Switch"](#) in "DI" section.

## **GLOVE BOX LAMP**

Refer to [LT-156, "Bulb Replacement, Removal and Installation"](#) .

## **FRONT DOOR INSIDE ILLUMINATION**

Refer to [EI-34, "Removal and Installation"](#) in "EI" section.

# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PFP:26297

### Headlamp

AKS007EO

Item	Wattage (W)
High/Low (Xenon type)	35 (D2S)

### Exterior Lamp

AKS007EP

Item	Wattage (W)	
Front combination lamp	Front turn signal lamp	21 (amber)
	Daytime/Parking lamp	21/5
	Front side marker lamp	3.8
Rear combination lamp	Stop/Tail lamp and Rear Turn signal lamp	LED
	Rear side marker lamp	3.8
Front fog lamp	51 (HB4)	
Back-up lamp	18	
License plate lamp	5	
High-mounted stop lamp (back door mount)	LED	

### Interior Lamp/Illumination

AKS007EQ

Item	Wattage (W)
Map lamp	8
Interior room lamp	10
Personal lamp	8
Luggage room lamp	8
Step lamp	5
Glove box lamp	1.4
Vanity mirror lamp	1.32
Ignition key hole illumination	0.8
Front door inside handle illumination	LED
Rear door inside handle illumination	LED
Console illumination lamp	1.4

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# BULB SPECIFICATIONS

---