

SECTION PG

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

POWER SUPPLY ROUTING CIRCUIT	3	GROUND	31																																																																																														
Schematic	3	Ground Distribution	31																																																																																														
Wiring Diagram - POWER -	4	MAIN HARNESS	31																																																																																														
BATTERY POWER SUPPLY - IGNITION SW. IN ANY POSITION	4	ENGINE ROOM HARNESS	34																																																																																														
ACCESSORY POWER SUPPLY-IGNITION SW. IN "ACC" OR "ON"	10	ENGINE HARNESS/VK ENGINE MODELS	37																																																																																														
IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START"	12	ENGINE HARNESS/VQ ENGINE MODELS	38																																																																																														
Fuse	17	ENGINE CONTROL HARNESS/VK ENGINE MODELS	39																																																																																														
Fusible Link	17	ENGINE CONTROL HARNESS/VQ ENGINE MODELS	40																																																																																														
Circuit Breaker	17	BODY HARNESS	41																																																																																														
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	BODY NO. 2 HARNESS	44																																																																																														
System Description	18	ROOM LAMP HARNESS	45																																																																																														
SYSTEMS CONTROLLED BY IPDM E/R	18	HARNESS	46																																																																																														
CAN COMMUNICATION LINE CONTROL	18	IPDM E/R STATUS CONTROL	19	Harness Layout	46	CAN Communication System Description	19	HOW TO READ HARNESS LAYOUT	46	CAN Communication Unit	19	OUTLINE	47	Function of Detecting Ignition Relay Malfunction ...	19	MAIN HARNESS	48	CONSULT-II Function (IPDM E/R)	20	ENGINE ROOM HARNESS	51	CONSULT-II INSPECTION PROCEDURE	20	ENGINE HARNESS/VK ENGINE MODELS	54	SELF-DIAG RESULTS	21	ENGINE HARNESS/VQ ENGINE MODELS	55	DATA MONITOR	22	ENGINE CONTROL HARNESS/VK ENGINE MODELS	56	ACTIVE TEST	22	ENGINE CONTROL HARNESS/VQ ENGINE MODELS	58	Auto Active Test	24	BODY HARNESS	60	DESCRIPTION	24	BODY NO. 2 HARNESS	62	OPERATION PROCEDURE	24	ROOM LAMP HARNESS	63	INSPECTION IN AUTO ACTIVE TEST MODE... 24	24	FRONT DOOR HARNESS	64	Schematic	26	REAR DOOR HARNESS	65	IPDM E/R Terminal Arrangement	27	BACK DOOR HARNESS	66	IPDM E/R Power/Ground Circuit Inspection	28	Wiring Diagram Codes (Cell Codes)	67	Inspection With CONSULT-II (Self-Diagnosis)	29	ELECTRICAL UNITS LOCATION	70	Removal and Installation of IPDM E/R	30	Electrical Units Location	70	REMOVAL	30	ENGINE COMPARTMENT	70	INSTALLATION	30	PASSENGER COMPARTMENT	71			LUGGAGE COMPARTMENT	73			HARNESS CONNECTOR	74			Description	74			HARNESS CONNECTOR (TAB-LOCKING)	
IPDM E/R STATUS CONTROL	19	Harness Layout	46																																																																																														
CAN Communication System Description	19	HOW TO READ HARNESS LAYOUT	46																																																																																														
CAN Communication Unit	19	OUTLINE	47																																																																																														
Function of Detecting Ignition Relay Malfunction ...	19	MAIN HARNESS	48																																																																																														
CONSULT-II Function (IPDM E/R)	20	ENGINE ROOM HARNESS	51																																																																																														
CONSULT-II INSPECTION PROCEDURE	20	ENGINE HARNESS/VK ENGINE MODELS	54																																																																																														
SELF-DIAG RESULTS	21	ENGINE HARNESS/VQ ENGINE MODELS	55																																																																																														
DATA MONITOR	22	ENGINE CONTROL HARNESS/VK ENGINE MODELS	56																																																																																														
ACTIVE TEST	22	ENGINE CONTROL HARNESS/VQ ENGINE MODELS	58																																																																																														
Auto Active Test	24	BODY HARNESS	60																																																																																														
DESCRIPTION	24	BODY NO. 2 HARNESS	62																																																																																														
OPERATION PROCEDURE	24	ROOM LAMP HARNESS	63																																																																																														
INSPECTION IN AUTO ACTIVE TEST MODE... 24	24	FRONT DOOR HARNESS	64																																																																																														
Schematic	26	REAR DOOR HARNESS	65																																																																																														
IPDM E/R Terminal Arrangement	27	BACK DOOR HARNESS	66																																																																																														
IPDM E/R Power/Ground Circuit Inspection	28	Wiring Diagram Codes (Cell Codes)	67																																																																																														
Inspection With CONSULT-II (Self-Diagnosis)	29	ELECTRICAL UNITS LOCATION	70																																																																																														
Removal and Installation of IPDM E/R	30	Electrical Units Location	70																																																																																														
REMOVAL	30	ENGINE COMPARTMENT	70																																																																																														
INSTALLATION	30	PASSENGER COMPARTMENT	71																																																																																														
		LUGGAGE COMPARTMENT	73																																																																																														
		HARNESS CONNECTOR	74																																																																																														
		Description	74																																																																																														
		HARNESS CONNECTOR (TAB-LOCKING)																																																																																															

TYPE)	74	STANDARDIZED RELAY	80
HARNESS CONNECTOR (SLIDE-LOCKING		Description	80
TYPE)	75	NORMAL OPEN, NORMAL CLOSED AND	
ELECTRICAL UNITS	76	MIXED TYPE RELAYS	80
Terminal Arrangement	76	TYPE OF STANDARDIZED RELAYS	80
SMJ (SUPER MULTIPLE JUNCTION)	78	FUSE BLOCK - JUNCTION BOX (J/B)	82
Terminal Arrangement	78	Terminal Arrangement	82
		FUSE, FUSIBLE LINK AND RELAY BOX	83
		Terminal Arrangement	83


POWER SUPPLY ROUTING CIRCUIT

POWER SUPPLY ROUTING CIRCUIT

PFP:24110

Schematic




AKS007VU



POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram - POWER - BATTERY POWER SUPPLY - IGNITION SW. IN ANY POSITION


AKS007VV



TKWM0708E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02




A
B
C
D
E
F
G
H
I
J

PG

L



M



TKWM1306E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-03





REFER TO THE FOLLOWING.
E211 -SUPER MULTIPLE
 JUNCTION (SMJ)

TKWB0264E

POWER SUPPLY ROUTING CIRCUIT


PG-POWER-04



TKWM0711E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-05




TKWM0712E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-06


: DATA LINE



TKWM0713E


POWER SUPPLY ROUTING CIRCUIT

ACCESSORY POWER SUPPLY - IGNITION SW. IN "ACC" OR "ON"




REFER TO THE FOLLOWING.
E211 -SUPER MULTIPLE

**M1 , E204 -FUSE BLOCK-
FUNCTION BOX (L/R)**



POWER SUPPLY ROUTING CIRCUIT

PG-POWER-08



A
B
C
D
E
F
G
H
I
J


PG

L

M

POWER SUPPLY ROUTING CIRCUIT


IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START"



TKWM2098E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10



A
B
C
D
E
F
G
H
I
J

PG

L
M

REFER TO THE FOLLOWING.



(M1) , (E201) -FUSE BLOCK-
JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM2099E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-11



REFER TO THE FOLLOWING.


(M2, E201, E202)-FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM1096E




POWER SUPPLY ROUTING CIRCUIT

PG-POWER-12



TKWM0719E

POWER SUPPLY ROUTING CIRCUIT



REFER TO THE FOLLOWING.

(M2, E201) -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22


TKWM2525E

POWER SUPPLY ROUTING CIRCUIT

Fuse

AKS007VW

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

AKS007VX

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

AKS007VY

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

AKS005S9

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control, oil pressure switch signal, and hood switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:

None of the IPDM E/R-integrated relays can be removed.

SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control
Using CAN communication line, it receives signal from BCM and controls the following lamps:
 - Headlamps (Hi, Lo)
 - Parking, license plate and tail lamps
 - Tail lamps
 - Front fog lamps
2. Wiper control
Using CAN communication line, it receives signals from BCM and controls the front wipers.
3. Rear window defogger relay control
Using CAN communication line, it receives signals from BCM and controls the rear window defogger relay.
4. A/C compressor control
Using CAN communication line, it receives signals from ECM and controls the A/C compressor.
5. Cooling fan control
Using CAN communication line, it receives signals from ECM and controls cooling fan .
6. Horn control
Using CAN communication line, it receives signals from BCM and controls horn relay.

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L line, CAN H line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control
 - When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
 - Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none">• With the ignition switch ON, the headlamp (low) is ON.• With the ignition switch OFF, the headlamp (low) is OFF.
Parking, license plate and tail lamps	<ul style="list-style-type: none">• With the ignition switch ON, the parking, license plate and tail lamps is ON.• With the ignition switch OFF, the parking, license plate and tail lamps is OFF.
Cooling fan	<ul style="list-style-type: none">• With the ignition switch ON, the cooling fan HI operates.• With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay is OFF
A/C compressor	A/C compressor is OFF
Front fog lamps	Front fog lamp is OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.
 - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 3 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
 - IPDM E/R operates in low power mode.
 - CAN communication is stopped.
 - When a change in CAN communication line is detected, mode switches to CAN communication status.
 - When a change hood switch or ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

AKS005SA

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS00AOF

Refer to [LAN-30, "CAN Communication Unit"](#).

Function of Detecting Ignition Relay Malfunction

AKS005SB

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes to indicate ignition relay malfunction.
- When a state of ignition relay having built-in does not agree with a state of Ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CONSULT-II Function (IPDM E/R)

AKS005SC

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II INSPECTION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".




- Touch "IPDM E/R" on "SELECT SYSTEM" screen.

If "IPDM E/R" is not indicated, refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Select the desired part to be diagnosed on the “SELECT DIAG MODE” screen.



SELF-DIAG RESULTS

Operation Procedure

1. Touch “SELF-DIAG RESULTS” on “SELECT DIAG MODE” screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	CONSULT-II display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	—	—	—	—	—
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> ● If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. ● When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have errors. ● TRANSMIT DIAG ● ECM ● BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

A
B
C
D
E

F
G
H
I
J

PG

L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

DATA MONITOR

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT MONITOR ITEM" screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	SELECT MONITOR ITEM			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Tail & clear request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR fog request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
FR wiper request	FR WIP REQ	STOP/LO/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/BLOCK	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ ^{*1}	ON/OFF	×		×	Status of input signal
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
Hood switch	HOOD SW	ON/OFF	×		×	Input signal status
Theft warning horn request	THFT HRN REQ	ON/OFF	×		×	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	×		×	Output status of IPDM E/R
Cornering lamp request	CRNRNG LMP REQ ^{*2}	OFF/LEFT/RIGHT	×		×	Signal status input from BCM

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- *1: The vehicle without the Intelligent Key system displays only ON without change.
- *2: The cornering lamp item is displayed, but it cannot be monitored.

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

-
3. Touch "START", and confirm its operation.
 4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp operation	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger operation	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) operation	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan operation	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan can be operated.
Lamp (HI, LO, FOG) operation	LAMPS	With a certain operation (OFF, HI ON, LO ON, FOG ON), the lamp relay (Lo, Hi, Fog) can be operated.
Cornering lamp operation	CORNERING LAMP ^{NOTE}	—
Horn operation	HORN	With a certain ON-OFF operation, the horn relay can be operated.

NOTE:

This item is displayed, but cannot be tested.

A

B

C

D

E

F

G

H

I

J

PG

L

M

Auto Active Test

DESCRIPTION

AKS005SD

In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:

- Rear window defogger
- Front wipers
- Parking, license plate and tail lamps
- Front fog lamps
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood and front door (passenger side), and then lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press drivers door switch 10 times (close other doors). Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once oil pressure warning lamp starts blinking.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect [BL-42, "Check Door Switch"](#) when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

- When auto active test mode is actuated, the following eight steps are repeated three times.



NOTE:

Turns ON-OFF the solenoid to switch Hi/Lo. In this case, the bulb does not illuminate.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.


Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	<ul style="list-style-type: none"> BCM signal input system malfunction
		NO	<ul style="list-style-type: none"> Lamp/wiper motor malfunction Lamp/wiper motor ground circuit malfunction Harness/connector malfunction between IPDM E/R and system in question IPDM E/R (integrated relay) malfunction
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction
		NO	<ul style="list-style-type: none"> Rear window defogger relay malfunction Harness/connector malfunction between IPDM E/R and rear window defogger relay. Open circuit of rear window defogger IPDM E/R malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction CAN communication signal between BCM and ECM. CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness/connector malfunction between IPDM E/R and magnetic clutch IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> ECM signal input circuit CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Cooling fan motor malfunction Harness/connector malfunction between IPDM E/R and cooling fan motor IPDM E/R (integrated relay) malfunction
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> Harness/connector malfunction between IPDM E/R and oil pressure switch Oil pressure switch malfunction IPDM E/R malfunction
		NO	<ul style="list-style-type: none"> CAN communication signal between BCM and Unified Meter and A/C Amp Combination meter

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic

AKS005SE




TKWM0654E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Terminal Arrangement

AKS005SF



CKIM0237E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Power/Ground Circuit Inspection

AKS007NW

1. CHECK FUSE AND FUSIBLE LINK

Make sure the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Power source	Fuse and fusible link No.
1, 2	Battery power	C
		E
		71
		78

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link blown, be sure to eliminate cause of malfunction before installing new one.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E3.
3. Check voltage between IPDM E/R harness connector E3 terminals 1 (W/R), 2 (W/L) and ground.


1, 2 – Ground

: Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Replace IPDM E/R power supply circuit harness.



3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors E8 and E9.
2. Check continuity between IPDM E/R harness connectors E8 terminal 38 (B), E9 terminal 50 (B), 60 (B) and ground.


38, 50, 60 – Ground

: Continuity should exist.

OK or NG

OK >> INSPECTION END

NG >> Replace ground circuit harness of IPDM E/R.



Inspection With CONSULT-II (Self-Diagnosis)

AKS005SG

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. CHECK SELF DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the "SELECT SYSTEM" screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-	-	-	No malfunction
CAN COMM CIRC	U1000	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> ● TRANSMIT DIAG ● ECM ● BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END
CAN COMM CIRC>>[LAN-5, "Precautions When Using CONSULT-II".](#)

A

B

C

D

E

F

G

H

J

PG

L

M



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Removal and Installation of IPDM E/R


AKS005SM

REMOVAL

1. Remove battery. Refer to [SC-9, "Removal and Installation"](#) in "Starting and Charging System (SC)" section.
2. Remove IPDM E/R cover A. While pressing pawl on backside of IPDM E/R cover B toward vehicle front to unlock, lift up IPDM E/R.



3. While pressing pawls on right and left side of IPDM E/R, remove IPDM E/R cover B from IPDM E/R.
4. Remove harness connector from IPDM E/R.



INSTALLATION

Installation is the reverse order of removal.


GROUND

GROUND


PFP:00011

Ground Distribution MAIN HARNESS

AKS007VZ



GROUND



CKIM0406E


GROUND

  Preceding page

CONNECTOR NUMBER	CONNECT TO
M34	Intelligent Key unit
M48	Rear view camera control unit
M53	Front cigarette lighter socket ·Cigarette lighter socket illumination ·Ashtray illumination
M56	Unified meter and A/C amp.(Terminal No.29)
M56	Unified meter and A/C amp.(Terminal No.30)
M62	Display unit (Terminal No.6) (Without NAVI)
M63	Display (With NAVI)
M62	Display unit (Terminal No.15) (Without NAVI)
M75	Display control unit (Terminal No.13) (With NAVI)
M64	A/C and AV switch
M67	A/T device (Terminal No.2) ·Detention switch
M67	A/T device (Terminal No.9) ·Mode select switch ·Position select switch
M68	Heated seat switch (Driver side)
M69	Heated seat switch (Passenger side)
M72	Air bag diagnosis sensor unit (Terminal No.2)
M75	Display control unit (Terminal No.3)
M88	ICC unit (Terminal No.19)
M88	ICC unit (Terminal No.20)
M89	ICC unit (Terminal No.46)
M92	AWD control unit (Terminal No.10)
M92	AWD control unit (Terminal No.11)
M152	Glove box lamp
M252	Air mix door motor (Driver side)
M253	Intake door motor
M257	Air mix door motor (Passenger side)
M258	Mode door motor
D32	Door mirror (Passenger side) ·Door mirror defogger
D36	Front power window switch (Passenger side) ·Door lock and unlock switch ·CPU ·Illumination
D40	Front door lock assembly (Passenger side) ·Door unlock sensor
D42	Front door request switch (Passenger side)

*:This sub-harness is not shown in "HARNESS LAYOUT".

Body ground




CKIM0407E

GROUND

ENGINE ROOM HARNESS

CONNECTOR NUMBER	CONNECT TO
(E6)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No.15) (With VQ engine) ·Cooling fan relay-1 ·Cooling fan relay-3
(E8)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No.38) ·CPU ·Ignition relay ·Front wiper relay
(E9)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No.50) ·CPU
(E9)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No.60) ·CPU
(E12)	Accessory relay-2
(E14)	ICC brake hold relay
(E22)	Front side marker lamp RH
(E23)	Clearance lamp RH ·Parking ·Daytime
(E24)	Front combination lamp RH (Terminal No.7) ·Headlamp ·High beam solenoid
(E24)	Front combination lamp RH (Terminal No.8) ·Turn signal
(E39)	ICC sensor
(E41)	Cooling fan motor (Terminal No.3) (With VK engine)
(E123)	Cooling fan motor-2 (Terminal No.4) (With VQ engine)
(E41)	Cooling fan motor (Terminal No.4) (With VK engine)
(E123)	Cooling fan motor-2 (Terminal No.3) (With VQ engine)
(E45)	Front fog lamp LH






Next page

GROUND

A
B
C
D
E
F
G
H
I
J

PG


 Preceding page



Body ground

CKIM0292E

GROUND



CKIM0202E

GROUND




ENGINE HARNESS/VK ENGINE MODELS

A
B
C
D
E
F
G
H
I
J

PG

L
M


CONNECTOR NUMBER	CONNECT TO
(E309)	Alternator



CKIM0203E

GROUND


ENGINE HARNESS/VQ ENGINE MODELS



CKIM0204E

GROUND


ENGINE CONTROL HARNESS/VK ENGINE MODELS



CKIM0408E


GROUND

ENGINE CONTROL HARNESS/VQ ENGINE MODELS



GROUND



BODY HARNESS



CKIH0251E


GROUND

J Preceding page



GROUND

A
B
C
D
E
F
G
H
I
J



PG


L

M

CKIM0209E


GROUND

BODY NO. 2 HARNESS



GROUND

ROOM LAMP HARNESS



A
B
C
D
E
F
G
H
I
J
L
M

CKIM0211E

PG

HARNESS

HARNESS

PFP:00011


Harness Layout

HOW TO READ HARNESS LAYOUT

AKS007W0

The following Harness Layouts use a map style grid to help locate connectors on the figures:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness



To Use the Grid Reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the figure, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL


Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

CKIT0108E

HARNESS

OUTLINE



TKIM0061E

A
B
C
D
E
F
G
H
I
J


PG

L

M

HARNESS

MAIN HARNESS



TKIM0291E


HARNESS

A4 ★ (M1)	W/16	Fuse block (J/B)	
A4 (M2)	W/8	Fuse block (J/B)	
A5 (M3)	W/40	BCM (Body control module)	
A5 (M4)	B/15	BCM (Body control module)	
B5 (M5)	W/16	Data link connector	
A4 (M6)	W/2	Low tire pressure warning check switch	
D2 (M7)	W/2	Diode	
D2 (M8)	W/2	Diode	
C1 (M9)	W/2	Diode	
D1 (M10)	W/2	Diode	
A4 ★ (M11)	SMJ	To (B1)	
D1 (M12)	W/2	Diode	
C4 (M13)	GY/6	ADP steering switch	
C4 (M14)	W/8	Steering angle sensor	
D4 ★ (M15)	GY/8	Combination switch (Spiral cable)	
D4 (M16)	Y/6	Combination switch (Spiral cable)	
C3 (M17)	W/16	Combination switch	
A3 (M18)	BR/16	Door mirror remote control switch (With automatic drive positioner)	E1
C4 (M19)	W/16	Door mirror remote control switch (Without automatic drive positioner)	E1
C1 ★ (M20)	W/24	Combination meter	
A4 (M21)	SMJ	To (D1)	
D2 (M22)	GY/6	Key switch and ignition knob switch (With Intelligent Key)	
C1 (M23)	BR/2	Key switch (Without Intelligent Key)	
C1 (M24)	W/2	Ignition keyhole illumination	
D4 (M25)	W/4	NATS antenna amp.	
D4 (M26)	W/4	Steering lock unit	
C4 (M27)	W/4	Tilt motor and telescopic motor	
C4 (M28)	W/4	Tilt sensor and telescopic sensor	
C4 (M29)	W/2	Circuit breaker	
B2 (M30)	B/5	Passenger side select unlock relay	
A1 (M31)	W/18	To (R1)	
B5 (M32)	GY/6	VDC off switch	
A3 (M34)	W/40	Intelligent Key unit	
A2 ★ (M35)	—	Body ground	
A2 (M36)	BR/2	Instrument speaker LH	
A1 (M37)	W/3	Optical sensor	
A2 (M38)	BR/2	Security indicator lamp	
D4 ★ (M41)	SMJ	To (E211)	
D4 (M42)	Y/4	To (E212)	
C1 ★ (M45)	—	Body ground	
D3 (M46)	W/2	In vehicle sensor	
E3 (M48)	W/16	Rear view camera control unit	
E3 (M49)	W/32	Automatic drive positioner control unit	
E3 (M50)	W/16	Automatic drive positioner control unit	
E4 (M51)	W/4	Hazard switch	
E4 (M52)	W/4	Clock	
E4 (M53)	W/3	Front cigarette lighter socket	
E4 (M54)	BR/2	A/T device (Illumination)	
G3 ★ (M55)	GY/20	Unified meter and A/C amp.	
E2 (M56)	GY/16	Unified meter and A/C amp.	
E2 (M57)	W/24	Unified meter and A/C amp.	
F3 (M58)	W/10	Audio unit	
E3 (M59)	W/6	Audio unit	
E2 (M60)	W/16	Audio unit	
E3 (M61)	BR/2	Antenna amp.	
E1 (M62)	W/24	Display unit (Without NAVI)	
E1 (M63)	W/24	Display (With NAVI)	
E1 (M64)	W/16	A/C and AV switch	
E1 (M65)	BR/8	Audio unit	
D1 (M66)	BR/2	Instrument speaker center	
F4 ★ (M67)	W/10	A/T device	
E4 (M68)	W/6	Heated seat switch (Driver side)	
G4 (M69)	BR/6	Heated seat switch (Passenger side)	
G4 (M70)	W/2	Inside key antenna-1 (Dashboard)	
G4 (M71)	B/6	Yaw rate / Side / Decel G sensor (AWD models)	
G5 (M72)	Y/28	Air bag diagnosis sensor unit	
G4 (M73)	-16	DVD player	
E1 (M75)	W/24	Display control unit (With NAVI)	
F1 (M76)	W/32	Display control unit (With NAVI)	
E1 (M77)	W/6	Heater and cooling unit (Via sub-harness)	
F3 (M78)	W/6	Blower motor	
G5 (M79)	B/6	Yaw rate / Side G sensor (2WD models)	
G2 (M81)	SMJ	To (B201)	
G2 ★ (M82)	SMJ	To (E102)	

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0292E

HARNESS



G1	(M83)	W/4	:	To (M151)
G1	(M84)	Y/4	:	Front passenger air bag module
G1 *	(M85)	—	:	Body ground
F1	(M86)	BR/2	:	Instrument speaker RH
F1	(M87)	BR/2	:	Sunload sensor
F1	(M88)	W/24	:	ICC unit
G2	(M89)	GY/24	:	ICC unit
G3 *	(M90)	SMJ	:	ECM
G2	(M91)	SMJ	:	To (D31)
G3	(M92)	W/16	:	AWD control unit
F3	(M94)	W/12	:	Option connector-1 for audio unit
B4	(M95)	W/8	:	Snow mode switch
C5	(M96)	GY/8	:	LDW switch
D1	(M97)	BR/4	:	LDW chime
E1	(M98)	W/4	:	Remote keyless entry receiver

Glove box lamp sub-harness


G1	(M151)	W/4	:	To (M83)
G1	(M152)	W/2	:	Glove box lamp
G1	(M153)	W/2	:	Inside key antenna-2 (Dashboard)

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

Harness

ENGINE ROOM HARNESS

Engine Compartment



TKIH0004E

HARNESS


Engine room harness		Front fog lamp RH sub-harness (With VQ engine)		Cooling fan sub-harness	
C2 (E1)	B/2 : Fusible link holder	B4 (E39)	GY/6 : ICC sensor	B4 (E40)	Y/2 : Crash zone sensor
C2 (E2)	GY/2 : Fusible link holder	B4 (E41)	GY/4 : Cooling fan motor (With VK engine)	B4 (E42)	B/2 : Front side marker lamp LH
C1 (E3)	B/2 : IPDM E/R (Intelligent power distribution module engine room)	E3		D3	GY/3 : Clearance lamp LH
C1 ★ (E4)	W/4 : IPDM E/R (Intelligent power distribution module engine room)	E3		E3	B/8 : Front combination lamp LH
B1 ★ (E5)	B/4 : IPDM E/R (Intelligent power distribution module engine room)	D3		D5	BR/2 : Front fog lamp LH
D2 ★ (E6)	W/6 : IPDM E/R (Intelligent power distribution module engine room)	E3		E4	GY/2 : Front wheel sensor LH
C1 ★ (E7)	GY/16 : IPDM E/R (Intelligent power distribution module engine room)	E3		E4	GY/2 : Body ground
C1 ★ (E8)	W/12 : IPDM E/R (Intelligent power distribution module engine room)	D3		E3	GY/2 : Body ground
D2 ★ (E9)	W/16 : IPDM E/R (Intelligent power distribution module engine room)	D3		D3	GY/2 : Body ground
F1 ★ (E10)	– : Fuse and fusible link block	D3		D3	GY/2 : Body ground
C2 (E11)	– : Fuse, fusible link and relay box	D3		E1	GY/2 : Brake fluid level switch
F1 (E12)	L/4 : Accessory relay-2	E1		E3	B/3 : Pressure sensor
B1 (E13)	BR/6 : Rear window defogger relay	E2		E2	GY/6 : Brake booster
B1 ★ (E14)	GY/6 : ICC brake hold relay	D2		D2	To (E141) SMJ : ABS actuator and electric unit (Control unit)
A1 (E15)	L/4 : Daytime light relay	F2		F2	GY/5 : Front wiper motor
B1 (E16)	– : Relay box	F2		F2	GY/5 : Front fog lamp RH
D1 ★ (E17)	GY/6 : To (F47) (With VK engine)	A4		A4	B/2 : To (E25)
D1 ★ (E18)	GY/9 : To (F48) (With VQ engine)	A4		A4	BR/2 : Front fog lamp RH
D1 ★ (E19)	B/8 : To (F49)	C3 ★ (E121)	DGY/8 : To (E29)		
B1 (E20)	GY/2 : Hood switch	B3 ★ (E122)	GY/4 : Cooling fan motor-1		
B2 ★ (E21)	– : Body ground	C3 ★ (E123)	GY/4 : Cooling fan motor-2		
A2 (E22)	B/2 : Front side marker lamp RH				
A2 (E23)	GY/3 : Clearance lamp RH				
A1 (E24)	B/8 : Front combination lamp RH				
A3 (E25)	B/2 : To (E101)				
A3 (E26)	GY/2 : Washer level sensor				
A3 (E27)	BR/2 : Rear washer motor				
A3 (E28)	GY/2 : Front washer motor				
C2 ★ (E29)	B/8 : To (E121) (With VQ engine)				
C2 (E30)	GY/1 : To (E33)				
C2 (E31)	– : Body ground				
A2 (E32)	B/3 : Refrigerant pressure sensor				
A2 (E33)	GY/2 : Front wheel sensor RH				
B3 (E34)	B/2 : Ambient sensor				
C3 (E35)	B/1 : Horn low				
C3 (E36)	B/1 : Horn low				
C4 (E37)	B/1 : Horn high				
C4 (E38)	B/1 : Horn high				

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC section.

TKIH0005E

HARNESS

Passenger Compartment




TKIM0162E

A
B
C
D
E
F
G
H
I
J
K
L
M
PG

HARNESS


ENGINE HARNESS/VK ENGINE MODELS



TKIM0068E

HARNESS


ENGINE HARNESS/VQ ENGINE MODELS



TKIM0069E

HARNESS

ENGINE CONTROL HARNESS/VK ENGINE MODELS



TKIM0294E

HARNESS

Engine control harness


D4 (F1) GY/1	: Oil pressure switch	D1 ★ (F49)	B/8 : To (E19)
E4 (F2) B/1	: Compressor (Magnet clutch)	E4 (F51)	- : Engine ground
D5 ★ (F4) B/3	: Camshaft position sensor (PHASE)	D4 ★ (F52)	B/4 : Heated oxygen sensor 2 (Bank 2)
E5 (F6) B/2	: Compressor (ECV solenoid valve)	A5 ★ (F101)	SMJ : ECM
F4 ★ (F7) B/6	: Mass air flow sensor	B5 ★ (F102)	SMJ : To (M82)
F4 (F11) -	: Engine ground		
E4 ★ (F12) B/3	: Intake valve timing control position sensor (Bank 1)		
D4 ★ (F13) LGY/2	: Intake valve timing control solenoid valve (Bank 1)	F2 ★ (F201)	GY/6 : To (F21)
F3 (F15) GY/3	: Ignition coil No.1 (With power transistor)	E3 ★ (F202)	GY/2 : Injector No.1
F3 (F16) GY/3	: Ignition coil No.3 (With power transistor)	E2 ★ (F203)	GY/2 : Injector No.3
F3 (F17) GY/3	: Ignition coil No.5 (With power transistor)	E3 ★ (F204)	GY/2 : Injector No.5
F3 (F18) GY/3	: Ignition coil No.7 (With power transistor)	E2 ★ (F205)	GY/2 : Injector No.7
F1 ★ (F19) DGY/6	: Electric throttle control actuator		
F1 ★ (F21) DGY/6	: To (F201)		
F3 ★ (F22) GY/4	: Heated oxygen sensor 1 (Bank 1)	B2 ★ (F221)	GY/6 : To (F41)
F1 (F23) W/2	: Condenser	C3 ★ (F222)	GY/2 : Injector No.2
F1 ★ (F24) B/2	: To (F261)	C4 ★ (F223)	GY/2 : Injector No.4
E1 ★ (F25) LGY/2	: EVAP canister purge volume control solenoid valve	C4 ★ (F224)	GY/2 : Injector No.6
C3 (F29) B/2	: VIAS control solenoid valve	D2 ★ (F225)	GY/2 : Injector No.8
B3 ★ (F30) B/3	: Intake valve timing control position sensor (Bank 2)		
B3 ★ (F31) LGY/2	: Intake valve timing control solenoid valve (Bank 2)	E1 ★ (F241)	B/4 : To (F40)
D3 ★ (F32) GY/4	: Heated oxygen sensor 2 (Bank 1)	D3 ★ (F242)	L/2 : Knock sensor (Bank 1)
B2 (F35) GY/3	: Ignition coil No.2 (With power transistor)	C4 ★ (F243)	L/2 : Knock sensor (Bank 2)
B2 (F36) GY/3	: Ignition coil No.4 (With power transistor)		
B2 (F37) GY/3	: Ignition coil No.6 (With power transistor)		
C1 (F38) GY/3	: Ignition coil No.8 (With power transistor)		
D1 ★ (F40) B/4	: To (F241)	F3 ★ (F261)	SB/2 : To (F24)
B2 ★ (F41) DGY/6	: To (F221)	E1 ★ (F262)	GY/2 : Engine coolant temperature sensor
D1 ★ (F42) GY/4	: Heated oxygen sensor 1 (Bank 2)		
E1 (F43) B/8	: Transfer assembly		
E1 ★ (F44) DGY/10	: A/T assembly		
D3 ★ (F45) B/3	: Crankshaft position sensor (POS)		
C1 ★ (F46) GY/6	: To (E306)		
D1 ★ (F47) GY/6	: To (E17)		

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

TKIM0295E

HARNESS

ENGINE CONTROL HARNESS/VQ ENGINE MODELS



TKIM0296E

HARNESS

Engine control harness

B4	F1	GY/1	: Oil pressure switch
C5	F2	B/1	: Compressor (Magnet clutch)
D5	F6	B/2	: Compressor (ECV solenoid valve)
E3	*	F8	: Mass air flow sensor
B2	*	F10	To (F211)
C4	F11	—	: Engine ground
D1	*	F12	GY/3 : Camshaft position sensor (PHASE) (Bank 1)
B1	F17	GY/3	: Ignition coil No.5 (With power transistor)
E2	*	F19	DGY/6 : Electric throttle control actuator
B1	*	F20	To (F252)
B1	F23	W/2	: Condenser
D1	*	F25	LGY/2 : EVAP canister purge volume control solenoid valve
B3	F26	GY/2	: Alternator
A3	*	F27	B/3 : Power steering pressure sensor
C1	*	F28	GY/2 : Engine coolant temperature sensor
E2	*	F30	B/3 : Camshaft position sensor (PHASE) (Bank 2)
D4	*	F31	LGY/2 : Intake valve timing control solenoid valve (Bank 2)
C3	*	F32	B/4 : Heated oxygen sensor 2 (Bank 1)
C3,D4	F33	GY/1	: Starter motor
E3	F35	GY/3	: Ignition coil No.2 (With power transistor)
E3	F36	GY/3	: Ignition coil No.4 (With power transistor)
E3	F37	GY/3	: Ignition coil No.6 (With power transistor)
E2	F43	B/8	: Transfer assembly
D1	*	F44	DGY/10 : A/T assembly
C4	*	F45	B/3 : Crankshaft position sensor (POS)
C1	*	F48	GY/9 : To (E18)
C1	*	F49	B/8 : To (E19)
D1	*	F50	G/8 : To (F251)
C4	F51	—	: Engine ground
C4	*	F52	GY/4 : Heated oxygen sensor 2 (Bank 2)
B2	*	F61	-6 : Air fuel ratio (A/F) sensor 1 (Bank 1)
E3	*	F62	-6 : Air fuel ratio (A/F) sensor 1 (Bank 2)
F5	*	F101	SMJ : ECM
G5	*	F102	SMJ : To (M82)

Engine control sub-harness-1

B2	*	F211	L/6 : To (F10)
B3		F212	GY/3 : Ignition coil No.1 (With power transistor)
B2		F213	GY/3 : Ignition coil No.3 (With power transistor)
B3	*	F214	G/2 : Intake valve timing control solenoid valve (Bank 1)


Engine control sub-harness-2

D2	*	F251	G/8 : To (F50)
B1	*	F252	SB/2 : To (F20)
B3	*	F253	GY/2 : Injector No.1
C3	*	F254	GY/2 : Injector No.3
C1	*	F255	GY/2 : Injector No.5
C3	*	F256	GY/2 : Injector No.2
D3	*	F257	GY/2 : Injector No.4
D2	*	F258	GY/2 : Injector No.6
D2	*	F259	L/2 : Knock sensor

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

HARNESS

BODY HARNESS



HARNESS

Body harness				
B2 ★	(B1) SMJ	: To (M1)		
A2	(B5) W/16	: To (E205)		
A2 ★	(B6) W/6	: To (E206)		
B3	(B7) Y/2	: Front LH side air bag module		
B3	(B8) W/16	: Front power seat (Driver side) (With automatic drive positioner)	F3	W/16 : To (B191) (With DVD player)
B3	(B9) W/4	: Front power seat (Driver side) (Without automatic drive positioner)	E3	GY/1 : Not used
A3	(B14) W/15	: BCM (Body control module)	E3	W/12 : Rear combination lamp control unit
B3 ★	(B15) -	: Body ground	E3	W/2 : Diode
C2	(B17) Y/12	: Air bag diagnosis sensor unit	F2	BR/2 : Inside key antenna-3 (Luggage room)
D2	(B18) Y/12	: Air bag diagnosis sensor unit	F2	SB/4 : Rear wheel sensor
C2	(B19) -/16	: DVD player	F2	W/2 : Diode
C2	(B20) W/3	: To (B101)	F3	W/12 : To (B81)
B2	(B21) W/18	: To (D51)	F3	W/12 : To (B80)
C3	(B23) Y/2	: Front LH seat belt pre-tensioner	F2 ★	GY/6 : To (B216)
C3	(B24) Y/2	: LH side air bag (Satellite) sensor	D2	W/4 : To (B217)
B2	(B25) -	: Body ground		
B3	(B26) W/3	: Front door switch (Driver side)		
D1	(B27) Y/2	: Front RH side air bag module		
C1	(B28) W/6	: Front power seat (Passenger side)		
C1	(B31) W/18	: To (D71)		
E2	(B33) Y/2	: Front RH seat belt pre-tensioner	D1	W/16 : To (B61)
E2	(B34) Y/2	: RH side air bag (Satellite) sensor	C1	-/16 : DVD display
D1	(B35) -	: Body ground		
D1	(B36) W/3	: Front door switch (Passenger side)		
D3 ★	(B39) GY/5	: Fuel level sensor unit and fuel pump (Main)		
D3	(B40) GY/2	: Fuel level sensor unit (Sub)		
D3	(B44) W/4	: Back-up lamp relay		
D3 ★	(B45) -	: Body ground		
D2	(B46) W/3	: Rear door switch LH		
D3	(B49) W/3	: Luggage room lamp (Body side)		
F1	(B51) W/16	: To (D10)		
F1	(B52) W/6	: To (D102)		
F1	(B53) W/3	: Luggage room lamp (Back door side)		
E1	(B54) OR/2	: LH side curtain air bag module		
F1	(B55) Y/2	: RH side curtain air bag module		
F2	(B56) BR/2	: Tweeter LH		
F2	(B57) W/4	: Rear combination lamp LH		
F2	(B58) B/2	: Luggage room power socket		

TKIM0299E


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

HARNESS



BODY NO. 2 HARNESS

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC section.

★(B201)	SMJ	:	To (M81)
(B202)	GY/1	:	GPS antenna
(B203)	-	:	Body ground
(B206)	W/3	:	Rear door switch RH
(B207)	GY/24	:	NAVI control unit
(B208)	W/24	:	NAVI control unit
(B209)	GY/1	:	NAVI control unit
(B210)	-	:	Body ground




For detail ground distribution information,
refer to "GROUND DISTRIBUTION".



TKIM0169E

HARNESS

ROOM LAMP HARNESS




TKIM0300E

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
PG

HARNESS


FRONT DOOR HARNESS

LH Side



TKIH0012E

RH Side




TKIH0013E

HARNESS

REAR DOOR HARNESS

LH Side


- (D51) W/18 : To (B21)
- (D52) B/6 : Rear door lock actuator LH
- (D53) BR/2 : Rear door speaker LH
(With BOSE system)
- (D54) W/2 : Rear door speaker LH
(Without BOSE system)
- (D55) W/8 : Rear power window switch LH
(Without interruption detection function)



TKIH0014E

RH Side

- (D71) W/18 : To (B31)
- (D72) B/6 : Rear door lock actuator RH
- (D73) BR/2 : Rear door speaker RH
(With BOSE system)
- (D74) W/2 : Rear door speaker RH
(Without BOSE system)




- (D75) W/8 : Rear power window switch RH
(Without interruption detection function)
- (D76) BR/2 : Rear power window motor RH
(Without interruption detection function)
- (D78) W/16 : Rear power window switch RH
(With interruption detection function)
- (D79) GY/6 : Rear power window motor RH
(With interruption detection function)
- (D80) W/2 : Rear step lamp RH
- (D81) GY/2 : Rear door inside handle illumination RH
- (D82) GY/2 : Outside key antenna-2 (Rear door RH)

TKIH0015E

HARNESS

BACK DOOR HARNESS

D101	W/16	:	To (B51)
D102	W/6	:	To (B52)
D103	GY/2	:	High-mounted stop lamp
D104	GY/1	:	Rear window defogger (+)
D105	W/2	:	Back-up lamp LH
D106	W/10	:	Back door closure control unit
D107	W/4	:	Rear wiper motor
D108	W/4	:	Rear view camera
D109	W/8	:	Back door closure motor
D110	W/2	:	License plate lamp LH
D111	W/2	:	License plate lamp RH
D112	W/2	:	Back door opener switch
D113	BR/2	:	Back door request switch
D114	GY/1	:	Rear window defogger (-)
D115	W/2	:	Back-up lamp RH
D116	BR/2	:	Outside key antenna-3 (Back door)



TKIH0016E

HARNESS

Wiring Diagram Codes (Cell Codes)

AKS007X0

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner
AUTO/L	LT	Automatic Light System
AWD	TF	AWD Control System
B/CLOS	BL	Back Door Closure System
BACK/L	LT	Back-Up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
CLOCK	DI	Clock
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication Line
COMPAS	DI	Compass
COOL/F	EC	Cooling Fan Control
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECM/PW	EC	ECM Power Supply for Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Electric Throttle Control Motor Relay
ETC3	EC	Electric Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FTS	AT	A/T Fluid Temperature Sensor Circuit
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)

HARNESS

Code	Section	Wiring Diagram Name
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/KEY	BL	Intelligent Key System
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
IATS	EC	Intake Air Temperature Sensor
ICC	ACS	Intelligent Cruise Control System
ICC/BS	EC	ICC Brake Switch
ICC/SW	EC	ICC Steering Switch
ICCB0F	EC	ICC Brake Switch
IGNSYS	EC	Ignition System
ILL	LT	Illumination
INF/D	AV	Vehicle Information and Integrated Switch System
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
IVCSB1	EC	Intake Valve Timing Control Position Sensor Bank 1
IVCSB2	EC	Intake Valve Timing Control Position Sensor Bank 2
IVTB1	EC	Intake Valve Timing Control System (Bank 1)
IVTB2	EC	Intake Valve Timing Control System (Bank 2)
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
LDW	DI	Lane Departure Warning System
M/ANT	AV	Manual Antenna
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
MES	AV	Mobile Entertainment System
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL & Data Link Connectors
MIRROR	GW	Power Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
NONDTC	AT	Non-Detective Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater Bank 1
O2H1B2	EC	Heated Oxygen Sensor 1 Heater Bank 2
O2H2B1	EC	Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Heated Oxygen Sensor 2 Heater Bank 2
O2S1B1	EC	Heated Oxygen Sensor 1 Bank 1
O2S1B2	EC	Heated Oxygen Sensor 1 Bank 2
O2S2B1	EC	Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Heated Oxygen Sensor 2 Bank 2

HARNESS

Code	Section	Wiring Diagram Name
P/SCKT	WW	Power Socket
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank 2)
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
R/VIEW	DI	Rear View Camera Control System
ROOM/L	LT	Interior Room Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SNOWSW	EC	Snow Mode Switch
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal Circuit
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	Homelink Universal Transceiver
TURN	LT	Turn Signal and Hazard Warning Lamp
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System
VENT/V	EC	EVAP Canister Vent Control Valve
VIAS/V	EC	VIAS Control Solenoid Valve
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer
WIPER	WW	Front Wiper and Washer



ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT


AKS007W2




CKIM0212E

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT



A Behind dash side lower finisher LH




Fuse block (J/B) rear view



CKIM0411E


ELECTRICAL UNITS LOCATION

B Driver side view with lower instrument panel removed




Intelligent Key unit (M34)

C Driver side view with cluster lid A removed




Steering lock unit (M26)

D Under driver seat




Driver seat control unit (B152, B153)

E View with cluster lid C removed




Unified meter and A/C amp.
(M55, M56, M57)

F View with instrument panel center removed




Rear view camera control unit (M48)

G Behind lower instrument panel on passenger side



Blower motor

H Behind lower instrument panel on passenger side




ECM
(M90, F101)

AWD control unit (M92)

J View with floor console box removed


Yaw rate/side/decel G sensor(AWD models)
(M71)

Yaw rate/side G sensor(2WD models)
(M79)




Air bag diagnosis sensor unit
(M72, B17, B18)

K View with passenger seat removed



NAVI control unit
(B207, B208, B209)

L Map lamp garnish removed








LDW camera unit (R9)

CKIM0412E

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT



CKIM0215E

A
B
C
D
E
F
G
H
I
J

PG
L
M

HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

AKS007W3


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]

Waterproof type




① Firmly grasp shell of connector housing at A.

② Push slider until connector pops or snaps apart.

③ Disconnect harness connector.

Non-waterproof type



① Firmly grasp shell of connector housing at A.

② Pull back on the slider while pulling apart male and female halves of connector.

③ Disconnect harness connector.

SEL769V

ELECTRICAL UNITS


ELECTRICAL UNITS

PFP:00011


Terminal Arrangement

AKS007W5


ECM




ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



UNIFIED METER AND A/C AMP.



BCM (BODY CONTROL MODULE)



CKIM0217E

ELECTRICAL UNITS

A

INTELLIGENT KEY UNIT

B

C

D

E


F

G

H

I

J




(White)




ICC UNIT

K



(White)



(Gray)



PG

L

M

CKIM0218E


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

Terminal Arrangement


PFP:B4341

AKS007W6



CKIH0255E

SMJ (SUPER MULTIPLE JUNCTION)



CKIM0220E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

AKS007W7

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make















1T 1 Transfer

1M·1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

CKIM0221E

A
B
C
D
E
F
G
H
I
J

PG
L
M

FUSE BLOCK - JUNCTION BOX (J/B)


FUSE BLOCK - JUNCTION BOX (J/B)

PFP:24350


Terminal Arrangement

AKS007W8

To main harness



To engine room harness





FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

Terminal Arrangement

AKS007W9



FUSE, FUSIBLE LINK AND RELAY BOX
