

A
B
C

SECTION SC

STARTING & CHARGING SYSTEM

CONTENTS

<p>PRECAUTIONS 2</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 2</p> <p>PREPARATION 3</p> <p>Special Service Tools 3</p> <p>Commercial Service Tools 3</p> <p>BATTERY 4</p> <p>How to Handle Battery 4</p> <p style="padding-left: 20px;">METHODS OF PREVENTING OVER-DISCHARGE 4</p> <p style="padding-left: 20px;">CHECKING ELECTROLYTE LEVEL 5</p> <p style="padding-left: 20px;">SPECIFIC GRAVITY CHECK 5</p> <p style="padding-left: 20px;">CHARGING THE BATTERY 6</p> <p>Trouble Diagnoses with Battery Service Center 7</p> <p>Removal and Installation 7</p> <p style="padding-left: 20px;">REMOVAL 7</p> <p style="padding-left: 20px;">INSTALLATION 7</p> <p>STARTING SYSTEM 8</p> <p>System Description 8</p> <p>Wiring Diagram — START — 9</p> <p style="padding-left: 20px;">VK45DE ENGINE MODELS 9</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS 10</p> <p>Trouble Diagnosis with Starting/Charging System</p> <p>Tester (Starting) 11</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 1 12</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 2 13</p> <p style="padding-left: 20px;">MINIMUM SPECIFICATION OF CRANKING VOLTAGE REFERENCING COOLANT TEMPERATURE 13</p> <p>Removal and Installation 14</p>	<p style="text-align: right;">D E F G H I J K L M</p> <p style="text-align: right;">VK45DE ENGINE MODELS 14</p> <p style="text-align: right;">VQ35DE ENGINE MODELS (2WD) 15</p> <p style="text-align: right;">VQ35DE ENGINE MODELS (AWD) 16</p> <p style="text-align: right;">Disassembly and Assembly 17</p> <p style="padding-left: 20px;">VK45DE ENGINE MODELS 17</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS (2WD) 18</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS (AWD) 19</p> <p style="padding-left: 20px;">INSPECTION AFTER DISASSEMBLY 19</p> <p>CHARGING SYSTEM 20</p> <p>System Description 20</p> <p style="padding-left: 20px;">MALFUNCTION INDICATOR 20</p> <p>Wiring Diagram — CHARGE — 21</p> <p style="padding-left: 20px;">VK45DE ENGINE MODELS 21</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS 22</p> <p>Trouble Diagnosis with Starting/Charging System</p> <p>Tester (Charging) 23</p> <p style="padding-left: 20px;">PRELIMINARY INSPECTION 24</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 1 25</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 2 25</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 3 25</p> <p style="padding-left: 20px;">DIAGNOSTIC PROCEDURE 4 26</p> <p>Removal and Installation 27</p> <p style="padding-left: 20px;">VK45DE ENGINE MODELS 27</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS 28</p> <p>Disassembly and Assembly 30</p> <p style="padding-left: 20px;">VK45DE ENGINE MODELS 30</p> <p style="padding-left: 20px;">VQ35DE ENGINE MODELS 31</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS) 32</p> <p style="padding-left: 20px;">Battery 32</p> <p style="padding-left: 20px;">Starter 32</p> <p style="padding-left: 20px;">Alternator 32</p>
---	---

PRECAUTIONS

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS002UK

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PREPARATION

PREPARATION

PF0:00002

Special Service Tools

NKS0056N

Tool number (Kent-Moore No.) Tool name	Description
<p>— (J-48087) Battery Service Center</p>  <p style="text-align: right; margin-right: 50px;">WKIA5280E</p>	<p>Tests battery. For operating instructions, refer to Technical Service Bulletin and Battery Service Center User Guide.</p>
<p>— (J-44373 Model MCR620) Starting/Charging System Tester</p>  <p style="text-align: right; margin-right: 50px;">SEL403X</p>	<p>Tests starting and charging systems. For operating instructions, refer to Technical Service Bulletin.</p>

Commercial Service Tools

NKS0056O

Tool name	Description
<p>Power tool</p>  <p style="text-align: right; margin-right: 50px;">PIIB1407E</p>	<p>Loosening bolts, nuts and screws</p>

A
B
C
D
E
F
G
H
I
J
SC
L
M

BATTERY

BATTERY

PFP:AYBGL

How to Handle Battery

NKS0056P




CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as “low maintenance” and “maintenance-free”.
- When the vehicle is not going to be used over a long period of time, disconnect the battery cable from the negative terminal.
- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.




BATTERY

CHECKING ELECTROLYTE LEVEL

WARNING:

Never allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, never touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




Sulphation

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.


To determine if a battery has been “sulphated”, note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.



Hydrometer Temperature Correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004

BATTERY

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
16 (60)	-0.008
10 (50)	-0.012
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Never “quick charge” a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Never turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 55 °C (131 °F), stop charging. Always charge battery at a temperature below 55 °C (131 °F).

Charging Rates

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

Never charge at more than 50 ampere rate.

NOTE:

The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.

BATTERY

Trouble Diagnoses with Battery Service Center

NKS0056Q


For battery testing, use Battery Service Center (J-48087). For details and operating instructions, refer to Technical Service Bulletin and/or Battery Service Center User Guide.

Removal and Installation

NKS002UP

REMOVAL

1. Remove hoodledge cover (right).




2. Disconnect both battery cables from terminals.

CAUTION:

When disconnecting, disconnect the battery cable from the negative terminal first.

3. Remove battery fix frame mounting nuts and battery fix frame.
4. Remove relay box from bracket.
5. Remove battery.



INSTALLATION

Installation is the reverse order of removal.

CAUTION:

When connecting, connect the battery cable to the positive terminal first.

Battery fix frame mounting nut

: 3.9 N·m (0.4 kg-m, 35 in-lb)

Battery terminal nut

: 5.4 N·m (0.55 kg-m, 48 in-lb)

A
B
C
D
E
F
G
H
I
J
L
M

SC

STARTING SYSTEM

PFP:23300

System Description

NKS002UQ

Power is supplied at all times

- through 40A fusible link (letter F, located in the fuse and fusible link block)
- to ignition switch terminal 1,
- through 15A fuse (No. 78, located in the IPDM E/R)
- to CPU of IPDM E/R,
- through 10A fuse (No. 71, located in the IPDM E/R)
- to CPU of IPDM E/R.

When the selector lever in the P or N position, power is supplied

- from TCM, and through A/T assembly terminal 9
- to IPDM E/R terminal 53.

Ground is supplied

- to IPDM E/R terminals 38, 50 and 60
- from grounds E21, E50 and E51.

With the ignition switch in the START position, and provided that the IPDM E/R receives a starter relay ON signal from the CAN lines, the IPDM E/R is energized and power is supplied

- from ignition switch terminal 5
- to IPDM E/R terminal 4 and
- through IPDM E/R terminal 3
- to starter motor terminal 1.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

STARTING SYSTEM

Wiring Diagram — START — VK45DE ENGINE MODELS



NKS002UR

A
B
C
D
E
F
G
H
I
J
SC
L
M

SC-START-01

▬ : DATA LINE

REFER TO PG-POWER.



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM1275E



STARTING SYSTEM

VQ35DE ENGINE MODELS

SC-START-02

▬ : DATA LINE

REFER TO PG-POWER.



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWM1276E

STARTING SYSTEM

Trouble Diagnosis with Starting/Charging System Tester (Starting)

NKS002US

For starting system testing, use Starting/Charging System Tester (J-44373). For details and operating instructions, refer to Technical Service Bulletin.



SKIB1369E

A
B
C
D
E
F
G
H
I
J
SC
L
M

STARTING SYSTEM

*1 For battery testing, use Battery Service Center (J-48087). For details and operating instructions, refer to Technical Service Bulletin and/or Battery Service Center User Guide.

*2 [SC-13. "MINIMUM SPECIFICATION OF CRANKING VOLTAGE REFERENCING COOLANT TEMPERATURE"](#)

*3 [SC-12. "Check "B" Terminal Circuit"](#)

*4 [SC-13. "Check "S" Connector Circuit"](#)

DIAGNOSTIC PROCEDURE 1

Check "B" Terminal Circuit

1. CHECK POWER SUPPLY FOR STARTER MOTOR "B" TERMINAL

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.
3. Turn ignition switch OFF.
4. Make sure that the starter motor "B" terminal E313 terminal 2 connection is clean and tight.
5. Check voltage between starter motor "B" terminal E313 terminal 2 and ground.


2 – Ground

: Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check harness between battery and starter motor for open circuit.



2. CHECK BATTERY CABLE CONNECTION (VOLTAGE DROP TEST)

Check voltage between starter motor "B" terminal E313 terminal 2 and battery positive terminal.


2 – Battery positive terminal

When ignition switch is in START position : Less than 0.5 V

OK or NG

OK >> GO TO 3.

NG >> Check harness between battery and starter motor for poor continuity.



3. CHECK STARTER MOTOR GROUND CIRCUIT (VOLTAGE DROP TEST)

1. Turn ignition switch OFF.
2. Check voltage between starter motor case and battery negative terminal.


Starter motor case – Battery negative terminal

When ignition switch is in START position : Less than 0.2 V

OK or NG

OK >> "B" terminal circuit is OK. Further inspection necessary. Refer to [SC-11. "Trouble Diagnosis with Starting/Charging System Tester \(Starting\)"](#).

NG >> Check starter motor case and ground for poor continuity.



STARTING SYSTEM

DIAGNOSTIC PROCEDURE 2

Check "S" Connector Circuit

1. CHECK POWER SUPPLY FOR STARTER MOTOR "S" TERMINAL

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.
3. Turn ignition switch OFF.
4. Disconnect starter motor connector.
5. Check voltage between starter motor harness connector E312 (VK45DE) or F33 (VQ35DE) terminal 1 and ground.

1 – Ground


When ignition switch is in START position : Battery voltage

OK or NG

OK >> "S" connector circuit is OK. Further inspection necessary. Refer to [SC-11, "Trouble Diagnosis with Starting/Charging System Tester \(Starting\)"](#).

NG >> Check the following.

- 40A fusible link (letter F , located in fuse and fusible link box)
- Ignition switch
- Starter relay (within the IPDM E/R)
- Harness for open or short




MINIMUM SPECIFICATION OF CRANKING VOLTAGE REFERENCING COOLANT TEMPERATURE

Engine coolant temperature	Voltage [V]
-30°C to -20°C (-22°F to -4°F)	8.4
-19°C to -10°C (-2°F to 14°F)	8.9
-9°C to 0°C (16°F to 32°F)	9.3
More than 1°C (More than 34°F)	9.7

STARTING SYSTEM

NKS002UT

Removal and Installation VK45DE ENGINE MODELS



1. Starter motor

2. Starter motor mounting bolt

3. B terminal harness

4. B terminal nut

5. S connector


6. Cylinder block

: N·m (kg·m, ft·lb)

: Engine front

Removal

1. Disconnect the battery cable from the negative terminal.
2. Remove engine front and rear undercover, using power tools.
3. Disconnect "S" connector.
4. Remove "B" terminal nut.
5. Remove starter motor mounting bolts.
6. Loosen A/T fluid cooler tube clip bolts. Refer to [AT-266](#). "[TRANSMISSION ASSEMBLY](#)".
7. Remove starter motor downward from the vehicle.



Installation


Installation is the reverse order of removal.

CAUTION:

Be sure to tighten "B" terminal nut carefully.

STARTING SYSTEM

VQ35DE ENGINE MODELS (2WD)



1. Starter motor mounting bolt

2. Harness clip bracket

3. S connector

4. B terminal nut

5. B terminal harness

6. Starter motor

7. Oil pan


: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Engine front

Removal

1. Disconnect the battery cable from the negative terminal.
2. Remove engine rear undercover, using power tools.
3. Disconnect "S" connector.
4. Remove "B" terminal nut.
5. Remove starter motor mounting bolts and harness clip bracket, using power tools.
6. Remove starter motor downward from the vehicle.



Installation

Installation is the reverse order of removal.


CAUTION:

Be sure to tighten "B" terminal nut carefully.

STARTING SYSTEM

VQ35DE ENGINE MODELS (AWD)

SEC. 233



1. Starter motor mounting bolt

2. Oil pan

3. Starter motor

4. B terminal harness

5. B terminal nut

6. S connector


: N·m (kg-m, ft-lb)

: Engine front

SKIB7207E

Removal

1. Disconnect the battery cable from the negative terminal.
2. Remove engine front and rear undercover, using power tools.
3. Disconnect "S" connector.
4. Remove "B" terminal nut.
5. Remove starter motor mounting bolts.
6. Remove starter motor downward from the vehicle.



Installation

Installation is the reverse order of removal.

CAUTION:


Be sure to tighten "B" terminal nut carefully.

STARTING SYSTEM

Disassembly and Assembly VK45DE ENGINE MODELS

NKS002UU

A
B
C
D
E
F
G
H
I
J
SC
L
M



- 1. Nut
- 4. Packing
- 7. Front bracket assembly
- 10. Washer
- 13. Rear bracket assembly
- 16. Ball
- 19. Pinion stopper
- 20. Stopper clip

- 2. Magnetic switch assembly
- 5. Plate
- 8. Yoke assembly
- 11. Rear bearing
- 14. Cover
- 17. Shaft gear assembly

- 3. Adjusting plate
- 6. Shift lever
- 9. Armature assembly
- 12. Brush holder assembly
- 15. Packing
- 18. Clutch gear assembly

: N-m (kg-m, in-lb)


: N-m (kg-m, ft-lb)

(H): High-temperature grease point

STARTING SYSTEM

VQ35DE ENGINE MODELS (2WD)

SEC. 233
S114-880



- | | | |
|-----------------------------|-------------------|------------------------|
| 1. Magnetic switch assembly | 2. Dust cover kit | 3. Shift lever set |
| 4. Center bracket (A) | 5. Yoke assembly | 6. Armature assembly |
| 7. Brush holder assembly | 8. Thrust washer | 9. Rear cover assembly |
| 10. Shaft gear assembly | 11. Packing | 12. Thrust washer |
| 13. Center bracket (P) | 14. E-ring | 15. Pinion assembly |
| 16. Ball bearing | 17. Caul | 18. Gear case assembly |

 : N·m (kg-m, in-lb)


 (H): High-temperature grease point

PKIB8804E

STARTING SYSTEM

VQ35DE ENGINE MODELS (AWD)

SEC. 233
S114-881



- | | | |
|-----------------------------|-------------------|------------------------|
| 1. Magnetic switch assembly | 2. Dust cover kit | 3. Shift lever set |
| 4. Center bracket (A) | 5. Yoke assembly | 6. Armature assembly |
| 7. Brush holder assembly | 8. Thrust washer | 9. Rear cover assembly |
| 10. Shaft gear assembly | 11. Packing | 12. Thrust washer |
| 13. Center bracket (P) | 14. E-ring | 15. Pinion assembly |
| 16. Ball bearing | 17. Caul | 18. Gear case assembly |

: N·m (kg-m, in-lb)

(H): High-temperature grease point

PKIB8805E

INSPECTION AFTER DISASSEMBLY

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

CHARGING SYSTEM

CHARGING SYSTEM

PFP:23100

System Description

NKS002UV

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times

- through 10A fuse (No. 33, located in the fuse and fusible link block)
- to alternator terminal 4 ("S" terminal).

"B" Terminal supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal 4 ("S" terminal) detecting the input voltage.

The charging circuit is protected by the 120A fusible link (VK45DE and VQ35DE AWD).

The alternator is grounded to the engine block.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 7 for the charge warning lamp.

Ground is supplied

- to combination meter terminal 2
- through alternator terminal 3 ("L" terminal)
- to alternator terminal 2 ("E" terminal) (VK45DE) or through case ground (VQ35DE)
- through ground E304 (VK45DE).

With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a malfunction is indicated.

MALFUNCTION INDICATOR

The IC regulator warning function activates to illuminate charge warning lamp, if any of the following symptoms occur while alternator is operating:


- Excessive voltage is produced.
- No voltage is produced.

CHARGING SYSTEM



NKS002UW

Wiring Diagram — CHARGE — VK45DE ENGINE MODELS

SC-CHARGE-01



A
B
C
D
E
F
G
H
I
J
SC
L
M



REFER TO THE FOLLOWING.

- (F102) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM4287E



CHARGING SYSTEM

VQ35DE ENGINE MODELS

SC-CHARGE-02

: 2WD MODELS



: AWD MODELS



W

5

6



REFER TO THE FOLLOWING.

-SUPER MULTIPLE JUNCTION (SMJ)

-FUSE BLOCK-JUNCTION BOX (J/B)


TKWM4288E

CHARGING SYSTEM

Trouble Diagnosis with Starting/Charging System Tester (Charging)

NKS002UX

For charging system testing, use Starting/Charging System Tester (J-44373). For details and operating instructions, refer to Technical Service Bulletin.



SKIB0527E

A
B
C
D
E
F
G
H
I
J
SC
L
M

CHARGING SYSTEM

- *1 [SC-25, "Check "L" Terminal Circuit \(Open\)"](#) *2 [SC-25, "Check "L" Terminal Circuit \(Short\)"](#) *3 [SC-25, "Check "S" Terminal Circuit"](#)
- *4 [SC-26, "Check "B" Terminal Circuit"](#) *5 [SC-28, "Alternator Pulley Inspection" \(VK45DE\)](#)
[SC-29, "Alternator Pulley Inspection" \(VQ35DE\)](#)

PRELIMINARY INSPECTION

1. CHECK BATTERY TERMINALS CONNECTION

Check if battery terminals are clean and tight.

OK or NG

- OK >> GO TO 2.
NG >> Repair battery terminals connection.

2. CHECK FUSE AND FUSIBLE LINK

Check for blown alternator and combination meter fuses.

Unit	Power source (Power supply terminals)	Fuse No.
Alternator	Battery ("S" terminal)	33
Combination meter	Ignition switch ON ("L" terminal)	14

OK or NG

- OK >> GO TO 3.
NG >> If fuse is blown, be sure eliminate cause of malfunction before installing new fuse.

3. CHECK "E" TERMINAL CONNECTION

Check if "E" terminal is clean and tight.

OK or NG

- OK >> GO TO 4.
NG >> Repair "E" terminal connection.

4. CHECK ALTERNATOR DRIVE BELT TENSION

Check alternator drive belt tension. Refer to [EM-174, "Checking Drive Belts"](#) (VK45DE) or [EM-15, "Checking Drive Belts"](#) (VQ35DE).

OK or NG

- OK >> INSPECTION END
NG >> Repair as needed.

CHARGING SYSTEM

DIAGNOSTIC PROCEDURE 1

Check "L" Terminal Circuit (Open)

1. CHECK "L" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "L" terminal is clean and tight.

OK or NG

- OK >> GO TO 2.
NG >> Repair "L" terminal connection. Confirm repair by performing complete Starting/Charging system test. Refer to Technical Service Bulletin.

2. CHECK "L" TERMINAL CIRCUIT (OPEN)


1. Disconnect alternator connector.
2. Apply ground to alternator harness connector E311 (VK45DE) or F26 (VQ35DE) terminal 3 with the ignition switch in the ON position.

3 – Ground : Charge warning lamp should light up.

OK or NG

- OK >> Go to [SC-23, "Trouble Diagnosis with Starting/Charging System Tester \(Charging\)"](#) .
NG >> Check the following.

- Charge warning lamp (combination meter)
- Harness for open between combination meter and fuse
- Harness for open between combination meter and alternator



DIAGNOSTIC PROCEDURE 2

Check "L" Terminal Circuit (Short)

1. CHECK "L" TERMINAL CIRCUIT (SHORT)

1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Turn ignition switch ON.

Charge warning lamp should light up?

- YES >> Check the following.
- Harness for short between combination meter and alternator
 - Charge warning lamp (Combination meter)

NO >> Go to [SC-23, "Trouble Diagnosis with Starting/Charging System Tester \(Charging\)"](#) .

DIAGNOSTIC PROCEDURE 3

Check "S" Terminal Circuit

1. CHECK "S" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "S" terminal is clean and tight.

OK or NG

- OK >> GO TO 2.
NG >> Repair "S" terminal connection. Confirm repair by performing complete Starting/Charging system test. Refer to Technical Service Bulletin.

CHARGING SYSTEM


2. CHECK ALTERNATOR "S" TERMINAL CIRCUIT

1. Disconnect alternator connector.
2. Check voltage between alternator harness connector E311 (VK45DE) or F26 (VQ35DE) terminal 4 and ground.

4 – Ground : **Battery voltage**

OK or NG

- OK >> Go to [SC-23. "Trouble Diagnosis with Starting/Charging System Tester \(Charging\)"](#) .
- NG >> Harness for open between alternator and fuse.



DIAGNOSTIC PROCEDURE 4

Check "B" Terminal Circuit

1. CHECK "B" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "B" terminal is clean and tight.

OK or NG

- OK >> GO TO 2.
- NG >> Repair "B" terminal connection. Confirm repair by performing complete Starting/Charging system test. Refer to Technical Service Bulletin.


2. CHECK ALTERNATOR "B" TERMINAL CIRCUIT

Check voltage between alternator "B" terminal E307 terminal 1 and ground.

1 – Ground : **Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> Check the following.
- Harness for open between alternator and fusible link (VK45DE and VQ35DE AWD)
 - Harness for open between alternator and battery (VQ35DE 2WD)




3. CHECK "B" TERMINAL CONNECTION (VOLTAGE DROP TEST)

1. Start engine.
2. When engine running at idle and warm, check voltage between alternator "B" terminal E307 terminal 1 and battery positive terminal.

1 – Battery positive terminal : **Less than 0.2 V**

OK or NG

- OK >> Go to [SC-23. "Trouble Diagnosis with Starting/Charging System Tester \(Charging\)"](#) .
- NG >> Check harness between battery and alternator for poor continuity.



CHARGING SYSTEM

Removal and Installation VK45DE ENGINE MODELS


NKS002UY

A
B
C
D
E
F
G

H
I
J

SC


L
M




- | | | |
|--|-----------------------------------|-------------------------------|
| 1. Alternator ground harness mounting bolt | 2. B terminal nut | 3. B terminal harness |
| 4. Alternator Nut | 5. Alternator bracket | 6. Alternator connector |
| 7. Alternator | 8. Alternator mounting bolt | 9. Alternator stay |
| 10. Alternator mounting bolt | 11. Alternator stay mounting bolt | 12. Alternator ground harness |
- : N-m (kg-m, in-lb)
 : N-m (kg-m, ft-lb)
 : Engine front

Removal

1. Disconnect the battery cable from the negative terminal.
2. Remove engine front undercover, using power tools.
3. Remove radiator shroud (lower). Refer to [CO-41, "RADIATOR"](#).
4. Remove alternator, water pump and A/C compressor belt. Refer to [EM-174, "Removal and Installation"](#).
5. Remove alternator mounting bolts, using power tools.



6. Disconnect alternator connector.
7. Remove "B" terminal nut.
8. Remove alternator ground harness mounting bolt.
9. Remove alternator assembly downward from the vehicle.



CHARGING SYSTEM

Alternator Pulley Inspection

Perform the following.

- Make sure that alternator pulley does not rattle.
- Make sure that alternator pulley nut is tight.

Alternator pulley nut:

: 73.5 N·m (7.5 kg-m, 54 ft-lb)

Installation


Installation is the reverse order of removal.

- Install alternator, and check tension of belt. Refer to [EM-174, "Checking Drive Belts"](#).

CAUTION:

Be sure to tighten "B" terminal nut carefully.

VQ35DE ENGINE MODELS




- | | | |
|-----------------------------|----------------------------------|-------------------------|
| 1. B terminal nut | 2. B terminal harness | 3. Alternator connector |
| 4. Alternator mounting bolt | 5. Alternator stay mounting bolt | 6. Alternator stay |
| 7. Alternator | | |

 : N·m (kg-m, ft-lb)

 : Engine front


Removal

1. Disconnect the battery cable from the negative terminal.
2. Remove engine front undercover, using power tools.
3. Remove alternator and power steering oil pump belt. Refer to [EM-16, "Removal and Installation"](#).
4. Disconnect alternator connector.
5. Remove "B" terminal nut.
6. Remove harness clip and water hose bracket from alternator.



CHARGING SYSTEM

7. Remove oil pressure switch harness clip from alternator stay. (2WD)
8. Disconnect oil pressure switch connector. (2WD)
9. Remove alternator stay mounting bolts and alternator stay, using power tools.
10. Remove alternator mounting bolt, using power tools.
11. Remove alternator assembly downward from the vehicle.



A
B
C
D
E
F
G
H
I
J
SC
L
M

Alternator Pulley Inspection

Perform the following.

- Make sure that alternator pulley does not rattle.
- Make sure that alternator pulley nut is tight.

Alternator pulley nut:

: 118 N·m (12.0 kg-m, 87 ft-lb)

Installation

Installation is the reverse order of removal.

- Install alternator, and check tension of belt. Refer to [EM-15, "Checking Drive Belts"](#).


CAUTION:

Be sure to tighten "B" terminal nut carefully.

CHARGING SYSTEM

NKS002UZ

Disassembly and Assembly VK45DE ENGINE MODELS



SKIB7210E


- | | | |
|---------------------------|-----------------------------------|---------------------------|
| 1. Stator assembly | 2. Slip ring | 3. Rotor assembly |
| 4. Retainer | 5. Front bearing | 6. Front bracket assembly |
| 7. Pulley | 8. Pulley nut | 9. Fun guide |
| 10. Double labyrinth seal | 11. IC voltage regulator assembly | 12. Diode assembly |
| 13. Rear bracket assembly | 14. B terminal nut | 15. Through-bolt and nut |

: N-m (kg-m, in-lb)

: N-m (kg-m, ft-lb)

CHARGING SYSTEM

VQ35DE ENGINE MODELS



- | | | |
|-----------------------------------|--------------------|---------------------------|
| 1. Rear bearing | 2. Rotor assembly | 3. Retainer |
| 4. Front bearing | 5. Through-bolt | 6. Front bracket assembly |
| 7. Pulley | 8. Pulley nut | 9. Stator assembly |
| 10. IC voltage regulator assembly | 11. Diode assembly | 12. Rear bracket assembly |
| 13. B terminal nut | | |

: N·m (kg·m, in·lb)

: N·m (kg·m, ft·lb)

: Always replace after every disassembly

A
B
C
D
E
F
G
H
I
J
SC
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Battery

NKS002V0

Type		110D26L
Capacity	V - AH	12 - 64
Cold cranking current (For reference value)	A	720

Starter

NKS002V1

Applied model		VK45DE	VQ35DE (2WD)	VQ35DE (AWD)
		M2T85075	S114-880	S114-881
Type		MITSUBISHI make	HITACHI make	
		Reduction gear type		
System voltage	V	12		
	Terminal voltage	V 11		
No-load	Current	A	Less than 145	Less than 90
	Revolution	rpm	More than 3,300	More than 2,880
Minimum diameter of commutator	mm (in)	31.4 (1.236)	28.0 (1.102)	
Minimum length of brush	mm (in)	11.0 (0.433)	10.5 (0.413)	
Brush spring tension	N (kg, lb)	26.7 - 36.1 (2.72 - 3.68, 6.80 - 8.12)	16.2 (1.65, 3.6)	
Clearance between bearing metal and armature shaft	mm (in)	Less than 0.2 (0.008)		
Clearance between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	0.3 - 2.5 (0.012 - 0.098)	

Alternator

NKS002V2

Applied model		VK45DE	VQ35DE
Type		LR1110 - 716V	A3TG0191
		HITACHI make	MITSUBISHI make
Nominal rating	V - A	12 - 110	
Ground polarity		Negative	
Minimum revolution under no-load (When 13.5 V is applied)	rpm	Less than 1,100	Less than 1,000
Hot output current (When 13.5 V is applied)	A/rpm	More than 70/1,800 More than 91/2,500 More than 110/5,000	More than 37/1,300 More than 92/2,500 More than 103/5,000
Regulated output voltage	V	14.1 - 14.7	
Minimum length of brush	mm (in)	More than 6.00 (0.236)	More than 5.00 (0.197)
Brush spring pressure	N (g, oz)	1.00 - 3.43 (102 - 350, 3.60 - 12.34)	4.8 - 6.0 (490 - 612, 17.28 - 21.60)
Slip ring minimum outer diameter	mm (in)	More than 26.0 (1.024)	More than 22.1 (0.870)
Rotor (Field coil) resistance	Ω	2.31	1.7 - 2.1