

PG SECTION

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS



POWER SUPPLY ROUTING CIRCUIT	3	GROUND	29
Schematic	3	Ground Distribution	29
Wiring Diagram — POWER —	4	MAIN HARNESS	29
BATTERY POWER SUPPLY — IGNITION SW.		ENGINE ROOM HARNESS	32
IN ANY POSITION	4	ENGINE HARNESS/VK ENGINE MODELS	35
ACCESSORY POWER SUPPLY — IGNITION		ENGINE HARNESS/VQ ENGINE MODELS	36
SW. IN "ACC" OR "ON"	10	ENGINE CONTROL HARNESS/VK ENGINE	
IGNITION POWER SUPPLY — IGNITION SW.		MODELS	37
IN "ON" AND/OR "START"	12	ENGINE CONTROL HARNESS/VQ ENGINE	
Fuse	16	MODELS	38
Fusible Link	16	BODY HARNESS	39
Circuit Breaker	16	BODY NO. 2 HARNESS	41
IPDM E/R (INTELLIGENT POWER DISTRIBUTION		ROOM LAMP HARNESS	42
MODULE ENGINE ROOM)	17	HARNESS	43
System Description	17	Harness Layout	43
SYSTEMS CONTROLLED BY IPDM E/R	17	HOW TO READ HARNESS LAYOUT	43
CAN COMMUNICATION LINE CONTROL	17	OUTLINE	44
IPDM E/R STATUS CONTROL	18	MAIN HARNESS	45
CAN Communication System Description	18	ENGINE ROOM HARNESS	48
CAN Communication Unit	18	ENGINE HARNESS/VK ENGINE MODELS	51
Function of Detecting Ignition Relay Malfunction	18	ENGINE HARNESS/VQ ENGINE MODELS	52
CONSULT-II Function (IPDM E/R)	19	ENGINE CONTROL HARNESS/VK ENGINE	
CONSULT-II INSPECTION PROCEDURE	19	MODELS	53
SELF-DIAG RESULTS	19	ENGINE CONTROL HARNESS/VQ ENGINE	
DATA MONITOR	19	MODELS	55
ACTIVE TEST	20	BODY HARNESS	57
Auto Active Test	21	BODY NO. 2 HARNESS	59
DESCRIPTION	21	ROOM LAMP HARNESS	60
OPERATION PROCEDURE	21	FRONT DOOR HARNESS	61
INSPECTION IN AUTO ACTIVE TEST MODE... <td>22</td> <td>REAR DOOR HARNESS</td> <td>62</td>	22	REAR DOOR HARNESS	62
Schematic	24	BACK DOOR HARNESS	63
IPDM E/R Terminal Arrangement	25	Wiring Diagram Codes (Cell Codes)	64
IPDM E/R Power/Ground Circuit Inspection	26	ELECTRICAL UNITS LOCATION	67
Inspection With CONSULT-II (Self-Diagnosis)	27	Electrical Units Location	67
Removal and Installation of IPDM E/R	28	ENGINE COMPARTMENT	67
REMOVAL	28	PASSENGER COMPARTMENT	68
INSTALLATION	28	LUGGAGE COMPARTMENT	70
		HARNESS CONNECTOR	71
		Description	71
		HARNESS CONNECTOR (TAB-LOCKING)	

TYPE)	71	STANDARDIZED RELAY	78
HARNESS CONNECTOR (SLIDE-LOCKING TYPE)	72	Description	78
HARNESS CONNECTOR (LEVER LOCKING TYPE)	73	NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS	78
ELECTRICAL UNITS	74	TYPE OF STANDARDIZED RELAYS	78
Terminal Arrangement	74	FUSE BLOCK - JUNCTION BOX (J/B)	80
SMJ (SUPER MULTIPLE JUNCTION)	76	Terminal Arrangement	80
Terminal Arrangement	76	FUSE, FUSIBLE LINK AND RELAY BOX	81
		Terminal Arrangement	81

POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram — POWER — BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION


NKS003G7



TKWM4458E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02



A
B
C
D
E
F
G
H
I
J

PG

L

M

REFER TO THE FOLLOWING.



(M1, M2, E201, E203)
-FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM4459E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-03




REFER TO THE FOLLOWING.
E211 -SUPER MULTIPLE
 JUNCTION (SMJ)

TKWM4460E


POWER SUPPLY ROUTING CIRCUIT

PG-POWER-04



A
B
C
D
E
F
G
H
I
J


PG



TKWM4461E

POWER SUPPLY ROUTING CIRCUIT


PG-POWER-05




TKWM0712E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-06


 : DATA LINE



TKWM4462E


POWER SUPPLY ROUTING CIRCUIT

ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”



POWER SUPPLY ROUTING CIRCUIT


PG-POWER-08



TKWM4904E


POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”



POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10



REFER TO THE FOLLOWING.


(M2, E201, E202)-FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM4466E




POWER SUPPLY ROUTING CIRCUIT

PG-POWER-11



TKWM4467E

POWER SUPPLY ROUTING CIRCUIT




TKWM4468E

POWER SUPPLY ROUTING CIRCUIT

Fuse

NKS003G8

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

NKS003G9

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

NKS003GA

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

NKS003GB

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control, oil pressure switch signal, and hood switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:**None of the IPDM E/R-integrated relays can be removed.****SYSTEMS CONTROLLED BY IPDM E/R**

IPDM E/R receives a request signal from each control unit with CAN communication. It controls each system.

Control system	Transmit control unit	Control part
Lamp control	BCM	<ul style="list-style-type: none"> Headlamps (HI, LO) Front fog lamps Parking, license plate, side marker and tail lamps
Wiper control	BCM	Front wipers
Rear window defogger control	BCM	Rear window defogger
A/C compressor control	ECM	A/C compressor (magnet clutch)
Cooling fan control	ECM	Cooling fan
Horn control	BCM	Horn

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L line, CAN H line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

Fail-Safe Control

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none"> With the ignition switch ON, the headlamp (low) is ON. With the ignition switch OFF, the headlamp (low) is OFF.
Parking, license plate side marker and tail lamps	<ul style="list-style-type: none"> With the ignition switch ON, the parking, license plate, side marker and tail lamps is ON. With the ignition switch OFF, the parking, license plate, side marker and tail lamps is OFF.
Cooling fan	<ul style="list-style-type: none"> With the ignition switch ON, the cooling fan HI operates. With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned OFF, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C compressor OFF
Front fog lamps	Front fog lamp relay OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.
 - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 3 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
 - IPDM E/R operates in low power mode.
 - CAN communication is stopped.
 - When a change in CAN communication line is detected, mode switches to CAN communication status.
 - When a change hood switch or ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

NKS003GC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

NKS003GD

Refer to [LAN-49, "CAN System Specification Chart"](#).

Function of Detecting Ignition Relay Malfunction

NKS003GE

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON parking, license plate, side marker and tail lamps for 10 minutes to indicate ignition relay malfunction.
- When a state of ignition relay having built-in does not agree with a state of ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

CONSULT-II Function (IPDM E/R)

NKS003GF

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II INSPECTION PROCEDURERefer to [GI-38, "CONSULT-II Start Procedure"](#).**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

SELF-DIAG RESULTS**Operation Procedure**

1. Touch “SELF-DIAG RESULTS” on “SELECT DIAG MODE” screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	CONSULT-II display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	—	—	—	—	—
CAN COMM CIRCUIT	U1000	<ul style="list-style-type: none"> • If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. • When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> • TRANSMIT DIAG • ECM • BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

DATA MONITOR**Operation Procedure**

1. Touch “DATA MONITOR” on “SELECT MONITOR ITEM ” screen.
2. Touch “ALL SIGNALS”, “MAIN SIGNALS” or “SELECTION FROM MENU” on the “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

3. Touch the required monitoring item on “SELECTION FROM MENU”. In “ALL SIGNALS”, all items are monitored. In “MAIN SIGNALS”, predetermined items are monitored.
4. Touch “START”.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	SELECT MONITOR ITEM			Description
			ALL SIG-NALS	MAIN SIG-NALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Tail & clear request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR fog request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
FR wiper request	FR WIP REQ	STOP/LO/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/BLOCK	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ ^{*1}	ON/OFF	×		×	Status of input signal
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
Hood switch	HOOD SW	ON/OFF	×		×	Input signal status
Theft warning horn request	THFT HRN REQ	ON/OFF	×		×	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	×		×	Output status of IPDM E/R
Cornering lamp request	CRNRNG LMP REQ ^{*2}	OFF/LEFT/RIGHT	×		×	Signal status input from BCM

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- *1: The vehicle without the Intelligent Key system displays only ON without change.
- *2: The cornering lamp item is displayed, but it cannot be monitored.

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested.
3. Touch "START", and confirm its operation.
4. Touch "OFF" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp operation	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger operation	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) operation	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan operation	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan can be operated.
Lamp (HI, LO, FOG) operation	LAMPS	With a certain operation (OFF, HI ON, LO ON, FOG ON), the lamp relay (Lo, Hi, Fog) can be operated.
Cornering lamp operation	CORNERING LAMP ^{NOTE}	—
Horn operation	HORN	With a certain ON-OFF operation, the horn relay can be operated.

NOTE:

This item is displayed, but cannot be tested.

Auto Active Test

DESCRIPTION

NKS003GG

In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:

- Rear window defogger
- Front wipers
- Parking, license plate, side marker and tail lamps
- Front fog lamps
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood and front door (passenger side), and then lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press drivers door switch 10 times (close other doors). Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once oil pressure warning lamp starts blinking.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect [BL-40, "Check Door Switch"](#) when the auto active test cannot be performed.

A

B

C

D

E

F

G

H

I

J

PG


L

M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

INSPECTION IN AUTO ACTIVE TEST MODE

When auto active test mode is actuated, the following eight steps are repeated three times.



PKIB6583E

NOTE:

Turns ON-OFF the solenoid to switch Hi/Lo. In this case, the bulb does not illuminate.

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	<ul style="list-style-type: none"> BCM signal input system malfunction
		NO	<ul style="list-style-type: none"> Lamp/wiper motor malfunction Lamp/wiper motor ground circuit malfunction Harness/connector malfunction between IPDM E/R and system in question IPDM E/R (integrated relay) malfunction
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction
		NO	<ul style="list-style-type: none"> Rear window defogger relay malfunction Harness/connector malfunction between IPDM E/R and rear window defogger relay. Open circuit of rear window defogger IPDM E/R malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction CAN communication signal between BCM and ECM. CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness/connector malfunction between IPDM E/R and magnetic clutch IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> ECM signal input circuit CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Cooling fan motor malfunction Harness/connector malfunction between IPDM E/R and cooling fan motor IPDM E/R (integrated relay) malfunction

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Symptom	Inspection contents		Possible cause
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none">● Harness/connector malfunction between IPDM E/R and oil pressure switch● Oil pressure switch malfunction● IPDM E/R malfunction
		NO	<ul style="list-style-type: none">● CAN communication signal between BCM and unified meter and A/C amp.● Combination meter

A

B

C

D

E

F

G

H

I

J

PG


L

M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic

NKS003GH




TKWM4469E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Terminal Arrangement

NKS003GI

A
B
C
D
E
F
G
H
I
J
PG
L
M



CKIM0237E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Power/Ground Circuit Inspection

NKS003GJ

1. CHECK FUSES AND FUSIBLE LINKS

Make sure the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Power source	Fuse and fusible link No.
1, 2	Battery power	C
		E
		71
		78

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link blown, be sure to eliminate cause of malfunction before installing new one.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E3.
3. Check voltage between IPDM E/R harness connector E3 terminals 1, 2 and ground.


1, 2 – Ground

: Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors E8 and E9.
2. Check continuity between IPDM E/R harness connectors E8 terminal 38, E9 terminal 50, 60 and ground.


38, 50, 60 – Ground

: Continuity should exist.

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



Inspection With CONSULT-II (Self-Diagnosis)

NKS003GK

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. CHECK SELF DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the "SELECT SYSTEM" screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	No malfunction
CAN COMM CIRCUIT	U1000	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> TRANSMIT DIAG ECM BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>> INSPECTION END
CAN COMM CIRCUIT>> Refer to [LAN-49, "CAN System Specification Chart"](#) .

A

B

C

D

E

F

G

H

I

J

PG

L

M



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Removal and Installation of IPDM E/R


REMOVAL

NKS003GL

1. Remove battery. Refer to [SC-10, "Removal and Installation"](#).
2. Remove IPDM E/R cover A. While pressing pawl on backside of IPDM E/R cover B toward vehicle front to unlock, lift up IPDM E/R.



3. While pressing pawls on right and left side of IPDM E/R, remove IPDM E/R cover B from IPDM E/R.
4. Remove harness connector from IPDM E/R.



INSTALLATION

Installation is the reverse order of removal.


GROUND

GROUND

Ground Distribution MAIN HARNESS

PFP:00011

NKS003GM



A

B

Next page

A

B

C

D

E

G

H


J

PG

L


M

GROUND



CKIM0640E

GROUND




CKIM0641E

GROUND

ENGINE ROOM HARNESS

CONNECTOR NUMBER	CONNECT TO
E6	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 15) (With VQ engine) ·Cooling fan relay-1 ·Cooling fan relay-3
E8	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 38) ·CPU ·Ignition relay ·Front wiper relay
E9	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 50) ·CPU
E9	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 60) ·CPU
E12	Accessory relay-2
E14	ICC brake hold relay
E22	Front side marker lamp RH
E23	Parking lamp RH ·Parking ·Daytime
E24	Front combination lamp RH (Terminal No. 7) ·Headlamp ·High beam solenoid
E24	Front combination lamp RH (Terminal No. 8) ·Turn signal
E39	ICC sensor
E41	Cooling fan motor (Terminal No. 3) (With VK engine)
E123	Cooling fan motor-2 (Terminal No. 4) (With VQ engine)
E41	Cooling fan motor (Terminal No. 4) (With VK engine)
E123	Cooling fan motor-2 (Terminal No. 3) (With VQ engine)
E45	Front fog lamp LH



Next page




GROUND

A
B
C
D
E
F
G
H
I
J


PG

L
M

 Preceding page



GROUND



CKIM0642E

GROUND




ENGINE HARNESS/VK ENGINE MODELS

A
B
C
D
E
F
G
H
I
J

PG

L
M


CONNECTOR NUMBER	CONNECT TO
(E309)	Alternator



CKIM0203E

GROUND


ENGINE HARNESS/VQ ENGINE MODELS



CKIM0204E

GROUND


ENGINE CONTROL HARNESS/VK ENGINE MODELS



CKIM0408E


GROUND

ENGINE CONTROL HARNESS/VQ ENGINE MODELS



GROUND

BODY HARNESS



A
B
C
D
E
F
G
H
I
J

PG

L



M

CKIM0643E

GROUND




Preceding page



GROUND


BODY NO. 2 HARNESS



A
B
C
D
E
F
G
H
I
J
PG
L
M

GROUND

ROOM LAMP HARNESS



CKIM0211E

HARNESS

PFP:00011


Harness Layout

NKS003GN

HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the figures:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness



To Use the Grid Reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the figure, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL


Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

CKIT0108E

HARNESS


OUTLINE



TKIM0061E

Harness

MAIN HARNESS



★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

For detail ground distribution information,
refer to "GROUND DISTRIBUTION".

TKIM0624E


HARNESS

A4	<u>M1</u>	W/16	Fuse block (J/B)		D3	<u>M46</u>	W/2	In-vehicle sensor
A4	<u>M2</u>	W/8	Fuse block (J/B)		E3	<u>M48</u>	W/16	Rear view camera control unit
A5	<u>M3</u>	W/40	BCM (Body control module)		E3	<u>M49</u>	W/32	Automatic drive positioner control unit
A5	<u>M4</u>	B/15	BCM (Body control module)		E3	<u>M50</u>	W/16	Automatic drive positioner control unit
B5	<u>M5</u>	W/16	Data link connector		F4	<u>M51</u>	W/4	Hazard switch
A4	<u>M6</u>	W/2	Low tire pressure warning check switch		E4	<u>M52</u>	W/4	Clock
D2	<u>M7</u>	W/2	Diode		E4	<u>M53</u>	W/3	Front power socket-1
D2	<u>M8</u>	W/2	Diode		E4	<u>M54</u>	BR/2	A/T device (Illumination)
C1	<u>M9</u>	W/2	Diode		G3	* <u>M55</u>	GY/20	Unified meter and A/C amp.
D1	<u>M10</u>	W/2	Diode		E2	* <u>M56</u>	GY/16	Unified meter and A/C amp.
A4	* <u>M11</u>	SMJ	To <u>(B1)</u>		E2	<u>M57</u>	W/24	Unified meter and A/C amp.
D1	<u>M12</u>	W/2	Diode		E3	<u>M58</u>	W/10	Audio unit
C4	<u>M13</u>	GY/6	ADP steering switch		F3	<u>M59</u>	W/6	Audio unit
C4	<u>M14</u>	W/8	Steering angle sensor		E3	<u>M60</u>	W/16	Audio unit
D4	* <u>M15</u>	GY/8	Combination switch (Spiral cable)		E3	<u>M61</u>	BR/2	Antenna amp.
D4	<u>M16</u>	Y/6	Combination switch (Spiral cable)		E1	<u>M63</u>	W/24	Display
D4	<u>M17</u>	W/16	Combination switch		E1	<u>M64</u>	W/16	A/C and AV switch
C3	<u>M18</u>	BR/16	Door mirror remote control switch		E1	<u>M65</u>	BR/8	Audio unit
A3	<u>M19</u>	W/24	Combination meter		D1	<u>M66</u>	BR/2	Instrument speaker center
C1	* <u>M20</u>	SMJ	To <u>(D1)</u>		E4	* <u>M67</u>	W/10	A/T device
A4	<u>M21</u>	GY/6	Key switch and ignition knob switch (With Intelligent Key)		F4	<u>M68</u>	W/6	Heated seat switch (Driver side)
D2	<u>M22</u>	BR/2	Key switch (Without Intelligent Key)		G4	<u>M69</u>	BR/6	Heated seat switch (Passenger side)
C1	<u>M23</u>				G4	<u>M70</u>	W/2	Inside key antenna-1 (Dashboard)
C1	<u>M24</u>	W/2	Ignition keyhole illumination		G4	<u>M71</u>	B/6	Yaw rate / Side / Decel G sensor (AWD models)
D4	<u>M25</u>	W/4	NATS antenna amp.		G5	<u>M72</u>	Y/28	Air bag diagnosis sensor unit
D4	<u>M26</u>	W/4	Steering lock unit		G4	<u>M73</u>	-/16	DVD player
C4	<u>M27</u>	W/4	Tilt motor and telescopic motor		E1	<u>M75</u>	W/24	Display control unit
C4	<u>M28</u>	W/4	Tilt sensor and telescopic sensor		F2	<u>M76</u>	W/32	Display control unit
C4	<u>M29</u>	W/2	Circuit breaker		E1	<u>M77</u>	W/6	Heater and cooling unit (Via sub-harness)
B2	<u>M30</u>	B/5	Passenger side select unlock relay		F3	<u>M78</u>	W/6	Blower motor
A1	<u>M31</u>	W/18	To <u>(R1)</u>		G5	<u>M79</u>	B/6	Yaw rate / Side G sensor (2WD models)
B5	<u>M32</u>	GY/6	VDC off switch		G2	* <u>MB1</u>	SMJ	To <u>(E201)</u>
A3	* <u>M34</u>	W/40	Intelligent Key unit		G2	* <u>MB2</u>	SMJ	To <u>(F102)</u>
A2	* <u>M35</u>	-	Body ground					
A2	<u>M36</u>	BR/2	Instrument speaker LH					
A1	<u>M37</u>	W/3	Optical sensor					
A2	<u>M38</u>	BR/2	Security indicator lamp					
D4	* <u>M41</u>	SMJ	To <u>(E211)</u>					
C1	* <u>M45</u>	-	Body ground					

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0625E

HARNESS



G1	(M83)	W/4 : To (M151)
G1	(M84)	Y/4 : Front passenger air bag module
G1 *	(M85)	- : Body ground
F1	(M86)	BR/2 : Instrument speaker RH
F1	(M87)	B/2 : Sunload sensor
G2	(M88)	W/24 : ICC unit
G2	(M89)	GY/24 : ICC unit
G3 *	(M90)	SMJ : ECM
G2	(M91)	SMJ : To (D31)
G3	(M92)	W/16 : AWD control unit
F3	(M94)	W/12 : Option connector-1 for audio unit (Without satellite radio)
B4	(M95)	W/8 : Snow mode switch
C5	(M96)	GY/8 : LDW switch
D1	(M97)	BR/4 : LDW chime
E1	(M98)	W/4 : Remote keyless entry receiver
B1	(M100)	W/8 : To (R10)
D1	(M101)	-/2 : Resistor
F1	(M102)	W/32 : TEL adapter unit
F3	(M103)	W/12 : Audio unit (With satellite radio)

Glove box lamp sub-harness

G1	(M151)	W/4 : To (M83)
G1	(M152)	W/2 : Glove box lamp
G1	(M153)	W/2 : Inside key antenna-2 (Dashboard)


* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0626E

Harness

ENGINE ROOM HARNESS

Engine Compartment



★ Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


HARNESS

Engine room harness			
C2	E1	B/2	Fusible link holder
C2	E2	GY/2	Fusible link holder
C1	E3	B/2	IPDM E/R (Intelligent power distribution module engine room)
C1 ★ E4	W/4	B/4	IPDM E/R (Intelligent power distribution module engine room)
B1 ★ E5	W/4	B/4	IPDM E/R (Intelligent power distribution module engine room)
D2 ★ E6	W/6	B/6	IPDM E/R (Intelligent power distribution module engine room)
C1 ★ E7	GY/16	B/16	IPDM E/R (Intelligent power distribution module engine room)
C1 ★ E8	W/12	B/12	IPDM E/R (Intelligent power distribution module engine room)
D2 ★ E9	W/16	B/16	IPDM E/R (Intelligent power distribution module engine room)
F1 ★ E10	—	—	Fuse and fusible link block
C2	E11	—	Fuse, fusible link and relay box
F1	E12	L/4	Accessory relay-2
B1	E13	BR/6	Rear window defogger relay
B1 ★ E14	GY/6	ICC	Brake hold relay
A1	E14	L/4	Daytime light relay
B1	E15	—	Relay box
D1 ★ E16	GY/6	To F47	(With VK engine)
D1 ★ E17	GY/9	To F48	(With VQ engine)
D1 ★ E18	B/8	To F49	(With VK engine)
B1	E20	GY/2	Hood switch
B2 ★ E21	—	—	Body ground
A2	E22	B/2	Front side marker lamp RH
A2	E23	GY/3	Parking lamp RH
A1	E24	B/8	Front combination lamp RH
A3	E25	B/2	To E10
A3	E26	BR/2	Washer level sensor
C2 ★ E29	B/8	To E12D	(With VQ engine)
C2	E30	GY/1	To E303
C2	E31	—	Body ground
A2	E32	B/3	Refrigerant pressure sensor
A2	E33	GY/2	Front wheel sensor RH
B3	E34	B/2	Ambient sensor
C3	E35	B/1	Horn low
C3	E36	B/1	Horn low
C4	E37	B/1	Horn high
C4	E38	B/1	Horn high
B4	E39	GY/6	ICC sensor
B4	E40	Y/2	Crash zone sensor
C4 ★ E41		GY/4	Cooling fan motor (With VK engine)
E3		B/2	Front side marker lamp LH
D3		GY/3	Parking lamp LH
E3		B/8	Front combination lamp LH
D5		E45	Front fog lamp LH
E4		E46	Front wheel sensor LH
D3		E49	—
E3 ★ E50		GY/2	Body ground
D3 ★ E51		GY/2	Body ground
E1		E52	Brake fluid level switch
E3		B/3	Pressure sensor
E2		E54	Brake booster
D2		E55	To E141
F2		E56	ABS actuator and electric unit (Control unit)
F2		E57	Front wiper motor
G2		E61	Back-up lamp relay
F2		E62	Relay box-2
A3		E63	Front and rear washer pump
D1 ★ E64		GY/6	To F65 (With VQ engine)
C3 ★ E101		B/2	To E25
A4		E102	-/2 : Front fog lamp RH
Cooling fan sub-harness (With VQ engine)			
C3 ★ E101		DGY/8	To E29
B3 ★ E102		GY/4	Cooling fan motor-1
C3 ★ E103		GY/4	Cooling fan motor-2
Front fog lamp RH sub-harness			
A4		E101	B/2 : To E25
A4		E102	-/2 : Front fog lamp RH
ICC sub-harness			
D2		E141	BR/3 : To E55
E3		E142	B/3 : Brake pressure sensor
★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.			

TKIM0628E

HARNESS


Passenger Compartment



TKIM0629E

HARNESS


ENGINE HARNESS/VK ENGINE MODELS



TKIM0068E

HARNESS


ENGINE HARNESS/VQ ENGINE MODELS



TKIM0069E

HARNESS

ENGINE CONTROL HARNESS/VK ENGINE MODELS



HARNESS

Engine control harness


D4	(F1)	GY/1	:	Oil pressure switch	D4 ★ (F52)	L/4	:	Heated oxygen sensor 2 (Bank 2)
E4	(F2)	B/1	:	Compressor (Magnet clutch)	F2 ★ (F61)	-/6	:	Air fuel ratio (A/F) sensor 1 (Bank 1)
D5 ★	(F4)	B/3	:	Camshaft position sensor (PHASE)	D1 ★ (F62)	-/6	:	Air fuel ratio (A/F) sensor 1 (Bank 2)
E5	(F6)	B/2	:	Compressor (ECV solenoid valve)	A5 ★ (F101)	SMJ	:	ECM
F4 ★	(F7)	B/6	:	Mass air flow sensor	B5 ★ (F102)	SMJ	:	To (M82)
F4	(F11)	-	:	Engine ground				
E4 ★	(F12)	B/3	:	Intake valve timing control position sensor (Bank 1)				
D4 ★	(F13)	LGY/2	:	Intake valve timing control solenoid valve (Bank 1)	F2 ★ (F201)	G/6	:	To (F21)
F3	(F15)	GY/3	:	Ignition coil No.1 (With power transistor)	E3 ★ (F202)	GY/2	:	Fuel injector No.1
F3	(F16)	GY/3	:	Ignition coil No.3 (With power transistor)	E2 ★ (F203)	GY/2	:	Fuel injector No.3
F3	(F17)	GY/3	:	Ignition coil No.5 (With power transistor)	E3 ★ (F204)	GY/2	:	Fuel injector No.5
F3	(F18)	GY/3	:	Ignition coil No.7 (With power transistor)	E2 ★ (F205)	GY/2	:	Fuel injector No.7
D4 ★	(F19)	B/6	:	Electric throttle control actuator				
F3 ★	(F21)	DGY/6	:	To (F201)				
F1	(F23)	W/2	:	Condenser	B2 ★ (F221)	G/6	:	To (F41)
F1 ★	(F24)	B/2	:	To (F261)	C3 ★ (F222)	GY/2	:	Fuel injector No.2
B1	(F25)	LGY/2	:	EVAP canister purge volume control solenoid valve	C4 ★ (F223)	GY/2	:	Fuel injector No.4
D3 ★	(F29)	B/2	:	VIAS control solenoid valve	C4 ★ (F224)	GY/2	:	Fuel injector No.6
B3 ★	(F30)	B/3	:	Intake valve timing control position sensor (Bank 2)	D2 ★ (F225)	GY/2	:	Fuel injector No.8
B3 ★	(F31)	LGY/2	:	Intake valve timing control solenoid valve (Bank 2)				
D3 ★	(F32)	G/4	:	Heated oxygen sensor 2 (Bank 1)				
B2	(F35)	GY/3	:	Ignition coil No.2 (With power transistor)	E1 ★ (F241)	B/4	:	To (F40)
B2	(F36)	GY/3	:	Ignition coil No.4 (With power transistor)	D3 ★ (F242)	L/2	:	Knock sensor (Bank 1)
B2	(F37)	GY/3	:	Ignition coil No.6 (With power transistor)	C4 ★ (F243)	L/2	:	Knock sensor (Bank 2)
C1	(F38)	GY/3	:	Ignition coil No.8 (With power transistor)				
D1 ★	(F40)	B/4	:	To (F241)				
B2 ★	(F41)	DGY/6	:	To (F221)	F2 ★ (F261)	SB/2	:	To (F24)
E1	(F43)	B/8	:	Transfer assembly	E1 ★ (F262)	GY/2	:	Engine coolant temperature sensor
E1 ★	(F44)	DGY/10	:	A/T assembly				
D3 ★	(F45)	B/3	:	Crankshaft position sensor (POS)				
C1 ★	(F46)	GY/6	:	To (E306)				
C1 ★	(F47)	GY/6	:	To (E17)				
D1 ★	(F49)	B/8	:	To (E19)				
E4	(F51)	-	:	Engine ground				

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Harness

ENGINE CONTROL HARNESS/VQ ENGINE MODELS

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



For detail ground distribution information,
refer to "GROUND DISTRIBUTION".

*1 : 2WD models
*2 : AWD models

For detail ground distribution information refer to "GROUND DISTRIBUTION".

PG

IV

HARNESS


Engine control harness

B4	F1	GY/1	: Oil pressure switch
C5	F2	B/1	: Compressor (Magnet clutch)
D5	F6	B/2	: Compressor (ECV solenoid valve)
E3	*	F8	B/6 : Mass air flow sensor
B2	*	F10	B/6 : To <u>(F211)</u>
C4	F11	—	: Engine ground
D1	*	F12	GY/3 : Camshaft position sensor (PHASE) (Bank 1)
B1	E17	GY/3	: Ignition coil No.5 (With power transistor)
E2	*	F19	DGY/6 : Electric throttle control actuator
B1	*	F20	B/2 : To <u>(F252)</u>
B1	F23	W/2	: Condenser
D1	*	F25	LGY/2 : EVAP canister purge volume control solenoid valve
B3	F26	GY/2	: Alternator
A3	*	F27	B/3 : Power steering pressure sensor
C1	*	F28	GY/2 : Engine coolant temperature sensor
E2	*	F30	B/3 : Camshaft position sensor (PHASE) (Bank 2)
D4	*	F31	LGY/2 : Intake valve timing control solenoid valve (Bank 2)
C3	*	F32	B/4 : Heated oxygen sensor 2 (Bank 1)
C3,D4	E33	GY/1	: Starter motor
E3	F35	GY/3	: Ignition coil No.2 (With power transistor)
E3	F36	GY/3	: Ignition coil No.4 (With power transistor)
E3	F37	GY/3	: Ignition coil No.6 (With power transistor)
E2	F43	B/8	: Transfer assembly
D1	*	F44	DGY/10 : A/T assembly
C4	*	F45	B/3 : Crankshaft position sensor (POS)
C1	*	F48	GY/9 : To <u>(E18)</u>
D1	*	F50	G/8 : To <u>(F251)</u>
C4	F51	—	: Engine ground
C4	*	F52	B/4 : Heated oxygen sensor 2 (Bank 2)
B2	*	E61	B/6 : Air fuel ratio (A/F) sensor 1 (Bank 1)
E3	*	F62	B/6 : Air fuel ratio (A/F) sensor 1 (Bank 2)
C1	*	F63	GY/6 : To <u>(E64)</u>
F5	*	F101	SMJ : ECM
G5	*	F102	SMJ : To <u>(M82)</u>

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT
sections.

HARNESS

BODY HARNESS



TKIM0751E

Harness

Body harness				
B1	SMJ : To M11	C1	B61 : -/16	DVD display
B2	W/12 : To E205	F3	B64 : GY/1	Not used
A2	W/6 : To E206	E3	B65 : W/12	Rear combination lamp control unit
A2	Y/2 : Front LH side air bag module	E3	B67 : W/2	Diode
B3	Y/18 : Front power seat (Driver side)	F2	B68 : GY/2	Inside key antenna-3 (Luggage room)
B3	W/8 : Front power seat (Driver side)	F3	B69 : SB4	Rear wheel sensor
B3	W/15 : BCM (Body control module)	E3	B79 : W/2	Diode
A3	B14 : —	F3	B80 : W/12	To B81
B3	B15 : Body ground	F2	B81 : W/12	To B80
B3	Y/12 : Air bag diagnosis sensor unit	F2	B84 : GY/6	To B2/16
D2	Y/12 : Air bag diagnosis sensor unit	D1	B85 : W/4	To B2/17
C2	—/16 : DVD player	Power socket sub-harness		
C2	W/3 : To B101	C2	B101 : W/3	To B20
B20	W/18 : To D51	C2	B102 : B2	Front power socket-2
B21	W/18 : To D51	C1	B103 : B2	Rear power socket
B2	Diode B67, B79		Luggage room lamp (Body side)	Diode B67, B79
C3	Y/2 : Front LH seat belt pre-tensioner	C2	B102 : B2	Front power socket-2
C3	Y/2 : LH side air bag (Satellite) sensor	C1	B103 : B2	Rear power socket
B3	W/3 : Front door switch (Driver side)	Luggage room lamp (Back door side)		
D1	Y/2 : Front RH side air bag module	Luggage room lamp (Back door side)		
C1	B28 : Front power seat (Passenger side)	D3	B39 : GY/5	Fuel level sensor unit and fuel pump (Main)
D1	B29 : W/6	D3	B40 : GY/2	Fuel level sensor unit (Sub)
B31	Y/2 : Front RH seat belt pre-tensioner	D3	—	Body ground
E2	B33 : RH side air bag (Satellite) sensor	D2	B46 : W/3	Rear door switch LH
E2	Y/2 : Front door switch (Passenger side)	D3	B49 : W/3	Luggage room lamp (Body side)
D1	W/3 : Fuel level sensor unit and fuel pump (Main)	D3	W/16 : To D101	To D101
D3	★	D3	W/6 : To D102	To D102
D3	GY/5 : Fuel level sensor unit and fuel pump (Main)	D2	W/3 : Luggage room lamp (Back door side)	Luggage room lamp (Back door side)
D3	GY/2 : Fuel level sensor unit (Sub)	D2	W/3 : LH side curtain air bag module	LH side curtain air bag module
D3	—	D3	Y/2 : RH side curtain air bag module	RH side curtain air bag module
D2	W/3 : Rear door switch LH	F1	B51 : W/16	Tweeter LH
D3	W/3 : Luggage room lamp (Back door side)	F2	B52 : W/6	Rear combination lamp LH
D3	W/3 : LH side curtain air bag module	F2	B53 : W/3	Luggage room power socket
D3	W/3 : RH side curtain air bag module	F2	B54 : Y/2	Failure to do so may cause the ECM to have diagnostic
F1	B51 : W/16	F2	B55 : W/4	Failure to connect and lock the connectors securely after
F1	B52 : W/6	F2	B56 : W/4	Failure to do so may cause the ECM to have diagnostic
F1	B53 : W/3	F2	B57 : W/4	Failure to do so may cause the ECM to have diagnostic
F1	B54 : Y/2	F2	B58 : B2	★ : Be sure to connect and lock the connectors securely after

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC section

TKIM0752E

HARNESS



BODY NO. 2 HARNESS

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC section.


★ B201	SMJ	: To (M81)
B202	GY/1	: GPS antenna
B203	-	: Body ground
B206	W/3	: Rear door switch RH
B207	W/32	: NAVI control unit
B208	W/40	: NAVI control unit
B209	GY/1	: NAVI control unit
B210	-	: Body ground
B211	W/16	: Satellite radio tuner (With satellite radio)

Without big size luggage floor
under box

With big size luggage floor
under box



View with rear side garnishes removed




Passenger side view with
floor garnishes removed

B212	GY/8	: BOSE speaker amp.
B213	B/24	: BOSE speaker amp.
★ B216	GY/6	: To B84
B217	W/4	: To B85
B218	BR/2	: Tweeter RH
B219	W/4	: Rear combination lamp RH
B220	W/4	: Fuel lid lock actuator
★ B221	B/2	: EVAP canister vent control valve
★ B222	GY/3	: EVAP control system pressure sensor
B223	B/8	: Woofer
B224	W/12	: Option connector-2 for satellite radio tuner (Without satellite radio)

For detail ground distribution information,
refer to "GROUND DISTRIBUTION".

HARNESS

ROOM LAMP HARNESS




TKIM0637E

HARNESS

FRONT DOOR HARNESS


LH Side

- (D1) SMJ : To (M21)
- (D2) W/16 : Door mirror (Driver side)
- (D3) GY/2 : Front door inside handle illumination (Driver side)
- (D4) BR/2 : Front door speaker LH
- (D6) W/16 : Power window main switch
- (D7) W/3 : Power window main switch
- (D8) W/6 : Front power window motor (Driver side)
- (D9) W/2 : Front step lamp (Driver side)
- (D10) B/6 : Front door lock assembly (Driver side)
- (D11) BR/2 : Intelligent Key warning buzzer (Driver side)
- (D12) GY/2 : Front door request switch (Driver side)
- (D13) W/8 : Seat memory switch (Via sub-harness)



TKIM0638E

RH Side




- (D31) SMJ : To (M91)
- (D32) W/16 : Door mirror (Passenger side)
- (D33) GY/2 : Front door inside handle illumination (Passenger side)
- (D34) BR/2 : Front door speaker RH
- (D36) W/16 : Front power window switch (Passenger side)
- (D38) W/6 : Front power window motor (Passenger side)
- (D39) W/2 : Front step lamp (Passenger side)
- (D40) B/6 : Front door lock assembly (Passenger side)
- (D41) BR/2 : Intelligent Key warning buzzer (Passenger side)
- (D42) GY/2 : Front door request switch (Passenger side)

TKIM0639E

HARNESS


REAR DOOR HARNESS

LH Side



TKIM0640E

RH Side




TKIM0641E

HARNESS

BACK DOOR HARNESS

(D101) W/16	:	To (B51)
(D102) W/6	:	To (B52)
(D103) GY/2	:	High-mounted stop lamp
(D104) GY/1	:	Rear window defogger (+)
(D105) W/2	:	Back-up lamp LH
(D106) W/10	:	Back door closure control unit
(D107) W/4	:	Rear wiper motor
(D108) W/4	:	Rear view camera
(D109) W/8	:	Back door closure motor
(D110) W/2	:	License plate lamp LH
(D111) W/2	:	License plate lamp RH
(D112) W/2	:	Back door opener switch
(D113) BR/2	:	Back door request switch
(D114) GY/1	:	Rear window defogger (-)
(D115) W/2	:	Back-up lamp RH
(D116) BR/2	:	Outside key antenna-3 (Back door)



TKIH0016E

A
B
C
D
E
F
G
H
I
J
K
L
M

PG

HARNESS

Wiring Diagram Codes (Cell Codes)

NKS003GO

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
AF1B1	EC	Air Fuel Ratio Sensor 1 Bank 1
AF1B2	EC	Air Fuel Ratio Sensor 1 Bank 2
AF1HB1	EC	Air Fuel Ratio Sensor 1 Heater Bank 1
AF1HB2	EC	Air Fuel Ratio Sensor 1 Heater Bank 2
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner
AUTO/L	LT	Automatic Light System
AWD	TF	AWD Control System
B/CLOS	BL	Back Door Closure System
BACK/L	LT	Back-Up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CLOCK	DI	Clock
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication Line
COMPAS	DI	Compass
COOL/F	EC	Cooling Fan Control
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECM/PW	EC	ECM Power Supply for Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Electric Throttle Control Motor Relay
ETC3	EC	Electric Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FTS	AT	A/T Fluid Temperature Sensor Circuit

HARNESS

Code	Section	Wiring Diagram Name
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
H/PHON	AV	Hands Free Telephone
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/KEY	BL	Intelligent Key System
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
IATS	EC	Intake Air Temperature Sensor
ICC	ACS	Intelligent Cruise Control System
ICC/BS	EC	ICC Brake Switch
ICC/SW	EC	ICC Steering Switch
ICCB0F	EC	ICC Brake Switch
IGNSYS	EC	Ignition System
ILL	LT	Illumination
INF/D	AV	Vehicle Information and Integrated Switch System
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
IVCSB1	EC	Intake Valve Timing Control Position Sensor Bank 1
IVCSB2	EC	Intake Valve Timing Control Position Sensor Bank 2
IVTB1	EC	Intake Valve Timing Control System (Bank 1)
IVTB2	EC	Intake Valve Timing Control System (Bank 2)
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
LDW	DI	Lane Departure Warning System
M/ANT	AV	Manual Antenna
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
MES	AV	Mobile Entertainment System
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL & Data Link Connector
MIRROR	GW	Power Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
NONDTC	AT	Non-Detective Items
O2H2B1	EC	Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Heated Oxygen Sensor 2 Heater Bank 2
O2S2B1	EC	Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Heated Oxygen Sensor 2 Bank 2

HARNESS

Code	Section	Wiring Diagram Name
P/SCKT	WW	Power Socket
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank 2)
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
R/VIEW	DI	Rear View Camera Control System
ROOM/L	LT	Interior Room Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SNOWSW	EC	Snow Mode Switch
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal Circuit
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	Homelink Universal Transceiver
TURN	LT	Turn Signal and Hazard Warning Lamp
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System
VENT/V	EC	EVAP Canister Vent Control Valve
VIAS	EC	Variable Induction Air Control System
VIAS/V	EC	VIAS Control Solenoid Valve
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer
WIPER	WW	Front Wiper and Washer


ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION


PFP:25230

Electrical Units Location ENGINE COMPARTMENT


NKS003GP



FUSE, FUSIBLE LINK AND RELAY BOX



RELAY BOX-2




A
B
C
D
E
F
G
H
I
J


PG
L
M

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT



A Behind dash side lower finisher LH




Fuse block (J/B) rear view



CKIM0647E


ELECTRICAL UNITS LOCATION

B Driver side view with lower instrument panel removed




Intelligent Key unit (M34)

C Driver side view with cluster lid A removed




Steering lock unit (M26)

D Under driver seat




Driver seat control unit (B152, B153)

E View with cluster lid C removed




Unified meter and A/C amp.
(M55), (M56), (M57)

F View with instrument panel center removed




Rear view camera control unit (M48)

G Behind lower instrument panel on passenger side



Display control unit
Blower motor (M75, M76)

H Behind lower instrument panel on passenger side



ICC unit (M88, M89)

ECM (M90, F101)

AWD control unit (M92)


J View with floor console box removed

Yaw rate/side/decel G sensor(AWD models)

(M71)


Yaw rate/side G sensor(2WD models)

(M79)




Air bag diagnosis sensor unit
(M72, B17, B18)

K View with passenger seat removed



NAVI control unit
(B207, B208, B209)

L Map lamp garnish removed



LDW camera unit (R9)

A

B

C

D

E

F

G

H

I

PG





L

M

CKIM0648E

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT



HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

NKS003GQ

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Never pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:


- Never pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]

Waterproof type



Non-waterproof type



SEL769V


HARNESS CONNECTOR

HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.



1. Control unit with single lever
 - A. Fasten
 - B. Loosen
 - C. Lever
2. Control unit with dual levers
 - A. Levers
 - B. Fasten
 - C. Loosen
3. SMJ connector
 - A. Lever
 - B. Fasten
 - C. Loosen

ELECTRICAL UNITS


ELECTRICAL UNITS

PFP:00011


Terminal Arrangement

NKS003GR


ECM




ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



UNIFIED METER AND A/C AMP.



BCM (BODY CONTROL MODULE)




CKIM0650E

ELECTRICAL UNITS

A

INTELLIGENT KEY UNIT

M34



(White)

B

C

D

E

F

G


H

I

J


ICC UNIT

M88



(White)

M89



(Gray)



PG

L

M

CKIM0218E

SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

Terminal Arrangement


PFP:B4341

NKS003GS


MAIN HARNESS




M41 (White)




M11 (White)



M81 (White)




E211 (White)



ENGINE ROOM HARNESS

B1 (White)




BODY HARNESS

B201 (White)

BODY No.2 HARNESS

SMJ (SUPER MULTIPLE JUNCTION)



CKIM0220E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

NKS003GT

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.




SEL881H

TYPE OF STANDARDIZED RELAYS















1M 1 Make
1T 1 Transfer

2M 2 Make
1M·1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

CKIM0221E

A
B
C
D
E
F
G
H
I
J

PG
L
M


FUSE BLOCK - JUNCTION BOX (J/B)

FUSE BLOCK - JUNCTION BOX (J/B)


PFP:24350

Terminal Arrangement

NKS003GU



To engine room harness





FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

Terminal Arrangement

NKS003GV



FUSE, FUSIBLE LINK AND RELAY BOX
