

SECTION PG

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

SERVICE INFORMATION	2		A
DTC INDEX	2		B
U1000	2		C
POWER SUPPLY ROUTING CIRCUIT	3		D
Schematic	3		E
Wiring Diagram - POWER -	4		F
Fuse	16		G
Fusible Link	16		H
Circuit Breaker	16		I
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	17		J
System Description	17		K
CAN Communication System Description	18		L
CAN Communication Unit	18		M
Function of Detecting Ignition Relay Malfunction	18		N
CONSULT-III Function (IPDM E/R)	18		O
Auto Active Test	20		P
Schematic	22		
IPDM E/R Terminal Arrangement	23		
IPDM E/R Power/Ground Circuit Inspection	23		
U1000 CAN COMM CIRCUIT	24		
Removal and Installation of IPDM E/R	24		
GROUND	26		
Ground Distribution	26		
HARNESS	40		
Harness Layout	40		
Wiring Diagram Codes (Cell Codes)	60		
ELECTRICAL UNITS LOCATION	64		
Electrical Units Location	64		
HARNESS CONNECTOR	68		
Description	68		
ELECTRICAL UNITS	71		
Terminal Arrangement	71		
SMJ (SUPER MULTIPLE JUNCTION)	73		
Terminal Arrangement	73		
STANDARDIZED RELAY	75		
Description	75		
FUSE BLOCK - JUNCTION BOX (J/B)	77		
Terminal Arrangement	77		
FUSE, FUSIBLE LINK AND RELAY BOX	78		
Terminal Arrangement	78		

PG

DTC INDEX

< SERVICE INFORMATION >

SERVICE INFORMATION

DTC INDEX

U1000

INFOID:000000001351918

DTC	Items (CONSULT screen terms)	Reference
U1000	CAN COMM CIRCUIT	PG-24, "U1000 CAN COMM CIRCUIT"


POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

POWER SUPPLY ROUTING CIRCUIT

Schematic

INFOID:0000000001328865



(intelligent power distribution module engine room).

(AW) : AWD models

- * : AWD models
- * : This relay is built into the IPDM E/R (intelligent power distribution module engine room).

AW

Revision: 2007 April


POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

Wiring Diagram - POWER -

INFOID:000000001328866

BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION




TKWM4458E

POWER SUPPLY ROUTING CIRCUIT


< SERVICE INFORMATION >

PG-POWER-02



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG





TKWM4459E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-03




REFER TO THE FOLLOWING.
E211 -SUPER MULTIPLE
 JUNCTION (SMJ)

TKWM4460E

POWER SUPPLY ROUTING CIRCUIT


< SERVICE INFORMATION >

PG-POWER-04



A
B
C
D
E
F
G
H
I
J

PG



L
M
N
O


O
P

TKWM4461E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-05




TKWM0712E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-06



A

B

C

D

E

F

G

H

I

J

PG

L

M

N

O


P

TKWM4462E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >


ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”



TKWM4463E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >




TKWM4904E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”




TKWM4465E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

PG-POWER-10



A
B
C
D
E
F
G
H
I
J

PG



REFER TO THE FOLLOWING:										
(M2 , E201 , E202)-FUSE BLOCK-JUNCTION BOX (J/B)										
1	2									
12	13	14	15	16	17	18	19	20	21	22
8	9	10	11							


TKWM4466E

L
M
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >


PG-POWER-11



TKWM4467E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >




TKWM4468E

POWER SUPPLY ROUTING CIRCUIT

< SERVICE INFORMATION >

Fuse

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.


CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

System Description

INFOID:000000001328870

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control, oil pressure switch signal, and hood switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:

None of the IPDM E/R-integrated relays can be removed.

SYSTEMS CONTROLLED BY IPDM E/R

IPDM E/R receives a request signal from each control unit with CAN communication. It controls each system.

Control system	Transmit control unit	Control part
Lamp control	BCM	<ul style="list-style-type: none">• Headlamps (HI, LO)• Front fog lamps• Parking, license plate, side marker and tail lamps
Wiper control	BCM	Front wipers
Rear window defogger control	BCM	Rear window defogger
A/C compressor control	ECM	A/C compressor (magnet clutch)
Cooling fan control	ECM	Cooling fan
Horn control	BCM	Horn

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN-L line, CAN-H line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

Fail-Safe Control

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none">• With the ignition switch ON, the headlamp (low) is ON.• With the ignition switch OFF, the headlamp (low) is OFF.
Parking, license plate side marker, and tail lamps	<ul style="list-style-type: none">• With the ignition switch ON, the parking, license plate, side marker and tail lamps is ON.• With the ignition switch OFF, the parking, license plate, side marker and tail lamps is OFF.
Cooling fan	<ul style="list-style-type: none">• With the ignition switch ON, the cooling fan HI operates.• With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned OFF, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C compressor OFF
Front fog lamps	Front fog lamp relay OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.
 - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
 - Process to stop CAN communication is activated.

A

B

C

D

E

F

G

H

I

J

PG

L

M

N

O

P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

- All systems controlled by IPDM E/R are stopped. When 3 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.

3. Sleep status

- IPDM E/R operates in low power mode.
- CAN communication is stopped.
- When a change in CAN communication line is detected, mode switches to CAN communication status.
- When a change hood switch or ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

INFOID:0000000001328871

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

INFOID:0000000001328872

Refer to [LAN-43, "CAN System Specification Chart"](#).

Function of Detecting Ignition Relay Malfunction

INFOID:0000000001328873

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON parking, license plate, side marker and tail lamps for 10 minutes to indicate ignition relay malfunction.
- When a state of ignition relay having built-in does not agree with a state of ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

CONSULT-III Function (IPDM E/R)

INFOID:0000000001328874

CONSULT-III can display each diagnostic item using the diagnostic test mode shown following.

Inspection Item, Diagnosis Mode	Description
Self Diagnostic Result	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
Data Monitor	The input/output data of the IPDM E/R is displayed in real time.
CAN Diag Support Monitor	The result of transmit/receive diagnosis of CAN communication can be read.
Active test	The IPDM E/R sends a drive signal to electronic components to check their operation.

Self Diagnostic Result

Display Item List

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

DTC	Display Items	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
—	NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	—	—	—	—
U1000	CAN COMM CIRCUIT	<ul style="list-style-type: none"> If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> TRANSMIT DIAG ECM BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

DATA MONITOR

Item name	CONSULT-III screen display	Display or unit	MAIN SIGNALS	Description
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	Signal status input from ECM
Compressor request	AC COMP REQ	On/Off	×	Signal status input from ECM
Tail & clear request	TAIL&CLR REQ	On/Off	×	Signal status input from BCM
H/L LO request	HL LO REQ	On/Off	×	Signal status input from BCM
H/L HI request	HL HI REQ	On/Off	×	Signal status input from BCM
FR fog request	FR FOG REQ	On/Off	×	Signal status input from BCM
FR wiper request	FR WIP REQ	Stop/1LOW/Lo/Hi	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	Output status of IPDM E/R
Wiper protection	WIP PROT	Off/BLOCK	×	Control status of IPDM E/R
Starter request	ST RLY REQ ^{*1}	On/Off		Status of input signal
Ignition relay status	IGN RLY	On/Off	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	On/Off	×	Signal status input from BCM
Oil pressure switch	OIL P SW	Open/Close		Signal status input in IPDM E/R
Hood switch	HOOD SW	On/Off		Input signal status
Theft warning horn request	THFT HRN REQ	On/Off		Signal status input from BCM
Horn chirp	HORN CHIRP	On/Off		Output status of IPDM E/R
Cornering lamp request	CRNRNG LMP REQ ^{*2}	Off		Signal status input from BCM

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- *1: The vehicle without the Intelligent Key system displays only ON without change.
- *2:The cornering lamp item is displayed, but it cannot be monitored.

ACTIVE TEST

Test item	CONSULT-III screen display	Description
Tail lamp operation	TAIL LAMP	With a certain On-Off operation, the tail lamp relay can be operated.
Rear window defogger operation	REAR DEFOGGER	With a certain On-Off operation, the rear window defogger relay can be operated.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

Test item	CONSULT-III screen display	Description
Front wiper (HI, LO) operation	FRONT WIPER	With a certain operation (Off, Hi, Lo), the front wiper relay (Lo, Hi) can be operated.
Cooling fan operation	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan can be operated.
Lamp (HI, LO, FOG) operation	LAMPS	With a certain operation (Off, Hi, Lo, Fog), the lamp relay (Lo, Hi, Fog) can be operated.
Cornering lamp operation	CORNERING LAMPNOTE	—
Horn operation	HORN	With a certain On-Off operation, the horn relay can be operated.

NOTE:

This item is displayed, but cannot be tested.

Auto Active Test

INFOID:0000000001328875

DESCRIPTION

In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:

- Rear window defogger
- Front wipers
- Parking, license plate, side marker and tail lamps
- Front fog lamps
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood and front door (passenger side), and then lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press drivers door switch 10 times (close other doors). Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once oil pressure warning lamp starts blinking.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect [BL-38. "Check Door Switch"](#) when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

When auto active test mode is actuated, the following eight steps are repeated three times.



PKIB6583E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

NOTE:

Turns ON-OFF the solenoid to switch Hi/Lo. In this case, the bulb does not illuminate.

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	<ul style="list-style-type: none"> BCM signal input system malfunction
		NO	<ul style="list-style-type: none"> Lamp/wiper motor malfunction Lamp/wiper motor ground circuit malfunction Harness/connector malfunction between IPDM E/R and system in question IPDM E/R (integrated relay) malfunction
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction
		NO	<ul style="list-style-type: none"> Rear window defogger relay malfunction Harness/connector malfunction between IPDM E/R and rear window defogger relay. Open circuit of rear window defogger IPDM E/R malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit malfunction CAN communication signal between BCM and ECM. CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness/connector malfunction between IPDM E/R and magnetic clutch IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> ECM signal input circuit CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Cooling fan motor malfunction Harness/connector malfunction between IPDM E/R and cooling fan motor IPDM E/R (integrated relay) malfunction
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> Harness/connector malfunction between IPDM E/R and oil pressure switch Oil pressure switch malfunction IPDM E/R malfunction
		NO	<ul style="list-style-type: none"> CAN communication signal between BCM and unified meter and A/C amp. Combination meter

A

B

C

D

E

F

G

H

I

J

PG

L

M

N

O


P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

Schematic

INFOID:000000001328876




TKWM4469E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

IPDM E/R Terminal Arrangement

INFOID:000000001328877



A
B
C
D
E
F
G
H
I
J
PG
L
M
N
O
P

IPDM E/R Power/Ground Circuit Inspection

INFOID:000000001370717

1. CHECK FUSE AND FUSIBLE LINK

Make sure the following fusible links or IPDM E/R fuses are not blown.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >

Terminal No.	Power source	Fuse and fusible link No.
1	Battery power	E
2		C
—		71
		78

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link blown, be sure to eliminate cause of malfunction before installing new one.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Ap-prox.)
(+)	(-)	
IPDM E/R connector	Terminal	Ground
E3	1	Battery voltage
	2	



OK or NG


OK >> GO TO 3.

NG >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors.
2. Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R connector	Terminal	Ground	Continuity
E8	38		Yes
E9	50		
	60		



OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.

U1000 CAN COMM CIRCUIT

INFOID:0000000001366489

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of IPDM E/R.

Is "CAN COMM CIRCUIT" displayed?

YES >> Refer to [LAN-43, "CAN System Specification Chart"](#).

NO >> Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

Removal and Installation of IPDM E/R

INFOID:0000000001328880


REMOVAL

1. Remove battery. Refer to [SC-6, "Removal and Installation"](#).

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< SERVICE INFORMATION >


2. Remove IPDM E/R cover A. While pressing pawl on backside of IPDM E/R cover B toward vehicle front to unlock, lift up IPDM E/R.



A
B
C
D
E
F
G
H
I
J

PG

3. While pressing pawls on right and left side of IPDM E/R, remove IPDM E/R cover B from IPDM E/R.
4. Remove harness connector from IPDM E/R.



L
M
N
O
P

INSTALLATION

Installation is the reverse order of removal.

GROUND


< SERVICE INFORMATION >

GROUND

Ground Distribution


INFOID:0000000001328881

MAIN HARNESS



GROUND


< SERVICE INFORMATION >



CKIM0640E

GROUND

< SERVICE INFORMATION >



CKIM0641E


GROUND

< SERVICE INFORMATION >

ENGINE ROOM HARNESS

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

CONNECTOR NUMBER	CONNECT TO
E6	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 15) (With VQ engine) ·Cooling fan relay-1 ·Cooling fan relay-3
E8	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 38) ·CPU ·Ignition relay ·Front wiper relay
E9	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 50) ·CPU
E9	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 60) ·CPU
E12	Accessory relay-2
E14	ICC brake hold relay
E22	Front side marker lamp RH
E23	Parking lamp RH ·Parking ·Daytime
E24	Front combination lamp RH (Terminal No. 7) ·Headlamp ·High beam solenoid
E24	Front combination lamp RH (Terminal No. 8) ·Turn signal
E39	ICC sensor
E41	Cooling fan motor (Terminal No. 3) (With VK engine)
E123	Cooling fan motor-2 (Terminal No. 4) (With VQ engine)
E41	Cooling fan motor (Terminal No. 4) (With VK engine)
E123	Cooling fan motor-2 (Terminal No. 3) (With VQ engine)
E45	Front fog lamp LH




CKIM0654E

GROUND

< SERVICE INFORMATION >


 Preceding page



CKIM0655E

GROUND

< SERVICE INFORMATION >



A
B
C
D
E
F
G
H
I
J

PG

L

M

N

O


P

CKIM0642E

GROUND

< SERVICE INFORMATION >

ENGINE HARNESS/VK ENGINE MODELS



CKIM0203E

GROUND

< SERVICE INFORMATION >

ENGINE HARNESS/VQ ENGINE MODELS

A

B

C

D

E

F

G

H

I

J

PG


L

M

N

O

P




CKIM0204E

GROUND

< SERVICE INFORMATION >

ENGINE CONTROL HARNESS/VK ENGINE MODELS




CKIM0408E

GROUND

< SERVICE INFORMATION >

ENGINE CONTROL HARNESS/VQ ENGINE MODELS



A
B
C
D
E
F
G
H
I
J

PG


L
M
N
O
P

CKIM0409E

GROUND

< SERVICE INFORMATION >


BODY HARNESS



CKIM0643E

GROUND

< SERVICE INFORMATION >



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PG

CKIM0644E

GROUND

< SERVICE INFORMATION >

BODY NO. 2 HARNESS




CKIM0645E

GROUND

< SERVICE INFORMATION >

ROOM LAMP HARNESS



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CKIM0211E

PG

HARNESS

< SERVICE INFORMATION >

HARNESS


Harness Layout

INFOID:0000000001328882

HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the figures:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness



To Use the Grid Reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the figure, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.


Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

CKIT0108E

HARNESS

< SERVICE INFORMATION >

OUTLINE



A
B
C
D
E
F
G
H
I
J


PG

L
M
N
O
P

Harness

< SERVICE INFORMATION >

MAIN HARNESS



- Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC AND AT sections.

For detail ground distribution information, refer to "GROUND DISTRIBUTION".

HARNESS

< SERVICE INFORMATION >

A4 M1	W/16	Fuse block (J/B)	D3 M46	W/2	In-vehicle sensor
A4 M2	W/8	Fuse block (J/B)	E3 M48	W/16	Rear view camera control unit
A5 M3	W/40	BCM (Body control module)	E3 M49	W/32	Automatic drive positioner control unit
A5 M4	B/15	BCM (Body control module)	E3 M50	W/16	Automatic drive positioner control unit
B5 M5	W/16	Data link connector	F4 M51	W/4	Hazard switch
A4 M6	W/2	Low tire pressure warning check switch	E4 M52	W/4	Clock
D2 M7	W/2	Diode	E4 M53	W/3	Front power socket-1
D2 M8	W/2	Diode	E4 M54	BR/2	A/T device (illumination)
C1 M9	W/2	Diode	G3 ★ M55	GY/20	Unified meter and A/C amp.
D1 M10	W/2	Diode	E2 ★ M56	GY/16	Unified meter and A/C amp.
A4 ★ M11	SMJ	To (B1)	E2 M57	W/24	Unified meter and A/C amp.
D1 M12	W/2	Diode	F3 M58	W/10	Audio unit
C4 M13	GY/6	ADP steering switch	E2 M59	W/6	Audio unit
C4 M14	W/8	Steering angle sensor	E2 M60	W/16	Audio unit
D4 ★ M15	GY/8	Combination switch (Spiral cable)	E3 M61	BR/2	Antenna amp.
D4 M16	Y/6	Combination switch (Spiral cable)	E1 M63	W/24	Display
C3 M17	W/16	Combination switch	E1 M64	W/16	A/C and AV switch
A3 M18	BR/16	Door mirror remote control switch	E1 M65	BR/8	Audio unit
C1 ★ M20	W/24	Combination meter	D1 M66	BR/2	Instrument speaker center
A4 M21	SMJ	To (D1)	E4 ★ M67	W/10	A/T device
D2 M22	GY/6	Key switch and ignition knob switch (With Intelligent Key)	F4 M68	W/6	Heated seat switch (Driver side)
C1 M23	BR/2	Key switch (Without Intelligent Key)	G4 M69	BR/6	Heated seat switch (Passenger side)
C1 M24	W/2	Ignition keyhole illumination	G4 M70	W/2	Inside key antenna-1 (Dashboard)
D4 M25	W/4	NATS antenna amp.	G4 M71	B/6	Yaw rate / Side / Decel G sensor (AWD models)
D4 M26	W/4	Steering lock unit	G5 M72	Y/28	Air bag diagnosis sensor unit
C4 M27	W/4	Tilt motor and telescopic motor	G4 M73	-/16	DVD player
C4 M28	W/4	Tilt sensor and telescopic sensor	E1 M75	W/24	Display control unit
C4 M29	W/2	Circuit breaker	F2 M76	W/32	Display control unit
B2 M30	B/5	Passenger side select unlock relay	E1 M77	W/6	Heater and cooling unit (Via sub-harness)
A1 M31	W/18	To (R1)	F3 M78	W/6	Blower motor
B5 M32	GY/6	VDC off switch	G5 M79	B/6	Yaw rate / Side G sensor (2WD models)
A3 M34	W/40	Intelligent Key unit	G2 ★ M81	SMJ	To (B201)
A2 ★ M35	-	Body ground	G2 ★ M82	SMJ	To (F102)
A2 M36	BR/2	Instrument speaker LH			
A1 M37	W/3	Optical sensor			
A2 M38	BR/2	Security indicator lamp			
D4 ★ M41	SMJ	To (E211)			
C1 ★ M45	-	Body ground			


★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working sections according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0625E

PG

HARNESS

< SERVICE INFORMATION >



- ★ : Be sure to connect and lock the connectors securely after repair work.
- Failure to do so may cause the ECM to have diagnostic trouble codes.
- Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


ENGINE ROOM HARNESS

TKIM0626E

Harness

< SERVICE INFORMATION >

Engine Compartment



- ★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0627E

HARNESS

< SERVICE INFORMATION >

Engine room harness

C2	E1	B/2	Fusible link holder
C2	E2	GY/2	Fusible link holder
C1	E3	B/2	IPDM E/R (Intelligent power distribution module engine room)
C1 ★	E4	W/4	IPDM E/R (Intelligent power distribution module engine room)
B1 ★	E5	B/4	IPDM E/R (Intelligent power distribution module engine room)
D2 ★	E6	W/6	IPDM E/R (Intelligent power distribution module engine room)
C1 ★	E7	GY/16	IPDM E/R (Intelligent power distribution module engine room)
C1 ★	E8	W/12	IPDM E/R (Intelligent power distribution module engine room)
D2 ★	E9	W/16	IPDM E/R (Intelligent power distribution module engine room)
F1 ★	E10	—	Fuse and fusible link block
C2	E11	—	Fuse, fusible link and relay box
F1	E12	L/4	Accessory relay-2
B1	E13	BR/6	Rear window defogger relay
B1 ★	E14	GY/6	ICC brake hold relay
A1	E15	L/4	Daytime light relay
B1	E16	—	Relay box
D1 ★	E17	GY/6	To (F47) (With VK engine)
D1 ★	E18	GY/9	To (F48) (With VQ engine)
D1 ★	E19	B/8	To (F49) (With VK engine)
B1	E20	GY/2	Hood switch
B2 ★	E21	—	Body ground
A2	E22	B/2	Front side marker lamp RH
A2	E23	GY/3	Parking lamp RH
A1	E24	B/8	Front combination lamp RH
A3	E25	B/2	To (E101)
A3	E26	BR/2	Washer level sensor
C2 ★	E29	B/8	To (E121) (With VQ engine)
C2	E30	GY/1	To (E303)
C2	E31	—	Body ground
A2	E32	B/3	Refrigerant pressure sensor
A2	E33	GY/2	Front wheel sensor RH
B3	E34	B/2	Ambient sensor
C3	E35	B/1	Horn low
C3	E36	B/1	Horn low
C4	E37	B/1	Horn high
C4	E38	B/1	Horn high
B4	E39	GY/6	ICC sensor
B4	E40	Y/2	Crash zone sensor

★ E41 Cooling fan motor (With VK engine)

C4 ★	E41	GY/4	Cooling fan motor (With VK engine)
C4 ★	E42	B/2	Front side marker lamp LH
D3	E43	GY/3	Parking lamp LH
E3	E44	B/8	Front combination lamp LH
D5	E45	—/2	Front fog lamp LH
E4	E46	GY/2	Front wheel sensor LH
D3	E49	—	Body ground
E3 ★	E50	—	Body ground
D3 ★	E51	—	Body ground
E1	E52	GY/2	Brake fluid level switch
E3	E53	B/3	Pressure sensor
E2	E54	GY/6	Brake booster
D2	E55	BR/3	To (E141)
F2	E56	SMU	ABS actuator and electric unit (Control unit)
F2	E57	GY/5	Front wiper motor
G2	E61	L/4	Back-up lamp relay
F2	E62	—	Relay box-2
A3	E63	GY/2	Front and rear washer pump
D1 ★	E64	GY/6	To (F66) (With VQ engine)

Front fog lamp RH sub-harness

A4	E101	B/2	To (E25)
A4	E102	—/2	Front fog lamp RH

Cooling fan sub-harness (With VQ engine)

C3 ★	E121	DGY/8	To (E29)
B3 ★	E122	GY/4	Cooling fan motor-1
C3 ★	E123	GY/4	Cooling fan motor-2

ICC sub-harness

D2	E141	BR/3	To (E55)
E3	E142	B/3	Brake pressure sensor


★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT
sections.

TKIM0628E

HARNESS

< SERVICE INFORMATION >

Passenger Compartment



★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC section.


PG

TKIM0629E

HARNESS

< SERVICE INFORMATION >

ENGINE HARNESS/VK ENGINE MODELS




TKIM0068E

HARNESS

< SERVICE INFORMATION >

ENGINE HARNESS/VQ ENGINE MODELS


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



HARNESS

< SERVICE INFORMATION >

ENGINE CONTROL HARNESS/VK ENGINE MODELS



TKIM0630E

HARNESS

< SERVICE INFORMATION >

Engine control harness

D4 F1	GY/1	: Oil pressure switch
E4 F2	B/1	: Compressor (Magnet clutch)
D5 F4	B/3	: Camshaft position sensor (PHASE)
E5 F6	B/2	: Compressor (ECV solenoid valve)
F4 F7	B/6	: Mass air flow sensor
F4 F11	—	: Engine ground
E4 ★ F12	B/3	: Intake valve timing control position sensor (Bank 1)
D4 ★ F13	LGY/2	: Intake valve timing control solenoid valve (Bank 1)
F3 F15	GY/3	: Ignition coil No.1 (With power transistor)
F3 F16	GY/3	: Ignition coil No.3 (With power transistor)
F3 F17	GY/3	: Ignition coil No.5 (With power transistor)
F3 F18	GY/3	: Ignition coil No.7 (With power transistor)
D4 ★ F19	B/6	: Electric throttle control actuator
F3 ★ F21	DGY/6	: To (F201)
F1 F23	W/2	: Condenser
F1 ★ F24	B/2	: To (F261)
B1 F25	LGY/2	: EVAP canister purge volume control solenoid valve
D3 ★ F29	B/2	: VIAS control solenoid valve
B3 ★ F30	B/3	: Intake valve timing control position sensor (Bank 2)
B3 ★ F31	LGY/2	: Intake valve timing control solenoid valve (Bank 2)
D3 ★ F32	G/4	: Heated oxygen sensor 2 (Bank 1)
B2 F35	GY/3	: Ignition coil No.2 (With power transistor)
B2 F36	GY/3	: Ignition coil No.4 (With power transistor)
B2 F37	GY/3	: Ignition coil No.6 (With power transistor)
C1 F38	GY/3	: Ignition coil No.8 (With power transistor)
D1 ★ F40	B/4	: To (F241)
B2 ★ F41	DGY/6	: To (F221)
E1 F43	B/8	: Transfer assembly
E1 F44	DGY/10	: A/T assembly
D3 ★ F45	B/3	: Crankshaft position sensor (POS)
C1 ★ F46	GY/6	: To (E306)
C1 ★ F47	GY/6	: To (E17)
D1 ★ F49	B/8	: To (E19)
E4 F51	—	: Engine ground

Engine control sub-harness-1

F2 ★ F201	G/6	: To (F21)
E3 ★ F202	GY/2	: Fuel injector No.1
E2 ★ F203	GY/2	: Fuel injector No.3
E3 ★ F204	GY/2	: Fuel injector No.5
E2 ★ F205	GY/2	: Fuel injector No.7

Engine control sub-harness-2

B2 ★ F221	G/6	: To (F41)
C3 ★ F222	GY/2	: Fuel injector No.2
C4 ★ F223	GY/2	: Fuel injector No.4
C4 ★ F224	GY/2	: Fuel injector No.6
D2 ★ F225	GY/2	: Fuel injector No.8

Engine control sub-harness-3

E1 ★ F241	B/4	: To (F40)
D3 ★ F242	L/2	: Knock sensor (Bank 1)
C4 ★ F243	L/2	: Knock sensor (Bank 2)

Engine control sub-harness-4

F2 ★ F261	SB/2	: To (F24)
E1 ★ F262	GY/2	: Engine coolant temperature sensor

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0631E

A

B

C

D

E

F

G

H

I
J

K

L


M

P

HARNESS

< SERVICE INFORMATION >

ENGINE CONTROL HARNESS/V/Q ENGINE MODELS



HARNESS

< SERVICE INFORMATION >

Engine control harness		Engine control sub-harness-1		Engine control sub-harness-2	
B4 C5 D5 E3 *B2 *C4 D1 * B1 E2 * B1 D1 * B1 B3 *A3 *C1 *E2 *D4 *C3,D4 E3 E3 E3 E2 D1 * C4 *C1 *D1 *C4 *C4 *B2 *E3 C1 *F5	F1 F2 F6 F8 F10 F11 F12 F17 F19 F20 F23 F25 F26 F27 F28 F30 F31 F32 F33 F35 F36 F37 F43 F44 F45 F48 F50 F51 F52 F56 F61 F62 F65 F70 F72	GY1 : Oil pressure switch B/1 : Compressor (Magnet clutch) B/2 : Compressor (ECV solenoid valve) B/6 : Mass air flow sensor B/6 : To (F211) — : Engine ground GY3 : Camshaft position sensor (PHASE) (Bank 1) GY3 : Ignition coil No.5 (With power transistor) DGY/6 : Electric throttle control actuator B/2 : To (F252) W/2 : Condenser LGY/2 : EVAP canister purge volume control solenoid valve GY/2 : Alternator B/3 : Power steering pressure sensor B/3 : Engine coolant temperature sensor LGY/2 : Camshaft position sensor (PHASE) (Bank 2) LGY/2 : Intake valve timing control solenoid valve (Bank 2) B/4 : Heated oxygen sensor 2 (Bank 1) GY1 : Starter motor GY3 : Ignition coil No.2 (With power transistor) GY3 : Ignition coil No.4 (With power transistor) GY3 : Ignition coil No.6 (With power transistor) B/8 : Transfer assembly DGY/10 : A/T assembly B/3 : Crankshaft position sensor (POS) GY/9 : To (E18) G/8 : To (F251) — : Engine ground B/4 : Heated oxygen sensor 2 (Bank 2) B/6 : Air fuel ratio (A/F) sensor 1 (Bank 1) B/6 : Air fuel ratio (A/F) sensor 1 (Bank 2) GY/6 : To (E64) SMJ : ECM SMJ : To (M82)	B2 * (F211) L/6 : To (F10) B3 (F212) GY/3 : Ignition coil No.1 (With power transistor) B2 (F213) GY/3 : Ignition coil No.3 (With power transistor) B3 * (F214) G/2 : Intake valve timing control solenoid valve (Bank 1)	D2 * (F251) G/8 : To (F50) B1 * (F252) SB/2 : To (F20) C3 * (F253) GY/2 : Fuel injector No.1 C3 * (F254) GY/2 : Fuel injector No.3 C1 * (F255) GY/2 : Fuel injector No.5 C3 * (F256) GY/2 : Fuel injector No.2 D3 * (F257) GY/2 : Fuel injector No.4 D2 * (F258) GY/2 : Fuel injector No.6 D2 * (F259) L/2 : Knock sensor	★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIM0750E

P

PG

A

B

C

D

E

F

G

J

M

Z


O

L

HARNESS


< SERVICE INFORMATION >

BODY HARNESS



HARNESS

< SERVICE INFORMATION >



TKIM0752E

A

B

C

D

E

F

G

H

I

M

Z

O

P

PG

HARNESS

< SERVICE INFORMATION >


BODY NO. 2 HARNESS

* : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC section.


* B201	SMU	: To M81
B202	GY/1	: GPS antenna
B203	-	: Body ground
B206	W/3	: Rear door switch RH
B207	W/32	: NAVI control unit
B208	W/40	: NAVI control unit
B209	GY/1	: NAVI control unit
B210	-	: Body ground
B211	W/16	: Satellite radio tuner (With satellite radio)

Without big size luggage floor
under box

With big size luggage floor
under box



Body ground



View with rear side garnishes RH removed

Passenger side view with floor garnishes removed

B212	GY/8	: BOSE speaker amp.
B213	B/24	: BOSE speaker amp.
*	GY/6	: To B84
B217	W/4	: To B85
B218	BR/2	: Tweeter RH
B219	W/4	: Rear combination lamp RH
B220	W/4	: Fuel lid lock actuator
*	B12	: EVAP canister vent control valve
B222	GY/3	: EVAP control system pressure sensor
B223	B/8	: Woofer
B224	W/12	: Option connector-2 for satellite radio tuner (Without satellite radio)


For detail ground distribution information,
refer to "GROUND DISTRIBUTION".

TKIM0636E

HARNESS

< SERVICE INFORMATION >

ROOM LAMP HARNESS



TKIM0637E


FRONT DOOR HARNESS

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z PG

HARNESS


< SERVICE INFORMATION >

LH Side



TKIM0638E

RH Side




TKIM0639E

REAR DOOR HARNESS


HARNESS

< SERVICE INFORMATION >

LH Side



RH Side



A
B
C
D
E
F
G
H
I
J

PG


L
M
N
O
P

HARNESS

< SERVICE INFORMATION >

BACK DOOR HARNESS

W/16	W/6	To (B51)
W/16	W/6	To (B52)
GY/2		High-mounted stop lamp
GY/1		Rear window defogger (+)
W/2		Back-up lamp LH
W/10		Back door closure control unit
		Rear wiper motor
		Rear view camera
		Back door closure motor
		License plate lamp LH
		License plate lamp RH
		Back door opener switch
		Back door request switch
		Rear window defogger (-)
		Back-up lamp RH
		Outside key antenna-3 (Back door)



TKIH0016E

Wiring Diagram Codes (Cell Codes)

INFOID:0000000001328883

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

HARNESS

< SERVICE INFORMATION >

Code	Section	Wiring Diagram Name	
A/C	ATC	Air Conditioner	A
AF1B1	EC	Air Fuel Ratio Sensor 1 Bank 1	B
AF1B2	EC	Air Fuel Ratio Sensor 1 Bank 2	C
AF1HB1	EC	Air Fuel Ratio Sensor 1 Heater Bank 1	D
AF1HB2	EC	Air Fuel Ratio Sensor 1 Heater Bank 2	E
APPS1	EC	Accelerator Pedal Position Sensor	F
APPS2	EC	Accelerator Pedal Position Sensor	G
APPS3	EC	Accelerator Pedal Position Sensor	H
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch	I
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch	J
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch	K
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator	L
AT/IND	DI	A/T Indicator Lamp	M
AUDIO	AV	Audio	N
AUT/DP	SE	Automatic Drive Positioner	O
AUTO/L	LT	Automatic Light System	P
AWD	TF	AWD Control System	
B/CLOS	BL	Back Door Closure System	
BACK/L	LT	Back-Up Lamp	
BRK/SW	EC	Brake Switch	
CAN	AT	CAN Communication Line	
CAN	EC	CAN Communication Line	
CAN	LAN	CAN System	
CHARGE	SC	Charging System	
CHIME	DI	Warning Chime	
CLOCK	DI	Clock	
COMBSW	LT	Combination Switch	
COMM	AV	Audio Visual Communication Line	
COMPAS	DI	Compass	
COOL/F	EC	Cooling Fan Control	
D/LOCK	BL	Power Door Lock	
DEF	GW	Rear Window Defogger	
DTRL	LT	Headlamp - With Daytime Light System	
ECM/PW	EC	ECM Power Supply for Back-Up	
ECTS	EC	Engine Coolant Temperature Sensor	
ETC1	EC	Electric Throttle Control Function	
ETC2	EC	Electric Throttle Control Motor Relay	
ETC3	EC	Electric Throttle Control Motor	
F/FOG	LT	Front Fog Lamp	
F/PUMP	EC	Fuel Pump	
FTS	AT	A/T Fluid Temperature Sensor Circuit	
FTTS	EC	Fuel Tank Temperature Sensor	
FUELB1	EC	Fuel Injection System Function (Bank 1)	
FUELB2	EC	Fuel Injection System Function (Bank 2)	

A

B

C

D

E

F

G

H

I

J

PG

L

M

N

O

P

HARNESS

< SERVICE INFORMATION >

Code	Section	Wiring Diagram Name
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
H/PHON	AV	Hands Free Telephone
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/KEY	BL	Intelligent Key System
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
IATS	EC	Intake Air Temperature Sensor
ICC	ACS	Intelligent Cruise Control System
ICC/BS	EC	ICC Brake Switch
ICC/SW	EC	ICC Steering Switch
ICCBOF	EC	ICC Brake Switch
IGNSYS	EC	Ignition System
ILL	LT	Illumination
INF/D	AV	Vehicle Information and Integrated Switch System
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
IVCSB1	EC	Intake Valve Timing Control Position Sensor Bank 1
IVCSB2	EC	Intake Valve Timing Control Position Sensor Bank 2
IVTB1	EC	Intake Valve Timing Control System (Bank 1)
IVTB2	EC	Intake Valve Timing Control System (Bank 2)
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
LDW	DI	Lane Departure Warning System
M/ANT	AV	Manual Antenna
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
MES	AV	Mobile Entertainment System
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL & Data Link Connector
MIRROR	GW	Power Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
NONDTC	AT	Non-Detective Items
O2H2B1	EC	Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Heated Oxygen Sensor 2 Heater Bank 2
O2S2B1	EC	Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Heated Oxygen Sensor 2 Bank 2
P/SCKT	WW	Power Socket
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)

HARNESS

< SERVICE INFORMATION >

Code	Section	Wiring Diagram Name
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank 2)
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
R/VIEW	DI	Rear View Camera Control System
ROOM/L	LT	Interior Room Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SNOWSW	EC	Snow Mode Switch
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal Circuit
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	Homelink Universal Transceiver
TURN	LT	Turn Signal and Hazard Warning Lamp
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System
VENT/V	EC	EVAP Canister Vent Control Valve
VIAS	EC	Variable Induction Air Control System
VIAS/V	EC	VIAS Control Solenoid Valve
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer
WIPER	WW	Front Wiper and Washer

A

B

C

D

E

F

G

H

I

J

PG

L

M

N

O

P

ELECTRICAL UNITS LOCATION


< SERVICE INFORMATION >

ELECTRICAL UNITS LOCATION

Electrical Units Location


INFOID:0000000001328884

ENGINE COMPARTMENT



FUSE, FUSIBLE LINK AND RELAY BOX


RELAY BOX-2




CKIM0646E

ELECTRICAL UNITS LOCATION


< SERVICE INFORMATION >
PASSENGER COMPARTMENT



A Behind dash side lower finisher LH



Fuse block (J/B) rear view



CKIM0647E

PG

L

M

N


O

P

ELECTRICAL UNITS LOCATION


< SERVICE INFORMATION >

B Driver side view with lower instrument panel removed




Intelligent Key unit (M34)

C Driver side view with cluster lid A removed



Steering lock unit (M26)


D Under driver seat



Front
↑


Driver seat control unit (B152, B153)

E View with cluster lid C removed




Unified meter and A/C amp.
(M55, M56, M57)

F View with instrument panel center removed



Rear view camera control unit (M48)

G Behind lower instrument panel on passenger side




TEL adapter unit (M102)

Display control unit (M75, M76)

Blower motor

H Behind lower instrument panel on passenger side


ICC unit (M88, M89)



AWD control unit (M92)


J View with floor console box removed

Yaw rate/side/decel G sensor(AWD models)
(M71)
Yaw rate/side G sensor(2WD models)
(M79)




Air bag diagnosis sensor unit
(M72, B17, B18)

K View with passenger seat removed



NAVI control unit
(B207, B208, B209)

L Map lamp garnish removed




LDW camera unit (R9)

CKIM0648E

ELECTRICAL UNITS LOCATION

< SERVICE INFORMATION >

LUGGAGE COMPARTMENT



A
B
C
D
E
F
G
H
I
J

PG

L
M
N

O
P

CKIM0649E

HARNESS CONNECTOR

< SERVICE INFORMATION >

HARNESS CONNECTOR

Description

INFOID:0000000001328885


HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

CAUTION:

Never pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.


CAUTION:

HARNESS CONNECTOR

< SERVICE INFORMATION >


- Never pull the harness or wires when disconnecting the connector.
 - Be careful not to damage the connector support bracket when disconnecting the connector.
- [Example]

Waterproof type



- ① Firmly grasp shell of connector housing at A.
- ② Push slider until connector pops or snaps apart.
- ③ Disconnect harness connector.

Non-waterproof type



- ① Firmly grasp shell of connector housing at A.
- ② Pull back on the slider while pulling apart male and female halves of connector.
- ③ Disconnect harness connector.

SEL769V

HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:

A
B
C
D
E
F
G
H
I
J


PG

L
M
N
O
P

HARNESS CONNECTOR

< SERVICE INFORMATION >

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.



LKIA0670E

1. Control unit with single lever
 - A. Fasten
 - B. Loosen
 - C. Lever
2. Control unit with dual levers
 - A. Levers
 - B. Fasten
 - C. Loosen
3. SMJ connector
 - A. Lever
 - B. Fasten
 - C. Loosen


ELECTRICAL UNITS

< SERVICE INFORMATION >



ELECTRICAL UNITS

Terminal Arrangement


INFOID:0000000001328886




ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



UNIFIED METER AND A/C AMP.



BCM (BODY CONTROL MODULE)



A

B

C

D

E

F

G

H

I

J

PG

L

M

N


O

P


ELECTRICAL UNITS

< SERVICE INFORMATION >

INTELLIGENT KEY UNIT



ICC UNIT



CKIM0218E


SMJ (SUPER MULTIPLE JUNCTION)

< SERVICE INFORMATION >

SMJ (SUPER MULTIPLE JUNCTION)


Terminal Arrangement

INFOID:0000000001328887



SMJ (SUPER MULTIPLE JUNCTION)

< SERVICE INFORMATION >



CKIM0220E

STANDARDIZED RELAY

< SERVICE INFORMATION >


STANDARDIZED RELAY

Description

INFOID:0000000001328888

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make

1T 1 Transfer

1M·1B 1 Make 1 Break



SEL882H

A

B

C

D

E

F

G

H

I

J

PG

L

M















N

O

P

STANDARDIZED RELAY

< SERVICE INFORMATION >

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

CKIM0221E


FUSE BLOCK - JUNCTION BOX (J/B)

< SERVICE INFORMATION >

FUSE BLOCK - JUNCTION BOX (J/B)

Terminal Arrangement

INFOID:0000000001328889



CKIM0652E



FUSE, FUSIBLE LINK AND RELAY BOX

< SERVICE INFORMATION >

FUSE, FUSIBLE LINK AND RELAY BOX

Terminal Arrangement

INFOID:0000000001328890



CKIM0223E