

SECTION **EC**

CI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CONTENTS

TROUBLE DIAGNOSIS — INDEX2	Two Trip Detection Logic.....44
Alphabetical & P No. Index for DTC2	Emission-related Diagnostic Information.....45
PRECAUTIONS7	Malfunction Indicator Lamp (MIL).....55
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....7	OBD System Operation Chart.....59
Precautions for On Board Diagnostic (OBD) System of Engine and A/T.....7	CONSULT64
Engine Fuel & Emission Control System8	Generic Scan Tool (GST)77
Precautions9	TROUBLE DIAGNOSIS — INTRODUCTION79
Wiring Diagrams and Trouble Diagnosis.....10	Introduction79
PREPARATION11	Work Flow81
Special Service Tools11	TROUBLE DIAGNOSIS — BASIC INSPECTION83
Commercial Service Tools.....11	Basic Inspection.....83
ENGINE AND EMISSION CONTROL OVERALL SYSTEM13	TROUBLE DIAGNOSIS — GENERAL DESCRIPTION90
Engine Control Component Parts Location.....13	DTC Inspection Priority Chart.....90
Circuit Diagram18	Fail-safe Chart91
System Diagram20	Symptom Matrix Chart.....92
Vacuum Hose Drawing21	CONSULT Reference Value in Data Monitor Mode96
System Chart.....22	Major Sensor Reference Graph in Data Monitor Mode98
ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION23	ECM Terminals and Reference Value101
Multiport Fuel Injection (MFI) System23	TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT110
Distributor Ignition (DI) System25	Description110
Air Conditioning Cut Control.....26	Diagnostic Procedure110
Fuel Cut Control (at no load & high engine speed).....27	TROUBLE DIAGNOSIS FOR POWER SUPPLY111
Evaporative Emission System27	Main Power Supply and Ground Circuit.....111
Positive Crankcase Ventilation33	DTC P0100 MASS AIR FLOW SENSOR (MAFS)116
BASIC SERVICE PROCEDURE34	Component Description116
Fuel Pressure Release34	CONSULT Reference Value in Data Monitor Mode116
Fuel Pressure Check34	ECM Terminals and Reference Value116
Fuel Pressure Regulator Check35	On Board Diagnosis Logic.....117
Injector35	DTC Confirmation Procedure117
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment.....36	Overall Function Check120
ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION44	Wiring Diagram121
Introduction44	Diagnostic Procedure122
	Component Inspection.....124
	DTC P0105 ABSOLUTE PRESSURE SENSOR125

CONTENTS (Cont'd)

Component Description	125	DTC Confirmation Procedure	162
On Board Diagnosis Logic.....	125	Overall Function Check	163
DTC Confirmation Procedure	125	Wiring Diagram	164
Overall Function Check	127	Diagnostic Procedure	165
Wiring Diagram	128	Component Inspection.....	166
Diagnostic Procedure	129	DTC P0131 FRONT HEATED OXYGEN SENSOR	
Component Inspection.....	133	(FRONT HO2S) (LEAN SHIFT MONITORING)	167
DTC P0110 INTAKE AIR TEMPERATURE		Component Description	167
SENSOR	134	CONSULT Reference Value in Data Monitor	
Component Description	134	Mode	167
On Board Diagnosis Logic.....	134	ECM Terminals and Reference Value	167
DTC Confirmation Procedure	134	On Board Diagnosis Logic.....	168
Wiring Diagram	137	DTC Confirmation Procedure	168
Diagnostic Procedure	138	Overall Function Check	169
Component Inspection.....	139	Diagnostic Procedure	169
DTC P0115 ENGINE COOLANT TEMPERATURE		Component Inspection.....	171
SENSOR (ECTS) (CIRCUIT)	140	DTC P0132 FRONT HEATED OXYGEN SENSOR	
Component Description	140	(FRONT HO2S) (RICH SHIFT MONITORING)	172
CONSULT Reference Value in Data Monitor		Component Description	172
Mode	140	CONSULT Reference Value in Data Monitor	
On Board Diagnosis Logic.....	140	Mode	172
DTC Confirmation Procedure	141	ECM Terminals and Reference Value	172
Wiring Diagram	142	On Board Diagnosis Logic.....	173
Diagnostic Procedure	143	DTC Confirmation Procedure	173
Component Inspection.....	144	Overall Function Check	174
DTC P0120 THROTTLE POSITION SENSOR	145	Diagnostic Procedure	174
Component Description	145	Component Inspection.....	176
CONSULT Reference Value in Data Monitor		DTC P0133 FRONT HEATED OXYGEN SENSOR	
Mode	145	(FRONT HO2S) (RESPONSE MONITORING)	177
ECM Terminals and Reference Value	145	Component Description	177
On Board Diagnosis Logic.....	146	CONSULT Reference Value in Data Monitor	
DTC Confirmation Procedure	146	Mode	177
Wiring Diagram	152	ECM Terminals and Reference Value	177
Diagnostic Procedure	153	On Board Diagnosis Logic.....	178
Component Inspection.....	155	DTC Confirmation Procedure	178
DTC P0125 ENGINE COOLANT TEMPERATURE		Overall Function Check	179
(ECT) SENSOR	156	Wiring Diagram	180
Component Description	156	Diagnostic Procedure	181
CONSULT Reference Value in Data Monitor		Component Inspection.....	183
Mode	156	DTC P0134 FRONT HEATED OXYGEN SENSOR	
On Board Diagnosis Logic.....	156	(FRONT HO2S) (HIGH VOLTAGE)	184
DTC Confirmation Procedure	156	Component Description	184
Wiring Diagram	158	CONSULT Reference Value in Data Monitor	
Diagnostic Procedure	159	Mode	184
Component Inspection.....	160	ECM Terminals and Reference Value	184
DTC P0130 FRONT HEATED OXYGEN SENSOR		On Board Diagnosis Logic.....	185
(FRONT HO2S) (CIRCUIT)	161	DTC Confirmation Procedure	185
Component Description	161	Wiring Diagram	187
CONSULT Reference Value in Data Monitor		Diagnostic Procedure	188
Mode	161	Component Inspection.....	189
ECM Terminals and Reference Value	161	DTC P0135 FRONT HEATED OXYGEN SENSOR	
On Board Diagnosis Logic.....	162	HEATER	190

CONTENTS (Cont'd)

Description.....	190	DTC Confirmation Procedure.....	219	CI
CONSULT Reference Value in Data Monitor		Overall Function Check.....	219	
Mode.....	190	Wiring Diagram.....	220	MA
ECM Terminals and Reference Value.....	190	Diagnostic Procedure.....	221	
On Board Diagnosis Logic.....	190	Component Inspection.....	222	
DTC Confirmation Procedure.....	191	DTC P0141 REAR HEATED OXYGEN SENSOR		EM
Wiring Diagram.....	192	HEATER.....	224	
Diagnostic Procedure.....	193	Description.....	224	
Component Inspection.....	193	CONSULT Reference Value in Data Monitor		LC
DTC P0137 REAR HEATED OXYGEN SENSOR		Mode.....	224	
(REAR HO2S) (MIN. VOLTAGE MONITORING).....	195	ECM Terminals and Reference Value.....	224	EC
Component Description.....	195	On Board Diagnosis Logic.....	224	
CONSULT Reference Value in Data Monitor		DTC Confirmation Procedure.....	225	
Mode.....	195	Wiring Diagram.....	226	FE
ECM Terminals and Reference Value.....	195	Diagnostic Procedure.....	227	
On Board Diagnosis Logic.....	195	Component Inspection.....	228	
DTC Confirmation Procedure.....	196	DTC P0171 FUEL INJECTION SYSTEM		CL
Overall Function Check.....	197	FUNCTION (LEAN SIDE).....	229	
Wiring Diagram.....	198	On Board Diagnosis Logic.....	229	
Diagnostic Procedure.....	199	DTC Confirmation Procedure.....	229	MT
Component Inspection.....	201	Wiring Diagram.....	231	
DTC P0138 REAR HEATED OXYGEN SENSOR		Diagnostic Procedure.....	232	AT
(REAR HO2S) (MAX. VOLTAGE MONITORING).....	203	DTC P0172 FUEL INJECTION SYSTEM		
Component Description.....	203	FUNCTION (RICH SIDE).....	235	
CONSULT Reference Value in Data Monitor		On Board Diagnosis Logic.....	235	AX
Mode.....	203	DTC Confirmation Procedure.....	235	
ECM Terminals and Reference Value.....	203	Wiring Diagram.....	237	
On Board Diagnosis Logic.....	203	Diagnostic Procedure.....	238	SU
DTC Confirmation Procedure.....	204	DTC P0180 TANK FUEL TEMPERATURE		
Overall Function Check.....	205	SENSOR.....	241	
Wiring Diagram.....	206	Component Description.....	241	BR
Diagnostic Procedure.....	207	On Board Diagnosis Logic.....	241	
Component Inspection.....	209	DTC Confirmation Procedure.....	241	ST
DTC P0139 REAR HEATED OXYGEN SENSOR		Wiring Diagram.....	243	
(REAR HO2S) (RESPONSE MONITORING).....	210	Diagnostic Procedure.....	244	
Component Description.....	210	Component Inspection.....	244	RS
CONSULT Reference Value in Data Monitor		DTC P0300 - P0304 NO. 4 - 1 CYLINDER		
Mode.....	210	MISFIRE, MULTIPLE CYLINDER MISFIRE.....	245	
ECM Terminals and Reference Value.....	210	On Board Diagnosis Logic.....	245	BT
On Board Diagnosis Logic.....	210	DTC Confirmation Procedure.....	245	
DTC Confirmation Procedure.....	211	Diagnostic Procedure.....	246	HA
Overall Function Check.....	212	Component Inspection.....	249	
Wiring Diagram.....	213	DTC P0325 KNOCK SENSOR (KS).....	250	
Diagnostic Procedure.....	214	Component Description.....	250	SC
Component Inspection.....	216	ECM Terminals and Reference Value.....	250	
DTC P0140 REAR HEATED OXYGEN SENSOR		On Board Diagnosis Logic.....	250	
(REAR HO2S) (HIGH VOLTAGE).....	218	DTC Confirmation Procedure.....	250	EL
Component Description.....	218	Wiring Diagram.....	252	
CONSULT Reference Value in Data Monitor		Diagnostic Procedure.....	253	
Mode.....	218	Component Inspection.....	254	IDX
ECM Terminals and Reference Value.....	218	DTC P0335 CRANKSHAFT POSITION SENSOR		
On Board Diagnosis Logic.....	218	(CKPS) (OBD).....	255	

CONTENTS (Cont'd)

Component Description	255	Diagnostic Procedure	294
ECM Terminals and Reference Value	255	Component Inspection.....	295
On Board Diagnosis Logic.....	255	DTC P0446 EVAPORATIVE EMISSION (EVAP)	
DTC Confirmation Procedure	256	CANISTER VENT CONTROL VALVE (CIRCUIT)	296
Wiring Diagram	257	Component Description	296
Diagnostic Procedure	258	CONSULT Reference Value in Data Monitor	
Component Inspection.....	259	Mode	296
DTC P0340 CAMSHAFT POSITION SENSOR		ECM Terminals and Reference Value	296
(CMPS)	260	On Board Diagnosis Logic.....	296
Component Description	260	DTC Confirmation Procedure	297
ECM Terminals and Reference Value	260	Wiring Diagram	298
On Board Diagnosis Logic.....	261	Diagnostic Procedure	299
DTC Confirmation Procedure	261	Component Inspection	300
Wiring Diagram.....	263	DTC P0450 EVAPORATIVE EMISSION (EVAP)	
Diagnostic Procedure	264	CONTROL SYSTEM PRESSURE SENSOR	302
Component Inspection.....	266	Component Description	302
DTC P0400 EGR FUNCTION (CLOSE)	267	CONSULT Reference Value in Data Monitor	
Description	267	Mode	302
On Board Diagnosis Logic.....	268	ECM Terminals and Reference Value	302
DTC Confirmation Procedure	269	On Board Diagnosis Logic.....	303
Overall Function Check	270	DTC Confirmation Procedure	303
Wiring Diagram	271	Wiring Diagram	305
Diagnostic Procedure	272	Diagnostic Procedure	306
Component Inspection.....	274	Component Inspection.....	308
DTC P0402 EGRC-BPT VALVE FUNCTION	275	DTC P0500 VEHICLE SPEED SENSOR (VSS)	310
Description	275	Component Description	310
On Board Diagnosis Logic.....	275	ECM Terminals and Reference Value	310
DTC Confirmation Procedure	276	On Board Diagnosis Logic.....	310
Overall Function Check	277	DTC Confirmation Procedure	310
Diagnostic Procedure	277	Overall Function Check	312
Component Inspection.....	278	Wiring Diagram.....	313
DTC P0420 THREE WAY CATALYST FUNCTION	279	Diagnostic Procedure	314
On Board Diagnosis Logic.....	279	DTC P0505 IDLE AIR CONTROL VALVE (IACV)	
DTC Confirmation Procedure	279	— AUXILIARY AIR CONTROL (AAC) VALVE	315
Overall Function Check	280	Description	315
Diagnostic Procedure	281	CONSULT Reference Value in Data Monitor	
DTC P0440 EVAPORATIVE EMISSION (EVAP)		Mode	315
CONTROL SYSTEM (SMALL LEAK) (NEGATIVE		ECM Terminals and Reference Value	316
PRESSURE)	283	On Board Diagnosis Logic.....	316
On Board Diagnosis Logic.....	283	DTC Confirmation Procedure	316
DTC Confirmation Procedure	284	Wiring Diagram	318
Diagnostic Procedure	286	Diagnostic Procedure	319
DTC P0443 EVAPORATIVE EMISSION (EVAP)		Component Inspection.....	319
CANISTER PURGE VOLUME CONTROL VALVE		DTC P0510 CLOSED THROTTLE POSITION	
(CIRCUIT)	291	SWITCH	320
Description	291	Component Description	320
CONSULT Reference Value in Data Monitor		ECM Terminals and Reference Value	320
Mode	291	On Board Diagnosis Logic.....	320
ECM Terminals and Reference Value	292	DTC Confirmation Procedure	320
On Board Diagnosis Logic.....	292	Overall Function Check	321
DTC Confirmation Procedure	292	Wiring Diagram	322
Wiring Diagram	293	Diagnostic Procedure	323

CONTENTS (Cont'd)

Component Inspection.....	324	CONSULT Reference Value in Data Monitor	GI
DTC P0600 A/T CONTROL	325	Mode.....	355
System Description.....	325	ECM Terminals and Reference Value.....	355
ECM Terminals and Reference Value.....	325	On Board Diagnosis Logic.....	355
On Board Diagnosis Logic.....	325	DTC Confirmation Procedure.....	355
DTC Confirmation Procedure.....	325	Wiring Diagram.....	357
Overall Function Check.....	326	Diagnostic Procedure.....	358
Wiring Diagram.....	327	Component Inspection.....	359
Diagnostic Procedure.....	328	DTC P1401 EGR TEMPERATURE SENSOR	360
DTC P0605 ECM	329	Component Description.....	360
Component Description.....	329	On Board Diagnosis Logic.....	360
On Board Diagnosis Logic.....	329	DTC Confirmation Procedure.....	361
DTC Confirmation Procedure.....	329	Overall Function Check.....	362
Diagnostic Procedure.....	330	Wiring Diagram.....	363
DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE	331	Diagnostic Procedure.....	364
Description.....	331	Component Inspection.....	365
CONSULT Reference Value in Data Monitor		DTC P1402 EGR FUNCTION (OPEN)	366
Mode.....	331	Description.....	366
ECM Terminals and Reference Value.....	332	On Board Diagnosis Logic.....	367
On Board Diagnosis Logic.....	332	DTC Confirmation Procedure.....	367
DTC Confirmation Procedure.....	332	Wiring Diagram.....	369
Wiring Diagram.....	335	Diagnostic Procedure.....	370
Diagnostic Procedure.....	336	Component Inspection.....	371
Component Inspection.....	340	DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)	372
DTC P1148 CLOSED LOOP CONTROL	341	On Board Diagnosis Logic.....	372
On Board Diagnosis Logic.....	341	DTC Confirmation Procedure.....	373
DTC Confirmation Procedure.....	341	Diagnostic Procedure.....	374
Overall Function Check.....	342	DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE	380
Diagnostic Procedure.....	342	Description.....	380
DTC P1320 IGNITION SIGNAL	343	CONSULT Reference Value in Data Monitor	
Component Description.....	343	Mode.....	380
CONSULT Reference Value in Data Monitor		ECM Terminals and Reference Value.....	381
Mode.....	343	On Board Diagnosis Logic.....	381
ECM Terminals and Reference Value.....	343	DTC Confirmation Procedure.....	381
On Board Diagnosis Logic.....	344	Diagnostic Procedure.....	384
DTC Confirmation Procedure.....	344	Component Inspection.....	385
Wiring Diagram.....	346	DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)	386
Diagnostic Procedure.....	347	Component Description.....	386
Component Inspection.....	348	CONSULT Reference Value in Data Monitor	
DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)	350	Mode.....	386
Component Description.....	350	ECM Terminals and Reference Value.....	386
ECM Terminals and Reference Value.....	350	On Board Diagnosis Logic.....	386
On Board Diagnosis Logic.....	350	DTC Confirmation Procedure.....	387
DTC Confirmation Procedure.....	351	Diagnostic Procedure.....	388
Wiring Diagram.....	352	Component Inspection.....	389
Diagnostic Procedure.....	353	DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING	390
Component Inspection.....	354		
DTC P1400 EGRC-SOLENOID VALVE	355		
Component Description.....	355		

CONTENTS (Cont'd)

System Description.....	390	DTC P1493 EVAPORATIVE EMISSION (EVAP)	
On Board Diagnosis Logic.....	390	CANISTER PURGE CONTROL	
DTC Confirmation Procedure.....	391	VALVE/SOLENOID VALVE.....	420
Overall Function Check.....	392	Description.....	420
Diagnostic Procedure.....	393	CONSULT Reference Value in Data Monitor	
Component Inspection.....	396	Mode.....	421
DTC P1448 EVAPORATIVE EMISSION (EVAP)		ECM Terminals and Reference Value.....	421
CANISTER VENT CONTROL VALVE (OPEN).....	397	On Board Diagnosis Logic.....	422
Component Description.....	397	DTC Confirmation Procedure.....	422
CONSULT Reference Value in Data Monitor		Diagnostic Procedure.....	424
Mode.....	397	Component Inspection.....	427
ECM Terminals and Reference Value.....	397	DTC P1605 A/T DIAGNOSIS COMMUNICATION	
On Board Diagnosis Logic.....	397	LINE.....	428
DTC Confirmation Procedure.....	398	System Description.....	428
Overall Function Check.....	399	ECM Terminals and Reference Value.....	428
Diagnostic Procedure.....	399	On Board Diagnosis Logic.....	428
Component Inspection.....	401	DTC Confirmation Procedure.....	428
DTC P1490 VACUUM CUT VALVE BYPASS		Wiring Diagram.....	429
VALVE (CIRCUIT).....	402	Diagnostic Procedure.....	430
Description.....	402	DTC P1706 PARK/NEUTRAL POSITION (PNP)	
CONSULT Reference Value in Data Monitor		SWITCH.....	431
Mode.....	402	Component Description.....	431
ECM Terminals and Reference Value.....	402	CONSULT Reference Value in Data Monitor	
On Board Diagnosis Logic.....	403	Mode.....	431
DTC Confirmation Procedure.....	403	ECM Terminals and Reference Value.....	431
Wiring Diagram.....	404	On Board Diagnosis Logic.....	431
Diagnostic Procedure.....	405	DTC Confirmation Procedure.....	431
Component Inspection.....	406	Overall Function Check.....	432
DTC P1491 VACUUM CUT VALVE BYPASS		Wiring Diagram.....	433
VALVE.....	407	Diagnostic Procedure For M/T Models.....	434
Description.....	407	Diagnostic Procedure For A/T Models.....	435
CONSULT Reference Value in Data Monitor		TROUBLE DIAGNOSIS FOR OVERHEAT	
Mode.....	407	(COOLING SYSTEM).....	436
ECM Terminals and Reference Value.....	407	System Description.....	436
On Board Diagnosis Logic.....	408	CONSULT Reference Value in Data Monitor	
DTC Confirmation Procedure.....	408	Mode.....	436
Overall Function Check.....	410	ECM Terminals and Reference Value.....	437
Diagnostic Procedure.....	410	On Board Diagnosis Logic.....	437
Component Inspection.....	413	Overall Function Check.....	438
DTC P1492 EVAPORATIVE EMISSION (EVAP)		Wiring Diagram.....	439
CANISTER PURGE CONTROL		Diagnostic Procedure.....	440
VALVE/SOLENOID VALVE (CIRCUIT).....	414	Main 12 Causes of Overheating.....	448
Description.....	414	Component Inspection.....	449
CONSULT Reference Value in Data Monitor		INJECTOR.....	450
Mode.....	415	Component Description.....	450
ECM Terminals and Reference Value.....	415	CONSULT Reference Value in Data Monitor	
On Board Diagnosis Logic.....	415	Mode.....	450
DTC Confirmation Procedure.....	416	ECM Terminals and Reference Value.....	450
Wiring Diagram.....	417	Wiring Diagram.....	451
Diagnostic Procedure.....	418	Diagnostic Procedure.....	452
Component Inspection.....	419	Component Inspection.....	453
		START SIGNAL.....	454

CONTENTS (Cont'd)

CONSULT Reference Value in Data Monitor		
Mode	454	
ECM Terminals and Reference Value	454	
Wiring Diagram	455	
Diagnostic Procedure	456	
FUEL PUMP	457	
System Description	457	
Component Description	457	
CONSULT Reference Value in Data Monitor		
Mode	457	
ECM Terminals and Reference Value	457	
Wiring Diagram	458	
Diagnostic Procedure	459	
Component Inspection	460	
POWER STEERING OIL PRESSURE SWITCH	461	
Component Description	461	
CONSULT Reference Value in Data Monitor		
Mode	461	
ECM Terminals and Reference Value	461	
Wiring Diagram	462	
Diagnostic Procedure	463	
Component Inspection	464	
IACV-AIR REGULATOR	465	
Description	465	
ECM Terminals and Reference Value	465	
Wiring Diagram	466	
Diagnostic Procedure	467	
Component Inspection	468	
IACV-FICD SOLENOID VALVE	469	GI
Component Description	469	
ECM Terminals and Reference Value	469	
Wiring Diagram	470	MA
Diagnostic Procedure	471	
Component Inspection	474	EM
MIL & DATA LINK CONNECTORS	475	
Wiring Diagram	475	
SERVICE DATA AND SPECIFICATIONS (SDS)	476	LC
Fuel Pressure Regulator	476	
Idle Speed and Ignition Timing	476	EC
Ignition Coil	476	
Mass Air Flow Sensor	476	FE
Engine Coolant Temperature Sensor	476	
EGR Temperature Sensor	476	
Fuel Pump	476	
IACV-AAC Valve	477	GL
Injector	477	
Resistor	477	
Throttle Position Sensor	477	INT
Front Heated Oxygen Sensor Heater	477	
Calculated Load Value	477	AT
Intake Air Temperature Sensor	477	
EVAP Canister Purge Volume Control Valve	477	AX
Rear Heated Oxygen Sensor Heater	477	
Crankshaft Position Sensor (OBD)	477	
Tank Fuel Temperature Sensor	477	SU
		SR
		ST
		RS
		BT
		HA
		SC
		EL
		IDX

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC

Alphabetical & P No. Index for DTC

NCEC0001

ALPHABETICAL INDEX FOR DTC

NCEC0001S01

Items (CONSULT screen terms)	DTC*6		Reference page
	CONSULT GST*2	ECM*1	
Unable to access ECM	—	—	EC-91
*COOLAN T SEN/CIRC	P0125	0908	EC-156
A/T 1ST GR FNCTN	P0731	1103	AT-112
A/T 2ND GR FNCTN	P0732	1104	AT-118
A/T 3RD GR FNCTN	P0733	1105	AT-124
A/T 4TH GR FNCTN	P0734	1106	AT-130
A/T COMM LINE	P0600	—	EC-325
A/T DIAG COMM LINE	P1605	0804	EC-428
A/T TCC S/V FNCTN	P0744	1107	AT-144
ABSL PRES SEN/CIRC	P0105	0803	EC-125
AIR TEMP SEN/CIRC	P0110	0401	EC-134
ATF TEMP SEN/CIRC	P0710	1208	AT-97
CAM POS SEN/CIRC	P0340	0101	EC-260
CLOSED LOOP	P1148	0307	EC-341
CLOSED TP SW/CIRC	P0510	0203	EC-320
COOLANT T SEN/CIRC	P0115	0103	EC-140
CPS/CIRC (OBD) COG	P1336	0905	EC-350
CPS/CIRCUIT (OBD)	P0335	0802	EC-255
CYL 1 MISFIRE	P0301	0608	EC-245
CYL 2 MISFIRE	P0302	0607	EC-245
CYL 3 MISFIRE	P0303	0606	EC-245
CYL 4 MISFIRE	P0304	0605	EC-245
ECM	P0605	0301	EC-329
EGR SYSTEM	P0400	0302	EC-267
EGR SYSTEM	P1402	0514	EC-366
EGR TEMP SEN/CIRC	P1401	0305	EC-360
EGRC SOLENOID/V	P1400	1005	EC-355
EGRC-BPT VALVE	P0402	0306	EC-275
ENGINE SPEED SIG	P0725	1207	AT-108
EVAP PURG FLOW/MON	P1447	0111	EC-390
EVAP SMALL LEAK	P0440	0705	EC-283
EVAP SMALL LEAK	P1440	0213	EC-372
EVAPO SYS PRES SEN	P0450	0704	EC-302
FR O2 SEN HEATER	P0135	0901	EC-190

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

Items (CONSULT screen terms)	DTC*6		Reference page	
	CONSULT GST*2	ECM*1		
FRONT O2 SENSOR	P0130	0303	EC-161	GI
FRONT O2 SENSOR	P0131	0411	EC-167	MA
FRONT O2 SENSOR	P0132	0410	EC-172	EM
FRONT O2 SENSOR	P0133	0409	EC-177	
FRONT O2 SENSOR	P0134	0412	EC-184	LC
FUEL SYS DIAG-LEAN	P0171	0115	EC-229	
FUEL SYS DIAG-RICH	P0172	0114	EC-235	EC
FUEL TEMP SEN/CIRC	P0180	0402	EC-241	
IACV/AAC VLV/CIRC	P0505	0205	EC-315	FE
IGN SIGNAL-PRIMARY	P1320	0201	EC-343	
KNOCK SEN/CIRCUIT	P0325	0304	EC-250	CL
L/PRESS SOL/CIRC	P0745	1205	AT-152	
MAF SEN/CIRCUIT*3	P0100	0102	EC-116	MT
MAP/BARO SW SOL/CIR	P1105	1302	EC-331	AT
MULTI CYL MISFIRE	P0300	0701	EC-245	
NO SELF DIAGNOSTIC FAILURE INDICATED	P0000	0505	—	AX
NO SELF DIAGNOSTIC FAILURE INDICATED	No DTC	Flashing*5	EC-56	
O/R CLTCH SOL/CIRC	P1760	1203	AT-176	SU
OVER HEAT	—	0208	EC-436	
P-N POS SW/CIRCUIT	P1706	1003	EC-431	BR
PNP SW/CIRC	P0705	1101	AT-92	
PURG CONT/V & S/V	P1493	0312	EC-420	ST
PURG CONT/V S/V	P1492	0807	EC-414	
PURG VOLUME CONT/V	P0443	1008	EC-291	RS
PURG VOLUME CONT/V	P1444	0214	EC-380	
REAR O2 SENSOR	P0137	0511	EC-195	BT
REAR O2 SENSOR	P0138	0510	EC-203	
REAR O2 SENSOR	P0139	0707	EC-210	HA
REAR O2 SENSOR	P0140	0512	EC-218	
RR O2 SEN HEATER	P0141	0902	EC-224	SC
SFT SOL A/CIRC*3	P0750	1108	AT-158	
SFT SOL B/CIRC*3	P0755	1201	AT-163	EL
TCC SOLENOID/CIRC	P0740	1204	AT-139	
THRTL POS SEN/CIRC*3	P0120	0403	EC-145	IDX
TP SEN/CIRC A/T*3	P1705	1206	AT-168	
TW CATALYST SYSTEM	P0420	0702	EC-279	

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

Items (CONSULT screen terms)	DTC*6		Reference page
	CONSULT GST*2	ECM*1	
VC CUT/V BYPASS/V	P1491	0311	EC-407
VC/V BYPASS/V	P1490	0801	EC-402
VEH SPD SEN/CIR AT*4	P0720	1102	AT-103
VEH SPEED SEN/CIRC*4	P0500	0104	EC-310
VENT CONTROL VALVE	P0446	0903	EC-296
VENT CONTROL VALVE	P1446	0215	EC-386
VENT CONTROL VALVE	P1448	0309	EC-397

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

P NO. INDEX FOR DTC

NCEC0001S02

DTC*6		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	ECM*1		
—	—	Unable to access ECM	EC-91
No DTC	Flashing*5	NO SELF DIAGNOSTIC FAILURE INDICATED	EC-56
P0000	0505	NO SELF DIAGNOSTIC FAILURE INDICATED	—
P0100	0102	MAF SEN/CIRCUIT*3	EC-116
P0105	0803	ABSL PRES SEN/CIRC	EC-125
P0110	0401	AIR TEMP SEN/CIRC	EC-134
P0115	0103	COOLANT T SEN/CIRC	EC-140
P0120	0403	THRTL POS SEN/CIRC*3	EC-145
P0125	0908	*COOLAN T SEN/CIRC	EC-156
P0130	0303	FRONT O2 SENSOR	EC-161
P0131	0411	FRONT O2 SENSOR	EC-167
P0132	0410	FRONT O2 SENSOR	EC-172
P0133	0409	FRONT O2 SENSOR	EC-177
P0134	0412	FRONT O2 SENSOR	EC-184
P0135	0901	FR O2 SEN HEATER	EC-190
P0137	0511	REAR O2 SENSOR	EC-195
P0138	0510	REAR O2 SENSOR	EC-203
P0139	0707	REAR O2 SENSOR	EC-210
P0140	0512	REAR O2 SENSOR	EC-218
P0141	0902	RR O2 SEN HEATER	EC-224
P0171	0115	FUEL SYS DIAG-LEAN	EC-229

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

DTC*6		Items (CONSULT screen terms)	Reference page	
CONSULT GST*2	ECM*1			
P0172	0114	FUEL SYS DIAG-RICH	EC-235	GI
P0180	0402	FUEL TEMP SEN/CIRC	EC-241	MA
P0300	0701	MULTI CYL MISFIRE	EC-245	EM
P0301	0608	CYL 1 MISFIRE	EC-245	
P0302	0607	CYL 2 MISFIRE	EC-245	LC
P0303	0606	CYL 3 MISFIRE	EC-245	
P0304	0605	CYL 4 MISFIRE	EC-245	EC
P0325	0304	KNOCK SEN/CIRCUIT	EC-250	
P0335	0802	CPS/CIRCUIT (OBD)	EC-255	FE
P0340	0101	CAM POS SEN/CIRC	EC-260	
P0400	0302	EGR SYSTEM	EC-267	CL
P0402	0306	EGRC-BPT VALVE	EC-275	
P0420	0702	TW CATALYST SYSTEM	EC-279	MT
P0440	0705	EVAP SMALL LEAK	EC-283	
P0443	1008	PURG VOLUME CONT/V	EC-291	AT
P0446	0903	VENT CONTROL VALVE	EC-296	
P0450	0704	EVAPO SYS PRES SEN	EC-302	AX
P0500	0104	VEH SPEED SEN/CIRC*4	EC-310	SU
P0505	0205	IACV/AAC VLV/CIRC	EC-315	
P0510	0203	CLOSED TP SW/CIRC	EC-320	BR
P0600	—	A/T COMM LINE	EC-325	
P0605	0301	ECM	EC-329	ST
P0705	1101	PNP SW/CIRC	AT-92	
P0710	1208	ATF TEMP SEN/CIRC	AT-97	RS
P0720	1102	VEH SPD SEN/CIR AT*4	AT-103	
P0725	1207	ENGINE SPEED SIG	AT-108	BT
P0731	1103	A/T 1ST GR FNCTN	AT-112	
P0732	1104	A/T 2ND GR FNCTN	AT-118	HA
P0733	1105	A/T 3RD GR FNCTN	AT-124	
P0734	1106	A/T 4TH GR FNCTN	AT-130	SC
P0740	1204	TCC SOLENOID/CIRC	AT-139	
P0744	1107	A/T TCC S/V FNCTN	AT-144	EL
P0745	1205	L/PRESS SOL/CIRC	AT-152	
P0750	1108	SFT SOL A/CIRC*3	AT-158	IDX
P0755	1201	SFT SOL B/CIRC*3	AT-163	
P1105	1302	MAP/BARO SW SOL/CIR	EC-331	

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

DTC*6		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	ECM*1		
P1148	0307	CLOSED LOOP	EC-341
P1320	0201	IGN SIGNAL-PRIMARY	EC-343
P1336	0905	CPS/CIRC (OBD) COG	EC-350
P1400	1005	EGRC SOLENOID/V	EC-355
P1401	0305	EGR TEMP SEN/CIRC	EC-360
P1402	0514	EGR SYSTEM	EC-366
P1440	0213	EVAP SMALL LEAK	EC-372
P1444	0214	PURG VOLUME CONT/V	EC-380
P1446	0215	VENT CONTROL VALVE	EC-386
P1447	0111	EVAP PURG FLOW/MON	EC-390
P1448	0309	VENT CONTROL VALVE	EC-397
P1490	0801	VC/V BYPASS/V	EC-402
P1491	0311	VC CUT/V BYPASS/V	EC-407
P1492	0807	PURG CONT/V S/V	EC-414
P1493	0312	PURG CONT/V & S/V	EC-420
P1605	0804	A/T DIAG COMM LINE	EC-428
P1705	1206	TP SEN/CIRC A/T*3	AT-168
P1706	1003	P-N POS SW/CIRCUIT	EC-431
P1760	1203	O/R CLTCH SOL/CIRC	AT-176
—	0208	OVERHEAT	EC-436

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: The MIL illuminates when the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

*5: While engine is running.

*6: 1st trip DTC No. is the same as DTC No.

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NCEC0002

The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

In addition to the supplemental air bag modules for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses (except "SEAT BELT PRE-TENSIONER" connector) can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).

Precautions for On Board Diagnostic (OBD) System of Engine and A/T

NCEG0003

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to EL section, "Description", "HARNESS CONNECTOR".
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission Control Module) before returning the vehicle to the customer.

PRECAUTIONS

Engine Fuel & Emission Control System

NCEC0004

ECM


- Do not disassemble ECM.
- Do not turn diagnosis test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - 1) Keep the antenna as far as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



ECCS PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IAC valve-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.






FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

ECM HARNESS HANDLING

- Securely connect ECM harness connectors. A Poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (4 in) away from adjacent harness, to prevent an ECM system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harness dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

SEF331W



Precautions


NCE0005

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.
 - ⚙️ : 3 - 5 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminals when connecting pin connectors.
- Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-101.
- After performing each TROUBLE DIAGNOSIS, perform "Overall Function Check" or "DTC Confirmation Procedure". The DTC should not be displayed in the "DTC Confirmation Procedure" if the repair is completed. The "Overall Function Check" should be a good result if the repair is completed.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS

Precautions (Cont'd)



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.

Wiring Diagrams and Trouble Diagnosis

NCEC0006

When you read Wiring diagrams, refer to the followings:

- "HOW TO READ WIRING DIAGRAMS" in GI section
- "POWER SUPPLY ROUTING" for power distribution circuit in EL section

When you perform trouble diagnosis, refer to the followings:

- "HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS" in GI section
- "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section



PREPARATION

Special Service Tools

Special Service Tools

NCEC0007

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV10117100 (J36471-A) Heated oxygen sensor wrench	 <p data-bbox="415 570 472 591">NT379</p>	Loosening or tightening front heated oxygen sensor with 22 mm (0.87 in) hexagon nut
KV10114400 (J-38365) Heated oxygen sensor wrench	 <p data-bbox="415 783 472 804">NT636</p>	Loosening or tightening rear heated oxygen sensor a: 22 mm (0.87 in)

GI

MA

EM

LC

EC




FE

CL

MT

Commercial Service Tools

NCEC0008

Tool name	Description	
Fuel filler cap adapter	 <p data-bbox="410 1257 467 1278">NT653</p>	Checking fuel tank vacuum relief valve opening pressure
Leak detector (J41416)	 <p data-bbox="410 1544 467 1566">NT703</p>	Locating the EVAP leak
EVAP service port adapter (J41413-OBDD)	 <p data-bbox="410 1830 467 1851">NT704</p>	Applying positive pressure through EVAP service port

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

PREPARATION

Commercial Service Tools (Cont'd)


Tool name	Description
Hose clipper (—)	 <p data-bbox="527 414 779 436">Approx. 20 mm (0.79 in)</p> <p data-bbox="406 457 470 478">NT720</p> <p data-bbox="950 212 1469 319">Clamping the EVAP purge hose between the fuel tank and EVAP canister applied to DTC P1440 [EVAP control system (Small leak — Positive pressure)]</p>

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location

Engine Control Component Parts Location

NCEC0009



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC






EL

IDX

SEF332W

ENGINE AND EMISSION CONTROL OVERALL SYSTEM







Engine Control Component Parts Location (Cont'd)



SEF333W

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

SEF334W

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location (Cont'd)



ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location (Cont'd)

NOTE:

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram

Circuit Diagram


NCEC0010



TEC521

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TEC560

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Diagram

System Diagram

NCEC0011



SEF720W

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Vacuum Hose Drawing

Vacuum Hose Drawing

NCEC0012

Refer to "System Diagram" on EC-20 for vacuum control system.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



NOTE: Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

SEF335W

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart

System Chart

NCEC0013

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Front heated oxygen sensor ● Ignition switch ● Throttle position sensor ● PNP switch ● Air conditioner switch ● Knock sensor ● EGR temperature sensor*1 ● Crankshaft position sensor (OBD)*1 ● EVAP control system pressure sensor*1 ● Tank fuel temperature sensor*1 ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Intake air temperature sensor ● Absolute pressure sensor ● Rear heated oxygen sensor*3 ● TCM (Transmission control module)*2 ● Closed throttle position switch*4 ● Ambient air temperature switch 	Fuel injection & mixture ratio control	Injectors
	Distributor ignition system	Power transistor
	Idle air control system	IACV-AAC valve and IACV-FICD solenoid valve
	IACV-air regulator control	IACV-air regulator
	Fuel pump control	Fuel pump relay
	Front heated oxygen sensor monitor & on board diagnostic system	Malfunction indicator lamp (On the instrument panel)
	EGR control	EGRC-solenoid valve
	Front and rear heated oxygen sensor heater control	Heated oxygen sensor heater
	EVAP canister purge flow control	<ul style="list-style-type: none"> ● EVAP canister purge volume control valve ● EVAP canister purge control solenoid valve
	Cooling fan control	Cooling fan relay
	Air conditioning cut control	Air conditioner relay
	ON BOARD DIAGNOSIS for EVAP system	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve ● MAP/BARO switch solenoid valve

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: The DTC related to A/T will be sent to ECM.

*3: Under normal conditions, this sensor is not for engine control operation.

*4: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System

Multiport Fuel Injection (MFI) System

DESCRIPTION

Input/Output Signal Chart

NCEC0014

GI

NCEC0014S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Injector
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Front heated oxygen sensor	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
PNP switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Electrical load	Electrical load signal		
Battery	Battery voltage		
Power steering oil pressure switch	Power steering operation		
Rear heated oxygen sensor*	Density of oxygen in exhaust gas		

* Under normal conditions, this sensor is not for engine control operation.

Basic Multiport Fuel Injection System

NCEC0014S02

SU

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

Various Fuel Injection Increase/Decrease Compensation

NCEC0014S03

ST

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D" (A/T models only)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation
- During high vehicle speed operation (M/T models)
- Extremely high engine coolant temperature

RS

BT

HA

SC

EL


IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multipoint Fuel Injection (MFI) System (Cont'd)

Mixture Ratio Feedback Control (Closed loop control)

NCEC0014S04



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the front heated oxygen sensor, refer to EC-161. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Rear heated oxygen sensor is located downstream of the three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

NCEC0014S05

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

Mixture Ratio Self-learning Control

NCEC0014S06

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.


"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

Fuel Injection Timing

NCEC0014S07



Two types of systems are used.

Sequential Multiport Fuel Injection System

NCEC0014S0701

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

NCEC0014S0702

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

Fuel Shut-off

NCEC0014S08

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System

DESCRIPTION

NCEC0015

Input/Output Signal Chart

NCEC0015S01


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
PNP switch	Gear position		
Battery	Battery voltage		

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Distributor Ignition (DI) System (Cont'd)

System Description

NCEC0015S02



The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown above.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec
A°BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.

If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control

DESCRIPTION

Input/Output Signal Chart

NCEC0016

NCEC0016S01

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
PNP switch	Neutral position		
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		

System Description

NCEC0016S02

This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Fuel Cut Control (at no load & high engine speed)

Fuel Cut Control (at no load & high engine speed)

DESCRIPTION

Input/Output Signal Chart

NCEC0017

NCEC0017S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
PNP switch	Neutral position		
Throttle position sensor	Throttle position		
Engine coolant temperature sensor	Engine coolant temperature		
Camshaft position sensor	Engine speed		

If the engine speed is above 3,950 rpm with no load, (for example, in Neutral and engine speed over 4,000 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,150 rpm, then fuel cut is cancelled.


NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", EC-23.

Evaporative Emission System

DESCRIPTION

NCEC0018



SEF338W

The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.


The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control valve is proportionally regulated as the air flow increases.

EVAP canister purge control valve also shuts off the vapor purge line during decelerating and idling.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)



INSPECTION


EVAP Canister

Check EVAP canister as follows:

1. Pinch the fresh air hose.
2. Blow air into port **A** and check that air flows freely through port **B**.

NCEC0019

NCEC0019S01




Tightening Torque

Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.

NCEC0019S02



Fuel Tank Vacuum Relief Valve (Built into fuel filler cap)

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.

Pressure:

16.0 - 20.0 kPa (0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)

Vacuum:


-6.0 to -3.5 kPa (-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.

NCEC0019S03



Evaporative Emission (EVAP) Canister Purge Control Valve

Refer to EC-420.

NCEC0019S04

Vacuum Cut Valve and Vacuum Cut Valve Bypass Valve

Refer to EC-407.

NCEC0019S05

Evaporative Emission (EVAP) Canister Purge Volume Control Valve

Refer to EC-380.

NCEC0019S06

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

Evaporative Emission (EVAP) Canister Purge Control Solenoid Valve

Refer to EC-420.

NCEC0019S07 GI


Tank Fuel Temperature Sensor

Refer to EC-241.

NCEC0019S08 MA

EM

LC



EVAP Service Port

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.

NCEC0019S09 EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

■ EVAP SYSTEM CLOSE ■
 APPLY PRESSURE TO EVAP SYSTEM FROM SERVICE PORT USING HAND PUMP WITH PRESSURE GAUGE AT NEXT SCREEN.
 NEVER USE COMPRESSED AIR OR HIGH PRESSURE PUMP!
 DO NOT START ENGINE.
 TOUCH START.

CANCEL

START

SEF658U

How to Detect Fuel Vapor Leakage

NCEC0019S10

CAUTION:

- Never use compressed air or a high pressure pump.
- Do not start engine.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.

NOTE:




Improper installation of adapter to the service port may cause a leak.

Ⓜ With CONSULT

- 1) Attach the EVAP service port adapter securely to the EVAP service port.
- 2) Also attach the pressure pump and hose.
- 3) Turn ignition switch "ON".
- 4) Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT.
- 5) Touch "START". A bar graph (Pressure indicating display) will appear on the screen.
- 6) Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
- 7) Remove the EVAP service port adapter and hose with pressure pump.
- 8) Locate the leak using a leak detector. Refer to "Evaporative Emission Line Drawing", EC-31.

ⓧ Without CONSULT

- 1) Attach the EVAP service port adapter securely to the EVAP service port and pressure pump with pressure gauge to the EVAP service port.
- 2) Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
- 3) To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm², 0.2 to 0.4 psi).
- 4) Remove the EVAP service port adapter and hose with pressure pump.
- 5) Locate the leak using a leak detector. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31.




ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

EVAPORATIVE EMISSION LINE DRAWING

NCEC0020



NOTE: Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


SEF339W

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

NOTE:

Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.




SEF340W

Positive Crankcase Ventilation

DESCRIPTION

NCEC0022



AEC923

This system returns blow-by gas to the intake collector.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air duct into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the intake collector under all conditions.



SEC137A


INSPECTION

PCV (Positive Crankcase Ventilation) Valve

NCEC0023

NCEC0023S01

With engine running at idle, remove PCV valve from breather separator. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.



ET277


Ventilation Hose

NCEC0023S02

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

BASIC SERVICE PROCEDURE

Fuel Pressure Release



Fuel Pressure Release


NCEC0024

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

Ⓜ WITH CONSULT

NCEC0024901



1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.



⊗ WITHOUT CONSULT

NCEC0024502

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF and reconnect fuel pump fuse.



Fuel Pressure Check

NCEC0025

- When reconnecting fuel line, always use new clamps.
 - Make sure that clamp screw does not contact adjacent parts.
 - Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.
 4. Start engine and check for fuel leakage.
 5. Read the indication of fuel pressure gauge.

At idle speed:


With vacuum hose connected

Approximately 235 kPa (2.4 kg/cm², 34 psi)

With vacuum hose disconnected

Approximately 294 kPa (3.0 kg/cm², 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check, EC-35.




Fuel Pressure Regulator Check

NCEC0026

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a rubber cap.
3. Connect variable vacuum source to fuel pressure regulator.
4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.





Injector

REMOVAL AND INSTALLATION


NCEC0027

1. Release fuel pressure to zero.
2. Remove intake manifold collector. Refer to EM section ("CYLINDER HEAD").
3. Disconnect vacuum hose from pressure regulator.
4. Disconnect fuel hoses from fuel tube assembly.
5. Disconnect injector harness connectors.
6. Remove injectors with fuel tube assembly.

- Push injector tail piece.
- Do not pull on the connector.



7. Install injectors.
- Clean exterior of injector tail piece.
 - Use new O-rings.



8. Install injectors with fuel tube assembly to intake manifold.
9. Install fuel hoses to fuel tube assembly.
10. Tighten fuel tube bolts to 9.32 to 10.8 N·m (0.95 to 1.10 kg-m, 6.9 to 8.0 ft-lb) as shown in the figure. Then tighten the bolts to 20.6 to 26.5 N·m (2.10 to 2.70 kg-m, 15 to 20 ft-lb).

Lubricate fuel hoses with a smear of silicone oil.

11. Reinstall any parts removed in reverse order of removal.

CAUTION:

After properly connecting fuel hose to injector and fuel tube assembly, check connection for fuel leakage.

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

NCEC0028

NCEC0028S01

PREPARATION


- Make sure that the following parts are in good order.
 - a) Battery
 - b) Ignition system
 - c) Engine oil and coolant levels
 - d) Fuses
 - e) ECM harness connector
 - f) Vacuum hoses
 - g) Air intake system
(Oil filler cap, oil level gauge, etc.)
 - h) Fuel pressure
 - i) Engine compression
 - j) EGR valve operation
 - k) Throttle valve
 - l) EVAP system
- On models equipped with air conditioner, checks should be carried out while the air conditioner is "OFF".
- On models equipped with automatic transaxle, when checking idle speed, ignition timing and mixture ratio, checks should be carried out while shift lever is in "P" or "N" position.
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear window defogger.
- Keep front wheels pointed straight ahead.
- Make the check after the cooling fan has stopped.

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

Overall Inspection Sequence

NCEC0026S0101



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



SEF941VB



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

INSPECTION PROCEDURE

=NCEC0028S02

1	INSPECTION START
<p>1. Visually check the following:</p> <ul style="list-style-type: none"> ● Air cleaner clogging ● Hoses and duct for leaks ● EGR valve operation ● Electrical connectors ● Gasket (intake manifold, cylinder head, exhaust system) ● Throttle valve and throttle position sensor operation <p>2. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine speed stays below 1,000 rpm.</p>	
	
SEF976U	
<p>3. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.</p> <p>4. Perform the Diagnostic Test Mode II (Self-diagnostic results). Refer to EC-57.</p>	
	
OK or NG	
OK	<ul style="list-style-type: none"> ▶ ● GO TO 2. (With CONSULT) ▶ ● GO TO 3. (Without CONSULT)
NG	<ul style="list-style-type: none"> ▶ 1. Repair or replace components as necessary. ▶ 2. GO TO 2. (With CONSULT) ▶ 3. GO TO 3. (Without CONSULT)


2	CHECK IGNITION TIMING
<p>ⓑ With CONSULT</p> <ol style="list-style-type: none"> 1. Run engine at about 2,000 rpm for about 2 minutes under no-load. 2. Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute. 	
	
SEF978U	
<ol style="list-style-type: none"> 3. Select "IGNITION TIMING ADJ" in WORK SUPPORT mode. 4. Touch "START". 	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ IGN TIMING ADJ ■ <input type="checkbox"/></p> <p style="text-align: center;">IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.</p> <p style="text-align: center; border: 1px solid black; padding: 2px;">START</p> </div>	
SEF546N	
<ol style="list-style-type: none"> 5. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 6. Check ignition timing with a timing light. 	
	
AEC804	
<p>M/T: 15°±2° BTDC A/T: 15°±2° BTDC (in "P" or "N" position)</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)


3 CHECK IGNITION TIMING

- Without CONSULT**
- Run engine at about 2,000 rpm for about 2 minutes under no-load.
 - Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute.




SEF978U

- Turn off engine and disconnect throttle position sensor harness connector.



SEF341W

- Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
- Check ignition timing with a timing light.



AEC804


M/T: $15^{\circ} \pm 2^{\circ}$ BTDC
A/T: $15^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)

OK or NG

OK	▶	GO TO 5.
NG	▶	GO TO 4.

4 ADJUST IGNITION TIMING

- With CONSULT**
- Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.
- Without CONSULT**
- Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.
 - Turn off engine and connect throttle position sensor harness connector to throttle position sensor.




SEF297W

Models with CONSULT	▶	GO TO 2.
Models without CONSULT	▶	GO TO 3.

5 CHECK BASE IDLE SPEED

- With CONSULT**
- Read idle speed in "IGN TIMING ADJ" in "WORK SUPPORT" mode.



SEF773W


M/T: 750 ± 50 rpm
A/T: 750 ± 50 rpm (in "P" or "N" position)


- Without CONSULT**
- Check idle speed.
M/T: 750 ± 50 rpm
A/T: 750 ± 50 rpm (in "P" or "N" position)
- OK or NG



OK (With CONSULT)	▶	GO TO 7.
OK (Without CONSULT)	▶	GO TO 8.
NG	▶	GO TO 6.

BASIC SERVICE PROCEDURE

Idle Speed/ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

6	ADJUST BASE IDLE SPEED
<ol style="list-style-type: none"> Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. Adjust idle speed by turning idle speed adjusting screw. 	
	
<p>SEF053P</p> <p>M/T: 750±50 rpm A/T: 750±50 rpm (in "P" or "N" position)</p>	
Models with CONSULT	▶ GO TO 7.
Models without CONSULT	▶ GO TO 8.

8	CHECK TARGET IDLE SPEED
<p>⊗ Without CONSULT</p> <ol style="list-style-type: none"> Turn off engine and connect throttle position sensor harness connector. 	
	
<p>SEF273V</p> <ol style="list-style-type: none"> Start engine. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. Check target idle speed. <p>M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position)</p> <p>OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.




7	CHECK TARGET IDLE SPEED
<p>⊕ With CONSULT</p> <ol style="list-style-type: none"> Touch "BACK" on CONSULT. 	
	
<p>SEF774W</p> <ol style="list-style-type: none"> Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. Read idle speed in "DATA MONITOR" mode with CONSULT. 	
	
<p>SEF550N</p> <p>M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position)</p> <p>OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.



9	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ol style="list-style-type: none"> Check IACV-AAC valve and replace if necessary. Refer to EC-315. Check IACV-AAC valve harness and repair if necessary. Refer to EC-315. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.) 	
<p>▶ GO TO 10.</p>	

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

10	CHECK FRONT HEATED OXYGEN SENSOR SIGNAL
<p>With CONSULT</p> <ol style="list-style-type: none"> See "FR O2 MNTR" in "DATA MONITOR" mode. Run engine at about 2,000 rpm for about 2 minutes under no-load. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature) and check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds. 	
	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">RECORD</div>	
<p style="text-align: right;">SEF054P</p> <p>1 cycle: RICH → LEAN → RICH 2 cycles: RICH → LEAN → RICH → LEAN → RICH</p>	
<p>Without CONSULT</p> <ol style="list-style-type: none"> Set "Front heated oxygen sensor monitor" in the Diagnostic Test Mode II. (See page EC-56.) 	
	
SEF987K	
<ol style="list-style-type: none"> Run engine at about 2,000 rpm for about 2 minutes under no-load (engine is warmed up to normal operating temperature). Maintain engine at 2,000 rpm under no-load and check that MIL goes on more than five times during 10 seconds. 	
	
SEF217U	
OK or NG	
OK	▶ INSPECTION END
NG	▶ GO TO 11.

11	CHECK FRONT HEATED OXYGEN SENSOR HARNESS	
<ol style="list-style-type: none"> Turn off engine and disconnect battery ground cable. Disconnect ECM harness connector. Disconnect front heated oxygen sensor harness connector. Then connect harness connector terminal for front heated oxygen sensor to ground with a jumper wire. 		
<p>Front heated oxygen sensor harness connector</p> 		
MEF031DA		
<ol style="list-style-type: none"> Check for continuity between terminal 46 of ECM harness connector and body ground. 		
		
SEF056P		
<p>Continuity exists...OK Continuity does not exist...NG</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	<ol style="list-style-type: none"> Connect ECM harness connector to ECM. GO TO 13.
NG	▶	<ol style="list-style-type: none"> Repair or replace harness. GO TO 12.


BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

12 PREPARATION FOR IDLE SPEED ADJUSTING

With CONSULT


1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
2. Touch "START".



SEF546N

Without CONSULT

1. Stop engine and disconnect throttle position sensor harness connector.



SEF341W


2. Start engine.

▶ GO TO 5.

13 PREPARATION FOR "CO" % CHECK

With CONSULT



1. Connect ECM harness connector to ECM.
2. Connect battery ground cable.
3. Select "ENGINE COOLANT TEMP" in "ACTIVE TEST" mode.
4. Set "COOLANT TEMP" to 5°C (41°F) by touching "Qu" and "Qd" and "UP", "DOWN".



AEC681

Without CONSULT

1. Connect ECM harness connector to ECM.
2. Disconnect engine coolant temperature sensor harness connector.
3. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector.





SEF053RA

4. Connect battery ground cable.

▶ GO TO 14.

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

14	CHECK "CO" %
<p>1. Start engine and warm it up until engine coolant temperature indicator points to middle of gauge. (Be sure to start engine after setting "COOLANT TEMP" or installing a 4.4 kΩ resistor.)</p>	
	
SEF976U	
<p>2. Rev engine two or three times under no-load, then run engine at idle speed.</p>	
	
SEF978U	
<p>3. Check "CO"%. Idle CO: Less than 11% and engine runs smoothly.</p>	
<p>4. <input checked="" type="checkbox"/> Without CONSULT After checking CO%,</p>	
<p>a. Disconnect the resistor from terminals of engine coolant temperature sensor harness connector.</p>	
<p>b. Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.</p>	
OK or NG	
OK	▶ GO TO 15.
NG	▶ GO TO 16.

15	CHECK FRONT HEATED OXYGEN SENSOR SIGNAL
<p><input checked="" type="checkbox"/> With CONSULT</p>	
<p>1. Replace front heated oxygen sensor.</p>	
<p>2. See "FR O2 MNTR" in "DATA MONITOR" mode.</p>	
<p>3. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.). Check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds.</p>	
<p>1 cycle: RICH → LEAN → RICH</p>	
<p>2 cycles: RICH → LEAN → RICH → LEAN → RICH</p>	
<p><input checked="" type="checkbox"/> Without CONSULT</p>	
<p>1. Replace front heated oxygen sensor.</p>	
<p>2. Set "Front heated oxygen sensor monitor" in the Diagnostic Test Mode II. (See page EC-56.)</p>	
<p>3. Maintain engine at 2,000 rpm under no-load. Check that the malfunction indicator lamp goes on and off more than five times during 10 seconds.</p>	
OK or NG	
OK	▶ GO TO 12.
NG	▶ GO TO 16.

16	DETECT MALFUNCTIONING PART
<p>1. Connect front heated oxygen sensor harness connector to front heated oxygen sensor.</p>	
<p>2. Check fuel pressure regulator. Refer to EC-35.</p>	
<p>3. Check mass air flow sensor and its circuit. Refer to EC-116.</p>	
<p>4. Check injector and its circuit. Refer to EC-450. Clean or replace if necessary.</p>	
<p>5. Check engine coolant temperature sensor and its circuit. Refer to EC-140, 156.</p>	
<p>6. Check ECM function by substituting another known good ECM. (ECM may be the cause of a problem, but this is rarely the case.)</p>	
OK or NG	
	▶ GO TO 12.

- If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

Introduction

NCEC0029

The ECM has an on board diagnostic system which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Diagnostic Trouble Code (DTC)	Mode 3 of SAE J1979
Freeze Frame data	Mode 2 of SAE J1979
System Readiness Test (SRT) code	Mode 1 of SAE J1979
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of SAE J1979
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of SAE J1979

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
ECM*3	X	X*1	—	—	—	—
CONSULT	X	X	X	X	X	—
GST	X	X*2	X	—	X	X

*1: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

*2: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*3: In diagnostic test mode II (Self-diagnostic results)

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-91.)

Two Trip Detection Logic

NCEC0030

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

Items	MIL			DTC		1st trip DTC	
	1st trip		2nd trip lighting up	1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up					
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) is being detected	X	—	—	X	—	X	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) has been detected	—	X	—	X	—	X	—
Closed loop control — DTC: P1148 (0307)	—	X	—	X	—	X	—
Fail-safe items (Refer to EC-91.)	—	X	—	X*1	—	X*1	—
Except above	—	—	X	—	X	X	X

*1: Except "ECM".

Emission-related Diagnostic Information

NCEC0031

DTC AND 1ST TRIP DTC

NCEC0031S01

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed. If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-54.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-51. These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to page EC-81. Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to read DTC and 1st Trip DTC

NCEC0031S0101

DTC and 1st trip DTC can be read by the following methods.

1) **No Tools**

The number of blinks of MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.

These DTCs are controlled by NISSAN.

2) **With CONSULT**

With GST

CONSULT or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, Mode II and GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal.**
CONSULT can identify malfunction status as shown below. Therefore, using CONSULT (if available) is recommended.

A sample of CONSULT display for DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">■ SELF-DIAG RESULTS ■ <input type="checkbox"/></p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">FAILURE DETECTED</td> <td style="width: 40%;">TIME</td> </tr> <tr> <td>IACV-AAC VALVE</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="2" style="text-align: center;">【 P0505 】</td> </tr> </table> </div>	FAILURE DETECTED	TIME	IACV-AAC VALVE	0	【 P0505 】		1st trip DTC display	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">■ SELF-DIAG RESULTS ■ <input type="checkbox"/></p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">FAILURE DETECTED</td> <td style="width: 40%;">TIME</td> </tr> <tr> <td>IACV-AAC VALVE</td> <td style="text-align: center;">[1t]</td> </tr> <tr> <td colspan="2" style="text-align: center;">【 P0505 】</td> </tr> </table> </div>	FAILURE DETECTED	TIME	IACV-AAC VALVE	[1t]	【 P0505 】	
FAILURE DETECTED	TIME														
IACV-AAC VALVE	0														
【 P0505 】															
FAILURE DETECTED	TIME														
IACV-AAC VALVE	[1t]														
【 P0505 】															
	<div style="display: flex; justify-content: space-around; margin-top: 5px;"> ERASE PRINT FFdata </div>		<div style="display: flex; justify-content: space-around; margin-top: 5px;"> ERASE PRINT FFdata </div>												

SEF180U

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

NCEC0031S02

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed and absolute pressure sensor at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT or GST. The 1st trip freeze frame data can only be displayed on the CONSULT screen, not on the GST. For details, see EC-68.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 (0701, 0605 - 0608) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114)
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-54.

SYSTEM READINESS TEST (SRT) CODE

NCEC0031S03

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979. It indicates whether the self-diagnostic tests for non-continuously monitored items have been completed or not.

Inspection/Maintenance (I/M) tests of the on board diagnostic (OBD) II system may become the legal requirements in some states/areas. All SRT codes must be set in this case. Unless all SRT codes are set, conducting the I/M test may not be allowed.

SRT codes are set after self-diagnosis has been performed one or more times. This occurs regardless of whether the diagnosis is in "OK" or "NG", and whether or not the diagnosis is performed in consecutive trips. The following table lists the five SRT items (18 test items) for the ECM used in G20 models.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

SRT items	Self-diagnostic test items	
Catalyst monitoring	<ul style="list-style-type: none"> • Three way catalyst function P0420 (0702) 	GI
EVAP system monitoring	<ul style="list-style-type: none"> • EVAP control system (Small leak — Negative pressure) P0440 (0705) • EVAP control system (Small leak — Positive pressure) P1440 (0213) • EVAP control system purge flow monitoring P1447 (0111) 	MA
Oxygen sensor monitoring	<ul style="list-style-type: none"> • Front heated oxygen sensor (Circuit) P0130 (0303) • Front heated oxygen sensor (Lean shift monitoring) P0131 (0411) • Front heated oxygen sensor (Rich shift monitoring) P0132 (0410) • Front heated oxygen sensor (Response monitoring) P0133 (0409) • Front heated oxygen sensor (High voltage) P0134 (0412) • Rear heated oxygen sensor (Min. voltage monitoring) P0137 (0511) • Rear heated oxygen sensor (Max. voltage monitoring) P0138 (0510) • Rear heated oxygen sensor (Response monitoring) P0139 (0707) • Rear heated oxygen sensor (High voltage) P0140 (0512) 	EM LC EC
Oxygen sensor heater monitoring	<ul style="list-style-type: none"> • Front heated oxygen sensor heater P0135 (0901) • Rear heated oxygen sensor heater P0141 (0902) 	FE
EGR system monitoring	<ul style="list-style-type: none"> • EGR function (Close) P0400 (0302) • EGRC-BPT valve function P0402 (0306) • EGR function (Open) P1402 (0514) 	CL

Together with the DTC, the SRT code is cleared from the ECM memory using the method described later (Refer to EC-54). In addition, after engine control components/system are repaired or if the battery terminals remain disconnected for more than 24 hours, all SRT codes may be cleared from the ECM memory.


How to Display SRT Code

NCEC0031S0301

1. With CONSULT

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT screen; for items whose SRT codes are not set, "INCMP" is displayed as shown below.



2. With GST

Selecting Mode 1 with GST (Generic Scan Tool)

How to Set SRT Code

NCEC0031S0302

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions. The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

Driving Pattern

NCEC0031S0303

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.



SEF942V

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest. Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminals 51 and 50 is 3.0 - 4.3V).
- The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminals 51 and 50 is lower than 1.4V).
- The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 63 and ground is less than 4.1V).

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least three times.
On M/T models, shift gears following "suggested upshift speeds" schedule on next page.


Pattern 4:

- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

- 1) Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
- 2) Repeat driving pattern shown below at least 10 times.
 - **During acceleration, hold the accelerator pedal as steady as possible. (The THROTL POS SEN value of CONSULT should be between 0.8 to 1.2V.)**
- 3) Repeat steps 1 and 2 until the EGR system SRT is set.



*3: Checking the vehicle speed with CONSULT or GST is advised.

*4: The driving pattern may be omitted when "PURG FLOW P1447" is performed using the "DTC WORK SUPPORT" mode with CONSULT.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

*5: The driving pattern may be omitted when "EVAP SML LEAK P0440" is performed using the "DTC WORK SUPPORT" mode with CONSULT.

*6: The driving pattern may be omitted when all the followings are performed using the "DTC WORK SUPPORT" mode with CONSULT.

- "EGR SYSTEM P0400"
- "EGR SYSTEM P1402"

*7: The driving pattern may be omitted when "EGRC-BPT/VLV P0402" is performed using the "DTC WORK SUPPORT" mode with CONSULT.

Suggested transmission gear position for A/T models

Set the selector lever in the "D" position with "OD" ON.

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:

Gear change	ACCEL shift point km/h (MPH)
1st to 2nd	24 (15)
2nd to 3rd	40 (25)
3rd to 4th	65 (40)
4th to 5th	75 (45)

For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]:

Gear change	km/h (MPH)
1st to 2nd	25 (15)
2nd to 3rd	40 (25)
3rd to 4th	65 (40)
4th to 5th	75 (45)

Suggested maximum speed in each gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

Gear	km/h (MPH)
1st	55 (35)
2nd	95 (60)
3rd	135 (85)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT)

NCEC0031S04

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (9 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

X: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application	
		TID	CID			
CATALYST	Three way catalyst function	01H	01H	Max.	X	GI
		02H	81H	Min.	X	MA
EVAP SYSTEM	EVAP control system (Small leak)	05H	03H	Max.	X	EM
	EVAP control system purge flow monitoring	06H	83H	Min.	X	LC
O2 SENSOR	Front heated oxygen sensor	09H	04H	Max.	X	
		0AH	84H	Min.	X	EC
		0BH	04H	Max.	X	
		0CH	04H	Max.	X	FE
	Rear heated oxygen sensor	19H	86H	Min.	X	CL
		1AH	86H	Min.	X	
		1BH	06H	Max.	X	MT
		1CH	06H	Max.	X	AT
O2 SENSOR HEATER	Front heated oxygen sensor heater	29H	08H	Max.	X	
		2AH	88H	Min.	X	AX
	Rear heated oxygen sensor heater	2DH	0AH	Max.	X	
		2EH	8AH	Min.	X	SU
EGR SYSTEM	EGR function	31H	8CH	Min.	X	
		32H	8CH	Min.	X	BR
		33H	8CH	Min.	X	
		34H	8CH	Min.	X	ST
		35H	0CH	Max.	X	
	EGRC-BPT valve function	36H	0CH	Max.	X	RS
		37H	8CH	Min.	X	BT

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable NCEC0031S05

Items (CONSULT screen terms)	DTC*4		SRT code	Test value/Test limit (GST only)	1st trip DTC*4	Reference page	
	CONSULT GST*2	ECM*1					
NO SELF DIAGNOSTIC FAILURE INDICATED	P0000	0505	—	—	—	—	
MAF SEN/CIRCUIT	P0100	0102	—	—	X	EC-116	HA
ABSL PRES SEN/CIRC	P0105	0803	—	—	X	EC-125	SC
AIR TEMP SEN/CIRC	P0110	0401	—	—	X	EC-134	EL
COOLANT T SEN/CIRC	P0115	0103	—	—	X	EC-140	IDX
THRTL POS SEN/CIRC	P0120	0403	—	—	X	EC-145	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

Items (CONSULT screen terms)	DTC*4		SRT code	Test value/Test limit (GST only)	1st trip DTC*4	Reference page
	CONSULT GST*2	ECM*1				
*COOLAN T SEN/CIRC	P0125	0908	—	—	X	EC-156
FRONT O2 SENSOR	P0130	0303	X	X	X*3	EC-161
FRONT O2 SENSOR	P0131	0411	X	X	X*3	EC-167
FRONT O2 SENSOR	P0132	0410	X	X	X*3	EC-172
FRONT O2 SENSOR	P0133	0409	X	X	X*3	EC-177
FRONT O2 SENSOR	P0134	0412	X	X	X*3	EC-184
FR O2 SEN HEATER	P0135	0901	X	X	X*3	EC-190
REAR O2 SENSOR	P0137	0511	X	X	X*3	EC-195
REAR O2 SENSOR	P0138	0510	X	X	X*3	EC-203
REAR O2 SENSOR	P0139	0707	X	X	X*3	EC-210
REAR O2 SENSOR	P0140	0512	X	X	X*3	EC-218
RR O2 SEN HEATER	P0141	0902	X	X	X*3	EC-224
FUEL SYS DIAG-LEAN	P0171	0115	—	—	X	EC-229
FUEL SYS DIAG-RICH	P0172	0114	—	—	X	EC-235
FUEL TEMP SEN/CIRC	P0180	0402	—	—	X	EC-241
MULTI CYL MISFIRE	P0300	0701	—	—	X	EC-245
CYL 1 MISFIRE	P0301	0608	—	—	X	EC-245
CYL 2 MISFIRE	P0302	0607	—	—	X	EC-245
CYL 3 MISFIRE	P0303	0606	—	—	X	EC-245
CYL 4 MISFIRE	P0304	0605	—	—	X	EC-245
KNOCK SEN/CIRCUIT	P0325	0304	—	—	—	EC-250
CPS/CIRCUIT (OBD)	P0335	0802	—	—	X	EC-255
CAM POS SEN/CIRC	P0340	0101	—	—	X	EC-260
EGR SYSTEM	P0400	0302	X	X	X*3	EC-267
EGRC-BPT VALVE	P0402	0306	X	X	X*3	EC-275
TW CATALYST SYSTEM	P0420	0702	X	X	X*3	EC-279
EVAP SMALL LEAK	P0440	0705	X	X	X*3	EC-283
PURG VOLUME CONT/V	P0443	1008	—	—	X	EC-291
VENT CONTROL VALVE	P0446	0903	—	—	X	EC-296
EVAP SYS PRES SEN	P0450	0704	—	—	X	EC-302
VEH SPEED SEN/CIRC	P0500	0104	—	—	X	EC-310
IACV/AAC VLV/CIRC	P0505	0205	—	—	X	EC-315
CLOSED TP SW/CIRC	P0510	0203	—	—	X	EC-320
A/T COMM LINE	P0600	—	—	—	—	EC-325
ECM	P0605	0301	—	—	X	EC-329
PNP SW/CIRC	P0705	1101	—	—	X	AT-92

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

Items (CONSULT screen terms)	DTC*4		SRT code	Test value/Test limit (GST only)	1st trip DTC*4	Reference page	
	CONSULT GST*2	ECM*1					
ATF TEMP SEN/CIRC	P0710	1208	—	—	X	AT-97	GI
VEH SPD SEN/CIR AT	P0720	1102	—	—	X	AT-103	MA
ENGINE SPEED SIG	P0725	1207	—	—	X	AT-108	EM
A/T 1ST GR FNCTN	P0731	1103	—	—	X	AT-112	
A/T 2ND GR FNCTN	P0732	1104	—	—	X	AT-118	LC
A/T 3RD GR FNCTN	P0733	1105	—	—	X	AT-124	
A/T 4TH GR FNCTN	P0734	1106	—	—	X	AT-130	EC
TCC SOLENOID/CIRC	P0740	1204	—	—	X	AT-139	
A/T TCC S/V FNCTN	P0744	1107	—	—	X	AT-144	FE
L/PRESS SOL/CIRC	P0745	1205	—	—	X	AT-152	
SFT SOL A/CIRC	P0750	1108	—	—	X	AT-158	CL
SFT SOL B/CIRC	P0755	1201	—	—	X	AT-163	
MAP/BARO SW SOL/CIR	P1105	1302	—	—	X	EC-331	MT
CLOSED LOOP	P1148	0307	—	—	—	EC-341	
IGN SIGNAL-PRIMARY	P1320	0201	—	—	X	EC-343	AT
CPS/CIRC (OBD) COG	P1336	0905	—	—	X	EC-350	
EGRC SOLENOID/V	P1400	1005	—	—	X	EC-355	AX
EGR TEMP SEN/CIRC	P1401	0305	—	—	X	EC-360	
EGR SYSTEM	P1402	0514	X	X	X*3	EC-366	SU
EVAP SMALL LEAK	P1440	0213	X	X	X*3	EC-372	BR
PURG VOLUME CONT/V	P1444	0214	—	—	X	EC-380	
VENT CONTROL VALVE	P1446	0215	—	—	X	EC-386	ST
EVAP PURG FLOW/MON	P1447	0111	X	X	X*3	EC-390	
VENT CONTROL VALVE	P1448	0309	—	—	X	EC-397	RS
VC/V BYPASS/V	P1490	0801	—	—	X	EC-402	
VC CUT/V BYPASS/V	P1491	0311	—	—	X	EC-407	BT
PURG CONT/V S/V	P1492	0807	—	—	X	EC-414	
PURG CONT/V & S/V	P1493	0312	—	—	X	EC-420	HA
A/T DIAG COMM LINE	P1605	0804	—	—	X	EC-428	
TP SEN/CIRC A/T	P1705	1206	—	—	X	AT-168	SC
P-N POS SW/CIRCUIT	P1706	1003	—	—	X	EC-431	
O/R CLTCH SOL/CIRC	P1760	1203	—	—	X	AT-176	EL

*1: In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

*2: These numbers are prescribed by SAE J2012.

*3: These are not displayed with GST.

*4: 1st trip DTC No. is the same as DTC No.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

NCEC0031S06


ⓑ How to Erase DTC (With CONSULT)

NCEC0031S0601

NOTE:

If the diagnostic trouble code is not for A/T related items (see EC-2), skip steps 2 through 4.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
 2. Turn CONSULT "ON" and touch "A/T".
 3. Touch "SELF-DIAG RESULTS".
 4. Touch "ERASE". [The DTC in the TCM (Transmission control module) will be erased.] Then touch "BACK" twice.
 5. Touch "ENGINE".
 6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)
- If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).



The emission-related diagnostic information can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT.

Ⓒ How to Erase DTC (With GST)

NCEC0031S0602

NOTE:

If the diagnostic trouble code is not for A/T related items (see EC-2), skip step 2.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)

3. Select Mode 4 with GST (Generic Scan Tool).

The emission-related diagnostic information can be erased by selecting Mode 4 with GST (Generic Scan Tool).

How to Erase DTC (No Tools)

NCEC003150603

NOTE:

If the diagnostic trouble code is not for A/T related items (see EC-2), skip step 2.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See EC-57.)

The emission-related diagnostic information can be erased by changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM. (Refer to EC-57.)

NOTE:


- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
- Erasing the emission-related diagnostic information using CONSULT or GST is easier and quicker than switching the mode selector on the ECM.
- The following data are cleared when the ECM memory is erased.
 - 1) Diagnostic trouble codes
 - 2) 1st trip diagnostic trouble codes
 - 3) Freeze frame data
 - 4) 1st trip freeze frame data
 - 5) System readiness test (SRT) codes
 - 6) Test values
 - 7) Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

Malfunction Indicator Lamp (MIL)

DESCRIPTION

NCEC0092



The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to EL section ("WARNING LAMPS") or see EC-475.
2. When the engine is started, the MIL should go off.

If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

—NCF-C0032S01

On Board Diagnostic System Function

The on board diagnostic system has the following four functions.

Diagnostic Test Mode I

1. BULB CHECK:

This function checks the MIL bulb for damage (blown, open circuit, etc.).

If the MIL does not come on, check MIL circuit and ECM test mode selector. (See next page.)

2. MALFUNCTION WARNING:

This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected.

The following malfunctions will light up or blink the MIL in the 1st trip.

- “Misfire (Possible three way catalyst damage)”
- “Closed loop control”
- Fail-safe mode

Diagnostic Test Mode II

3. SELF-DIAGNOSTIC RESULTS:

This function allows DTCs and 1st trip DTCs to be read.

4. FRONT HEATED OXYGEN SENSOR MONITOR:




This function allows the fuel mixture condition (lean or rich), monitored by front heated oxygen sensor, to be read.

MIL Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MIL may flash when engine is running. In this case, check ECM test mode selector following “HOW TO SWITCH DIAGNOSTIC TEST MODES” on next page.

NCEC0032S0101

How to switch the diagnostic test (function) modes, and details of the above functions are described later. (Refer to EC-57.)

Condition		Diagnostic Test Mode I	Diagnostic Test Mode II
Ignition switch in “ON” position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	FRONT HEATED OXYGEN SENSOR MONITOR

The following emission-related diagnostic information is cleared when the ECM memory is erased.


- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

How to Switch Diagnostic Test Modes

NCEC0032S02



- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 5 seconds. The diagnosis will automatically return to Diagnostic Test Mode I.
- Turn back diagnostic test mode selector to the fully counterclockwise position whenever vehicle is in use.

*1: EC-475
*2: EC-56

*3: EC-475

*4: EC-91

SEF344W

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

Diagnostic Test Mode I — Bulb Check

NCEC0032S03

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the MIL bulb. Refer to EL section ("WARNING LAMPS") or see EC-475.

Diagnostic Test Mode I — Malfunction Warning

NCEC0032S04



MIL	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

Diagnostic Test Mode II — Self-diagnostic Results

NCEC0032S05

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MIL. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT or GST. A DTC will be used as an example for how to read a code.



Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the malfunction indicator lamp blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position (PNP) switch.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0505" refers to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-2.)

How to Erase Diagnostic Test Mode II (Self-diagnostic results)

NCEC0032S0501

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- If the battery is disconnected, the DTC will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

Diagnostic Test Mode II — Front Heated Oxygen Sensor Monitor

NCEC0032506

In this mode, the MIL displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

MIL	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the front heated oxygen sensor function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MIL comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

NCEC0033

NCEC0033501

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to "Two Trip Detection Logic" on EC-44.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

NCEC0033502

Items	Fuel Injection System	Misfire	Other
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see EC-61.

For details about patterns "A" and "B" under "Other", see EC-63.

*1: Clear timing is at the moment OK is detected.


*2: Clear timing is when the same malfunction is detected in the 2nd trip.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"

NCEC0033503



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame

- data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip

- freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NCEC0033S04

GI

Driving Pattern B

NCEC0033S0401

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

MA

EM

Driving Pattern C

NCEC0033S0402

Driving pattern C means the vehicle operation as follows:

1) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

LC

EC

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

CL

MT

AT

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NCEC0033S05



SEF393S

- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC

- and the 1st trip freeze frame data will be stored in ECM.
- *6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

Driving Pattern A

NCEC0033S06

NCEC0033S0601



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

Driving Pattern B

NCEC0033S0602


Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT




CONSULT

#NCEC0034


CONSULT INSPECTION PROCEDURE

NCEC0034S01


1. Turn ignition switch OFF.
2. Connect "CONSULT" to data link connector for CONSULT.
(Data link connector for CONSULT is located behind the fuse box cover.)



3. Turn ignition switch ON.
4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT Operation Manual. This sample shows the display when using the UE990 program card. Screen differs in accordance with the program card used.



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

NCEC0034S02

Item		DIAGNOSTIC TEST MODE										
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONITOR	ACTIVE TEST	FUNC-TION TEST	DTC CONFIRMATION				
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT			
ENGINE CONTROL COMPONENT PARTS	INPUT	Camshaft position sensor		X	X	X					GI	
		Mass air flow sensor		X		X					MA	
		Engine coolant temperature sensor		X	X	X	X					EW
		Front heated oxygen sensor		X		X		X	X	X		LC
		Rear heated oxygen sensor		X		X			X	X		EC
		Vehicle speed sensor		X	X	X		X				FE
		Throttle position sensor	X	X		X		X				CL
		Tank fuel temperature sensor		X		X	X					MT
		EVAP control system pressure sensor		X		X						AT
		Absolute pressure sensor		X	X	X						AX
		EGR temperature sensor		X		X						SU
		Intake air temperature sensor		X		X						BR
		Crankshaft position sensor (OBD)		X								ST
		Knock sensor		X								RS
		Ignition switch (start signal)				X		X				BT
		Closed throttle position switch		X		X						HA
		Closed throttle position switch (throttle position sensor signal)				X		X				SC
		Air conditioner switch				X						EL
		Park/Neutral position (PNP) switch		X		X		X				IDX
		Power steering oil pressure switch				X		X				
Battery voltage				X								

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONITOR	ACTIVE TEST	FUNC-TION TEST	DTC CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS	OUT-PUT	Injectors			X	X	X		
	Power transistor (Ignition timing)	X	X (Ignition signal)		X	X	X		
	IACV-AAC valve	X	X		X	X	X		
	EVAP canister purge control solenoid valve		X		X	X			X
	EVAP canister purge volume control valve		X		X	X			X
	Air conditioner relay				X				
	Fuel pump relay	X			X	X	X		
	EGRC-solenoid valve		X		X	X	X*3		
	Front heated oxygen sensor heater		X		X			X	
	Rear heated oxygen sensor heater		X		X			X	
	Cooling fan		X		X	X	X		
	EVAP canister vent control valve		X		X	X			
	Vacuum cut valve bypass valve		X		X	X			X
	MAP/BARO switch solenoid valve		X		X	X			
Calculated load value			X	X					

X: Applicable

*1: This item includes 1st trip DTCs.

*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-46.

*3: If this function test mode is not available, use the "ACTIVE TEST" mode.

FUNCTION

NCEC0034503

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Diagnostic test mode	Function	
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".	GI
ECM part number	ECM part numbers can be read.	MA

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Others

GI

MA

EM

LC

EC

WORK SUPPORT MODE

NCEC0034S04

WORK ITEM	CONDITION	USAGE	
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● IGN SW "ON" ● ENG NOT RUNNING ● ACC PEDAL NOT PRESSED 	When adjusting throttle position sensor initial position	FE
IGNITION TIMING ADJ	<ul style="list-style-type: none"> ● IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR. 	When adjusting initial ignition timing	CL
IACV-AAC VALVE ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● ENGINE WARMED UP ● NO-LOAD 	When adjusting idle speed	MT
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line	AT
EVAP SYSTEM CLOSE	OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● BATTERY VOLTAGE IS SUFFICIENT. ● IGN SW "ON" ● ENGINE NOT RUNNING ● AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). ● NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM ● TANK FUEL TEMP. IS MORE THAN 0°C (32°F). ● WITHIN 10 MINUTES AFTER STARTING "EVAP SYSTEM CLOSE" WHEN TRYING TO EXECUTE "EVAP SYSTEM CLOSE" UNDER THE CONDITIONS ABOVE, CONSULT WILL DISCONTINUE AND DISPLAY INSTRUCTIONS. <p style="font-size: small; margin-top: 5px;">NOTE: WHEN STARTING ENGINE, CONSULT MAY DISPLAY "BATTERY VOLTAGE IS LOW. CHARGE BATTERY", EVEN WHEN USING A CHARGED BATTERY.</p>	When detecting EVAP vapor leak point of EVAP system	AX

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SELF DIAGNOSTIC MODE

DTC and 1st Trip DTC

Regarding items of "DTC and 1st trip DTC", refer to "TROUBLE DIAGNOSIS — INDEX", EC-2.

NCEC0034S05

NCEC0034S0501

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Freeze Frame Data and 1st Trip Freeze Frame Data

NCEC0034S0502

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> Engine Control component part/control system has a trouble code, it is displayed as "PXXXX". [Refer to "Alphabetical & P No. Index for DTC" (EC-2).]
FUEL SYS DATA	<ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. <ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM [%]	<ul style="list-style-type: none"> "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM [%]	<ul style="list-style-type: none"> "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL PRESS [kPa] or [kg/cm ²] or [psi]	<ul style="list-style-type: none"> The absolute pressure at the moment a malfunction is detected is displayed.

*: The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

NCEC0034S06

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
CMPS-RPM (REF) [rpm]	○	○	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS AIR/FL SE [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
COOLAN TEMP/S [°C] or [°F]	○	○	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
FR O2 SENSOR [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the front heated oxygen sensor is displayed. 	
RR O2 SENSOR [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the rear heated oxygen sensor is displayed. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks	
FR O2 MNTR [RICH/LEAN]	○	○	<ul style="list-style-type: none"> Display of front heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously. 	GI MA EM LC
RR O2 MNTR [RICH/LEAN]	○		<ul style="list-style-type: none"> Display of rear heated oxygen sensor signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. 	EC FE CL
VHCL SPEED SE [km/h] or [mph]	○	○	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 		MT
BATTERY VOLT [V]	○	○	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 		AT
THRTL POS SEN [V]	○	○	<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 		AX
TANK F/TMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> The fuel temperature judged from the tank fuel temperature sensor signal voltage is displayed. 		SU
EGR TEMP SEN [V]	○		<ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. 		BR
INT/A TEMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. 		ST
START SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal. 	RS
CLSD THL/P SW [ON/OFF]			<ul style="list-style-type: none"> Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch. 		BT
CLSD THL POS [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal. 		HA
AIR COND SIG [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioning signal. 		SC
P/N POSI SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the PNP switch signal. 		EL
PW/ST SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure switch signal. 		IDX
IGNITION SW [ON/OFF]	○		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 		

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
INJ PULSE [msec]		○	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
B/FUEL SCHDL [msec]		○	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
IGN TIMING [BTDC]		○	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	
IACV-AAC/V [%]		○	<ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. 	
PURG VOL C/V [step]		○	<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 	
A/F ALPHA [%]			<ul style="list-style-type: none"> Indicates the mean value of the air-fuel ratio feedback correction factor per cycle. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
EVAP SYS PRES [V]		○	<ul style="list-style-type: none"> The signal voltage of EVAP control system pressure sensor is displayed. 	
AIR COND RLY [ON/OFF]			<ul style="list-style-type: none"> Indicates the air conditioner relay control condition determined by ECM according to the input signals. 	
FUEL PUMP RLY [ON/OFF]			<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]			<ul style="list-style-type: none"> Indicates the control condition of the cooling fan determined by ECM according to the input signals. HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	
EGRC SOL/V [ON/OFF] (FLOW/CUT)			<ul style="list-style-type: none"> Indicates the control condition of the EGRC-solenoid valve determined by ECM according to the input signals. ON ... EGR valve is operational OFF ... EGR valve operation is cut-off 	
VENT CONT/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open 	
FR O2 HEATER [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks	
RR O2 HEATER [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of rear heated oxygen sensor heater determined by ECM according to the input signals. 		GI
VC/V BYPASS/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed 		MA EM LC
PURG CONT S/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister purge control solenoid valve (computed by the ECM according to the input signals) is indicated. ON ... Canister purge is operational OFF ... Canister purge operation is cut-off 		EC FE CL
CAL/LD VALUE [%]			<ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. 		MT
ABSOL TH-P/S [%]			<ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 		AT
MASS AIRFLOW [gm/s]			<ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor. 		AX
MAP/BARO SW/V [MAP/BARO]			<ul style="list-style-type: none"> The control condition of the MAP/BARO switch solenoid valve (determined by ECM according to the input signal) is indicated. MAP ... Intake manifold absolute pressure BARO ... Ambient barometric pressure 		SU BR ST
ABSOL PRES/SE [V]			<ul style="list-style-type: none"> The signal voltage of the absolute pressure sensor is displayed. 		RS
VOLTAGE [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 		BT
PULSE [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only "#" is displayed if item is unable to be measured. Figures with "#"'s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. 	HA SC

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

NCEC0034S07

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)	
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Front heated oxygen sensor 	EL IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
IACV-AAC/V OPENING	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Change the IACV-AAC valve opening percent using CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● IACV-AAC valve
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature indication using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor ● Fuel injectors
IGNITION TIM- ING	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Adjust initial ignition timing
POWER BAL- ANCE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Air conditioner switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time using CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connector ● Compression ● Injectors ● Power transistor ● Spark plugs ● Ignition coils
COOLING FAN	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn the cooling fan "ON" and "OFF" using CONSULT. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connector ● Cooling fan motor
FUEL PUMP RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
EGRC SOLE- NOID VALVE	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn EGRC-solenoid valve "ON" and "OFF" using CONSULT and listen to operating sound. 	EGRC-solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● EGRC-solenoid valve
SELF-LEARNING CONT	<ul style="list-style-type: none"> ● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control valve opening step using CONSULT. 	Engine speed changes according to the opening step.	<ul style="list-style-type: none"> ● Harness and connector ● EVAP canister purge volume control valve
TANK F/TEMP SEN	<ul style="list-style-type: none"> ● Change the tank fuel temperature using CONSULT. 		
VENT CONTROL/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
VC/V BYPASS/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
PURG CONT S/V	<ul style="list-style-type: none"> Start engine. Turn the EVAP canister purge control solenoid valve "ON" and "OFF" using CONSULT and listen for operating sound. 	EVAP canister purge control solenoid valve makes an operating sound. Check vacuum signal for EVAP canister purge control valve. VC ON ... Vacuum exists. VC OFF ... Vacuum does not exist.	<ul style="list-style-type: none"> Harness and connector EVAP canister purge control solenoid valve Vacuum hose
MAP/BARO SW/V	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the MAP/BARO switch solenoid valve between "MAP" and "BARO" using CONSULT and listen to operating sound. 	MAP/BARO switch solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector MAP/BARO switch solenoid valve

DTC CONFIRMATION MODE

SRT STATUS Mode

NCEC0034S08

NCEC0034S0801

For details, refer to "SYSTEM READINESS TEST (SRT) CODE", EC-46.

DTC Work Support Mode

NCEC0034S0802

TEST MODE	TEST ITEM	CONDITION	REFERENCE PAGE
EVAPORATIVE SYSTEM	EVAP SML LEAK P0440	Refer to corresponding trouble diagnosis for DTC.	EC-283
	EVAP SML LEAK P1440		EC-372
	PURG VOL CN/V P1444		EC-380
	PURGE FLOW P1447		EC-390
	VC CUT/V BP/V P1491		EC-407
	PURG CN/V & S/V P1493		EC-420
FR O2 SENSOR	FR O2 SENSOR P0130		EC-161
	FR O2 SENSOR P0131		EC-167
	FR O2 SENSOR P0132		EC-172
	FR O2 SENSOR P0133		EC-177
RR O2 SENSOR	RR O2 SENSOR P0137	EC-195	
	RR O2 SENSOR P0138	EC-203	
	RR O2 SENSOR P0139	EC-210	
EGR SYSTEM	EGR SYSTEM P0400	EC-267	
	EGRC-BPT/VLV P0402	EC-275	
	EGR SYSTEM P1402	EC-366	

FUNCTION TEST MODE

NCEC0034S09

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
SELF-DIAG RESULTS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Displays the results of on board diagnostic system. 	—	Objective system

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
CLOSED THROTTLE POSI	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Closed throttle position sensor circuit is tested when throttle is opened and closed fully. ("IDLE POSITION" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> Harness and connector Throttle position sensor (Closed throttle position) Throttle position sensor (Closed throttle position) adjustment Throttle linkage Verify operation in DATA MONITOR mode.
		Throttle valve: closed	ON	
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode.
PARK/NEUT POSI SW CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) PNP switch circuit is tested when shift lever is manipulated. 	Out of N/P positions	OFF	<ul style="list-style-type: none"> Harness and connector PNP switch Linkage or PNP switch adjustment
		In N/P positions	ON	
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level
EGRC SOL/V CIRCUIT*	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) EGRC-solenoid valve circuit is tested by checking solenoid valve operating noise. 	The EGRC-solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector EGRC-solenoid valve
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Cooling fan circuit is tested when cooling fan is rotated. 	The cooling fan rotates and stops every 3 seconds.		<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON → START Start signal circuit is tested when engine is started by operating the starter. Before cranking, battery voltage and engine coolant temperature are displayed. During cranking, average battery voltage, mass air flow sensor output voltage and cranking speed are displayed. 	Start signal: OFF → ON		<ul style="list-style-type: none"> Harness and connector Ignition switch
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine running) Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> Harness and connector Power steering oil pressure switch Power steering oil pump
		Neutral position	OFF	
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor Electric speedometer

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
IGN TIMING ADJ	<ul style="list-style-type: none"> After warming up, idle the engine. Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.	<ul style="list-style-type: none"> Adjust ignition timing (by moving camshaft position sensor or distributor) Camshaft position sensor drive mechanism
MIXTURE RATIO TEST	<ul style="list-style-type: none"> Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the front heated oxygen sensor output at 2,000 rpm under non-loaded state. 	Front heated oxygen sensor COUNT: More than 5 times during 10 seconds	<ul style="list-style-type: none"> INJECTION SYS (Injector, fuel pressure regulator, harness or connector) IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) VACUUM SYS (Intake air leaks) Front heated oxygen sensor circuit Front heated oxygen sensor operation Fuel pressure high or low Mass air flow sensor
POWER BALANCE	<ul style="list-style-type: none"> After warming up, idle the engine. Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multiport fuel injection system is used.) 	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.	<ul style="list-style-type: none"> Injector circuit (Injector, harness or connector) Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) Compression Valve timing
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> After warming up, idle the engine. IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% and at 20%.	<ul style="list-style-type: none"> Harness and connector IACV-AAC valve Air passage restriction between air inlet and IACV-AAC valve IAS (Idle adjusting screw) adjustment

*: If this function test mode is not available, use the "ACTIVE TEST" mode.

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

NCEC00034S10

CONSULT has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1) "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM. DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONITOR cannot continue any longer after the malfunction detection.

2) "MANU TRIG" (Manual trigger):


- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT screen even though a malfunction is detected by ECM. DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


CONSULT (Cont'd)

- 1) "AUTO TRIG"
 - While trying to detect the DTC/1st trip DTC by performing the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)
- 2) "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Generic Scan Tool (GST)




Generic Scan Tool (GST)

=NCEC0035

DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 7 different functions explained on the next page. ISO9141 is used as the protocol. The name "GST" or "Generic Scan Tool" is used in this service manual.


NCEC0035S01



GST INSPECTION PROCEDURE


NCEC0035S02

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.




For further information, see the GST Operation Manual of the tool maker.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Generic Scan Tool (GST) (Cont'd)

FUNCTION		
Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-68).]
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
MODE 4	CLEAR DIAG INFO	<p>This mode can clear all emission-related diagnostic information. This includes:</p> <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	<p>This mode can close EVAP system in ignition switch "ON" position (Engine stopped). When this mode is performed, following parts can be opened or closed.</p> <ul style="list-style-type: none"> ● EVAP canister vent control valve open ● Vacuum cut valve bypass valve closed <p>In the following conditions, this mode cannot function.</p> <ul style="list-style-type: none"> ● Low ambient temperature ● Low battery voltage ● Engine running ● Ignition switch "OFF" ● Low fuel temperature ● Too much pressure is applied to EVAP system.

NCEC0036S03



KEY POINTS	
WHAT	Vehicle & engine model
WHEN	Date, Frequencies
WHERE	Road conditions
HOW	Operating conditions, Weather conditions, Symptoms

SEF907L

Introduction

NCEC0036

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on EC-81.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

DIAGNOSTIC WORKSHEET

NCEC0036S01

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the malfunction indicator lamp to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for the models with EVAP (SMALL LEAK) diagnosis].

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow

Work Flow

NGEC0037

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEF944VB

*1: If the incident cannot be duplicated, refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.

*2: If the on board diagnostic system cannot be performed, check main power supply and ground circuit.

Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-111.
*3: If time data of "SELF-DIAG RESULTS" is other than "0" or "1" refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT", EC-110.
*4: If the malfunctioning part cannot

be found, refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.

*5: EC-91
*6: EC-48

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow (Cont'd)

DESCRIPTION FOR WORK FLOW	
STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-80.
STEP II	<p>Before confirming the concern, check and write down (print out using CONSULT or Generic Scan Tool) the (1st trip) Diagnostic Trouble Code (DTC) and the (1st trip) freeze frame data, then erase the code and the data. (Refer to EC-54.) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV.</p> <p>Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-92.)</p> <p>Also check related service bulletins for information.</p>
STEP III	<p>Try to confirm the symptom and under what conditions the incident occurs.</p> <p>The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.)</p> <p>If the malfunction code is detected, skip STEP IV and perform STEP V.</p>
STEP IV	<p>Try to detect the (1st trip) Diagnostic Trouble Code by driving in (or performing) the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT or Generic Scan Tool.</p> <p>During the (1st trip) DTC verification, be sure to connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.)</p> <p>In case the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" is not available, perform the "OVERALL FUNCTION CHECK" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative.</p> <p>The "NG" result of the "OVERALL FUNCTION CHECK" is the same as the (1st trip) DTC detection.</p>
STEP V	<p>Take the appropriate action based on the results of STEP I through IV.</p> <p>If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX.</p> <p>If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-83.) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-92.)</p>
STEP VI	<p>Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT set in "DATA MONITOR (AUTO TRIG)" mode.</p> <p>Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT. Refer to EC-101.</p> <p>The "DIAGNOSTIC PROCEDURE" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to GI section ("HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection").</p> <p>Repair or replace the malfunction parts.</p>
STEP VII	<p>Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint.</p> <p>Perform the "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" and confirm the normal code [Diagnostic trouble code No. P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one.</p> <p>Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM. (Refer to EC-54.)</p>

NGEC0037501

Basic Inspection

NCEC0038

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT


HA


SC

EL

IDX

1	INSPECTION START	<ol style="list-style-type: none"> 1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance. 2. Open engine hood and check the following: <ul style="list-style-type: none"> ● Harness connectors for improper connections ● Vacuum hoses for splits, kinks, or improper connections ● Wiring for improper connections, pinches, or cuts
		
		SEF142I
With CONSULT		▶ GO TO 2.
Without CONSULT		▶ GO TO 11.


2	CONNECT CONSULT TO THE VEHICLE	<p>Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. Refer to EC-64.</p>
		
		AEC678
		▶ GO TO 3.

3	CHECK IGNITION TIMING	<p>With CONSULT</p> <ol style="list-style-type: none"> 1. Warm up engine to normal operating temperature. 2. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode. 3. Touch "START". <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 80%; text-align: center;"> <p>■ IGN TIMING ADJ ■ □</p> <p>IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.</p> <p style="font-size: 1.2em; font-weight: bold;">START</p> </div> <p>4. Check ignition timing at idle using timing light.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF555N</p> <p>Ignition timing: $15^{\circ} \pm 2^{\circ}$ BTDC (M/T) $15^{\circ} \pm 2^{\circ}$ BTDC (A/T in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td> <ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 4. </td> </tr> </table>	OK	▶	GO TO 4.	NG	▶	<ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 4.
OK	▶	GO TO 4.						
NG	▶	<ol style="list-style-type: none"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 4. 						
		SEF284G						

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

4	CHECK BASE IDLE SPEED						
<p>Ⓟ With CONSULT</p> <p>1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode and touch "START".</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center;">■ IGN TIMING ADJ ■ <input type="checkbox"/></p> <p>IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.</p> <p style="text-align: center; border: 1px solid black; padding: 2px;">START</p> </div> <p style="text-align: right; margin-right: 20px;">SEF546N</p> <p>2. Check idle speed.</p> <p style="margin-left: 20px;">M/T: 750±50 rpm</p> <p style="margin-left: 20px;">A/T: 750±50 rpm (in "P" or "N" position)</p> <p style="text-align: center; margin-left: 100px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td> 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 5. </td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 5.
OK	▶	GO TO 5.					
NG	▶	1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 5.					

5	CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION						
<p>Ⓟ With CONSULT</p> <p>NOTE:</p> <p>Always check ignition timing and base idle speed before performing the following.</p> <ol style="list-style-type: none"> 1. Warm up engine to normal operating temperature. 2. Stop engine. 3. Turn ignition switch "ON". 4. Select "DATA MONITOR" mode with CONSULT. 5. Select "CLSD THL/P SW" from the menu. 6. Read "CLSD THL/P SW" signal under the following conditions. <ul style="list-style-type: none"> ● Insert a 0.15 mm (0.006 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal. <div style="text-align: center; margin: 10px 0;">  <p style="margin: 0;">Throttle drum Feeler gauge</p> <p style="text-align: right; margin-right: 20px;">SEF342W</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center;">☆ MONITOR ☆ NO FAIL <input type="checkbox"/></p> <p style="text-align: center;">CLSD THL/P SW ON</p> </div> <p style="text-align: center; border: 1px solid black; padding: 2px; margin: 10px 0;">RECORD</p> <p style="text-align: right; margin-right: 20px;">SEF577W</p> <p>"CLSD THL/P SW" signal should remain "ON" while inserting 0.15 mm (0.006 in) feeler gauge. "CLSD THL/P SW" signal should remain "OFF" while inserting 0.3 mm (0.012 in) feeler gauge.</p> <p style="text-align: center; margin-left: 100px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 9.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> </table>		OK	▶	GO TO 9.	NG	▶	GO TO 6.
OK	▶	GO TO 9.					
NG	▶	GO TO 6.					

6	ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1												
<p> With CONSULT</p> <p>NOTE:</p> <ul style="list-style-type: none"> ● Never adjust throttle adjust screw (TAS). ● Do not touch throttle drum when checking "CLSD THL/P SW" signal. <p>Doing so may cause an incorrect adjustment.</p> <ol style="list-style-type: none"> 1. Warm engine up to normal operating temperature. 2. Stop engine. 3. Loosen throttle position sensor fixing bolts. 4. Turn ignition switch "ON". 5. Select "CLSD THL/P SW" in "DATA MONITOR" mode. 6. Insert a 0.15 mm (0.006 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure. 													
<p style="text-align: right;">SEF342W</p>													
<ol style="list-style-type: none"> 7. Open throttle valve and then close. 8. Check "CLSD THL/P SW" signal. 													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; text-align: center;">☆ MONITOR</td> <td style="width: 15%; text-align: center;">☆ NO FAIL</td> <td style="width: 15%;"></td> <td style="width: 15%;"></td> </tr> <tr> <td style="text-align: center;">CLSD THL/P SW</td> <td style="text-align: center;">OFF</td> <td style="text-align: center;">OFF</td> <td style="text-align: center;"><input type="checkbox"/></td> </tr> <tr> <td colspan="4" style="text-align: center; padding: 5px;">RECORD</td> </tr> </table> <p style="text-align: right; font-size: small;">SEF122W</p>		☆ MONITOR	☆ NO FAIL			CLSD THL/P SW	OFF	OFF	<input type="checkbox"/>	RECORD			
☆ MONITOR	☆ NO FAIL												
CLSD THL/P SW	OFF	OFF	<input type="checkbox"/>										
RECORD													
<p>"CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed.</p> <p style="text-align: center;">OK or NG</p>													
OK	▶ GO TO 8.												
NG	▶ GO TO 7.												



7	ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2
<p> With CONSULT</p> <p>Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".</p>	
<p style="text-align: right;">SEF033W</p>	
<p>▶ GO TO 8.</p>	


8	ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3
<p> With CONSULT</p> <ol style="list-style-type: none"> 1. Temporarily tighten sensor body fixing bolts. ● Gradually move the sensor body clockwise and stop it when "CLSD THL/P SW" signal switches from "OFF" to "ON" when tightening sensor body fixing bolts. 	
<p style="text-align: right;">SEF033W</p>	
<ol style="list-style-type: none"> 2. Make sure two or three times that the signal is "ON" when the throttle valve is closed and "OFF" when it is opened. 3. Remove 0.15 mm (0.006 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge. 4. Make sure two or three times that the signal remains "OFF" when the throttle valve is closed. 5. Tighten throttle position sensor. 6. Check "CLSD THL/P SW" signal again. <p style="text-align: center;">The signal remains "OFF" while closing throttle valve.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ 1. Remove 0.3 mm (0.012 in) feeler gauge. 2. GO TO 9.
NG	▶ GO TO 6.




CI
 MA
 EV
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IIX


TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

9	RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY				
<p> With CONSULT NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> 1. Start engine. 2. Warm up engine to normal operating temperature. 3. Select "CLSD THL POS" in "DATA MONITOR" mode. 4. Stop engine. (Turn ignition switch "OFF".) 5. Turn ignition switch "ON" and wait at least 5 seconds. 					
					
SEF864V					
<ol style="list-style-type: none"> 6. Turn ignition switch "OFF" and wait at least 5 seconds. 7. Repeat steps 5 and 6 until "CLSD THL POS" in "DATA MONITOR" mode with CONSULT changes to "ON". 					
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;"> ☆ MONITOR ☆ NO FAIL CLSD THL POS ON </td> <td style="text-align: right; vertical-align: top;"><input type="checkbox"/></td> </tr> <tr> <td colspan="2" style="text-align: center; padding: 5px;">RECORD</td> </tr> </table>		☆ MONITOR ☆ NO FAIL CLSD THL POS ON	<input type="checkbox"/>	RECORD	
☆ MONITOR ☆ NO FAIL CLSD THL POS ON	<input type="checkbox"/>				
RECORD					
SEF123W					
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">▶</td> <td style="padding: 5px;">GO TO 10.</td> </tr> </table>		▶	GO TO 10.		
▶	GO TO 10.				

10	CHECK TARGET IDLE SPEED						
<p> With CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "CMPS-RPM (REF)" in "DATA MONITOR" mode. 3. Check idle speed. M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position) <p style="text-align: center;">OK or NG</p>							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="padding: 5px;">INSPECTION END</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td style="padding: 5px;">Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36.</td> </tr> </table>		OK	▶	INSPECTION END	NG	▶	Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36.
OK	▶	INSPECTION END					
NG	▶	Adjust idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36.					

11	CHECK IGNITION TIMING						
<p> Without CONSULT</p> <ol style="list-style-type: none"> 1. Warm up engine to normal operating temperature. 2. Stop engine and disconnect throttle position sensor harness connector. 							
							
SEF341W							
<ol style="list-style-type: none"> 3. Start engine. 4. Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed. 5. Check ignition timing at idle using timing light. 							
							
SEF284G							
<p>Ignition timing: 15°±2° BTDC (M/T) 15°±2° BTDC (A/T in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p>							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="padding: 5px;">GO TO 12.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td style="padding: 5px;"> 1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 12. </td> </tr> </table>		OK	▶	GO TO 12.	NG	▶	1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 12.
OK	▶	GO TO 12.					
NG	▶	1. Adjust ignition timing by turning distributor. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 12.					

12	CHECK BASE IDLE SPEED						
<p> Without CONSULT</p> <p>Make sure that engine speed falls to the following speed. M/T: 750±50 rpm A/T: 750±50 rpm (in "P" or "N" position)</p> <p style="text-align: center;">OK or NG</p>							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="padding: 5px;">GO TO 13.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td style="padding: 5px;"> 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 13. </td> </tr> </table>		OK	▶	GO TO 13.	NG	▶	1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 13.
OK	▶	GO TO 13.					
NG	▶	1. Adjust base idle speed by turning idle speed adjusting screw. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. 2. GO TO 13.					

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)



13 CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Stop engine.
3. Disconnect closed throttle position switch harness connector.
4. Connect the tester probe to closed throttle position switch terminals 4 and 5.
5. Check harness continuity under the following conditions.



SEF735W

- Insert the 0.15 mm (0.006 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.



SEF342W

"Continuity should exist" while inserting 0.15 mm (0.006 in) feeler gauge.

"Continuity should not exist" while inserting 0.3 mm (0.012 in) feeler gauge.

OK or NG

OK	▶	GO TO 15.
NG	▶	GO TO 14.


14 ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1

⊗ Without CONSULT

NOTE:



- Never adjust throttle adjust screw (TAS).
- Do not touch throttle drum when checking "continuity". Doing so may cause an incorrect adjustment.

1. Warm engine up to normal operating temperature.
2. Stop engine.
3. Loosen throttle position sensor fixing bolts.
4. Disconnect closed throttle position sensor harness connector.
5. Insert 0.15 mm (0.006 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.



SEF342W

6. Open throttle valve then close.
7. Check continuity between closed throttle position switch terminal 4 and 5.



SEF735W

The continuity should not exist while closing the throttle position sensor body.

OK or NG

OK	▶	GO TO 16.
NG	▶	GO TO 15.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

15	ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2
<p> Without CONSULT Turn throttle position sensor body counterclockwise until continuity does not exist.</p>	
▶ GO TO 16.	

16	ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3
<p> Without CONSULT</p> <ol style="list-style-type: none"> Temporarily tighten sensor body fixing bolts. Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then tighten sensor body fixing bolts. 	
<ol style="list-style-type: none"> Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened. Remove 0.15 mm (0.006 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge. Make sure two or three times that continuity does not exist when the throttle valve is closed. Tighten throttle position sensor. Check the continuity again. Continuity does not exist while closing the throttle valve. <p style="text-align: center;">OK or NG</p>	
OK ▶	GO TO 17.
NG ▶	GO TO 14.

17	REINSTALLATION
<p> Without CONSULT</p> <ol style="list-style-type: none"> Remove 0.3 mm (0.012 in) feeler gauge. Reconnect throttle position sensor harness connector and closed throttle position switch harness connector. Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed. 	
▶ GO TO 18.	

18	RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY
<p> Without CONSULT</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> Start engine. Warm up engine to normal operating temperature. Stop engine. (Turn ignition switch "OFF".) Turn ignition switch "ON" and wait at least 5 seconds. 	
<ol style="list-style-type: none"> Turn ignition switch "OFF" and wait at least 5 seconds. Repeat steps 4 and 5, 20 times. 	
▶ GO TO 19.	

19	CHECK TARGET IDLE SPEED
<p> Without CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Check idle speed. M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position) <p style="text-align: center;">OK or NG</p>	
OK ▶	GO TO 20.
NG ▶	<ol style="list-style-type: none"> Adjust target idle speed. Refer to "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment", EC-36. GO TO 20.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

20	ERASE UNNECESSARY DTC
After this inspection, unnecessary DTC No. might be displayed. Erase the stored memory in ECM and TCM. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" (EC-54) and "HOW TO ERASE DTC" in AT section.	
▶	INSPECTION END

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

DTC Inspection Priority Chart

DTC Inspection Priority Chart

NCEC0039

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● P0100 Mass air flow sensor (0102) ● P0110 Intake air temperature sensor (0401) ● P0115, P0125 Engine coolant temperature sensor (0103) (0908) ● P0120 Throttle position sensor (0403) ● P0180 Tank fuel temperature sensor (0402) ● P0325 Knock sensor (0304) ● P0340 Camshaft position sensor (0101) ● P0500 Vehicle speed sensor (0104) ● P0605 ECM (0301) ● P1320 Ignition signal (0201) ● P1400 EGRC-solenoid valve (1005) ● P1605 A/T diagnosis communication line (0804) ● P1706 Park/Neutral position switch (1003)
2	<ul style="list-style-type: none"> ● P0105 Absolute pressure sensor (0803) ● P0130 - P0134 Front heated oxygen sensor (0303 - 0412) ● P0135 Front heated oxygen sensor heater (0901) ● P0137 - P0140 Rear heated oxygen sensor (0510 - 0707) ● P0141 Rear heated oxygen sensor heater (0902) ● P0335, P1336 Crankshaft position sensor (OBD) (0802) (0905) ● P0450 EVAP control system pressure sensor (0704) ● P0510 Closed throttle position switch (0203) ● P0705 - P0725, P0740 - P1760 A/T related sensors, solenoid valves and switches (1101 - 1208) (1108 - 1206) ● P1105 MAP/BARO switch solenoid valve (1302) ● P1401 EGR temperature sensor (0305) ● P1444, P0443 EVAP canister purge volume control valve (0214) (1008) ● P1447 EVAP control system purge flow monitoring (0111) ● P1448, P0446, P1446 EVAP canister vent control valve (0309) (0903) (0215) ● P1490, P1491 Vacuum cut valve bypass valve (0801) (0311) ● P1492, P1493 EVAP canister purge control valve/solenoid valve (0807) (0312)
3	<ul style="list-style-type: none"> ● P0172, P0171 Fuel injection system function (0114), (0115) ● P0300 - P0304 Misfire (0701 - 0605) ● P0400, P1402 EGR function (0302) (0514) ● P0402 EGRC-BPT valve function (0306) ● P0420 Three way catalyst function (0702) ● P0440, P1440 EVAP control system (SMALL LEAK) (0705) (0213) ● P0505 IACV-AAC valve (0205) ● P0731 - P0734, P0744 A/T function (1103 - 1106) (1107) ● P1148 Closed loop control (0307)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Fail-safe Chart

Fail-safe Chart

—NCEC0040

The ECM enters fail-safe mode if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode, the MIL illuminates.

DTC No.		Detected items	Engine operating condition in fail-safe mode	
CONSULT GST	ECM*1			
P0100	0102	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
P0110	0401	Intake air temperature sensor	The ECM functions on the assumption that the intake air temperature is 25°C (77°F).	
P0115	0103	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT displays the engine coolant temperature decided by ECM.	
			Condition	Engine coolant temperature decided (CONSULT display)
			Just as ignition switch is turned ON or Start	40°C (104°F)
			More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
			Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
P0120	0403	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
			Condition	Driving condition
			When engine is idling	Normal
			When accelerating	Poor acceleration
Unable to access ECM	Unable to access Diagnostic Test Mode II	ECM	ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.	
			Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation and IACV-AAC valve operation are controlled under certain limitations.	
			ECM fail-safe operation	
			Engine speed	Engine speed will not rise more than 3,000 rpm
			Fuel injection	Simultaneous multipoint fuel injection system
			Ignition timing	Ignition timing is fixed at the preset valve
			Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls
			IACV-AAC valve	Full open
			Replace ECM, if ECM fail-safe condition is confirmed.	

*: In Diagnostic Test Mode II (Self-diagnostic results)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart

Symptom Matrix Chart SYSTEM — ENGINE CONTROL SYSTEM

NCEC0041

NCEC0041S01

		SYMPTOM											Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION		EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-457
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-35
	Injector circuit	1	1	2	3	2		2	2			2			EC-451
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-27
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-33
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-36
	IACV-AAC valve circuit	1	1	2	3	3	2	2	2	2		2		2	EC-315
	IACV-FICD solenoid valve circuit	2	2	3	3	3	3	3	3	3		3			EC-470
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-36
	Ignition circuit	1	1	2	2	2		2	2			2			EC-343
EGR	EGRC-solenoid valve circuit		2	2	3	3						3			EC-355
	EGR system	2	1	2	3	3	3	2	2	3		3			EC-267, 275, 366
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3		2	EC-111
Air conditioner circuit		2	2	3	3	3	3	3	3	3		3		2	HA section

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Camshaft position sensor circuit	2	2	3	3	3		3	3			3			EC-260
Mass air flow sensor circuit	1	1	2	2	2		2	2			2			EC-116
Front heated oxygen sensor circuit		1	2	3	2		2	2			2			EC-161, 167
Engine coolant temperature sensor circuit	1	1	2	3	2	3	2	2	3		2			EC-140, 156
Throttle position sensor circuit		1	2		2	2	2	2	2		2			EC-145
Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1		1			EC-83
Vehicle speed sensor circuit		2	3		3						3			EC-310
Knock sensor circuit			2								3			EC-250
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-329, 91
Start signal circuit	2													EC-455
PNP switch circuit			3		3		3	3			3			EC-431
Power steering oil pressure switch circuit		2					3	3						EC-462

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

GI
 MA
 EM
 LG
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

SYSTEM — ENGINE MECHANICAL & OTHER

NCEC0041503

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank	5													FE section
	Fuel piping			5	5	5		5	5			5			
	Vapor lock		5												
	Valve deposit														
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5			
Air	Air duct														—
	Air cleaner														
	Air leakage from air duct (Mass air flow sensor — throttle body)		5	5		5		5	5			5			
	Throttle body, Throttle wire	5			5		5			5				FE section	
	Air leakage from intake manifold/Collector/Gasket														
Cranking	Battery	1	1	1		1		1	1					1	EL section
	Alternator circuit														
	Starter circuit	3										1			
	Flywheel/Drive plate	6												EM section	
	PNP switch	4												AT section	

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM section
	Cylinder head gasket										4	5	3		
	Cylinder block												4		
	Piston														
	Piston ring	6	6	6	6	6		6	6			6			
	Connecting rod														
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM section
	Camshaft	5	5	5	5	5		5	5			5			
	Intake valve												3		
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5		5	5			5		FE section	
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5		MA, EM and LC sections	
	Oil level (Low)/Filthy oil														
Cooling	Radiator/Hose/Radiator filler cap													LC section	
	Thermostat									5					
	Water pump														
	Water gallery	5	5	5	5	5		5	5		4	5			
	Cooling fan										5				
	Coolant level (low)/Contaminated coolant														

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

1 - 6: The numbers refer to the order of inspection.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT Reference Value in Data Monitor Mode

CONSULT Reference Value in Data Monitor Mode

NCEC0042

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.

* Specification data may not be directly related to their components signals/values/operations.

(i.e., Adjust ignition timing with a timing light before monitoring IGN TIMING. Specification data might be displayed even when ignition timing is not adjusted to specification. This IGN TIMING monitors the data calculated by the ECM according to the input signals from the camshaft position sensor and other ignition timing related sensors.)

- If the real-time diagnosis results are NG, and the on board diagnostic system results are OK, when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	CONDITION		SPECIFICATION
CMPS-RPM (REF)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.3 - 1.7V
		2,500 rpm	1.8 - 2.4V
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
FR O2 SENSOR	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V
FR O2 MNTR			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
RR O2 SENSOR	<ul style="list-style-type: none"> ● Engine: After warming up 	Revving engine from idle to 3,000 rpm quickly	0 - 0.3V ↔ 0.6 - 1.0V
RR O2 MNTR			LEAN ↔ RICH
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
THRTL POS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Engine: After warming up 	Throttle valve fully closed	0.2 - 0.8V
		Throttle valve fully opened	3.5 - 4.5V
EGR TEMP SEN	<ul style="list-style-type: none"> ● Engine: After warming up 		Less than 4.5V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL/P SW CLSD THL POS	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	A/C switch "OFF"	OFF
		A/C switch "ON" (Compressor operates)	ON
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever "P" or "N"	ON
		Except above	OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is turned	ON
IGNITION SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF 		ON → OFF
INJ PULSE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	2.4 - 3.2 msec
		2,000 rpm	1.9 - 2.8 msec

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION		
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.6 msec	GI
		2,000 rpm	0.7 - 1.3 msec	MA
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	13 - 15° BTDC	EM
		2,000 rpm	More than 25° BTDC	
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	20 - 40%	LC
		2,000 rpm	—	EC
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● No-load ● M/T models: Lift up drive wheels and shift to 1st gear position. 	Idle	0 step	
		More than 60 seconds after starting engine Rev engine up from 2,000 to 4,000 rpm.	More than 1 step	FE
A/F ALPHA	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	53 - 155%	CL
EVAP SYS PRES	<ul style="list-style-type: none"> ● Ignition switch: ON 		Approx. 3.4V	MT
AIR COND RLY	<ul style="list-style-type: none"> ● Air conditioner switch: OFF → ON 		OFF → ON	AT
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking ● When engine is stopped (stops in 1.0 seconds) 		ON	AX
	<ul style="list-style-type: none"> ● Except as shown above 		OFF	
COOLING FAN	<ul style="list-style-type: none"> ● After warming up engine, idle the engine. ● Air conditioner switch: OFF 	Engine coolant temperature is 94°C (201°F) or less	OFF	SU
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F)	LOW	BR
		Engine coolant temperature is 105°C (221°F) or more	HIGH	ST
VENT CONT/V	<ul style="list-style-type: none"> ● Ignition switch: ON 		OFF	RS
EGRC SOL/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N (A/T models) ● No-load ● M/T models: Lift up drive wheels and shift to 1st gear position. 	Idle	OFF (CUT)	
		A/T models: Rev engine up from 2,000 to 4,000 rpm. M/T models: Rev engine up from 2,000 to 4,000 rpm.	ON (FLOW)	BT
FR O2 HEATER	<ul style="list-style-type: none"> ● Engine speed: Below 3,200 rpm 		ON	
	<ul style="list-style-type: none"> ● Engine speed: Above 3,200 rpm 		OFF	SC
RR O2 HEATER	<ul style="list-style-type: none"> ● Engine speed: Running [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 		ON	
	<ul style="list-style-type: none"> ● Ignition switch ON (Engine stopped) 		OFF	EL
VC/V BYPASS/V	<ul style="list-style-type: none"> ● Ignition switch: ON 		OFF	IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION	
PURG CONT S/V	Idle	OFF	
	<ul style="list-style-type: none"> Engine: After warming up No-load M/T models: Lift up drive wheels and shift to 1st gear position. 	More than 60 seconds after starting engine A/T models: 2,000 rpm M/T models: 2,000 rpm and more than 16 km/h (10 MPH)	
CAL/LD VALUE	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: OFF Shift lever: "N" No-load 	Idle	20.0 - 35.5%
		2,500 rpm	17.0 - 30.0%
ABSOL TH·P/S	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) After warming up 	Throttle valve fully closed	0.0%
		Throttle valve fully opened	Approx. 88%
MASS AIRFLOW	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: OFF Shift lever: N No-load 	Idle	2.5 - 5.0 g·m/s
		2,500 rpm	7.1 - 12.5 g·m/s
MAP/BARO SW/V	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Engine speed: Idle 	For 5 seconds after starting engine	MAP
		More than 5 seconds after starting engine	BARO
		More than 5 seconds after starting engine	MAP
ABSOL PRES/SE	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Engine speed: Idle 	For 5 seconds after starting engine	Approx. 4.4V
		More than 5 seconds after starting engine	Approx. 4.4V
		More than 5 seconds after starting engine	Approx. 1.2V

Major Sensor Reference Graph in Data Monitor Mode

NCEC0043


The following are the major sensor reference graphs in "DATA MONITOR" mode.
(Select "HI SPEED" in "DATA MONITOR" with CONSULT.)

THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS

NCEC0043S01

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch "ON".

The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Major Sensor Reference Graph in Data Monitor Mode (Cont'd)

CMPS-RPM (REF), MAS AIR/FL SE, THRTL POS SEN, RR O2 SEN, FR O2 SEN, INJ PULSE

Below is the data for "CMPS-RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SEN", "FR O2 SEN" and "INJ PULSE" when revving engine quickly up to 4,800 rpm under no load after warming up engine to normal operating temperature.

Each value is for reference, the exact value may vary.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "RR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "FR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.




- "INJ PULSE" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

SEF417R

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value



ECM Terminals and Reference Value

NCEC0044

PREPARATION

NCEC0044S01


1. ECM is located behind the center console. For this inspection:
 - Remove the front passenger center console panel.

GI

MA

EM

LC




2. Remove ECM harness protector.

EC

FE

CL

MT



3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

ECM HARNESS CONNECTOR TERMINAL LAYOUT

NCEC0044S02







SEF064P

ECM INSPECTION TABLE



NCEC0044S03

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	W/B	Ignition signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0.2 - 0.3V</p>  <p style="text-align: right;">SEF996V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 0.5V</p>  <p style="text-align: right;">SEF997V</p>
2	W	Ignition check	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 13V</p>  <p style="text-align: right;">SEF998V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 13V</p>  <p style="text-align: right;">SEF999V</p>


TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
3	L/OR	Tachometer	[Engine is running] ● Warm-up condition ● Idle speed	0.6 - 1.6V 	GI MA EM LC
			[Engine is running] ● Engine speed is 2,000 rpm	2 - 3V 	EC
4	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 5 seconds after turning ignition switch "OFF"	0 - 1V	MT
			[Ignition switch "OFF"] ● 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)	AT
5	L	EVAP canister purge volume control valve	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.6V	AX
6	G				SU
7	PU (A/T models)	A/T check signal	[Ignition switch "ON"] [Engine is running]	5 - 7V	BR
8	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 5 seconds after turning ignition switch "ON" [Engine is running]	0 - 1V	ST
			[Ignition switch "ON"] ● More than 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	RS
10	B	ECM ground	[Engine is running] ● Idle speed	Engine ground	BT
13	LG	Cooling fan relay (High)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)	HA
			[Engine is running] ● Cooling fan (High) is operating	0 - 0.6V	SC
14	L/Y	Cooling fan relay (Low)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)	EL
			[Engine is running] ● Cooling fan is operating	0 - 0.6V	IDX
15	L/W	Air conditioner relay	[Engine is running] ● Both A/C switch and blower switch are "ON"	0 - 0.6V	
			[Engine is running] ● A/C switch is "OFF"	BATTERY VOLTAGE (11 - 14V)	



TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	EVAP canister purge volume control valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
17	OR			
18	OR/L	Malfunction indicator lamp	[Ignition switch "ON"]	Approximately 0.1V
			[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
19	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
20	B/Y	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	9 - 12V
21	L/W	Air conditioner switch	[Engine is running] ● Both air conditioner switch and blower switch are "ON" (Compressor operates)	Approximately 0V
			[Engine is running] ● Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
22	G/OR	PNP switch	[Ignition switch "ON"] ● Gear position is "Neutral position" (M/T models) ● Gear position is "N" or "P" (A/T models)	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	BATTERY VOLTAGE (11 - 14V)
23	Y	Throttle position sensor	[Ignition switch "ON"] ● Accelerator pedal released	0.2 - 0.8V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	3.5 - 4.5V
24	Y/R	A/T signal No. 1	[Ignition switch "ON"] [Engine is running] ● Idle speed	6 - 8V
25	SB	Power steering oil pressure switch	[Engine is running] ● Steering wheel is fully turned	Approximately 0V
			[Engine is running] ● Steering wheel is not turned	Approximately 5V
26	Y/G	Vehicle speed sensor	[Engine is running] ● Lift up the vehicle ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH)	0 - Approximately 4.2V  SEF003W
27	Y	Throttle position switch (Closed position)	[Ignition switch "ON"] ● Warm-up condition ● Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Accelerator pedal depressed	Approximately 0V
28	R/Y	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION




ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
29	Y/G	A/T signal No. 2	[Ignition switch "ON"] [Engine is running] ● Idle speed	6 - 8V	GI MA
30	Y/B	A/T signal No. 3	[Ignition switch "ON"]	0V	EM
37	G	Ambient air temperature switch	[Engine is running] ● Idle speed ● Ambient air temperature is above 23.5°C (74°F) ● Air conditioner is operating	Approximately 0.15V	LC
			[Engine is running] ● Idle speed ● Ambient air temperature is above 23.5°C (74°F) ● Air conditioner is not operating	Approximately 0V	EC
			[Engine is running] ● Idle speed ● Ambient air temperature is below 20.5°C (69°F) ● Air conditioner is operating	BATTERY VOLTAGE (11 - 14V)	FE CL
			[Engine is running] ● Idle speed ● Ambient air temperature is below 20.5°C (69°F) ● Air conditioner is not operating	Approximately 4.6V	MT
38	W/R	Ignition switch	[Ignition switch "OFF"]	0V	AT
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	AX
39	B	ECM ground	[Engine is running] ● Idle speed	Engine ground	SU
40 44	L L	Camshaft position sensor (Reference signal)	[Engine is running] ● Warm-up condition ● Idle speed	0.1 - 0.4V 	BR ST
			[Engine is running] ● Engine speed is 2,000 rpm	0.1 - 0.4V 	RS BT HA SC
43	B	ECM ground	[Engine is running] ● Idle speed	Engine ground (Probe this terminal with (-) tester probe when measuring)	EL

IDX



TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
41	B/W	Camshaft position sensor (Position signal)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.5V  SEF004W
			[Engine is running] ● Engine speed is 2,000 rpm	Approximately 2.4V  SEF005W
46	W	Front heated oxygen sensor	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	0 - Approximately 0.7V  SEF008W
47	OR	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.3 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.8 - 2.4V
48	W	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
49	P/L	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
50	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
51	BR/Y	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
52	W	Rear heated oxygen sensor	[Engine is running] ● After warming up to normal operating temperature and engine speed is 2,000 rpm	0 - Approximately 1.0V





TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
53	W	Crankshaft position sensor (OBD)	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	3 - 5V (AC range)  SEF721W	GI
			[Engine is running] <ul style="list-style-type: none"> • Engine speed is 2,000 rpm 	6 - 9V (AC range)  SEF722W	MA EM LC EC
54	W	Knock sensor	[Engine is running] <ul style="list-style-type: none"> • Idle speed 	2.0 - 3.0V	CL
56 61	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	MT
58	L/B	Data link connector for GST	[Engine is running] <ul style="list-style-type: none"> • Idle speed (GST is disconnected) 	6 - 10V	AT
62	R/B	EGR temperature sensor	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	Less than 4.5V	AX
			[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • EGR system is operating 	0 - 1.5V	SU
63	LG/R	Tank fuel temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with fuel temperature	BR
64	G/B	Data link connector for CONSULT	[Engine is running] • Idle speed (CONSULT is connected and turned on)	Approximately 0 - 14V	ST
65	GY/L			Approximately 0 - 10V	
68	G/W			Approximately 0 - 4V	RS
66	W	Absolute pressure sensor	[Ignition switch "ON"] [Engine is running] <ul style="list-style-type: none"> • For 5 seconds after starting engine 	Approximately 4.4V	BT
			[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • More than 5 seconds after starting engine 	Approximately 1.4V	HA
67	W	EVAP control system pressure sensor	[Ignition switch "ON"]	Approximately 3.4V	SC
69	GY/R	MAP/BARO switch solenoid valve	[Ignition switch "ON"] <ul style="list-style-type: none"> • For 5 seconds after turning ignition switch "ON" [Engine is running] <ul style="list-style-type: none"> • For 5 seconds after starting engine 	0 - 1V	EL
			[Ignition switch "ON"] <ul style="list-style-type: none"> • More than 5 seconds after turning ignition switch "ON" [Engine is running] <ul style="list-style-type: none"> • More than 5 seconds after starting engine 	BATTERY VOLTAGE (11 - 14V)	IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
70	W/L	Power supply for ECM (Back-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
101	SB	IACV-AAC valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 10V  <p style="text-align: right; margin-right: 20px;">SEF015W</p>
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	Approximately 5 - 13V  <p style="text-align: right; margin-right: 20px;">SEF016W</p>
102 104 107 109	R/B G/B Y/B L/B	Injector No. 1 Injector No. 3 Injector No. 2 Injector No. 4	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)  <p style="text-align: right; margin-right: 20px;">SEF011W</p>
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)  <p style="text-align: right; margin-right: 20px;">SEF012W</p>
103	P	EGRC-solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● M/T models: Lift up drive wheels and shift to 1st gear position ● Rev engine up from 2,000 to 4,000 rpm 	0 - 0.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
105	PU	EVAP canister purge control solenoid valve	[Engine is running] ● Warm-up condition ● More than 60 seconds after starting engine ● M/T models: Lift up drive wheels and shift to 1st gear position ● Engine speed is 2,000 rpm	Approximately 0V	GI MA EM
			[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)	LC
106	B	ECM ground	[Engine is running] ● Idle speed	Engine ground	EC
108	PU/W	EVAP canister vent control valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	FE
110	R/Y	Rear heated oxygen sensor heater	[Engine is running] ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more	Approximately 0.7V	CL
			[Ignition switch "ON"] ● Engine stopped	BATTERY VOLTAGE (11 - 14V)	MT
112	B	ECM ground	[Engine is running] ● Idle speed	Engine ground	AT
113	W/L	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)	AX
115	OR	Front heated oxygen sensor heater	[Engine is running] ● Engine speed is below 3,200 rpm	Approximately 0V	
			[Engine is running] ● Engine speed is above 3,200 rpm	BATTERY VOLTAGE (11 - 14V)	SU
117	PU/R	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	BR
118	B	ECM ground	[Engine is running] ● Idle speed	Engine ground	ST

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

Description

Description

NCEC0045

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC (1st trip) visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

COMMON I/I REPORT SITUATIONS

NCEC0045S01

STEP in Work Flow	Situation
II	The CONSULT is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "1t".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC data does not appear during the DTC CONFIRMATION PROCEDURE.
VI	The TROUBLE DIAGNOSIS for PXXXX does not indicate the problem area.

Diagnostic Procedure

NCEC0046

1	INSPECTION START
Erase (1st trip) DTCs. Refer to "HOW TO ERASE EMISSION-RELATED INFORMATION" (EC-54).	
	GO TO 2.

2	CHECK GROUND TERMINALS
Check ground terminals for corroding or loose connection. Refer to "Circuit Inspection", "GROUND INSPECTION" in GI section.	
OK or NG	
OK	GO TO 3.
NG	Repair or replace.

3	SEARCH FOR ELECTRICAL INCIDENT
Perform "Incident Simulation Tests" in GI section.	
OK or NG	
OK	GO TO 4.
NG	Repair or replace.

4	CHECK CONNECTOR TERMINALS
Refer to "How to Check Enlarged Contact Spring of Terminal" in GI section.	
OK or NG	
OK	INSPECTION END
NG	Repair or replace connector.



TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit

Main Power Supply and Ground Circuit WIRING DIAGRAM

NCEC0047

EC-MAIN-01



Refer to last page (Foldout page).

M6, E75, M5

F26 W H.S.

TEC522

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

ECM TERMINALS AND REFERENCE VALUE

NCEC0049

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 5 seconds after turning ignition switch "OFF"	0 - 1V
			[Ignition switch "OFF"] ● 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
10	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
19	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
38	W/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
39	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
43	B	ECM ground	[Engine is running] ● Idle speed	Engine ground (Probe this terminal with (-) tester probe when measuring)
56 61	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
70	W/L	Power supply for ECM (Back-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
106	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
112	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
113	W/L	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
118	B	ECM ground	[Engine is running] ● Idle speed	Engine ground

DIAGNOSTIC PROCEDURE

NCEC0049

1	INSPECTION START	
Start engine. Is engine running?		
Yes or No		
Yes	▶	GO TO 4.
No	▶	GO TO 2.

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

2	CHECK POWER SUPPLY-I
<ol style="list-style-type: none"> Turn ignition switch "OFF" and then "ON". Check voltage between ECM terminal 38 and ground with CONSULT or tester. 	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 14.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors E75, M6 Harness connectors M49, F23 Harness for open or short between ECM and ignition switch 	
▶ Repair harness or connectors.	

4	CHECK POWER SUPPLY-II
<ol style="list-style-type: none"> Stop engine. Check voltage between ECM terminals 70, 113 and ground with CONSULT or tester. 	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.



5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors M62, F24 Fuse block (J/B) 7.5A fuse Harness for open or short between ECM and fuse 	
▶ Repair harness or connectors.	

6	CHECK POWER SUPPLY-III
<ol style="list-style-type: none"> Turn ignition switch "ON" and then "OFF". Check voltage between ECM terminals 56, 61 and ground with CONSULT or tester. 	
<p>Voltage:</p> <p>After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop to approximately 0V.</p> <p>OK or NG</p>	
OK	▶ GO TO 14.
NG (Battery voltage does not exist.)	▶ GO TO 7.
NG (Battery voltage exists for more than a few seconds.)	▶ GO TO 13.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY


Main Power Supply and Ground Circuit (Cont'd)

7	CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM						
<p>1. Disconnect ECM harness connector. 2. Disconnect ECM relay.</p>  <p style="text-align: center;">Front door drivers side</p> <p style="text-align: right;">SEF291W</p> <p>3. Check harness continuity between ECM terminals 56, 61 and relay terminal 3.</p>  <p style="text-align: right;">SEF195W</p> <p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 8.</td> </tr> </table>		OK	▶	GO TO 9.	NG	▶	GO TO 8.
OK	▶	GO TO 9.					
NG	▶	GO TO 8.					

8	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness for open or short between ECM relay and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

9	CHECK VOLTAGE BETWEEN ECM RELAY AND GROUND						
<p>Check voltage between relay terminals 1, 5 and ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF196W</p> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 11.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 10.</td> </tr> </table>		OK	▶	GO TO 11.	NG	▶	GO TO 10.
OK	▶	GO TO 11.					
NG	▶	GO TO 10.					


10	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness for open or short between ECM relay and fuse <p style="text-align: right;">▶ Repair harness or connectors.</p>	


11	CHECK OUTPUT SIGNAL CIRCUIT						
<p>1. Check harness continuity between ECM terminal 4 and relay terminal 2.</p>  <p style="text-align: right;">AEC492</p> <p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 13.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 12.</td> </tr> </table>		OK	▶	GO TO 13.	NG	▶	GO TO 12.
OK	▶	GO TO 13.					
NG	▶	GO TO 12.					

12	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness for open or short between ECM relay and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

13	CHECK ECM RELAY
<ol style="list-style-type: none"> 1. Apply 12V direct current between relay terminals 1 and 2. 2. Check continuity between relay terminals 3 and 5. 	
	
<p>12V (1 - 2) applied: Continuity exists. No voltage applied: No continuity</p> <p style="text-align: right;">SEF511P</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 14.
NG	▶ Replace ECM relay.


14	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 10, 19, 39, 43, 106, 112, 118 and engine ground. 	
	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: right;">AEC496</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 15.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

15	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

CI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Component Description



Component Description

NCEC0050

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

CONSULT Reference Value in Data Monitor Mode

NCEC0051

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	1.3 - 1.7V
		2,500 rpm	1.8 - 2.4V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	20.0 - 35.5%
		2,500 rpm	17.0 - 30.0%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	2.5 - 5.0 g·m/s
		2,500 rpm	7.1 - 12.5 g·m/s

ECM Terminals and Reference Value

NCEC0052

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	OR	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.3 - 1.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	1.8 - 2.4V
48	W	Mass air flow sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0053

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P0100 0102	A)	An excessively high voltage from the sensor is sent to ECM when engine is not running.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Mass air flow sensor
	C)	A high voltage from the sensor is sent to ECM under light load driving condition.	
	B)	An excessively low voltage from the sensor is sent to ECM* when engine is running.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Intake air leaks • Mass air flow sensor
	D)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

NCEC0054


Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C". If there is no problem on "PROCEDURE FOR MALFUNCTION C", perform "PROCEDURE FOR MALFUNCTION D".

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.



SEF232UA

PROCEDURE FOR MALFUNCTION A

NCEC0054S01

ⓐ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

ⓑ With GST

- 1) Turn ignition switch "ON", and wait at least 6 seconds.
- 2) Select "MODE 7" with GST.


DTC P0100 MASS AIR FLOW SENSOR (MAFS)

DTC Confirmation Procedure (Cont'd)

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

No Tools

- 1) Turn ignition switch "ON", and wait at least 6 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.



PROCEDURE FOR MALFUNCTION B

NCEC0054S02

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait 5 seconds at most.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

With GST


- 1) Turn ignition switch "ON".
- 2) Start engine and wait 5 seconds at most.
- 3) Select "MODE 7" with GST.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

No Tools

- 1) Turn ignition switch "ON".
- 2) Start engine and wait 5 seconds at most.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

NOTE:

If 1st trip DTC is confirmed after more than 5 seconds, there may be malfunction C.



PROCEDURE FOR MALFUNCTION C

NCEC0054S03

NOTE:

If engine will not start or stops soon wait at least 10 seconds with engine stopped (Ignition switch "ON") instead of running engine at idle speed.

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up to normal operating temperature.
- 4) Run engine for at least 10 seconds at idle speed.

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

DTC Confirmation Procedure (Cont'd)

- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

With GST

- Start engine and warm it up to normal operating temperature.
- Run engine for at least 10 seconds at idle speed.
- Select "MODE 7" with GST.
- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

No Tools

- Start engine and warm it up to normal operating temperature.
- Run engine for at least 10 seconds at idle speed.
- Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

CI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



PROCEDURE FOR MALFUNCTION D

NCEC0054904

With CONSULT

- Turn ignition switch "ON".
- Start engine and warm it up to normal operating temperature. If engine cannot be started, go to "Diagnostic Procedure", EC-122.
- Select "DATA MONITOR" mode with CONSULT.
- Check the voltage of MAS AIR/FL SE with "DATA MONITOR".
- Increases engine speed to about 4,000 rpm.
- Monitor the linear voltage rise in response to engine speed increases.
If NG, go to "Diagnostic Procedure", EC-122.
If OK, go to following step.
- Maintain the following conditions for at least 10 consecutive seconds.

CMPS-RPM (REF)	More than 2,000 rpm
THRTL POS SEN	More than 3V
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-122.

7

☆ MONITOR ☆ NO FAIL

CMPS-RPM(REF) 3000rpm
 VHCL SPEED SE 70km/h
 THRTL POS SEN 3.2V

RECORD


SEF231UA

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Overall Function Check

CALC LOAD	20%
COOLANT TEMP	95°C
SHORT FT #1	2%
LONG FT #1	0%
SHORT FT #2	4%
LONG FT #2	0%
ENGINE SPD	2637RPM
VEHICLE SPD	0MPH
IGN ADVANCE	41.0°
INTAKE AIR	41°C
MAF	14.1gm/sec
THROTTLE POS	3%

SEF534P



SEF999N

Overall Function Check

NCEC0055

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a 1st trip DTC might not be confirmed.

PROCEDURE FOR MALFUNCTION D

NCEC0055S01

With GST

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up to normal operating temperature.
- 3) Select "MODE 1" with GST.
- 4) Check the mass air flow sensor signal with "MODE 1".
- 5) Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.
- 6) If NG, go to "Diagnostic Procedure", EC-122.

No Tools

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up to normal operating temperature.
- 3) Check the voltage between ECM terminal 47 (Mass air flow sensor signal) and ground.
- 4) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.
- 5) If NG, go to "Diagnostic Procedure", EC-122.

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Wiring Diagram

Wiring Diagram

NCEC0066

EC-MAFS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



Refer to last page (Foldout page).

(M5)

(F26)



TEC523

DTC P0100 MASS AIR FLOW SENSOR (MAFS)


Diagnostic Procedure



Diagnostic Procedure

NCEC0057

1	INSPECTION START						
Which malfunction (A, B, C or D) is duplicated?							
<table border="1"> <thead> <tr> <th>MALFUNCTION</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>A and/or C</td> <td>I</td> </tr> <tr> <td>B and/or D</td> <td>II</td> </tr> </tbody> </table>		MALFUNCTION	Type	A and/or C	I	B and/or D	II
MALFUNCTION	Type						
A and/or C	I						
B and/or D	II						
MTBL0063							
Type I or Type II							
Type I	▶ GO TO 3.						
Type II	▶ GO TO 2.						

2	CHECK INTAKE SYSTEM
Check the followings for connection.	
<ul style="list-style-type: none"> • Air duct • Vacuum hoses • Intake air passage between air duct to collector 	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Reconnect the parts.

3	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 4.	

4	CHECK POWER SUPPLY
1. Disconnect mass air flow sensor harness connector.	
 <p>Mass air flow sensor harness connector</p> <p>Air cleaner</p> <p style="text-align: right;">SEF293W</p>	
2. Turn ignition switch "ON".	
3. Check voltage between terminal 2 and ground with CONSULT or tester.	
 <p>DISCONNECT</p> <p>V</p> <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEF197W</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness for open or short between ECM relay and mass air flow sensor • Harness for open or short between mass air flow sensor and ECM 	
▶ Repair harness or connectors.	

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Diagnostic Procedure (Cont'd)

6	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between terminal 3 and ECM terminal 48. 	
SEF198W	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Check harness continuity between terminal 4 and ECM terminal 47. 	
SEF199W	
<p>Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK MASS AIR FLOW SENSOR
Refer to "Component Inspection", EC-124.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace mass air flow sensor.



9	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect joint connector-1. Check the following. <ul style="list-style-type: none"> Continuity between joint connector-1 terminal 2 and ground Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) <p style="text-align: center;">Continuity should exist.</p> Also check harness for short to ground and short to power. Then reconnect joint connector-1. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

10	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Component Inspection



Component Inspection MASS AIR FLOW SENSOR

NCEC0058

NCEC0058S01

1. Turn ignition switch "ON".
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground.


Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.3 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.8 - 2.4
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.


DTC P0105 ABSOLUTE PRESSURE SENSOR

Component Description



Component Description

The absolute pressure sensor is connected to the MAP/BARO switch solenoid valve by a hose. The sensor detects ambient barometric pressure and intake manifold pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises.



On Board Diagnosis Logic

NCEC0060

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P0105 0803	A)	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> • Harness or connectors (Absolute pressure sensor circuit is open or shorted.) • Absolute pressure sensor
	B)	A high voltage from the sensor is sent to ECM under light load driving conditions.	<ul style="list-style-type: none"> • Hoses (Hoses between the intake manifold and absolute pressure sensor are disconnected or clogged.) • Intake air leaks • MAP/BARO switch solenoid valve • Absolute pressure sensor
	C)	A low voltage from the sensor is sent to ECM under heavy load driving conditions.	<ul style="list-style-type: none"> • Absolute pressure sensor

DTC Confirmation Procedure

NCEC0061


Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If the 1st trip DTC is not confirmed on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

DTC P0105 ABSOLUTE PRESSURE SENSOR

DTC Confirmation Procedure (Cont'd)



PROCEDURE FOR MALFUNCTION A

NCEC0061S01

With CONSULT


- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

With GST

- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

No Tools

- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.



PROCEDURE FOR MALFUNCTION B

NCEC0061S02

With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and let it idle.
- 5) Wait at least 15 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine.
- 4) Let engine idle and wait at least 15 seconds.
- 5) Select "MODE 7" with GST.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine.
- 4) Let engine idle and wait at least 15 seconds.
- 5) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

DTC P0105 ABSOLUTE PRESSURE SENSOR

DTC Confirmation Procedure (Cont'd)

7

MONITOR NO FAIL

CMPS•RPM(REF)	4000rpm
VHCL SPEED SE	70km/h
B/FUEL SCHDL	4.8msec
ABSOL PRES/SE	4.4V

RECORD

SEF127VB

PROCEDURE FOR MALFUNCTION C

NCEC0061S03

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT and check "ABSOL PRES/SE" signal.

The voltage of "ABSOL PRES/SE" should be more than 1.74 [V].

If the check result is NG, go to "Diagnostic Procedure", EC-129.

If the check result is OK, go to following step.


- 3) Start engine and warm it up to normal operating temperature.
- 4) Turn ignition switch "OFF" and wait at least 5 seconds.
- 5) Start engine and let it idle for at least 13 seconds.
- 6) Select "DATA MONITOR" mode with CONSULT.
- 7) Drive the vehicle at least 3 consecutive seconds under the following conditions,

B/FUEL SCHDL	More than 3.7 msec
CMPS-RPM (REF)	3,000 - 4,800 rpm
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-129.

ENGINE SPD	0RPM
COOLANT TEMP	69°C
VEHICLE SPD	0MPH
IGN ADVANCE	3.0°
CALC LOAD	0.0%
MAP	101KPaA
MAF	0.25gm/s
THROTTLE POS	0.0%
INTAKE AIR	27°C
FUEL SYS #1	OL
FUEL SYS #2	UNUSED
SHORT FT #1	0.0%
LONG FT #1	0.0%
O2S B1 S1	0.000V
O2FT B1 S1	0.0%
O2S B1 S2	0.000V

SEF518R



Overall Function Check

NCEC0062

PROCEDURE FOR MALFUNCTION C

NCEC0062S01

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

- 1) Turn ignition switch "ON".
- 2) Select absolute pressure sensor signal in "MODE 1" with GST.
- 3) Make sure that the pressure of absolute pressure sensor signal is more than 46 kPa (0.47 kg/cm², 6.7 psi).
- 4) If NG, go to "Diagnostic Procedure", EC-129.

No Tools

- 1) Turn ignition switch "ON".
- 2) Make sure that the voltage between ECM terminal 66 (Absolute pressure sensor signal) and ground is more than 1.74 [V].
- 3) If NG, go to "Diagnostic Procedure", EC-129.




DTC P0105 ABSOLUTE PRESSURE SENSOR

Wiring Diagram

Wiring Diagram

NCEC0063

EC-AP/SEN-01




TLC624


Diagnostic Procedure


If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION A or C", perform "PROCEDURE A" below. If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE B" EC-131.


PROCEDURE A

NCEC0064S01

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 2.	

2	CHECK CONNECTOR
<ol style="list-style-type: none"> Disconnect absolute pressure sensor harness connector. 	
 <p>Absolute pressure sensor harness connector</p> <p>Intake manifold collector</p> <p style="text-align: right;">SEF294W</p>	
<ol style="list-style-type: none"> Check sensor harness connector for water. Water should not exist. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair or replace harness connector.

3	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 1 and engine ground with CONSULT or tester. 	
 <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEF200W</p>	
OK	▶ GO TO 4.
NG	▶ Repair harness or connectors.

4	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Check harness continuity between terminal 3 and engine ground. 	
 <p style="text-align: center;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEF201W</p>	
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0105 ABSOLUTE PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

5	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 66 and terminal 2. 	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness for open or short between ECM and absolute pressure sensor • Harness for open or short between absolute pressure sensor and TCM (Transmission control module) 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK ABSOLUTE PRESSURE SENSOR
<p>"Refer to Component Inspection", EC-133.</p> <p>OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace absolute pressure sensor.

8	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Remove joint connector-2. 3. Check the following. <ul style="list-style-type: none"> • Continuity between joint connector-2 terminal 1 and ground • Joint connector-1 • Joint connector-2 <p>(Refer to "HARNES LAYOUT" in EL section.)</p> <p>Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector-2. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.



9	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

DTC P0105 ABSOLUTE PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

PROCEDURE B

-NCEC0064S02

1	INSPECTION START
<ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Attach the vacuum gauge between the absolute pressure sensor and the rubber tube connected to the MAP/BARO switch solenoid valve. 	
 <p style="text-align: right;">SEF294W</p>	
 <p style="text-align: right;">SEF290W</p>	
Models with CONSULT	▶ GO TO 2.
Models without CONSULT	▶ GO TO 3.


2	CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR						
<p>(With CONSULT)</p> <ol style="list-style-type: none"> Start engine and let it idle. Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT. Touch "MAP" and "BARO" alternately and check for vacuum. 							
<div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>MAP/BARO SW/V MAP</p> <p>===== MONITOR =====</p> <p>CMPS•RPM(REF) 700rpm</p> <p>MAP/BARO SW/V MAP</p> <p>ABSOL PRES/SE 1.3V</p> <p>BARO MAP</p> </div> <p style="text-align: right;">SEF500R</p>							
<div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>MAP/BARO SW/V BARO</p> <p>===== MONITOR =====</p> <p>CMPS•RPM(REF) 700rpm</p> <p>MAP/BARO SW/V BARO</p> <p>ABSOL PRES/SE 4.3V</p> <p>BARO MAP</p> </div> <p style="text-align: right;">SEF498R</p>							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>MAP/BARO SW/V</td> <td>Vacuum</td> </tr> <tr> <td>BARO</td> <td>Should not exist</td> </tr> <tr> <td>MAP</td> <td>Should exist</td> </tr> </table> <p style="text-align: right;">MTBL0079</p>		MAP/BARO SW/V	Vacuum	BARO	Should not exist	MAP	Should exist
MAP/BARO SW/V	Vacuum						
BARO	Should not exist						
MAP	Should exist						
OK or NG							
OK	▶ GO TO 8.						
NG	▶ GO TO 4.						


3	CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR						
<p>(Without CONSULT)</p> <ol style="list-style-type: none"> Start engine and let it idle. Check for vacuum under the following condition. 							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th>Vacuum</th> </tr> </thead> <tbody> <tr> <td>For 5 seconds after starting engine</td> <td>Should not exist</td> </tr> <tr> <td>More than 5 seconds after starting engine</td> <td>Should exist</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0080</p>		Condition	Vacuum	For 5 seconds after starting engine	Should not exist	More than 5 seconds after starting engine	Should exist
Condition	Vacuum						
For 5 seconds after starting engine	Should not exist						
More than 5 seconds after starting engine	Should exist						
OK or NG							
OK	▶ GO TO 8.						
NG	▶ GO TO 4.						

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0105 ABSOLUTE PRESSURE SENSOR


Diagnostic Procedure (Cont'd)

4	CHECK VACUUM HOSE
<ol style="list-style-type: none"> Turn ignition switch "OFF". Check vacuum hose for clogging, cracks, disconnection or improper connection. 	
	
SEF109L	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Clean, repair or replace the hose.

5	CHECK VACUUM PORT
Check vacuum port for clogging.	
	
Intake manifold	
SEF368U	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Clean or repair the vacuum port.

6	CHECK MAP/BARO SWITCH SOLENOID VALVE
Refer to "Component Inspection", EC-340.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace MAP/BARO switch solenoid valve.


7	CHECK INTAKE SYSTEM
Check intake system for air leaks.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Repair it.

8	CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE
<ol style="list-style-type: none"> Turn ignition switch "OFF". Check hose for clogging, cracks, disconnection or improper connection. 	
	
SEF109L	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Repair or reconnect hose.

9	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> Disconnect absolute pressure sensor harness connector. Check sensor harness connector for water. Water should not exist. 	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Repair or replace harness connector.

10	CHECK ABSOLUTE PRESSURE SENSOR
Refer to "Component Inspection", EC-133.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace absolute pressure sensor.

11	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	



Component Inspection ABSOLUTE PRESSURE SENSOR

NCEC0065

NCEC0065S01

1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch "ON" and check output voltage between ECM terminal 66 (Absolute pressure sensor signal) and engine ground.
The voltage should be 3.2 to 4.8V.
4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg) to absolute pressure sensor as shown in figure and check the output voltage.
The voltage should be 1.0 to 1.4V lower than the value measured in step 3.

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
 - Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.
5. If NG, replace absolute pressure sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Component Description



Component Description

NCEC0066

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 28 (Intake air temperature sensor) and ECM terminal 43 (ECM ground).

On Board Diagnosis Logic

NCEC0067

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P0110 0401	A)	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Intake air temperature sensor
	B)	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	

Engine operating condition in fail-safe mode

The ECM functions on the assumption that the intake air temperature is 25°C (77°F).

DTC Confirmation Procedure

NCEC0068


Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

DTC Confirmation Procedure (Cont'd)



PROCEDURE FOR MALFUNCTION A

NCEC068S01

With CONSULT


- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

With GST

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select MODE 7 with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

No Tools

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.



PROCEDURE FOR MALFUNCTION B

NCEC068S02

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

With CONSULT


- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - a) Turn ignition switch "ON".
 - b) Select "DATA MONITOR" mode with CONSULT.
 - c) Check the engine coolant temperature.
 - d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 2) Turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT.
- 4) Start engine.
- 5) Hold vehicle speed more than 70 km/h (44 MPH) for 105 consecutive seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

DTC Confirmation Procedure (Cont'd)

FUEL SYS #1	OPEN
FUEL SYS #2	UNUSED
CALC LOAD	0%
COOLANT TEMP	28°C
SHORT FT #1	0%
LONG FT #1	0%
ENGINE SPD	0RPM
VEHICLE SPD	0km/h
IGN ADVANCE	5.0
INTAKE AIR	25°C
MAF	0.0gm/sec
THROTTLE POS	0%
O2S LOCATION	3
O2S B1,S1	0.380V
O2FT B1,S1	0%
O2S B1,S2	0.000V

SEF950N



SEF006P

With GST

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - a) Turn ignition switch "ON".
 - b) Select MODE 1 with GST.
 - c) Check the engine coolant temperature.
 - d) If the engine coolant temperature is above 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
 - 2) Start engine.
 - 3) Hold vehicle speed more than 70 km/h (44 MPH) for 105 consecutive seconds.
 - 4) Select MODE 7 with GST.
 - 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

No Tools

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - a) Turn ignition switch "ON".
 - b) Check voltage between ECM terminal 51 (Engine coolant temperature sensor signal) and ground.

Voltage: More than 1.0V
 - c) If the voltage is less than 1.0V, turn ignition switch "OFF" and cool down engine.
- Perform the following steps before the voltage is below 1.0V.
 - 2) Start engine.
 - 3) Hold vehicle speed more than 70 km/h (44 MPH) for 105 consecutive seconds.
 - 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
 - 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Wiring Diagram

Wiring Diagram

NCEC0069

EC-IATS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA



SC

EL

IDX



Refer to last page (Foldout page).





TEC525

DTC P0110 INTAKE AIR TEMPERATURE SENSOR


Diagnostic Procedure

Diagnostic Procedure

NCEC0070

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect intake air temperature sensor harness connector.</p>	
 <p>Air duct Intake air temperature sensor harness connector</p>	
SEF213T	
<p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester.</p>	
 <p>DISCONNECT T.S. OFF</p> <p>Voltmeter connected to terminal 1 and ground.</p>	
<p>Voltage: Approximately 5V</p> <p>OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E75, M6 ● Harness connectors M49, F23 ● Harness for open or short between ECM and intake air temperature sensor 	
▶ Repair harness or connectors.	

3	CHECK GROUND CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 2 and engine ground.</p>	
 <p>DISCONNECT T.S. OFF</p>	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p>OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E75, M6 ● Harness connectors M49, F23 ● Harness for open or short between ECM and intake air temperature sensor ● Harness for open or short between intake air temperature sensor and TCM (Transmission control module) 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK INTAKE AIR TEMPERATURE SENSOR
<p>Refer to "Component Inspection", EC-139.</p> <p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Replace intake air temperature sensor.

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	

DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Component Inspection

NCEC0071

NCEC0071S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

Component Inspection INTAKE AIR TEMPERATURE SENSOR

Check resistance as shown in the figure.



SEF205W



SEF012P



<Reference data>

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

If NG, replace intake air temperature sensor.

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Component Description



Component Description

NCEC0072

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 51 (Engine coolant temperature sensor) and ECM terminal 43 (ECM ground).

CONSULT Reference Value in Data Monitor Mode

NCEC0073

MONITOR ITEM	CONDITION	SPECIFICATION
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)

On Board Diagnosis Logic

NCEC0074


DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0115 0103	● An excessively high or low voltage from the sensor is sent to ECM.*	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while the engine is running.		

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0075

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-143.

Ⓢ With GST

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-143.

Ⓜ No Tools

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-143.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Wiring Diagram

Wiring Diagram

NCEC0076



EC-ECTS-01




TEC526

Diagnostic Procedure

NCEC0077

1	CHECK POWER SUPPLY						
<p>1. Turn ignition switch "OFF". 2. Disconnect engine coolant temperature sensor harness connector.</p>  <p>Engine coolant temperature sensor harness connector ASCD actuator</p> <p style="text-align: right;">SEF296W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester.</p>  <p>Voltmeter Terminal 1 Ground</p> <p style="text-align: right;">SEF206W</p> <p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>		OK	▶	GO TO 3.	NG	▶	GO TO 2.
OK	▶	GO TO 3.					
NG	▶	GO TO 2.					

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E123, F6 • Harness for open or short between ECM and engine coolant temperature sensor <p style="text-align: right;">▶ Repair harness or connectors.</p>	

3	CHECK GROUND CIRCUIT						
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 2 and engine ground.</p>  <p style="text-align: right;">SEF207W</p> <p style="text-align: center;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.					
NG	▶	GO TO 4.					

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E123, F6 • Harness for open or short between ECM and engine coolant temperature sensor • Harness for open or short between engine coolant temperature sensor and TCM (Transmission control module) <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	


5	CHECK ENGINE COOLANT TEMPERATURE SENSOR						
<p>Refer to "Component Inspection", EC-144.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace engine coolant temperature sensor.</td> </tr> </table>		OK	▶	GO TO 6.	NG	▶	Replace engine coolant temperature sensor.
OK	▶	GO TO 6.					
NG	▶	Replace engine coolant temperature sensor.					

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <p style="text-align: right;">▶ INSPECTION END</p>	

GI
 MA
 EM
 LC
EC
 FE
 GI
 MI
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IX

DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Component Inspection



Component Inspection

ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.


<Reference data>

NCEC0078

NCEC0078501

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.



DTC P0120 THROTTLE POSITION SENSOR

Component Description

Component Description


NCEC0079

NOTE:

If DTC P0120 (0403) is displayed with DTC P0510 (0203), first perform trouble diagnosis for DTC P0510, EC-320.

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT Reference Value in Data Monitor Mode

NCEC0080

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL POS SEN	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Engine: After warming up 	Throttle valve: fully closed	0.2 - 0.8V
		Throttle valve: fully opened	3.5 - 4.5V
ABSOL TH-P/S	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Engine: After warming up 	Throttle valve: fully closed	0.0%
		Throttle valve: fully opened	Approx. 88%

ECM Terminals and Reference Value

NCEC0081

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
23	Y	Throttle position sensor	[Ignition switch "ON"] <ul style="list-style-type: none"> Warm-up condition Accelerator pedal fully released 	0.2 - 0.8V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Accelerator pedal fully depressed 	3.5 - 4.5V
49	P/L	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V

DTC P0120 THROTTLE POSITION SENSOR

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V

On Board Diagnosis Logic

NCEC0082

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0120 0403	A) An excessively low or high voltage from the sensor is sent to ECM.*	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor
	B) A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor ● Fuel injector ● Camshaft position sensor ● Mass air flow sensor
	C) A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Intake air leaks ● Throttle position sensor

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

NCEC0083

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)

NCEC0083S01


PROCEDURE FOR MALFUNCTION A

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.



With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

With GST

- 1) Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

No Tools


- 1) Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)



PROCEDURE FOR MALFUNCTION B

NCEC0083502

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

A/T model	Selector lever	Suitable position except "P" or "N" position
	Brake pedal	Depressed
	Vehicle speed	0 km/h (0 MPH)
M/T model	Selector lever	Suitable position except "N" (Higher gear position such as 3rd or 4th is better to keep low engine rpm.)
	Accelerator pedal	Released
	Vehicle speed	As slow as possible

- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

With GST

- 1) Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

A/T model	Selector lever	Suitable position except "P" or "N" position
	Brake pedal	Depressed
	Vehicle speed	0 km/h (0 MPH)
M/T model	Selector lever	Suitable position except "N" (Higher gear position such as 3rd or 4th is better to keep low engine rpm.)
	Accelerator pedal	Released
	Vehicle speed	As slow as possible

- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

No Tools

- 1) Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

A/T model	Selector lever	Suitable position except "P" or "N" position
	Brake pedal	Depressed
	Vehicle speed	0 km/h (0 MPH)

DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)

M/T model	Selector lever	Suitable position except "N" (Higher gear position such as 3rd or 4th is better to keep low engine rpm.)	GI
	Accelerator pedal	Released	MA
	Vehicle speed	As slow as possible	

- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC




EL

IDX

DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)

NCEC0083S03



PROCEDURE FOR MALFUNCTION C

CAUTION:

Always drive vehicle at a safe speed.

ⓑ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT.
- 5) Select "THRTL POS SEN" and "ABSOL TH·P/S" in "DATA MONITOR" mode with CONSULT.
- 6) Press RECORD on CONSULT SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.



If NG, go to "Diagnostic Procedure", EC-153.
If OK, go to following step.
- 8) Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT.
- 9) Maintain the following conditions for at least 10 consecutive seconds.

CMPS·RPM (REF)	More than 2,000 rpm
MAS AIR/FL SE	More than 3V
COOLAN TEMP/S	More than 70°C (158°F)
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

- 10) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)



With GST

- 1) Maintain the following conditions for at least 10 consecutive seconds.

Gear position	Suitable position
Engine speed	More than 2,000 rpm
Engine coolant temperature	More than 70°C (158°F)
Voltage between ECM terminal 47 (Mass air flow sensor signal) and ground	More than 3V

- 2) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

No Tools

- 1) Maintain the following conditions for at least 10 consecutive seconds.

Gear position	Suitable position
Engine speed	More than 2,000 rpm
Voltage between ECM terminal 47 (Mass air flow sensor signal) and ground	More than 3V
Voltage between ECM terminal 51 (Engine coolant temperature sensor signal) and ground	Less than 1.5V

- 2) Stop the vehicle, turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-153.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




DTC P0120 THROTTLE POSITION SENSOR

Wiring Diagram

Wiring Diagram

NCEC0084

EC-TPS-01




TEC527



Diagnostic Procedure


1	INSPECTION START
Which malfunction A, B or C is duplicated?	
MALFUNCTION	Type
A	A
B	B
C	C
MTBL0066	
Type A, B or C	
Type A or B	▶ GO TO 4.
Type C	▶ GO TO 2.

2	ADJUST THROTTLE POSITION SENSOR
Perform "Basic Inspection", EC-83.	
OK or NG	
OK	▶ GO TO 3.

3	CHECK INTAKE SYSTEM
Check the followings for connection.	
<ul style="list-style-type: none"> ● Air duct ● Vacuum hoses ● Intake air passage between air duct to intake manifold collector 	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Reconnect the parts.

4	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 5.	

5	CHECK POWER SUPPLY
<ol style="list-style-type: none"> 1. Disconnect throttle position sensor harness connector. 	
 <p>Throttle body</p> <p>Throttle position sensor harness connector</p> <p>Throttle position switch harness connector</p> <p style="text-align: right;">SEF297W</p>	
<ol style="list-style-type: none"> 2. Turn ignition switch "ON". 3. Check voltage between terminal 3 and ground with CONSULT or tester. 	
 <p style="text-align: right;">SEF209W</p>	
Voltage: Approximately 5V	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair harness or connectors.

6	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 1 and engine ground. 	
 <p style="text-align: right;">SEF210W</p>	
Continuity should exist.	
<ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0120 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

7	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM and throttle position sensor ● Harness for open or short between throttle position sensor and TCM (Transmission control module) 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 23 and terminal 2. 	
SEF211W	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK THROTTLE POSITION SENSOR
Refer to "Component Inspection", EC-155.	
OK or NG	
OK (Type B in step1)	▶ GO TO 10.
OK (Type A or C in step1)	▶ GO TO 13.
NG	▶ Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-83.



10	CHECK MASS AIR FLOW SENSOR
Refer to "Component Inspection", EC-124.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace mass air flow sensor.

11	CHECK CAMSHAFT POSITION SENSOR
Refer to "Component Inspection", EC-266.	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Replace camshaft position sensor.

12	CHECK FUEL INJECTOR
Refer to "Component Inspection", EC-453.	
OK or NG	
OK	▶ GO TO 13.
NG	▶ Replace fuel injector.

13	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Remove joint connector-1. 3. Check the following. <ul style="list-style-type: none"> ● Continuity between joint connector-1 terminal 2 and ground ● Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) <p style="text-align: center;">Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. 	
OK or NG	
OK	▶ GO TO 14.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

14	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection THROTTLE POSITION SENSOR

NCEC0086

NCEC0086S01

④ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT.
- 4) Check voltage of "THRTL POS SEN" under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage (V)
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-83.

- 5) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and turn ignition switch "ON".
- 3) Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.



Throttle valve conditions	Voltage (V)
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-83.

- 4) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

Component Description



Component Description

NCEC0087

NOTE:

If DTC P0125 (0908) is displayed with P0115 (0103), first perform trouble diagnosis for DTC P0115, EC-140.

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	9.2
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 51 (Engine coolant temperature sensor) and ECM terminal 43 (ECM ground).

CONSULT Reference Value in Data Monitor Mode


NCEC0088

MONITOR ITEM	CONDITION	SPECIFICATION
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)

On Board Diagnosis Logic

NCEC0089

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0125 0908	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> ● Harness or connectors (High resistance in the circuit) ● Engine coolant temperature sensor ● Thermostat



DTC Confirmation Procedure

NCEC0090

CAUTION:

Be careful not to overheat engine.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

DTC Confirmation Procedure (Cont'd)



- 3) Check that "COOLAN TEMP/S" is above 15°C (59°F).
If it is above 15°C (59°F), the test result will be OK. If it is below 15°C (59°F), go to following step.
- 4) Start engine and run it for 65 minutes at idle speed.
If "COOLAN TEMP/S" increases to more than 15°C (59°F) within 65 minutes, stop engine because the test result will be OK.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-159.

With GST

- 1) Turn ignition switch "ON".
- 2) Select "MODE 1" with GST.
- 3) Check that engine coolant temperature is above 15°C (59°F).
If it is above 15°C (59°F), the test result will be OK. If it is below 15°C (59°F), go to following step.
- 4) Start engine and run it for 65 minutes at idle speed.
If engine coolant temperature increases to more than 15°C (59°F) within 65 minutes, stop engine because the test result will be OK.
- 5) Select "MODE 7" with GST.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-159.

No Tools

- 1) Turn ignition switch "ON".
- 2) Check that voltage between ECM terminal 51 (Engine coolant temperature sensor signal) and ground is less than 3.72V.
If it is less than 3.72V, the test result will be OK. If it is over 3.72V, go to following step.
- 3) Start engine and run it for 65 minutes at idle speed. Then measure voltage between ECM terminal 51 and ground.
If the voltage decreases to less than 3.72V within 65 minutes, stop engine because the test result will be OK.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-159.





DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR


Diagnostic Procedure

Diagnostic Procedure

NCEC0092

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect engine coolant temperature sensor harness connector.</p>  <p style="text-align: right;">SEF296W</p>	
<p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF206W</p> <p>Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E123, F6 • Harness for open or short between ECM and engine coolant temperature sensor 	
▶ Repair harness or connectors.	

3	CHECK GROUND CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 2 and engine ground.</p>  <p style="text-align: right;">SEF207W</p> <p style="text-align: center;">Continuity should exist.</p>	
<p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E123, F6 • Harness for open or short between ECM and engine coolant temperature sensor • Harness for open or short between engine coolant temperature sensor and TCM (Transmission control module) 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK ENGINE COOLANT TEMPERATURE SENSOR
<p>Refer to "Component Inspection" on next page.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Replace engine coolant temperature sensor.


6	CHECK THERMOSTAT OPERATION
<p>When the engine is cooled [lower than 76.5°C (170°F)], condition grasp lower radiator hose and confirm the engine coolant does not flow.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Repair or replace thermostat. Refer to LC section ("Thermostat", "ENGINE COOLING SYSTEM").

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0125 ENGINE COOLANT TEMPERATURE (ECT) SENSOR

Diagnostic Procedure (Cont'd)

7	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection

ENGINE COOLANT TEMPERATURE SENSOR

NCEC0093


Check resistance as shown in the figure.

NCEC0093S01

<Reference data>


Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.



DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

Component Description




SEF463R

Component Description

NCEC0094

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



SEF288D

CONSULT Reference Value in Data Monitor Mode

NCEC0095

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FR O2 SENSOR		0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR	<ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value

NCEC0096


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	W	Front heated oxygen sensor	[Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V

SEF008W

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

On Board Diagnosis Logic






On Board Diagnosis Logic

NCEC0007

Under the condition in which the front heated oxygen sensor signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0130 0303	<ul style="list-style-type: none"> The voltage from the sensor is constantly approx. 0.3V. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Front heated oxygen sensor



DTC Confirmation Procedure

NCEC0098

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

⑤ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "FR O2 SENSOR P0130" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- 3) Touch "START".
- 4) Let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 4.

- 5) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

CMPS-RPM (REF)	1,400 - 2,800 rpm (A/T) 2,200 - 2,800 rpm (M/T)
Vehicle speed	70 - 100 km/h (43 - 62 MPH)
B/FUEL SCHDL	1.0 - 4.5 msec (A/T) 1.0 - 3.7 msec (M/T)
Selector lever	Suitable position


If "TESTING" is not displayed after 5 minutes, retry from step 2.

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

DTC Confirmation Procedure (Cont'd)

- 6) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-165.

During this test, P1148 may be displayed on CONSULT screen.



Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
- 4) If NG, go to "Diagnostic Procedure", EC-165.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

Wiring Diagram


Wiring Diagram

NCEC0100

EC-FRO2-01



Refer to last page (Foldout page).






DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

Diagnostic Procedure

Diagnostic Procedure

NCEC0101

1	INSPECTION START
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
<ol style="list-style-type: none"> Disconnect front heated oxygen sensor harness connector. 	
 <p>Distributor</p> <p>Front heated oxygen sensor harness connector</p> <p style="text-align: right;">SEF089P</p>	
▶ GO TO 2.	

2	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Disconnect ECM harness connector. Check harness continuity between ECM terminal 46 and terminal 2. 	
 <p style="text-align: right;">SEF212W</p>	
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> Check harness continuity between ECM terminal 46 (or terminal 2) and ground. <p style="text-align: center;">Continuity should not exist.</p> <ol style="list-style-type: none"> Also check harness for short to power. 	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK FRONT HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-166.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace front heated oxygen sensor.

4	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Remove joint connector-1. Check the following. <ul style="list-style-type: none"> Continuity between joint connector-1 terminal 1 and ground Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) <p style="text-align: center;">Continuity should exist.</p> Also check harness for short to ground and short to power. Then reconnect joint connector. 	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair open circuit, short to ground or short to power in harness or connectors.

5	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0130 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (CIRCUIT)

Component Inspection

☆ MONITOR ☆ NO FAIL

CMPS•RPM(REF)	2137rpm
MAS AIR/FL SE	1.96V
COOLAN TEMP/S	84°C
FR O2 SENSOR	0.37V
FR O2 MNTR	LEAN
INJ PULSE	2.6msec

RECORD

SEF084P

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

SEF947V

Component Inspection

NCEC0102

FRONT HEATED OXYGEN SENSOR



NCEC0102S01

④ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"
 - "FR O2 SENSOR" voltage goes above 0.6V at least once.
 - "FR O2 SENSOR" voltage goes below 0.3V at least once.
 - "FR O2 SENSOR" voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



⊗ Without CONSULT


- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)


Component Description



Component Description

NCEC0103

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT Reference Value in Data Monitor Mode

NCEC0104

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FR O2 SENSOR		0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR	<ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value


NCEC0105

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	W	Front heated oxygen sensor	[Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V <p>SEF008W</p>

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

On Board Diagnosis Logic






On Board Diagnosis Logic

NCEC0106

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0131 0411	<ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are not reached to the specified voltages. 	<ul style="list-style-type: none"> Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors Intake air leaks



DTC Confirmation Procedure

NCEC0107

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch “ON” and select “FR O2 SENSOR P0131” of “FRONT O2 SENSOR” in “DTC WORK SUPPORT” mode with CONSULT.
- Touch “START”.
- Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- When the following conditions are met, “TESTING” will be displayed on the CONSULT screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 20 seconds or more.)

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

DTC Confirmation Procedure (Cont'd)

CMPS-RPM (REF)	1,400 - 2,800 rpm (A/T) 2,000 - 3,000 rpm (M/T)
Vehicle speed	80 - 100 km/h (50 - 62 MPH)
B/FUEL SCHDL	1.3 - 4.5 msec (A/T) 1.0 - 4.5 msec (M/T)
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.


- Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-169.

Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- Start engine and warm it up to normal operating temperature.
- Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
- If NG, go to "Diagnostic Procedure", EC-169.





Diagnostic Procedure

1	RETIGHTEN FRONT HEATED OXYGEN SENSOR
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten front heated oxygen sensor. Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb) 	
▶	GO TO 2.

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

2	CLEAR THE SELF-LEARNING DATA.
<p>With CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. Clear the self-learning control coefficient by touching "CLEAR". 	
	
AEC547	
<ol style="list-style-type: none"> Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171 detected? Is it difficult to start engine? 	
<p>Without CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 	
	
SEF293W	
<ol style="list-style-type: none"> Stop engine and reconnect mass air flow sensor harness connector. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0115 detected? Is it difficult to start engine? 	
Yes or No	
Yes	▶ Perform trouble diagnosis for DTC P0171. Refer to EC-229.
No	▶ GO TO 3.

3	CHECK FRONT HEATED OXYGEN SENSOR HEATER
Refer to "Component Inspection", EC-193.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace front heated oxygen sensor.

4	CHECK FRONT HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-171.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace front heated oxygen sensor.

5	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110. Refer to "Wiring Diagram", EC-164, for circuit.	
▶ INSPECTION END	

DTC P0131 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (LEAN SHIFT MONITORING)

Component Inspection

☆ MONITOR ☆ NO FAIL

CMPS•RPM(REF)	2137rpm
MAS AIR/FL SE	1.96V
COOLAN TEMP/S	84°C
FR O2 SENSOR	0.37V
FR O2 MNTR	LEAN
INJ PULSE	2.6msec

RECORD

SEF084P

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

SEF947V

Component Inspection

NCEC0110

FRONT HEATED OXYGEN SENSOR



NCEC0110S02

④ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"
 - "FR O2 SENSOR" voltage goes above 0.6V at least once.
 - "FR O2 SENSOR" voltage goes below 0.3V at least once.
 - "FR O2 SENSOR" voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)


Component Description



Component Description

NCEC0111

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT Reference Value in Data Monitor Mode

NCEC0112

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
FR O2 SENSOR			0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value


NCEC0113

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	W	Front heated oxygen sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V</p> <p>SEF008W</p>

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

On Board Diagnosis Logic






On Board Diagnosis Logic

NCEC0114

To judge the malfunction, the output from the front heated oxygen sensor is monitored to determine whether the "rich" output is sufficiently high. The "lean" output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0132 0410	<ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are beyond the specified voltages. 	<ul style="list-style-type: none"> Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors



DTC Confirmation Procedure

NCEC0115

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch "ON" and select "FR O2 SENSOR P0132" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- Touch "START".
- Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 20 seconds or more.)


DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

DTC Confirmation Procedure (Cont'd)

CMPS-RPM (REF)	1,400 - 2,800 rpm (A/T) 2,000 - 3,000 rpm (M/T)
Vehicle speed	80 - 100 km/h (50 - 62 MPH)
B/FUEL SCHDL	1.3 - 4.5 msec (A/T) 1.0 - 4.5 msec (M/T)
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-174.



Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

NCEC0116

⊗ Without CONSULT

- Start engine and warm it up to normal operating temperature.
- Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
- If NG, go to "Diagnostic Procedure", EC-174.



Diagnostic Procedure

NCEC0117

1	RETIGHTEN FRONT HEATED OXYGEN SENSOR
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten front heated oxygen sensor. Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb) 	
▶ GO TO 2.	

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

2	CLEAR THE SELF-LEARNING DATA
<p>(A) With CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. Clear the self-learning control coefficient by touching "CLEAR". 	
	
AEC547	
<ol style="list-style-type: none"> Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0172 detected? Is it difficult to start engine? 	
<p>(B) Without CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 	
	
SEF293W	
<ol style="list-style-type: none"> Stop engine and reconnect mass air flow sensor harness connector. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 detected? Is it difficult to start engine? 	
Yes or No	
Yes	▶ Perform trouble diagnosis for DTC P0172. Refer to EC-235.
No	▶ GO TO 3.

3	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect front heated oxygen sensor harness connector. Check harness connector for water. Water should not exit. 	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair or replace harness connector.

4	CHECK FRONT HEATED OXYGEN SENSOR HEATER
Refer to "Component Inspection", EC-193.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace front heated oxygen sensor.

5	CHECK FRONT HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-176.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace front heated oxygen sensor.

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110. Refer to "Wiring Diagram", EC-164, for circuit.	
▶ INSPECTION END	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0132 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RICH SHIFT MONITORING)

Component Inspection

☆ MONITOR ☆ NO FAIL

CMPS•RPM(REF)	2137rpm
MAS AIR/FL SE	1.96V
COOLAN TEMP/S	84°C
FR O2 SENSOR	0.37V
FR O2 MNTR	LEAN
INJ PULSE	2.6msec

RECORD

SEF084P

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

SEF947V

Component Inspection

FRONT HEATED OXYGEN SENSOR

NCEC0118

NCLC0118S02

① With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"
 - "FR O2 SENSOR" voltage goes above 0.6V at least once.
 - "FR O2 SENSOR" voltage goes below 0.3V at least once.
 - "FR O2 SENSOR" voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


	CMPS •RPM (REF) (rpm)	FR O2 SEN (V)
09"13	2050	0.19
09"11	2050	0.18
09"09	2050	0.18
09"07	2037	0.18
09"05	2037	0.18
09"03	2060	0.23
09"01	2012	0.43

FR O2 SENSOR x0.01V

- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

GRAPH

SEF736W



⊗ Without CONSULT


- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

Component Description




SEF463R

Component Description

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

NCEC0119



SEF288D

CONSULT Reference Value in Data Monitor Mode

NCEC0120

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FR O2 SENSOR	<ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR		LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value

NCEC0121


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	W	Front heated oxygen sensor	[Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V

SEF008W

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

On Board Diagnosis Logic




On Board Diagnosis Logic

NCEC0122

To judge the malfunction of front heated oxygen sensor, this diagnosis measures response time of front heated oxygen sensor signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and front heated oxygen sensor temperature index. Judgment is based on whether the compensated time (front heated oxygen sensor cycling time index) is inordinately long or not.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0133 0409	<ul style="list-style-type: none"> The response of the voltage signal from the sensor takes more than the specified time. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Front heated oxygen sensor Front heated oxygen sensor heater Fuel pressure Injectors Intake air leaks Exhaust gas leaks PCV Mass air flow sensor



DTC Confirmation Procedure

NCEC0123

CAUTION:


Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.




With CONSULT

- Start engine and warm it up to normal operating temperature.
- Stop engine and wait at least 5 seconds.
- Turn ignition switch "ON" and select "FR O2 SENSOR P0133" of "FRONT O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- Touch "START".
- Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,200 rpm after this step. If the engine speed limit is exceeded, return to step 5.



- When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 20 seconds.)

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)


DTC Confirmation Procedure (Cont'd)

CMPS-RPM (REF)	1,900 - 3,100 rpm (A/T) 2,200 - 3,200 rpm (M/T)	GI
Vehicle speed	78 - 100 km/h (49 - 62 MPH)	
B/FUEL SCHDL	2.0 - 4.5 msec (A/T) 1.7 - 4.5 msec (M/T)	MA
Selector lever	Suitable position	EM

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-181.

EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Overall Function Check

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed. NCEC0124

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
- 4) If NG, go to "Diagnostic Procedure", EC-181.



DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

Wiring Diagram


Wiring Diagram

NCEC0125

EC-FRO2-01



Refer to last page (Foldout page).




DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)


Diagnostic Procedure

NCEC0126



Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 2.	

2	RETIGHTEN FRONT HEATED OXYGEN SENSOR
Loosen and retighten front heated oxygen sensor. Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)	
▶ GO TO 3.	

3	CHECK EXHAUST AIR LEAK
<ol style="list-style-type: none"> Start engine and run it at idle. Listen for an exhaust air leak before three way catalyst. 	
 <p style="text-align: right;">SEF099P</p>	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair or replace.

4	CHECK FOR INTAKE AIR LEAK
Listen for an intake air leak after the mass air flow sensor.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair or replace.

5	CLEAR THE SELF-LEARNING DATA
Ⓟ With CONSULT <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. Clear the self-learning control coefficient by touching "CLEAR". 	
 <p style="text-align: right;">AEC547</p>	
<ol style="list-style-type: none"> Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171 or P0172 detected? Is it difficult to start engine? 	
Ⓧ Without CONSULT <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 	
 <p style="text-align: right;">SEF293W</p>	
<ol style="list-style-type: none"> Stop engine and reconnect mass air flow sensor harness connector. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 or 0115 detected? Is it difficult to start engine? 	
Yes or No	
Yes	▶ Perform trouble diagnosis for DTC P0171, P0172. Refer to EC-229, 235.
No	▶ GO TO 6.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

6	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect front heated oxygen sensor harness connector and ECM harness connector. 2. Check harness continuity between ECM terminal 46 and terminal 2. 	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> 3. Check harness continuity between ECM terminal 46 (or terminal 2) and ground. <p>Continuity should not exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to power. 	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK FRONT HEATED OXYGEN SENSOR HEATER
Refer to "Component Inspection", EC-193.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace front heated oxygen sensor.

8	CHECK FRONT HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-183.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace front heated oxygen sensor.

9	CHECK MASS AIR FLOW SENSOR
Refer to "Component Inspection", EC-124.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace mass air flow sensor.

10	CHECK PCV VALVE
Refer to "Positive Crankcase Ventilation", EC-33.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Repair or replace PCV valve.

11	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Remove joint connector-1. 3. Check the following. <ul style="list-style-type: none"> • Continuity between joint connector-1 terminal 1 and ground • Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) <p>Continuity should exist.</p> 4. Also check harness for short to ground and short to power. 5. Then reconnect joint connector. 	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Repair open circuit, short to ground or short to power in harness or connectors.

12	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

DTC P0133 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (RESPONSE MONITORING)

Component Inspection

NCEC0127

NCEC0127902

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Component Inspection

FRONT HEATED OXYGEN SENSOR

Ⓜ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" five times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"
 - "FR O2 SENSOR" voltage goes above 0.6V at least once.
 - "FR O2 SENSOR" voltage goes below 0.3V at least once.
 - "FR O2 SENSOR" voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

☆ MONITOR	☆ NO FAIL	<input type="checkbox"/>
CMPS•RPM(REF)	2137rpm	
MAS AIR/FL SE	1.96V	
COOLAN TEMP/S	84°C	
FR O2 SENSOR	0.37V	
FR O2 MNTR	LEAN	
INJ PULSE	2.6msec	

RECORD

SEF084P


cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

SEF947V

	CMPS •RPM (REF) (rpm)	FR O2 SEN (V)
09'13	2050	0.19
09'11	2050	0.18
09'09	2050	0.18
09'07	2037	0.18
09'05	2037	0.18
09'03	2060	0.23
09'01	2012	0.43

GRAPH


FR O2 SENSOR
x0.01V



- Maximum voltage should be over 0.6V at least one time.

- Minimum voltage should be below 0.30V at least one time.

SEF736W



SEF948V

Ⓧ Without CONSULT


- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

Component Description




SEF463R

Component Description

NCEC0128

The front heated oxygen sensor is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



SEF288D

CONSULT Reference Value in Data Monitor Mode

NCEC0129

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FR O2 SENSOR		0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR	<ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value

NCEC0130


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	W	Front heated oxygen sensor	[Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V

SEF008W

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

On Board Diagnosis Logic



On Board Diagnosis Logic

NCEC0131

To judge the malfunction, the diagnosis checks that the front heated oxygen sensor output is not inordinately high.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0134 0412	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Front heated oxygen sensor



SEF361VE

DTC Confirmation Procedure

NCEC0132

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "DATA MONITOR" mode with CONSULT.
- 5) Restart engine and let it idle for 2 minutes.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-188.

With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Restart engine and let it idle for 2 minutes.
- 4) Turn ignition switch "OFF" and wait at least 5 seconds.
- 5) Restart engine and let it idle for 2 minutes.
- 6) Select "MODE 3" with GST.
- 7) If DTC is detected, go to "Diagnostic Procedure", EC-188.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Restart engine and let it idle for 2 minutes.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-188.

- When using GST, "DTC Confirmation Procedure" should

EC-185

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

DTC Confirmation Procedure (Cont'd)

be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT or ECM (Diagnostic Test Mode II) is recommended.

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

Wiring Diagram

Wiring Diagram

NCEC0133

EC-FRO2-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA


SC

EL

IDX



Refer to last page (Foldout page).



TEC528



DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

Diagnostic Procedure

Diagnostic Procedure

NC/EC0134

1	RETIGHTEN FRONT HEATED OXYGEN SENSOR
Loosen and retighten front heated oxygen sensor. Tightening torque: 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)	
▶	GO TO 2.

2	CHECK INPUT SIGNAL CIRCUIT
1. Disconnect front heated oxygen sensor harness connector and ECM harness connector.	
 <p style="text-align: right;">SEF089P</p>	
2. Check harness continuity between ECM terminal 46 and terminal 2.	
 <p style="text-align: right;">SEF212W</p>	
Continuity should exist.	
3. Check harness continuity between ECM terminal 46 (or terminal 2) and ground. Continuity should not exist.	
4. Also check harness for short to power.	
OK or NG	
OK ▶	GO TO 3.
NG ▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK HARNESS CONNECTOR
Check front heated oxygen sensor harness connector for water. Water should not exist.	
OK or NG	
OK ▶	GO TO 4.
NG ▶	Repair or replace harness connector.

4	CHECK FRONT HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-189.	
OK or NG	
OK ▶	GO TO 5.
NG ▶	Replace front heated oxygen sensor.

5	CHECK SHIELD CIRCUIT
1. Turn ignition switch "OFF".	
2. Remove joint connector-1.	
3. Check the following.	
<ul style="list-style-type: none"> ● Continuity between joint connector-1 terminal 1 and ground ● Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) Continuity should exist.	
4. Also check harness for short to ground and short to power. Then reconnect joint connector.	
OK or NG	
OK ▶	GO TO 6.
NG ▶	Repair open circuit, short to ground or short to power in harness or connectors.

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

DTC P0134 FRONT HEATED OXYGEN SENSOR (FRONT HO2S) (HIGH VOLTAGE)

Component Inspection

☆ MONITOR
☆ NO FAIL

CMPS•RPM(REF)	2137rpm
MAS AIR/FL SE	1.96V
COOLAN TEMP/S	84°C
FR O2 SENSOR	0.37V
FR O2 MNTR	LEAN
INJ PULSE	2.6msec

RECORD

SEF084P

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

SEF947V

Component Inspection

NCEC0135

FRONT HEATED OXYGEN SENSOR



NCEC0135S01

ⓑ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" five times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"
 - "FR O2 SENSOR" voltage goes above 0.6V at least once.
 - "FR O2 SENSOR" voltage goes below 0.3V at least once.
 - "FR O2 SENSOR" voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



ⓐ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than five times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0135 FRONT HEATED OXYGEN SENSOR HEATER

Description

Description

NCEC0136

SYSTEM DESCRIPTION

NCEC0136S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Front heated oxygen sensor heater control	Front heated oxygen sensor heater

The ECM performs ON/OFF control of the front heated oxygen sensor heater corresponding to the engine operating condition.

OPERATION

NCEC0136S02

Engine speed	Front heated oxygen sensor heater
Above 3,200 rpm	OFF
Below 3,200 rpm	ON

CONSULT Reference Value in Data Monitor Mode

NCEC0137

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FR O2 HEATER	● Engine speed: Below 3,200 rpm	ON
	● Engine speed: Above 3,200 rpm	OFF

ECM Terminals and Reference Value

NCEC0138

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115	OR	Front heated oxygen sensor heater	[Engine is running] ● Engine speed is below 3,200 rpm.	Approximately 0V
			[Engine is running] ● Engine speed is above 3,200 rpm.	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0139

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0135 0901	<ul style="list-style-type: none"> ● The current amperage in the front heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.) 	<ul style="list-style-type: none"> ● Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) ● Front heated oxygen sensor heater

DTC Confirmation Procedure


NCE00140

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.



With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-193.

With GST

- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine and run it for at least 5 seconds at idle speed.
- 4) Select "MODE 3" with GST.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-193.

No Tools

- 1) Start engine and run it for at least 5 seconds at idle speed.
 - 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
 - 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-193.
- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT or ECM (Diagnostic Test Mode II) is recommended.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0135 FRONT HEATED OXYGEN SENSOR HEATER

Wiring Diagram


Wiring Diagram

NCEC0141

EC-FRO2/H-01



Refer to last page (Foldout page).





TEC529

DTC P0135 FRONT HEATED OXYGEN SENSOR HEATER


Diagnostic Procedure

NCEC0142

Diagnostic Procedure


1	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect front heated oxygen sensor harness connector. 	
	
SEF089P	
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 1 and ground with CONSULT or tester. 	
	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors M62, F24 10A fuse Harness for open or short between front heated oxygen sensor and fuse 	
▶ Repair harness or connectors.	

3	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between terminal 3 and ECM terminal 115. 	
	
SEF214W	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK FRONT HEATED OXYGEN SENSOR HEATER
Refer to "Component Inspection", EC-193.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace front heated oxygen sensor.

5	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	


SEF220W

Component Inspection

FRONT HEATED OXYGEN SENSOR HEATER

NCEC0143
NCEC0143S01

Check resistance between terminals 3 and 1.

Resistance: 2.3 - 4.3 Ω at 25°C (77°F)

Check continuity between terminals 2 and 1, 3 and 2.

Continuity should not exist.

If NG, replace the front heated oxygen sensor.

DTC P0135 FRONT HEATED OXYGEN SENSOR HEATER


Component Inspection (Cont'd)

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

Component Description



Component Description

NCEC0144

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT Reference Value in Data Monitor Mode

NCEC0145

Specification data are reference values.


MONITOR ITEM	CONDITION	SPECIFICATION
RR O2 SENSOR	● Engine: After warming up	0 - 0.3V ↔ Approx. 0.6 - 1.0V
RR O2 MNTR		LEAN ↔ RICH

ECM Terminals and Reference Value

NCEC0146

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
52	W	Rear heated oxygen sensor	[Engine is running] ● After warming up to normal operating temperature and engine speed is 2,000 rpm	0 - Approximately 1.0V



On Board Diagnosis Logic

NCEC0147




The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the minimum voltage of the sensor is sufficiently low during various driving conditions such as fuel-cut.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0137 0511	● The minimum voltage from the sensor does not reach the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

DTC Confirmation Procedure

NCCE0148



DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

④ With CONSULT

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "RR O2 SENSOR P0137" of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm 2 or 3 times quickly under no load. If "COMPLETED" appears on CONSULT screen, go to step 2 in "Procedure for COND3". If "COMPLETED" does not appear on CONSULT screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds.)


CMPS-RPM (REF)	1,400 - 3,400 rpm
Vehicle speed	64 - 120 km/h (40 - 75 MPH)
B/FUEL SCHDL	0.5 - 3.9 msec
Selector lever	Suitable position

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

DTC Confirmation Procedure (Cont'd)




Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT screen has turned to "COMPLETED". (It will take approximately 4 seconds.)


NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".



Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-199.



Overall Function Check

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed. NCEC0149

⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.) **The voltage should be below 0.43V at least once during this procedure.**
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T). **The voltage should be below 0.43V at least once during this procedure.**
- 6) If NG, go to "Diagnostic Procedure", EC-199.



DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

Wiring Diagram

Wiring Diagram

NCEC0150

EC-RRO2-01





DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure

Diagnostic Procedure

NCEC0151



1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p>SEF292W</p>	
▶ GO TO 2.	

2	CLEAR THE SELF-LEARNING DATA																
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. Clear the self-learning control coefficient by touching "CLEAR". 																	
<table border="1" style="margin: auto;"> <tr> <td style="text-align: center;">■ ACTIVE TEST ■</td> <td style="text-align: center;"><input type="checkbox"/></td> </tr> <tr> <td>SELF-LEARN CONTROL</td> <td style="text-align: right;">100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">=== MONITOR ===</td> </tr> <tr> <td>CMPS-RPM (REF)</td> <td style="text-align: right;">812rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td style="text-align: right;">93°C</td> </tr> <tr> <td>FR O2 SENSOR</td> <td style="text-align: right;">0.91V</td> </tr> <tr> <td>A/F ALPHA</td> <td style="text-align: right;">102%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table>		■ ACTIVE TEST ■	<input type="checkbox"/>	SELF-LEARN CONTROL	100%	=== MONITOR ===		CMPS-RPM (REF)	812rpm	COOLAN TEMP/S	93°C	FR O2 SENSOR	0.91V	A/F ALPHA	102%	CLEAR	
■ ACTIVE TEST ■	<input type="checkbox"/>																
SELF-LEARN CONTROL	100%																
=== MONITOR ===																	
CMPS-RPM (REF)	812rpm																
COOLAN TEMP/S	93°C																
FR O2 SENSOR	0.91V																
A/F ALPHA	102%																
CLEAR																	
AEC547																	
<ol style="list-style-type: none"> Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0172 detected? Is it difficult to start engine? 																	
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 																	
 <p>Mass air flow sensor harness connector</p> <p>Air cleaner</p> <p>SEF293W</p>																	
<ol style="list-style-type: none"> Stop engine and reconnect mass air flow sensor harness connector. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 detected? Is it difficult to start engine? 																	
Yes or No																	
Yes	▶ Perform trouble diagnosis for DTC P0172. Refer to EC-235.																
No	▶ GO TO 3.																


CI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)


Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL CIRCUIT						
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect rear heated oxygen sensor harness connector and ECM harness connector. 							
<p>Under the vehicle view</p>  <p style="text-align: right;">SEF298W</p>							
<ol style="list-style-type: none"> Check harness continuity between ECM terminal 52 and terminal 1. 							
 <p style="text-align: right;">SEF215W</p>							
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Check harness continuity between ECM terminal 52 (or terminal 1) and ground. <p>Continuity should not exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 4.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.					
NG	▶	GO TO 4.					

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors B3, M8 Harness connectors M49, F23 Harness for open or short between rear heated oxygen sensor and ECM 	
▶	
<p>Repair open circuit or short to ground or short to power in harness or connectors.</p>	

5	CHECK GROUND CIRCUIT						
<ol style="list-style-type: none"> Check harness continuity between terminal 4 and body ground. 							
 <p style="text-align: right;">SEF216W</p>							
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		OK	▶	GO TO 6.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
OK	▶	GO TO 6.					
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.					

6	CHECK REAR HEATED OXYGEN SENSOR						
<p>Refer to "Component Inspection", EC-201.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 7.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Replace rear heated oxygen sensor.</td> </tr> </table>		OK	▶	GO TO 7.	NG	▶	Replace rear heated oxygen sensor.
OK	▶	GO TO 7.					
NG	▶	Replace rear heated oxygen sensor.					

7	CHECK SHIELD CIRCUIT						
<ol style="list-style-type: none"> Reconnect harness connectors disconnected. Disconnect harness connectors B3, M8. Check harness continuity between terminal 8 and engine ground. 							
 <p style="text-align: right;">SEF217W</p>							
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. Then reconnect harness connectors. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 8.</td> </tr> </table>		OK	▶	GO TO 9.	NG	▶	GO TO 8.
OK	▶	GO TO 9.					
NG	▶	GO TO 8.					

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

8	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors M49, F23 ● Harness connectors B3, M8 ● Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) ● Harness for open or short between harness connector M8 and engine ground 	
▶	Repair open circuit, short to ground or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

GI
MA
EM
LC
EC

■ ACTIVE TEST ■		□
FUEL INJECTION	25%	
===== MONITOR =====		
CMPS-RPM(REF)	725rpm	
FR O2 SENSOR	0.94V	
RR O2 SENSOR	1.89V	
FR O2 MNTR	RICH	
RR O2 MNTR	RICH	
Qu	UP	DWN Qd

SEF102P

Component Inspection REAR HEATED OXYGEN SENSOR

NCEC0152
NCEC0152S01


④ With CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 4) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%. "RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.

CAUTION:


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0137 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MIN. VOLTAGE MONITORING)

Component Inspection (Cont'd)



⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.48V at least once.

If the voltage is above 0.48V at step 4, step 5 is not necessary.

- 5) Check the voltage when revving up to 6,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).


The voltage should be below 0.43V at least once.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

Component Description



Component Description

NCEC0153

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT Reference Value in Data Monitor Mode

NCEC0154

Specification data are reference values.


MONITOR ITEM	CONDITION	SPECIFICATION
RR O2 SENSOR	● Engine: After warming up Revsing engine from idle to 3,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
RR O2 MNTR		LEAN ↔ RICH

ECM Terminals and Reference Value

NCEC0155

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
52	W	Rear heated oxygen sensor	[Engine is running] ● After warming up to normal operating temperature and engine speed is 2,000 rpm	0 - Approximately 1.0V



On Board Diagnosis Logic

NCEC0156

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the maximum voltage of the sensor is sufficiently high during various driving conditions such as fuel-cut.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0138 0510	● The maximum voltage from the sensor does not reach the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

DTC Confirmation Procedure

NCEC0157

8 ■ RR O2 SENSOR P0138 ■ □

COND1: OUT OF COMD
COND2: INCOMPLETE
COND3: INCOMPLETE

===== MONITOR =====

CMPS-RPM(REF) 912rpm
THRTL POS SEN 0.51V
B/FUEL SCHDL 1.0msec

SEF160VB

8 ■ RR O2 SENSOR P0138 ■ □

COND1: **TESTING**
COND2: INCOMPLETE
COND3: INCOMPLETE

===== MONITOR =====

CMPS-RPM(REF) 1687rpm
THRTL POS SEN 0.94V
B/FUEL SCHDL 3.6msec

SEF161VB

8 ■ RR O2 SENSOR P0138 ■ □

COND1: COMPLETED
COND2: INCOMPLETE
COND3: INCOMPLETE

===== MONITOR =====

CMPS-RPM(REF) 1687rpm
THRTL POS SEN 0.94V
B/FUEL SCHDL 3.6msec

SEF162VB

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

④ With CONSULT

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "RR O2 SENSOR P0138" of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm two or three times quickly under no load.
If "COMPLETED" appears on CONSULT screen, go to step 3 in "Procedure for COND2".
If "COMPLETED" does not appear on CONSULT screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds.)


CMPS-RPM (REF)	1,400 - 3,400 rpm
Vehicle speed	64 - 120 km/h (40 - 75 MPH)
B/FUEL SCHDL	0.5 - 3.9 msec
Selector lever	Suitable position

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

DTC Confirmation Procedure (Cont'd)




Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT screen is turned to "COMPLETED". (It will take approximately 4 seconds.)


NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".



Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to "Diagnostic Procedure", EC-207.



Overall Function Check

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.48V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).
The voltage should be above 0.48V at least once during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-207.


DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

Wiring Diagram




Wiring Diagram

NCEC0159

EC-RRO2-01




: Detectable line for DTC
 : Non-detectable line for DTC



Refer to last page (Foldout page).

(M2)





DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

Diagnostic Procedure

Diagnostic Procedure

NCEC0180

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
▶ GO TO 2.	

2	CLEAR THE SELF-LEARNING DATA																
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. 3. Clear the self-learning control coefficient by touching "CLEAR". 																	
<table border="1" style="margin: auto;"> <tr> <td style="text-align: center;">■ ACTIVE TEST ■</td> <td style="text-align: center;"><input type="checkbox"/></td> </tr> <tr> <td>SELF-LEARN CONTROL</td> <td style="text-align: right;">100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">=== MONITOR ===</td> </tr> <tr> <td>CMPS-RPM (REF)</td> <td style="text-align: right;">812rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td style="text-align: right;">93°C</td> </tr> <tr> <td>FR O2 SENSOR</td> <td style="text-align: right;">0.91V</td> </tr> <tr> <td>A/F ALPHA</td> <td style="text-align: right;">102%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table>		■ ACTIVE TEST ■	<input type="checkbox"/>	SELF-LEARN CONTROL	100%	=== MONITOR ===		CMPS-RPM (REF)	812rpm	COOLAN TEMP/S	93°C	FR O2 SENSOR	0.91V	A/F ALPHA	102%	CLEAR	
■ ACTIVE TEST ■	<input type="checkbox"/>																
SELF-LEARN CONTROL	100%																
=== MONITOR ===																	
CMPS-RPM (REF)	812rpm																
COOLAN TEMP/S	93°C																
FR O2 SENSOR	0.91V																
A/F ALPHA	102%																
CLEAR																	
AEC547																	
<ol style="list-style-type: none"> 4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0171 detected? Is it difficult to start engine? 																	
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch "OFF". 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 																	
																	
<ol style="list-style-type: none"> 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. 7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0115 detected? Is it difficult to start engine? 																	
Yes or No																	
Yes	▶ Perform trouble diagnosis for DTC P0171. Refer to EC-229.																
No	▶ GO TO 3.																

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect rear heated oxygen sensor harness connector and ECM harness connector. 2. Check harness continuity between ECM terminal 52 and terminal 1. 	
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> 3. Check harness continuity between ECM terminal 52 (or terminal 1) and ground. Continuity should not exist. 4. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors B3, M8 • Harness connectors M62, F24 • Harness for open or short between ECM and rear heated oxygen sensor 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> 1. Check harness continuity between terminal 3 and engine ground. 	
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> 2. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK REAR HEATED OXYGEN SENSOR
Refer to "Component Inspection", EC-209.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace rear heated oxygen sensor.


7	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Reconnect harness connectors disconnected. 2. Disconnect harness connectors B3, M8. 3. Check harness continuity between terminal 8 and engine ground. 	
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

8	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness connectors B3, M8 • Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) • Harness for open or short between harness connector M8 and engine ground 	
▶	Repair open circuit, short to ground or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

DTC P0138 REAR HEATED OXYGEN SENSOR (REAR HO2S) (MAX. VOLTAGE MONITORING)

Component Inspection



Component Inspection REAR HEATED OXYGEN SENSOR

NCEC0161

NCEC0161S01

④ With CONSULT



- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes..
- 2) Stop vehicle with engine running.
- 3) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 4) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%.

"RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.48V at least once.

If the voltage is above 0.48V at step 4, step 5 is not necessary.

- 5) Check the voltage when revving up to 6,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).

The voltage should be below 0.43V at least once.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

Component Description



Component Description

NCEC0162

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas. Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT Reference Value in Data Monitor Mode

NCEC0163

Specification data are reference values.


MONITOR ITEM	CONDITION		SPECIFICATION
RR O2 SENSOR	● Engine: After warming up	Revsing engine from idle to 3,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
RR O2 MNTR			LEAN ↔ RICH

ECM Terminals and Reference Value

NCEC0164

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
52	W	Rear heated oxygen sensor	[Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 2,000 rpm	0 - Approximately 1.0V



On Board Diagnosis Logic

NCEC0165




The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether the switching response of the sensor's voltage is faster than specified during various driving conditions such as fuel-cut.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0139 0707	● It takes more than the specified time for the sensor to respond between rich and lean.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

DTC Confirmation Procedure

NCEC0166



DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

④ With CONSULT

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "RR O2 SENSOR P0139" of "REAR O2 SENSOR" in "DTC WORK SUPPORT" mode with CONSULT.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm two or three times quickly under no load.
If "COMPLETED" appears on CONSULT screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds.)

CMPS-RPM (REF)	1,400 - 3,400 rpm
Vehicle speed	64 - 120 km/h (40 - 75 MPH)
B/FUEL SCHDL	0.5 - 3.9 msec
Selector lever	Suitable position

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

DTC Confirmation Procedure (Cont'd)




Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT screen has turned to "COMPLETED". (It will take approximately 4 seconds.)

NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".



Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to "Diagnostic Procedure", EC-214.


Overall Function Check

NCEC0167

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ **Without CONSULT**

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).
The voltage should change at more than 0.06V for 1 second during this procedure.
- 6) If NG, go to "Diagnostic Procedure", EC-214.



DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

Wiring Diagram

Wiring Diagram

NCEC0168

EC-RRO2-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX




TEC530


DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

Diagnostic Procedure

Diagnostic Procedure



NCEC0169

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws. 	
	
▶ GO TO 2.	


2	CLEAR THE SELF-LEARNING DATA																
<p>Ⓜ With CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT. 3. Clear the self-learning control coefficient by touching "CLEAR". 																	
<table border="1" style="margin: auto;"> <tr> <td colspan="2" style="text-align: center;">■ ACTIVE TEST ■</td> </tr> <tr> <td>SELF-LEARN CONTROL</td> <td style="text-align: right;">100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">=== MONITOR ===</td> </tr> <tr> <td>CMPS-RPM (REF)</td> <td style="text-align: right;">812rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td style="text-align: right;">93°C</td> </tr> <tr> <td>FR O2 SENSOR</td> <td style="text-align: right;">0.91V</td> </tr> <tr> <td>A/F ALPHA</td> <td style="text-align: right;">102%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table>		■ ACTIVE TEST ■		SELF-LEARN CONTROL	100%	=== MONITOR ===		CMPS-RPM (REF)	812rpm	COOLAN TEMP/S	93°C	FR O2 SENSOR	0.91V	A/F ALPHA	102%	CLEAR	
■ ACTIVE TEST ■																	
SELF-LEARN CONTROL	100%																
=== MONITOR ===																	
CMPS-RPM (REF)	812rpm																
COOLAN TEMP/S	93°C																
FR O2 SENSOR	0.91V																
A/F ALPHA	102%																
CLEAR																	
AEC547																	
<ol style="list-style-type: none"> 4. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC P0172 detected? Is it difficult to start engine? 																	
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch "OFF". 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed. 																	
																	
<ol style="list-style-type: none"> 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II. 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION", EC-54. 7. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II. 8. Run engine for at least 10 minutes at idle speed. Is the 1st trip DTC 0114 detected? Is it difficult to start engine? 																	
Yes or No																	
Yes	▶ Perform trouble diagnosis for DTC P0172. Refer to EC-235.																
No	▶ GO TO 3.																

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)


Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL CIRCUIT						
<p>1. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.</p> <p>Under the vehicle view</p>  <p style="text-align: right;">SEF298W</p>							
<p>2. Check harness continuity between ECM terminal 52 and terminal 1.</p>  <p style="text-align: right;">SEF215W</p> <p>Continuity should exist.</p>							
<p>3. Check harness continuity between ECM terminal 52 (or terminal 1) and ground.</p> <p>Continuity should not exist.</p>							
<p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 4.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.					
NG	▶	GO TO 4.					

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors B3, M8 • Harness connectors M62, F24 • Harness for open or short between rear heated oxygen sensor and ECM 	
▶	
<p>Repair open circuit or short to ground or short to power in harness or connectors.</p>	

5	CHECK GROUND CIRCUIT						
<p>1. Check harness continuity between terminal 3 and engine ground.</p>  <p style="text-align: right;">SEF216W</p> <p>Continuity should exist.</p>							
<p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		OK	▶	GO TO 6.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
OK	▶	GO TO 6.					
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.					

6	CHECK REAR HEATED OXYGEN SENSOR						
<p>Refer to "Component Inspection", EC-216.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 7.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Replace rear heated oxygen sensor.</td> </tr> </table>		OK	▶	GO TO 7.	NG	▶	Replace rear heated oxygen sensor.
OK	▶	GO TO 7.					
NG	▶	Replace rear heated oxygen sensor.					

7	CHECK SHIELD CIRCUIT						
<p>1. Reconnect harness connectors disconnected.</p> <p>2. Disconnect harness connectors B3, M8.</p> <p>3. Check harness continuity between terminal 8 and engine ground.</p>  <p style="text-align: right;">SEF217W</p> <p>Continuity should exist.</p>							
<p>4. Also check harness for short to ground and short to power.</p> <p>5. Then reconnect harness connectors.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 9.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 8.</td> </tr> </table>		OK	▶	GO TO 9.	NG	▶	GO TO 8.
OK	▶	GO TO 9.					
NG	▶	GO TO 8.					


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

8	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors M62, F24 ● Harness connectors B3, M8 ● Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) ● Harness for open or short between harness connector M8 and engine ground 	
▶	Repair open circuit, short to ground or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection REAR HEATED OXYGEN SENSOR

NCEC0170

NCEC0170S01

Ⓜ With CONSULT


- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 4) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%.

"RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



DTC P0139 REAR HEATED OXYGEN SENSOR (REAR HO2S) (RESPONSE MONITORING)

Component Inspection (Cont'd)



⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.48V at least once.
If the voltage is above 0.48V at step 4, step 5 is not necessary.
- 5) Check the voltage when revving up to 6,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).
The voltage should be below 0.43V at least once.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
FA
SC
EL
IDX

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

Component Description



Component Description

NCEC0171

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas. Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

CONSULT Reference Value in Data Monitor Mode

NCEC0172

Specification data are reference values.


MONITOR ITEM	CONDITION		SPECIFICATION
RR O2 SENSOR	● Engine: After warming up	Revsing engine from idle to 3,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
RR O2 MNTR			LEAN ↔ RICH

ECM Terminals and Reference Value

NCEC0173

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
52	W	Rear heated oxygen sensor	[Engine is running] ● After warming up to normal operating temperature and revving engine from idle to 2,000 rpm	0 - Approximately 1.0V



On Board Diagnosis Logic


NCEC0174

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors whether or not the voltage is too high during various driving conditions such as fuel-cut.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0140 0512	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Rear heated oxygen sensor

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0175

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

ⓐ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) Stop vehicle with engine running.
- 4) Let engine idle for 1 minute.
- 5) Maintain the following conditions for at least 5 consecutive seconds.

CMPS-RPM (REF)	1,400 - 3,400 rpm
VHCL SPEED SE	64 - 120 km/h (40 - 75 MPH)
B/FUEL SCHDL	0.5 - 3.9 msec
COOLAN TEMP/S	70 - 100°C (158 - 212°F)
Selector lever	Suitable position

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-221.



Overall Function Check

NCEC0176

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.

ⓧ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage after revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 2V during this procedure.
- 5) If NG, go to "Diagnostic Procedure", EC-221.



DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

Wiring Diagram

Wiring Diagram

NCEC0177

EC-RRO2-01



Refer to last page (Foldout page).



TEC530

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

Diagnostic Procedure

Diagnostic Procedure

NCEC0178

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
▶ GO TO 2.	

2	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Disconnect rear heated oxygen sensor harness connector and ECM harness connector. 	
<p>Under the vehicle view</p>	
<ol style="list-style-type: none"> Check harness continuity between ECM terminal 52 and terminal 1. 	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Check harness continuity between ECM terminal 52 (or terminal 1) and ground. <p>Continuity should not exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors B3, M8 Harness connectors M62, F24 Harness for open or short between rear heated oxygen sensor and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

4	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Check harness continuity between terminal 3 and engine ground. 	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK HARNESS CONNECTOR
<p>Check rear heated oxygen sensor harness connector for water. Water should not exist.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Repair or replace harness connector.

6	CHECK REAR HEATED OXYGEN SENSOR
<p>Refer to "Component Inspection", EC-222.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Replace rear heated oxygen sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

7	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Reconnect harness connectors disconnected. 2. Disconnect harness connectors B3, M8. 3. Check harness continuity between terminal 8 and engine ground. 	
SEF217W	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Then reconnect harness connectors. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

8	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness connectors B3, M8 • Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) • Harness for open or short between harness connector M8 and engine ground 	
▶	Repair open circuit, short to ground or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

■ ACTIVE TEST ■	
FUEL INJECTION	25%
----- MONITOR -----	
CMPS-RPM(REF)	725rpm
FR O2 SENSOR	0.94V
RR O2 SENSOR	1.89V
FR O2 MNTR	RICH
RR O2 MNTR	RICH
Qu	UP
	DWN
	Qd
SEF102P	

Component Inspection

REAR HEATED OXYGEN SENSOR

NCEC0179

NCEC0179S01

With CONSULT


- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 4) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%.

"RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



DTC P0140 REAR HEATED OXYGEN SENSOR (REAR HO2S) (HIGH VOLTAGE)

Component Inspection (Cont'd)



⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminals 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.48V at least once.
If the voltage is above 0.48V at step 4, step 5 is not necessary.

- 5) Check the voltage when revving up to 6,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), D position with "OD" OFF (A/T).
The voltage should be below 0.43V at least once.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0141 REAR HEATED OXYGEN SENSOR HEATER

Description

Description

SYSTEM DESCRIPTION

NCEC0180

NCEC0180S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Rear heated oxygen sensor heater control	Rear heated oxygen sensor heater

The ECM performs ON/OFF control of the rear heated oxygen sensor heater corresponding to the engine speed.

OPERATION

NCEC0180S02

Engine condition	Rear heated oxygen sensor heater
Engine stopped	OFF
Engine is running. [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON

CONSULT Reference Value in Data Monitor Mode

NCEC0181

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
RR O2 HEATER	<ul style="list-style-type: none"> Engine speed: Idle [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 	ON
	<ul style="list-style-type: none"> Ignition switch ON (Engine stopped) 	OFF

ECM Terminals and Reference Value

NCEC0182

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
110	R/Y	Rear heated oxygen sensor heater	[Engine is running] <ul style="list-style-type: none"> After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more 	Approximately 0.7V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Engine stopped 	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0183

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0141 0902	<ul style="list-style-type: none"> The current amperage in the rear heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the rear heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The rear heated oxygen sensor heater circuit is open or shorted.) Rear heated oxygen sensor heater

DTC P0141 REAR HEATED OXYGEN SENSOR HEATER

DTC Confirmation Procedure

DTC Confirmation Procedure


NCEC0184

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is in between 10.5V and 16V at idle.



④ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-227.

④ With GST

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 4) Select "MODE 3" with GST.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-227.

④ No Tools

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-227.

When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT or ECM (Diagnostic Test Mode II) is recommended.





DTC P0141 REAR HEATED OXYGEN SENSOR HEATER

Wiring Diagram

Wiring Diagram

NCEC0185

EC-RRO2/H-01



Refer to last page (Foldout page).



(M2)

DTC P0141 REAR HEATED OXYGEN SENSOR HEATER


Diagnostic Procedure

Diagnostic Procedure

NCEC0186

1	CHECK POWER SUPPLY						
<p>1. Turn ignition switch "OFF". 2. Disconnect rear heated oxygen sensor harness connector.</p> <p>Under the vehicle view</p>  <p style="text-align: right;">SEF298W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 2 and ground.</p>  <p style="text-align: right;">SEF218W</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>		OK	▶	GO TO 3.	NG	▶	GO TO 2.
OK	▶	GO TO 3.					
NG	▶	GO TO 2.					

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness connectors B3, M8 • Harness for open or short between rear heated oxygen sensor and fuse <p style="text-align: right;">▶ Repair harness or connectors.</p>	

3	CHECK GROUND CIRCUIT						
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between terminal 3 and ECM terminal 110.</p>  <p style="text-align: right;">SEF219W</p> <p style="text-align: center;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.					
NG	▶	GO TO 4.					

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors B3, M5 • Harness connectors M62, F24 • Harness for open or short between rear heated oxygen sensor heater and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	


5	CHECK REAR HEATED OXYGEN SENSOR HEATER						
<p>Refer to "Component Inspection", EC-228.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace rear heated oxygen sensor.</td> </tr> </table>		OK	▶	GO TO 6.	NG	▶	Replace rear heated oxygen sensor.
OK	▶	GO TO 6.					
NG	▶	Replace rear heated oxygen sensor.					

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <p style="text-align: right;">▶ INSPECTION END</p>	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0141 REAR HEATED OXYGEN SENSOR HEATER

Component Inspection



Component Inspection

REAR HEATED OXYGEN SENSOR HEATER

NCEC0187

NCEC0187S01

Check the following.

1. Check resistance between terminals 1 and 4.
Resistance: 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity.

Terminal No.	Continuity
2 and 1, 3, 4	No
3 and 1, 2, 4	

If NG, replace the rear heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

On Board Diagnosis Logic




On Board Diagnosis Logic

NCEC0188

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection & mixture ratio control	Injectors

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0171 0115	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> Intake air leaks Front heated oxygen sensor Injectors Exhaust gas leaks Incorrect fuel pressure Lack of fuel Mass air flow sensor



DTC Confirmation Procedure

NCEC0189

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-232.
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
- Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-232. If engine does not start, visually check for exhaust and intake air leak.

Ⓜ With GST

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- Stop engine and reconnect mass air flow sensor harness connector.
- Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- Select "MODE 4" with GST and erase the 1st trip DTC P0100.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

DTC Confirmation Procedure (Cont'd)

- 7) Start engine again and run it for at least 10 minutes at idle speed.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-232.
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-232. If engine does not start, visually check for exhaust and intake air leak.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Turn ignition switch "ON".
- 6) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- 7) Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I. Refer to "How to Erase DTC (No Tools)", EC-55.
- 8) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 9) Start engine again and run it for at least 10 minutes at idle speed. The 1st trip DTC 0115 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-232.
- 10) If it is difficult to start engine at step 9, the fuel injection system also has a malfunction.
- 11) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-232. If engine does not start, visually check for exhaust and intake air leak.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

Wiring Diagram

Wiring Diagram

NCEC0190

EC-FUEL-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL



IDX



Refer to EL-POWER.

— : Detectable line for DTC
 — : Non-detectable line for DTC

Refer to last page (Foldout page).




TEC532

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)



Diagnostic Procedure

Diagnostic Procedure

NCEC0191

1	CHECK EXHAUST AIR LEAK
<ol style="list-style-type: none"> 1. Start engine and run it at idle. 2. Listen for an exhaust air leak before three way catalyst. 	
	
SEF099P	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.

2	CHECK FOR INTAKE AIR LEAK
Listen for an intake air leak after the mass air flow sensor.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

3	CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect front heated oxygen sensor harness connector and ECM harness connector. 	
	
SEF089P	
<ol style="list-style-type: none"> 3. Check harness continuity between ECM terminal 46 and terminal 1. 	
	
SEF212W	
Continuity should exist.	
<ol style="list-style-type: none"> 4. Check harness continuity between ECM terminal 46 (or terminal 2) and ground. 	
Continuity should not exist.	
<ol style="list-style-type: none"> 5. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK FUEL PRESSURE
<ol style="list-style-type: none"> 1. Release fuel pressure to zero. Refer to EC-34. 2. Install fuel pressure gauge and check fuel pressure. At idling: <ul style="list-style-type: none"> When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm², 34 psi) When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm², 43 psi) 	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Fuel pump and circuit Refer to EC-457. ● Fuel pressure regulator Refer to EC-35. ● Fuel lines Refer to "ENGINE MAINTENANCE" in MA section. ● Fuel filter for clogging 	
▶	Repair or replace.

6	CHECK MASS AIR FLOW SENSOR
(C) With CONSULT Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT. <ul style="list-style-type: none"> at idling: 2.5 - 5.0 g·m/sec at 2,500 rpm: 7.1 - 12.5 g·m/sec 	
(SST) With GST Check mass air flow sensor signal in MODE 1 with GST. <ul style="list-style-type: none"> at idling: 2.5 - 5.0 g·m/sec at 2,500 rpm: 7.1 - 12.5 g·m/sec 	
(NO TOOLS) No Tools Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground. <ul style="list-style-type: none"> at idling: 1.3 - 1.7V at 2,500 rpm: 1.8 - 2.4V 	
OK or NG	
OK ▶	GO TO 7.
NG ▶	Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-116.


7	CHECK FUNCTION OF INJECTORS
(C) With CONSULT <ol style="list-style-type: none"> 1. Install all parts removed. 2. Start engine. 3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT. 	
MEF354F	
<ol style="list-style-type: none"> 4. Make sure that each circuit produces a momentary engine speed drop. 	
(X) Without CONSULT <ol style="list-style-type: none"> 1. Install all parts removed. 2. Start engine. 3. Listen to each injector operating sound. 	
Clicking noise should be heard.	
OK or NG	
OK ▶	GO TO 8.
NG ▶	Perform trouble diagnosis for "INJECTORS", EC-451.

8	REMOVE INJECTOR
<ol style="list-style-type: none"> 1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. 2. Turn ignition switch "OFF". 3. Remove injector with fuel tube assembly. Refer to EC-35. Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors should remain connected. 	
▶	GO TO 9.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (LEAN SIDE)

Diagnostic Procedure (Cont'd)

9	CHECK INJECTOR
<p>1. Disconnect all ignition coil harness connectors. 2. Place pans or saucers under each injector. 3. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.</p>	
	
<p style="text-align: right;">SEF595Q</p>	
<p>Fuel should be sprayed evenly for each cylinder.</p>	
<p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 10.
NG	▶ Replace injectors from which fuel does not spray out. Always replace O-ring with new one.

10	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

On Board Diagnosis Logic


On Board Diagnosis Logic

NCEC0192


With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection & mixture ratio control	Injectors


DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0172 0114	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> Front heated oxygen sensor Injectors Exhaust gas leaks Incorrect fuel pressure Mass air flow sensor



SEF737W



SEF190PF



SEF293W

DTC Confirmation Procedure

NCEC0193

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-238.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
- 8) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-238. If engine does not start, remove ignition plugs and check for fouling, etc.

⑤ With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- 6) Select "MODE 4" with GST and erase the 1st trip DTC P0100.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

DTC Confirmation Procedure (Cont'd)

- 7) Start engine again and run it for at least 10 minutes at idle speed.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-238.
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-238. If engine does not start, remove ignition plugs and check for fouling, etc.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart engine and run it for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Turn ignition switch "ON".
- 6) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- 7) Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I. Refer to "How to Erase DTC (No Tools)", EC-55.
- 8) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 9) Start engine again and run it for at least 10 minutes at idle speed. The 1st trip DTC 0114 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-238.
- 10) If it is difficult to start engine at step 9, the fuel injection system also has a malfunction.
- 11) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-238. If engine does not start, remove ignition plugs and check for fouling, etc.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

Wiring Diagram

Wiring Diagram

NCEC0194

EC-FUEL-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC


EL

IDX




Refer to EL-POWER.

— : Detectable line for DTC
 - - - : Non-detectable line for DTC



Refer to last page (Foldout page).




TEC532



DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

Diagnostic Procedure

Diagnostic Procedure

NCEC0195

1	CHECK FOR EXHAUST AIR LEAK
<ol style="list-style-type: none"> 1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the three way catalyst. 	
	
SEF099P	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.

2	CHECK FRONT HEATED OXYGEN SENSOR CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect front heated oxygen sensor harness connector and ECM harness connector. 	
	
SEF089P	
<ol style="list-style-type: none"> 3. Check harness continuity between ECM terminal 46 and terminal 1. 	
	
SEF212W	
Continuity should exist.	
<ol style="list-style-type: none"> 4. Check harness continuity between ECM terminal 46 (or terminal 2) and ground. 	
Continuity should not exist.	
<ol style="list-style-type: none"> 5. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK FUEL PRESSURE
<ol style="list-style-type: none"> 1. Release fuel pressure to zero. Refer to EC-34. 2. Install fuel pressure gauge and check fuel pressure. At idling: <ul style="list-style-type: none"> When fuel pressure regulator valve vacuum hose is connected. Approximately 235 kPa (2.4 kg/cm², 34 psi) When fuel pressure regulator valve vacuum hose is disconnected. Approximately 294 kPa (3.0 kg/cm², 43 psi) 	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)

Diagnostic Procedure (Cont'd)

4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Fuel pump and circuit (Refer to EC-457.) ● Fuel pressure regulator (Refer to EC-35.) 	
▶	Repair or replace.

5	CHECK MASS AIR FLOW SENSOR
(H) With CONSULT Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT. at idling: 2.5 - 5.0 g-m/sec at 2,500 rpm: 7.1 - 12.5 g-m/sec	
(S) With GST Check mass air flow sensor signal in MODE 1 with GST. at idling: 2.5 - 5.0 g-m/sec at 2,500 rpm: 7.1 - 12.5 g-m/sec	
(N) No Tools Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground. at idling: 1.3 - 1.7V at 2,500 rpm: 1.8 - 2.4V <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-122.

6	CHECK FUNCTION OF INJECTORS
(H) With CONSULT 1. Install all parts removed. 2. Start engine. 3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.	
4. Make sure that each circuit produces a momentary engine speed drop.	
(X) Without CONSULT 1. Install all parts removed. 2. Start engine. 3. Listen to each injector operating sound.	
Clicking noise should be heard. OK or NG	
OK	▶ GO TO 7.
NG	▶ Perform trouble diagnosis for "INJECTORS", EC-451.

7	REMOVE INJECTOR
1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle. 2. Turn ignition switch "OFF". 3. Remove injector assembly. Refer to EC-35. Keep fuel hose and all injectors connected to injector gallery.	
▶	GO TO 8.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (RICH SIDE)


Diagnostic Procedure (Cont'd)

8	CHECK INJECTOR
1. Disconnect all injector harness connectors. 2. Disconnect all ignition coil harness connectors. 3. Prepare pans or saucers under each injectors. 4. Crank engine for about 3 seconds. Make sure fuel does not drip from injector.	
OK or NG	
OK (Does not drip) ▶	GO TO 9.
NG (Drips) ▶	Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

DTC P0180 TANK FUEL TEMPERATURE SENSOR


Component Description



Component Description

NCEC0196

The tank fuel temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>


Fluid temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 63 (Tank fuel temperature sensor) and ECM terminal 43 (ECM ground).

On Board Diagnosis Logic

NCEC0197

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0180 0402	<ul style="list-style-type: none"> An excessively high or low voltage is sent to ECM. Rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Tank fuel temperature sensor



DTC Confirmation Procedure

NCEC0198

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT.
- Wait at least 10 seconds.
If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.
If the result is OK, go to following step.
- Check "COOLAN TEMP/S" signal.
If the signal is less than 60°C (140°F), the result will be OK.
If the signal is above 60°C (140°F), go to the following step.
- Cool engine down until "COOLAN TEMP/S" signal is less than 60°C (140°F).
- Wait at least 10 seconds.
- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.

DTC P0180 TANK FUEL TEMPERATURE SENSOR

DTC Confirmation Procedure (Cont'd)

With GST

- 1) Turn ignition switch "ON" and wait at least 10 seconds.
- 2) Select "MODE 7" with GST.
If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.
If the result is OK, go to following step.
- 3) Select "MODE 1" with GST and check for the engine coolant temperature.
If the temperature is less than 60°C (140°F), the result will be OK.
If the temperature is above 60°C (140°F), go to the following step.
- 4) Cool engine down until the engine coolant temperature is less than 60°C (140°F).
- 5) Wait at least 10 seconds.
- 6) Select "MODE 7" with GST.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.

No Tools

- 1) Turn ignition switch "ON" and wait at least 10 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.
If the result is OK, go to following step.
- 4) Check voltage between ECM terminal 51 (Engine coolant temperature sensor signal) and ground.
If the voltage is more than 1.9V, the result will be OK.
If the voltage is less than 1.9V, go to the following step.
- 5) Cool engine down until the voltage becomes more than 1.9V.
- 6) Wait at least 10 seconds.
- 7) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 8) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 9) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-244.

DTC P0180 TANK FUEL TEMPERATURE SENSOR

Wiring Diagram

Wiring Diagram

NCEC0199

EC-TFTS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX





TEC533

DTC P0180 TANK FUEL TEMPERATURE SENSOR


Diagnostic Procedure

Diagnostic Procedure

NCEC0200


1	CHECK POWER SUPPLY				
<p>1. Turn ignition switch "OFF". 2. Disconnect fuel tank gauge unit harness connector.</p>  <p style="text-align: right;">SEF299W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 2 and ground with CONSULT or tester.</p>  <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: right;">SEF222W</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">OK</td> <td style="width: 50%;">▶ GO TO 3.</td> </tr> <tr> <td>NG</td> <td>▶ GO TO 2.</td> </tr> </table>		OK	▶ GO TO 3.	NG	▶ GO TO 2.
OK	▶ GO TO 3.				
NG	▶ GO TO 2.				

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors B102, M74 • Harness connectors M49, F23 • Harness for open or short between ECM and fuel tank gauge unit <p style="text-align: right;">▶ Repair harness or connector.</p>	

3	CHECK GROUND CIRCUIT				
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 1 and body ground.</p>  <p style="text-align: right;">SEF223W</p> <p style="text-align: center;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">OK</td> <td style="width: 50%;">▶ GO TO 4.</td> </tr> <tr> <td>NG</td> <td>▶ Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		OK	▶ GO TO 4.	NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.
OK	▶ GO TO 4.				
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.				

4	CHECK TANK FUEL TEMPERATURE SENSOR				
<p>Refer to "Component Inspection", EC-244.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">OK</td> <td style="width: 50%;">▶ GO TO 5.</td> </tr> <tr> <td>NG</td> <td>▶ Replace tank fuel temperature sensor.</td> </tr> </table>		OK	▶ GO TO 5.	NG	▶ Replace tank fuel temperature sensor.
OK	▶ GO TO 5.				
NG	▶ Replace tank fuel temperature sensor.				

5	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <p style="text-align: right;">▶ INSPECTION END</p>	



SEF224W

Component Inspection TANK FUEL TEMPERATURE SENSOR

NCEC0201

NCEC0201 S01

Check resistance by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

If NG, replace tank fuel temperature sensor.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0202


If a misfire occurs, the engine speed will fluctuate. If the fluctuation is detected by the crankshaft position sensor (OBD), the misfire is diagnosed.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (OBD)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 When a misfire is detected which will overheat and damage the three way catalyst, the MIL will start blinking; even during the first trip. In this condition, ECM monitors the misfire every 200 revolutions. If the misfire frequency decreases to a level that will not damage the three way catalyst, the MIL will change from blinking to lighting up. (After the first trip detection, the MIL will light up from engine starting. If a misfire is detected that will cause three way catalyst damage, the MIL will start blinking.)
- Two Trip Detection Logic (Exhaust quality deterioration)**
 When a misfire that will not damage the three way catalyst (but will affect exhaust emission) occurs, the MIL will light up based on two trip detection logic. In this condition, ECM monitors the misfire for every 1,000 revolutions of the engine.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0300 (0701)	• Multiple cylinders misfire.	<ul style="list-style-type: none"> • Improper spark plug • Insufficient compression
P0301 (0608)	• No. 1 cylinder misfires.	<ul style="list-style-type: none"> • Incorrect fuel pressure • EGR valve
P0302 (0607)	• No. 2 cylinder misfires.	<ul style="list-style-type: none"> • The injector circuit is open or shorted • Injectors
P0303 (0606)	• No. 3 cylinder misfires.	<ul style="list-style-type: none"> • Intake air leak • The ignition secondary circuit is open or shorted
P0304 (0605)	• No. 4 cylinder misfires.	<ul style="list-style-type: none"> • Lack of fuel • Drive plate/Flywheel • Front heated oxygen sensor • Incorrect distributor rotor



DTC Confirmation Procedure

NCEC0203

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓢ With CONSULT

- 1) Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch "OFF" and wait at least 5 seconds.
- 4) Start engine again and drive at 1,500 - 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-246.

Ⓢ With GST

- 1) Start engine and warm it up to normal operating temperature.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

DTC Confirmation Procedure (Cont'd)

- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

- 4) Select "MODE 7" with GST.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-246.

Ⓝ No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.
- 4) Turn ignition switch "OFF", wait at least 5 seconds, and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-246.

Diagnostic Procedure

NCEC0204

1	CHECK FOR INTAKE AIR LEAK	
1. Start engine and run it at idle speed. 2. Listen for the sound of the intake air leak.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Discover air leak location and repair.

2	CHECK FOR EXHAUST SYSTEM CLOGGING	
Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace it.

3	CHECK EGR FUNCTION	
Perform DTC Confirmation Procedure for DTC P1402 EGR FUNCTION (OPEN). Refer to EC-366.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair EGR system.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT


HA


SC

EL


IDX

4	PERFORM POWER BALANCE TEST
<p>With CONSULT</p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center;">■ ACTIVE TEST ■</p> <p style="text-align: center;">*** POWER BALANCE ***</p> <p style="text-align: center;">== == MONITOR == ==</p> <p>CMPS•RPM (REF) 825rpm</p> <p>MAS AIR/FL SE 1.53V</p> <p>IACV-AAC/V 26%</p> </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px;">1</div> <div style="border: 1px solid black; padding: 2px;">2</div> <div style="border: 1px solid black; padding: 2px;">3</div> <div style="border: 1px solid black; padding: 2px;">4</div> <div style="border: 1px solid black; padding: 2px;">TEST START</div> </div> <p style="text-align: right; font-size: small;">SEF564N</p>	
<p>2. Is there any cylinder which does not produce a momentary engine speed drop?</p>	
<p>Without CONSULT</p> <p>When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?</p> <div style="text-align: center; margin: 10px 0;">  <p style="font-size: small;">Remove to test other injectors</p> </div> <p style="text-align: right; font-size: small;">SEF565N</p>	
<p>Yes or No</p>	
Yes	▶ GO TO 5.
No	▶ GO TO 8.

5	CHECK INJECTOR
<p>Does each injector make an operating sound at idle?</p> <div style="text-align: center; margin: 10px 0;">  <p style="font-size: small;">At idle</p> <p style="font-size: small;">Click Click</p> <p style="font-size: small;">Suitable tool</p> </div> <p style="text-align: right; font-size: small;">MEC703B</p>	
<p>Yes or No</p>	
Yes	▶ GO TO 6.
No	▶ Check injector(s) and circuit(s). Refer to EC-451.

6	CHECK IGNITION SPARK
<ol style="list-style-type: none"> 1. Turn Ignition switch "OFF". 2. Disconnect ignition wire from spark plug. 3. Connect a known good spark plug to the ignition wire. 4. Place end of spark plug against a suitable ground and crank engine. 5. Check for spark. <div style="text-align: center; margin: 10px 0;">  <p style="font-size: small;">Ignition wire</p> <p style="font-size: small;">Spark plug</p> </div> <p style="text-align: right; font-size: small;">SEF282G</p>	
<p>OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.


7	CHECK IGNITION WIRES
<p>Refer to "Component Inspection", EC-249.</p>	
<p>OK or NG</p>	
OK	▶ Check distributor rotor head for incorrect parts. Check ignition coil, power transistor and their circuits. Refer to EC-343.
NG	▶ Replace.

8	CHECK SPARK PLUGS
<p>Remove the spark plugs and check for fouling, etc.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; font-size: small;">SEF156I</p>	
<p>OK or NG</p>	
OK	▶ GO TO 9.
NG	▶ Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to "ENGINE MAINTENANCE" in MA section.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

9	CHECK COMPRESSION PRESSURE		
Refer to EM section.			
● Check compression pressure.			
Standard:			
1,226 kPa (12.5 kg/cm ² , 178 psi)/300 rpm			
Minimum:			
1,030 kPa (10.5 kg/cm ² , 149 psi)/300 rpm			
Difference between each cylinder:			
98 kPa (1.0 kg/cm ² , 14 psi)/300 rpm			
OK or NG			
OK	▶	GO TO 10.	
NG	▶	Check pistons, piston rings, valves, valve seats and cylinder head gaskets.	

10	CHECK FUEL PRESSURE		
1. Install any parts removed.			
2. Release fuel pressure to zero. Refer to EC-34.			
3. Install fuel pressure gauge and check fuel pressure.			
			
At idle: Approx. 235 kPa (2.4 kg/cm ² , 34 psi) SEF300W			
OK or NG			
OK	▶	GO TO 12.	
NG	▶	GO TO 11.	

11	DETECT MALFUNCTIONING PART		
Check the following.			
● Fuel pump and circuit Refer to EC-457.			
● Fuel pressure regulator Refer to EC-35.			
● Fuel lines Refer to "ENGINE MAINTENANCE" in MA section.			
● Fuel filter for clogging			
▶			Repair or replace.

12	CHECK IGNITION TIMING		
Perform "Basic Inspection", EC-83.			
OK or NG			
OK	▶	GO TO 13.	
NG	▶	Adjust ignition timing.	

13	CHECK FRONT HEATED OXYGEN SENSOR		
Refer to "Component Inspection", EC-171.			
OK or NG			
OK	▶	GO TO 14.	
NG	▶	Replace front heated oxygen sensor.	

14	CHECK MASS AIR FLOW SENSOR		
P With CONSULT Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.			
at idling: 2.5 - 5.0 g-m/sec			
at 2,500 rpm: 7.1 - 12.5 g-m/sec			
GST With GST Check mass air flow sensor signal in MODE 1 with GST.			
at idling: 2.5 - 5.0 g-m/sec			
at 2,500 rpm: 7.1 - 12.5 g-m/sec			
NO TOOLS No Tools Check voltage between ECM terminal 47 (Mass air flow sensor signal) and ground.			
at idling: 1.3 - 1.7V			
at 2,500 rpm: 1.8 - 2.4V			
OK or NG			
OK	▶	GO TO 16.	
NG	▶	GO TO 15.	

15	CHECK CONNECTORS		
Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-116.			
OK or NG			
NG	▶	Repair or replace it.	

16	CHECK SYMPTOM MATRIX CHART		
Check items on the rough idle symptom in "Symptom Matrix Chart", EC-92.			
OK or NG			
OK	▶	GO TO 17.	
NG	▶	Repair or replace.	

17	ERASE THE 1ST TRIP DTC		
Some tests may cause a 1st trip DTC to be set. Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to EC-54.			
▶			GO TO 18.

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)


18	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

GI

MA

EM

LC



Component Inspection IGNITION WIRES

NCEC0205

NCEC0205S01

EC

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

FE

CL

Resistance:

13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F)

If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0325 KNOCK SENSOR (KS)

Component Description



Component Description

NCEC0206

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM. **Freeze frame data will not be stored in the ECM for the knock sensor. The MIL will not light for knock sensor malfunction. The knock sensor has one trip detection logic.**

ECM Terminals and Reference Value

NCEC0207


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	W	Knock sensor	[Engine is running] ● Idle speed	2.0 - 3.0V

On Board Diagnosis Logic

NCEC0208

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0325 0304	● An excessively low or high voltage from the knock sensor is sent to ECM.	● Harness or connectors (The knock sensor circuit is open or shorted.) ● Knock sensor



DTC Confirmation Procedure

NCEC0209

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

ⓑ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-253.

ⓐ With GST

- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Select "MODE 3" with GST.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-253.

ⓐ No Tools

- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".

DTC P0325 KNOCK SENSOR (KS)

DTC Confirmation Procedure (Cont'd)

- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-253.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




DTC P0325 KNOCK SENSOR (KS)

Wiring Diagram

Wiring Diagram

NCEC0210

EC-KS-01



TEC534

Diagnostic Procedure

1	RETIGHTEN GROUND SCREWS
Loosen and retighten engine ground screws.	
▶ GO TO 2.	

2	CHECK INPUT SIGNAL CIRCUIT-1
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector and knock sensor harness connector. 	
<p>Under the vehicle view</p>	
<ol style="list-style-type: none"> Check harness continuity between terminal 1 and ECM terminal 54. 	
Continuity should exist.	
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> Harness connectors F13, F51 Harness for open or short between knock sensor and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

4	CHECK KNOCK SENSOR
Knock sensor	
Refer to "Component Inspection", EC-254.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace knock sensor.

5	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Reconnect harness connectors disconnected. Disconnect harness connectors F13, F51. Check harness continuity between terminal 5 and engine ground. 	
Continuity should exist.	
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. Then reconnect harness connectors. 	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.


6	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> Harness connectors F13, F51 Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) Harness for open or short between harness connector F13 and engine ground 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0325 KNOCK SENSOR (KS)

Diagnostic Procedure (Cont'd)

7	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection KNOCK SENSOR

NCEC0212



NCEC0212SD1

- Use an ohmmeter which can measure more than 10 M Ω .
1. Disconnect knock sensor harness connector.
 2. Check resistance between terminal 2 and ground.
Resistance: 500 - 620 k Ω [at 25°C (77°F)]

CAUTION:
Discard any knock sensors that have been dropped or physically damaged. Use only new ones.

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

Component Description



Component Description

NCEC0213

The crankshaft position sensor (OBD) is located on the transaxle housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system. It is used only for the on board diagnosis.

GI

MA

EM

LC

EC

FE

CL

MT

ECM Terminals and Reference Value

NCEC0214

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
53	W	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	<p>3 - 5V</p> <p>SEF721W</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> • Engine speed is 2,000 rpm 	<p>6 - 9V</p> <p>SEF722W</p>

AX

SU

BR

ST

RS

BT

HA

On Board Diagnosis Logic

NCEC0215

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0335 0802	<ul style="list-style-type: none"> • The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> • Harness or connectors (The crankshaft position sensor (OBD) circuit is open.) • Crankshaft position sensor (OBD)


SC

EL

IDX

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0216

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

ⓑ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 10 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-258.

ⓐ With GST

- 1) Start engine and run it for at least 10 seconds at idle speed.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-258.

ⓐ No Tools

- 1) Start engine and run it for at least 10 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-258.

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

Wiring Diagram

Wiring Diagram

NCEC0217

EC-CKPS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX




TEC535



DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)

Diagnostic Procedure


Diagnostic Procedure

NCEC0218

1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 2.	

2	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Disconnect crankshaft position sensor (OBD) and ECM harness connectors. 	
 <p>Crankshaft position sensor (OBD) harness connector</p> <p>Radiator</p> <p style="text-align: right;">SEF957N</p>	
<ol style="list-style-type: none"> Check continuity between ECM terminal 53 and terminal 2. 	
 <p style="text-align: right;">SEF228W</p>	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.


3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F5, E122 Harness for open or short between crankshaft position sensor (OBD) and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

4	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Reconnect ECM harness connector. Check harness continuity between terminal 1 and engine ground. 	
 <p style="text-align: right;">SEF229W</p>	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F5, E122 Harness for open or short between crankshaft position sensor (OBD) and ECM Harness for open or short between crankshaft position sensor (OBD) and TCM (Transmission control module) 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (OBD)


Diagnostic Procedure (Cont'd)

6	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect harness connectors F5, E122. 2. Check harness continuity between terminal 3 and engine ground. 	
	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 3. Also check harness for short to ground and short to power. 4. Then reconnect harness connectors. 	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors F5, E122 • Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) • Harness for open or short between harness connector F5 and Engine ground 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK CRANKSHAFT POSITION SENSOR (OBD)
Refer to "Component Inspection", EC-259.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace crankshaft position sensor (OBD).

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END




Component Inspection

CRANKSHAFT POSITION SENSOR (OBD)

NCEC0219

NCEC0218S01

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.





5. Check resistance as shown in the figure.
Resistance: 166 - 204 Ω [at 25°C (77°F)]
 If NG, replace crankshaft position sensor (OBD).

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

Component Description



Component Description

NCEC0220

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the engine control system are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 4 slits for a 180° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

ECM Terminals and Reference Value



NCEC0221

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
40	L	Camshaft position sensor (Reference signal)	[Engine is running] ● Warm-up condition ● Idle speed	0.1 - 0.4V SEF006W
44	L		[Engine is running] ● Engine speed is 2,000 rpm	0.1 - 0.4V SEF007W

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
41	B/W	Camshaft position sensor (Position signal)	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	Approximately 2.5V  SEF004W
			[Engine is running] <ul style="list-style-type: none"> • Engine speed is 2,000 rpm 	Approximately 2.3 - 2.5V  SEF005W

On Board Diagnosis Logic

NCEC0222

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P0340 0101	A)	Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking.	<ul style="list-style-type: none"> • Harness or connectors (The camshaft position sensor circuit is open or shorted.) • Camshaft position sensor • Starter motor (Refer to EL section.) • Starting system circuit (Refer to EL section.) • Dead (Weak) battery
	B)	Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed.	
	C)	The relation between 1° and 180° signal is not in the normal range during the specified engine speed.	

DTC Confirmation Procedure

NCEC0223

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B and C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

PROCEDURE FOR MALFUNCTION A

NCEC0223S01

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Crank engine for at least 2 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.

With GST

- 1) Crank engine for at least 2 seconds.
- 2) Select "MODE 7" with GST.

2

☆ MONITOR ☆ NO FAIL

COOLAN TEMP/S 30°C

RECORD

SEF002PE


DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

DTC Confirmation Procedure (Cont'd)

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.

 **No Tools**

- 1) Crank engine for at least 2 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.



PROCEDURE FOR MALFUNCTION B AND C

NCEC0223S02

 **With CONSULT**

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.

 **With GST**

- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.

 **No Tools**

- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-264.




DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

Wiring Diagram

Wiring Diagram

NCEC0224

EC-CMPS-01 GI



Refer to last page (Foldout page).



MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT

HA
SC
EL
IDX

TEC536


DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)



Diagnostic Procedure

Diagnostic Procedure

NCEC0225

1	CHECK STARTING SYSTEM	
Does the engine turn over? (Does the starter motor operate?)		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Check starting system. (Refer to EL section.)

2	RETIGHTEN GROUND SCREWS	
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.		
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>		
▶		GO TO 3.

3	CHECK POWER SUPPLY	
1. Disconnect camshaft position sensor harness connector.		
 <p>Distributor</p> <p>Camshaft position sensor harness connector</p> <p style="text-align: right;">AEC685</p>		
2. Turn ignition switch "ON".		
3. Check voltage between terminal 2 and ground with CONSULT or tester.		
 <p>DISCONNECT T.S. ON</p> <p>6 5 4 3 2 1</p> <p>V</p> <p>+</p> <p>-</p> <p style="text-align: right;">SEF232W</p>		
Voltage: Battery voltage		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

4	DETECT MALFUNCTIONING PART	
Check the following.		
<ul style="list-style-type: none"> ● Harness connectors M62, F24 ● Harness for open or short between camshaft position sensor and ECM relay ● Harness for open or short between camshaft position sensor and ECM 		
▶		Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

Diagnostic Procedure (Cont'd)

5	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between sensor terminal 3 and ECM terminal 41, sensor terminal 4 and ECM terminals 40, 44. 	
SEF233W	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK CAMSHAFT POSITION SENSOR
Refer to "Component Inspection", EC-266.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace camshaft position sensor.

8	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect joint connector-1. Check the following. <ul style="list-style-type: none"> Continuity between joint connector-1 terminal 2 and ground Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) <p>Continuity should exist.</p> Also check harness for short to ground and short to power. Then reconnect joint connector-1. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Repair open circuit, short to ground or short to power in harness or connectors.


6	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Check harness continuity between sensor terminal 1 and engine ground. 	
SEF234W	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0340 CAMSHAFT POSITION SENSOR (CMPS)

Component Inspection



Component Inspection

CAMSHAFT POSITION SENSOR

—NCEC0226

NCEC0226S01

1. Start engine and warm it up to normal operating temperature.
2. Check voltage between ECM terminals 40, 41 and engine ground under the following conditions.

Terminal 40 (or 44) and engine ground

Condition	Idle	2,000 rpm
Voltage	0.1 - 0.4V	0.1 - 0.4V
Pulse signal	<p>SEF006W</p>	<p>SEF007W</p>

Terminal 41 and engine ground

Condition	Idle	2,000 rpm
Voltage	Approximately 2.5V	Approximately 2.4V
Pulse signal	<p>SEF004W</p>	<p>SEF005W</p>

If NG, replace distributor assembly with camshaft position sensor.

DTC P0400 EGR FUNCTION (CLOSE)

Description

Description SYSTEM DESCRIPTION



NCEC0227

NCEC0227S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve is cut. This causes the vacuum to be discharged into the atmosphere. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve


NCEC0227S02

NCEC0227S0201

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

DTC P0400 EGR FUNCTION (CLOSE)


Description (Cont'd)



EGRC-Solenoid Valve

NCEC0227S0202

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.



On Board Diagnosis Logic

NCEC0228




If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0400 0302	<ul style="list-style-type: none"> No EGR flow is detected under conditions that call for EGR. 	<ul style="list-style-type: none"> EGR valve stuck closed EGRC-BPT valve Vacuum hose EGRC-solenoid valve EGR passage EGR temperature sensor Exhaust gas leaks

DTC P0400 EGR FUNCTION (CLOSE)

DTC Confirmation Procedure

NCEC0229



DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.
- P0400 will not be displayed at "SELF-DIAG RESULTS" mode with CONSULT even though DTC work support test result is "NG".

TESTING CONDITION:

For best results, perform the test at a temperature above 5°C (41°F).

① With CONSULT

- 1) Turn ignition switch "ON".
- 2) Check "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT and confirm it is within the range listed below.

COOLAN TEMP/S: Less than 40°C (104°F)

If the value is out of range, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to lower the coolant temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

- 3) Start engine and let it idle monitoring "COOLAN TEMP/S" value. When the "COOLAN TEMP/S" value reaches 70°C (158°F), immediately go to the next step.
- 4) Select "EGR SYSTEM P0400" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 5) Touch "START".
- 6) Accelerate vehicle to a speed of 40 km/h (25 MPH) once and then stop vehicle with engine running. If "COMPLETED" appears on CONSULT screen, go to step 9. If "COMPLETED" does not appear on CONSULT screen, go to the following step.
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds or more.)




CMPS-RPM (REF)	1,800 - 2,800 rpm (A/T) 1,600 - 2,800 rpm (M/T)
Vehicle speed	10 km/h (6 MPH) or more
B/FUEL SCHDL	2.0 - 3.5 msec (A/T) 1.8 - 3.0 msec (M/T)
THRTL POS SEN	$(X + 0.05) - (X + 0.87) V$ X = Voltage value measured at step 7
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 9) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-272.

DTC P0400 EGR FUNCTION (CLOSE)

Overall Function Check



Overall Function Check

NCEC0230

Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the EGR valve lifting when revving engine from idle to 3,000 rpm under no load.

EGR valve should lift up and down without sticking.

If NG, go to "Diagnostic Procedure", EC-272.

- 3) Check voltage between ECM terminal 62 (EGR temperature sensor signal) and ground at idle speed.

Less than 4.5V should exist.



If NG, go to next step.

- 4) Turn ignition switch "OFF".
- 5) Disconnect EGR temperature sensor harness connector.
- 6) Check harness continuity between EGR temperature sensor harness connector terminal 2 and engine ground.

Continuity should exist.

- 7) Perform "Component Inspection", "EGR TEMPERATURE SENSOR". Refer to EC-365.

Overall function check



Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

SEF-642Q





DTC P0400 EGR FUNCTION (CLOSE)

Wiring Diagram

Wiring Diagram

NCEC0231

EC-EGRC1-01 GI



Refer to last page (Foldout page).



MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TEC537



DTC P0400 EGR FUNCTION (CLOSE)

Diagnostic Procedure

Diagnostic Procedure


NCEC0232

1	CHECK EXHAUST SYSTEM
<p>1. Start engine. 2. Check exhaust pipes and muffler for leaks.</p>	
	
SEF099P	
OK or NG	
OK (With CONSULT) ▶	GO TO 2.
OK (Without CONSULT) ▶	GO TO 3.
NG ▶	Repair or replace exhaust system.


2	CHECK VACUUM SOURCE TO EGR VALVE												
<p> With CONSULT</p> <p>1. Warm engine up to normal operating temperature. 2. Disconnect vacuum hose to EGR valve. 3. Check for vacuum existence at idle.</p>													
													
SEF302W													
<p>Vacuum should not exist at idle.</p> <p>4. Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and turn the solenoid valve "ON". 5. Check for vacuum existence when revving engine from idle up to 3,000 rpm.</p>													
<table border="1" style="width: 100%;"> <tr> <td style="text-align: center;"><input checked="" type="checkbox"/> ACTIVE TEST</td> <td style="text-align: center;"><input type="checkbox"/></td> </tr> <tr> <td>EGRC SOL/V (EGR)</td> <td style="text-align: center;">ON FLOW</td> </tr> <tr> <td colspan="2" style="text-align: center;">===== MONITOR =====</td> </tr> <tr> <td>CMPS-RPM(REF)</td> <td style="text-align: center;">2850rpm</td> </tr> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">ON/OFF</td> </tr> <tr> <td style="text-align: center;">OFF</td> <td></td> </tr> </table>		<input checked="" type="checkbox"/> ACTIVE TEST	<input type="checkbox"/>	EGRC SOL/V (EGR)	ON FLOW	===== MONITOR =====		CMPS-RPM(REF)	2850rpm	ON	ON/OFF	OFF	
<input checked="" type="checkbox"/> ACTIVE TEST	<input type="checkbox"/>												
EGRC SOL/V (EGR)	ON FLOW												
===== MONITOR =====													
CMPS-RPM(REF)	2850rpm												
ON	ON/OFF												
OFF													
SEF788U													
<p>Vacuum should exist when revving engine.</p> <p style="text-align: center;">OK or NG</p>													
OK ▶	GO TO 4.												
NG ▶	GO TO 5.												

DTC P0400 EGR FUNCTION (CLOSE)

Diagnostic Procedure (Cont'd)

3	CHECK VACUUM SOURCE TO EGR VALVE						
<p>⊗ Without CONSULT</p> <ol style="list-style-type: none"> 1. Warm engine up to normal operating temperature. 2. Disconnect vacuum hose to EGR valve. 3. Check for vacuum existence at idle.  <p>Vacuum should not exist at idle.</p> <ol style="list-style-type: none"> 4. Check for vacuum existence when revving engine from idle up to 3,000 rpm quickly. <p>Vacuum should exist when revving engine.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 5.</td> </tr> </table>		OK	▶	GO TO 4.	NG	▶	GO TO 5.
OK	▶	GO TO 4.					
NG	▶	GO TO 5.					

4	CHECK EGR VALVE						
<p>Refer to "Component Inspection", EC-274.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td style="text-align: center;">▶</td> <td>GO TO 11.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EGR valve.</td> </tr> </table>		OK	▶	GO TO 11.	NG	▶	Replace EGR valve.
OK	▶	GO TO 11.					
NG	▶	Replace EGR valve.					



5	CHECK VACUUM HOSE									
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Check vacuum hose for clogging, cracks or improper connection.  <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK (With CONSULT)</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> <tr> <td>OK (Without CONSULT)</td> <td style="text-align: center;">▶</td> <td>GO TO 7.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair or replace vacuum hose.</td> </tr> </table>		OK (With CONSULT)	▶	GO TO 6.	OK (Without CONSULT)	▶	GO TO 7.	NG	▶	Repair or replace vacuum hose.
OK (With CONSULT)	▶	GO TO 6.								
OK (Without CONSULT)	▶	GO TO 7.								
NG	▶	Repair or replace vacuum hose.								

6	CHECK EGRC-SOLENOID VALVE OPERATION						
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT. <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: center;">■ EGRC SOL/V CIRCUIT ■</p> <p style="text-align: center;">DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?</p> <p style="text-align: center;"> <input type="button" value="NEXT"/> <input type="button" value="NO"/> <input type="button" value="YES"/> </p> </div> <p style="text-align: right;">MEF957D</p>							
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound. <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>EGRC SOL/V (EGR) ON FLOW</p> <p style="text-align: center;">----- MONITOR -----</p> <p>CMPS•RPM(REF) 0rpm</p> <p style="text-align: center;"> <input type="button" value="ON"/> <input type="button" value="ON/OFF"/> <input type="button" value="OFF"/> </p> </div> <p style="text-align: right;">SEF789U</p> <p style="text-align: center;">Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td>OK</td> <td style="text-align: center;">▶</td> <td>GO TO 8.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair or replace EGRC-solenoid valve or repair circuit.</td> </tr> </table>		OK	▶	GO TO 8.	NG	▶	Repair or replace EGRC-solenoid valve or repair circuit.
OK	▶	GO TO 8.					
NG	▶	Repair or replace EGRC-solenoid valve or repair circuit.					

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0400 EGR FUNCTION (CLOSE)

Diagnostic Procedure (Cont'd)


7	CHECK EGRC-SOLENOID VALVE OPERATION
<p> Without CONSULT</p> <ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Turn ignition switch "ON". 3. Connect a suitable jumper wire between ECM terminal 103 and engine ground. 	
	
<p>4. Check operating sound of the solenoid valve when disconnecting and reconnecting the jumper wire. Clicking noise should be heard.</p> <p style="text-align: right;">SEF491V</p>	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair or replace EGRC-solenoid valve or repair circuit.

8	CHECK EGRC-SOLENOID VALVE
Refer to "Component Inspection", EC-359.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EGRC-solenoid valve.

9	CHECK EGRC-BPT VALVE
Refer to "Component Inspection", EC-274.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EGRC-BPT valve.

10	CHECK EGR TEMPERATURE SENSOR
Refer to "Component Inspection", EC-365.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace EGR temperature sensor.

11	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	




Component Inspection

EGR VALVE

- Apply vacuum to EGR vacuum port with a hand vacuum pump. **EGR valve spring should lift.**
- Check for sticking.
If NG, repair or replace EGR valve.

NCEC0233

NCEC0233S01



EGRC-BPT VALVE

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.


NCEC0233S04

DTC P0402 EGRC-BPT VALVE FUNCTION

Description

Description

NCEC0234



SEF453PC

SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

NCEC0234S01

On Board Diagnosis Logic

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.


NCEC0235

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0402 0306	<ul style="list-style-type: none"> The EGRC-BPT valve does not operate properly. 	<ul style="list-style-type: none"> EGRC-BPT valve EGR valve Loose or disconnected rubber tube Blocked rubber tube Camshaft position sensor Blocked exhaust system Orifice Mass air flow sensor EGRC-solenoid valve

DTC P0402 EGRC-BPT VALVE FUNCTION

DTC Confirmation Procedure

NCEC0236



DTC Confirmation Procedure

CAUTION:


Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

- Always perform at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.




With CONSULT

- 1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Stop engine and wait at least 5 seconds.
- 4) Turn ignition switch "ON" and select "EGRC-BPT/V P0402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 5) Start engine and let it idle.
- 6) Touch "START".
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen and the bar chart may increase. Maintain the conditions many times until "COMPLETED" appears.




Selector lever	Suitable position
CMPS-RPM (REF)	1,400 - 1,600 rpm (A/T) 1,400 - 2,200 rpm (M/T)
Vehicle speed	30 - 54 km/h (19 - 34 MPH) (A/T) 30 - 100 km/h (19 - 62 MPH) (M/T)
B/FUEL SCHDL	1.5 - 2.0 msec (A/T) 1.3 - 2.0 msec (M/T)
THRTL POS SEN	$X - (X + 0.8) V$ X = Voltage value measured at step 7





NOTE:

- The bar chart on CONSULT screen indicates the status of this test. However, the test may be finished before the bar chart becomes full scale.
 - If the bar chart indication does not continue to progress, completely release accelerator pedal once and try to meet the conditions again.
 - If "TESTING" does not appear on CONSULT screen, retry from step 2.
- 9) If CONSULT instructs to carry out "Overall Function Check", go to next step. If "NG" is displayed, refer to "Diagnostic Procedure", EC-277.
 - 10) Open engine hood.
 - 11) Raise engine speed to 2,000 to 2,800 rpm under no-load and hold it. Then touch "NEXT" on CONSULT screen.



DTC P0402 EGRC-BPT VALVE FUNCTION

DTC Confirmation Procedure (Cont'd)



12) Check vacuum gauge while keeping engine speed at 2,000 to 2,800 rpm.

Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).

If NG, go to "Diagnostic Procedure", EC-277.

If OK, touch "YES" on the CONSULT screen.

13) Check the rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for cracks, blockages or twisting.

If NG, repair or replace.

If OK, touch "YES" on the CONSULT screen.

Overall Function Check

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

1) Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.

2) Lift up vehicle.

3) Start engine and shift to 1st gear position (M/T) or "1" position (A/T).

4) Check vacuum gauge while keeping engine speed at 2,000 to 2,800 rpm.

Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).

If NG, go to "Diagnostic Procedure", EC-277.

If OK, go to next step.

5) Check rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for misconnection, cracks or blockages.

6) If NG, go to "Diagnostic Procedure", EC-277.

Diagnostic Procedure

1	CHECK HOSE
Check vacuum hose for clogging and improper connection.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace vacuum hose.

2	CHECK EXHAUST SYSTEM
Check exhaust system for collapse.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace exhaust system.

3	CHECK ORIFICE
Check if orifice is installed in vacuum hose between EGRC-BPT valve and EGRC-solenoid valve.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace vacuum hose.

4	CHECK EGRC-BPT VALVE
Refer to "Component Inspection", EC-278.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace EGRC-BPT valve.

DTC P0402 EGRC-BPT VALVE FUNCTION

Diagnostic Procedure (Cont'd)


5	CHECK CAMSHAFT POSITION SENSOR
Refer to "Component Inspection", EC-266.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace camshaft position sensor.

8	CHECK EGR VALVE
Refer to "Component Inspection", EC-274.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EGR valve.

6	CHECK MASS AIR FLOW SENSOR
Refer to "Component Inspection", EC-124.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace mass air flow sensor.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

7	CHECK EGRC-SOLENOID VALVE
Refer to "Component Inspection", EC-359.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace EGRC-solenoid valve.



Component Inspection EGRC-BPT VALVE


NCEC0239

NCEC0239S01

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve.
Leakage should exist.

DTC P0420 THREE WAY CATALYST FUNCTION

On Board Diagnosis Logic



On Board Diagnosis Logic

NCEC0240

The ECM monitors the switching frequency ratio of front and rear heated oxygen sensors.

A three way catalyst with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase.

When the frequency ratio of front and rear heated oxygen sensors approaches a specified limit value, the three way catalyst malfunction is diagnosed.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0420 0702	<ul style="list-style-type: none"> • Three way catalyst does not operate properly. • Three way catalyst does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> • Three way catalyst • Exhaust tube • Intake air leaks • Injectors • Injector leaks • Spark plug • Improper ignition timing

3

☆ MONITOR ☆ NO FAIL

CMPS•RPM (REF)	2037rpm
FR O2 SEN	0.68V
RR O2 SEN	0.04V
FR O2 MNTR	RICH
RR O2 MNTR	LEAN
VHCL SPEED SE	0km/h

RECORD

SEF321UA

7

■ SRT STATUS ■

CATALYST	CMPLT
EVAP SYSTEM	INCMP
O2 SENSOR	CMPLT
O2 SEN HEATER	CMPLT
EGR SYSTEM	INCMP

PRINT

SEF215UB

DTC Confirmation Procedure

NCEC0241

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set "MANU TRIG" and "HI SPEED", then select "FR O2 SENSOR", "RR O2 SENSOR", "FR O2 MNTR", "RR O2 MNTR" in "DATA MONITOR" mode with CONSULT.
- 4) Touch "RECORD" on CONSULT screen with engine speed held at 2,000 rpm constantly under no load.
- 5) Make sure that the switching frequency between "RICH" and "LEAN" of "RR O2 MNTR" is much less than that of "FR O2 MNTR" as shown below.

Switching frequency ratio = A/B

A: Rear heated oxygen sensor switching frequency

B: Front heated oxygen sensor switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, the three way catalyst is not operating properly.

If the "FR O2 MNTR" does not indicate "RICH" and "LEAN" periodically more than 5 times within 10 seconds at step 4, perform trouble diagnoses for DTC P0133 first. (See EC-177.)

If the result is NG, go to "Diagnostic Procedure", EC-281.

If the result is OK, go to following step.

- 6) Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT.
- 7) Drive vehicle at a speed of approximately 84 to 96 km/h (52 to 60 MPH).

DTC P0420 THREE WAY CATALYST FUNCTION


DTC Confirmation Procedure (Cont'd)

60 MPH) with the following for at least 10 consecutive minutes.
(Drive the vehicle in an area where vehicle speed and accelerator pressure can be held steady and constant.)

M/T	5th position
A/T	D position ("OD" ON)

If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-281.

- 8) Select "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT.
- 9) Verify that "CATALYST" is "CMPLT".
If not "CMPLT", repeat the test from step 6.



Overall Function Check

NCEC0242

Use this procedure to check the overall function of the three way catalyst. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeters probes between ECM terminals 46 (Front heated oxygen sensor signal), 52 (Rear heated oxygen sensor signal) and engine ground.
- 4) Keep engine speed at 2,000 rpm constant under no load.
- 5) Make sure that the voltage switching frequency (high & low) between ECM terminal 52 and engine ground is much less than that of ECM terminal 46 and engine ground.

Switching frequency ratio = A/B

A: Rear heated oxygen sensor voltage switching frequency

B: Front heated oxygen sensor voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly.

NOTE:

If the voltage at terminal 46 does not switch periodically more than 5 times within 10 seconds at step 4, perform trouble diagnosis for DTC P0133 first. (See EC-161.)


DTC P0420 THREE WAY CATALYST FUNCTION

Diagnostic Procedure

Diagnostic Procedure


NCEC0243


1	CHECK EXHAUST SYSTEM
Visually check exhaust tubes and muffler for dent.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.

2	CHECK EXHAUST AIR LEAK
1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the three way catalyst.	
	
SEF099P	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

3	CHECK INTAKE AIR LEAK
Listen for an intake air leak after the mass air flow sensor.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair or replace.

4	CHECK IGNITION TIMING
Check for ignition timing. Refer to TROUBLE DIAGNOSIS — "BASIC INSPECTION", EC-83.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Adjust ignition timing.

5	CHECK INJECTORS
1. Refer to Wiring Diagram for Injectors, EC-451. 2. Stop engine and then turn ignition switch "ON". 3. Check voltage between ECM terminals 102, 104, 107 and 109 and ground with CONSULT or tester.	
	
SEF236W	
Battery voltage should exist.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Perform "Diagnostic Procedure" INJECTOR, EC-452.

6	CHECK IGNITION SPARK
1. Disconnect ignition wire from spark plug. 2. Connect a known good spark plug to the ignition wire. 3. Place end of spark plug against a suitable ground and crank engine. 4. Check for spark.	
	
SEF282G	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	CHECK IGNITION WIRES
Refer to "Component Inspection", EC-249.	
OK or NG	
OK	▶ Check ignition coil, power transistor and their circuits. Refer to EC-343.
NG	▶ Replace.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0420 THREE WAY CATALYST FUNCTION

Diagnostic Procedure (Cont'd)

8		CHECK INJECTOR
1. Turn ignition switch "OFF". 2. Remove injector assembly. Refer to EC-35. Keep fuel hose and all injectors connected to injector gallery. 3. Disconnect camshaft position sensor harness connector. 4. Turn ignition switch "ON". Make sure fuel does not drip from injector. <p style="text-align: center;">OK or NG</p>		
OK (Does not drip)	▶	GO TO 9.
NG (Drips)	▶	Replace the injector(s) from which fuel is dripping.

9		CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.		
Trouble is fixed	▶	INSPECTION END
Trouble is not fixed	▶	Replace three way catalyst.

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0244


NOTE:

If DTC P0440 is displayed with DTC P1448, perform trouble diagnosis for DTC P1448 first. (See EC-397.)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge control valve under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control valve and EVAP canister purge control valve are opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control valve and EVAP canister purge control valve will be closed.



DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0440 0705	<ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge control valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge control valve ● EVAP canister purge volume control valve ● EVAP canister purge control solenoid valve and the circuit ● Absolute pressure sensor ● Tank fuel temperature sensor ● MAP/BARO switch solenoid valve and the circuit ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water. ● EVAP control system pressure sensor

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

DTC Confirmation Procedure

5

■ EVAP SML LEAK P0440 ■ □

- 1) PERFORM TEST AT A LOCATION OF 0-30C (32-86F)
- 2) OPEN ENGINE HOOD.
- 3) START ENGINE WITH VEHICLE STOPPED. IF ENG IS ON, STOP FOR 5 SEC. THEN RESTART.
- 4) TOUCH START.

EXIT START

SEF405WA

5

■ EVAP SML LEAK P0440 ■ □

WAIT. . .

2 TO 10 MINUTES
KEEP ENGINE RUNNING
AT IDLE SPEED.

SEF929V

5

■ EVAP SML LEAK P0440 ■ □

CAN NOT BE DIAGNOSED

FUEL TEMPERATURE IS TOO HIGH. RETEST AFTER FUEL HAS COOLED.

EXIT PRINT

SEF669UC

6

■ EVAP SML LEAK P0440 ■ □

***** OK *****

END PRINT

SEF297UC

DTC Confirmation Procedure

NCEC0245

NOTE:

- If DTC P0440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. Refer to EC-397.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
- 1) Turn ignition switch "ON".
 - 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 - 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 - 4) Check that the following conditions are met.

COOLAN TEMP/S	0 - 70°C (32 - 158°F)
INT/A TEMP SE	0 - 60°C (32 - 140°F)

- 5) Select "EVAP SML LEAK P0440" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT. Follow the instruction displayed.

NOTE:

- If the CONSULT screen shown at left is displayed, stop the engine and stabilize the vehicle temperature at 25°C (77°F) or cooler. After "TANK F/TMP SE" becomes less than 30°C (86°F), retest. (Use a fan to reduce the stabilization time.)
 - If the engine cannot be maintained within the range on CONSULT screen, go to "Basic Inspection", EC-83.
- 6) Make sure that "OK" is displayed. If "NG" is displayed, refer to "Diagnostic Procedure", EC-286.

Ⓟ With GST

- 1) Start engine.
- 2) Drive vehicle according to "Driving pattern", EC-48.

NOTE:

Be sure to read the explanation of "Driving pattern" on EC-48 before driving vehicle.

- 3) Stop vehicle.
- 4) Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch "OFF" and wait at least 5 seconds.
- 6) Start engine.

It is not necessary to cool engine down before driving.
- 7) Drive vehicle again according to the "Driving pattern", EC-48.
- 8) Stop vehicle.
- 9) Select "MODE 3" with GST.
 - If P1447 is displayed on the screen, go to "Diagnostic Procedure", EC-393.
 - If P0440 is displayed on the screen, go to "Diagnostic Procedure", EC-286.

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

DTC Confirmation Procedure (Cont'd)

- If P1440 is displayed on the screen, go to "Diagnostic Procedure", EC-374.
- If P0440, P1440 and P1447 are not displayed on the screen, go to the following step.

GI

10) Select "MODE 1" with GST.

MA

- If SRT of EVAP system is set, the result will be OK.
- If SRT of EVAP system is not set, go to step 5.

EM

No Tools

- 1) Start engine.
- 2) Drive vehicle according to "Driving pattern", EC-48.

LC

NOTE:

- **Be sure to read the explanation of "Driving pattern" on EC-48 before driving vehicle.**

EC

- 3) Stop vehicle.
- 4) Turn ignition switch "OFF" and wait at least 5 seconds.
- 5) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-286.

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

Diagnostic Procedure

Diagnostic Procedure



-NCEC0246

1	CHECK FUEL FILLER CAP DESIGN	
1. Turn ignition switch "OFF". 2. Check for genuine NISSAN fuel filler cap design.		
		
SEF915U		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace with genuine NISSAN fuel filler cap.

2	CHECK FUEL FILLER CAP INSTALLATION	
Check that the cap is tightened properly rotating the cap clockwise.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	<ul style="list-style-type: none"> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower. ● Retighten until ratching sound is heard.



3	CHECK FUEL FILLER CAP FUNCTION	
Check for air releasing sound while opening the fuel filler cap.		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 4.




4	CHECK FUEL TANK VACUUM RELIEF VALVE	
Refer to "Evaporative Emission System", EC-27.		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Replace fuel filler cap with a genuine one.

5	INSTALL PRESSURE PUMP	
1. Install the EVAP service port adapter and the pressure pump securely to EVAP service port.		
		
SEF303W		
EVAP service port adapter		
		
SEF462UE		
NOTE:		
<ul style="list-style-type: none"> ● Improper installation of service port may cause leaking. 		
Models with CONSULT	▶	GO TO 6.
Models without CONSULT	▶	GO TO 7.

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

Diagnostic Procedure (Cont'd)


6	CHECK FOR EVAP LEAK
<p>Ⓜ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT. 	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>■ EVAP SYSTEM CLOSE ■ APPLY PRESSURE TO EVAP SYSTEM FROM SERVICE PORT USING HAND PUMP WITH PRESSURE GAUGE AT NEXT SCREEN. NEVER USE COMPRESSED AIR OR HIGH PRESSURE PUMP! DO NOT START ENGINE. TOUCH START.</p> </div>	
<div style="display: flex; justify-content: center; gap: 20px;"> <div style="border: 1px solid black; padding: 2px 10px;">CANCEL</div> <div style="border: 1px solid black; padding: 2px 10px;">START</div> </div>	
SEF658U	
<ol style="list-style-type: none"> Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of bar graph. <p>NOTE:</p> <ul style="list-style-type: none"> Never use compressed air or a high pressure pump. Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system. 	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>■ EVAP SYSTEM CLOSE ■ <input type="checkbox"/></p> <p>APPLY PRESSURE TO SERVICE PORT TO RANGE BELOW. DO NOT EXCEED 0.6psi.</p> <div style="text-align: center;">  </div> </div>	
END	
SEF917U	
<ol style="list-style-type: none"> Using EVAP leak detector, locate the leak portion. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31. 	
<p>Leak detector</p> 	
SEF200U	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair or replace.


7	CHECK FOR EVAP LEAK
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.) 	
<p>Under the vehicle view</p> 	
SEF304W	
<ol style="list-style-type: none"> Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12 volts until the end of test.) 	
<p>Under the vehicle view</p> 	
SEF305W	
<ol style="list-style-type: none"> Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg). <p>NOTE:</p> <ul style="list-style-type: none"> Never use compressed air or a high pressure pump. Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system. 	
<ol style="list-style-type: none"> Using EVAP leak detector, locate the leak. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31. 	
<p>Leak detector</p> 	
SEF200U	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair or replace.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

Diagnostic Procedure (Cont'd)

8	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
Refer to "Component Inspection", EC-295.	
 <p>EVAP canister purge volume control valve harness connector</p> <p>Intake manifold collector</p> <p style="text-align: right;">SEF306W</p>	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EVAP canister purge volume control valve.

9	CHECK EVAP CANISTER PURGE CONTROL VALVE
Refer to "Component Inspection", EC-427.	
 <p>Brake fluid reservoir</p> <p>EVAP canister purge control valve</p> <p style="text-align: right;">SEF307W</p>	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP canister purge control valve.

10	CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT
Refer to "DTC Confirmation Procedure", EC-297.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Repair or replace EVAP canister vent control valve and O-ring or harness/connectors.

11	CHECK IF EVAP CANISTER IS SATURATED WITH WATER
<ol style="list-style-type: none"> Remove EVAP canister with EVAP canister vent control valve attached. Check if water will drain from the EVAP canister. 	
 <p>EVAP canister</p> <p>Water</p> <p>EVAP canister vent control valve</p> <p style="text-align: right;">SEF596U</p>	
Yes or No	
Yes	▶ GO TO 12.
No (With CONSULT)	▶ GO TO 14.
No (Without CONSULT)	▶ GO TO 15.

12	CHECK EVAP CANISTER
Weigh the EVAP canister with EVAP canister vent control valve attached.	
The weight should be less than 1.8 kg (4.0 lb).	
OK or NG	
OK (With CONSULT)	▶ GO TO 14.
OK (Without CONSULT)	▶ GO TO 15.
NG	▶ GO TO 13.

13	DETECT MALFUNCTIONING PART
Check the following.	
<ol style="list-style-type: none"> Visually check the EVAP canister for damage. Check hose connection between EVAP canister and water separator for clogging and poor connection. Check water separator. <p>Refer to "Component Inspection", EC-389.</p>	
▶	Repair hose or replace EVAP canister or water separator.

DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)


Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


14 CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE

With CONSULT

1. Disconnect vacuum hose from EVAP canister purge control valve and install vacuum gauge.




SEF307W



SEF622U

2. Start engine and let it idle.
3. Perform "PURG CONT S/V" in "ACTIVE TEST" mode.
4. Rev engine up to 2,000 rpm.
5. Select "ON" and "OFF" on CONSULT screen to turn on "PURG CONT/V S/V".



SEF738W

ON: Vacuum should exist.
OFF: Vacuum should not exist.


OK or NG

OK	▶	GO TO 17.
NG	▶	GO TO 16.


15 CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE

Without CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Lift up drive wheels.
4. Disconnect vacuum hose from EVAP canister purge volume control valve and install vacuum gauge.



SEF307W



SEF622U

5. Start engine and let it idle for at least 60 seconds.
6. Shift selector lever to 1st gear position (M/T models).
7. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
While operating solenoid valve, vacuum should exist.
8. Release the accelerator pedal and let idle.
Vacuum should not exist.

OK or NG

OK	▶	GO TO 17.
NG	▶	GO TO 16.

16 DETECT MALFUNCTIONING PART


Check the following.


- EVAP canister purge control solenoid valve
Refer to "Component Inspection", EC-419.
- Vacuum hoses for clogging or disconnection.
Refer to "Vacuum Hose Drawing", EC-21.


▶ Repair hoses or replace EVAP canister purge control solenoid valve.


DTC P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (NEGATIVE PRESSURE)

Diagnostic Procedure (Cont'd)

17	CHECK ABSOLUTE PRESSURE SENSOR
Refer to "Component Inspection", EC-133.	
 <p>Absolute pressure sensor harness connector</p> <p>Intake manifold collector</p> <p style="text-align: right;">SEF294W</p>	
OK or NG	
OK	▶ GO TO 18.
NG	▶ Replace absolute pressure sensor.

18	CHECK MAP/BARO SWITCH SOLENOID VALVE AND CIRCUIT
Refer to "DTC Confirmation Procedure", EC-332.	
Under view of engine compartment	
 <p>Exhaust front tube</p> <p>Vehicle front</p> <p>MAP/BARO switch solenoid valve</p> <p>Harness connector</p> <p style="text-align: right;">SEF290V</p>	
OK or NG	
OK	▶ GO TO 19.
NG	▶ Repair or replace MAP/BARO switch solenoid valve or harness/connector.

19	CHECK TANK FUEL TEMPERATURE SENSOR
Refer to "Component Inspection", EC-244.	
Under rear seat cushion	
 <p>Fuel pump harness connector</p> <p>Fuel tank gauge unit harness connector</p> <p style="text-align: right;">SEF299W</p>	
OK or NG	
OK	▶ GO TO 20.
NG	▶ Replace tank fuel temperature sensor.

20	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR
Refer to "Component Inspection", EC-308.	
Under the vehicle view (Rear left)	
 <p>EVAP control system pressure sensor harness connector</p> <p>EVAP canister</p> <p style="text-align: right;">SEF309W</p>	
OK or NG	
OK	▶ GO TO 21.
NG	▶ Replace EVAP control system pressure sensor.

21	CHECK EVAP PURGE LINE
Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31.	
OK or NG	
OK	▶ GO TO 22.
NG	▶ Repair or reconnect the hose.

22	CLEAN EVAP PURGE LINE
Clean EVAP purge line (pipe and rubber tube) using air blower.	
▶ GO TO 23.	

23	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

DTC P0443 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE (CIRCUIT)

Description

Description SYSTEM DESCRIPTION

NCEC0248

NCEC0248S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge control	EVAP canister purge volume control valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage		
Ignition switch	Start signal		
Closed throttle position switch	Closed throttle position		
Throttle position sensor	Throttle position		
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Tank fuel temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

GI
MA
EM
LC
EC
FE
CL

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor bypass passage in the EVAP canister purge volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.


MT
AT
AX
SU
BR

COMPONENT DESCRIPTION

NCEC0248S02

The EVAP canister purge volume control valve uses a step motor to control the flow rate of fuel vapor from the EVAP canister. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

ST
RS
BT
HA



CONSULT Reference Value in Data Monitor Mode

NCEC0249

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● No-load ● Lift up drive wheels and shift to 1st gear position.	Idle More than 60 seconds after starting engine More than 16 km/h (10 MPH)
		0 step More than 1 step

EL
IDX

DTC P0443 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE (CIRCUIT)

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NCEC0250

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
5	L	EVAP canister purge vol- ume control valve	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.6V
6	G			
16	Y	EVAP canister purge vol- ume control valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
17	OR			

On Board Diagnosis Logic

NCEC0251

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0443 1008	<ul style="list-style-type: none"> An improper voltage signal is sent to ECM through the valve. 	<ul style="list-style-type: none"> Harness or connectors (The valve circuit is open or shorted.) EVAP canister purge volume control valve

DTC Confirmation Procedure


NCEC0252

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V with ignition switch "ON".



③ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-294.

④ With GST

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-294.

⑤ No Tools

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-294.

DTC P0443 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE (CIRCUIT)

Wiring Diagram

Wiring Diagram

NCEC0263

EC-PGC/V-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA


SC

EL

IDX




— : Detectable line for DTC
 - - - : Non-detectable line for DTC



Refer to last page (Foldout page).

M5



F26
W





TEC538

DTC P0443 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE (CIRCUIT)


Diagnostic Procedure

Diagnostic Procedure

NCEC0254

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect EVAP canister purge volume control valve harness connector.</p>  <p style="text-align: right;">SEF306W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminals 2, 5 and engine ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF237W</p> <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness for open or short between EVAP canister purge volume control valve and ECM relay • Harness for open or short between EVAP canister purge volume control valve and ECM <p style="text-align: right;">▶ Repair harness or connectors.</p>	




3	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 16 and terminal 3, ECM terminal 17 and terminal 6, ECM terminal 5 and terminal 1, ECM terminal 6 and terminal 4.</p>  <p style="text-align: right;">SEF238W</p> <p style="text-align: center;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
<p>Refer to "Component Inspection" EC-295.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Replace EVAP canister purge volume control valve.

5	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <p style="text-align: right;">▶ INSPECTION END</p>	

DTC P0443 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE (CIRCUIT)

Component Inspection



Component Inspection

EVAP CANISTER PURGE VOLUME CONTROL VALVE

NCEC0255
NCEC0255S01

With CONSULT

- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal 2 and terminals 1, 3
terminal 5 and terminals 4, 6

Resistance: 35 - 43Ω [At 20°C (68°F)]

If NG, replace the EVAP canister purge volume control valve.
If OK, go to the following step.

- 3) Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve. (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON".
- 6) Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.

If NG, replace the EVAP canister purge volume control valve.

Without CONSULT

- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal 2 and terminals 1, 3
terminal 5 and terminals 4, 6

Resistance: 35 - 43Ω [At 20°C (68°F)]

If NG, replace the EVAP canister purge volume control valve.
If OK, go to the following step.

- 3) Reconnect EVAP canister purge volume control valve harness connector.
 - 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve. (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
 - 5) Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
- If NG, replace the EVAP canister purge volume control valve.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

Component Description



Component Description

NCEC0256

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

CONSULT Reference Value in Data Monitor Mode

NCEC0257

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

ECM Terminals and Reference Value

NCEC0258

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
108	PU/W	EVAP canister vent control valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)


On Board Diagnosis Logic

NCEC0259

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0446 0903	● An improper voltage signal is sent to ECM through EVAP canister vent control valve.	<ul style="list-style-type: none"> ● Harness or connectors (EVAP canister vent control valve circuit is open or shorted.) ● EVAP canister vent control valve

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0260

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓟ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-299.

Ⓢ With GST

- 1) Start engine and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-299.

Ⓜ No Tools

- 1) Start engine and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-299.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

Wiring Diagram

Wiring Diagram


NCEC0261

EC-VENT/V-01



Refer to last page (Foldout page).

M3



TEC539

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)



Diagnostic Procedure

Diagnostic Procedure

NCEC0262

1	INSPECTION START	
Do you have CONSULT?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK CIRCUIT	
1. Turn ignition switch "ON".		
2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.		
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></p> <p style="text-align: center;">VENT CONTROL/V OFF</p> <p style="text-align: center;">===== MONITOR =====</p> <p>CMPS-RPM(REF) 0rpm</p> <p>FR O2 MNTR RICH</p> <p>A/F ALPHA 100%</p> <p>THRTL POS SEN 0.52V</p> <p style="text-align: center;"> <input type="button" value="ON"/> <input checked="" type="button" value="ON/OFF"/> <input type="button" value="OFF"/> </p> </div>		
SEF361U		
3. Make sure that ratcheting sound is heard from the vent control valve.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	GO TO 3.

3	CHECK POWER SUPPLY	
1. Turn ignition switch "OFF".		
2. Disconnect EVAP canister vent control valve harness connector.		
<p>Under the vehicle view</p>  <p style="text-align: right;">EVAP canister vent control valve harness connector</p> <p style="text-align: right;">EVAP canister</p> <p style="text-align: right;">SEF310W</p>		
3. Turn ignition switch "ON".		
4. Check voltage between terminal 1 and ground with CONSULT or tester.		
 <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: right;">SEF240W</p>		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

4	DETECT MALFUNCTIONING PART	
Check the following.		
<ul style="list-style-type: none"> ● Harness connectors M8, B3 ● Harness connectors B10, B120 ● Harness connectors B113, T1 ● Harness connectors T20, T19 ● 10A fuse ● Harness for open or short between EVAP canister vent control valve and fuse 		
▶		Repair harness or connectors.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

Diagnostic Procedure (Cont'd)

5	CHECK OUTPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between ECM terminal 108 and terminal 2. 	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M8, B3 • Harness connectors B10, B120 • Harness connectors B113, T1 • Harness connectors T20, T19 • Harness for open or short between EVAP canister vent control valve and ECM 	
▶	<p>Repair open circuit or short to ground or short to power in harness or connectors.</p>

7	CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING
<p>Refer to "Component Inspection", EC-300.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace EVAP canister vent control valve and O-ring.

8	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

Component Inspection

EVAP CANISTER VENT CONTROL VALVE

NCEC0263

NCEC0263S01

Check air passage continuity.

ⓑ With CONSULT

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.

Condition	Air passage continuity between A and B
VENT CONTROL/V ON	No
VENT CONTROL/V OFF	Yes

ⓧ Without CONSULT

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
No supply	Yes

DTC P0446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CIRCUIT)

Component Inspection (Cont'd)

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


Component Description



Component Description

NCEC0264

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT Reference Value in Data Monitor Mode

NCEC0265

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	Approx. 3.4V

ECM Terminals and Reference Value

NCEC0266

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	P/L	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
50	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
67	W	EVAP control system pres-sure sensor	[Ignition switch "ON"]	Approximately 3.4V

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0267

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0450 0704	<ul style="list-style-type: none"> An improper voltage signal from EVAP control system pressure sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The EVAP control system pressure sensor circuit is open or shorted.) Rubber hose to EVAP control system pressure is clogged, vent, kinked, disconnected or improper connection. EVAP control system pressure sensor EVAP canister vent control valve EVAP canister purge volume control valve EVAP canister Rubber hose from EVAP canister vent control valve to water separator

GI

MA

EM

LC

EC

FE

CL

MT

DTC Confirmation Procedure

NCEC0268

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform test at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm battery voltage is more than 10V at idle.

Ⓟ With CONSULT


- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT.
- Make sure that "TANK F/TEMP SE" is more than 0°C (32°F).
- Start engine and wait at least 20 seconds.
- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

Ⓢ With GST

- Start engine and warm it up to normal operating temperature.
- Check that voltage between ECM terminal 63 (Tank fuel temperature sensor signal) and ground is less than 4.2V.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Start engine and wait at least 20 seconds.
- Select "MODE 7" with GST.
- If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

Ⓣ No Tools

- Start engine and warm it up to normal operating temperature.
- Check that voltage between ECM terminal 63 (Tank fuel temperature sensor signal) and ground is less than 4.2V.
- Turn ignition switch "OFF" and wait at least 5 seconds.



AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

489

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

DTC Confirmation Procedure (Cont'd)

- 4) Start engine and wait at least 20 seconds.
- 5) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

Wiring Diagram

Wiring Diagram

NCEC0269

EC-PRE/SE-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEC540



491

EVAP CONTROL SYSTEM PRESSURE SENSOR (T13)

— : Detectable line for DTC

- - - : Non-detectable line for DTC

Ⓐ : With A/T




DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR


Diagnostic Procedure


Diagnostic Procedure

NCEC0270


1	CHECK RUBBER TUBE CONNECTED TO THE SENSOR
Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Reconnect, repair or replace.

2	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
 <p>Engine ground</p> <p>Throttle body</p> <p style="text-align: right;">SEF292W</p>	
▶ GO TO 3.	

3	CHECK HARNESS CONNECTOR
1. Disconnect EVAP control system pressure sensor harness connector.	
<p>Under the vehicle view (Rear left)</p>  <p>EVAP control system pressure sensor harness connector</p> <p>EVAP canister</p> <p style="text-align: right;">SEF309W</p>	
2. Check sensor harness connector for water. Water should not exist.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Repair or replace harness connector.

4	CHECK POWER SUPPLY
1. Turn ignition switch "ON". 2. Check voltage between terminal 1 and engine ground with CONSULT or tester.	
 <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: right;">SEF242W</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> • Harness connectors F24, M62 • Harness connectors M8, B3 • Harness connectors B10, B120 • Harness connectors B113, T1 • Harness connectors T20, T19 • Harness for open or short between EVAP control system pressure sensor and ECM 	
▶ Repair harness or connectors.	

6	CHECK GROUND CIRCUIT
1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 3 and engine ground.	
 <p style="text-align: center;">Continuity should exist.</p> <p style="text-align: right;">SEF243W</p>	
3. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

7	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F24, M62 ● Harness connectors M8, B3 ● Harness connectors B10, B120 ● Harness connectors B113, T1 ● Harness connectors T20, T19 ● Harness for open or short between EVAP control system pressure sensor and ECM ● Harness for open or short between EVAP control system pressure sensor and TCM (Transmission control module) 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK INPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 67 and terminal 2.</p>	
<p style="text-align: right;">SEF244W</p>	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK ▶	GO TO 10.
NG ▶	GO TO 9.

9	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F24, M62 ● Harness connectors M8, B3 ● Harness connectors B10, B120 ● Harness connectors B113, T1 ● Harness connectors T20, T19 ● Harness for open or short between ECM and EVAP control system pressure sensor 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

10	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
Refer to "Component Inspection", EC-295.	
OK or NG	
OK ▶	GO TO 11.
NG ▶	Replace EVAP canister purge volume control valve.

11	CHECK EVAP CANISTER VENT CONTROL VALVE
Refer to "Component Inspection", EC-389.	
OK or NG	
OK ▶	GO TO 12.
NG ▶	Replace EVAP canister vent control valve.

12	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR
Refer to "Component Inspection", EC-308.	
OK or NG	
OK ▶	GO TO 13.
NG ▶	Replace EVAP control system pressure sensor.

13	CHECK RUBBER TUBE FOR CLOGGING
<p>Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower.</p> <p>For water separator, refer to EC-389.</p>	
OK or NG	
OK ▶	GO TO 14.
NG ▶	Clean, repair or replace rubber tube and/or water separator.

CI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

14	CHECK IF EVAP CANISTER SATURATED WITH WATER
<ol style="list-style-type: none"> Remove EVAP canister with EVAP canister vent control valve attached. Check if water will drain from the EVAP canister. 	
SEF596U	
Yes or No	
Yes	▶ GO TO 15.
No	▶ GO TO 17.


15	CHECK EVAP CANISTER
<p>Weigh the EVAP canister with EVAP canister vent control valve attached.</p> <p>The weight should be less than 1.8 kg (4.0 lb).</p>	
OK or NG	
OK	▶ GO TO 17.
NG	▶ GO TO 16.

16	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ol style="list-style-type: none"> Visually check the EVAP canister for damage. Check hose connection between EVAP canister and water separator for clogging and poor connection. Check water separator. Refer to "Component Inspection", EC-389. 	
▶ Repair hose or replace EVAP canister or water separator.	

17	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Reconnect disconnected harness connectors. Disconnect harness connectors T19, T20. Check harness continuity between terminal 8 and engine ground. 	
SEF245W	
Continuity should exist.	
<ol style="list-style-type: none"> Also check harness for short to power. Then reconnect harness connectors. 	
OK or NG	
OK	▶ GO TO 19.
NG	▶ GO TO 18.

18	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors T20, T19 • Harness connectors B113, T1 • Harness connectors B10, B120 • Harness connectors M8, B3 • Harness connectors F24, M62 • Joint connector-2 (Refer to "HARNES LAYOUT" in EL section.) • Joint connector-1 (Refer to "HARNES LAYOUT" in EL section.) • Harness for open or short between harness connector T20 and engine ground 	
▶ Repair open circuit, short to ground or short to power in harness or connectors.	

19	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	



Component Inspection

EVAP CONTROL SYSTEM PRESSURE SENSOR

NCEC0271

NCEC02/1501

- Remove EVAP control system pressure sensor with its harness connector connected.
- Remove hose from EVAP control system pressure sensor.
- Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
- Check output voltage between ECM terminal 67 and engine ground.

DTC P0450 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PRESSURE SENSOR

Component Inspection (Cont'd)

Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg)	0.4 - 0.6

GI

MA

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
 - Do not apply below -20 kPa (-150 mmHg, -5.91 inHg) or over 20 kPa (150 mmHg, 5.91 inHg) of pressure.
5. If NG, replace EVAP control system pressure sensor.

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

DTC P0500 VEHICLE SPEED SENSOR (VSS)

Component Description



Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

NCEC0272

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

NCEC0273

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
26	Y/G	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> Lift up the vehicle In 2nd gear position Vehicle speed is 40 km/h (25 MPH) 	<p>0 - Approximately 4.2V</p> <p>SEF003W</p>

On Board Diagnosis Logic

NCEC0274

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0500 0104	<ul style="list-style-type: none"> The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven. 	<ul style="list-style-type: none"> Harness or connector (The vehicle speed sensor circuit is open or shorted.) Vehicle speed sensor

2

■ VEHICLE SPEED SEN CKT ■

AFTER TOUCH START.
DRIVE VEHICLE
AT 10km/h (6mph) OR
MORE WITHIN 15 sec.

MEF559DB

DTC Confirmation Procedure

NCEC0275

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

With CONSULT

- Start engine.
- Perform "VEHICLE SPEED SEN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.
- If NG, go to "Diagnostic Procedure", EC-314. If OK, go to following step.
- Select "DATA MONITOR" mode with CONSULT.
- Warm engine up to normal operating temperature.
- Maintain the following conditions for at least 10 consecutive seconds.

6

☆ MONITOR ☆ NO FAIL

CMPS•RPM(REF)	2000rpm
COOLAN TEMP/S	88°C
B/FUEL SCHDL	3.0msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	56km/h


SEF199VD

DTC P0500 VEHICLE SPEED SENSOR (VSS)

DTC Confirmation Procedure (Cont'd)

CMPS-RPM (REF)	2,000 - 3,200 rpm (A/T) 1,950 - 2,900 rpm (M/T)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2.3 - 3.5 msec (A/T) 2.3 - 3.7 msec (M/T)
Selector lever	Suitable position
PW/ST SIGNAL	OFF

- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-314.



ⓑ With CONSULT

- 1) Start engine
- 2) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT. The vehicle speed on CONSULT should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- 3) If NG, go to "Diagnostic Procedure", EC-314. If OK, go to following step.
- 4) Select "DATA MONITOR" mode with CONSULT.
- 5) Warm engine up to normal operating temperature.
- 6) Maintain the following conditions for at least 10 consecutive seconds.

CMPS-RPM (REF)	2,000 - 3,200 rpm (A/T) 1,950 - 2,900 rpm (M/T)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2.3 - 3.5 msec (A/T) 2.3 - 3.7 msec (M/T)
Selector lever	Suitable position
PW/ST SIGNAL	OFF

- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-314.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0500 VEHICLE SPEED SENSOR (VSS)


Overall Function Check

Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a 1st trip DTC might not be confirmed. NCEC0276

With GST

- 1) Lift up drive wheels.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with GST.
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- 4) If NG, go to "Diagnostic Procedure", EC-314.



No Tools

- 1) Lift up drive wheels.
- 2) Start engine.
- 3) Read the voltage signal between ECM terminal 26 (Vehicle speed sensor signal) and ground with oscilloscope.
- 4) Verify that the oscilloscope screen shows the signal wave as shown at "ECM Terminals and Reference Value", EC-310.
- 5) If NG, go to "Diagnostic Procedure", EC-314.

DTC P0500 VEHICLE SPEED SENSOR (VSS)

Wiring Diagram

Wiring Diagram

NCEG0277

EC-VSS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS





BT

HA


SC

EL

IDX



Refer to last page (Foldout page).



TEC541

DTC P0500 VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure

Diagnostic Procedure

NCEC0278

1	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector and combination meter harness connector. Check harness continuity between ECM terminal 26 and meter terminal 32. 	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

5	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

2	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> Harness connectors F23, M49 Harness for open or short between ECM and combination meter 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK SPEEDOMETER FUNCTION
Make sure that speedometer functions properly.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> Harness connectors M6, E75 Harness connectors E33, E101 Harness for open or short between combination meter and vehicle speed sensor 	
▶	Repair harness or connectors. Check vehicle speed sensor and its circuit. Refer to EL section.

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Description

Description SYSTEM DESCRIPTION

NCEC0279

NCEC0279S01


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	ECM	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
PNP switch	Park/Neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Cooling fan	Cooling fan operation		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).

COMPONENT DESCRIPTION

NCEC0279S02

The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT Reference Value in Data Monitor Mode

NCEC0280

MONITOR ITEM	CONDITION	SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle
		2,000 rpm
		20 - 40%
		—



DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NCEC0281

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	SB	IACV-AAC valve	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 10V  SEF015W
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	Approximately 5 - 13V  SEF016W

On Board Diagnosis Logic

NCEC0282


DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P0505 0205	A)	The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open.) ● IACV-AAC valve
	B)	The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is shorted.) ● IACV-AAC valve

DTC Confirmation Procedure

NCEC0283

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.
- Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B".



PROCEDURE FOR MALFUNCTION A

NCEC0283501

① With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it at idle at least 2 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

② With GST

- 1) Start engine and run it at idle at least 2 seconds.
- 2) Select "MODE 7" with GST.

DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

DTC Confirmation Procedure (Cont'd)

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

Ⓜ No Tools

- 1) Start engine and run it at idle at least 2 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

GI

MA

EM

LC

4

☆ MONITOR
☆ NO FAIL

CMPS•RPM(REF)	700rpm
COOLAN TEMP/S	85°C
INT/A TEMP SE	18°C

RECORD

SEF327UA

PROCEDURE FOR MALFUNCTION B

NCEC0283S02

TESTING CONDITION:

Before performing the following procedure, make sure battery voltage is more than 11V at idle.

EC

Ⓜ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and run it for at least 1 minute at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

FE

CL

MT

Ⓜ With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine again and run it for at least 1 minute at idle speed.
- 4) Select "MODE 7" with GST.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

AT

AX

SU

Ⓜ No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine again and run it for at least 1 minute at idle speed.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-319.

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Wiring Diagram


Wiring Diagram

NCEC0284

EC-AAC/V-01




: Detectable line for DTC
 : Non-detectable line for DTC



Refer to last page (Foldout page).

M3



F26
W





DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


Diagnostic Procedure

NCEC0285

Diagnostic Procedure


1	CHECK POWER SUPPLY						
<ol style="list-style-type: none"> Stop engine. Disconnect IACV-AAC valve harness connector. 							
 <p style="text-align: right;">SEF311W</p>							
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 2 and ground with CONSULT or tester. 							
 <p style="text-align: right;">SEF247W</p>							
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>		OK	▶	GO TO 3.	NG	▶	GO TO 2.
OK	▶	GO TO 3.					
NG	▶	GO TO 2.					

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F24, M62 10A fuse Harness for open or short between IACV-AAC and fuse 	
▶ Repair harness or connectors.	

3	CHECK OUTPUT SIGNAL CIRCUIT						
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between ECM terminal 101 and terminal 1. 							
 <p style="text-align: right;">SEF248W</p>							
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		OK	▶	GO TO 4.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
OK	▶	GO TO 4.					
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.					

4	CHECK IACV-AAC VALVE						
<p>Refer to "Component Inspection", EC-319.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace IACV-AAC valve.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	Replace IACV-AAC valve.
OK	▶	GO TO 5.					
NG	▶	Replace IACV-AAC valve.					

5	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	

 <p style="text-align: right;">SEF249W</p>	
-------------------------------------------------------------------------------------------------------------------------------	--

Component Inspection IACV-AAC VALVE

NCEC0286

NCEC0286S01

Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance: Approximately 10 Ω [at 25°C (77°F)]

- Check plunger for seizing or sticking.
- Check for broken spring.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX
505

DTC P0510 CLOSED THROTTLE POSITION SWITCH

Component Description



Component Description

NCEC0287

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control. When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge control valve when the throttle position sensor is malfunctioning.

ECM Terminals and Reference Value

NCEC0288


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
27	Y	Throttle position switch (Closed position)	[Ignition switch "ON"] • Warm-up condition • Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] • Accelerator pedal depressed	Approximately 0V

On Board Diagnosis Logic

NCEC0289

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0510 0203	<ul style="list-style-type: none"> Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened. 	<ul style="list-style-type: none"> Harness or connectors (The closed throttle position switch circuit is shorted.) Closed throttle position switch Throttle position sensor



DTC Confirmation Procedure

NCEC0290

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.


With CONSULT

- Start engine and warm it up to normal operating temperature.
- Check voltage between ECM terminal 27 (Closed throttle position switch signal) and ground under the following conditions.

Condition	Voltage
At idle	Battery voltage
At 2,000 rpm	Approximately 0V

If the result is NG, go to "Diagnostic Procedure", EC-323.
If OK, go to following step.

- Select "DATA MONITOR" mode with CONSULT.
- Drive the vehicle for at least 5 consecutive seconds under the following condition.




DTC P0510 CLOSED THROTTLE POSITION SWITCH

DTC Confirmation Procedure (Cont'd)

THRTL POS SEN	More than 2.3V
VHCL SPEED SE	More than 4 km/h (2 MPH)
Selector lever	Suitable position
Driving pattern	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-323.



Overall Function Check

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 27 (Closed throttle position switch signal) and ground under the following conditions.

Condition	Voltage
At idle	Battery voltage
At 2,000 rpm	Approximately 0V

3) If NG, go to "Diagnostic Procedure", EC-323.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P0510 CLOSED THROTTLE POSITION SWITCH

Wiring Diagram

Wiring Diagram

NCEC0292

EC-TP/SW-01





TEC543

DTC P0510 CLOSED THROTTLE POSITION SWITCH


Diagnostic Procedure

NCEC0293

Diagnostic Procedure

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect throttle position switch harness connector.</p>	
 <p style="text-align: right;">SEF297W</p>	
<p>3. Turn ignition switch "ON". 4. Check voltage between terminal 5 and engine ground with CONSULT or tester.</p>	
 <p style="text-align: right;">SEF250W</p>	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors F24, M62 • 10A fuse • Harness for open or short between throttle position switch and fuse 	
▶ Repair harness or connectors.	

3	CHECK INPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 27 and terminal 4.</p>	
 <p style="text-align: right;">SEF251W</p>	
<p style="text-align: center;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness for open or short between throttle position switch and ECM • Harness for open or short between throttle position switch and TCM (Transmission control module) 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	ADJUST THROTTLE POSITION SWITCH IDLE POSITION
<p>Perform Basic Inspection, EC-83.</p>	
▶ GO TO 6.	

6	CHECK CLOSED THROTTLE POSITION SWITCH
<p>Refer to "Component Inspection", EC-324.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Replace throttle position switch.



7	CHECK THROTTLE POSITION SENSOR
<p>Refer to "Component Inspection", EC-155.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace throttle position sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0510 CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure (Cont'd)

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection

CLOSED THROTTLE POSITION SWITCH

NCEC0294

NCEC0294S01

Ⓜ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT.
- 4) Check indication of "CLSD THL/P SW" under the following conditions.

NOTE:

Measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely open	OFF

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-83.

- 5) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF".
- 3) Disconnect throttle position switch harness connector.
- 4) Check continuity between terminals 4 and 5 under the following conditions.

NOTE:

Continuity measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely open	No

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-83.

- 5) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

DTC P0600 A/T CONTROL

System Description

System Description

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration. Voltage signals are exchanged between ECM and TCM (Transmission control module). NCEC0494

ECM Terminals and Reference Value


Specification data are reference values and are measured between each terminal and 43 (ECM ground). NCEC0495

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	Y/R	A/T signal No. 1	[Ignition switch "ON"] [Engine is running] ● Idle speed	6 - 8V
29	Y/G	A/T signal No. 2	[Ignition switch "ON"] [Engine is running] ● Idle speed	6 - 8V
30	Y/B	A/T signal No. 3	[Ignition switch "ON"]	0V

On Board Diagnosis Logic

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0600*	● ECM receives incorrect voltage from TCM (Transmission control module) continuously.	● Harness or connectors [The circuit between ECM and TCM (Transmission control module) is open or shorted.]

*: This DTC can be detected only by "DATA MONITOR (AUTO TRIG)" with CONSULT.



DTC Confirmation Procedure

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine, and rev engine more than 1,000 rpm once, then let it idle for more than 40 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-328.

DTC P0600 A/T CONTROL

Overall Function Check



Overall Function Check

Use this procedure to check the overall function of the A/T control circuit. During this check, a DTC might not be confirmed. NCEC0498

⊗ Without CONSULT

- 1) Start engine.
- 2) Check voltage between
ECM terminal 24 and ground.
ECM terminal 29 and ground.

Voltage: 6 - 8V

- 3) If NG, go to "Diagnostic Procedure", EC-328.


DTC P0600 A/T CONTROL

Wiring Diagram

Wiring Diagram

NCEC0499

EC-AT/C-01 GI



MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX





TEC672

DTC P0600 A/T CONTROL


Diagnostic Procedure


Diagnostic Procedure

NCEC0500

1	CHECK INPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and TCM (Transmission control module) harness connector.</p>	
 <p style="text-align: right;">SEF313W</p>	
<p>3. Check harness continuity between ECM terminal 24 and terminal 5, ECM terminal 29 and terminal 6, ECM terminal 30 and terminal 7.</p>	
 <p style="text-align: right;">SEF253W</p>	
<p style="text-align: center;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Repair harness or connectors.

3	CHECK INTERMITTENT INCIDENT
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	

2	CHECK INPUT SIGNAL CIRCUIT
<p>1. Check harness continuity between ECM terminal 24 and ground, ECM terminal 29 and ground, ECM terminal 30 and ground.</p>	
 <p style="text-align: right;">SEF254W</p>	
<p style="text-align: center;">Continuity should not exist.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Repair short to ground or short to power in harness.




Component Description

The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The ECM controls the engine.

On Board Diagnosis Logic

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0605 0301	<ul style="list-style-type: none"> ECM calculation function is malfunctioning. 	<ul style="list-style-type: none"> ECM



DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine.
- 4) Run engine for at least 30 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-330.

Ⓠ With GST

- 1) Turn ignition switch "ON".
- 2) Start engine.
- 3) Run engine for at least 30 seconds at idle speed.
- 4) Select "Mode 7" with GST.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-330.

Ⓡ No Tools

- 1) Turn ignition switch "ON".
- 2) Start engine and wait at least 30 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-330.




GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0605 ECM

Diagnostic Procedure

Diagnostic Procedure

NCEC0298

1	INSPECTION START
<p> With CONSULT</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select "SELF DIAG RESULTS" mode with CONSULT. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See previous page. 5. Is the 1st trip DTC P0605 displayed again? 	
<p> With GST</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select MODE 4 with GST. 3. Touch "ERASE". 4. Perform "DTC Confirmation Procedure". See previous page. 5. Is the 1st trip DTC P0605 displayed again? 	
<p> No Tools</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to EC-55. 3. Perform "DTC Confirmation Procedure". See previous page. 4. Is the 1st trip DTC 0301 displayed again? <p style="text-align: center;">Yes or No</p>	
Yes	▶ Replace ECM.
No	▶ INSPECTION END

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Description

Description SYSTEM DESCRIPTION


NCEC0299

NCEC0299S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	On board diagnosis of EVAP system	MAP/BARO switch solenoid valve
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		

This system allows the absolute pressure sensor to monitor either ambient barometric pressure or intake manifold pressure. The MAP/BARO switch solenoid valve switches between two passages by ON-OFF pulse signals from the ECM. (One passage is from the intake air duct, the other is from the intake manifold.) Either ambient barometric pressure or intake manifold pressure is applied to the absolute pressure sensor.

Solenoid	Conditions
ON	<ul style="list-style-type: none"> • For 5 seconds after turning ignition switch "ON" (Engine is not running) <li style="text-align: center;">or • For 5 seconds after starting engine <li style="text-align: center;">or • More than 5 minutes after the solenoid valve shuts OFF.



COMPONENT DESCRIPTION

NCEC0299S02

The MAP/BARO switch solenoid valve switches its air flow passage according to the voltage signal sent from the ECM. When voltage is supplied from the ECM, the MAP/BARO switch solenoid turns "ON". Then, the absolute pressure sensor can monitor the ambient barometric pressure. When voltage is not supplied from the ECM, the MAP/BARO switch solenoid valve turns "OFF". Then, the sensor monitors intake manifold pressure.

CONSULT Reference Value in Data Monitor Mode

NCEC0300

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAP/BARO SW/V	<ul style="list-style-type: none"> • For 5 seconds after starting engine 	BARO
	<ul style="list-style-type: none"> • More than 5 seconds after turning ignition switch "ON" • More than 5 seconds after starting engine 	MAP

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NCEC0301


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
69	GY/R	MAP/BARO switch sole- noid valve	[Ignition switch "ON"] ● For 5 seconds after turning ignition switch "ON" [Engine is running] ● For 5 seconds after starting engine	0 - 1V
			[Ignition switch "ON"] ● More than 5 seconds after turning ignition switch "ON" [Engine is running] ● More than 5 seconds after starting engine	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0302

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1105 1302	A) MAP/BARO switch solenoid valve receives the voltage supplied though ECM does not supply the voltage to the valve.	<ul style="list-style-type: none"> ● Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) ● MAP/BARO switch solenoid valve
	B) There is little difference between MAP/BARO switch solenoid valve input voltage at ambient barometric pressure and voltage at intake manifold pressure.	<ul style="list-style-type: none"> ● Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) ● Hoses (Hoses are clogged, vent, kinked, disconnected or improper connection.) ● Absolute pressure sensor ● MAP/BARO switch solenoid valve



DTC Confirmation Procedure

NCEC0303

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NCEC0303S01

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

④ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Wait at least 10 seconds.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

With GST

- 1) Turn ignition switch "ON" and wait at least 10 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.

No Tools

- 1) Turn ignition switch "ON" and wait at least 10 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.

5	☆ MONITOR ☆ NO FAIL <input type="checkbox"/>
CMPS•RPM(REF)	812rpm
COOLAN TEMP/S	85°C
TANK F/TMP SE	29°C
RECORD	

SEF195VA

PROCEDURE FOR MALFUNCTION B

TESTING CONDITION:

Always perform at a temperature above 5°C (41°F).

With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
- 4) Make sure that "TANK/F/TEMP SE" is more than 0°C (32°F).
- 5) Start engine and let it idle for at least 10 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.

With GST

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Check that voltage between ECM terminal 63 and ground is less than 4.2V.
- 5) Start engine and let it idle for at least 10 seconds.
- 6) Select "MODE 7" with GST.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.

No Tools

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Check that voltage between ECM terminal 63 and ground is less than 4.2V.
- 5) Start engine and let it idle for at least 10 seconds.
- 6) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".

GI

MA

EM

LC

EC

FE

CL

MT

NCEC0303S02

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

- 7) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-336.


DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Wiring Diagram

Wiring Diagram

NCEC0304

EC-SW/V-01 GI



Refer to EL-POWER.

— : Detectable line for DTC
 — : Non-detectable line for DTC

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC


EL

IDX



Refer to last page (Foldout page).

M2



F26
W



TEC544

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Diagnostic Procedure



Diagnostic Procedure

If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION A", perform "PROCEDURE A" below. If the trouble is duplicated after "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE B" on next page.


NCEC0305

PROCEDURE A

NCEC0305S01

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect MAP/BARO switch solenoid valve harness connector.</p>	
 <p>Throttle body MAP/BARO switch solenoid valve harness connector</p> <p style="text-align: right;">SEF314W</p>	
<p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and engine ground with CONSULT or tester.</p>	
 <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEF255W</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness connectors F6, E123 • 10A fuse • Harness for open or short between MAP/BARO switch solenoid valve and fuse 	
▶ Repair harness or connectors.	

3	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 69 and terminal 2.</p>	
 <p style="text-align: right;">SEF256W</p>	
Continuity should exist.	
4. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E123, F6 • Harness for open or short between MAP/BARO switch solenoid valve and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK MAP/BARO SWITCH SOLENOID VALVE
Refer to "Component Inspection", EC-340.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace MAP/BARO switch solenoid valve.



6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Diagnostic Procedure (Cont'd)

PROCEDURE B

-NCEC0305S02

1	INSPECTION START
<ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Turn ignition switch "OFF". Connect MAP/BARO switch solenoid valve and absolute pressure sensor with a rubber tube that has vacuum gauge. 	
 <p>Throttle body MAP/BARO switch solenoid valve harness connector</p> <p>SEF314W</p>	
 <p>From air duct Absolute pressure sensor Vacuum gauge Three-way connector Intake manifold vacuum</p> <p>SEF676T</p>	
Models with CONSULT	▶ GO TO 2.
Models without CONSULT	▶ GO TO 3.


2	CHECK VACUUM SOURCE TO MAP/BARO SWITCH SOLENOID VALVE AND CIRCUIT														
<p>ⓐ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Select "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT. Start engine and let it idle. Touch "MAP" and "BARO" alternately and check for vacuum. 															
<table border="1" style="width: 100%;"> <tr> <td colspan="2" style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></td> </tr> <tr> <td>MAP/BARO SW/V</td> <td>MAP</td> </tr> <tr> <td colspan="2" style="text-align: center;">----- MONITOR -----</td> </tr> <tr> <td>CMPS•RPM(REF)</td> <td>700rpm</td> </tr> <tr> <td>MAP/BARO SW/V</td> <td>MAP</td> </tr> <tr> <td>ABSOL PRES/SE</td> <td>1.3V</td> </tr> <tr> <td style="text-align: center;">BARO</td> <td style="text-align: center;">MAP</td> </tr> </table> <p>SEF500R</p>		■ ACTIVE TEST ■ <input type="checkbox"/>		MAP/BARO SW/V	MAP	----- MONITOR -----		CMPS•RPM(REF)	700rpm	MAP/BARO SW/V	MAP	ABSOL PRES/SE	1.3V	BARO	MAP
■ ACTIVE TEST ■ <input type="checkbox"/>															
MAP/BARO SW/V	MAP														
----- MONITOR -----															
CMPS•RPM(REF)	700rpm														
MAP/BARO SW/V	MAP														
ABSOL PRES/SE	1.3V														
BARO	MAP														
<table border="1" style="width: 100%;"> <tr> <td colspan="2" style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></td> </tr> <tr> <td>MAP/BARO SW/V</td> <td>BARO</td> </tr> <tr> <td colspan="2" style="text-align: center;">----- MONITOR -----</td> </tr> <tr> <td>CMPS•RPM(REF)</td> <td>700rpm</td> </tr> <tr> <td>MAP/BARO SW/V</td> <td>BARO</td> </tr> <tr> <td>ABSOL PRES/SE</td> <td>4.3V</td> </tr> <tr> <td style="text-align: center;">BARO</td> <td style="text-align: center;">MAP</td> </tr> </table> <p>SEF498R</p>		■ ACTIVE TEST ■ <input type="checkbox"/>		MAP/BARO SW/V	BARO	----- MONITOR -----		CMPS•RPM(REF)	700rpm	MAP/BARO SW/V	BARO	ABSOL PRES/SE	4.3V	BARO	MAP
■ ACTIVE TEST ■ <input type="checkbox"/>															
MAP/BARO SW/V	BARO														
----- MONITOR -----															
CMPS•RPM(REF)	700rpm														
MAP/BARO SW/V	BARO														
ABSOL PRES/SE	4.3V														
BARO	MAP														
<table border="1" style="width: 100%;"> <tr> <td>MAP/BARO SW/V</td> <td>Vacuum</td> </tr> <tr> <td>BARO</td> <td>Should not exist</td> </tr> <tr> <td>MAP</td> <td>Should exist</td> </tr> </table> <p>MTBL0079</p>		MAP/BARO SW/V	Vacuum	BARO	Should not exist	MAP	Should exist								
MAP/BARO SW/V	Vacuum														
BARO	Should not exist														
MAP	Should exist														
OK or NG															
OK	▶ GO TO 12.														
NG	▶ GO TO 4.														


3	CHECK VACUUM SOURCE TO ABSOLUTE PRESSURE SENSOR						
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> Start engine and let it idle. Check for vacuum under the following condition. 							
<table border="1" style="width: 100%;"> <thead> <tr> <th>Condition</th> <th>Vacuum</th> </tr> </thead> <tbody> <tr> <td>For 5 seconds after starting engine</td> <td>Should not exist</td> </tr> <tr> <td>More than 5 seconds after starting engine</td> <td>Should exist</td> </tr> </tbody> </table> <p>MTBL0080</p>		Condition	Vacuum	For 5 seconds after starting engine	Should not exist	More than 5 seconds after starting engine	Should exist
Condition	Vacuum						
For 5 seconds after starting engine	Should not exist						
More than 5 seconds after starting engine	Should exist						
OK or NG							
OK	▶ GO TO 12.						
NG	▶ GO TO 4.						


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX
523

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE


Diagnostic Procedure (Cont'd)

4	CHECK VACUUM HOSE
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Check hose for clogging, cracks, disconnection or improper connection. 	
	
SEF109L	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Clean, repair or reconnect the hose.

5	CHECK VACUUM PORT
Check vacuum port for clogging.	
	
SEF368U	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Clean or repair the vacuum port.

6	CHECK POWER SUPPLY
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect MAP/BARO switch solenoid valve harness connector. 3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester. 	
	
SEF255W	
Voltage: Battery voltage	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> • Harness connectors M62, F24 • Harness connectors F6, E123 • 10A fuse • Harness for open or short between MAP/BARO switch solenoid valve and fuse 	
▶ Repair harness or connectors.	

8	CHECK OUTPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 69 and terminal 2. 	
	
SEF256W	
Continuity should exist.	
4. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ GO TO 9.


DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Diagnostic Procedure (Cont'd)

9	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F6, E123 ● Harness for open or short between MAP/BARO switch solenoid valve and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

10	CHECK MAP/BARO SWITCH SOLENOID VALVE
Refer to "Component Inspection", EC-340.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace MAP/BARO switch solenoid valve.

11	CHECK INTAKE SYSTEM
Check intake system for air leaks.	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Repair it.

12	CHECK HOSE BETWEEN ABSOLUTE PRESSURE SENSOR AND MAP/BARO SWITCH SOLENOID VALVE
Check hose for clogging, cracks, disconnection or improper connection.	
	
SEF109L	
OK or NG	
OK	▶ GO TO 13.
NG	▶ Repair or reconnect hose.

13	CHECK HARNESS CONNECTOR
1. Disconnect absolute pressure sensor harness connector. 2. Check sensor harness connector for water. Water should not exist.	
OK or NG	
OK	▶ GO TO 14.
NG	▶ Repair or replace harness connector.




14	CHECK ABSOLUTE PRESSURE SENSOR
Refer to "Component Inspection", EC-133.	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Replace absolute pressure sensor.

15	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1105 MANIFOLD ABSOLUTE PRESSURE (MAP)/BAROMETRIC PRESSURE (BARO) SWITCH SOLENOID VALVE

Component Inspection



Component Inspection

MAP/BARO SWITCH SOLENOID VALVE

NCEC0306

NCEC0306S01

Ⓜ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
- 3) Check the following.
 - Condition: At idle under no-load
 - CONSULT display

MAP/BARO	ABSOL PRES/SE (Voltage)
BARO	More than 2.6V
MAP	Less than the voltage at BARO

- Time for voltage to change

MAP/BARO SW/V	Required time to switch
BARO to MAP	Less than 1 second
MAP to BARO	

- 4) If NG, check solenoid valve as shown below.

ⓧ Without CONSULT

- 1) Turn ignition switch "OFF" and remove MAP/BARO switch solenoid valve.
- 2) Check air passage continuity.

Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

- 3) Check the time required for the solenoid valve to switch. It should be less than 1 second.
- 4) If NG, replace solenoid valve.

DTC P1148 CLOSED LOOP CONTROL


On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0307

★ The closed loop control has the one trip detection logic.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1148 0307	<ul style="list-style-type: none"> The closed loop control function does not operate even when vehicle is driving in the specified condition. 	<ul style="list-style-type: none"> The front heated oxygen sensor circuit is open or shorted. Front heated oxygen sensor Front heated oxygen sensor heater



DTC Confirmation Procedure

NCEC0308

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 3,200 rpm during the "DTC Confirmation Procedure". If the engine speed limit is exceeded, retry the procedure from step 4.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT

- Start engine and warm it up to normal operating temperature.
- Select "DATA MONITOR" mode with CONSULT.
- Hold engine speed at 2,000 rpm and check the following.
 - "FR O2 SENSOR" voltage should go above 0.70V at least once.
 - "FR O2 SENSOR" voltage should go below 0.23V at least once.

If the result is NG, perform "Diagnosis Procedure", EC-342.
If the result is OK, perform the following step.
- Let engine idle at least 4 minutes.
- Maintain the following condition at least 50 consecutive seconds.


B/FUEL SCHDL	1.0 msec or more (A/T) 0.9 msec or more (M/T)
CMPS-RPM (REF)	1,800 - 3,200 rpm (A/T) 1,900 - 3,200 rpm (M/T)
Selector lever	Suitable position
VHCL SPEED SE	More than 70 km/h (44 MPH)

During this test, P0130 DTC may be displayed on CONSULT screen.

- If DTC is detected, go to "Diagnostic Procedure", EC-342.

DTC P1148 CLOSED LOOP CONTROL

Overall Function Check



Overall Function Check

NCEC0309

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 46 (Front heated oxygen sensor signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.23V at least once.
- 4) If NG, go to "Diagnostic Procedure", EC-342.


Diagnostic Procedure

NCEC0310

Refer to "Diagnostic Procedure" for DTC P0133, EC-181.

DTC P1320 IGNITION SIGNAL

Component Description



Component Description

IGNITION COIL & POWER TRANSISTOR (BUILT INTO DISTRIBUTOR)

NCEC0319

NCEC0319S01

The ignition coil is built into distributor. The ignition signal from the ECM is sent to the power transistor. The power transistor switches on and off the ignition coil primary circuit. As the primary circuit is turned on and off, the proper high voltage is induced in the coil secondary circuit.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

CONSULT Reference Value in Data Monitor Mode

NCEC0320

MONITOR ITEM	CONDITION	SPECIFICATION
IGN TIMING	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: OFF Shift lever: "N" No-load 	Idle
		2,000 rpm
		13 - 15° BTDC
		More than 25° BTDC

ECM Terminals and Reference Value



NCEC0321

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	W/B	Ignition signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> Warm-up condition Idle speed 	<p>0.2 - 0.6V</p> <p>SEF996V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> Engine speed is 2,000 rpm 	<p>Approximately 0.5V</p> <p>SEF997V</p>

DTC P1320 IGNITION SIGNAL

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	W	Ignition check	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 13V</p>  <p style="text-align: right;">SEF998V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 13V</p>  <p style="text-align: right;">SEF999V</p>

On Board Diagnosis Logic

NCEC0322


DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1320 0201	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not sent to ECM during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness or connectors (The ignition primary circuit is open or shorted.) ● Power transistor unit. ● Resistor ● Camshaft position sensor ● Camshaft position sensor circuit

DTC Confirmation Procedure

NCEC0323

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.
- If DTC P1320 (0201) is displayed with P0340 (0101), perform trouble diagnosis for DTC P0340 first. Refer to EC-260.



ⓑ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 4 seconds. (If engine does not run, turn ignition switch to "START" at least 5 seconds.)
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-347.

Ⓒ With GST

- 1) Turn ignition switch "ON".
- 2) Start engine and wait at least 4 seconds. (If engine does not run, turn ignition switch to "START" at least 5 seconds.)

DTC P1320 IGNITION SIGNAL

DTC Confirmation Procedure (Cont'd)

- 3) Select MODE 3 with GST.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-347.

 **No Tools**

- 1) Turn ignition switch "ON".
- 2) Start engine and wait at least 4 seconds. (If engine does not run, turn ignition switch to "START" at least 5 seconds.)
- 3) Turn ignition switch "OFF" and wait at least 5 seconds, and then turn "ON".
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-347.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P1320 IGNITION SIGNAL

Wiring Diagram


Wiring Diagram

NCEC0324


EC-IGN/SG-01



— : Detectable line for DTC
 — : Non-detectable line for DTC





Refer to last page (Foldout page).
 (M6), (E75)




TEC645


Diagnostic Procedure

1	CHECK ENGINE START	
Turn ignition switch "OFF", and restart engine. is engine running?		
Yes or No		
Yes	▶	GO TO 7.
No	▶	GO TO 2.

2	CHECK POWER SUPPLY	
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ignition coil harness connector. 		
 <p style="text-align: right;">SEF010P</p>		
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 8 and ground with CONSULT or tester. 		
 <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: right;">SEF257W</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

3	DETECT MALFUNCTIONING PART	
Check the following.		
<ul style="list-style-type: none"> Harness connectors E75, M6 Harness connectors M49, F23 Harness for open or short between ignition coil and ignition switch 		
▶		Repair harness or connectors.

4	CHECK GROUND CIRCUIT	
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect power transistor harness connector. Check harness continuity between terminal 5 and engine ground. 		
 <p style="text-align: right;">SEF258W</p>		
Continuity should exist.		
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.



5	CHECK INPUT SIGNAL CIRCUIT	
<ol style="list-style-type: none"> Disconnect ECM harness connector. Check harness continuity between ECM terminal 1 and power transistor terminal 6. 		
 <p style="text-align: right;">SEF259W</p>		
Continuity should exist.		
<ol style="list-style-type: none"> Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK IGNITION COIL, POWER TRANSISTOR	
Refer to "Component Inspection", EC-348.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Replace malfunctioning component(s).

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P1320 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

7	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Stop engine. 2. Disconnect ignition coil harness connector. 3. Strip tape covering resistor. 4. Disconnect resistor harness connector. 	
 <p style="text-align: right;">SEF315W</p>	
<ol style="list-style-type: none"> 5. Disconnect ECM harness connector. 6. Check harness continuity between ignition coil terminal 7 and resistor terminal 1, resistor terminal 2 and ECM terminal 2. 	
 <p style="text-align: right;">SEF260W</p>	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 7. Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK RESISTOR
Refer to "Component Inspection" EC-349.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace resistor.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	




Component Inspection IGNITION COIL

1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.

NCEC0326
NCEC0326S01

DTC P1320 IGNITION SIGNAL


Component Inspection (Cont'd)



- For checking secondary coil, remove distributor cap.
- Check resistance between ignition coil harness connector terminal 8 and coil tower metal tip 9 (secondary terminal) on the distributor head.

Terminal	Resistance [at 25°C (77°F)]
7 - 8 (Primary coil)	Approximately 0.5 - 1.0Ω
8 - secondary terminal on distributor head (Secondary coil)	Approximately 25 kΩ

If NG, replace distributor.




POWER TRANSISTOR

NCEC0326502

- Disconnect power transistor harness connector.
- Check power transistor resistance between terminals 5 and 7.

Terminals	Resistance	Result
5 and 7	Except 0Ω	OK
	0Ω	NG

If NG, replace distributor.



RESISTOR

NCEC0326503

- Disconnect resistor harness connector.
- Check resistance between terminals 1 and 2.

Resistance: Approximately 2.2 kΩ [at 25°C (77°F)]

If NG, replace resistor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

Component Description



Component Description

NCEC0327

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.

ECM Terminals and Reference Value

NCEC0328

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
50	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
53	W	Crankshaft position sensor (OBD)	[Engine is running] ● Warm-up condition ● Idle speed	3 - 5V (AC range) SEF721W
			[Engine is running] ● Engine speed is 2,000 rpm	6 - 9V (AC range) SEF722W


On Board Diagnosis Logic

NCEC0329

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1336 0905	● A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM.	● Harness or connectors ● Crankshaft position sensor (OBD) ● Drive plate/Flywheel

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0390

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

ⓑ With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 4 minutes at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-353.

ⓐ With GST

- 1) Start engine and run it for at least 4 minutes at idle speed.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-353.

ⓐ No Tools

- 1) Start engine and run it for at least 4 minutes at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-353.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

Wiring Diagram

Wiring Diagram

NCEC0301

EC-CKPS-01



TEC535



DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

Diagnostic Procedure


NCEC0932

Diagnostic Procedure


1	RETIGHTEN GROUND SCREWS
<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws. 	
▶	GO TO 2.

2	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Disconnect crankshaft position sensor (OBD) and ECM harness connectors. 	
 <p style="text-align: right;">SEF957N</p>	
<ol style="list-style-type: none"> Check continuity between ECM terminal 53 and terminal 2. 	
 <p style="text-align: right;">SEF228W</p>	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F5, E122 Harness for open or short between crankshaft position sensor (OBD) and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Reconnect ECM harness connectors. Check harness continuity between terminal 1 and engine ground. 	
 <p style="text-align: right;">SEF229W</p>	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F5, E122 Harness for open or short between crankshaft position sensor (OBD) and ECM Harness for open or short between crankshaft position sensor (OBD) and TCM (Transmission control module) 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK SHIELD CIRCUIT
<ol style="list-style-type: none"> Disconnect harness connectors F5, E122. Check harness continuity between terminal 3 and engine ground. 	
 <p style="text-align: right;">SEF230W</p>	
<p>Continuity should exist</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. Then reconnect harness connectors. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (OBD) (COG)

Diagnostic Procedure (Cont'd)



7	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F5, E122 ● Joint connector-1 (Refer to "HARNESS LAYOUT" in EL section.) ● Harness for open or short between harness connector F5 and engine ground 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK IMPROPER INSTALLATION
Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD). Then retest.	
Trouble is not fixed. ▶	GO TO 9.

9	CHECK CRANKSHAFT POSITION SENSOR (OBD)
Refer to "Component Inspection", EC-354.	
OK or NG	
OK ▶	GO TO 10.
NG ▶	Replace crankshaft position sensor (OBD).

10	CHECK GEAR TOOTH
Visually check for chipping flywheel or drive plate gear tooth (cog).	
OK or NG	
OK ▶	GO TO 11.
NG ▶	Replace the flywheel or drive plate.

11	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection CRANKSHAFT POSITION SENSOR (OBD)


NCEC0333

NCEC0333S01

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.
5. Check resistance as shown in the figure.
Resistance: 166 - 204 Ω [at 25°C (77°F)]

DTC P1400 EGRC-SOLENOID VALVE

Component Description



Component Description

NCEC0334

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.

CONSULT Reference Value in Data Monitor Mode

NCEC0335

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EGRC SOL/V	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: "OFF" Shift lever: "N" (A/T models) No-load M/T models: Lift up drive wheels and shift to 1st gear position. Idle	OFF
	Rev engine up from 2,000 to 4,000 rpm.	ON

ECM Terminals and Reference Value

NCEC0336


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
103	P	EGRC-solenoid valve	[Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> Warm-up condition M/T models: Lift up drive wheels and shift to 1st gear position. Rev engine up from 2,000 to 4,000 rpm. 	0 - 0.7V

On Board Diagnosis Logic

NCEC0337

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1400 1005	<ul style="list-style-type: none"> The improper voltage signal is sent to ECM through EGRC-solenoid valve. 	<ul style="list-style-type: none"> Harness or connectors (The EGRC-solenoid valve circuit is open or shorted.) EGRC-solenoid valve



DTC Confirmation Procedure

NCEC0338

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT and wait at least 5 seconds.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-358.

DTC P1400 EGRC-SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

With GST

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-358.

No Tools

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-358.

DTC P1400 EGRC-SOLENOID VALVE

Wiring Diagram

Wiring Diagram

NCEC0339

EC-EGRC/V-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA


SC

EL

IDX



Refer to last page (Foldout page).





DTC P1400 EGRC-SOLENOID VALVE


Diagnostic Procedure

NCEC0340

Diagnostic Procedure

1	CHECK POWER SUPPLY						
<p>1. Turn ignition switch "OFF". 2. Disconnect EGRC-solenoid valve harness connector.</p>  <p style="text-align: right;">SEF317W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF261W</p> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>		OK	▶	GO TO 3.	NG	▶	GO TO 2.
OK	▶	GO TO 3.					
NG	▶	GO TO 2.					

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M62, F24 ● Harness connectors F6, E123 ● 10A fuse ● Harness for open or short between EGRC-solenoid valve and fuse <p style="text-align: right;">▶ Repair harness or connectors.</p>	

3	CHECK OUTPUT SIGNAL CIRCUIT						
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 103 and terminal 2.</p>  <p style="text-align: right;">SEF262W</p> <p style="text-align: center;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	GO TO 4.
OK	▶	GO TO 5.					
NG	▶	GO TO 4.					

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F6, E123 ● Harness for open or short between EGRC-solenoid valve and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

5	CHECK EGRC-SOLENOID VALVE						
<p>Refer to "Component Inspection", EC-359.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="width: 75%;">GO TO 6.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EGRC-solenoid valve.</td> </tr> </table>		OK	▶	GO TO 6.	NG	▶	Replace EGRC-solenoid valve.
OK	▶	GO TO 6.					
NG	▶	Replace EGRC-solenoid valve.					

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <p style="text-align: right;">▶ INSPECTION END</p>	

DTC P1400 EGRC-SOLENOID VALVE

Component Inspection

NCEC0341

NCEC0341S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Component Inspection

EGRC-SOLENOID VALVE

Check air passage continuity.

Ⓜ With CONSULT


Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.

Condition	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes


ⓧ Without CONSULT

Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

If NG or operation takes more than 1 second, replace solenoid valve.




SEF193W



AEC919

DTC P1401 EGR TEMPERATURE SENSOR

Component Description



Component Description

NCEC0342

The EGR temperature sensor detects temperature changes in the EGR passageway. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passageway changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. This sensor is not used to control the engine system.

It is used only for the on board diagnosis.


<Reference data>

EGR temperature °C (°F)	Voltage* V	Resistance MΩ
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

*: These data are reference values and are measured between ECM terminal 62 (EGR temperature sensor) and ECM terminal 43 (ECM ground).

When EGR system is operating.

Voltage: 0 - 1.5V




On Board Diagnosis Logic

NCEC0343

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
P1401 0305	A)	An excessively low voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is low.	<ul style="list-style-type: none"> • Harness or connectors (The EGR temperature sensor circuit is shorted.) • EGR temperature sensor • Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve
	B)	An excessively high voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is high.	<ul style="list-style-type: none"> • Harness or connectors (The EGR temperature sensor circuit is open.) • EGR temperature sensor • Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

DTC P1401 EGR TEMPERATURE SENSOR

DTC Confirmation Procedure



DTC Confirmation Procedure

NCEC0344

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NCEC0344S01

① With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Verify that engine coolant temperature is less than 40°C (104°F).
If the engine coolant temperature is above the range, cool the engine down.
- 4) Start engine and let it idle for at least 8 seconds.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-364.

② With GST

- 1) Turn ignition switch "ON".
- 2) Select "MODE 1" with GST.
- 3) Verify that engine coolant temperature is less than 40°C (104°F).
If the engine coolant temperature is above the range, cool the engine down.
- 4) Start engine and let it idle for at least 8 seconds.
- 5) Select "MODE 7" with GST.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-364.

③ No Tools

- 1) Turn ignition switch "ON".
- 2) Verify that voltage between ECM terminal 51 (Engine coolant temperature sensor signal) is more than 2.7V.
If the voltage is below the range, cool the engine down.
- 3) Start engine and let it idle for at least 8 seconds.
- 4) Turn ignition switch "OFF" and wait at least 5 seconds.
- 5) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-364.

PROCEDURE FOR MALFUNCTION B

NCEC0344S02

CAUTION:



Always drive vehicle at a safe speed.

TESTING CONDITION:

Always perform the test at a temperature above 5°C (41°F).

① With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Confirm that EGR valve is not lifting.
If the result is NG, perform trouble diagnosis for DTC P1402. Refer to EC-366.
- 3) Select "DATA MONITOR" mode with CONSULT.





DTC P1401 EGR TEMPERATURE SENSOR

DTC Confirmation Procedure (Cont'd)

- 4) Read "EGR TEMP SEN" at about 1,500 rpm while holding the EGR valve in full open position by hand.
Voltage should decrease to less than 1.0V.
 If the result is NG, go to "Diagnostic Procedure", EC-364.
 If the result is OK, go to following step.
- 5) Turn ignition switch "OFF" and wait at least 5 seconds.
- 6) Turn ignition switch "ON".
- 7) Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
- 8) Start engine.
- 9) Maintain the following conditions for at least 5 consecutive seconds.

CMPS-RPM (REF)	1,800 - 2,800 rpm (A/T) 1,600 - 2,800 rpm (M/T)
COOLAN TEMP/S	Above 80°C (176°F)
VHCL SPEED SE	10 km/h (6 MPH) or more
B/FUEL SCHDL	2.0 - 3.5 msec (A/T) 1.8 - 3.0 msec (M/T)
THRTL POS SEN	(X + 0.05) - (X + 0.87) V X = Voltage value measured at step 7
Selector lever	Suitable position

- 10) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-364.



Overall Function Check

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

PROCEDURE FOR MALFUNCTION B

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Confirm that EGR valve is not lifting. If NG, perform trouble diagnosis for DTC P1402. Refer to EC-367.
- 3) Check voltage between ECM terminal 62 (EGR temperature sensor signal) and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.0V.
- 4) If NG, go to "Diagnostic Procedure", EC-364.
 If OK, perform trouble diagnoses for DTC P0400 and P1400. Refer to EC-267, 355.

DTC P1401 EGR TEMPERATURE SENSOR

Wiring Diagram

Wiring Diagram

NCEC0346

EC-EGR/TS-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX





TEC547


DTC P1401 EGR TEMPERATURE SENSOR

Diagnostic Procedure

Diagnostic Procedure

NCEC0947

1	CHECK POWER SUPPLY						
<p>1. Turn ignition switch "OFF". 2. Disconnect EGR temperature sensor harness connector.</p>  <p style="text-align: right;">SEF301W</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF263W</p> <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 2.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair harness or connectors.</td> </tr> </table>		OK	▶	GO TO 2.	NG	▶	Repair harness or connectors.
OK	▶	GO TO 2.					
NG	▶	Repair harness or connectors.					

2	CHECK GROUND CIRCUIT						
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between terminal 2 and engine ground.</p>  <p style="text-align: right;">SEF264W</p> <p style="text-align: center;">Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 3.</td> </tr> </table>		OK	▶	GO TO 4.	NG	▶	GO TO 3.
OK	▶	GO TO 4.					
NG	▶	GO TO 3.					


3	DETECT MALFUNCTIONING PART			
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness for open or short between EGR temperature sensor and ECM • Harness for open or short between EGR temperature sensor and TCM (Transmission control module) <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 20%;"></td> <td style="width: 10%; text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connector.</td> </tr> </table>			▶	Repair open circuit or short to ground or short to power in harness or connector.
	▶	Repair open circuit or short to ground or short to power in harness or connector.		

4	CHECK EGR TEMPERATURE SENSOR						
<p>Refer to "Component Inspection", EC-365.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 5.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Replace EGR temperature sensor.</td> </tr> </table>		OK	▶	GO TO 5.	NG	▶	Replace EGR temperature sensor.
OK	▶	GO TO 5.					
NG	▶	Replace EGR temperature sensor.					

5	CHECK INTERMITTENT INCIDENT			
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p> <table border="1" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 20%;"></td> <td style="width: 10%; text-align: center;">▶</td> <td>INSPECTION END</td> </tr> </table>			▶	INSPECTION END
	▶	INSPECTION END		

DTC P1401 EGR TEMPERATURE SENSOR

Component Inspection



SEF643Q

Component Inspection EGR TEMPERATURE SENSOR

NCEC0348

NCEC0348S01

Check resistance change and resistance value.
<Reference data>

EGR temperature °C (°F)	Voltage V	Resistance MΩ
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

GI

MA

EM

LC

If NG, replace EGR temperature sensor.

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEF526Q

DTC P1402 EGR FUNCTION (OPEN)

Description

Description SYSTEM DESCRIPTION


NCEC0349

NCEC0349S01


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current through the solenoid valve is cut. This causes the vacuum to be cut. The EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



SEF317U



SEF783K

COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve


NCEC0349S02

NCEC0349S0201

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

DTC P1402 EGR FUNCTION (OPEN)

Description (Cont'd)



EGRC-solenoid Valve

NCEC0349S0202


The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.

GI

MA

EM

LC



On Board Diagnosis Logic

NCEC0350

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

NOTE:

Diagnosis for this DTC will occur when engine coolant temperature is below 50 to 60°C (122 to 140°F). Therefore, it will be better to turn ignition switch "ON" (Start engine) at the engine coolant temperature below 30°C (86°F) when starting DTC confirmation procedure.

EC

FE

CL

MT


DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1402 0514	<ul style="list-style-type: none"> EGR flow is detected under conditions that do not call for EGR. 	<ul style="list-style-type: none"> EGRC-solenoid valve EGR valve leaking or stuck open EGR temperature sensor EGRC-BPT valve

AT

AX

SU

BR



DTC Confirmation Procedure

NCEC0351

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Engine coolant temperature and EGR temperature must be verified in "DATA MONITOR" mode with CONSULT before starting DTC WORK SUPPORT test. If it is out of range below, the test cannot be conducted.

COOLAN TEMP/S: -10 to 30°C (14 to 86°F)*

EGR TEMP SEN: Less than 4.8V

If the values are out of the ranges indicated above, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to reduce the engine coolant or EGR temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

ST

RS

BT

HA

SC





EL

IDX

*: Although CONSULT screen displays "-10 to 40°C (14 to 104°F)" as a range of engine coolant temperature, ignore it.

DTC P1402 EGR FUNCTION (OPEN)

DTC Confirmation Procedure (Cont'd)



With CONSULT

- 1) Turn ignition switch "OFF" and wait at least 5 seconds, then turn ignition switch "ON".
- 2) Select "EGR SYSTEM P1402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 3) Touch "START". Follow instruction of CONSULT.
- 4) Start engine and let it idle until "TESTING" on CONSULT screen is turned to "COMPLETED". (It will take 60 seconds or more.)
If "TESTING" is not displayed after 5 minutes, turn ignition "OFF" and cool the engine coolant temperature to the range of -10 to 30°C (14 to 86°F). Retry from step 1.
- 5) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-370.

With GST

- 1) Turn ignition switch "ON" and select "MODE 1" with GST.
- 2) Check that engine coolant temperature is within the range of -10 to 30°C (14 to 86°F).
- 3) Check that voltage between ECM terminal 62 (EGR temperature sensor signal) and ground is less than 4.8V.
- 4) Start engine and let it idle for at least 60 seconds.
- 5) Stop engine.
- 6) Perform from step 1 to 4.
- 7) Select "MODE 3" with GST.
- 8) If DTC is detected, go to "Diagnostic Procedure", EC-370.

No Tools

- 1) Turn ignition switch "ON".
- 2) Check the following voltages.

ECM terminal 51 (Engine coolant temperature sensor signal) and ground: 3.2 - 4.4V

ECM terminal 62 (EGR temperature sensor signal) and ground: Less than 4.8V

- 3) Start engine and let it idle for at least 60 seconds.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-370.

When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT or ECM (Diagnostic Test Mode II) is recommended.





DTC P1402 EGR FUNCTION (OPEN)

Wiring Diagram

Wiring Diagram

NCEC0352

EC-EGRC1-01 GI



Refer to last page (Foldout page).

M2

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEC537

DTC P1402 EGR FUNCTION (OPEN)

Diagnostic Procedure

Diagnostic Procedure

NCEC0353

1	CHECK VACUUM HOSE
<p>Check vacuum hose for clogging, cracks or improper connection. Refer to "Vacuum Hose Drawing", EC-21.</p>	
SEF109L	
OK or NG	
OK (With CONSULT) ▶	GO TO 2.
OK (Without CONSULT) ▶	GO TO 3.
NG ▶	Repair or replace vacuum hose.

2	CHECK EGRC-SOLENOID VALVE CIRCUIT
<p>With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT. 	
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: auto;"> <p style="text-align: center;">■ EGRC SOL/V CIRCUIT ■</p> <p style="text-align: center;">DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?</p> <p style="text-align: center;"> <input type="button" value="NEXT"/> <input type="button" value="NO"/> <input type="button" value="YES"/> </p> </div>	
MEF957D	
<p>With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound. 	
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: auto;"> <p style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>EGRC SOL/V (EGR) ON FLOW</p> <p style="text-align: center;">----- MONITOR -----</p> <p>CMPS•RPM (REF) 732rpm</p> <p style="text-align: center;"> <input type="button" value="ON"/> <input type="button" value="ON/OFF"/> <input type="button" value="OFF"/> </p> </div>	
SEF319U	
Clicking noise should be heard.	
OK or NG	
OK ▶	GO TO 4.
NG ▶	Repair or replace EGRC-solenoid valve or repair circuit.

DTC P1402 EGR FUNCTION (OPEN)

Diagnostic Procedure (Cont'd)

3	CHECK EGRC-SOLENOID VALVE CIRCUIT						
<p>⊗ Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Turn ignition switch "ON". Connect a suitable jumper wire between ECM terminal 103 and engine ground. 							
<p>5. Check operating sound of the solenoid valve when disconnecting the jumper wire. Clicking noise should be heard.</p> <p style="text-align: center;">OK or NG</p> <table border="1"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Repair or replace EGRC-solenoid valve or repair circuit.</td> </tr> </table>		OK	▶	GO TO 4.	NG	▶	Repair or replace EGRC-solenoid valve or repair circuit.
OK	▶	GO TO 4.					
NG	▶	Repair or replace EGRC-solenoid valve or repair circuit.					


4	CHECK EGRC-SOLENOID VALVE	
Refer to "Component Inspection", EC-359.		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Replace EGRC-solenoid valve.

5	CHECK EGR VALVE	
Refer to "Component Inspection", EC-371.		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Replace EGR valve.

6	CHECK EGRC-BPT VALVE	
Refer to "Component Inspection", EC-371.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Replace EGRC-BPT valve.

7	CHECK EGR TEMPERATURE SENSOR	
Refer to "Component Inspection" on EC-365.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace EGR temperature sensor.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	



Component Inspection EGR VALVE


NCEC0354

- Apply vacuum to EGR vacuum port with a hand vacuum pump.
EGR valve spring should lift.

NCEC0364S01

- Check for sticking.

If NG, repair or replace EGR valve.



EGRC-BPT VALVE

NCEC0354S04

- Plug one of two ports of EGRC-BPT valve.
- Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.
- If a leakage is noted, replace the valve.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

On Board Diagnosis Logic


On Board Diagnosis Logic

NCEC0355

NOTE:

If DTC P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. Refer to EC-397.

This diagnosis detects leaks in the EVAP purge line using vapor pressure in the fuel tank. The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank. If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge control valve.



DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1440 0213	<ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge control valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge control valve ● EVAP canister purge volume control valve ● EVAP canister purge control solenoid valve ● Absolute pressure sensor ● Tank fuel temperature sensor ● MAP/BARO switch solenoid valve ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water.





CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

DTC Confirmation Procedure

NCEC0356



DTC Confirmation Procedure

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.
- If DTC P1440 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. Refer to EC-397.

Ⓜ With CONSULT

CAUTION:

- Never use compressed air or high pressure pump. Otherwise, EVAP system may be damaged.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.
- Do not start engine.

NOTE:

- Always remove EVAP service port adapter from EVAP service port after applying air up to 0.69 to 1.38 kPa (5.14 to 10.34 mmHg, 0.202 to 0.407 inHg).

- During the test, clamp the EVAP hose tightly as shown at left.

- 1) Turn ignition switch "OFF".
- 2) Clamp the EVAP hose as shown at left.
- 3) Install EVAP service port adapter and pressure pump to EVAP service port securely.
- 4) Turn ignition switch "ON".
- 5) Select "EVAP SML LEAK P1440" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT. Follow the instruction displayed.
- 6) Make sure that "OK" is displayed. If "NG" is displayed, refer to "Diagnostic Procedure", EC-374.

Ⓜ With GST

NOTE:

Be sure to read the explanation of "Driving pattern" on EC-48 before driving vehicle.

- 1) Start engine.
- 2) Drive vehicle according to "Driving pattern", EC-48.
- 3) Stop vehicle.
- 4) Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- 5) Turn ignition switch "OFF" and wait at least 5 seconds.
- 6) Start engine.

It is not necessary to cool engine down before driving.

- 7) Drive vehicle again according to the "Driving pattern", EC-48.
- 8) Stop vehicle.
- 9) Select "MODE 3" with GST.
 - If P1447 is displayed on the screen, go to "Diagnostic Procedure", EC-393.
 - If P0440 is displayed on the screen, go to "Diagnostic Procedure", EC-286.
 - If P1440 is displayed on the screen, go to trouble diagnosis for DTC P1440, EC-374.
 - If P0440, P1440 and P1447 are not displayed on the screen, go to the following step.
- 10) Select "MODE 1" with GST.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

DTC Confirmation Procedure (Cont'd)

- If SRT of EVAP system is set, the result will be OK.
- If SRT of EVAP system is not set, go to step 5.


 **No Tools**

NOTE:

- Be sure to read the explanation of "Driving pattern" on EC-48 before driving vehicle.
 - It is better that the fuel level is low.
- 1) Start engine.
 - 2) Drive vehicle according to "Driving pattern", EC-48.
 - 3) Stop vehicle.
 - 4) Turn ignition switch "OFF" and wait at least 5 seconds.
 - 5) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
 - 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-374.

Diagnostic Procedure

NCEC0367

1	CHECK FUEL FILLER CAP DESIGN
1. Turn ignition switch "OFF".	
	
SEF915U	
2. Check for genuine NISSAN fuel filler cap design.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Replace with genuine NISSAN fuel filler cap.

2	CHECK FUEL FILLER CAP INSTALLATION
Check that the cap is tightened properly rotating the cap clockwise.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ <ul style="list-style-type: none"> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower. ● Retighten until ratcheting sound is heard.

3	CHECK FUEL FILLER CAP FUNCTION
Check for air releasing sound while opening the fuel filler cap.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.


4	CHECK FUEL TANK VACUUM RELIEF VALVE
Refer to "Evaporative Emission System", EC-27.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace fuel filler cap with a genuine one.

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)


Diagnostic Procedure (Cont'd)

5 INSTALL PRESSURE PUMP

1. Install the EVAP service port adapter and the pressure pump securely to EVAP service port.



SEF303W



SEF462UE

NOTE:

- Improper installation of service port may cause leaking.

Models with CONSULT	▶	GO TO 6.
Models without CONSULT	▶	GO TO 7.

6 CHECK FOR EVAP LEAK

With CONSULT

- Turn ignition switch "ON".
- Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT.

EVAP SYSTEM CLOSE

APPLY PRESSURE TO EVAP SYSTEM FROM SERVICE PORT USING HAND PUMP WITH PRESSURE GAUGE AT NEXT SCREEN. NEVER USE COMPRESSED AIR OR HIGH PRESSURE PUMP! DO NOT START ENGINE. TOUCH START.

CANCEL **START**

SEF658U


- Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of bar graph.

NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.

EVAP SYSTEM CLOSE

APPLY PRESSURE TO SERVICE PORT TO RANGE BELOW. DO NOT EXCEED 0.6psi.




0.2 0.4

END

SEF917U

- Using EVAP leak detector, locate the leak portion. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31.

Leak detector



SEF200U

OK or NG

OK	▶	GO TO 8.
NG	▶	Repair or replace.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA




SC


EL


IDX

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

Diagnostic Procedure (Cont'd)

7	CHECK FOR EVAP LEAK
<p>⊗ Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.) 	
<p style="text-align: center;">Under the vehicle view</p> 	
<ol style="list-style-type: none"> Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12 volts until the end of test.) 	
<p style="text-align: center;">Under the vehicle view</p> 	
<ol style="list-style-type: none"> Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg). NOTE: <ul style="list-style-type: none"> Never use compressed air or a high pressure pump. Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system. Using EVAP leak detector, locate the leak. For the leak detector, refer to instruction manual for more details. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31. 	
<p style="text-align: center;">Leak detector</p> 	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair or replace.

8	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
Refer to "Component Inspection", EC-295.	
	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EVAP canister purge volume control valve.

9	CHECK EVAP CANISTER PURGE CONTROL VALVE
Refer to "Component Inspection", EC-427.	
	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP canister purge control valve.

10	CHECK WATER SEPARATOR
Refer to "Component Inspection", EC-389.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace water separator.

11	CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT
Refer to "DTC Confirmation Procedure", EC-297.	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Repair or replace EVAP canister vent control valve and O-ring or harness/connectors.

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

Diagnostic Procedure (Cont'd)

12	CHECK IF EVAP CANISTER SATURATED WITH WATER
<ol style="list-style-type: none"> Remove EVAP canister with EVAP canister vent control valve attached. Check if water will drain from the EVAP canister. 	
SEF596U	
Yes or No	
Yes	▶ GO TO 13.
No (With CONSULT)	▶ GO TO 15.
No (Without CONSULT)	▶ GO TO 16.

13	CHECK EVAP CANISTER
Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).	
OK or NG	
OK (With CONSULT)	▶ GO TO 15.
OK (Without CONSULT)	▶ GO TO 16.
NG	▶ GO TO 14.



14	DETECT MALFUNCTIONING PART
Check the following. <ol style="list-style-type: none"> Visually check the EVAP canister for damage. Check hose connection between EVAP canister and water separator for clogging and poor connection. Check water separator. Refer to "Component Inspection", EC-389. 	
▶	Repair hose or replace EVAP canister or water separator.

15	CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE																					
Ⓜ With CONSULT <ol style="list-style-type: none"> Disconnect vacuum hose from EVAP canister purge control valve and install vacuum gauge. 																						
SEF307W																						
SEF622U																						
<ol style="list-style-type: none"> Start engine and let it idle. Perform "PURG CONT S/V" in "ACTIVE TEST" mode. Rev engine up to 2,000 rpm. Select "ON" and "OFF" on CONSULT screen to turn on "PURG CONT/V S/V". 																						
<table border="1" style="width: 100%;"> <tr> <td colspan="2" style="text-align: center;">ACTIVE TEST</td> <td style="text-align: center;"><input type="checkbox"/></td> </tr> <tr> <td>PURG CONT S/V (PURG CONT VAC)</td> <td style="text-align: center;">ON</td> <td style="text-align: center;">VC ON</td> </tr> <tr> <td colspan="3" style="text-align: center;">----- MONITOR -----</td> </tr> <tr> <td>CMPS•RPM(REF)</td> <td style="text-align: center;">2000rpm</td> <td></td> </tr> <tr> <td>CLSD THL/P SW</td> <td style="text-align: center;">OFF</td> <td></td> </tr> <tr> <td>PURG CONT S/V</td> <td style="text-align: center;">ON</td> <td></td> </tr> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">ON/OFF</td> <td style="text-align: center;">OFF</td> </tr> </table>		ACTIVE TEST		<input type="checkbox"/>	PURG CONT S/V (PURG CONT VAC)	ON	VC ON	----- MONITOR -----			CMPS•RPM(REF)	2000rpm		CLSD THL/P SW	OFF		PURG CONT S/V	ON		ON	ON/OFF	OFF
ACTIVE TEST		<input type="checkbox"/>																				
PURG CONT S/V (PURG CONT VAC)	ON	VC ON																				
----- MONITOR -----																						
CMPS•RPM(REF)	2000rpm																					
CLSD THL/P SW	OFF																					
PURG CONT S/V	ON																					
ON	ON/OFF	OFF																				
SEF738W																						
ON: Vacuum should exist. OFF: Vacuum should not exist.																						
OK or NG																						
OK	▶ GO TO 18.																					
NG	▶ GO TO 17.																					


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


LTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)


Diagnostic Procedure (Cont'd)

16	CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE
<p>⊗ Without CONSULT</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Lift up drive wheels. 4. Disconnect vacuum hose from EVAP canister purge volume control valve and install vacuum gauge. 	
 <p style="text-align: right;">SEF307W</p>	
 <p style="text-align: right;">SEF622U</p>	
<ol style="list-style-type: none"> 5. Start engine and let it idle for at least 60 seconds. 6. Shift selector lever to 1st gear position (M/T models). 7. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. While operating solenoid valve, vacuum should exist. 8. Release the accelerator pedal and let idle. Vacuum should not exist. 	
OK or NG	
OK	▶ GO TO 18.
NG	▶ GO TO 17.

17	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • EVAP canister purge control solenoid valve Refer to "Component Inspection", EC-419. • Vacuum hoses for clogging or disconnection. Refer to "Vacuum Hose Drawing", EC-21. 	
▶	Repair hoses or replace EVAP canister purge control solenoid valve.

18	CHECK ABSOLUTE PRESSURE SENSOR
<p>Refer to "Component Inspection", EC-133.</p>	
 <p style="text-align: right;">SEF294W</p>	
OK or NG	
OK	▶ GO TO 19.
NG	▶ Replace absolute pressure sensor.

19	CHECK MAP/BARO SWITCH SOLENOID VALVE
<p>Refer to "Component Inspection", EC-336.</p>	
 <p style="text-align: right;">SEF314W</p>	
OK or NG	
OK	▶ GO TO 20.
NG	▶ Replace MAP/BARO switch solenoid valve.

20	CHECK TANK FUEL TEMPERATURE SENSOR
<p>Refer to "Component Inspection", EC-244.</p>	
 <p style="text-align: right;">SEF299W</p>	
OK or NG	
OK	▶ GO TO 21.
NG	▶ Replace tank fuel temperature sensor.

DTC P1440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM (SMALL LEAK) (POSITIVE PRESSURE)

Diagnostic Procedure (Cont'd)

21	CHECK EVAP PURGE LINE	
Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to "Evaporative Emission System", EC-31.		
OK or NG		
OK	▶	GO TO 22.
NG	▶	Repair or reconnect the hose.

22	CLEAN EVAP PURGE LINE	
Clean EVAP purge line (pipe and rubber tube) using air blower.		
		▶ GO TO 23.

23	CHECK INTERMITTENT INCIDENT	
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.		
		▶ INSPECTION END

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Description


Description SYSTEM DESCRIPTION

NCEC0359

NCEC0359S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP purge flow control	EVAP canister purge volume control valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage		
Ignition switch	Start signal		
Closed throttle position switch	Closed throttle position		
Throttle position sensor	Throttle position		
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Tank fuel temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

NCEC0359S02

The EVAP canister purge volume control valve uses a step motor to control the flow rate of fuel vapor from the EVAP canister. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

CONSULT Reference Value in Data Monitor Mode

NCEC0360

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	Idle	0 step
	<ul style="list-style-type: none"> Engine: After warming up No-load Lift up drive wheels and shift to 1st gear position. More than 60 seconds after starting engine A/T models: 2,000 rpm M/T models: 2,000 rpm and more than 16 km/h (10 MPH)	More than 1 step

DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NCEC0361

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
5	L	EVAP canister purge vol- ume control valve	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.6V
6	G			
16	Y	EVAP canister purge vol- ume control valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
17	OR			

On Board Diagnosis Logic

NCEC0362

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1444 0214	<ul style="list-style-type: none"> The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control valve is completely closed. 	<ul style="list-style-type: none"> EVAP control system pressure sensor and circuit EVAP canister purge volume control valve (The valve is stuck open.) EVAP canister purge control valve EVAP canister Hoses (Hoses are connected incorrectly or clogged.) EVAP canister vent control valve

4

■ PURG CNV&S/V P1493 ■

THIS SUPPORT FUNCTION
IS FOR
DTC P1493.
SEE THE SERVICE MANUAL
ABOUT THE OPERATING
CONDITION FOR THIS
DIAGNOSIS.

EXIT START

SEF610UA

7

■ PURG CNV&S/V P1493 ■

***** OK *****

■ SELF-DIAG RESULTS ■

**** NO FAILURE ****

END PRINT

SEF611UA

DTC Confirmation Procedure

NCEC0363

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above 5°C (41°F).

④ With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "PURG CNV & S/V P1493" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 5) Touch "START".
- 6) Start engine and let it idle for at least 90 seconds.
- 7) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

DTC Confirmation Procedure (Cont'd)

9

■ PURG VOL CN/V P1444 ■ □

THIS SUPPORT FUNCTION IS FOR DTC P1447. SEE THE SERVICE MANUAL ABOUT THE OPERATING CONDITION FOR THIS DIAGNOSIS.

EXIT START

SEF612UA

11

■ PURG VOL CN/V P1444 ■ □

TESTING

===== MONITOR =====

CMPS•RPM(REF)	1687rpm
THRTL POS SEN	0.74V
B/FUEL SCHDL	2.5msec

SEF853UB

11

■ PURG VOL CN/V P1444 ■ □

COMPLETED

SELF-DIAG RESULTS

SEF902UC

ENGINE SPD	825RPM
COOLANT TEMP	69°C
VEHICLE SPD	0MPH
IGN ADVANCE	8.0°
CALC LOAD	28.2%
MAP	36KPaA
MAF	5.20gm/s
THROTTLE POS	0.0%
INTAKE AIR	27°C
FUEL SYS #1	OLDRIVE
FUEL SYS #2	UNUSED
SHORT FT #1	0.8%
LONG FT #1	0.0%
O2S B1 S1	0.200V
O2FT B1 S1	0.8%
O2S B1 S2	0.010V

SEF519R

Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
CMPS-RPM (REF)	1,000 rpm or more
B/FUEL SCHDL	1 - 4.5 msec

- 8) Stop vehicle with engine running.
- 9) Select "PURG VOL CN/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 10) Touch "START".
If "COMPLETED" is displayed, go to step 12.
- 11) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 20 seconds.)

Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
CMPS-RPM (REF)	1,000 rpm or more
B/FUEL SCHDL	1 - 4.5 msec

NOTE:

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 12) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-384.

With GST

NOTE:

It is better that the fuel level is low.

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MODE 1" with GST.
- 3) Check engine coolant temperature.

Engine coolant temperature: 40 - 100°C (104 - 212°F)

Be sure that engine coolant temperature does not exceed 100°C (212°F). If it becomes higher than 100°C (212°F), cool down the engine and perform the procedure again from the beginning.

- 4) Turn ignition switch "OFF" and wait at least 5 seconds.
- 5) Restart engine and let it idle for at least 100 seconds.
- 6) Maintain the following conditions for at least 80 seconds.

Gear position	Suitable gear position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
Engine speed	1,000 rpm or more
Engine coolant temperature	40 - 100°C (104 - 212°F)


DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

DTC Confirmation Procedure (Cont'd)

NOTE:

- Hold the accelerator pedal as steady as possible during driving in step 6.
 - If the driving conditions are not satisfied in step 6, restart the procedure.
- 7) Select "MODE 7" with GST.
 - 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-384.

GI
MA
EM
LC



⊗ Without CONSULT

NOTE:

It is better that the fuel level is low.

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check voltage between ECM terminal 51 (Engine coolant temperature sensor signal) and ground

Voltage: 0.8 - 1.5V

Perform the following procedure before the voltage drops below 0.8V. If the voltage drops below 0.8V, cool down the engine and perform the procedure again from the beginning.

- 3) Turn ignition switch "OFF" and wait at least 5 seconds.
- 4) Restart engine and let it idle for at least 100 seconds.
- 5) Maintain the following conditions for at least 80 seconds.

EC
FE
CL
MT
AT

Gear position	Suitable gear position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
Engine speed	1,000 rpm or more
Voltage between ECM terminal 51 and ground	0.8 - 1.5V

AX
SU

NOTE:

- Hold the accelerator pedal as steady as possible during driving in step 5.
 - If the driving conditions are not satisfied in step 5, restart the procedure.
- 6) Turn ignition switch "OFF", wait at least 5 seconds, and then turn "ON".
 - 7) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
 - 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-384.

BR
ST
RS
BT
HA


SC
EL
IDX

DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Diagnostic Procedure

Diagnostic Procedure

=NCEC0364

1	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
Refer to "Component Inspection", EC-385.	
 <p style="text-align: center;">EVAP canister purge volume control valve harness connector</p> <p style="text-align: center;">Intake manifold collector</p> <p style="text-align: right;">SEF306W</p>	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Replace EVAP canister purge volume control valve.


2	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Install hose properly or replace it.

3	CHECK HARNESS CONNECTOR
1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace EVAP control system pressure sensor.

4	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT
Refer to "DTC confirmation Procedure", EC-303.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace EVAP control system pressure sensor and repair or replace harness and connector.

5	CHECK EVAP CANISTER VENT CONTROL VALVE
Refer to "Component Inspection", EC-389.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace EVAP canister vent control valve.

6	CHECK RUBBER TUBE FOR CLOGGING
Check obstructed water separator, improper connection of hose and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower. For water separator, refer to "Component Inspection", EC-389.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Clean, repair or replace rubber tube and/or water separator.

7	CHECK IF EVAP CANISTER IS SATURATED WITH WATER
1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water will drain from the EVAP canister.	
 <p style="text-align: right;">EVAP canister</p> <p style="text-align: center;">Water</p> <p style="text-align: center;">EVAP canister vent control valve</p> <p style="text-align: right;">SEF596U</p>	
Yes or No	
Yes	▶ GO TO 8.
No	▶ GO TO 10.

8	CHECK EVAP CANISTER
Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).	
OK or NG	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

DTC P1444 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Diagnostic Procedure (Cont'd)

9	DETECT MALFUNCTIONING PART
Check the following. 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection.	
▶	Repair hose or replace EVAP canister.

10	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110. Refer to "Wiring Diagram", EC-293 for the circuit.	
▶	INSPECTION END

GI
MA
EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA


SC

EL


IDX



SEF239W



SEF507R



Component Inspection

EVAP CANISTER PURGE VOLUME CONTROL VALVE

NCEC0365
NCEC0365S01

Ⓟ With CONSULT

- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal 2 and terminals 1, 3
terminal 5 and terminals 4, 6

Resistance: 35 - 43Ω [At 20°C (68°F)]

- 3) Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve. (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON".
- 6) Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
If NG, replace the EVAP canister purge volume control valve.

ⓧ Without CONSULT


- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal 2 and terminals 1, 3
terminal 5 and terminals 4, 6

Resistance: 35 - 43Ω [At 20°C (68°F)]

- 3) Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve. (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
If NG, replace the EVAP canister purge volume control valve.

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

Component Description



Component Description

NCEC0366

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

CONSULT Reference Value in Data Monitor Mode

NCEC0367

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

ECM Terminals and Reference Value

NCEC0368

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
108	PU/W	EVAP canister vent control valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0369

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1446 0215	<ul style="list-style-type: none"> ● EVAP canister vent control valve remains closed under specified driving conditions. 	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water.

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

DTC Confirmation Procedure

4	★ MONITOR ★ NO FAIL <input type="checkbox"/>
CMPS•RPM(REF)	2300rpm
COOLAN TEMP/S	85°C
VHCL SPEED SEN	80km/h
THRTL POS SEN	1.68V
B/FUEL SCHDL	1.8msec

SEF725W

DTC Confirmation Procedure

NCEC0370

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine.
- 4) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.

NOTE:

If a malfunction exists, NG result may be displayed quicker.

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-388.

Ⓜ With GST

- 1) Start engine.
- 2) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for 15 minutes.
- 3) Select "MODE 7" with GST.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-388.

Ⓜ No Tools

- 1) Start engine.
- 2) Drive vehicle at a speed of approximately 80 km/h (50 MPH) for 15 minutes.
- 3) Turn ignition switch "OFF" and wait at least 5 seconds.
- 4) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-388.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)


Diagnostic Procedure

Diagnostic Procedure

=NCEC0371

1	CHECK RUBBER TUBE FOR CLOGGING
Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower. For water separator, refer to EC-389.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Clean, repair or replace rubber tube and/or water separator.

2	CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING
Refer to "COMPONENT INSPECTION", EC-389.	
Under the vehicle view	
 <p>EVAP canister vent control valve harness connector</p> <p>EVAP canister.</p> <p style="text-align: right;">SEF310W</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace EVAP canister vent control valve and O-ring.

3	CHECK IF EVAP CANISTER IS SATURATED WITH WATER
<ol style="list-style-type: none"> Remove EVAP canister with EVAP canister vent control valve attached. Check if water will drain from the EVAP canister. 	
 <p>EVAP canister</p> <p>Water</p> <p>EVAP canister vent control valve</p> <p style="text-align: right;">SEF596U</p>	
Yes or No	
Yes	▶ GO TO 4.
No	▶ GO TO 6.

4	CHECK EVAP CANISTER
Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
Check the following. <ol style="list-style-type: none"> Visually check the EVAP canister for damage. Check hose connection between EVAP canister and water separator for clogging and poor connection. Check water separator. Refer to "Component Inspection", EC-389.	
▶ Repair hose or replace EVAP canister or water separator.	

6	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Install hose properly or replace it.

7	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> Disconnect EVAP control system pressure sensor harness connector. Check harness connector for water. Water should not exist. 	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace EVAP control system pressure sensor.

8	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT
Refer to "DTC Confirmation Procedure", EC-303.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EVAP control system pressure sensor and repair or replace harness and connector.

DTC P1446 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (CLOSE)

Diagnostic Procedure (Cont'd)


9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

GI

MA

EM

LC



Component Inspection

EVAP CANISTER VENT CONTROL VALVE

NCEC0372

NCEC0372S01

EC

Check air passage continuity.

① With CONSULT


Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.

FE

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

CL

MT



⊗ Without CONSULT

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
No supply	Yes

AT

AX

SU

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve.

Make sure new O-ring is installed properly.

BR

ST

RS


BT

HA

SC

EL

IDX



WATER SEPARATOR

NCEC0372S03

1. Check visually for insect nests in the water separator air inlet.
 2. Check visually for cracks or flaws in the appearance.
 3. Check visually for cracks or flaws in the hose.
 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged.
 5. In case of NG in items 2 - 4, replace the parts.
- **Do not disassemble water separator.**

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING


System Description

System Description

NCEC0373

NOTE:

If DTC P1447 is displayed with P0510, perform trouble diagnosis for DTC P0510 first. (See EC-320.)



In this evaporative emission (EVAP) control system, purge flow occurs during non-vehicle stopped conditions (M/T models) and non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control valve and EVAP canister purge control valve are open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

NCEC0374

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1447 0111	<ul style="list-style-type: none"> ● EVAP control system does not operate properly. ● EVAP control system has a leak between intake manifold and EVAP control system pressure sensor. 	<ul style="list-style-type: none"> ● EVAP canister purge volume control valve stuck closed ● EVAP canister purge control valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● EVAP canister purge control solenoid valve ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● Cracked EVAP canister ● Closed throttle position switch ● Improper connection of one-way valve ● Blocked purge port ● EVAP canister vent control valve

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

DTC Confirmation Procedure

NCEC0375

4

■ PURG CN/V&S/V P1493 ■ □

THIS SUPPORT FUNCTION IS FOR DTC P1493. SEE THE SERVICE MANUAL ABOUT THE OPERATING CONDITION FOR THIS DIAGNOSIS.

EXIT START

SEF610UB

7

■ PURG CN/V&S/V P1493 ■ □

***** OK *****

■ SELF-DIAG RESULTS ■

**** NO FAILURE ****

END PRINT

SEF611UD

8

■ PURG VOL CN/V P1444 ■ □

THIS SUPPORT FUNCTION IS FOR DTC P1447. SEE THE SERVICE MANUAL ABOUT THE OPERATING CONDITION FOR THIS DIAGNOSIS.

EXIT START

SEF612UB

9

■ PURG VOL CN/V P1444 ■ □

COMPLETED

SELF-DIAG RESULTS

SEF902UD

12

■ PURG FLOW 1447 ■ □

OUT OF CONDITION

===== MONITOR =====

CMPS-RPM(REF) 1062rpm
 THRTL POS SEN 0.59V
 B/FUEL SCHDL 1.2msec

SEF250VA

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above 5°C (41°F).

① With CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine and let it idle for at least 1 minute.
- 4) Select "PURG CN/V & S/V P1493" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 5) Touch "START".
- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

CMPS-RPM (REF)	1,000 rpm or more
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	1 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS" and go to the following step. If "NG" is displayed, refer to "Diagnostic Procedure" of DTC P1493, EC-424.
- 8) Select "PURG VOL CN/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 9) Touch "START".
If "COMPLETED" is displayed, go to step 11.
- 10) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 20 seconds.)


CMPS-RPM (REF)	1,000 rpm or more
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	1 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 11) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS" and go to the following step. If "NG" is displayed, refer to "Diagnostic Procedure" of DTC P1444, EC-381.
- 12) Select "PURG FLOW P1447" of "EVAPORATIVE SYSTEM" in "DTC CONFIRMATION" mode with CONSULT.
- 13) Touch "START".

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING


DTC Confirmation Procedure (Cont'd)




14) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 35 seconds.)

Selector lever	Suitable position
Vehicle speed	30 - 120 km/h (19 - 75 MPH)
CMPS-RPM (REF)	1,000 rpm or more
Engine coolant temperature	70 - 100°C (158 - 212°F)

If "TESTING" is not displayed after 5 minutes, retry from step 2.



15) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-393.



Overall Function Check

Use this procedure to check the overall monitoring function of the EVAP control system purge flow. During this check, a 1st trip DTC might not be confirmed. NCEC0376

⊗ Without CONSULT

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF", wait at least 5 seconds.
- 3) Start engine and wait at least 70 seconds.
- 4) Set voltmeter probes to ECM terminal 67 (EVAP control system pressure sensor signal) and ground.
- 5) Check EVAP control system pressure sensor value at idle speed.
- 6) Establish and maintain the following conditions for at least 1 minute.

Air conditioner switch	ON	
Steering wheel	Fully turned	
Headlamp switch	ON	
Rear window defogger switch	ON	
Engine speed	Approx. 3,000 rpm	
Gear position	M/T models	Any position other than "Neutral" or "Reverse"
	A/T models	Any position other than "P", "N" or "R"

Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed for at least 1 second.

- 7) If NG, go to "Diagnostic Procedure", EC-393.


DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING


Diagnostic Procedure

NCEC0977

Diagnostic Procedure

1	CHECK EVAP CANISTER
1. Turn ignition switch "OFF". 2. Check EVAP canister for cracks. <p style="text-align: center;">OK or NG</p>	
OK (With CONSULT)	▶ GO TO 2.
OK (Without CONSULT)	▶ GO TO 3.
NG	▶ Replace EVAP canister.

2	CHECK PURGE FLOW												
<input checked="" type="checkbox"/> With CONSULT 1. Disconnect vacuum hose from EVAP canister purge control valve and install vacuum gauge.  <p style="text-align: right;">SEF622U</p>													
2. Start engine and let it idle. 3. Perform "PURG CONT S/V" in "ACTIVE TEST" mode. 4. Rev engine up to 2,000 rpm. 5. Select "ON" and "OFF" on CONSULT screen to turn on "PURG CONT/V S/V". <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">PURG CONT S/V</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>(PURG CONT VAC)</td> <td style="text-align: right;">VC ON</td> </tr> <tr> <td colspan="2" style="text-align: center;">----- MONITOR -----</td> </tr> <tr> <td>CMPS•RPM(REF)</td> <td style="text-align: right;">2000rpm</td> </tr> <tr> <td>CLSD THL/P SW</td> <td style="text-align: right;">OFF</td> </tr> <tr> <td>PURG CONT S/V</td> <td style="text-align: right;">ON</td> </tr> </table> <p style="text-align: center;"> <input checked="" type="checkbox"/> ON <input type="checkbox"/> ON/OFF <input type="checkbox"/> OFF </p> </div> <p style="text-align: right;">SEF738W</p>		PURG CONT S/V	ON	(PURG CONT VAC)	VC ON	----- MONITOR -----		CMPS•RPM(REF)	2000rpm	CLSD THL/P SW	OFF	PURG CONT S/V	ON
PURG CONT S/V	ON												
(PURG CONT VAC)	VC ON												
----- MONITOR -----													
CMPS•RPM(REF)	2000rpm												
CLSD THL/P SW	OFF												
PURG CONT S/V	ON												
ON: Vacuum should exist.													
OFF: Vacuum should not exist.													
OK or NG													
OK	▶ GO TO 8.												
NG	▶ GO TO 4.												

3	CHECK PURGE FLOW
<input checked="" type="checkbox"/> Without CONSULT 1. Start engine and warm it up to normal operating temperature. 2. Stop engine. 3. Lift up drive wheels. 4. Disconnect vacuum hose from EVAP canister purge volume control valve and install vacuum gauge.  <p style="text-align: right;">SEF622U</p>	
5. Start engine and let it idle for at least 60 seconds. 6. Shift selector lever to 1st gear position (M/T models). 7. Check vacuum hose for vacuum when revving engine up to 2,000 rpm. While operating solenoid valve, vacuum should exist. 8. Release the accelerator pedal and let idle. Vacuum should not exist. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 4.

4	CHECK EVAP PURGE LINE
Check EVAP purge line for improper connection or disconnection. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair it.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

Diagnostic Procedure (Cont'd)

5	CHECK EVAP PURGE HOSE AND PURGE PORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect purge hoses connected to EVAP canister purge control valve A and EVAP canister purge volume control valve B.</p>	
<p>3. Blow air into each hose and EVAP purge port C.</p>	
<p>4. Check that air flows freely.</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair or clean hoses and/or purge port.


6	CHECK ONE-WAY VALVE
Refer to "Component Inspection", EC-396.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Reconnect one-way valve properly or replace it.


7	CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE
Refer to "Component Inspection", EC-419.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace EVAP canister purge control solenoid valve.

8	CHECK EVAP CANISTER PURGE VOLUME CONTROL VALVE
Refer to "Component Inspection", EC-295.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EVAP canister purge volume control valve.

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

Diagnostic Procedure (Cont'd)

9	CHECK EVAP CANISTER PURGE CONTROL VALVE
Refer to "Component Inspection", EC-419.	
 <p style="text-align: right; margin-right: 50px;">SEF307W</p>	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP canister purge control valve.

13	CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING
Refer to "Component Inspection", EC-389.	
<p style="text-align: center;">Under the vehicle view</p>  <p style="text-align: right; margin-right: 50px;">SEF310W</p>	
OK or NG	
OK	▶ GO TO 14.
NG	▶ Replace EVAP canister vent control valve and O-ring.

10	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Install hose properly or replace it.

14	CHECK EVAP PURGE LINE
Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Replace it.

11	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist. 	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Replace EVAP control system pressure sensor.

15	CLEAN EVAP PURGE LINE
Clean EVAP purge line (pipe and rubber tube) using air blower.	
▶ GO TO 16.	


12	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT
Perform to "DTC Confirmation Procedure", EC-303.	
OK or NG	
OK	▶ GO TO 13.
NG	▶ Replace EVAP control system pressure sensor and repair or replace harness and connector.

16	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1447 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE FLOW MONITORING

Component Inspection



Component Inspection

ONE-WAY VALVE

NCEC0378

NCEC0378S05

Check one-way valve air passage continuity.


Condition	Air passage continuity
Blow air into side B to A	Yes
Blow air into side A to B	No

If NG, replace one-way valve.

Make sure to install one-way valve with the colored side facing the vacuum.

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

Component Description



Component Description

NCEC0379

NOTE:

If DTC P1448 is displayed with P0440 or P1440, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

CONSULT Reference Value in Data Monitor Mode

NCEC0380

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

ECM Terminals and Reference Value

NCEC0381

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
108	PU/W	EVAP canister vent control valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0382

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1448 0309	● EVAP canister vent control valve remains opened under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water. ● Vacuum cut valve

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

DTC Confirmation Procedure

5

■ EVAP SML LEAK P0440 ■

- 1) PERFORM TEST AT A LOCATION OF 0-30C (32-86F)
- 2) OPEN ENGINE HOOD.
- 3) START ENGINE WITH VEHICLE STOPPED. IF ENG IS ON, STOP FOR 5 SEC. THEN RESTART.
- 4) TOUCH START.

EXIT START

SEF405WA

5

■ EVAP SML LEAK P0440 ■

WAIT. . .

KEEP ENGINE RUNNING
AT IDLE SPEED.

SEF551VB

5

■ EVAP SML LEAK P0440 ■

CAN NOT BE DIAGNOSED

FUEL TEMPERATURE IS TOO HIGH. RETEST AFTER FUEL HAS COOLED.

EXIT PRINT

SEF669UE

6

■ EVAP SML LEAK P0440 ■

***** OK *****

END PRINT

SEF297UC

10

CONNECT

O-ring

■ ACTIVE TEST ■

VENT CONTROL/V OFF

===== MONITOR =====

CMPS-RPM(REF) 0rpm
FR O2 MNTR RICH
A/F ALPHA 100%
THIRTL POS SEN 0.52V

ON ON/OFF OFF

SEF191VC

DTC Confirmation Procedure

NCEC0383

NOTE:

- If DTC P1448 is displayed with P0440 or P1440, perform trouble diagnosis for DTC P1448 first.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
- 1) Turn ignition switch "ON".
 - 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 - 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 - 4) Check that the following conditions are met.

COOLAN TEMP/S	0 - 70°C (32 - 158°F)
INT/A TEMP SE	0 - 60°C (32 - 140°F)

- 5) Select "EVAP SML LEAK P0440" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT. Follow the instruction displayed.

NOTE:


- If the CONSULT screen shown at left is displayed, stop the engine and stabilize the vehicle temperature at 25°C (77°F) or cooler. After "TANK F/TMP SE" becomes less than 30°C (86°F), retest. (Use a fan to reduce the stabilization time.)
 - If the engine speed cannot be maintained within the range displayed on CONSULT screen, go to "Basic Inspection", EC-83.
 - The engine idle portion of this test (See illustration at left.) will take approximately 5 minutes.
- 6) Make sure that "OK" is displayed. If "NG" is displayed, go to following step.
 - 7) Disconnect hose from water separator.
 - 8) Select "VENT CONTROL/V" of "ACTIVE TEST" mode with CONSULT.
 - 9) Touch "ON" and "OFF" alternately.
 - 10) Make sure of the following.

Condition	Air passage continuity between A and B
Touching "ON"	No
Touching "OFF"	Yes

If the result is NG, go to "Diagnostic Procedure", EC-399.
If the result is OK, go to "Diagnostic Procedure" for DTC P0440, EC-286.

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

Overall Function Check



Overall Function Check

NCEC0384

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

⊗ Without CONSULT

- 1) Disconnect hose from water separator.
- 2) Disconnect EVAP canister vent control valve harness connector.
- 3) Verify the following.

Condition	Air passage continuity
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If the result is NG, go to "Diagnostic Procedure", EC-399.
If the result is OK, perform trouble diagnosis for DTC P0440.
Refer to EC-283.

Diagnostic Procedure

NCEC0385


1	CHECK RUBBER TUBE
1. Turn ignition switch "OFF". 2. Check disconnection or obstruction of rubber tube connected to EVAP canister vent control valve.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or clean rubber tube.

2	CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING
Refer to "Component Inspection", EC-401.	
Under the vehicle view	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace EVAP canister vent control valve and O-ring.

3	CHECK VACUUM CUT VALVE
Refer to "Component Inspection", EC-413.	
Under the vehicle view	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace vacuum cut valve.

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

Diagnostic Procedure (Cont'd)

4	CHECK IF EVAP CANISTER IS SATURATED WITH WATER
<p>1. Remove EVAP canister with the vent control valve attached. 2. Check if water will drain from the EVAP canister.</p>	
	
Yes or No	
Yes	▶ GO TO 7.
No	▶ GO TO 5.

5	CHECK EVAP CANISTER
<p>Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0lb).</p>	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ol style="list-style-type: none"> 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. 3. Check water separator. Refer to "Component Inspection", EC-401. 	
▶	Repair hose or replace EVAP canister or water separator.

7	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
<p>Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.</p>	
OK or NG	
OK	▶ GO TO 8.
NG	▶ install hose property or replace it.


8	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist. 	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace EVAP control system pressure sensor.

9	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR
<p>Perform "DTC Confirmation Procedure", EC-303.</p>	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP control system pressure sensor and repair or replace harness and connector.

10	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

DTC P1448 EVAPORATIVE EMISSION (EVAP) CANISTER VENT CONTROL VALVE (OPEN)

Component Inspection



Component Inspection

EVAP CANISTER VENT CONTROL VALVE

NCEC0386

NCEC0386S01

Check air passage continuity.


With CONSULT

Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.

Condition	Air passage continuity between A and B
VENT CONTROL/V ON	No
VENT CONTROL/V OFF	Yes


Without CONSULT

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
No supply	Yes



If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If the portion B is rusted, replace EVAP canister vent control valve. Make sure new O-ring is installed properly.




WATER SEPARATOR

NCEC0386S03

1. Check visually for insect nests in water separator air inlet.
 2. Check visually for cracks or flaws in the appearance.
 3. Check visually for cracks or flaws in the hose.
 4. Check that A and C are not clogged by blowing air into B with A, and then C plugged.
 5. In case of NG in items 2 - 4, replace the parts.
- Do not disassemble water separator.

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

Description



Description

COMPONENT DESCRIPTION


The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.

The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
117	PU/R	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0390

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1490 0801	<ul style="list-style-type: none"> An improper voltage signal is sent to ECM through vacuum cut valve bypass valve. 	<ul style="list-style-type: none"> Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted.) Vacuum cut valve bypass valve

GI

MA

EM

LC

DTC Confirmation Procedure

NCEC0391

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Before performing the following procedure, confirm battery voltage is more than 11V at idle.

EC

FE

CL

MT



Ⓟ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-405.

AT

AX

Ⓢ With GST

- 1) Start engine and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-405.

SU

BR

Ⓝ No Tools

- 1) Start engine and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-405.

ST

RS

BT

HA

SC

EL

IDX




DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

Wiring Diagram






Wiring Diagram

NCEC0392

EC-BYPS/V-01



Refer to last page (Foldout page).
(M3)



DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)



Diagnostic Procedure

Diagnostic Procedure

NCEC0393

1	INSPECTION START
Do you have CONSULT?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2	CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT								
1. Turn ignition switch "ON".									
2. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.									
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <div style="text-align: center;"> ACTIVE TEST <input type="checkbox"/> </div> <p style="text-align: center;">VC/V BYPASS/V</p> <p style="text-align: center;">----- MONITOR -----</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 80%;">CMPS•RPM(REF)</td> <td style="text-align: right;">0rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td style="text-align: right;">RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td style="text-align: right;">100%</td> </tr> <tr> <td>THRTL POS SEN</td> <td style="text-align: right;">0.52V</td> </tr> </table> <div style="text-align: center; margin-top: 5px;"> ON ON/OFF OFF </div> </div>		CMPS•RPM(REF)	0rpm	FR O2 MNTR	RICH	A/F ALPHA	100%	THRTL POS SEN	0.52V
CMPS•RPM(REF)	0rpm								
FR O2 MNTR	RICH								
A/F ALPHA	100%								
THRTL POS SEN	0.52V								
SEF364U									
3. Make sure that clicking sound is heard from the vacuum cut valve bypass valve.									
OK or NG									
OK	▶ GO TO 7.								
NG	▶ GO TO 3.								

3	CHECK POWER SUPPLY
1. Turn ignition switch "OFF".	
2. Disconnect vacuum cut valve bypass valve harness connector.	
<p>Under the vehicle view</p>  <p>Vacuum cut valve bypass valve harness connector</p> <p>EVAP canister</p> <p style="text-align: right;">SEF320W</p>	
3. Turn ignition switch "ON".	
4. Check voltage between terminal 1 and ground with CONSULT or tester.	
 <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: right;">SEF282W</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> ● Harness connectors M8, B3 ● Harness connectors B10, B120 ● Harness connectors B113, T1 ● Harness connectors T20, T19 ● 10A fuse ● Harness for open or short between vacuum cut valve bypass valve and fuse 	
▶ Repair harness or connectors.	

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1490 VACUUM CUT VALVE BYPASS VALVE (CIRCUIT)

Diagnostic Procedure (Cont'd)

5	CHECK OUTPUT SIGNAL CIRCUIT						
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between ECM terminal 117 and terminal 2. 							
SEF283W							
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%;"> <tr> <td style="width: 30%;">OK</td> <td style="width: 30%; text-align: center;">▶</td> <td style="width: 40%;">GO TO 7.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 6.</td> </tr> </table>		OK	▶	GO TO 7.	NG	▶	GO TO 6.
OK	▶	GO TO 7.					
NG	▶	GO TO 6.					

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors T19, T20 • Harness connectors T1, B113 • Harness connectors B120, B10 • Harness connectors B3, M8 • Harness for open or short between vacuum cut valve bypass valve and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK VACUUM CUT VALVE BYPASS VALVE	
Refer to "Component Inspection", EC-406.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace vacuum cut valve bypass valve.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

CONNECT	ACTIVE TEST																
	<input type="checkbox"/>																
	<table border="1" style="width: 100%;"> <tr> <td>VC/V BYPASS/V</td> <td>OFF</td> </tr> <tr> <td colspan="2" style="text-align: center;">===== MONITOR =====</td> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>0rpm</td> </tr> <tr> <td>FR O2 MNTR</td> <td>RICH</td> </tr> <tr> <td>A/F ALPHA</td> <td>100%</td> </tr> <tr> <td>THRTL POS SEN</td> <td>0.52V</td> </tr> <tr> <td>ON</td> <td>ON/OFF</td> </tr> <tr> <td></td> <td>OFF</td> </tr> </table>	VC/V BYPASS/V	OFF	===== MONITOR =====		CMPS-RPM(REF)	0rpm	FR O2 MNTR	RICH	A/F ALPHA	100%	THRTL POS SEN	0.52V	ON	ON/OFF		OFF
VC/V BYPASS/V	OFF																
===== MONITOR =====																	
CMPS-RPM(REF)	0rpm																
FR O2 MNTR	RICH																
A/F ALPHA	100%																
THRTL POS SEN	0.52V																
ON	ON/OFF																
	OFF																
SEF254V																	

BATTERY
SEF351Q

Component Inspection VACUUM CUT VALVE BYPASS VALVE

NCEC0394

NCEC0394S01

Check air passage continuity.

With CONSULT

Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No


Without CONSULT

Condition	Air passage continuity between A and B
12V direct current supply between terminals	Yes
No supply	No

If NG or operation takes more than 1 second, replace vacuum cut valve bypass valve.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Description



Description

COMPONENT DESCRIPTION


The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.

The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
117	PU/R	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)




DTC P1491 VACUUM CUT VALVE BYPASS VALVE

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0398

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1491 0311	<ul style="list-style-type: none"> • Vacuum cut valve bypass valve does not operate properly. 	<ul style="list-style-type: none"> • Vacuum cut valve bypass valve • Vacuum cut valve • Bypass hoses for clogging • EVAP control system pressure sensor • EVAP canister vent control valve • Hose between fuel tank and vacuum cut valve clogged • Hose between vacuum cut valve and EVAP canister clogged • EVAP canister • EVAP purge port of fuel tank for clogging



DTC Confirmation Procedure

NCEC0399

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5 to 30°C (41 to 86°F).

① With CONSULT






- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch "OFF" and wait at least 5 seconds.
- 4) Start engine and let it idle for at least 1 minute.
- 5) Select "PURG CN/V & S/V P1493" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 6) Touch "START".
- 7) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

CMPS-RPM (REF)	1,000 rpm or more
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	1 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 3.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

DTC Confirmation Procedure (Cont'd)



- 8) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS" and go to the following step. If "NG" is displayed, refer to "Diagnostic Procedure" for DTC P1493, EC-427.
- 9) Select "PURG VOL CN/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 10) Touch "START". If "COMPLETED" is displayed, go to step 12.
- 11) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 20 seconds.)

CMPS-RPM (REF)	1,000 rpm or more
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	1 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 3.

- 12) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS" and go to the following step. If "NG" is displayed, refer to "Diagnostic Procedure" for DTC P1444, EC-384.
- 13) Select "VC/V BYPASS/V P1491" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- 14) Touch "START".
- 15) When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)


CMPS-RPM (REF)	1,000 rpm or more
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	0.5 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 3.

- 16) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-410.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Overall Function Check



Overall Function Check

NCEC0400

⊗ Without CONSULT

- 1) Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
- 2) Apply vacuum to port **A** and check that there is no suction from port **B**.
- 3) Apply vacuum to port **B** and check that there is suction from port **A**.
- 4) Blow air in port **B** and check that there is a resistance to flow out of port **A**.
- 5) Supply battery voltage to the terminal.
- 6) Blow air in port **A** and check that air flow freely out of port **B**.
- 7) Blow air in port **B** and check that air flow freely out of port **A**.
- 8) If NG, go to "Diagnostic Procedure", EC-410.

Diagnostic Procedure

NCEC0401

1	INSPECTION START	
Do you have CONSULT?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Diagnostic Procedure (Cont'd)

2	CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION
<p>With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. Apply vacuum to port A and check that there is no suction from port B. Apply vacuum to port B and check that there is suction from port A. Blow air in port B and check that there is a resistance to flow out of port A. Turn ignition switch "ON". Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT and touch "ON". Blow air in port A and check that air flows freely out of port B. Blow air in port B and check that air flows freely out of port A. 	
<p style="text-align: right;">SEF069W</p>	
OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 5.

3	CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION
<p>Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly. Apply vacuum to port A and check that there is no suction from port B. Apply vacuum to port B and check that there is suction from port A. Blow air in port B and check that there is a resistance to flow out of port A. Disconnect vacuum cut valve bypass valve harness connector. Supply battery voltage to the terminal. Blow air in port A and check that air flows freely out of port B. Blow air in port B and check that air flows freely out of port A. 	
<p style="text-align: right;">SEF914U</p>	
OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 5.

4	CHECK EVAP PURGE LINE
<ol style="list-style-type: none"> Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection. Check EVAP purge port of fuel tank for clogging. Check EVAP canister. Refer to EC-28. 	
OK or NG	
OK	▶ GO TO 8.
NG (Step 1)	▶ Repair it.
NG (Step 2)	▶ Clean EVAP purge port.
NG (Step 3)	▶ Replace EVAP canister.

5	CHECK BYPASS HOSE
Check bypass hoses for clogging.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair or replace hoses.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Diagnostic Procedure (Cont'd)

6	CHECK VACUUM CUT VALVE BYPASS VALVE
Refer to "Component Inspection", EC-413.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace vacuum cut valve bypass valve.

7	CHECK VACUUM CUT VALVE
Refer to "Component Inspection", EC-413.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace vacuum cut valve.

8	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
1. Turn ignition switch "OFF". 2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Repair it

9	CHECK CONNECTOR
1. Disconnect EVAP control system pressure sensor harness connector.	
	
2. Check connectors for water. Water should not exist.	
SEF190S	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP control system pressure sensor.


10	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION
Refer to "DTC Confirmation Procedure" for DTC P0450, EC-303.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Replace EVAP control system pressure sensor.

11	CHECK EVAP CANISTER VENT CONTROL VALVE
Refer to "Component Inspection", EC-401.	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Replace EVAP canister vent control valve.

12	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Component Inspection



Component Inspection

NCEC0402

VACUUM CUT VALVE BYPASS VALVE

NCEC0402S01

Check air passage continuity.

① With CONSULT



Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

② Without CONSULT

Condition	Air passage continuity between A and B
12V direct current supply between terminals	Yes
No supply	No

If NG or operation takes more than 1 second, replace vacuum cut valve bypass valve.



VACUUM CUT VALVE

NCEC0402S02

Check vacuum cut valve as follows:

1. Plug port C and D with fingers.
2. Apply vacuum to port A and check that there is no suction from port B.
3. Apply vacuum to port B and check that there is suction from port A.
4. Blow air in port B and check that there is a resistance to flow out of port A.
5. Open port C and D.
6. Blow air in port A check that air flows freely out of port C.
7. Blow air in port B check that air flows freely out of port D.

DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)

Description

Description SYSTEM DESCRIPTION

NCEC0403

NCEC0403S01


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge control	EVAP canister purge control solenoid valve ↓ Vacuum signal ↓ EVAP canister purge control valve
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		

This system controls the vacuum signal applied to the EVAP canister purge control valve.

When the ECM detects any of the following conditions, current does not flow through the EVAP canister purge control solenoid valve.

The solenoid valve cuts the vacuum signal so that the EVAP canister purge control valve remains closed.

- Ignition switch "ON"
- Closed throttle position
- Low engine coolant temperature
- During deceleration
- Engine stopped
- Low vehicle speed (M/T models)
- For 60 seconds after starting engine (After warm-up to normal operating temperature)



COMPONENT DESCRIPTION


NCEC0403S02

EVAP Canister Purge Control Solenoid Valve

NCEC0403S0201

The EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal (from the intake manifold to the EVAP canister purge control valve) is cut.

When the ECM sends an ON (ground) signal, the vacuum signal passes through the EVAP canister purge control solenoid valve. The signal then opens the EVAP canister purge control valve.



EVAP Canister Purge Control Valve

NCEC0403S0202


When the vacuum signal is cut by EVAP canister purge control solenoid valve, EVAP canister purge control valve closes.

DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)

Description (Cont'd)

EVAPORATIVE EMISSION SYSTEM DIAGRAM

NCEC0403S03



CONSULT Reference Value in Data Monitor Mode

NCEC0404

MONITOR ITEM	CONDITION	SPECIFICATION
PURG CONT S/V	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N No-load M/T models: Lift up drive wheels and shift to 1st gear position. 	OFF
	<ul style="list-style-type: none"> Idle More than 60 seconds after starting engine Rev engine up from 2,000 to 4,000 rpm. 	ON

ECM Terminals and Reference Value

NCEC0405

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
105	PU	EVAP canister purge control solenoid valve	<ul style="list-style-type: none"> [Engine is running] • Warm-up condition • More than 60 seconds after starting engine • M/T models: Lift up drive wheels and shift to 1st gear position. • Engine speed is 2,000 rpm. 	Approximately 0V
			<ul style="list-style-type: none"> [Engine is running] • Warm-up condition • Idle speed 	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0406

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1492	<ul style="list-style-type: none"> An improper voltage signal is sent to ECM through EVAP canister purge control solenoid valve. 	<ul style="list-style-type: none"> Harness or connectors (The EVAP canister purge control solenoid valve circuit is open or shorted.) EVAP canister purge control solenoid valve

DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)

DTC Confirmation Procedure

DTC Confirmation Procedure

NCEC0407

NOTE:

If "DTC Confirmation Procedure has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-418.

With GST

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 3" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-418.

No Tools

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-418.


DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)

Wiring Diagram


Wiring Diagram

NCECD408


EC-CANI/V-01



— : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to last page (Foldout page).



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



TEC549

DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)


Diagnostic Procedure

Diagnostic Procedure

NCEC0409

1	CHECK POWER SUPPLY
<p>1. Disconnect EVAP canister purge control solenoid valve harness connector.</p>  <p>EVAP canister purge control solenoid valve harness connector</p> <p>ASCD actuator</p> <p style="text-align: right;">SEF308W</p>	
<p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between terminal 1 and ground with CONSULT or tester.</p>  <p style="text-align: right;">SEF286W</p>	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse ● Harness connectors M62, F24 ● Harness connectors F6, E123 ● Harness for open or short between EVAP canister purge control solenoid valve and fuse 	
▶ Repair harness or connectors.	

3	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 105 and terminal 2.</p>  <p style="text-align: right;">SEF287W</p>	
<p>Continuity should exist.</p> <p>4. also check harness for short to ground and short to power.</p> <p>OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F6, E123 ● Harness for open or short between EVAP canister purge control solenoid valve and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE
<p>Refer to "Component Inspection", EC-419.</p> <p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Replace EVAP canister purge control solenoid valve.

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	

DTC P1492 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE (CIRCUIT)




Component Inspection

■ ACTIVE TEST ■ □

PURG CONT S/V (PURG CONT VAC)	○ N VC ON
----- MONITOR -----	
PURG CONT S/V	ON
CMPS•RPM(REF)	2000rpm
CLSD THL/P SW	OFF
COOLANT TEMP/S	84°C

ON
ON/OFF
OFF

SEF516T



Component Inspection

EVAP CANISTER PURGE CONTROL SOLENOID VALVE NCEC0410 NCEC0410S01

① With CONSULT

1. Lift up driving wheels (M/T models only).
2. Turn ignition switch "ON".
3. Select "PURG CONT S/V" of "ACTIVE TEST" mode with CONSULT.
4. Start engine and warm it up to normal operating temperature.
5. Disconnect vacuum hose at EVAP canister purge control valve.
6. Touch "ON" and "OFF" and check for vacuum passing through the hose.

Condition	Vacuum
Idle	Not exist
2,000 rpm (A/T models) 2,000 rpm with 1st gear position (M/T models)	Exist

② Without CONSULT

Check air passage continuity.

Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG or operation takes more than 1 second, replace solenoid valve.

EVAP CANISTER PURGE CONTROL VALVE NCEC0410S02

Check EVAP canister purge control valve as follows:

1. Blow air in port A and B, then ensure that there is no leakage.
2. Plug port B and blow air in port C and check that air flows freely from port D.
3. Plug port D and blow air in port C, check that there is no leakage.
4. Apply vacuum to port A. [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg)] Plug port D and blow air in port C and ensure free flow out of port B.

DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

Description

Description SYSTEM DESCRIPTION

NCEC0411

NCEC0411S01


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge control	EVAP canister purge control solenoid valve ↓ Vacuum signal ↓ EVAP canister purge control valve
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		

This system controls the vacuum signal applied to the EVAP canister purge control valve.

When the ECM detects any of the following conditions, current does not flow through the EVAP canister purge control solenoid valve.

The solenoid valve cuts the vacuum signal so that the EVAP canister purge control valve remains closed.

- Ignition switch "ON"
- Closed throttle position
- Low engine coolant temperature
- During deceleration
- Engine stopped
- Low vehicle speed (M/T models)
- For 60 seconds after starting engine (After warm-up to normal operating temperature)



COMPONENT DESCRIPTION


NCEC0411S02

EVAP Canister Purge Control Solenoid Valve

NCEC0411S0201

The EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal (from the intake manifold to the EVAP canister purge control valve) is cut.

When the ECM sends an ON (ground) signal, the vacuum signal passes through the EVAP canister purge control solenoid valve. The signal then opens the EVAP canister purge control valve.



EVAP Canister Purge Control Valve

NCEC0411S0202


When the vacuum signal is cut by EVAP canister purge control solenoid valve, EVAP canister purge control valve closes.

DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

Description (Cont'd)

EVAPORATIVE EMISSION SYSTEM DIAGRAM

NCEC0411S03



SEF603U

CONSULT Reference Value in Data Monitor Mode

NCEC0412

MONITOR ITEM	CONDITION		SPECIFICATION
PURG CONT S/V	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N No-load M/T models: Lift up drive wheels and shift to 1st gear position. 	Idle	OFF
		More than 60 seconds after starting engine Rev engine up from 2,000 to 4,000 rpm.	ON

ECM Terminals and Reference Value

NCEC0413

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
105	PU	EVAP canister purge control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Warm-up condition More than 60 seconds after starting engine M/T models: Lift up drive wheels and shift to 1st gear position. Engine speed is 2,000 rpm. 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed 	BATTERY VOLTAGE (11 - 14V)



DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

On Board Diagnosis Logic

On Board Diagnosis Logic

NCEC0414

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1493	<ul style="list-style-type: none"> EVAP canister purge control valve does not operate properly (stuck open). 	<ul style="list-style-type: none"> EVAP canister purge control valve EVAP canister purge control solenoid valve Vacuum hoses for clogging or disconnection EVAP control system pressure sensor EVAP canister vent control valve Water separator EVAP canister saturated with water



DTC Confirmation Procedure

NCEC0415

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If DTC P1493 is displayed with P1492, first perform trouble diagnosis for DTC P1492. (See EC-414.)
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓟ With CONSULT

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Start engine and let it idle for at least 90 seconds.
- Select "PURG CNV & S/V P1493" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT.
- Touch "START".
- When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds.)

Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
CMPS-RPM (REF)	1,000 rpm or more
B/FUEL SCHDL	1 - 4.5 msec

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to "Diagnostic Procedure", EC-424.

DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

ENGINE SPD 825RPM
COOLANT TEMP 69°C
 VEHICLE SPD 0MPH
 IGN ADVANCE 8.0°
 CALC LOAD 28.2%
 MAP 36KPaA
 MAF 5.20gm/s
 THROTTLE POS 0.0%
 INTAKE AIR 27°C
 FUEL SYS #1 OLDRIVE
 FUEL SYS #2 UNUSED
 SHORT FT #1 0.8%
 LONG FT #1 0.0%
 O2S B1 S1 0.200V
 O2FT B1 S1 0.8%
 O2S B1 S2 0.010V

SEF519R

With GST

NOTE:

- Hold the accelerator pedal as steady as possible during driving in step 6. GI
- If the driving conditions are not satisfied in step 6, restart the procedure. MA
- It is better that the fuel level is low. EM

- 1) Start engine and warm it up to normal operating temperature. EM
- 2) Select "MODE 1" with GST. EM
- 3) Check engine coolant temperature. LC

Engine coolant temperature: 40 - 100°C (104 - 212°F)

Be sure that engine coolant temperature does not exceed 100°C (212°F). If it becomes higher than 100°C (212°F), cool down the engine and perform the procedure again from the beginning. EC

- 4) Turn ignition switch "OFF" and wait at least 5 seconds. FE
- 5) Restart engine and let it idle for at least 100 seconds. FE
- 6) Maintain the following conditions for at least 30 seconds. CL

Gear position	Suitable gear position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
Engine speed	1,000 rpm or more
Engine coolant temperature	40 - 100°C (104 - 212°F)

- 7) Select "MODE 7" with GST. AT
- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-424. AX

Without CONSULT

NOTE:


- Hold the accelerator pedal as steady as possible during driving in step 5. ST
- If the driving conditions are not satisfied in step 5, restart the procedure. RS
- It is better that the fuel level is low. BT

- 1) Start engine and warm it up to normal operating temperature. HA
- 2) Check voltage between ECM terminal 51 (Engine control temperature sensor signal) and ground HA

Voltage: 0.8 - 1.5V

Perform the following procedure before the voltage drops below 0.8V. If the voltage drops below 0.8V, cool down the engine and perform the entire procedure all over again. SC

- 3) Turn ignition switch "OFF" and wait at least 5 seconds. EL
- 4) Restart engine and let it idle for at least 100 seconds. EL
- 5) Maintain the following conditions for at least 30 seconds. IDX



DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

Gear position	Suitable gear position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
Engine speed	1,000 rpm or more
Check voltage between ECM terminal 51 and ground	0.8 - 1.5V

- 6) Stop the vehicle, turn ignition switch "OFF", wait at least 5 seconds, and then turn "ON".
- 7) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 8) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-424.

Diagnostic Procedure

NCEC0416

1	INSPECTION START	
Do you have CONSULT?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.



DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

2 CHECK VACUUM SIGNAL

- Ⓐ With CONSULT**
1. Turn ignition switch "OFF".
 2. Disconnect vacuum hose to EVAP canister purge control valve and install vacuum gauge.



3. Start engine.
4. Perform "PURG CONT S/V" in "ACTIVE TEST" mode.
5. Select "ON" and "OFF" on CONSULT screen.
6. Check vacuum hose for vacuum while revving engine up to 2,000 rpm.

■ ACTIVE TEST ■	
PURG CONT S/V (PURG CONT VAC)	O N VC ON
----- MONITOR -----	
PURG CONT S/V	ON
CMPS+RPM(REF)	2000rpm
CLSD THL/P SW	OFF
COOLANT TEMP/S	84°C
<input type="checkbox"/> ON <input type="checkbox"/> ON/OFF <input type="checkbox"/> OFF	



ON: Vacuum should exist.
OFF: Vacuum should not exist.

OK or NG

OK	▶	GO TO 5.
NG	▶	GO TO 4.

3 CHECK VACUUM SIGNAL

- ⓧ Without CONSULT**
1. Start engine and warm it up to normal operating temperature.
 2. Stop engine.
 3. Lift up drive wheels.
 4. Disconnect vacuum hose to EVAP canister purge control valve.



5. Install vacuum gauge and start engine and let it idle at least 60 seconds.

6. Shift selector lever to 1st gear position (M/T models).
7. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
While operating solenoid valve, vacuum should exist.
8. Release the accelerator pedal and let it idle.
Vacuum should not exist.

OK or NG

OK	▶	GO TO 5.
NG	▶	GO TO 4.

4 CHECK EVAP CANISTER PURGE CONTROL SOLENOID VALVE

Refer to "Component Inspection", EC-427.

OK or NG


OK	▶	Check vacuum hoses for improper connection, clogging or disconnection. Refer to "Vacuum Hose Drawing", EC-21.
NG	▶	Replace EVAP canister purge control solenoid valve.

DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE

Diagnostic Procedure (Cont'd)

5	CHECK EVAP CANISTER VENT CONTROL VALVE
Refer to "Components Inspection", EC-401.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace EVAP canister vent control valve.

9	CHECK EVAP CANISTER PURGE CONTROL VALVE
Refer to "Component Inspection", EC-427.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace EVAP canister purge control valve.

6	CHECK IF EVAP CANISTER IS SATURATED WITH WATER
<ol style="list-style-type: none"> 1. Remove EVAP canister with EVAP canister vent control valve attached. 2. Check if water drains from the EVAP canister. 	
	
Yes or No	
Yes	▶ GO TO 7.
No	▶ GO TO 9.

10	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE
Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Install hose properly or replace it.

11	CHECK HARNESS CONNECTOR
<ol style="list-style-type: none"> 1. Disconnect EVAP control system pressure sensor harness connector. 2. Check harness connector for water. Water should not exist. 	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Replace EVAP control system pressure sensor.

7	CHECK EVAP CANISTER
Weigh the EVAP canister with EVAP canister vent control valve attached. The weight should be less than 1.8 kg (4.0 lb).	
OK or NG	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

12	CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT
Perform "DTC Confirmation Procedure", EC-303.	
OK or NG	
OK	▶ GO TO 13.
NG	▶ Replace EVAP control system pressure sensor and repair or replace harness and connector.

8	DETECT MALFUNCTIONING PART
Check the following. <ol style="list-style-type: none"> 1. Visually check the EVAP canister for damage. 2. Check hose connection between EVAP canister and water separator for clogging and poor connection. 3. Check water separator. Refer to "Component Inspection", EC-401. 	
	▶ Repair hose or replace EVAP canister or water separator.

13	CHECK EVAPORATIVE EMISSION LINE
Check EVAP purge line hoses for leak or clogging. Refer to "EVAPORATIVE EMISSION LINE DRAWING", EC-31.	
OK or NG	
OK	▶ GO TO 14.
NG	▶ Repair EVAP purge line hoses.

14	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
	▶ INSPECTION END

DTC P1493 EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL VALVE/SOLENOID VALVE




Component Inspection

■ ACTIVE TEST ■ ☐

PURG CONT S/V (PURG CONT VAC)	○ N	VC ON
----- MONITOR -----		
PURG CONT S/V	ON	
CMPS•RPM(REF)	2000rpm	
CLSD THL/P SW	OFF	
COOLANT TEMP/S	84°C	

ON
ON/OFF
OFF

SEF516T



Component Inspection

EVAP CANISTER PURGE CONTROL SOLENOID VALVE NCEC0417 NCEC0417S01

Ⓟ With CONSULT

1. Lift up driving wheels (M/T models only).
2. Turn ignition switch "ON".
3. Select "PURG CONT S/V" of "ACTIVE TEST" mode with CONSULT.
4. Start engine and warm it up to normal operating temperature.
5. Disconnect vacuum hose at EVAP canister purge control valve.
6. Touch "ON" and "OFF" and check for vacuum passing through the hose.

Condition	Vacuum
Idle	Not exist
2,200 rpm (A/T models) 2,000 rpm with 1st gear position (M/T models)	Exist

ⓧ Without CONSULT

Check air passage continuity.

Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG or operation takes more than 1 second, replace solenoid valve.

EVAP CANISTER PURGE CONTROL VALVE NCEC0417S02

Check EVAP canister purge control valve as follows:

1. Blow air in port A and B, then ensure that there is no leakage.
2. Plug port B and blow air in port C and check that air flows freely from port D.
3. Plug port D and blow air in port C, check that there is no leakage.
4. Apply vacuum to port A. [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg)] Plug port D and blow air in port C and ensure free flow out of port B.

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

System Description

System Description

NCEC0418

The malfunction information related to A/T (Automatic Transaxle) is transferred through the line (circuit) from TCM (Transmission Control Module) to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in TCM (Transmission Control Module) but also ECM after the A/T related repair.

ECM Terminals and Reference Value

NCEC0419


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
7	PU	A/T check signal	[Ignition switch "ON"] [Engine is running]	5 - 7V

On Board Diagnosis Logic

NCEC0420

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1605 0804	<ul style="list-style-type: none"> An incorrect signal from TCM (Transmission Control Module) is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors [The communication line circuit between ECM and TCM (Transmission Control Module) is open or shorted.] Dead (Weak) battery TCM (Transmission Control Module)



DTC Confirmation Procedure

NCEC0421

NOTE:

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

⑨ With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and let it idle for at least 40 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-430.

Ⓢ With GST

- 1) Start engine and let it idle for at least 40 seconds.
- 2) Select "MODE 7" with GST.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-430.

Ⓢ No Tools

- 1) Start engine and let it idle for at least 40 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-430.

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

Wiring Diagram

Wiring Diagram

NCEC0422

EC-ATDIAG-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX





TEC550

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

Diagnostic Procedure

Diagnostic Procedure


NCEC0423

1	CHECK INPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and TCM harness connector.</p>	
 <p style="text-align: right;">SEF313W</p>	
<p>3. Check harness continuity between ECM terminal 7 and TCM terminal 15.</p>	
 <p style="text-align: right;">SEF266W</p>	
<p>Continuity should exist.</p>	
<p>4. Also check harness for short to ground and short to power.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

2	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

Component Description



Component Description

NCEC0424

When the gear position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON".
ECM detects the park/neutral position when continuity with ground exists.

CONSULT Reference Value in Data Monitor Mode

NCEC0425

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON Shift lever: "P" or "N"	ON
	Except above	OFF

ECM Terminals and Reference Value

NCEC0426


Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22	G/OR	PNP switch	[Ignition switch "ON"] ● Gear position is "Neutral position" (M/T models) ● Gear position is "N" or "P" (A/T models)	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0427

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1706 1003	● The signal of the PNP switch is not changed in the process of engine starting and driving.	● Harness or connectors (The PNP switch circuit is open or shorted.) ● PNP switch



DTC Confirmation Procedure

NCEC0428

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓢ With CONSULT

- 1) Turn ignition switch "ON".

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

DTC Confirmation Procedure (Cont'd)

5

☆ MONITOR ☆ NO FAIL

CMPS-RPM(REF)	2300rpm
COOLAN TEMP/S	85°C
VHCL SPEED SE	80km/h
P/N POSI SW	OFF
B/FUEL SCHDL	2.1msec

RECORD

SEF726W

- 2) Perform "PARK/NEUT POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.
 Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT. Then check the "P/N POSI SW" signal under the following conditions.


Position (Selector lever)	Known good signal
"N" and "P" (A/T only) position	ON
Except the above position	OFF

If NG, go to "Diagnostic Procedure", EC-434.
 If OK, go to following step.

- 3) Select "DATA MONITOR" mode with CONSULT.
 4) Start engine and warm it up to normal operating temperature.
 5) Maintain the following conditions for at least 50 consecutive seconds.

CMPS-RPM (REF)	2,100 - 3,000 rpm (M/T) 1,800 - 2,600 rpm (A/T)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	0.9 - 3.7 msec (M/T) 1 - 4 msec (A/T)
VHCL SPEED SE	70 - 100 km/h (43 - 62 MPH)
Selector lever	Suitable position

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-434.



Overall Function Check

NCEC0429

Use this procedure to check the overall function of the park/neutral position switch circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ Without CONSULT

- 1) Turn ignition switch "ON".
 2) Check voltage between ECM terminal 22 (PNP switch signal) and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known good data)
"P" (A/T only) and "N" position	Approx. 0
Except the above position	BATTERY VOLTAGE (11 - 14V)

- 3) If NG, go to "Diagnostic Procedure", EC-434.




DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

Wiring Diagram

Wiring Diagram

NCEC0430

EC-PNP/SW-01



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX



TEC551

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH


Diagnostic Procedure For M/T Models

Diagnostic Procedure For M/T Models

NCEC0431

1	CHECK GROUND CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect PNP switch harness connector.</p>	
 <p>PNP switch harness connector</p>	
SEF740W	
<p>3. Check harness continuity between terminal 2 and body ground.</p>	
	
SEF267W	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E101, E33 • Harness for open or short between PNP switch and body ground 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK INPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 22 and terminal 1.</p>	
	
SEF268W	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors F6, E123 • Harness for open or short between ECM and PNP switch 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK PNP SWITCH
<p>Refer to MT section.</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace PNP switch.

6	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure For A/T Models

Diagnostic Procedure For A/T Models

-NCEC0432

1	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect PNP switch harness connector. Check continuity between terminal 2 and ground with CONSULT or tester. 	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: right;">SEF269W</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors E101, E33 Harness for open or short between PNP switch and body ground 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Disconnect ECM harness connector. Check harness continuity between ECM terminal 22 and terminals 1. 	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: right;">SEF270W</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F6, E123 Harness for open or short between PNP switch and ECM 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK PNP SWITCH
Refer to AT section.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace PNP switch.

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶ INSPECTION END	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

System Description

System Description

NCEC0433

COOLING FAN CONTROL


NCEC0433S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	ECM	Cooling fan relay(s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal		
Ignition switch	Start signal		

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

OPERATION

NCEC0433S02



CONSULT Reference Value in Data Monitor Mode

NCEC0496

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
COOLING FAN	● After warming up engine, idle the engine. ● Air conditioner switch: OFF	Engine coolant temperature is 94°C (201°F) or less	OFF
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F)	LOW
		Engine coolant temperature is 105°C (221°F) or more	HIGH

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NCEC0487

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	LG	Cooling fan relay (High)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Cooling fan (High) is operating	0 - 0.6V
14	L/Y	Cooling fan relay (Low)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Cooling fan (Low) is operating	0.06V
21	L/W	Air conditioner switch	[Engine is running] ● Both air conditioner switch and blower switch are "ON" (Compressor operates)	Approximately 0V
			[Engine is running] ● Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

NCEC0488

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
0208	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", EC-448.</p>





CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Overall Function Check



Overall Function Check

NCEC0489

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

Ⓟ With CONSULT

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-440.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-440.
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.
- 5) If the results are NG, go to "Diagnostic Procedure", EC-440.

ⓧ Without CONSULT

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-440.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-440.
- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that cooling fan operates at low speed.
If NG, go to "Diagnostic Procedure", EC-440.
If OK, go to the following step.
- 9) Turn ignition switch "OFF".
- 10) Turn air conditioner switch and blower fan switch "OFF".
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.
- 14) If NG, go to "Diagnostic Procedure", EC-440.



TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Wiring Diagram



Wiring Diagram

NCEC0490

EC-COOL/F-01



Refer to last page (Foldout page).



TEC552


TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure

Diagnostic Procedure

NCEC0491

1	INSPECTION START	
Do you have CONSULT?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 4.



2	CHECK COOLING FAN LOW SPEED OPERATION	
<p>Ⓟ With CONSULT</p> <p>1. Disconnect cooling fan relays-2 and -3.</p>		
		
AEC707		
<p>2. Turn ignition switch "ON".</p> <p>3. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.</p>		
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ COOLING FAN CIRCUIT ■</p> <p style="text-align: center;">DOES</p> <p style="text-align: center;">COOLING FAN</p> <p style="text-align: center;">ROTATE AND STOP</p> <p style="text-align: center;">EVERY 3 SECONDS ?</p> <p style="text-align: center;"> <input type="button" value="NEXT"/> <input type="button" value="NO"/> <input type="button" value="YES"/> </p> </div>		
MEF311F		
<p>Ⓟ With CONSULT</p> <p>1. Disconnect cooling fan relays-2 and -3.</p> <p>2. Turn ignition switch "ON".</p> <p>3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.</p>		
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ ACTIVE TEST ■ <input type="checkbox"/></p> <p style="text-align: center;">COOLING FAN OFF</p> <p style="text-align: center;">=== MONITOR ===</p> <p style="text-align: center;">COOLAN TEMP/S 88°C</p> <p style="text-align: center;"> <input type="button" value="HI"/> <input type="button" value="LOW"/> <input checked="" type="button" value="OFF"/> </p> </div>		
MEF313F		
<p>4. Make sure that cooling fans-1 and -2 operate at low speed.</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-444.)

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


3	CHECK COOLING FAN HIGH SPEED OPERATION
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Reconnect cooling fan relays-2 and -3. Disconnect cooling fan relay-1. Turn ignition switch "ON". Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT. 	
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p>■ COOLING FAN CIRCUIT ■</p> <p>DOES</p> <p>COOLING FAN</p> <p>ROTATE AND STOP</p> <p>EVERY 3 SECONDS ?</p> <p style="text-align: center;"> <input type="button" value="NEXT"/> <input type="button" value="NO"/> <input type="button" value="YES"/> </p> </div>	
MEF311F	
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Reconnect cooling fan relays-2 and -3. Disconnect cooling fan relay-1. Turn ignition switch "ON". Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT. 	
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p>■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>COOLING FAN OFF</p> <p>== == MONITOR == ==</p> <p>COOLAN TEMP/S 88°C</p> <p style="text-align: center;"> <input type="button" value="HI"/> <input type="button" value="LOW"/> <input checked="" type="button" value="OFF"/> </p> </div>	
MEF314F	
<p>6. Make sure that cooling fans-1 and -2 operate at higher speed than low speed.</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-446.)


4	CHECK COOLING FAN LOW SPEED OPERATION
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> Disconnect cooling fan relays-2 and -3. 	
 <p style="text-align: right;">AEC707</p>	
<ol style="list-style-type: none"> Start engine and let it idle. Set temperature lever at full cold position. Turn air conditioner switch "ON". Turn blower fan switch "ON". Make sure that cooling fans-1 and -2 operate at low speed. 	
 <p style="text-align: right;">SEC163BA</p>	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-444.)


TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

5	CHECK COOLING FAN HIGH SPEED OPERATION
<p> Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Reconnect cooling fan relays-2 and -3. Disconnect cooling fan relay-1. Turn air conditioner switch and blower fan switch "OFF". Disconnect engine coolant temperature sensor harness connector. Connect 150Ω resistor to engine coolant temperature sensor harness connector. Restart engine and make sure that cooling fans-1 and -2 operate at higher speed than low speed. 	
	
MEF613EA	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-446.)

6	CHECK COOLING SYSTEM FOR LEAK
<p>Apply pressure to the cooling system with a tester, and check if the pressure drops.</p> <p>Testing pressure: 157 kPa (1.6 kg/cm², 23 psi)</p> <p>CAUTION: Higher than the specified pressure may cause radiator damage.</p>	
	
SLC754A	
Pressure should not drop.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Check the following for leak <ul style="list-style-type: none"> • Hose • Radiator • Water pump Refer to LC section ("Water Pump").

7	CHECK RADIATOR CAP
Apply pressure to cap with a tester.	
	
SLC755A	
Radiator cap relief pressure: 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi)	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace radiator cap.

8	CHECK THERMOSTAT
<ol style="list-style-type: none"> Check valve seating condition at normal room temperatures. It should seat tightly. Check valve opening temperature and valve lift. 	
	
SLC343	
Valve opening temperature: 76.5°C (170°F) [standard]	
Valve lift: More than 8 mm/90°C (0.31 in/194°F)	
<ol style="list-style-type: none"> Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section ("Thermostat").	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace thermostat

9	CHECK ENGINE COOLANT TEMPERATURE SENSOR
Refer to "COMPONENT INSPECTION", EC-160.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace engine coolant temperature sensor.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

10	CHECK MAIN 12 CAUSES
If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-448.	
▶	INSPECTION END

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

PROCEDURE A

#NCEC0491S01

1	CHECK POWER SUPPLY
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect cooling fan relay-1. 3. Turn ignition switch "ON". 4. Check voltage between terminals 1, 3, 7 and ground with CONSULT or tester. 	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • 10A fuse • 40A fusible link • Harness for open or short between cooling fan relay-1 and fuse • Harness for open or short between cooling fan relay-1 and battery 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector. 	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Check harness continuity between relay-1 terminal 5 and motor-2 terminal 1, motor-2 terminal 4 and body ground. 	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 6. Also check harness for short to ground and short to power. 	
<p>OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

4	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 14 and relay-1 terminal 2.</p>	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors E75, M6 • Harness connectors M49, F23 • Harness for open or short between cooling fan relay-1 and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK COOLING FAN RELAY-1
<p>Refer to "Component Inspection", EC-449.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Replace cooling fan relay.

7	CHECK COOLING FAN MOTORS-1 AND -2
<p>Refer to "Component Inspection", EC-449.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ Replace cooling fan motors.

8	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶	INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

PROCEDURE B

=NCEC0491S02

1	CHECK POWER SUPPLY
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect cooling fan relays-2 and -3. 3. Turn ignition switch "ON". 4. Check voltage between cooling fan relays-2 and -3 terminals 1, 3 and ground with CONSULT or tester. 	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between cooling fan relays-2 and -3 and fuse ● Harness for open or short between cooling fan relays-2 and -3 and fusible link 	
▶ Repair harness or connectors.	

3	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector. 3. Check harness continuity between relay-2 terminal 5 and motor-1 terminal 2, relay-2 terminal 6 and motor-1 terminal 3, relay-2 terminal 7 and body ground. 	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 4. Also check harness for short to ground and short to power. 5. Check harness continuity between relay-3 terminal 5 and motor-2 terminal 2, relay-3 terminal 6 and motor-2 terminal 3, relay-3 terminal 7 and body ground. 	
<p>Continuity should exist.</p>	
<ol style="list-style-type: none"> 6. Also check harness for short to ground and short to power. 	
<p>OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

4	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 13 and cooling fan relay-2 terminal 2, cooling fan relay-3 terminal 2.</p>	
SEF733W	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E75, M6 ● Harness connectors M49, F23 ● Harness for open or short between cooling fan relays-2 and -3 and ECM 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK COOLING FAN RELAYS-2 AND -3
Refer to "Component Inspection", EC-449.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace cooling fan relays.

7	CHECK COOLING FAN MOTORS
Refer to "Component Inspection", EC-449.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace cooling fan motors.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Main 12 Causes of Overheating

Main 12 Causes of Overheating

NCEC0492

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section.
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See "System Check", "ENGINE COOLING SYSTEM" in LC section.
ON*2	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section.
ON*1	7	<ul style="list-style-type: none"> Cooling fan 	<ul style="list-style-type: none"> CONSULT 	Operating	See "TROUBLE DIAGNOSIS FOR OVERHEAT" (EC-436).
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—
ON*3	9	<ul style="list-style-type: none"> Coolant temperature gauge 	<ul style="list-style-type: none"> Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> Visual 	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
OFF*4	10	<ul style="list-style-type: none"> Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> Visual 	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section.
OFF	11	<ul style="list-style-type: none"> Cylinder head 	<ul style="list-style-type: none"> Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section.
	12	<ul style="list-style-type: none"> Cylinder block and pistons 	<ul style="list-style-type: none"> Visual 	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section.

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.


*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.

TROUBLE DIAGNOSIS FOR OVERHEAT (COOLING SYSTEM)

Component Inspection



Component Inspection

NCEC0493


COOLING FAN RELAYS-1, -2 AND -3

NCEC0493S01

Check continuity between terminals 3 and 5, 6 and 7.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.



COOLING FAN MOTORS-1 AND -2

NCEC0493S02

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Speed	Terminals	
		(+)	(-)
Cooling fan motor	Low	1	4
	High	1, 2	3, 4

Cooling fan motor should operate.

If NG, replace cooling fan motor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

INJECTOR

Component Description



Component Description

NCEC0435

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

CONSULT Reference Value in Data Monitor Mode

NCEC0436

MONITOR ITEM	CONDITION	SPECIFICATION
INJ PULSE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle	2.4 - 3.2 msec
	2,000 rpm	1.9 - 2.8 msec
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load Idle	1.0 - 1.6 msec
	2,000 rpm	0.7 - 1.3 msec

ECM Terminals and Reference Value

NCEC0437

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	R/B	Injector No. 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V) SEF011W
104	G/B	Injector No. 3		
107	Y/B	Injector No. 2		
109	L/B	Injector No. 4		
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V) SEF012W



INJECTOR

Wiring Diagram

Wiring Diagram


NCEC0434

EC-INJECT-01



Refer to last page (Foldout page).

M4





GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEC553

INJECTOR


Diagnostic Procedure

NCEC0438

1	CHECK OVERALL FUNCTION
<p>With CONSULT</p> <ol style="list-style-type: none"> Start engine. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT. 	
	
<p>3. Make sure that each circuit produces a momentary engine speed drop.</p>	
<p>Without CONSULT</p> <ol style="list-style-type: none"> Start engine. Listen to each injector operating sound. 	
	
<p>Clicking noise should be heard.</p> <p>OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ GO TO 2.


MEF354F

MEC703B

2	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Stop engine. Disconnect injector harness connector. Turn ignition switch "ON". Check voltage between terminal 1 and ground with CONSULT or tester. 	
	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

SEF271W

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> 10A fuse Harness connectors M62, F24 Harness connectors F13, F51 Harness for open or short between injector and fuse 	
<p>▶ Repair harness or connectors.</p>	

4	CHECK OUTPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between injector harness connector terminal 2 and ECM terminals 102, 104, 107, 109. 	
	
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

SEF272W

INJECTOR

Diagnostic Procedure (Cont'd)


5	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F51, F13 ● Harness for open or short between ECM and injector 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK INJECTOR	
Refer to "Component Inspection", EC-453.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Replace injector.

7	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	
INSPECTION END	

GI
MA
EM
LC
EC

FE
CL
MT



Component Inspection INJECTOR

NCEC0439
NCEC0439S01

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.
Resistance: 10 - 14Ω [at 25°C (77°F)]
 If NG, replace injector.

AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

START SIGNAL

CONSULT Reference Value in Data Monitor Mode

CONSULT Reference Value in Data Monitor Mode

NCEC0441

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF

ECM Terminals and Reference Value

NCEC0442

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
20	B/Y	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	9 - 12V



START SIGNAL

Wiring Diagram


Wiring Diagram

NCEC0440

EC-S/SIG-01 GI



Refer to last page (Foldout page).



MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEC554

START SIGNAL

Diagnostic Procedure

Diagnostic Procedure

=NCEC0443

1	INSPECTION START
Do you have CONSULT?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2	CHECK OVERALL FUNCTION
<p><input checked="" type="checkbox"/> With CONSULT</p> <p>1. Turn ignition switch "ON".</p> <p>2. Perform "START SIGNAL CKT" in "FUNCTION TEST" mode with CONSULT.</p>	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ START SIGNAL CKT ■</p> <p>1. CLOSE THROTTLE, SHIFT TO P OR N RANGE</p> <p>2. TOUCH START AND START ENGINE IMMEDIATELY.</p> </div>	
<div style="display: flex; justify-content: center; gap: 20px;"> NEXT START </div>	
SEF191L	

<p><input checked="" type="checkbox"/> With CONSULT</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT under the following conditions.</p>									
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>☆ MONITOR ☆ NO FAIL <input type="checkbox"/></p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>START SIGNAL</td> <td style="text-align: right;">OFF</td> </tr> <tr> <td>CLSD TH/P SW</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>AIR COND SIG</td> <td style="text-align: right;">OFF</td> </tr> <tr> <td>P/N POSI SW</td> <td style="text-align: right;">ON</td> </tr> </table> </div>		START SIGNAL	OFF	CLSD TH/P SW	ON	AIR COND SIG	OFF	P/N POSI SW	ON
START SIGNAL	OFF								
CLSD TH/P SW	ON								
AIR COND SIG	OFF								
P/N POSI SW	ON								
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">RECORD</div>									
SEF111P									
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Condition</td> <td style="width: 50%;">"START SIGNAL"</td> </tr> <tr> <td>IGN "ON"</td> <td style="text-align: right;">OFF</td> </tr> <tr> <td>IGN "START"</td> <td style="text-align: right;">ON</td> </tr> </table>		Condition	"START SIGNAL"	IGN "ON"	OFF	IGN "START"	ON		
Condition	"START SIGNAL"								
IGN "ON"	OFF								
IGN "START"	ON								
MTBL0140									
OK or NG									
OK	▶ INSPECTION END								
NG	▶ GO TO 4.								

3	CHECK OVERALL FUNCTION						
<p><input checked="" type="checkbox"/> Without CONSULT</p> <p>1. Turn ignition switch to "START".</p> <p>2. Check voltage between ECM terminal 20 and ground under the following conditions.</p>							
SEF109P							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Condition</td> <td style="width: 50%;">Voltage</td> </tr> <tr> <td>Ignition switch "START"</td> <td style="text-align: right;">Battery voltage</td> </tr> <tr> <td>Except above</td> <td style="text-align: right;">Approximately 0V</td> </tr> </table>		Condition	Voltage	Ignition switch "START"	Battery voltage	Except above	Approximately 0V
Condition	Voltage						
Ignition switch "START"	Battery voltage						
Except above	Approximately 0V						
MTBL0143							
OK or NG							
OK	▶ INSPECTION END						
NG	▶ GO TO 4.						

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M62, F24 ● 10A fuse ● Harness for open or short between ECM and ignition switch 	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
▶ INSPECTION END	

FUEL PUMP

System Description


System Description

NCEC0444

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	ECM	Fuel pump relay
Ignition switch	Start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops



Component Description

A turbine type design fuel pump is used in the fuel tank.

NCEC0501

CONSULT Reference Value in Data Monitor Mode

NCEC0445

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> Ignition switch is turned to ON (Operates for 5 seconds) Engine running and cranking When engine is stopped (stops in 1.0 seconds) 	ON
	<ul style="list-style-type: none"> Except as shown above 	OFF

ECM Terminals and Reference Value

NCEC0446

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
8	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "ON" [Engine is running]	0 - 1V
			[Ignition switch "ON"] <ul style="list-style-type: none"> More than 5 seconds after turning ignition switch "ON" 	BATTERY VOLTAGE (11 - 14V)



FUEL PUMP

Wiring Diagram

Wiring Diagram


NCEC0447



EC-F/PUMP-01





Diagnostic Procedure

NCEC048

1	CHECK OVERALL FUNCTION
<ol style="list-style-type: none"> Turn ignition switch "ON". Pinch fuel feed hose with fingers. 	
 <p style="text-align: right;">SEF325W</p>	
<p>Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ GO TO 2.

2	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect fuel pump relay. 	
 <p style="text-align: right;">SEF291W</p>	
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminals 1, 3 and ground with CONSULT or tester. 	
 <p style="text-align: right;">SEF479P</p>	
<p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> 15A fuse Harness for open or short between fuse and fuel pump relay 	
▶ Repair harness or connectors.	

4	CHECK POWER GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect fuel pump harness connector. 	
<p style="text-align: center;">Under rear seat cushion</p>  <p style="text-align: right;">SEF299W</p>	
<ol style="list-style-type: none"> Check harness continuity between terminal 2 and body ground, terminal 1 and fuel pump relay connector terminal 5. 	
 <p style="text-align: right;">AEC758</p>	
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FUEL PUMP

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> • Harness connectors M74, B102 • Harness for open or short between fuel pump and body ground • Harness for open or short between fuel pump and fuel pump relay 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.


6	CHECK OUTPUT SIGNAL CIRCUIT
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 8 and fuel pump relay connector terminal 2.	
Continuity should exist.	
3. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

7	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> • Harness connectors M49, F23 • Harness for open or short between ECM and fuel pump relay 	
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK FUEL PUMP RELAY
Refer to "Component Inspection", EC-460.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace fuel pump relay.

9	CHECK FUEL PUMP
Refer to "Component Inspection", EC-460.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace fuel pump.

10	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection FUEL PUMP RELAY


NCEC0449

NCEC0449S01

Check continuity between terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.



FUEL PUMP

NCEC0449S02


1. Disconnect fuel pump harness connector.
2. Check resistance between terminals 1 and 2.

Resistance: 0.2 - 5.0Ω [at 25°C (77°F)]

If NG, replace fuel pump.

POWER STEERING OIL PRESSURE SWITCH

Component Description



Component Description

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

CONSULT Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction) OFF
		The steering wheel is fully turned ON

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	SB	Power steering oil pressure switch	[Engine is running] <ul style="list-style-type: none"> Steering wheel is fully turned 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> Steering wheel is not turned 	Approximately 5V




POWER STEERING OIL PRESSURE SWITCH

Wiring Diagram

Wiring Diagram

NCEC0450

EC-PST/SW-01



TEC556

POWER STEERING OIL PRESSURE SWITCH

Diagnostic Procedure


Diagnostic Procedure


=NCEC0454

1	INSPECTION START
Do you have CONSULT?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2	CHECK OVERALL FUNCTION
<p>Ⓟ With CONSULT</p> <p>1. Turn ignition switch "ON".</p> <p>2. Perform "PW/ST SIGNAL CIRCUIT" in "FUNCTION TEST" mode with CONSULT.</p>	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">■ PW/ST SIGNAL CIRCUIT ■</p> <p style="text-align: center;">HOLD STEERING WHEEL IN A FULL LOCKED POSITION THEN TOUCH START</p> <p style="text-align: center;"> <input type="button" value="NEXT"/> <input type="button" value="START"/> </p> </div>	
MEF023E	

<p>Ⓟ With CONSULT</p> <p>1. Start engine.</p> <p>2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT under the following conditions.</p>					
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">☆ MONITOR ☆ NO FAIL <input type="checkbox"/></p> <p style="text-align: center;">PW/ST SIGNAL OFF</p> <p style="text-align: center; margin-top: 10px;"><input type="button" value="RECORD"/></p> </div>					
SEF591I					
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Steering is in neutral position</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>Steering is turned</td> <td style="text-align: center;">ON</td> </tr> </table>		Steering is in neutral position	OFF	Steering is turned	ON
Steering is in neutral position	OFF				
Steering is turned	ON				
MTBL0141					
OK or NG					
OK	▶ INSPECTION END				
NG	▶ GO TO 4.				

3	CHECK OVERALL FUNCTION						
<p>ⓧ Without CONSULT</p> <p>1. Start engine.</p> <p>2. Check voltage between ECM terminal 25 and ground under the following conditions.</p>							
							
SEF126P							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>When steering wheel is turned quickly</td> <td style="text-align: center;">Approximately 0V</td> </tr> <tr> <td>Except above</td> <td style="text-align: center;">Approximately 5V</td> </tr> </tbody> </table>		Condition	Voltage	When steering wheel is turned quickly	Approximately 0V	Except above	Approximately 5V
Condition	Voltage						
When steering wheel is turned quickly	Approximately 0V						
Except above	Approximately 5V						
MTBL0142							
OK or NG							
OK	▶ INSPECTION END						
NG	▶ GO TO 4.						

4	CHECK GROUND CIRCUIT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect power steering oil pressure switch harness connector.</p> <p>3. Check harness continuity between terminal 2 and engine ground.</p>	
	
AEC760	
Continuity should exist.	
4. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER STEERING OIL PRESSURE SWITCH


Diagnostic Procedure (Cont'd)

5	CHECK INPUT SIGNAL CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 25 and terminal 1. 	
AEC761	
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors F24, M62 • Harness for open or short between ECM and power steering oil pressure switch 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK POWER STEERING OIL PRESSURE SWITCH
Refer to "Component Inspection", EC-464.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace power steering oil pressure switch.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.	
▶	INSPECTION END



Component Inspection

POWER STEERING OIL PRESSURE SWITCH

NCEC0455

NCEC0455S01


1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals 1 and 2.

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

If NG, replace power steering oil pressure switch.

IACV-AIR REGULATOR

Description



Description

The idle air control valve (IACV)-air regulator provides an air bypass when the engine is cold for a fast idle during warm-up. A bimetal, heater and rotary shutter are built into the IACV-air regulator. When the bimetal temperature is low, the air bypass port opens. As the engine starts and electric current flows through a heater, the bimetal begins to turn the shutter to close the bypass port. The air passage remains closed until the engine stops and the bimetal temperature drops.

NCEC0457

GI

MA

EM

LC

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

NCEC0458

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
8	B/P	Fuel pump relay	[Ignition switch "ON"] • For 5 seconds after turning ignition switch "ON" [Engine is running]	0 - 1V
			[Ignition switch "ON"] • More than 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



IACV-AIR REGULATOR

Wiring Diagram

Wiring Diagram

NCEC0456

EC-AIRREG-01




Refer to last page (Foldout page).



(M6), (E75)
(M4)



TEC557

Diagnostic Procedure

1	CHECK CONTROL FUNCTION			
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Perform "FUEL PUMP CIRCUIT" in "FUNCTION TEST" mode with CONSULT. 				
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>■ FUEL PUMP CIRCUIT ■</p> <p>PINCH FUEL FEED HOSE WITH FINGERS IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?</p> <p style="text-align: center;">OR</p> <p>DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?</p> </div>				
<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px 10px;">NEXT</td> <td style="padding: 2px 10px;">NO</td> <td style="padding: 2px 10px;">YES</td> </tr> </table>		NEXT	NO	YES
NEXT	NO	YES		
MEF591B				
<p>Ⓟ With CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound. 				
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>■ ACTIVE TEST ■ <input type="checkbox"/></p> <p>FUEL PUMP RELAY ON</p> <p>=== MONITOR ===</p> <p>CMPS-RPM(REF) 0rpm</p> </div>				
<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="padding: 2px 10px;">ON</td> <td style="padding: 2px 10px;">ON/OFF</td> <td style="padding: 2px 10px;">OFF</td> </tr> </table>		ON	ON/OFF	OFF
ON	ON/OFF	OFF		
MEF309F				
<p>ⓧ Without CONSULT</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Pinch fuel feed hose with fingers. 				
 <p style="text-align: right;">Fuel filter Pinch</p> <p style="text-align: right;">SEF325W</p>				
<p>Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".</p>				
OK or NG				
OK	▶ GO TO 2.			
NG	▶ Check fuel pump control circuit. Refer to EC-457.			

2	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect IACV-air regulator harness connector. 	
 <p style="text-align: right;">IACV-air regulator harness connector ASCD actuator SEF328W</p>	
<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 2 and ground with CONSULT or tester. 	
 <p style="text-align: right;">SEF274W</p>	
<p>Battery voltage should exist for 5 seconds after ignition switch is turned "ON".</p>	
OK or NG	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M6, E75 • Harness connectors E36, E104 • Harness for open or short between IACV-air regulator and fuel pump relay 	
▶ Repair harness or connectors.	

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


IACV-AIR REGULATOR

Diagnostic Procedure (Cont'd)

4	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch "OFF". Check harness continuity between terminal 1 and body ground. 	
SEF275W	
<p style="text-align: center;">Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors E101, E33 Harness for open or short between IACV-air regulator and body ground. 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK IACV-AIR REGULATOR
Refer to "COMPONENT INSPECTION" below.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Replace IACV-air regulator.



Component Inspection IACV-AIR REGULATOR

NCEC0460

NCEC0460S01

Disconnect IACV-air regulator harness connector.


- Check IACV-air regulator resistance.

Resistance: Approximately 70 - 80 Ω [at 25°C (77°F)]

- Check IACV-air regulator for clogging.

IACV-FICD SOLENOID VALVE

Component Description



Component Description

When the air conditioner is on, the IAC valve-FICD solenoid valve supplies additional air to adjust to the increased load.

NCEC0462

GI
MA
EM
LC

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and 43 (ECM ground).

NCEC0463

EC

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	LW	Air conditioner relay	[Engine is running] ● Both A/C switch and blower switch are "ON"	0 - 0.6V
			[Engine is running] ● A/C switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
21	LW	Air conditioner switch	[Engine is running] ● Both air conditioner switch and blower switch are "ON" (Compressor operates)	Approximately 0V
			[Engine is running] ● Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
37	G	Ambient air temperature switch	[Engine is running] ● Idle speed ● Ambient air temperature is above 23.5°C (74°F) ● Air conditioner is operating	Approximately 0.15V
			[Engine is running] ● Idle speed ● Ambient air temperature is above 23.5°C (74°F) ● Air conditioner is not operating	Approximately 0V
			[Engine is running] ● Idle speed ● Ambient air temperature is below 20.5°C (69°F) ● Air conditioner is operating	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Idle speed ● Ambient air temperature is below 20.5°C (69°F) ● Air conditioner is not operating	Approximately 4.6V

FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX





IACV-FICD SOLENOID VALVE

Wiring Diagram

Wiring Diagram


NCEC0461

EC-FICD-01





TEC558

Diagnostic Procedure

1	CHECK OVERALL FUNCTION
<ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Check idle speed. M/T: 800±50 rpm A/T: 800±50 rpm (in "N" position) If NG, adjust idle speed. Turn air conditioner switch and blower fan switch "ON". Recheck idle speed. 	
	
<p>M/T: 850 rpm or more A/T: 850 rpm or more (in "N" position)</p> <p>OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ GO TO 2.

2	CHECK AIR CONDITIONER FUNCTION
<p>Check if air conditioner compressor functions normally.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Refer to "TROUBLE DIAGNOSES" in HA section.



3	CHECK POWER SUPPLY
<ol style="list-style-type: none"> Stop engine. Disconnect IACV-FICD solenoid valve harness connector. 	
	
<ol style="list-style-type: none"> Start engine, then turn air conditioner switch and blower fan switch "ON". Check voltage between terminal 2 and ground with CONSULT or tester. 	
	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK (With auto A/C)	▶ GO TO 5.
OK (With manual A/C)	▶ GO TO 10.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors E122, F5 Harness for open or short between IACV-FICD solenoid valve and harness connector E101 	
▶	Repair harness or connectors.


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

IACV-FICD SOLENOID VALVE

Diagnostic Procedure (Cont'd)

5	CHECK GROUND CIRCUIT	
<p>(Models with auto A/C)</p> <ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect A/C auto amp. harness connector. 		
		
SEF739W		
<ol style="list-style-type: none"> Check harness continuity between solenoid valve terminal 1 and amp. terminal 23. 		
		
SEF277W		
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	GO TO 6.

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors F24, M62 Diode M86 Harness for open or short between IACV-FICD solenoid valve and A/C auto amp. 	
<p style="text-align: right;">▶</p>	
<p>Repair open circuit or short to ground or short to power in harness or connectors.</p>	

7	CHECK INPUT SIGNAL CIRCUIT	
<ol style="list-style-type: none"> Disconnect ECM harness connectors. Check harness continuity between ECM terminal 37 and amp. terminal 23. 		
		
SEF278W		
<p>Continuity should exist.</p> <ol style="list-style-type: none"> Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

8	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> Harness connectors M49, F23 Harness for open or short between ECM and A/C auto amp. 	
<p style="text-align: right;">▶</p>	
<p>Repair open circuit or short to ground or short to power in harness or connectors.</p>	

9	CHECK A/C AUTO AMP.	
<p>Refer to "TROUBLE DIAGNOSES" in HA section.</p>		
OK or NG		
OK	▶	GO TO 15.
NG	▶	Replace A/C auto amp.

IACV-FICD SOLENOID VALVE

Diagnostic Procedure (Cont'd)

10	CHECK GROUND CIRCUIT						
(Models with manual A/C)							
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ambient air temperature switch harness connector. 3. Check harness continuity between solenoid valve terminal 1 and switch terminal 1, and switch terminal 2 and body ground. 							
<p>Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 12.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 11.</td> </tr> </table>		OK	▶	GO TO 12.	NG	▶	GO TO 11.
OK	▶	GO TO 12.					
NG	▶	GO TO 11.					

11	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors F24, M62 • Harness connectors M6, E75 • Diode M86 • Harness for open or short between IACV-FICD solenoid valve and ambient air temperature switch • Harness for open or short between ambient air temperature switch and body ground 	
<p>▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

12	CHECK INPUT SIGNAL CIRCUIT						
<ol style="list-style-type: none"> 1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 37 and switch terminal 1. 							
<p>Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 14.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>GO TO 13.</td> </tr> </table>		OK	▶	GO TO 14.	NG	▶	GO TO 13.
OK	▶	GO TO 14.					
NG	▶	GO TO 13.					

13	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> • Harness connectors M49, F23 • Harness for open or short between ECM and harness connector M6 	
<p>▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	

14	CHECK AMBIENT AIR TEMPERATURE SWITCH						
<p>Refer to "TROUBLE DIAGNOSES" in HA section.</p> <p style="text-align: center;">OK or NG</p> <table border="1"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 15.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Replace ambient air temperature switch.</td> </tr> </table>		OK	▶	GO TO 15.	NG	▶	Replace ambient air temperature switch.
OK	▶	GO TO 15.					
NG	▶	Replace ambient air temperature switch.					


15	CHECK IACV-FICD SOLENOID VALVE						
<p>Refer to "Component Inspection", EC-474.</p> <p style="text-align: center;">OK or NG</p> <table border="1"> <tr> <td>OK</td> <td>▶</td> <td>GO TO 16.</td> </tr> <tr> <td>NG</td> <td>▶</td> <td>Replace IACV-FICD solenoid valve.</td> </tr> </table>		OK	▶	GO TO 16.	NG	▶	Replace IACV-FICD solenoid valve.
OK	▶	GO TO 16.					
NG	▶	Replace IACV-FICD solenoid valve.					

16	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-110.</p>	
<p>▶ INSPECTION END</p>	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

IACV-FICD SOLENOID VALVE

Component Inspection




Component Inspection IACV-FICD SOLENOID VALVE

NCEC0465

NCEC0465S01

Disconnect IACV-FICD solenoid valve harness connector.

- Check for clicking sound when applying 12V direct current to terminals.
- Check plunger for seizing or sticking.
- Check for broken spring.




MIL & DATA LINK CONNECTORS

Wiring Diagram

Wiring Diagram


NCEC0466

EC-MIL/DL-01



— : Detectable line for DTC
 - - - : Non-detectable line for DTC

Refer to EL-POWER.



Refer to last page (Foldout page).

M2
M5

F26
W



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEC559

SERVICE DATA AND SPECIFICATIONS (SDS)

Fuel Pressure Regulator

Fuel Pressure Regulator

NCEC0467

Fuel pressure at idling kPa (kg/cm ² , psi)	Vacuum hose is connected	Approximately 235 (2.4, 34)
	Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Idle Speed and Ignition Timing

NCEC0468

Base idle speed*1 rpm	No-load*4 (in "P" or "N" position)	750±50
Target idle speed*2 rpm	No-load*4 (in "P" or "N" position)	800±50
Air conditioner: ON rpm	In "P" or "N" position	850 or more
Ignition timing*3	In "P" or "N" position	15°±2° BTDC
Throttle position sensor idle position V		0.2 - 0.8

*1: Throttle position sensor harness connector disconnected or using CONSULT "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electrical load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

NCEC0469

Primary voltage V	Battery voltage (11 - 14)
Primary resistance [at 25°C (77°F)] Ω	0.5 - 1.0
Secondary resistance [at 25°C (77°F)] kΩ	Approximately 25

Mass Air Flow Sensor

NCEC0470

Supply voltage V	Battery voltage (11 - 14)
Output voltage V	1.3 - 1.7*
Mass air flow (Using CONSULT or GST) g·m/sec	2.5 - 5.0 at idle* 7.1 - 12.5 at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and idling under no-load.

Engine Coolant Temperature Sensor

NCEC0471

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

EGR Temperature Sensor

NCEC0472

EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

Fuel Pump

NCEC0473

Resistance [at 25°C (77°F)] Ω	0.2 - 5.0
-------------------------------	-----------

SERVICE DATA AND SPECIFICATIONS (SDS)

IACV-AAC Valve

IACV-AAC Valve		<small>NCEC0474</small>
Resistance [at 25°C (77°F)] Ω		Approximately 10.0
Injector		<small>NCEC0475</small>
Resistance [at 25°C (77°F)] Ω		10 - 14
Resistor		<small>NCEC0476</small>
Resistance [at 25°C (77°F)] Ω		Approximately 2.2
Throttle Position Sensor		<small>NCEC0477</small>
Throttle valve conditions	Resistance [at 25°C (77°F)]	
Completely closed	Approximately 0.6 kΩ	
Partially open	0.6 - 4.0 kΩ	
Completely open	Approximately 4.0 kΩ	
Front Heated Oxygen Sensor Heater		<small>NCEC0478</small>
Resistance [at 25°C (77°F)] Ω		2.3 - 4.3
Calculated Load Value		<small>NCEC0479</small>
	Calculated load value % (Using CONSULT or GST)	
At idle	20.0 - 35.5	
At 2,500 rpm	17.0 - 30.0	
Intake Air Temperature Sensor		<small>NCEC0480</small>
Temperature °C (°F)	Resistance kΩ	
20 (68)	2.1 - 2.9	
80 (176)	0.27 - 0.38	
EVAP Canister Purge Volume Control Valve		<small>NCEC0481</small>
Resistance [at 20°C (68°F)] Ω		35 - 43
Rear Heated Oxygen Sensor Heater		<small>NCEC0483</small>
Resistance [at 25°C (77°F)] Ω		2.3 - 4.3
Crankshaft Position Sensor (OBD)		<small>NCEC0484</small>
Resistance [at 25°C (77°F)] Ω		166 - 204
Tank Fuel Temperature Sensor		<small>NCEC0485</small>
Temperature °C (°F)	Resistance kΩ	
20 (68)	2.3 - 2.7	
50 (122)	0.79 - 0.90	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX