

# STC

## SECTION

### STEERING CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

## CONTENTS

<b>EPS</b>		
<hr/>		
<b>PRECAUTIONS</b> .....	<b>3</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	
Precautions for Battery Service .....	3	
Service Notice or Precautions .....	3	
<b>SYSTEM DESCRIPTION</b> .....	<b>4</b>	
Components .....	4	
EPS System Function .....	4	
Fail-Safe Function .....	4	
FAIL-SAFE INPUT/CANCEL CONDITIONS .....	5	
<b>RAS</b>		
<hr/>		
<b>PRECAUTIONS</b> .....	<b>6</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	6	
Precautions for Battery Service .....	6	
Service Notice or Precautions .....	6	
<b>REAR ACTIVE STEER</b> .....	<b>7</b>	
Removal and Installation .....	7	
COMPONENTS .....	7	
REMOVAL .....	7	
INSTALLATION .....	7	
Disassembly and Assembly .....	8	
COMPONENTS .....	8	
DISASSEMBLY .....	8	
INSPECTION AFTER DISASSEMBLY .....	8	
ASSEMBLY .....	8	
Neutral Position Adjustment .....	8	
<b>SYSTEM DESCRIPTION</b> .....	<b>10</b>	
Components .....	10	
RAS Function .....	10	
Fail-Safe Function .....	11	
<b>TROUBLE DIAGNOSIS</b> .....	<b>12</b>	
How to Perform Trouble Diagnosis .....	12	
BASIC CONCEPT .....	12	
Component Parts Location .....	13	
Schematic .....	14	
Wiring Diagram—RAS— .....	15	
Control Unit Input/Output Signal Standard .....	21	
CIRCUIT TESTER REFERENCE VALUE .....	21	
STANDARD BY CONSULT-II .....	22	
CONSULT-II Function (RAS/HICAS) .....	23	
CONSULT-II MAIN FUNCTION .....	23	
CONSULT-II SETTING PROCEDURE .....	23	
Self-Diagnosis .....	23	
OPERATION PROCEDURE .....	23	
ERASE MEMORY .....	23	
DISPLAY ITEM LIST .....	23	
Data Monitor .....	25	
OPERATION PROCEDURE .....	25	
DISPLAY ITEM LIST .....	25	
Active Test .....	26	
OPERATION PROCEDURE .....	26	
Control Unit Part Number .....	26	
OPERATION PROCEDURE .....	26	
Diagnosis Procedure With Self-Diagnosis Function (Without CONSULT-II) .....	26	
DESCRIPTION .....	26	
SELF-DIAGNOSIS PROCEDURE .....	26	
SELF-DIAGNOSIS DISPLAY .....	26	
SELF-DIAGNOSIS DISPLAY ITEMS .....	26	
HOW TO ERASE SELF-DIAGNOSIS .....	27	
CAN Communication .....	27	
SYSTEM DESCRIPTION .....	27	
For Fast and Accurate Trouble Diagnosis .....	27	
Basic Inspection .....	27	
BASIC INSPECTION 1: POWER SUPPLY CIRCUIT TERMINAL LOOSENESS AND BATTERY..	27	
BASIC INSPECTION 2: RAS WARNING LAMP INSPECTION .....	27	
BASIC INSPECTION 3: RAS CONTROL UNIT POWER SUPPLY CIRCUIT AND GROUND CIRCUIT INSPECTION .....	27	
Trouble Diagnosis Chart .....	28	
SELF-DIAGNOSIS .....	28	
DIAGNOSIS CHART BY SYMPTOM .....	29	

STC

Inspection 1: RAS Control Unit Malfunction .....	30
Inspection 2: Motor Power Supply System .....	30
Inspection 3: RAS Motor Output Malfunction .....	32
Inspection 4: Vehicle Speed Signal .....	33
Inspection 5: Steering Angle Signal Malfunction ...	33
Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction .....	35
Inspection 7: VDC Malfunction .....	37
Inspection 8: Engine Speed Signal Malfunction ...	37
Inspection 9: CAN Communication System Mal- function .....	38
Inspection 10: Stop Lamp Switch Harness .....	39
Inspection 11: RAS Warning Lamp Harness .....	39
Diagnosis Chart by Symptom 1 .....	41
Diagnosis Chart by Symptom 2 .....	41
Check RAS Static/Dynamic Characteristics .....	43
Component Parts Inspection .....	44
RAS MOTOR RELAY .....	44
RAS MOTOR .....	44
REAR WHEEL STEERING ANGLE SENSOR ...	44

---

## TILT/TELESCOPIC

---

<b>PRECAUTIONS .....</b>	<b>45</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	45
Precautions for Battery Service .....	45
<b>TILT &amp; TELESCOPIC SYSTEM .....</b>	<b>46</b>
System Description .....	46
OPERATION .....	46
Component Parts and Harness Connector Location..	46
Schematic .....	47
Wiring Diagram—TILTEL— .....	48
Terminals and Reference Values for Automatic Drive Positioner Control Unit .....	51
Preliminary Check .....	52
POWER SUPPLY AND GROUND CIRCUIT INSPECTION .....	52
Symptom 1: Telescopic System does not Operate...	53
Symptom 2: Tilt System does not Operate .....	55

## PRECAUTIONS

PF0:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NGS000AM

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions for Battery Service

NGS000AN

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

### Service Notice or Precautions

NGS000AO

The following abbreviations are used.

- EPS: Electronically controlled power steering
- RAS: Rear active steer

A  
B  
C  
D  
E  
F  
H  
I  
J  
K  
L  
M


STC

SYSTEM DESCRIPTION

PFP:00000

Components


NGS000A5



EPS System Function

NGS000A6


- Vehicle speed sensing electronically controlled power steering (that properly controls the steering force by the vehicle speed) has been adopted. When it is normal, it controls the power steering solenoid valve according to the vehicle speed as shown in the figure and makes the steering force proper.
- For schematic, wiring diagram and trouble diagnosis, refer to [STC-14, "Schematic"](#) , [STC-15, "Wiring Diagram—RAS—"](#) , [STC-41, "Diagnosis Chart by Symptom 2"](#) , because EPS is controlled by RAS control unit.



Fail-Safe Function

NGS000A7

When the fail-safe function operate, it controls power steering solenoid valve by the engine speed as shown in the figure and maintains the steering force.



# SYSTEM DESCRIPTION

[EPS]

## FAIL-SAFE INPUT/CANCEL CONDITIONS

Input conditions	Cancel conditions
When vehicle runs at an engine speed of 1,500 rpm or higher and no vehicle speed signal is received for 10 seconds.	● A vehicle speed of 2 km/h (1.2 MPH) or more is input.
The continuous vehicle speed signal 30 km/h (19 MPH) or more suddenly drops to less than 2 km/h (1.2 MPH) within 1.4 seconds.	● Turn the ignition switch ON after turning it OFF.

**CAUTION:**

Fail-safe function is activated when the engine runs at 1,500 rpm or higher for 10 seconds with the vehicle stopped. This is normal and the fail-safe function is automatically deactivated when a vehicle speed signal of 2 km/h (1.2 MPH) or higher is input or the ignition switch is turned OFF.

A  
B  
C  
D  
E  
F  
H  
I  
J  
K  
L  
M

STC

---

**PRECAUTIONS**

PFP:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

NGS000AY

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions for Battery Service**

NGS000AZ

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

**Service Notice or Precautions**


NGS000B0

The following abbreviations are used.

RAS: Rear active steer

## REAR ACTIVE STEER

### Removal and Installation COMPONENTS




1. Rear lower link
2. Decenter cam
3. RAS actuator assembly

Refer to [GI-10, "Components"](#), for the symbol in the figure.

### REMOVAL


1. Remove coil spring. Refer to [RSU-15, "Removal and Installation"](#).
2. Disconnect harness connector from RAS actuator assembly and rear suspension member.
3. Remove fixing bolts and nuts of RAS actuator assembly (1), and then remove RAS actuator assembly (1) from rear suspension member.



### INSTALLATION

- Installation is the reverse order of removal. For tightening torque, refer to [STC-7, "COMPONENTS"](#).
- When installing RAS actuator assembly to rear suspension member, check the mounting surfaces of RAS actuator assembly and rear suspension member for oil, dirt, sand, or other foreign materials.
- To perform the neutral position adjustment. Refer to [STC-8, "Neutral Position Adjustment"](#).

## Disassembly and Assembly COMPONENTS



- |                    |                                     |           |
|--------------------|-------------------------------------|-----------|
| 1. Ground terminal | 2. RAS motor assembly               | 3. O-ring |
| 4. RAS actuator    | 5. Rear wheel steering angle sensor |           |

Refer to [GI-10. "Components"](#) , for the symbols in the figure.

### DISASSEMBLY

1. Remove mounting bolts of RAS motor assembly, and then remove RAS motor assembly, ground terminal, O-ring from RAS actuator.
2. Remove mounting bolt of rear wheel steering angle sensor, and then remove rear wheel steering angle sensor, O-ring from RAS actuator.

### INSPECTION AFTER DISASSEMBLY

Check RAS actuator bracket (rear wheel steering angle sensor mounting area) for crush, deformation, cracks, or other damage. Replace the RAS actuator malfunction is detected.

### ASSEMBLY

- Assembly is the reverse order of disassembly. For tightening torque, refer to [STC-8. "COMPONENTS"](#) .
- After assembling RAS actuator assembly (after removing and installing rear wheel angle sensor and RAS motor), perform the neutral position adjustment.

### Neutral Position Adjustment

Adjust neutral position after performing the following procedure.

- Removing and installing or replacing the RAS actuator assembly
- Disassembling the RAS actuator assembly (when removing rear wheel steering angle sensor and RAS motor)

#### CAUTION:

**Perform the neutral position adjustment after installing the RAS actuator assembly to the vehicle. Before that, remove the rear lower link from the RAS actuator.**

1. Disconnect harness connector and remove rear wheel steering angle sensor from the RAS actuator assembly.
2. Disconnect RAS motor harness connector.
3. Turn ignition switch ON.



# REAR ACTIVE STEER

[RAS]

- Supply 6 V voltage by connecting the four 1.5 V batteries in a series. Connect them to the RAS motor connector (motor side), and then operate the motor and adjust the rack in the neutral position (A).

**Full stroke (B) : 6.8 - 7.2 mm (0.268 - 0.283 in)**


**CAUTION:**

**Do not supply 12 V voltage (battery, etc) to the RAS motor.**

**NOTE:**

For right stroke, connect positive probe to the RAS motor connector terminal 1. For left stroke, connect it to the terminal 2.

- Install rear wheel steering angle sensor with O-ring to the RAS actuator assembly. Temporarily tighten the mounting bolts in the specified torque that the sensor can be moved by hand.
- Turn and adjust the rear wheel steering angle sensor so as to make each sensor signal of "DATA MONITOR" mode to the following standard with CONSULT-II.



STEERING ANG (°)	L - 0, R - 0, N - 0
RR ST ANG-MAI (V)	Approx. 2.4
RR ST ANG-SUB (V)	Approx. 2.4
RR ST ANG-VOL (V)	Approx. 5.0

**CAUTION:**

**During DATA MONITOR mode, "MONITORING ERROR" is displayed. But there is not malfunction in this procedure.**


- Tighten rear wheel steering angle sensor mounting bolts.
- Perform "ERASE" with CONSULT-II, and then erase the error memory of rear wheel steering angle sensor. Refer to [STC-23. "ERASE MEMORY"](#) .
- Perform CONSULT-II "SELF-DIAG RESULTS" again, and then make sure that there is no malfunction. Refer to [STC-23. "Self-Diagnosis"](#) .

SYSTEM DESCRIPTION

PFP:00000

Components

NGS00097



SGIA1241E

- A. RAS control unit
- B. Model following control
- C. Target vehicle dynamics model
- D. Rear wheel steering angle command value operation
- E. Rear wheel steering angle servo
- F. Vehicle speed signal (CAN)
- G. Steering angle signal (CAN)
- H. Vehicle speed sensor
- I. Steering angle sensor
- J. RAS actuator assembly

RAS Function

NGS00098

Part name	Function
RAS control unit	<ul style="list-style-type: none"> <li>● Calculate the vehicle speed signal from CAN communication and the signals from steering angle sensor and rear wheel steering angle sensor by a computer, and then control the rear wheel steering angle.</li> <li>● Fail-safe function is activated when the electrical system is malfunctioning. The output signal to the actuator is turned OFF during this mode. At that time, the RAS warning lamp illuminates and indicates the system is malfunctioning.</li> <li>● It performs the communication control function with other control units via CAN communication.</li> <li>● This enables system diagnosis with CONSULT-II.</li> </ul>
RAS actuator	The efficiency of the rear wheel steer improves by locating the electric motor actuator into the lower link of rear suspension.
Steering angle sensor	<ul style="list-style-type: none"> <li>● Measure the steering angle and send it to RAS control unit via CAN communication.</li> <li>● It is shared with the steering angle sensor for VDC.</li> </ul>
Rear wheel steering angle sensor	<ul style="list-style-type: none"> <li>● It sends the rear wheel steering angle status to RAS control unit. The accuracy of rear wheel steer improves by comparing the vehicle speed signal from CAN communication with the rear wheel steering angle target value calculated from the wheel angle sensor signal, and it controls them.</li> <li>● There are 2 types of rear wheel steering angle sensors (main/sub). If one of them is malfunctioning, the other operates the fail-safe mode and stops the control.</li> </ul>
RAS warning lamp	<ul style="list-style-type: none"> <li>● It turns on when the fail-safe function is operated and indicates that a RAS control malfunction has occurred.</li> <li>● It turns on when ignition switch turns on and turns off after the engine is started.</li> <li>● It indicates the suspect system by blinking when performing the self-diagnosis (without CONSULT-II).</li> </ul>

**Fail-Safe Function**

NGS00099

In the event there is a malfunction with the electrical system, the RAS control is stopped and the fail-safe mode is activated. At that time, it indicates the malfunction by turning the RAS warning lamp ON and stops the rear wheel control.

- A
- B
- C
- D
- E
- F
- STC
- H
- I
- J
- K
- L
- M


## TROUBLE DIAGNOSIS

### How to Perform Trouble Diagnosis BASIC CONCEPT

- The most important point to perform trouble diagnosis is to understand systems (control and mechanism) in vehicle thoroughly.
- It is also important to clarify customer complaints before inspection.  
First of all, reproduce symptom, and understand it fully.  
Ask customer about his/her complaints carefully. In some cases, they will be necessary to check symptom by driving vehicle with customer.


**CAUTION:**

**Customers are not professionals. Do not assume “maybe customer means...” or “maybe customer mentioned this symptom”.**



EFJ0028D

- It is essential to check symptoms right from beginning in order to repair a malfunction completely.  
For an intermittent malfunction, it is important to reproduce symptom based on interview with customer and past examples. Do not perform inspection on ad hoc basis. Most intermittent malfunctions are caused by poor contacts. In this case, it will be effective to shake suspected harness or connector by hand. When repairs are performed without any symptom check, no one can judge if malfunction has actually been eliminated.
- After diagnosis, make sure to perform “ERASE MEMORY”. Refer to [STC-23, "ERASE MEMORY"](#).
- Always read “GI General Information” to confirm general precautions. Refer to [GI-9, "HOW TO USE THIS MANUAL"](#).




SEF233G

Component Parts Location


NGS0009B

A  
B  
C  
D  
E  
F  
STC  
H  
I  
J  
K  
L  
M



SGIA1513E

## Schematic








# TROUBLE DIAGNOSIS

[RAS]

NGS0009D

## Wiring Diagram—RAS—


STC-RAS-01



REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)



TGWM0055E



1	2	3	4	5	6	7	8	9	10	21	22	23	24	25	26	27	28	37	38	39	40
11	12	13	14	15	16	17	18	19	20	29	30	31	32	33	34	35	36				



REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)






# TROUBLE DIAGNOSIS




[RAS]

STC-RAS-03



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




STC



REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (E101) -FUSE BLOCK-JUNCTION  
 BOX (J/B)

TGWM0057E

STC-RAS-04




REFER TO THE FOLLOWING.  
 F102, B1 -SUPER  
 MULTIPLE JUNCTION (SMJ)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.



# TROUBLE DIAGNOSIS

[RAS]

STC-RAS-05




A  
B  
C  
D  
E  
F  
STC  
H  
I  
J  
K  
L  
M




REFER TO THE FOLLOWING.  
M93 -ELECTRICAL UNITS

TGWM0059E

STC-RAS-06



1	2	3	4	5	6	7	8	9	10	21	22	23	24	25	26	27	28	37	38	39	40
11	12	13	14	15	16	17	18	19	20	29	30	31	32	33	34	35	36				



REFER TO THE FOLLOWING.  
 (F102), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (F108) -ELECTRICAL UNITS

# TROUBLE DIAGNOSIS

[RAS]

NGS0009E

## Control Unit Input/Output Signal Standard CIRCUIT TESTER REFERENCE VALUE

**CAUTION:**

When checked using a circuit tester for voltage measurement, connector terminals should not be forcefully extended.

Terminal		Measuring point	Measuring condition	Standard	
+	-				
(wire color)	—				
1 (L)	—	CAN-H	—		
4 (G)	Ground	RAS MAIN OUTPUT	Neutral	Approx. 2.4 V	
5 (W)		RAS SENS POWER	Ignition switch ON	Approx. 5 V	
			Ignition switch OFF	Approx. 0 V	
7 (R)		RR SUB OUTPUT	Neutral	Approx. 2.4 V	
8 (P)	—	CAN-L	—		
15 (B/W)	Ground	RAS SENS GND	—	Continuity exit	
22 (P/L)		BRAKE	Brake pedal depressed		Battery voltage (Approx. 12 V)
			Brake pedal not depressed		Approx. 0 V
25 (L/W)		RAS RLY OUTPUT	Ignition switch ON		Battery voltage (Approx. 12 V)
			Ignition switch OFF		Approx. 0 V
26 (G/W)		W/L	ON		Approx. 1.4 V or less
			OFF		Ignition voltage: 2.8 V or more
27 (G/R)		IGN	Ignition switch ON		Battery voltage (Approx. 12 V)
			Ignition switch OFF		Approx. 0 V
34 (B)		GND	—		Continuity exit
36 (LG)		TOPS SOL	Normal (Vehicle speed)	0 km/h (0 MPH)	Approx. 4.4 - 6.6 V
				100 km/h (62 MPH)	Approx. 2.4 - 3.6 V
			In fail-safe mode (Engine speed)	0 - 1,500 rpm	Approx. 4.4 - 6.6 V
	1,500 - 3,000 rpm			Approx. 3.5 V	
	3,000 rpm or more			Approx. 2.1 V	
37 (L/Y)	RAS MOTOR POWER	Ignition switch ON		Battery voltage (Approx. 12 V)	
		Ignition switch OFF		Approx. 0 V	
38 (G/R)	MOTOR OUTPUT (RH)	—			
39 (G/Y)	MOTOR OUTPUT (LH)	—			
40 (B/W)	RAS MOTOR GND	—		Continuity exit	

A  
B  
C  
D  
E  
F  
STC  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

[RAS]

## STANDARD BY CONSULT-II

### CAUTION:

The output signal indicates the RAS control unit calculation data. The normal values will be displayed even in the event that the output circuit (harness) is open.

Monitor item	DATA MONITOR		Malfunction inspection checklist
	Condition	Reference values	
VHCL SPEED SE (km/h)	Ignition switch ON or engine running	Almost in accordance with the speedometer display. It is not a malfunction, through it might not be corresponding just after ignition switch is turned ON.	<a href="#">STC-33, "Inspection 4: Vehicle Speed Signal"</a>
STEERING ANG (°)	Turning steering wheel clockwise or counterclockwise.	Displays the angle when the steering wheel turns from the neutral position	<a href="#">STC-33, "Inspection 5: Steering Angle Signal Malfunction"</a>
ENGINE SPEED (rpm)	Engine running	Almost in accordance with tachometer display	<a href="#">STC-37, "Inspection 8: Engine Speed Signal Malfunction"</a>
POWER STR SOL (A)	Accelerate the vehicle from 0 to 100 km/h (0 to 62 MPH)	0 km/h (0 MPH): Approx. 1.10 A 100 km/h (62 MPH): Approx. 0.54 A	<a href="#">STC-41, "Diagnosis Chart by Symptom 2"</a>
RR ST ANG-MAI (V)	Perform the ACTIVE TEST and stroke the actuator (with tires off the ground)	Neutral: Approx. 2.4 V Turn steering wheel to right for full stroke: Approx. 4.4 V Turn steering wheel to left for full stroke: Approx. 0.4 V	<a href="#">STC-35, "Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction"</a>
RR ST ANG- SUB (V)			
RR ST ANG-VOL (V)	Ignition switch ON or engine running	Approx. 5 V	<a href="#">STC-35, "Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction"</a>
C/U VOLTAGE (V)		Battery voltage (Approx. 12 V)	<a href="#">STC-30, "Inspection 1: RAS Control Unit Malfunction"</a>
MOTOR VOLTAGE (V)		Battery voltage (Approx. 12V)	<a href="#">STC-30, "Inspection 2: Motor Power Supply System"</a>
MOTOR CURRENT (A)	Perform the ACTIVE TEST and stroke the actuator.	It is normal when there is the current output at stroke	<a href="#">STC-30, "Inspection 2: Motor Power Supply System"</a>
MTR CRNT OPE (A)	Turning steering wheel clockwise or counterclockwise while ignition switch is ON or running the engine	Neutral (Steering force is zero and straight-ahead position): Approx. 0 A The value is changed according to steering left or right	<a href="#">STC-32, "Inspection 3: RAS Motor Output Malfunction"</a>
RR ANGLE OPE (°)	Rear wheel steering angle detected by rear wheel steering angle sensor		Approx. 1°
			Approx. 0°
			Approx. - 1°
STOP LAMP SW	Depressing or releasing brake pedal	Brake pedal depressed: ON	<a href="#">STC-39, "Inspection 10: Stop Lamp Switch Harness"</a>
		Brake pedal not depressed: OFF	
HICAS RELAY	Ignition switch ON or engine running	Ignition switch ON: ON	<a href="#">STC-30, "Inspection 2: Motor Power Supply System"</a>
FAIL SAFE		Not activated	Self-diagnosis and suspect system inspection on DATA MONITOR
WARNING LAMP (ON/OFF)		RAS warning lamp ON: ON RAS warning lamp OFF: OFF	Warning lamp circuit inspection

## CONSULT-II Function (RAS/HICAS)

NGS0009F

### CONSULT-II MAIN FUNCTION

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Mode	Function	Reference
SELF-DIAG RESULTS	Receives self-diagnosis results from RAS control unit and indicates DTCs.	<a href="#">STC-23, "Self-Diagnosis"</a>
DATA MONITOR	Receives input/output signals from RAS control unit and indicates and stores them to facilitate locating cause of malfunctions.	<a href="#">STC-25, "Data Monitor"</a>
CAN DIAG SUPPORT MNTR	Monitors transmitting/receiving status of CAN communication.	<a href="#">STC-27, "CAN Communication"</a>
ACTIVE TEST	Sends command to RAS actuator to change output signals and check operation of output system.	<a href="#">STC-26, "Active Test"</a>
ECU PART NUMBER	Displays RAS control unit part number.	<a href="#">STC-26, "Control Unit Part Number"</a>

### CONSULT-II SETTING PROCEDURE

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### Self-Diagnosis OPERATION PROCEDURE

NGS0009G

1. Turn ignition switch OFF.
2. Perform "CONSULT-II Start Procedure". Refer to [GI-37, "CONSULT-II Start Procedure"](#) .
3. Touch "SELF-DIAG RESULTS".
4. The self-diagnostic results are displayed. (Touch "PRINT" to print out the self-diagnostic results if necessary.) Check RAS warning lamp if "NO FAILURE" is displayed.
5. Perform the appropriate inspection from the display item list, and repair or replace the malfunctioning component. Refer to [STC-23, "DISPLAY ITEM LIST"](#) .

### ERASE MEMORY

1. Turn ignition switch OFF.
2. Start engine, and touch "SELF-DIAG RESULTS" and "ERASE" in this order to erase the diagnostic memory.

**CAUTION:**

**If memory cannot be erased, perform applicably diagnosis.**

3. Perform self-diagnosis again, and make sure that DTC memory is erased.

### DISPLAY ITEM LIST

**CAUTION:**

**When malfunctions are detected in several systems, including the "CAN COMM CIRCUIT [U1000]" and "CONTROL UNIT (CAN) [U1010]", inspect the CAN communication system.**

DTC code	Diagnostic item	Diagnostic item is detected when...	Check items
C1923	STEERING ANGLE SEN [NO CHANGE]	While driving at 60 km/h (37 MPH) or more, steering angle does not change for a while.	Inspection 5 <a href="#">STC-33</a>
C1924	STEERING ANGLE SEN [NO NEUT STATE]	When driving some distance, no neutral signal (ON signal) is input.	Inspection 5 <a href="#">STC-33</a>
C1915	RR ST ANGLE SENSOR [MAIN SIGNAL]	The main sensor input signal is malfunctioning for some time against the sensor power supply value.	Inspection 6 <a href="#">STC-35</a>
C1916	RR ST ANGLE SENSOR [SUB SIGNAL]	When the main sensor input signal is 2.4 - 2.6 V, the sub sensor input signal is malfunctioning for some time compared to the sensor power supply value.	Inspection 6 <a href="#">STC-35</a>

# TROUBLE DIAGNOSIS

**[RAS]**

DTC code	Diagnostic item	Diagnostic item is detected when...	Check items
C1917, C1918	RR ST ANGLE SENSOR [OFFSET SIG1, 2]	An excessive difference has occurred in the input values of main sensor and sub sensor.	Inspection 6 <a href="#">STC-35</a>
C1914	RR ST ANGLE SENSOR [ABNORMAL VOL]	Higher or lower value compared to the standard voltage.	Inspection 6 <a href="#">STC-35</a>
C1921	MOTOR OUTPUT	No engine speed is input for a certain time.	Inspection 8 <a href="#">STC-37</a>
C1911	MOTOR VOLTAGE [LOW VOLTAGE]	The motor power supply voltage is lower than ignition power supply voltage with RAS motor relay ON.	Inspection 2 <a href="#">STC-30</a>
C1912	MOTOR VOLTAGE [BAD OBSTRCT]	The motor power supply voltage is inputting for some time with motor power supply OFF by RAS control unit.	Inspection 2 <a href="#">STC-30</a>
C1913	MOTOR OUTPUT [ABNORMAL SIG]	When the motor current value is 10A or more, actual output is excessively low and the condition continues for some time.	Inspection 3 <a href="#">STC-32</a>
C1902	MOTOR OUTPUT [REV CURRENT]	The current flows in the opposite direction when the motor current is output.	Inspection 3 <a href="#">STC-32</a>
C1903	MOTOR OUTPUT [NO CURRENT]	The current flows when the motor current is not output.	Inspection 3 <a href="#">STC-32</a>
C1904	MOTOR OUTPUT [OVER CURRENT]	The excessive high current flows when the motor current is output.	Inspection 3 <a href="#">STC-32</a>
C1910	MOTOR OUTPUT [MOTOR LOCK]	When 17 A or more current flows to the motor, the rear wheel steering angle sensor signal does not change for some time.	Inspection 3 <a href="#">STC-32</a>
C1919	VEHICLE SPEED SEN [NO SIGNAL]	No vehicle speed signal is input for some time.	Inspection 4 <a href="#">STC-33</a>
C1900	CONTROL UNIT [ABNORMAL1 - 9]	Control unit malfunction	Inspection 1 <a href="#">STC-30</a>
C1901			
C1905			
C1906			
C1907			
C1908			
C1909			
C1922			
C1928			
C1920	STEERING ANGLE SEN [NO SIGNAL]	No steering angle signal is input for some time.	Inspection 5 <a href="#">STC-33</a>
C1926	STEERING ANGLE SEN	<ul style="list-style-type: none"> <li>● An unexpected signal is input.</li> <li>● Steering angle sensor outputs the malfunction signal.</li> </ul>	Inspection 5 <a href="#">STC-33</a>
C1929	VDC	ABS actuator and electric unit (control unit) outputs the malfunction signal.	Inspection 7 <a href="#">STC-37</a>



# TROUBLE DIAGNOSIS

**[RAS]**

DTC code	Diagnostic item	Diagnostic item is detected when...	Check items
U1000	CAN COMM CIRCUIT	When RAS control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	Inspection 9 <a href="#">STC-38</a>
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of RAS control unit.	Inspection 9 <a href="#">STC-38</a>

## Data Monitor OPERATION PROCEDURE

NGS0009H

1. Touch "DATA MONITOR".
2. Return to the monitor item selection screen, and touch any of "ALL SIGNALS", "SELECTION FROM MENU".
3. Touch "START".
4. "DATA MONITOR" screen is displayed.

## DISPLAY ITEM LIST

Item (Display or Unit)	Remarks
VHCL SPEED SE (km/h)	Vehicle speed received via CAN communication is displayed.
STEERING ANG (°)	Steering angle received via CAN communication is displayed.
ENGINE SPEED (rpm)	Engine speed received via CAN communication is displayed.
POWER STR SOL (A)	Power steering solenoid controlling current that RAS control unit outputs is displayed.
RR ST ANG MAI (V)	Rear wheel steering angle main sensor output voltage is displayed.
RR ST ANG SUB (V)	Rear wheel angle sub sensor output voltage is displayed.
RR ST ANG VOL (V)	Voltage supplied from RAS control unit to rear wheel steering angle sensor is displayed.
C/U VOLTAGE (V)	Voltage supplied to RAS control unit is displayed.
MOTOR VOLTAGE (V)	Voltage supplied from RAS control unit to RAS motor is displayed.
MOTOR CURRENT (A)	RAS motor relay controlling current that RAS control unit outputs is displayed.
MOTOR CRNT OPE (A)	Current commanded value to RAS motor is displayed.
RR ANG OPE (°)	Angle commanded value to rear wheel steering angle sensor is displayed.
STOP LAMP SW (ON/OFF)	Condition of stop lamp switch ON/OFF is displayed.
HICAS RELAY (ON/OFF)	RAS motor relay ON/OFF condition is displayed.
FAILSAFE (ON/OFF)	Fail-safe ON/OFF condition is displayed.
WARNING LAMP (ON/OFF)	RAS warning lamp operating condition is displayed.

## Active Test

NGS0009I

### OPERATION PROCEDURE

1. Touch "ACTIVE TEST".
2. When turning the steering wheel right or left, the rear wheel turns in the same direction. If the steering wheel is not turned, the rear wheel turns left and right 5 times.

STEERING ANG	RR ST ANG MAI	RR ST ANG SUB	MOTOR CURRENT
0° (Neutral)	2.4 V	2.4 V	No output (Approx. 0 A)
R 90°	Approx. 4.4 V	Approx. 4.4 V	Output (change)
L 90°	Approx. 0.4 V	Approx. 0.4 V	

## Control Unit Part Number

NGS0009J

### OPERATION PROCEDURE

1. Touch "ECU PART NUMBER".
2. The part number described on RAS control unit sticker is displayed.

## Diagnosis Procedure With Self-Diagnosis Function (Without CONSULT-II)

NGS0009K

### DESCRIPTION

If a malfunction is detected in the system, the RAS warning lamp turns on and indicates the malfunction. At that time, fail-safe activates, and then stops the function.


### SELF-DIAGNOSIS PROCEDURE

1. Start engine.
2. Turn steering wheel left and right at 20° or more and 5 times or more within 10 seconds. And then depress the service brake 5 times or more.
3. RAS warning lamp blinks (displays normal/malfunction).

### SELF-DIAGNOSIS DISPLAY

RAS warning lamp blinks and displays the self-diagnostic results.

- Only DTCs are displayed as the pattern shown in the figure, and then repeat the display.
- If all items are normal, RAS warning lamp blinks at 4 Hz cycle.



### SELF-DIAGNOSIS DISPLAY ITEMS

DTC (warning lamp blinks)	Diagnosis item	Inspection item
11	RAS control unit	<a href="#">STC-30, "Inspection 1: RAS Control Unit Malfunction"</a>
12	Motor power supply	<a href="#">STC-30, "Inspection 2: Motor Power Supply System"</a>
13	Motor output	<a href="#">STC-32, "Inspection 3: RAS Motor Output Malfunction"</a>
21	Vehicle speed signal	<a href="#">STC-33, "Inspection 4: Vehicle Speed Signal"</a>
22	Steering angle signal	<a href="#">STC-33, "Inspection 5: Steering Angle Signal Malfunction"</a>
24	Rear wheel steering angle (main)	<a href="#">STC-35, "Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction"</a>
25	Rear wheel steering angle (sub)	<a href="#">STC-35, "Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction"</a>
26	VDC	<a href="#">STC-37, "Inspection 7: VDC Malfunction"</a>
33	Engine speed signal	<a href="#">STC-37, "Inspection 8: Engine Speed Signal Malfunction"</a>

**HOW TO ERASE SELF-DIAGNOSIS**

If there is the history data for when the fail-safe has activated in the past, erase the memory with CONSULT-II. Refer to [STC-23, "ERASE MEMORY"](#) .

**CAN Communication SYSTEM DESCRIPTION**

NGS0009L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. Refer to [LAN-47, "CAN System Specification Chart"](#) .

**For Fast and Accurate Trouble Diagnosis**

NGS0009M

Check the following items with the vehicle stopped

- Is air pressure and size of tires proper?
- Is the specified part used for the steering wheel?
- Is control unit a genuine part?
- Are there any fluid leakage from steering gear assembly, power steering oil pump, and hydraulic pipes, etc? Refer to [PS-7, "POWER STEERING FLUID"](#) .
- Is the fluid level proper? Refer to [PS-7, "POWER STEERING FLUID"](#) .
- Is the wheel alignment is adjusted properly? Refer to [PS-37, "SERVICE DATA AND SPECIFICATIONS \(SDS\)"](#) .
- Are there any damage or modification to suspension or body resulting in increased weight or altered ground clearance?
- Check each link installation condition of suspension and axle.
- Is the battery voltage proper?
- Check each connector connection condition.

Check the following items while driving the vehicle

- Conditions when the error occurred (5W 1H).
- Is the engine is normal?

**Basic Inspection**

NGS0009N

**BASIC INSPECTION 1: POWER SUPPLY CIRCUIT TERMINAL LOOSENESS AND BATTERY**

Check battery terminals for looseness on both positive and negative ones and ground connection. Also make sure that battery voltage does not drop.

**BASIC INSPECTION 2: RAS WARNING LAMP INSPECTION**

1. Make sure RAS warning lamp turns on when ignition switch is turned ON.
  - If it does not turn on, refer to [STC-28, "Trouble Diagnosis Chart"](#) .
2. Make sure that RAS warning lamp turns off when the engine is started after ignition switch is turned ON. If it does not turn off, perform self-diagnosis. Refer to [STC-23, "Self-Diagnosis"](#) .
3. Always erase DTC memory after completing self-diagnosis. Refer to [STC-23, "ERASE MEMORY"](#) .

**BASIC INSPECTION 3: RAS CONTROL UNIT POWER SUPPLY CIRCUIT AND GROUND CIRCUIT INSPECTION****1. CHECK RAS CONTROL UNIT CONNECTOR**

Turn ignition switch OFF, disconnect RAS control unit harness connector, and check terminal for deformation, disconnection, looseness, etc.

**OK or NG**

OK >> GO TO 2.

NG >> Poor connection of connector terminal. Repair or replace the terminal.


## 2. CHECK RAS CONTROL UNIT GROUND CIRCUIT

1. Disconnect RAS control unit harness connector.
2. Check continuity between RAS control unit harness connector and ground.

Connector	Terminal	Continuity
B136	34 – Ground	Yes

**OK or NG**

- OK >> GO TO 3.
- NG >> Ground circuit open or shorted. Repair or replace any inoperative parts.




## 3. CHECK RAS CONTROL UNIT POWER SUPPLY CIRCUIT

Turn ignition switch ON, and then check voltage between RAS control unit harness connector and ground.

Connector	Terminal	Voltage
B136	27 – Ground	Battery voltage (Approx. 12 V)

**OK or NG**

- OK >> Power supply and ground circuit are normal.
- NG >> Power supply circuit open or shorted. Repair or replace any inoperative parts.



## Trouble Diagnosis Chart SELF-DIAGNOSIS

NGS00090

Self-diagnosis function		CONSULT-II	Reference
DTC (warning lamp blinks)	Diagnosis item	Diagnosis item	
11	Control unit	CONTROL UNIT [ABNORMAL 1 - 9]	<a href="#">STC-30</a>
12	Motor power supply	MOTOR VOLTAGE [LOW VOLTAGE] MOTOR VOLTAGE [BAD OBSTRCT]	<a href="#">STC-30</a>
13	Motor output	MOTOR OUTPUT [ABNORMAL SIG] MOTOR OUTPUT [REV CURRENT] MOTOR OUTPUT [NO CURRENT] MOTOR OUTPUT [OVER CURRENT] MOTOR OUTPUT [MOTOR LOCK]	<a href="#">STC-32</a>
21	Vehicle speed signal	VEHICLE SPEED SEN [NO SIGNAL]	<a href="#">STC-33</a>
22	Steering angle signal	STEERING ANGLE SEN [NO CHANGE] STEERING ANGLE SEN [NO NEUT STATE] STEERING ANGLE SEN [NO SIGNAL] STEERING ANGLE SEN	<a href="#">STC-33</a>

# TROUBLE DIAGNOSIS

[RAS]

24	Rear wheel steering angle (main)	RR ST ANGLE SENSOR [MAIN SIGNAL]	<a href="#">STC-35</a>
		RR ST ANGLE SENSOR [ABNORMAL VOL]	
		RR ST ANGLE SENSOR [OFFSET SIG1, 2]	
25	Rear wheel steering angle (sub)	RR ST ANGLE SENSOR [SUB AIGNAL]	<a href="#">STC-37</a>
		RR ST ANGLE SENSOR [ABNORMAL VOL]	
		RR ST ANGLE SENSOR [OFFSET SIG1, 2]	
26	VDC	VDC	<a href="#">STC-37</a>
27	Engine speed signal	MOTOR OUTPUT	<a href="#">STC-37</a>
	—	CAN COMM CIRCUIT [U1000]	<a href="#">STC-38</a>
	—	CONTROL UNIT (CAN) [U1010]	

## DIAGNOSIS CHART BY SYMPTOM

Symptom	Reference
It is not entering the self-diagnosis mode.	<a href="#">STC-27, "BASIC INSPECTION 3: RAS CONTROL UNIT POWER SUPPLY CIRCUIT AND GROUND CIRCUIT INSPECTION"</a>
	<a href="#">STC-39, "Inspection 10: Stop Lamp Switch Harness"</a>
	<a href="#">STC-39, "Inspection 11: RAS Warning Lamp Harness"</a>
RAS warning lamp does not turn on with ignition switch ON.	<a href="#">STC-27, "BASIC INSPECTION 3: RAS CONTROL UNIT POWER SUPPLY CIRCUIT AND GROUND CIRCUIT INSPECTION"</a>
	<a href="#">STC-39, "Inspection 11: RAS Warning Lamp Harness"</a>
RAS warning lamp turns on with ignition switch ON. It does not turn off even if the engine is started.	<a href="#">STC-27, "Basic Inspection"</a>
	<ul style="list-style-type: none"> <li>● <a href="#">STC-23, "Self-Diagnosis"</a></li> <li>● <a href="#">STC-26, "Diagnosis Procedure With Self-Diagnosis Function (Without CONSULT-II)"</a></li> </ul>
RAS warning lamp may turn on after the engine is started.	<a href="#">STC-23, "Self-Diagnosis"</a>
The steering force does not change smoothly according to the vehicle speed.	<a href="#">STC-41, "Diagnosis Chart by Symptom 2"</a>
Noise	<ul style="list-style-type: none"> <li>● <a href="#">STC-23, "Self-Diagnosis"</a></li> <li>● <a href="#">STC-26, "Diagnosis Procedure With Self-Diagnosis Function (Without CONSULT-II)"</a></li> </ul>
	<a href="#">STC-8, "INSPECTION AFTER DISASSEMBLY"</a>
Malfunction other than above	<a href="#">STC-41, "Diagnosis Chart by Symptom 1"</a>

## Inspection 1: RAS Control Unit Malfunction

NGS0009P

### 1. CHECK SELF-DIAGNOSIS RESULTS

Check self-diagnosis results.

**With CONSULT-II**

Self-diagnostic results
CONTROL UNIT [ABNORMAL1 - 9]

**Without CONSULT-II**

DTC (warning lamp blinks)
11

Is above displayed on self-diagnosis display?

- YES >> Replace RAS control unit. Perform self-diagnosis again after replacing.
- NO >> INSPECTION END

## Inspection 2: Motor Power Supply System

NGS0009Q

### 1. CHECK RAS CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and motor connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

**With CONSULT-II**

Self-diagnosis results
MOTOR VOLTAGE [LOW VOLTAGE]
MOTOR VOLTAGE [BAD OBSTRCT]

**Without CONSULT-II**

DTC (warning lamp blinks)
12

Is above displayed on self-diagnosis display?

- YES >> GO TO 2.
- NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.


### 2. CHECK RAS MOTOR RELAY BATTERY CIRCUIT

1. Turn ignition switch OFF, and disconnect RAS motor relay harness connector.
2. Check voltage between RAS motor relay harness connector and ground.

Connector	Terminal	Voltage
B139	3 – Ground	Battery voltage (Approx. 12 V)

OK or NG

- OK >> GO TO 3.
- NG >> RAS motor relay power supply circuit open or shorted. Repair or replace power supply circuit and fuse.



### 3. CHECK RAS MOTOR RELAY HARNESS


1. Disconnect RAS motor relay harness connector and RAS control unit harness connector.
2. Check continuity between the following terminals.
  - RAS motor relay harness connector B139 terminal 5 and RAS control unit harness connector B136 terminal 37.
  - RAS motor relay harness connector B139 terminal 1 and RAS control unit harness connector B136 terminal 25.
  - RAS motor relay harness connector B139 terminal 2 and ground.

**Continuity should exist.**

OK or NG

OK >> GO TO 4.

NG >> RAS motor relay harness open or shorted. Repair or replace applicable malfunctioning harness.



### 4. CHECK RAS MOTOR RELAY RESISTANCE


Check the resistance between RAS motor relay connector.

Connector	Terminal	Resistance
B139	1 – 2	Approx. 74 Ω

OK or NG

OK >> GO TO 5.

NG >> RAS motor relay malfunction (replacement)



### 5. CHECK RAS CONTROL UNIT OUTPUT SIGNAL


1. Connect RAS control unit harness connector and RAS motor relay harness connector.
2. Check voltage between RAS motor relay harness connector and ground.

Connector	Terminal	Condition	Voltage
B139	1 – Ground	Ignition switch ON	Battery voltage (Approx. 12 V)
		Ignition switch OFF	Approx. 0 V

OK or NG

OK >> Check RAS motor relay separately from other parts. Refer to [STC-44, "RAS MOTOR RELAY"](#).

NG >> RAS control unit malfunction (replacement)



## Inspection 3: RAS Motor Output Malfunction

### 1. CHECK RAS CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and RAS motor harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

 **With CONSULT-II**

Self-diagnosis results
MOTOR OUTPUT [ABNORMAL SIG]
MOTOR OUTPUT [REV CURRENT]
MOTOR OUTPUT [NO CURRENT]
MOTOR OUTPUT [OVER CURRENT]
MOTOR OUTPUT [MOTOR LOCK]

 **Without CONSULT-II**

DTC (warning lamp blinks)
13

Is above displayed on self-diagnosis display?

YES >> GO TO 2.

NG >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

### 2. CHECK RAS MOTOR RESISTANCE


1. Turn ignition switch OFF, and disconnect RAS motor harness connector.
2. Check the resistance RAS motor connector.

Connector	Terminal	Resistance
B134	1 – 2	Approx. 0.6 Ω

OK or NG

OK >> GO TO 3.

NG >> RAS motor malfunction. Replace RAS motor.



### 3. CHECK RAS MOTOR HARNESS


1. Connect RAS motor harness connector.
2. Disconnect RAS control unit harness connector.
3. Check continuity RAS control unit harness connector.

Connector	Terminal	Continuity
B136	38 – 39	Yes

OK or NG

OK >> RAS control unit malfunction. Replace RAS control unit.

NG >> Harness between RAS motor and RAS control unit open or shorted. Repair or replace harness.





**Inspection 4: Vehicle Speed Signal**

NGS0009S

**1. CHECK VDC/TCS/ABS CONTROL UNIT**

Perform self-diagnosis with VDC/TCS/ABS control unit. Refer to [BRC-25, "DESCRIPTION"](#).

Is any malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.  
NO >> GO TO 2.

**2. CHECK RAS CONTROL UNIT CONNECTOR**

1. Turn ignition switch OFF, disconnect RAS control unit harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

**Ⓟ With CONSULT-II**

Self-diagnosis results
VEHICLE SPEED SEN [NO SIGNAL]

**ⓧ Without CONSULT-II**

DTC (warning lamp blinks)
21

Is above displayed on self-diagnosis display?

- YES >> RAS control unit malfunction. Replace RAS control unit.  
NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

**Inspection 5: Steering Angle Signal Malfunction**

NGS0009T

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and steering angle sensor harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

**Ⓟ With CONSULT-II**

Self-diagnosis results
STEERING ANGLE SEN [NO CHANGE]
STEERING ANGLE SEN [NO NEUT STATE]
STEERING ANGLE SEN [NO SIGNAL]
STEERING ANGLE SEN

**ⓧ Without CONSULT-II**

DTC (warning lamp blinks)
22

Is above displayed on self-diagnosis display?

- YES >> GO TO 2.  
NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

**2. ADJUST NEUTRAL POSITION OF STEERING ANGLE SENSOR**

Adjust the steering angle sensor neutral position, and then perform self-diagnosis again. Refer to [BRC-6, "Adjustment of Steering Angle Sensor Neutral Position"](#).


Is the result of self-diagnosis normal?

- OK >> Inappropriate neutral position adjustment of steering angle sensor.  
NG >> GO TO 3.

## 3. CHECK STEERING ANGLE SENSOR POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF, and disconnect steering angle sensor harness connector.
2. Check continuity steering angle sensor harness connector and ground.

Connector	Terminal	Continuity
M22	2 – Ground	Yes




3. Turn ignition switch ON, and then check voltage steering angle sensor harness connector and ground.

Connector	Terminal	Voltage
M22	3 – Ground	Battery voltage (Approx. 12 V)

**OK or NG**

OK >> GO TO 4.

NG >> Steering angle sensor power supply and ground circuit open or shorted. Repair or replace the applicable malfunctioning circuit.



## 4. DATA MONITOR

1. Connect steering angle sensor harness connector.
2. Select "DATA MONITOR" on "STEERING ANG" mode, and then check the steering angle.

Steering condition	DATA MONITOR
Straight-ahead position	– 3.5 - +3.5°
Turn wheel to the right by 90°	Approx. R 90°
Turn wheel to the left by 90°	Approx. R 90°

**OK or NG**

OK >> RAS control unit malfunction. Replace RAS control unit.

NG >> Replace steering angle sensor and adjust neutral position of steering angle sensor. Refer to [BRC-6, "Adjustment of Steering Angle Sensor Neutral Position"](#) .

## Inspection 6: Rear Main Signal and Rear Sub Signal Malfunction

NGS0009U

### 1. CHECK RAS CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and rear wheel steering angle sensor harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

**With CONSULT-II**

Self-diagnosis results
RR ST ANGLE SENSOR [MAIN SIGNAL]
RR ST ANGLE SENSOR [SUB SIGNAL]
RR ST ANGLE SENSOR [OFFSET SIG 1, 2]
RR ST ANGLE SENSOR [ABNORMAL VOL]

**Without CONSULT-II**

DTC (warning lamp blinks)
24
25

Is above displayed on self-diagnosis display?


YES >> GO TO 2.

NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

### 2. CHECK (1): REAR WHEEL STEERING ANGLE SENSOR POWER SUPPLY AND GROUND CIRCUIT


1. Turn ignition switch OFF, and disconnect rear wheel steering angle sensor harness connector.
2. Check continuity rear wheel steering angle sensor harness connector and ground.

Connector	Terminal	Continuity
B133	3 – Ground	Yes



3. Turn ignition switch ON, and then check voltage rear wheel steering angle sensor harness connector and ground.

Connector	Terminal	Voltage
B133	1 – Ground	Approx. 5 V



**OK or NG**


OK >> GO TO 4.

NG >> GO TO 3.

## 3. CHECK (2): REAR WHEEL STEERING ANGLE SENSOR POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF, disconnect rear wheel steering angle sensor harness connector and RAS control unit harness connector.
2. Check continuity between the following terminals.
  - Rear wheel steering angle sensor harness connector B133 terminal 1 and RAS control unit harness connector B136 terminal 5.
  - Rear wheel steering angle sensor harness connector B133 terminal 3 and RAS control unit harness connector B136 terminal 15.

**Continuity should exist.**




**OK or NG**

- OK >> RAS control unit malfunction. Replace RAS control unit.
- NG >> Harness between rear wheel steering angle sensor and RAS control unit open or shorted. Repair or replace harness.

## 4. CHECK REAR WHEEL STEERING ANGLE SENSOR OUTPUT SIGNAL

1. Connect rear wheel steering angle sensor harness connector B133.
2. Check voltage RAS control unit harness connector B136 when starting the engine and turning the steering wheel from neutral position clockwise/counterclockwise by 180°.



Steering condition	Rear wheel steering angle sensor	
	Rear main output Terminal 4 (+) - 15 (-)	Rear sub output Terminal 7 (+) - 15 (-)
Straight-ahead (neutral position)	Approx. 2.4 V	Approx. 2.4 V
Turn wheel to the right by 180°	Approx. 4.4 V	Approx. 4.4 V
Turn wheel to the left by 180°	Approx. 0.4 V	Approx. 0.4 V

**CAUTION:**

**There is approximately 1 V or more difference between main output and sub output at straight-ahead position, inspection results are "NG".**


**OK or NG**

- OK >> RAS control unit malfunction. Replace RAS control unit.
- NG >> GO TO 5.

**5. CHECK REAR WHEEL STEERING ANGLE SENSOR OUTPUT SIGNAL CIRCUIT**

1. Turn ignition switch OFF, disconnect rear wheel steering angle sensor harness connector and RAS control unit harness connector.
2. Check continuity between the following terminals.
  - Rear wheel steering angle sensor harness connector B133 terminal 2 and RAS control unit harness connector B136 terminal 7.
  - Rear wheel steering angle sensor harness connector B133 terminal 4 and RAS control unit harness connector B136 terminal 4.

**Continuity should exist.**



OK or NG

- OK >> Rear wheel steering angle sensor malfunction. Replace rear wheel steering angle sensor.
- NG >> Harness between rear wheel steering angle sensor and RAS control unit open or shorted. Repair or replace harness.

**Inspection 7: VDC Malfunction**

NGS0009V

**1. CHECK RAS CONTROL UNIT CONNECTOR**

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and rear wheel steering angle sensor harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

**With CONSULT-II**

Self-diagnosis results
VDC

**Without CONSULT-II**

DTC (warning lamp blinks)
26

Is above displayed on self-diagnosis display?

- YES >> GO TO 2.
- NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

**2. CHECK SELF-DIAGNOSTIC RESULTS**

Perform VDC self-diagnosis. Refer to [BRC-25, "Self-Diagnosis"](#) .

OK or NG

- OK >> RAS control unit malfunction. Replace RAS control unit.
- NG >> Repair or replace indicated part. After that, perform RAS self-diagnosis again to make sure that there is no malfunction.

**Inspection 8: Engine Speed Signal Malfunction**

NGS0009W

**1. CHECK SPEEDOMETER**

Start the engine, and then check the combination meter (tachometer) operation.

Does it operate normally?

- YES >> GO TO 2.
- NO >> Combination meter. Refer to [DI-4, "COMBINATION METERS"](#) .

## 2. CHECK RAS CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF, disconnect RAS control unit harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform self-diagnosis.

 **With CONSULT-II**

Self-diagnostic results
MOTOR OUTPUT

 **Without CONSULT-II**

DTC (warning lamp blinks)
27

Is above displayed on self-diagnosis display?

- YES >> RAS control unit malfunction. Replace RAS control unit.  
 NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

## Inspection 9: CAN Communication System Malfunction

NGS0009X

### 1. CHECK RAS CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and rear wheel steering angle sensor harness connector, and check terminal for deformation, disconnection, looseness, etc.
2. Reconnect harness connector securely, and perform CONSULT-II self-diagnosis.

Self-diagnostic results
CAN COMM CIRCUIT [U1000]
CONTROL UNIT (CAN) [U1010]

Is above displayed on self-diagnosis display?

- YES >> ● If “CAN COMM CIRCUIT [U1000]” is displayed, print out self-diagnosis. And then, GO TO [LAN-47, "CAN System Specification Chart"](#) .  
 ● Replace RAS control unit if “CONTROL UNIT (CAN) [U1010]” is displayed.  
 NO >> Connector terminal connection is loose, damaged, open, or shorted. Repair or replace the terminal.

## Inspection 10: Stop Lamp Switch Harness

### 1. CHECK STOP LAMP SWITCH SIGNAL

With CONSULT-II

Select "STOP LAMP SW" on DATA MONITOR, and then check the stop lamp switch.

Measuring condition	Data monitor
Brake pedal depressed	ON
Brake pedal released	OFF

Without CONSULT-II


1. Turn ignition switch OFF, disconnect RAS control unit harness connector.
2. Operate brake pedal, and then check voltage between RAS control unit harness connector and ground.

Connector	Terminal	Condition	Voltage
B136	22 – Ground	Brake pedal depressed	Battery voltage (Approx. 12 V)
		Brake pedal released	Approx. 0 V

OK or NG

OK >> Stop lamp switch harness is normal.

NG >> Stop lamp switch harness malfunction. Repair circuit.



## Inspection 11: RAS Warning Lamp Harness

### 1. CHECK RAS WARNING LAMP SIGNAL


Turn ignition switch ON, and then check voltage between RAS control unit harness connector and ground.

Connector	Terminal	Voltage
B136	26 – Ground	Warning lamp OFF : Approx. 2.8 V or more
		Warning lamp ON : Approx. 1.4 V or less

OK or NG

OK >> Perform self-diagnosis. Refer to [STC-23, "Self-Diagnosis"](#).


NG >> GO TO 2.



**2. CHECK RAS WARNING LAMP HARNESS**

1. Turn ignition switch OFF, disconnect RAS control unit harness connector and combination meter harness connector.
2. Check continuity between the following terminals.
  - RAS control unit harness connector B136 terminal 26 and combination meter harness connector M19 terminal 36.

**Continuity should exist.**




3. Check continuity between RAS control unit harness connector and ground.
  - RAS control unit harness connector B136 terminal 26 and ground.

**Continuity should exist.**

OK or NG

- OK >> GO TO combination meter power supply circuit.
- NG >> Harness between RAS control unit and combination meter open or shorted. Repair or replace harness.





**Diagnosis Chart by Symptom 1**

NGS000A0

**1. CHECK SELF-DIAGNOSTIC RESULTS**

Perform RAS self-diagnosis.

- With CONSULT-II: [STC-23, "Self-Diagnosis"](#)
- Without CONSULT-II: [STC-26, "Diagnosis Procedure With Self-Diagnosis Function \(Without CONSULT-II\)"](#)

Are malfunctioning items displayed in self-diagnosis results?

- YES >> Repair or replace any malfunctioning items.  
NO >> GO TO 2.

**2. CHECK RAS STATIC/DYNAMIC CHARACTERISTICS**

Check RAS static/dynamic characteristics. Refer to [STC-43, "Check RAS Static/Dynamic Characteristics"](#).

Is the malfunction corrected?

- YES >> INSPECTION END  
NO >> Perform the following check, and then check the symptom again.
- Adjust neutral position of steering angle sensor. Refer to [BRC-6, "Adjustment of Steering Angle Sensor Neutral Position"](#).
  - Steering angle sensor mounting condition. Refer to [BRC-63, "STEERING ANGLE SENSOR"](#).

**Diagnosis Chart by Symptom 2**

NGS000A1

The steering force does not change smoothly according to the vehicle speed (Heavy steering force with the vehicle stopped/Light handle operation during high-speed driving)


**1. CHECK (1): POWER STEERING SOLENOID VALVE SIGNAL**

1. Start engine.
2. Change the vehicle speed from 0 to 100 km/h (0 to 62 MPH) slowly, and then check voltage RAS control unit harness connector B136.

**Terminal 36 – 34 : The voltage has changed from approximately 4.4 - 6.6 V to approximately 2.4 - 3.6 V.**

OK or NG

- OK >> GO TO 2.  
NG >> GO TO 7.


**2. CHECK (2): POWER STEERING SOLENOID VALVE SIGNAL**

1. Activate fail-safe function by running engine speed at 1,500 rpm or higher for 10 seconds with the vehicle stopped.
2. Change the engine speed to the idling speed, approx. 1,600 rpm, and approximately 3,000 rpm slowly, and then check voltage RAS control unit harness connector B136.

**Terminal 36 – 34 : The voltage is changed from approximately 5.5 V to approximately 2.1 V step-by-step.**

OK or NG

- OK >> GO TO 3.  
NG >> GO TO 7.



## 3. CHECK POWER STEERING SOLENOID VALVE CONNECTOR

Turn ignition switch OFF, disconnect power steering solenoid valve harness connector, and check terminal for deformation, disconnection, looseness, etc.

OK or NG

OK >> GO TO 4.

NG >> Harness or connector open or shorted. Repair or replace any inoperative parts.

## 4. CHECK POWER STEERING SOLENOID VALVE POWER SUPPLY CIRCUIT


Check continuity between RAS control unit harness connector (A) B136 and power steering solenoid valve harness connector (B) F8.

RAS control unit	Power steering solenoid valve	Continuity
36	Terminal 1	Yes

OK or NG

OK >> GO TO 5.

NG >> Open or short in harness. Repair or replace any inoperative parts.



## 5. CHECK POWER STEERING SOLENOID VALVE GROUND CIRCUIT


Check continuity between power steering solenoid valve harness connector (A) and ground.

Connector	Terminal	Continuity
F8	2 – Ground	Yes

OK or NG

OK >> GO TO 6.

NG >> Open or short in harness. Repair or replace any inoperative parts.



## 6. CHECK POWER STEERING SOLENOID VALVE


Apply voltage power steering solenoid valve connector F8 (A) and then make sure that the operating sound (clicking sound) is heard.

**Terminal 1 (+) - 2 (-) : Operating sound is heard.**

OK or NG

OK >> Perform steering turning torque inspection. Refer to [PS-9, "CHECKING STEERING WHEEL TURNING FORCE"](#).

NG >> Power steering solenoid valve is inoperating. Replace it.



## 7. CHECK SELF-DIAGNOSIS RESULTS

Perform RAS self-diagnosis.

- With CONSULT-II: [STC-23, "Self-Diagnosis"](#)
- Without CONSULT-II: [STC-26, "Diagnosis Procedure With Self-Diagnosis Function \(Without CONSULT-II\)"](#)

Are malfunctioning items displayed in self-diagnosis results?

YES >> Repair or replace any malfunctioning items.

NO >> RAS control unit malfunction. Replace it.

**Check RAS Static/Dynamic Characteristics****1. CHECK (1): RAS ACTUATOR STROKE**

Perform CONSULT-II "ACTIVE TEST", and then check the actuator stroke when turning the steering wheel clockwise or counterclockwise by 180° or more.


**Neutral position (A)**

**Actuator stroke (B) : 2.8 - 3.0 mm (0.110 - 0.118 in)**

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.

**2. CHECK (2): RAS ACTUATOR STROKE**


Perform CONSULT-II "ACTIVE TEST". When turning the steering wheel in neutral position (A), the rear wheel turns clockwise/counterclockwise periodically. At that time, check actuator stroke (B).

**Actuator stroke (B) : 2.3 - 2.5 mm (0.091 - 0.098 in)**

OK or NG

OK >> RAS static/dynamic characteristics inspection is completed.

NG >> GO TO 3.

**3. CHECK RAS MOTOR**

Check RAS motor itself separated from other parts. Refer to [STC-44, "RAS MOTOR"](#) .

OK or NG

OK >> GO TO 4.

NG >> RAS motor malfunction. Check the stroke again after replacing.

**4. CHECK REAR WHEEL STEERING ANGLE SENSOR**

Check rear wheel steering angle sensor separated from other parts. Refer to [STC-44, "REAR WHEEL STEERING ANGLE SENSOR"](#) .

OK or NG

OK >> GO TO 5.

NG >> Rear wheel steering angle sensor malfunction. Check the stroke again after replacing.

**5. CHECK RAS CONTROL UNIT**

Replace RAS control unit. Check the symptom of malfunction again.

Is the malfunction corrected?

YES >> RAS control unit malfunction

NO >> GO TO 6.

**6. REPLACE RAS ACTUATOR ASSEMBLY**

Replace RAS actuator assembly. Check the symptom of malfunction again.

Is the malfunction corrected?

YES >> RAS actuator malfunction


NO >> Check rear suspension components. Refer to [RSU-7, "Components"](#) .

## Component Parts Inspection

### RAS MOTOR RELAY

1. Check the resistance between RAS motor relay connector.


**Terminal 1 – 2 : Approx. 74 Ω**



2. When applying or not supplying approximately 12 V between RAS motor relay connector, check continuity RAS motor relay connector.

**Terminal 3 – 5 : When applying 12 V voltage: Continuity exist.**

**: When not applying 12 V voltage: Continuity not exist.**



### RAS MOTOR

1. Check the resistance RAS motor connector.


**Terminal 1 – 2 : Approx. 0.6 Ω**

2. Remove RAS motor from RAS actuator, and then turn the motor by 6 V battery.

**If it is normal, it turns.**

**CAUTION:**

**Do not apply 12 V (battery voltage) to the RAS motor terminal because RAS motor might be damaged.**




### REAR WHEEL STEERING ANGLE SENSOR

1. Disconnect rear wheel steering angle sensor harness connector B133.
2. Check resistance of rear wheel steering angle sensor side connectors.

**Terminal 2 – 3 : Approx. 1kΩ**

**Terminal 4 – 3 : Approx. 1kΩ**

**Terminal 1 – 3 : Approx. 1.25 kΩ**



**PRECAUTIONS**

PF0:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

NGS000B2

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions for Battery Service**

NGS000B3

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

A  
B  
C  
D  
E  
F  
H  
I  
J  
K  
L  
M

STC

**TILT & TELESCOPIC SYSTEM**

PFP:48805

**System Description**  
**OPERATION**

NGS0001J


Steering wheel position can be adjusted with the ADP steering switch.

**NOTE:**

Steering wheel position can be manually operated with the ignition switch OFF.

**Component Parts and Harness Connector Location**

NGS0001K



SGIA1081E

# TILT & TELESCOPIC SYSTEM


[TILT/TELESCOPIC]

## Schematic

NGS000AJ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

STC



(IK) : With Intelligent Key  
(OK) : Without Intelligent Key

TGWM0050E



# TILT & TELESCOPIC SYSTEM

[TILT/TELESCOPIC]

NGS0001L

## Wiring Diagram—TILTEL—

STC-TILTEL-01



REFER TO THE FOLLOWING.

(E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

(M1), (M2), (B4) -ELECTRICAL UNITS

TGWM0051E




# TILT & TELESCOPIC SYSTEM

[TILT/TELESCOPIC]






STC-TILTEL-02

A  
B  
C  
D  
E  
F  
H  
I  
J  
K  
L  
M

STC



: DATA LINE  
 : WITH INTELLIGENT KEY  
 : WITHOUT INTELLIGENT KEY



REFER TO THE FOLLOWING.



- SUPER MULTIPLE JUNCTION (SMJ)
- FUSE BLOCK-JUNCTION BOX (J/B)
- ELECTRICAL UNITS

TGWM0052E

# TILT & TELESCOPIC SYSTEM

[TILT/TELESCOPIC]

STC-TILTEL-03



TGWM0053E

# TILT & TELESCOPIC SYSTEM

[TILT/TELESCOPIC]

## Terminals and Reference Values for Automatic Drive Positioner Control Unit

NGS0001M

Terminal	Wire color	Item	Condition	Data (Approx.)
1	Y/G	ADP steering switch signal (UPWARD)	ADP steering switch turned to up	0 V
			Other than above	5 V
7	OR/L	Tilt sensor and telescopic sensor signal (Tilt sensor)	Tilt position, top	2 V
			Tilt position, bottom	4 V
11	P/L	ADP steering switch signal (FRONTWARD)	ADP steering switch turned to forward	0 V
			Other than above	5 V
17	LG/B	ADP steering switch signal (DOWNWARD)	ADP steering switch turned to downward	0 V
			Other than above	5 V
23	R/Y	Tilt sensor and telescopic sensor signal (Telescopic sensor)	Telescopic position, top	1 V
			Telescopic position, bottom	4 V
27	G/W	ADP steering switch signal (BACKWARD)	ADP steering switch turned to backward	0 V
			Other than above	5 V
33	W/L	Tilt sensor and telescopic sensor power supply	—	5 V
34	GY	Automatic drive positioner control unit power supply (FUSE)	—	Battery voltage (Approx. 12 V)
35	G/Y	Tilt motor and telescopic motor signal [Tilt motor (UPWARD)]	ADP steering switch turned upward	Battery voltage (Approx. 12 V)
			Other than above	0 V
36	R	Tilt motor and telescopic motor signal [Telescopic motor (FORWARD)]	ADP steering switch turned to forward	Battery voltage (Approx. 12 V)
			Other than above	0 V
39	W	Automatic drive positioner control unit power supply (PTC)	—	Battery voltage (Approx. 12 V)
40	B	Automatic drive positioner control unit ground (signal)	—	0 V
41	Y	Tilt sensor and telescopic sensor ground (signal)	—	0 V
42	G/W	Tilt motor and telescopic motor signal [Tilt motor (DOWNWARD)]	ADP steering switch turned to downward	Battery voltage (Approx. 12 V)
			Other than above	0 V
44	G	Tilt motor and telescopic motor signal [Telescopic motor (BACKWARD)]	ADP steering switch turned backward	Battery voltage (Approx. 12 V)
			Other than above	0 V
48	B	Automatic drive positioner control unit ground (power)	—	0 V

A

B

C

D

E

F

STC

H

I

J

K

L

M

**Preliminary Check**  
**POWER SUPPLY AND GROUND CIRCUIT INSPECTION**

**1. CHECK FUSE**

Check if any of the following fuse in the automatic drive positioner control unit are blown.

Unit	Terminal No.	Voltage (V)
Automatic drive Positioner control unit	34	Approx. 12

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

**2. CHECK POWER SUPPLY CIRCUIT (AUTOMATIC DRIVE POSITIONER CONTROL UNIT)**


1. Disconnect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between automatic drive positioner control unit harness connector and ground.

Connector	Terminal	Condition	Voltage (V)
M97	34 – Ground	Ignition switch ON	Battery voltage (Approx. 12 V)
	39 – Ground		

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness. Check harness for open or short between Automatic drive Positioner control unit and fuse.



**3. CHECK GROUND CIRCUIT (AUTOMATIC DRIVE POSITIONER CONTROL UNIT)**


1. Turn ignition switch OFF.
2. Check continuity between automatic drive positioner control unit harness connector and ground.

Connector	Terminal	Continuity
M97	40 – Ground	Yes
	48 – Ground	

OK or NG

OK >> Preliminary check is OK.

NG >> Repair or replace Automatic drive Positioner control unit ground harness.



**Symptom 1: Telescopic System does not Operate**

**1. CHECK STEERING WHEEL TELESCOPIC MECHANISM**

Check the following.

- Operation malfunction caused by steering wheel telescopic mechanism deformation or pinched harness or other foreign materials.
- Operation malfunction and interference with other parts by poor installation.

OK or NG

- OK >> GO TO 2.
- NG >> Repair the malfunctioning part and check again.


**2. CHECK TELESCOPIC SWITCH INPUT/OUTPUT**

1. Disconnect ADP steering switch connector.
2. Turn ignition switch ON.
3. Check voltage between ADP steering switch harness connector and ground.

Connector	Terminal	Voltage
M100	4 – Ground	Approx. 5 V
	5 – Ground	

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 5.




**3. CHECK ADP STEERING SWITCH GROUND CIRCUIT**

1. Turn ignition switch OFF.
2. Check continuity between ADP steering switch harness connector and ground.

Connector	Terminal	Continuity
M100	1 – Ground	Yes

OK or NG

- OK >> GO TO 4.
- NG >> Replace or replace harness.



A  
B  
C  
D  
E  
F  
H  
I  
J  
K  
L  
M

STC


### 4. CHECK TELESCOPIC SWITCH

Check continuity between ADP steering switch connector.

Connector	Terminal	Condition	Continuity
M100	4 - 1	Backward position	Yes
		Neutral or forward position	No
	5 - 1	Forward position	Yes
		Neutral or backward position	No

OK or NG

- OK >> GO TO 6.
- NG >> Replace ADP steering switch.




### 5. CHECK HARNESS CONTINUITY

1. Disconnect automatic drive positioner control unit connector.
2. Check continuity between the following terminals.
  - Automatic drive positioner control unit harness connector M96 terminal 11 and ADP steering switch harness connector M100 terminal 5.
  - Automatic drive positioner control unit harness connector M96 terminal 27 and ADP steering switch harness connector M100 terminal 4.
  - Automatic drive positioner control unit harness connector M96 terminal 11 and ground.
  - Automatic drive positioner control unit harness connector M96 terminal 27 and ground.

- 11 - 5 : Continuity should exist.**
- 27 - 4 : Continuity should exist.**
- 11 - Ground : Continuity should not exist.**
- 27 - Ground : Continuity should not exist.**

OK or NG


- OK >> Replace Automatic drive Positioner control unit.
- NG >> Repair or replace harness.



**6. CHECK AUTOMATIC DRIVE POISONER CONTROL UNIT OUTPUT SIGNAL**

1. Disconnect tilt motor and telescopic motor connector.
2. Check voltage between tilt motor and telescopic motor harness connector and ground.

Connector	Terminal	Condition	Voltage (V)
M98	3- Ground	Telescopic switch ON (FORWARD operation)	Battery voltage (Approx. 12 V)
		Telescopic switch OFF	0 V
	4 – Ground	Telescopic switch ON (BACKWARD operation)	Battery voltage (Approx. 12 V)
		Telescopic switch OFF	0 V



**OK or NG**

- OK >> Replace tilt motor and telescopic motor.
- NG >> GO TO 7.


**7. CHECK TELESCOPIC MOTOR CIRCUIT**

1. Disconnect automatic drive positioner control unit and tilt motor and telescopic motor connectors.
2. Check continuity between the following terminals.
  - Automatic drive positioner control unit harness connector M97 terminal 36 and tilt motor and telescopic motor harness connector M98 terminal 3.
  - Automatic drive positioner control unit harness connector M97 terminal 44 and tilt motor and telescopic motor harness connector M98 terminal 4.
  - Automatic drive positioner control unit harness connector M97 terminal 36 and ground.
  - Automatic drive positioner control unit harness connector M97 terminal 44 and ground.

- 36 – 3 : Continuity should exist.**
- 44 – 4 : Continuity should exist.**
- 36 – Ground : Continuity should not exist.**
- 44 – Ground : Continuity should not exist.**

**OK or NG**

- OK >> Replace automatic drive positioner control unit.
- NG >> Repair or replace harness.



**Symptom 2: Tilt System does not Operate**

**1. CHECK STEERING WHEEL TILT MECHANISM**

Check the following.

- Operation malfunction caused by steering wheel tilt mechanism deformation or pinched harness or other foreign materials.
- Operation malfunction and interference with other parts by poor installation.

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair the malfunctioning part and check again.


### 2. CHECK TILT SWITCH INPUT/OUTPUT

1. Disconnect ADP steering switch connector.
2. Turn ignition switch ON.
3. Check voltage between ADP steering switch harness connector and ground.

Connector	Terminal	Voltage
M100	2 – Ground	Approx. 5 V
	3 – Ground	

#### OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 5.




### 3. CHECK ADP STEERING SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ADP steering switch harness connector ground.

Connector	Terminal	Continuity
M100	1 – Ground	Yes

#### OK or NG

- OK >> GO TO 4.  
 NG >> Repair or replace harness.




### 4. CHECK TILT SWITCH

Check continuity between ADP steering switch connector.

Connector	Terminal	Condition	Continuity
M100	2 – 1	Tilt up position	Yes
		Neutral or tilt down position	No
	3 – 1	Tilt down position	Yes
		Neutral or up position	No

#### OK or NG

- OK >> GO TO 6.  
 NG >> Replace ADP steering switch.






**5. CHECK HARNESS CONTINUITY**

1. Disconnect automatic drive positioner control unit connector.
2. Check continuity between the following terminals.
  - Automatic drive positioner control unit harness connector M96 terminal 1 and ADP steering switch harness connector M100 terminal 2.
  - Automatic drive positioner control unit harness connector M96 terminal 17 and ADP steering switch harness connector M100 terminal 3.
  - Automatic drive positioner control unit harness connector M96 terminal 1 and ground.
  - Automatic drive positioner control unit harness connector M96 terminal 17 and ground.

- 1 – 2 : Continuity should exist.**
- 17 – 3 : Continuity should exist.**
- 1 – Ground : Continuity should not exist.**
- 17 – Ground : Continuity should not exist.**

OK or NG

- OK >> Replace Automatic drive Positioner control unit.
- NG >> Repair or replace harness.




**6. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL**

1. Disconnect tilt motor and telescopic motor connector.
2. Check voltage between tilt motor and telescopic motor harness connector ground.

Connector	Terminal	Condition	Voltage (V)
M98	1- Ground	ADP steering switch ON (UP operation)	Battery voltage (Approx. 12 V)
		ADP steering switch OFF	0 V
	2 – Ground	ADP steering switch ON (DOWN operation)	Battery voltage (Approx. 12 V)
		ADP steering switch OFF	0 V

OK or NG

- OK >> Replace tilt motor and telescopic motor.
- NG >> GO TO 7.



## 7. CHECK TILT MOTOR CIRCUIT

1. Disconnect automatic drive positioner control unit and tilt motor and telescopic motor connectors.
2. Check continuity between the following terminals.
  - Automatic drive positioner control unit harness connector M97 terminal 35 and tilt motor and telescopic motor harness connector M98 terminal 1.
  - Automatic drive positioner control unit harness connector M97 terminal 42 and tilt motor and telescopic motor harness connector M98 terminal 2.
  - Automatic drive positioner control unit harness connector M97 terminal 35 and ground.
  - Automatic drive positioner control unit harness connector M97 terminal 42 and ground.

**35 – 1 : Continuity should exist.**

**42 – 2 : Continuity should exist.**

**35 – Ground : Continuity should not exist.**

**42 – Ground : Continuity should not exist.**

### OK or NG

- OK >> Replace automatic drive positioner control unit.  
 NG >> Repair or replace harness.

