

SECTION WCS

WARNING CHIME SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
WCS
O
P

CONTENTS

BASIC INSPECTION	3	PARKING BRAKE RELEASE WARNING CHIME : System Description	10
DIAGNOSIS AND REPAIR WORKFLOW	3	PARKING BRAKE RELEASE WARNING CHIME : Component Parts Location	11
Work Flow	3	PARKING BRAKE RELEASE WARNING CHIME : Component Description	11
FUNCTION DIAGNOSIS	4	DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)	12
WARNING CHIME SYSTEM	4	CONSULT-III Function (METER/M&A)	12
WARNING CHIME SYSTEM	4	DIAGNOSIS SYSTEM (BCM)	15
WARNING CHIME SYSTEM : System Diagram	4	COMMON ITEM	15
WARNING CHIME SYSTEM : System Description	4	COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)	15
WARNING CHIME SYSTEM : Component Parts Location	5	BUZZER	15
WARNING CHIME SYSTEM : Component De- scription	5	BUZZER : CONSULT-III Function (BCM - BUZZ- ER)	15
LIGHT REMINDER WARNING CHIME	6	COMPONENT DIAGNOSIS	17
LIGHT REMINDER WARNING CHIME : System Diagram	6	POWER SUPPLY AND GROUND CIRCUIT	17
LIGHT REMINDER WARNING CHIME : System Description	6	COMBINATION METER	17
LIGHT REMINDER WARNING CHIME : Compo- nent Parts Location	7	COMBINATION METER : Diagnosis Procedure	17
LIGHT REMINDER WARNING CHIME : Compo- nent Description	7	UNIFIED METER AND A/C AMP.	17
SEAT BELT WARNING CHIME	7	UNIFIED METER AND A/C AMP. : Diagnosis Pro- cedure	17
SEAT BELT WARNING CHIME : System Diagram	8	BCM (BODY CONTROL MODULE)	18
SEAT BELT WARNING CHIME : System Descrip- tion	8	BCM (BODY CONTROL MODULE) : Diagnosis Procedure	18
SEAT BELT WARNING CHIME : Component Parts Location	9	BCM (BODY CONTROL MODULE) : Special Re- pair Requirement	19
SEAT BELT WARNING CHIME : Component De- scription	9	METER BUZZER CIRCUIT	20
PARKING BRAKE RELEASE WARNING CHIME	9	Description	20
PARKING BRAKE RELEASE WARNING CHIME : System Diagram	10	Component Function Check	20
		Diagnosis Procedure	20

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT	21	DTC Inspection Priority Chart	89
Description	21	DTC Index	90
Component Function Check	21	SYMPTOM DIAGNOSIS	93
Diagnosis Procedure	21	THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	93
Component Inspection	21	Description	93
WARNING CHIME SYSTEM	23	Diagnosis Procedure	93
Wiring Diagram — WARNING CHIME —	23	THE LIGHT REMINDER WARNING DOES NOT SOUND	94
ECU DIAGNOSIS	27	Description	94
COMBINATION METER	27	Diagnosis Procedure	94
Reference Value	27	THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	95
Wiring Diagram — METER —	30	Description	95
Fail Safe	39	Diagnosis Procedure	95
DTC Index	40	PRECAUTION	96
UNIFIED METER AND A/C AMP.	41	AIR BAG (PATTERN 2)	96
Reference Value	41	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	96
Wiring Diagram — METER —	48		
Fail Safe	57		
DTC Index	58		
BCM (BODY CONTROL MODULE)	59		
Reference Value	59		
Wiring Diagram — BCM —	82		
Fail Safe	87		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000000964467

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2.CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

3.CHECK CONSULT-III SELF-DIAGNOSIS RESULTS

Connect CONSULT-III and perform self-diagnosis. Refer to [WCS-12, "CONSULT-III Function \(METER/M&A\)"](#).

Are self-diagnosis results normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts and go to 5.

4.NARROW DOWN MALFUNCTIONING PARTS THROUGH SYMPTOM DIAGNOSIS

Perform symptom diagnosis and repair or replace the identified malfunctioning parts.

>> GO TO 5.

5.FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

WARNING CHIME SYSTEM


< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM : System Diagram




WARNING CHIME SYSTEM : System Description

INFOID:000000000964469

COMBINATION METER

- The buzzer (1) for warning chime system is installed in the combination meter.
- The buzzer sounds when the combination meter receives buzzer output signal from each unit through unified meter and A/C amp.



UNIFIED METER AND A/C AMP.

The unified meter and A/C amp. transmits the buzzer output signal received from BCM with CAN communication line to the combination meter.

BCM

BCM receives signals from various units and transmits a buzzer output signal to the unified meter and A/C amp. with CAN communication line if it judges that the warning buzzer should be activated.

BCM warning function list


Warning functions	Signal name
Light reminder warning chime	<ul style="list-style-type: none"> • Lighting switch position signal • Door switch signal
Seat belt warning chime	Seat belt buckle switch signal

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

WARNING CHIME SYSTEM : Component Parts Location

INFOID:000000000964470



- | | | |
|---|--------------------------------|------------------------------------|
| 1. BCM | 2. Parking brake switch (A/T) | 3. Combination meter |
| 4. Combination switch (Lighting switch) | 5. Unified meter and A/C amp. | 6. Front door switch (driver side) |
| 7. Seat belt buckle switch | 8. Parking brake switch (M/T) | |
| A. Dash side lower (passenger side) | B. Behind cluster lid C (back) | |

WARNING CHIME SYSTEM : Component Description

INFOID:000000000964471

Unit	Description
Combination meter	<ul style="list-style-type: none"> Receives a buzzer output signal from the unified meter and A/C amp. and sounds the buzzer. Judges whether the parking brake is released from the vehicle speed signal received from the unified meter and A/C amp. with CAN communication line and the parking brake switch signal from the parking brake switch, and sounds the buzzer if necessary.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Receives the seat belt buckle switch signal from the seat belt buckle switch and transmits it to BCM with CAN communication line. Receives a buzzer output signal from BCM with CAN communication line and transmits it to the combination meter by means of communication line.
BCM	Transmits signals provided by various units to the unified meter and A/C amp. with CAN communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to BCM with CAN communication line.
Seat belt buckle switch (driver side)	Transmits a seat belt buckle switch signal to the unified meter and A/C amp.
Combination switch (Lighting switch)	Transmits the lighting switch position signal to BCM.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
Front door switch (driver side)	Transmits the door switch signal to BCM.
Parking brake switch	Refer to MWI-59, "Description" .

LIGHT REMINDER WARNING CHIME

LIGHT REMINDER WARNING CHIME : System Diagram



LIGHT REMINDER WARNING CHIME : System Description

INFOID:000000000964473

DESCRIPTION

With ignition switch in OFF or ACC position, driver door open, and lighting switch in 1ST or 2ND position, the light warning chime will sound.

- BCM detects ignition switch in OFF or ACC position, front door switch (driver side) ON, and lighting switch in 1ST or 2ND position. And then transmits buzzer output signal (light reminder warning chime) to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits buzzer output signal (light reminder warning chime) to combination meter with communication line.
- When combination meter receives buzzer output signal (light reminder warning chime), it sounds the buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Lighting switch is at 1st or 2nd position
- Ignition switch is at OFF or ACC
- Front door switch (driver side) is ON

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.


- Lighting switch OFF
- Ignition switch ON
- Front door switch (driver side) is OFF

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

LIGHT REMINDER WARNING CHIME : Component Parts Location

INFOID:000000000964474



- | | | |
|---|--------------------------------|------------------------------------|
| 1. BCM | 2. Parking brake switch (A/T) | 3. Combination meter |
| 4. Combination switch (Lighting switch) | 5. Unified meter and A/C amp. | 6. Front door switch (driver side) |
| 7. Seat belt buckle switch | 8. Parking brake switch (M/T) | |
| A. Dash side lower (passenger side) | B. Behind cluster lid C (back) | |

LIGHT REMINDER WARNING CHIME : Component Description

INFOID:000000000964475

Unit	Description
Combination meter	Receives a buzzer output signal from the unified meter and A/C amp. and sounds the buzzer.
Unified meter and A/C amp.	Receives a buzzer output signal from BCM via CAN communication line and transmits it to the combination meter by means of communication line.
BCM	Judges the light warning conditions from the signals provided by various switches and transmits a buzzer output signal to the unified meter and A/C amp. via CAN communication line if necessary.
Combination switch (Lighting switch)	Transmits the lighting switch position signal to BCM.
Front door switch (driver side)	Transmits the door switch signal to BCM.

SEAT BELT WARNING CHIME

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WCS

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

SEAT BELT WARNING CHIME : System Diagram

INFOID:000000000964476



SEAT BELT WARNING CHIME : System Description

INFOID:000000000964477

DESCRIPTION

With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime will sound for approximately 6 seconds.

- BCM receives seat belt buckle switch signal from unified meter and A/C amp. with CAN communication line.
- BCM detects ignition switch turned ON and seat belt buckle switch (driver side) ON. And then transmits buzzer output signal (seat belt warning chime) to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits buzzer output signal (seat belt warning chime) to combination meter with communication line.
- When combination meter receives buzzer output signal (seat belt warning chime), it sounds the buzzer.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Ignition switch OFF→ON
- Seat buckle switch (driver side) is ON (driver seat belt not fastened)

WARNING CANCEL CONDITIONS

Cancels the warning if any of the following conditions is fulfilled.


- Ignition switch OFF
- Seat buckle switch (driver side) is OFF (driver seat belt fastened)
- 90 seconds have passed since the start of the warning

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

SEAT BELT WARNING CHIME : Component Parts Location

INFOID:000000000964478



- | | | |
|---|--------------------------------|------------------------------------|
| 1. BCM | 2. Parking brake switch (A/T) | 3. Combination meter |
| 4. Combination switch (Lighting switch) | 5. Unified meter and A/C amp. | 6. Front door switch (driver side) |
| 7. Seat belt buckle switch | 8. Parking brake switch (M/T) | |
| A. Dash side lower (passenger side) | B. Behind cluster lid C (back) | |

SEAT BELT WARNING CHIME : Component Description

INFOID:000000000964479

Unit	Description
Combination meter	Receives a buzzer output signal from the unified meter and A/C amp. and sounds the buzzer.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Receives the seat belt buckle switch signal from the seat belt buckle switch and transmits it to BCM via CAN communication line. Receives a buzzer output signal from BCM via CAN communication line and transmits it to the combination meter by means of communication line.
BCM	Judges the seat belt warning condition from the seat belt buckle switch signal received from the unified meter and A/C amp. and transmits a buzzer output signal to the unified meter and A/C amp via CAN communication line if necessary.
Seat belt buckle switch (driver side)	Refer to WCS-21. "Description" .

PARKING BRAKE RELEASE WARNING CHIME

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


WCS

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

PARKING BRAKE RELEASE WARNING CHIME : System Diagram

INFOID:000000000964480



PARKING BRAKE RELEASE WARNING CHIME : System Description

INFOID:000000000964481

DESCRIPTION

- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line and transmits it to the combination meter by means of communication line.
- The combination meter judges whether the parking brake is released from the vehicle speed signal received from the unified meter and A/C amp. and the parking brake switch signal from the parking brake switch, and sounds the warning buzzer if necessary.

WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions is fulfilled.


- Vehicle speed is approximately 3 km/h (1.9 MPH) or less
- Parking brake switch OFF

WARNING CHIME SYSTEM

< FUNCTION DIAGNOSIS >

PARKING BRAKE RELEASE WARNING CHIME : Component Parts Location

INFOID:000000000964482



- | | | |
|---|--------------------------------|------------------------------------|
| 1. BCM | 2. Parking brake switch (A/T) | 3. Combination meter |
| 4. Combination switch (Lighting switch) | 5. Unified meter and A/C amp. | 6. Front door switch (driver side) |
| 7. Seat belt buckle switch | 8. Parking brake switch (M/T) | |
| A. Dash side lower (passenger side) | B. Behind cluster lid C (back) | |

PARKING BRAKE RELEASE WARNING CHIME : Component Description

INFOID:000000000964483

Unit	Description
Combination meter	Judges whether the parking brake is released from the vehicle speed signal received from the unified meter and A/C amp. via CAN communication line and the parking brake switch signal from the parking brake switch, and sounds the buzzer if necessary.
Unified meter and A/C amp.	Receives a vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication line and transmits it to the combination meter by means of communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to combination meter via CAN communication line.
Parking brake switch	Refer to MWI-59. "Description" .

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

CONSULT-III Function (METER/M&A)

INFOID:000000000964484

CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes with CAN communication with the unified meter and A/C amp.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	Unified meter and A/C amp. checks the conditions and displays memorized error.
	Data Monitor	Displays unified meter and A/C amp. input/output data in real time.

SELF DIAG RESULT

Refer to [MWI-97, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line. NOTE: 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units with CAN communication line. NOTE: 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h or mph]		Odometer signal value transmitted to other units with CAN communication line.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM with CAN communication line. NOTE: 8191.875 is displayed when the malfunction signal is received.
FUEL METER [lit.]	X	Fuel level indicated on combination meter.
W TEMP METER [°C]	X	Value of engine coolant temperature signal received from ECM with CAN communication line. NOTE: 215 is displayed when the malfunction signal is input.
ABS W/L [On/Off]		Status of ABS warning lamp judged from ABS warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
VDC/TCS IND [On/Off]		Status of VDC indicator lamp judged from VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
SLIP IND [On/Off]		Status of slip indicator lamp judged from slip indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
BRAKE W/L [On/Off]		Status of brake warning lamp judged from brake warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line. NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.
DOOR W/L [On/Off]		Status of door warning judged from door switch signal received from BCM with CAN communication line.
TRUNK/GLAS-H [On/Off]		Status of trunk warning judged from trunk switch signal received from BCM with CAN communication line.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

Display item [Unit]	MAIN SIGNALS	Description	A
HI-BEAM IND [On/Off]		Status of high beam indicator lamp judged from high beam request signal received from BCM with CAN communication line.	A
TURN IND [On/Off]		Status of turn indicator lamp judged from turn indicator signal received from BCM with CAN communication line.	B
FR FOG IND [On/Off]		Status of front fog light indicator lamp judged from front fog light request signal received from BCM with CAN communication line.	C
RR FOG IND [Off]		This item is displayed, but cannot be monitored.	
LIGHT IND [On/Off]		Status of light indicator lamp judged from position light request signal received from BCM with CAN communication line.	D
OIL W/L [On/Off]		Status of oil pressure warning lamp judged from oil pressure switch signal received from IPDM E/R with CAN communication line.	E
MIL [On/Off]		Status of malfunction indicator lamp judged from malfunctioning indicator lamp signal received from ECM with CAN communication line.	
CRUISE IND [On/Off]		Status of CRUISE indicator judged from ASCD status signal received from ECM with CAN communication line.	F
SET IND [On/Off]		Status of set indicator judged from ASCD SET indicator signal received from ECM with CAN communication line.	G
CRUISE W/L [On/Off]		Status of CRUISE warning lamp judged from ASCD status signal received from ECM with CAN communication line.	
BA W/L [Off]		This item is displayed, but cannot be monitored.	H
ATC/T-AMT W/L [On/Off]		Status of A/T check warning lamp judged from A/T check indicator signal received from TCM with CAN communication line.	I
4WD W/L [On/Off]		Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line.	
4WD LOCK IND [Off]		This item is displayed, but cannot be monitored.	J
FUEL W/L [On/Off]		Low-fuel warning status judged by the identified fuel level.	
WASHER W/L [On/Off]		Status of washer warning lamp judged from washer level switch input to combination meter.	K
AIR PRES W/L [On/Off]		Status of tire pressure warning lamp judged from tire pressure signal received from BCM with CAN communication line.	L
KEY G/Y W/L [On/Off]		Status of key warning lamp (G/Y) judged from key warning signal received from BCM with CAN communication line.	
AFS OFF IND [On/Off]		Status of AFS OFF indicator lamp judged from AFS OFF indicator lamp signal received from AFS control unit with CAN communication line.	M
4WAS/RAS W/L [On/Off]		Status of 4WAS warning lamp judged from 4WAS warning lamp signal received from 4WAS main control unit with CAN communication line.	WCS
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY,OUTKY, LK WN, C&P N,C&P I]		Displays status of Intelligent Key system warning judged from meter display signal received from BCM with CAN communication line.	O
ACC TARGET [On/Off]		Status of vehicle ahead detection indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	P
ACC DISTANCE [Off, SHOR, MID, LONG]		Status of set distance indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	
ACC OWN VHL [On/Off]		Status of own vehicle indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	
ACC SET SPEED [On/Off]		Status of set vehicle speed indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.	

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

Display item [Unit]	MAIN SIGNALS	Description
ACC UNIT [On/Off]		Status of display unit judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
SHIFT IND [P, R, N, D, M1, M2, M3, M4, M5]		Status of A/T position indicator judged from shift position signal and manual mode indicator signal received from TCM with CAN communication line.
AT S MODE SW [On/Off]		Status of snow mode switch.
AT P MODE SW [On/Off]		This item is displayed, but cannot be monitored.
M RANGE SW [On/Off]		Status of manual mode switch.
NM RANGE SW [On/Off]		Status of not manual mode switch.
AT SFT UP SW [On/Off]		Status of A/T shift up switch.
AT SFT DWN SW [On/Off]		Status of A/T shift down switch.
ST SFT UP SW [On/Off]		Status of paddle shifter up switch.
ST SFT DWN SW [On/Off]		Status of paddle shifter down switch.
COMP FB SIG [On/Off]		A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.
4WD LOCK SW [Off]		This item is displayed, but cannot be monitored.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch.
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
DISTANCE [km]		Value of possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C or °F]		Ambient temperature value converted from ambient sensor signal received from ambient sensor. NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit with CAN communication line.
BUZZER [On/Off]		Buzzer status (in the combination meter) is judged with the buzzer output signal received from each unit with CAN communication line and the warning output condition of the combination meter.

NOTE:

Some items are not available according to vehicle specification.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000000964485

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to BCS-74, "DTC Index" .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	This function is not used even though it is displayed.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioner*	AIR CONDITONER		×	
Intelligent Key system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
BCM	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONI-TOR)	×	×	×

*: This item is displayed, but is not used.

BUZZER

BUZZER : CONSULT-III Function (BCM - BUZZER)

INFOID:000000000964486

CONSULT-III APPLICATION ITEMS

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

Test item	Diagnosis mode	Description
BUZZER	Data Monitor	Displays BCM input data in real time.
	Active Test	Operation of electrical loads can be checked by sending driving signal to them.

DATA MONITOR

Display item [Unit]	Description
VEH SPEED 1 [Km/h]	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line.
PUSH SW [On/Off]	Status of push button ignition switch judged by BCM.
UNLK SEN-DR [On/Off]	Status of unlock sensor judged by BCM.
KEY SW-SLOT [On/Off]	Status of key slot judged by BCM.
TAIL LAMP SW [On/Off]	Status of each switch judged by BCM using the combination switch readout function.
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM.
DOOR SW-DR [On/Off]	Status of driver side door switch judged by BCM.

ACTIVE TEST

Display item [Unit]	Description
IGN KEY WARN ALM	The key warning chime operation can be checked by operating the relevant function (On/Off).
SEAT BELT WARN TEST	The seat belt warning chime operation can be checked by operating the relevant function (On/Off).
ID REGIST WARNING	The ID regist warning chime operation can be checked by operating the relevant function (On/Off).
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).
RUN FLAT/T WARN BUZZER	The run-flat tire warning chime operation can be checked by operating the relevant function (On/Off).

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000000964487

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector M53 terminals 1, 21 and ground.

Terminal No.	Signal name	Ignition switch position	Value (Approx.)
1	Battery power supply	OFF	Battery voltage
21	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M53 terminals 5, 15, 22 and ground.

5, 15, 22 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

UNIFIED METER AND A/C AMP.

UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000000964488

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	6
Ignition switch ACC or ON	19
Ignition switch ON or START	3

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector M67 terminals 54, 41, 53 and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M

O
P

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

Terminal No.	Signal name	Ignition switch position	Value (Approx.)
54	Battery power supply	OFF	Battery voltage
41	ACC power supply	ACC	Battery voltage
53	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector M67 terminals 55, 71 and ground.

55, 71 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000000964489

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	K
11		10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground Battery voltage
Connector	Terminal	
M118	1	
M119	11	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE) : Special Repair Requirement

INFOID:000000000964490

1.REQUIRED WORK WHEN REPLACING BCM

Initialize IVIS by CONSULT-III. For the details of initialization refer to CONSULT-III operation manual NATS-IVIS/NVIS.

>> Work end.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

METER BUZZER CIRCUIT

< COMPONENT DIAGNOSIS >

METER BUZZER CIRCUIT

Description

INFOID:000000000964491

- The buzzer for warning chime system is installed in the combination meter.
- The combination meter sounds the alarm buzzer based on the signals transmitted from various units.

Component Function Check

INFOID:000000000964492

1. CHECK OPERATION OF METER BUZZER

1. Select "BUZZER" of "BCM" on CONSULT-III.
2. Perform "LIGHT WARN ALM" of "ACTIVE TEST".

Does meter buzzer beep?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUZZER" monitor value.

BUZZER
Under the condition of buzzer input : ON
Except above : OFF

Is the inspection result normal?

- YES >> Replace combination meter.
NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000000964493

1. CHECK POWER SUPPLY OF COMBINATION METER

Check power supply of combination meter. Refer to [WCS-17, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair power supply circuit of combination meter.

2. CHECK BATTERY POWER SUPPLY OF UNIFIED METER AND A/C AMP.

Check battery power supply of unified meter and A/C amp. Refer to [WCS-17, "UNIFIED METER AND A/C AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair power supply circuit of unified meter and A/C amp.

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

Description

INFOID:000000000964494

Transmits a seat belt buckle switch signal to the unified meter and A/C amp.

Component Function Check

INFOID:000000000964495

1.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUCKLE SW" monitor value.

BUCKLE SW

When seat belt is fastened : OFF

When seat belt is unfastened : ON

>> INSPECTION END

Diagnosis Procedure

INFOID:000000000964496

1.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between unified meter and A/C amp. harness connector M66 terminal 9 and ground.

9 - Ground

When driver seat belt is fastened : Approx. 12 V

When driver seat belt is unfastened : Approx. 0 V

Is the inspection result normal?

YES >> Replace unified meter and A/C amp.

NO >> GO TO 2.

2.CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector and seat belt buckle switch (driver side) connector.
3. Check continuity between unified meter and A/C amp. harness connector M66 terminal 9 and seat belt buckle switch (driver side) harness connector B13 terminal 1.

9 - 1 : Continuity should exist.

4. Check harness continuity between unified meter and A/C amp. harness connector M66 terminal 9 and ground.

9 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (driver side) harness connector B13 terminal 2 and ground.

2 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:000000000964497

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

1. CHECK SEAT BELT BUCKLE SWITCH UNIT

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch connector.
3. Check continuity between terminals 1 and 2.

1-2

When seat belt is fastened : Continuity should not exist.

When seat belt is unfastened : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the seat belt buckle. Refer to [SB-7, "SEAT BELT BUCKLE : Removal and Installation"](#).


WARNING CHIME SYSTEM

< COMPONENT DIAGNOSIS >

WARNING CHIME SYSTEM

Wiring Diagram — WARNING CHIME —

INFOID:000000000964498



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




WARNING CHIME SYSTEM

< COMPONENT DIAGNOSIS >

WARNING CHIME

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
96	V	-
97	SB	-
98	V	-

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B	-

Connector No.	B14
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name
1	V	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name
2	V	-

Connector No.	E07
Connector Name	ICC SENSOR INTEGRATED UNIT
Connector Type	RS06FB-PR



Terminal No.	Color of Wire	Signal Name
3	L	CAN-H
6	P	CAN-L

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
18	O	-
91	W	-

Connector No.	E107
Connector Name	PARKING BRAKE SWITCH (A/T)
Connector Type	TB01FW



Terminal No.	Color of Wire	Signal Name
1	O	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name
1A	GR	-
2A	G	-
7A	R	-

WARNING CHIME SYSTEM

< COMPONENT DIAGNOSIS >


WARNING CHIME

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
18	V	-
31	W	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
66	V	-
97	SB	-
98	GR	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name
6	L	-
14	P	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name
2	SB	OUTPUT 4
5	LL	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name
1	GR	BAT
2	LG	COMM (METER->METER)
3	GR	COMM (AMP->METER)
5	B	GND
15	B	GND
21	R	IGN
22	B	GND
24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
27	V	PARKING BRAKE SW

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH




Terminal No.	Color of Wire	Signal Name
7	GR	COMM (AMP->METER)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
14	BR	COMM (LCD->AMP)
27	LG	COMM (METER->AMP)
34	Y	COMM (AMP->LCD)

WARNING CHIME SYSTEM

< COMPONENT DIAGNOSIS >

WARNING CHIME

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color of Wire	Signal Name
53	G	IGN
54	Y	BAT
55	B	GND
56	L	CAN-H
71	B	GND
72	P	CAN-L

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name
1	W	BAT (F/L)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS




Terminal No.	Color of Wire	Signal Name
11	R	BAT (FUSE)
13	B	GND

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
90	P	CAN-L
91	L	CAN-H
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color of Wire	Signal Name
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DOOR SW (DR)

COMBINATION METER

< ECU DIAGNOSIS >

ECU DIAGNOSIS

COMBINATION METER


Reference Value

INFOID:000000000964499

VALUES ON THE DAIAGNOSIS TOOL

Refer to [MWI-80](#), "Reference Value".

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (LG)	Ground	Communication signal (METER→ AMP.)	Output	Ignition switch ON	—	<p style="text-align: right; font-size: x-small;">JSNIA0027GB</p>
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—	<p style="text-align: right; font-size: x-small;">JSNIA0027GB</p>
5 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6 (W)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	12 V
7 (LG)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V
10 (G)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON	0 V
					Security warning lamp OFF	12 V

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

COMBINATION METER

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
16 (B)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
21 (R)	Ground	Ignition signal	Input	Ignition switch ON	—	12 V
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (BR)	Ground	Communication signal (LCD→ AMP.)	Output	Ignition switch ON	—	 <small>JSNIA0028GB</small>
25 (Y)	Ground	Communication signal (AMP.→ LCD)	Input	Ignition switch ON	—	 <small>JSNIA0027GB</small>
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p>  <small>JSNIA0012GB</small>
27 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
				Ignition switch ON	Parking brake OFF	 <small>JSNIA0007GB</small>

COMBINATION METER

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
28 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	<p style="text-align: right; font-size: small;">JSNIA0008GB</p>
					The brake fluid level is lower than the low level	0 V
29 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened	12 V
					When driver seat belt is unfastened	0 V
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON	0 V
					Washer level switch OFF	5 V
34 (R)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.	<p>NOTE: When brightness level is midway</p> <p style="text-align: right; font-size: small;">JSNIA0010GB</p>
36 (LG)	16 (B)	Select switch signal	Input	Ignition switch ON	When ● is pressed	0 V
					Other than the above	5 V
37 (SB)	16 (B)	Enter switch signal	Input	Ignition switch ON	When □ is pressed	0 V
					Other than the above	5 V
38 (L)	16 (B)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed	0 V
					Other than the above	5 V
39 (P)	16 (B)	Illumination control switch signal (-)	Input	Ignition switch ON	When switch is pressed	0 V
					Other than the above	5 V
40 (O)	16 (B)	Illumination control switch signal (+)	Input	Ignition switch ON	When switch is pressed	0 V
					Other than the above	5 V

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


WCS

COMBINATION METER

< ECU DIAGNOSIS >

Wiring Diagram — METER —

INFOID:00000000964500



2006/09/15


JCNWA0001GE

COMBINATION METER

< ECU DIAGNOSIS >

- ◊ A : With AT
- ◊ NV : With NAVI
- ◊ ON : Without NAVI
- ◊ IC : With ICC
- ◊ AS : With 4WAS
- ◊ PA : With automatic drive positioner or 4WAS
- ◊ AP : Without automatic drive positioner and 4WAS
- ◊ SS : With paddle shifter switch

*: This connector is not shown in "Harness Layout".



JCNWA0002GE


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



COMBINATION METER

< ECU DIAGNOSIS >

⬡: With ICC







JCNWA0003GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

<table border="1"> <tr><td>Connector No.</td><td>B1</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH08FW-CS16-TM4</td></tr> </table> 	Connector No.	B1	Connector Name	WIRE TO WIRE	Connector Type	TH08FW-CS16-TM4	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>23</td><td>L</td><td>-</td></tr> <tr><td>24</td><td>P</td><td>-</td></tr> <tr><td>25</td><td>L</td><td>-</td></tr> <tr><td>26</td><td>P</td><td>-</td></tr> <tr><td>80</td><td>Y</td><td>-</td></tr> <tr><td>82</td><td>B</td><td>-</td></tr> <tr><td>96</td><td>V</td><td>-</td></tr> <tr><td>97</td><td>SB</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	23	L	-	24	P	-	25	L	-	26	P	-	80	Y	-	82	B	-	96	V	-	97	SB	-
Connector No.	B1																																	
Connector Name	WIRE TO WIRE																																	
Connector Type	TH08FW-CS16-TM4																																	
Terminal No.	Color of Wire	Signal Name																																
23	L	-																																
24	P	-																																
25	L	-																																
26	P	-																																
80	Y	-																																
82	B	-																																
96	V	-																																
97	SB	-																																
<table border="1"> <tr><td>Connector No.</td><td>B13</td></tr> <tr><td>Connector Name</td><td>SEAT BELT BUCKLE SWITCH (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>A03FW</td></tr> </table> 	Connector No.	B13	Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	Connector Type	A03FW	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>SB</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	SB	-	2	B	-																		
Connector No.	B13																																	
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)																																	
Connector Type	A03FW																																	
Terminal No.	Color of Wire	Signal Name																																
1	SB	-																																
2	B	-																																
<table border="1"> <tr><td>Connector No.</td><td>B14</td></tr> <tr><td>Connector Name</td><td>PARKING BRAKE SWITCH</td></tr> <tr><td>Connector Type</td><td>P01FB-A</td></tr> </table> 	Connector No.	B14	Connector Name	PARKING BRAKE SWITCH	Connector Type	P01FB-A	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	V	-																					
Connector No.	B14																																	
Connector Name	PARKING BRAKE SWITCH																																	
Connector Type	P01FB-A																																	
Terminal No.	Color of Wire	Signal Name																																
1	V	-																																
<table border="1"> <tr><td>Connector No.</td><td>B21</td></tr> <tr><td>Connector Name</td><td>FUEL LEVEL SENSOR UNIT (SUB)</td></tr> <tr><td>Connector Type</td><td>E02FGY-RS</td></tr> </table> 	Connector No.	B21	Connector Name	FUEL LEVEL SENSOR UNIT (SUB)	Connector Type	E02FGY-RS	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	Y	-	2	W	-																		
Connector No.	B21																																	
Connector Name	FUEL LEVEL SENSOR UNIT (SUB)																																	
Connector Type	E02FGY-RS																																	
Terminal No.	Color of Wire	Signal Name																																
1	Y	-																																
2	W	-																																
<table border="1"> <tr><td>Connector No.</td><td>B22</td></tr> <tr><td>Connector Name</td><td>FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)</td></tr> <tr><td>Connector Type</td><td>E08FGY-RS</td></tr> </table> 	Connector No.	B22	Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)	Connector Type	E08FGY-RS	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>5</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	2	W	-	5	B	-																		
Connector No.	B22																																	
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)																																	
Connector Type	E08FGY-RS																																	
Terminal No.	Color of Wire	Signal Name																																
2	W	-																																
5	B	-																																
<table border="1"> <tr><td>Connector No.</td><td>B54</td></tr> <tr><td>Connector Name</td><td>4WS MAIN CONTROL UNIT</td></tr> <tr><td>Connector Type</td><td>A38FW-M4</td></tr> </table> 	Connector No.	B54	Connector Name	4WS MAIN CONTROL UNIT	Connector Type	A38FW-M4	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>L</td><td>CAN-H</td></tr> <tr><td>8</td><td>P</td><td>CAN-L</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	L	CAN-H	8	P	CAN-L																		
Connector No.	B54																																	
Connector Name	4WS MAIN CONTROL UNIT																																	
Connector Type	A38FW-M4																																	
Terminal No.	Color of Wire	Signal Name																																
1	L	CAN-H																																
8	P	CAN-L																																
<table border="1"> <tr><td>Connector No.</td><td>E5</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>SA43MB-RS10-SJZ</td></tr> </table> 	Connector No.	E5	Connector Name	WIRE TO WIRE	Connector Type	SA43MB-RS10-SJZ	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>35</td><td>Y</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	35	Y	-																					
Connector No.	E5																																	
Connector Name	WIRE TO WIRE																																	
Connector Type	SA43MB-RS10-SJZ																																	
Terminal No.	Color of Wire	Signal Name																																
35	Y	-																																
<table border="1"> <tr><td>Connector No.</td><td>E6</td></tr> <tr><td>Connector Name</td><td>IPDM F/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Type</td><td>TH08FW-NH</td></tr> </table> 	Connector No.	E6	Connector Name	IPDM F/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type	TH08FW-NH	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>39</td><td>P</td><td>-</td></tr> <tr><td>40</td><td>L</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	39	P	-	40	L	-																		
Connector No.	E6																																	
Connector Name	IPDM F/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																	
Connector Type	TH08FW-NH																																	
Terminal No.	Color of Wire	Signal Name																																
39	P	-																																
40	L	-																																


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

COMBINATION METER

< ECU DIAGNOSIS >

METER





Connector No. E7	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) TH02FW-GS12-M4		Terminal No. 75	Color of Wire Y	Signal Name -
Connector No. E47	BRAKE FLUID LEVEL SWITCH YV02F3Y		Terminal No. 1 2	Color of Wire W B/W	Signal Name -
Connector No. E41	ABS ACTUATOR AND ELECTRIC UNIT BAA42FB-AH24-LH		Terminal No. 14 35	Color of Wire P L	Signal Name CAN-L CAN-H
Connector No. E32	WASHER LEVEL SWITCH Z02FBR		Terminal No. 1 2	Color of Wire LG B	Signal Name -
Connector No. E51	ICC BRAKE HOLD RELAY MS02FL-M2		Terminal No. 1 2 3 5	Color of Wire B V R P	Signal Name -
Connector No. E67	ICC SENSOR INTEGRATED UNIT RS02FB-PR		Terminal No. 2 3 4 5 6	Color of Wire V L L P	Signal Name BRK LMP RLY CAN-H CAN-L
Connector No. E76	AMBIENT SENSOR RS02FB		Terminal No. 1 2	Color of Wire G P	Signal Name -
Connector No. E103	FUSE BLOCK (U/B) NS18FW-GS		Terminal No. 2F 8F	Color of Wire W L	Signal Name -

JCNWA0005GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No. E106	WIRE TO WIRE THROFW-CS16-TM4		Terminal No.	Color of Wire	Signal Name
			6	P	-
			7	L	-
			18	O	-
			80	W	-
			81	P	-
			82	G	-
			93	LG	-
Connector No. F1	WIRE TO WIRE SAA38FB-RS10-SJZ2		Terminal No.	Color of Wire	Signal Name
			35	Y	-
Connector No. E110	STOP LAMP SWITCH M04FW-LC		Terminal No.	Color of Wire	Signal Name
			1	L	-
			2	W	-
			3	L	-
			4	SB	-
Connector No. E107	PARKING BRAKE SWITCH (A/T) TE01FW		Terminal No.	Color of Wire	Signal Name
			1	O	-
Connector No. F36	ALTERNATOR HS03FB		Terminal No.	Color of Wire	Signal Name
			2	G	L
Connector No. F51	A/T ASSEMBLY RK10FC-DGY		Terminal No.	Color of Wire	Signal Name
			3	L	-
			8	P	-
Connector No. F37	OIL PRESSURE SWITCH E01FGY-RS-AR		Terminal No.	Color of Wire	Signal Name
			1	Y	-
Connector No. F103	WIRE TO WIRE TK38FW-RS10		Terminal No.	Color of Wire	Signal Name
			2	G	-
			35	L	-
			36	P	-
			43	P	-
			44	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS


JCNWA0006GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	F108
Connector Name	AWD CONTROL UNIT
Connector Type	TH10FW-NH




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
16	P	CAN-L

Connector No.	F151
Connector Name	TGM (TRANSMISSION CONTROL MODULE)
Connector Type	SF10FBGY



Terminal No.	Color of Wire	Signal Name
1	BR	CAN-H
2	L/Y	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-H2




Terminal No.	Color of Wire	Signal Name
1A	GR	-
2A	G	-
5A	V	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-GS




Terminal No.	Color of Wire	Signal Name
3B	P	-
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-GS




Terminal No.	Color of Wire	Signal Name
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS(B)-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
18	V	-
80	W	-
81	BR	-
82	P	-
93	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-GS(B)-TM4



Terminal No.	Color of Wire	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
80	Y	-
82	B	-
96	V	-
97	SB	-

Connector No.	M16
Connector Name	AFS CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
30	L	CAN-H


JCNWA0007GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	M32
Connector Name	PADDLE SHIFTER (SHIFT DOWN)
Connector Type	AQ9FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	G	-

Connector No.	M39
Connector Name	PADDLE SHIFTER (SHIFT UP)
Connector Type	AQ4FW



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	O	-

Connector No.	M63
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name
1	GR	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	LG	AIR BAG
10	G	SECURITY
15	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-RH



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	L	-
7	B	-
9	O	-
10	P	-

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
4	P	STOP LAMP SW
5	L	SHIFT UP SW
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE SW
11	G	AUTO MODE SW
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN SW
26	G	PADDLE DOWN

24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	WASHER LEVEL SW
28	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
31	L	WASHER LEVEL SW
34	R	ILLUMINATION CONTROL
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

27	LG	COMM (METER->AMP)
28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)

JCNWA0008GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH

Terminal No.	Color of Wire	Signal Name
41	Y	ACC
42	Y	FUEL LEVEL SENS
43	G	AMB SENS
44	P	IGN
45	Y	BAT
46	B	GND
47	L	CAN-H
48	W	BRAKE FLUID LEVEL SW
49	B	FUEL LEVEL SENS GND
50	BR	AMB SENS GND
51	B	GND

Terminal No.	Color of Wire	Signal Name
41	Y	ACC
42	Y	FUEL LEVEL SENS
43	G	AMB SENS
44	P	IGN
45	Y	BAT
46	B	GND
47	L	CAN-H
48	W	BRAKE FLUID LEVEL SW
49	B	FUEL LEVEL SENS GND
50	BR	AMB SENS GND
51	B	GND

Connector No.	M87
Connector Name	AV CONTROL UNIT
Connector Type	TH40FW-NH

Terminal No.	Color of Wire	Signal Name
21	W	WIRE TO WIRE
22	W	WIRE TO WIRE
23	W	WIRE TO WIRE
24	W	WIRE TO WIRE
25	W	WIRE TO WIRE
26	W	WIRE TO WIRE
27	W	WIRE TO WIRE
28	W	WIRE TO WIRE
29	W	WIRE TO WIRE
30	W	WIRE TO WIRE
31	W	WIRE TO WIRE
32	W	WIRE TO WIRE
33	W	WIRE TO WIRE
34	W	WIRE TO WIRE
35	W	WIRE TO WIRE
36	W	WIRE TO WIRE
37	W	WIRE TO WIRE
38	W	WIRE TO WIRE
39	W	WIRE TO WIRE
40	W	WIRE TO WIRE
41	W	WIRE TO WIRE
42	W	WIRE TO WIRE
43	W	WIRE TO WIRE
44	W	WIRE TO WIRE
45	W	WIRE TO WIRE
46	W	WIRE TO WIRE
47	W	WIRE TO WIRE
48	W	WIRE TO WIRE
49	W	WIRE TO WIRE
50	W	WIRE TO WIRE
51	W	WIRE TO WIRE
52	W	WIRE TO WIRE
53	W	WIRE TO WIRE
54	W	WIRE TO WIRE
55	W	WIRE TO WIRE
56	W	WIRE TO WIRE
57	W	WIRE TO WIRE
58	W	WIRE TO WIRE
59	W	WIRE TO WIRE
60	W	WIRE TO WIRE
61	W	WIRE TO WIRE
62	W	WIRE TO WIRE
63	W	WIRE TO WIRE
64	W	WIRE TO WIRE
65	W	WIRE TO WIRE
66	W	WIRE TO WIRE
67	W	WIRE TO WIRE
68	W	WIRE TO WIRE
69	W	WIRE TO WIRE
70	W	WIRE TO WIRE
71	W	WIRE TO WIRE
72	W	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name
52	L	CAN-H
53	P	CAN-L

Terminal No.	Color of Wire	Signal Name
72	P	CAN-L

Connector No.	M83
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH

Terminal No.	Color of Wire	Signal Name
47	W	WIRE TO WIRE
48	W	WIRE TO WIRE
49	W	WIRE TO WIRE
50	W	WIRE TO WIRE
51	W	WIRE TO WIRE
52	W	WIRE TO WIRE
53	W	WIRE TO WIRE
54	W	WIRE TO WIRE
55	W	WIRE TO WIRE
56	W	WIRE TO WIRE
57	W	WIRE TO WIRE
58	W	WIRE TO WIRE
59	W	WIRE TO WIRE
60	W	WIRE TO WIRE
61	W	WIRE TO WIRE
62	W	WIRE TO WIRE
63	W	WIRE TO WIRE
64	W	WIRE TO WIRE
65	W	WIRE TO WIRE
66	W	WIRE TO WIRE
67	W	WIRE TO WIRE
68	W	WIRE TO WIRE
69	W	WIRE TO WIRE
70	W	WIRE TO WIRE
71	W	WIRE TO WIRE
72	W	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name
44	BR	COMM (DISP->CONT)
55	SHIELD	SHIELD
56	Y	COMM (CONT->DISP)

Connector No.	M107
Connector Name	ECM
Connector Type	MAA24EGY-MEA8-LH-Z

Terminal No.	Color of Wire	Signal Name
128	W	WIRE TO WIRE
129	W	WIRE TO WIRE
130	W	WIRE TO WIRE
131	W	WIRE TO WIRE
132	W	WIRE TO WIRE
133	W	WIRE TO WIRE
134	W	WIRE TO WIRE
135	W	WIRE TO WIRE
136	W	WIRE TO WIRE
137	W	WIRE TO WIRE
138	W	WIRE TO WIRE
139	W	WIRE TO WIRE
140	W	WIRE TO WIRE
141	W	WIRE TO WIRE
142	W	WIRE TO WIRE
143	W	WIRE TO WIRE
144	W	WIRE TO WIRE
145	W	WIRE TO WIRE
146	W	WIRE TO WIRE
147	W	WIRE TO WIRE
148	W	WIRE TO WIRE
149	W	WIRE TO WIRE
150	W	WIRE TO WIRE
151	W	WIRE TO WIRE
152	W	WIRE TO WIRE
153	W	WIRE TO WIRE
154	W	WIRE TO WIRE
155	W	WIRE TO WIRE
156	W	WIRE TO WIRE
157	W	WIRE TO WIRE
158	W	WIRE TO WIRE
159	W	WIRE TO WIRE
160	W	WIRE TO WIRE
161	W	WIRE TO WIRE
162	W	WIRE TO WIRE
163	W	WIRE TO WIRE
164	W	WIRE TO WIRE
165	W	WIRE TO WIRE
166	W	WIRE TO WIRE
167	W	WIRE TO WIRE
168	W	WIRE TO WIRE
169	W	WIRE TO WIRE
170	W	WIRE TO WIRE
171	W	WIRE TO WIRE
172	W	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name
113	P	VHECANLI
114	L	VHECANHI

Connector No.	M85
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH

Terminal No.	Color of Wire	Signal Name
91	W	WIRE TO WIRE
92	W	WIRE TO WIRE
93	W	WIRE TO WIRE
94	W	WIRE TO WIRE
95	W	WIRE TO WIRE
96	W	WIRE TO WIRE
97	W	WIRE TO WIRE
98	W	WIRE TO WIRE
99	W	WIRE TO WIRE
100	W	WIRE TO WIRE
101	W	WIRE TO WIRE
102	W	WIRE TO WIRE
103	W	WIRE TO WIRE
104	W	WIRE TO WIRE
105	W	WIRE TO WIRE
106	W	WIRE TO WIRE
107	W	WIRE TO WIRE
108	W	WIRE TO WIRE
109	W	WIRE TO WIRE
110	W	WIRE TO WIRE
111	W	WIRE TO WIRE
112	W	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name
86	L	CAN-H
87	P	CAN-L

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK36MW-HS10

Terminal No.	Color of Wire	Signal Name
1	W	WIRE TO WIRE
2	W	WIRE TO WIRE
3	W	WIRE TO WIRE
4	W	WIRE TO WIRE
5	W	WIRE TO WIRE
6	W	WIRE TO WIRE
7	W	WIRE TO WIRE
8	W	WIRE TO WIRE
9	W	WIRE TO WIRE
10	W	WIRE TO WIRE
11	W	WIRE TO WIRE
12	W	WIRE TO WIRE
13	W	WIRE TO WIRE
14	W	WIRE TO WIRE
15	W	WIRE TO WIRE
16	W	WIRE TO WIRE
17	W	WIRE TO WIRE
18	W	WIRE TO WIRE
19	W	WIRE TO WIRE
20	W	WIRE TO WIRE
21	W	WIRE TO WIRE
22	W	WIRE TO WIRE
23	W	WIRE TO WIRE
24	W	WIRE TO WIRE
25	W	WIRE TO WIRE
26	W	WIRE TO WIRE
27	W	WIRE TO WIRE
28	W	WIRE TO WIRE
29	W	WIRE TO WIRE
30	W	WIRE TO WIRE
31	W	WIRE TO WIRE
32	W	WIRE TO WIRE
33	W	WIRE TO WIRE
34	W	WIRE TO WIRE
35	W	WIRE TO WIRE
36	W	WIRE TO WIRE
37	W	WIRE TO WIRE
38	W	WIRE TO WIRE
39	W	WIRE TO WIRE
40	W	WIRE TO WIRE
41	W	WIRE TO WIRE
42	W	WIRE TO WIRE
43	W	WIRE TO WIRE
44	W	WIRE TO WIRE
45	W	WIRE TO WIRE
46	W	WIRE TO WIRE
47	W	WIRE TO WIRE
48	W	WIRE TO WIRE
49	W	WIRE TO WIRE
50	W	WIRE TO WIRE
51	W	WIRE TO WIRE
52	W	WIRE TO WIRE
53	W	WIRE TO WIRE
54	W	WIRE TO WIRE
55	W	WIRE TO WIRE
56	W	WIRE TO WIRE
57	W	WIRE TO WIRE
58	W	WIRE TO WIRE
59	W	WIRE TO WIRE
60	W	WIRE TO WIRE
61	W	WIRE TO WIRE
62	W	WIRE TO WIRE
63	W	WIRE TO WIRE
64	W	WIRE TO WIRE
65	W	WIRE TO WIRE
66	W	WIRE TO WIRE
67	W	WIRE TO WIRE
68	W	WIRE TO WIRE
69	W	WIRE TO WIRE
70	W	WIRE TO WIRE
71	W	WIRE TO WIRE
72	W	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name
2	W	WIRE TO WIRE
35	L	WIRE TO WIRE
36	P	WIRE TO WIRE
43	P	WIRE TO WIRE
44	L	WIRE TO WIRE

COMBINATION METER

< ECU DIAGNOSIS >

METER	Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name
	M122	BCM (BODY CONTROL MODULE)	TH40FB-NH	90	P	CAN-L
				91	L	CAN-H
	M123	BCM (BODY CONTROL MODULE)	TH40FG-NH	141	G	SECURITY INDICATOR OUTPUT
	M137	A/T DEVICE	TH12FW-NH	1	W	-
				2	V	-
				3	L	-
				4	B	-
				5	G	-
	M147	AIR BAG DIAGNOSIS SENSOR UNIT	TK28FY-EX-SG	15	LG	AIR BAG W/L

Fail Safe

FAIL SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

JCNWA0010GE

INFOID:000000000964501

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

COMBINATION METER

< ECU DIAGNOSIS >

Function		Specifications
Speedometer		Reset to zero by suspending communication.
Tachometer		
Fuel gauge		
Water temperature gauge		
Illumination control		When suspending communication, change to nighttime mode.
Information display		The display turns off by suspending communication.
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	VDC OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	BA warning lamp	
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Front fog indicator lamp	
	Oil pressure warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	Key warning lamp	
	AFS OFF indicator lamp	
	4WAS warning lamp	
Master warning lamp		

DTC Index

INFOID:000000000964502

Refer to [MWI-97, "DTC Index"](#).

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

UNIFIED METER AND A/C AMP.

Reference Value

INFOID:000000000964503

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h] or [mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [lit.]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC indicator lamp ON	On
		VDC indicator lamp OFF	Off
SLIP IND	Ignition switch ON	Slip indicator lamp ON	On
		Slip indicator lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning displayed	On
		Door warning not displayed	Off
TRUNK/GLAS-H	Ignition switch ON	Trunk warning displayed	On
		Trunk warning not displayed	Off
HI-BEAM IND	Ignition switch ON	Hi-beam indicator lamp ON	On
		Hi-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn indicator lamp ON	On
		Turn indicator lamp OFF	Off
FR FOG IND	Ignition switch ON	Front fog indicator lamp ON	On
		Front fog indicator lamp OFF	Off
RR FOG IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
LIGHT IND	Ignition switch ON	Light indicator lamp ON	On
		Light indicator lamp OFF	Off

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On
		Oil pressure warning lamp OFF	Off
MIL	Ignition switch ON	Malfunction warning lamp ON	On
		Malfunction warning lamp OFF	Off
CRUISE IND	Ignition switch ON	Cruise indicator displayed	On
		Cruise indicator not displayed	Off
SET IND	Ignition switch ON	Set indicator lamp ON	On
		Set indicator lamp OFF	Off
CRUISE W/L	Ignition switch ON	Cruise warning lamp ON	On
		Cruise warning lamp OFF	Off
BA W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
ATC/T-AMT W/L	Ignition switch ON	A/T check warning lamp ON	On
		A/T check warning lamp OFF	Off
4WD W/L	Ignition switch ON	AWD warning lamp ON	On
		AWD warning lamp OFF	Off
4WD LOCK IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
FUEL W/L	Ignition switch ON	Low-fuel warning displayed	On
		Low-fuel warning not displayed	Off
WASHER W/L	Ignition switch ON	Washer warning displayed	On
		Washer warning not displayed	Off
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On
		Low tire pressure lamp OFF	Off
KEY G/Y W/L	Ignition switch ON	Key warning lamp ON	On
		Key warning lamp OFF	Off
AFS OFF IND	Ignition switch ON	AFS OFF indicator lamp ON	On
		AFS OFF indicator lamp OFF	Off
4WAS/RAS W/L	Ignition switch ON	4WAS warning lamp ON	On
		4WAS warning lamp OFF	Off

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status	
LCD	Ignition switch ON	Engine start information display (A/T model)	B&P I	A
		Engine start information display (M/T model)	C&P I	
	Ignition switch ACC	Engine start information display (A/T model)	B&P N	B
		Engine start information display (M/T model)	C&P N	
	Ignition switch LOCK	Key ID warning display	ID NG	C
	Ignition switch LOCK	Steering lock information display	ROTAT	
	Ignition switch LOCK	P position warning display	SFT P	D
	Ignition switch LOCK	Intelligent Key insert information display	INSRT	E
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT	
	Ignition switch ON	Take away warning display	NO KY	F
	Ignition switch LOCK	Key warning display	OUTKY	G
Ignition switch ON	ICC sensor integrated unit warning display	LK WN		
ACC TARGET	Ignition switch ON	Vehicle ahead detection indicator displayed	On	H
		Vehicle ahead detection indicator not displayed	Off	
ACC DISTANCE	Ignition switch ON	When following distance set to "LONG"	LONG	I
		When following distance set to "MIDDLE"	MID	
		When following distance set to "SHORT"	SHORT	J
		Set distance indicator not displayed	Off	
ACC OWN VHL	Ignition switch ON	Own vehicle indicator displayed	On	
		Own vehicle indicator not displayed	Off	K
ACC SET SPEED	Ignition switch ON	Set vehicle speed indicator not displayed	Off	
		Set vehicle speed indicator displayed	On	L
ACC UNIT	Ignition switch ON	Set vehicle speed indicator unit display ON	On	
		Set vehicle speed indicator unit display OFF	Off	M
SHIFT IND	Ignition switch ON	Shift position indicator P display	P	
		Shift position indicator R display	R	
		Shift position indicator N display	N	
		Shift position indicator D display	D	WCS
		Shift position indicator M1 display	M1	
		Shift position indicator M2 display	M2	O
		Shift position indicator M3 display	M3	
		Shift position indicator M4 display	M4	
Shift position indicator M5 display	M5	P		
AT S MODE SW	Ignition switch ON	Snow mode switch ON	On	
		Snow mode switch OFF	Off	
AT P MODE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off	

UNIFIED METER AND A/C AMP.


< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status
M RANGE SW	Ignition switch ON	Selector lever manual mode position	On
		Other than the above	Off
NM RANGE SW	Ignition switch ON	Selector lever manual mode position	Off
		Other than the above	On
AT SFT UP SW	Ignition switch ON	Selector lever + position	On
		Other than the above	Off
AT SFT DWN SW	Ignition switch ON	Selector lever – position	On
		Other than the above	Off
ST SFT UP SW	Ignition switch ON	Paddle shifter switch up operation	On
		Other than the above	Off
ST SFT DWN SW	Ignition switch ON	Paddle shifter switch down operation	On
		Other than the above	Off
COMP FB SIG	Ignition switch ON	A/C compressor activation condition	On
		A/C compressor deactivation condition	Off
4WD LOCK SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt not fastened	On
		Seat belt fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low-fuel warning displayed	
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off

NOTE:

Some items are not available according to vehicle specification.




TERMINAL LAYOUT



PHYSICAL VALUES

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
4 (P)	Ground	Stop lamp switch signal	Input	Ignition switch OFF	Brake pedal is depressed	12 V
					Other than the above	0 V
5 (L)	Ground	Manual mode shift up signal	Input	Ignition switch ON	Selector lever UP operation	0 V
					Other than the above	12 V
6 (O)	Ground	Paddle shifter up signal	Input	Ignition switch ON	<ul style="list-style-type: none"> • Selector lever DS position • Paddle shift up operation 	0 V
					Other than the above	12 V
7 (GR)	Ground	Communication signal (AMP. → METER)	Output	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIA3362E</p>
8 (L)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0015GB</p>
9 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When seat belt is fastened	12 V
					When seat belt is not fastened	0 V
10 (W)	Ground	Manual mode signal	Input	Ignition switch ON	Selector lever DS position	0 V
					Other than the above	12 V
11 (G)	Ground	Not manual mode signal	Input	Ignition switch ON	Selector lever DS position	12 V
					Other than the above	0 V
14 (BR)	Ground	Communication signal (LCD → AMP.)	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0028GB</p>
23 (Y)	Ground	A/T snow switch signal	Input	Ignition switch ON	Snow mode switch ON	12 V
					Snow mode switch OFF	0 V
25 (V)	Ground	Manual mode shift down signal	Input	Ignition switch ON	Selector lever down operation	0 V
					Other than the above	12 V

A
B
C
D
E
F
G
H
I
J
K
L
M
P

WCS

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
26 (G)	Ground	Paddle shift down signal	Input	Ignition switch ON	<ul style="list-style-type: none"> • Selector lever DS position • Paddle shift down operation 	0 V
				Other than the above	12 V	
27 (LG)	Ground	Communication signal (METER → AMP.)	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIA3361E</p>
28 (R)	Ground	Vehicle speed signal output (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0012GB</p>
30 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
				Ignition switch ON	Parking brake OFF	 <p style="text-align: right; font-size: small;">JSNIA0007GB</p>
34 (Y)	Ground	Communication signal (AMP. → LCD)	Output	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0027GB</p>
41 (V)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
42 (Y)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0013GB</p>

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
45 (P)	Ground	Ambient sensor signal	Input	—	—	<p style="text-align: right; font-size: small;">JSNIA0014GB</p>
53 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
54 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
55 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
56 (L)	Ground	CAN-H	—	—	—	—
57 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	<p style="text-align: right; font-size: small;">JSNIA0008GB</p>
				—	The brake fluid level is lower than the low level	0 V
58 (B)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
61 (BR)	Ground	Ambient sensor signal ground	—	Ignition switch ON	—	0 V
71 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
72 (P)	Ground	CAN-L	—	—	—	—

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O


P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Wiring Diagram — METER —

INFOID:00000000964504




UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

- ◊ A : With AT
- ◊ NV : With NAVI
- ◊ ON : Without NAVI
- ◊ IC : With ICC
- ◊ AS : With 4WAS
- ◊ PA : With automatic drive positioner or 4WAS
- ◊ AP : Without automatic drive positioner and 4WAS
- ◊ SS : With paddle shifter switch

*: This connector is not shown in "Harness Layout".



JCNWA0002GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No. E7	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) TH02FW-GS12-M4		Terminal No. 75	Color of Wire Y	Signal Name -
Connector No. E32	WASHER LEVEL SWITCH Z02FBR		Terminal No. 1 2	Color of Wire LG B	Signal Name -
Connector No. E41	ABS ACTUATOR AND ELECTRIC UNIT BAA42FB-AH24-LH		Terminal No. 14 35	Color of Wire P L	Signal Name CAN-L CAN-H
Connector No. E47	BRAKE FLUID LEVEL SWITCH YV02F3Y		Terminal No. 1 2	Color of Wire W B/W	Signal Name -
Connector No. E51	ICC BRAKE HOLD RELAY MS02FL-M2		Terminal No. 1 2 3 5	Color of Wire B V R P	Signal Name -
Connector No. E67	ICC SENSOR INTEGRATED UNIT RS02FB-PR		Terminal No. 2 3 4 6	Color of Wire V L P	Signal Name BRK LMP RLY CAN-H CAN-L
Connector No. E76	AMBIENT SENSOR RS02FB		Terminal No. 1 2	Color of Wire G P	Signal Name -
Connector No. E103	FUSE BLOCK (U/B) NS18FW-GS		Terminal No. 2F 8F	Color of Wire W L	Signal Name -


JCNWA0005GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No.	F108
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
16	P	CAN-L

Connector No.	F151
Connector Name	TGM (TRANSMISSION CONTROL MODULE)
Connector Type	SF10FEGY




Terminal No.	Color of Wire	Signal Name
1	BR	CAN-H
2	L/Y	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-H2




Terminal No.	Color of Wire	Signal Name
1A	GR	-
2A	G	-
5A	V	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-GS




Terminal No.	Color of Wire	Signal Name
3B	P	-
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-GS




Terminal No.	Color of Wire	Signal Name
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS(B)-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
18	V	-
80	W	-
81	BR	-
82	P	-
93	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-GS(B)-TM4



Terminal No.	Color of Wire	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
80	Y	-
82	B	-
96	V	-
97	SB	-

Connector No.	M16
Connector Name	AFS CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
30	L	CAN-H


JCNWA0007GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No.	M32
Connector Name	PADDLE SHIFTER (SHIFT DOWN)
Connector Type	AQ9FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	G	-

Connector No.	M39
Connector Name	PADDLE SHIFTER (SHIFT UP)
Connector Type	AQ4FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	O	-

Connector No.	M63
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name
1	GR	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	LG	AIR BAG
10	G	SECURITY
15	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-RH



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	L	-
7	B	-
9	O	-
10	P	-

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
4	P	STOP LAMP SW
5	L	SHIFT UP SW
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE SW
11	G	AUTO MODE SW
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN SW
26	G	PADDLE DOWN

24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	WASHER LEVEL SW
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
31	L	WASHER LEVEL SW
34	R	ILLUMINATION CONTROL
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

27	LG	COMM (METER->AMP)
28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)

JCNWA0008GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
41	Y	ACC
42	Y	FUEL LEVEL SENS
43	G	AMB SENS
44	P	IGN
45	Y	BAT
46	B	GND
47	L	CAN-H
48	W	BRAKE FLUID LEVEL SW
49	B	FUEL LEVEL SENS GND
50	BR	AMB SENS GND
51	B	GND

Connector No.	M87
Connector Name	AV CONTROL UNIT
Connector Type	TH40FW-NH



42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
52	L	CAN-H
53	P	CAN-L

72	P	CAN-L
----	---	-------

Connector No.	M83
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



47	46	45	44	43	42	41	40	39	38	37	36
59	58	57	56	55	54	53	52	51	50	49	48

Terminal No.	Color of Wire	Signal Name
44	BR	COMM (DISP->CONT)
55	SHIELD	SHIELD
56	Y	COMM (CONT->DISP)

Connector No.	M107
Connector Name	ECM
Connector Type	MAA24EGY-MEA8-LH-Z



128	124	123	118	112	108	104	100
127	123	118	113	111	107	103	99
126	122	118	114	110	106	102	98
125	121	117	113	108	104	101	97

Terminal No.	Color of Wire	Signal Name
113	P	VHECANLI
114	L	VHECANHI

Connector No.	M85
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76
107	106	105	104	103	102	101	100	99	98	97	96	95	94	93	92

Terminal No.	Color of Wire	Signal Name
86	L	CAN-H
87	P	CAN-L

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK36MW-NS10



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32


Terminal No.	Color of Wire	Signal Name
2	W	-
35	L	-
36	P	-
43	P	-
44	L	-

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >


METER

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH




Terminal No.	Color of Wire	Signal Name
90	P	CAN-L
91	L	CAN-H

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH




Terminal No.	Color of Wire	Signal Name
141	G	SECURITY INDICATOR OUTPUT

Connector No.	M137
Connector Name	A/T DEVICE
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	L	-
4	B	-
5	G	-

Connector No.	M147
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	TK28FY-EX-SC



Terminal No.	Color of Wire	Signal Name
15	LG	AIR BAG W/L

Fail Safe

FAIL SAFE

The unified meter and A/C amp. activates the fail-safe control if CAN communication with each unit is malfunctioning.

JCNWA0010GE

INFOID:000000000964505

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Function	Specifications	
Speedometer	Reset to zero by suspending communication.	
Tachometer		
Fuel gauge		
Water temperature gauge		
Illumination control	When suspending communication, change to nighttime mode.	
Information display	The display turns off by suspending communication.	
Buzzer	The buzzer turns off by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	VDC OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	BA warning lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	4WAS warning lamp	The lamp blinking caused by communication malfunction
	AFS OFF indicator lamp	
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Front fog indicator lamp	
	Oil pressure warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
Key warning lamp		
Master warning lamp		

DTC Index

INFOID:000000000964506

Display contents of CONSULT-III	Time	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	CRNT, 1 - 39	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-40
CONTROL UNIT (CAN) [U1010]	CRNT, 1 - 39	When detecting error during the initial diagnosis of CAN controller of unified meter and A/C amp.	MWI-41
COMM ERROR 1 [B2201]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-42
COMM ERROR 2 [B2202]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-44
VEHICLE SPEED [B2205]	CRNT, 1 - 39	The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-46
ENGINE SPEED [B2267]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-47
WATER TEMP [B2268]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-48

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000000964507

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Other than front wiper switch LO	OFF
	Front wiper switch LO	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER INT	Other than front wiper switch INT	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Front wiper is not in STOP position	OFF
	Front wiper is in STOP position	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Other than turn signal switch LH	OFF
	Turn signal switch LH	ON
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	OFF
	Lighting switch 1ST or 2ND	ON
HI BEAM SW	Other than lighting switch HI	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
AUTO LIGHT SW	Other than lighting switch AUTO	OFF
	Lighting switch AUTO	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
RR FOG SW	NOTE: The item is indicated, but not monitored.	OFF
DOOR SW-DR	Driver door closed	OFF
	Driver door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	OFF
CDL LOCK SW	Other than power door lock switch LOCK	OFF
	Power door lock switch LOCK	ON
CDL UNLOCK SW	Other than power door lock switch UNLOCK	OFF
	Power door lock switch UNLOCK	ON
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	OFF
HAZARD SW	Hazard switch is not pressed	OFF
	Hazard switch is pressed	ON
REAR DEF SW	NOTE: The item is indicated, but not monitored.	OFF
H/L WASH SW	NOTE: The item is indicated, but not monitored.	OFF
TR CANCEL SW	Trunk lid opener cancel switch OFF	OFF
	Trunk lid opener cancel switch ON	ON
TR/BD OPEN SW	Trunk lid opener switch OFF	OFF
	While the trunk lid opener switch is turned ON	ON
TRNK/HAT MNTR	Trunk lid closed	OFF
	Trunk lid opened	ON
RKE-LOCK	LOCK button of Intelligent Key is not pressed	OFF
	LOCK button of Intelligent Key is pressed	ON
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	OFF
	UNLOCK button of Intelligent Key is pressed	ON
RKE-TR/BD	TRUNK OPEN button of Intelligent Key is not pressed	OFF
	TRUNK OPEN button of Intelligent Key is pressed	ON
RKE-PANIC	PANIC button of Intelligent Key is not pressed	OFF
	PANIC button of Intelligent Key is pressed	ON
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	OFF
	UNLOCK button of Intelligent Key is pressed and held	ON
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	OFF
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	ON
OPTICAL SENSOR	Outside of the vehicle bright	Close to 5 V
	Outside of the vehicle dark	Close to 0 V
REQ SW-DR	Driver door request switch is not pressed	OFF
	Driver door request switch is pressed	ON
REQ SW-AS	Passenger door request switch is not pressed	OFF
	Passenger door request switch is pressed	ON
REQ SW-BD/TR	Trunk request switch is not pressed	OFF
	Trunk request switch is pressed	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
PUSH SW	Push-button ignition switch (push switch) is not pressed	OFF	A
	Push-button ignition switch (push switch) is pressed	ON	
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	OFF	B
	Ignition switch in ON position	ON	
ACC RLY -F/B	Ignition switch in OFF position	OFF	C
	Ignition switch in ACC or ON position	ON	
CLUCH SW	The clutch pedal is not depressed	OFF	D
	The clutch pedal is depressed	ON	
BRAKE SW 1	The brake pedal is not depressed	ON	E
	The brake pedal is depressed	OFF	
DETE/CANCL SW	Selector lever in P position	OFF	F
	Selector lever in any position other than P	ON	
SFT PN/N SW	Selector lever in any position other than P and N	OFF	G
	Selector lever in P or N position	ON	
S/L -LOCK	Steering is locked	OFF	H
	Steering is unlocked	ON	
S/L -UNLOCK	Steering is unlocked	OFF	I
	Steering is locked	ON	
S/L RELAY-F/B	Ignition switch is OFF or ACC position	OFF	J
	Ignition switch is ON position	ON	
UNLK SEN-DR	Driver door is unlocked	OFF	K
	Driver door is locked	ON	
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	OFF	L
	Push-button ignition switch (push-switch) is pressed	ON	
IGN RLY1 -F/B	Ignition switch is OFF or ACC position	OFF	M
	Ignition switch is ON position	ON	
DETE SW -IPDM	Selector lever in P position	OFF	WCS
	Selector lever in any position other than P	ON	
SFT PN -IPDM	Selector lever in any position other than P and N	OFF	O
	Selector lever in P or N position	ON	
SFT P -MET	Selector lever in any position other than P	OFF	P
	Selector lever in P position	ON	
SFT N -MET	Selector lever in any position other than N	OFF	
	Selector lever in N position	ON	
ENGINE STATE	Engine stopped	STOP	
	While the engine stalls	STALL	
	At engine cranking	CRANK	
	Engine running	RUN	
S/L LOCK-IPDM	Steering is locked	OFF	
	Steering is unlocked	ON	
S/L UNLK-IPDM	Steering is unlocked	OFF	
	Steering is locked	ON	
S/L RELAY-REQ	Ignition switch in OFF or ACC position	OFF	
	Ignition switch in ON position	ON	


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLK
ID OK FLAG	Ignition switch in ACC or ON position	RESET
	Ignition switch in OFF position	SET
PRMT ENG STRT	The engine start is prohibited	RESET
	The engine start is permitted	SET
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	RESET
KEY SW -SLOT	Intelligent Key is not inserted into key slot	OFF
	Intelligent Key is inserted into key slot	ON
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	DONE
	ID of front LH tire transmitter is not registered	YET
ID REGST FR1	ID of front RH tire transmitter is registered	DONE
	ID of front RH tire transmitter is not registered	YET
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE
	ID of rear RH tire transmitter is not registered	YET
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE
	ID of rear LH tire transmitter is not registered	YET
WARNING LAMP	Tire pressure indicator OFF	OFF
	Tire pressure indicator ON	ON
BUZZER	Tire pressure warning alarm is not sounding	OFF
	Tire pressure warning alarm is sounding	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >
 TERMINAL LAYOUT




PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time		0 V
				Any other time after passing the interior room lamp battery saver operation time		Battery voltage
5 (V)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	Battery voltage
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	Battery voltage
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right;"><small>JSNIA0010GB</small></p>
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF	Battery voltage
					ACC or ON	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
17 (W)	Ground	Turn signal (front RH)	Output	Ignition switch ON	Turn signal switch OFF	0 V
				Turn signal switch RH	 <p style="text-align: right;">PKID0926E 6.5 V</p>	
18 (O)	Ground	Turn signal (front LH)	Output	Ignition switch ON	Turn signal switch OFF	0 V
				Turn signal switch LH	 <p style="text-align: right;">PKID0926E 6.5 V</p>	
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
				ON	0 V	
20 (V)	Ground	Turn signal (rear RH)	Output	Ignition switch ON	Turn signal switch OFF	0 V
				Turn signal switch RH	 <p style="text-align: right;">PKID0926E 6.5 V</p>	
23 (G)	Ground	Trunk lid opening.	Output	Trunk lid	Open (Trunk lid opener actuator is activated)	Battery voltage
				Close (Trunk lid opener actuator is not activated)	0 V	
25 (G)	Ground	Turn signal (rear LH)	Output	Ignition switch ON	Turn signal switch OFF	0 V
				Turn signal switch LH	 <p style="text-align: right;">PKID0926E 6.5 V</p>	
30 (R)	Ground	Trunk room lamp	Output	Trunk room lamp	ON	0 V
				OFF	Battery voltage	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
34 (SB)	Ground	Trunk room antenna 1 (-)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
35 (V)	Ground	Trunk room antenna 1 (+)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
38 (B)	Ground	Rear bumper anten- na (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
39 (W)	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC Battery voltage
				ON	0 V
50 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	OFF (Trunk is closed)
				ON (Trunk is open)	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch OFF (M/T models)	When the clutch pedal is depressed Battery voltage
				Ignition switch ON (A/T models)	When the clutch pedal is not depressed 0 V
					When selector lever is in P or N position and the brake is depressed Battery voltage
				When selector lever is in P or N position and the brake is not depressed 0 V	
61 (W)	Ground	Trunk request switch	Input	Trunk request switch	ON (Pressed) 0 V
				OFF (Not pressed)	<p style="text-align: right; font-size: small;">JPMIA0016GB</p>
64 (V)	Ground	Request switch buzzer	Output	Request switch buzzer	Sounding 0 V
				Not sounding Battery voltage	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
67 (GR)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Pressed	0 V
					Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (When rear RH door opens)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (When rear LH door opens)	0 V
72 (R)	Ground	Room antenna 2 (-) (center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >







Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
73 (G)	Ground	Room antenna 2 (+) (center console)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
75 (BR)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>
78 (Y)	Ground	Room antenna (-) (in- strument panel)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
79 (BR)	Ground	Room antenna (+) (instrument panel)	Output	Ignition switch OFF		
				When Intelligent Key is not in the passenger compart- ment		
80 (GR)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay (relay box) control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
83 (Y)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting		
				When operating either button on Intelligent Key		

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P








BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
87 (BR)	Ground	Combination switch INPUT 5	Input	All switch OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4 V
				Front fog lamp switch ON (Wiper intermittent dial 4)	 <small>JPMIA0037GB</small> 1.3 V
				Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	 <small>JPMIA0040GB</small> 1.3 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4 V
					Lighting switch HI (Wiper intermittent dial 4)	 <small>JPMIA0036GB</small> 1.3 V
					Lighting switch 2ND (Wiper intermittent dial 4)	 <small>JPMIA0037GB</small> 1.3 V
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 <small>JPMIA0040GB</small> 1.3 V
89 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
90 (P)	Ground	CAN - L	Input/ Output	—	—	
91 (L)	Ground	CAN - H	Input/ Output	—	—	
92 (LG)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF	0 V
					Blinking	 <small>JPMIA0015GB</small> 6.5 V
					ON	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T device (detention switch) power supply	Output	—		Battery voltage
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage
106 (W)	Ground	Steering wheel lock unit power supply	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Turn signal switch LH	 <p style="text-align: right; font-size: small;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch LO	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front washer switch ON	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P









BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF	<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6  <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 1.4 V
					Lighting switch PASS	 1.3 V
					Lighting switch 2ND	 1.3 V
					Front wiper switch INT	 1.3 V
					Front wiper switch HI	 1.3 V
					Pressed	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	Not pressed  1.1 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage	
					LOCK or UNLOCK	 <p style="text-align: right; font-size: small;">JMkia0066GB</p>	
					For 15 seconds after UN- LOCK	Battery voltage	
					15 seconds or later after UNLOCK	0 V	
113 (P)	Ground	Optical sensor signal	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
114 (R)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V	
						ON (Clutch pedal is de- pressed)	Battery voltage
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
						ON (Brake pedal is de- pressed)	Battery voltage
				ICC brake hold relay (With ICC)	OFF	0 V	
					ON	Battery voltage	
119 (SB)	Ground	Front door lock as- sembly driver side (unlock sensor)	Input	Driver door	LOCK status	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p>	
						UNLOCK status	0 V
							11.8 V
121 (R)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	Battery voltage		
				When Intelligent Key is not inserted into key slot	0 V		
122 (V)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0 V	
					ACC or ON	Battery voltage	
123 (W)	Ground	IGN feedback signal	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	<p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>	
				OFF (When passenger door closes)	0 V	
129 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	<p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p>	
				CANCEL	0 V	
132 (V)	Ground	Power window switch communication	Input/ Output	Ignition switch ON	<p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p>	
				Ignition switch OFF or ACC	0 V	
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	<p>NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p> <p style="text-align: right; font-size: small;">JPMIA0159GB</p>	
				ON (When tail lamps OFF)	5.5 V	
				ON (When tail lamps ON)	<p>NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p> <p style="text-align: right; font-size: small;">JPMIA0159GB</p>	
OFF	0 V					
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	ON	0 V
				OFF	Battery voltage	
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON	0 V	
138 (V)	Ground	Receiver and sensor power supply output	Output	Ignition switch	OFF	0 V
				ACC or ON	5.0 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
139 (L)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	Standby state  OCC3881D	
				When receiving the signal from the transmitter  OCC3880D		
140 (GR)	Ground	Selector lever P/N position signal	Input	Selector lever	P or N position 12.0 V Except P and N positions 0 V	
				141 (G)	Ground	Security indicator signal
Blinking  JPMIA0014GB 11.3 V						
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0 V
					Lighting switch 1ST Lighting switch HI Lighting switch 2ND Turn signal switch RH  JPMIA0031GB 10.7 V	
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4) Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7  JPMIA0032GB 10.7 V	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	
					Front washer switch ON (Wiper intermittent dial 4)		
					Any of the conditions below with all switches OFF		
					<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 		
					10.7 V		
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V	
					Front wiper switch INT		
					Front wiper switch LO		
					Lighting switch AUTO		
					10.7 V		
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V	
					Front fog lamp switch ON		
					Lighting switch 2ND		
					Lighting switch PASS		
					10.7 V		
149 (W)	Ground	Tire pressure warn- ing check switch	Input	—	5 V		
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closes)		
					ON (When driver door opens)	0 V	
151 (G)	Ground	Rear window defog- ger relay	Output	Rear window de- fogger	Active	0 V	
					Not activated	Battery voltage	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Wiring Diagram — BCM —

INFOID:00000000964508




*: This connector is not shown in "Harness Layout".

2006/09/15

JCMWA0005Gf

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



JCMWA0006GE



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

- ◊ A : With AT
- ◊ NV : With NAVI
- ◊ ON : Without NAVI
- ◊ RE : With sunroof
- ◊ AN : With rear anti-pinch system
- ◊ OA : Without rear anti-pinch system
- ◊ SP : With sports seat
- ◊ PM : With automatic drive positioner




*: This connector is not shown in "Harness Layout".

JCMWA0007G1

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



JCMWA0008GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name
20	V	REAR FLASHER OUTPUT(RIGHT)
23	G	TRUNK OPENER OUTPUT
24	G	REAR FLASHER OUTPUT(LEFT)
30	R	TRUNK LAMP OUTPUT

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color of Wire	Signal Name
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(RAP)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color of Wire	Signal Name
34	SB	TRUNK ANTI+
35	V	TRUNK ANTI-
38	B	BACK ANTI+
39	W	BACK ANTI-
47	Y	ING USM CONTI
50	R	TRUNK SW
52	SB	ST CONT USM
61	W	TRUNK REQUEST SW
64	V	BUZZER
67	GR	INTERIOR TRUNK SW
68	BR	DOOR SW (RR RH)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name
4	LG	BAT SAVER OUTPUT
5	V	DOOR UNLOCK OUTPUT (AS)
7	Y	STEP LAMP OUTPUT
8	Y	DOOR LOCK OUTPUT (ALL)
9	G	DOOR UNLOCK OUTPUT (DR)
10	BR	DOOR UNLOCK OUTPUT (RR)
11	R	BAT FUSE
13	B	GND
14	W	RING/SW LED GND
15	Y	ACC LED
17	W	FRONT FLASHER OUTPUT(RIGHT)

69	R	DOOR SW (RR LH)
----	---	-----------------

18	O	FRONT FLASHER OUTPUT(LEFT)
19	V	ROOM LAMP OUTPUT

JCMWA0009G1


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

BCM (BODY CONTROL MODULE)


Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	AS DOOR ANT-
75	BR	AS DOOR ANT+
76	V	DR DOOR ANT-
77	LG	DR DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	W	IMMOBI ANTENNA SIGNAL
82	R	IGN ELEC CONT

83	Y	KEYLESS TUNER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	ENG SW
90	P	GAN-H
91	L	GAN-L
92	LG	KEY SLOT ILL ON LED
93	V	ACC CONT
95	O	A-T DEVICE
96	GR	S/L CONDITION 1
97	L	S/L CONDITION 2
98	P	AS REQUEST SW
99	R	SHIFT P
100	G	DR REQUEST SW
101	SB	IGN2 CONT
102	O	KEYLESS TUNER POWER SUPPLY
103	LG	S/L TRV (CRUI)
106	W	COMBI SW INPUT 1
107	LG	COMBI SW INPUT 4
108	R	COMBI SW INPUT 2
109	Y	HAZARD SW
110	G	S/L (K LINE)
111	Y	

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FC-NH



Terminal No.	Color of Wire	Signal Name
113	P	AUTO LIGHT SENSOR INPUT
114	R	CLUTCH SW
116	SB	STOP LAMP LOW
118	P	STOP LAMP HIGH
119	SB	DR CONDITION SW
121	R	KEY SWITCH SIGNAL
122	V	ACC F/B
123	W	IGN F/B
124	LG	DOOR SW (AS)
129	O	TRUNK CANDEL SW
132	V	POWER WINDOW SERIAL LINK

133	W	RMG/SW LED
134	GR	LOCK LED
137	O	SENSOR GND
138	V	AUTO LIGHT SENSOR POWER SUPPLY
139	L	RECEIVER SIGNAL
140	GR	SHIFT N/P
141	G	SECURITY INDICATOR OUTPUT
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	MODE TRG SW
150	GR	DOOR SW (DR)
151	G	REAR DEFOGGER OUTPUT

Fail Safe

JCMWA0010GE

INFOID:000000000964509

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals have been received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2563: HI VOLTAGE	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	500 ms after the power supply voltage decreases to less than 18 V
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 /h or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position <ul style="list-style-type: none"> - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)

DTC Inspection Priority Chart

INFOID:000000000964510

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> • B2562: LOW VOLTAGE • B2563: HI VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Priority	DTC
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2611: ACC RELAY • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-33
U1010: CONTROL UNIT (CAN)	—	—	—	BCS-34
U0415: VEHICLE SPEED SIG	—	—	—	BCS-35
B2013: ID DISCORD BCM-S/L	×	—	—	SEC-43
B2014: CHAIN OF S/L-BCM	×	—	—	SEC-44
B2190: NATS ANTENNA AMP	×	—	—	SEC-37
B2191: DIFFERENCE OF KEY	×	—	—	SEC-40
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-41
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-42
B2553: IGNITION RELAY	—	—	—	PCS-48
B2555: STOP LAMP	—	—	—	SEC-47
B2556: PUSH-BTN IGN SW	—	×	—	SEC-49
B2557: VEHICLE SPEED	×	×	—	SEC-51
B2560: STARTER CONT RELAY	×	×	—	SEC-52
B2562: LOW VOLTAGE	—	—	—	BCS-36
B2563: HI VOLTAGE	×	×	—	BCS-37
B2601: SHIFT POSITION	×	×	—	SEC-53
B2602: SHIFT POSITION	×	×	—	SEC-56
B2603: SHIFT POSI STATUS	×	×	—	SEC-58
B2604: PNP SW	×	×	—	SEC-61
B2605: PNP SW	×	×	—	SEC-63
B2606: S/L RELAY	×	×	—	SEC-65
B2607: S/L RELAY	×	×	—	SEC-66
B2608: STARTER RELAY	×	×	—	SEC-68
B2609: S/L STATUS	×	×	—	SEC-70
B260A: IGNITION RELAY	×	×	—	PCS-50
B260B: STEERING LOCK VNIT	—	×	—	SEC-74
B260C: STEERING LOCK VNIT	—	×	—	SEC-75
B260D: STEERING LOCK VNIT	—	×	—	SEC-76
B260F: ENG STATE SIG LOST	×	×	—	SEC-77
B2611: ACC RELAY	—	—	—	PCS-52
B2612: S/L STATUS	×	×	—	SEC-79
B2614: ACC RELAY CIRC	—	×	—	PCS-54
B2615: BLOWER RELAY CIRC	—	×	—	PCS-57

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2616: IGN RELAY CIRC	—	×	—	PCS-60
B2617: STARTER RELAY CIRC	×	×	—	SEC-83
B2618: BCM	×	×	—	PCS-63
B2619: BCM	×	×	—	SEC-85
B261A: PUSH-BTN IGN SW	—	×	—	SEC-86
B261E: VEHICLE TYPE	×	× (Turn ON for 15 seconds)	—	SEC-88
B2621: INSIDE ANTENNA	—	—	—	DLK-58
B2622: INSIDE ANTENNA	—	—	—	DLK-60
B2623: INSIDE ANTENNA	—	—	—	DLK-62
B26E1: ENG STATE NO RES	×	×	—	SEC-78
C1704: LOW PRESSURE FL	—	—	×	WT-14
C1705: LOW PRESSURE FR	—	—	×	WT-14
C1706: LOW PRESSURE RR	—	—	×	WT-14
C1707: LOW PRESSURE RL	—	—	×	WT-14
C1708: [NO DATA] FL	—	—	×	WT-16
C1709: [NO DATA] FR	—	—	×	WT-16
C1710: [NO DATA] RR	—	—	×	WT-16
C1711: [NO DATA] RL	—	—	×	WT-16
C1712: [CHECKSUM ERR] FL	—	—	×	WT-19
C1713: [CHECKSUM ERR] FR	—	—	×	WT-19
C1714: [CHECKSUM ERR] RR	—	—	×	WT-19
C1715: [CHECKSUM ERR] RL	—	—	×	WT-19
C1716: [PRESSDATA ERR] FL	—	—	×	WT-22
C1717: [PRESSDATA ERR] FR	—	—	×	WT-22
C1718: [PRESSDATA ERR] RR	—	—	×	WT-22
C1719: [PRESSDATA ERR] RL	—	—	×	WT-22
C1720: [CODE ERR] FL	—	—	×	WT-24
C1721: [CODE ERR] FR	—	—	×	WT-24
C1722: [CODE ERR] RR	—	—	×	WT-24
C1723: [CODE ERR] RL	—	—	×	WT-24
C1724: [BATT VOLT LOW] FL	—	—	×	WT-27
C1725: [BATT VOLT LOW] FR	—	—	×	WT-27
C1726: [BATT VOLT LOW] RR	—	—	×	WT-27
C1727: [BATT VOLT LOW] RL	—	—	×	WT-27
C1729: VHCL SPEED SIG ERR	—	—	×	WT-30
C1734: CONTROL UNIT	—	—	×	WT-31

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:000000000964512

- The parking brake warning buzzer sounds continuously during vehicle travel though the parking brake is released
- The parking brake warning buzzer does not sound at all even though driving the vehicle with the parking brake applied.

Diagnosis Procedure

INFOID:000000000964513

1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

Parking brake ON : ON
Parking brake OFF : OFF

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Perform a inspection for the parking brake switch signal circuit. Refer to [MWI-59, "Diagnosis Procedure \(A/T model\)"](#) or [MWI-59, "Diagnosis Procedure \(M/T model\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit inspection for the parking brake switch. Refer to [BRC-69, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the parking brake switch. Refer to [PB-7, "PEDAL TYPE : Removal and Installation"](#) (pedal type) or [PB-8, "LEVER TYPE : Removal and Installation"](#) (lever type).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE LIGHT REMINDER WARNING DOES NOT SOUND

Description

INFOID:000000000964514

Light reminder warning does not sound even though headlamp is illuminated.

Diagnosis Procedure

INFOID:000000000964515

1.CHECK COMBINATION SWITCH (LIGHT SWITCH) OPERATION

Check that the headlamps operate normally by operating the combination switch (light switch).

Do they operate normally?

YES >> GO TO 2.

NO >> Refer to [EXL-179, "Diagnosis Procedure"](#).

2.CHECK FRONT DOOR SWITCH (DRIVER SIDE) SIGNAL CIRCUIT

Perform the inspection for the front door switch (driver side) signal circuit. Refer to [DLK-65, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK FRONT DOOR SWITCH (DRIVER SIDE) UNIT

Perform a unit inspection for the front door switch (driver side). Refer to [DLK-67, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Replace the front door switch (driver side). Refer to [DLK-218, "Removal and Installation"](#).

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:000000000964516

- Seat belt warning does not sound even though driver seat belt is not fastened.
- Seat belt warning sounds even though driver seat belt is fastened.

Diagnosis Procedure

INFOID:000000000964517

1. CHECK SEAT BELT WARNING LAMP

1. Turn ignition switch ON.
2. Check the operation of the seat belt warning lamp in the combination meter.

Seat belt fastened : OFF
Seat belt not fastened : ON

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Check the buckle switch input signal with the "Data Monitor". Refer to [WCS-21, "Component Function Check"](#).

Is the inspection result normal?

- YES >> Replace the unified meter and A/C amp.
NO >> GO TO 3.

3. CHECK SEAT BELT BUCKLE SWITCH CIRCUIT

Perform the inspection for the seat belt buckle switch circuit. Refer to [WCS-21, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace the unified meter and A/C amp.
NO >> Repair harness or connector.

4. CHECK SEAT BELT BUCKLE SWITCH UNIT

Perform a unit inspection for the seat belt buckle switch. Refer to [WCS-21, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter.
NO >> Replace the seat belt buckle. Refer to [SB-7, "SEAT BELT BUCKLE : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

AIR BAG (PATTERN 2)

< PRECAUTION >

PRECAUTION

AIR BAG (PATTERN 2)

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000000964518

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.