

ENGINE CONTROL SYSTEM

SECTION EC

GI
MA
EM
LC

CONTENTS

PRECAUTIONS AND PREPARATION	3	OBD System Operation Chart	43	EC
Special Service Tools	3	CONSULT	48	
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Generic Scan Tool (GST)	60	
Precautions for On-Board Diagnostic (OBD) System of Engine and A/T	3	TRUBLE DIAGNOSIS — Introduction	62	FE
Engine Fuel & Emission Control System	4	Introduction	62	
Precautions	5	Diagnostic Worksheet	63	AT
ENGINE AND EMISSION CONTROL OVERALL SYSTEM	7	TRUBLE DIAGNOSIS — Work Flow	64	
Circuit Diagram	7	Work Flow	64	PD
System Diagram	8	Description for Work Flow	65	
ECCS Component Parts Location	9	TRUBLE DIAGNOSIS — Basic Inspection	66	FA
Vacuum Hose Drawing	12	Basic Inspection	66	
System Chart	13	TRUBLE DIAGNOSIS — General Description	68	RA
ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION	14	Diagnostic Trouble Code (DTC) Chart	68	
Multiport Fuel Injection (MFI) System	14	Fail-Safe Chart	83	BR
Electronic Ignition (EI) System	17	Symptom Matrix Chart	84	
Air Conditioning Cut Control	18	CONSULT Reference Value in Data Monitor Mode	87	ST
Fuel Cut Control (at no load & high engine speed)	19	Major Sensor Reference Graph in Data Monitor Mode	89	
EVAPORATIVE EMISSION SYSTEM	20	ECM Terminals and Reference Value	91	RS
Description	20	TRUBLE DIAGNOSIS FOR POWER SUPPLY	98	
Inspection	20	Main Power Supply and Ground Circuit	98	BT
POSITIVE CRANKCASE VENTILATION	22	TRUBLE DIAGNOSIS FOR DTC P0100	102	HA
Description	22	Mass Air Flow Sensor (MAFS) (DTC: 0102)	102	
Inspection	22	TRUBLE DIAGNOSIS FOR DTC P0110	107	EL
BASIC SERVICE PROCEDURE	24	Intake Air Temperature Sensor (DTC: 0401)	107	IDX
Fuel Pressure Release	24	TRUBLE DIAGNOSIS FOR DTC P0115	112	
Fuel Pressure Check	24	Engine Coolant Temperature Sensor (ECTS) (DTC: 0103)	112	
Injector Removal and Installation	25	TRUBLE DIAGNOSIS FOR DTC P0120	116	
Fast Idle Cam (FIC) Inspection and Adjustment	25	Throttle Position Sensor (DTC: 0403)	116	
Direct Ignition System — How to Check Idle Speed and Ignition Timing	27	TRUBLE DIAGNOSIS FOR DTC P0125	121	
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment	29	Engine Coolant Temperature (ECT) Sensor (DTC: 0908)	121	
ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION	36	TRUBLE DIAGNOSIS FOR DTC P0130	126	
Introduction	36	Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303)	126	
Two Trip Detection Logic	36	TRUBLE DIAGNOSIS FOR DTC P0130, P0150	131	
Diagnostic Trouble Code (DTC)	36	Closed Loop Control (DTC: 0307, 0308)	131	
Freeze Frame Data	38	TRUBLE DIAGNOSIS FOR DTC P0135	133	
Malfunction Indicator Lamp (MIL)	38	Front Heated Oxygen Sensor Heater (Left bank) (DTC: 0901)	133	
		TRUBLE DIAGNOSIS FOR DTC P0136	136	
		Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707)	136	

CONTENTS (Cont'd)

TROUBLE DIAGNOSIS FOR DTC P0141	141	TROUBLE DIAGNOSIS FOR DTC P0505	215
Rear Heated Oxygen Sensor Heater (Left bank) (DTC: 0902).....	141	Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205).....	215
TROUBLE DIAGNOSIS FOR DTC P0150	145	TROUBLE DIAGNOSIS FOR DTC P0600	220
Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503).....	145	A/T Communication Line (DTC: 0504).....	220
TROUBLE DIAGNOSIS FOR DTC P0155	150	TROUBLE DIAGNOSIS FOR DTC P0605	223
Front Heated Oxygen Sensor Heater (Right bank) (DTC: 1001).....	150	Engine Control Module (ECM)-ECCS Control Module (DTC: 0301).....	223
TROUBLE DIAGNOSIS FOR DTC P0156	153	TROUBLE DIAGNOSIS FOR DTC P0705	225
Rear Heated Oxygen Sensor (Rear HO2S) (Right Bank) (DTC: 0708).....	153	Park/Neutral Position Switch (DTC: 1003).....	225
TROUBLE DIAGNOSIS FOR DTC P0161	158	TROUBLE DIAGNOSIS FOR DTC P1120	229
Rear Heated Oxygen Sensor Heater (Right bank) (DTC: 1002).....	158	Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only).....	229
TROUBLE DIAGNOSIS FOR DTC P0171	162	TROUBLE DIAGNOSIS FOR DTC P1125	234
Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115).....	162	Tandem Throttle Position Sensor (DTC: 1502) (Models with TCS).....	234
TROUBLE DIAGNOSIS FOR DTC P0172	167	TROUBLE DIAGNOSIS FOR DTC P1210	235
Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114).....	167	Traction Control System (TCS) Signal Circuit (DTC: 0106).....	235
TROUBLE DIAGNOSIS FOR DTC P0174	172	TROUBLE DIAGNOSIS FOR DTC P1220	238
Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210).....	172	Fuel Pump Control Module (FPCM) (DTC: 1305).....	238
TROUBLE DIAGNOSIS FOR DTC P0175	177	TROUBLE DIAGNOSIS FOR DTC P1320	244
Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209).....	177	Ignition Signal (DTC: 0201).....	244
TROUBLE DIAGNOSIS FOR DTC P0300 - P0308	182	TROUBLE DIAGNOSIS FOR DTC P1336	250
No. 1 - 8 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0601).....	182	Crankshaft Position Sensor (CKPS) (OBD) (COG) (DTC: 0905).....	250
TROUBLE DIAGNOSIS FOR DTC P0325	186	TROUBLE DIAGNOSIS FOR DTC P1400	254
Knock Sensor (KS) (DTC: 0304).....	186	EGR Valve and EVAP Canister Purge Control Solenoid Valve (DTC: 1005).....	254
TROUBLE DIAGNOSIS FOR DTC P0335	189	TROUBLE DIAGNOSIS FOR DTC P1401	258
Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802).....	189	EGR Temperature Sensor (DTC: 0305).....	258
TROUBLE DIAGNOSIS FOR DTC P0340	193	TROUBLE DIAGNOSIS FOR DTC P1900	263
Camshaft Position Sensor (CMPS) (DTC: 0101).....	193	Cooling Fan (DTC: 1308).....	263
TROUBLE DIAGNOSIS FOR DTC P0400	197	TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS	279
EGR Function (DTC: 0302).....	197	Injector.....	279
TROUBLE DIAGNOSIS FOR DTC P0402	206	Start Signal.....	284
EGRC-BPT Valve Function (DTC: 0306).....	206	Fuel Pump Control.....	286
TROUBLE DIAGNOSIS FOR DTC P0420, P0430	208	Power Steering Oil Pressure Switch.....	292
Three Way Catalyst Function (DTC: 0702, 0703).....	208	MIL & Data Link Connectors.....	295
TROUBLE DIAGNOSIS FOR DTC P0500	211	TROUBLE DIAGNOSIS — Index	296
Vehicle Speed Sensor (VSS) (DTC: 0104).....	211	Alphabetical & P No. Index for DTC.....	296
		SERVICE DATA AND SPECIFICATIONS (SDS)	298
		General Specifications.....	298
		Inspection and Adjustment.....	298

When you read wiring diagrams:


- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

PRECAUTIONS AND PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10114400 (J38365) Heated oxygen sensor wrench	<div style="display: flex; align-items: center; justify-content: space-around;">  <div style="text-align: right;"> <p>Loosening or tightening heated oxygen sensor</p> <p>a: 22 mm (0.87 in)</p> </div> </div> <p>NT636</p>

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System "Air Bag" and "Seat Belt Pre-tensioner", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Precautions for On-Board Diagnostic (OBD) System of Engine and A/T

The ECM (ECCS control module) has an on-board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.


CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before the repair or inspection work. The open/short circuit of the related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after the work. The loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure to connect the connector without water, grease, dirt, bent terminals, etc. in it.)
- Be sure to route and clamp the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after the work. The misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or the fuel injection system, etc.
- Be sure to erase the unnecessary (already fixed) malfunction information in the ECM or A/T control unit before returning the vehicle to the customer.

Engine Fuel & Emission Control System


ECM

- Do not disassemble ECM (ECCS control module).
- Do not turn diagnosis test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.



BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.




ECMS PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).



WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - 1) Keep the antenna as far away as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.








FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

ECM HARNESS HANDLING

- Securely connect ECM harness connectors. Poor connections can cause extremely high (surge) voltage in coil and condenser, resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) from adjacent harnesses, to prevent ECM system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harness dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

PRECAUTIONS AND PREPARATION



Precautions

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM. Because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, tighten securing bolt until the gap between the orange indicators disappears.
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. (See page EC-91.)
- After performing each TROUBLE DIAGNOSIS, perform "OVERALL FUNCTION CHECK" or "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE". The DTC should not be displayed in the "DTC CONFIRMATION PROCEDURE" if the repair is completed. The "OVERALL FUNCTION CHECK" should be a good result if the repair is completed.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

PRECAUTIONS AND PREPARATION


Precautions (Cont'd)

- When measuring ECM signals with a circuit tester, never bring the two tester probes into contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.




ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram




GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

System Diagram



ECCS Component Parts Location



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT







HA

EL

IDX




ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)



ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM


Vacuum Hose Drawing



Refer to "System Diagram" in ENGINE AND EMISSION CONTROL SYSTEM for vacuum control system.

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart



*1: These sensors are not directly used to control the engine system. They are used only for the on-board diagnosis.


*2: The DTC related to A/T and gear position will be sent to ECM.

*3: This sensor is not used to control the engine system under normal conditions.

*4: Models with TCS

Multiport Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL LINE



*1: This sensor is not used to control the engine system under normal conditions.

*2: Models with TCS

BASIC MULTIPOINT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

The amount of fuel injected is compensated for to improve engine performance. This will be made under various operating conditions as listed below.


<Fuel increase >

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- High-load, high-speed operation

<Fuel decrease >

- During deceleration
- During high speed operation

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION



Multiport Fuel Injection (MFI) System (Cont'd)

MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about front heated oxygen sensor, refer to pages EC-145, 126. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture). This stage is referred to as the closed loop control condition. Rear heated oxygen sensor is located downstream of the three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

OPEN LOOP CONTROL

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Engine idling
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High-engine coolant temperature
- During warm-up
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both Manufacturing differences (i.e. mass air flow sensor hot film) and characteristic changes during operation (i.e. injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

GI
MA
EM
LC
EC


FE
AT
PD
FA
RA
BR

ST
RS
BT
HA
EL
IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

"Long-term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short-term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.



FUEL INJECTION SYSTEM

Two types of systems are used.

Sequential multiport fuel injection system

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous multiport fuel injection system

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.


This system is used when the engine is being started and/or if the fail-safe mode (CPU) or crankshaft position sensor (REF) is operating.

FUEL SHUT-OFF


Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Electronic Ignition (EI) System

INPUT/OUTPUT SIGNAL LINE



*: Models with TCS



SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown below.

The ECM detects information such as the injection pulse width and camshaft position sensor signal. Responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- 1 At starting
- 2 During warm-up
- 3 At idle
- 4 Hot engine operation
- 5 At acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.


ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Electronic Ignition (EI) System (Cont'd)

If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM (ECCS control module). The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL LINE



*: Models with TCS

SYSTEM DESCRIPTION


This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.

Fuel Cut Control (at no load & high engine speed)

INPUT/OUTPUT SIGNAL LINE



If the engine speed is above 1,400 rpm with no load (for example, in neutral and engine speed over 1,400 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,000 rpm, then fuel cut is cancelled.


NOTE:

This function is different than deceleration control listed under multiport fuel injection on EC-14.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

EVAPORATIVE EMISSION SYSTEM

Description




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor from sealed fuel tank is led into the EVAP canister when the engine is off. The fuel vapor is then stored in the EVAP canister. The EVAP canister retains the fuel vapor until the EVAP canister is purged by air.

When the engine is running, the air is drawn through the bottom of the EVAP canister. The fuel vapor will then be led to the intake manifold.

When the engine runs at idle, the EVAP canister purge control valve is closed. Only a small amount of vapor flows into the intake manifold through the constant purge orifice.

As the engine speed increases and the throttle vacuum rises, the EVAP canister purge control valve opens. The vapor is sucked through both main purge and constant purge orifices.



Inspection

EVAP CANISTER

Check EVAP canister as follows:

1. Blow air in port **A** and check that there is no leakage.
2. Apply vacuum to port **A**. [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg)]
3. Cover port **D** by hand.
4. Blow air in port **C** and check that air flows freely out of port **B**.

EVAPORATIVE EMISSION SYSTEM

Inspection (Cont'd)



FUEL CHECK VALVE (With rollover valve)

Check valve operation

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
2. Blow air through connector on canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

Rollover valve operation

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.



FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.

Use genuine fuel filler cap as a replacement.

EGR VALVE & EVAP CANISTER PURGE CONTROL SOLENOID VALVE

Refer to EC-254.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

POSITIVE CRANKCASE VENTILATION

Description

This system returns blow-by gas to both the intake manifold and air cleaner.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.



During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air cleaner, through the hose connecting air cleaner to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the air cleaner under all conditions.



Inspection

PCV (Positive Crankcase Ventilation) VALVE


With engine running at idle, remove ventilation hose from PCV valve; if valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.

POSITIVE CRANKCASE VENTILATION

Inspection (Cont'd)

PCV HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX


BASIC SERVICE PROCEDURE



Fuel Pressure Release

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
(Touch "START" and after engine stalls, crank it two or three times to release all fuel pressure.)
3. Turn ignition switch off.



1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch off and reconnect fuel pump fuse.

Fuel Pressure Check

- When reconnecting fuel line, always use new clamps.
- Make sure that clamp screw does not contact adjacent parts.
- Use a torque driver to tighten clamps.
- Use Pressure Gauge to check fuel pressure.

1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idling:

Approximately 235 kPa (2.4 kg/cm², 34 psi)



A few seconds after ignition switch is turned OFF to ON:


Approximately 294 kPa (3.0 kg/cm², 43 psi)

6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.

9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.






Injector Removal and Installation

1. Release fuel pressure to zero.
2. Remove intake manifold collector. Refer to EM section ("TIMING CHAIN").
3. Disconnect vacuum hose from pressure regulator.
4. Disconnect fuel hoses from fuel tube assembly.
5. Disconnect injector harness connectors.
6. Remove injectors with fuel tube assembly.
 - Push injector tail piece.
 - Do not pull on the connector.
7. Push out any malfunctioning injector from fuel tube assembly.
8. Replace or clean injector as necessary.

GI
 MA
 EM
 LC


EC

FE
 AT



9. Install injector to fuel tube assembly.
Always replace O-rings and insulators with new ones. Lubricate O-rings with a smear of engine oil.

PD
 FA
 RA
 BR



10. Install injectors with fuel tube assembly to intake manifold.
Tighten in numerical order shown in the figure.

- a) First, tighten all bolts to 9.3 to 10.8 N·m (0.95 to 1.1 kg-m, 82.5 to 95.5 in-lb).
- b) Then, tighten all bolts to 21 to 26 N·m (2.1 to 2.7 kg-m, 15 to 20 ft-lb).

11. Install fuel hoses to fuel tube assembly.
12. Reinstall any parts removed in reverse order of removal.

CAUTION:

After properly connecting fuel hose to injector and fuel tube assembly, check connection for fuel leakage.

Fast Idle Cam (FIC) Inspection and Adjustment


1. Remove throttle body from engine.
2. Wait for at least 3 hours.
 (This step is necessary to bring the temperature of the thermo-element to the room temperature)

HA
 EL
 DX


BASIC SERVICE PROCEDURE

Fast Idle Cam (FIC) Inspection and Adjustment (Cont'd)

3. Measure thermo-element stroke (L) and room temperature.



4. Check thermo-element stroke (L) as shown in the figure.




L: Thermo-element stroke	①	②	③
Go to step	—*	5	2**

*: No adjustment is needed.



** : Thermo-element is malfunctioning. Replace thermo-element, and perform inspection beginning with step 2.

5. Align hole **A** with hole **B** by turning adjusting screw (S₁), and insert pin through holes **A** and **B** so that the position of hole **A** will not be changed.



BASIC SERVICE PROCEDURE

Fast Idle Cam (FIC) Inspection and Adjustment (Cont'd)



6. Adjust clearance **C** between throttle stopper and throttle adjusting screw to specification by turning adjusting screw (S_2).

Clearance C:
0.62 - 0.74 mm (0.0244 - 0.0291 in)

7. Remove pin from holes **A** and **B**.

8. Adjust clearance **D** to the specified value by turning adjusting screw (S_1).

Clearance D:
3.8 mm (0.150 in)

9. Rotate adjusting screw (S_1) clockwise or counterclockwise by Z turns according to the following equation, then tighten the adjusting screw lock nut.

$$Z = \frac{L \text{ (mm)} - LS^* \text{ (mm)}}{0.50 \text{ (mm)}} / Z = \frac{L \text{ (in)} - LS^* \text{ (in)}}{0.0197 \text{ (in)}}$$

*: Value of the specified line (L_s) at the temperature of thermo-element actually measured.

● Direction of adjusting screw (S_1) rotation

- (1) Positive (+) Z: Counterclockwise
- (2) Negative (-) Z: Clockwise

For example:

	Case I	Case II
Thermo-element temperature °C (°F)	25 (77)	0 (32)
Thermo-element specified stroke (L_s) mm (in)	5.0 (0.197)	2.75 (0.1083)
Thermo-element stroke (L) mm (in)	5.5 (0.217)	2.00 (0.0787)
Revolutions of adjusting screw (Z) mm/in	$Z = \frac{5.5 - 5.0}{0.50} = 1.0 / \frac{0.217 - 0.197}{0.0197} = 1.0$	$Z = \frac{2.00 - 2.75}{0.50} = -1.5 / \frac{0.0787 - 0.1083}{0.0197} = -1.5$
Direction of revolution	Counterclockwise	Clockwise

☆ MONITOR ☆ NO FAIL

CMPS•RPM (POS) 650rpm

RECORD

SEF848Q

Direct Ignition System — How to Check Idle Speed and Ignition Timing

IDLE SPEED

● Using CONSULT

Check idle speed in "DATA MONITOR" mode with CONSULT.

BASIC SERVICE PROCEDURE


Direct Ignition System — How to Check Idle Speed and Ignition Timing (Cont'd)

IGNITION TIMING

Any of the following two methods may be used.


● Method A

1. Attach timing light to loop wire as shown.
2. Check ignition timing.





● Method B

1. Remove intake air duct.
2. Remove No. 1 ignition coil.



3. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.
4. Install air duct.
5. Check ignition timing.



Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment


PREPARATION

- Make sure that the following parts are in good order.

- (1) Battery
- (2) Ignition system
- (3) Engine oil and coolant levels
- (4) Fuses
- (5) ECM harness connector
- (6) Vacuum hoses
- (7) Air intake system
(Oil filler cap, oil level gauge, etc.)
- (8) Fuel pressure
- (9) Engine compression
- (10) EGR valve operation
- (11) Throttle valve

- On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
- When checking idle speed, ignition timing and mixture ratio of A/T models, shift lever to "N" position.
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear defogger.
- Keep front wheels pointed straight ahead.
- Make the check after the cooling fan has stopped.







Overall inspection sequence



G1
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



(A)
Connect throttle position sensor harness connector.

(G)
Check idle speed.

Read idle speed in "DATA MONITOR" mode with CONSULT

OR

Check idle speed.

650 ± 50 rpm (in "N" position)

OK

NG

(H)
Disconnect throttle position sensor harness connector.

(I)
Adjust idle speed by turning idle speed adjusting screw.

600 ± 25 rpm (in "N" position)

Connect throttle position sensor harness connector.

(J)
Run engine at about 2,000 rpm for about 2 minutes under no-load.

(D)

(B)

(H)

GI

VA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



K

Set on-board diagnostic system of ECM to Diagnostic Test Mode II (Front heated oxygen sensor monitor).



L M



Check left bank front heated oxygen sensor signal.

- 1) See "FR O2 SEN MNTR-B1 and B2 (left and right sides)" in "Data monitor" mode.
- 2) Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 cycle: RICH → LEAN → RICH
2 cycles: RICH → LEAN → RICH → LEAN → RICH

OR

Make sure that malfunction indicator lamp goes on and off more than 5 times during 10 seconds at 2,000 rpm.

Monitor does not fluctuate. Malfunction indicator lamp does not blink.



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

N

☆ MONITOR	☆ NO FAIL	<input type="checkbox"/>
CMPS•RPM (POS)	2000rpm	
FR O2 MNTR-B1	RICH	
FR O2 MNTR-B2	RICH	


RECORD

SEF855Q

O

CHECK




SEF051P



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX





BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



- R S**
- 1) Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode.
 - 2) Set "COOLANT TEMP" to 20°C (68°F) by touching "DWN" and "Qd".
- OR
- 1) Disconnect engine coolant temperature sensor harness connector.
 - 2) Connect a resistor (2.5 kΩ) between terminals of engine coolant temperature sensor harness connector.

T Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge.

U Race engine two or three times under no-load, then run engine at idle speed.

Check "CO" %.

Idle CO: Less than 8% with engine running smoothly

After checking CO%,

- 1) Disconnect the resistor from terminals of engine coolant temperature sensor.
- 2) Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.

NG

Connect front heated oxygen sensor harness connectors to front heated oxygen sensors.

Check fuel pressure regulator.

Check mass air flow sensor.

Check injector.
Clean or replace if necessary.

Check engine coolant temperature sensor.

Check ECM function* by substituting another known good ECM.

*: ECM may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

The ECM (ECCS control module) has an on-board diagnostic system, which detects engine system malfunctions related to sensors or actuators. The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (two trip detection logic).

Two Trip Detection Logic

When a malfunction is detected for the first time, the malfunction (DTC and freeze frame data) is stored in the ECM memory. <1st trip> The malfunction indicator lamp will not light up at this stage.

If the same malfunction is detected again during next drive, this second detection causes the malfunction indicator lamp to light up. <2nd trip> (See page EC-43.)

The "trip" in the "Two Trip Detection Logic" means performing of the "DTC CONFIRMATION PROCEDURE". Specific on-board diagnostic items will light up or blink the MIL even in the 1st trip as below.

Items	MIL		
	1st trip		2nd trip lighting up
	Blinking	Lighting up	
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0308 (0701 - 0601) is being detected	X		
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0308 (0701 - 0601) has been detected		X	
Three way catalyst function — DTC: P0420 (0702), P0430 (0703)		X	
Closed loop control — DTC: P0130 (0307), P0150 (0308)		X	
Except above			X

Diagnostic Trouble Code (DTC)

HOW TO READ DTC

The diagnostic trouble code can be read by the following methods.

(Either code for the 1st trip or the 2nd trip can be read.)


1. The number of blinks of the malfunction indicator lamp in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.
These DTCs are controlled by NISSAN.
2. CONSULT or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.
These DTCs are prescribed by SAE J2012.
(CONSULT also displays the malfunctioning component or system.)


- **Output of the trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**

CONSULT can identify them. Therefore, using CONSULT (if available) is recommended.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by the following methods.

 Changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM (Refer to page EC-40.)

 Selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT

 Selecting Mode 4 with GST (Generic Scan Tool)

- **If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.**
- **When you erase the DTC, using CONSULT or GST is easier and quicker than switching the mode selector on the ECM.**


ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Diagnostic Trouble Code (DTC) (Cont'd)

HOW TO ERASE DTC (With CONSULT)

Note: If the diagnostic trouble code is not for A/T related items (see page EC-80), skip steps 2 through 4.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" (engine stopped) again.
 2. Turn CONSULT "ON" and touch "A/T".
 3. Touch "SELF-DIAG RESULTS".
 4. Touch "ERASE". (The DTC in the A/T control unit will be erased.) And touch "BACK" twice.
 5. Touch "ENGINE".
 6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)
- If DTCs are displayed for both ECM and A/T control unit, they need to be erased individually for both ECM and A/T control unit.



HOW TO ERASE DTC (With Generic Scan Tool)

- If the diagnostic trouble code is not for A/T related items (refer to EC-80), skip step 2.
1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" (engine stopped) again.
 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
 3. Select Mode 4 with GST (Generic Scan Tool).

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Diagnostic Trouble Code (DTC) (Cont'd)



HOW TO ERASE DTC (No Tools)

Note: If the diagnostic trouble code is not for A/T related items (see page EC-80), skip step 2.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See page EC-40.)

Freeze Frame Data

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short fuel trim, long fuel trim, engine speed, vehicle speed at the moment the ECM detects a malfunction.

Stored data is called Freeze Frame Data.

This data is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.


This data can be utilized to duplicate the malfunction and to diagnose the trouble.

This data will be erased at the same time with the diagnostic trouble code by the above mentioned methods.

The data can be stored only at the 1st trip. It can not be renewed even at the 2nd trip. The freeze frame data can be stored for only one item. Therefore, the ECM has the following priorities to update the data.

Priority	Detected items
1	Misfires — DTC: P0300-P0308 (0701-0601) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114), P0174 (0210), P0175 (0209)
2	Except the above items (includes A/T items)

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 1st trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction for the misfire.



Malfunction Indicator Lamp (MIL)

The malfunction indicator lamp is located on the instrument panel.

1. The malfunction indicator lamp will light up when the ignition switch is turned ON without the engine running. This is for checking the blown lamp.
 - If the malfunction indicator lamp does not light up, see the WARNING LAMPS AND CHIME (BUZZER) in the EL section. (Or see EC-295.)
2. When the engine is started, the malfunction indicator lamp should go off.

If the lamp remains on, the on-board diagnostic system has detected an engine system malfunction.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION




Malfunction Indicator Lamp (MIL) (Cont'd)

ON-BOARD DIAGNOSTIC SYSTEM FUNCTION

The on-board diagnostic system has the following four functions.

- | | | | |
|---------------------------------------|---|---|----------|
| 1. BULB CHECK | : | This function checks the bulb for damage (blown, open circuit, etc.) of the malfunction indicator lamp. | GI |
| 2. MALFUNCTION WARNING | : | This is a usual driving condition. When a malfunction is detected twice (2 trip detection logic), the malfunction indicator lamp will light up to inform the driver that a malfunction has been detected. Only the following malfunctions will light up or blink the MIL even in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (possible three way catalyst damage)" ● "Three way catalyst function" ● "Closed loop control" | MA
EM |
| 3. SELF-DIAGNOSTIC RESULTS | : | By using this function, the diagnostic trouble codes can be read. | LC |
| 4. FRONT HEATED OXYGEN SENSOR MONITOR | : | In this mode, the fuel mixture condition (lean or rich) monitored by front heated oxygen sensor can be read. | EC |


How to switch the diagnostic test (function) modes and details of the above functions are described later. (See page EC-40.)

Condition		Diagnostic Test Mode I	Diagnostic Test Mode II
Ignition switch in "ON" position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	FRONT HEATED OXYGEN SENSOR MONITOR

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

HOW TO SWITCH DIAGNOSTIC TEST MODES



*1: If the selector is turned fully clockwise at this time, the diagnostic trouble code will be erased from the backup memory in the ECM.

- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 5 seconds. The diagnosis will automatically return to Diagnostic Test Mode I.
- Turn back diagnostic test mode selector to the fully counterclockwise position whenever vehicle is in use.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE I—BULB CHECK

In this mode, the MALFUNCTION INDICATOR LAMP on the instrument panel should stay ON. If it remains OFF, check the bulb. (See the WARNING LAMPS AND CHIME in the EL section. Or see EC-295.)



DIAGNOSTIC TEST MODE I—MALFUNCTION WARNING

MALFUNCTION INDICATOR LAMP	Condition
ON	When the malfunction (The "1 trip" or "2 trip" is shown in the "MIL Illumination" of the "DTC Chart". See page EC-68.) is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction

- These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

DIAGNOSTIC TEST MODE II—SELF-DIAGNOSTIC RESULTS

In this mode, a diagnostic trouble code is indicated by the number of blinks of the MALFUNCTION INDICATOR LAMP as shown below.



Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the malfunction indicator lamp blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position switch.

In this way, all the detected malfunctions are classified by their diagnostic trouble code numbers. The DTC "0505" refers to no malfunction. (See DIAGNOSTIC TROUBLE CODE CHART, refer to page EC-68.)

HOW TO ERASE DIAGNOSTIC TEST MODE II (Self-diagnostic results)

The diagnostic trouble code can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- If the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE II—FRONT HEATED OXYGEN SENSOR MONITOR

In this mode, the MALFUNCTION INDICATOR LAMP displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

MALFUNCTION INDICATOR LAMP	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop control
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop control

*: Maintains conditions just before switching to open loop.


To check the front heated oxygen sensor function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MALFUNCTION INDICATOR LAMP comes ON more than 5 times every 10 seconds when measured at 2,000 rpm under no-load.

How to switch monitored sensor from left bank to right bank or vice versa

● The following procedure should be performed while the engine is running.

1. Turn diagnostic test mode selector on ECM fully clockwise.
2. Wait at least 2 seconds.
3. Turn diagnostic test mode selector on ECM fully counterclockwise.



OBD System Operation Chart

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the DTC and the freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the MIL will come on. For details, refer to "Two Trip Detection Logic" on EC-36.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset. The MIL will remain on until the vehicle is driven (in the recorded driving pattern) 3 times with no malfunction.
- The DTC and the freeze frame data can be displayed until the vehicle is driven 40 times (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data can be displayed until the vehicle is driven 80 times. The "TIME" IN "SELF-DIAGNOSTIC RESULTS" mode of CONSULT will count in response to the number of times the vehicle is driven.

SUMMARY CHART

Items	MIL (goes off)	DTC, Freeze Frame Data (no display)
Fuel Injection System	3 (pattern C)	80 (pattern B)
Misfire	3 (pattern C)	80 (pattern B)
Except the aboves	3 (pattern B)	40 (pattern A)

Details about patterns "A", "B", and "C" are on EC-45.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DRIVING PATTERNS FOR "MISFIRE" < EXHAUST QUALITY DETERIORATION >, "FUEL INJECTION SYSTEM"



SEF299Q

- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern C) without any malfunctions.
- *3: When a malfunction is detected for the first time, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern B) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


- *5: Other screen except DATA MONITOR (AUTO TRIG) can not display the malfunction.
- *6: DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.
- *7: The malfunction can not be displayed because the timing to set DATA MONITOR (AUTO TRIG) screen was missed against the NG detection.
- *8: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern B) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBd System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE < EXHAUST QUALITY DETERIORATION >", "FUEL INJECTION SYSTEM"

< Driving pattern A >



< Driving pattern B >

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will reset when the malfunction is detected twice regardless of the driving pattern.
- The B counter will count the number of times driving pattern B is satisfied without the malfunction.
- The DTC will not be displayed after the B counter reaches 80.

< Driving pattern C >

Driving pattern C means the vehicle operation as follows:

(1) Driving pattern A should be satisfied.

(2) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:


Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than $\geq 70^\circ\text{C}$ (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1), (2). (*1 in "OBd SYSTEM OPERATION CHART")
- The C counter will be counted up when (1), (2) are satisfied without the same malfunction.
- The MIL will go off when the C counter reaches 3. (*2 in "OBd SYSTEM OPERATION CHART")

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DRIVING PATTERNS EXCEPT FOR "MISFIRE" < EXHAUST QUALITY DETERIORATION >, "FUEL INJECTION SYSTEM"



SEF300Q

- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When a malfunction is detected for the first time, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


- *5: Other screen except DATA MONITOR (AUTO TRIG) can not display the malfunction.
- *6: DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.
- *7: The malfunction can not be displayed because the timing to set DATA MONITOR (AUTO TRIG) screen was missed against the NG detection.
- *8: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE < EXHAUST QUALITY DETERIORATION >", "FUEL INJECTION SYSTEM"

<Driving pattern A >



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.


<Driving pattern B >

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected twice regardless of the driving pattern (*1 in "OBD SYSTEM OPERATION CHART").
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").


ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION




CONSULT

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located behind the fuse box cover.)



3. Turn on ignition switch.
4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT Operation Manual.



ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

ECCS COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		Item	DIAGNOSTIC TEST MODE					
			WORK SUP-PORT	SELF-DIAG-NOSTIC RESULTS	DATA MON-ITOR	ACTIVE TEST	FUNC-TION TEST	FREEZE FRAME DATA*
ECCS COMPONENT PARTS	INPUT	Camshaft position sensor		X	X			
		Mass air flow sensor		X	X			
		Engine coolant temperature sensor		X	X	X		X
		Front heated oxygen sensors		X	X		X	
		Rear heated oxygen sensor		X	X			
		Vehicle speed sensor		X	X		X	X
		Throttle position sensor	X	X	X		X	
		EGR temperature sensor		X	X			
		Intake air temperature sensor		X	X			
		Knock sensor		X				
		Ignition switch (start signal)			X		X	
		Closed throttle position (throttle position sensor signal)			X		X	
		Air conditioner switch			X			
		Park/Neutral position switch		X	X		X	
		Power steering oil pressure switch			X		X	
		Air conditioner pressure switch			X			
	Battery voltage			X				
	OUTPUT	Injectors			X	X	X	
		Power transistor (Ignition timing)		X (Ignition signal)	X	X	X	
		IACV-AAC valve	X	X	X	X	X	
		Air conditioner relay			X			
		Fuel pump relay	X		X	X	X	
		Cooling fan		X	X	X	X	
		EGRC-solenoid valve (EGR valve & EVAP canister purge control solenoid valve)		X	X	X	X	
		Front heated oxygen sensor heaters		X	X			
		FPCM		X	X			
		Calculated load value			X			X

X: Applicable

*: The items appear on CONSULT screen in FREEZE FRAME DATA mode only if a diagnostic trouble code (DTC) is detected. For details, refer to EC-58.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".
Freeze frame data	ECM stores the driving condition at the moment a malfunction is detected, and the stored data can be read. [Regarding the details, refer to "Freeze Frame Data" (EC-38).]
ECM part numbers	ECM part numbers can be read.

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● IGN SW "ON" ● ENG NOT RUNNING ● ACC PEDAL NOT PRESSED 	When adjusting throttle position sensor initial position
IACV-AAC VALVE ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● ENGINE WARMED UP ● NO-LOAD 	When adjusting idle speed
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

SELF-DIAGNOSTIC MODE

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to "Diagnostic Trouble Code (DTC) chart" (See page EC-68.)

DATA MONITOR MODE

Monitored item [Unit]	ECM input sig- nals	Main sig- nals	Description	Remarks	
CMPS-RPM (POS) [rpm]	○	○	<ul style="list-style-type: none"> Indicates the engine speed computed from the POS signal (1° signal) of the crankshaft position sensor (POS). 		GI
CMPS-RPM (REF) [rpm]	○		<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (90° signal) of the crankshaft position sensor (REF). 	<ul style="list-style-type: none"> The accuracy of detection becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated. 	MA EM LC
MAS AIR/FL SE [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. 	EC FE
COOLAN TEMP/S [°C] or [°F]	○	○	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed. 	AT
FR O2 SEN-B1 [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the front heated oxygen sensor is displayed. 		PD
FR O2 SEN-B2 [V]	○				FA
RR O2 SEN-B1 [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the rear heated oxygen sensor is displayed. 		RA
RR O2 SEN-B2 [V]	○	○			BR
FR O2 MNTR-B1 [RICH/LEAN]	○	○	<ul style="list-style-type: none"> Display of front heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously. 	ST
FR O2 MNTR-B2 [RICH/LEAN]	○	○			RS
RR O2 MNTR-B1 [RICH/LEAN]	○	○	<ul style="list-style-type: none"> Display of rear heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the amount of oxygen after three way catalyst is relatively large. LEAN ... means the amount of oxygen after three way catalyst is relatively small. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. 	BT
RR O2 MNTR-B2 [RICH/LEAN]	○	○			HA
VHCL SPEED SE [km/h] or [mph]	○	○	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 		EL IDX

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
Regarding G50 model, "B1" indicates left bank and "B2" indicates right bank.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input sig- nals	Main sig- nals	Description	Remarks
BATTERY VOLT [V]	○	○	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
THRTL POS SEN [V]	○	○	<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 	
THRTL/P SEN2 [V]	○		<ul style="list-style-type: none"> Models with traction control system, TCS throttle position (Secondary throttle position) sensor signal voltage is displayed. 	
EGR TEMP SEN [V]	○		<ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. 	
INT/A TEMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. 	
START SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL/P SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the throttle position sensor signal. 	
AIR COND SIG [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
P/N POSI SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position switch signal. 	
PW/ST SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated. 	
IGNITION SW [ON/OFF]	○		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 	
INJ PULSE-B1 [msec]		○	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec]				
B/FUEL SCHDL [msec]		○	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on-board correction. 	
IGN TIMING [BTDC]		○	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
IACV-AAC/V [%]		○	<ul style="list-style-type: none"> Indicates the idle air control valve (AAC valve) control value computed by ECM according to the input signals. 	
A/F ALPHA-B1 [%]			<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
A/F ALPHA-B2 [%]				<ul style="list-style-type: none"> This data also includes the data for the air-fuel ratio learning control.
AIR COND RLY [ON/OFF]		○	<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
FUEL PUMP RLY [ON/OFF]		○	<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]		○	<ul style="list-style-type: none"> The control condition of the cooling fan (determined by ECM according to the input signal) is indicated. HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input sig- nals	Main sig- nals	Description	Remarks	
EGRC SOL/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EGR valve & EVAP canister purge control solenoid valve (determined by ECM according to the input signal) is indicated. ON ... EGR and EVAP canister purge operation is cut-off OFF ... EGR and EVAP canister purge is operational 	GI MA EM	
FR O2 HTR-B1 [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of front heated oxygen sensor's heater determined by ECM according to the input signals. 	LC	
FR O2 HTR-B2 [ON/OFF]					
RR O2 HTR-B1 [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of rear heated oxygen sensor's heater determined by ECM according to the input signals. 	EC	
RR O2 HTR-B2 [ON/OFF]					
CAL/LD VALUE [%]			<ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	FE AT	
ABSOL TH-P/S [%]			<ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 	PD	
MASS AIRFLOW [gm/s]			<ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. 	FA	
FPCM [LOW/MID/HI]			<ul style="list-style-type: none"> The control condition of the fuel pump control module (FPCM) (determined by ECM according to the input signal) is indicated. LOW ... Low amount of fuel flow MID ... Middle amount of fuel flow HI ... High amount of fuel flow 	RA BR	
FPCM F/P VOLT [V]			<ul style="list-style-type: none"> The voltage between fuel pump and FPCM is displayed. 	ST	
VOLTAGE [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 		
PULSE [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only "#" is displayed if item is unable to be measured. Figures with "#"s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. 	RS BT

HA

EL

IDX

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the amount of fuel injection using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel injectors ● Front heated oxygen sensor
IACV-AAC/V OPENING	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Change the IACV-AAC valve opening percent using CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● IACV-AAC valve
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor ● Fuel injectors
IGNITION TIMING	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Adjust ignition timing (by moving camshaft position sensor)
POWER BALANCE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time using CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connector ● Compression ● Injectors ● Ignition coil with power transistor ● Spark plugs
COOLING FAN	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn the cooling fan "ON" and "OFF" using CONSULT. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connector ● Cooling fan motor
FUEL PUMP RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn solenoid valve "ON" and "OFF" with CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● EGR valve & EVAP canister purge control solenoid valve
SELF-LEARNING CONT	<ul style="list-style-type: none"> ● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		
FPCM	<ul style="list-style-type: none"> ● Ignition switch: ON ● Select "LOW", "MID" and "HI" with CONSULT and check that "FPCM F/P VOLT" of CONSULT changes. 	"FPCM F/P VOLT" of CONSULT changes as follows; LOW ... Approx. 6.6 V MID ... Approx. 3.4 V HI ... Approx. 0.4 V	<ul style="list-style-type: none"> ● Harness and connector ● FPCM

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST MODE

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Displays the results of on-board diagnostic system. 	—		Objective system	GI MA
CLOSED THROTTLE POSI	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Throttle position sensor circuit is tested when throttle is opened and closed fully. ("IDLE POSITION" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor (Closed throttle position) ● Throttle position sensor (Closed throttle position) adjustment ● Throttle linkage ● Verify operation in DATA MONITOR mode. 	EM LC
		Throttle valve: closed	ON		EC
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor ● Throttle position sensor adjustment ● Throttle linkage ● Verify operation in DATA MONITOR mode. 	FE AT PD
PARK/NEUT POSI SW CKT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Inhibitor/Neutral position switch circuit is tested when shift lever is manipulated. 	Out of N/P positions	OFF	<ul style="list-style-type: none"> ● Harness and connector ● Neutral position switch or Inhibitor switch ● Linkage or Inhibitor switch adjustment 	FA
		In N/P positions	ON		RA
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump ● Fuel pump relay ● Fuel filter clogging ● Fuel level 	BR ST
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● EGR valve & EVAP canister purge control solenoid valve circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> ● Harness and connector ● EGR valve & EVAP canister purge control solenoid valve 	RS BT
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Cooling fan circuit is tested when cooling fan is rotated. 	The cooling fan rotates and stops every 3 seconds.		<ul style="list-style-type: none"> ● Harness and connector ● Cooling fan motor ● Cooling fan relay 	HA EL

IDX

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON → START ● Start signal circuit is tested when engine is started by operating the starter. Battery voltage and water temperature before cranking, and average battery voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed. 	Start signal: OFF → ON		<ul style="list-style-type: none"> ● Harness and connector ● Ignition switch
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine running) ● Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> ● Harness and connector ● Power steering oil pressure switch ● Power steering oil pump
		Neutral position	OFF	
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> ● Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor ● Electric speedometer
IGN TIMING ADJ	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● Ignition timing is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> ● Adjust ignition timing (by moving camshaft position sensor) ● Camshaft position sensor drive mechanism
MIXTURE RATIO TEST	<ul style="list-style-type: none"> ● Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the front heated oxygen sensor output at 2,000 rpm under non-loaded state. 	Front heated oxygen sensor COUNT: More than 5 times during 10 seconds		<ul style="list-style-type: none"> ● INJECTION SYS (Injector, fuel pressure regulator, harness or connector) ● IGNITION SYS (Spark plug, ignition coil with power transistor harness or connector) ● VACUUM SYS (Intake air leaks) ● Front heated oxygen sensor circuit ● Front heated oxygen sensor operation ● Fuel pressure high or low ● Mass air flow sensor
POWER BALANCE	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multiport fuel injection system is used.) 	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.		<ul style="list-style-type: none"> ● Injector circuit (Injector, harness or connector) ● Ignition circuit (Spark plug, ignition coil with power transistor harness or connector) ● Compression ● Valve timing

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> ● After warming up, idle the engine. ● IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% and at 20%.	<ul style="list-style-type: none"> ● Harness and connector ● IACV-AAC valve ● Air passage restriction between air inlet and IACV-AAC valve ● IAS (Idle adjusting screw) adjustment

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FREEZE FRAME DATA

Freeze frame data item	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ● ECCS component part/control system has a trouble code, it is displayed as "PXXXX". [Refer to "Alphabetical & P No. Index for DTC (EC-296).]
FUEL SYS-B1*	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed. ● One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction
FUEL SYS-B2*	<ul style="list-style-type: none"> ● "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) ● "MODE 4": Closed loop - using heated oxygen sensor(s) as feedback for fuel control ● "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> ● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.

*: Regarding G50 model, "B1" indicates left bank and "B2" indicates right bank.

ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

REAL TIME DIAGNOSIS IN DATA MONITOR MODE

CONSULT has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT screen in real time. In other words, DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM.
- DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONITOR cannot continue any longer after the malfunction detection.

2. "MANU TRIG" (Manual trigger):

- DTC and malfunction item will not be displayed automatically on CONSULT screen even though a malfunction is detected by ECM.
- DATA MONITOR can be performed continuously even though a malfunction is detected.


Use these triggers as follows:

1. "AUTO TRIG"


- While trying to detect the DTC by performing the "DTC CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC CONFIRMATION PROCEDURE", the moment a malfunction is found the DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.




SEF529Q



Generic Scan Tool (GST)



DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has five different functions explained on the next page. ISO9141 is used as the protocol. The name "GST" or "Generic Scan Tool" is used in this service manual.



GST INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)
3. Turn ON ignition switch.
4. Enter the program according to instruction on the screen or in the operation manual.
(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.




ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Generic Scan Tool (GST) (Cont'd)

FUNCTION

Diagnostic test mode		Function
MODE 1	(CURRENT DATA)	This mode accesses to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode accesses to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-58).]
MODE 3	(TROUBLE CODES)	This mode accesses to emission-related power train trouble codes which were stored by ECM.
MODE 4	(CLEAR CODES)	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Clear heated oxygen sensor test data (MODE 5) ● Reset status of system monitoring test (MODE 1)
MODE 5	(O2 TEST RESULTS)	This mode accesses to the on-board heated oxygen sensor monitoring test results.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Introduction

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on the next page. Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

TROUBLE DIAGNOSIS — Introduction

KEY POINTS

- WHAT** Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

Diagnostic Worksheet



There are many operating conditions that lead to the malfunctions of engine components.

A good knowledge of such conditions can make trouble-shooting faster and more accurate.

In general, each customer may feel differently about a given problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one shown below in order to organize all the information for troubleshooting.


WORKSHEET SAMPLE

Customer name MR/MS		Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Symptoms	<input type="checkbox"/> Startability	<input type="checkbox"/> Impossible to start <input type="checkbox"/> No combustion <input type="checkbox"/> Partial combustion <input type="checkbox"/> Partial combustion affected by throttle position <input type="checkbox"/> Partial combustion NOT affected by throttle position <input type="checkbox"/> Possible but hard to start <input type="checkbox"/> Others []	
	<input type="checkbox"/> Idling	<input type="checkbox"/> No fast idle <input type="checkbox"/> Unstable <input type="checkbox"/> High idle <input type="checkbox"/> Low idle <input type="checkbox"/> Others []	
	<input type="checkbox"/> Driveability	<input type="checkbox"/> Stumble <input type="checkbox"/> Surge <input type="checkbox"/> Knock <input type="checkbox"/> Lack of power <input type="checkbox"/> Intake backfire <input type="checkbox"/> Exhaust backfire <input type="checkbox"/> Others []	
	<input type="checkbox"/> Engine stall	<input type="checkbox"/> At the time of start <input type="checkbox"/> While idling <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating <input type="checkbox"/> Just after stopping <input type="checkbox"/> While loading	
Incident occurrence		<input type="checkbox"/> Just after delivery <input type="checkbox"/> Recently <input type="checkbox"/> In the morning <input type="checkbox"/> At night <input type="checkbox"/> In the daytime	
Frequency		<input type="checkbox"/> All the time <input type="checkbox"/> Under certain conditions <input type="checkbox"/> Sometimes	
Weather conditions		<input type="checkbox"/> Not affected	
		Weather <input type="checkbox"/> Fine <input type="checkbox"/> Raining <input type="checkbox"/> Snowing <input type="checkbox"/> Others []	
		Temperature <input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Humid °F	
Engine conditions		<input type="checkbox"/> Cold <input type="checkbox"/> During warm-up <input type="checkbox"/> After warm-up Engine speed 	
Road conditions		<input type="checkbox"/> In town <input type="checkbox"/> In suburbs <input type="checkbox"/> Highway <input type="checkbox"/> Off road (up/down)	
Driving conditions		<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH) Vehicle speed 	
Malfunction indicator lamp		<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on	

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — Work Flow

Work Flow



*1: If the incident cannot be duplicated, see "Incident Simulation Tests" of "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section.


*2: If the on-board diagnostic system cannot be performed, check main power supply and ground circuit (See TROUBLE DIAGNOSIS FOR POWER SUPPLY, EC-98).

TROUBLE DIAGNOSIS — Work Flow

Description for Work Flow

STEP	DESCRIPTION	
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", as shown EC-63.	GI
STEP II	Before confirming the concern, check and write down (print out using CONSULT or Generic Scan Tool) the Diagnostic Trouble Code (DTC) and the freeze frame data, then erase the code and the data. (Refer to EC-36.) The DTC and the freeze frame data can be used when duplicating the incident at STEP III & IV. Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See page EC-84.)	MA EM
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) If the malfunction code is detected, skip STEP IV and perform STEP V.	LC
STEP IV	Try to detect the Diagnostic Trouble Code (DTC) by driving in (or performing) the "DTC CONFIRMATION PROCEDURE". Check and read the DTC and freeze frame data by using CONSULT or Generic Scan Tool. During the DTC verification, be sure to connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) In case the "DTC CONFIRMATION PROCEDURE" is not available, perform the "OVERALL FUNCTION CHECK" instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "OVERALL FUNCTION CHECK" is the same as the DTC detection.	EC FE AT PD
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION on next page. Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-84.)	FA
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT. Refer to EC-87. The "DIAGNOSTIC PROCEDURE" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to GI section ("HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection"). Repair or replace the malfunction parts.	RA BR ST RS
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC CONFIRMATION PROCEDURE" and confirm the normal code (Diagnostic trouble code No. 0505 or P0000) is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM and A/T control unit. (Refer to EC-36.)	BT HA EL

IDX




Basic Inspection

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;


- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.



A

BEFORE STARTING

1. Check service records for recent repairs of related problems, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts




B

CONNECT CONSULT TO THE VEHICLE

Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. (Refer to page EC-48.)

Warm up engine sufficiently.




C

CHECK IGNITION TIMING.

1. Disconnect throttle position sensor harness connector.
2. Check ignition timing at idle using timing light. (Refer to EC-27.)

Ignition timing:
15° ± 2° BTDC

NG → Adjust ignition timing by turning camshaft position sensor.



D

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

When disconnecting throttle position sensor harness connector, does engine speed fall to the following speed? (Refer to EC-27.)



600 ± 50 rpm (in "N" position)

No → Adjust engine speed by turning idle adjusting screw.

Yes
↓
(Go to **A**) on next page.)

TROUBLE DIAGNOSIS — Basic Inspection

Basic Inspection (Cont'd)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
(P0000)	0505	No failure (NO SELF DIAGNOSTIC FAILURE INDICATED...)	<ul style="list-style-type: none"> ● No malfunction related to OBD system is detected by both ECM and A/T control unit.
P0100	0102	Mass air flow sensor circuit (MASS AIR FLOW SEN)	<ul style="list-style-type: none"> ● An excessively high or low voltage is sent to ECM. ● Voltage sent to ECM is not practical when compared with the camshaft position sensor signal and throttle position sensor signals.
P0110	0401	Intake air temperature sensor circuit (INT AIR TEMP SEN)	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM. ● Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.
P0115	0103	Engine coolant temperature sensor circuit (COOLANT TEMP SEN)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is sent to ECM.
P0120	0403	Throttle position sensor circuit (THROTTLE POSI SEN)	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM. ● Rationally incorrect voltage from the sensor is sent to ECM compared with the voltage signals from mass air flow sensor and camshaft position sensor.
P0125	0908	Engine coolant temperature sensor function (*COOLANT TEMP SEN)	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control.
P0130	0303	Front heated oxygen sensor (right bank) circuit (FRONT O2 SENSOR-B1)	<ul style="list-style-type: none"> ● An excessively high voltage from the sensor is sent to ECM. ● The voltage from the sensor is constantly approx. 0.3V. ● The maximum and minimum voltages from the sensor are not reached to the specified voltages. ● It takes more time for the sensor to respond between rich and lean than the specified time.
P0130	0307	Closed loop control (right bank) (CLOSED LOOP-B1)	<ul style="list-style-type: none"> ● The closed loop control function does not operate even when vehicle is driving in the specified condition.
P0135	0901	Front heated oxygen sensor heater (right bank) circuit (FR O2 SEN HTR-B1)	<ul style="list-style-type: none"> ● The current amperage in the heater circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the heater.)
P0136	0707	Rear heated oxygen sensor (left bank) circuit (REAR O2 SENSOR-B1)	<ul style="list-style-type: none"> ● An excessively high voltage from the sensor is sent to ECM. ● The maximum and minimum voltages from the sensor are not reached to the specified voltages. ● It takes more time for the sensor to respond between "rich" and "lean" than the specified time.

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	*1 "DTC CONFIRMA- TION PROCEDURE" Quick Ref.	*2 "OVERALL FUNCTION CHECK" Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
● No failure	—	—	—	—	—	GI MA
● Harness or connectors (The sensor circuit is open or shorted.)	RUNNING	RUNNING	X	2 trip	EC-102	EM
● Mass air flow sensor						
● Harness or connectors (The sensor circuit is open or shorted.)	IGN: ON	—	—	2 trip	EC-107	LC
● Intake air temperature sensor						
● Harness or connectors (The sensor circuit is open or shorted.)	IGN: ON	—	X	2 trip	EC-112	EC
● Engine coolant temperature sensor						
● Harness or connectors (The sensor circuit is open or shorted.)	—	IGN: ON	X	2 trip	EC-116	FE
● Throttle position sensor						
● Harness or connectors (High resistance in the sensor circuit)	—	RUNNING	—	2 trip	EC-121	AT
● Engine coolant temperature sensor						
● Thermostat						
● Harness or connectors (The sensor circuit is open or shorted.)	—	RUNNING	—	2 trip	EC-126	PD FA
● Front heated oxygen sensor (right bank)						
● Injectors						
● Intake air leaks						
● Fuel pressure						
● The front heated oxygen sensor (right bank) cir- cuit is open or shorted.	—	RUNNING	—	1 trip	EC-131	RA
● Front heated oxygen sensor (right bank)						
● Front heated oxygen sensor heater (right bank)						
● Harness or connectors (The heater circuit is open or shorted.)	RUNNING	—	—	2 trip	EC-133	BR
● Front heated oxygen sensor heater (right bank)						
● Harness or connectors (The sensor circuit is open or shorted.)	—	RUNNING (DRIVING)	—	2 trip	EC-136	ST RS
● Rear heated oxygen sensor						
● Fuel pressure						
● Injectors						
● Intake air leaks						

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

● This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0141	0902	Rear heated oxygen sensor heater (left bank) circuit (RR O2 SEN HTR-B1)	<ul style="list-style-type: none"> The current amperage in the heater circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the heater.)
P0150 (*3)	0308	Closed loop control (left bank) (CLOSED LOOP-B2)	<ul style="list-style-type: none"> The closed loop control function does not operate even when vehicle is driving in the specified condition.
P0150	0503	Front heated oxygen sensor (left bank) circuit (FRONT O2 SENSOR-B2)	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. The voltage from the sensor is constantly approx. 0.3V. The maximum and minimum voltages from the sensor are not reached to the specified voltages. It takes more time for the sensor to respond between rich and lean than the specified time.
P0155	1001	Front heated oxygen sensor heater (left bank) circuit (FR O2 SEN HTR-B2)	<ul style="list-style-type: none"> The current amperage in the heater circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the heater.)
P0156	0708	Rear heated oxygen sensor circuit (REAR O2 SENSOR-B2)	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. The maximum and minimum voltages from the sensor are not reached to the specified voltages. It takes more time for the sensor to respond between "rich" and "lean" than the specified time.
P0161	1002	Rear heated oxygen sensor heater (right bank) circuit (RR O2 SEN HTR-B2)	<ul style="list-style-type: none"> The current amperage in the heater circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the heater.)
P0171	0115	Fuel injection system function (right bank) (lean side) (FUEL SYS LEAN/BK1)	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.)

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
 RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
 LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
 DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
 RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
 LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
 DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

*3: Using CONSULT, "P0130" will be displayed.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC CONFIRMATION PROCEDURE" Quick Ref. *1	"OVERALL FUNCTION CHECK" Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> ● Harness or connectors (The heater circuit is open or shorted.) ● Rear heated oxygen sensor heater (left bank) 	RUNNING	—	—	2 trip	EC-141	GI MA EM
<ul style="list-style-type: none"> ● The front heated oxygen sensor (left bank) circuit is open or shorted. ● Front heated oxygen sensor (left bank) ● Front heated oxygen sensor heater (left bank) 	—	RUNNING	—	1 trip	EC-131	LC
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Front heated oxygen sensor (left bank) ● Injectors ● Intake air leaks ● Fuel pressure 	—	RUNNING	—	2 trip	EC-145	EC FE
<ul style="list-style-type: none"> ● Harness or connectors (The heater circuit is open or shorted.) ● Front heated oxygen sensor heater (left bank) 	RUNNING	—	—	2 trip	EC-150	AT
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Rear heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks 	—	RUNNING (DRIVING)	—	2 trip	EC-153	PD FA
<ul style="list-style-type: none"> ● Harness or connectors (The heater circuit is open or shorted.) ● Rear heated oxygen sensor heater (right bank) 	RUNNING	—	—	2 trip	EC-158	RA
<ul style="list-style-type: none"> ● Intake air leaks ● Front heated oxygen sensor (right bank) ● Injector (right bank) ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor 	RUNNING	—	—	2 trip	EC-162	BR ST

- *1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.
- *2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.
- During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
 - This is Quick Reference of "OVERALL FUNCTION CHECK".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...	
CONSULT GST	MIL			
P0172	0114	Fuel injection system function (right bank) (rich side) (FUEL SYS RICH/BK1)	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	
P0174	0210	Fuel injection system function (left bank) (lean side) (FUEL SYS LEAN/BK2)	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	
P0175	0209	Fuel injection system function (left bank) (rich side) (FUEL SYS RICH/BK2)	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	
P0300	0701	Multiple cylinders' misfire (MULTI CYL MISFIRE)	<Three way catalyst damage> The misfire occurs, which will damage three way catalyst by overheating.	<Exhaust quality deterioration> The misfire occurs, which will not damage three way catalyst but will affect emission deterioration.
P0301	0608	No. 1 cylinder's misfire (CYL 1 MISFIRE)		
P0302	0607	No. 2 cylinder's misfire (CYL 2 MISFIRE)		
P0303	0606	No. 3 cylinder's misfire (CYL 3 MISFIRE)		
P0304	0605	No. 4 cylinder's misfire (CYL 4 MISFIRE)		
P0305	0604	No. 5 cylinder's misfire (CYL 5 MISFIRE)		
P0306	0603	No. 6 cylinder's misfire (CYL 6 MISFIRE)		
P0307	0602	No. 7 cylinder misfire (CYL 7 MISFIRE)		
P0308	0601	No. 8 cylinder misfire (CYL 8 MISFIRE)		
P0325 (*4)	0304	Knock sensor circuit (KNOCK SENSOR)	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is entered to ECM. 	
P0335	0802	Crankshaft position sensor (OBD) circuit [CRANK POS SEN (OBD)]	<ul style="list-style-type: none"> ● The proper pulse signal from the sensor is not entered to ECM while the engine is running with the specified rpm. 	

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

*4: Freeze frame data is not stored in the ECM for the "Knock sensor". The MIL will not light up for a "Knock sensor" malfunction.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC CONFIRMATION PROCEDURE" Quick Ref. *1	"OVERALL FUNCTION CHECK" Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> ● Front heated oxygen sensor (right bank) ● Injectors (right bank) ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor 	RUNNING	—	—	2 trip	EC-167	GI MA EM
<ul style="list-style-type: none"> ● Intake air leaks ● Front heated oxygen sensor (left bank) ● Injectors (left bank) ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor 	RUNNING	—	—	2 trip	EC-172	LC EC
<ul style="list-style-type: none"> ● Front heated oxygen sensor (left bank) ● Injectors (left bank) ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor 	RUNNING	—	—	2 trip	EC-177	FE
<ul style="list-style-type: none"> ● Improper spark plug ● The ignition secondary circuit is open or shorted. ● Insufficient compression ● Incorrect fuel pressure ● EGR valve ● The injector circuit is open or shorted. ● Injectors ● Intake air leaks ● Lack of fuel ● Magnetized signal plate (drive plate) 	DRIVING	—	—	< Three way catalyst damage > 1 trip < Exhaust quality deterioration > 2 trip	EC-182	AT PD FA RA BR ST
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor 	RUNNING	—	—	—	EC-186	RS
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Crankshaft position sensor (OBD) 	RUNNING	—	—	2 trip	EC-189	BT

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

● This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0340	0101	Camshaft position sensor circuit (CAMSHAFT POSI SEN)	<ul style="list-style-type: none"> ● The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. ● The cylinder No. signal is not sent to ECM during engine running. ● The cylinder No. signal is not in the normal pattern during engine running.
P0400	0302	EGR function (EGR SYSTEM)	<ul style="list-style-type: none"> ● The EGR flow is excessively low or high during the specified driving condition.
P0402	0306	EGRC-BPT valve function (EGRC-BPT VALVE)	<ul style="list-style-type: none"> ● EGRC-BPT valve does not operate properly.
P0420	0702	Three way catalyst function (left bank) (TW CATALYST SYS-B1)	<ul style="list-style-type: none"> ● Three way catalyst does not operate properly. ● Three way catalyst does not have enough oxygen storage capacity.
P0430	0703	Three way catalyst function (right bank) (TW CATALYST SYS-B2)	<ul style="list-style-type: none"> ● Three way catalyst does not operate properly. ● Three way catalyst does not have enough oxygen storage capacity.
P0500	0104	Vehicle speed sensor circuit (VEHICLE SPEED SEN)	<ul style="list-style-type: none"> ● The almost 0 km/h (0 MPH) signal from the sensor is sent to ECM even when vehicle is driving.
P0505	0205	Idle speed control function (IACV-AAC VALVE)	<ul style="list-style-type: none"> ● The idle speed control function does not operate properly.
P0600 (*5)	0504	Signal circuit from A/T control unit to ECM (A/T COMM LINE)	<ul style="list-style-type: none"> ● Signal from A/T control unit is not sent continuously to ECM. ● ECM receives incorrect voltage from A/T control unit continuously.

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

*5: In case of these diagnostic items, the freeze frame data will not be stored in ECM.

These diagnoses do not have the 2 trip detection logic, and will not light up the MIL.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	*1 "DTC CONFIRMATION PROCEDURE" Quick Ref.	*2 "OVERALL FUNCTION CHECK" Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Camshaft position sensor ● Starter motor ● Starting system circuit (EL section) ● Dead (Weak) battery 	RUNNING	—	—	2 trip	EC-193	GI MA EM LC
<ul style="list-style-type: none"> ● EGR valve stuck closed, open or leak ● Passage obstructed ● EGR valve & EVAP canister purge control solenoid valve ● EGR valve vacuum tube leaks ● EGRC-BPT valve leaks ● EGR temperature sensor 	—	RUNNING	—	2 trip	EC-197	EC FE
<ul style="list-style-type: none"> ● EGRC-BPT valve ● Rubber tube (obstructed, loose or disconnected) 	—	RUNNING	—	2 trip	EC-206	AT
<ul style="list-style-type: none"> ● Three way catalyst ● Exhaust tube ● Intake air leaks ● Injectors ● Injector leaks 	—	RUNNING	—	1 trip	EC-208	PD
<ul style="list-style-type: none"> ● Three way catalyst ● Exhaust tube ● Intake air leaks ● Injectors ● Injector leaks 	—	RUNNING	—	1 trip	EC-208	FA
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Vehicle speed sensor 	DRIVING	LIFTING	—	2 trip	EC-211	RA
<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is shorted.) ● IACV-AAC valve 	RUNNING	—	—	2 trip	EC-215	BR ST
<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open.) ● IACV-AAC valve 	IGN: ON	—	—	2 trip	EC-215	RS
<ul style="list-style-type: none"> ● Harness or connectors (The circuit between ECM and A/T control unit is open or shorted.) ● Dead (Weak) battery ● A/T control unit 	RUNNING	—	—	2 trip	EC-220	BT

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

● This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0605	0301	ECM (ECM)	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning.
P0705	1003	Park/Neutral position switch circuit (PARK/NEUT POSI SW)	<ul style="list-style-type: none"> ● The signal of the park/neutral position switch is not changed in the process of engine starting and driving.
P1120	0406	Secondary throttle position sensor circuit (TCS THRTL POS SEN)	<ul style="list-style-type: none"> ● An excessively low or high voltage from the secondary throttle sensor is sent to ECM. ● Rationally incorrect voltage from the sensor is sent to ECM compared with the voltage signals from mass air flow sensor and camshaft position sensor.
P1125	1502	Tandem throttle sensor (TANDEM T/P SEN)	<ul style="list-style-type: none"> ● Rationally incorrect voltage compared with the voltage signal from the mass air flow sensor and camshaft position sensor is sent from the sensor to ECM.
P1210	0106	Traction control system signal circuit (TCS SIGNAL)	<ul style="list-style-type: none"> ● An excessively low or high voltage is sent to ECM.
P1220	1305	FPCM circuit (FPCM)	<ul style="list-style-type: none"> ● An improper signal from the FPCM is detected by ECM.
P1320	0201	Ignition signal circuit (IGN SIGNAL-PRIMARY)	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not entered to ECM during engine cranking or running.
P1336	0905	Crankshaft position sensor (OBD) [CRANK P/S (OBD) COG]	<ul style="list-style-type: none"> ● The chipping of the signal plate (drive plate) gear tooth (cog) is detected by ECM.
P1400	1005	EGR valve and EVAP canister purge control solenoid valve (EGRC SOLENOID/V)	<ul style="list-style-type: none"> ● The improper voltage signal is sent to ECM through the solenoid valve.

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
 RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
 LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
 DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
 RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
 LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
 DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC CONFIRMATION PROCEDURE" Quick Ref. *1	"OVERALL FUNCTION CHECK" Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> ● ECM (ECCS control module) 	IGN: ON	—	X	2 trip	EC-223
<ul style="list-style-type: none"> ● Harness or connectors (The switch circuit is open or shorted.) ● Neutral position switch ● Inhibitor switch 	—	IGN: ON	—	2 trip	EC-225
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Secondary throttle position sensor ● TCM 	—	IGN: ON	X	2 trip	EC-229
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuits are open or shorted.) ● Throttle position sensor or secondary throttle position sensor ● TCM 	RUNNING	—	—	2 trip	EC-234
<ul style="list-style-type: none"> ● Harness or connectors ● TCM 	IGN: ON	—	—	—	EC-235
<ul style="list-style-type: none"> ● Harness or connectors (The FPCM circuit is open or shorted.) ● FPCM 	RUNNING	—	—	2 trip	EC-238
<ul style="list-style-type: none"> ● Harness or connectors (The ignition primary circuit is open or shorted.) ● Power transistor unit built into ignition coil ● Condenser ● Camshaft position sensor ● Camshaft position sensor circuit 	RUNNING	—	—	2 trip	EC-244
<ul style="list-style-type: none"> ● Harness or connectors ● Crankshaft position sensor (OBD) ● Signal plate (Drive plate) 	RUNNING	—	—	2 trip	EC-250
<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open or shorted.) ● EGR valve and EVAP canister purge control solenoid valve 	—	IGN: ON	—	2 trip	EC-254

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

- During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
- This is Quick Reference of "OVERALL FUNCTION CHECK".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P1401	0305	EGR temperature sensor circuit (EGR TEMP SENSOR)	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM, even when engine coolant temperature is low or high.
P1900	1308	Cooling fan circuit (COOLING FAN)	<ul style="list-style-type: none"> ● Cooling fan does not operate properly. (Overheat) ● Cooling system does not operate properly. (Overheat) ● Engine coolant was not added to the system using the proper filling method.

Note: A dead (weak) battery will reduce the accuracy of the on-board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC CONFIRMATION PROCEDURE" Quick Ref. *1	"OVERALL FUNCTION CHECK" Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EGR temperature sensor 	—	RUNNING	—	2 trip	EC-258
<ul style="list-style-type: none"> ● Harness or connectors. (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", (EC-277).</p>	—	IGN: ON (RUNNING)	—	2 trip	EC-263

- *1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.
- *2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.
- During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
 - This is Quick Reference of "OVERALL FUNCTION CHECK".
Details are described in each TROUBLE DIAGNOSIS FOR DTC XXXXX.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

A/T RELATED ITEMS (Be sure to erase the DTC stored in ECM after the A/T related repair.)

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0705	1101	Inhibitor switch circuit (INHIBITOR SWITCH)	● A/T control unit does not receive the correct voltage signal from the switch based on the gear position.
P0710	1208	Fluid temperature sensor (FLUID TEMP SENSOR)	● A/T control unit receives an excessively low or high voltage from the sensor.
P0720	1102	Revolution sensor (VHCL SPEED SEN-A/T)	● A/T control unit does not receive the proper voltage signal from the sensor.
P0725	1207	Engine speed signal (ENGINE SPEED SIG)	● A/T control unit does not receive the proper voltage signal from the ECM.
P0731	1103	Improper shifting to 1st gear position (A/T 1ST SIGNAL)	● A/T cannot be shifted to the 1st gear position even electrical circuit is good.
P0732	1104	Improper shifting to 2nd gear position (A/T 2ND SIGNAL)	● A/T cannot be shifted to the 2nd gear position even electrical circuit is good.
P0733	1105	Improper shifting to 3rd gear position (A/T 3RD SIGNAL)	● A/T cannot be shifted to the 3rd gear position even electrical circuit is good.
P0734	1106	Improper shifting to 4th gear position or TCC (A/T 4TH SIGNAL OR TCC)	● A/T cannot be shifted to the 4th gear position or perform lock-up even electrical circuit is good.
P0740	1204	T/C clutch solenoid valve (TOR CONV CLUTCH SV)	● A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0745	1205	Line pressure solenoid valve (LINE PRESSURE S/V)	● A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0750	1108	Shift solenoid valve A (SHIFT SOLENOID/V A)	● A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0755	1201	Shift solenoid valve B (SHIFT SOLENOID/V B)	● A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P1705	1206	Throttle position sensor Throttle position switch (THRTL POSI SEN-A/T)	● A/T control unit receives an excessively low or high voltage from the sensor.
P1760	1203	Overrun clutch solenoid valve (OVERRUN CLUTCH S/V)	● A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.

*1: DRIVING pattern 1-6 means as follows:

- Pattern 1 should meet b and c.
- Pattern 2 should meet a and c.
- Pattern 3 should meet a through e.
- Pattern 4 should meet a and b.
- Pattern 5 should meet a through c.
- Pattern 6 should meet a through d.

a: Selector lever is in "D" position.

b: Vehicle speed is over 10 km/h (6 MPH).

c: Throttle opening is over 1/8.

d: Engine speed is over 450 rpm.

e: A/T fluid temperature is 20 - 120°C (68 - 248°F).

*: For details, refer to each DTC CONFIRMATION PROCEDURE in AT section.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC CONFIRMATION PROCEDURE" Quick Ref. *1	"OVERALL FUNCTION CHECK" Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> ● Harness or connectors (The switch circuit is open or shorted.) ● Inhibitor switch 	DRIVING (pattern 1)	—	—	2 trip	See "Self-diagnosis", "TROUBLE DIAGNOSES" in AT section.
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fluid temperature sensor 	DRIVING (pattern 6)	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Revolution sensor 	DRIVING (pattern 2)	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The signal circuit is open or shorted.) 	DRIVING (pattern 5)	—	X	2 trip	
<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Overrun clutch solenoid valve ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit 	DRIVING (pattern 3)	—	—	2 trip	
<ul style="list-style-type: none"> ● T/C clutch solenoid valve 					
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● T/C clutch solenoid valve 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● Line pressure solenoid valve 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● Shift solenoid valve A 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● Shift solenoid valve B 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor ● Throttle position switch 	DRIVING (pattern 4)	—	X	2 trip	
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● Overrun clutch solenoid valve 	IGN: ON	—	X	2 trip	

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

● This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

INSPECTION PRIORITY

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)		
1	<ul style="list-style-type: none"> ● ECM (P0605, 0301) ● Mass air flow sensor circuit (P0100, 0102) ● Throttle position sensor circuit (P0120, 0403) ● EGR valve & EVAP canister control solenoid valve circuit (P1400, 1005) ● A/T communication line (P0600, 0504) 	<ul style="list-style-type: none"> ● Vehicle speed sensor circuit (P0500, 0104) ● Intake air temperature sensor circuit (P0110, 0401) ● Knock sensor circuit (P0325, 0304) ● Crankshaft position sensor (OBD) circuit (P0335, 0802) (P1336, 0905) 	<ul style="list-style-type: none"> ● Engine coolant temperature sensor circuit (P0115, 0103) (P0125, 0908) ● Ignition signal circuit (P1320, 0201) ● Park/Neutral position switch circuit (P0705, 1003)
2	<ul style="list-style-type: none"> ● EGR temperature sensor circuit (P1401, 0305) ● A/T related sensors, solenoid valves and switches (P0705-P0710, 1101-1208) ● Tandem throttle position sensor (P1125, 1502) ● Secondary throttle position sensor circuit (P1120, 0406) ● Rear heated oxygen sensor heater circuit (P0141,0902) (P0161, 1002) 	<ul style="list-style-type: none"> ● Front heated oxygen sensor's heater circuit (P0135, 0901) (P0155, 1001) ● Cooling fan circuit (P1900, 1308) ● Closed throttle position switch circuit (P0510, 0203) 	<ul style="list-style-type: none"> ● Front heated oxygen sensor circuit (P0130, 0303) (P0150, 0503) ● Rear heated oxygen sensors circuit (P0136, 0707), (P0156, 0708)
3	<ul style="list-style-type: none"> ● EGR function (P0400, 0302) ● EGRC-BPT valve function (P0402, 0306) ● IACV-AAC valve circuit (P0505, 0205) ● TCS signal circuit (P1210, 0106) 	<ul style="list-style-type: none"> ● Misfire (P0300 - P0308, 0701 - 0601) ● Closed loop control (P0130, 0307) (P0150, 0308) ● Improper shifting (P0731 - P0734, 1103 - 1106) ● Fuel pump control module (FPCM) circuit (P1220, 1305) 	<ul style="list-style-type: none"> ● Fuel injection system function (P0172, 0114), (P0171, 0115), (P0175, 0209), (P0174, 0210) ● Three way catalyst function (P0420, 0702) (P0430, 0703)

TROUBLE DIAGNOSIS — General Description

Fail-Safe Chart

The ECM enters fail-safe mode, if any of the following DTCs is recorded due to the open or short circuit.

DTC No.		Detected items	Engine operating condition in fail-safe mode												
CONSULT GST	MIL														
P0100	0102	Mass air flow sensor circuit	Engine speed will not rise more than 2,000 rpm due to the fuel cut.												
P0115	0103	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined based on the time after turning ignition switch "ON" or "START". <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Engine coolant temperature decided</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td style="text-align: center;">20°C (68°F)</td> </tr> <tr> <td>More than 4 minutes after ignition Start</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td style="text-align: center;">20 - 80°C (68 - 176°F) (Depends on the time)</td> </tr> </tbody> </table>		Condition	Engine coolant temperature decided	Just as ignition switch is turned ON or Start	20°C (68°F)	More than 4 minutes after ignition Start	80°C (176°F)	Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)			
Condition	Engine coolant temperature decided														
Just as ignition switch is turned ON or Start	20°C (68°F)														
More than 4 minutes after ignition Start	80°C (176°F)														
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)														
P0120	0403	Throttle position sensor circuit	Throttle position will be determined based on the amount of mass air flow and the engine speed. Therefore, acceleration will be poor. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">Driving condition</th> </tr> </thead> <tbody> <tr> <td>When engine is idling</td> <td style="text-align: center;">Normal</td> </tr> <tr> <td>When accelerating</td> <td style="text-align: center;">Poor acceleration</td> </tr> </tbody> </table>		Driving condition	When engine is idling	Normal	When accelerating	Poor acceleration						
Driving condition															
When engine is idling	Normal														
When accelerating	Poor acceleration														
P1120	0406	Secondary throttle position sensor circuit	TCS does not operate. For details, refer to BR section ("TROUBLE DIAGNOSIS FOR TCS").												
—	—	Start signal circuit	If the ECM always receives a start signal, the ECM will judge the start signal "OFF" when engine speed is above 1,000 rpm. This prevents extra enrichment. After the engine speed is below 200 rpm, start-up enrichment will be allowed until the engine speed reaches 1,000 rpm.												
—	—	ECM	<p>Fail-safe system activating condition when ECM is malfunctioning The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates, i.e. if the ECM detects a malfunction condition in the CPU of ECM, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.</p> <p>Engine control, with fail-safe system, operates when ECM is malfunctioning When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, IACV-AAC valve operation and cooling fan operation are controlled under certain limitations.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">Operation</th> </tr> </thead> <tbody> <tr> <td>Engine speed</td> <td style="text-align: center;">Engine speed will not rise more than 3,000 rpm.</td> </tr> <tr> <td>Fuel injection</td> <td style="text-align: center;">Simultaneous multiport fuel injection system</td> </tr> <tr> <td>Ignition timing</td> <td style="text-align: center;">Ignition timing is fixed at the preset value.</td> </tr> <tr> <td>Fuel pump</td> <td style="text-align: center;">Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.</td> </tr> <tr> <td>Cooling fans</td> <td style="text-align: center;">Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.</td> </tr> </tbody> </table>		Operation	Engine speed	Engine speed will not rise more than 3,000 rpm.	Fuel injection	Simultaneous multiport fuel injection system	Ignition timing	Ignition timing is fixed at the preset value.	Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.	Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.
Operation															
Engine speed	Engine speed will not rise more than 3,000 rpm.														
Fuel injection	Simultaneous multiport fuel injection system														
Ignition timing	Ignition timing is fixed at the preset value.														
Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.														
Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.														

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart

SYSTEM — Basic engine control system		SYMPTOM														Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS	OVERCHARGING		BATTERY DEAD (UNDER CHARGE)
New CT/CS		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA	
Fuel	Fuel pump circuit	●	●	●	○	●		○	○			○					EC-286
	Fuel pressure regulator system	●	○	○	○	○	○	○	○	○		○					EC-24
	Injector circuit	●	●	●	●	●	●	●	●	●		●					EC-279
	Evaporative emission system	○	○	○	○	○	○	○	○	○	○		○				EC-20
Air	Positive crankcase ventilation system	○	○	○	○	○	○	○	○	○		○	○				EC-22
	Incorrect idle speed adjustment	○	○				●	○	○	●		○					EC-29
	IACV-AAC valve circuit	●	●	●	●	●	●	●	●	●		●					EC-215
Ignition	Incorrect ignition timing adjustment	○	○	●	●	●		●	●			●					EC-29
	Ignition circuit	●	●	●	○	●		●	○			●					EC-244
EGR	EGR & EVAP canister purge control solenoid valve circuit	●	○	○	○	○		○				○					EC-254
	EGR system	●	○	●	○	○	○	●	○	○		○					EC-197
	Main power supply and ground circuit	●	○	○	○	○		●	●		○	○				○	EC-98
Cooling	Cooling fan circuit	○	○	○	○	○	○	○	○	○	●	○		●		○	EC-263
Air conditioner circuit		○	○	○	○	○	○	○	○	○		○				○	HA section

● ; High Possibility Item
○ ; Low Possibility Item

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (Cont'd)

SYSTEM — ECCS system		SYMPTOM														Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS	OVERCHARGING		BATTERY DEAD (UNDER CHARGE)	
New CT/CS		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA		
ECCS	Camshaft position sensor circuit	●	●	●	●	●	○	○	○								EC-193	
	Mass air flow sensor circuit	●	●	●	○	●	●	●	●	●		●						EC-102
	Front heated oxygen sensor circuit	●	●	●	○	●		●	○			●						EC-145, 126
	Engine coolant temperature sensor circuit	●	●	○	○	○	○	●	○	○	●	○						EC-112, 121
	Throttle position sensor circuit		●	●		●	○	●	●	○		●						EC-116
	Incorrect throttle position sensor adjustment		●	○		○	●	○	○	●		○						EC-66
	Vehicle speed sensor circuit		○	○		○						○						EC-211
	Knock sensor circuit	●	○	●	●	●	○	●				○						EC-186
	ECM	○	○	○	○	○	○	○	○	○	○	○						EC-223, 83
	Start signal circuit	○																EC-284
	Park/Neutral position switch circuit			○		○		○	○			○						EC-225
	FPCM	●	●	●		●		●										EC-238
Power steering oil pressure switch circuit		○					○	○									EC-292	

● ; High Possibility Item
○ ; Low Possibility Item

GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (Cont'd)

SYSTEM — Engine mechanical & other		SYMPTOM														Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERCOOLS	OVERCHARGING		BATTERY DEAD (UNDER CHARGE)
New CT/CS		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	1P	1X	HA	
Fuel	Fuel tank	○	○														
	Fuel piping	●	○	○	○	●		○	○			○					
	Vapor lock		○	○													
	Valve deposit	○	○	○	○	○			○	○			○				
	Poor fuel (Heavy weight gasoline, Low octane)	○	○	○	○	○		○	○			○					
Air	Air duct	○	○	○		○		○	○			○					
	Air cleaner		○	●		○		○	○			○					
	Air leakage from air duct (Mass air flow sensor — throttle body)	○	○	○	○	○	○	○	○	○		○					
	Throttle body, Throttle wire	●	●	●	●	●	●	●	○	○		○					FE section
	Air leakage from intake manifold/Collector/Gasket	●	●	●	○	●	○	○	●	○		●					
Cranking	Battery	○	○	○		○		○	○			○			○	○	
	Alternator circuit	○	○	○		○		○	○			○			○	○	EL section
	Starter circuit	●		○													
	Drive plate	○															
	Inhibitor switch	●															AT section
	Theft warning circuit	○															EL section
Engine	Cylinder head	●	○	○	○	○		○	○			○					
	Cylinder head gasket	○	○	○	○	○		○	○		○	○	○				
	Cylinder block	●	●	○	○	○		○	○			○	○				
	Piston	●	○	○	○	○		○	○			○	○				
	Piston ring	○	○	○	○	○		○	○			○	○				
	Connecting rod	○	○	○	○	○		○	○			○	○				
	Bearing	●	●	○	○	○		○	○			○	○				
	Crankshaft	○	○	○	○	●		○	○			○	●				
Valve mechanism	Timing chain	●	●	●	●	●		●	●			○	○				
	Camshaft	○	○	○	○	●		●	●			○	○				
	Intake valve	●	○	○	○	●		●	○			○	○				
	Exhaust valve	●	●	○	○	○		●	○			○	○				
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	●	●	●	●	○		●	●			○					
	Three way catalytic converter	○	○	○	○	○		○	○			○					
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	●	●	○	○	○		●	○			○	●				
	Oil level (Low)/Filthy oil	○	○	○	○	○		○	○			○	○				
Cooling	Radiator/Hose/Radiator filler cap	○	○	○	○	○		○	○		○	○					
	Thermostat	○	○	○	○	○	○	○	○	○	○	○		○			
	Water pump	○	○	○	○	○		○	○		●	○					
	Water gallery	○	○	○	○	○		○	○		○	○					
	Cooling fan	○	○	○	○	○	○	○	○	○	○	○		○			
	Coolant level (low)/Contaminated coolant	○	○	○	○	○		○	○		○	○					

● ; High Possibility Item
○ ; Low Possibility Item

TROUBLE DIAGNOSIS — General Description

CONSULT Reference Value in Data Monitor Mode

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.
- i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the crankshaft position sensor (POS) and other ignition timing related sensors.
- If the real-time diagnosis results are NG and the on-board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	CONDITION		SPECIFICATION
CMPS-RPM (POS)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.
CMPS-RPM (REF)			
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.7V
		2,000 rpm	1.5 - 2.1V
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
FR O2 SEN-B1	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V
FR O2 SEN-B2			
FR O2 MNTR-B1			LEAN ↔ RICH
FR O2 MNTR-B2			Changes more than 5 times during 10 seconds.
RR O2 SEN-B1	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V
RR O2 SEN-B2			
RR O2 MNTR-B1			LEAN ↔ RICH
RR O2 MNTR-B2			
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
THRTL POS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully closed	0.35 - 0.65V
		Throttle valve: fully opened	Approx. 4.0V
THRTL/P SEN2	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully closed	0.60 - 1.15V
		Throttle valve: fully open	4.3 - 4.7V
EGR TEMP SEN	<ul style="list-style-type: none"> ● Engine: After warming up 		Less than 4.5V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL/P SW	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: "OFF"	OFF
		Air conditioner switch: "ON" (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: "P" or "N"	ON
		Except above	OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is turned	ON

TROUBLE DIAGNOSIS — General Description

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION
IGNITION SW	● Ignition switch: ON → OFF	ON → OFF
INJ PULSE-B1	● Engine: After warming up ● Air conditioner switch: "OFF"	Idle 2.4 - 3.2 msec.
INJ PULSE-B2	● Shift lever: "N" ● No-load	2,000 rpm 1.9 - 2.8 msec.
B/FUEL SCHDL	ditto	Idle 1.0 - 1.6 msec
		2,000 rpm 0.7 - 1.3 msec
IGN TIMING	ditto	Idle 15° BTDC
		2,000 rpm More than 25° BTDC
IACV-AAC/V	ditto	Idle 20% - 40%
		2,000 rpm —
A/F ALPHA-B1 A/F ALPHA-B2	● Engine: After warming up	Maintaining engine speed at 2,000 rpm 50 - 159%
AIR COND RLY	● Air conditioner switch: OFF → ON	OFF → ON
FUEL PUMP RLY	● Ignition switch is turned to ON (Operates for 1 second) ● Engine running and cranking	ON
	Except as shown above	OFF
COOLING FAN	● After warming up engine, idle the engine. ● Air conditioner switch: "OFF"	Engine coolant temperature is 94°C (201°F) or less OFF
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F) LOW
		Engine coolant temperature is 105°C (221°F) or more HIGH
EGRC SOL/V	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle ON
		Racing up to 1,500 - 2,000 rpm OFF
O2 SEN HTR-B1	● Engine speed: Idle	ON
O2 SEN HTR-B2	● Engine speed: Above 3,200 or 2,100 rpm	OFF
CAL/LD VALUE	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle 14.0 - 33.0%
		2,500 rpm 12.0 - 25.0%
MASS AIRFLOW	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle 2.0 - 6.0 g·m/s
		2,500 rpm 7.0 - 20.0 g·m/s
FPCM	● Engine: After warming up ● Engine start then keep it idle speed	LOW → MID → HIGH
FPCM F/P VOLT	● Engine: After warming up ● Engine start then keep it idle speed	Approx. 6.6V → Approx. 3.4V → Approx. 0.4V


Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode. (Select "HI SPEED" in "DATA MONITOR" with CONSULT.)

THRTL POS SEN, ABSOL TH·P/S, CLSD THL/P SW

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL/P SW" when depressing the accelerator pedal with the ignition switch "ON".


The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL/P SW" is changed from "ON" to "OFF".



CMPS·RPM (POS), MAS AIR/FL SE, THRTL POS SEN, RR O2 SENSOR, FR O2 SENSOR, INJ PULSE


Below is the data for "CMPS·RPM (POS)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SENSOR", "FR O2 SENSOR" and "INJ PULSE" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

Each value is for reference, the exact value may vary.




TROUBLE DIAGNOSIS — General Description


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.




- "RR O2 SEN-B1" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "FR O2 SEN-B1" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.




- "INJ PULSE" should increase when depressing the accelerator pedal and should decrease when the pedal is released.




ECM Terminals and Reference Value

PREPARATION

1. ECM is located behind the center console panel. For this inspection, remove the center console under cover.




2. Remove ECM harness protector.



3. Perform all voltage measurements with the connectors connected. Extend tester probe as shown to perform tests easily.

ECM HARNESS CONNECTOR TERMINAL LAYOUT



SEF533P

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

ECM INSPECTION TABLE

Remarks: Specification data are reference values, and are measured between each terminal and Ⓜ (ECCS ground) with a voltmeter.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
1	G	Ignition signal (No. 1)	Engine is running. └ Idle speed	Approximately 0.38V★ (AC voltage)
2	Y	Ignition signal (No. 2)		
3	G/W	Ignition signal (No. 3)	Engine is running. └ Engine speed is 2,000 rpm.	Approximately 0.55V★ (AC voltage)
4	GY/R	ECCS relay (Self-shutoff)	Engine is running. Ignition switch "OFF" └ For a few seconds after turning ignition switch "OFF"	0 - 1V
			Ignition switch "OFF" └ A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
5	W/G	Tachometer	Engine is running. └ Idle speed	Approximately 7V★
7	Y/W	Ignition signal (No. 4)	Engine is running. └ Idle speed	Approximately 0.38V★ (AC voltage)
8	G/B	Ignition signal (No. 5)		
9	Y/B	Ignition signal (No. 6)	Engine is running. └ Engine speed is 2,000 rpm	Approximately 0.55V★ (AC voltage)
10	B	ECCS ground	Engine is running. └ Idle speed	Engine ground
11	P/B	Fuel pump relay	Ignition switch "ON" └ For 5 second after turning ignition switch "ON"	0 - 1V
			Engine is running. Ignition switch "ON" └ 5 second after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
12	B/R	Air conditioner relay	Engine is running. └ Both air conditioner switch and blower switch are "ON".	0 - 1V
			Engine is running. └ Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
13	G/R	Ignition signal (No. 7)	Engine is running. └ Idle speed	Approximately 0.38V★ (AC voltage)
14	Y/R	Ignition signal (No. 8)	Engine is running. └ Engine speed is 2,000 rpm.	Approximately 0.55V★ (AC voltage)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
15 16	G/OR P/L	Fuel pump control module	Engine is running. └ For 5 seconds after turning ignition switch "ON"	Approximately 1.9V	GI
			Engine is running. └ 5 seconds after starting engine and thereafter	Approximately 0V	MA EM
			Engine is running. (Warm-up condition) └ Idle speed	1.8 - 2.0V	LC
18	PU	Malfunction indicator lamp	Ignition switch "ON"	Approximately 0.1V	EC
			Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	FE
19	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	AT
20	G/B	Start signal	Ignition switch "ON"	Approximately 0V	
			Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)	PD
21	G/B	Air conditioner switch	Engine is running. └ A/C switch is "ON".	Approximately 0V	FA
			Engine is running. └ Air conditioner switch is "OFF".	Approximately 5V	RA
22	L/Y	Inhibitor switch	Ignition switch "ON" └ Gear position is "N" or "P".	Approximately 0V	BR
			Ignition switch "ON" └ Except the above gear position	Approximately 5V	ST RS
23	W	Throttle position sensor	Ignition switch "ON" (Warm-up condition) └ Accelerator pedal released	0.35 - 0.65V	BT
			Ignition switch "ON" └ Accelerator pedal fully depressed	Approximately 4V	HA
24	B/W	Ignition switch	Ignition switch "OFF"	0V	
			Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	EL
25	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	IDX
29	Y/G	Vehicle speed sensor	Engine is running. └ Jack up rear wheels and run engine at idle in "1st" position.	Approximately 5.2V★ (AC voltage)	

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
30	PU/W	Secondary throttle position sensor	Ignition switch "ON" └ Approximately 3 seconds after ignition switch "ON"	Approximately 3.4V
			Ignition switch "ON" └ Disconnect throttle motor harness connector. └ Fully close secondary throttle valve by hand.	Approximately 0.4V
31	R/G	TCS signal	Ignition switch "ON"	Approximately 5V
			Ignition switch "ON" └ Disconnect throttle motor harness connector. └ Fully close secondary throttle valve by hand.	Approximately 0V
32	B	ECCS ground	Engine is running. └ Idle speed	Engine ground
33	G	Cooling fan relay (High)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
34	BR/Y	Cooling fan relay (Low)	Engine is running. └ Cooling fan is operating.	0 - 1V
37	L/W	Throttle position sensor signal	Ignition switch "ON" (Warm-up condition) └ Accelerator pedal released	Approximately 0.4V
			Ignition switch "ON" └ Accelerator pedal fully depressed	Approximately 3V
39	B/R	Power steering oil pressure switch	Engine is running. └ Steering wheel is being turned.	0 - 1.5V
			Engine is running. └ Steering wheel is not being turned.	BATTERY VOLTAGE (11 - 14V)
42	R/W	Sensor's power supply	Ignition switch "ON"	Approximately 5V
43	B/Y	Sensor's ground	Engine is running. (Warm-up condition) └ Idle speed	0V
44 48	OR	Crankshaft position sensor (REF)	Engine is running. └ Idle speed	Approximately 1.7V★ (AC voltage)
45	B/P	Camshaft position sensor (POS)	Engine is running. └ Idle speed	Approximately 2.5V★ (AC voltage)
47	OR	Crankshaft position sensor (OBD)	Engine is running. └ Idle speed	Approximately 1.7V★ (AC voltage)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
50 51	W W	Front heated oxygen sensor (Right bank) Front heated oxygen sensor (Left bank)	Engine is running. └ After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V (periodically change)	GI MA
54	W	Mass air flow sensor	Engine is running. (Warm-up condition) └ Idle speed	1.0 - 1.4V	EM
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm.	1.4 - 1.9V	LC
55	B	Mass air flow sensor ground	Engine is running. (Warm-up condition) └ Idle speed	Approximately 0V	EC
56 57	W W	Rear heated oxygen sensor (RH) Rear heated oxygen sensor (LH)	Engine is running. └ After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V	FE AT
59	Y/B	Engine coolant temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with engine coolant temperature.	PD
60	G/R	Intake air temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with intake air temperature.	FA RA
62	BR/Y	Fuel pump control	Ignition switch "ON" └ For 5 seconds after turning ignition switch "ON".	Approximately 0.8V	BR
			Ignition switch "ON" └ 5 seconds after turning ignition switch "ON" and thereafter	BATTERY VOLTAGE (11 - 14V)	ST RS
			Engine is running. └ Idle speed	Approximately 0.9V	BT
63	OR/B	EGR temperature sensor	Engine is running. (Warm-up condition) └ Idle speed	Less than 4.5V	HA
			Engine is running. (Warm-up condition) └ EGR system is operating.	0 - 1.0V	EL
64 68	W W	Knock sensor (RH) Knock sensor (LH)	Engine is running. └ Idle speed	2.0 - 3.0V	IDX
67 72	B/W	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
69	G/W	Data link connector for GST	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div> <ul style="list-style-type: none"> └ GST is disconnected. 	6 - 10V
73	L/R	A/T signal No. 1	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	Approximately 9V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Idle speed 	Approximately 11V
74	L	A/T signal No. 2	<div style="border: 1px solid black; padding: 2px;">Ignition switch "ON"</div>	Approximately 9V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Idle speed 	Approximately 11V
75	BR/Y	Data link connector for CONSULT	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div>	Approximately 0V
76	B/L		<ul style="list-style-type: none"> └ Idle speed 	Approximately 4 - 6V
78	BR/W		<ul style="list-style-type: none"> └ Connect CONSULT and select DATA MONITOR mode. 	Approximately 3.5V
80	W/R	Power supply (Back-up)	<div style="border: 1px solid black; padding: 2px;">Ignition switch "OFF"</div>	BATTERY VOLTAGE (11 - 14V)
101	BR/W	IACV-AAC valve	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Idle speed 	10 - 11V
			<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Steering wheel is being turned. └ Air conditioner is operating. └ Rear window defogger is "ON". └ Headlamps are in high position. 	6 - 9V
102	L	Injector No. 1	<div style="border: 1px solid black; padding: 2px;">Engine is running.</div> <ul style="list-style-type: none"> └ Idle speed 	BATTERY VOLTAGE (11 - 14V)
104	L/B	Injector No. 3		
106	L/Y	Injector No. 5		
109	R	Injector No. 2		
111	R/B	Injector No. 4		
113	R/Y	Injector No. 6		
118	B/G	Injector No. 7		
120	R/G	Injector No. 8		
103	L/R	EGR valve & EVAP canister purge control solenoid valve	<div style="border: 1px solid black; padding: 2px;">Engine is running. (Warm-up condition)</div> <ul style="list-style-type: none"> └ Jack up rear wheels and run engine at 2,000 rpm in "1st" position. 	BATTERY VOLTAGE (11 - 14V)
			<div style="border: 1px solid black; padding: 2px;">Engine is running. (Warm-up condition)</div> <ul style="list-style-type: none"> └ Idle speed 	0 - 0.7V

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
107	LG/B	Rear heated oxygen sensor heater (Right bank)	Engine is running. └ Engine speed is below 3,000 rpm.	0 - 0.5V	GI
			Engine is running. └ Engine speed is above 3,000 rpm.	BATTERY VOLTAGE (11 - 14V)	MA
108	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	EM
116	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	LC
117	B/W	Current return	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	EC
119	R/B	Front heated oxygen sensor heater (right bank)	Engine is running. └ Engine speed is below 2,250 rpm.	0 - 0.5V	FE
			Engine is running. └ Engine speed is above 2,250 rpm.	BATTERY VOLTAGE (11 - 14V)	AT PD
121	R/B	Front heated oxygen sensor heater (left bank)	Engine is running. └ Engine speed is below 2,250 rpm.	0 - 0.5V	FA
			Engine is running. └ Engine speed is above 2,250 rpm.	BATTERY VOLTAGE (11 - 14V)	RA
123	L/R	Rear heated oxygen sensor heater (left bank)	Engine is running. └ Engine speed is below 3,000 rpm.	0 - 0.5V	BR
			Engine is running. └ Engine speed is above 3,000 rpm.	BATTERY VOLTAGE (11 - 14V)	ST
124	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	RS

BT



HA

EL

IDX


Main Power Supply and Ground Circuit

EC-MAIN-01



Refer to last page (Foldout page).

(M12) , (E102)
(M96) , (E110)




TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

EC-MAIN-02

: Detectable line for DTC
 : Non-detectable line for DTC



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA





EL

IDX



TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)



INSPECTION START

Start engine.
Is engine running?

A

CHECK POWER SUPPLY-I.

1. Turn ignition switch "ON".
2. Check voltage between ECM terminal (24) and ground with CONSULT or tester.

Voltage: Battery voltage

If NG, check the following.

- Harness connectors (F52, M94)
- Harness connectors (M12, E102)
- Harness for open or short between ECM and ignition switch

If NG, repair harness or connectors.

OK

Go to "CHECK GROUND CIRCUIT" on next page.

B

CHECK POWER SUPPLY-II.

1. Stop engine.
2. Check voltage between ECM terminal (80) and ground with CONSULT or tester.

Voltage: Battery voltage

NG

Check the following.

- Harness connectors (F52, M94)
- Harness connectors (M96, E110)
- 25A fuse
- Harness for open or short between ECM and battery

If NG, repair harness or connectors.

OK

C

CHECK POWER SUPPLY-III.

1. Turn ignition switch "ON" and then turn "OFF".
2. Check voltage between ECM terminals (67), (72), (117) and ground with CONSULT or tester.

Voltage:
After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop to approximately 0V.

OK

Go to "CHECK GROUND CIRCUIT" on next page.

Case-1: Battery voltage does not exist.
Case-2: Battery voltage exists for more than a few seconds.

NG

Case-1













Case-2

Go to "CHECK ECSS RELAY" on next page.

A

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0100



Mass Air Flow Sensor (MAFS) (DTC: 0102)

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to the hot film as air flow increases. This maintains the temperature of the hot film. The ECM detects the air flow by means of this current change.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0100 0102	A) An excessively high or low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor
	B)C) Voltage sent to ECM is not practical when compared with the camshaft position sensor and throttle position sensor signals.	


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Procedure for malfunction A

- | | |
|----------------|--|
| | <ol style="list-style-type: none"> 1) Turn ignition switch "ON", and wait at least 6 seconds. 2) Select "DATA MONITOR" mode with CONSULT. 3) Start engine and wait at least 3 seconds. |
| _____ OR _____ | |
| | <ol style="list-style-type: none"> 1) Turn ignition switch "ON", and wait at least 6 seconds. 2) Start engine and wait at least 3 seconds. 3) Select "MODE 3" with GST. |
| _____ OR _____ | |
| | <ol style="list-style-type: none"> 1) Turn ignition switch "ON", and wait at least 6 seconds. 2) Start engine and wait at least 3 seconds. 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON". 4) Perform diagnostic test mode II (Self-diagnostic results) with ECM. |

TROUBLE DIAGNOSIS FOR DTC P0100


Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)



SEF998N

CALC LOAD	20%
COOLANT TEMP	95°C
SHORT FT #1	2%
LONG FT #1	0%
SHORT FT #2	4%
LONG FT #2	0%
ENGINE SPD	2637RPM
VEHICLE SPD	0MPH
IGN ADVANCE	41.0°
INTAKE AIR	41°C
MAF	14.1gm/sec
THROTTLE POS	3%

SEF534P



SEF535P

Procedure for malfunction B



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
- 4) Wait at least 10 seconds at idle speed.

OR



- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Wait at least 10 seconds at idle speed.
- 4) Select "MODE 3" with GST.

OR



- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Wait at least 10 seconds at idle speed.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform diagnostic test mode II (Self-diagnostic results) with ECM.

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a DTC might not be confirmed.

Procedure for malfunction C



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
- 4) Check the voltage of mass air flow sensor with "DATA MONITOR".
- 5) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

OR



- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Select "MODE 1" with GST.
- 4) Check the mass air flow with "MODE 1".
- 5) Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.

OR




- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Check the voltage between ECM terminal 54 and ground.
- 4) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

TROUBLE DIAGNOSIS FOR DTC P0100



Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)

EC-MAFS-01



Refer to last page (Foldout page).

(M96), (E110)




TROUBLE DIAGNOSIS FOR DTC P0100

Mass Air Flow Sensor (MAFS) (DTC: 0102)

(Cont'd)


DIAGNOSTIC PROCEDURE

INSPECTION START




A
CHECK POWER SUPPLY.
 1. Turn ignition switch "OFF".
 2. Disconnect mass air flow sensor harness connector.
 3. Turn ignition switch "ON".
 4. Check voltage between terminal ② and ground with CONSULT or tester.
Voltage: Battery positive voltage

NG → Check the following.
 ● Harness for open or short between mass air flow sensor and ECM
 ● Harness for open or short between mass air flow sensor and harness connector (F52)
 If NG, repair harness or connector.




B
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect ECM harness connector.
 3. Loosen and retighten engine ground screws.
 4. Check harness continuity between terminal ③ and ECM terminal ⑤⑤.
Continuity should exist.
 If OK, check harness for short.

NG → Repair harness or connectors.



C
CHECK INPUT SIGNAL CIRCUIT.
 Check harness continuity between terminal ④ and ECM terminal ⑤④.
Continuity should exist.
 If OK, check harness for short.

NG → Repair harness or connectors.



CHECK COMPONENT
 (Mass air flow sensor).
 Refer to "COMPONENT INSPECTION" on next page.


NG → Replace mass air flow sensor.

OK → Disconnect and reconnect harness connectors in the circuits. Then retest.

→ Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P0100

Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)

COMPONENT INSPECTION



Mass air flow sensor

1. Turn ignition switch "ON".
2. Start engine and warm it up sufficiently.
3. Check voltage between terminal ④ and ground.


Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up sufficiently.)	1.0 - 1.7
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increase to about 4,000 rpm in engine speed.

4. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.



TROUBLE DIAGNOSIS FOR DTC P0110




Intake Air Temperature Sensor (DTC: 0401)

The intake air temperature sensor is mounted to the air cleaner housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor, which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

This sensor is not directly used to control the engine system. It is used only for the on-board diagnosis.



Intake air temperature °C (°F)	Voltage (V)	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0110 0401	<p>A) An excessively low or high voltage from the sensor is sent to ECM.</p> <p>B) Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.</p>	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Procedure for malfunction A

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.

OR

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select MODE 3 with GST.




OR

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform diagnostic test mode II (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

Procedure for malfunction B



- 1) Lift up vehicle and open engine hood.
- 2) Wait until engine coolant temperature is less than 90°C (194°F).
 - (a) Turn ignition switch "ON".
 - (b) Select "DATA MONITOR" mode with CONSULT.
 - (c) Check the engine coolant temperature.
 - (d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 3) Turn ignition switch "ON".
- 4) Select "DATA MONITOR" mode with CONSULT.
- 5) Start engine.
- 6) Shift selector lever to "D" position.
- 7) Hold vehicle speed at 70 - 80 km/h (43 - 50 MPH) for 2 minutes.

OR



- 1) Lift up vehicle and open engine hood.
- 2) Wait until engine coolant temperature is less than 90°C (194°F).
 - (a) Turn ignition switch "ON".
 - (b) Select MODE 1 with GST.
 - (c) Check the engine coolant temperature.
 - (d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 3) Start engine.
- 4) Shift selector lever to "D" position.
- 5) Hold vehicle speed at 70 - 80 km/h (43 - 50 MPH) for 2 minutes.
- 6) Select MODE 3 with GST.

OR




- 1) Lift up vehicle and open engine hood.
- 2) Wait until engine coolant temperature is less than 90°C (194°F).
 - (a) Turn ignition switch "ON".
 - (b) Check voltage between ECM terminal 59 and ground.

Voltage: More than 1.0 (V)
 - (c) If the voltage is not more than 1.0 (V), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before the voltage is below 1.0V.
- 3) Start engine.
- 4) Shift selector lever to "D" position.
- 5) Hold vehicle speed at 70 - 80 km/h for 2 minutes.
- 6) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 7) Perform diagnostic test mode II (Self-diagnostic results) with ECM.


TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

EC-IATS-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX







Refer to last page (Foldout page).
M96, E110

TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

DIAGNOSTIC PROCEDURE




TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)


COMPONENT INSPECTION

Intake air temperature sensor

Check resistance as shown in the figure.



SEF947Q



SEF012P

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX



Engine Coolant Temperature Sensor (ECTS) (DTC: 0103)

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



< Reference data >

Engine coolant temperature °C (°F)	Voltage (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	1.0	0.236 - 0.260

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0115 0103	<ul style="list-style-type: none"> An excessively high or low voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Engine coolant temperature sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.

OR



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 3" with GST.

OR




- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform diagnostic test mode II (Self-diagnostic results) with ECM.


TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)

EC-ECTS-01






GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature sensor harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ② and ground with CONSULT or tester.
Voltage:
Approximately 5V

NG → Check the following.
● Harness connectors
 ● (F4), (S1)
● Harness for open or short between ECM and engine coolant temperature sensor
If NG, repair harness or connectors.

B
CHECK GROUND CIRCUIT.
1. Turn ignition switch "OFF".
2. Check harness continuity between terminal ① and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Check the following.
● Harness connectors
 ● (F4), (S1)
● Harness connectors
 ● (F52), (M94)
● Joint connector-7
● Harness for open or short between ECM and engine coolant temperature sensor
● Harness for open or short between A/T control unit and engine coolant temperature sensor
● Harness for open or short between engine coolant temperature sensor and throttle control module
If NG, repair harness or connectors.

CHECK COMPONENT
(Engine coolant temperature sensor).
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace engine coolant temperature sensor.

OK → Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed. → Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END


TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)


COMPONENT INSPECTION

Engine coolant temperature sensor

Check resistance as shown in the figure.



SEF152P



SEF012P

Temperature °C (°F)	Resistance k Ω
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Throttle Position Sensor (DTC: 0403)

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This one controls engine operation such as fuel cut. The throttle position sensor unit has a built-in "Wide open and closed throttle position switch".






Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0120 0403	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM. ● Rationally incorrect voltage is sent to ECM compared with the signals from mass air flow sensor, crankshaft position sensor and IACV-AAC valve. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor

TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the throttle position sensor circuit. During this check, a DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently. GI
- 2) Turn ignition switch "OFF" and wait at least 5 seconds. MA
- 3) Turn ignition switch "ON". EM
- 4) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT. LC
- 5) Select "THRTL POS SEN" and "ABSOL TH/P/S" in "DATA MONITOR" mode with CONSULT.
- 6) Press RECORD on CONSULT SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded data and check the following:
 - The voltage when accelerator pedal fully released is approximately 0.35 - 0.65V. EC
 - The voltage rise is linear in response to accelerator pedal depression. FE
 - The voltage when accelerator pedal fully depressed is approximately 4V. AT





OR

- 1) Start engine and warm it up sufficiently. PD
- 2) Turn ignition switch "OFF" and wait at least 5 seconds. FA
- 3) Turn ignition switch "ON". RA
- 4) Check the voltage between ECM terminal 23 and 25 (ground) and check the following: BR
 - The voltage when accelerator pedal fully released is approximately 0.35 - 0.65V. ST
 - The voltage rise is linear in response to accelerator pedal depression. RS
 - The voltage when accelerator pedal fully depressed is approximately 4V. BT

TROUBLE DIAGNOSIS FOR DTC P0120






Throttle Position Sensor (DTC: 0403) (Cont'd)

EC-TPS-01



TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd) DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF".
2. Disconnect throttle position sensor harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ③ and ground with CONSULT or tester.
Voltage: Approximately 5V

NG → Repair harness or connectors.

B

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Loosen and retighten ground screw.
3. Check harness continuity between terminal ① and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Check the following.

- Joint connector-7
- Harness connectors (F52, M94)
- Harness for open or short between throttle position sensor and ECM
- Harness for open or short between throttle position sensor and A/T control unit
- Harness for open or short between throttle position sensor and throttle control module (models with TCS)

If NG, repair harness or connectors.

C

CHECK INPUT SIGNAL CIRCUIT.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ②③ and terminal ②.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

ADJUST THROTTLE POSITION SENSOR.
Perform "BASIC INSPECTION", EC-66.

CHECK COMPONENT
(Throttle position sensor).
Refer to "COMPONENT INSPECTION", on next page.



NG → Replace throttle position sensor. To adjust it, perform "BASIC INSPECTION", EC-66.

OK → (A)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd)



COMPONENT INSPECTION


Throttle position sensor

1. Start engine and warm it up sufficiently.
2. Turn ignition switch "OFF".
3. Disconnect throttle position sensor harness connector.
4. Make sure that resistance between terminals ② and ③ changes when opening throttle valve manually.

Throttle valve conditions	Resistance at 25°C (77°F)
Completely closed	Approximately 0.6 kΩ
Partially open	0.6 - 4.0 kΩ
Completely open	Approximately 5 kΩ

If NG, replace throttle position sensor.


To adjust throttle position sensor, perform "BASIC INSPECTION", EC-66.



Engine Coolant Temperature (ECT) Sensor (DTC: 0908)

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

GI
MA
EM



<Reference data>

Engine coolant temperature °C (°F)	Voltage (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	1.0	0.236 - 0.260

LC
EC
FE
AT


Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0125 0908	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> ● Harness or connectors (High resistance in the circuit) ● Engine coolant temperature sensor ● Thermostat

PD
FA
RA
BR

ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)



FUEL SYS #1	OPEN
FUEL SYS #2	OPEN
CALC LOAD	15%
COOLANT TEMP	31°C
SHORT FT #1	0%
LONG FT #1	0%
SHORT FT #2	0%
LONG FT #2	0%
ENGINE SPD	1065RPM
VEHICLE SPD	0MPH
IGN ADVANCE	15.0°
INTAKE AIR	25°C

SEF729P



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the engine coolant temperature sensor circuit. During this check, a DTC might not be confirmed.

Note: If both DTC P0115 (0103) and P0125 (0908) are displayed, first perform TROUBLE DIAGNOSIS FOR DTC P0115, EC-112.



- 1) Turn ignition switch "ON".
- 2) Select "COOLANT TEMP/S" in "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it at idle speed.
- 4) Check that the engine coolant temperature rises to 25°C (77°F) or more within 15 minutes. (Be careful not to overheat engine.)

OR



- 1) Turn ignition switch "ON".
- 2) Select "MODE 1" with GST.
- 3) Start engine and run it at idle speed.
- 4) Check that the engine coolant temperature rises to 25°C (77°F) or more within 15 minutes. (Be careful not to overheat engine.)

OR





- 1) Turn ignition switch "ON".
- 2) Probe voltage meter between ECM terminal 59 and ground.
- 3) Start engine and run it at idle speed.
- 4) Check that voltage of engine coolant temperature changes to less than 3.3 (V) within 15 minutes. (Be careful not to overheat engine.)

TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

EC-ECTS-01







GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

DIAGNOSTIC PROCEDURE





TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

COMPONENT INSPECTION

Engine coolant temperature sensor

Check resistance as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

KA


EL

IDX




Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303)

The front heated oxygen sensor (left bank) is placed into the front tube (left bank). It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor (left bank) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor (left bank) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0130 0303	<ul style="list-style-type: none"> ● An excessively high voltage from the sensor is sent to ECM. ● The voltage from the sensor is constantly approx. 0.3V. ● The maximum and minimum voltages from the sensor are not reached to the specified voltages. ● It takes more time for the sensor to respond between rich and lean than the specified time. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Front heated oxygen sensor (left bank) ● Fuel pressure ● Injectors ● Intake air leaks



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a DTC might not be confirmed.

- 1) Start engine and warm it up sufficiently.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT, and select "FR O2 SEN-B1" and "FR O2 MNTR-B1".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR-B1" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.

5 times (cycles) are counted as shown below:



cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR-B1 R-L-R-L-R-L-R-L-R-L-R

R = "FR O2 MNTR-B1", "RICH"
L = "FR O2 MNTR-B1", "LEAN"

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303) (Cont'd)

- "FR O2 SEN-B1" voltage goes above 0.6V at least once.
- "FR O2 SEN-B1" voltage goes below 0.35V at least once.
- The voltage never exceeds 1.0V.






OR

- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminal ⑤1 (sensor signal) and ②5 (engine ground).
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.35V at least one time.
 - The voltage never exceeds 1.0V.

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303) (Cont'd)





EC-FRO2LH-01



TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect front heated oxygen sensor (left bank) harness connector and ECM harness connector.
 3. Check harness continuity between ECM terminal ⑤① and terminal ②. **Continuity should exist.**
 4. Check harness continuity between ECM terminal ⑤① (or terminal ②) and ground. **Continuity should not exist.**
 If OK, check harness for short.

NG → Repair harness or connectors.

OK
 Loosen and retighten engine ground screws.

B
CLEAR THE SELF-LEARNING DATA
 1. Start engine and warm it up sufficiently.
 2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT.
 3. Clear the self-learning control coefficient by touching "CLEAR".
 4. Run engine for at least 10 minutes at idle speed.
Are the DTCs P0171, P0172 detected? Is it difficult to start engine?

Yes → Go to "TROUBLE DIAGNOSIS FOR DTC P0171, P0172", EC-162, 167.



OR
 2. Turn ignition switch "OFF".
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
 6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
 7. Run engine for at least 10 minutes at idle speed.
Are the DTCs 0114, 0115 detected? Is it difficult to start engine?

↓ No
 (A)

GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (Left bank) (DTC: 0303) (Cont'd)



COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between terminals ② and ①, ③ and ②.

Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

Closed Loop Control (DTC: 0307, 0308)

★ The closed loop control has the one trip detection logic.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0130 0307	<ul style="list-style-type: none"> The closed loop control function for left bank does not operate even when vehicle is driving in the specified condition. 	<ul style="list-style-type: none"> The front heated oxygen sensor (left bank) circuit is open or shorted. Front heated oxygen sensor (left bank) Front heated oxygen sensor heater (left bank)
P0150* 0308	<ul style="list-style-type: none"> The closed loop control function for right bank does not operate even when vehicle is driving in the specified condition. 	<ul style="list-style-type: none"> The front heated oxygen sensor (right bank) circuit is open or shorted. Front heated oxygen sensor (right bank) Front heated oxygen sensor heater (right bank)

*: Using CONSULT, "P0130" will be displayed in this case.



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.

- 1) Start engine and warm it up sufficiently.
 - 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT, and select "FRO2 MNTR-B1(B2)".
 - 3) Hold engine speed at 2,000 rpm under no load during the following steps.
 - 4) Touch "RECORD" on CONSULT screen.
 - 5) Check the following.
 - "FR O2 MNTR-B1(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
- 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
 FR O2 MNTR-B1(B2) R-L-R-L-R-L-R-L-R-L-R

R = "FR O2 MNTR-B1(B2)", "RICH"
 L = "FR O2 MNTR-B1(B2)", "LEAN"

OR

- 1) Start engine and warm it up sufficiently.
- 2) Make sure that malfunction indicator lamp goes on more than 5 times within 10 seconds while keeping at 2,000 rpm in Diagnostic Test Mode II (Front heated oxygen sensor monitor).

TROUBLE DIAGNOSIS FOR DTC P0130, P0150

Closed Loop Control (DTC: 0307, 0308) (Cont'd) DIAGNOSTIC PROCEDURE

For left bank

Refer to TROUBLE DIAGNOSIS FOR DTC P0130, EC-126.

Refer to TROUBLE DIAGNOSIS FOR DTC P0135, on next page.


For right bank

Refer to TROUBLE DIAGNOSIS FOR DTC P0150, EC-145.

Refer to TROUBLE DIAGNOSIS FOR DTC P0155, EC-150.

**Front Heated Oxygen Sensor Heater (Left bank)
(DTC: 0901)**

SYSTEM DESCRIPTION



The ECM performs ON/OFF control of the front heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Engine condition	Front heated oxygen sensor heaters
Above 2,250	—	OFF
Below 2,250	Heavy load	OFF
	Except above	ON

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0135 0901	<ul style="list-style-type: none"> The current amperage in the front heated oxygen sensor heater (left bank) circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) Front heated oxygen sensor heater (left bank)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 2) Start engine and run it for at least 5 seconds at idle speed.

OR

- 1) Start engine and run it for at least 5 seconds at idle speed.
 2) Select "MODE 3" with GST.






OR

- 1) Start engine and run it for at least 5 seconds in idle condition.
 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0135

Front Heated Oxygen Sensor Heater (Left bank) (DTC: 0901) (Cont'd)






EC-F02H-L-01



TROUBLE DIAGNOSIS FOR DTC P0135

Front Heated Oxygen Sensor Heater (Left bank) (DTC: 0901) (Cont'd)

DIAGNOSTIC PROCEDURE



COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between terminals ② and ①, ③ and ②.


Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707)

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas on left bank.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

ON-BOARD DIAGNOSIS LOGIC

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors the sensor's voltage value and the switching response during the various driving condition such as fuel-cut.



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0136 0707	<ul style="list-style-type: none"> ● An excessively high voltage from the sensor is sent to ECM. <hr style="border-top: 1px dotted black;"/> <ul style="list-style-type: none"> ● The maximum and minimum voltages from the sensor are not reached to the specified voltages. ● It takes more time for the sensor to respond between rich and lean than the specified time. 	<ul style="list-style-type: none"> ● Harness or connectors on left bank (The sensor circuit is open.) ● Rear heated oxygen sensor (left bank) <hr style="border-top: 1px dotted black;"/> <ul style="list-style-type: none"> ● Harness or connectors on left bank (The sensor circuit is shorted.) ● Rear heated oxygen sensor (left bank) ● Fuel pressure ● Injectors ● Intake air leaks

TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- 2) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR-B1" as the monitor item with CONSULT.
- 3) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%.

"RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.

OR

- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminals 57 (sensor signal) and 25 (engine ground).
- 3) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.


(depress and release accelerator pedal as soon as possible)

The voltage should be above 0.48V and below 0.43V at least once during this procedure.

If the voltage can be confirmed in step 3, step 4 is not necessary.

- 4) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.




The voltage should be above 0.48V and below 0.43V at least once during this procedure.



TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707) (Cont'd)





EC-RR02LH-01



TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK INPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.

- Rear heated oxygen sensor harness connector is located under console box. Remove console box to disconnect rear heated oxygen sensor harness connector.

Refer to BT section ("INSTRUMENT PANEL").

3. Check harness continuity between ECM terminal ⑤⑦ and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ⑤⑦ (or terminal ②) and ground. **Continuity should not exist.**

If OK, check harness for short.

NG

Check the following.

- Harness connectors (F58), (M111)

If NG, repair harness or connectors.

B

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Loosen and retighten ground screws.
3. Check harness continuity between terminal ③ and engine ground. **Continuity should exist.**

If OK, check harness for short.

NG

Check the following.

- Harness connectors (F58), (M111)
- Harness for open or short between rear heated oxygen sensor and engine ground

If NG, repair harness or connectors.



OK

Ⓐ

CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (Left Bank) (DTC: 0707) (Cont'd)



COMPONENT INSPECTION

Rear heated oxygen sensor heater

Check the following.

1. Check resistance between terminals ④ and ①.
Resistance: 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity.

Terminal No.	Continuity
② and ①, ③, ④	No
③ and ①, ②, ④	

If NG, replace the rear heated oxygen sensor.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

TROUBLE DIAGNOSIS FOR DTC P0141

Rear Heated Oxygen Sensor Heater (Left bank) (DTC: 0902)

SYSTEM DESCRIPTION



The ECM performs ON/OFF control of the rear heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Engine condition	Rear heated oxygen sensor heaters
Above 3,175	—	OFF
Below 3,175	Heavy load	OFF
	Except above	ON

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0141 0902	<ul style="list-style-type: none"> The current amperage in the rear heated oxygen sensor heater (left bank) circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the rear heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The rear heated oxygen sensor heater circuit is open or shorted.) Rear heated oxygen sensor heater (left bank)



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 - 2) Start engine and run it for at least 5 seconds at idle speed.
- OR
- 1) Start engine and run it for at least 5 seconds at idle speed.
 - 2) Select "MODE 3" with GST.
- OR
- 1) Start engine and run it for at least 5 seconds in idle condition.
 - 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0141

Rear Heated Oxygen Sensor Heater (Left bank) (DTC: 0902) (Cont'd)




EC-R02H-L-01



TROUBLE DIAGNOSIS FOR DTC P0141

Rear Heated Oxygen Sensor Heater (Left bank) (DTC: 0902) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF".
2. Disconnect rear heated oxygen sensor (left bank) harness connector.
 - Rear heated oxygen sensor harness connector is located under console box. Remove console box to disconnect rear heated oxygen sensor harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ④ and ground.

Voltage: Battery voltage

NG

Check the following.

- 15A fuse
- Joint connector-7
- Harness for open or short between front heated oxygen sensor and fuse

If NG, repair harness or connectors.

B

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between terminal ① and ECM terminal (123).

Continuity should exist.

If OK, check harness for short.

NG

Check the following.

- Harness connectors (F51, M83)
- Harness for open or short between sensor and ECM.

If NG, repair harness or connectors.

CHECK COMPONENT
(Rear heated oxygen sensor heater). Refer to "COMPONENT INSPECTION" on next page.

NG

Replace rear heated oxygen sensor (left bank).

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

TROUBLE DIAGNOSIS FOR DTC P0141

Rear Heated Oxygen Sensor Heater (Left bank) (DTC: 0902) (Cont'd)

COMPONENT INSPECTION

Rear heated oxygen sensor heater

Check the following.


1. Check resistance between terminals ④ and ①.
Resistance: 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity.



Terminal No.	Continuity
② and ①, ③, ④	No
③ and ①, ②, ④	

If NG, replace the front heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.





Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503)

The front heated oxygen sensor (right bank) is placed into the front tube (right bank). It detects the amount of oxygen in the exhaust gas compared to the outside air. The front heated oxygen sensor (right bank) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The front heated oxygen sensor (right bank) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0150 0503	<ul style="list-style-type: none"> • An excessively high voltage from the sensor is sent to ECM. • The voltage from the sensor is constantly approx. 0.3V. • The maximum and minimum voltages from the sensor are not reached to the specified voltages. • It takes more time for the sensor to respond between rich and lean than the specified time. 	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Front heated oxygen sensor (right bank) • Fuel pressure • Injectors • Intake air leaks



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a DTC might not be confirmed.

- 1) Start engine and warm it up sufficiently.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT, and select "FR O2 SEN-B2" and "FR O2 MNTR-B2".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR-B2" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.

5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |

FR O2 MNTR-B2 R-L-R-L-R-L-R-L-R-L-R



R = "FR O2 MNTR-B2", "RICH"

L = "FR O2 MNTR-B2", "LEAN"

TROUBLE DIAGNOSIS FOR DTC P0150

Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503) (Cont'd)

- "FR O2 SEN-B2" voltage goes above 0.6V at least once.
- "FR O2 SEN-B2" voltage goes below 0.35V at least once.
- The voltage never exceeds 1.0V.



OR




- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminal 50 (sensor signal) and 25 (engine ground).
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.35V at least one time.
 - The voltage never exceeds 1.0V.



TROUBLE DIAGNOSIS FOR DTC P0150

Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503) (Cont'd)

EC-FRO2RH-01







GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0150

Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK INPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor (right bank) harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal ⑤⑩ and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ⑤⑩ (or terminal ②) and ground. **Continuity should not exist.**
If OK, check harness for short.

NG → Repair harness or connectors.

OK

Loosen and retighten engine ground screws.

B

CLEAR THE SELF-LEARNING DATA

1. Start engine and warm it up sufficiently.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Are the DTCs P0174, P0175 detected? Is it difficult to start engine?

Yes → Go to "TROUBLE DIAGNOSIS FOR DTC P0174, P0175, EC-177, 172."

OR



2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
7. Run engine for at least 10 minutes at idle speed.
Are the DTCs 0209, 0210 detected? Is it difficult to start engine?

No

Ⓐ

TROUBLE DIAGNOSIS FOR DTC P0150

Front Heated Oxygen Sensor (Front HO2S) (Right bank) (DTC: 0503) (Cont'd)



COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between terminals ② and ①, ③ and ②.

Continuity should not exist.

If NG, replace the front heated oxygen sensor.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Front Heated Oxygen Sensor Heater (Right bank) (DTC: 1001)

SYSTEM DESCRIPTION




The ECM performs ON/OFF control of the front heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Engine condition	Front heated oxygen sensor heaters
Above 3,175	—	OFF
Below 3,175	Heavy load	OFF
	Except above	ON

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0155 1001	<ul style="list-style-type: none"> The current amperage in the front heated oxygen sensor heater (right bank) circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) Front heated oxygen sensor heater (right bank)


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 
 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 2) Start engine and run it for at least 5 seconds at idle speed.

_____ OR _____

- 1) Start engine and run it for at least 5 seconds at idle speed.
 2) Select "MODE 3" with GST.




_____ OR _____

- 
 1) Start engine and run it for at least 5 seconds in idle condition.
 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0155

Front Heated Oxygen Sensor Heater (Right bank) (DTC: 1001) (Cont'd)

EC-FO2H-R-01






GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0155

Front Heated Oxygen Sensor Heater (Right bank) (DTC: 1001) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
 1. Disconnect front heated oxygen sensor (right bank) harness connector.
 2. Turn ignition switch "ON".
 3. Check voltage between terminal ③ and ground.
Voltage: Battery voltage

NG → Check the following.
 ● Harness connectors (F52, M84)
 ● Joint connector-7
 ● 15A fuse
 ● Harness for open or short between front heated oxygen sensor and fuse
 If NG, repair harness or connectors.

OK →

B
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect ECM harness connector.
 3. Check harness continuity between terminal ① and ECM terminal (119).
Continuity should exist.
 If OK, check harness for short.

NG → Repair harness or connectors.

OK →

CHECK COMPONENT
 (Front heated oxygen sensor heater).
 Refer to "COMPONENT INSPECTION" below.

NG → Replace front heated oxygen sensor (right bank).

OK →

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 2.3 - 4.3Ω at 25°C (77°F)


Check continuity between terminals ② and ①, ③ and ②.


Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.





Rear Heated Oxygen Sensor (Rear HO2S) (Right Bank) (DTC: 0708)

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas on right bank.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

GI

MA

EM

LC

ON-BOARD DIAGNOSIS LOGIC

The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors the sensor's voltage value and the switching response during the various driving condition such as fuel-cut.

EC

FE

AT

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0156 0708	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors on right bank (The sensor circuit is open.) Rear heated oxygen sensor (right bank)
	<ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are not reached to the specified voltages. It takes more time for the sensor to respond between rich and lean than the specified time. 	<ul style="list-style-type: none"> Harness or connectors on right bank (The sensor circuit is shorted.) Rear heated oxygen sensor (right bank) Fuel pressure Injectors Intake air leaks

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

TROUBLE DIAGNOSIS FOR DTC P0156

Rear Heated Oxygen Sensor (Rear HO2S) (Right Bank) (DTC: 0708) (Cont'd)

OVERALL FUNCTION CHECK


Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- 2) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR-B2" as the monitor item with CONSULT.
- 3) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.
"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%.
"RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.

OR





- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminals 56 (sensor signal) and 25 (engine ground).
- 3) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
 (depress and release accelerator pedal as soon as possible)
The voltage should be above 0.48V and below 0.43V at least once during this procedure.
If the voltage can be confirmed in step 3, step 4 is not necessary.
- 4) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be above 0.48V and below 0.43V at least once during this procedure.



TROUBLE DIAGNOSIS FOR DTC P0156

Rear Heated Oxygen Sensor (Rear HO2S) (Right Bank) (DTC: 0708) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK INPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.

- Rear heated oxygen sensor harness connector is located under console box. Remove console box to disconnect rear heated oxygen sensor harness connector.

Refer to BT section ("INSTRUMENT PANEL").

3. Check harness continuity between ECM terminal 56 and terminal 2.

Continuity should exist.

4. Check harness continuity between ECM terminal 56 (or terminal 2) and ground.

Continuity should not exist.

If OK, check harness for short.

NG

Check the following.

- Harness connectors

(F57), (M108)

If NG, repair harness or connectors.

OK

B

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Loosen and retighten ground screws.
3. Check harness continuity between terminal 3 and engine ground.

Continuity should exist.

If OK, check harness for short.

NG

Check the following.

- Harness connectors
- Harness for open or short between rear heated oxygen sensor and engine ground


If NG, repair harness or connectors.

OK


(A)

TROUBLE DIAGNOSIS FOR DTC P0156

Rear Heated Oxygen Sensor (Rear HO2S) (Right Bank) (DTC: 0708) (Cont'd)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



COMPONENT INSPECTION

Rear heated oxygen sensor heater

Check the following.

1. Check resistance between terminals ④ and ①.
Resistance: 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity.

Terminal No.	Continuity
② and ①, ③, ④	No
③ and ①, ②, ④	

Continuity should not exist.

If NG, replace the rear heated oxygen sensor.


CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

TROUBLE DIAGNOSIS FOR DTC P0161

Rear Heated Oxygen Sensor Heater (Right bank) (DTC: 1002)

SYSTEM DESCRIPTION



The ECM performs ON/OFF control of the rear heated oxygen sensor heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Engine condition	Front heated oxygen sensor heaters
Above 3,175	—	OFF
Below 3,175	Heavy load	OFF
	Except above	ON

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0161 1002	<ul style="list-style-type: none"> The current amperage in the rear heated oxygen sensor heater (right bank) circuit is out of the normal range. (The improper voltage drop signal is sent to ECM through the rear heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The rear heated oxygen sensor heater circuit is open or shorted.) Rear heated oxygen sensor heater (right bank)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.

OR



- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Select "MODE 3" with GST.

OR




- 1) Start engine and run it for at least 5 seconds in idle condition.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.



TROUBLE DIAGNOSIS FOR DTC P0161

Rear Heated Oxygen Sensor Heater (Right bank) (DTC: 1002) (Cont'd)

EC-RO2H-R-01




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0161

Rear Heated Oxygen Sensor Heater (Right bank) (DTC: 1002) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF"
2. Disconnect rear heated oxygen sensor (right bank) harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ④ and ground.

● Rear heated oxygen sensor harness connector is located under console box. Remove console box to disconnect rear heated oxygen sensor harness connector. Refer to BT section ("INSTRUMENT PANEL").


Voltage: Battery voltage

NG

Check the following.

- Joint connector-7
- 15A fuse
- Harness for open or short between front heated oxygen sensor and fuse

If NG, repair harness or connectors.



B

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between terminal ① and ECM terminal ⑩⑦.

Continuity should exist.


If OK, check harness for short.

NG

Check the following.

- Harness connectors (F51), (M93)
- Harness for open or short between sensor and ECM

If NG, repair harness or connectors.



CHECK COMPONENT
(Rear heated oxygen sensor heater). Refer to "COMPONENT INSPECTION" on next page.

NG

Replace rear heated oxygen sensor (right bank).

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

TROUBLE DIAGNOSIS FOR DTC P0161


Rear Heated Oxygen Sensor Heater (Right bank) (DTC: 1002) (Cont'd)

COMPONENT INSPECTION

Rear heated oxygen sensor heater

Check the following.

1. Check resistance between terminals ④ and ①.
Resistance: 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity.



Terminal No.	Continuity
② and ①, ③, ④	No
③ and ①, ②, ④	

If NG, replace the front heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115)


ON-BOARD DIAGNOSIS LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0171 0115	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Front heated oxygen sensor (left bank) ● Injectors (left bank) ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0115 should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

OR

TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115) (Cont'd)



- 1) Disconnect mass air flow sensor harness connector.
- 2) Start engine and run it at least 3 seconds at idle speed.
- 3) Stop engine and reconnect mass air flow sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.

The DTC 0115 should be detected at this stage, if a malfunction exists.

- 9) If it is difficult to start engine at step 8, the fuel injection system also has a malfunction.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115) (Cont'd)




EC-FUELLH-01



TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK EXHAUST AIR LEAK.
 Start engine and run it at idle. Listen for an exhaust air leak before three way catalyst.

NG → Repair or replace.

OK →

CHECK FOR INTAKE AIR LEAK.
 Start engine and run it at idle. Listen for an intake air leak after the mass air flow sensor.

NG → Repair or replace.

OK →

B
CHECK FRONT HEATED OXYGEN SENSOR (LEFT BANK).

1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor (left bank) harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal ① and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ① (or terminal ②) and ground. **Continuity should not exist.** If OK, check harness for short.

NG → Repair harness or connectors.

OK →

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. Refer to EC-24.
2. Install fuel pressure gauge and check fuel pressure.

At idle:
 Approx. 235 kPa (2.4 kg/cm², 34 psi)

A few seconds after Ignition switch is turned OFF to ON:
 Approx. 294 kPa (3.0 kg/cm², 43 psi)

NG → Check fuel pump and circuit. Refer to EC-286.

OK →

CHECK MASS AIR FLOW SENSOR.

Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.

3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm

OR

Check "mass air flow" in MODE 1 with GST.

3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm

NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-102.




OK →

Ⓐ

GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Left bank) (Lean side) (DTC: 0115) (Cont'd)



C

CHECK FUNCTION OF INJECTORS (LEFT BANK).

1. Install all parts removed.
2. Start engine.
3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
4. Make sure that each circuit produces a momentary engine speed drop.

OR

3. Listen to each injector operating sound. **Clicking noise should be heard.**

NG → Perform TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS, "Injectors", EC-279. Repair harness or connectors.

OK ↓

Confirm that the engine is cooled down and there are no fire hazards near the vehicle.

1. Turn ignition switch "OFF".
2. Disconnect injector harness connectors on left bank.
3. Remove injector gallery on right bank. Refer to EC-25. Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors on right bank should remain connected.

D

1. Disconnect all ignition coil harness connectors.
2. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

NG → Replace injectors from which fuel does not spray out.

OK ↓

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.


INSPECTION END

Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114)


ON-BOARD DIAGNOSIS LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0172 0114	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> Front heated oxygen sensor (left bank) Injectors (left bank) Exhaust gas leaks Incorrect fuel pressure Mass air flow sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT.
- Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0114 should be detected at this stage, if a malfunction exists.
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

OR

TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114) (Cont'd)






- 1) Disconnect mass air flow sensor harness connector.
- 2) Start engine and run it for at least 3 seconds at idle speed.
- 3) Stop engine and reconnect mass air flow sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0114 should be detected at this stage, if a malfunction exists.
- 9) If it is difficult to start engine at step 8, the fuel injection system also has a malfunction.

TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114) (Cont'd)


EC-FUELLH-01



TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114) (Cont'd)

DIAGNOSTIC PROCEDURE




INSPECTION START

A
CHECK FOR EXHAUST AIR LEAK.
Start engine and run it at idle. Listen for an exhaust air leak before the three way catalyst.

NG → Repair or replace.


OK



B
CHECK FRONT HEATED OXYGEN SENSOR (LEFT BANK).
1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor (left bank) harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal ⑤① and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ⑤① (or terminal ②) and ground. **Continuity should not exist.**
If OK, check harness for short.

NG → Repair harness or connectors.

OK



CHECK FUEL PRESSURE.
1. Release fuel pressure to zero. Refer to EC-24.
2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 235 kPa (2.4 kg/cm², 34 psi)
A few seconds after ignition switch is turned OFF to ON:
Approx. 294 kPa (3.0 kg/cm², 43 psi)

NG → Check fuel pump and circuit. Refer to EC-286.

OK

CHECK MASS AIR FLOW SENSOR.
Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.
3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm
OR
Check "mass air flow" in MODE 1 with GST.
3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm


NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-102.

OK

Ⓐ

TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Left bank) (Rich side) (DTC: 0114) (Cont'd)



C

CHECK INJECTORS (LEFT BANK).

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals (102), (104), (111), (113) and ground with CONSULT or tester. **Battery voltage should exist.**
3. Turn ignition switch "OFF".

NG → Perform TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS, "Injectors", EC-279. Repair harness or connectors.

OK

Remove injector assembly. Refer to EC-25. Keep fuel hose and all injectors connected to injector gallery.

Confirm that the engine is cooled down and there are no fire hazards near the vehicle.

1. Disconnect all injector harness connectors.
2. Disconnect all ignition coil harness connectors.
3. Crank engine for about 3 seconds. Make sure fuel does not drip from injector.

Drips → Replace the injectors from which fuel is dripping.

Does not drip.

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0174

Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210)


ON-BOARD DIAGNOSIS LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0174 0210	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Front heated oxygen sensor (right bank) ● Injectors (right bank) ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0210 should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

OR

TROUBLE DIAGNOSIS FOR DTC P0174

Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210) (Cont'd)



- 1) Disconnect mass air flow sensor harness connector.
- 2) Start engine and run it for at least 3 seconds at idle speed.
- 3) Stop engine and reconnect mass air flow sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.

The DTC 0210 should be detected at this stage, if a malfunction exists.

- 9) If it is difficult to start engine at step 8, the fuel injection system also has a malfunction.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0174

Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210) (Cont'd)




EC-FUELRH-01



TROUBLE DIAGNOSIS FOR DTC P0174

Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK EXHAUST AIR LEAK.
Start engine and run it at idle. Listen for an exhaust air leak before three way catalyst.

NG → Repair or replace.

OK

CHECK FOR INTAKE AIR LEAK.
Start engine and run it at idle. Listen for an intake air leak after mass air flow sensor.

NG → Repair or replace.

OK

B
CHECK FRONT HEATED OXYGEN SENSOR (RIGHT BANK).
1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor (right bank) harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal ⑤ and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ⑤ (or terminal ②) and ground. **Continuity should not exist.**
If OK, check harness for short.

NG → Repair harness or connectors.

OK

CHECK FUEL PRESSURE.
1. Release fuel pressure to zero. Refer to EC-24.
2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 235 kPa (2.4 kg/cm², 34 psi)
A few seconds after Ignition switch is turned OFF to ON:
Approx. 294 kPa (3.0 kg/cm², 43 psi)

NG → Check fuel pump and circuit. Refer to EC-286.

OK

CHECK MASS AIR FLOW SENSOR.
Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.
3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm
OR
Check "mass air flow" in MODE 1 with GST.
3.0 - 6.3 g·m/sec: at idling
12.9 - 25.3 g·m/sec: at 2,500 rpm

NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-102.




OK

Ⓐ

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0174

Fuel Injection System Function (Right bank) (Lean side) (DTC: 0210) (Cont'd)



A

C

CHECK FUNCTION OF INJECTORS (RIGHT BANK).

1. Install all parts removed.
2. Start engine.
3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
4. Make sure that each circuit produces a momentary engine speed drop.

OR

3. Listen to each injector operating sound.
Clicking noise should be heard.

NG → Perform TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS, "Injectors", EC-279.
Repair harness or connectors.

OK

Confirm that the engine is cooled down and there are no fire hazards near the vehicle.

1. Turn ignition switch "OFF".
2. Disconnect injector harness connectors on right bank.
3. Remove injector gallery on left bank. Refer to EC-25.
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors on left bank should remain connected.

D

1. Disconnect all ignition coil harness connectors.
2. Crank engine for about 3 seconds.
Make sure that fuel sprays out from injector.

NG → Replace injectors from which fuel does not spray out.

OK

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END


TROUBLE DIAGNOSIS FOR DTC P0175

Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209)


ON-BOARD DIAGNOSIS LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensors. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0175 0209	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Front heated oxygen sensor (right bank) ● Injectors (right bank) ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0209 should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

OR

TROUBLE DIAGNOSIS FOR DTC P0175

Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209) (Cont'd)






- 1) Disconnect mass air flow sensor harness connector.
- 2) Start engine and run it for at least 3 seconds at idle speed.
- 3) Stop engine and reconnect mass air flow sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0209 should be detected at this stage, if a malfunction exists.
- 9) If it is difficult to start engine at step 8, the fuel injection system also has a malfunction.

TROUBLE DIAGNOSIS FOR DTC P0175

Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209) (Cont'd)


EC-FUELRH-01



TROUBLE DIAGNOSIS FOR DTC P0175

Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209) (Cont'd)

DIAGNOSTIC PROCEDURE




INSPECTION START

A
CHECK FOR EXHAUST AIR LEAK.
Start engine and run it at idle. Listen for an exhaust air leak before the three way catalyst.

NG → Repair or replace.


OK



B
CHECK FRONT HEATED OXYGEN SENSOR (RIGHT BANK).
1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor (right bank) harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal ⑤⑩ and terminal ②. **Continuity should exist.**
4. Check harness continuity between ECM terminal ⑤⑩ (or terminal ②) and ground. **Continuity should not exist.**
If OK, check harness for short.

NG → Repair harness or connectors.

OK



CHECK FUEL PRESSURE.
1. Release fuel pressure to zero. Refer to EC-24.
2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 235 kPa
(2.4 kg/cm², 34 psi)
A few seconds after ignition switch is turned OFF to ON:
Approx. 294 kPa
(3.0 kg/cm², 43 psi)

NG → Check fuel pump and circuit. Refer to EC-286.

OK

CHECK MASS AIR FLOW SENSOR.
Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.
3.0 - 6.3 g-m/sec: at idling
12.9 - 25.3 g-m/sec: at 2,500 rpm
OR
Check "mass air flow" in MODE 1 with GST.
3.0 - 6.3 g-m/sec: at idling
12.9 - 25.3 g-m/sec: at 2,500 rpm



NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-102.

OK

A

TROUBLE DIAGNOSIS FOR DTC P0175

Fuel Injection System Function (Right bank) (Rich side) (DTC: 0209) (Cont'd)




GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

No. 1 - 8 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0601)

ON-BOARD DIAGNOSIS LOGIC

If misfire occurs, the engine speed will fluctuate. If the fluctuation is detected by the crankshaft position sensor (OBD), the misfire is diagnosed.

The misfire detection logic consists of the following two conditions.



1. One Trip Detection Logic (Three Way Catalyst Damage)

When a misfire is detected which will overheat and damage the three way catalyst, the malfunction indicator lamp (MIL) will start blinking; even during the first trip. In this condition, ECM monitors the misfire every 200 engine revolutions.

If the misfire frequency decreases to a level that will not damage the three way catalyst, the MIL will change from blinking to lighting up.


(After the first trip detection, the MIL will light up from engine starting. If a misfire is detected that will cause three way catalyst damage, the MIL will start blinking.)

2. Two Trip Detection Logic (Exhaust quality deterioration)


When a misfire that will not damage the three way catalyst (but will affect exhaust emission) occurs, the malfunction indicator lamp will light up based on the second consecutive trip detection logic. In this condition, ECM monitors the misfire for each 1,000 revolutions of the engine.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0300 (0701)	● Multiple cylinders misfire.	● Improper spark plug
P0301 (0608)	● No. 1 cylinder misfires.	● Insufficient compression
P0302 (0607)	● No. 2 cylinder misfires.	● Incorrect fuel pressure
P0303 (0606)	● No. 3 cylinder misfires.	● EGR valve
P0304 (0605)	● No. 4 cylinder misfires.	● The injector circuit is open or shorted.
P0305 (0604)	● No. 5 cylinder misfires.	● Injectors
P0306 (0603)	● No. 6 cylinder misfires.	● Intake air leaks
P0307 (0602)	● No. 7 cylinder misfires.	● The ignition secondary circuit is open or shorted.
P0308 (0601)	● No. 8 cylinder misfires.	● Lack of fuel
		● Magnetized signal plate (drive plate)


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

-  1) Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT.
 2) Start engine and warm it up sufficiently.
 3) Turn ignition switch "OFF" and wait at least 5 seconds.
 4) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.

OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.
 4) Select "MODE 3" with GST.







OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.
 4) Turn ignition switch "OFF", wait at least 5 seconds, and then turn "ON".
 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0300 - P0308

No. 1 - 8 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0601) (Cont'd)

DIAGNOSTIC PROCEDURE



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT





HA

EL

IDX


TROUBLE DIAGNOSIS FOR DTC P0300 - P0308


No. 1 - 8 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0601) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P0300 - P0308

No. 1 - 8 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0601) (Cont'd)





Knock Sensor (KS) (DTC: 0304)

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

* Freeze frame data is not stored in the ECM for the knock sensor.
The MIL will not light for knock sensor malfunction.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0325 0304	<ul style="list-style-type: none"> ● An excessively low or high voltage from the knock sensor is sent to ECM. 	<ul style="list-style-type: none"> ● Harness or connectors (The knock sensor circuit is open or shorted.) ● Knock sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.

OR



- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Select "MODE 3" with GST.

OR




- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.


TROUBLE DIAGNOSIS FOR DTC P0325

Knock Sensor (KS) (DTC: 0304) (Cont'd)

EC-KS-01








GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX



TROUBLE DIAGNOSIS FOR DTC P0325

Knock Sensor (KS) (DTC: 0304) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

Loosen and retighten engine ground screws.

A

CHECK INPUT SIGNAL CIRCUIT-1.

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and knock sensor sub-harness connector-2.
3. Check harness continuity between terminal ③ (right bank), ⑥ (left bank) and ECM terminal ⑥④ (right bank), ⑥⑧ (left bank).
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

B

CHECK INPUT SIGNAL CIRCUIT-2.

Check harness continuity between terminal ③ (right bank), ⑥ (left bank) and engine ground.
Continuity should exist.
If OK, check harness for short.
It is necessary to use an ohmmeter which can measure more than 10 MΩ.

NG → Check the following.

- Harness for open or short between knock sensor sub-harness connector-2 and knock sensor
- Knock sensor (Component inspection)

If NG, repair harness or connectors.
If NG, replace knock sensor.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

COMPONENT INSPECTION

Knock sensor



1. Disconnect knock sensor harness connector.
2. Check resistance between terminal ② and ground.

Approximately 500 - 620 kΩ [at 25°C (77°F)]

- It is necessary to use an ohmmeter which can measure more than 10 MΩ.

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use a new one.



Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802)

The crankshaft position sensor (OBD) is located on the transaxle housing facing the gear teeth (cogs) of the drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.


The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system. It is used only for the on-board diagnosis of misfire.


Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0335 0802	<ul style="list-style-type: none"> The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> Harness or connectors (The crankshaft position sensor (OBD) circuit is open.) Crankshaft position sensor (OBD) Dead (Weak) battery

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE


Before performing the following procedure, confirm that battery voltage is more than 10.5V.

- 
 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 2) Crank engine for at least 2 seconds.

OR

- 
 1) Crank engine for at least 2 seconds.
 2) Select "MODE 3" with GST.


OR

- 
 1) Crank engine for at least 2 seconds.
 2) Turn ignition switch "OFF", wait at least 3 seconds and then turn "ON".
 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.


TROUBLE DIAGNOSIS FOR DTC P0335

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)

EC-CKPS-01








Refer to last page (Foldout page).
 (M96) , (E110)



TROUBLE DIAGNOSIS FOR DTC P0335

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)

DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0335

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)

COMPONENT INSPECTION

Crankshaft position sensor (OBD)


1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.





5. Check resistance as shown in the figure.

Resistance:

166.5 - 203.5 Ω [at 25°C (77°F)]





Camshaft Position Sensor (CMPS) (DTC: 0101)

The camshaft position sensor (POS) is a basic component of the ECCS. It monitors engine speed and piston position. It sends signals to the ECM to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 8 slits for 90° signal. Light Emitting Diodes (LED) and photo diodes are built into the wave-forming circuit.

When the rotor plate passes between the LED and the photo diode, the following happens:

Slits in the rotor plate continually cut the transmitted light to the photo diode from the LED. This generates rough-shaped pulses converted into on-off pulses by the wave forming circuit sent to the ECM.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0340 0101	<ul style="list-style-type: none"> The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. The cylinder No. signal is not sent to ECM during engine running. The cylinder No. signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The camshaft position sensor circuit is open or shorted.) Camshaft position sensor Starter motor (Refer to EL section.) Starting system circuit (Refer to EL section.) Dead (Weak) battery

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If both DTC P0340 and P0335 (0802) or P1336 (0905) are displayed, perform TROUBLE DIAGNOSIS FOR DTC P0335 or P1336 first. (See EC-189 or EC-250.)

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 2) Crank engine for at least 2 seconds.

OR

- 1) Crank engine for at least 2 seconds.
 2) Select "MODE 3" with GST.

OR

- 1) Crank engine for at least 2 seconds.
 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 3) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

GI
MA
EM
LC
EC

FE
AT

PD

FA
RA

BR
ST

RS
BT



HA
EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0340

Camshaft Position Sensor (CMPS) (DTC: 0101) (Cont'd)






EC-CMPS-01



TROUBLE DIAGNOSIS FOR DTC P0340

Camshaft Position Sensor (CMPS) (DTC: 0101) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

CHECK STARTING SYSTEM.
Does the engine turn over?
(Does the starter motor operate?)

No → Check starting system.
(Refer to EL section.)

Yes

A
CHECK POWER SUPPLY.
1. Turn ignition switch "OFF".
2. Disconnect camshaft position sensor harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ② and ground with CONSULT or tester.
Voltage: Battery voltage

NG → Check the following.
● Harness connectors (F52, M94)
● Harness for open or short between camshaft position sensor and ECCS relay
If NG, repair harness or connector.

OK

B
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect camshaft position sensor harness connector and ECM harness connector.
3. Check harness continuity between terminal ③ and ECM terminal ④⑤, terminal ④ and ECM terminals ④④, ④⑧.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

OK

C
CHECK GROUND CIRCUIT.
1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.
3. Check harness continuity between terminal ① and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

OK

CHECK COMPONENT [Camshaft position sensor].
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace camshaft position sensor.

OK

Ⓐ

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0340

Camshaft Position Sensor (CMPS) (DTC: 0101) (Cont'd)



COMPONENT INSPECTION

Camshaft position sensor

1. Start engine
2. Check voltage between terminals ③, ④ and ground with AC range.


Condition	Terminals	Voltage
Engine running at idle	③ and ground	Approx. 2.5V
	④ and ground	Approx. 1.8V

*: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

If NG, replace camshaft position sensor.



EGR Function (DTC: 0302)

SYSTEM DESCRIPTION



This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGR valve & EVAP canister purge control solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve. This causes the port vacuum to be discharged into the atmosphere. The EGR valve remain closed.

- Low engine coolant temperature
- Engine starting
- Engine stopped
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction
- Low vehicle speed



COMPONENT DESCRIPTION

Exhaust gas recirculation (EGR) valve

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

EGR valve and EVAP canister purge control solenoid valve

The EGR valve & EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EVAP canister and the EGR valve.



ON-BOARD DIAGNOSIS LOGIC

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0400 0302	A) The exhaust gas recirculation (EGR) flow is excessively low during the specified driving condition.	<ul style="list-style-type: none"> ● EGR valve stuck closed ● EGRC-BPT valve leaks ● Passage blocked ● EGR valve & EVAP canister purge control solenoid valve ● Tube leaking for EGR valve ● EGR temperature sensor
	B) The exhaust gas recirculation (EGR) flow is excessively high during the specified driving condition.	<ul style="list-style-type: none"> ● EGR valve & EVAP canister purge control solenoid valve ● EGR valve leaking or stuck open ● EGR temperature sensor

OVERALL FUNCTION CHECK

Use this procedure to check the overall EGR function. During this check, a DTC might not be confirmed.

Before starting with the following procedure, check the engine coolant temperature of the freeze frame data with CONSULT or Generic Scan Tool.

If the engine coolant temperature is higher than or equal to 55°C (131°F), perform only "Procedure for malfunction A".






If the engine coolant temperature is lower than 55°C (131°F), perform both "Procedure for malfunction A" and "Procedure for malfunction B".

If the freeze frame data for another malfunction is stored in the ECM, perform both "Procedure for malfunction A" and "Procedure for malfunction B". In this case, check DTCs in the ECM and perform inspections one by one based on "INSPECTION PRIORITY", EC-82.

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

Procedure for malfunction A



- 1) Start engine and warm it up sufficiently.
- 2) Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and turn the solenoid valve "OFF".
- 3) Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should lift up and down without sticking.
- 4) Check voltage between EGR temperature sensor harness connector terminal ① and ground at idle speed.
Less than 4.5V should exist.
- 5) Turn ignition switch "OFF".
- 6) Check harness continuity between EGR temperature sensor harness connector terminal ② and ECM terminal ④③.
Continuity should exist.
- 7) Perform "COMPONENT CHECK", "EGR temperature sensor", EC-205.

OR

- 1) Disconnect EGR valve & EVAP canister purge control solenoid valve harness connector. (The DTC for EGR valve & EVAP canister purge control solenoid valve will be displayed, however, ignore it.)
- 2) Start engine and warm it up sufficiently.
- 3) Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should lift up and down without sticking.
- 4) Reconnect EGR valve & EVAP canister purge control solenoid valve harness connector.
- 5) Check voltage between EGR temperature sensor harness connector terminal ① and ground at idle speed.
Less than 4.5V should exist.
- 6) Turn ignition switch "OFF".
- 7) Check harness continuity between EGR temperature sensor harness connector terminal ② and ECM terminal ④③.
Continuity should exist.
- 8) Perform "COMPONENT CHECK", "EGR temperature sensor", EC-205.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL



IDX

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)



Overall function check




Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

SEF642Q

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

Procedure for malfunction B



- 1) Start engine.
- 2) Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and turn the solenoid valve "ON".
- 3) Check for the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should be closed and should not lift up.


GI
MA

FUEL SYS #1	OPEN
FUEL SYS #2	OPEN
CALC LOAD	0%
COOLANT TEMP	31°C
SHORT FT #1	0%
LONG FT #1	0%
SHORT FT #2	0%
LONG FT #2	0%
ENGINE SPD	0RPM
VEHICLE SPD	0MPH
IGN ADVANCE	1.0°
INTAKE AIR	25°C

SEF549P

- OR
- 1) Turn ignition switch "ON".
 - 2) Confirm the engine coolant temperature is lower than 52°C (126°F) in "Mode 1" with GST. Perform the following steps before its temperature becomes higher than 52°C (126°F).
 - 3) Start engine.
 - 4) Check for the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should be closed and should not lift up.



EM
LC
EC



- OR
- 1) Turn ignition switch "ON".
 - 2) Confirm the voltage between ECM terminals 59 and 25 is higher than 2.24V. Perform the following steps before the voltage becomes lower than 2.24V.
 - 3) Start engine.
 - 4) Check for the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should be closed and should not lift up.

FE
AT
PD
FA

Overall function check



Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.



SEF642Q

RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)





EC-EGRC1-01



TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK VACUUM SOURCE TO EGR VALVE.
 1. Start engine and warm it up sufficiently.
 2. Rev engine to about 2,000 - 4,000 rpm.
 3. Disconnect vacuum hose to EGR valve.
 4. Make sure that vacuum exists.
Vacuum should exist.

OK → **CHECK COMPONENT (EGR valve).**
 Refer to "COMPONENT INSPECTION", EC-205.

NG → **Replace EGR valve.**

NG → **E**
CHECK VACUUM HOSE.
 Check vacuum hose for clogging, cracks or improper connection.

NG → **Repair it.**

OK → **C**

C
CHECK COMPONENT (EGR valve & EVAP canister purge control solenoid valve).
 1. Turn ignition switch "ON".
 2. Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

NG → **Repair or replace EGR valve & EVAP canister purge control solenoid valve or repair circuit.**

OR
 1. Turn ignition switch "ON".
 2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.


OR
 1. Turn ignition switch "ON".
 2. When disconnecting and reconnecting the solenoid valve harness connector, make sure that the solenoid valve makes operating sound. (The DTC for the solenoid valve will be displayed, however, ignore it.)

OK → **A**

GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

COMPONENT INSPECTION

EGR valve

Apply vacuum to EGR valve vacuum port with a hand vacuum pump.


EGR valve spring should lift.

If NG, replace EGR valve.

GI

MA

EM



EGR valve & EVAP canister purge control solenoid valve


Check solenoid valve, following the table as shown below:

LC

EC

FE

AT



Conditions	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

If NG, replace the solenoid valve.

EVAP canister

Gently blow air from (A).


No leakage should exist.

PD

FA

RA

BR



ST


EGR temperature sensor

Check resistance change and resistance value.

RS

BT

HA



EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10


If NG, replace EGR temperature sensor.

EL


EGRC-BPT valve

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.

IDX



EGRC-BPT Valve Function (DTC: 0306)



SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

ON-BOARD DIAGNOSIS LOGIC

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is excessive, then the vacuum to the EGR valve is interrupted through the EGR valve & EVAP canister purge control solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0402 0306	<ul style="list-style-type: none"> ● The EGRC-BPT valve does not operate properly. 	<ul style="list-style-type: none"> ● EGRC-BPT valve ● Loose or disconnected rubber tube ● Blocked rubber tube

TROUBLE DIAGNOSIS FOR DTC P0402

EGRC-BPT Valve Function (DTC: 0306) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGRC-BPT valve. During the check, a DTC might not be confirmed.




- 1) Disconnect the rubber tube to the fuel pressure regulator from the intake manifold at the fuel pressure regulator.
- 2) Disconnect the rubber tube to the EGR valve & EVAP canister purge control solenoid valve from the EGRC-BPT valve at the EGR valve & EVAP canister purge control solenoid valve.
- 3) Connect these two rubber tubes using a rubber tube that is approx. 2 meter in length and has 1 mm (0.04 in) dia. orifice made in it. (The intake manifold vacuum will be directly applied to the EGRC-BPT valve.)
- 4) Start engine.
- 5) Check for the EGR valve lifting with engine at less than 1,500 rpm under no load.

EGR valve should remain closed or slightly lift up.

- 6) Keep engine speed at about 2,000 rpm, then check the EGR valve lifting when revving engine up to 4,000 rpm under no load.

EGR valve should lift up to the full position, and go down without sticking when the engine is returned to idle.

- 7) Check rubber tube between the EGR valve & EVAP canister purge control solenoid valve and throttle body for misconnection, cracks or obstruction.




COMPONENT INSPECTION

EGRC-BPT valve

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check leakage without applying any pressure from under EGRC-BPT valve.
Leakage should exist.

Three Way Catalyst Function (DTC: 0702, 0703)

ON-BOARD DIAGNOSIS LOGIC



ECM monitors the switching frequency ratio of front and rear heated oxygen sensors. A three way catalyst with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase. When the frequency ratio of front and rear heated oxygen sensors approaches a specified limit value, the second stage diagnosis is applied. The second stage diagnosis switches the mixture ratio feedback control using front heated oxygen sensor to rear heated oxygen sensor. Then ECM measures the switching lag time between front and rear heated oxygen sensors. The longer lag time indicates the greater oxygen storage capacity. If the lag time is within the specified level, the three way catalyst malfunction is diagnosed.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
For left bank P0420 0702	<ul style="list-style-type: none"> ● Three way catalyst does not operate properly. ● Three way catalyst does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> ● Three way catalyst ● Exhaust tube ● Intake air leaks ● Injectors ● Injector leaks
For right bank P0430 0703		

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the three way catalyst. During this check, a DTC might not be confirmed.


TROUBLE DIAGNOSIS FOR DTC P0420, P0430

Three Way Catalyst Function (DTC: 0702, 0703) (Cont'd)

☆ MONITOR	☆ NO FAIL <input type="checkbox"/>
CMPS • RPM (POS)	2137rpm
FR O2 SEN-B1	0.37V
FR O2 SEN-B2	0.37V
RR O2 SEN-B1	0.32V
RR O2 SEN-B2	0.32V
FR O2 MNTR-B1	LEAN
FR O2 MNTR-B2	LEAN
RR O2 MNTR-B1	LEAN
RR O2 MNTR-B2	LEAN

RECORD

SEF907Q



- 1) Start engine and warm it up sufficiently.
- 2) Set "MANU TRIG" and "HI SPEED", then select "FR O2 SEN-B1", "FR O2 SEN-B2", "RR O2 SEN-B1 or -B2", "FR O2 MNTR-B2", "FR O2 MNTR-B1", "RR O2 MNTR" in "DATA MONITOR" mode with CONSULT.
- 3) Touch "RECORD" on CONSULT screen with engine speed held at 2,000 rpm constant under no load.
- 4) Make sure that the switching frequency between "RICH" and "LEAN" of "RR O2 SEN-B1 or -B2" is very less than that of "FR O2 SEN-B1" or "FR O2 SEN-B2".

Switching frequency ratio =

Rear heated oxygen sensor switching frequency

Front heated oxygen sensor switching frequency

This ratio should be less than 0.7.

If the ratio is greater than above, the three way catalyst is not operating properly.

Note: If the "FR O2 MNTR-B1" or "FR O2 MNTR-B2" does not indicate "RICH" and "LEAN" periodically more than 5 times within 10 seconds at step 3, perform TROUBLE DIAGNOSIS FOR DTC 0503 or 0303 first, EC-126 or EC-145.

OR



- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeters probes between ECM terminals 50 [front heated oxygen sensor (left bank) signal], 51 [front heated oxygen sensor (right bank) signal] and 25 (engine ground), and ECM terminals 56, 57 [rear heated oxygen sensor signal (left and right)] and 25 (engine ground).
- 3) Keep engine speed at 2,000 rpm constant under no load.
- 4) Make sure that the voltage switching frequency (high & low) between ECM terminals 56 and 25 is very less than that of ECM terminals 50 and 25, or 51 and 25.

Switching frequency ratio =

Rear heated oxygen sensor voltage switching frequency

Front heated oxygen sensor voltage switching frequency

This ratio should be less than 0.7.

If the ratio is greater than above, it means three way catalyst does not operate properly.


Note: If the voltage at terminal 50 or 51 does not switch periodically more than 5 times within 10 seconds at step 3, perform TROUBLE DIAGNOSIS FOR DTC 0503 or 0303 first, EC-126 or EC-145.

TROUBLE DIAGNOSIS FOR DTC P0420, P0430


Three Way Catalyst Function (DTC: 0702, 0703)

(Cont'd)


DIAGNOSTIC PROCEDURE




SEF099P



SEF904Q






TROUBLE DIAGNOSIS FOR DTC P0500



Vehicle Speed Sensor (VSS) (DTC: 0104)

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0500 0104	<ul style="list-style-type: none"> ● The almost 0 km/h (0 MPH) signal from the vehicle speed sensor is sent to ECM even when the vehicle is driving. 	<ul style="list-style-type: none"> ● Harness or connector (The vehicle speed sensor circuit is open or shorted.) ● Vehicle speed sensor



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a DTC might not be confirmed.

- 1) Jack up drive wheels.
- 2) Start engine.
- 3) Perform "VEHICLE SPEED SEN CKT" in "FUNCTION TEST" mode with CONSULT.

OR

- 2) Start engine.
- 3) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT.

The vehicle speed on CONSULT should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OR

- 2) Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with GST.

The vehicle speed on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OR

Vehicle Speed Sensor (VSS) (DTC: 0104)

(Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE




- 1) Start engine and warm it up sufficiently.
- 2) Perform test drive for at least 10 seconds continuously in the following recommended condition.
 - Engine speed : 1,500 - 2,000 rpm
 - Intake manifold vacuum: -61.3 to -50.7 kPa
(-460 to -380 mmHg, -18.11 to -14.96 inHg)
 - Gear position : Suitable position (except "N" or "P" position)
- 3) Stop the vehicle, turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Even if a Diagnostic Trouble Code is not detected, perform the above test drive at least one more time.




TROUBLE DIAGNOSIS FOR DTC P0500

Vehicle Speed Sensor (VSS) (DTC: 0104) (Cont'd)

EC-VSS-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





TROUBLE DIAGNOSIS FOR DTC P0500

Vehicle Speed Sensor (VSS) (DTC: 0104)


(Cont'd)

DIAGNOSTIC PROCEDURE




Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205)

SYSTEM DESCRIPTION



This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).



COMPONENT DESCRIPTION

IACV-AAC valve

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.


TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)


Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0505 0205	A) The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open.) ● IACV-AAC valve
	B) The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is shorted.) ● IACV-AAC valve

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE


Procedure for malfunction A

-  1) Turn ignition switch "ON".
 2) Select "DATA MONITOR" mode with CONSULT.
 3) Wait at least 2 seconds.


OR

-  1) Turn ignition switch "ON" and wait at least 2 seconds.
 2) Select "MODE 3" with GST.


OR

-  1) Turn ignition switch "ON" and wait at least 2 seconds.
 2) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.


Procedure for malfunction B

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 3 seconds.
 3) Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
 4) Start engine and run it for at least 30 seconds at idle speed.

OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 3 seconds.
 3) Start engine again and run it for at least 30 seconds at idle speed.
 4) Select "MODE 3" with GST.


OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 3 seconds.
 3) Start engine again and run it for at least 30 seconds at idle speed.
 4) Turn ignition switch "OFF", wait at least 3 seconds and then turn "ON".
 5) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P0505





Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

EC-AAC/V-01



: Detectable line for DTC
 : Non-detectable line for DTC




GI
WA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ② and ground with CONSULT or tester.

Voltage: Battery voltage

NG →

Check the following.

- Harness connectors (F52, M94)
- Joint connector-7.
- 15A fuse
- Harness for open or short between IACV-AAC valve harness connector and fuse

If NG, repair harness or connectors.

B

CHECK OUTPUT SIGNAL CIRCUIT.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ⑩ and terminal ①.

Continuity should exist.

If OK, check harness for short.

NG →

Repair harness or connectors.

CHECK COMPONENT (IACV-AAC valve).

Refer to "COMPONENT INSPECTION" below.

NG →

Replace IACV-AAC valve.


OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END



COMPONENT INSPECTION

IACV-AAC valve

Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance:

Approximately 10Ω [at 25°C (77°F)]

- Check plunger for seizing or sticking.
- Check for broken spring.

TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)



- Check plunger for seizing or sticking.
- Check for broken spring.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0600

A/T Communication Line (DTC: 0504)

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from A/T control unit to ECM.

These circuit lines are also used to control the smooth shifting up and down of A/T during the hard acceleration/deceleration. Pulse signals are exchanged between ECM and A/T control unit.

Be sure to erase the malfunction information such as DTC not only in A/T control unit but also ECM after the A/T related repair.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0600 0504	<ul style="list-style-type: none"> ● Signal from A/T control units is not sent to ECM. ● ECM receives incorrect voltage from A/T control unit continuously. 	<ul style="list-style-type: none"> ● Harness or connectors (The communication line circuit between ECM and A/T control unit is open or shorted.) ● A/T control unit ● Dead (Weak) battery

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, confirm that battery voltage is more than 10.5V.



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and let it idle for 40 seconds or start engine and wait at least 40 seconds.

OR



- 1) Start engine and let it idle for at least 40 seconds or start engine and wait at least 40 seconds.
- 2) Select "MODE 3" with GST.

OR







- 1) Start engine and let it idle for at least 40 seconds or start engine and wait at least 40 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform diagnostic test mode II (self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P0600

A/T Communication Line (DTC: 0504) (Cont'd)





EC-AT/C-01



TROUBLE DIAGNOSIS FOR DTC P0600

A/T Communication Line (DTC: 0504) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect ECM harness connector and A/T control unit harness connector.
 3. Check harness continuity between ECM terminal ⑩ and terminal ⑦③, ECM terminal ⑪ and terminal ⑦④.
Continuity should exist.
 If OK, check harness for short.

NG → Check the following.
 ● Harness connectors
 ● Check harness for open or short between ECM and A/T control unit.
 If NG, repair harness or connectors.

OK →
B
CHECK INPUT SIGNAL CIRCUIT.
 Check harness continuity between ECM terminal ⑩ and ground, ECM terminal ⑪ and ground.
Continuity should not exist.
 If OK, check harness for short.


NG → Repair harness or connectors.

OK →
 Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
 Check ECM and A/T control unit pin terminals for damage and check the connection of ECM and A/T control unit harness connectors. Reconnect ECM and A/T control unit harness connectors and retest.

INSPECTION END

TROUBLE DIAGNOSIS FOR DTC P0605



Engine Control Module (ECM)-ECCS Control Module (DTC: 0301)

The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The unit controls the engine.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
P0605 0301	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning. 	<ul style="list-style-type: none"> ● ECM (ECCS control module)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 📱
 - 1) Turn ignition switch "ON".
 - 2) Select "DATA MONITOR" mode with CONSULT.
 - 3) Start engine and run it for at least 30 seconds at idle speed.
- OR
- 📺
 - 1) Turn ignition switch "ON".
 - 2) Select "Mode 3" with GST.
 - 3) Start engine and run it for at least 30 seconds at idle speed.
- OR
- NO TOOLS
 - 1) Turn ignition switch "ON".
 - 2) Start engine and run it for at least 30 seconds at idle speed.
 - 3) Turn ignition switch "OFF" and wait at least 5 seconds.
 - 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0605

Engine Control Module (ECM)-ECCS Control Module (DTC: 0301) (Cont'd)




TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003)

When the gear position is in "P" or "N", park/neutral position is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0705 1003	<ul style="list-style-type: none"> ● The signal of the park/neutral position switch is not changed in the process of engine starting and driving. 	<ul style="list-style-type: none"> ● Harness or connectors (The inhibitor switch circuit is open or shorted.) ● Inhibitor switch

GI
MA
EM
LC
EC



OVERALL FUNCTION CHECK



Use this procedure to check the overall function of the park/neutral position switch circuit. During this check, a DTC might not be confirmed.

- 1) Turn ignition switch "ON".
 - 2) Perform "PARK/NEUT POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.
- _____ OR _____
- 2) Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT.
 - 3) Check the "P/N POSI SW" signal under the following conditions.

Condition (Gear position)	Known good signal
"P" and "N" position	ON
Except the above position	OFF

- _____ OR _____
- 1) Turn ignition switch "ON".
 - 2) Check voltage between ECM terminal 22 and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known good data)
"P" and "N" position	Approx. 0
Except the above position	Approx. 5



FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX



TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003)

(Cont'd)

EC-PNP/SW-01

— : Detectable line for DTC
 — : Non-detectable line for DTC








TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003)

(Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Disconnect inhibitor switch harness connector.
2. Turn ignition switch "ON".
3. Check voltage between terminal ③ and ground with CONSULT or tester.
Voltage: Battery voltage

NG

Check the following.

- Joint connector-7
- 10A fuse
- Harness for open or short between inhibitor switch and fuse

If NG, repair harness or connectors.

OK

B

CHECK OUTPUT SIGNAL CIRCUIT-I.

1. Turn ignition switch "OFF".
2. Disconnect park/neutral position relay harness connector.
3. Check harness continuity between relay terminal ① and park/neutral position switch terminals ④, ⑥.
Continuity should exist.

If OK, check harness for short.

NG

Check the following.

- Joint connector-7
- Harness for open or short between position switch and relay

If NG, repair harness or connectors.

OK

C

CHECK GROUND CIRCUIT.

1. Check harness continuity between relay terminals ②, ⑦ and engine ground.
Continuity should exist.

If OK, check harness for short.

NG

Repair harness or connectors.

OK

D

CHECK OUTPUT SIGNAL CIRCUIT-II.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ② and relay terminal ⑥.
Continuity should exist.

If OK, check harness for short.

NG

Check the following.

- Harness connectors (E110, M96)
- Harness connectors (M94, F52)
- Harness for open or short between ECM and relay

If NG, repair harness or connectors.

OK

CHECK COMPONENT
(Inhibitor switch).
Refer to AT section.

NG

Replace inhibitor switch.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

↓ Trouble is not fixed.

Ⓐ

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0705


Park/Neutral Position Switch (DTC: 1003) (Cont'd)



Ⓐ

Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END




Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only)

The secondary throttle position sensor responds to the movement of the throttle motor which is controlled by the TCM.

This sensor is a kind of potentiometer which transforms the secondary throttle position into output voltage, and emits the voltage signal to the TCM. In addition, the sensor detects the opening and closing speed and position of the secondary throttle valve and feeds the voltage signal to the TCM.

Another case is when the secondary throttle valve opening becomes smaller than the ordinary throttle valve opening due to TCS operation. In this case, the signal from the secondary throttle valve is used for engine control. This replaces the signal from the ordinary throttle position sensor. The signal of the secondary throttle valve first enters the TCM, from where it is sent to the ECM.

GI
MA
EM
LC
EC



FE
AT
PD
FA
RA
BR
ST
RS

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1120 0406	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM. ● Rationally incorrect voltage is sent to ECM compared with the signals from mass air flow sensor, camshaft position sensor and IACV-AAC valve. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Secondary throttle position sensor ● TCM

BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1120




Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the secondary throttle position sensor circuit. During this check, a DTC might not be confirmed.

WARNING:

Before touching the secondary throttle valve, be sure to disconnect the throttle motor harness connector. Failure to do so may cause injury due to accidental actuation of the valve.



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and disconnect throttle motor harness connector.
- 3) Remove intake air duct.
- 4) Turn ignition switch "ON".
- 5) Select "MANUAL TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT.
- 6) Select "THRTL/P SEN2" in "DATA MONITOR" mode with CONSULT.
- 7) Press RECORD on CONSULT SCREEN at the same time close the secondary throttle valve by hand.
- 8) Print out the recorded data and check the following:
 - The voltage when secondary throttle valve is closed by hand is approximately 0.60 - 1.15V.
 - The voltage decrease is linear in response to secondary throttle valve closing.
 - The voltage when secondary throttle valve is fully opened is approximately 4.3 - 4.7V.

OR




- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and disconnect throttle motor harness connector.
- 3) Remove intake air duct.
- 4) Turn ignition switch "ON".
- 5) Check the voltage between ECM terminals ⑩ and ⑳ (ground) and check the following:
 - The voltage when secondary throttle valve is closed by hand is approximately 0.60 - 1.15V.
 - The voltage decrease is linear in response to secondary throttle valve closing.
 - The voltage when secondary throttle valve is fully opened is approximately 4.3 - 4.7V.


TROUBLE DIAGNOSIS FOR DTC P1120

Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only) (Cont'd)

EC-STPS-01




GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



TROUBLE DIAGNOSIS FOR DTC P1120

Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only) (Cont'd)


DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
 1. Turn ignition switch "OFF".
 2. Disconnect secondary throttle position sensor harness connector.
 3. Turn ignition switch "ON".
 4. Check voltage between terminal ③ and ground with CONSULT or tester.
Voltage: Approximately 5V


NG → Check the following.
 ● Harness connectors (F52), (M94)
 ● Harness connectors (M11), (F58)
 ● Joint connector-5
 ● Harness for open or short between sensor and ECM
 ● Harness for open or short between sensor and TCM
 If NG, repair harness or connectors.



OK →

B
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Loosen and retighten ground screw.
 3. Check harness continuity between terminal ① and engine ground.
Continuity should exist.
 If OK, check harness for short.


NG → Check the following.
 ● Harness connectors (F52), (M94)
 ● Harness connectors (M11), (F58)
 ● Joint connector-5
 ● Harness for open or short between sensor and ECM
 ● Harness for open or short between secondary throttle position sensor and ECM
 ● Harness for open or short between secondary throttle position sensor and A/T control unit
 If NG, repair harness or connectors.



OK →

C
CHECK INPUT SIGNAL CIRCUIT.
 1. Disconnect ECM harness connector and TCM harness connector.
 2. Check harness continuity between ECM terminal ⑩ and TCM terminal ④, sensor terminal ② and TCM terminal ③.
Continuity should exist.
 If OK, check harness for short.


NG → Repair harness or connectors.



OK →

CHECK COMPONENT
 (Secondary throttle position sensor). Refer to BR section ("Adjustment for Secondary Throttle Position", "TRAC-TION CONTROL SYSTEM — TCS —").

NG → Replace secondary throttle position sensor. To adjust it, perform BASIC INSPECTION, EC-66.





OK →

①

TROUBLE DIAGNOSIS FOR DTC P1120

Secondary Throttle Position Sensor (TPS) (DTC: 0406) (Models with TCS only) (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

**Tandem Throttle Position Sensor (DTC: 1502)
(Models with TCS)**

This diagnosis is applied to models with TCS, which have tandem throttles (main throttle and secondary throttle). The quantity of intake air is determined by these two throttle valves. A rationality check is then carried out by ECM after monitoring the signals of these two throttle position sensors.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1125 1502	<ul style="list-style-type: none"> ● An excessively low or high voltage from the sensor is sent to ECM. ● Rationally incorrect voltage is entered to ECM compared with the signals from mass air flow sensor, camshaft position sensor and IACV-AAC valve. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuits are open or shorted.) ● Throttle position sensor or secondary throttle position sensor ● TCM

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, start engine and warm it up sufficiently.



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it for 15 seconds.

OR



- 1) Start engine and run it for 15 seconds.
- 2) Select MODE 3 with GST.

OR



- 1) Start engine and run it for 15 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test mode II (Self-diagnostic results)" with ECM.

DIAGNOSTIC PROCEDURE

Refer to TROUBLE DIAGNOSIS FOR DTC P0120, EC-116 OR Refer to TROUBLE DIAGNOSIS FOR DTC P1120, EC-229.

**Traction Control System (TCS) Signal Circuit
(DTC: 0106)**

The ECM uses this circuit line for checking the TCS operation. Voltage signals are sent and received between the ECM and the TCM.

- ★ Freeze frame data is not stored in the ECM for the TCS signal circuit.
- The MIL will not light for TCS signal circuit malfunction.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1210 0106	<ul style="list-style-type: none"> ● An excessively low or high voltage from the TCM is sent to ECM. 	<ul style="list-style-type: none"> ● Harness or connectors. (The circuit is open or shorted.) ● TCM

GI

MA

EM

LC

EC

FE

AT

**DIAGNOSTIC TROUBLE CODE CONFIRMATION
PROCEDURE**

PD



- 1) Turn ignition switch "ON" and TCS switch "ON", the start engine.
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 3 seconds.

FA

OR

RA



- 1) Turn ignition switch "ON" and TCS switch "ON", the start engine.
- 2) Run engine for at least 3 seconds at idle speed.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

BR

ST

RS

BT

HA




EL

IDX

TROUBLE DIAGNOSIS FOR DTC P1210

Traction Control System (TCS) Signal Circuit (DTC: 0106) (Cont'd)




EC-TCS/SW-01



TROUBLE DIAGNOSIS FOR DTC P1210

Traction Control System (TCS) Signal Circuit (DTC: 0106) (Cont'd)

DIAGNOSTIC PROCEDURE



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


Fuel Pump Control Module (FPCM) (DTC: 1305)

SYSTEM DESCRIPTION



This system controls the fuel pump operation. The amount of fuel flow delivered from the fuel pump is altered between two flow rates by the FPCM operation. The FPCM determines the voltage supplied to the fuel pump (and therefore fuel flow) according to the following conditions.

Conditions	Amount of fuel flow	Supplied voltage
<ul style="list-style-type: none"> ● Engine cranking ● Engine coolant temperature below 0°C (32°F) ● Engine is running under heavy load and high speed conditions 	high	Battery voltage (11 - 14V)
<ul style="list-style-type: none"> ● Engine is running under middle load and middle speed conditions 	middle	Approximately 7.8V
Those other than above	low	Approximately 5.6V



COMPONENT DESCRIPTION

The FPCM adjusts the voltage supplied to the fuel pump to control the amount of fuel flow. When the FPCM increases the voltage supplied to the fuel pump, the fuel flow is increased. When the FPCM decreases the voltage, the fuel flow is decreased.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1220 1305	<ul style="list-style-type: none"> ● An improper voltage signal from the FPCM is detected by ECM. 	<ul style="list-style-type: none"> ● Harness or connectors (FPCM circuit is open or shorted.) ● FPCM

TROUBLE DIAGNOSIS FOR DTC P1220

Fuel Pump Control Module (FPCM) (DTC: 1305) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, warm up engine sufficiently.



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it for at least 20 seconds.

OR



- 1) Start engine and run it for at least 20 seconds.
- 2) Select MODE 3 with GST.

OR



- 1) Start engine and run it for at least 20 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test mode II (Self-diagnostic results)" with ECM.

GI

WA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

TROUBLE DIAGNOSIS FOR DTC P1220

Fuel Pump Control Module (FPCM) (DTC: 1305) (Cont'd)







EC-FPCM-01



TROUBLE DIAGNOSIS FOR DTC P1220

Fuel Pump Control Module (FPCM) (DTC: 1305) (Cont'd)

DIAGNOSTIC PROCEDURE



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

DX

TROUBLE DIAGNOSIS FOR DTC P1220

Fuel Pump Control Module (FPCM) (DTC: 1305) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P1220

Fuel Pump Control Module (FPCM) (DTC: 1305) (Cont'd)


COMPONENT INSPECTION

CAUTION:

Be sure to ground the FPCM body before inspection.

Fuel pump control module

1. Turn off engine and disconnect fuel pump control module harness connector.
2. Connect proper wires between the fuel pump control module harness terminals.
3. Start engine and check voltage between terminal ⑦ and terminal ④ on fuel pump control module.
If NG, replace fuel pump control module.



Connected terminal connections and measured terminals		Voltage
	Battery voltage	
	7.5 - 8.1V	
	5.4 - 5.8V	

SEF337R

If NG, replace fuel pump control module.

GI
MA
EM
LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



Ignition Signal (DTC: 0201)

Ignition coil & power transistor

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1320 0201	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not sent during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness or connectors (The ignition primary circuit is open or shorted.) ● Power transistor unit built into ignition coil ● Camshaft position sensor ● Camshaft position sensor circuit

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If both DTC P1320 (0201) and DTC P0340 (0101), P0335 (0802) or P1336 (0905) are displayed, perform TROUBLE DIAGNOSIS FOR DTC P0340, P0335 or P1336 first. (See EC-189, 193 or 250.)



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)

OR



- 1) Turn ignition switch "ON".
- 2) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 3) Select MODE 3 with GST.

OR




- 1) Turn ignition switch "ON".
- 2) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform diagnostic test mode II (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)

EC-IGN/SG-01



: Detectable line for DTC
 : Non-detectable line for DTC

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX






Refer to last page (Foldout page).
 (M12), (E102)

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)




EC-IGN/SG-02



TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)

EC-IGN/SG-03



GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)

DIAGNOSTIC PROCEDURE

A

■ ACTIVE TEST ■ □

*** POWER BALANCE ***

=== MONITOR ===





CMPS-RPM(POS) 650rpm

MAS AIR/FL SE 1.12V

IACV-AAC/V 23%

1	2	3	4	TEST START
5	6	7	8	


SEF375N




INSPECTION START

Does engine start?

No

Yes (without )

Yes (with )

B

SEARCH FOR MALFUNCTIONING CIRCUIT-2.

1. Turn ignition switch "ON".
2. Check voltage between ignition coil terminal ③ (No. 1 and No. 2 cylinder) or ① (Except No. 1 and No. 2 cylinder) and ground.

Voltage:
Approx. 0.4V at AC range

A

SEARCH FOR MALFUNCTIONING CIRCUIT-1.

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
3. Search for circuit which does not produce a momentary engine speed drop.

C

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF".
2. Disconnect ignition harness connectors.
3. Turn ignition switch "ON".
4. Check voltage between each ignition coil harness connector terminal ① (No. 1 and No. 2 cylinders) or ③ (except No. 1 and No. 2 cylinders) and ground.

Voltage: Battery voltage

NG

Check the following.

- Harness connectors (S69, F13) (left bank)
- Harness connectors (S8, F1) (right bank)
- Harness connectors (F52, M94)
- Harness connectors (M12, E102)
- Harness for open or short between ignition switch and ignition coils

If NG, repair harness, connectors or component.

D

CHECK OUTPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect each ignition coil harness connector and ECM harness connector.
3. Check harness continuity between each ignition coil harness connector terminal ③ (No. 1 and No. 2 cylinders) or ① (Except No. 1 and No. 2 cylinders) and each ECM harness connector terminal.

Continuity should exist.

If OK, check harness for short.

NG

Check the following.

- Harness connectors (S8, F1) (right bank)
- Harness connectors (S69, F13) (left bank)
- Harness for open or short between ignition coil and ECM






If NG, repair harness or connectors.

OK

A

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)



COMPONENT INSPECTION


Ignition coil with power transistor

1. Disconnect ignition coil with power transistor harness connector.
2. Check ignition coil with power transistor for resistance between terminals ① and ②.

Cylinder numbers	Terminals	Resistance	Result
1 and 2	① and ②	Not 0Ω	OK
		0Ω	NG
3, 4, 5, 6, 7, 8	③ and ②	Not 0Ω	OK
		0Ω	NG

If NG, replace ignition coil with power transistor assembly.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Crankshaft Position Sensor (CKPS) (OBD) (COG) (DTC: 0905)

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system. It is used only for the on-board diagnosis of misfire.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1336 0905	<ul style="list-style-type: none"> ● Chipping of the signal plate (on drive plate) gear teeth (cogs) is detected by the ECM. 	<ul style="list-style-type: none"> ● Harness or connectors ● Crankshaft position sensor (POS) ● Signal plate (drive plate) ● Dead (Weak) battery

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

- ① 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
2) Start engine and run it for at least 1 minute and 10 seconds at idle speed.

OR

- ② 1) Start engine and run it for at least 1 minute and 10 seconds at idle speed.
2) Select "MODE 3" with GST.



OR

- ③ 1) Start engine and run it for at least 1 minute and 10 seconds at idle speed.
2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P1336

Crankshaft Position Sensor (CKPS) (OBD) (COG) (DTC: 0905) (Cont'd)

EC-CKPS-01








Refer to last page (Foldout page).
 (M96), (E110)

GI
 MA
 EV
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IX

TROUBLE DIAGNOSIS FOR DTC P1336



Crankshaft Position Sensor (CKPS) (OBD) (COG) (DTC: 0905) (Cont'd)

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P1336


Crankshaft Position Sensor (CKPS) (OBD) (COG) (DTC: 0905) (Cont'd)



COMPONENT INSPECTION

Crankshaft position sensor (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.




5. Check resistance as shown in the figure.

Resistance:

166.5 - 203.5Ω [at 25°C (77°F)]

TROUBLE DIAGNOSIS FOR DTC P1400





EGR Valve and EVAP Canister Purge Control Solenoid Valve (DTC: 1005)

The EGR valve and EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve.)

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EVAP canister and the EGR valve.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1400 1005	<ul style="list-style-type: none"> ● The improper voltage signal is sent to ECM through EGR valve & EVAP canister purge control solenoid valve. 	<ul style="list-style-type: none"> ● Harness or connectors (The EGR valve & EVAP canister purge control solenoid valve circuit is open or shorted.) ● EGR valve & EVAP canister purge control solenoid valve



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGR valve and EVAP canister purge control solenoid valve circuit. During this check, a DTC might not be confirmed.

- 1) Turn ignition switch "ON".
- 2) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 1) Turn ignition switch "ON".
- 2) Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and check the operating sound, according to ON/OFF switching.


OR

- 1) Turn ignition switch "ON".
- 2) When disconnecting and reconnecting the EGR valve & EVAP canister purge control solenoid valve harness connector, make sure that the solenoid valve makes operating sound.

TROUBLE DIAGNOSIS FOR DTC P1400

EGR Valve and EVAP Canister Purge Control Solenoid Valve (DTC: 1005) (Cont'd)




EC-EGRC/V-01



Refer to EL-POWER.

: Detectable line for DTC
 : Non-detectable line for DTC




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P1400

EGR Valve and EVAP Canister Purge Control Solenoid Valve (DTC: 1005) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK POWER SUPPLY.

1. Disconnect EGR valve & EVAP canister purge control solenoid valve harness connector.
2. Turn ignition switch "ON".
3. Check voltage between terminal ② and ground with CONSULT or tester.

Voltage: Battery voltage

NG

Check the following.

- Harness connectors (F62), (M94)
- 15A fuse
- Joint connector-7
- Harness continuity between EGR valve & EVAP canister purge control solenoid valve and fuse

If NG, repair harness or connectors.

OK

B

CHECK OUTPUT SIGNAL CIRCUIT.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal (103) and terminal ①.

Continuity should exist.

If OK, check harness for short.

NG

Repair harness or connectors.

OK

CHECK COMPONENT (EGR valve & EVAP canister purge control solenoid valve). Refer to "COMPONENT INSPECTION" on next page.

NG

Replace EGR valve & EVAP canister purge control solenoid valve.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END


TROUBLE DIAGNOSIS FOR DTC P1400

EGR Valve and EVAP Canister Purge Control Solenoid Valve (DTC: 1005) (Cont'd)

COMPONENT INSPECTION

EGR valve & EVAP canister purge control solenoid valve

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX



EGR Temperature Sensor (DTC: 0305)

The EGR temperature sensor detects temperature changes in the EGR passage way. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passage way changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. This sensor is not directly used to control the engine system. It is used only for the on-board diagnosis.



EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1401 0305	A) An excessively low voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is low.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is shorted.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGR valve & EVAP canister purge control solenoid valve
	B) An excessively high voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is high.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is open.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGR valve & EVAP canister purge control solenoid valve

TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)

OVERALL FUNCTION CHECK





Use this procedure to check the overall function of the EGR temperature sensor. During this check, a DTC might not be confirmed.

Procedure for malfunctions A and B

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Confirm that engine coolant temperature and intake air temperature are lower than 40°C (104°F). (If necessary, wait until the temperatures equal atmospheric temperature.)
- 3) Confirm that "EGR TEMP SEN" reading is between 3.45V and 5.0V.
- 4) Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0306, EC-197 and 206.
- 7) Read "EGR TEMP SEN" at about 1,500 rpm with EGR valve lifted up to the full position by hand. **Voltage should decrease to less than 1.0V.**
- 8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0306 and P1400, EC-197, 206 and 254.

OR

- 1) Turn ignition switch "ON".
- 2) Confirm that voltage between ECM terminals 59, 60 and ground is more than 2.72V. (If necessary, wait until engine coolant temperature and intake air temperature equal atmospheric temperature.)
- 3) Confirm that voltage between ECM terminal 63 and ground is between 3.45V and 5.0V.
- 4) Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0402, EC-197 and 206.
- 7) Check voltage between ECM terminal 63 and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand. **Voltage should decrease to less than 1.0V.**
- 8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0306 and P1400, EC-197, 206 and 254.








GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)

EC-EGR/TS-01


-  : Detectable line for DTC
-  : Non-detectable line for DTC
-  : Models with TCS



TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)

DIAGNOSTIC PROCEDURE




INSPECTION START

A
CHECK POWER SUPPLY.
 1. Disconnect EGR temperature sensor harness connector.
 2. Turn ignition switch "ON".
 3. Check voltage between terminal ① and ground with CONSULT or tester.
Voltage: Approximately 5V

NG → Repair harness or connectors.


GI
MA
EM



B
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Check harness continuity between terminal ② and engine ground.
Continuity should exist.
 If OK, check harness for short.

NG → Check the following.
 ● Harness connectors (F52, M94)
 ● Joint connector-7
 ● Harness for open or short between ECM and EGR temperature sensor
 ● Harness for open or short between EGR temperature sensor and throttle control module
 ● Harness for open or short between A/T control unit and EGR temperature sensor
 If NG, repair harness or connector.

LC
EC



CHECK COMPONENT
 (EGR temperature sensor).
 Refer to "COMPONENT INSPECTION" on next page.

NG → Replace EGR temperature sensor.

FE
AT
PD
FA
RA

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
 Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)

COMPONENT INSPECTION

EGR temperature sensor

Check resistance change and resistance value.




EGR temperature °C (°F)	Voltage (V)	Resistance (M Ω)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

If NG, replace EGR temperature sensor.

Cooling Fan (DTC: 1308)

SYSTEM DESCRIPTION FOR USA


Input/output signal line



The ECM controls the cooling fan corresponding to vehicle speed, engine coolant temperature and

air conditioner ON signal. The control system has a 2-step control [HIGH/LOW/OFF].


Operation



The cooling fan operates at HIGH if diagnostic test mode II (self-diagnostic results) for engine coolant temperature sensor is "NG".

SYSTEM DESCRIPTION FOR CANADA


Input/output signal line



The ECM controls the cooling fan corresponding to vehicle speed, engine coolant temperature and

air conditioner ON signal. The control system has a 1-step control [ON/OFF].

Operation



The cooling fan operates if diagnostic test mode II (self-diagnostic results) for engine coolant temperature sensor is "NG".

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

ON-BOARD DIAGNOSIS LOGIC

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, the engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Diagnostic trouble code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1900 1308	<ul style="list-style-type: none">● Cooling fan does not operate properly (Overheat).● Cooling fan system does not operate properly (Overheat).● Engine coolant was not added to the system using the proper filling method.	<ul style="list-style-type: none">● Harness or connectors. (The cooling fan circuit is open or shorted.)● Cooling fan● Radiator hose● Radiator● Radiator cap● Water pump● Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", (EC-277).</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- After refilling coolant, run engine to ensure that no water-flow noise is emitted.

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)


OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.


Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.




AEC640



MEF314F



SEF911Q



MEF986E

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "DIAGNOSTIC PROCEDURE", EC-268.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "DIAGNOSTIC PROCEDURE", EC-268.



- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT (LOW speed and HI speed).

OR



- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that cooling fan operates at low speed.
- 9) Turn ignition switch "OFF".
- 10) Turn air conditioner switch and blower fan switch "OFF".
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

EC-COOL/F-01



US : Models for U.S.A.
 CN : Models for Canada



Refer to last page (Foldout page).





(M96) . (E110)



TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

EC-COOL/F-02



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX






TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

DIAGNOSTIC PROCEDURE

Models for USA

INSPECTION START



A

CHECK COOLING FAN LOW SPEED OPERATION.

1. Disconnect cooling fan relay-2.
2. Turn ignition switch "ON".
3. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

2. Turn ignition switch "ON".
3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

OR

2. Start engine.
3. Set temperature lever at full cold position.
4. Turn air conditioner switch "ON".
5. Turn blower fan switch "ON".
6. Run engine at idle for a few minutes with air conditioner operating.
7. Make sure that cooling fan operates at low speed.

NG → Check cooling fan low speed control circuit. (Go to PROCEDURE A.)

OK
A

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

B

■ COOLING FAN CIRCUIT ■

DOES
COOLING FAN
ROTATE AND STOP
EVERY 3 SECONDS ?

NEXT NO YES

MEF311F

B

■ ACTIVE TEST ■

COOLING FAN OFF

=== MONITOR ===

COOLANT TEMP/S 88°C

HI LOW OFF

MEF314F

B

Cooling fan

Engine coolant temperature sensor harness connector

150Ω resistor

DISCONNECT

DISCONNECT

MEF986E

C

DISCONNECT

DISCONNECT

SEF820Q

B

CHECK COOLING FAN HIGH SPEED OPERATION.

1. Turn ignition switch "OFF".
2. Reconnect cooling fan relay-2.
3. Disconnect cooling fan relay-1.
4. Turn ignition switch "ON".
5. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

4. Turn ignition switch "ON".
5. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

OR

4. Turn air conditioner switch and blower fan switch "OFF".
5. Disconnect engine coolant temperature sensor harness connector.
6. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
7. Restart engine and make sure that cooling fan operates at higher speed than low speed.

NG → Check cooling fan high speed control circuit. (Go to PROCEDURE B.)

C

CHECK HARNESS CONTINUITY BETWEEN COOLING FAN RELAY-1 AND GROUND.

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Disconnect triple-pressure switch harness connector.
4. Check harness continuity between relay-1 terminal ② and switch terminal ④, switch terminal ③ and engine ground.

Continuity should exist.
If OK, check harness for short.

NG → Check the following.

- Joint connector-6
- Harness for open or short between triple-pressure switch and relay-1

If NG, repair harness or connectors.

CHECK COMPONENT (Triple-pressure switch).
Refer to HA section ("Electrical Components Inspection", "TROUBLE DIAGNOSES").






NG → Replace triple-pressure switch.

OK → (Go to EC-275.)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



PROCEDURE A

INSPECTION START

D **CHECK POWER SUPPLY.**

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".
4. Check voltage between terminals ①, ⑤ and ground with CONSULT or tester.

Voltage: Battery voltage

NG → Check the following.

- Harness connectors (E110, M96)
- 10A fuse
- 30A fusible links
- Joint connector-1
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

If NG, repair harness or connectors.

E **CHECK GROUND CIRCUIT.**

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor harness connector.
3. Check harness continuity between relay terminal ③ and cooling fan motor terminal ①.
4. Check harness continuity between terminal ④ and engine ground.

Continuity should exist.

If OK, check harness for short.

NG → Repair harness or connectors.

F **CHECK OUTPUT SIGNAL CIRCUIT.**

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ③④ and relay-1 terminal ②.

Continuity should exist.

If OK, check harness for short.

NG → Check the following.


- Harness connectors (F58, M111)
- Harness connectors (M96, E110)
- Joint connector-6
- Harness for open or short between cooling fan relay-1 and ECM

If NG, repair harness or connectors.


OK → (A)

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




PROCEDURE B

INSPECTION START

J
CHECK POWER SUPPLY.
1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-2.
3. Turn ignition switch "ON".
4. Check voltage between cooling fan relay-2 terminals ①, ⑤ and ground with CONSULT or tester.
Voltage: Battery voltage

- NG
- Check the following.
- Joint connector-1
 - Harness connectors (E110, M96)
 - 30A fusible links
 - 10A fuse
 - Harness continuity between cooling fan relay-2 and fuse
 - Harness continuity between cooling fan relay-2 and battery
- If NG, repair harness or connectors.




OK

B

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)




K

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor harness connector.
3. Check harness continuity between relay terminal ③ and cooling fan motor terminal ②, fan motor terminal ④ and ground.

Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.



L

CHECK OUTPUT SIGNAL CIRCUIT-I.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ⑬ and terminal ②.

Continuity should exist.
If OK, check harness for short.

NG → Check the following.

- Harness connectors (F58, M111)
- Harness connectors (M98, E110)
- Harness for open or short between cooling fan relay-2 and ECM

If NG, repair harness or connectors.

CHECK COMPONENT
(Cooling fan relay-2).
Refer to "COMPONENT INSPECTION", EC-278.

NG → Replace cooling fan relays.

CHECK COMPONENTS
(Cooling fan motors).
Refer to "COMPONENT INSPECTION", EC-278.

NG → Replace cooling fan motors.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

A

■ COOLING FAN CIRCUIT ■

DOES COOLING FAN ROTATE AND STOP EVERY 3 SECONDS?

NEXT NO YES

SEF383N

A

■ ACTIVE TEST ■

COOLING FAN LOW

=== MONITOR ===

COOLAN TEMP/S 177°F

HI LOW OFF

SEF382N

A

Cooling fan

MEF985E

B

DISCONNECT T.S. OFF

DISCONNECT T.S. ON

SEF820Q

C

DISCONNECT T.S. ON

SEF828Q

Models for CANADA

INSPECTION START

A

CHECK COOLING FAN OPERATION.

1. Turn ignition switch "OFF".
2. Turn ignition switch "ON".
3. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

● The cooling fan control system for Canada carries out the 1-step control [OFF/ON] while "OFF", "LOW" and "HI" are being displayed on the CONSULT screen.

OR

2. Start engine.
3. Set temperature lever at full cold position.
4. Turn A/C switch "ON".
5. Run engine at idle for a while with air conditioner operating.
6. Make sure that cooling fan begins to operate.

B

CHECK HARNESS CONTINUITY BETWEEN COOLING FAN RELAY-1 AND GROUND.

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Disconnect triple-pressure switch harness connector.
4. Check harness continuity between relay-1 terminal ② and switch terminal ④, switch terminal ③ and engine ground.

Continuity should exist. If OK, check harness for short.

CHECK COMPONENT (Triple-pressure switch). Refer to HA section ("Electrical Components Inspection", "TROUBLE DIAGNOSES"). If NG, replace triple-pressure switch.

C

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".
4. Check voltage between terminals ①, ⑤ and ground with CONSULT or tester.

Voltage: Battery voltage




Check the following.

- Harness connectors (M96, E110)
- Joint connector-1
- 10A fuse
- 30A fusible link
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

If NG, repair harness or connectors.


TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P1900


Cooling Fan (DTC: 1308) (Cont'd)



L

CHECK COOLING SYSTEM FOR LEAK.
Apply pressure to the cooling system with a tester, and check if the pressure drops.
Testing pressure:
157 kPa (1.6 kg/cm², 23 psi)
Pressure should not drop.
CAUTION:
Higher than the specified pressure may cause radiator damage.


NG → Check the following for leak.
● Hose
● Radiator
● Water pump
Refer to LC section ("Water Pump").



M

CHECK RADIATOR CAP.
Apply pressure to cap with a tester.
Radiator cap relief pressure:
Standard
78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)
Limit
59 - 98 kPa (0.6 - 0.9 kg/cm², 9 - 13 psi)

NG → Replace radiator cap.



N

CHECK THERMOSTAT.

1. Check valve seating condition at normal room temperatures. It should seat tightly.
2. Check valve opening temperature and maximum valve lift.
Valve opening temperature:
76.5°C (170°F) [standard]
Maximum valve lift:
8.6 mm/95°C (0.339 in/203°F)
3. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section ("Thermostat").

NG → Replace thermostat

OK → Check engine coolant temperature sensor. Refer to "COMPONENT INSPECTION", EC-115.

NG → Replace engine coolant temperature sensor.

If the cause can not be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-277.

INSPECTION END

Perform FINAL CHECK by the following procedure after repair is completed.

1. Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

2. Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
3. Allow engine to cool and visually check for oil and coolant leaks. Then, perform "OVERALL FUNCTION CHECK".

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

MAIN 12 CAUSES OF OVERHEATING

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
	4	● Radiator cap	● Pressure tester	78 - 98 kPa (0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON* ²	5	● Coolant leaks	● Visual	No leaks	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON* ²	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section
ON* ¹	7	● Cooling fan	● CONSULT	Operating	See "TROUBLE DIAGNOSIS FOR DTC P1900" (EC-263)
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON* ³	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
OFF* ⁴	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.


TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

COMPONENT INSPECTION

Cooling fan relays-1 and -2

Check continuity between terminals ③ and ⑤.



SEF684P

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No


Cooling fan motor

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Speed	Terminals	
		(⊕)	(⊖)
Cooling fan motor (For USA)	Low	①	③
	High	②	④
Cooling fan motor (For Canada)		①	②

Cooling fan motor should operate.

If NG, replace cooling fan motor.




SEF347R



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector

EC-INJECT-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector (Cont'd)

EC-INJECT-02






: Detectable line for DTC
 : Non-detectable line for DTC




Injector (Cont'd)

COMPONENT DESCRIPTION

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.








DIAGNOSTIC PROCEDURE






TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector (Cont'd)



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector (Cont'd)



COMPONENT INSPECTION




Injector

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.
Resistance: 10 - 14Ω at 25°C (77°F)
 If NG, replace injector.


GI
MA
EM
IC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Start Signal

EC-S/SIG-01



Refer to last page (Foldout page).
(M96), (E110)



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Start Signal (Cont'd)

DIAGNOSTIC PROCEDURE

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE, SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY.

NEXT START

SEF191L

A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLSD TH/P SW	ON
AIR COND SIG	OFF
P/N POSI SW	ON

RECORD

SEF111P

A

ECM CONNECTOR

20

V

CONNECT H.S.

ST

SEF109P

B

ECM CONNECTOR

20

DISCONNECT H.S.


DISCONNECT T.S.

Fuse block 40

Ω

OFF

SEF801Q



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Fuel Pump Control

SYSTEM DESCRIPTION



Fuel pump ON-OFF control


The ECM activates the fuel pump for several seconds after the ignition switch is turned ON to improve engine start-up. If the ECM receives a 1° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to activate. If the 1° signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents the battery from discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
When engine is stopped	Stops for 1.5 seconds
Except as shown above	Stops



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump Control (Cont'd)

EC-F/PUMP-01







GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump Control (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK OVERALL FUNCTION.
 1. Turn ignition switch "ON".
 2. Perform "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT.
 3. Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt on the fuel feed hose.
 OR
 2. Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".

OK → *INSPECTION END

* If fuel pump noise is greater than normal during idling after completing warm-up, then go to "CHECK GROUND CIRCUIT".

B
CHECK POWER SUPPLY.
 1. Turn ignition switch "OFF".
 2. Disconnect fuel pump relay.
 3. Turn ignition switch "ON".
 4. Check voltage between fuel pump relay terminals ②, ⑤ and ground with CONSULT or tester.
Voltage: Battery voltage

NG → Check the following.
 • Harness connectors (B2, M95)
 • Harness connectors (M12, E102)
 • 15A fuse
 • Harness continuity between fuel pump relay and fuse
 • Harness continuity between fuel pump relay and ignition switch
 If NG, repair harness or connectors.


C
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect fuel pump harness connector and fuel pump control module harness connector.
 3. Check harness continuity between relay terminal ③ and ②, ④, ③, fuel pump terminal ① and FPCM terminal ⑤.
Continuity should exist.

NG → Repair harness or connectors.


OK → A

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump Control (Cont'd)



SEF346R



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump Control (Cont'd)


COMPONENT INSPECTION

Fuel pump relay

Check continuity between terminals ③ and ⑤.

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.




Fuel pump

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals ① and ③.


Resistance: 0.2 - 5.0Ω at 20°C (68°F)

If NG, replace fuel pump.



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump Control (Cont'd)



CAUTION:

Be sure to ground the FPCM body before inspection.

Fuel pump control module

1. Turn off engine and disconnect fuel pump control module harness connector.
2. Connect proper wires between the fuel pump control module harness terminals.
3. Start engine and check voltage between terminal ⑦ and terminal ④ on fuel pump control module.
If NG, replace fuel pump control module.

Connected terminal connections and measured terminals	Voltage
	Battery voltage
	7.5 - 8.1V
	5.4 - 5.8V

SEF337R

If NG, replace fuel pump control module.

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT






HA

EL

DX

Power Steering Oil Pressure Switch

EC-PST/SW-01



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Power Steering Oil Pressure Switch (Cont'd)

COMPONENT DESCRIPTION

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



DIAGNOSTIC PROCEDURE

A

■ PW/ST SIGNAL CIRCUIT ■

HOLD STEERING WHEEL
IN A FULL
LOCKED POSITION
THEN
TOUCH START

NEXT START

MEF023E

A

☆ MONITOR ☆ NO FAIL

PW/ST SIGNAL OFF

RECORD

SEF5911

A

CONNECT

ECM CONNECTOR

39

V

SEF662P


B

DISCONNECT

1 2 3


V

SEF808Q




TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS


Power Steering Oil Pressure Switch (Cont'd)




SEF809Q




SEF810Q



SEF811Q



SEF812Q



COMPONENT INSPECTION

Power steering oil pressure switch


1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals ① and ②.

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No


If NG, replace power steering oil pressure switch.

MIL & Data Link Connectors

EC-MIL-01



GI
 MA
 EM
 LC
EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX



Alphabetical & P No. Index for DTC

ALPHABETICAL INDEX FOR DTC

Items (CONSULT screen terms)	DTC		Reference page
	MIL*1	CONSULT GST*2	
*COOLANT TEMP SEN	0908	P0125	EC-121
A/T 1ST SIGNAL	1103	P0731	AT section
A/T 2ND SIGNAL	1104	P0732	AT section
A/T 3RD SIGNAL	1105	P0733	AT section
A/T 4TH SIG OR TCC	1106	P0734	AT section
A/T COMM LINE	0504	P0600	EC-220
CAM POS SEN	0101	P0340	EC-193
CLOSED LOOP-B1	0307	P0130	EC-131
CLOSED LOOP-B2	0308	P0150*3	EC-131
COOLANT TEMP SEN	0103	P0115	EC-112
COOLING FAN	1308	P1900	EC-263
CRANK P/S (OBD) COG	0905	P1336	EC-250
CRANK POS SEN (OBD)	0802	P0335	EC-189
CYL 1 MISFIRE	0608	P0301	EC-182
CYL 2 MISFIRE	0607	P0302	EC-182
CYL 3 MISFIRE	0606	P0303	EC-182
CYL 4 MISFIRE	0605	P0304	EC-182
CYL 5 MISFIRE	0604	P0305	EC-182
CYL 6 MISFIRE	0603	P0306	EC-182
CYL 7 MISFIRE	0602	P0307	EC-182
CYL 8 MISFIRE	0601	P0308	EC-182
ECM	0301	P0605	EC-223
EGR SYSTEM	0302	P0400	EC-197
EGR TEMP SENSOR	0305	P1401	EC-258
EGRC SOLENOID/V	1005	P1400	EC-254
EGRC-BPT VALVE	0306	P0402	EC-206
ENGINE SPEED SIG	1207	P0725	AT section
FLUID TEMP SENSOR	1208	P0710	AT section
FPCM	1305	P1220	EC-238
FR O2 SEN HTR-B1	0901	P0135	EC-133

Items (CONSULT screen terms)	DTC		Reference page
	MIL*1	CONSULT GST*2	
FR O2 SEN HTR-B2	1001	P0155	EC-150
FRONT O2 SENSOR-B1	0503	P0130	EC-126
FRONT O2 SENSOR-B2	0303	P0150	EC-145
FUEL SYS LEAN/BK1	0115	P0171	EC-162
FUEL SYS LEAN/BK2	0210	P0174	EC-172
FUEL SYS RICH/BK1	0114	P0172	EC-167
FUEL SYS RICH/BK2	0209	P0175	EC-177
IACV-AAC VALVE	0205	P0505	EC-215
IGN SIGNAL-PRIMARY	0201	P1320	EC-244
INHIBITOR SWITCH	1101	P0705	AT section
INT AIR TEMP SEN	0401	P0110	EC-107
KNOCK SENSOR	0304	P0325	EC-186
LINE PRESSURE S/V	1205	P0745	AT section
MASS AIR FLOW SEN	0102	P0100	EC-102
OVERRUN CLUTCH S/V	1203	P1760	AT section
PARK/NEUT POSI SW	1003	P0705	EC-225
MULTI CYL MISFIRE	0701	P0300	EC-182
RR O2 SENSOR-B1	0707	P0136	EC-136
RR O2 SENSOR-B2	0708	P0156	EC-153
RR O2 SEN HTR-B1	0902	P0141	EC-141
RR O2 SEN HTR-B2	1002	P0161	EC-158
TCS THRTL POS SEN	0406	P1120	EC-229
SHIFT SOLENOID/V A	1108	P0750	AT section
SHIFT SOLENOID/V B	1201	P0755	AT section
TANDEM T/P SEN	1502	P1125	EC-234
TCS SIGNAL	0106	P1210	EC-235
THROTTLE POSI SEN	0403	P0120	EC-116
THRTL POSI SEN A/T	1206	P1705	AT section
TOR CONV CLUTCH SV	1204	P0740	AT section
TW CATALYST SYS-B1	0702	P0420	EC-208
TW CATALYST SYS-B2	0703	P0430	EC-208
VEHICLE SPEED SEN	0104	P0500	EC-211
VHCL SPEED SEN A/T	1102	P0720	AT section

*1: These are controlled by NISSAN.

*2: These are prescribed by SAE J2012.

*3: Using CONSULT, "P0130" will be displayed in this case.

TROUBLE DIAGNOSIS — Index

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

DTC		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	MIL*1		
P0000	0505	NO SELF-DIAGNOSTIC FAILURE INDICATED	—
P0100	0102	MASS AIR FLOW SEN	EC-102
P0110	0401	INT AIR TEMP SEN	EC-107
P0115	0103	COOLANT TEMP SEN	EC-112
P0120	0403	THROTTLE POSI SEN	EC-116
P0125	0908	*COOLANT TEMP SEN	EC-121
P0130	0307	CLOSED LOOP-B1	EC-131
P0130	0503	FRONT O2 SENSOR-B1	EC-126
P0135	0901	FR O2 SEN HTR-B1	EC-133
P0136	0707	RR O2 SENSOR-B1	EC-136
P0141	0902	RR O2 SEN HTR-B1	EC-141
P0150*3	0308	CLOSED LOOP-B2	EC-131
P0150	0303	FRONT O2 SENSOR-B2	EC-145
P0155	1001	FR O2 SEN HTR-B2	EC-150
P0156	0708	RR O2 SENSOR-B2	EC-153
P0161	1002	RR O2 SEN HTR-B2	EC-158
P0171	0115	FUEL SYS LEAN/BK1	EC-162
P0172	0114	FUEL SYS RICH/BK1	EC-167
P0174	0210	FUEL SYS LEAN/BK2	EC-172
P0175	0209	FUEL SYS RICH/BK2	EC-177
P0300	0701	MULTI CYL MISFIRE	EC-182
P0301	0608	CYL 1 MISFIRE	EC-182
P0302	0607	CYL 2 MISFIRE	EC-182
P0303	0606	CYL 3 MISFIRE	EC-182
P0304	0605	CYL 4 MISFIRE	EC-182
P0305	0604	CYL 5 MISFIRE	EC-182
P0306	0603	CYL 6 MISFIRE	EC-182
P0307	0602	CYL 7 MISFIRE	EC-182
P0308	0601	CYL 8 MISFIRE	EC-182
P0325	0304	KNOCK SENSOR	EC-186
P0335	0802	CRANK POS SEN (OBD)	EC-189
P0340	0101	CAM POS SEN	EC-193
P0400	0302	EGR SYSTEM	EC-197
P0402	0306	EGRC-BPT VALVE	EC-206
P0420	0702	TW CATALYST SYS-B1	EC-208
P0430	0703	TW CATALYST SYS-B2	EC-208

DTC		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	MIL*1		
P0500	0104	VEHICLE SPEED SEN	EC-211
P0505	0205	IACV-AAC VALVE	EC-215
P0600	0504	A/T COMM LINE	EC-220
P0605	0301	ECM	EC-223
P0705	1003	PARK/NEUT POSI SW	EC-225
P0705	1101	INHIBITOR SWITCH	AT section
P0710	1208	FLUID TEMP SENSOR	AT section
P0720	1102	VHCL SPEED SEN A/T	AT section
P0725	1207	ENGINE SPEED SIG	AT section
P0731	1103	A/T 1ST SIGNAL	AT section
P0732	1104	A/T 2ND SIGNAL	AT section
P0733	1105	A/T 3RD SIGNAL	AT section
P0734	1106	A/T 4TH SIG OR TCC	AT section
P0740	1204	TOR CONV CLUTCH SV	AT section
P0745	1205	LINE PRESSURE S/V	AT section
P0750	1108	SHIFT SOLENOID/V A	AT section
P0755	1201	SHIFT SOLENOID/V B	AT section
P1120	0406	TCS THRTL POS SEN	EC-229
P1125	1502	TANDEM T/P SEN	EC-234
P1220	1305	FPCM	EC-238
P1320	0201	IGN SIGNAL-PRIMARY	EC-244
P1336	0905	CRANK P/S (POS) COG	EC-250
P1400	1005	EGRC SOLENOID/V	EC-254
P1401	0305	EGR TEMP SENSOR	EC-258
P1705	1206	THRTL POSI SEN A/T	AT section
P1760	1203	OVERRUN CLUTCH S/V	AT section
P1900	1308	COOLING FAN	EC-263

*1: These are controlled by NISSAN.

*2: These are prescribed by SAE J2012.

*3: Using CONSULT, "P0130" will be displayed in this case.

GI

VA

EM

LC

EC

FE

AT

FD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

General Specifications

PRESSURE REGULATOR

Fuel pressure	kPa (kg/cm ² , psi)	
At idle		Approximately 235 (2.4, 34)
A few seconds after ignition switch is turned OFF to ON		Approximately 299.1 (3.5, 43.4)

Inspection and Adjustment

Idle speed*1	rpm	
No-load*2 (in "N" position)		650 ± 50
Air conditioner: ON (in "N" position)		650 ± 50
Ignition timing		15° ± 2° BTDC

*1: Feedback controlled and needs no adjustments

*2: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater, fan & rear defogger)

MASS AIR FLOW SENSOR

Supply voltage	V	Battery voltage (11 - 14)
Output voltage	V	1.0 - 1.7 at idle*
Mass air flow (Using CONSULT or GST)	g·m/sec	3.0 - 6.0 at idle* 12.9 - 25.3 at 2,500 rpm*

*: Engine is warmed up sufficiently and idling under no-load.

ENGINE COOLANT TEMPERATURE SENSOR

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
50 (122)	0.68 - 1.00 kΩ
90 (194)	0.236 - 0.260 kΩ

EGR TEMPERATURE SENSOR

EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

FRONT HEATED OXYGEN SENSOR HEATER

Resistance [at 25°C (77°F)]	Ω	2.3 - 4.3
-----------------------------	---	-----------

REAR HEATED OXYGEN SENSOR HEATER

Resistance [at 25°C (77°F)]	Ω	2.3 - 4.3
-----------------------------	---	-----------

FUEL PUMP

Resistance [at 25°C (77°F)]	Ω	0.2 - 5.0
-----------------------------	---	-----------

IACV-AAC VALVE (Step motor type)

Resistance [at 25°C (77°F)]	Ω	Approximately 30
-----------------------------	---	------------------

INJECTOR

Resistance [at 25°C (77°F)]	Ω	10 - 14
-----------------------------	---	---------

THROTTLE POSITION SENSOR

Accelerator pedal conditions	Resistance [at 25°C (77°F)]
Completely released	Approximately 0.5 kΩ
Partially released	0.5 - 4.0 kΩ
Completely depressed	Approximately 4.0 kΩ

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CALCULATED LOAD VALUE

	Calculated load value % (Using CONSULT or GST)
At idle	13.0 - 27.1
At 2,500 rpm	13.0 - 25.5

INTAKE AIR TEMPERATURE SENSOR

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
80 (176)	0.68 - 1.00 kΩ

CAMSHAFT POSITION SENSOR (OBD)

Resistance	Ω	166.5 - 203.5Ω [at 25°C (77°F)]
------------	---	---------------------------------

CRANKSHAFT POSITION SENSOR (REF)

Resistance [at 25°C (77°F)]	Ω	470 - 570
-----------------------------	---	-----------

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX