

ACCELERATOR CONTROL, FUEL & EXHAUST SYSTEMS

SECTION FE

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS


PREPARATION/ACCELERATOR CONTROL SYSTEM2	Adjusting Accelerator Wire3
Special Service Tool2	FUEL SYSTEM4
	EXHAUST SYSTEM5

PREPARATION/ACCELERATOR CONTROL SYSTEM

Special Service Tool

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
(J38365-A) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 3/8 drive a: 22 mm (0.87 in)



NT636

CAUTION:

- When removing accelerator wire, make a mark to indicate lock nut's initial position.
- Check that throttle valve opens fully when accelerator pedal is fully depressed. Also check that it returns to idle position when pedal is released.
- Check accelerator control parts for improper contact with any adjacent parts.
- When connecting accelerator wire, be careful not to twist or scratch wire.



Adjusting Accelerator Wire

CAUTION:

- Make sure the ASCD wire is not pulling the throttle drum.
- Refer to "AUTOMATIC SPEED CONTROL DEVICE" in EL section for ASCD wire adjustment.

MIDDLE THROTTLE DRUM ADJUSTMENT

1. Loosen lock nut, and tighten adjusting nut until middle throttle drum starts to move.
2. Fasten adjusting nut with lock nut.

THROTTLE DRUM ADJUSTMENT

1. Start engine and warm it up.
2. Loosen lock nut, and tighten adjusting nut until throttle drum starts to move.
3. From that position turn back adjusting nut 1.5 to 2 turns, and fasten it with lock nut.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

FUEL SYSTEM

WARNING:


When replacing fuel line parts, be sure to observe the following:

- Put a "CAUTION: FLAMMABLE" sign in workshop.
- Be sure to furnish workshop with a CO₂ fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to disconnect battery ground cable before conducting operations.
- Drain fuel from Fuel Tank and put drained fuel in an explosion-proof container and put lid on securely.

CAUTION:


- Before disconnecting fuel hose, release fuel pressure from fuel line. Refer to "Changing Fuel Filter" in MA section.
- Do not disconnect any fuel line unless absolutely necessary.
- Plug hose and pipe openings to prevent entry of dust or dirt.
- Always replace O-ring and clamps with new ones.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose clamps excessively to avoid damaging hoses.
- Tighten bolts to specified torque.
- When installing fuel check valve, be careful of its designated direction. (Refer to "EVAPORATIVE EMISSION SYSTEM" in EC section.)
- After installation, run engine and check for fuel leaks at connections.
- Use only a genuine fuel filler cap as a replacement.

SEC. 172



- | | | |
|-----------------------------|-------------------|----------------------------|
| ① Fuel tube | ⑥ Drain hose | ⑩ Fuel vent tube |
| ② EVAP tube | ⑦ Grommet | ⑪ Fuel warning lamp sensor |
| ③ Fuel tank | ⑧ Fuel filler cap | ⑫ Strainer |
| ④ Fuel tank tightening band | ⑨ Cover | ⑬ Fuel pump |
| ⑤ Filler tube | | ⑭ Float arm |

EXHAUST SYSTEM



CAUTION:

- Always replace exhaust gaskets with new ones when reassembling. If gasket is left on flange surface, scrape off completely as shown at left.
- With engine running, check all tube connections for exhaust gas leaks, and entire system for unusual noises.
- Check to ensure that mounting brackets and mounting insulators are installed properly free from undue stress. Improper installation could result in excessive noise or vibration.
- For removal and installation of rear heated oxygen sensor, refer to "TROUBLE DIAGNOSIS FOR DTC P0136 and P0156" in EC section.
- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

EXHAUST SYSTEM


For California
SEC. 200



SFE466A

EXHAUST SYSTEM

For non-California
SEC. 200



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
JDX