

A

ACC

C

D

E

F

G

H

I

J

K

L

M

SECTION ACC

ACCELERATOR CONTROL SYSTEM

CONTENTS

ACCELERATOR CONTROL SYSTEM	2	SERVICE DATA AND SPECIFICATIONS (SDS)	4
Removal and Installation	2	Standard and Limit	4
REMOVAL	2	Tightening Torque	4
INSTALLATION	2		
INSPECTION AFTER INSTALLATION	3		


ACCELERATOR CONTROL SYSTEM

PFP:18005

EBS001JM

ACCELERATOR CONTROL SYSTEM

Removal and Installation




SBIA0339E

- | | | |
|-----------------------------|-----------------------------|----------------------|
| 1. Accelerator wire | 2. Accelerator wire bracket | 3. Seal rubber |
| 4. Accelerator wire bracket | 5. Pedal bracket | 6. E-ring |
| 7. Bush | 8. Stopper | 9. Accelerator pedal |

Accelerator wire should be adjusted when removing and replacing any parts of the Accelerator Control System, shown in the illustration.

REMOVAL

1. Remove engine cover. Refer to [EM-11, "ENGINE ROOM COVER"](#).
2. Loosen lock nut, and remove accelerator wire from throttle drum.
3. Remove accelerator wire from accelerator pedal.
4. Remove accelerator wire bracket bolt and nut, and pull accelerator wire into vehicle interior.
5. Remove accelerator pedal bracket nuts, then remove accelerator pedal and bracket assembly.



SBIA0330E

INSTALLATION

Install in reverse order of removal procedures, paying extra attention to the items below.

CAUTION:

- Do not leave scratches, twist or bends on accelerator wire cores.
- Do not apply lubricant to inside accelerator wire.
- Check if accelerator pedal is free from contact with other parts, and releases smoothly.
- For ASCD wire adjustment, refer to [ACS-29, "ASCD Wire Adjustment"](#).

ACCELERATOR CONTROL SYSTEM

Adjusting Accelerator Wire

1. Loosen lock nut and adjusting nut.
2. Tighten accelerator adjusting nut until throttle drum starts to move.
3. From that position, turn back adjusting nut 1.5 to 2 turns.
4. Tighten lock nut to specified torque holding adjusting nut.

A

ACC

INSPECTION AFTER INSTALLATION

- Check if throttle drum opens fully when accelerator pedal is fully depressed to the floor, and operates smoothly in all process.
- Check if throttle drum returns to idle position when pedal is released.
- Check if the ASCD wire is not pulling the throttle drum.

C

D

E

F

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit

EBS003TU

Turning back of accelerator wire adjusting nut	1.5 - 2 turns (From position throttle drum just starts to move)
--	---

Tightening Torque

EBS001ZB

Unit: N·m (kg·m, in·lb)

Accelerator pedal assembly	4.3 - 5.9 (0.43 - 0.61, 38 - 52)
Accelerator wire bracket	4.3 - 5.9 (0.43 - 0.61, 38 - 52)
Accelerator wire lock nut	7.8 - 10.8 (0.8 - 1.1, 69 - 95)