

SECTION **ATC**

AUTOMATIC AIR CONDITIONER

A
B
C
D
E
F
G
H
I
K
L
M

CONTENTS

<p>PRECAUTIONS 5</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 5</p> <p>Precautions for Working with HFC-134a (R-134a)..... 5</p> <p style="padding-left: 20px;">CONTAMINATED REFRIGERANT 6</p> <p>General Refrigerant Precautions 6</p> <p>Precautions for Refrigerant Connection 6</p> <p style="padding-left: 20px;">FEATURES OF NEW TYPE REFRIGERANT CONNECTION 6</p> <p style="padding-left: 20px;">O-RING AND REFRIGERANT CONNECTION..... 7</p> <p>Precautions for Servicing Compressor 9</p> <p>Precautions for Service Equipment 9</p> <p style="padding-left: 20px;">RECOVERY/RECYCLING EQUIPMENT 9</p> <p style="padding-left: 20px;">ELECTRONIC LEAK DETECTOR 9</p> <p style="padding-left: 20px;">VACUUM PUMP 10</p> <p style="padding-left: 20px;">MANIFOLD GAUGE SET 10</p> <p style="padding-left: 20px;">SERVICE HOSES 10</p> <p style="padding-left: 20px;">SERVICE COUPLERS 11</p> <p style="padding-left: 20px;">REFRIGERANT WEIGHT SCALE 11</p> <p style="padding-left: 20px;">CHARGING CYLINDER 11</p> <p>Precautions for Leak Detection Dye 12</p> <p style="padding-left: 20px;">IDENTIFICATION 12</p> <p style="padding-left: 20px;">IDENTIFICATION LABEL FOR VEHICLE 12</p> <p>PREPARATION 13</p> <p>Special Service Tools 13</p> <p>HFC-134a (R-134a) Service Tools and Equipment.. 14</p> <p>Commercial Service Tools 16</p> <p>REFRIGERATION SYSTEM 17</p> <p>Refrigerant Cycle 17</p> <p style="padding-left: 20px;">REFRIGERANT FLOW 17</p> <p style="padding-left: 20px;">FREEZE PROTECTION 17</p> <p>Refrigerant System Protection 17</p> <p style="padding-left: 20px;">REFRIGERANT PRESSURE SENSOR 17</p> <p style="padding-left: 20px;">PRESSURE RELIEF VALVE 17</p> <p>V-6 Variable Displacement Compressor 18</p> <p style="padding-left: 20px;">GENERAL INFORMATION 18</p> <p style="padding-left: 20px;">DESCRIPTION 19</p> <p>Component Layout 22</p>	<p>LUBRICANT 23</p> <p>Maintenance of Lubricant Quantity in Compressor.. 23</p> <p style="padding-left: 20px;">LUBRICANT 23</p> <p style="padding-left: 20px;">LUBRICANT RETURN OPERATION 23</p> <p style="padding-left: 20px;">LUBRICANT ADJUSTING PROCEDURE FOR COMPONENTS REPLACEMENT EXCEPT COMPRESSOR 24</p> <p style="padding-left: 20px;">LUBRICANT ADJUSTING PROCEDURE FOR COMPRESSOR REPLACEMENT 24</p> <p>AIR CONDITIONER CONTROL 26</p> <p>Description of Air Conditioner LAN Control System.. 26</p> <p>System Construction 26</p> <p style="padding-left: 20px;">OPERATION 27</p> <p style="padding-left: 20px;">TRANSMISSION DATA AND TRANSMISSION ORDER 27</p> <p style="padding-left: 20px;">AIR MIX DOOR CONTROL (AUTOMATIC TEMPERATURE CONTROL) 28</p> <p style="padding-left: 20px;">FAN SPEED CONTROL 28</p> <p style="padding-left: 20px;">INTAKE DOOR CONTROL 28</p> <p style="padding-left: 20px;">MODE DOOR CONTROL 28</p> <p style="padding-left: 20px;">MAGNET CLUTCH CONTROL 29</p> <p style="padding-left: 20px;">SELF-DIAGNOSIS SYSTEM 29</p> <p>Description of Control System 30</p> <p>Control Operation 31</p> <p style="padding-left: 20px;">DISPLAY SCREEN 31</p> <p style="padding-left: 20px;">AUTO SWITCH (DRIVER SIDE) 31</p> <p style="padding-left: 20px;">AUTO SWITCH (PASSENGER SIDE) 31</p> <p style="padding-left: 20px;">TEMPERATURE DIAL (POTENTIO TEMPERATURE CONTROL) (DRIVER SIDE) 31</p> <p style="padding-left: 20px;">TEMPERATURE DIAL (POTENTIO TEMPERATURE CONTROL) (PASSENGER SIDE) 31</p> <p style="padding-left: 20px;">INTAKE SWITCH 32</p> <p style="padding-left: 20px;">DEFROSTER (DEF) SWITCH 32</p> <p style="padding-left: 20px;">OFF SWITCH 32</p> <p style="padding-left: 20px;">MODE SWITCH (DRIVER SIDE) 32</p> <p style="padding-left: 20px;">MODE SWITCH (PASSENGER SIDE) 32</p> <p style="padding-left: 20px;">ECON (ECONOMY) SWITCH 32</p> <p style="padding-left: 20px;">FAN SWITCH 32</p> <p style="padding-left: 20px;">DUAL SWITCH 32</p> <p style="padding-left: 20px;">REAR CONTROL SWITCH 32</p>
---	---

ATC

Fail-Safe Function	32	Rear Ventilator Door Motor Circuit	79
Discharge Air Flow	33	COMPONENT DESCRIPTION	79
System Description	34	DIAGNOSIS PROCEDURE FOR REAR VENTI-	
SWITCHES AND THEIR CONTROL FUNCTION..	34	LATOR DOOR MOTOR	79
TROUBLE DIAGNOSIS	35	Rear Control Switch Circuit	80
How to Perform Trouble Diagnosis for Quick and		DIAGNOSIS PROCEDURE FOR REAR CON-	
Accurate Repair	35	TROL SWITCH	80
WORK FLOW	35	Rear Control Cancel Switch	80
SYMPTOM TABLE	35	DIAGNOSIS PROCEDURE FOR REAR CON-	
Component Parts and Harness Connector Location..	37	TROL CANCEL SWITCH	80
ENGINE COMPARTMENT	37	Blower Motor Circuit	81
PASSENGER COMPARTMENT	38	INSPECTION FLOW	81
Schematic	39	SYSTEM DESCRIPTION	81
Wiring Diagram — A/C —	40	COMPONENT DESCRIPTION	83
Auto Amp. Terminals and Reference Value	50	DIAGNOSIS PROCEDURE FOR BLOWER	
PIN CONNECTOR TERMINAL LAYOUT	50	MOTOR	83
TERMINALS AND REFERENCE VALUE FOR		COMPONENT INSPECTION	85
AUTO AMP.	50	Magnet Clutch Circuit	86
Self-diagnosis Function	53	INSPECTION FLOW	86
DESCRIPTION	53	SYSTEM DESCRIPTION	87
FUNCTION CONFIRMATION PROCEDURE	54	DIAGNOSIS PROCEDURE FOR MAGNET	
AUXILIARY MECHANISM: TEMPERATURE		CLUTCH	87
SETTING TRIMMER	61	COMPONENT INSPECTION	92
Operational Check	62	Insufficient Cooling	93
CHECKING MEMORY FUNCTION	62	INSPECTION FLOW	93
CHECKING BLOWER	62	PERFORMANCE TEST DIAGNOSIS	95
CHECKING DISCHARGE AIR	62	PERFORMANCE CHART	97
CHECKING INTAKE AIR (INTAKE SWITCH)	63	TROUBLE DIAGNOSIS FOR UNUSUAL PRES-	
CHECKING TEMPERATURE DECREASE	63	SURE	98
CHECKING TEMPERATURE INCREASE	63	DIAGNOSIS PROCEDURE FOR INSUFFI-	
CHECK ECON (ECONOMY) MODE	63	CIENT COOLING	100
CHECKING AUTO MODE	63	Insufficient Heating	102
Power Supply and Ground Circuit for Auto Amp. ...	64	INSPECTION FLOW	102
INSPECTION FLOW	64	Noise	103
COMPONENT DESCRIPTION	64	INSPECTION FLOW	103
DIAGNOSIS PROCEDURE FOR A/C SYSTEM..	65	Self-Diagnosis	104
LAN System Circuit	66	INSPECTION FLOW	104
DIAGNOSIS PROCEDURE FOR LAN CIRCUIT..	66	Memory Function	105
Mode Door Motor Circuit	70	INSPECTION FLOW	105
INSPECTION FLOW	70	ECON (ECONOMY) MODE	106
SYSTEM DESCRIPTION	71	INSPECTION FLOW	106
COMPONENT DESCRIPTION	72	A/C Display is Malfunctioning	107
DIAGNOSIS PROCEDURE FOR MODE DOOR		DIAGNOSIS PROCEDURE	107
MOTOR	72	A/C Operation is Malfunctioning	108
Air Mix Door Motor Circuit	73	DIAGNOSIS PROCEDURE	108
INSPECTION FLOW	73	Ambient Sensor Circuit	110
SYSTEM DESCRIPTION	74	COMPONENT DESCRIPTION	110
COMPONENT DESCRIPTION	75	AMBIENT TEMPERATURE INPUT PROCESS..	110
DIAGNOSIS PROCEDURE FOR AIR MIX DOOR		DIAGNOSIS PROCEDURE FOR AMBIENT	
MOTOR	75	SENSOR	110
Air Mix Door Motor PBR Circuit	75	COMPONENT INSPECTION	112
DIAGNOSIS PROCEDURE FOR AIR MIX DOOR		In-Vehicle Sensor Circuit	112
MOTOR PBR	75	COMPONENT DESCRIPTION	112
Intake Door Motor Circuit	76	DIAGNOSIS PROCEDURE FOR IN-VEHICLE	
INSPECTION FLOW	76	SENSOR	113
SYSTEM DESCRIPTION	77	COMPONENT INSPECTION	114
COMPONENT DESCRIPTION	78	Sunload Sensor Circuit	115
DIAGNOSIS PROCEDURE FOR INTAKE DOOR		COMPONENT DESCRIPTION	115
MOTOR	78	SUNLOAD INPUT PROCESS	115

DIAGNOSIS PROCEDURE FOR SUNLOAD SENSOR	115	IN-CABIN MICROFILTER	134
COMPONENT INSPECTION	117	Removal and Installation	134
Intake Sensor Circuit	118	FUNCTION	134
COMPONENT DESCRIPTION	118	REPLACEMENT TIMING	134
DIAGNOSIS PROCEDURE FOR INTAKE SENSOR	118	REPLACEMENT PROCEDURES	134
COMPONENT INSPECTION	119	HEATER & COOLING UNIT ASSEMBLY	135
Multiplex Communication Circuit	120	Removal and Installation	135
DIAGNOSIS PROCEDURE FOR MULTIPLEX COMMUNICATION CIRCUIT (FRONT CONTROLLER)	120	REMOVAL	135
DIAGNOSIS PROCEDURE FOR MULTIPLEX COMMUNICATION CIRCUIT (REAR CONTROL SWITCH)	123	INSTALLATION	136
CONTROLLER	125	Disassembly and Assembly	137
Removal and Installation of Multifunction Switch	125	HEATER CORE	139
REMOVAL	125	Removal and Installation	139
INSTALLATION	125	REMOVAL	139
Removal and Installation of Rear Control Switch	125	INSTALLATION	139
REMOVAL	125	MODE DOOR MOTOR	140
INSTALLATION	125	Removal and Installation	140
Removal and Installation of Rear Control Cancel Switch	125	REMOVAL	140
REMOVAL	125	INSTALLATION	140
INSTALLATION	125	AIR MIX DOOR MOTOR	141
AMBIENT SENSOR	126	Removal and Installation	141
Removal and Installation	126	REMOVAL	141
REMOVAL	126	INSTALLATION	141
INSTALLATION	126	REAR VENTILATOR DOOR MOTOR	142
IN-VEHICLE SENSOR	127	Removal and Installation	142
Removal and Installation	127	REMOVAL	142
REMOVAL	127	INSTALLATION	142
INSTALLATION	127	DUCTS AND GRILLES	143
SUNLOAD SENSOR	128	Removal and Installation	143
Removal and Installation	128	REMOVAL	143
REMOVAL	128	INSTALLATION	145
INSTALLATION	128	REFRIGERANT LINES	146
INTAKE SENSOR	129	HFC-134a (R-134a) Service Procedure	146
Removal and Installation	129	SETTING OF SERVICE TOOLS AND EQUIPMENT	146
REMOVAL	129	Components	148
INSTALLATION	129	Removal and Installation of Compressor	149
BLOWER UNIT	130	REMOVAL	149
Removal and Installation	130	INSTALLATION	150
REMOVAL	130	Removal and Installation of Compressor Clutch	150
INSTALLATION	130	REMOVAL	150
Disassembly and Assembly	131	INSTALLATION	152
BLOWER MOTOR	132	Removal and Installation of Low-Pressure Flexible Hose and Pipe	153
Removal and Installation	132	REMOVAL	153
REMOVAL	132	INSTALLATION	154
INSTALLATION	132	Removal and Installation of High-Pressure Flexible Hose	154
INTAKE DOOR MOTOR	133	REMOVAL	154
Removal and Installation	133	INSTALLATION	155
REMOVAL	133	Removal and Installation of High-Pressure Pipe	155
INSTALLATION	133	REMOVAL	155
		INSTALLATION	156
		Removal and Installation of Refrigerant Pressure Sensor	156
		REMOVAL	156
		INSTALLATION	156
		Removal and Installation of Condenser	157
		REMOVAL	157
		INSTALLATION	157

A
B
C
D
E
F
G
H
I
K
L
M

ATC

Removal and Installation of Liquid Tank	158	Dye Injection	161
REMOVAL	158	Electronic Refrigerant Leak Detector	162
INSTALLATION	158	PRECAUTIONS FOR HANDLING LEAK	
Removal and Installation of Evaporator	159	DETECTOR	162
REMOVAL	159	CHECKING PROCEDURE	163
INSTALLATION	159	SERVICE DATA AND SPECIFICATIONS (SDS) ...	165
Removal and Installation of Expansion Valve	159	Compressor	165
REMOVAL	159	Lubricant	165
INSTALLATION	160	Refrigerant	165
Checking for Refrigerant Leaks	161	Engine Idling Speed	165
Checking System for Leaks Using the Fluorescent		Belt Tension	165
Leak Detector	161		

PRECAUTIONS

PRECAUTIONS

PPF:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NJS0007I

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Working with HFC-134a (R-134a)

NJS0007J

CAUTION:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. If the refrigerants are mixed and compressor malfunction is likely to occur, refer to “CONTAMINATED REFRIGERANT” below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment and refrigerant identifier.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor malfunction is likely to occur.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - When installing refrigerant components to a vehicle, never remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - Never allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

PRECAUTIONS

CONTAMINATED REFRIGERANT

If a refrigerant other than pure HFC-134a (R-134a) is identified in a vehicle, take appropriate steps shown below:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage service equipment and refrigerant supply.
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- In case of repairing, recover the refrigerant using only **dedicated equipment and containers. Never recover contaminated refrigerant into the existing service equipment.** If the facility does not have dedicated recovery equipment, contact a local refrigerant product retailer for available service. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- If the vehicle is within the warranty period, the air conditioner warranty is void. Please contact Nissan Customer Affairs for further assistance.

General Refrigerant Precautions

NJS0007K

WARNING:

- **Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system, using certified service equipment meeting requirements of SAE J-2210 [HFC-134a (R-134a) recycling equipment], or J-2209 [HFC-134a (R-134a) recovery equipment]. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.**
- **Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.**
- **Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.**
- **Never store or heat refrigerant containers above 52°C (125°F).**
- **Never heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.**
- **Never intentionally drop, puncture, or incinerate refrigerant containers.**
- **Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.**
- **Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.**
- **Never pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.**

Precautions for Refrigerant Connection

NJS0007M

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.


- Expansion valve to cooling unit
- Refrigerant pressure sensor to condenser

FEATURES OF NEW TYPE REFRIGERANT CONNECTION


- The O-ring has been relocated. It has also been provided with a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.

PRECAUTIONS

- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.



O-RING AND REFRIGERANT CONNECTION




CAUTION:

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.

PRECAUTIONS

O-Ring Part Numbers and Specifications



Connection type	O-ring size	Part number	D mm (in)	W mm (in)
New	8	92471 N8210	6.80 (0.2680)	1.85 (0.0728)
Former		92470 N8200	6.07 (0.2390)	1.78 (0.0701)
Former	10	J2476 89956	9.25 (0.3642)	1.78 (0.0701)
New	12	92472 N8210	10.90 (0.429)	2.43 (0.0957)
Former		92475 71L00	11.00 (0.433)	2.40 (0.0940)
New	16	92473 N8210	13.60 (0.535)	2.43 (0.0957)
Former		92475 72L00	14.30 (0.563)	2.30 (0.0910)
New	19	92474 N8210	16.50 (0.650)	2.43 (0.0957)
Former		92477 N8200	17.12 (0.674)	1.78 (0.0701)
New	24	92195 AH300	21.80 (0.858)	2.40 (0.0940)

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:

When replacing or cleaning refrigerant cycle components, observe the following.


- When the compressor is removed, store it in the same way as it is when mounted on the car. Failure to do so will cause lubricant to enter the low-pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.
- When installing an air conditioner in the vehicle, connect the pipes at the final stage of the operation. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to circle of the O-rings shown in illustration. Be careful not to apply lubricant to threaded portion.

Lubricant name : Nissan A/C System Oil Type S

- O-ring must be closely attached to dented portion of tube.
- When replacing the O-ring, be careful not to damage O-ring and tube.
- Connect tube until a click can be heard, then tighten the nut or bolt by hand until snug. Make sure that the O-ring is installed to tube correctly.

PRECAUTIONS

- After connecting line, perform leak test and make sure that there is no leakage from connections. When the refrigerant leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



Precautions for Servicing Compressor

NJS0007N

- Plug all openings to prevent moisture and foreign matter from entering.
- When the compressor is removed, store it in the same way as it is when mounted on the car.
- When replacing or repairing compressor, follow "Maintenance of Lubricant Quantity in Compressor" exactly. Refer to [ATC-23, "Maintenance of Lubricant Quantity in Compressor"](#).
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with lubricant, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

Precautions for Service Equipment RECOVERY/RECYCLING EQUIPMENT

NJS0007O

Be certain to follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

Be certain to follow the manufacturer's instructions for tester operation and tester maintenance.

PRECAUTIONS

VACUUM PUMP


The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched off after evacuation (vacuuming) and hose is connected to it.

To prevent this migration, use a manual valve placed near the hose-to-pump connection, as follows.


- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut-off valve, disconnect the hose from the pump. As long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.

With isolator valve




Without isolator valve




MANIFOLD GAUGE SET

Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.




PRECAUTIONS

SERVICE COUPLERS


Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. If the scale controls refrigerant flow electronically, the hose fitting must be 1/2"-16 ACME.



CHARGING CYLINDER

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

PRECAUTIONS

Precautions for Leak Detection Dye

NJS0007P

- The A/C system contains a fluorescent leak detection dye used for locating refrigerant leaks. An ultraviolet (UV) lamp is required to illuminate the dye when inspecting for leaks.
- Always wear fluorescence enhancing UV safety goggles to protect your eyes and enhance the visibility of the fluorescent dye.
- The fluorescent dye leak detector is not a replacement for an electronic refrigerant leak detector. The fluorescent dye leak detector should be used in conjunction with an electronic refrigerant leak detector (SST: J-41995) to pin-point refrigerant leaks.
- For your safety and your customer's satisfaction, read and follow all manufacturer's operating instructions and precautions prior to performing the work.
- A compressor shaft seal should not be repaired because of dye seepage. The compressor shaft seal should only be repaired after confirming the leak with an electronic refrigerant leak detector (SST: J-41995).
- Always remove any remaining dye from the leak area after repairs are completed to avoid a misdiagnosis during a future service.
- Never allow dye to come into contact with painted body panels or interior components. If dye is spilled, clean immediately with the approved dye cleaner. Fluorescent dye left on a surface for an extended period of time cannot be removed.
- Never spray the fluorescent dye cleaning agent on hot surfaces (engine exhaust manifold, etc.).
- Never use more than one refrigerant dye bottle (1/4 ounce /7.4 cc) per A/C system.
- Leak detection dyes for HFC-134a (R-134a) and CFC-12 (R-12) A/C systems are different. Never use HFC-134a (R-134a) leak detection dye in CFC-12 (R-12) A/C system or CFC-12 (R-12) leak detection dye in HFC-134a (R-134a) A/C system, or A/C system damage may result.
- The fluorescent properties of the dye will remain for three years or a little over unless a compressor malfunction occurs.

IDENTIFICATION

NOTE:

Vehicles with factory installed fluorescent dye have a green label.

Vehicles without factory installed fluorescent dye have a blue label.

IDENTIFICATION LABEL FOR VEHICLE

Vehicles with factory installed fluorescent dye have the identification label on the front side of hood.

PREPARATION




PREPARATION

PPF:00002

Special Service Tools

NJS0007R

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV99106100 (J-41260) Clutch disc wrench  <p style="text-align: right;">S-NT232</p>  <p style="text-align: right;">SJA1168E</p>	Removing shaft nut and clutch disc
KV99232340 (J-38874) Clutch disc puller  <p style="text-align: right;">S-NT376</p>	Removing clutch disc
KV99106200 (J-41261) Pulley installer  <p style="text-align: right;">S-NT235</p>	Installing pulley

A
B
C
D
E
F
G
H
I
K
L
M

ATC

PREPARATION

NJS0007S



HFC-134a (R-134a) Service Tools and Equipment

Never mix HFC-134a (R-134a) refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.





Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.

Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricant.



Never use adapters that convert one size fitting to another: refrigerant/lubricant contamination will occur and compressor malfunction will result.

Tool number (Kent-Moore No.) Tool name	Description
<p>HFC-134a (R-134a) refrigerant</p> <div style="text-align: center;">  <p>S-NT196</p> </div>	<p>Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size</p> <ul style="list-style-type: none"> ● Large container 1/2"-16 ACME
<p>(-) Nissan A/C System Oil Type S (DH-PS)</p> <div style="text-align: center;">  <p>S-NT197</p> </div>	<p>Type: Polyalkaline glycol oil (PAG), type S (DH-PS) Application: HFC-134a (R-134a) wobble (swash) plate compressors (Nissan only) Capacity: 40 mℓ (1.4 US fl oz, 1.4 Imp fl oz)</p>
<p>(ACR2005-NI) ACR5 A/C Service Center</p> <div style="text-align: center;">  <p>WJIA0293E</p> </div>	<p>Function: Refrigerant recovery, recycling and recharging</p>
<p>(J-41995) Electrical leak detector</p> <div style="text-align: center;">  <p>AHA281A</p> </div>	<p>Power supply: DC 12 V (Battery terminal)</p>

PREPARATION



Tool number (Kent-Moore No.) Tool name	Description	A
(J-43926) Refrigerant dye leak detection kit Kit includes: (J-42220) UV lamp and UV safety goggles (J-41459) HFC-134a (R-134a) dye injector Use with J-41447, 1/4 ounce bottle (J-41447) HFC-134a (R-134a) fluorescent leak detection dye (Box of 24, 1/4 ounce bottles) (J-43872) Refrigerant dye cleaner	 <p>Power supply: DC 12 V (Battery terminal)</p>	B C D E
(J-42220) UV lamp and UV safety goggles	 <p>Power supply: DC 12 V (Battery terminal) For checking refrigerant leak when fluorescent dye is installed in A/C system Includes: UV lamp and UV safety goggles</p>	F G
(J-41447) HFC-134a (R-134a) fluorescent leak detection dye (Box of 24, 1/4 ounce bottles)	 <p>Application: For HFC-134a (R-134a) PAG oil Container: 1/4 ounce (7.4cc) bottle (Includes self- adhesive dye identification labels for affixing to vehicle after charging system with dye.)</p>	H I ATC
(J-41459) HFC-134a (R-134a) dye injector Use with J-41447, 1/4 ounce bottle	 <p>For injecting 1/4 ounce of fluorescent leak detection dye into A/C system</p>	K L
(J-43872) Refrigerant dye cleaner	 <p>For cleaning dye spills</p>	M
(J-39183) Manifold gauge set (with hoses and couplers)	 <p>Identification: ● The gauge face indicates HFC-134a (R-134a). Fitting size: Thread size ● 1/2"-16 ACME</p>	RJA0196E

PREPARATION

Tool number (Kent-Moore No.) Tool name	Description
<p>Service hoses</p> <ul style="list-style-type: none"> ● High-pressure side hose (J-39501-72) ● Low-pressure side hose (J-39502-72) ● Utility hose (J-39476-72) 	 <p style="text-align: right;">S-NT201</p> <p>Hose color:</p> <ul style="list-style-type: none"> ● Low hose: Blue with black stripe ● High hose: Red with black stripe ● Utility hose: Yellow with black stripe or green with black stripe <p>Hose fitting to gauge:</p> <ul style="list-style-type: none"> ● 1/2"-16 ACME
<p>Service couplers</p> <ul style="list-style-type: none"> ● High-pressure side coupler (J-39500-20) ● Low-pressure side coupler (J-39500-24) 	 <p style="text-align: right;">S-NT202</p> <p>Hose fitting to service hose:</p> <ul style="list-style-type: none"> ● M14 x 1.5 fitting is optional or permanently attached.
<p>(J-39650) Refrigerant weight scale</p>	 <p style="text-align: right;">S-NT200</p> <p>For measuring of refrigerant Fitting size: Thread size</p> <ul style="list-style-type: none"> ● 1/2"-16 ACME
<p>(J-39649) Vacuum pump (Including the isolator valve)</p>	 <p style="text-align: right;">S-NT203</p> <p>Capacity:</p> <ul style="list-style-type: none"> ● Air displacement: 4 CFM ● Micron rating: 20 microns ● Oil capacity: 482 g (17 oz) <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> ● 1/2"-16 ACME

Commercial Service Tools

NJS0007T

Tool name	Description
<p>Refrigerant identifier equipment</p>	 <p style="text-align: right;">RJIA0197E</p> <p>Checking for refrigerant purity and system contamination</p>
<p>Power tool</p>	 <p style="text-align: right;">PBIC0190E</p> <p>For loosening bolts and nuts</p>

REFRIGERATION SYSTEM

REFRIGERATION SYSTEM

PFP:KA990

Refrigerant Cycle REFRIGERANT FLOW

NJS0007U

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser with liquid tank, through the evaporator, and back to the compressor. The refrigerant evaporation through the evaporator is controlled by an externally equalized expansion valve, located inside the evaporator case.

FREEZE PROTECTION

To prevent evaporator frozen up, the evaporator air temperature is monitored, and the voltage signal to the A/C auto amp. will make the A/C relay go OFF and stop the compressor.


Refrigerant System Protection REFRIGERANT PRESSURE SENSOR

NJS0007V

The refrigerant system is protected against excessively high- or low- pressures by the refrigerant pressure sensor, located on the condenser. If the system pressure rises above, or falls below the specifications, the refrigerant pressure sensor detects the pressure inside the refrigerant line and sends the voltage signal to the ECM. ECM makes the A/C relay go OFF and stops the compressor when pressure on the high-pressure side detected by refrigerant pressure sensor is over about 2,746 kPa (28 kg/cm² , 398 psi), or below about 134 kPa (1.4 kg/cm² , 20 psi).

PRESSURE RELIEF VALVE

The refrigerant system is also protected by a pressure relief valve, located in the rear head of the compressor. When the pressure of refrigerant in the system increases to an unusual level [more than 3,727 kPa (38 kg/cm² , 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.



REFRIGERATION SYSTEM

V-6 Variable Displacement Compressor

NJS0007W

GENERAL INFORMATION

1. The V-6 variable compressor differs from previous units. The vent temperatures of the V-6 variable compressor do not drop too far below 5°C (41°F) when:
Evaporator intake air temperature is less than 20°C (68°F).
Engine is running at speeds less than 1,500 rpm.
This is because the V-6 compressor provides a means of “capacity” control.
2. The V-6 variable compressor provides refrigerant control under varying conditions. During cold winters, it may not produce high refrigerant pressure discharge (compared to previous units) when used with air conditioning systems.
3. A “clanking” sound may occasionally be heard during refrigerant charge. The sound indicates that the tilt angle of the wobble (swash) plate has changed and is not a problem.
4. For air conditioning systems with the V-6 compressor, the clutch remains engaged unless: the system main switch, fan switch or ignition switch is turned OFF. When ambient (outside) temperatures are low or when the amount of refrigerant is insufficient, the clutch is disengaged to protect the compressor.


REFRIGERATION SYSTEM

DESCRIPTION

General

The variable compressor is basically a swash plate type that changes piston stroke in response to the required cooling capacity.

The tilt of the wobble (swash) plate allows the piston's stroke to change so that refrigerant discharge can be continuously changed from 14.5 to 184 cm³ (0.885 to 11.228 cu in).




Operation

1. Operation Control Valve
 - By changing high-pressure valve lift amount, built-in compressor control valve executes the following:
 - Controls high-pressure valve discharge amount.
 - Changes crankcase pressure in compressor.
 - Changes angle of wobble (swash) plate.

REFRIGERATION SYSTEM


- Amount of high-pressure valve lift is determined by factors below.
 - Low-pressure applied to diaphragm
 - Spring load of set spring
 - Balance of magnetic force generated by magnet coil
- Electronic control valve (ECV) magnet coil receives electric signal (duty control) from auto amp. Then, magnetic force generated by electric current is changed to control high-pressure valve lift amount.
- 2. Maximum Cooling
 High-pressure valve is closed by magnetic force generated by electric signal sent from auto amp. At this time, cylinder moves full stroke due to pressure balance between inside crankcase (P_c) and suction line (P_s).
 Under this condition, the wobble (swash) plate is set to the maximum stroke position.



- 3. Capacity Control
 When no electric signal is sent from auto amp. (current: OFF), high-pressure valve is opened by spring force.
 Since suction pressure is low, it makes the suction port close and the discharge port open. Thus, crankcase pressure becomes high as high-pressure enters the crankcase.
 - The force acts around the journal pin near the wobble (swash) plate, and is generated by the pressure difference before and behind the piston.
 - The drive lug and journal pin are located where the piston generates the highest pressure. Piston pressure is between suction pressure P_s and discharge pressure P_d , which is close to suction pressure P_s . If crankcase pressure P_c rises due to capacity control, the force around the journal pin makes the wobble (swash) plate angle decrease and also the piston stroke decrease. In other words, crankcase pressure

REFRIGERATION SYSTEM

increase triggers pressure difference between the piston and the crankcase. The pressure difference changes the angle of the wobble (swash) plate.



A
B
C
D
E
F
G
H
I
K
L
M


ATC

REFRIGERATION SYSTEM

Component Layout

NJS0007X

SEC. 278•279



☆ For removal, it is necessary to remove the instrument panel assembly.

SJIA1348E

LUBRICANT

PFP:KLG00

Maintenance of Lubricant Quantity in Compressor

NJS0007Y

The lubricant in the compressor circulates through the system with the refrigerant. Add lubricant to compressor when replacing any component or after a large refrigerant leakage occurred. It is important to maintain the specified amount.

If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor.
- Excessive lubricant: Inadequate cooling (thermal exchange interference)

LUBRICANT

Name : Nissan A/C System Oil Type S

LUBRICANT RETURN OPERATION

Adjust the lubricant quantity according to the test group shown below.

1. CHECK LUBRICANT RETURN OPERATION

Can lubricant return operation be performed?

- A/C system works properly.
- There is no evidence of a large amount of lubricant leakage.

CAUTION:

If excessive lubricant leakage is noted, never perform the lubricant return operation.

OK or NG

- OK >> GO TO 2.
- NG >> GO TO 3.

2. PERFORM LUBRICANT RETURN OPERATION, PROCEEDING AS FOLLOWS

1. Start engine, and set the following conditions:
 - Engine speed: Idling to 1,200 rpm
 - A/C or AUTO switch: ON
 - Blower speed: Max. position
 - Temp. control: Optional [Set so that intake air temperature is 25 to 30°C (77 to 86°F).]
 - Intake position: Recirculation (REC)
2. Perform lubricant return operation for about 10 minutes.
3. Stop engine.

>> GO TO 3.

3. CHECK REPLACEMENT PART

Should the compressor be replaced?

- YES >> GO TO [ATC-24, "LUBRICANT ADJUSTING PROCEDURE FOR COMPRESSOR REPLACEMENT"](#).
- NO >> GO TO [ATC-24, "LUBRICANT ADJUSTING PROCEDURE FOR COMPONENTS REPLACEMENT EXCEPT COMPRESSOR"](#).

LUBRICANT

LUBRICANT ADJUSTING PROCEDURE FOR COMPONENTS REPLACEMENT EXCEPT COMPRESSOR

After replacing any of the following major components, add the correct amount of lubricant to the system.
Amount of lubricant to be added

Part replaced	Lubricant to be added to system	Remarks
	Amount of lubricant m ℓ (US fl oz, Imp fl oz)	
Evaporator	75 (2.5, 2.6)	—
Condenser	35 (1.2, 1.2)	—
Liquid tank	10 (0.3, 0.4)	—
In case of refrigerant leak	30 (1.0, 1.1)	Large leak
	—	Small leak *1


*1: If refrigerant leak is small, no addition of lubricant is needed.

LUBRICANT ADJUSTING PROCEDURE FOR COMPRESSOR REPLACEMENT

1. Before connecting recovery/recycling recharging equipment to vehicle, check recovery/recycling recharging equipment gauges. No refrigerant pressure should be displayed. If NG, recover refrigerant from equipment lines.
2. Connect recovery/recycling recharging equipment to vehicle. Confirm refrigerant purity in supply tank using recovery/recycling recharging equipment and refrigerant identifier. If NG, refer to [ATC-6, "CONTAMINATED REFRIGERANT"](#).
3. Confirm refrigerant purity in vehicle A/C system using recovery/recycling recharging equipment and refrigerant identifier. If NG, refer to [ATC-6, "CONTAMINATED REFRIGERANT"](#).
4. Discharge refrigerant into the refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
5. Drain the lubricant from the old (removed) compressor into a graduated container and recover the amount of lubricant drained.
6. Drain the lubricant from the new compressor into a separate, clean container.
7. Measure an amount of new lubricant installed equal to amount drained from old compressor. Add this lubricant to new compressor through the suction port opening.
8. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to new compressor through the suction port opening.
9. If the liquid tank also needs to be replaced, add another 5 m ℓ (0.2 US fl oz, 0.2 Imp fl oz) of lubricant at this time.
Do not add this 5 m ℓ (0.2 US fl oz, 0.2 Imp fl oz) of lubricant only when replaces the compressor.

LUBRICANT

Lubricant adjusting procedure for compressor replacement



RJIA3578E

A
B
C
D
E
F
G
H
I
K
L
M

ATC

AIR CONDITIONER CONTROL

AIR CONDITIONER CONTROL


PFP:27500

Description of Air Conditioner LAN Control System

NJS0007Z

The LAN (Local Area Network) system consists of auto amp., mode door motor, air mix door motor and intake door motor.

A configuration of these components is shown in the figure below.



System Construction


NJS00080

A small network is constructed among the auto amp., air mix door motor, mode door motor and intake door motor. The auto amp. and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of each door motor.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the auto amp. and each door motor.

The following functions are contained in LCUs built into the air mix door motor, mode door motor and intake door motor.

- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (Auto amp. indicated value and motor opening angle comparison)




AIR CONDITIONER CONTROL

OPERATION

The auto amp. receives data from each of the sensors. The auto amp. sends mode door, air mix door and intake door opening angle data to the mode door motor LCU, air mix door motor LCU and intake door motor LCU.

The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors is compared by the LCUs in each door motor with the existing decision and opening angles. Subsequently, HOT/COLD, DEF/VENT and FRESH/RECIRCULATION operation is selected. The new selection data is returned to the auto amp.



TRANSMISSION DATA AND TRANSMISSION ORDER

Auto amp. data is transmitted consecutively to each of the door motor following the form shown in figure below.

Start:

Initial compulsory signal is sent to each of the door motor.

Address:

Data sent from the auto amp. are selected according to data-based decisions made by the air mix door motor, mode door motor and intake door motor.

If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data have no error, door control begins.

If an error exists, the received data are rejected and corrected data received. Finally, door control is based upon the corrected opening angle data.

Opening angle:

Data that show the indicated door opening angle of each door motor.

Error check:


Procedure by which sent and received data are checked for errors. Error data are then compiled. The error check prevents corrupted data from being used by the air mix door motor, mode door motor and intake door motor. Error data can be related to the following problems.

- Malfunction electrical frequency
- Poor electrical connections
- Signal leakage from transmission lines
- Signal level fluctuation

AIR CONDITIONER CONTROL

Stop signal:

At the end of each transmission, a stop operation, in-operation, or internal malfunction message is delivered to the auto amp. This completes one data transmission and control cycle.



AIR MIX DOOR CONTROL (AUTOMATIC TEMPERATURE CONTROL)

The air mix doors are automatically controlled so that in-vehicle temperature is maintained at a predetermined value by the temperature setting, ambient temperature, in-vehicle temperature and amount of sunload.

FAN SPEED CONTROL

Blower speed is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.

With pressing AUTO switch, the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

INTAKE DOOR CONTROL

The intake doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON-OFF operation of the compressor.


MODE DOOR CONTROL

The mode doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

AIR CONDITIONER CONTROL

MAGNET CLUTCH CONTROL

The ECM controls compressor operation using input signals from the refrigerant pressure sensor, throttle position sensor and auto amp.



SELF-DIAGNOSIS SYSTEM

The self-diagnosis system is built into the auto amp. to quickly locate the cause of symptoms.

A
B
C
D
E
F
G
H
I
K
L
M


ATC

AIR CONDITIONER CONTROL

NJS00081

Description of Control System

The control system consists of input sensors, switches, auto amp. (microcomputer) and outputs. The relationship of these components is shown in the figure below:




RJIA1584E

AIR CONDITIONER CONTROL

Control Operation

NJS00082

A
B
C
D
E
F
G
H
I



SJIA1134E

ATC

DISPLAY SCREEN

The operation status of the system is displayed on the screen.

AUTO SWITCH (DRIVER SIDE)

- The compressor, intake doors, air mix doors, outlet doors and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.
- When the A/C system is operating, if the screen is not displayed, press the AUTO switch once to display the A/C screen. (The display time is determined by the navigation system settings.)
- When the A/C system is in manual control, and the DUAL switch is depressed, pressing the AUTO switch changes to auto-control for the driver side only.

AUTO SWITCH (PASSENGER SIDE)

- The compressor, intake doors, air mix doors, outlet doors and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.
- When the A/C system is operating, if the screen is not displayed, press the AUTO switch once to display the A/C screen. (The display time is determined by the navigation system settings.)
- When the A/C system is in manual control, and the DUAL switch is depressed, pressing the AUTO switch changes to auto-control for the passenger side only.

TEMPERATURE DIAL (POTENTIO TEMPERATURE CONTROL) (DRIVER SIDE)

The set temperature is increased or decreased with this dial.

TEMPERATURE DIAL (POTENTIO TEMPERATURE CONTROL) (PASSENGER SIDE)

- The set temperature is increased or decreased with this dial.

K
L
M

AIR CONDITIONER CONTROL

- When the temperature dial is turned, the DUAL switch indicator will automatically illuminate.

INTAKE SWITCH

Set the inlet to automatic control or to REC-fixed. However, REC-fixed cannot be selected in DEF mode. When the FRE switch is ON, the air inlet will be automatically controlled.

DEFROSTER (DEF) SWITCH

Mode doors are set to the defrost position with this switch. Also, intake doors are set to the outside air position, and compressor turns ON.

OFF SWITCH

Compressor and blower are OFF, the intake doors are set to the outside air position, and the mode doors are set to the foot (80% foot and 20% defrost) position.

MODE SWITCH (DRIVER SIDE)

- When the DUAL switch indicator is not illuminated, the left and right outlets are switched together.
- When the DUAL switch indicator is illuminated, only the driver-side outlet is switched.

MODE SWITCH (PASSENGER SIDE)

When the MODE switch is pressed, the DUAL switch indicator illuminates, and only the passenger-side outlet is switched.

ECON (ECONOMY) SWITCH

- By pressing the ECON switch, the indicator of ECON switch should illuminate, and the control is switched to economy control.
- When press ECON switch again, the indicator of ECON switch should not illuminate and the compressor always turns OFF. With the compressor OFF, the system will not remove heat (cool) or de-humidify. The system will maintain the in-vehicle temperature at the set temperature when the set temperature is above the ambient (outside) temperature. The system will set the intake doors to the outside air position.
- When press ECON switch again, the control is switched to economy control.

FAN SWITCH

The blower speed is manually controlled with this switch. Five speeds are available for manual control (as shown on the display screen).

DUAL SWITCH

- When the DUAL switch indicator is illuminated, the driver-side outlet and passenger-side outlet, as well as the setting temperature, can each be set independently.
- When the DUAL switch indicator is not illuminated, the driver-side outlet and setting temperature is applied to both sides.

REAR CONTROL SWITCH

Pressing rear control switch activates rear seat switch operation screen. It allows operating rear seat air outlet switch and air cleaner switch.

Fail-Safe Function

NJS00083

- If a communication error exists between auto amp. and AV C/U or AV and NAVI C/U for 30 seconds or longer, air conditioner is controlled under the following conditions:
 - Compressor: ON
 - Air outlet: AUTO
 - Air inlet: FRE (Fresh)
 - Blower fan speed: AUTO
 - Set temperature: Setting before communication error occurs


AIR CONDITIONER CONTROL

NJS00084


Discharge Air Flow

A
B
C
D
E
F
G
H
I
ATC
K
L
M


① : Defroster ② : Ventilation ③ : Foot




Ventilation




Bi-level




Foot



Defroster and foot



Defroster




RJIA0205E

AIR CONDITIONER CONTROL

NJS00085

System Description SWITCHES AND THEIR CONTROL FUNCTION



RJIA1873E

Position or switch	DUAL SW		MODE SW					DEF SW		AUTO SW (Driver side)	AUTO SW (Passenger side)	Intake SW		Rear control sw		Temperature dial (Driver side)		Temperature dial (Passenger side)		OFF SW
	ON	OFF	VENT	B/L	B/L2 *1	FOOT	D/F *2	ON	OFF	REC	FRE	ON	OFF	AUTO A/C		AUTO PASS				
														18°C (60°F)	~	32°C (90°F)	18°C (60°F)	~	32°C (90°F)	
VENT door (Driver side)	-		(A)	(B)	(C)	(D)	(D)	(D)	-	AUTO										(D)
VENT door (Passenger side)	ON		(A)	(B)	(C)	(D)	-	(D)	-	-	AUTO									(D)
	OFF		(A)	(B)	(C)	(D)	(D)	(D)	-	AUTO	-									(D)
Foot door (Driver side)	-		(D)	(C)	(B)	(A)	(B)	(D)	-	AUTO										(A)
Foot door (Passenger side)	ON		(D)	(C)	(B)	(A)	-	(D)	-	-	AUTO									(A)
	OFF		(D)	(C)	(B)	(A)	(B)	(D)	-	AUTO	-									(A)
DEF door	-		(D)	(D)	(D)	(C)	(B)	(A)	-	AUTO										(C)
Air mix door (Driver side)	-									-					(A)	AUTO	(B)			
Air mix door (Passenger side)	ON									-							(A)	AUTO	(B)	-
	OFF									-							(A)	AUTO	(B)	-
Bi-level door	-		(A) *3	AUTO	(B)	(B)	(B)	(B)	(B)											(B)
Rear VENT door	-		-	-	-	-	-	(B)	-					(A)	(B)					-
Intake door	-		-	-	-	-	-	(B)	-					(A)	AUTO					(B)

*1: The B/L2 mode is selected only when the mode door is automatically controlled.

*2: When the DUAL SW is ON, passenger cannot select the D/F mode.

*3: When air door mix door position is in (A) (Full cold), bi-level door position will be at (A) (Open).

SJIA1135E


TROUBLE DIAGNOSIS

TROUBLE DIAGNOSIS

PPF:00004

How to Perform Trouble Diagnosis for Quick and Accurate Repair WORK FLOW

NJS00086



SHA900E

*1 [ATC-62. "Operational Check"](#)

SYMPTOM TABLE

Symptom	Reference Page
A/C system does not come on.	Go to Trouble Diagnosis Procedure for A/C System. ATC-64. "Power Supply and Ground Circuit for Auto Amp."
A/C system cannot be controlled.	Go to Trouble Diagnosis Procedure for Multiplex Communication Circuit. ATC-120. "Multiplex Communication Circuit"
A/C display is not shown.	Go to Trouble Diagnosis Procedure for A/C Display. ATC-107. "A/C Display is Malfunctioning"
A/C operation is not possible.	Go to Trouble Diagnosis Procedure for A/C Operation. ATC-108. "A/C Operation is Malfunctioning"
Air outlet does not change.	Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN) ATC-70. "Mode Door Motor Circuit"
Mode door motor does not operate normally.	
Discharge air temperature does not change.	
Air mix door motor does not operate normally.	Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN) ATC-73. "Air Mix Door Motor Circuit"
Intake door does not change.	Go to Trouble Diagnosis Procedure for Intake Door Motor. (LAN) ATC-76. "Intake Door Motor Circuit"
Intake door motor does not operate normally.	
Blower motor operation is malfunctioning.	Go to Trouble Diagnosis Procedure for Blower Motor. ATC-81. "Blower Motor Circuit"
Magnet clutch does not engage.	Go to Trouble Diagnosis Procedure for Magnet Clutch. ATC-86. "Magnet Clutch Circuit"
Insufficient cooling	Go to Trouble Diagnosis Procedure for Insufficient Cooling. ATC-93. "Insufficient Cooling"
	Go to Diagnosis Procedure for Insufficient Cooling. ATC-100. "DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING"
Insufficient heating	Go to Trouble Diagnosis Procedure for Insufficient Heating. ATC-102. "Insufficient Heating"
Noise	Go to Trouble Diagnosis Procedure for Noise. ATC-103. "Noise"
Self-diagnosis cannot be performed.	Go to Trouble Diagnosis Procedure for Self-diagnosis. ATC-104. "Self-Diagnosis"







TROUBLE DIAGNOSIS

Symptom	Reference Page	
Memory function does not operate.	Go to Trouble Diagnosis Procedure for Memory Function.	ATC-105. "Memory Function"
ECON mode does not operate.	Go to Trouble Diagnosis Procedure for ECON (ECONOMY) mode.	ATC-106. "ECON (ECONOMY) MODE"
Rear control does not operate.	Go to Trouble Diagnosis Procedure for Real Control Switch.	ATC-80. "Rear Control Switch Circuit"

TROUBLE DIAGNOSIS

Component Parts and Harness Connector Location ENGINE COMPARTMENT

NJS00087










A
B
C
D
E
F
G
H
I
K
L
M

ATC

RJIA3196E

TROUBLE DIAGNOSIS

PASSENGER COMPARTMENT



RJIA0209E


TROUBLE DIAGNOSIS

Schematic

NJS00088

A
B
C
D
E
F
G
H
I
J
K
L
M

ATC



- (NV) : With NAVI
- (ON) : Without NAVI
- *1 39 : (NV) *3 38 : (NV) *5 44 : (NV) *7 43 : (NV)
- 45 : (ON) 43 : (ON) 47 : (ON) 46 : (ON)
- *2 37 : (NV) *4 36 : (NV) *6 45 : (NV) 48 : (ON)
- 44 : (ON) 40 : (ON)





TJWM0091E

TROUBLE DIAGNOSIS

Wiring Diagram — A/C —

NJS00089

ATC-A/C-01





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.
 (M144), (M145) - FUSE BLOCK-
 JUNCTION BOX (J/B) NO.2

TJWM0221E

TROUBLE DIAGNOSIS

ATC-A/C-03




REFER TO THE FOLLOWING.
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TJWM0223E

TROUBLE DIAGNOSIS


ATC-A/C-04

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
K
L
M

ATC




TJWM0224E

TROUBLE DIAGNOSIS


ATC-A/C-05

▬ : DATA LINE



PRECEDING PAGE

NEXT PAGE





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TJWM0225E

TROUBLE DIAGNOSIS

ATC-A/C-06




REFER TO THE FOLLOWING.
 (E205) -SUPER MULTIPLE JUNCTION (SMJ)

TJWM0226E

TROUBLE DIAGNOSIS

ATC-A/C-07




FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B) REFER TO PG-POWER. (E3)

TO ATC-A/C-03

REFER TO THE FOLLOWING.

- (F105) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)
- (F101) -ELECTRICAL UNITS







*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TJWM0227E

TROUBLE DIAGNOSIS

ATC-A/C-08








REFER TO THE FOLLOWING.
(M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TJWM0228E

TROUBLE DIAGNOSIS

ATC-A/C-09

▬ : DATA LINE









TJWM0229E

TROUBLE DIAGNOSIS

ATC-A/C-10

▬ : DATA LINE




TJWM0230E

TROUBLE DIAGNOSIS


Auto Amp. Terminals and Reference Value

NJS0008A

Measure voltage between each terminal and ground by referring terminals and reference value for auto amp.








PIN CONNECTOR TERMINAL LAYOUT



TERMINALS AND REFERENCE VALUE FOR AUTO AMP.

Terminal No.	Wire color	Item	Ignition switch	Condition	Voltage (V)
1	G/OR	Intake sensor	—	—	—
2	G/R	Ambient sensor	—	—	—
3	LG/B	In-vehicle sensor	—	—	—
4	PL	Vehicle speed signal	ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	<p>ELF1080D</p>
5	G/Y	A/C LAN signal	ON	—	Approx. 5
6	LG	Power supply for rear vent door motor	ON	Rear vent SW: Open	Approx. 0
				Rear vent SW: Close	Approx. 12
7	GY/L	Power supply for ACC	ON	—	Battery voltage
9	W	Multiplex communication signal (Fr TX)	ON	—	<p>RJA0212E</p>




TROUBLE DIAGNOSIS

Terminal No.	Wire color	Item	Ignition switch	Condition	Voltage (V)
10	R	Multiplex communication signal (Fr RX)	ON	—	 <p style="text-align: right; font-size: small;">RJIA0213E</p>
11	R/Y	Sensor ground	ON	—	Approx. 0
12	SB	Sunload sensor	—	—	—
15	G	Multiplex communication signal (Rr RX)	ON	—	 <p style="text-align: right; font-size: small;">RJIA0214E</p>
16	W/B	Power supply for rear vent door motor	ON	Rear vent switch: Open	Approx. 12
				Rear vent switch: Close	Approx. 0
17	L/OR	Water temperature sensor	—	At idle [after warming up, approx. 80°C (176°F)] NOTE: The waveforms vary depending on coolant temperature.	 <p style="text-align: right; font-size: small;">PKIA0098J</p>
18	OR	Compressor feedback signal (Low-pressure cut)	ON	AUTO SW: ON (Start engine)	Blower motor operates. Approx. 0
				When refrigerant pressure sensor connector is disconnected	Approx. 5
20	B	Multiplex communication signal (Fr CLK)	ON	—	 <p style="text-align: right; font-size: small;">HAK0363D</p>
21	GY	Power supply for each door motor	ON	—	Battery voltage
22	Y/B	Compressor ON signal	ON	AUTO switch: ON (Blower motor operates.)	Approx. 0
				AUTO switch: OFF (A/C system: OFF)	Approx. 5
23	Y	ECV (Electronic Control Valve) signal	ON	Self-diagnosis: STEP- 4. (Code No. 42)	 <p style="text-align: right; font-size: small;">RJIA1563E</p>
25	B	Ground	ON	—	Approx. 0

A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS

Terminal No.	Wire color	Item	Ignition switch	Condition	Voltage (V)
26	Y/G	Power supply for BAT	OFF	—	Battery voltage
27	P	Power supply for IGN	ON	—	Battery voltage
29	SB	Blower motor ON signal	ACC or ON	AUTO SW: ON (Blower motor operates.)	Approx. 0
				AUTO switch: OFF (A/C system: OFF)	Approx. 5
30	BR/W	Multiplex communication signal (Rr CLK)	ON	—	 <p style="text-align: right; font-size: small;">HAK0364D</p>
31	GY/L	Multiplex communication signal (Rr TX)	ON	—	 <p style="text-align: right; font-size: small;">RJA0215E</p>
35	L/OR	Blower motor drive signal	ACC or ON	Blower speed: 1st speed	 <p style="text-align: right; font-size: small;">SJA0116J</p>


TROUBLE DIAGNOSIS

NJS0008B

Self-diagnosis Function DESCRIPTION

The self-diagnosis system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from usual control to the self-diagnosis system is accomplished by starting the engine (turning the ignition switch ON) and pressing OFF switch for at least 5 seconds. The OFF switch must be pressed within 10 seconds after starting the engine (ignition switch is turned ON). This system will be canceled by either pressing AUTO switch or turning the ignition switch OFF. Shifting from one step to another is accomplished by means of turning temperature dial, as required.

Shifting from STEP-5 to AUXILIARY MECHANISM is accomplished by means of pushing  (fan) UP switch.



SJIA1282E

TROUBLE DIAGNOSIS

FUNCTION CONFIRMATION PROCEDURE

1. SET IN SELF-DIAGNOSIS MODE

1. Turn ignition switch ON.
2. Set in self-diagnosis mode as follows. Within 10 seconds after starting engine (ignition switch is turned ON.), press OFF switch for at least 5 seconds.



CAUTION:

If battery voltage drops below 12 V during diagnosis STEP-3, door motor speed becomes slower and as a result, the system may generate an error even when operation is normal. To avoid this, start engine before performing this diagnosis.

>> GO TO 2.

2. STEP-1: LEDS AND DISPLAY ARE CHECKED

Check LED illumination and display screen.



OK or NG

OK >> GO TO 3.

NG >> Malfunctioning OFF switch, LED or auto amp. Refer to [ATC-104, "Self-Diagnosis"](#).

3. CHECK TO ADVANCE SELF-DIAGNOSIS STEP-2

Turn temperature dial (driver side) clockwise.

Advance to self-diagnosis STEP-2?

YES >> GO TO 4.

NO >> Replace multifunction switch. (Temperature dial is malfunctioning.)

4. CHECK TO RETURN SELF-DIAGNOSIS STEP-1

Turn temperature dial (driver side) counterclockwise.

Return to self-diagnosis STEP-1?

YES >> GO TO 5.

NO >> Replace multifunction switch. (Temperature dial is malfunctioning.)


TROUBLE DIAGNOSIS

5. STEP-2: SENSOR CIRCUITS ARE CHECKED FOR OPEN OR SHORT CIRCUIT

Turn temperature dial (driver side) clockwise.

Does code No.20 appear on the display?

- YES >> GO TO 6.
- NO >> GO TO 14.




6. STEP-3: MODE DOOR AND INTAKE DOOR POSITIONS ARE CHECKED

Turn temperature dial (driver side) clockwise.

Does code No.30 appear on the display?


- YES >> GO TO 7.
- NO >> GO TO 15.



7. STEP-4: OPERATION OF EACH ACTUATOR IS CHECKED

1. Turn temperature dial (driver side) clockwise.
2. Press  (DEF) switch, code No. of each actuator test is indicated on the display.

>> GO TO 8.



A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS

8. CHECK ACTUATORS

Refer to the following chart and confirm discharge air flow, air temperature, blower motor duty ratio and compressor operation.

Mode position indication		Condition	Air outlet/distribution				
Driver side	Passenger side		Front VENT	Rear VENT	Front FOOT	Rear FOOT	DEF
		DUAL SW: OFF Rear ventilator door: OPEN	87%	13%			
			50%	13%	24%	13%	
					50%	30%	20%
					37%	23%	40%
							100%

RJIA0222E

Code No.	41	42	43	44	45	46	47	48
Mode door position (Driver side)	VENT (B/L OPEN)	VENT (B/L SHUT)	B/L 1 (B/L SHUT)	B/L 1 (B/L OPEN)	B/L 2	FOOT	D/F	DEF
Mode door position (Passenger side)	VENT (B/L OPEN)	VENT (B/L SHUT)	B/L 1 (B/L SHUT)	B/L1 (B/L OPEN)	B/L 2	FOOT 1	FOOT 2	DEF
Intake door position	REC	REC	REC	20% FRE	20% FRE	FRE	FRE	FRE
Air mix door position	FULL COLD	FULL COLD	FULL COLD	FULL HOT	FULL HOT	FULL HOT	FULL HOT	FULL HOT
Blower motor duty ratio	37%	37%	91%	65%	65%	65%	65%	91%
Compressor	ON	ON	ON	OFF	OFF	OFF	ON	ON
Rear vent door position	OPEN	SHUT	SHUT	SHUT	SHUT	SHUT	SHUT	SHUT
Electronic control valve (ECV) duty ratio	100%	50%	100%	0%	0%	0%	50%	100%

Checks must be made visually, by listening to any noise, or by touching air outlets with hand, etc. for improper operation.

OK or NG

OK >> GO TO 9.

NG >> ● Air outlet does not change.

Go to Mode Door Motor Circuit. Refer to [ATC-70, "Mode Door Motor Circuit"](#) .

● Intake door does not change.

Go to Intake Door Motor Circuit. Refer to [ATC-76, "Intake Door Motor Circuit"](#) .

● Discharge air temperature does not change.

Go to Air Mix Door Motor Circuit. Refer to [ATC-73, "Air Mix Door Motor Circuit"](#) .

● Blower motor operation is malfunctioning.

Go to Blower Motor Circuit. Refer to [ATC-81, "Blower Motor Circuit"](#) .

● Magnet clutch does not engage.

Go to Magnet Clutch Circuit. Refer to [ATC-86, "Magnet Clutch Circuit"](#) .

TROUBLE DIAGNOSIS

9. STEP-5: TEMPERATURE OF EACH SENSOR IS CHECKED

1. Turn the temperature dial (driver side) clockwise.
2. Code No. 51 appears on the display.

>> GO TO 10.

10. CHECK AMBIENT SENSOR

Press  (DEF) switch one time. Temperature detected by ambient sensor is indicated on the display.


NOTE:

If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.

OK or NG

OK >> GO TO 11.

NG >> Go to Ambient Sensor Circuit. Refer to [ATC-110, "Ambient Sensor Circuit"](#).



11. CHECK IN-VEHICLE SENSOR

Press  (DEF) switch the second time. Temperature detected by in-vehicle sensor is indicated on the display.


NOTE:

If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.

OK or NG

OK >> GO TO 12.

NG >> Go to In-vehicle Sensor Circuit. Refer to [ATC-112, "In-Vehicle Sensor Circuit"](#).



12. CHECK INTAKE SENSOR

Press  (DEF) switch the third time. Temperature detected by intake sensor is indicated on the display.


NOTE:

If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.

OK or NG

OK >> GO TO 13.

NG >> Go to Intake Sensor Circuit. Refer to [ATC-118, "Intake Sensor Circuit"](#).



TROUBLE DIAGNOSIS

13. CHECK MULTIPLEX COMMUNICATION ERROR

1. Press intake switch.
2. Multiplex communication error between AV C/U (AV and NAVI C/U) and auto amp. can be detected as self-diagnosis results. (If plural errors occur, the display of each error will blink two times for 0.5 second intervals.)
3. Is multiplex communication error detected as self-diagnosis results?

CAUTION:

Rear control cancel switch has two positions "CANCEL" and "ON". If rear control cancel switch has been canceled, Multiplex communication error might be detected even there is no malfunction.

So it is necessary to follow the procedure below:

1. Switch "ON" position on the rear control cancel switch.
2. Disconnect the battery negative terminal for approx. 10 seconds or more in order to delete the memory of self-diagnosis.
3. Reconfirm the multiplex communication error as self-diagnosis result is detected.

YES or NO

- YES >> Go to Multiplex Communication Circuit. Refer to [ATC-120, "Multiplex Communication Circuit"](#).
- NO >> 1. Turn ignition switch OFF or AUTO switch ON.
2. INSPECTION END

Display	Multiplex communication error
52	In good order
52 	AV(and NAVI) control unit ⇨ Auto amp.
52 	Rear control SW ⇨ Auto amp.
52 	Auto amp. ⇨ AV (and NAVI) control unit or rear control SW

RJIA1589E

TROUBLE DIAGNOSIS

14. CHECK MALFUNCTIONING SENSOR

Refer to the following chart for malfunctioning code No.

(If two or more sensors malfunction, corresponding code Nos. blink respectively twice.)

*1: Perform self-diagnosis STEP-2 under sunshine.

When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise code No. 25 will indicate despite that sunload sensor is functioning properly.

Code No.	Malfunctioning sensor (Including circuits)	Reference page
21 / -21	Ambient sensor	*2
22 / -22	In-vehicle sensor	*3
24 / -24	Intake sensor	*4
25 / -25	Sunload sensor *1	*5
26 / -26	Air mix door motor PBR (Driver side)	*6
27 / -27	Air mix door motor PBR (Passenger side)	*6


*2: [ATC-110, "DIAGNOSIS PROCEDURE FOR AMBIENT SENSOR"](#) .

*3: [ATC-113, "DIAGNOSIS PROCEDURE FOR IN-VEHICLE SENSOR"](#) .

*4: [ATC-118, "DIAGNOSIS PROCEDURE FOR INTAKE SENSOR"](#) .

*5: [ATC-115, "DIAGNOSIS PROCEDURE FOR SUNLOAD SENSOR"](#) .

*6: [ATC-75, "DIAGNOSIS PROCEDURE FOR AIR MIX DOOR MOTOR PBR"](#) .



>> INSPECTION END

TROUBLE DIAGNOSIS

15. CHECK MALFUNCTIONING DOOR MOTOR POSITION SWITCH

Mode and/or intake door motor position switch(es) is/are malfunctioning.

Code No. *1 *2	Mode or intake door position	Reference page
31	VENT (Driver side)	*3
32	FOOT (Driver side)	
33	DEF (Driver side)	
34	VENT (Passenger side)	
35	FOOT1 (Passenger side)	
36	DEF (Passenger side)	
37	FRE	*4
38	20%FRE	
39	REC	

(If two or more mode or intake doors are out of order, corresponding code numbers blink respectively twice.)

*1: If mode door motor harness connector is disconnected, the following display pattern will appear.


31→32→33→34→35→36→Return to 31

*2: If intake door motor harness connector is disconnected, the following display pattern will appear.

37→38→39→Return to 37

*3: [ATC-72, "DIAGNOSIS PROCEDURE FOR MODE DOOR MOTOR"](#) .

*4: [ATC-78, "DIAGNOSIS PROCEDURE FOR INTAKE DOOR MOTOR"](#) .



>> INSPECTION END


TROUBLE DIAGNOSIS

AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER

The trimmer compensates for differences in range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$) between temperature setting (displayed digitally) and temperature felt by customer.

Operating procedures for this trimmer are as follows:

- Begin self-diagnosis STEP-5 mode. Refer to [ATC-53, "Self-diagnosis Function"](#).
- Press  (fan) UP switch to set system in auxiliary mode.
- Display shows "61" in auxiliary mechanism. It takes approximately 3 seconds.
- Turn the temperature dial (driver side) as desired. Temperature will change at a rate of 0.5°C (1.0°F) each time a dial is turned.



When battery cable is disconnected or battery voltage below 10 V, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C (0°F).

TROUBLE DIAGNOSIS

NJS0008C

Operational Check

The purpose of the operational check is to check if the individual system operates properly.

Conditions : Engine running at normal operating temperature

CHECKING MEMORY FUNCTION

1. Set the temperature to 32°C (90°F).
2. Press OFF switch.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Press AUTO switch.
6. Confirm that the set temperature remains at previous temperature.
7. Press OFF switch.

If NG, go to trouble diagnosis procedure for [ATC-105, "Memory Function"](#) .

If OK, continue the check.

CHECKING BLOWER

1. Press fan switch (up side) one time. Blower should operate on low speed. The fan symbol should have one blade lit.
2. Press fan switch (up side) one more time, and continue checking blower speed and fan symbol until all speeds are checked.
3. Leave blower on max. speed.

If NG, go to trouble diagnosis procedure for [ATC-81, "Blower Motor Circuit"](#) .

If OK, continue the check.

CHECKING DISCHARGE AIR

1. Press MODE switch and DEF switch.
2. Each position indicator should change shape.
3. Confirm that discharge air comes out according to the air distribution table. Refer to [ATC-33, "Discharge Air Flow"](#) .

Mode position indication		Condition	Air outlet/distribution				
Driver side	Passenger side		Front VENT	Rear VENT	Front FOOT	Rear FOOT	DEF
		DUAL SW: OFF Rear ventilator door: OPEN	87%	13%			
			50%	13%	24%	13%	
					50%	30%	20%
					37%	23%	40%
							100%

RJIA0222E

If NG, go to trouble diagnosis procedure for [ATC-70, "Mode Door Motor Circuit"](#) .

If OK, continue the check.

NOTE:

Confirm that the compressor clutch is engaged (sound or visual inspection) and intake door position is at FRESH when the DEF is selected.

TROUBLE DIAGNOSIS

CHECKING INTAKE AIR (INTAKE SWITCH)

1. Press intake switch one time.
2. Press intake switch again. Recirculation indicator should illuminate.
3. Listen for intake door position change. (Slight change of blower sound can be heard.)

If NG, go to trouble diagnosis procedure for [ATC-76, "Intake Door Motor Circuit"](#) .

If OK, continue the check.

CHECKING TEMPERATURE DECREASE

1. Turn temperature dial (driver side) until 18°C (60°F) is displayed.
2. Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for [ATC-93, "Insufficient Cooling"](#) .

If OK, continue the check.

CHECKING TEMPERATURE INCREASE

1. Turn temperature dial (driver side) until 32°C (90°F) is displayed.
2. Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for [ATC-102, "Insufficient Heating"](#) .

If OK, continue the check.

CHECK ECON (ECONOMY) MODE

1. Set temperature dial 25°C (75°F).
2. Press ECON switch.
3. Display should indicate ECON (not AUTO).
4. Press ECON switch again. Display should disappear ECON.

- Confirm that the compressor clutch is not engaged (sound or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle, and set temperatures.)

If NG, go to trouble diagnosis procedure for [ATC-106, "ECON \(ECONOMY\) MODE"](#) .

If OK, continue the check.

CHECKING AUTO MODE

1. Press AUTO switch.
2. Display should indicate AUTO (not ECON).

- Confirm that the compressor clutch engages (sound or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle, and set temperatures.)

If NG, go to trouble diagnosis procedure for [ATC-64, "Power Supply and Ground Circuit for Auto Amp."](#) , then if necessary, trouble diagnosis procedure for [ATC-86, "Magnet Clutch Circuit"](#) .

If all operational checks are OK (symptom cannot be duplicated), go to Incident Simulation Tests in [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) and perform tests as outlined to simulate driving conditions environment. If symptom appears, refer to [ATC-35, "SYMPTOM TABLE"](#) and perform applicable trouble diagnosis procedures.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS


NJS0008D

Power Supply and Ground Circuit for Auto Amp.

SYMPTOM: A/C system does not come on.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – AUTO mode

- a. Press AUTO switch (driver side).
- b. Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (sound or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

**If OK (symptom cannot be duplicated), perform complete operational check (*2).
If NG (symptom is confirmed), continue with STEP-2 following.**

2. Check for any service bulletins.

3. Check main power supply and ground circuit. (*1)

4. Check multiplex communication circuit (*3).

OK

5. Replace auto amp.

RJIA1898E

*1 [ATC-65. "DIAGNOSIS PROCEDURE FOR A/C SYSTEM"](#)

*2 [ATC-62. "Operational Check"](#)

*3 [ATC-120. "Multiplex Communication Circuit"](#)


COMPONENT DESCRIPTION

Auto Amp. (Automatic Amplifier)

The auto amp. has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled.

When the various switches and temperature dial are operated, data are input to the auto amp. from the AV C/U or AV and NAVI C/U using multiplex communication.

Self-diagnosis functions are also built into auto amp. to provide quick check of malfunctions in the auto air conditioner system.




RJIA0210E

TROUBLE DIAGNOSIS


Potential Temperature Control (PTC)

The PTC is built into the multifunction switch. It can be set at an interval of 0.5°C (1.0°F) in the 18°C (60°F) to 32°C (90°F) temperature range by turning the temperature dial. The set temperature is displayed.



DIAGNOSIS PROCEDURE FOR A/C SYSTEM

SYMPTOM: A/C system does not come on.



1. CHECK POWER SUPPLY CIRCUIT FOR AUTO AMP.

1. Disconnect auto amp. connector.
2. Check voltage between auto amp. harness connector M119 terminal 7, M120 terminals 26, 27 and ground.


Terminals		(-)	Ignition switch position		
Auto amp. connector	Terminal No.		OFF	ACC	ON
M119	7	Ground	Approx. 0 V	Battery voltage	Battery voltage
M120	26		Battery voltage	Battery voltage	Battery voltage
M120	27		Approx. 0 V	Approx. 0 V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check 10 A fuses [Nos. 2, 6 and 21 located in the fuse block (J/B) No. 1]. Refer to [PG-70, "FUSE BLOCK - JUNCTION BOX \(J/B\) NO. 1"](#).

- If fuses are OK, check harness for open circuit. Repair or replace if necessary.
- If fuses are NG, replace fuse and check harness for short circuit. Repair or replace if necessary.



A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS


2. CHECK GROUND CIRCUIT FOR AUTO AMP.

1. Turn ignition switch OFF.
2. Check continuity between auto amp. harness connector M120 terminal 25 and ground.

25 – Ground : **Continuity should exist.**

OK or NG


- OK >> Replace auto amp.
 NG >> Repair harness or connector.



LAN System Circuit

NJS0008E

SYMPTOM: Mode door motor, intake door motor and/or air mix door motor(s) does not operate normally.



DIAGNOSIS PROCEDURE FOR LAN CIRCUIT


1. CHECK POWER SUPPLY FOR AUTO AMP.

1. Turn ignition switch ON.
2. Check voltage between auto amp. harness connector M120 terminal 21 and ground.

21 – Ground : **Battery voltage**

OK or NG

- OK >> GO TO 2.
 NG >> Replace auto amp.



TROUBLE DIAGNOSIS


2. CHECK SIGNAL FOR AUTO AMP.

Check voltage between auto amp. harness connector M119 terminal 5 and ground.

5 – Ground : Approx. 5 V

OK or NG

- OK >> GO TO 3.
- NG >> Replace auto amp.




3. CHECK POWER SUPPLY FOR EACH DOOR MOTOR

Check voltage between passenger side mode door motor harness connector M106 terminal 1, passenger side air mix door motor harness connector M107 terminal 1, intake door motor harness connector M118 terminal 1, driver side mode door motor harness connector M471 terminal 3, driver side air mix door motor harness connector M472 terminal 3 and ground.

1, 3 – Ground : Approx. 12 V

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.




4. CHECK SIGNAL FOR EACH DOOR MOTOR

Check voltage between passenger side mode door motor harness connector M106 terminal 3, passenger side air mix door motor harness connector M107 terminal 3, intake door motor harness connector M118 terminal 3, driver side door motor harness connector M471 terminal 6, driver side door motor connector M472 terminal 6 and ground.

3, 6 – Ground : Approx. 5 V

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.




5. CHECK MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect each door motor connector.
3. Check continuity between passenger side mode door motor harness connector M106 terminal 2, passenger side air mix door motor harness connector M107 terminal 2, intake door motor harness connector M118 terminal 2, driver side mode door motor harness connector M471 terminal 11, driver side air mix door motor harness connector M472 terminal 11 and ground.

2, 11 – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 6.
- NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

6. CHECK MOTOR OPERATION

1. Reconnect each door motor connector.
2. Turn ignition switch ON.
3. Confirm each door motor operation.

OK or NG

- OK >> (Return to operate normally.)
- Poor contacting the motor connector
- NG >> (Does not operate normally.)
- GO TO 7.

7. CHECK AIR MIX DOOR MOTOR AND INTAKE DOOR MOTOR OPERATION

1. Turn ignition switch OFF.
2. Disconnect mode door motor (driver side, passenger side), air mix door motor (driver side, passenger side) and intake door motor connectors.
3. Reconnect air mix door motor (driver side, passenger side) and intake door motor connectors.
4. Turn ignition switch ON.
5. Confirm air mix door motor (driver side, passenger side) and intake door motor operation.

OK or NG

- OK >> (Air mix and intake door motors operate normally.)
- GO TO 10.
- NG >> (Air mix and intake door motors does not operate normally.)
- GO TO 8.

8. CHECK MODE DOOR MOTOR AND INTAKE DOOR MOTOR OPERATION

1. Turn ignition switch OFF.
2. Disconnect air mix door motor connectors (driver side, passenger side).
3. Reconnect mode door motor connectors (driver side, passenger side).
4. Turn ignition switch ON.
5. Confirm mode door motor (driver side, passenger side) and intake door motor operation.

OK or NG

- OK >> (Mode and intake door motors operate normally.)
- GO TO 11.
- NG >> (Mode and intake door motors does not operate normally.)
- GO TO 9.

9. CHECK MODE DOOR MOTOR AND AIR MIX DOOR MOTOR OPERATION

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Reconnect air mix door motor connectors (driver side, passenger side).
4. Turn ignition switch ON.
5. Confirm mode door motor and air mix door motor operation.

OK or NG

- OK >> (Mode and air mix door motors operate normally.)
- Replace intake door motor.
- NG >> (Intake door motor does not operate normally.)
- Replace auto amp.

TROUBLE DIAGNOSIS

10. CHECK MODE DOOR MOTOR OPERATION

1. Turn ignition switch OFF.
2. Reconnect mode door motor (driver side) connector.
3. Turn ignition switch ON.
4. Confirm mode door motor (driver side) operation.

OK or NG

- OK >> [Mode door motor (driver side) operates normally.]
- Replace mode door motor (passenger side).
- NG >> [Mode door motor (driver side) does not operate normally.]
- Replace mode door motor (driver side).

11. CHECK AIR MIX DOOR MOTOR OPERATION

1. Turn ignition switch OFF.
2. Reconnect air mix door motor (driver side) connector.
3. Turn ignition switch ON.
4. Confirm air mix door motor (driver side) operation.

OK or NG

- OK >> [Air mix door motor (driver side) operates normally.]
- Replace air mix door motor (passenger side).
- NG >> [Air mix door motor (driver side) does not operate normally.]
- Replace air mix door motor (driver side).

A

B

C

D

E

F

G

H

I

ATC

K

L

M

TROUBLE DIAGNOSIS


NJS0008F

Mode Door Motor Circuit

SYMPTOM:

- Air outlet does not change.
- Mode door motor does not operate normally.

INSPECTION FLOW



RJIA3198E

*1 [ATC-33, "Discharge Air Flow"](#)

*2 [ATC-62, "Operational Check"](#)

*3 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 1.

*4 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5 to 7.

*5 [ATC-110, "Ambient Sensor Circuit"](#)

*6 [ATC-112, "In-Vehicle Sensor Circuit"](#)

*7 [ATC-115, "Sunload Sensor Circuit"](#)

*8 [ATC-75, "Air Mix Door Motor PBR Circuit"](#)

*9 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.

*10 [ATC-66, "LAN System Circuit"](#)

*11 [ATC-140, "MODE DOOR MOTOR"](#)

*12 [ATC-35, "SYMPTOM TABLE"](#)

*13 [ATC-118, "Intake Sensor Circuit"](#)

TROUBLE DIAGNOSIS

SYSTEM DESCRIPTION

Component Parts


Mode door control system components are:

- Auto amp.
- Mode door motor (LCU)
- A/C LAN system (PBR built-in mode door motor, air mix door motor and intake door motor)
- In-vehicle sensor
- Ambient sensor
- Sunload sensor
- Intake sensor


System Operation

The auto amp. receives data from each of the sensors. The auto amp. sends air mix door, mode door and intake door opening angle data to the air mix door motor LCU, mode door motor LCU and intake door motor LCU.

The air mix door motor, mode door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles. Subsequently, HOT/COLD, DEF/VENT and FRESH/RECIRCULATION operation is selected. The new selection data are returned to the auto amp.



Mode Door Control Specification





TROUBLE DIAGNOSIS

COMPONENT DESCRIPTION

Mode Door Motor

The mode door motor is attached to the heater & cooling unit. It rotates so that air is discharged from the outlet set by the auto amp. Motor rotation is conveyed to a link which activates the mode door.



DIAGNOSIS PROCEDURE FOR MODE DOOR MOTOR

SYMPTOM: Mode door motor does not operate normally.

Perform diagnosis procedure. Refer to [ATC-66, "DIAGNOSIS PROCEDURE FOR LAN CIRCUIT"](#) .

TROUBLE DIAGNOSIS

NJS0008G


Air Mix Door Motor Circuit

SYMPTOM:

- Discharge air temperature does not change.
- Air mix door motor does not operate normally.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK


Temperature increase

- Turn the temperature dial clockwise until 32°C (90°F) is displayed.
- Check for hot air at discharge air outlets.

Temperature decrease

- Turn the temperature dial counterclockwise until 18°C (60°F) is displayed.
- Check for cold air at discharge air outlets.

**If OK (symptom cannot be duplicated), perform complete operational check (*9).
If NG (symptom is confirmed), continue with STEP-2 following.**



*1 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 1.

*4 [ATC-115, "Sunload Sensor Circuit"](#)

*7 [ATC-66, "LAN System Circuit"](#)

*10 [ATC-35, "SYMPTOM TABLE"](#)

*2 [ATC-110, "Ambient Sensor Circuit"](#)

*5 [ATC-75, "Air Mix Door Motor PBR Circuit"](#)

*8 [ATC-141, "AIR MIX DOOR MOTOR"](#)

*11 [ATC-118, "Intake Sensor Circuit"](#)

*3 [ATC-112, "In-Vehicle Sensor Circuit"](#)

*6 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.

*9 [ATC-62, "Operational Check"](#)

*12 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5 to 7.

RJA3199E

TROUBLE DIAGNOSIS

SYSTEM DESCRIPTION

Component Parts


Air mix door control system components are:

- Auto amp.
- Air mix door motor (LCU)
- A/C LAN system (PBR built-in mode door motor, air mix door motor and intake door motor)
- In-vehicle sensor
- Ambient sensor
- Sunload sensor
- Intake sensor


System Operation

The auto amp. receives data from each of the sensors. The auto amp. sends air mix door, mode door and intake door opening angle data to the air mix door motor LCU, mode door motor LCU and intake door motor LCU.

The air mix door motor, mode door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles. Subsequently, HOT/COLD, DEF/VENT and FRESH/RECIRCULATION operation is selected. The new selection data are returned to the auto amp.



Air Mix Door Control Specification





TROUBLE DIAGNOSIS

COMPONENT DESCRIPTION

Air Mix Door Motor

The air mix door motor is attached to the heater & cooling unit. It rotates so that the air mix door is opened or closed to a position set by the auto amp. Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the auto amp. by PBR built-in air mix door motor.



DIAGNOSIS PROCEDURE FOR AIR MIX DOOR MOTOR

SYMPTOM: Discharge air temperature does not change.

Perform diagnosis procedure. Refer to [ATC-66, "DIAGNOSIS PROCEDURE FOR LAN CIRCUIT"](#) .

Air Mix Door Motor PBR Circuit

NJS0008H

SYMPTOM: If PBR circuit is open or shorted. (26/-26 or 27/-27 is indicated on auto amp. as a result of conducting self-diagnosis STEP-2.)

DIAGNOSIS PROCEDURE FOR AIR MIX DOOR MOTOR PBR

Perform diagnosis procedure. Refer to [ATC-66, "DIAGNOSIS PROCEDURE FOR LAN CIRCUIT"](#) .

A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS

SYSTEM DESCRIPTION


Component Parts

Intake door control system components are:


- Auto amp.
- Intake door motor
- A/C LAN system (PBR built-in mode door motor, air mix door motor and intake door motor)
- In-vehicle sensor
- Ambient sensor
- Sunload sensor
- Intake sensor

System Operation

The intake door control determines intake door position based on the ambient temperature, the intake air temperature and the in-vehicle temperature. When the ECON, DEF and OFF switches are pressed, the auto amp. sets the intake door at the FRESH position.



Intake Door Control Specification



A
B
C
D
E
F
G
H
I
K
L
M


ATC

TROUBLE DIAGNOSIS

COMPONENT DESCRIPTION

Intake Door Motor

The intake door motor is attached to the blower unit. It rotates so that air is drawn from inlets set by the auto amp. Motor rotation is conveyed to a lever which activates the intake door.



DIAGNOSIS PROCEDURE FOR INTAKE DOOR MOTOR

SYMPTOM: Intake door motor does not operate normally.


Perform diagnosis procedure. Refer to [ATC-66, "DIAGNOSIS PROCEDURE FOR LAN CIRCUIT"](#) .

TROUBLE DIAGNOSIS

Rear Ventilator Door Motor Circuit COMPONENT DESCRIPTION


NJS0006J

Rear ventilator door motor is attached to the rear ventilator duct No. 1. Rear ventilator door is opened or closed by rear ventilator door motor.



DIAGNOSIS PROCEDURE FOR REAR VENTILATOR DOOR MOTOR

SYMPTOM: Rear ventilator door motor does not operate.




1. CHECK FOR AUTO AMP. OUTPUT

1. Disconnect rear ventilator door motor connector.
2. Set up code No. 41 and 42 in self-diagnosis STEP-4.
3. Check voltage between rear ventilator door motor harness connector M93 terminals 1, 2 and ground.

Terminals			Voltage
Code No.	Rear ventilator door motor connector	Terminal No.	
41	M93	1	Approx. 12 V
	M93	2	Approx. 0 V
42	M93	1	Approx. 0 V
	M93	2	Approx. 12 V

OK or NG

- OK >> Replace rear ventilator door motor.
NG >> GO TO 2.



A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS

2. CHECK CIRCUIT CONTINUITY BETWEEN REAR VENTILATOR DOOR MOTOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between rear ventilator door motor harness connector M93 terminals 1, 2 and auto amp. harness connector M119 terminals 6, 16.


1 – 6 : Continuity should exist.

2 – 16 : Continuity should exist.

OK or NG

OK >> Replace auto amp.

NG >> GO TO [ATC-80, "DIAGNOSIS PROCEDURE FOR REAR CONTROL SWITCH"](#).



Rear Control Switch Circuit DIAGNOSIS PROCEDURE FOR REAR CONTROL SWITCH

NJS0008K

SYMPTOM: Rear control switch does not operate.

1. CHECK MULTIPLEX COMMUNICATION ERROR

1. Set in self-diagnosis STEP-5. Refer to [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#).
2. Press intake switch.
3. Check multiplex communication error between rear control switch and auto amp.

OK or NG

OK >> GO TO [AV-47, "Rear Control Switch Does Not Operate"](#).

NG >> GO TO [ATC-123, "DIAGNOSIS PROCEDURE FOR MULTIPLEX COMMUNICATION CIRCUIT \(REAR CONTROL SWITCH\)"](#).

Rear Control Cancel Switch DIAGNOSIS PROCEDURE FOR REAR CONTROL CANCEL SWITCH

NJS000CK

SYMPTOM: Rear control switch does not operate.

Refer to [AV-47, "Rear Control Switch Does Not Operate"](#).


TROUBLE DIAGNOSIS

NJS0008L

Blower Motor Circuit

SYMPTOM: Blower motor operation is malfunctioning.

INSPECTION FLOW



A
B
C
D
E
F
G
H
I
K
L
M

ATC

*1 [ATC-62, "Operational Check"](#)

*2 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 1.

*3 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5.

*4 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 7.

*5 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.

*6 [ATC-81, "Blower Motor Circuit"](#)

*7 [ATC-110, "Ambient Sensor Circuit"](#)

*8 [ATC-112, "In-Vehicle Sensor Circuit"](#)

*9 [ATC-115, "Sunload Sensor Circuit"](#)

*10 [ATC-118, "Intake Sensor Circuit"](#)

*11 [ATC-35, "SYMPTOM TABLE"](#)

SJIA1136E

SYSTEM DESCRIPTION

Component Parts


Fan speed control system components are:

- Auto amp.

TROUBLE DIAGNOSIS

- A/C LAN system (PBR built-in mode door motor, air mix door motor and intake door motor)
- In-vehicle sensor
- Ambient sensor
- Sunload sensor
- Intake sensor

System Operation



Automatic Mode

In the automatic mode, the blower motor speed is calculated by the auto amp. based on the input from the PBR, in-vehicle sensor, sunload sensor, intake sensor and ambient sensor.

When the air flow is increased, the duty ratio of the blower fan motor's drive signal is changed at 8%/sec. to prevent a sudden increase in air flow.

In addition to manual air flow control and the usual automatic air flow control, starting air flow control, low water temperature starting control and high passenger compartment temperature starting control are available.

When the audio-recognition signal is input to the auto amp., the maximum fan speed is limited to the 3rd step. (Except DEF).

Starting Fan Speed Control

Start up from COLD SOAK Condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 56°C (133°F), the blower will not operate for a short period of time (up to 150 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient) the blower starting delay will be 150 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 56°C (133°F), at which time the blower speed will increase to the objective speed.

Start up from usual or HOT SOAK Condition (Automatic mode)

The blower will begin operation momentarily after the AUTO switch is pushed. The blower speed will gradually rise to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).


TROUBLE DIAGNOSIS

Blower Speed Compensation

Sunload

When the in-vehicle temperature and the set temperature are very close, the blower will be operating at low speed. The low speed will vary depending on the sunload. During conditions of low or no sunload, the blower speed is at duty ratio 25%. During high sunload conditions, the auto amp. raise the blower fan speed to increase.(duty ratio 49%).


Fan Speed Control Specification



COMPONENT DESCRIPTION


Brush-Less Motor

The blower motor utilizes a brush-less motor with a rotating magnet. Quietness is improved over previous motors where the brush was the point of contact and the coil rotated.



DIAGNOSIS PROCEDURE FOR BLOWER MOTOR

SYMPTOM: Blower motor operation is malfunctioning.



TROUBLE DIAGNOSIS

1. CHECK POWER SUPPLY FOR BLOWER MOTOR

1. Disconnect blower motor connector.
2. Turn ignition switch ON.
3. Check voltage between blower motor harness connector M112 terminal 4 and ground.


4 – Ground : **Battery voltage**

OK or NG

OK >> GO TO 2.

NG >> Check power supply circuit and 15 A fuses [Nos. 31 and 33, located in the fuse block (J/B) No. 2]. Refer to [PG-71, "FUSE BLOCK - JUNCTION BOX \(J/B\) NO. 2"](#).

- If fuse are OK, check harness for open circuit. Repair or replace if necessary.
- If fuse are NG, replace fuse and check harness for short circuit. Repair or replace if necessary.



2. CHECK GROUND CIRCUIT FOR BLOWER MOTOR


1. Turn ignition switch OFF.
2. Check continuity between blower motor harness connector M112 terminal 1 and ground.

1 – Ground : **Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



3. CHECK CIRCUIT CONTINUITY BLOWER MOTOR AND AUTO AMP.


1. Disconnect auto amp. connector.
2. Check continuity between blower motor harness connector M112 terminal 3 and auto amp. harness connector M120 terminal 35.

3 – 35 : **Continuity should exist.**

OK or NG

OK >> GO TO 4.


NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

4. CHECK FOR AUTO AMP. OUTPUT

1. Reconnect blower motor connector and check connector.
2. Turn ignition switch ON.
3. Change the fan speed from Lo to Hi, and check the duty ratios between blower motor harness connector M112 terminal 3 and ground by using an oscilloscope. Normal terminal 3 drive signal duty ratios are shown in the table below.



Blower fan speed	1st	2nd	3rd	4th	5th
Blower motor connector M112 Terminal No. 3 (Oscilloscope)					
Duty ratio	Approx. 25%	Approx. 37%	Approx. 51%	Approx. 65%	Approx. 91%

NOTE: Duty ratio = $\frac{T_x}{\text{Approx. } 1.6 \text{ ms}} \times 100 (\%)$

RJA0338E

OK or NG


- OK >> Replace blower motor after confirming the fun air flow does not change.
- NG >> Replace auto amp.

COMPONENT INSPECTION

Blower Motor

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the blower unit.



A
B
C
D
E
F
G
H
I
K
L
M

ATC


TROUBLE DIAGNOSIS

NJS0008M

Magnet Clutch Circuit

SYMPTOM: Magnet clutch does not engage.

INSPECTION FLOW



RJIA1912E

*1 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No .1.

*2 [ATC-110, "Ambient Sensor Circuit"](#)

*3 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.

*4 [ATC-87, "DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH"](#)

*5 [ATC-98, "TROUBLE DIAGNOSIS FOR UNUSUAL PRESSURE"](#)

*6 [ATC-62, "Operational Check"](#)

*7 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5 to 7.

*8 [ATC-35, "SYMPTOM TABLE"](#)

*9 [ATC-118, "Intake Sensor Circuit"](#)

TROUBLE DIAGNOSIS


SYSTEM DESCRIPTION

Auto amp. controls compressor operation by ambient temperature, intake air temperature and signal from ECM.


Low Temperature Protection Control

Auto amp. will turn compressor ON or OFF as determined by a signal detected by ambient sensor and intake sensor.

When ambient temperature is higher than -2°C (28°F), the compressor turns ON. The compressor turns OFF when ambient temperature is lower than -5°C (23°F).




When intake air temperature is higher than 1°C (34°F), the compressor turns ON. The compressor turns OFF when intake air temperature is lower than -5°C (23°F).



DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

SYMPTOM: Magnet clutch does not engage when AUTO switch is ON.



A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS


1. CHECK POWER SUPPLY FOR COMPRESSOR

1. Disconnect compressor connector.
2. Start engine and AUTO switch ON.
3. Check voltage between compressor (magnet clutch) harness connector F2 terminal 1 and ground.

1 – Ground : **Battery voltage**

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.




2. CHECK MAGNET CLUTCH CIRCUIT

Check for operation sound when applying battery voltage direct current to terminal.

OK or NG

- OK >> 1. Repair harness or connector.
2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation is normal.
- NG >> 1. Replace magnet clutch. Refer to [ATC-150, "Removal and Installation of Compressor Clutch"](#).
2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation is normal.




3. CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR

1. Turn ignition switch OFF.
2. Disconnect A/C relay.
3. Check continuity between compressor (magnet clutch) harness connector F2 terminal 1 and A/C relay harness connector E3-2 terminal 3.

1 – 3 : **Continuity should exist.**

OK or NG

- OK >> Check harness for short. And GO TO 4.
NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

4. CHECK POWER SUPPLY FOR A/C RELAY

Check voltage between A/C relay harness connector E3-2 terminals 2, 5 and ground.


2, 5 – Ground : **Battery voltage**

OK or NG

OK >> GO TO 5.

NG >> Check power supply circuit and 10 A fuse [No. 51 located in the fuse, fusible link and relay block (J/B)]. Refer to [PG-72, "FUSE, FUSIBLE LINK AND RELAY BLOCK \(J/B\)"](#).

- If fuse is OK, check harness for open circuit. Repair or replace if necessary.
- If fuse is NG, replace fuse and check harness for short circuit. Repair or replace if necessary.



5. CHECK A/C RELAY AFTER DISCONNECTING IT

Refer to [ATC-92, "A/C Relay"](#).

OK or NG

OK >> GO TO 6.

NG >> 1. Replace A/C relay.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation is usual.

6. CHECK COIL SIDE CIRCUIT OF A/C RELAY


1. Reconnect A/C relay.
2. Turn ignition switch OFF.
3. Check voltage between ECM harness connector F101 terminal 105 and ground.

105 – Ground : **Battery voltage**

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.



7. CHECK CIRCUIT CONTINUITY BETWEEN ECM AND A/C RELAY


1. Turn ignition switch OFF.
2. Disconnect A/C relay and ECM connector.
3. Check continuity between ECM harness connector F101 terminal 105 and A/C relay harness connector E3-2 terminal 1.

105 – 1 : **Continuity should exist.**

OK or NG

OK >> Replace A/C relay.

NG >> Repair harness or connector.




TROUBLE DIAGNOSIS

8. CHECK VOLTAGE FOR COMBINATION METER (FAN ON SIGNAL)

1. Turn ignition switch ON.
2. Check voltage between auto amp. harness connector M120 terminal 29 and ground.

Terminals		(-)	Condition	Voltage
(+) Auto amp. connector				
Auto amp. connector	Terminal No.			
M120	29	Ground	AUTO SW: ON (Blower motor operates.)	Approx. 0 V
			OFF SW: ON (A/C system: OFF)	Approx. 5 V




OK or NG

- OK >> GO TO 9.
NG >> GO TO 12.

9. CHECK VOLTAGE FOR COMBINATION METER (COMPRESSOR ON SIGNAL)

Check voltage between auto amp. harness connector M120 terminal 22 and ground.

Terminals		(-)	Condition	Voltage
(+) Auto amp. connector				
Auto amp. connector	Terminal No.			
M120	22	Ground	AUTO SW: ON (Blower motor operates.)	Approx. 0 V
			OFF SW: ON (A/C system: OFF)	Approx. 5 V




OK or NG

- OK >> GO TO 10.
NG >> GO TO 13.

10. CHECK VOLTAGE FOR ECM (COMPRESSOR FEEDBACK SIGNAL)

1. Start engine and AUTO switch ON.
2. Check voltage between auto amp. harness connector M119 terminal 18 and ground.

Terminals		(-)	Condition	Voltage
(+) Auto amp. connector				
Auto amp. connector	Terminal No.			
M119	18	Ground	AUTO SW: ON (Blower motor operates.)	Approx. 0 V
			AUTO SW: ON (When refrigerant pressure sensor connector is disconnected)	Approx. 5 V



OK or NG

- OK >> GO TO 11.
NG >> GO TO 14.

TROUBLE DIAGNOSIS

11. CHECK REFRIGERANT PRESSURE SENSOR CIRCUIT

Refer to [EC-744, "REFRIGERANT PRESSURE SENSOR"](#) .

OK or NG

- OK >> INSPECTION END
- NG >> Repair or replace the malfunctioning part(s).


12. CHECK CIRCUIT CONTINUITY BETWEEN ECM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect ECM connector and auto amp. connector.
3. Check continuity between ECM harness connector F101 terminal 96 and auto amp. harness connector M120 terminal 29.

96 – 29 : Continuity should exist.

OK or NG

- OK >> Replace auto amp.
- NG >> Repair harness or connector.




13. CHECK CIRCUIT CONTINUITY BETWEEN ECM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect ECM connector and auto amp. connector.
3. Check continuity between ECM harness connector F101 terminal 110 and auto amp. harness connector M120 terminal 22.

110 – 22 : Continuity should exist.

OK or NG

- OK >> Replace auto amp.
- NG >> Repair harness or connector.




14. CHECK CIRCUIT CONTINUITY BETWEEN ECM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect ECM connector and auto amp. connector.
3. Check continuity between ECM harness connector F101 terminal 30 and auto amp. harness connector M119 terminal 18.

30 – 18 : Continuity should exist.

OK or NG

- OK >> Check ECM.
- NG >> Repair harness or connector.



TROUBLE DIAGNOSIS


COMPONENT INSPECTION

A/C Relay

Check continuity between terminal Nos. 3 and 5.



Conditions	Continuity
12 V direct current supply between terminal Nos. 1 and 2	Yes
No current supply	No

If NG, replace relay.



Refrigerant Pressure Sensor

The refrigerant pressure sensor is attached to the condenser. Make sure that the A/C refrigerant pressure and the sensor output voltage are within the specified range as shown in the A/C operating condition figure. Refer to [EC-744, "REFRIGERANT PRESSURE SENSOR"](#).



TROUBLE DIAGNOSIS

NJS0008N

Insufficient Cooling


SYMPTOM: Insufficient cooling

INSPECTION FLOW

A
B
C
D
E
F
G
H
I
K
L
M

ATC


1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Temperature decrease

- Turn temperature dial counterclockwise until 18°C (60°F) is displayed.
- Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*10).
If NG (symptom is confirmed), continue with STEP-2 following.




SJIA1306E

TROUBLE DIAGNOSIS

- *1 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 1.
- *2 [ATC-73, "Air Mix Door Motor Circuit"](#)
- *3 [ATC-97, "Test Reading"](#)
- *4 [ATC-61, "AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER"](#)
- *5 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.
- *6 [ATC-66, "LAN System Circuit"](#)
- *7 [ATC-81, "Blower Motor Circuit"](#)
- *8 [ATC-86, "Magnet Clutch Circuit"](#)
- *9 [ATC-95, "PERFORMANCE TEST DIAGNOSIS"](#)
- *10 [ATC-62, "Operational Check"](#)
- *11 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5 to 7.
- *12 [ATC-6, "CONTAMINATED REFRIGERANT"](#)
- *13 [EM-14, "Checking Drive Belts"](#)
- *14 [EC-514, "SYSTEM DESCRIPTION"](#)

TROUBLE DIAGNOSIS

PERFORMANCE TEST DIAGNOSIS



Note: **A - F** correspond to those in TROUBLE DIAGNOSIS FOR UNUSUAL PRESSURE. (*3)


SJIA1226E

*1 [ATC-97, "PERFORMANCE CHART"](#) *2 [ATC-97, "PERFORMANCE CHART"](#) *3 [ATC-98, "TROUBLE DIAGNOSIS FOR UNUSUAL PRESSURE"](#)
 *4 [ATC-73, "Air Mix Door Motor Circuit"](#)

A
B
C
D
E
F
G
H
I
K
L
M

ATC

TROUBLE DIAGNOSIS



RJIA3107E

*1 [ATC-150, "Removal and Installation of Compressor Clutch"](#)

*2 [ATC-81, "Blower Motor Circuit"](#)

*3 [EM-14, "Checking Drive Belts"](#)

TROUBLE DIAGNOSIS

PERFORMANCE CHART

Test Condition

Testing must be performed as follows:

Vehicle location	Indoors or in the shade (in a well-ventilated place)
Doors	Closed
Door windows	Open
Hood	Open
TEMP.	Max. COLD
Mode switch	 (Ventilation) set
Intake switch	 (Recirculation) set
 Fan (blower) speed	Max. speed set
Engine speed	Idle speed

Operate the air conditioning system for 10 minutes before taking measurements.

Test Reading

Recirculating-to-discharge Air Temperature Table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	25 (77)	8.8 - 11.1 (48 - 52)
	30 (86)	12.2 - 15.1 (54 - 59)
	35 (95)	16.4 - 20.0 (62 - 68)
60 - 70	25 (77)	11.1 - 13.5 (52 - 56)
	30 (86)	15.1 - 18.0 (59 - 64)
	35 (95)	20.0 - 23.2 (68 - 74)

Ambient Air Temperature-to-operating Pressure Table


Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	30 (86)	1,360 - 1,660 (13.87 - 16.93, 197.2 - 240.7)	210 - 270 (2.14 - 2.75, 30.5 - 39.2)
	35 (95)	1,480 - 1,800 (15.10 - 18.36, 214.6 - 261.0)	250 - 320 (2.55 - 3.26, 36.3 - 46.4)
	40 (104)	1,900 - 2,080 (19.38 - 21.22, 275.5 - 301.6)	300 - 360 (3.06 - 3.67, 43.5 - 52.2)

TROUBLE DIAGNOSIS


TROUBLE DIAGNOSIS FOR UNUSUAL PRESSURE

Whenever system's high and/or low side pressure(s) is/are unusual, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (usual) pressure range. Since the standard (usual) pressure, however, differs from vehicle to vehicle, refer to above table (Ambient air temperature-to-operating pressure table).

Both High- and Low-pressure Sides are Too High


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too high.</p>  <p style="text-align: right; font-size: small;">AC359A</p>	Pressure is reduced soon after water is splashed on condenser.	Excessive refrigerant charge in refrigeration cycle.	Reduce refrigerant until specified pressure is obtained.
	Air suction by cooling fan is insufficient.	Insufficient condenser cooling performance. ↓ 1. Condenser fins are clogged. 2. Improper fan rotation of cooling fan.	<ul style="list-style-type: none"> ● Clean condenser. ● Check and repair cooling fan as necessary.
	<ul style="list-style-type: none"> ● Low-pressure pipe is not cold. ● When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	Poor heat exchange in condenser. (After compressor operation stops, high-pressure decreases too slowly.) ↓ Air in refrigeration cycle.	Evacuate repeatedly and recharge system.
	Engine tends to overheat.	Engine cooling systems malfunction.	Check and repair each engine cooling system.
	<ul style="list-style-type: none"> ● An area of the low-pressure pipe is colder than areas near the evaporator outlet. ● Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> ● Excessive liquid refrigerant on low-pressure side. ● Excessive refrigerant discharge flow. ● Expansion valve is open a little compared with the specification. ↓ <ul style="list-style-type: none"> ● Improper expansion valve adjustment. 	Replace expansion valve.

High-pressure Side is Too High and Low-pressure Side is Too Low


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p>  <p style="text-align: right; font-size: small;">AC360A</p>	Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.	High-pressure tube or parts located between compressor and condenser are clogged or crushed.	<ul style="list-style-type: none"> ● Check and repair or replace malfunctioning parts. ● Check lubricant for contamination.

TROUBLE DIAGNOSIS

High-pressure Side is Too Low and Low-pressure Side is Too High


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
High-pressure side is too low and low-pressure side is too high. 	High- and low-pressure sides become equal soon after compressor operation stops.	Compressor pressure operation is improper. ↓ Damaged inside compressor packings.	Replace compressor.
	No temperature difference between high- and low-pressure sides.	Compressor pressure operation is improper. ↓ Damaged inside compressor packings.	Replace compressor.

Both High- and Low-pressure Sides are Too Low


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
Both high- and low-pressure sides are too low. 	<ul style="list-style-type: none"> There is a big temperature difference between liquid tank outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. 	Liquid tank inside is slightly clogged.	<ul style="list-style-type: none"> Replace liquid tank. Check lubricant for contamination.
	<ul style="list-style-type: none"> Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high-pressure side. 	High-pressure pipe located between liquid tank and expansion valve is clogged.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	Expansion valve and liquid tank are warm or slightly cool when touched.	Low refrigerant charge. ↓ Leaking fittings or components.	Check refrigerant for leaks. Refer to ATC-161, "Checking for Refrigerant Leaks" .
	There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.	Expansion valve closes a little compared with the specification. ↓ <ol style="list-style-type: none"> Improper expansion valve adjustment. Malfunctioning expansion valve. Outlet and inlet may be clogged. 	<ul style="list-style-type: none"> Remove foreign particles by using compressed air. Replace expansion valve. Check lubricant for contamination.
	An area of the low-pressure pipe is colder than areas near the evaporator outlet.	Low-pressure pipe is clogged or crushed.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	Air flow volume is not enough or is too low.	Evaporator is frozen.	<ul style="list-style-type: none"> Check intake sensor circuit. Refer to ATC-118, "Intake Sensor Circuit". Replace compressor. Repair evaporator fins. Replace evaporator. Refer to ATC-81, "Blower Motor Circuit".

TROUBLE DIAGNOSIS

Low-pressure Side Sometimes Becomes Negative

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side sometimes becomes negative.</p> 	<ul style="list-style-type: none"> ● Air conditioning system does not function and does not cyclically cool the compartment air. ● The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p>↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p>↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> ● Drain water from refrigerant or replace refrigerant. ● Replace liquid tank.

Low-pressure Side Becomes Negative

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> 	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p>↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the malfunction is caused by water or foreign particles.</p> <ul style="list-style-type: none"> ● If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. ● If due to foreign particles, remove expansion valve and remove the particles with dry and compressed air (not shop air). ● If either of the above methods cannot correct the malfunction, replace expansion valve. ● Replace liquid tank. ● Check lubricant for contamination.

DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

SYMPTOM: Insufficient cooling

1. CHECK POWER SUPPLY FOR ECV (ELECTRONIC CONTROL VALVE)

1. Disconnect compressor (ECV) connector.
2. Turn ignition switch ON.
3. Check voltage between compressor (ECV) harness connector F6 terminal 2 and ground.

2 – Ground


: Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check power supply circuit and 10 A fuse [No. 2, located in the fuse block (J/B) No. 1]. Refer to [PG-70. "FUSE BLOCK - JUNCTION BOX \(J/B\) NO. 1"](#).


- If fuse is OK, check harness for open circuit. Repair or replace if necessary.
- If fuse is NG, replace fuse and check harness for short circuit. Repair or replace if necessary.



TROUBLE DIAGNOSIS

2. CHECK ECV CONTROL SIGNAL


1. Turn ignition switch OFF.
2. Reconnect compressor (ECV) connector.
3. Turn ignition switch ON.
4. Set in self-diagnosis STEP-4 (Code No. 42). Refer to [ATC-54](#), "[FUNCTION CONFIRMATION PROCEDURE](#)".



5. Confirm ECV control signal between auto amp. harness connector M120 terminal 23 and ground using an oscilloscope.

OK or NG

- OK >> Replace compressor.
 NG >> GO TO 3.




3. CHECK CIRCUIT CONTINUITY BETWEEN ECV AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect compressor (ECV) connector and auto amp. connector.
3. Check continuity between compressor (ECV) harness connector F6 terminal 3 and auto amp. harness connector M120 terminal 23.

3 – 23 : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness or connector.




4. CHECK ECV

- Check continuity between compressor (ECV) connector F6 terminals 2 and 3.

2 – 3 : Continuity should exist.

OK or NG

- OK >> Replace auto amp.
 NG >> Replace compressor.




TROUBLE DIAGNOSIS

NJS00080

Insufficient Heating

SYMPTOM: Insufficient heating

INSPECTION FLOW



SJIA1307E

*1 [ATC-62, "Operational Check"](#)

*2 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 1.

*3 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 5.

*4 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 7.

*5 [ATC-73, "Air Mix Door Motor Circuit"](#)

*6 [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#), see No. 14.

*7 [ATC-66, "LAN System Circuit"](#)

*8 [ATC-81, "Blower Motor Circuit"](#)

*9 Thermostat [CO-22, "Removal and Installation"](#).

*10 [CO-8, "Changing Engine Coolant"](#)

*11 [CO-12, "CHECKING RADIATOR CAP"](#)


TROUBLE DIAGNOSIS

NJS0008P

Noise

SYMPTOM: Noise

INSPECTION FLOW



A
B
C
D
E
F
G
H
I
J
K
L
M

ATC

*1 Compressor clutch, [ATC-150. "REMOVAL"](#) .

*2 Compressor clutch, [ATC-152. "INSTALLATION"](#) .

*3 [ATC-23. "Maintenance of Lubricant Quantity in Compressor"](#)

*4 [ATC-62. "Operational Check"](#)

*5 [EM-14. "Checking Drive Belts"](#)

RJIA3108E

TROUBLE DIAGNOSIS


NJS0008Q

Self-Diagnosis

SYMPTOM: Self-diagnosis cannot be performed.

INSPECTION FLOW


1. Confirm symptom by performing operational check.



OPERATIONAL CHECK – AUTO mode

- Press AUTO switch (driver side).
- Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (sound or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

**If OK (symptom cannot be duplicated), perform complete operational check (*7).
If NG (symptom is confirmed), continue with STEP-2 following.**



*1 [ATC-64, "Power Supply and Ground Circuit for Auto Amp."](#)

*2 [ATC-110, "Ambient Sensor Circuit"](#)

*3 [ATC-112, "In-Vehicle Sensor Circuit"](#)

*4 [ATC-115, "Sunload Sensor Circuit"](#)

*5 [ATC-118, "Intake Sensor Circuit"](#)

*6 [ATC-75, "Air Mix Door Motor PBR Circuit"](#)

*7 [ATC-62, "Operational Check"](#)

*8 [ATC-35, "SYMPTOM TABLE"](#)

RJIA1917E

TROUBLE DIAGNOSIS


NJS0008R

Memory Function

SYMPTOM: Memory function does not operate.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Memory function

- Set the temperature 32°C (90°F).
- Press OFF switch.
- Turn the ignition off.
- Turn the ignition on.
- Press the A/C switch.
- Confirm that the set temperature remains at previous temperature.
- Press OFF switch.

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis function confirmation procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

*1 [ATC-64. "Power Supply and Ground Circuit for Auto Amp."](#) *2 [ATC-62. "Operational Check"](#)

*3 [ATC-54. "FUNCTION CONFIRMATION PROCEDURE"](#)

SJIA1308E

A
B
C
D
E
F
G
H
I
ATC
K
L
M

TROUBLE DIAGNOSIS


NJS0008S

ECON (ECONOMY) MODE

SYMPTOM: ECON mode does not operate.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – ECON (ECONOMY) mode

- Set the temperature 25°C (75°F).
- Press ECON switch.
- Display should indicate ECON (not AUTO).
Confirm that the compressor clutch is not engaged (sound or visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle, and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis function confirmation procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

*1 [ATC-64. "Power Supply and Ground Circuit for Auto Amp."](#)

*2 [ATC-62. "Operational Check"](#)

*3 [ATC-54. "FUNCTION CONFIRMATION PROCEDURE"](#)

SJIA1309E

TROUBLE DIAGNOSIS

NJS0008T

A/C Display is Malfunctioning DIAGNOSIS PROCEDURE

SYMPTOM: A/C display is not shown.

1. CHECK CIRCUIT CONTINUITY BETWEEN AV AND NAVI C/U (AV C/U) AND AUTO AMP.

1. Disconnect auto amp. connector and AV and NAVI C/U (AV C/U) connector.
2. Check continuity between AV and NAVI C/U harness connector B29 terminals 37, 39 or AV C/U harness connector M77 terminals 44, 45 and ground.

37, 39 – Ground : Continuity should not exist.

44, 45 – Ground : Continuity should not exist.

3. Check continuity between AV and NAVI C/U harness connector B29 terminals 37, 39 or AV C/U harness connector M77 terminals 44, 45 and auto amp. harness connector M119 terminals 9, 20.



37, 44 – 9 : Continuity should exist.

39, 45 – 20 : Continuity should exist.

OK or NG

OK >> GO TO 2.

- NG >> ● Check harness between auto amp. and AV and NAVI C/U or AV C/U.
- Check connector housings for disconnected or loose terminals.



2. A/C-AV, AC-CLK COMMUNICATION SIGNAL CHECK

1. Reconnect auto amp. connector.
2. Turn the ignition switch ON.
3. Check voltage between AV and NAVI C/U harness connector B29 terminals 37, 39 or AV C/U harness connector M77 terminals 44, 45 and ground.


37, 39 – Ground : Approx. 3.5 V or more

44, 45 – Ground : Approx. 3.5 V or more

OK or NG

OK >> GO TO 3.

NG >> Replace auto amp.



A
B
C
D
E
F
G
H
I
K
L
M

ATC


TROUBLE DIAGNOSIS

3. A/C-NAV, AC-CLK COMMUNICATION SIGNAL CHECK

1. Turn ignition switch OFF.
2. Reconnect AV and NAVI C/U (AV C/U) connector.
3. Turn the ignition switch ON.
4. Check voltage between AV and NAVI C/U harness connector B29 terminals 37, 39 or AV C/U harness connector M77 terminals 44, 45 and ground.

37, 39 – Ground : [AV-97, "Terminals and Reference Value for AV and NAVI Control Unit"](#)

44, 45 – Ground : [DI-120, "Terminals and Reference Value for AV Control Unit"](#)



OK or NG

- OK >> Replace auto amp.
- NG >> Replace AV and NAVI C/U or AV C/U.

A/C Operation is Malfunctioning DIAGNOSIS PROCEDURE

NJS0008U

SYMPTOM: A/C operation is not possible.

1. CHECK CIRCUIT CONTINUITY BETWEEN AV AND NAVI C/U (AV C/U) AND AUTO AMP.

1. Disconnect auto amp. connector and AV and NAVI C/U (AV C/U) connector.
2. Check continuity between AV and NAVI C/U harness connector B29 terminals 38, 39 or AV C/U harness connector M77 terminals 43, 45 and ground.



38, 39 – Ground : **Continuity should not exist.**

43, 45 – Ground : **Continuity should not exist.**

3. Check continuity between AV and NAVI C/U harness connector B29 terminals 38, 39 or AV C/U harness connector M77 terminals 43, 45 and auto amp. harness connector M119 terminals 10, 20.

38, 43 – 10 : **Continuity should exist.**

39, 45 – 20 : **Continuity should exist.**



OK or NG

- OK >> GO TO 2.
- NG >>
 - Check harness for open or short between auto amp. and AV and NAVI C/U or AV C/U.
 - Check connector housings for disconnected or loose terminals.

TROUBLE DIAGNOSIS

2. AV-A/C, AC-CLK COMMUNICATION SIGNAL CHECK

1. Connect auto amp. connector.
2. Turn ignition switch ON.
3. Check voltage between AV and NAVI C/U harness connector B29 terminal 38 or AV C/U harness connector M77 terminal 43 and ground.


38 – Ground : Approx. 3.5 V or more

43 – Ground : Approx. 3.5 V or more

OK or NG

OK >> GO TO 3.

NG >> Replace auto amp.



3. AV-A/C, AC-CLK COMMUNICATION SIGNAL CHECK

1. Turn ignition switch OFF.
2. Reconnect AV and NAVI C/U (AV C/U) connector.
3. Turn the ignition switch ON.
4. Check voltage between AV and NAVI C/U harness connector B29 terminals 38, 39 or AV C/U harness connector M77 terminals 43, 45 and ground.


38, 39 – Ground : AV-97, "Terminals and Reference Value for AV and NAVI Control Unit"

43, 45 – Ground : DI-120, "Terminals and Reference Value for AV Control Unit"

OK or NG

OK >> Replace auto amp.

NG >> Replace AV and NAVI C/U or AV C/U.



A
B
C
D
E
F
G
H
I
K
L
M

ATC


TROUBLE DIAGNOSIS

NJS0008V

Ambient Sensor Circuit COMPONENT DESCRIPTION

Ambient Sensor

The ambient sensor is attached on the hood lock stay. It detects ambient temperature and converts it into a resistance value which is then input into the auto amp.




AMBIENT TEMPERATURE INPUT PROCESS

The auto amp. includes a processing circuit for the ambient sensor input. However, when the temperature detected by the ambient sensor increases quickly, the processing circuit retards the auto amp. function. It only allows the auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds. As an example, consider stopping for a few minutes after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the ambient sensor will increase. This is because the heat from the engine compartment can radiate to the front grille area, location of the ambient sensor.

DIAGNOSIS PROCEDURE FOR AMBIENT SENSOR

SYMPTOM: Ambient sensor circuit is open or shorted. (21 or -21 is indicated on auto amp. as a result of performing self-diagnosis STEP-2.)




1. CHECK VOLTAGE BETWEEN AMBIENT SENSOR AND GROUND

1. Disconnect ambient sensor connector.
2. Turn ignition switch ON.
3. Check voltage between ambient sensor harness connector E58 terminal 1 and ground.

1 – Ground : **Approx. 5 V**

OK or NG

- OK >> GO TO 2.
- NG >> GO TO 4.



TROUBLE DIAGNOSIS

2. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND AUTO AMP.


1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between ambient sensor harness connector E58 terminal 2 and auto amp. harness connector M119 terminal 11.

2 – 11 : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



3. CHECK AMBIENT SENSOR

Refer to [ATC-112, "Ambient Sensor"](#) .

OK or NG

OK >> 1. Replace auto amp.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

NG >> 1. Replace ambient sensor.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

4. CHECK CIRCUIT CONTINUITY BETWEEN AMBIENT SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between ambient sensor harness connector E58 terminal 1 and auto amp. harness connector M119 terminal 2.

1 – 2 : Continuity should exist.

4. Check continuity between auto amp. harness connector M119 terminal 2 and ground.


2 – Ground : Continuity should not exist.

OK or NG

OK >> 1. Replace auto amp.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

COMPONENT INSPECTION

Ambient Sensor

After disconnecting ambient sensor connector E58, measure resistance between terminals 1 and 2 at sensor side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace ambient sensor.


In-Vehicle Sensor Circuit COMPONENT DESCRIPTION

In-vehicle Sensor



The in-vehicle sensor is located on instrument lower driver panel. It converts variations in temperature of compartment air drawn from the aspirator into a resistance value. It is then input into the auto amp.

Aspirator


The aspirator is located on driver's side of heater & cooling unit. It produces vacuum pressure due to air discharged from the heater & cooling unit, continuously taking compartment air in the aspirator.



NJS0008W




TROUBLE DIAGNOSIS



A
B
C
D

DIAGNOSIS PROCEDURE FOR IN-VEHICLE SENSOR

SYMPTOM: In-vehicle sensor circuit is open or shorted. (22 or -22 is indicated on auto amp. as a result of performing self-diagnosis STEP-2.)



E
F
G


1. CHECK VOLTAGE BETWEEN IN-VEHICLE SENSOR AND GROUND

1. Disconnect in-vehicle sensor connector.
2. Turn ignition switch ON.
3. Check voltage between in-vehicle sensor harness connector M68 terminal 2 and ground.

2 – Ground : Approx. 5 V

OK or NG

- OK >> GO TO 2.
NG >> GO TO 4.



ATC

K


2. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector M68 terminal 1 and auto amp. harness connector M119 terminal 11.

1 – 11 : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness or connector.



L

M

TROUBLE DIAGNOSIS

3. CHECK IN-VEHICLE SENSOR

Refer to [ATC-114, "In-vehicle Sensor"](#) .

OK or NG

- OK >> 1. Replace auto amp.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
- NG >> 1. Replace in-vehicle sensor.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.


4. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

- Turn ignition switch OFF.
- Disconnect auto amp. connector.
- Check continuity between in-vehicle sensor harness connector M68 terminal 2 and auto amp. harness connector M119 terminal 3.

2 – 3 : Continuity should exist.

- Check continuity between auto amp. harness connector M119 terminal 3 and ground.

3 – Ground : Continuity should not exist.



OK or NG

- OK >> 1. Replace auto amp.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
- NG >> Repair harness or connector.


COMPONENT INSPECTION

In-vehicle Sensor

After disconnecting in-vehicle sensor connector M68, measure resistance between terminals 1 and 2 at sensor side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace in-vehicle sensor.




TROUBLE DIAGNOSIS

Sunload Sensor Circuit COMPONENT DESCRIPTION

NJS0008X

Sunload Sensor

The sunload sensor is located on the left defroster grille. It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the auto amp.




SUNLOAD INPUT PROCESS

The auto amp. also includes a processing circuit which averages the variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.

DIAGNOSIS PROCEDURE FOR SUNLOAD SENSOR

SYMPTOM: Sunload sensor circuit is open or shorted. (25 or -25 is indicated on auto amp. as a result of performing self-diagnosis STEP-2.)




1. CHECK VOLTAGE BETWEEN SUNLOAD SENSOR AND GROUND

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector M44 terminal 1 and ground.

1 – Ground : Approx. 5 V

OK or NG

- OK >> GO TO 2.
NG >> GO TO 4.



TROUBLE DIAGNOSIS

2. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.


1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between sunload sensor harness connector M44 terminal 2 and auto amp. harness connector M119 terminal 11.

2 – 11 : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



3. CHECK SUNLOAD SENSOR.

1. Reconnect sunload sensor connector and auto amp. connector.
2. Refer to [ATC-117, "Sunload Sensor"](#).

OK or NG

OK >> 1. Replace auto amp.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

NG >> 1. Replace sunload sensor.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

4. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between sunload sensor harness connector M44 terminal 1 and auto amp. harness connector M119 terminal 12.

1 – 12 : Continuity should exist.

4. Check continuity between auto amp. harness connector M119 terminal 12 and ground.


12 – Ground : Continuity should not exist.

OK or NG

OK >> 1. Replace auto amp.

2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

NG >> Repair harness or connector.




TROUBLE DIAGNOSIS


COMPONENT INSPECTION

Sunload Sensor

Measure voltage between auto amp. harness connector M119 terminal 12 and ground.



- When checking sunload sensor, select a place where sun shines directly on it.



If NG, replace sunload sensor.


TROUBLE DIAGNOSIS

NJS0008Y

Intake Sensor Circuit COMPONENT DESCRIPTION


Intake Sensor

The intake sensor is located on the heater & cooling unit. It converts temperature of air after it passes through the evaporator into a resistance value which is then input to the auto amp.



DIAGNOSIS PROCEDURE FOR INTAKE SENSOR

SYMPTOM: Intake sensor circuit is open or shorted. (24 or -24 is indicated on auto amp. as a result of performing self-diagnosis STEP-2.)




1. CHECK VOLTAGE BETWEEN INTAKE SENSOR AND GROUND

1. Disconnect intake sensor connector.
2. Turn ignition switch ON.
3. Check voltage between intake sensor harness connector M90 terminal 32 and ground.

32 – Ground : Approx. 5 V

OK or NG

- OK >> GO TO 2.
NG >> GO TO 4.




2. CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between intake sensor harness connector M90 terminal 36 and auto amp. harness connector M119 terminal 11.

36 – 11 : Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

3. CHECK INTAKE SENSOR


Refer to [ATC-119, "Intake Sensor"](#) .

OK or NG

- OK** >> 1. Replace auto amp.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
- NG** >> 1. Replace intake sensor.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

4. CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

- Turn ignition switch OFF.
- Disconnect auto amp. connector.
- Check continuity between intake sensor harness connector M90 terminal 32 and auto amp. harness connector M119 terminal 1.
32 – 1 : Continuity should exist.
- Check continuity between auto amp. connector M119 terminal 1 and ground.
1 – Ground : continuity should not exist.



OK or NG

- OK** >> 1. Replace auto amp.
 2. Go to self-diagnosis [ATC-54, "FUNCTION CONFIRMATION PROCEDURE"](#) and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
- NG** >> Repair harness or connector.


COMPONENT INSPECTION

Intake Sensor

After disconnecting intake sensor connector M90, measure resistance between terminals 32 and 36 at sensor side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.34
-10 (14)	9.62
-5 (23)	7.56
0 (32)	6.00
5 (41)	4.80
10 (50)	3.87
15 (59)	3.15
20 (68)	2.57
25 (77)	2.12
30 (86)	1.76
35 (95)	1.47
40 (104)	1.23
45 (113)	1.04

If NG, replace intake sensor.



TROUBLE DIAGNOSIS

NJS0008Z

Multiplex Communication Circuit



DIAGNOSIS PROCEDURE FOR MULTIPLEX COMMUNICATION CIRCUIT (FRONT CONTROLLER)


SYMPTOM:

- A/C system does not come on.
- A/C system cannot be controlled.

1. CHECK FOR AUTO AMP. OUTPUT

1. Turn ignition switch ON.
2. Confirm multiplex communication signal between auto amp. harness connector M119 terminal 9, 20 and ground using an oscilloscope.

Terminals		Voltage
(+)	(-)	
Auto amp. connector	Terminal No.	
M119	9	 <p>RJIA0212E</p>
	20	 <p>HAK0363D</p>
	Ground	




OK or NG

- OK >> GO TO 2
 NG >> Replace auto amp.

TROUBLE DIAGNOSIS

2. CHECK CIRCUIT CONTINUITY BETWEEN AV AND NAVI C/U (AV C/U) AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI C/U (AV C/U) connector and auto amp. connector.
3. Check continuity between AV and NAVI C/U harness connector B29 terminals 37, 39 or AV C/U harness connector M77 terminals 44, 45 and auto amp. harness connector M119 terminals 9, 20.



	Terminals				Continuity
	AV C/U or AV and NAVI C/U connector	Terminal No.	Auto amp. connector	Terminal No.	
AV C/U	M77	44	M119	9	Yes
	M77	45	M119	20	
AV and NAVI C/U	B29	37	M119	9	
	B29	39	M119	20	


OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK FOR AUTO AMP. INPUT

1. Reconnect AV and NAVI C/U (AV C/U) connector and auto amp. connector.
2. Turn ignition switch ON.
3. Confirm multiplex communication signal between auto amp. harness connector M119 terminal 10 and ground using an oscilloscope.



Terminals			Voltage
Auto amp. connector	(+) Terminal No.	(-) Terminal No.	
M119	10	Ground	

OK or NG


OK >> INSPECTION END

NG >> GO TO 4.

TROUBLE DIAGNOSIS

4. CHECK CIRCUIT CONTINUITY BETWEEN AV AND NAVI C/U (AV C/U) AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI C/U (AV C/U) connector and auto amp. connector.
3. Check continuity between AV and NAVI C/U harness connector B29 terminal 38 or AV C/U harness connector M77 terminal 43 and auto amp. harness connector M119 terminal 10.



38 – 10 : Continuity should exist.

43 – 10 : Continuity should exist.

OK or NG

- OK >> Replace auto amp.
- NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

DIAGNOSIS PROCEDURE FOR MULTIPLEX COMMUNICATION CIRCUIT (REAR CONTROL SWITCH)

SYMPTOM: Rear control switch A/C operation does not work.

1. CHECK FOR AUTO AMP. OUTPUT

1. Turn ignition switch ON.
2. Confirm multiplex communication signal between auto amp. harness connector M120 terminal 30, 31 and ground using an oscilloscope.



OK or NG

- OK >> GO TO 2
 NG >> Replace auto amp.


2. CHECK CIRCUIT CONTINUITY BETWEEN REAR CONTROL SWITCH AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect rear control switch connector and auto amp. connector.
3. Check continuity between rear control switch harness connector B502 terminals 3, 4 and auto amp. harness connector M120 terminals 30, 31.

- 3 – 30 : Continuity should exist.**
4 – 31 : Continuity should exist.

OK or NG


- OK >> GO TO 3.
 NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

3. CHECK FOR AUTO AMP. INPUT

1. Reconnect rear control switch connector and auto amp. connector.
2. Turn ignition switch ON.
3. Confirm multiplex communication signal between auto amp. harness connector M119 terminal 15 and ground using an oscilloscope.



Terminals		Voltage
(+)	(-)	
Auto amp. connector	Terminal No.	
M119	15	Ground

OK or NG

- OK >> INSPECTION END
 NG >> GO TO 4.


4. CHECK CIRCUIT CONTINUITY BETWEEN REAR CONTROL SWITCH AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect rear control switch connector and auto amp. connector.
3. Check continuity between rear control switch harness connector B502 terminal 11 and auto amp. harness connector M119 terminal 15.

11-15 : Continuity should exist.

OK or NG

- OK >> Replace rear control switch.
 NG >> Repair harness or connector.



CONTROLLER

CONTROLLER

PFP:27500

Removal and Installation of Multifunction Switch REMOVAL

NJS000CL

Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .

INSTALLATION

Installation is basically the reverse order of removal.

Removal and Installation of Rear Control Switch REMOVAL

NJS000CM

Refer to [AV-55, "Removal and Installation of Rear Control Switch"](#) .

INSTALLATION

Installation is basically the reverse order of removal.

Removal and Installation of Rear Control Cancel Switch REMOVAL

NJS000CN

Refer to [AV-55, "Removal and Installation of Rear Control Cancel Switch"](#) .

INSTALLATION

Installation is basically the reverse order of removal.

A

B

C

D

E

F

G

H

I

ATC

K

L

M

AMBIENT SENSOR

AMBIENT SENSOR


PFP:27722

Removal and Installation

NJS00091

REMOVAL

1. Remove front grille. Refer to [EI-21, "FRONT GRILLE"](#) .
2. Disconnect ambient sensor connector, and then remove ambient sensor.



INSTALLATION

Installation is basically the reverse order of removal.

IN-VEHICLE SENSOR

IN-VEHICLE SENSOR


PFP:27720

Removal and Installation

NJS00092

REMOVAL

1. Remove instrument lower driver panel. Refer to [IP-10, "Removal and Installation"](#).
2. Disconnect in-vehicle sensor connector and aspirator duct.
3. Remove mounting screw, and then remove in-vehicle sensor.



INSTALLATION

Installation is basically the reverse order of removal.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

SUNLOAD SENSOR

SUNLOAD SENSOR


PFP:27721

Removal and Installation

NJS00093

REMOVAL

1. Remove sunload sensor garnish.
2. Disconnect sunload sensor connector, and then remove sunload sensor.



INSTALLATION

Installation is basically the reverse order of removal.

INTAKE SENSOR

INTAKE SENSOR


PFP:27723

Removal and Installation

NJS00094

REMOVAL

1. Remove heater & cooling unit assembly. Refer to [ATC-135, "HEATER & COOLING UNIT ASSEMBLY"](#) .
2. Remove evaporator from heater & cooling unit assembly.
3. Separate heater & cooling unit case.
4. Remove intake sensor.



INSTALLATION

Installation is basically the reverse order of removal.

- Mark mounting position of intake sensor bracket prior to removal so that the reinstalled sensor can be located in the same position.
- When recharging refrigerant, check for leaks.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

BLOWER UNIT

PF27200


NJS00095

BLOWER UNIT

Removal and Installation

REMOVAL


1. Remove glove box assembly. Refer to [IP-10, "Removal and Installation"](#) .
2. Remove glove box cover, instrument lower cover and instrument panel bracket. Refer to [IP-10, "Removal and Installation"](#) .
3. Remove audio unit. Refer to [AV-52, "Removal and Installation of Audio Unit"](#) .
4. Disconnect blower motor connector, intake door motor connector and auto amp. connector.
5. Remove ECM with bracket attached.
6. Remove blower unit mounting screws.



7. Remove blower unit.

CAUTION:

Move blower unit rightward, and remove locating pins (2 parts) and joint. Then remove blower unit downward.



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

Make sure locating pins (2 parts) are securely installed.

NOTE:


When attaching the blower unit, the work will be easier if the blower motor is removed first.

BLOWER UNIT

Disassembly and Assembly

NJS00096

A
B
C
D
E
F
G
H
I
K
L
M



- | | | |
|--------------------------|-----------------------------|----------------------------|
| 1. Blower motor assembly | 2. Screw | 3. Lower case |
| 4. Screw | 5. Bell mouth | 6. Screw |
| 7. Clamp | 8. Screw | 9. Intake door lever No. 1 |
| 10. Intake door motor | 11. Screw | 12. Auto amp. |
| 13. Screw | 14. Intake door lever No. 2 | 15. Intake door link |
| 16. Screw | 17. Filter cover | 18. In-cabin microfilter |
| 19. Intake door No. 2 | 20. Upper case | 21. Intake door No. 1 |

ATC

BLOWER MOTOR

BLOWER MOTOR


PFP:27226

Removal and Installation

NJS00097

REMOVAL

1. Remove glove box cover and instrument lower cover. Refer to [IP-10, "Removal and Installation"](#).
2. Disconnect blower motor connector.
3. Remove mounting screws, and then remove blower motor.



INSTALLATION

Installation is basically the reverse order of removal.

INTAKE DOOR MOTOR

INTAKE DOOR MOTOR


PF2:27730

Removal and Installation

NJS00098

REMOVAL

1. Remove instrument lower cover and instrument panel bracket. Refer to [IP-10, "Removal and Installation"](#).
2. Remove ECM with bracket attached.
3. Disconnect intake door motor connector.
4. Remove mounting screws, and then remove intake door motor from blower unit.



INSTALLATION

Installation is basically the reverse order of removal.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

IN-CABIN MICROFILTER


IN-CABIN MICROFILTER

PFP:27277

Removal and Installation FUNCTION

NJS00099

Air inside passenger compartment is kept clean at either recirculation or fresh mode by installing in-cabin microfilter into blower unit.



REPLACEMENT TIMING


Replace in-cabin microfilter.

Refer to [MA-7, "CHASSIS AND BODY MAINTENANCE"](#) in Schedule 1 and [MA-9, "CHASSIS AND BODY MAINTENANCE"](#) in Schedule 2.


Caution label is fixed inside glove box.

REPLACEMENT PROCEDURES

1. Remove glove box assembly. Refer to [IP-10, "Removal and Installation"](#).
2. Remove center cover of glove box cover.



3. Remove filter cover.
4. Take out in-cabin microfilter from blower unit.
5. Replace with new one and reinstall on blower unit.
6. Reinstall glove box assembly.



HEATER & COOLING UNIT ASSEMBLY

HEATER & COOLING UNIT ASSEMBLY

PF27110

Removal and Installation


NJS0009A

REMOVAL


1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#) and [EM-17, "AIR CLEANER AND AIR DUCT"](#) .
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Remove tower bar. Refer to [FSU-5, "FRONT SUSPENSION ASSEMBLY"](#) .
4. Drain coolant from cooling system. Refer to [CO-8, "Changing Engine Coolant"](#) .
5. Disconnect two heater hoses from heater core pipe.
6. Disconnect low-pressure flexible hose and high-pressure pipe from evaporator.

CAUTION:


Cap or wrap the joint of the pipe with a suitable material such as vinyl tape to avoid the entry of air.



7. Remove instrument panel and pad assembly. Refer to [IP-10, "Removal and Installation"](#) .
8. Remove blower unit. Refer to [ATC-130, "BLOWER UNIT"](#) .
9. Remove clips of vehicle harness from steering member.
10. Remove mounting nuts, and then remove instrument stays (driver side, passenger side).
11. Remove center defroster nozzle and ventilator ducts. Refer to [ATC-144, "Removal of Center Defroster Nozzle, Duct and Ventilator Duct"](#) .



12. Remove mounting bolts from heater & cooling unit assembly.




A
B
C
D
E
F
G
H
I
K
L
M

ATC

HEATER & COOLING UNIT ASSEMBLY

13. Remove mounting bolts, and then remove steering member.



14. Remove heater & cooling unit assembly.

INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of low-pressure flexible hose and high-pressure pipe with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.

NOTE:


- When filling radiator with coolant, refer to [CO-8, "Changing Engine Coolant"](#).
- Recharge the refrigerant.

HEATER & COOLING UNIT ASSEMBLY

Disassembly and Assembly

NJS0009B

A
B
C
D
E
F
G
H
I
K
L
M



ATC

HEATER & COOLING UNIT ASSEMBLY

- | | | |
|---|--|---|
| 1. Foot duct (right) | 2. Screw | 3. Heater core |
| 4. Aspirator | 5. Aspirator duct | 6. Mode door motor (passenger side) |
| 7. Air mix door motor (passenger side) | 8. Ventilator door lever (right) | 9. Bi-level door lever (right) |
| 10. Bi-level door (right) | 11. Air mix door (right) | 12. Sub harness |
| 13. Expansion valve | 14. Bolt | 15. Expansion valve cover |
| 16. Cooler grommet | 17. Heater & cooling unit case (lower) | 18. Intake sensor |
| 19. Side link (left) | 20. Mode door motor (driver side) | 21. Mode door motor bracket (left) |
| 22. Ventilator door lever (left) | 23. Foot door link (left) | 24. Foot door lever (left) |
| 25. Evaporator cover | 26. Foot duct (left) | 27. Evaporator |
| 28. Side link (right) | 29. Heater pipe bracket | 30. Mode door motor bracket (right) |
| 31. Air mix door lever (right) | 32. Rod holder | 33. Rod |
| 34. Ventilator door (right) | 35. Bi-level door (left) | 36. Air mix door (left) |
| 37. Air mix door lever (left) | 38. Air mix door motor (driver side) | 39. Bi-level door lever (left) |
| 40. Heater & cooling unit case (driver side) | 41. Foot door (left) | 42. Foot door (right) |
| 43. Foot door lever (right) | 44. Foot door link (right) | 45. Defroster door lever (right) |
| 46. Heater & cooling unit case (passenger side) | 47. Ventilator door (left) | 48. Heater & cooling unit case (center) |
| 49. Defroster door | | |

HEATER CORE


HEATER CORE

PPF:27140

Removal and Installation

NJS0009C

1. Remove heater & cooling unit assembly. Refer to [ATC-135, "HEATER & COOLING UNIT ASSEMBLY"](#).
2. Remove mounting screw, and then remove foot duct (right).



3. Remove heater core from heater & cooling unit assembly.

INSTALLATION

Installation is basically the reverse order of removal.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

MODE DOOR MOTOR

MODE DOOR MOTOR

PFP:27731


Removal and Installation

NJS0009D

REMOVAL


Driver Side

1. Remove instrument lower driver panel. Refer to [IP-10, "Removal and Installation"](#) .
2. Remove ventilator duct. Refer to [ATC-144, "Removal of Center Defroster Nozzle, Duct and Ventilator Duct"](#) .
3. Disconnect mode door motor connector.
4. Remove mounting screws, and then remove mode door motor.



Passenger Side

1. Remove blower unit. Refer to [ATC-130, "BLOWER UNIT"](#) .
2. Disconnect mode door motor connector.
3. Remove mounting screws, and then remove mode door motor.



INSTALLATION

Installation is basically the reverse order of removal.

AIR MIX DOOR MOTOR

PFJ:27732


AIR MIX DOOR MOTOR

Removal and Installation

NJS0009E


Driver Side

1. Remove instrument lower driver panel. Refer to [IP-10, "Removal and Installation"](#).
2. Remove air mix door rod from rod holder.
3. Disconnect air mix door motor connector.
4. Remove mounting screws, and then remove air mix door motor.



Passenger Side

1. Remove blower unit. Refer to [ATC-130, "BLOWER UNIT"](#).
2. Remove air mix door rod from rod holder.
3. Disconnect air mix door motor connector.
4. Remove mounting screws, and then remove air mix door motor.



INSTALLATION

Installation is basically the reverse order of removal.

A
B
C
D
E
F
G
H
I
K
L
M

ATC

REAR VENTILATOR DOOR MOTOR


PFP:27141

REAR VENTILATOR DOOR MOTOR

Removal and Installation

NJS009F

1. Remove rear ventilator duct No. 1. Refer to [ATC-145, "Removal of Rear Ventilator Ducts"](#).



- | | | |
|--|-------------------------------|---|
| 1. Rear ventilator duct No. 1 (front side) | 2. Rear ventilator door lever | 3. Screw |
| 4. Rear ventilator door motor bracket | 5. Rear ventilator door motor | 6. Rear ventilator duct No. 1 (rear side) |
| 7. Rear ventilator door | | |

2. Remove mounting screws, and then remove rear ventilator door motor bracket.
3. Remove mounting screws, and then remove rear ventilator door motor.

INSTALLATION

Installation is basically the reverse order of removal.


DUCTS AND GRILLES

DUCTS AND GRILLES

PF2:27860

Removal and Installation REMOVAL


NJS0009G



- | | | |
|------------------------------------|-------------------------------------|-----------------------------------|
| 1. Side defroster duct (right) | 2. Center defroster nozzle | 3. Side defroster duct (left) |
| 4. Side ventilator duct (left) | 5. Instrument panel | 6. Side ventilator grille (left) |
| 7. Center ventilator grille (left) | 8. Center ventilator grille (right) | 9. Side ventilator grille (right) |
| 10. Side ventilator duct (right) | 11. Ventilator duct | |


Removal of Center Ventilator Grilles

1. Remove cluster lid C. Refer to [IP-10, "Removal and Installation"](#).
2. Remove mounting screw and clips, and then remove center ventilator grilles (left and right).



Removal of Side Ventilator Grilles

1. Remove instrument finisher. Refer to [IP-10, "Removal and Installation"](#).
2. Remove mounting screw and clips, and then remove side ventilator grille (right).
3. Remove instrument lower driver panel. Refer to [IP-10, "Removal and Installation"](#).
4. Remove mounting screw and clips, and then remove side ventilator grille (left).




A
B
C
D
E
F
G
H
I
ATC
K
L
M

DUCTS AND GRILLES


Removal of Rear Ventilator Grille

1. Remove console rear cover. Refer to [IP-10, "Removal and Installation"](#) .
2. Remove mounting screws, and then remove rear ventilator grille.



Removal of Center Defroster Nozzle, Duct and Ventilator Duct

1. Remove instrument panel and pad assembly. Refer to [IP-10, "Removal and Installation"](#) .
2. Remove harness clip.




3. Remove mounting clips, and then remove side defroster ducts (left and right).
4. Remove mounting screws, and then remove center defroster nozzle.
5. Remove mounting screw, and then remove side ventilator ducts (left and right).
6. Remove mounting screws, and then remove ventilator duct.


DUCTS AND GRILLES

Removal of Rear Ventilator Ducts

1. Remove console box assembly. Refer to [IP-10, "Removal and Installation"](#) .
2. Remove mounting screws, and then remove rear ventilator duct No. 2.
3. Remove instrument panel and pad assembly. Refer to [IP-10, "Removal and Installation"](#) .




4. Remove mounting screws, and then remove rear ventilator duct No. 1 (rear side).
5. Disconnect rear ventilator door motor connector.
6. Remove rear ventilator duct No. 1 (front side).




Removal of Foot Ducts

1. Remove heater & cooling unit assembly. Refer to [ATC-135, "HEATER & COOLING UNIT ASSEMBLY"](#) .
2. Remove mounting screws, and then remove foot duct (right).
3. Remove aspirator from heater & cooling unit assembly.
4. Remove mounting screws, and then remove foot duct (left).



Removal of Floor Duct

1. Remove front seats and console box assembly. Refer to [SE-182, "FRONT SEAT"](#) and [IP-10, "Removal and Installation"](#) .
2. Peel back floor trim to a point where floor duct is visible.
3. Remove floor duct No. 2 (left and right).
4. Remove mounting screw, and then remove floor duct No. 1 (left and right).



INSTALLATION

Installation is basically the reverse order of removal.

REFRIGERANT LINES

REFRIGERANT LINES

PFP:92600


HFC-134a (R-134a) Service Procedure SETTING OF SERVICE TOOLS AND EQUIPMENT

NJS0009H


Discharging Refrigerant

WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from A/C system using certified service equipment meeting requirements of SAE J-2210 [HFC-134a (R-134a) recycling equipment] or J-2209 [HFC-134a (R-134a) recovery equipment]. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.




Evacuating System and Charging Refrigerant



REFRIGERANT LINES

A
B
C
D
E
F
G
H
I
K
L
M

ATC



*1 [ATC-23, "LUBRICANT RETURN OPERATION"](#)
 *4 [ATC-95, "PERFORMANCE TEST DIAGNOSIS"](#)

*2 [ATC-161, "Checking for Refrigerant Leaks"](#)
 *5 [ATC-6, "CONTAMINATED REFRIGERANT"](#)

*3 [ATC-163, "CHECKING PROCEDURE"](#)

SJIA1275E



REFRIGERANT LINES

NJS0009I

Components

Refer to [ATC-6, "Precautions for Refrigerant Connection"](#).

SEC. 270•271•274•276



- : Refrigerant leak checking point
- : Tightening torque
- □ : Wrench size
- : O-ring size
- ⊕ : N•m (kg-m, ft-lb)
- A** : 13.7 (1.4, 10)
- ⊕ : N•m (kg-m, in-lb)
- B** : 4.4 (0.45, 39)
- C** : 5.7 (0.58, 50)

SJIA1358E


REFRIGERANT LINES

Removal and Installation of Compressor


NJS0009J

REMOVAL


A
B
C
D
E
F
G
H
I
K
L
M



1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#).
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Remove engine under cover, using power tools.
4. Remove air cleaner assembly, air duct and air inlet pipe. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#).
5. Remove compressor-alternator belt. Refer to [EM-14, "DRIVE BELTS"](#).



6. Remove mounting nuts from both high-pressure flexible hose and low-pressure flexible hose.
CAUTION:
Cap or wrap the joint of the pipe with a suitable material such as vinyl tape to avoid the entry of air.
7. Disconnect compressor connectors (magnet clutch and ECV).
8. Remove mounting bolt from radiator pipe bracket.
9. Remove low-pressure flexible hose and low-pressure pipe. Refer to [ATC-153, "Removal and Installation of Low-Pressure Flexible Hose and Pipe"](#).
10. Remove high-pressure flexible hose. Refer to [ATC-154, "Removal and Installation of High-Pressure Flexible Hose"](#).



11. Remove high-pressure pipe mounting clips.
12. Remove mounting bolts from compressor, using power tools.
13. Move radiator hose rightward of the vehicle.
14. Remove compressor upward of the vehicle.

REFRIGERANT LINES

INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of low-pressure flexible hose and high-pressure flexible hose with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.


Removal and Installation of Compressor Clutch

NJS0009K



REMOVAL

Overhaul

1. When removing center bolt, hold clutch disc with a clutch disc wrench (SST).




2. Remove clutch disc using a clutch disc puller (SST).




REFRIGERANT LINES


3. Remove snap ring using external snap ring pliers.




4. Position center pulley puller on the end of the drive shaft, and remove pulley assembly using any commercially available pulley puller.
To prevent pulley groove from being deformed, puller claws should be positioned into the edge of pulley assembly.



5. Remove field coil harness clip using a pair of pliers.



6. Remove snap ring using external snap ring pliers.



A
B
C
D
E
F
G
H
I
ATC
K
L
M

REFRIGERANT LINES

Inspection

Clutch disc


If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley

Check appearance of pulley assembly. If contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces should be cleaned with a suitable solvent before reinstallation.


Coil

Check coil for loose connection or cracked insulation.




INSTALLATION


1. Install field coil.
Be sure to align coil's pin with the hole in compressor's front head.
2. Install field coil harness clip using a screwdriver.



3. Install pulley assembly using installer (SST) and a hand press, and then install snap ring using snap ring pliers.



4. Install clutch disc on drive shaft, together with original shim(s). Press clutch disc down by hand.




REFRIGERANT LINES

5. Using a holder to prevent clutch disc rotation.

 : 14 N-m (1.4 kg-m, 10 ft-lb)


After tightening the bolt, make sure the pulley rotates smoothly.



6. Check clearance around the entire periphery of clutch disc.

Disc to pulley clearance : 0.25 - 0.6 mm (0.010 - 0.024 in)

If specified clearance is not obtained, replace adjusting spacer and readjust.



Break-In Operation


When replacing compressor clutch assembly, always carry out break-in operation. This is done by engaging and disengaging clutch about thirty-times. Break-in operation raises level of transmitted torque.

Removal and Installation of Low-Pressure Flexible Hose and Pipe


NJS0009L

REMOVAL

1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#).
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Drain coolant from cooling system, and disconnect two heater hoses. Refer to [CO-8, "Changing Engine Coolant"](#).
4. Remove tower bar, air cleaner assembly, air duct and air inlet pipe. Refer to [FSU-5, "FRONT SUSPENSION ASSEMBLY"](#) and [EM-17, "AIR CLEANER AND AIR DUCT"](#).



5. Remove low-pressure flexible hose from clip.




A
B
C
D
E
F
G
H
I
K
L
M

ATC

REFRIGERANT LINES

6. Remove vehicle harness from clip.
7. Remove mounting bolts from low-pressure flexible hose bracket.
8. Remove clip from low-pressure flexible hose.




9. Remove mounting nut from low-pressure flexible hose.


CAUTION:

Cap or wrap the joint of the pipe with a suitable material such as vinyl tape to avoid the entry of air.

10. Remove low-pressure flexible hose.
11. Remove high-pressure flexible hose from compressor.



12. Remove mounting nut, and then remove low-pressure pipe.



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of low-pressure flexible hose with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.

Removal and Installation of High-Pressure Flexible Hose

NJS0009M

REMOVAL


1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#).
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Remove air cleaner assembly, air duct and air inlet pipe. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#).
4. Remove low-pressure flexible hose from low-pressure pipe. Refer to [ATC-153, "Removal and Installation of Low-Pressure Flexible Hose and Pipe"](#).

REFRIGERANT LINES

5. Remove mounting bolt and nut, and then remove high-pressure flexible hose.

CAUTION:

Cap or wrap the joint of the pipe with a suitable material such as vinyl tape to avoid the entry of air.



INSTALLATION

Installation is basically the reverse order of removal.


CAUTION:

- Replace O-rings of high-pressure flexible hose with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.


Removal and Installation of High-Pressure Pipe

REMOVAL

1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#).
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Drain coolant from cooling system and disconnect heater hoses. Refer to [CO-8, "Changing Engine Coolant"](#).
4. Remove tower bar, air cleaner assembly, air duct and air inlet pipe. Refer to [FSU-5, "FRONT SUSPENSION ASSEMBLY"](#) and [EM-17, "AIR CLEANER AND AIR DUCT"](#).




5. Remove vehicle harness from clip.



6. Remove low-pressure flexible hose. Refer to [ATC-153, "Removal and Installation of Low-Pressure Flexible Hose and Pipe"](#).
7. Remove high-pressure flexible hose. Refer to [ATC-154, "Removal and Installation of High-Pressure Flexible Hose"](#).

REFRIGERANT LINES


8. Remove high-pressure pipe from vehicle clips.



9. Remove front grille, battery, battery tray and radiator mounting bracket. Refer to [EI-21, "FRONT GRILLE"](#) , [SC-4, "BATTERY"](#) and [CO-11, "RADIATOR"](#) .
10. Slide the radiator assembly to the right side of vehicle.
11. Remove mounting bolt from high-pressure pipe, and then remove high-pressure pipe.

CAUTION:

Cap or wrap the joint of the pipe with suitable material such as vinyl tape to avoid the entry of air.



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of high-pressure pipe with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.

Removal and Installation of Refrigerant Pressure Sensor


NJS00090

REMOVAL

1. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
2. Remove front grille. Refer to [EI-21, "FRONT GRILLE"](#) .
3. Remove horn. Refer to [WW-41, "HORN"](#) .
4. Disconnect connector, and then remove refrigerant pressure sensor.

CAUTION:

- Secure refrigerant pressure sensor installation pipe with an open-end wrench. Be careful not to deform pipe during the operation.
- Be careful not to damage the core surface of the condenser during the operation.



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Apply compressor oil to O-ring of the refrigerant pressure sensor when installing it.
- When recharging refrigerant, check for leaks.

REFRIGERANT LINES

NJS0009P

Removal and Installation of Condenser

REMOVAL


1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#) .
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Remove air cleaner assembly, air duct and air inlet pipe. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

4. Disconnect high-pressure flexible hose and high-pressure pipe from condenser.


CAUTION:

Cap or wrap the joint of the pipe with a suitable material such as vinyl tape to avoid the entry of air.

5. Remove oil cooler pipe clips from left and right sides of condenser.
6. Slide condenser up, and then remove it from radiator clip.




7. Remove oil cooler from condenser (if equipped).
8. Remove front grille, battery, battery tray and radiator mounting bracket. Refer to [EI-21, "FRONT GRILLE"](#) , [SC-4, "BATTERY"](#) and [CO-11, "RADIATOR"](#) .



9. Remove cooling fan shroud. Refer to [CO-18, "Removal and Installation"](#) .
10. Remove mounting bolts from condenser.
11. Remove radiator from lower mount, move it toward engine side, and then remove condenser between radiator and radiator core support.

CAUTION:

Be careful not to damage the core surface of condenser and radiator.




INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of high-pressure pipe and high-pressure flexible hose with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.




A
B
C
D
E
F
G
H
I
K
L
M

ATC

REFRIGERANT LINES

Removal and Installation of Liquid Tank

NJS0009Q




SJIA0132J

- | | | |
|--------------------------|--------------------------------|-----------|
| 1. Liquid tank | 2. Liquid tank securing band | 3. Screw |
| 4. Pipe securing bracket | 5. Screw | 6. O-ring |
| 7. Condenser | 8. Refrigerant pressure sensor | |

REMOVAL

1. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
2. Remove air cleaner cover and front air guide. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .
3. Remove front grille. Refer to [EI-21, "FRONT GRILLE"](#) .
4. Remove mounting screw, and then remove pipe securing bracket.
5. Remove liquid tank securing band mounting screw.
6. Pull out liquid tank and liquid tank securing band through the upward.



SJIA0133E

INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of A/C piping with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.


REFRIGERANT LINES

Removal and Installation of Evaporator

NJS0009R

REMOVAL

1. Remove heater & cooling unit assembly. Refer to [ATC-135, "HEATER & COOLING UNIT ASSEMBLY"](#) .
2. Remove cooler grommet, expansion valve cover, expansion valve. Refer to [ATC-159, "Removal and Installation of Expansion Valve"](#) .
3. Remove air mix door motor (driver side) and mode door motor (driver side) with bracket attached. Refer to [ATC-141, "AIR MIX DOOR MOTOR"](#) and [ATC-140, "MODE DOOR MOTOR"](#) .
4. Remove evaporator cover.
5. Slide evaporator, and then remove it from heater & cooling unit assembly.
6. Remove intake sensor from evaporator, and then remove evaporator.



INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of low-pressure flexible hose and high-pressure pipe with new ones, and then apply compressor oil to it when installing it.
- Mark mounting position of intake sensor bracket prior to removal so that the reinstalled sensor can be located in the same position.
- When recharging refrigerant, check for leaks.

Removal and Installation of Expansion Valve


NJS0009S

REMOVAL


1. Remove engine cover and air cleaner cover, using power tools. Refer to [EM-13, "ENGINE ROOM COVER"](#) .
2. Use a refrigerant collecting equipment (for HFC-134a) to discharge the refrigerant.
3. Drain coolant from cooling system and disconnect heater hoses. Refer to [CO-8, "Changing Engine Coolant"](#) .
4. Disconnect low-pressure flexible hose and high-pressure pipe from evaporator.

CAUTION:

Cap or wrap the joint of low-pressure flexible hose and high-pressure pipe with a suitable material such as a vinyl tape to avoid the entry of air.



5. Remove mounting screw, and then remove expansion valve cover.
6. Remove mounting bolts, and then remove expansion valve.



REFRIGERANT LINES

INSTALLATION

Installation is basically the reverse order of removal.

CAUTION:

- Replace O-rings of evaporator with new ones, and then apply compressor oil to it when installing it.
- When recharging refrigerant, check for leaks.

REFRIGERANT LINES

Checking for Refrigerant Leaks

NJS0009T

Perform a visual inspection of all refrigeration parts, fittings, hoses and components for signs of A/C lubricant leakage, damage and corrosion. A/C lubricant leakage may indicate an area of refrigerant leakage. Allow extra inspection time in these areas when using either an electronic refrigerant leak detector or fluorescent dye leak detector (SST: J-42220).

If dye is observed, confirm the leak with an electronic refrigerant leak detector. It is possible a prior leak was repaired and not properly cleaned.

When searching for leaks, do not stop when one leak is found but continue to check for additional leaks at all system components and connections.

When searching for refrigerant leaks using an electronic leak detector, move the probe along the suspected leak area at 1 to 2 inches per second and no further than 1/4 inch from the component.

CAUTION:

Moving the electronic leak detector probe slower and closer to the suspected leak area will improve the chances of finding a leak.

Checking System for Leaks Using the Fluorescent Leak Detector

NJS0009U

1. Check A/C system for leaks using the UV lamp and safety goggles (SST: J-42220) in a low sunlight area (area without windows preferable). Illuminate all components, fittings and lines. The dye will appear as a bright green/yellow area at the point of leakage. Fluorescent dye observed at the evaporator drain opening indicates an evaporator core assembly (tubes, core or expansion valve) leak.
2. If the suspected area is difficult to see, use an adjustable mirror or wipe the area with a clean shop rag or cloth, with the UV lamp for dye residue.
3. After the leak is repaired, remove any residual dye using dye cleaner (SST: J-43872) to prevent future misdiagnosis.
4. Perform a system performance check and verify the leak repair with an approved electronic refrigerant leak detector.

NOTE:

Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean.

Clean with a dry cloth or blow off with shop air.

Do not allow the sensor tip of the detector to contact with any substance. This can also cause false readings and may damage the detector.

Dye Injection

NJS0009V

(This procedure is only necessary when recharging the system or when the compressor has seized and was replaced.)

1. Check A/C system static (at rest) pressure. Pressure must be at least 345 kPa (3.52 kg/cm², 50 psi).
2. Pour one bottle (1/4 ounce / 7.4 cc) of the A/C refrigerant dye into the injector tool (SST: J-41459).
3. Connect the injector tool to the A/C low-pressure side service valve.
4. Start engine and switch A/C ON.
5. When the A/C operating (compressor running), inject one bottle (1/4 ounce / 7.4 cc) of fluorescent dye through the low-pressure service valve using dye injector tool (SST: J-41459) (refer to the manufacture's operating instructions).
6. With the engine still running, disconnect the injector tool from the service valve.

CAUTION:

Be careful the A/C system or replacing a component, pour the dye directly into the open system connection and proceed with the service procedures.

7. Operate the A/C system for a minimum of 20 minutes to mix the dye with the system oil. Depending on the leak size, operating conditions and location of the leak, it may take from minutes to days for the dye to penetrate a leak and become visible.
8. Attach a blue label as necessary.

A
B
C
D
E
F
G
H
I
K
L
M

ATC


REFRIGERANT LINES

Electronic Refrigerant Leak Detector PRECAUTIONS FOR HANDLING LEAK DETECTOR


NJS0009W

When performing a refrigerant leak check, use an A/C electrical leak detector (SST) or equivalent. Ensure that the instrument is calibrated and set properly as per the operating instructions.


The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.




1. Position probe approximately 5 mm (3/16 in) away from point to be checked.



2. When testing, circle each fitting completely with probe.



3. Move probe along component approximately 25 to 50 mm (1 to 2 in)/sec.



REFRIGERANT LINES

CHECKING PROCEDURE

To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals, or cigarette smoke in the vicinity of the vehicle. Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

1. Stop engine.
2. Connect a suitable A/C manifold gauge set to the A/C service valves.
3. Check if the A/C refrigerant pressure is at least 345 kPa (3.52 kg/cm² , 50 psi) above 16°C (61°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

NOTE:

At temperatures below 16°C (61°F), leaks may not be detected since the system may not reach 345 kPa (3.52 kg/cm² , 50 psi).

4. Perform the leak test from the high-pressure side (compressor discharge a to evaporator inlet f) to the low-pressure side (evaporator drain hose g to shaft seal k). Refer to [ATC-148, "Components"](#) . Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detected probe completely around the connection/component.

Compressor

Check the fitting of high- and low- pressure flexible hoses, relief valve and shaft seal.

Condenser

Check the fitting of high-pressure flexible hose and pipe, refrigerant pressure sensor.

Liquid tank

Check the fitting of refrigerant connection.

Service valves

Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

NOTE:

After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

Cooling unit (Evaporator)


With engine OFF, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose.

Keep the probe inserted for at least 10 seconds. Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

5. If a leak detector detects a leak, verify it at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components. If no leaks are found, perform steps 7-10.
7. Start engine.
8. Set the heater A/C control as follows;
 - a. AUTO switch: ON
 - b. MODE door position: VENT (ventilation)
 - c. Intake position: Recirculation
 - d. Temperature dial: Max. cold
 - e. Fan speed: High
9. Run engine at 1,500 rpm for at least 2 minutes.
10. Stop engine and perform leak check again following steps 4 through 6 above.

REFRIGERANT LINES

Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high-pressure side will gradually drop after refrigerant circulation stops and pressure on the low-pressure side will gradually rise, as shown in the graph. Some leaks are more easily detected when pressure is high.



11. Before connecting recovery/recycling recharging equipment to vehicle, check recovery/recycling recharging equipment gauges. No refrigerant pressure should be displayed. If pressure is displayed, recover refrigerant from equipment lines and then check refrigerant purity.
12. Confirm refrigerant purity in supply tank using recovery/recycling recharging equipment and refrigerant identifier.
13. Confirm refrigerant purity in vehicle A/C system using recovery/recycling recharging equipment and refrigerant identifier.
14. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component if necessary.
15. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
16. Perform A/C performance test to ensure system works properly.

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Compressor

NJS0009X

Model		Calsonic Kansei make CWE-618
Type		V-6 variable displacement
Displacement cm ³ (cu in)/rev	Max.	184 (11.228)
	Min.	14.5 (0.885)
Cylinder bore × stroke mm (in)		37 (1.46) × [2.3 - 28.6 (0.091 - 1.126)]
Direction of rotation		Clockwise (viewed from drive end)
Drive belt		Poly V

Lubricant

NJS0009Y

Model		Calsonic Kansei make CWE-618
Name		Nissan A/C System Oil Type S (DH-PS)
Capacity m ℓ (US fl oz, Imp fl oz)	Total in system	180 (6.0, 6.3)
	Compressor (Service part) charging amount	180 (6.0, 6.3)

Refrigerant

NJS0009Z

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.60 (1.32)

Engine Idling Speed

NJS000A0

Refer to [EC-76, "Idle Speed and Ignition Timing Check"](#) .

Belt Tension

NJS000A1

Refer to [EM-14, "DRIVE BELTS"](#) .

A
B
C
D
E
F
G
H
I
K
L
M

ATC

SERVICE DATA AND SPECIFICATIONS (SDS)
