

SECTION **AV**

AUDIO VISUAL, NAVIGATION & TELEPHONE SYSTEM

CONTENTS

<b>PRECAUTIONS</b> .....	<b>4</b>	Power Supply Circuit Inspection .....	44
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	Steering Switch Does Not Operate .....	45
<b>AUDIO</b> .....	<b>5</b>	Rear Control Switch Does Not Operate .....	47
System Description .....	5	AudioPilot® Does Not Work .....	51
AUDIO SYSTEM .....	5	Removal and Installation of Audio Unit .....	52
Component Parts Location .....	7	REMOVAL .....	52
Schematic — AUDIO — / With Satellite Radio .....	8	INSTALLATION .....	52
Wiring Diagram — AUDIO — / With Satellite Radio... ..	9	Removal and Installation of CD Auto Changer .....	52
Wiring Diagram — CD AUTO CHANGER — / With Satellite Radio .....	16	REMOVAL .....	52
Schematic — AUDIO — / Without Satellite Radio.. ..	18	INSTALLATION .....	52
Wiring Diagram — AUDIO — / Without Satellite Radio .....	19	Removal and Installation of Door Speaker .....	53
Wiring Diagram — CD AUTO CHANGER — / Without Satellite Radio .....	26	REMOVAL .....	53
Wiring Diagram — REMOTE — .....	28	INSTALLATION .....	53
Terminals and Reference Value for Audio Unit .....	30	Removal and Installation of Instrument Panel Speaker .....	53
Terminals and Reference Value for BOSE Speaker Amp. ....	33	REMOVAL .....	53
Terminals and Reference Value for CD Auto Changer .....	36	INSTALLATION .....	53
Terminals and Reference Value for Satellite Radio Tuner .....	37	Removal and Installation of Woofer .....	53
Terminals and Reference Value for Rear Control Switch .....	39	REMOVAL .....	53
Terminals and Reference Value for Rear Control Cancel Switch .....	39	INSTALLATION .....	53
Terminals and Reference Value for Multifunction Switch .....	39	Removal and Installation of BOSE Speaker Amp... ..	54
On Board Self-Diagnosis Function .....	40	REMOVAL .....	54
DESCRIPTION .....	40	INSTALLATION .....	54
DIAGNOSIS ITEM .....	40	Removal and Installation of AudioPilot® Micro- phone .....	54
Self Diagnosis Mode .....	40	REMOVAL .....	54
OPERATION PROCEDURE .....	40	INSTALLATION .....	54
Confirmation/Adjustment Mode .....	40	Removal and Installation of Steering Wheel Switch.. ..	54
OPERATION PROCEDURE .....	40	Removal and Installation of Multifunction Switch ... ..	54
Trouble Diagnosis .....	42	Removal and Installation of Rear Control Switch ... ..	55
		REMOVAL .....	55
		INSTALLATION .....	55
		Removal and Installation of Rear Control Cancel Switch .....	55
		REMOVAL .....	55
		INSTALLATION .....	55
		Removal and Installation of Satellite Radio Tuner.. ..	56
		REMOVAL .....	56

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

INSTALLATION .....	56	CONSULT-II Function (MULTI AV) .....	115
Removal and Installation of Satellite Radio Antenna..	56	CONSULT-II BASIC OPERATION PROCEDURE	
REMOVAL .....	56	VERSION .....	115
INSTALLATION .....	56	SELF-DIAG RESULTS .....	116
<b>ANTENNA .....</b>	<b>57</b>	SIGNAL MONITOR .....	119
Wiring Diagram — W/ANT — .....	57	RGB Image Is Not Displayed (Rear View Image Is	
Location of Antenna .....	58	Displayed) .....	120
RADIO ANTENNA .....	58	All Images Are Not Displayed .....	121
SATELLITE RADIO ANTENNA AND TEL		Rear View Image Is Not Displayed .....	122
ANTENNA .....	59	Tint Is Strange for The RGB Image .....	123
Window Antenna Repair .....	60	RGB Image Is Rolling .....	125
CHECK ELEMENT .....	60	Voice Guidance Is Not Heard .....	126
Removal and Installation of Satellite Radio Antenna..	61	A/C Display Is Malfunctioning .....	127
Removal and Installation of TEL Antenna .....	61	A/C Operation Is Malfunctioning .....	127
<b>NAVIGATION SYSTEM .....</b>	<b>62</b>	Fuel Information Is Not Displayed/Warning Mes-	
System Description .....	62	sage Is Not Displayed .....	127
LOCATION DETECTION PRINCIPLE .....	62	Vehicle Condition Setting Is Not Possible .....	127
MAP-MATCHING .....	63	Vehicle Mark Is Not Displayed Properly .....	127
GPS (GLOBAL POSITIONING SYSTEM) .....	64	Example of Symptoms Possible No Malfunction ..	128
Component Description .....	65	BASIC OPERATION .....	128
AV AND NAVI CONTROL UNIT .....	65	VEHICLE MARK .....	128
GPS ANTENNA .....	65	DESTINATION, PASSING POINTS, AND MENU	
Component Parts Location .....	66	ITEMS CANNOT BE SELECTED/SET .....	129
Location of Antenna .....	66	VOICE GUIDANCE .....	129
Schematic — NAVI — .....	67	ROUTE SEARCHING .....	130
Wiring Diagram — NAVI — .....	68	Removal and Installation of AV and NAVI Control	
Schematic — COMM — / With Voice Activated Con-		Unit .....	131
trol System .....	77	REMOVAL .....	131
WITH SATELLITE RADIO .....	77	INSTALLATION .....	131
WITHOUT SATELLITE RADIO .....	78	Removal and Installation of GPS Antenna .....	131
Wiring Diagram — COMM — / With Voice Activated		REMOVAL .....	131
Control System .....	79	INSTALLATION .....	131
WITH SATELLITE RADIO .....	79	Removal and Installation of Multifunction Switch ..	131
WITHOUT SATELLITE RADIO .....	85	Removal and Installation of Display .....	131
Schematic — COMM — / Without Voice Activated		Removal and Installation of Steering Wheel Switch ..	131
Control System .....	91	Removal and Installation of Rear Control Switch ..	131
Wiring Diagram — COMM — / Without Voice Acti-		Removal and Installation of Rear Control Cancel	
ated Control System .....	92	Switch .....	131
Terminals and Reference Value for AV and NAVI		<b>TELEPHONE .....</b>	<b>132</b>
Control Unit .....	97	System Description .....	132
Terminals and Reference Value for Display .....	100	HANDS-FREE PHONE SYSTEM .....	132
Terminals and Reference Value for Multifunction		Component Parts Location .....	134
Switch .....	100	Schematic — H/PHON — / With Voice Activated	
Terminals and Reference Value for Voice Activated		Control System .....	135
Control Module .....	100	Wiring Diagram — H/PHON — / With Voice Acti-	
Special Note for Trouble Diagnosis .....	101	ated Control System .....	136
On Board Self-Diagnosis Function (Without CON-		Schematic — H/PHON — / Without Voice Activated	
SULT-II) .....	101	Control System .....	141
DESCRIPTION .....	101	Wiring Diagram — H/PHON — / Without Voice Acti-	
DIAGNOSIS ITEM .....	101	ated Control System .....	142
Self-Diagnosis Mode .....	102	Terminals and Reference Value for TEL Adapter	
OPERATION PROCEDURE .....	102	Unit .....	146
SELF-DIAGNOSIS RESULT .....	104	Terminals and Reference Value for Voice Activated	
Confirmation/Adjustment Mode .....	108	Control Module .....	147
OPERATION PROCEDURE .....	108	Special Note for Trouble Diagnosis .....	148
DISPLAY DIAGNOSIS .....	109	Self-Diagnosis Function .....	148
VEHICLE SIGNALS .....	110	OPERATION PROCEDURE .....	148
HISTORY OF ERRORS .....	111	Hands-Free Phone System Is Not Activated .....	150
NAVIGATION .....	113		

Hands-Free Phone System Cannot Transmit The Speaker's Voice to The Party ..... 152	REMOVAL ..... 158	
Hands-Free Phone System Cannot Transmit The Party's Voice to The Speaker ..... 153	INSTALLATION ..... 158	A
Removal and Installation of TEL Adapter Unit .... 158	Removal and Installation of Microphone (PHONE/ SEND and END Buttons) ..... 159	
REMOVAL ..... 158	REMOVAL ..... 159	B
INSTALLATION ..... 158	INSTALLATION ..... 159	
Removal and Installation for TEL Antenna ..... 158	<b>TELEPHONE (PRE WIRE) ..... 160</b>	
	Wiring Diagram — PHONE — ..... 160	C

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# PRECAUTIONS

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS001HL

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

## AUDIO

PFP:28111

### System Description AUDIO SYSTEM

NKS001HN

For Audio System operation information, refer to Owner's Manual.

Power is supplied at all times

- through 15 A fuse [No. 52, located in the fuse, fusible link and relay block (J/B)]
- to audio unit terminal 73
- to satellite radio tuner terminal 33 (With satellite radio)
- to jumping connector (For satellite radio tuner) terminal 33 (Without satellite radio)
- to CD auto changer terminal 12,
- through 15 A fuse [No. 56, located in the fuse, fusible link and relay block (J/B)]
- to combination switch (spiral cable) terminal 24,
- through combination switch (spiral cable) terminal 20
- to steering switch terminal 1,
- through 30 A fuse [No. J, located in the fuse, fusible link and relay box]
- to BOSE speaker amp. terminal 11.

With the ignition switch in the ACC or ON position, power is supplied

- through 10 A fuse [No. 21, located in the fuse block (J/B) No. 1]
- to audio unit terminal 72
- to BOSE speaker amp. terminal 34
- to satellite radio tuner terminal 34 (With satellite radio)
- to jumping connector (For satellite radio tuner) terminal 34 (Without satellite radio)
- to rear control cancel relay terminal 3
- to CD auto changer terminal 16,
- through 10 A fuse [No. 4, located in the fuse block (J/B) No. 1]
- to rear control cancel switch terminal 4.

When rear control cancel switch is in rear control position, power is supplied

- through rear control cancel switch terminal 3
- to rear control cancel relay terminal 2.

Then rear control cancel relay is energized and power is supplied

- through rear control cancel relay terminal 5
- to rear control switch terminal 1.

When steering switch pressed ON, signal is sent

- from steering switch terminal 2
- through combination switch (spiral cable) terminals 19 and 25
- to multifunction switch terminal 7.

Ground is supplied through the case of the audio unit.

Ground is also supplied

- to BOSE speaker amp. terminal 27
- to rear control cancel relay terminal 1
- through body grounds B217 and B256,
- to CD auto changer terminal 15
- through body grounds M24 and M114,
- to steering switch terminal 3
- through body ground,
- to rear control switch terminal 12
- through body grounds M25 and M115.

When the audio unit is turned to the ON position, audio signals are supplied

- through terminals 80, 79, 81 and 82 of audio unit

A

B

C

D

E

F

G

H

I

J

AV

L

M

# AUDIO

---

- to terminals 40, 39, 38 and 41 of BOSE speaker amp.
- through terminals 12, 13, 14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 28, 29 and 30 of BOSE speaker amp.
- to every terminals 1 and 2 of instrument speakers, front and rear door speakers and woofer.

## AV Communication Line

Audio system components (Audio unit, BOSE speaker amplifier, etc.) are connected by AV communication line and controlled by signals from the multifunction switch.

## AudioPilot® system

AudioPilot® is the sound improving system that picks up by a microphone under the clock any noises or the sound of music coming into the vehicle, and that uses the BOSE speaker amp. to revise the frequency feature of music in real time in response to the frequency feature of the noise while driving and listening to music.


- If low frequency area noise from vehicle is loud, it adjusts low frequency element of music to be bigger than vehicle noise.
- If high frequency area noise from vehicle is loud, it adjusts high frequency element of music to be bigger than vehicle noise.
- If vehicle noise is smaller than the setting volume, correction is not performed.

# AUDIO

## Component Parts Location

NKS001H0

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M




SKIB7593E

# AUDIO

## Schematic — AUDIO — / With Satellite Radio

NKS001HP







TKWM3787E





# AUDIO

AV-AUDIO-02







\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM3789E

# AUDIO

## AV-AUDIO-03




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# AUDIO

## AV-AUDIO-04

▬ : DATA LINE



24	22	20	18	16	14	12	10	8	6	4	2
23	21	19	17	15	13	11	9	7	5	3	1

(M82)  
GY

20	18	16	14	12	10	8	6	4	2	
19	17	15	13	11	10	9	7	5	3	1

(M83)  
W

82	80	76	74	72	16	14	12	8	6	4	2				
81	79	78	77	75	73	71	15	13	11	10	9	7	5	3	1

(M86)  
W

16	14	12	8	6	4	2		
15	13	11	10	9	7	5	3	1




(M87)  
W

TKWM3790E

# AUDIO





## AV-AUDIO-05

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (B211) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3791E





REFER TO THE FOLLOWING.  
B211, D1, D31 -SUPER  
MULTIPLE JUNCTION (SMJ)

# AUDIO

AV-AUDIO-07

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.  
 (B21), (B211), (B221) -SUPER  
 MULTIPLE JUNCTION (SMJ)

TKWM3985E









# AUDIO

## Wiring Diagram — CD AUTO CHANGER — / With Satellite Radio

NKS001HS

### AV-CD/CHG-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION (SMJ)






(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)



# AUDIO

## AV-CD/CHG-02




REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# AUDIO

## Schematic — AUDIO — / Without Satellite Radio

NKS002LW







TKWM3966E

# AUDIO

## Wiring Diagram — AUDIO — / Without Satellite Radio

NKS002LX

### AV-AUDIO-08



REFER TO THE FOLLOWING.

(E205), (B211) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1





(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

AV

# AUDIO






AV-AUDIO-09



TKWM3968E

# AUDIO

## AV-AUDIO-10




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# AUDIO

## AV-AUDIO-11

▬ : DATA LINE



24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82)  
GY

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83)  
W

82	80	76	74	72	16	14	12	8	6	4	2				
81	79	78	77	75	73	71	15	13	11	10	9	7	5	3	1

(M86)  
W




16	14	12	8	6	4	2		
15	13	11	10	9	7	5	3	1

(M87)  
W





TKWM3970E

# AUDIO

## AV-AUDIO-12



REFER TO THE FOLLOWING.  
**(B211)** -SUPER MULTIPLE JUNCTION (SMJ)





REFER TO THE FOLLOWING.  
(B211), (D1), (D31) -SUPER  
MULTIPLE JUNCTION (SMJ)



# AUDIO

## AV-AUDIO-14

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.  
 (B21), (B211), (B221) -SUPER  
 MULTIPLE JUNCTION (SMJ)

AV









# AUDIO

## Wiring Diagram — CD AUTO CHANGER — / Without Satellite Radio

NK5002LY

### AV-CD/CHG-03

▬ : DATA LINE



REFER TO THE FOLLOWING.


(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1





(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

# AUDIO

AV-CD/CHG-04



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M



REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)









# AUDIO

## Wiring Diagram — REMOTE —

NKS001HR

### AV-REMOTE-01

DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



REFER TO THE FOLLOWING.

- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3793E

# AUDIO

## AV-REMOTE-02









REFER TO THE FOLLOWING.  
(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWM3794E

# AUDIO

## Terminals and Reference Value for Audio Unit

NKS001HT

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
11 (PU)	Ground	Communication signal (-)	Input/ Output	ON	—	 <p style="text-align: right;">SKIB7379E</p>
12 (LG)	Ground	Communication signal (+)	Input/ Output	ON	—	 <p style="text-align: right;">SKIB7378E</p>
13	—	Shield	—	—	—	—
14	—	Shield	—	—	—	—
15 (R/L)	Ground	Communication signal (-)	Input/ Output	ON	—	 <p style="text-align: right;">SKIB7379E</p>
16 (Y)	Ground	Communication signal (+)	Input/ Output	ON	—	 <p style="text-align: right;">SKIB7378E</p>
52 (L/R)	51 (L)	Audio signal LH	Input	ON	Play back CD on CD auto changer, or receive satellite radio audio signal <sup>*1</sup>	 <p style="text-align: right;">SKIB3609E</p>
					Play back CD on CD auto changer <sup>*2</sup>	
54 (Y/R)	53 (Y)	Audio signal RH	Input	ON	Play back CD on CD auto changer, or receive satellite radio audio signal <sup>*1</sup>	 <p style="text-align: right;">SKIB3609E</p>
					Play back CD on CD auto changer <sup>*2</sup>	
55	—	Shield	—	—	—	—
56	—	Shield	—	—	—	—
57 (L/W)	Ground	Source change signal <sup>*1</sup>	Output	ON	CD auto changer mode	Approx. 10 V
					Other than the above	Approx. 0 V



# AUDIO

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
58 (R/W)	Ground	Communication signal REQ (SAT-AUDIO)* <sup>1</sup>	Input	ON	When setting to CD auto changer mode, or satellite radio mode* <sup>1</sup>	
		Communication signal REQ (CHG-AUDIO)* <sup>2</sup>			When setting to CD auto changer mode* <sup>2</sup>	
59 (R/L)	Ground	Communication signal Rx (CHG-AUDIO)	Input	ON	When setting to CD auto changer mode, or satellite radio mode* <sup>1</sup>	
					When setting to CD auto changer mode* <sup>2</sup>	
60 (B)	Ground	Communication signal Tx (AUDIO-CHG)	Output	ON	When setting to CD auto changer mode, or satellite radio mode* <sup>1</sup>	
					When setting to CD auto changer mode* <sup>2</sup>	
61 (OR/L)	Ground	Control signal* <sup>1</sup>	Output	ON	CD auto changer mode	Approx. 10 V
					Other than the above	Approx. 0 V
62 (OR)	Ground	Communication signal REQ (CHG-AUDIO)* <sup>1</sup>	Input	ON	When setting to CD auto changer mode	
71 (R/L)	76 (SB)	Illumination signal	Input	ON	Illumination control switch is operated by lighting switch in ON position	Changes between approx. 0 and approx. 12 V
					Lighting switch OFF	Approx. 0 V
72 (L/OR)	Ground	ACC power supply	Input	ACC	—	Battery voltage
73 (PU/W)	Ground	Battery power supply	Input	OFF	—	Battery voltage
75 (P/L)	Ground	Antenna amp. ON signal	Output	ON	—	Approx. 12 V
76 (SB)	Ground	Illumination control signal	—	ON	Illumination control switch is operated by lighting switch in ON position	Changes between approx. 0 and approx. 12 V
78	—	Shield	—	—	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# AUDIO

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
80 (BR)	79 (Y)	Audio signal LH	Output	ON	Receive audio signal	
82 (Y/R)	81 (Y/B)	Audio signal RH	Output	ON	Receive audio signal	

\*1: With satellite radio







\*2: Without satellite radio



# AUDIO

## Terminals and Reference Value for BOSE Speaker Amp.






NKS001HU

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
3 (W)	4 (R/L)	Microphone signal	Input	ON	When inputting some sounds (voice, etc.) toward the microphone	 <p>(reference value)</p> <p>PKIA2104E</p>
5 (LG)	Ground	Communication signal (+)	Input/Output	ON	—	 <p>SKIB7378E</p>
6 (PU)	Ground	Communication signal (-)	Input/Output	ON	—	 <p>SKIB7379E</p>
7	—	Shield	—	—	—	—
11 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
13 (P)	29 (L/Y)	Audio signal front door speaker RH	Output	ON	Receive audio signal	 <p>SKIB3609E</p>
15	—	Shield	—	—	—	—
16 (R/G)	17 (R/W)	Audio signal rear door speaker LH	Output	ON	Receive audio signal	 <p>SKIB3609E</p>
18 (G/R)	19 (G/W)	Audio signal instrument speaker LH	Output	ON	Receive audio signal	 <p>SKIB3609E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# AUDIO

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
21 (Y)	20 (L)	Audio signal instru- ment speaker center	Output	ON	Receive audio signal	 <small>SKIB3609E</small>
23 (G)	22 (R)	Audio signal instru- ment speaker RH	Output	ON	Receive audio signal	 <small>SKIB3609E</small>
25 (P)	24 (PU)	Audio signal rear door speaker RH	Output	ON	Receive audio signal	 <small>SKIB3609E</small>
27 (B)	Ground	Ground	—	ON	—	Approx. 0 V
28 (BR/W)	12 (BR)	Audio signal woofer	Output	ON	Receive audio signal	 <small>SKIB3609E</small>
30 (L/B)	14 (L/W)	Audio signal front door speaker LH	Output	ON	Receive audio signal	 <small>SKIB3609E</small>
31	—	Shield	—	—	—	—
32	—	Shield	—	—	—	—
34 (OR/L)	Ground	ACC power supply	Input	ACC	—	Battery voltage

# AUDIO






Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
40 (L/G)	39 (L/Y)	Audio signal LH	Input	ON	Receive audio signal	
41 (Y/R)	38 (Y/B)	Audio signal RH	Input	ON	Receive audio signal	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# AUDIO

## Terminals and Reference Value for CD Auto Changer







NKS001HV

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
2 (L/R)	1 (L/Y)	Audio signal LH	Output	ON	Play back CD on CD auto changer	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
4 (G)	3 (OR)	Audio signal RH	Output	ON	Play back CD on CD auto changer	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
5	—	Shield	—	—	—	—
6	—	Shield	—	—	—	—
8 (Y)	Ground	Communication signal REQ (CHG-AUDIO)	Output	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7338E</p>
9 (L)	Ground	Communication signal Tx (CHG-AUDIO)	Output	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7337E</p>
10 (G)	Ground	Communication signal Rx (AUDIO-CHG)	Input	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7336E</p>
12 (PU/W)	Ground	Battery power supply	Input	OFF	—	Battery voltage
13 (SB)	Ground	Illumination control signal	—	ON	illumination control switch is operated by lighting switch in ON position	Changes between approx. 0 and approx. 12 V
14 (R/L)	13 (SB)	Illumination signal	Input	ON	illumination control switch is operated by lighting switch in ON position	Changes between approx. 0 and approx. 12 V
					Lighting switch OFF	Approx. 0 V
15 (B)	Ground	Ground	—	ON	—	Approx. 0 V
16 (L/OR)	Ground	ACC power supply	Input	ACC	—	Battery voltage

# AUDIO

## Terminals and Reference Value for Satellite Radio Tuner






NKS00210

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
2 (B)	1 (W)	Audio signal LH	Input	ON	Play back CD on CD auto changer	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
4 (R)	3 (G)	Audio signal RH	Input	ON	Play back CD on CD auto changer	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
5	—	Shield	—	—	—	—
6	—	Shield	—	—	—	—
8 (LG)	Ground	Communication signal REQ (CHG-AUDIO)	Input	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7338E</p>
9 (L)	Ground	Communication signal Rx (CHG-AUDIO)	Input	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7337E</p>
10 (PU)	Ground	Communication signal Tx (AUDIO-CHG)	Output	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7336E</p>
17 (L/W)	Ground	Source change signal	Input	ON	CD auto changer mode	Approx. 10 V
					Other than the above	Approx. 0 V
22 (B)	21 (W)	Audio signal LH	Output	ON	Play back CD on CD auto changer, or receive satellite radio audio signal	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV


# AUDIO

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
24 (R)	23 (G)	Audio signal RH	Output	ON	Play back CD on CD auto changer, or receive satellite radio audio signal	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
25	—	Shield	—	—	—	—
26	—	Shield	—	—	—	—
28 (L/R)	Ground	Communication signal REQ (SAT-AUDIO)	Output	ON	When setting to CD auto changer mode, or satellite radio mode	 <p style="text-align: right; font-size: small;">SKIB7338E</p>
29 (L)	Ground	Communication signal Tx (SAT-AUDIO)	Output	ON	When setting to CD auto changer mode, or satellite radio mode	 <p style="text-align: right; font-size: small;">SKIB7337E</p>
30 (L/W)	Ground	Communication signal Rx (AUDIO-SAT)	Input	ON	When setting to CD auto changer mode, or satellite radio mode	 <p style="text-align: right; font-size: small;">SKIB7336E</p>
31 (P)	Ground	Control signal	Input	ON	CD auto changer mode	Approx. 10 V
					Other than the above	Approx. 0 V
32 (OR)	Ground	Communication signal REQ (CHG-AUDIO)	Output	ON	When setting to CD auto changer mode	 <p style="text-align: right; font-size: small;">SKIB7338E</p>
33 (SB)	Ground	Battery power supply	Input	OFF	—	Battery voltage
34 (L/OR)	Ground	ACC power supply	Input	ACC	—	Battery voltage
40	—	Satellite radio antenna	—	—	—	—

# AUDIO

## Terminals and Reference Value for Rear Control Switch

NKS001HW

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
1 (L/Y)	Ground	ACC power supply	Input	ACC	Rear control cancel switch ON	Battery voltage
10 (Y)	Ground	Communication signal Rx	Output	ON	Operate rear control switch	
12 (B)	Ground	Ground	—	ON	—	Approx. 0 V

## Terminals and Reference Value for Rear Control Cancel Switch

NKS001HX

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
3 (G)	Ground	Rear control cancel switch signal	Output	ON	Rear control cancel switch ON	Battery voltage
					Rear control cancel switch CANCEL	Approx. 0 V
4 (LG)	Ground	ACC power supply	Input	ACC	—	Battery voltage

## Terminals and Reference Value for Multifunction Switch

NKS002KE

Refer to [DI-125, "Terminals and Reference Value for Multifunction Switch"](#) (Without navigation system), or [DI-164, "Terminals and Reference Value for Multifunction Switch"](#) (With navigation system).

AV

L

M

## On Board Self-Diagnosis Function DESCRIPTION

NKS001HY

Refer to [DI-126, "DESCRIPTION"](#) (Without navigation system), or [AV-101, "DESCRIPTION"](#) (With navigation system).

### DIAGNOSIS ITEM

Mode		Description
Self Diagnosis		
Confirmation/ Adjustment	Display Diagnosis	Refer to <a href="#">DI-126, "DIAGNOSIS ITEM"</a> (Without navigation system), or <a href="#">AV-101, "DIAGNOSIS ITEM"</a> (With navigation system).
	Vehicle Signals	
	History of Errors	
	Rearview	
	Navigation	Refer to <a href="#">AV-101, "DIAGNOSIS ITEM"</a> .
	Auto Climate Control	Refer to <a href="#">DI-126, "DIAGNOSIS ITEM"</a> (Without navigation system), or <a href="#">AV-101, "DIAGNOSIS ITEM"</a> (With navigation system).
	Speaker Test	The connection of a speaker can be confirmed by test tone.
	Voice Mic. Test	Refer to <a href="#">DI-211, "DIAGNOSIS ITEM"</a> .

### Self Diagnosis Mode OPERATION PROCEDURE


NKS001HZ

Refer to [DI-126, "SELF-DIAGNOSIS MODE"](#) (Without navigation system), or [AV-102, "Self-Diagnosis Mode"](#) (With navigation system).


### Confirmation/Adjustment Mode OPERATION PROCEDURE

NKS00110

1. Start the engine.
2. Turn the audio system OFF.
3. While pressing the "INFO" button, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When self-diagnosis mode is aggravated, a short beep will be heard.)
  - Shifting from current screen to previous screen is performed by pressing "PREV" button.




4. The initial trouble diagnosis screen will be shown, and items "Self Diagnosis" and "Confirmation/Adjustment" will become selective.





# AUDIO

5. Each diagnosis is shown by selecting each screen switch on CONFIRMATION/ADJUSTMENT screen.




6. When selecting "Speaker Test", speaker diagnosis screen is displayed. When pressing "Start/Next", test tone emits from the speaker. At that time, when pressing "Start/Next", test tone emits from next speaker. Then, when pressing the "Stop", test tone stops.

**NOTE:**

The frequency of test tone emitted from each speaker is as follows.

- Instrument speaker** : 1 kHz
- Door speaker** : 1 kHz
- Woofers** : 100 Hz



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# AUDIO

NKS0011

## Trouble Diagnosis

- The majority of the audio malfunctions are the result of outside causes (bad CD/cassette, electromagnetic interference, etc.). Check the symptoms below to diagnose the malfunction.
- The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and then determine the cause.
- Make sure that other operation except audio system can be performed with multifunction switch. If these operations are inoperative with multifunction switch, refer to [DI-148, "Multifunction Switch Does Not Operate"](#) (Without navigation system), or [DI-169, "Multifunction Switch Does Not Operate"](#) (With navigation system) to repair malfunctioning parts.
- Refer to "SERVICE BULLETIN ITB04-055" for the diagnosis of satellite radio.

Symptom	Possible malfunction location
Audio system does not work properly.	<ul style="list-style-type: none"> <li>● Audio unit power supply circuit Refer to <a href="#">AV-44, "Power Supply Circuit Inspection"</a></li> <li>● BOSE speaker amp. power supply and ground circuit Refer to <a href="#">AV-44, "Power Supply Circuit Inspection"</a></li> <li>● Communication signal circuit between audio unit and BOSE speaker amp. Refer to <a href="#">AV-40, "Self Diagnosis Mode"</a></li> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> </ul>
CD auto changer does not work properly.	<ul style="list-style-type: none"> <li>● CD auto changer power supply and ground circuit Refer to <a href="#">AV-44, "Power Supply Circuit Inspection"</a></li> <li>● Communication signal circuit between audio unit and CD auto changer Refer to <a href="#">AV-40, "Self Diagnosis Mode"</a></li> <li>● CD auto changer</li> <li>● Audio unit</li> </ul>
No sound can be heard from all speakers.	<p><b>With voice activated control system and hands-free phone system</b></p> <ul style="list-style-type: none"> <li>● TEL ON signal circuit between TEL adapter unit and voice activated control module</li> <li>● TEL ON signal circuit between voice activated control module and audio unit</li> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> <li>● Voice activated control module</li> <li>● TEL adapter unit</li> </ul>
	<p><b>With voice activated control system</b></p> <ul style="list-style-type: none"> <li>● Mute signal circuit between voice activated control module and audio unit</li> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> <li>● Voice activated control module</li> </ul>
	<p><b>With hands-free phone system</b></p> <ul style="list-style-type: none"> <li>● TEL ON signal circuit between TEL adapter unit and audio unit</li> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> <li>● TEL adapter unit</li> </ul>
	<p><b>Without voice activated control system and hands-free phone system</b></p> <ul style="list-style-type: none"> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> </ul>

# AUDIO

Symptom	Possible malfunction location	
No sound can be heard from one or several speakers.	<ul style="list-style-type: none"> <li>● Audio signal circuit between audio unit and BOSE speaker amp.</li> <li>● Audio signal circuit between BOSE speaker amp. and speaker</li> <li>● Speaker</li> <li>● Woofer</li> <li>● Audio unit</li> <li>● BOSE speaker amp.</li> </ul>	A B C
Only the sound from CD auto changer cannot play from one or several speakers.	<ul style="list-style-type: none"> <li>● Audio signal circuit between CD auto changer and audio unit</li> <li>● CD auto changer</li> <li>● Audio unit</li> </ul>	D
No sound can be heard from radio or noise is caught.	<ul style="list-style-type: none"> <li>● Antenna amp. ON signal circuit</li> <li>● Antenna feeder</li> <li>● Antenna</li> <li>● Antenna amp.</li> <li>● Audio unit</li> </ul>	E F

**NOTE:**

Noise resulting from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from a time difference between the broadcast waves directly from the station arriving at the antenna and the waves reflected by mountains or buildings.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# AUDIO

NKS00113

## Power Supply Circuit Inspection

### 1. CHECK FUSE

Make sure that the following fuses and fusible link of the audio unit, BOSE speaker amp. and CD auto changer are not blown.

Unit	Signal name	Fuse and fusible link No.
Audio unit	Battery power supply	52
	ACC power supply	21
BOSE speaker amp.	Battery power supply	J
	ACC power supply	21
CD auto changer	Battery power supply	52
	ACC power supply	21

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-2, "POWER SUPPLY ROUTING"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


Check voltage between the following harness connector terminals and ground.

Unit	Terminals		OFF	ACC	ON	
	(+)					(-)
	Connector	Terminal				
Audio unit	M86	73	Battery voltage	Battery voltage	Battery voltage	
		72	0 V	Battery voltage	Battery voltage	
BOSE speaker amp.	B233	11	Battery voltage	Battery voltage	Battery voltage	
	B234	34	0 V	Battery voltage	Battery voltage	
CD auto changer	M109	12	Battery voltage	Battery voltage	Battery voltage	
		16	0 V	Battery voltage	Battery voltage	

#### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# AUDIO

## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. and CD auto changer connectors.
3. Check continuity between BOSE speaker amp. harness connector B233 terminal 27 and ground.


**27 – Ground : Continuity should exist.**

4. Check continuity between CD auto changer harness connector M109 terminal 15 and ground.

**15 – Ground : Continuity should exist.**

OK or NG

- OK >> INSPECTION END  
NG >> Repair harness or connector.



## Steering Switch Does Not Operate

### 1. SELF-DIAGNOSIS MODE OF MULTIFUNCTION SWITCH

1. Perform the self-diagnosis mode in the self-diagnosis function. Refer to [DI-136. "Multifunction Switch Self-Diagnosis Function"](#) (Without navigation system), or [DI-165. "Multifunction Switch Self-Diagnosis Function"](#) (With navigation system).
2. Press steering switch.

**Beep sound should operate.**

OK or NG

- OK >> GO TO 8.  
NG >> GO TO 2.

## 2. CHECK HORN OPERATION

Check horn operation.

**Horn should operate.**

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 3.


## 3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between combination switch (spiral cable) harness connector M441 terminal 20 and ground.

**20 – Ground : Battery voltage**

OK or NG

- OK >> GO TO 5.  
NG >> GO TO 4.



# AUDIO


## 4. CHECK SPIRAL CABLE

1. Disconnect combination switch (spiral cable) connector.
2. Check continuity between combination switch (spiral cable) connector M53 terminal 24 and connector M441 terminal 20.

**24 – 20 : Continuity should exist.**

OK or NG

- OK >> Repair power supply circuit of horn system.  
NG >> Replace spiral cable.



## 5. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect steering switch and combination switch (spiral cable) connectors.
3. Check continuity between steering switch harness connector M444 terminals 1, 2 and combination switch (spiral cable) harness connector M441 terminals 20, 19.

**1 – 20 : Continuity should exist.**

**2 – 19 : Continuity should exist.**

4. Check continuity between steering switch harness connector M444 terminals 1, 2 and ground.

**1, 2 – Ground : Continuity should not exist.**




5. Check continuity between steering switch harness connector M444 terminal 3 and ground.

**3 – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 6.  
NG >> Repair harness or connector.




## 6. CHECK SPIRAL CABLE

1. Disconnect combination switch (spiral cable) connector.
2. Check continuity between combination switch (spiral cable) connector M53 terminal 25 and connector M441 terminal 19.

**25 – 19 : Continuity should exist.**

OK or NG

- OK >> GO TO 7.  
NG >> Replace spiral cable.



## 7. CHECK HARNESS

1. Disconnect multifunction switch connector.
2. Check continuity between combination switch (spiral cable) harness connector M53 terminal 25 and multifunction switch harness connector M83 terminal 7.


**25 – 7 : Continuity should exist.**

3. Check continuity between combination switch (spiral cable) harness connector M53 terminal 25 and ground.

**25 – Ground : Continuity should not exist.**

OK or NG



- OK >> GO TO 8.
- NG >> Repair harness or connector.



## 8. CHECK COMMUNICATION SIGNAL

1. Connect steering switch, combination switch (spiral cable) and multifunction switch connectors.
2. Turn ignition switch ON.
3. Check voltage waveform between steering switch harness connector M444 terminal 2 and ground with CONSULT-II or oscilloscope, when operating the steering switch.

**2 – Ground:**



OK or NG

- OK >> Replace multifunction switch.
- NG >> Replace steering switch.

## Rear Control Switch Does Not Operate

NKS00115

### 1. CONFIRM STATUS OF REAR CONTROL CANCEL SWITCH

Is rear control cancel switch in the status of cancel?

YES or NO

- YES >> After turning on the switch reconfirm the status.
- NO >> GO TO 2.

### 2. SELF-DIAGNOSIS MODE OF MULTIFUNCTION SWITCH

1. Perform the self-diagnosis mode in the self-diagnosis function. Refer to [DI-136. "Multifunction Switch Self-Diagnosis Function"](#) (Without navigation system), or [DI-165. "Multifunction Switch Self-Diagnosis Function"](#) (With navigation system).
2. Press rear control switch.

**Beep sound should operate.**

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 3.

# AUDIO


## 3. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear control cancel switch harness connector R16 terminal 4 and ground.

**4 – Ground** : **Battery voltage**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.



## 4. CHECK REAR CONTROL CANCEL SWITCH


1. Turn ignition switch OFF.
2. Disconnect rear control cancel switch connector.
3. Check continuity between rear control cancel switch terminals 3 and 4.

**When press “ON”** : **Continuity should exist.**

**When press “CANCEL”** : **Continuity should not exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Replace rear control cancel switch.



## 5. CHECK HARNESS

1. Disconnect rear control cancel relay connector.
2. Check continuity between rear control cancel switch harness connector R16 terminal 3 and rear control cancel relay harness connector B253 terminal 2.


**3 – 2** : **Continuity should exist.**

3. Check continuity between rear control cancel switch harness connector R16 terminal 3 and ground.

**3 – Ground** : **Continuity should not exist.**

OK or NG

- OK >> GO TO 6.  
NG >> Repair harness or connector.





# AUDIO

## 6. CHECK REAR CONTROL CANCEL RELAY GROUND CIRCUIT


Check continuity rear control cancel relay harness connector B253 terminal 1 and ground.

**1 – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 7.

NG >> Repair harness or connector.



## 7. CHECK REAR CONTROL CANCEL RELAY


1. Supply 12 V current between rear control cancel relay terminals 1 and 2.
2. Check continuity between rear control cancel relay terminals 3 and 5.

**3 – 5 : Continuity should exist.**

OK or NG

OK >> GO TO 8.

NG >> Replace rear control cancel relay.



## 8. CHECK POWER SUPPLY CIRCUIT


1. Connect rear control cancel switch and rear control cancel relay connectors.
2. Turn ignition switch ON.
3. Check voltage between rear control cancel relay harness connector B253 terminal 3 and ground.

**3 – Ground : Battery voltage**

OK or NG

OK >> GO TO 9.

NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# AUDIO

## 9. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect rear control switch and rear control cancel relay connectors.
3. Check continuity between rear control switch harness connector B502 terminal 1 and rear control cancel relay harness connector B253 terminal 5.

**1 – 5 : Continuity should exist.**


4. Check continuity between rear control switch harness connector B502 terminal 1 and ground.

**1 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 10.

NG >> Repair harness or connector.



## 10. CHECK HARNESS


Check continuity between rear control switch harness connector B502 terminal 12 and ground.

**12 – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 11.

NG >> Repair harness or connector.



## 11. CHECK HARNESS

1. Disconnect multifunction switch connector.
2. Check continuity between rear control switch harness connector B502 terminal 10 and multifunction switch harness connector M83 terminal 8.

**10 – 8 : Continuity should exist.**


3. Check continuity between rear control switch harness connector B502 terminal 10 and ground.

**10 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 12.

NG >> Repair harness or connector.





# AUDIO

## 12. CHECK COMMUNICATION SIGNAL

1. Connect multifunction switch, rear control switch, rear control cancel relay and rear control cancel switch connectors.
2. Turn ignition switch ON.
3. Check voltage waveform between rear control switch harness connector B502 terminal 10 and ground with CONSULT-II or oscilloscope, when operating the rear control switch.

**10 – Ground:**



OK or NG

- OK >> Replace multifunction switch.  
 NG >> Replace rear control switch.



## AudioPilot® Does Not Work

NKS00116

### 1. CHECK MICROPHONE SIGNAL

1. Turn ignition switch ON.
2. Check voltage waveform between BOSE speaker amp. harness connector B231 terminals 3 and 4 with CONSULT-II or oscilloscope, when inputting some sounds (voice, etc.) toward the microphone.

**3 – 4:**



Does the voltage waveform change with sounds?

- YES >> Replace BOSE speaker amp.  
 NO >> GO TO 2.

## 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. and microphone connectors.
3. Check continuity between BOSE speaker amp. harness connector B231 terminal 3 and microphone harness connector M73 terminal 1.


**3 – 1 : Continuity should exist.**

4. Check continuity between BOSE speaker amp. harness connector B231 terminal 3 and ground.

**3 – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.



# AUDIO

## 3. CHECK HARNESS

1. Check continuity between BOSE speaker amp. harness connector B231 terminal 4 and microphone harness connector M73 terminal 2.


**4 – 2** : Continuity should exist.

2. Check continuity between BOSE speaker amp. harness connector B231 terminal 4 and ground.

**4 – Ground** : Continuity should not exist.

OK or NG

- OK >> Replace microphone.  
NG >> Repair harness or connector.




## Removal and Installation of Audio Unit

### REMOVAL

NKS00117

1. Remove glove box cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove screws (2), and remove audio unit.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of CD Auto Changer

### REMOVAL

NKS00118

1. Remove cluster lid center lower. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove console box assembly. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
3. Remove screws (4), and remove CD auto changer.



### INSTALLATION

Installation is the reverse order of removal.


# AUDIO

## Removal and Installation of Door Speaker

NKS00119

### REMOVAL

1. Remove door finisher. Refer to [EI-35, "DOOR FINISHER"](#) .
2. Remove screws (3), and remove speaker.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of Instrument Panel Speaker

NKS0011A

### REMOVAL

1. Remove instrument panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove screws (4), and remove instrument panel speaker.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of Woofer

NKS0011B

### REMOVAL

1. Remove rear parcel shelf finisher. Refer to [EI-48, "REAR PARCEL SHELF FINISHER"](#) .
2. Remove screws (4), and remove woofer.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV


# AUDIO

## Removal and Installation of BOSE Speaker Amp.

NKS0011C

### REMOVAL

1. Remove trunk front finisher. Refer to [EI-60, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove rear parcel shelf finisher. Refer to [EI-48, "REAR PARCEL SHELF FINISHER"](#) .
3. Remove screws (4), and remove BOSE speaker amp. from the trunk room side.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of AudioPilot® Microphone

NKS0011D

### REMOVAL

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove clock. Refer to [DI-227, "Removal and Installation"](#) .
3. Disconnect AudioPilot® microphone connector.
4. Remove screws (2), and remove AudioPilot® microphone.



### INSTALLATION

Installation is the reverse order of removal.

## Removal and Installation of Steering Wheel Switch

NKS0011E

Refer to [SRS-40, "DRIVER AIR BAG MODULE"](#) .

## Removal and Installation of Multifunction Switch

NKS002KF

Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .


# AUDIO

## Removal and Installation of Rear Control Switch

NKS0011F

### REMOVAL

1. Remove tray box from the center armrest. Refer to [SE-191, "REAR SEAT"](#) .
2. Remove rear control switch from tray box.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of Rear Control Cancel Switch

NKS0011G

### REMOVAL

1. Remove front interior lamp. Refer to [LT-143, "FRONT INTERIOR LAMP"](#) .
2. Remove rear control cancel switch from front interior lamp.



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# AUDIO


## Removal and Installation of Satellite Radio Tuner

NKS002JT

### REMOVAL

⇐: Vehicle front

1. Remove trunk side finisher (left). Refer to [EI-60, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove screws (A), and remove satellite radio tuner (1) and active damper suspension control unit (2) from vehicle.
3. Remove satellite radio tuner from bracket.



### INSTALLATION

Installation is the reverse order of removal.


## Removal and Installation of Satellite Radio Antenna

NKS002JU

### REMOVAL

⇐: Vehicle front

1. Remove head lining. Refer to [EI-58, "HEADLINING"](#) .
2. Remove nut (A), and then disconnect connector (1).
3. Remove satellite radio antenna.



### INSTALLATION

Installation is the reverse order of removal.

**Roof antenna mounting nut**  : 6.5 N·m (0.66 kg·m, 58 in·lb)






# ANTENNA

NKS002H8


## Location of Antenna RADIO ANTENNA



SKIB7606E

# ANTENNA

## SATELLITE RADIO ANTENNA AND TEL ANTENNA




# ANTENNA


## Window Antenna Repair CHECK ELEMENT

NKS002H9


1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.



- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.




2. If an element is broken, no continuity will exist.



# ANTENNA

3. To locate a break, move probe along element. Tester needle will swing abruptly when probe passes the broken point.



## Removal and Installation of Satellite Radio Antenna

Refer to [AV-56, "Removal and Installation of Satellite Radio Antenna"](#) .

## Removal and Installation of TEL Antenna

Refer to [AV-158, "Removal and Installation for TEL Antenna"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

## NAVIGATION SYSTEM

PF25915

### System Description


NKS001L

For Navigation System operation information, refer to Navigation System Owner's Manual.

### LOCATION DETECTION PRINCIPLE

The navigation system periodically calculates the vehicle's current position according to the following three signals:


- Travel distance of the vehicle as determined by the vehicle speed sensor
- Turning angle of the vehicle as determined by the gyroscope (angular velocity sensor)
- Direction of vehicle travel as determined by the GPS antenna (GPS information)



The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the DVD-ROM, which is stored in the DVD-ROM drive (map-matching), and indicated on the screen as a current-location mark. More accurate data is judged and used by comparing vehicle position detection results found by the GPS with the result by map-matching.

The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.

- Travel distance  
Travel distance calculations are based on the vehicle speed sensor input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance correction function has been adopted.
- Travel direction  
Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). They have both advantages and disadvantages.



Type	Advantage	Disadvantage
Gyroscope (angular velocity sensor)	Can detect the vehicle's turning angle quite accurately.	Direction errors may accumulate when vehicle is driven for long distances without stopping.
GPS antenna (GPS information)	Can detect the vehicle's travel direction (North/South/East/West).	Correct direction cannot be detected when vehicle speed is low.

More accurate traveling direction is selected because priorities are set for the signals from these two devices according to the situation.


# NAVIGATION SYSTEM

## MAP-MATCHING

Map-matching compares a current location detected by the method in the "Location Detection Principle" with a road map data from DVD-ROM stored in DVD-ROM drive.

### NOTE:


The road map data is based on data stored in the DVD-ROM.



The vehicle position may not be corrected under the following circumstances and after driving for a certain time when GPS information is difficult to receive. In this case, the current-location mark on the display must be corrected manually.

- In map-matching, alternative routes are prepared and prioritized in addition to the road judged currently driven. Due to the distance and/or direction error, the incorrect road may be prioritized and current-location mark may be repositioned to the wrong road.


When two roads are running in parallel, they are judged to the same priority. Therefore, the current-location mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.



- Map-matching does not function correctly when a road on which the vehicle is driving is new and not recorded in the DVD-ROM, or when road pattern stored in the map data and the actual road pattern are different due to repair.

When driving on a road not present in the map, the map-matching function may find another road and position the current-location mark on it. Then, when the correct road is detected, the current-location mark may change to it.

- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the DVD-ROM is limited. Therefore, when there is an excessive gap between current vehicle position and the position on the map, correction by map-matching is not possible.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

## GPS (GLOBAL POSITIONING SYSTEM)

GPS (Global Positioning System) was developed for and is controlled by the US Department of Defense. The system utilizes GPS satellites (NAVSTAR), sending out radio waves while flying on an orbit around the earth at an altitude of approximately 21,000 km (13,100 miles).

The GPS receiver calculates the vehicle's position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves received from four or more GPS satellites (three-dimensional positioning). If radio waves were received only from three GPS satellites, the GPS receiver calculates the vehicle's position in two dimensions (latitude/longitude), and utilize the altitude data calculated previously with radio waves from four or more GPS satellites (two-dimensional positioning).


Position correction by GPS is not available while the vehicle is stopped.

Accuracy of GPS will deteriorate under the following conditions:

- In two-dimensional positioning, GPS accuracy will deteriorate when altitude of the vehicle position changes.
- The accuracy can be even lower depending on the arrangement of the GPS satellites utilized for the positioning.
- Position detection is not possible when vehicle is in an area where radio waves from the GPS satellite do not reach, such as in a tunnel, parking lot in a building, and under an elevated highway. Radio waves from the GPS satellites may not be received when some object is located over the GPS antenna.

### NOTE:

- Even a high-precision three dimensional positioning, the detection result has an error about 10 m (30ft).
- Because the signals of GPS satellite is controlled by the Tracking and Control Center in the United States, the accuracy may be degraded lower intentionally or the radio waves may stop.






# NAVIGATION SYSTEM

## Component Description AV AND NAVI CONTROL UNIT


NKS001M

- The gyro (angular speed sensor) and the DVD-ROM drive are built-in units that control the navigation functions.
- Signals are received from the gyro, the vehicle speed sensor, and the GPS antenna. Vehicle location is determined by combining these data with the data contained in the DVD-ROM map. Locations information is shown on display unit.
- AV and NAVI control unit is connected to each control unit composing systems. The systems are controlled by transmitting and receiving request signals and response signal.
- NAVI control unit outputs ON signal and voice guidance signal to audio unit.



## DVD-ROM Drive

Maps, traffic control regulations, and other pertinent information can be easily read from the DVD-ROM.



## DVD-ROM


- The DVD-ROM has maps, traffic control regulations, and other pertinent information.
- To improve DVD-ROM map matching and route determination functions, the DVD-ROM uses an exclusive Nissan format. Therefore, the use of a DVD-ROM provided by other manufacturers cannot be used.

## Gyro (Angular Speed Sensor)

- The oscillator gyro sensor is used to detect changes in vehicle steering angle.
- The gyro is built into the NAVI control unit.

## GPS ANTENNA

The GPS antenna receives and amplifies the radio waves from the GPS satellites, and then transmits the GPS signal to AV and NAVI control unit.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J


AV

L  
M

# NAVIGATION SYSTEM

## Component Parts Location

NKS0011N



SKIB7671E

## Location of Antenna


NKS0011O

Refer to [AV-58, "Location of Antenna"](#) .

# NAVIGATION SYSTEM

## Schematic — NAVI —

NKS0011P



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M



TKWM1355E

# NAVIGATION SYSTEM

## Wiring Diagram — NAVI —

NKS0011Q

AV-NAVI-01



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.







REFER TO THE FOLLOWING.

- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)
- (M4) -ELECTRICAL UNITS

TKWM3798E

# NAVIGATION SYSTEM

AV-NAVI-02







REFER TO THE FOLLOWING.  
 (M4), (R4) -ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

# NAVIGATION SYSTEM


AV-NAVI-03



TKWM1358E


# NAVIGATION SYSTEM

AV-NAVI-04



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV



REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)






(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM3800E

# NAVIGATION SYSTEM

AV-NAVI-05




TKWM3801E



# NAVIGATION SYSTEM

AV-NAVI-06



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M131) BR

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16		7	4	1		

(B30) W





REFER TO THE FOLLOWING.

- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3802E

# NAVIGATION SYSTEM

AV-NAVI-07



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.





REFER TO THE FOLLOWING.  
(B211), (D1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3803E

# NAVIGATION SYSTEM

AV-NAVI-08

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M




REFER TO THE FOLLOWING.  
(M5) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3804E

# NAVIGATION SYSTEM

AV-NAVI-09

▬ : DATA LINE



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M6)  
GY

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82)  
GY

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83)  
W

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40				31	28	25


(B29)  
GY

TKWM1363E



# NAVIGATION SYSTEM

## WITHOUT SATELLITE RADIO




TKWM3806E

# NAVIGATION SYSTEM

## Wiring Diagram — COMM — / With Voice Activated Control System WITH SATELLITE RADIO

NKS001S

### AV-COMM-01



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M13)  
BR

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40				31	28	25

(B29)  
GY

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16				7	4	1

(B30)  
W

34	32	30	28	26	24	22	20	18	16	14
33	31	29	27	25	23	21	19	17	15	13

(B69)  
W

35	36
37	

(B71)  
GY

REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)



(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3807E

# NAVIGATION SYSTEM


## AV-COMM-02



TKWM3808E



# NAVIGATION SYSTEM



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M6) GY

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82) GY

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83) W

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40	31	28	25			

(B29) GY

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16	7	4	1			


(B30) W

TKWM3809E

# NAVIGATION SYSTEM

**AV-COMM-04**

▬ : DATA LINE



20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83) W

7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

(M84) W

16	14	12	8	6	4	2		
15	13	11	10	9	7	5	3	1

(M87) W




REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWM3810E


# NAVIGATION SYSTEM

AV-COMM-05

▬ : DATA LINE







REFER TO THE FOLLOWING.  
 (B211) -SUPER MULTIPLE JUNCTION (SMJ)



TKWM3811E

# NAVIGATION SYSTEM

AV-COMM-06







REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3812E

# NAVIGATION SYSTEM

## WITHOUT SATELLITE RADIO

### AV-COMM-07



REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)



(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3975E

# NAVIGATION SYSTEM


AV-COMM-08



TKWM3976E

# NAVIGATION SYSTEM

## AV-COMM-09



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1





48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40				31	28	25

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16				7	4	1

TKWM3977E

# NAVIGATION SYSTEM

## AV-COMM-10



REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1



TKWM3978E



# NAVIGATION SYSTEM

**AV-COMM-11**





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M



TKWM3979E

# NAVIGATION SYSTEM

AV-COMM-12




REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3813E

# NAVIGATION SYSTEM

## Schematic — COMM — / Without Voice Activated Control System

NKS002MB



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M





TKWM3815E

# NAVIGATION SYSTEM

## Wiring Diagram — COMM — / Without Voice Activated Control System

NKS002MC

### AV-COMM-13



REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)


(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3816E

# NAVIGATION SYSTEM

**AV-COMM-14**



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M6)  
GY

24	22	20	18	16	14	10	8	6	4	2		
23	21	19	17	15	13	12	11	9	7	5	3	1

(M82)  
GY

20	18	16	14	12	8	6	4	2		
19	17	15	13	11	10	9	7	5	3	1

(M83)  
W

48	45	42	39	37	35	33	30	27
47	44	41	38	36	34	32	29	26
46	43	40	31	28	25			

(B29)  
GY

24	21	18	15	13	11	9	6	3
23	20	17	14	12	10	8	5	2
22	19	16	7	4	1			





(B30)  
W

TKWM3817E

# NAVIGATION SYSTEM

## AV-COMM-15

▬ : DATA LINE






REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWM3818E


# NAVIGATION SYSTEM

AV-COMM-16

▬ : DATA LINE








REFER TO THE FOLLOWING.  
 B211 -SUPER MULTIPLE JUNCTION (SMJ)



TKWM3819E

# NAVIGATION SYSTEM

AV-COMM-17



REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM3821E



# NAVIGATION SYSTEM

## Terminals and Reference Value for AV and NAVI Control Unit





NKS0011T

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
1 (B)	Ground	Ground	—	ON	—	Approx. 0 V
2 (SB)	Ground	Battery power supply	Input	OFF	—	Battery voltage
3 (SB)						
4 (B)	Ground	Ground	—	ON	—	Approx. 0 V
6 (L/OR)	Ground	ACC power supply	Input	ACC	—	Battery voltage
7 (R)	8 (L)	Voice guidance signal	Output	ON	Press "VOICE" button	
9	—	Shield	—	—	—	—
11 (R)	Ground	Vertical synchronizing (VP) signal	Input	ON	Set the selector lever in R position, and then display the rear view image	
					Other than the above	Approx. 0 V
12 (B)	Ground	RGB area (YS) signal	Output	ON	Set the selector lever in R position, and then display the rear view image	
					Other than the above	
13 (W)	Ground	Horizontal synchronizing (HP) signal	Input	ON	Set the selector lever in R position, and then display the rear view image	
					Other than the above	Approx. 0 V
14	—	Shield	—	—	—	—








A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
15 (LG)	Ground	RGB signal (B: blue)	Output	ON	Start Confirmation/Adjustment mode, and then display color bar by selecting "Display Color Spectrum Bar" on DISPLAY DIAGNOSIS screen	 <small>SKIB3602E</small>
16 (G)	Ground	RGB synchronizing signal	Output	ON	When displaying RGB image	 <small>SKIB3603E</small>
18 (L)	Ground	RGB signal (R: red)	Output	ON	Start Confirmation/Adjustment mode, and then display color bar by selecting "Display Color Spectrum Bar" on DISPLAY DIAGNOSIS screen	 <small>SKIB3604E</small>
19	—	Shield	—	—	—	—
21 (PU)	Ground	RGB signal (G: green)	Output	ON	Start Confirmation/Adjustment mode, and then display color bar by selecting "Display Color Spectrum Bar" on DISPLAY DIAGNOSIS screen	 <small>SKIB3605E</small>
22 (W)	Ground	Camera-connection recognition signal	Input	ON	Connected to rear view camera control unit connector	Approx. 0 V
					Not connected rear view camera control unit connector	Approx. 5 V
25 (R/L)	Ground	Illumination dimmer signal	Input	ON	Lighting switch is ON, and then optical sensor is not illuminated	Approx. 12 V
					Lighting switch OFF	Approx. 0 V
					Lighting switch is ON, and then optical sensor is illuminated	
26 (W/G)	Ground	Ignition signal	Input	ON	—	Battery voltage
27 (R/B)	Ground	Reverse signal	Input	ON	Select R position	Approx. 12 V
					Other position	Approx. 0 V






# NAVIGATION SYSTEM

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
28 (OR/L)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>
31	—	Shield	—	—	—	—
32 (PU)	Ground	Communication signal (ME-AV)	Input	ON	—	 <p style="text-align: right; font-size: small;">SKIB7619E</p>
33 (LG)	Ground	Communication signal (AV-ME)	Output	ON	—	 <p style="text-align: right; font-size: small;">SKIB7620E</p>
34 (P)	Ground	Communication signal (AV-CN)	Output	ON	Perform CONSULT-II	 <p style="text-align: right; font-size: small;">SKIB7621E</p>
35 (BR/Y)	Ground	Communication signal (CN-AV)	Input	ON	Perform CONSULT-II	 <p style="text-align: right; font-size: small;">SKIB7622E</p>
36	—	Shield	—	—	—	—
37 (W)	Ground	Communication signal (AC-AV)	Input	ON	—	 <p style="text-align: right; font-size: small;">SKIB7623E</p>
38 (R)	Ground	Communication signal (AV-AC)	Output	ON	—	 <p style="text-align: right; font-size: small;">SKIB7624E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
39 (B)	Ground	A/C clock signal	Input	ON	—	 <small>SKIB7625E</small>
43	—	Shield	—	—	—	—
44 (Y)	Ground	Communication signal (+)	Input/ Output	ON	—	 <small>SKIB7378E</small>
45 (BR)	Ground	Communication signal (-)	Input/ Output	ON	—	 <small>SKIB7379E</small>
46	—	Shield	—	—	—	—
47 (LG)	Ground	Communication signal (+)	Input/ Output	ON	—	 <small>SKIB7378E</small>
48 (PU)	Ground	Communication signal (-)	Input/ Output	ON	—	 <small>SKIB7379E</small>
66	Ground	GPS signal	Input	ON	Connector is not connected	Approx. 5 V
67	—	Shield	—	—	—	—

## Terminals and Reference Value for Display

NKS001IU

Refer to [DI-162, "Terminals and Reference Value for Display"](#) .

## Terminals and Reference Value for Multifunction Switch

NKS001IV

Refer to [DI-164, "Terminals and Reference Value for Multifunction Switch"](#) .

## Terminals and Reference Value for Voice Activated Control Module

NKS001IW

Refer to [DI-210, "Terminals and Reference Values for Voice Activated Control Module"](#) .

# NAVIGATION SYSTEM

## Special Note for Trouble Diagnosis

NKS002KN

Prior to perform trouble diagnosis, make sure there are no corresponding description in the "Example of Symptoms Possible No Malfunction". Refer to [AV-128, "Example of Symptoms Possible No Malfunction"](#) .

## On Board Self-Diagnosis Function (Without CONSULT-II)

NKS001IX

### DESCRIPTION


- Trouble diagnosis function of navigation system has a Self Diagnosis mode by automatic operation and a Confirmation/Adjustment mode by manual operation.
- Self Diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the display.
- Confirmation/Adjustment mode displays trouble diagnosis that require an operation and a judgment by a human (auto-decision can not be performed by the system), confirmation of preset value, and an error history.
- If the on board self-diagnosis does not start (because the display is not displayed, the multifunction switch operation is not activated, etc.), perform diagnosis using CONSULT-II. Refer to [AV-115, "CONSULT-II Function \(MULTI AV\)"](#) .

### DIAGNOSIS ITEM


Mode		Description	
Self Diagnosis		<ul style="list-style-type: none"> <li>● AV and NAVI control unit diagnosis (DVD-ROM drive will not be diagnosed when no DVD-ROM is in it).</li> <li>● Analyzes connection between the AV and NAVI control unit and the GPS antenna, connection between the AV and NAVI control unit and each unit, and operation of each unit.</li> </ul>	
Confirmation/ Adjustment	Display Diagnosis	Color tone and shading of the screen can be checked by the display of a color bar and a gray scale.	
	Vehicle Signals	Diagnosis of signals that are input to AV and NAVI control unit can be performed for Vehicle Speed, Light, IGN (ignition switch) and Reverse.	
	History of Errors	Malfunctions that occurred in the past are displayed, along with the number of times each has occurred. Time and location when/where the errors occurred are also displayed.	
	Rearview	The guiding line position that overlaps rear view camera image can be adjusted. Refer to <a href="#">DI-185, "Side Distance Guideline Correction"</a> .	
	Navigation	Display Longitude & Latitude	This mode is to display the map. Use the joystick to adjust position. Longitude and latitude will be displayed.
		Speed Calibration	Under ordinary conditions, the navigation system distance measuring function will automatically compensate for minute decreases in wheel and tire diameter caused by tire wear or low-pressure. Speed Calibration can immediately restore system accuracy in cases such as when distance calibration is needed because of the use of tire chains.
		Angle Adjustment	This mode is used to correct difference between actual turning angle of a vehicle and turning angle of the vehicle mark on the display.
		Initialize Location	This mode is for initializing the current location. Use when the vehicle is transported a long distance on a trailer, etc.
	Auto Climate Control		Turns all A/C screens on display and A/C switch indicator lamp on. Refer to <a href="#">ATC-53, "Self-diagnosis Function"</a> .
	Speaker Test		Refer to <a href="#">AV-40, "DIAGNOSIS ITEM"</a> .
Voice Mic. Test		Refer to <a href="#">DI-211, "DIAGNOSIS ITEM"</a> .	

## Self-Diagnosis Mode OPERATION PROCEDURE


1. Start the engine.
2. Turn the audio system OFF.
3. While pressing the "INFO" button, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
  - Shifting from current screen to previous screen is performed by pressing "PREV" button.




4. The initial trouble diagnosis screen will be shown, and items "Self Diagnosis" and "Confirmation/Adjustment" will become selective.



5. Perform self-diagnosis by selecting the "Self Diagnosis".
  - Self-diagnosis screen is displayed, and then self-diagnosis starts.
  - The bar graph visible below self-diagnosis screen displays progress of the diagnosis.



6. When the self-diagnosis completes, optional part confirmation screen will be shown.
  - When connection of an optional part is judged error, a screen to check if the optional part is actually fitted on the vehicle or not will be shown. When fitted, select the switch of the part on the screen and press "End". Then the "SELF DIAGNOSIS" screen will be shown.
  - When the optional part is connected normally, the switch for the part will not appear on the screen.



# NAVIGATION SYSTEM

7. On the diagnosis results screen, each unit name will be colored according to the diagnosis result, as follows.

**Green** : No malfunctioning.


**Yellow** : Cannot be judged by self-diagnosis results.

**Red** : Unit is malfunctioning.


**Gray** : Diagnosis has not been done.

**NOTE:**

- Audio AMP = BOSE speaker amp.
- Center Control Unit = AV and NAVI control unit
- Bluetooth Handsfree Unit = TEL adapter unit
- SAT = Satellite radio tuner
- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > yellow > gray.



8. Select a switch on the diagnosis results screen, and comments for the diagnosis results will be shown.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

## SELF-DIAGNOSIS RESULT

### Quick Reference Table

1. Select the applicable diagnosis number in the quick reference table of diagnosis result.
2. Confirm the possible malfunction with the diagnosis table, and then perform inspection.
3. Turn ignition switch OFF and perform self-diagnosis again.

Switch color	Screen switch									Diagnosis No.
	Audio AMP	Center Control Unit	Audio Unit	Voice Activated Control Module	Tire Pressure Control Unit	Bluetooth Hands-free Unit	GPS Antenna	CD Changer	SAT	
Red		×								1
Gray		×								2
Yellow		×								3
		×					×			4
	×	×	×					× (Gray)	× (Gray)	5
		×			×					6
	×	×								7
		×	×					× (Gray)	× (Gray)	8
				×				×		9
				×				×	×	10
Screen switch not displayed*				×						11
						×				12
				×		×				13
			×		×					14

**NOTE:**

- Audio AMP = BOSE speaker amp.
- Center Control Unit = AV and NAVI control unit
- Bluetooth Handsfree Unit = TEL adapter unit
- SAT = Satellite radio tuner

\*: In a case that screen switches (on the self-diagnosis result screen) are not displayed though the vehicle has voice activated control module, or TEL adapter unit, or both of them.



# NAVIGATION SYSTEM

## Self-diagnosis Codes

Diagnosis No.	Possible cause	Action to take
1	AV and NAVI control unit malfunction is detected	Replace AV and NAVI control unit
2	DVD-ROM not inserted is detected	Insert DVD-ROM
3	<ul style="list-style-type: none"> <li>● Malfunction is detected on DVD-ROM drive pickup lens in AV and NAVI control unit</li> <li>● There is dirt and damage on the DVD-ROM</li> </ul>	<ol style="list-style-type: none"> <li>1. Check if the inserted DVD-ROM is specified for this navigation system, and the DVD-ROM is dirty, scratched or warped.</li> <li>2. If the results from the above checkup show no malfunction, insert the same DVD-ROM, and then restart self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace AV and NAVI control unit.</li> </ol>
4	GPS antenna connection malfunction is detected	<ol style="list-style-type: none"> <li>1. Check if GPS antenna feeder line is snapped or pinched.</li> <li>2. If the results from the above checkup show no malfunction, replace GPS antenna, and then restart self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace AV and NAVI control unit.</li> </ol>
5	Malfunction is detected on communication signal between multifunction switch and audio unit	<ol style="list-style-type: none"> <li>1. Check communication circuit between multifunction switch and audio unit.</li> <li>2. If the results from the above checkup show no malfunction, replace either multifunction switch or audio unit, and then start self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
6	<ul style="list-style-type: none"> <li>● Low tire pressure warning control unit power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between multifunction switch and low tire pressure warning control unit</li> </ul>	<ol style="list-style-type: none"> <li>1. Check low tire pressure warning control unit power supply and ground circuit.</li> <li>2. Check communication circuit between multifunction switch and low tire pressure warning control unit.</li> <li>3. If the results from the above checkup show no malfunction, replace either multifunction switch or low tire pressure warning control unit, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
7	<ul style="list-style-type: none"> <li>● BOSE speaker amp. power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between audio unit and BOSE speaker amp.</li> </ul>	<ol style="list-style-type: none"> <li>1. Check BOSE speaker amp. power supply and ground circuit.</li> <li>2. Check communication circuit between audio unit and BOSE speaker amp.</li> <li>3. If the results from the above checkup show no malfunction, replace either audio unit or BOSE speaker amp., and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
8	Audio unit power supply and ground circuit malfunction is detected	<ol style="list-style-type: none"> <li>1. Check audio unit power supply circuit.</li> <li>2. If the results from the above checkup show no malfunction, replace audio unit.</li> </ol>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

Diagnosis No.	Possible cause	Action to take
9	<p><b>Without satellite radio</b></p> <ul style="list-style-type: none"> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO)] between audio unit and CD auto changer</li> </ul>	<ol style="list-style-type: none"> <li>1. Check communication circuit [REQ (CHG-AUDIO)] between audio unit and CD auto changer.</li> <li>2. Check communication signal [REQ (CHG-AUDIO)] between audio unit and CD auto changer.</li> <li>3. If the results from the above checkup show no malfunction, replace either audio unit or CD auto changer, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
	<p><b>With satellite radio</b></p> <ul style="list-style-type: none"> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO)] between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on control signal (CONT) between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO)] between satellite radio tuner and CD auto changer</li> </ul>	<ol style="list-style-type: none"> <li>1. Check communication circuit [REQ (CHG-AUDIO)] between audio unit and satellite radio tuner.</li> <li>2. Check control signal circuit (CONT) between audio unit and satellite radio tuner.</li> <li>3. Check communication circuit [REQ (CHG-AUDIO)] between satellite radio tuner and CD auto changer.</li> <li>4. Check communication signal [REQ (CHG-AUDIO)] between audio unit and satellite radio tuner.</li> <li>5. Check control signal (CONT) between audio unit and satellite radio tuner.</li> <li>6. Check communication signal [REQ (CHG-AUDIO)] between satellite radio tuner and CD auto changer.</li> <li>7. If the results from the above checkup show no malfunction, replace audio unit, satellite radio tuner, or CD auto changer, and then start self-diagnosis.</li> <li>8. If self-diagnosis results still show any malfunction, replace one of the two units that is not replaced yet.</li> <li>9. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
10	<ul style="list-style-type: none"> <li>● Satellite radio tuner power supply and ground circuit malfunction is detected</li> <li>● CD auto changer power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on control signal (CONT) between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer</li> </ul>	<ol style="list-style-type: none"> <li>1. Check satellite radio tuner power supply and ground circuit.</li> <li>2. Check CD auto changer power supply and ground circuit.</li> <li>3. Check communication circuit [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner.</li> <li>4. Check control signal circuit (CONT) between audio unit and satellite radio tuner.</li> <li>5. Check communication circuit [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer.</li> <li>6. Check communication signal [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner.</li> <li>7. Check control signal (CONT) between audio unit and satellite radio tuner.</li> <li>8. Check communication signal [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer.</li> <li>9. If the results from the above checkup show no malfunction, replace audio unit, satellite radio tuner, or CD auto changer, and then start self-diagnosis.</li> <li>10. If self-diagnosis results still show any malfunction, replace one of the two units that is not replaced yet.</li> <li>11. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>

# NAVIGATION SYSTEM

Diagnosis No.	Possible cause	Action to take	A
11	Malfunction is detected on communication signal [REQ (SAT-AUDIO)] between audio unit and satellite radio tuner	<ol style="list-style-type: none"> <li>1. Check communication circuit [REQ (SAT-AUDIO)] between audio unit and satellite radio tuner.</li> <li>2. Check communication signal [REQ (SAT-AUDIO)] between audio unit and satellite radio tuner.</li> <li>3. If the results from the above checkup show no malfunction, replace either audio unit or satellite radio tuner, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>	B C D
12	Voice activated control module power supply and ground circuit malfunction is detected	<ol style="list-style-type: none"> <li>1. Check voice activated control module power supply and ground circuit.</li> <li>2. If the results from the above checkup show no malfunction, replace voice activated control module.</li> </ol>	E
13	<ul style="list-style-type: none"> <li>● TEL adapter unit power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between voice activated control module and TEL adapter unit</li> </ul>	<ol style="list-style-type: none"> <li>1. Check TEL adapter unit power supply and ground circuit.</li> <li>2. Check communication circuit between voice activated control module and TEL adapter unit.</li> <li>3. If the results from the above checkup show no malfunction, replace either voice activated control module or TEL adapter unit, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>	F G H
14	Malfunction is detected on communication signal between AV and NAVI control unit and voice activated control module	<ol style="list-style-type: none"> <li>1. Check communication circuit between AV and NAVI control unit and voice activated control module.</li> <li>2. If the results from the above checkup show no malfunction, replace either AV and NAVI control unit or voice activated control module, and then start self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>	I J

AV

L


M

# NAVIGATION SYSTEM


NKS001Z

## Confirmation/Adjustment Mode OPERATION PROCEDURE


1. Start the engine.
2. Turn the audio system OFF.
3. While pressing the "INFO" button, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
  - Shifting from current screen to previous screen is performed by pressing "PREV" button.



4. The initial trouble diagnosis screen will be shown, and items "Self Diagnosis" and "Confirmation/Adjustment" will become selective.
5. Select "Confirmation/Adjustment".




6. Each diagnosis is shown by selecting each screen switch on Confirmation/Adjustment screen.



# NAVIGATION SYSTEM

## DISPLAY DIAGNOSIS



- If RGB signal is malfunctioning, the tint of the color bar display is as follows.

**R (red) signal error** : Light blue (Cyan) tint  
**G (green) signal error** : Purple (Magenta) tint  
**B (blue) signal error** : Yellow tint

A

B

C

D

E

F

G

H

I

J

AV


L

M

# NAVIGATION SYSTEM

## VEHICLE SIGNALS

A comparison check can be made of each actual vehicle signal and the signals recognized by the AV and NAVI control unit.



Diagnosis item	Display	Condition	Remarks
Vehicle Speed	ON	When vehicle speed is more than 0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	When vehicle speed is 0 km/h (0 MPH)	
	—	Ignition switch in ACC position	
Lights	ON	Lighting switch is ON, and then optical sensor is not illuminated	—
	OFF	Lighting switch OFF Lighting switch is ON, and then optical sensor is illuminated	
Ignition	ON	Ignition switch ON	—
	OFF	Ignition switch ACC position	
Reverse	ON	Selector lever in R position	Changes in indication may be delayed. This is normal.
	OFF	Selector lever in any position other than R position	
	—	Ignition switch in ACC position	

**NOTE:**

If ignition signal is NG, each vehicle signal of vehicle speed and reverse is not displayed.

# NAVIGATION SYSTEM

## HISTORY OF ERRORS


Diagnosis results of self-diagnosis depend on if any error occurred during the time after selecting “Self Diagnosis” until self-diagnosis results is displayed.

Meanwhile, when an error occurs before selecting “Self Diagnosis”, and if an error does not occur until self-diagnosis results is displayed, a diagnosis result is judged as normal.

Consequently, a diagnosis needs to be performed with “History of Errors” for the past error that is not available with self-diagnosis.

“History of Errors” displays the time and place of the most recent occurrence of that error. However, take note of the following points.

- Correct time of the error occurrence may not be displayed when the GPS antenna substrate within the AV and NAVI control unit has malfunctioned.
- Place of the error occurrence is represented by the position of the vehicle mark at the time when the error occurred. If the vehicle mark has deviated from the correct position, then the place of the error occurrence may not be located correctly.
- “History of Errors” stores error occurrences up to 50, and errors after the 51st are displayed as the 50th.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

## Diagnosis by History of Errors

When having a difficulty on the investigation of cause due to multiple errors with a reproducible malfunction, turn ON the ignition switch from OFF mode after making a memo of the item and number of time (or delete "History of Errors"). Check "History of Errors" again after the malfunction was reproduced, and then perform diagnosis focusing on the item of which number of time increased.

Error item	Possible causes	Example of symptom
	Action/symptom	
Gyro sensor disconnected	Communications malfunction between AV and NAVI control unit and internal gyro.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Angular velocity cannot be detected.)</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	
GPS disconnected	Communication error between AV and NAVI control unit and internal GPS substrate.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.)</li> <li>GPS receiving status remains gray.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	
GPS transmission cable malfunction	Malfunctioning transmission wires to AV and NAVI control unit and internal GPS substrate.	<ul style="list-style-type: none"> <li>During self-diagnosis, GPS diagnosis is not performed.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	
GPS input line connection error	Malfunctioning receiving wires to AV and NAVI control unit and internal GPS substrate.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.)</li> <li>GPS receiving status remains gray.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	
GPS TCX0 over GPS TCX0 under	Oscillating frequency of the GPS substrate frequency synchronizing oscillation circuit exceeded (or below) the specification.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.)</li> <li>GPS receiving status remains gray.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference, or the control unit may have been subjected to excessively high or low temperatures.</li> </ul>	
GPS ROM malfunction GPS RAM malfunction	Contents of ROM (or RAM) in GPS substrate are malfunctioning.	<ul style="list-style-type: none"> <li>Location detection accuracy of the navigation system may have deteriorated, depending on the error area in the memory, because GPS could not make correct positioning. (Location correction using GPS is not performed.)</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	
GPS RTC malfunction	Clock IC in GPS substrate is malfunctioning.	<ul style="list-style-type: none"> <li>Correct time may not be displayed.</li> <li>After the power is turned on, the system always takes some time until GPS positioning becomes possible. (The GPS receiver starts positioning without re-collecting the whole satellite information when it judged the data stored in the receiver is correct.)</li> <li>Correct time of error occurrence may not be stored in the "History of Errors".</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When the AV and NAVI control unit is judged normal by self-diagnosis, the symptom may be intermittent, caused by strong radio interference.</li> </ul>	



# NAVIGATION SYSTEM


Error item	Possible causes	Example of symptom
	Action/symptom	
GPS antenna disconnected	Malfunctioning connection between GPS substrate in AV and NAVI control unit and GPS antenna.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.)</li> <li>GPS receiving status remains gray.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When connection between AV and NAVI control unit and GPS antenna is judged normal by self-diagnosis, the symptom may be intermittent, caused by impact or vibration.</li> </ul>	
Low voltage of GPS	The power voltage supplied to the GPS circuit board has decreased.	<ul style="list-style-type: none"> <li>Navigation location detection performance has deteriorated. (Location correction using GPS is not performed.)</li> <li>GPS receiving status remains gray.</li> </ul>
	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>When connection between AV and NAVI control unit and GPS antenna is judged normal by self-diagnosis, the symptom may be intermittent, caused by impact or vibration.</li> </ul>	
DVD-ROM malfunction DVD-ROM read error DVD-ROM response Error	Malfunctioning AV and NAVI control unit.	—
	Dedicated DVD-ROM is in the system, but the data cannot be read.	<ul style="list-style-type: none"> <li>The map of a particular location cannot be displayed.</li> <li>Specific guidance information cannot be displayed.</li> <li>Map display is slow.</li> <li>Guidance information display is slow.</li> <li>System has been affected by vibration.</li> </ul>
	<ul style="list-style-type: none"> <li>Is DVD-ROM damaged, warped, or dirty?                             <ul style="list-style-type: none"> <li>If damaged or warped, the DVD-ROM is malfunctioning.</li> <li>If dirty, wipe the DVD-ROM clean with a soft cloth.</li> </ul> </li> <li>Perform self-diagnosis.</li> <li>When AV and NAVI control unit is judged normal by self-diagnosis, the symptom is judged intermittent, caused by vibration.</li> </ul>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

## NAVIGATION


### Display Longitude & Latitude

Able to confirm/adjust longitude and latitude.



### Speed Calibration


During normal driving, distance error caused by tire wear and tire pressure change is automatically adjusted for by the automatic distance correction function. Speed calibration function, on the other hand, is for immediate adjustment, in cases such as driving with tire chain fitted on tires.



# NAVIGATION SYSTEM

## Angle Adjustment

The turning angle output detected by the gyroscope can be adjusted.



## Initialize Location

This mode is for initializing the current location.

# NAVIGATION SYSTEM

## CONSULT-II Function (MULTI AV)

NKS001J0

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


System part	Diagnosis mode	Description
MULTI AV	VERSION	Displays version of each unit connected to AV and NAVI control unit.
	SELF-DIAG RESULTS	<ul style="list-style-type: none"> <li>Performs the connection diagnosis of communication circuit between AV and NAVI control unit and each unit, and displays the current malfunctions.</li> <li>The DVD-ROM drive diagnosis of AV and NAVI control unit can be performed.</li> </ul>
	SIGNAL MONITOR	The diagnosis of vehicle signal that is input to the AV and NAVI control unit can be performed.

## CONSULT-II BASIC OPERATION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

### VERSION

Displays version of each unit connected to the AV and NAVI control unit.



Version display	Remarks
"PANEL SW"	Multifunction switch
"MAP DISK"	DVD-ROM
"HEAD UNIT"	AV and NAVI control unit
"FRONT SEAT DISPLAY"	Display
"AUDIO HEAD UNIT"	Audio unit
"AIR COMP RECEIVER"	Low tire pressure warning control unit
"BOSE AMP"	BOSE speaker amp.
"VOICE UNIT"	Voice activated control module

# NAVIGATION SYSTEM

## SELF-DIAG RESULTS

The self-diagnosis is started and self-diagnosis results are displayed by touching "START" after selecting "SELF-DIAG RESULTS".

### Display Item of SELF-DIAG RESULTS

Self-diagnosis results may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items.

#### NOTE:

When "IVCS [ABNORMAL CONNECTION]" is indicated, this is not malfunction.

Error item	Possible cause	Action to take
HEAD UNIT [ABNORMAL]	AV and NAVI control unit malfunction is detected	Replace AV and NAVI control unit
BOSE AMP [ABNORMAL]	BOSE speaker amp. malfunction is detected	Replace BOSE speaker amp.
VOICE UNIT [ABNORMAL]	Voice activated control module malfunction is detected	Replace voice activated control module
MAP DISC [NO INSERT]	DVD-ROM not inserted is detected	Insert DVD-ROM
MAP DISC [ABNORMAL]	<ul style="list-style-type: none"> <li>● Malfunction is detected on DVD-ROM drive pickup lens in AV and NAVI control unit</li> <li>● There is dirt and damage on the DVD-ROM</li> </ul>	<ol style="list-style-type: none"> <li>1. Check if the inserted DVD-ROM is specified for this navigation system, and the DVD-ROM is dirty, scratched or warped.</li> <li>2. If the results from the above checkup show no malfunction, insert the same DVD-ROM, and then restart self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace AV and NAVI control unit.</li> </ol>
MAP DISC DRIVER [ABNORMAL 1]		
MAP DISC OR DRIVER [ABNORMAL]		
<ul style="list-style-type: none"> <li>● PANEL SW [ABNORMAL CONNECTION]</li> <li>● AUDIO HEAD UNIT [ABNORMAL CONNECTION]</li> <li>● AIR COMP RECEIVER [ABNORMAL CONNECTION]</li> <li>● VOICE UNIT [ABNORMAL CONNECTION]</li> <li>● BOSE AMP [ABNORMAL CONNECTION]</li> <li>● FRONT SEAT DISPLAY [ABNORMAL CONNECTION]</li> </ul>	Malfunction is detected on communication signal	Check all communication circuits composing AV system. Repair malfunctioning parts.
<ul style="list-style-type: none"> <li>● PANEL SW [ABNORMAL CONNECTION]</li> <li>● AUDIO HEAD UNIT [ABNORMAL CONNECTION]</li> <li>● AIR COMP RECEIVER [ABNORMAL CONNECTION]</li> <li>● BOSE AMP [ABNORMAL CONNECTION]</li> <li>● FRONT SEAT DISPLAY [ABNORMAL CONNECTION]</li> </ul>	Malfunction is detected on communication signal between AV and NAVI control unit and display	<ol style="list-style-type: none"> <li>1. Check communication circuit between AV and NAVI control unit and display.</li> <li>2. If the results from the above checkup show no malfunction, replace either AV and NAVI control unit or display, and then start self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
<ul style="list-style-type: none"> <li>● PANEL SW [ABNORMAL CONNECTION]</li> <li>● AUDIO HEAD UNIT [ABNORMAL CONNECTION]</li> <li>● AIR COMP RECEIVER [ABNORMAL CONNECTION]</li> <li>● BOSE AMP [ABNORMAL CONNECTION]</li> </ul>	Malfunction is detected on communication signal between display and multifunction switch	<ol style="list-style-type: none"> <li>1. Check communication circuit between display and multifunction switch.</li> <li>2. If the results from the above checkup show no malfunction, replace either display or display, and then start self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>

# NAVIGATION SYSTEM

Error item	Possible cause	Action to take
PANEL SW [ABNORMAL CONNECTION]	Multifunction switch power supply and ground circuit malfunction is detected	<ol style="list-style-type: none"> <li>1. Check multifunction switch power supply and ground circuit.</li> <li>2. If the results from the above checkup show no malfunction, replace multifunction switch.</li> </ol>
<ul style="list-style-type: none"> <li>● AUDIO HEAD UNIT [ABNORMAL CONNECTION]</li> <li>● BOSE AMP [ABNORMAL CONNECTION]</li> </ul>	Multifunction is detected on communication signal between multifunction switch and audio unit	<ol style="list-style-type: none"> <li>1. Check communication circuit between multifunction switch and audio unit.</li> <li>2. If the results from the above checkup show no malfunction, replace either multifunction switch or audio unit, and then start self-diagnosis.</li> <li>3. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
AIR COMP RECEIVER [ABNORMAL CONNECTION]	<ul style="list-style-type: none"> <li>● Low tire pressure warning control unit power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between multifunction switch and low tire pressure warning control unit</li> </ul>	<ol style="list-style-type: none"> <li>1. Check low tire pressure warning control unit power supply and ground circuit.</li> <li>2. Check communication circuit between multifunction switch and low tire pressure warning control unit.</li> <li>3. If the results from the above checkup show no malfunction, replace either multifunction switch or low tire pressure warning control unit, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
BOSE AMP [ABNORMAL CONNECTION]	<ul style="list-style-type: none"> <li>● BOSE speaker amp. power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between audio unit and BOSE speaker amp.</li> </ul>	<ol style="list-style-type: none"> <li>1. Check BOSE speaker amp. power supply and ground circuit.</li> <li>2. Check communication circuit between audio unit and BOSE speaker amp.</li> <li>3. If the results from the above checkup show no malfunction, replace either audio unit or BOSE speaker amp., and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
AUDIO HEAD UNIT [ABNORMAL CONNECTION]	Audio unit power supply and ground circuit malfunction is detected	<ol style="list-style-type: none"> <li>1. Check audio unit power supply circuit.</li> <li>2. If the results from the above checkup show no malfunction, replace audio unit.</li> </ol>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# NAVIGATION SYSTEM

Error item	Possible cause	Action to take
CD CHANGER [ABNORMAL CONNECTION]	<b>Without satellite radio</b> <ul style="list-style-type: none"> <li>● CD auto changer power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO), Tx and RX] between audio unit and CD auto changer</li> </ul>	<ol style="list-style-type: none"> <li>1. Check CD auto changer power supply and ground circuit.</li> <li>2. Check communication circuit [REQ (CHG-AUDIO), Tx and RX] between audio unit and CD auto changer.</li> <li>3. Check communication signal [REQ (CHG-AUDIO), Tx and RX] between audio unit and CD auto changer.</li> <li>4. If the results from the above checkup show no malfunction, replace either audio unit or CD auto changer, and then start self-diagnosis.</li> <li>5. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
	<b>With satellite radio</b> <ul style="list-style-type: none"> <li>● CD auto changer power supply and ground circuit malfunction is detected</li> <li>● Satellite radio tuner power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on control signal (CONT) between audio unit and satellite radio tuner</li> <li>● Malfunction is detected on communication signal [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer</li> </ul>	<ol style="list-style-type: none"> <li>1. Check CD auto changer power supply and ground circuit.</li> <li>2. Check satellite radio tuner power supply and ground circuit.</li> <li>3. Check communication circuit [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner.</li> <li>4. Check control signal circuit (CONT) between audio unit and satellite radio tuner.</li> <li>5. Check communication circuit [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer.</li> <li>6. Check communication signal [REQ (CHG-AUDIO), REQ (SAT-AUDIO), Tx and RX] between audio unit and satellite radio tuner.</li> <li>7. Check control signal (CONT) between audio unit and satellite radio tuner.</li> <li>8. Check communication signal [REQ (CHG-AUDIO), Tx and Rx] between satellite radio tuner and CD auto changer.</li> <li>9. If the results from the above checkup show no malfunction, replace audio unit, satellite radio tuner, or CD auto changer, and then start self-diagnosis.</li> <li>10. If self-diagnosis results still show any malfunction, replace one of the two units that is not replaced yet.</li> <li>11. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>
FRONT SEAT DISPLAY [ABNORMAL CONNECTION]	Display power supply and ground circuit malfunction is detected	<ol style="list-style-type: none"> <li>1. Check display power supply and ground circuit.</li> <li>2. If the results from the above checkup show no malfunction, replace display.</li> </ol>
VOICE UNIT [ABNORMAL CONNECTION]	<ul style="list-style-type: none"> <li>● Voice activated control module power supply and ground circuit malfunction is detected</li> <li>● Malfunction is detected on communication signal between AV and NAVI control unit and voice activated control module</li> </ul>	<ol style="list-style-type: none"> <li>1. Check voice activated control module power supply and ground circuit.</li> <li>2. Check communication circuit between AV and NAVI control unit and voice activated control module.</li> <li>3. If the results from the above checkup show no malfunction, replace either AV and NAVI control unit or voice activated control module, and then start self-diagnosis.</li> <li>4. If self-diagnosis results still show any malfunction, replace the other unit.</li> </ol>

# NAVIGATION SYSTEM

## SIGNAL MONITOR

- When “SIGNAL MONITOR” is selected, “ALL SIGNALS” and “SELECTION FROM MENU” are displayed.
- For each signal, a comparison of actual operating status and the status recognized by the system can be checked.

DATA MONITOR			
MONITOR		NO DTC	
VHCL SPD SIG		OFF	
MTR ILL DIM		OFF	
IGN SW		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIB0653E

## Display Condition

Diagnosis item	Display	Condition	Remarks
VHCL SPD SIG	ON	When vehicle speed is more than 0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	When vehicle speed is 0 km/h (0 MPH)	
	—	Ignition switch in ACC position	
MTR ILL DIM	ON	Lighting switch is ON, and then optical sensor is not illuminated	—
	OFF	Lighting switch OFF Lighting switch is ON, and then optical sensor is illuminated	
IGN SW	ON	Ignition switch ON	—
	OFF	Ignition switch ACC position	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# NAVIGATION SYSTEM

## RGB Image Is Not Displayed (Rear View Image Is Displayed)

NKS001J6

Symptom: RGB image such as a map screen is not displayed. (No warning message though rear view image is displayed.)

### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI control unit and display connectors.
3. Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 12 and display harness connector (B) M82 terminal 8.

**12 – 8 : Continuity should exist.**


4. Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 12 and ground.

**12 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 2.


NG >> Repair harness or connector.



### 2. CHECK RGB AREA (YS) SIGNAL


1. Turn ignition switch OFF.
2. Connect AV and NAVI control unit and display connectors.
3. Check voltage waveform between AV and NAVI control unit harness connector B30 terminal 12 and ground with CONSULT-II or oscilloscope.

**When displaying rear view image**



**12 – Ground:**


**When displaying RGB image**



OK or NG

OK >> Replace display.

NG >> Replace AV and NAVI control unit.





# NAVIGATION SYSTEM

NKS002KL

## All Images Are Not Displayed

Symptom: RGB image and rear view image are not displayed.

### 1. DIAGNOSIS USING CONSULT-II

1. With the ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector, and then turn the ignition switch ON.
2. Check if "MULTI AV" is shown on the SELECT SYSTEM screen.


Is "MULTI AV" shown?

- YES >> GO TO 3.  
NO >> GO TO 2.

### 2. CHECK AV AND NAVI CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

1. Check voltage between AV and NAVI control unit harness connector terminals and ground.

Terminals		OFF	ACC	ON
(+)	(-)			
Connector	Terminal			
B30	2, 3	Battery voltage	Battery voltage	Battery voltage
	6	0 V	Battery voltage	Battery voltage




2. Turn ignition switch OFF.
3. Disconnect NAVI control unit connector.
4. Check continuity between NAVI control unit harness connector B30 terminals 1, 4 and ground.

**1, 4 – Ground : Continuity should exist.**

OK or NG

- OK >> Replace AV and NAVI control unit.  
NG >> Repair harness or connector.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# NAVIGATION SYSTEM

## 3. CHECK DISPLAY POWER SUPPLY AND GROUND CIRCUIT

1. Check voltage between display harness connector terminals and ground.

Terminals		(-)	OFF	ACC	ON
(+)	Connector				
	Terminal				
M82	21, 23	Ground	Battery voltage	Battery voltage	Battery voltage
	19		0 V	Battery voltage	Battery voltage




2. Turn ignition switch OFF.
3. Disconnect display connector.
4. Check continuity between display harness connector M82 terminals 22, 24 and ground.

**22, 24 – Ground : Continuity should exist.**

OK or NG

- OK >> Replace display.
- NG >> Repair harness or connector.



### Rear View Image Is Not Displayed

Refer to [DI-186, "Trouble Diagnosis"](#) .

NKS002KM

## Tint Is Strange for The RGB Image

Symptom: Tint of RGB image is strange.

### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI control unit and display connectors.
3. Check the malfunctioning circuit according to the symptoms.


- **Light blue (Cyan) tinged screen**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 18 and display harness connector (B) M82 terminal 1.

**18 – 1** : **Continuity should exist.**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 18 and ground.

**18 – Ground** : **Continuity should not exist.**




- **Purple (Magenta) tinged screen**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 21 and display harness connector (B) M82 terminal 2.

**21 – 2** : **Continuity should exist.**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 21 and ground.

**21 – Ground** : **Continuity should not exist.**




- **Yellow tinged screen**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 15 and display harness connector (B) M82 terminal 3.

**15 – 3** : **Continuity should exist.**

Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 15 and ground.

**15 – Ground** : **Continuity should not exist.**



OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# NAVIGATION SYSTEM



## 2. CHECK RGB SIGNAL

1. Connect AV and NAVI control unit and display connectors.
2. Turn ignition switch ON.
3. Start Confirmation/Adjustment mode. Refer to [AV-108, "Confirmation/Adjustment Mode"](#).
4. Display color bar by selecting "Display Color Spectrum Bar" on DISPLAY DIAGNOSIS screen. Refer to [AV-109, "DISPLAY DIAGNOSIS"](#).
5. Check the malfunctioning circuit according to the symptoms.

- **Light blue (Cyan) tinged screen**

Check voltage waveform between AV and NAVI control unit harness connector B30 terminal 18 and ground with CONSULT-II or oscilloscope.



18 – Ground:



- **Purple (Magenta) tinged screen**

Check voltage waveform between AV and NAVI control unit harness connector B30 terminal 21 and ground with CONSULT-II or oscilloscope.



21 – Ground:



- **Yellow tinged screen**

Check voltage waveform between AV and NAVI control unit harness connector B30 terminal 15 and ground with CONSULT-II or oscilloscope.

15 – Ground:



### OK or NG

- OK >> Replace display.
- NG >> Replace AV and NAVI control unit.

## RGB Image Is Rolling

NKS001J8

Symptom: RGB image such as a map screen is rolling.

### 1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI control unit and display connectors.
3. Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 16 and display harness connector (B) M82 terminal 7.


**16 – 7 : Continuity should exist.**

4. Check continuity between AV and NAVI control unit harness connector (A) B30 terminal 16 and ground.

**16 – Ground : Continuity should not exist.**

OK or NG



- OK >> GO TO 2.  
 NG >> Repair harness or connector.



### 2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect AV and NAVI control unit and display connectors.
2. Turn ignition switch ON.
3. When displaying RGB image, check voltage waveform between AV and NAVI control unit harness connector B30 terminal 16 and ground with CONSULT-II or oscilloscope.

**16 – Ground:**



OK or NG

- OK >> Replace display.  
 NG >> Replace AV and NAVI control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

## Voice Guidance Is Not Heard

Symptom: Voice guidance does not sound at route guidance.

### 1. PERFORM SELF-DIAGNOSIS

Perform on board self-diagnosis (Refer to [AV-101. "On Board Self-Diagnosis Function \(Without CONSULT-II\)"](#) ) or CONSULT-II self-diagnosis (Refer to [AV-115. "CONSULT-II Function \(MULTI AV\)"](#) ), and check the malfunction.

Is there a malfunction?

- YES >> Refer to [AV-104. "SELF-DIAGNOSIS RESULT"](#) (On board self-diagnosis) or [AV-116. "SELF-DIAG RESULTS"](#) (CONSULT-II self-diagnosis).
- NO >> GO TO 2.


### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV and NAVI control unit and BOSE speaker amp. connectors.
3. Check continuity between AV and NAVI control unit harness connector (A) B30 terminals 7, 8 and BOSE speaker amp. harness connector (B) B231 terminals 1, 2.

- 7 – 1** : Continuity should exist.
- 8 – 2** : Continuity should exist.

4. Check continuity between AV and NAVI control unit harness connector (A) B30 terminals 7, 8 and ground.

- 7, 8 – Ground** : Continuity should not exist.





OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

### 3. CHECK VOICE GUIDANCE SIGNAL

1. Connect AV and NAVI control unit and BOSE speaker amp. connectors.
2. Turn ignition switch ON.
3. When pressing "VOICE" button, check voltage waveform between AV and NAVI control unit harness connector B30 terminals 7 and 8 with CONSULT-II or oscilloscope.

**7 – 8:**



OK or NG

- OK >> Replace BOSE speaker amp.
- NG >> Replace AV and NAVI control unit

# NAVIGATION SYSTEM

---

## A/C Display Is Malfunctioning

NKS001JA

Refer to [DI-145, "No A/C Display is Shown"](#) .

A

## A/C Operation Is Malfunctioning

NKS001JB

Refer to [DI-145, "A/C Operation Is Not Possible"](#) .

B

## Fuel Information Is Not Displayed/Warning Message Is Not Displayed

NKS001JC

Refer to [DI-167, "Fuel Information Is Not Displayed/Warning Message Is Not Displayed"](#) .

C

## Vehicle Condition Setting Is Not Possible

NKS001JD

Refer to [DI-168, "Vehicle Condition Setting Is Not Possible"](#) .

D

## Vehicle Mark Is Not Displayed Properly

NKS001JE

### 1. NAVIGATION SYSTEM ADJUSTMENT

---

1. Select "Navigation" in Confirmation/Adjustment mode, and adjust items, "Display Longitude & Latitude", "Speed Calibration", "Angle Adjustment" and "Initialize Location". Refer to [AV-113, "NAVIGATION"](#) .
2. Check symptom with driving.

E

Is any malfunction observed?

- YES >> GO TO 2.  
NO >> INSPECTION END

F

G

### 2. SELF-DIAGNOSIS

---

Perform self-diagnosis, and check any malfunction related to GPS. Refer to [AV-102, "Self-Diagnosis Mode"](#) .

Is any malfunction related to GPS observed?

- YES >> Repair malfunctioning part by diagnosis results.  
NO >> GO TO 3.

H

I

### 3. CHECK VEHICLE SIGNAL

---

Select "Vehicle Signals" in Confirmation/Adjustment mode, and check the vehicle speed signal and reverse signal inputting to AV and NAVI control unit. Refer to [AV-110, "VEHICLE SIGNALS"](#) .

OK or NG

- OK >> Limit of position detection capacity.  
NG >> ● Check AV and NAVI control unit vehicle speed signal circuit, and repair malfunctioning part.  
● Check AV and NAVI control unit reverse signal circuit, and repair malfunctioning part.

J

AV

L

M

# NAVIGATION SYSTEM

NKS001JH

## Example of Symptoms Possible No Malfunction

For Navigation System operation information, refer to Navigation System Owner's Manual.

### BASIC OPERATION

Symptom	Cause	Remedy
No image is shown.	Display brightness adjustment is set fully to DARK side.	Adjust the display brightness.
No guide sound is heard. Audio guide volume is too low or too high.	Volume control is set to OFF, MIN or MAX.	Adjust the audio guide volume.
	Audio guidance is not available while the vehicle is driving on a dark pink route.	System is not malfunction.
Screen is too dark. Motion of the image is too slow.	Temperature inside the vehicle is low.	Wait until the temperature inside the vehicle reaches the proper temperature.
Small black or bright spots appear on the screen.	Symptom peculiar to a liquid crystal display.	System is not malfunction.

### VEHICLE MARK

Symptom	Cause	Remedy
Map screen and BIRDVIEW™ name of the place vary with the screen.	Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ. The same place name, street name, etc. may not be displayed every time on account of the data processing.	System is not malfunction.
Vehicle mark is not positioned correctly.	Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF.	Drive the vehicle for a while in the GPS satellite signal receiving condition.
Screen will not switch to nighttime mode after the lighting switch is turned ON.	The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screen may be inhibited by the automatic illumination adjustment function.	Perform screen dimming and select the nighttime screen by "SWITCH SCREENS".
Map screen will not scroll in accordance with the vehicle travel.	Current location is not displayed.	Press "MAP" switch to display the current location.
Vehicle mark will not be shown.	Current location is not displayed.	Press "MAP" switch to display the current location.
Accuracy indicator (GPS satellite mark) on the map screen stays gray.	GPS satellite signal is intercepted because the vehicle is in or behind a building.	Move the vehicle out to an open space.
	GPS satellite signal cannot be received because an obstacle is placed on top of the display.	Do not place anything in the center on top of the display.
	GPS satellites are located badly.	Wait until the location becomes better.
Vehicle location accuracy is low.	Accuracy indicator (GPS satellite mark) on the map screen stays gray.	Current location is not determined.
	Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle.	Drive the vehicle for a while [for approx. 30 minutes at approx. 30 km/h (19MPH)] and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by Confirmation/Adjustment Mode mode of diagnosis function.
	Map data has error or omission. (Vehicle mark is always deviated to the same position.)	As a rule, an updated map DVD-ROM will be released once a year.




# NAVIGATION SYSTEM

## DESTINATION, PASSING POINTS, AND MENU ITEMS CANNOT BE SELECTED/SET

Symptom	Cause	Remedy
Destination cannot be set.	Destination to be set is on an expressway.	Set the destination on an ordinary road.
Passing point is not searched when re-searching the route.	The vehicle has already passed the passing point, or the system judged so.	To include the passing points that have been passed into the route again, set the route again.
Route information will not be displayed.	Route searching has not been done.	Set the destination and perform route searching.
	Vehicle mark is not on the recommended route.	Drive on the recommended route.
	Route guidance is turned OFF.	Turn the route guidance ON.
	Route information is not available on the dark pink route.	System is not malfunction.
After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road.	Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.)	Drive on the recommended route.
Automatic route searching is not possible.	Vehicle is driving on a highway (gray route), or no recommended route is available.	Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched.
Performed automatic detour search (or detour search). However, the result is the same as that of the previous search.	Performed search with every conditions considered. However, the result is the same as that of the previous search.	System is not malfunction.
Passing points cannot be set.	More than five passing points were set.	Passing points can be set up to five. To stop at more than five points, perform sharing in several steps.
When setting the route, the starting point cannot be selected.	The current vehicle location is always set as the starting point of a route.	System is not malfunction.
Some menu items cannot be selected.	The vehicle is being driven.	Stop the vehicle at a safe place and then operate the system.

## VOICE GUIDANCE

Symptom	Cause	Remedy
Voice guidance will not operate.	Note: Voice guidance is only available at intersections that satisfy certain conditions (indicated by  on the map). Therefore, guidance may not be given even when the route on the map changes direction.	System is not malfunction.
	The vehicle is not on the recommended route.	Return to the recommended route or re-search the route.
	Voice guidance is turned OFF.	Turn the voice guidance ON.
	Route guidance is turned OFF.	Turn the route guidance ON.
Voice guidance does not match the actual road pattern.	Voice guidance may vary with the direction to which the vehicle is turn and the connection of the road to other roads.	Drive in conformity to the actual traffic rules.

# NAVIGATION SYSTEM

## ROUTE SEARCHING

Symptom	Cause	Remedy
No route is shown.	No road to be searched is found around the destination.	Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads.
	Starting point and the destination are too close.	Set the destination at more distant point.
	Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current position or the destination.	Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF.
Indicated route is intermittent.	In some areas, highways (gray routes) are not used for the search <sup>(Note)</sup> Therefore, the route to the current position or the passing points may be intermittent.	System is not malfunction.
When the vehicle has passed the recommended route, it is deleted from the screen.	A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.)	System is not malfunction.
Detouring route is recommended.	In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended.	Set the route closer to the basic route (gray route).
	A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination.	Slightly move the starting point or the destination, or set the passing point on the route of your choice.
	In the area where highways (gray routes) are used for the search, left turn has priority around the current position and the destination (passing points). For this reason, the recommended route may be detouring.	System is not malfunction.
Landmarks on the map do not match the actual ones.	This can be happen due to omission or error in the map data.	As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available.
Recommended route is far from the starting point, passing points, and destination.	Starting point, passing points, and destination of the route guidance were set far from the desired points because route searching data around these area were not stored.	Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route.

**NOTE:**

Except for the ordinance-designated cities and the prefectural capitals (Applicable areas may be changed in the updated map disc.)


# NAVIGATION SYSTEM

## Removal and Installation of AV and NAVI Control Unit

NKS001JJ

### REMOVAL

1. Remove trunk room trim. Refer to [EI-60, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove screws (4), and remove AV and NAVI control unit.



### INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation of GPS Antenna

NKS001JK

### REMOVAL

1. Remove rear parcel shelf finisher. Refer to [EI-48, "REAR PARCEL SHELF FINISHER"](#) .
2. Remove screws and remove the GPS antenna.



### INSTALLATION

Installation is the reverse order of removal.

## Removal and Installation of Multifunction Switch

NKS002KO

Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .

## Removal and Installation of Display

NKS002KP

Refer to [DI-170, "Removal and Installation of Display"](#) .

## Removal and Installation of Steering Wheel Switch

NKS001JL

Refer to [SRS-40, "DRIVER AIR BAG MODULE"](#) .

## Removal and Installation of Rear Control Switch

NKS001JM

Refer to [AV-55, "Removal and Installation of Rear Control Switch"](#) .

## Removal and Installation of Rear Control Cancel Switch

NKS001JN

Refer to [AV-55, "Removal and Installation of Rear Control Cancel Switch"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M



## TELEPHONE

PFP:28342

### System Description


NKS002JV

#### HANDS-FREE PHONE SYSTEM


- For Hands-free phone system operation information, refer to Owner's Manual.
- TEL adapter unit has Bluetooth® module. It can perform wireless hands-free telephone calls using a cellular phone in vehicle compartment.
- 5 or less cellular phones can be registered into the TEL adapter unit.
- Hands-free phone mode starts by transmitting switch signal to TEL adapter unit when pressing  button.
- Hands-free phone mode ends by transmitting switch signal to TEL adapter unit when pressing  button.
- When uttering to the microphone, microphone signal (audio signal) is transmitted from the microphone to the TEL adapter unit and transmitted to the cellular phone with the Bluetooth® communication.
- Audio signals from a party at the other end are transmitted from the cellular phone to the TEL adapter unit with the Bluetooth® communication, and transmitted from the TEL adapter unit to the BOSE speaker amp. through the voice activated control module, then the party's voice is output from the front door speaker RH. (With voice activated control system)
- Audio signals from a party at the other end are transmitted from the cellular phone to the TEL adapter unit with the Bluetooth® communication, and transmitted from the TEL adapter unit to the BOSE speaker amp., and then the party's voice is output from the front door speaker RH. (Without voice activated control system)
- BOSE speaker amp. switches the voice from front speaker RH to TEL voice when receiving TEL ON signal from TEL adapter unit, and when receiving request signal with the communication line.

# TELEPHONE

## With Voice Activated Control System



## Without Voice Activated Control System




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# TELEPHONE

## Component Parts Location


NKS002JW



# TELEPHONE

## Schematic — H/PHON — / With Voice Activated Control System

NKS002JX



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M




AV

# TELEPHONE

## Wiring Diagram — H/PHON — / With Voice Activated Control System

NKS002JY

### AV-H/PHON-01



REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (B2) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)


\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM3823E





# TELEPHONE

AV-H/PHON-02



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M





REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)  
 (R1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWM3824E

# TELEPHONE

AV-H/PHON-03

▬ : DATA LINE





TKWM3825E

# TELEPHONE

AV-H/PHON-04

▬ : DATA LINE









REFER TO THE FOLLOWING.  
 (M5) -SUPER MULTIPLE JUNCTION (SMJ)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M

# TELEPHONE

AV-H/PHON-05



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.


- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3827E

# TELEPHONE

## Schematic — H/PHON — / Without Voice Activated Control System

NKS002ME



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M




TKWM3828E

# TELEPHONE

## Wiring Diagram — H/PHON — / Without Voice Activated Control System

NKS002MF

### AV-H/PHON-06



REFER TO THE FOLLOWING.

(M5), (E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (B2) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1





(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM3829E

# TELEPHONE

AV-H/PHON-07



REFER TO THE FOLLOWING.



- (M5) -SUPER MULTIPLE JUNCTION (SMJ)
- (R1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

TKWM3830E

# TELEPHONE

AV-H/PHON-08

▬ : DATA LINE









TKWM3831E



# TELEPHONE

AV-H/PHON-09



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.






- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

TKWM3832E



# TELEPHONE

## Terminals and Reference Value for TEL Adapter Unit

NKS002JZ

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
1 (SB)	Ground	Battery power supply	Input	OFF	—	Battery voltage
2 (L/OR)	Ground	ACC power supply	Input	ACC	—	Battery voltage
3 (W/G)	Ground	Ignition signal	Input	ON	—	Battery voltage
4 (B)	Ground	Ground	—	ON	—	Approx. 0 V
6	—	Shield	—	—	—	—
7 (BR)	8 (G/L)	Microphone signal	Input	ON	Uttering in front of the microphone while using the hands-free phone system.	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
9 (P)	10 (L)	TEL voice signal	Output	ON	Receiving the party's voice while using the hands-free phone system.	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
11 (L/W)	Ground	TEL ON signal	Output	ON	While using hands-free phone system or voice activated control system	Approx. 0 V
					Except while using hands-free phone system and voice activated control system (*1)	Approx. 12 V (*1)
					Except while using hands-free phone system (*2)	Approx. 5 V (*2)
12 (LG)	Ground	TEL switch signal A	Input	ON	Press and hold  button	Approx. 0 V
					Other than the above	Approx. 5 V
13 (GY)	Ground	TEL switch signal B	Input	ON	Press and hold  button	Approx. 0 V
					Other than the above	Approx. 5 V
14 (B)	Ground	Ground	—	ON	—	Approx. 0 V
15 (PU)	Ground	Indicator signal	Output	ON	Microphone indicator ON, and lighting switch OFF	Approx. 1.3 V
					Microphone indicator ON, and lighting switch ON	Approx. 0.8 V
					Microphone unit indicator OFF	Approx. 12 V
28 (BR/W)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>

# TELEPHONE

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-			Ignition switch	Operation	
29 (W)	Ground	Microphone VCC	Output	ON	—	Approx. 5 V
33 (PU)	Ground	Communication signal (-)	Input/ Output	ON	—	
34 (LG)	Ground	Communication signal (+)	Input/ Output	ON	—	
35	—	Shield	—	—	—	—
41	—	TEL antenna signal	—	—	—	—

\*1: With voice activated control system

\*2: Without voice activated control system

## Terminals and Reference Value for Voice Activated Control Module

NKS002K0

Refer to [DI-210, "Terminals and Reference Values for Voice Activated Control Module"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

## Special Note for Trouble Diagnosis

NKS002Q3

When the hands-free phone system has a malfunction, check if the cellular phone and the communications circuit between control units have a malfunction (Refer to [AV-102, "Self-Diagnosis Mode"](#) ), and then start diagnoses. Also, when starting diagnoses, turn on the cellular phone to establish connection with the Bluetooth®.

## Self-Diagnosis Function


NKS002K2

The followings are diagnosis functions performed by TEL adapter unit.


- Performs the unit self-diagnosis and antenna diagnosis, and informs results with the indicator and voice guidance.
- Informs vehicle speed pulse count from the time of key switch ON with voice guidance, and enables to check vehicle speed signal.
- Outputs voice giving to microphone with speaker, and enables to check microphone function.



## OPERATION PROCEDURE


1. Start the engine.
2. Press and hold  button for 5 seconds or more.





- This allows the indicator to blink concurrently with voice guidance outputs, and determines if there is any current error in the state of blinking.
- When the indicator does not blink, check the microphone power supply circuit, and then repair malfunctioning part.



3. Press both  and  buttons simultaneously while voice guidance outputs.




# TELEPHONE



4. Press both  and  buttons simultaneously while beep sound outputs.

**NOTE:**

Turn ignition switch OFF and return to Step 1 again if beep sound does not output. Replace TEL adapter unit if beep sound still does not output.



5. Perform the followings.

- Check how many times indicator flashes with in 5 seconds after pressing  and  buttons.
- Inform the malfunction and vehicle speed pulse from the time of ignition switch ON with voice.

**NOTE:**

Vehicle speed pulse is reset to 0 when turning ignition switch OFF.

Number of indicator flashes	Voice guidance	Malfunction	Possible solution
1	Internal failure	TEL adapter unit is malfunctioning	Replace TEL adapter unit
2	Bluetooth antenna open	TEL antenna feeder is open	Replace TEL antenna
3	Bluetooth antenna shorted	TEL antenna feeder is short	

6. Beep sounds (while 1 second) outputs 3 seconds after voice guidance of microphone check.
7. Voice giving to microphone outputs from speaker. Microphone function can be checked.
8. Diagnosis mode exits after a beep sounds.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# TELEPHONE

NKS002LP

## Hands-Free Phone System Is Not Activated

Symptom: Hands-free phone system is not activated when pressing  button. (Voice dialing or receiving a call is not activated.)

### 1. CHECK CONDITION

Turn ignition switch ON. Check if microphone indicator blinks.

Does the indicator blink?

YES >> GO TO 2.

NO >> Start on board self-diagnosis. Repair malfunctioning part. Refer to [AV-102, "Self-Diagnosis Mode"](#)

### 2. CHECK CONDITION

Check if microphone indicator turns ON after the indicator blinks.

Does the indicator switch from blinking to turning ON?

YES >> GO TO 3.

NO >> Start the self-diagnosis of hands-free phone system. Check TEL antenna function. Refer to [AV-148, "Self-Diagnosis Function"](#).

### 3. CHECK CONDITION

Check if the speaker's voice outputs to the party when dialing cellular phone and uttering to the microphone.

Can the party hear speaker's voice?

YES >> GO TO 4.

NO >> GO TO 6.

### 4. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit and microphone connectors.
3. Check continuity between TEL adapter unit harness connector (A) B32 terminal 12 and microphone harness connector (B) R25 terminal 8.

**12 – 8 : Continuity should exist.**


4. Check continuity between TEL adapter unit harness connector (A) B32 terminal 12 and ground.

**12 – Ground : Continuity should not exist.**

OK or NG



OK >> GO TO 5.

NG >> Repair harness or connector.



### 5. CHECK TEL SWITCH SIGNAL A


1. Connect TEL adapter unit and microphone connectors.
2. Check voltage between microphone harness connector terminal and ground.

Terminals			Press and hold  button	 button not pressed
(+)		(-)		
Connector	Terminal			
R25	8	Ground	Approx. 0 V	Approx. 5 V

OK or NG

OK >> Replace TEL adapter unit.

NG >> Replace microphone.



# TELEPHONE

## 6. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit and microphone connectors.
3. Check continuity between TEL adapter unit harness connector (A) B32 terminal 8 and microphone harness connector (B) R25 terminal 6.

**8 – 6** : Continuity should exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness or connector.



## 7. CHECK MICROPHONE GROUND


1. Connect TEL adapter unit and microphone connectors.
2. Check continuity between microphone harness connector R25 terminal 6 and ground.

**6 – Ground** : Continuity should exist.

OK or NG

OK >> Replace TEL adapter unit.

NG >> Replace microphone.



A

B

C

D

E

F

G

H

I

J

AV

L

M

# TELEPHONE

## Hands-Free Phone System Cannot Transmit The Speaker's Voice to The Party

NKS002LQ

Symptom: Hands-free phone system cannot transmit the speaker's voice to the party, though the party's voice can be heard.

### 1. HANDS-FREE PHONE SYSTEM SELF-DIAGNOSIS

Start the self-diagnosis of hands-free phone system, and uttering to the microphone.

Can front speaker RH output the speaker's voice?

- YES >> Hands-free phone system have no malfunction. Check the symptom with a different cellular phone again.  
NO >> GO TO 2.


### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit and microphone connectors.
3. Check continuity between TEL adapter unit harness connector (A) B32 terminals 7, 8, 29 and microphone harness connector (B) R25 terminals 5, 6, 4.

**7 – 5 : Continuity should exist.**  
**8 – 6 : Continuity should exist.**  
**29 – 4 : Continuity should exist.**

4. Check continuity between TEL adapter unit harness connector (A) B32 terminals 7, 29 and ground.

**7, 29 – Ground : Continuity should not exist.**



OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.


### 3. CHECK MICROPHONE VCC

1. Connect TEL adapter unit and microphone connectors.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R25 terminal 4 and ground.

**4 – Ground : Approx. 5 V**

OK or NG

- OK >> GO TO 4.  
NG >> Replace TEL adapter unit.







# TELEPHONE

## 4. CHECK MICROPHONE SIGNAL

Uttering in front of the microphone while using the hands-free phone system, check voltage waveform between microphone harness connector R25 terminals 5 and 6 with CONSULT-II or oscilloscope.

5 – 6:



OK or NG

- OK >> Replace TEL adapter unit.
- NG >> Replace microphone.

## Hands-Free Phone System Cannot Transmit The Party's Voice to The Speaker

NKS002LR

Symptom: Hands-free phone system cannot transmit the party's voice to the speaker or cannot make listening tone, though the speaker's voice can be transmitted.

### 1. NAVIGATION SYSTEM SELF-DIAGNOSIS

Start the self-diagnosis of navigation system. Check the self-diagnosis result.

OK or NG

- OK >> ● GO TO 2. (With voice activated control system)  
● GO TO 9. (Without voice activated control system)
- NG >> Repair malfunctioning part.


### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit and voice activated control module connectors.
3. Check continuity between TEL adapter unit harness connector (A) B32 terminals 9, 10, 11 and voice activated control module harness connector (B) B67 terminals 12, 11, 8.

- 9 – 12 : Continuity should exist.
- 10 – 11 : Continuity should exist.
- 11 – 8 : Continuity should exist.

4. Check continuity between TEL adapter unit harness connector (A) B32 terminals 9, 10, 11 and ground.

- 9, 10, 11 – Ground : Continuity should not exist.



OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

# TELEPHONE

## 3. CHECK HARNESS

1. Disconnect voice activated control module and audio unit connectors.
2. Check continuity between voice activated control module harness connector (A) B69 terminal 27 and audio unit harness connector (B) M87 terminal 9.

**27 – 9 : Continuity should exist.**


3. Check continuity between voice activated control module harness connector (A) B69 terminal 27 and ground.

**27 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK TEL ON SIGNAL


1. Connect TEL adapter unit, voice activated control module and audio unit connectors.
2. Turn ignition switch ON.
3. Check voltage between TEL adapter unit harness connector terminal and ground.

Terminals		(-)	While using hands-free phone system	Except while using hands-free phone system
(+) Connector				
Terminal				
B32	11	Ground	Approx. 0 V	Approx. 12 V

OK or NG

OK >> GO TO 5.

NG >> Replace TEL adapter unit.



## 5. CHECK TEL ON SIGNAL


Check voltage between voice activated control module harness connector terminal and ground.

Terminals		(-)	While using hands-free phone system	Except while using hands-free phone system
(+) Connector				
Terminal				
B69	27	Ground	Approx. 0 V	Approx. 5 V

OK or NG

OK >> GO TO 6.

NG >> Replace voice activated control module.



# TELEPHONE

## 6. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect voice activated control module and BOSE speaker amp. connectors.
3. Check continuity between voice activated control module harness connector (A) B69 terminals 26, 25 and BOSE speaker amp. harness connector (B) B234 terminals 26, 42.

**26 – 26 : Continuity should exist.**

**25 – 42 : Continuity should exist.**


4. Check continuity between voice activated control module harness connector (A) B69 terminals 26, 25 and ground.

**26, 25 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 7.



NG >> Repair harness or connector.



## 7. CHECK TEL VOICE SIGNAL

1. Connect voice activated control module and BOSE speaker amp. connectors.
2. Turn ignition switch ON.
3. Receiving the party's voice while using the hands-free phone system, check voltage waveform between TEL adapter unit harness connector B32 terminals 9 and 10 with CONSULT-II or oscilloscope.

**9 – 10:**



OK or NG



OK >> GO TO 8.

NG >> Replace TEL adapter unit.

## 8. CHECK TEL VOICE SIGNAL

Receiving the party's voice while using the hands-free phone system, check voltage waveform between voice activated control module harness connector B69 terminals 26 and 25 with CONSULT-II or oscilloscope.

**26 – 25:**



OK or NG

OK >> Replace BOSE speaker amp.

NG >> Replace voice activated control module.

# TELEPHONE

## 9. CHECK HARNESS

1. Disconnect TEL adapter unit and audio unit connectors.
2. Check continuity between TEL adapter unit harness connector (A) B32 terminal 11 and audio unit harness connector (B) M87 terminal 9.

**11 – 9 : Continuity should exist.**


3. Check continuity between TEL adapter unit harness connector (A) B32 terminal 11 and ground.

**11 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 10.

NG >> Repair harness or connector.



## 10. CHECK TEL ON SIGNAL


1. Connect TEL adapter unit and audio unit connectors.
2. Turn ignition switch ON.
3. Check voltage between TEL adapter unit harness connector terminal and ground.

Terminals		(-)	While using hands-free phone system	Except while using hands-free phone system
(+) Connector Terminal				
B32	11	Ground	Approx. 0 V	Approx. 5 V

OK or NG

OK >> GO TO 11.

NG >> Replace TEL adapter unit.



## 11. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit and BOSE speaker amp. connectors.
3. Check continuity between TEL adapter unit harness connector (A) B32 terminals 9, 10 and BOSE speaker amp. harness connector (B) B234 terminals 26, 42.

**9 – 26 : Continuity should exist.**

**10 – 42 : Continuity should exist.**


4. Check continuity between TEL adapter unit harness connector (A) B32 terminals 9, 10 and ground.

**9, 10 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 12.

NG >> Repair harness or connector.





# TELEPHONE

## 12. CHECK TEL VOICE SIGNAL

Receiving the party's voice while using the hands-free phone system, check voltage waveform between TEL adapter unit harness connector B32 terminals 9 and 10 with CONSULT-II or oscilloscope.

9 – 10:



### OK or NG

- OK >> BOSE speaker amp.
- NG >> Replace TEL adapter unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
AV  
L  
M


# TELEPHONE

## Removal and Installation of TEL Adapter Unit REMOVAL

NKS002K6

⇐: Vehicle front

1. Remove trunk front finisher. Refer to [EI-60, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove rear parcel shelf finisher. Refer to [EI-48, "REAR PARCEL SHELF FINISHER"](#) .
3. Remove bolts (A), and remove TEL adapter unit (1) and AV and NAVI control unit from trunk room side.
4. Remove TEL adapter unit from bracket.



## INSTALLATION


Installation is the reverse order of removal.

## Removal and Installation for TEL Antenna REMOVAL

NKS002K7

⇐: Vehicle front

1. Remove trunk front finisher. Refer to [EI-60, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) .
2. Remove rear parcel shelf finisher. Refer to [EI-48, "REAR PARCEL SHELF FINISHER"](#) .
3. Disconnect TEL antenna connector from TEL adapter unit.
4. Remove bolt (A) and clips (B), and remove TEL antenna (1).



## INSTALLATION

Installation is the reverse order of removal.


# TELEPHONE

## Removal and Installation of Microphone (PHONE/SEND and END Buttons)

NKS002K8

### REMOVAL

1. Remove front interior lamp. Refer to [LT-143. "FRONT INTERIOR LAMP"](#) .
2. Remove screws (A), and remove microphone (☞☜ and ☞ buttons) (1).



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

AV

# TELEPHONE (PRE WIRE)



PFP:28342

## TELEPHONE (PRE WIRE)

### Wiring Diagram — PHONE —

NKS0011K

## AV-PHONE-01



REFER TO THE FOLLOWING.

- (B21) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (B20) -FUSE BLOCK-JUNCTION BOX (J/B) NO.2

TKWM1354E