

SECTION EL

CONTENTS

PRECAUTIONS	2	FRONT FOG LAMP	39
Supplemental Restraint System (SRS) "AIR BAG"	2	System Description	39
Wiring Diagrams and Trouble Diagnosis	2	Wiring Diagram — F/FOG —	40
HARNES CONNECTOR	3	Aiming Adjustment	41
Description	3	TURN SIGNAL AND HAZARD WARNING LAMPS	42
STANDARDIZED RELAY	4	System Description	42
Description	4	Wiring Diagram — TURN —	44
POWER SUPPLY ROUTING	6	Trouble Diagnoses	46
Schematic	6	Electrical Components Inspection	46
Wiring Diagram — POWER —	7	ILLUMINATION	47
Inspection	13	System Description	47
GROUND	14	Schematic	48
Ground Distribution	14	Wiring Diagram — ILL —	49
COMBINATION SWITCH	18	INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS	52
Check	18	System Description	52
Replacement	19	Schematic	53
STEERING SWITCH	20	Wiring Diagram — INT/L —	54
Check	20	METER AND GAUGES	58
HEADLAMP (FOR USA)	21	Component Parts and Harness Connector Location	58
System Description	21	System Description	58
Wiring Diagram — H/LAMP —	22	Combination Meter	60
Trouble Diagnoses	23	Wiring Diagram — METER —	61
Bulb Replacement	23	Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode	62
Aiming Adjustment	24	Flexible Print Circuit (FPC)	63
HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —	26	Trouble Diagnoses	64
System Description	26	Electrical Components Inspection	69
Schematic	28	COMPASS AND THERMOMETER	71
Wiring Diagram — DTRL —	29	System Description	71
Trouble Diagnoses	32	Wiring Diagram — COMPAS —	72
Bulb Replacement	33	Trouble Diagnoses	73
Aiming Adjustment	33	Calibration Procedure for Compass	74
PARKING, LICENSE AND TAIL LAMPS	34	WARNING LAMPS	75
Wiring Diagram — TAIL/L —	34	Schematic	75
STOP LAMP	36	Wiring Diagram — WARN —	76
Wiring Diagram — STOP/L —	36	Electrical Components Inspection	82
BACK-UP LAMP	38	WARNING CHIME	83
Wiring Diagram — BACK/L —	38		

CONTENTS (Cont'd)

Component Parts and Harness Connector		
Location	83	
System Description	83	
Wiring Diagram — CHIME —	85	
Trouble Diagnoses	87	
FRONT WIPER AND WASHER	91	
System Description	91	
Wiring Diagram — WIPER —	93	
Trouble Diagnoses	95	
Removal and Installation	97	
Washer Nozzle Adjustment	98	
Washer Tube Layout	99	
REAR WIPER AND WASHER	100	
System Description	100	
Schematic	102	
Wiring Diagram — WIP/R —	103	
Trouble Diagnoses	106	
Removal and Installation	106	
Washer Nozzle Adjustment	107	
Washer Tube Layout	107	
Check Valve	107	
HORN	108	
Wiring Diagram — HORN —	108	
CIGARETTE LIGHTER	109	
Wiring Diagram — CIGAR —	109	
REAR WINDOW DEFOGGER	110	
Component Parts and Harness Connector		
Location	110	
System Description	110	
Wiring Diagram — DEF —	112	
Trouble Diagnoses	114	
Electrical Components Inspection	116	
Filament Check	116	
Filament Repair	117	
AUDIO	118	
System Description	118	
Schematic	119	
Wiring Diagram — AUDIO —	120	
Trouble Diagnoses	124	
Inspection	125	
AUDIO ANTENNA	126	
System Description	126	
Wiring Diagram — P/ANT —	127	
Trouble Diagnoses	128	
Location of Antenna	128	
Antenna Rod Replacement	128	
POWER SUNROOF	130	
Wiring Diagram — SROOF —	130	
DOOR MIRROR	131	
Wiring Diagram — MIRROR —	131	
GLASS HATCH OPENER	132	
Wiring Diagram — TLID —	132	
POWER SEAT	133	
Wiring Diagram — SEAT —	133	
HEATED SEAT	135	
Wiring Diagram — HSEAT —	135	
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	136	
Component Parts and Harness Connector		
Location	136	
System Description	137	
Schematic	139	
Wiring Diagram — ASCD —	140	
Fail-safe System	145	
Trouble Diagnoses	146	
Electrical Component Inspection	155	
ASCD Wire Adjustment	155	
POWER WINDOW	157	
System Description	157	
Schematic	159	
Wiring Diagram — WINDOW —	160	
Trouble Diagnoses	164	
POWER DOOR LOCK	165	
Component Parts and Harness Connector		
Location	165	
System Description	165	
Schematic	167	
Wiring Diagram — D/LOCK —	168	
Trouble Diagnoses	172	
MULTI-REMOTE CONTROL SYSTEM	180	
Component Parts and Harness Connector		
Location	180	
System Description	180	
Schematic	182	
Wiring Diagram — MULTI —	183	
Trouble Diagnoses	187	
ID Code Entry Procedure	195	
Remote Controller Battery Replacement	196	
THEFT WARNING SYSTEM	197	
Component Parts and Harness Connector		
Location	197	
System Description	198	
Schematic	202	
Wiring Diagram — THEFT —	204	
Trouble Diagnoses	210	
SMART ENTRANCE CONTROL UNIT	223	
Description	223	
Schematic	224	
Smart Entrance Control Unit Inspection Table	226	
INTEGRATED HOMELINK TRANSMITTER	227	
Wiring Diagram — TRNSMT —	227	
Trouble Diagnoses	228	
ELECTRICAL UNITS LOCATION	229	
Engine Compartment	229	
Passenger Compartment	230	

CONTENTS (Cont'd)

HARNESS LAYOUT	232	BULB SPECIFICATIONS	248	GI
How to Read Harness Layout	232	Headlamp.....	248	
Outline.....	233	Exterior Lamp	248	MA
Main Harness.....	234	Interior Lamp.....	248	
Engine Room Harness	236	WIRING DIAGRAM CODES (CELL CODES)	249	
Engine Control Harness	238	SUPER MULTIPLE JUNCTION (SMJ)	Foldout	EM
Body Harness LH	240	Installation.....	Foldout	
Body Harness RH.....	241	Terminal Arrangement.....	Foldout	
Back Door Harness	242	FUSE BLOCK — JUNCTION BOX (J/B)	Foldout	LC
Engine and Transmission Harness.....	243	Terminal Arrangement.....	Foldout	
Room Lamp	244	FUSE AND FUSIBLE LINK BOX	Foldout	EC
Air Bag Harness	245	Terminal Arrangement.....	Foldout	
Front Door Harness	246	ELECTRICAL UNITS	Foldout	
Rear Door Harness.....	247	Terminal Arrangement.....	Foldout	FE
				AT
				TF
				PD
				AX
				SU
				BR
				ST
				RS
				BT
				HA
				SC
				EL
				IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG"

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "AIR BAG", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual. NBEL0001

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the followings: NBEL0002

- "HOW TO READ WIRING DIAGRAMS" in GI section
- "POWER SUPPLY ROUTING" for power distribution circuit in EL section

When you perform trouble diagnosis, refer to the followings:

- "HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS" in GI section
- "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section

Check for any Service bulletins before servicing the vehicle.

Description

HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]

NBEL0003

NBEL0003S01

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEL769D

STANDARDIZED RELAY

Description


Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NBEL0004

NBEL0004S01




SEL881H

TYPE OF STANDARDIZED RELAYS

NBEL0004S02













1M	1 Make	2M	2 Make
1T	1 Transfer	1M-1B	1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


SEL661TA

POWER SUPPLY ROUTING

Schematic

NBEL0005

Schematic



POWER SUPPLY ROUTING

Wiring Diagram — POWER —


Wiring Diagram — POWER —

BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

NBEL0006

NBEL0006S01




EL-POWER-01



FUSE AND FUSIBLE LINK BOX (E60)

FUSE BLOCK (J/B)
(M10), (M81), (M91), (E2), (E3)

Refer to last page (Foldout page).






GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



Refer to last page (Foldout page).



(M1), (E1)

MEL0311


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont)

EL-POWER-03



Refer to last page (Foldout page).





POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

NBEL006S02

EL-POWER-04



Refer to last page (Foldout page).



MEL0331



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

NBEL0006S03

EL-POWER-05




Refer to last page (Foldout page).



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL0341



Inspection

FUSE

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.

NBEL0007


NBEL0007S01

GI

MA

EM

LC



FUSIBLE LINK

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

NBEL0007S02

EC

FE

AT


TF

PD

AX

SU

BR



CIRCUIT BREAKER

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Warning chime
- Power window & power door lock
- Power sunroof
- Power seat
- Multi-remote control system
- Theft warning system

NBEL0007S03

SI'

RS

BT

HA

SC

EL

IDX

GROUND

Ground Distribution

Ground Distribution

NBEL0008

EARTH	CONNECT TO	CONN. NO.	CELL CODE
M4/M66	ASCD CONTROL UNIT	M3	EL-ASCD
	ASCD MAIN SWITCH	M18	EL-ASCD
	COMBINATION FLASHER UNIT	M15	EL-TURN
	DOOR MIRROR REMOTE CONTROL SWITCH	M17	EL-MIRROR
	POWER ANTENNA	M69	EL-P/ANT
	POWER WINDOW RELAY	M23	EL-SROOF EL-WINDOW
	REAR WIPER SWITCH	M50	EL-WIP/R
	REAR WINDOW DEFOGGER SWITCH	M36	EL-DEF
	DOOR MIRROR DEFOGGER RH	D31	EL-DEF
	FRONT DOOR KEY CYLINDER SWITCH RH	D39	EL-THEFT EL-D/LOCK
	AIR BAG DIAGNOSIS SENSOR UNIT	Z4	RS-SRS
	AIR MIX DOOR MOTOR	M55	HA-A/C, A
	MODE DOOR MOTOR	M38	HA-A/C, A
	SHIELD WIRE (TWEETER LH)	M8	EL-AUDIO
M4/M77	ABS RELAY UNIT (SOLENOID VALVE RELAY)	M74	BR-ABS
	A/C AUTO AMP.	M102	HA-A/C, A
	A/C AUTO AMP.	M103	HA-A/C, A
	COMBINATION METER (AIR BAG)	M24	RS-SRS EL-WARN
	COMBINATION METER (CRUISE INDICATOR)	M25	EL-ASCD
	COMBINATION METER (HIGH BEAM INDICATOR)	M25	EL-H/LAMP EL-DTRL
	COMBINATION METER (SPEEDOMETER)	M24	EC-VSS AT-VSSMTR EL-METER EL-ASCD TF-T/F
	COMBINATION METER (TACHOMETER)	M24	EL-METER TF-T/F
	COMBINATION METER (TURN SIGNAL)	M26	EL-TURN
	COMBINATION METER (WATER TEMPERATURE GAUGE)	M25	EL-METER
	CIGARETTE LIGHTER SOCKET	M56	EL-CIGAR
	DATA LINK CONNECTOR FOR CONSULT	M11	EC-MIL/DL AT-NONDTTC TF-T/F
	DATA LINK CONNECTOR FOR GST	M9	EC-MIL/DL
	FAN CONTROL AMP.	M60	HA-A/C, A
	FRONT WIPER AMP.	M79	EL-WIPER
	FRONT WIPER MOTOR	M78	EL-WIPER
	FUSE BLOCK (ACCESSORY RELAY, IGNITION RELAY AND BLOWER MOTOR RELAY)	M10	EL-POWER
	HEATED SEAT SWITCH LH	M52	EL-HSEAT
	HEATED SEAT SWITCH RH	M53	EL-HSEAT
	ILLUMINATION CONTROL SWITCH	M19	EL-ILL

GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
M4/M77	SMART ENTRANCE CONTROL UNIT	M16	EL-CHIME EL-D/LOCK EL-MULTI EL-THEFT EL-DEF	G
	COMPASS AND THERMOMETER	R4	EL-ILL EL-COMPAS	MA
	INTEGRATED HOMELINK® TRANSMITTER	R5	EL-TRNSMT	
	SPOT LAMP	R6	EL-INT/L	EM
	VANITY MIRROR LH (ILLUMINATION)	R5	EL-INT/L	
	VANITY MIRROR RH (ILLUMINATION)	R3	EL-INT/L	LC
	DOOR MIRROR DEFOGGER LH	D1	EL-DEF	
	FRONT DOOR KEY CYLINDER SWITCH LH	D9	EL-THEFT EL-D/LOCK	EC
	FRONT DOOR LOCK ACTUATOR LH	D7	EL-D/LOCK EL-MULTI EL-THEFT	
	FRONT DOOR LOCK ACTUATOR RH	D37	EL-D/LOCK EL-MULTI EL-THEFT	FE
	INTAKE DOOR MOTOR	M59	HA-A/C, A	
	FRONT DOOR SPEAKER LH	D12	EL-AUDIO	AT
	SHIELD WIRE (FRONT DOOR SPEAKER LH)	D12	EL-AUDIO	
	SHIELD WIRE (TWEETER RH)	M64	EL-AUDIO	TF
	SHIELD WIRE (FRONT DOOR SPEAKER RH)	D42	EL-AUDIO	
	FRONT DOOR SPEAKER RH	D42	EL-AUDIO	PD
	AUDIO AMP. RELAY	B47	EL-AUDIO	
M95	POWER WINDOW MAIN SWITCH	D6	EL-WINDOW EL-D/LOCK	AX
	ABS CONTROL UNIT	M54	BR-ABS	
	SHIELD WIRE (FRONT WHEEL SENSOR LH)	E14	BR-ABS	SU
	SHIELD WIRE (FRONT WHEEL SENSOR RH)	E51	BR-ABS	
	SHIELD WIRE (REAR WHEEL SENSOR LH)	B69	BR-ABS	BR
	SHIELD WIRE (REAR WHEEL SENSOR RH)	B8	BR-ABS	ST
E13/E41	AMBIENT AIR TEMPERATURE SWITCH	E34	EC-FICD HA-A/C, A	
	ASCD HOLD RELAY	E22	EL-ASCD	RS
	BRAKE FLUID LEVEL SWITCH	E28	EL-WARN	
	DAYTIME LIGHT CONTROL UNIT	E45	EL-DTRL	BT
	FRONT FOG LAMP LH	E61	EL-F/FOG	
	FRONT FOG LAMP RH	E62	EL-F/FOG	HA
	FRONT FOG LAMP SWITCH	E63	EL-F/FOG	
	FRONT TURN SIGNAL LAMP LH	E30	EL-TURN	SC
	FRONT TURN SIGNAL LAMP RH	E39	EL-TURN	
	COMBINATION SWITCH (FRONT WIPER SWITCH)	E9	EL-WIPER	EL
	HEADLAMP LH	E29	EL-H/LAMP EL-THEFT	
	HEADLAMP RH	E38	EL-H/LAMP EL-DTRL EL-THEFT	IDX
	HOOD SWITCH	E31	EL-THEFT	
INHIBITOR RELAY	E56	EC-PNP/SW SC-START		

GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE
E13/E41	PARKING LAMP LH	E12	EL-TAIL/L
	PARKING LAMP RH	E40	EL-TAIL/L
	PARK/NEUTRAL POSITION SWITCH	E24	EL-ASCD
	THEFT WARNING HORN RELAY	E23	EL-THEFT
	WASHER LEVEL SWITCH	E42	EL-WARN
E101	ALTERNATOR	E105	SC-CHARGE
	POWER STEERING OIL PRESSURE SWITCH	E110	EC-PST/SW
F20/F25	TCM (TRANSMISSION CONTROL MODULE)	M104	AT-INH/SW AT-NONDTG
	DATA LINK CONNECTOR FOR GST	M9	EC-MIL/DL
	CONDENSER	F19	EC-IGN/SG
	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	DISTRIBUTOR (POWER TRANSISTOR)	F7	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	F24	EC-MAIN
	REAR HEATED OXYGEN SENSOR LH	F3	EC-RRO2LH EC-RO2H-L
	REAR HEATED OXYGEN SENSOR RH	F1	EC-RRO2RH EC-RO2H-R
	SHIELD WIRE (ABSOLUTE PRESSURE SENSOR)	E88	EC-AP/SEN
	SHIELD WIRE (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (OBD)]	F110	EC-CKPS
	SHIELD WIRE (EVAP CONTROL SYSTEM PRESSURE SENSOR)	B102	EC-PRE/SE
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR LH)	F4	EC-FRO2LH EC-FO2H-L EC-FUELLH
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR RH)	F2	EC-FRO2RH EC-FO2H-R EC-FUELRH
	SHIELD WIRE (KNOCK SENSOR)	F102	EC-KS
	SHIELD WIRE (MASS AIR FLOW SENSOR)	F10	EC-MAFS
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR LH)	F3	EC-RRO2LH EC-RO2H-L
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR RH)	F1	EC-RRO2RH EC-RO2H-R
SHIELD WIRE (THROTTLE POSITION SENSOR)	F8	EC-TPS AT-TPS TF-T/F	
B11/B22/D210	FUEL PUMP	B13	EC-F/PUMP
	FUEL TANK GAUGE UNIT	B12	EC-TFTS EL-METER EL-WARN
	FRONT DOOR SWITCH LH	B9	RS-SRS EL-CHIME EL-THEFT EL-MULTI EL-D/LOCK
	HEATED SEAT LH	B5	EL-HSEAT
	POWER SEAT LH	B7	EL-SEAT
	POWER SOCKET	B41	EL-CIGAR
	REAR COMBINATION LAMP LH (BACK-UP LAMP LH)	B26	EL-BACK/L

GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
B11/B22/D210	REAR COMBINATION LAMP LH (REAR TURN SIGNAL LAMP LH)	B26	EL-TURN	GI
	REAR COMBINATION LAMP LH (STOP LAMP LH)	B26	EL-STOP/L	MA
	REAR COMBINATION LAMP LH (TAIL LAMP LH)	B26	EL-TAIL/L	
	REAR WIPER AMP.	B14	EL-WIP/R	EM
	SEAT BELT BUCKLE SWITCH	B6	EL-WARN EL-CHIME	
	BACK DOOR KEY CYLINDER SWITCH	D201	EL-THEFT EL-D/LOCK	LC
	BACK DOOR SWITCH	D208	EL-INT/L EL-MULTI EL-THEFT	
	GLASS HATCH SWITCH	D209	EL-WIP/R EL-INT/L EL-THEFT	EC
	HIGH-MOUNTED STOP LAMP	D302	EL-STOP/L	
	LICENSE PLATE LAMP LH	D202	EL-TAIL/L	FE
	LICENSE PLATE LAMP RH	D211	EL-TAIL/L	
	LUGGAGE ROOM LAMP	D103	EL-INT/L	AT
	REAR DOOR LOCK ACTUATOR LH	D54	EL-MULTI EL-THEFT	
	REAR WIPER MOTOR	D212	EL-WIP/R EL-TLID	TF
	POWER SOCKET RELAY	B48	EL-CIGAR	
REAR SPEAKER AMP.	B46	EL-AUDIO	PD	
B55/B75	A/T DEVICE (PARK POSITION SWITCH and OVERDRIVE CONTROL SWITCH)	B59	AT-SHIFT AT-NONDTC	AX
	ASHTRAY (ILLUMINATION)	B76	EL-ILL	
	HEATED SEAT RH	B56	EL-HSEAT	SU
	REAR COMBINATION LAMP RH (BACK-UP LAMP RH)	B74	EL-BACK/L	
	REAR COMBINATION LAMP RH (REAR TURN SIGNAL LAMP RH)	B74	EL-TURN	BR
	REAR COMBINATION LAMP RH (STOP LAMP RH)	B74	EL-STOP/L	ST
	REAR COMBINATION LAMP RH (TAIL LAMP RH)	B74	EL-TAIL/L	
	POWER SEAT RH	B57	EL-SEAT	RS
	REAR DOOR LOCK ACTUATOR RH	D74	EL-MULTI EL-THEFT	
	TRANSFER MOTOR	B212	TF-T/F AT-NONDTC	BT
	WAIT DETECTION SWITCH	B211	TF-T/F AT-NONDTC	
	NEUTRAL-4LO SWITCH	B213	TF-T/F AT-NONDTC EL-WARN	HA
	ATP SWITCH	B210	TF-T/F AT-NONDTC EL-WARN	
D305	REAR WINDOW DEFOGGER	D304	EL-DEF	SC

EL



IDX

COMBINATION SWITCH

Check

Check

NBEL0009




LIGHTING SWITCH

	OFF			1			2		
	A	B	C	A	B	C	A	B	C
5			○			○	○	○	○
6			○						
7						○	○	○	○
8			○			○	○	○	○
9			○			○	○	○	○
10						○	○	○	○
11				○	○	○	○	○	○
12				○	○	○	○	○	○

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○			
14	○		○		
15		○			
16				○	
17		○	○		○
18					○






FOG LAMP SWITCH

	OFF	ON
31		○
32		○

TURN SIGNAL SWITCH

	L	N	R
1	○		○
2			○
3	○		

MEL837G



Replacement

For removal and installation of spiral cable, refer to RS section ^{NBEL0010} ["Installation — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

STEERING SWITCH

Check

Check

NBEL0011



MEL645I

System Description

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 5
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to lighting switch terminal 8
- through 15A fuse (No. 60, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 2 of the LH headlamp, and
- from lighting switch terminal 7
- to terminal 2 of the RH headlamp.

Terminal 3 of each headlamp supplies ground through body grounds E13 and E41. With power and ground supplied, the headlamp(s) will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal 6
- to terminal 1 of each RH headlamp, and
- from lighting switch terminal 9
- to terminal 1 of each LH headlamp, and
- to combination meter terminal 33 for the high beam indicator.

Ground is supplied to terminal 19 of the combination meter through body grounds M4 and M77.

Terminal 3 of each headlamp supplies ground through body grounds E13 and E41.

With power and ground supplied, the high beams and the high beam indicator illuminate.

THEFT WARNING SYSTEM

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-198).

NBEL0012

GI

MA

EM

NBEL0012S01

LC

EC

FE

NBEL0012S02

AT

TF

PD

AX

NBEL0012S03

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Trouble Diagnoses

NBEL0014

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E13 and E41 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E13 and E41. 3. Check 15A fuse (No. 60, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E13 and E41 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E13 and E41. 3. Check 15A fuse (No. 59, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch.
LH high beams do not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check R/L wire between lighting switch and LH headlamps for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/G wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beams do not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check R/W wire between lighting switch and RH headlamps for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/B wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M4 and M77 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M4 and M77. 3. Check R/L wire between lighting switch and combination meter for an open circuit.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



Bulb Replacement

NBEL0015

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.

HEADLAMP (FOR USA)

Bulb Replacement (Cont'd)

4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Aiming Adjustment


NBEL0016

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle and tester on one and same flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).




AIMER ADJUSTMENT MARK

NBEL0016S01

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Adjustment value for mechanical aimer

	Mechanical aimer level
Horizontal side	-4 to 4
Vertical side	-4 to 4




LOW BEAM

NBEL0016S02

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**

HEADLAMP (FOR USA)

Aiming Adjustment (Cont'd)



- Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.
- Dotted lines in illustration show center of headlamp.

"H": Horizontal center line of headlamps

"W_L": Distance between each headlamp center

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

DX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description

System Description

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied. NBEL0017

Power is supplied at all times

- through 15A fuse (No. 60, located in the fuse and fusible link box)
- to daytime light control unit terminal 3 and
- to lighting switch terminal 8.

Power is also supplied at all times

- through 15A fuse (No. 59, located in the fuse and fusible link box)
- to daytime light control unit terminal 2 and
- to lighting switch terminal 5.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to daytime light control unit terminal 12.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 26, located in the fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied to daytime light control unit terminal 9 through body grounds E13 and E41.

HEADLAMP OPERATION

Low Beam Operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied NBEL0017S01

- from lighting switch terminal 7
- to RH headlamp terminal 2
- to daytime light control unit terminal 4.

Ground is supplied to RH headlamp terminal 3 through body grounds E13 and E41.

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied NBEL0017S0101

- from lighting switch terminal 10
- to LH headlamp terminal 2.

Ground is supplied

- to LH headlamp terminal 3
- from daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through body grounds E13 and E41.

With power and ground supplied, the low beam headlamps illuminate.

High Beam Operation/Flash-to-pass Operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied NBEL0017S0102

- from lighting switch terminal 6
- to terminal 1 of RH headlamp.

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal 9
- to daytime light control terminal 5
- to combination meter terminal 33 for the high beam indicator
- through daytime light control terminal 6
- to terminal 1 of LH headlamp.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to terminal 19 of the combination meter through body grounds M4 and M77.

With power and ground supplied, the high beam headlamps and HI BEAM indicator illuminate.

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

DAYTIME LIGHT OPERATION

NBEL0017S02

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- to daytime light control unit terminal 3
- through daytime light control unit terminal 6
- to terminal 1 of LH headlamp
- through terminal 3 of LH headlamp
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to terminal 1 of RH headlamp.

Ground is supplied to terminal 3 of RH headlamp through body grounds E13 and E41.

Because the high beam headlamps are now wired in series, they operate at half illumination.

OPERATION

NBEL0017S03

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	△*	△*	O	△*	△*	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

A: "HIGH BEAM" position

B: "LOW BEAM" position

C: "FLASH TO PASS" position

O : Lamp "ON"

X : Lamp "OFF"

△ : Lamp dims. (Added functions)

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Schematic

Schematic

NBEL0019



MEL0371


HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

Wiring Diagram — DTRL —

NBEL0020

EL-DTRL-01



- GI
- MA
- EM
- IC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX

Refer to EL-POWER.


Next page

Next page

Next page

Refer to last page (Foldout page).

(M1) (E1)





MEL038I

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).


(E3)

MEL039I




HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



Refer to EL-POWER.



Refer to last page (Foldout page).

M1 E1

M2 B1

M10

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SC

BR

ST

RS

BT

HA

SC

EL

IDX

MEL0401

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —











Trouble Diagnoses

Trouble Diagnoses

NBEL0021








DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NBEL0021S01

Terminal No.	Item	Condition	Voltage (Approximate values)
1	Start signal	 When turning ignition switch to "ST"	Battery voltage
		 When turning ignition switch to "ON" from "ST"	Less than 1V
		 When turning ignition switch to "OFF"	Less than 1V
2	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
3	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
4	Lighting switch (Lo beam)	When lighting switch is turned to the 2ND position with "LOW BEAM" position	Battery voltage
5	Lighting switch (Hi beam)	When turning lighting switch to "HI BEAM"	Battery voltage
		When turning lighting switch to "FLASH TO PASS"	Battery voltage
6	LH hi beam	When turning lighting switch to "HI BEAM"	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
7	LH headlamp control (ground)	When lighting switch is turned to the 2ND position with "LOW BEAM" position	Less than 1V
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
8	RH hi beam	When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
9	Ground	—	—

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Terminal No.	Item	Condition	Voltage (Approximate values)
10	Parking brake switch	 When parking brake is released	Battery voltage
		When parking brake is set	Less than 1.5V
11	Alternator	 When turning ignition switch to "ON"	Less than 1V
		 When engine is running	Battery voltage
		 When turning ignition switch to "OFF"	Less than 1V
12	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "ST"	Battery voltage
		 When turning ignition switch to "OFF"	Less than 1V

CI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

Bulb Replacement

Refer to "HEADLAMP (FOR USA)" (EL-23).

NBEL0022

ST

RS

BT

HA

Aiming Adjustment

Refer to "HEADLAMP (FOR USA)" (EL-24).

NBEL0023

SC

EL

IDX


PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

Wiring Diagram — TAIL/L —

NBEL0024

EL-TAIL/L-01



Refer to last page (Foldout page).

(E3)

11 5 10 12 E7
BR



1 2 E12 E40
GY GY

MEL0411

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



Refer to last page (Foldout page).

M2, B1
M91

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL0421


STOP LAMP

Wiring Diagram — STOP/L —


Wiring Diagram — STOP/L —

NBEL0025

EL-STOP/L-01



Refer to last page (Foldout page).




(M2) (B1)
(M10)

MEL0431

STOP LAMP

Wiring Diagram — STOP/L — (Cont'd)

EL-STOP/L-02



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS






BT

HA

SC

EL

IDX



MEL550F





BACK-UP LAMP

Wiring Diagram — BACK/L —


Wiring Diagram — BACK/L —

NBEL0026

EL-BACK/L-01



Refer to last page (Foldout page).



MEL0441

System Description

Power is supplied at all times to fog lamp relay terminal 3 through:

- 15A fuse (No. 53, located in the fuse and fusible link box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 15A fuse (No. 59, located in the fuse and fusible link box).
- to lighting switch terminal 5
- through terminal 7 of the lighting switch
- to fog lamp relay terminal 1.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal 2
- through the fog lamp switch and body grounds E13 and E41.

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal 5
- to terminal 1 of each fog lamp.

Ground is supplied to terminal 2 of each fog lamp through body grounds E13 and E41.

With power and ground supplied, the fog lamps illuminate.

NBEL0027

GI

MA

EM

NBEL0027S01

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



FRONT FOG LAMP

Wiring Diagram — F/FOG —


Wiring Diagram — F/FOG —

NBEL0028

EL-F/FOG-01



MEL4671




Aiming Adjustment

NBEL0029


Before performing aiming adjustment, make sure of the following.

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.

- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description

System Description

NBEL0030

TURN SIGNAL OPERATION

NBEL0030S01

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4 and M66.

LH Turn

NBEL0030S0101

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 2
- combination meter terminal 34
- rear combination lamp LH terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp LH terminal 6 through body grounds B11, B22 and D210.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH Turn

NBEL0030S0102

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 2
- combination meter terminal 32
- rear combination lamp RH terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp RH terminal 6 through body grounds B55 and B75.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

NBEL0030S02

Power is supplied at all times to hazard switch terminal 3 through:

- 15A fuse [No. 20, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4 and M66.

Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 2
- combination meter terminal 34
- rear combination lamp LH terminal 5.

Power is supplied through terminal 6 of the hazard switch to

- front turn signal lamp RH terminal 2
- combination meter terminal 32
- rear combination lamp RH terminal 5.

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.
Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.
Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.
Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.
With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

MULTI-REMOTE CONTROL SYSTEM OPERATION

NBEL0030S03

Power is supplied at all times

- through 15A fuse [No. 20, located in the fuse block (J/B)]
- to multi-remote control relay terminals 1, 3 and 6.

EM

Ground is supplied to multi-remote control relay terminal 2, when the multi-remote control system is triggered through the smart entrance control unit.

LC

Refer to "MULTI-REMOTE CONTROL SYSTEM", EL-180.

The multi-remote control relay is energized.

EC

Power is supplied through terminal 7 of the multi-remote control relay

- to front turn signal lamp LH terminal 2
- to combination meter terminal 34
- to rear combination lamp LH terminal 5.

FE

Power is supplied through terminal 5 of the multi-remote control relay

AT

- to front turn signal lamp RH terminal 2
- to combination meter terminal 32
- to rear combination lamp RH terminal 5.

TF

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.

PD

Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

AX

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

SU

BR

ST

RS

BT

HA

SC

EL

IDX



TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

Wiring Diagram — TURN —

NBEL0032

EL-TURN-01



Refer to last page (Foldout page).


(M10)

MEL0451

TURN SIGNAL AND HAZARD WARNING LAMPS


Wiring Diagram — TURN — (Cont'd)

EL-TURN-02



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Refer to last page (Foldout page).



E1, M1
M2, B1

MEL0881


TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Trouble Diagnoses

NBEL0033

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 12, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check G wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 15A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 15A fuse [No. 20, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check G wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E13 and E41 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E13 and E41.
Rear turn signal lamp LH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds B11, B22 and D210 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds B11, B22 and D210.
Rear turn signal lamp RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds B55 and B75 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds B55 and B75.
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Ground 	<ol style="list-style-type: none"> 1. Check grounds M4 and M77.
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.



Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NBEL0034

NBEL0034501

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

ILLUMINATION

System Description

System Description

NBEL0035

Power is supplied at all times

- through 10A fuse [No. 61, located in the fuse block (J/B)]
- to lighting switch terminal 11.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M19	1	3
Combination meter	M25, M26	37	29
A/T indicator	B59	3	4
Ashtray	B76	1	2
Cigarette lighter	M57	3	4
Rear wiper switch	M50	10	11
Compass and thermometer	R4	5	2
ASCD main switch	M18	5	6
Rear window defogger switch	M36	5	6
Power window main switch	D6	4	13
Audio	M48	8	7
Hazard switch	M35	7	8
Glass hatch opener switch	M106	1	3
A/C auto amp.	M102	24	25

The ground for all of the components except for compass, thermometer and ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M4 and M77.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ILLUMINATION

Schematic

NBEL0036

Schematic



MEL930H





ILLUMINATION

Wiring Diagram — ILL —

Wiring Diagram — ILL —

NBEL0037

EL-ILL-01



Refer to last page (Foldout page).



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT

HA
SC

EL




IDX

MEL0611

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02









MEL1341

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

MEL135I

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description

System Description

NBEL0038

INTERIOR LAMP

NBEL0038S01

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)]
- to interior lamp terminal 1,

With interior lamp switch ON, ground is supplied to turn interior lamp ON.

When any of following door switch is opened with interior lamp switch in DOOR, ground is supplied to interior lamp terminal 2 through door switch.

- front door switch LH
- front door switch RH
- rear door switch LH
- rear door switch RH
- back door switch

With power and ground supplied, the interior room lamp turns ON.

LUGGAGE ROOM LAMP

NBEL0038S02

The luggage room lamp will turn on in the same manner as interior lamp.

SPOT LAMP

NBEL0038S03

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)].

With the spot lamp switch in the ON position, ground is supplied

- to spot lamp terminal 2
- through body grounds M4 and M77.

With power and ground supplied, the spot lamp turns ON.

VANITY MIRROR LAMP

NBEL0038S04

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)]
- to vanity mirror lamp terminal 1.

With the vanity mirror lamp switch in the ON position, the vanity mirror lamp turns ON.

DOOR WARNING LAMP

NBEL0038S05

With ignition switch in ON position and with any of the following door switches opened, DOOR warning lamp (in combination meter) turns ON.


- front door switch LH
- front door switch RH
- rear door switch LH
- rear door switch RH
- back door switch
- glass hatch switch

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Schematic

Schematic

NBEL0158



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

MEL444I





INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L —

Wiring Diagram — INT/L —

NBEL0040

EL-INT/L-01



Refer to last page (Foldout page).

M2, B1

M10


M91

MEL1361


INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)


EL-INT/L-02



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Refer to last page (Foldout page).





MEL1371

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-03



Refer to last page (Foldout page).



(M2) (B1)

MEL4451

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-04



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


MEL4461

METER AND GAUGES

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0041



SEL290V

System Description

NBEL0042


UNIFIED CONTROL METER

NBEL004206

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit combined with speedometer.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NBEL0042S07



SEL253V

NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

NBEL0042S08

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to combination meter terminal 3.

GI

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 12.

MA

Ground is supplied

- to combination meter terminal 2
- through body grounds M4 and M77.

EM

LC

WATER TEMPERATURE GAUGE

NBEL0042S01

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

EC

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 6 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

FE

TACHOMETER

NBEL0042S02

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 15 for the tachometer.

AT

TF

FUEL GAUGE

NBEL0042S03

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 7 for the fuel gauge
- from terminal 3 of the fuel tank gauge unit
- through terminal 2 of the fuel tank gauge unit and
- through body grounds B11, B22 and D210.

PD

AX

SU

SPEEDOMETER

NBEL0042S04

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 16 and 14 for the speedometer
- from terminals 2 and 1 of the vehicle speed sensor.

BR

ST

The speedometer converts the voltage into the vehicle speed displayed.

RS

BT

HA

SC

EL



IDX

METER AND GAUGES

Combination Meter

NBEL0043

Combination Meter




MEL4551





Wiring Diagram — METER —

NBEL0045


EL-METER-01



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT



Refer to last page (Foldout page).



HA
SC
EL
JDX

METER AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NBEL0151

DIAGNOSIS FUNCTION


NBEL0151S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.


HOW TO ALTERNATE DIAGNOSIS MODE

NBEL0151S02

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.



SEL110V



SEL111V

6. All odo/trip meter segments should be turned on.

NOTE:

If some segments are not turned on, speedometer (unified meter control unit) with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.

7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE:

It takes about 1 minute for indication of fuel gauge to become stable.

Flexible Print Circuit (FPC)

=NBEL0152

Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.

GI

MA

EM

LC

DISCONNECT

NBEL0152S01


1. Open connector cover.
2. Release connector lock by holding both ends of it and pulling it up.
3. Disconnect FPC by pulling it up.

EC

FE

AT

TF



SEL109V

CONNECT

NBEL0152S02

1. Insert FPC into connector and lock connector pushing FPC downward.
2. Check secure connection of FPC.
3. Check continuity of check land terminal for secure connection of FPC.
Resistance: 0Ω
4. Close connector cover.

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEL114V


METER AND GAUGES

Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK

NBEL0046

NBEL0046S04



MEL474H

*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-62)
*2: METER/GAUGE RESISTANCE CHECK (EL-69)

*3: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-66)
*4: Flexible Print Circuit (FPC) (EL-63)

*5: Symptom Chart 1 (EL-65)
*6: Symptom Chart 2 (EL-65)

METER AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

Symptom Chart 1 (Malfunction is Indicated in Diagnosis Mode)

NBEL0046S10

NBEL0046S1001

Symptom	Possible causes	Repair order
Speedometer and/or odometer/trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Speedometer (Unified meter control unit) 	<ul style="list-style-type: none"> Replace speedometer (unified meter control unit).
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Meter/Gauge Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-69. If the resistance is OK, replace speedometer (unified meter control unit).

Symptom Chart 2 (No Malfunction is Indicated in Diagnosis Mode)

NBEL0046S1002

Symptom	Possible causes	Repair order
Speedometer and odometer/trip meter are malfunctioning.	<ol style="list-style-type: none"> Sensor <ul style="list-style-type: none"> Speedometer, Odo/Trip meter FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-67.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-63. Replace speedometer (unified meter control unit).
Multiple meter/gauge are malfunctioning. (except speedometer, odometer/trip meter)	<ol style="list-style-type: none"> FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-63. Replace speedometer (unified meter control unit).
One of tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> Sensor/Engine revolution signal <ul style="list-style-type: none"> Tachometer Fuel gauge Water temp. gauge FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-67.) INSPECTION/FUEL TANK GAUGE UNIT (Refer to EL-68.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-68.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-63. Replace speedometer (unified meter control unit).

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-64.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

METER AND GAUGES

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NBEL0046S07


Power Supply Circuit Check

NBEL0046S0701

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
3	Ground	Battery voltage	Battery voltage	Battery voltage
12	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 10A fuse [No. 8, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter



Ground Circuit Check

NBEL0046S0702

Terminals	Continuity
2 - Ground	Yes

INSPECTION/VEHICLE SPEED SENSOR

=NBEL0046S03

1	CHECK VEHICLE SPEED SENSOR OUTPUT
<p>1. Remove vehicle speed sensor from transmission. 2. Check voltage between combination meter terminals 14 and 16 while quickly turning speed sensor pinion. Voltage: Approx. 0.5V</p>	
<p>Vehicle speed sensor</p> <p>Vehicle speed sensor pinion</p> <p>Combination meter connector (M24)</p> <p>G/Y SB</p> <p>NOTE: Vehicle speed sensor connector should remain connected.</p> <p>SEL293V</p>	
OK or NG	
OK	▶ Vehicle speed sensor is OK.
NG	▶ GO TO 2.

2	CHECK VEHICLE SPEED SENSOR
<p>Check resistance between vehicle speed sensor terminals 1 and 2. Resistance: Approx. 250Ω</p>	
<p>Vehicle speed sensor connector (B63)</p> <p>SEL344V</p>	
OK or NG	
OK	▶ Check harness or connector between speedometer and vehicle speed sensor.
NG	▶ Replace vehicle speed sensor.

INSPECTION/ENGINE REVOLUTION SIGNAL

NBEL0046S02

1	CHECK ECM OUTPUT
<p>1. Start engine. 2. Check voltage between combination meter terminals 15 and ground at idle and 2,000 rpm. Higher rpm = Higher voltage Lower rpm = Lower voltage Voltage should change with rpm.</p>	
<p>Combination meter connector (M24)</p> <p>W/B</p> <p>SEL294V</p>	
OK or NG	
OK	▶ Engine revolution signal is OK.
NG	▶ Harness for open or short between ECM and combination meter

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METER AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/FUEL TANK GAUGE UNIT

=NBEL0046S08

1	CHECK GROUND CIRCUIT FOR FUEL TANK GAUGE UNIT
<p>Check harness continuity between fuel tank gauge unit terminal 2 and ground.</p> <p style="text-align: right;">MEL839G</p>	
Does continuity exist?	
Yes	▶ GO TO 2.
No	▶ Repair harness or connector.

2	CHECK GAUGE UNITS
<p>Refer to "FUEL TANK GAUGE UNIT CHECK" (EL-69).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Replace fuel tank gauge unit.

3	CHECK HARNESS FOR OPEN OR SHORT
<ol style="list-style-type: none"> 1. Disconnect combination meter connector and fuel tank gauge unit connector. 2. Check continuity between combination meter terminal 7 and fuel tank gauge unit terminal 3. Continuity should exist. 3. Check continuity between combination meter terminal 7 and ground. Continuity should not exist. 	
<p style="text-align: right;">SEL295V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Fuel tank gauge unit is OK.
NG	▶ Repair harness or connector.

INSPECTION/THERMAL TRANSMITTER

NBEL0046S09

1	CHECK THERMAL TRANSMITTER
<p>Refer to "THERMAL TRANSMITTER CHECK" (EL-70).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Replace.

2	CHECK HARNESS FOR OPEN OR SHORT
<ol style="list-style-type: none"> 1. Disconnect combination meter connector and thermal transmitter connector. 2. Check continuity between combination meter terminal 6 and thermal transmitter terminal 1. Continuity should exist. 3. Check continuity between combination meter terminal 6 and ground. Continuity should not exist. 	
<p style="text-align: right;">SEL296V</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Thermal transmitter is OK.
NG	▶ Repair harness or connector.

Electrical Components Inspection



NBEL0047

METER/GAUGE RESISTANCE CHECK

NBEL0047S04

1. Disconnect FPC connector. Refer to "Flexible Print Circuit (FPC)" (EL-63).
2. Check resistance between installation screws of meter/gauge.

Screws		Resistance Ω
Tachometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 70 - Approx. 140
B - D	B - C	Approx. 90 - Approx. 170



FUEL TANK GAUGE UNIT CHECK

NBEL0047S01

- For removal, refer to FE section.

Check the resistance between terminals 3 and 2.

Ohmmeter		Float position mm (in)		Resistance value (Ω)
(+)	(-)			
3	2	*1	Full	96 (3.78)
		*2	1/2	188 (7.40)
		*3	Empty	257 (10.12)


*1 and *3: When float rod is in contact with stopper.

EL

IDX

METER AND GAUGES

Electrical Components Inspection (Cont'd)




THERMAL TRANSMITTER CHECK

NBEL0047S02

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω




VEHICLE SPEED SENSOR SIGNAL CHECK

NBEL0047S03

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage across a and b.

System Description

NBEL0153



This unit displays following items:

- Earth magnetism and heading direction of vehicle.
- Outside air temperature.
- Caution for frozen road surfaces.

OUTSIDE TEMPERATURE DISPLAY

NBEL0153S01

Push the switch when the ignition key is in the "ACC" or "ON" position. The outside temperature will be displayed in "°F".

- Selecting the indication range
Push the switch to change from "°F" to "°C".
- When the outside temperature drops below freezing point, ICE is displayed on the unit.
- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F).
- When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "---" though it is operating. This is not a problem.
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds.
(This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
 - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

DIRECTION DISPLAY

NBEL0153S02

Push the switch when the ignition key is in the "ACC" or "ON" position. The direction will be displayed.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX





COMPASS AND THERMOMETER

Wiring Diagram — COMPAS —

Wiring Diagram — COMPAS —

NBEL0154

EL-COMPAS-01



Refer to last page (Foldout page).

(M1) (E1)

(M10)

MEL1401

Trouble Diagnoses

PRELIMINARY CHECK FOR THERMOMETER

NBEL0048

NBEL0048S02

1	COOL DOWN CHECK	
1. Turn the ignition key switch to the "ACC" position. 2. Cool down the ambient air temperature sensor with water or ice, so that the indicated temperature falls.		
Does the indicated temperature fall?		
Yes	▶	GO TO 2.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

2	WARM UP CHECK	
1. Leave the vehicle for 10 minutes, so that the indicated temperature rises. 2. With the ignition key in the "ACC" position, disconnect and reconnect the ambient air temperature sensor connector.		
Does the indicated temperature rise?		
Yes	▶	The system is OK.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

NOTE:

- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F). When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "----".
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds. (This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
 - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

INSPECTION/COMPASS AND THERMOMETER

NBEL0048S01

Symptom	Possible causes	Repair order
No display at all	1. 10A fuse 2. Ground circuit 3. Compass and thermometer	1. Check 10A fuse [No. 9, located in fuse block (J/B)]. Turn the ignition switch ON and verify that battery positive voltage is at terminal 7 of compass and thermometer. 2. Check ground circuit for compass and thermometer. 3. Replace compass and thermometer.
Forward direction indication slips off the mark or incorrect.	1. In manual correction mode (Bar and display vanish.) 2. Zone variation change is not done.	1. Drive the vehicle and turn at an angle of 90°. 2. Perform the zone variation change.
Compass reading remains unchanged.	1. Vehicle speed sensor is not entered. 2. Compass and thermometer	1. Check harness for open or short between combination meter terminal 36 and compass and thermometer terminal 1. 2. Replace compass and thermometer.
Displays wrong temperature when ambient temperature is between -30°C (-20°F) and 55°C (130°F). (See NOTE above)	1. Check operation 2. Ambient air temperature sensor circuit 3. Vehicle speed sensor is not entered. 4. Ambient air temperature sensor 5. Compass and thermometer	1. Perform preliminary check shown above. 2. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 3. Check harness for open or short between combination meter terminal 36 and compass and thermometer terminal 1. 4. Replace ambient air temperature sensor. 5. Replace compass and thermometer.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



COMPASS AND THERMOMETER

Calibration Procedure for Compass

Calibration Procedure for Compass

NBEL0155

The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.



CORRECTION FUNCTIONS OF COMPASS

NBEL0155S01

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

INITIAL CORRECTION PROCEDURE FOR COMPASS

NBEL0155S02

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The direction bar starts blinking.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.

NOTE:


In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.

WARNING LAMPS

Schematic

NBEL0049

Schematic



© : For Canada

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

MEL1411





WARNING LAMPS

Wiring Diagram — WARN —



Wiring Diagram — WARN —

NBEL0050

EL-WARN-01



Refer to last page (Foldout page).




MEL1421



WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




Refer to last page (Foldout page).
M2, B1

MEL1431

WARNING LAMPS






Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



COMBINATION
METER
(M24, M26)

Refer to last page (Foldout page).







(M1, E1)
(M2, B1)

MEL1441

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-04



Refer to last page (Foldout page).

(M54)

(M104)






GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL145I

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-05




Refer to last page (Foldout page).
(M10)

MEL1461


WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-06




GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



Refer to last page (Foldout page).

(M1) (E1)
(M104)

MEL1471




Electrical Components Inspection
FUEL WARNING LAMP SENSOR CHECK

NBEL0051

NBEL0051S01

- It will take a short time for the bulb to light.




OIL PRESSURE SWITCH CHECK

NBEL0051S02

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



DIODE CHECK

NBEL0051S03

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.


- Diodes for warning lamps are built into the combination meter printed circuit.
- For location of diodes, refer to Combination Meter, EL-60.

WARNING CHIME

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0052 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

SEL297V BR

System Description

NBEL0053 ST

The warning chime is controlled by the smart entrance control unit.

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to warning chime terminal 1
- to key switch terminal 1.

Power is supplied at all times

- through 10A fuse [No. 61, located in the fuse block (J/B)]
- to lighting switch terminal 11.

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box).
- to smart entrance control unit terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 11.

Ground is supplied to smart entrance control unit terminal 10 through body grounds M4 and M77.

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied

- through smart entrance control unit terminal 23
- to warning chime terminal 3.

With power and ground supplied, the warning chime will sound.

EL

IDX

WARNING CHIME

System Description (Cont'd)

IGNITION KEY WARNING CHIME

NBEL0053S01

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning chime will sound. A battery positive voltage is supplied

- from key switch terminal 2
- to smart entrance control unit terminal 24.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 15.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

LIGHT WARNING CHIME

NBEL0053S02

With ignition switch OFF or ACC, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. A battery positive voltage is supplied.

- from lighting switch terminal 12
- to smart entrance control unit terminal 25.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 15.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

SEAT BELT WARNING CHIME

NBEL0053S03

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied

- from seat belt switch terminal 1
- to smart entrance control unit terminal 21.

Seat belt switch terminal 2 is grounded through body grounds B11, B22 and D210.

WARNING CHIME


Wiring Diagram — CHIME —

NBEL0054

Wiring Diagram — CHIME —

EL-CHIME-01


Refer to EL-POWER.



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT

Refer to last page (Foldout page).

(M1) (E1)
(M10)
(E3)




HA
SC
EL
IDX

MEL1481

WARNING CHIME





Wiring Diagram — CHIME — (Cont'd)

EL-CHIME-02



Refer to last page (Foldout page).

(M2) (B1)



MEL149I

WARNING CHIME

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NBEL0055

NBEL0055S01

REFERENCE PAGE (EL-)	87	88	88	89	89	90
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	LIGHTING SWITCH INPUT SIGNAL CHECK	KEY SWITCH (INSERT) CHECK	SEAT BELT BUCKLE SWITCH CHECK	DRIVER SIDE DOOR SWITCH CHECK	WARNING CHIME CHECK
Light warning chime does not activate.	X	X			X	X
Ignition key warning chime does not activate.	X		X		X	X
Seat belt warning chime does not activate.	X			X		X
All warning chimes do not activate.	X				X	X

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU

BR

ST

RS


BT

HA

SC

EL

IDX



POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check

NBEL0055S02

NBEL0055S0201


Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage
11	Ground	0V	0V	Battery voltage

ST

RS

BT

HA



Ground Circuit Check

NBEL0055S0202

Terminals	Continuity
10 - Ground	Yes

SC

EL

IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)

LIGHTING SWITCH INPUT SIGNAL CHECK

=NBEL0055S03

1	CHECK LIGHTING SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 25 and ground. Voltage [V]: Condition of lighting switch: 1ST or 2ND Approx. 12 Condition of lighting switch: OFF 0</p>	
<p style="text-align: right;">SEL232V</p>	
OK or NG	
OK	▶ Lighting switch is OK.
NG	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse (No. 61, located in the fuse and fusible link box) • Harness for open or short between control unit and lighting switch

KEY SWITCH (INSERT) CHECK

NBEL0055S04

1	CHECK KEY SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 24 and ground. Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0</p>	
<p style="text-align: right;">SEL234V</p>	
OK or NG	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
<p>Check continuity between terminals 1 and 2. Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p>	
<p style="text-align: right;">SEL249V</p>	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> • 7.5A fuse [No. 24, located in fuse block (J/B)] • Harness for open or short between key switch and fuse • Harness for open or short between control unit and key switch
NG	▶ Replace key switch.

SEAT BELT BUCKLE SWITCH CHECK

-NBEL0055S05

1	CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL
<p>1. Turn ignition switch "ON". 2. Check voltage between control unit terminal 21 and ground. Voltage [V]: Condition of seat belt buckle switch: Fastened Approx. 12 Condition of seat belt buckle switch: Unfastened 0</p>	
<p>Smart entrance control unit connector (M16)</p> <p style="text-align: right;">SEL235V</p>	
OK or NG	
OK	▶ Seat belt buckle switch is OK.
NG	▶ GO TO 2.

2	CHECK SEAT BELT BUCKLE SWITCH
<p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened. Continuity: Seat belt is fastened. No Seat belt is unfastened. Yes</p>	
<p>Seat belt buckle switch connector (B6)</p> <p style="text-align: right;">SEL298V</p>	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> • Seat belt buckle switch ground circuit • Harness for open or short between control unit and seat belt buckle switch
NG	▶ Replace seat belt buckle switch.

DRIVER SIDE DOOR SWITCH CHECK

NBEL0055S06

1	CHECK DOOR SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 15 and ground. Voltage [V]: Condition of driver's door: CLOSED Approx. 12 Condition of driver's door: OPENED 0</p>	
<p>Smart entrance control unit connector (M16)</p> <p style="text-align: right;">SEL236V</p>	
OK or NG	
OK	▶ Driver side door switch is OK.
NG	▶ GO TO 2.

2	CHECK DRIVER SIDE DOOR SWITCH
<p>Check continuity between terminals 1 and 2, 3 and ground. Continuity: Door switch is pushed. No Door switch is released. Yes</p>	
<p>Door switch LH connector (B9)</p> <p style="text-align: right;">SEL237V</p>	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> • Door switch ground circuit • Harness for open or short between control unit and door switch
NG	▶ Replace driver side door switch.

WARNING CHIME

Trouble Diagnoses (Cont'd)

WARNING CHIME CHECK

-NBEL0055S07

1	CHECK CHIME POWER SUPPLY	
<p>Check voltage between warning chime terminal 1 and ground.</p> <div style="text-align: center;"> <p>Chime connector (M27)</p> </div> <p style="text-align: right;">SEL770UA</p>		
Does battery voltage exist?		
Yes	▶	GO TO 2.
No	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • 7.5A fuse (No. 24, located in fuse block (J/B)) • Harness for open or short between chime and fuse

2	CHECK WARNING CHIME	
<p>1. Disconnect warning chime connector. 2. Apply 12V direct current to warning chime and check operation.</p> <div style="text-align: center;"> <p>Chime connector (M27)</p> <p style="text-align: right;">SEL408V</p> </div>		
Does warning chime sound?		
Yes	▶	Check harness for open or short between control unit and warning chime.
No	▶	Replace warning chime.

System Description

WIPER OPERATION

NBEL0057

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

NBEL0057S01

- LO speed
- HI speed
- INT (Intermittent)

GI

MA

EM

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to wiper motor terminal 6.

LC

Low and High Speed Wiper Operation

NBEL0057S0101

Ground is supplied to wiper switch terminal 17 through body grounds E13 and E41.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

EC

FE

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 1.

AT

TF

With power and ground supplied, the wiper motor operates at high speed.

Auto Stop Operation

NBEL0057S0102

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

PD

AX

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper amplifier terminal 2
- through terminal 7 of the wiper amplifier
- to wiper motor terminal 5
- through terminal 4 of the wiper motor, and
- through body grounds M4 and M77.

SU

BR

ST

When wiper arms reach base of windshield, wiper motor terminals 5 and 6 are connected instead of terminals 4 and 5. Wiper motor will then stop wiper arms at the PARK position.

RS

Intermittent Operation

NBEL0057S0103

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal 1
- from wiper switch terminal 15
- through body grounds E13 and E41.
- to wiper motor terminal 2
- through the wiper switch terminal 14
- to wiper switch terminal 13
- through wiper amplifier terminal 2
- to wiper amplifier terminal 3
- through body grounds M4 and M77.

BT

HA

SC

EL

IDX

The desired interval time is input

- to wiper amplifier terminal 8
- from wiper switch terminal 19.

The wiper motor operates at low speed at the desired time interval.

FRONT WIPER AND WASHER

System Description (Cont'd)

WASHER OPERATION

NBEL0057S02

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal 2, and
- to wiper amplifier terminal 6
- from terminal 18 of the wiper switch
- through terminal 17 of the wiper switch, and
- through body grounds E13 and E41.

With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.



FRONT WIPER AND WASHER

Wiring Diagram — WIPER —

Wiring Diagram — WIPER —

NBEL0058

EL-WIPER-01 GI



Refer to last page (Foldout page).

(M1) (E1)

(M10)

(E4)



- MA
- EM
- LC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX

MEL1501

FRONT WIPER AND WASHER

Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-02



MEL1511


Trouble Diagnoses DIAGNOSTIC PROCEDURE 1


NBEL0059


NBEL0059S01

SYMPTOM: Intermittent wiper does not operate.

1	CHECK WIPER OPERATION
Check whether wiper operates with the wiper switch at Lo position.	
Does wiper operate at Lo speed?	
Yes	▶ GO TO 2.
No	<p style="text-align: center;">Check the following.</p> <ul style="list-style-type: none"> ● 20A fuse [No. 19, located in fuse block (J/B)] ● Wiper motor ● Wiper switch ● Harness for open or short

2	CHECK WIPER AMP. OUTPUT
<ol style="list-style-type: none"> 1. Turn front wiper switch to OFF. 2. Disconnect wiper amp. connector. 3. Check voltage between wiper amp. terminal 2 and ground. 	
	
SEL226V	
Does battery voltage exist?	
Yes	▶ GO TO 3.
No	<p style="text-align: center;">Check the following.</p> <ul style="list-style-type: none"> ● Wiper switch ● Harness for open or short between wiper amp. terminal 2 and wiper switch terminal 13

3	CHECK INTERMITTENT SWITCH INPUT SIGNAL
Check harness continuity between wiper amp. terminal 1 and ground.	
<p>Continuity:</p> <p style="padding-left: 20px;">Condition of wiper switch: OFF</p> <p style="padding-left: 20px;">No</p> <p style="padding-left: 20px;">Condition of wiper switch: INT</p> <p style="padding-left: 20px;">Yes</p>	
	
SEL227V	
OK or NG	
OK	▶ GO TO 4.
NG	<p style="text-align: center;">Check the following.</p> <ul style="list-style-type: none"> ● Wiper switch ● Harness for open or short between wiper amp. terminal 1 and wiper switch terminal 15 ● Ground circuit for front wiper switch terminal 17

4	CHECK WIPER AMP. POWER SUPPLY CIRCUIT
Check voltage between wiper amp. terminal 5 and ground while ignition switch is "ACC".	
	
SEL228V	
Does battery voltage exist?	
Yes	▶ GO TO 5.
No	<p style="text-align: center;">Check the following.</p> <ul style="list-style-type: none"> ● 20A fuse [No. 19, located in fuse block (J/B)] ● Harness for open or short between wiper amp. and fuse

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

FRONT WIPER AND WASHER

Trouble Diagnoses (Cont'd)

5	CHECK WIPER AMP. GROUND CIRCUIT
<p>Check harness continuity between wiper amp. terminal 3 and body ground.</p>	
<p style="text-align: right;">SEL229V</p>	
Does continuity exist?	
Yes	▶ Replace wiper amp.
No	▶ Repair harness or connector.

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted. NBEL0059S02

1	CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL
<p>1. Disconnect wiper amp. connector. 2. Measure resistance between wiper amp. terminals 8 and 3 while turning intermittent wiper volume.</p> <p>Resistance [Ω]: Position of wiper knob: S 0 Position of wiper knob: L Approx. 1 k</p>	
<p style="text-align: right;">SEL230V</p>	
OK or NG	
OK	▶ Replace wiper amp.
NG	▶ Check the following. <ul style="list-style-type: none"> ● Intermittent wiper volume ● Harness for open or short between wiper amp. terminal 8 and wiper switch terminal 19 ● Ground circuit for front wiper switch terminal 20

DIAGNOSTIC PROCEDURE 3

-NBEL0059S03

SYMPTOM: Wiper and washer activate individually but not in combination.

1 CHECK WASHER SWITCH INPUT SIGNAL	
1. Turn ignition switch to "OFF". 2. Disconnect wiper amp. connector. 3. Check harness continuity between wiper amp. terminal 6 and ground. Continuity: Condition of washer switch: OFF No Condition of washer switch: ON Yes	
<p style="text-align: right;">SEL231V</p>	
OK or NG	
OK	▶ Go to DIAGNOSTIC PROCEDURE 1.
NG	▶ Check harness for open or short between wiper amp. terminal 6 and wiper switch terminal 18.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

NBEL0060

NBEL0060S01

RS


BT

HA

SC

EL

IDX



Removal and Installation

WIPER ARMS

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".

Clearance "L₁": 34 mm (1.34 in)


Clearance "L₂": 37 mm (1.46 in)

- Tighten wiper arm nuts to specified torque.

Front wiper: 17 - 23 N·m (1.7 - 2.3 kg·m, 12 - 17 ft·lb)

FRONT WIPER AND WASHER


Removal and Installation (Cont'd)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER LINKAGE

NBEL0060S02



Removal

NBEL0060S0201

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation

NBEL0060S0202


- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

Washer Nozzle Adjustment

NBEL0061

- Adjust washer nozzle with suitable tool as shown in the figure at left.


Adjustable range: $\pm 10^\circ$



FRONT WIPER AND WASHER

Washer Nozzle Adjustment (Cont'd)


Unit: mm (in)



SEL544T

*1	390 (15.35)	*5	145 (5.71)
*2	160 (6.30)	*6	143 (5.63)
*3	379 (14.92)	*7	225 (8.86)
*4	140 (5.51)	*8	535 (21.06)

*: The diameters of these circles are less than 80 mm (3.15 in).



MEL074H

Washer Tube Layout

NBEL0062

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REAR WIPER AND WASHER

System Description

System Description

NBEL0063

NBEL0063S01

NBEL0063S0101

WIPER OPERATION

Power Supply and Ground

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 29, located in the fuse block (J/B)]
- to rear wiper relay terminals 4 and 1.

When the glass hatch switch is CLOSED, power is supplied

- from rear wiper relay terminal 3
- to rear wiper amp. terminal 5,
- to rear washer motor terminal 1 and
- to rear wiper motor terminal 6.

If the glass hatch switch is OPEN, ground is supplied

- to rear wiper relay terminal 2
- from glass hatch switch terminal 1.

Then rear wiper relay is energized and power to the rear wiper amp., washer motor and wiper motor is interrupted.

(If the glass hatch is opened, no function of rear wiper motor will operate.)

If the rear wiper switch is turned to the INT or ON position, when glass hatch is opened, rear wiper relay terminal 2 is also grounded

- through rear wiper relay terminals 6 and 7
- from rear wiper switch terminal 8.

(The purpose of this circuit is to prevent an abrupt operation of the rear wiper when the hatch is closed with the ignition switch turned to ON or ACC, and with the rear wiper switch set to INT or ON.)

Ground is supplied

- to rear wiper amplifier terminal 3
- through body grounds B11, B22 and D210.
- to rear wiper switch terminal 3
- through body grounds M4 and M66.

Rising Up Operation

When the rear wiper switch is turned to the INT or ON position, ground is supplied

- through terminal 1 of rear wiper switch
- to rear wiper amp. terminal 1.

Then wiper amp. is energized and power is supplied

- through rear wiper amp. terminal 4
- to rear wiper motor terminal 4.

Ground is supplied to rear wiper motor through rear wiper switch.

With power and ground supplied, rear wiper operates and rear wiper arm moves up.

Wiper does not return to resting position until wiper switch is turned to OFF position.

Low Speed Wiper Operation

When the rear wiper switch is placed in the ON position, ground is supplied

- through terminal 5 of rear wiper switch
- to rear wiper motor terminal 3.

With power and ground supplied, the wiper motor operates at low speed.

Auto Stop Operation

With rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arms reach rear wiper stopper.

When wiper arm is not located at rear wiper stopper with wiper switch OFF, ground is provided

- from terminal 5 of the rear wiper switch
- to wiper motor terminal 3, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 4 of the rear wiper switch

NBEL0063S0102

NBEL0063S0103

NBEL0063S0104

- to rear wiper amplifier terminal 2
- through terminal 7 of the rear wiper amplifier
- to rear wiper motor terminal 7
- through terminal 8 of the wiper motor, and
- through body grounds B11, B22 and D210.

GI

When wiper arms reach rear wiper stopper, rear wiper motor terminals 7 and 6 are connected instead of terminals 7 and 8. Rear wiper motor will then stop wiper arms at the PARK position.

MA

Intermittent Operation

The rear wiper motor operates the wiper arms at low speed approximately every 7 seconds. This feature is controlled by the wiper amplifier. NBEL0063S0105

EM

When the wiper switch is placed in the INT position, ground is supplied

LC

- to wiper amplifier terminal 1
- from rear wiper switch terminal 1
- through body grounds M4 and M66.
- to wiper motor terminal 3
- through the rear wiper switch terminal 5
- to rear wiper switch terminal 4
- through wiper amplifier terminal 2
- to wiper amplifier terminal 3
- through body grounds B11, B22 and D210.

EC

FE

AT

TF

The rear wiper motor operates at low speed intermittent.

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied NBEL0063S02

PD

- through 10A fuse (No. 29, located in the fuse block)
- to rear washer motor terminal 1.

AX

When the rear wiper switch is turned to WASH position, ground is supplied

- to rear washer motor terminal 2, and
- to rear wiper amplifier terminal 6
- from terminal 2 of rear wiper switch
- through terminal 3 of rear wiper switch, and
- through body grounds M4 and M66.

SU

BR

With power and ground supplied, the rear washer motor operates.

ST

When the rear wiper switch is turned to WASH position for one second or more, the rear wiper motor operates at low speed for approximately 3 seconds after the rear wiper switch is released. This feature is controlled by the rear wiper amplifier in the same manner as the intermittent operation.

RS

BT

HA

SC

EL


IDX

REAR WIPER AND WASHER

Schematic

Schematic

NBEL0064










MEL040H

REAR WIPER AND WASHER

Wiring Diagram — WIP/R —

Wiring Diagram — WIP/R —

NBEL0065




GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL1521

REAR WIPER AND WASHER

Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-02



11	3	0	1	9	6
7	10	5	4	2	8

(M50) W

2	1
---	---

(E43) GY

4	3	2	1
8	7	6	5

(B14) W

Refer to last page (Foldout page).


(M1)	(E1)
(M2)	(B1)

MEL931H





REAR WIPER AND WASHER

Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-03



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT



HA
SC
EL
IDX

MEL042H

REAR WIPER AND WASHER

Trouble Diagnoses







Trouble Diagnoses

NBEL0066

NBEL0066S01



REAR WIPER AMP. INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition		Voltage (Approximate value)	
1	Amp. ON signal		Rear wiper switch	ON or INT	1V or less
				OFF	Approx. 12V
2	Wiper amp. output		Rear wiper switch "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12V
3	Ground	—		—	
4	Rear wiper motor		Rear wiper switch	ON, INT or WASH	Approx. 12V
				OFF	1V or less
5	Power supply (See NOTE)		Rear glass hatch	OPENED	0V
				CLOSED	Approx. 12V
6	Washer switch		Rear wiper switch	WASH	1V or less
				OFF	Approx. 12V
7	Auto stop		Rear wiper switch "ON" or "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12V

NOTE:

Power to the rear wiper amp. will be interrupted when the rear glass hatch is opened. In that case, conduct the inspection of the rear wiper amp. with the rear glass hatch closed, unless otherwise indicated.




Removal and Installation


NBEL0067

WIPER ARMS

NBEL0067S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Install wiper arm to portion A as in figure below and tighten wiper arm nut to specification.
3. Then, set wiper arm to portion B.
 : 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.




Washer Nozzle Adjustment

NBEL0068


- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$ (In any direction)



Washer Tube Layout


NBEL0069



Check Valve

NBEL0070

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



HORN

Wiring Diagram — HORN —

Wiring Diagram — HORN —

NBEL0071

EL-HORN-01



* : This connector is not shown in "HARNESS LAYOUT".

Refer to last page (Foldout page).

(M1), (E1)

MEL1531


CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

Wiring Diagram — CIGAR —

NBEL0156

EL-CIGAR-01 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Refer to last page (Foldout page).

(M2) (B1)

(E1) (M1)

(M10)


MEL154I

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0072



SEL391V

System Description

NBEL0073

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 20A fuse (No. 56, located in the fuse and fusible link box) and
- to rear window defogger relay terminal 6
- through 20A fuse (No. 57, located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 18, located in the fuse block (J/B)]
- to the rear window defogger relay terminal 1 and
- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 11.

Ground is supplied to terminal 1 of the rear window defogger switch through body grounds M4 and M66.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal 2 of the rear window defogger switch
- to smart entrance control unit terminal 20.

Terminal 36 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

REAR WINDOW DEFOGGER

System Description (Cont'd)

- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch
- from terminal 7 of the rear window defogger relay.

Terminal 4 of the rear window defogger switch is grounded through body grounds M4 and M66.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX





REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

Wiring Diagram — DEF —

NBEL0074

EL-DEF-01



Refer to last page (Foldout page).


- (M1) . (E1)
- (M2) . (B1)
- (M10)
- (E3)

MEL1551






REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT



Refer to last page (Foldout page).

E1, M1

HA
SC
EL
IDX

MEL046H

REAR WINDOW DEFOGGER


Trouble Diagnoses


Trouble Diagnoses DIAGNOSTIC PROCEDURE

NBEL0075

NBEL0075S01

SYMPTOM: Rear window defogger does not activate, or does not go off after activating.

1	CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL
<p>1. Turn ignition switch to ON position. 2. Check voltage between control unit harness terminal 36 and ground.</p> <p>Voltage [V]: Rear window defogger switch is "OFF". Approx. 12 Rear window defogger switch is "ON". 0</p>  <p style="text-align: right;">SEL620U</p>	
OK or NG	
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Rear window defogger relay (Refer to EL-116.) ● Rear window defogger circuit ● Rear window defogger filament (Refer to EL-116.)
NG	▶ GO TO 2.

2	CHECK DEFOGGER RELAY COIL SIDE CIRCUIT
<p>1. Disconnect control unit connector. 2. Turn ignition switch to ON position. 3. Check voltage between control unit terminal 36 and ground.</p>  <p style="text-align: right;">SEL735U</p>	
Does battery voltage exist?	
Yes	▶ GO TO 3.
No	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 18, located in the fuse block (J/B)] ● Rear window defogger relay ● Harness for open or short between rear window defogger relay and control unit

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

3	CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL
<p>Check continuity between control unit terminal 20 and ground.</p> <p>Continuity: Rear window defogger switch is pushed. Yes Rear window defogger switch is released. No</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>20</p> <p>OR</p> <p>Ω</p> <p>SEL345V</p>	
OK or NG	
OK	▶ GO TO 4.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> • Rear window defogger switch (Refer to EL-116.) • Harness for open or short between control unit and rear window defogger switch • Rear window defogger switch ground circuit


4	CHECK IGNITION INPUT SIGNAL
<p>Check voltage between control unit terminal 11 and ground.</p> <p>Voltage [V]: Ignition switch is "ON". Approx. 12 Ignition switch is "OFF". 0</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>11</p> <p>w/B</p> <p>V</p> <p>+</p> <p>-</p> <p>DISCONNECT</p> <p>H.S.</p> <p>SEL424TB</p>	
OK or NG	
OK	▶ GO TO 5.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> • 7.5A fuse [No. 11, located in the fuse block (J/B)] • Harness for open or short between control unit and fuse

5	CHECK CONTROL UNIT GROUND CIRCUIT
<p>Check continuity between control unit terminal 10 and ground.</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>10</p> <p>B</p> <p>Ω</p> <p>DISCONNECT</p> <p>H.S.</p> <p>OFF</p> <p>SEL363TB</p>	
Does continuity exist?	
Yes	▶ Replace control unit.
No	▶ Repair harness or connectors.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

Electrical Components Inspection



SEC202B

Electrical Components Inspection


NBEL0076

REAR WINDOW DEFOGGER RELAY

NBEL0076S01

Check continuity between terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No




SEL430TB

REAR WINDOW DEFOGGER SWITCH

NBEL0076S02

Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No




SEL263

Filament Check


NBEL0077

1. Attach probe circuit tester (in volt range) to middle portion of each filament.



SEL265

2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

GI

MA

EM

LC

Filament Repair

REPAIR EQUIPMENT

NBEL0078

NBEL0078S01


- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth

EC

FE

AT

TF



REPAIRING PROCEDURE

NBEL0078S02

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

PD


AX

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

SU

BR



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.


ST

Do not touch repaired area while test is being conducted.

RS

BT

HA



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

SC

EL

IDX

System Description

NBEL0079

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio terminal 6,
- to audio amp. relay terminal 3 and
- to rear speaker amp. terminal 11.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio terminal 10.

Ground is supplied through the case of the audio.

Ground is supplied

- to audio amp. relay terminal 2,
- to front door speaker LH terminal 5 and
- to front door speaker RH terminal 5
- through body grounds M4 and M77
- to rear speaker amp. terminal 24
- through body grounds B11, B22 and D210.

When the radio POWER button is pressed, power is supplied to rear speaker amp. terminal 9 and audio amp. relay terminal 1 from audio terminal 12. Then audio amp. relay is energized and power is supplied

- to front door speaker LH terminal 4 and
- to front door speaker RH terminal 4.

Audio signals are supplied

- through audio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 2 and 6 of the LH and RH front speakers and terminals 5, 7, 18 and 20 of the rear speaker amp.
- to LH and RH tweeters through terminals 1 and 3 of the front speakers
- to rear LH and RH speakers through terminals 1, 2, 25 and 26 of the rear speaker amp.


AUDIO

Wiring Diagram — AUDIO —


Wiring Diagram — AUDIO —

NBEL0081

EL-AUDIO-01





Refer to last page (Foldout page).



MEL0461

EL-AUDIO-02




GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX

MEL0471

AUDIO



Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-03



Refer to last page (Foldout page).

(M2), (B1)




MEL0481

AUDIO

Wiring Diagram — AUDIO — (Cont'd)



EL-AUDIO-04



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Refer to last page (Foldout page).

(M2) (B1)



MEL049I

AUDIO

Trouble Diagnoses

NBEL0082

NBEL0082S01

RADIO

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse Poor radio case ground Radio 	<ol style="list-style-type: none"> Check 10A fuse [No. 10, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of radio. Check radio case ground. Remove radio for repair.
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 15A fuse Radio 	<ol style="list-style-type: none"> Check 15A fuse [No. 4, located in fuse block (J/B)] and verify that battery positive voltage is present at terminal 6 of radio. Remove radio for repair.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor radio ground Radio 	<ol style="list-style-type: none"> Check antenna. Check radio ground. Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Radio 	<ol style="list-style-type: none"> Check window antenna. Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor radio ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Radio 	<ol style="list-style-type: none"> Check radio ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor radio ground Antenna Accessory ground Faulty accessory 	<ol style="list-style-type: none"> Check radio ground. Check antenna. Check accessory ground. Replace accessory.
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> 15A fuse Radio output Radio 	<ol style="list-style-type: none"> Check 15A fuse [No. 4, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of audio amp. relay. Check radio output voltage (Terminal 12). Remove radio for repair.
All front speakers are inoperative.	<ol style="list-style-type: none"> Audio amp. relay Audio amp. relay ground Amp. ON signal 	<ol style="list-style-type: none"> Check audio amp. relay. Check audio amp. relay ground (Terminal 2). Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal 1 of audio amp. relay.
Individual front speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker ground Power supply Radio output Speaker 	<ol style="list-style-type: none"> Check speaker ground (Terminal 5). Check power supply for speaker (Terminal 4). Check radio output voltage for speaker. Replace speaker.
Both rear speakers are inoperative.	<ol style="list-style-type: none"> Poor rear speaker amp. ground Power supply Amp. ON signal Rear speaker amp. 	<ol style="list-style-type: none"> Check rear speaker amp. ground circuit. Check power supply for rear speaker amp. (Terminal 11). Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal 9 of rear speaker amp. Remove rear speaker amp. for repair.
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Radio/amp. output Speaker circuit Radio 	<ol style="list-style-type: none"> Check speaker. Check radio/amp. output. Check wires for open or short between radio/amp. and speakers. Remove radio for repair.

Inspection

RADIO AND AMP.

NBEL0083

NBEL0083S01

GI

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amps. connected (If radio or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

MA

EM

ANTENNA

NBEL0083S02

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface).
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUDIO ANTENNA

System Description

System Description

NBEL0084

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to power antenna terminal 6.

Ground is supplied to the power antenna terminal 2 through body grounds M4 and M66.

When the audio is turned to the ON position, battery positive voltage is supplied

- through audio terminal 5
- to power antenna terminal 4.

The antenna raises and is held in the extended position.

When the audio is turned to the OFF position, battery positive voltage is interrupted

- from audio terminal 5
- to power antenna terminal 4.


The antenna retracts.

AUDIO ANTENNA

Wiring Diagram — P/ANT —

Wiring Diagram — P/ANT —

NGEL0085



EL-P/ANT-01

Refer to EL-POWER.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

Refer to last page (Foldout page).



(M10)

HA

SC

EL

IDX



MEL0501

AUDIO ANTENNA

Trouble Diagnoses

Trouble Diagnoses

NBEL0086



NBEL0086S01

POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 7.5A fuse Radio signal Grounds M4 and M66 	<ol style="list-style-type: none"> Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal 6 of power antenna. Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal 4 of power antenna. Check grounds M4 and M66.

Location of Antenna

NBEL0087



Antenna Rod Replacement REMOVAL


NBEL0088

NBEL0088S01

- Remove antenna nut and antenna base.

AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)




2. Withdraw antenna rod while raising it by operating antenna motor.

GI

MA

EM

LC



INSTALLATION

NBEL0068502

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



POWER SUNROOF

Wiring Diagram — SROOF —

Wiring Diagram — SROOF —

NBEL0089

EL-SROOF-01



Refer to last page (Foldout page).

(M1), (E1)

(M10)

MEL0511

DOOR MIRROR

Wiring Diagram — MIRROR —

Wiring Diagram — MIRROR —

NBEL0090

EL-MIRROR-01

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA




SC

EL

IDX



Refer to last page (Foldout page).
M10





GLASS HATCH OPENER

Wiring Diagram — TLID —

Wiring Diagram — TLID —

NBEL0091

EL-TLID-01



Refer to last page (Foldout page).

(M2) (B1)
(M81)

MEL0541


POWER SEAT

Wiring Diagram — SEAT —

Wiring Diagram — SEAT —

NBEL0092

EL-SEAT-01 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

Refer to last page (Foldout page).

(E1), (M1)

(M2), (B1)





MEL1331

POWER SEAT

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-02



MEL601F


HEATED SEAT

Wiring Diagram — HSEAT —


Wiring Diagram — HSEAT —

NBEL0093


EL-HSEAT-01 GI



MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Refer to last page (Foldout page).




MEL0551

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0094










Fuse block (J/B)

1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

Front



Fuse and fusible link box



MEL4581

System Description

Refer to Owner's Manual for ASCD operating instructions.

NBEL0095

POWER SUPPLY AND GROUND

When ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to ASCD hold relay terminal 7 (A/T models) and
- to ASCD main switch terminal 1.

When ASCD main switch is in ON position, power is supplied

- from ASCD main switch terminal 3
- to ASCD hold relay terminal 1.

Ground is supplied

- to ASCD hold relay terminal 2
- through body grounds E13 and E41.

With power and ground is supplied, the ASCD hold relay is energized. And then power is supplied

- from ASCD hold relay terminal 6 (A/T models)
- to ASCD control unit terminal 4 and
- to ASCD main switch terminal 2.

After the ASCD main switch is released, power remains supplied

- to the coil circuit of ASCD hold relay
- through ASCD main switch terminals 2 and 3.

This power supply is kept until any of following conditions exist.

- Ignition switch is returned to the ACC or OFF position.
- ASCD main switch is turned to OFF position.

During ASCD hold relay is energized power is also supplied to ASCD control unit terminal 5

- through ASCD brake switch, ASCD hold relay and park/neutral position relay.

Ground is supplied

- to ASCD control unit terminal 3
- through body grounds M4 and M66.

INPUTS

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- park/neutral position relay
- ASCD brake switch.

A vehicle speed input is supplied

- to ASCD control unit terminal 7
- from terminal 36 of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal 1
- through 10A fuse [No. 14, located in the fuse block (J/B)].

When the brake pedal is depressed, power is supplied

- from terminal 2 of the stop lamp switch
- to ASCD control unit terminal 11.

Power is supplied at all times

- through 10A fuse [No. 54, located in the fuse and fusible link box]
- to horn relay terminal 2
- through terminal 1 of the horn relay
- to ASCD steering switch terminal 21.

When the SET/COAST switch is depressed, power is supplied

GI

NBEL0095S03

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

NBEL0095S01

ST

RS

BT

HA

SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

- from terminal 22 of the ASCD steering switch
- to ASCD control unit terminal 2.

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal 23 of the ASCD steering switch
- to ASCD control unit terminal 1.

When the system is activated, power is supplied

- to ASCD control unit terminal 5.

Power is interrupted when

- the selector lever is placed in P or N or
- the ASCD brake switch is depressed.

OUTPUTS

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. NBEL0095S02
The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal 8 of the ASCD control unit
- to ASCD pump terminal 1.

Ground is supplied to the vacuum motor

- from terminal 9 of the ASCD control unit
- to ASCD pump terminal 2.

Ground is supplied to the air valve

- from terminal 10 of the ASCD control unit
- to ASCD pump terminal 3.

Ground is supplied to the release valve

- from terminal 14 of the ASCD control unit
- to ASCD pump terminal 4.

When the system is activated, power is supplied

- from terminal 13 of the ASCD control unit
- to combination meter terminal 9 and
- to TCM (Transmission control module) terminal 8.

Ground is supplied

- to combination meter terminal 19
- through body grounds M4 and M66.

With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed, a signal is sent

- from terminal 12 of the ASCD control unit
- to TCM (Transmission control module) terminal 10.

When this occurs, the TCM (Transmission control module) cancels overdrive.


After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic

NBEL0096

Schematic



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL056I

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —



Wiring Diagram — ASCD —

NBEL0097

NBEL0097S01

EL-ASCD-01

FIG. 1



Refer to last page (Foldout page).

- (M1) , (E1)
- (E3)
- (M10)

MEL0571








AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 2

NBEL0097502

EL-ASCD-02 GI



Refer to last page (Foldout page).

(M1) (E1)

(M10)

(E3)

EL

IDX

MEL0581









AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 3

NGEL0097S03

EL-ASCD-03



Refer to last page (Foldout page).

- (M1) (E1)
- (M10)

* : This connector is not shown in "HARNESS LAYOUT".

MEL059I


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 4

NBEL0097504

EL-ASCD-04 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



Refer to last page (Foldout page).

(E1) (M1)



MEL800G

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 5

NBEL0097S05




Refer to last page (Foldout page).

(M10)
(M104)

MEL0601

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Fail-safe System



Fail-safe System

DESCRIPTION

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

NBEL0098

NBEL0098S01

GI

MA

EM

LC

MALFUNCTION DETECTION CONDITIONS

NBEL0098S02

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. Vacuum motor ground circuit or power circuit is open or shorted. Air valve ground circuit or power circuit is open or shorted. Release valve ground circuit or power circuit is open or shorted. Vehicle speed sensor is faulty. ASCD control unit internal circuit is malfunctioning. 	<ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is canceled.
<ul style="list-style-type: none"> ASCD brake switch or stop lamp switch is faulty. 	<ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is not canceled.

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NBEL0099

NBEL0099S01




PROCEDURE	Diagnostic procedure								
REFERENCE PAGE (EL-)	147	148	149	150	151	152	153	153	154
SYMPTOM	FAIL-SAFE SYSTEM CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	ASCD MAIN SWITCH CHECK	ASCD HOLD RELAY CHECK	ASCD BRAKE/STOP LAMP SWITCH CHECK	ASCD STEERING SWITCH CHECK	VEHICLE SPEED SENSOR CHECK	ASCD PUMP CIRCUIT CHECK	ASCD ACTUATOR/PUMP CHECK
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)		X	X	X		X	X		
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X				X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.						X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2						X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.						X			X
System is not released after CANCEL switch (steering) has been pressed.						X			X
Large difference between set speed and actual vehicle speed.									X
Deceleration is greatest immediately after ASCD has been set.									X

★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "FAIL-SAFE SYSTEM CHECK" (EL-147) to verify repairs.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



FAIL-SAFE SYSTEM CHECK

-NBEL0099S02

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the "cruise indicator" blinks.

If the indicator lamp blinks, check the following.

- ASCD steering switch. Refer to EL-152.

GI

MA

EM

LC

3. Drive the vehicle at more than 48 km/h (30 MPH) and push SET/COAST switch.

If the indicator lamp blinks, check the following.

- Vehicle speed sensor. Refer to EL-153.
- ASCD pump circuit. Refer to EL-153.
- Replace control unit.

EC

FE

AT

TF

4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

If the indicator lamp blinks, check the following.

- ASCD brake/stop lamp switch. Refer to EL-151.

PD

AX

SU

BR

5. END. (System is OK.)

ST

RS

BT

HA

SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

-NBEL0099S03

1	OPERATION CHECK	
1. Turn ignition switch ON. 2. Turn ASCD main switch "ON".		
Does ASCD indicator illuminate?		
Yes	▶	GO TO 2.
No	▶	Go to ASCD MAIN SWITCH CHECK. Refer to EL-149.

2	CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT	
1. Disconnect ASCD control unit connector. 2. Turn ignition switch ON. 3. Turn ASCD main switch "ON". 4. Check voltage between control unit connector terminal 4 and ground.		
ASCD control unit connector (M3)		
SEL289UD		
Refer to wiring diagram in EL-140.		
Does battery voltage exist?		
Yes	▶	GO TO 3.
No	▶	Go to ASCD HOLD RELAY CHECK. Refer to EL-150.


3	CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT	
Check continuity between ASCD control unit harness terminal 3 and body ground.		
SEL764U		
Refer to wiring diagram in EL-143.		
Does continuity exist?		
Yes	▶	Power supply and ground circuit is OK.
No	▶	Repair harness.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD MAIN SWITCH CHECK

-NBEL0099S04

1	CHECK POWER SUPPLY FOR ASCD MAIN SWITCH
<p>1. Disconnect main switch connector. 2. Check voltage between main switch terminals 1 and 4.</p>  <p>ASCD main switch connector (MT8)</p> <p>Refer to wiring diagram in EL-140.</p> <p>MEL842F</p> <p>Does battery voltage exist?</p>	
Yes	▶ GO TO 2.
No	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse (No. 11, located in the fuse block) ● Harness for open or short between fuse and ASCD main switch ● Ground circuit for ASCD main switch

2	CHECK ASCD MAIN SWITCH	
Refer to "Electrical Component Inspection" (EL-155).		
OK or NG		
OK	▶ Go to ASCD HOLD RELAY CHECK. Refer to EL-150.	
NG	▶ Replace ASCD main switch.	

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD HOLD RELAY CHECK

-NBEL0099S05

1	CHECK POWER SUPPLY CIRCUIT FOR ASCD HOLD RELAY
<p>1. Disconnect ASCD hold relay. 2. Check voltage between ASCD hold relay terminal 7 and body ground.</p>	
<p>ASCD hold relay connector (E22)</p> <p>W/B</p>	
MEL843F	
Refer to wiring diagram in EL-140.	
Does battery voltage exist?	
Yes	▶ GO TO 2.
No	▶ Check the following.
	<ul style="list-style-type: none"> • 7.5A fuse (No. 11, located in the fuse block) • Harness for open or short between fuse and ASCD hold relay

2	CHECK GROUND CIRCUIT FOR ASCD HOLD RELAY
Check continuity between ASCD hold relay terminal 2 and ground.	
<p>ASCD hold relay connector (E22)</p> <p>B</p>	
MEL844F	
Does continuity exist?	
Yes	▶ GO TO 3.
No	▶ Repair harness.

3	CHECK ASCD HOLD RELAY
Check ASCD hold relay.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace ASCD hold relay.

4	CHECK ASCD MAIN SWITCH
Refer to "Electrical Component Inspection" (EL-155).	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace ASCD main switch.

5	CHECK ASCD HOLD RELAY OPEN OR SHORT CIRCUIT
<p>1. Connect ASCD main switch. 2. Check ASCD hold relay terminals 1 and 6. Continuity should exist.</p>	
<p>ASCD hold relay connector (E22)</p> <p>BR</p>	
MEL845F	
<p>3. Check continuity between ASCD hold relay terminal 1 and ground. Continuity should not exist.</p>	
<p>ASCD hold relay connector (E22)</p> <p>BR</p>	
SEL392V	
OK or NG	
OK	▶ ASCD hold relay is OK.
NG	▶ Repair harness.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD BRAKE/STOP LAMP SWITCH CHECK

-NBEL0099S06

1 CHECK ASCD BRAKE SWITCH CIRCUIT	
<p>1. Disconnect control unit connector. 2. Turn ignition switch ON. 3. Turn ASCD main switch "ON". 4. Check voltage between control unit connector terminal 5 and ground. When brake pedal is depressed or A/T selector lever is in "N" or "P" range: Approx. 0V When both brake pedal is released or A/T selector lever is not in "N" or "P" range: Battery voltage should exist.</p> <p style="text-align: center;">ASCDC control unit connector (M3)</p> <p style="text-align: right;">SEL765U</p>	
Refer to wiring diagram in EL-141.	
OK or NG	
OK	▶ GO TO 2.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● ASCD brake switch Refer to "Electrical Component Inspection" (EL-155). ● Inhibitor switch Refer to "Electrical Component Inspection" (EL-155). ● ASCD hold relay ● Harness for open or short

2 CHECK STOP LAMP SWITCH CIRCUIT	
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 11 and ground. Voltage [V]: Stop lamp switch: Depressed Approx. 12 Stop lamp switch: Released 0</p> <p style="text-align: center;">ASCDC control unit connector (M3)</p> <p style="text-align: right;">SEL759U</p>	
Refer to wiring diagram in EL-142.	
OK or NG	
OK	▶ ASCD brake/stop lamp switch is OK.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 14, located in the fuse block (J/B)] ● Harness for open or short between ASCD control unit and stop lamp switch ● Stop lamp switch Refer to "Electrical Component Inspection" (EL-155).

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD STEERING SWITCH CHECK

-NBEL0099S07

1	CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT																												
<p>1. Disconnect control unit connector. 2. Check voltage between control unit harness terminals and ground.</p>																													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminal No.</th> <th colspan="2">Switch condition</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>Pressed</th> <th>Released</th> </tr> </thead> <tbody> <tr> <td>SET/COAST SW</td> <td>2</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td>RESUME/ACC SW</td> <td>1</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td rowspan="2">CANCEL SW</td> <td>2</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td>1</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> </tbody> </table>			Terminal No.		Switch condition		(+)	(-)	Pressed	Released	SET/COAST SW	2	ground	12V	0V	RESUME/ACC SW	1	ground	12V	0V	CANCEL SW	2	ground	12V	0V	1	ground	12V	0V
	Terminal No.		Switch condition																										
	(+)	(-)	Pressed	Released																									
SET/COAST SW	2	ground	12V	0V																									
RESUME/ACC SW	1	ground	12V	0V																									
CANCEL SW	2	ground	12V	0V																									
	1	ground	12V	0V																									
MTBL0002																													
<p>ASCD control unit connector (M3)</p>																													
SEL760U																													
Refer to wiring diagram in EL-142.																													
OK or NG																													
OK	▶ ASCD steering switch is OK.																												
NG	▶ GO TO 2.																												

2	CHECK POWER SUPPLY FOR ASCD STEERING SWITCH
Does horn work?	
Yes	▶ GO TO 3.
No	▶ Check the following. <ul style="list-style-type: none"> ● 10A fuse (No. 54, located in the relay box) ● Horn relay ● Harness for open or short between horn and fuse

3	CHECK ASCD STEERING SWITCH																						
<p>1. Disconnect ASCD steering switch. 2. Check continuity between terminals by pushing each switch.</p>																							
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Switch</th> <th colspan="3">Terminal</th> </tr> <tr> <th>21</th> <th>22</th> <th>23</th> </tr> </thead> <tbody> <tr> <td>RESUME/ACCEL</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td>SET/COAST</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td rowspan="2">CANCEL</td> <td style="text-align: center;">○</td> <td style="text-align: center;">▶</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">○</td> <td style="text-align: center;">▶</td> <td style="text-align: center;">○</td> </tr> </tbody> </table>		Switch	Terminal			21	22	23	RESUME/ACCEL	○	○	○	SET/COAST	○	○	○	CANCEL	○	▶	○	○	▶	○
Switch	Terminal																						
	21	22	23																				
RESUME/ACCEL	○	○	○																				
SET/COAST	○	○	○																				
CANCEL	○	▶	○																				
	○	▶	○																				
MTBL0003																							
<p>ASCD steering switch (EL2)</p>																							
SEL409V																							
OK or NG																							
OK	▶ Check harness for open or short between ASCD steering switch and ASCD control unit.																						
NG	▶ Replace ASCD steering switch.																						

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

VEHICLE SPEED SENSOR CHECK

-NBEL0099S08

1	CHECK SPEEDOMETER OPERATION	
Refer to wiring diagram in EL-144.		
Does speedometer operate normally?		
Yes	▶	GO TO 2.
No	▶	Check speedometer and vehicle speed sensor circuit. Refer to EL-64.

2	CHECK VEHICLE SPEED INPUT	
<ol style="list-style-type: none"> 1. Apply wheel chocks and jack up drive wheel. 2. Disconnect control unit connector. 3. Check voltage between control unit terminal 7 and ground with turning drive wheel slowly. 		
Does voltage pointer deflect?		
Yes	▶	Vehicle speed sensor is OK.
No	▶	Check harness for open or short between ASCD control unit terminal 7 and combination meter terminal 36.

ASCD PUMP CIRCUIT CHECK

NBEL0099S09

1	CHECK ASCD PUMP										
<ol style="list-style-type: none"> 1. Disconnect ASCD pump connector. 2. Measure resistance between ASCD pump terminals 1 and 2, 3, 4. 											
<table border="1"> <thead> <tr> <th>Terminals</th> <th>Resistance [Ω]</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">1</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Approx. 3</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approx. 65</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Approx. 65</td> </tr> </tbody> </table>			Terminals	Resistance [Ω]	1	2	Approx. 3	3	Approx. 65	4	Approx. 65
Terminals	Resistance [Ω]										
1	2	Approx. 3									
	3	Approx. 65									
	4	Approx. 65									
MTBL0048											
MEL243H											
Refer to wiring diagram in EL-143.											
OK or NG											
OK	▶	Check harness for open or short between ASCD pump and ASCD control unit.									
NG	▶	Replace ASCD pump.									


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)



ASCD ACTUATOR/PUMP CHECK

-NBEL0099S10

1	CHECK VACUUM HOSE
Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.	
	
MEL402G	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace hose.


2	CHECK ASCD WIRE
Check wire for improper installation, rust formation or breaks.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-155).

3	CHECK ASCD ACTUATOR
<ol style="list-style-type: none"> 1. Disconnect vacuum hose from ASCD actuator. 2. Apply -40 kPa (-0.41 kg/cm^2, -5.8 psi) vacuum to ASCD actuator with hand vacuum pump. ASCD wire should move to pull throttle drum. 3. Wait 10 seconds and check for decrease in vacuum pressure. Vacuum pressure decrease: Less than 2.7 kPa (0.028 kg/cm^2, 0.39 psi) 	
	
MEL403G	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace ASCD actuator.

4	CHECK ASCD PUMP																		
<ol style="list-style-type: none"> 1. Disconnect vacuum hose from ASCD pump and ASCD pump connector. 2. If necessary remove ASCD pump. 3. Connect vacuum gauge to ASCD pump. 4. Apply 12V direct current to ASCD pump and check operation. 																			
<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">12V direct current supply terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Air valve</td> <td></td> <td>3</td> <td>Close</td> </tr> <tr> <td>Release valve</td> <td>1</td> <td>4</td> <td>Close</td> </tr> <tr> <td>Vacuum motor</td> <td></td> <td>2</td> <td>Operate</td> </tr> </tbody> </table>			12V direct current supply terminals		Operation	(+)	(-)	Air valve		3	Close	Release valve	1	4	Close	Vacuum motor		2	Operate
	12V direct current supply terminals		Operation																
	(+)	(-)																	
Air valve		3	Close																
Release valve	1	4	Close																
Vacuum motor		2	Operate																
MTBL0004																			
<p>A vacuum pressure of at least -40 kPa (-0.41 kg/cm^2, -5.8 psi) should be generated.</p>																			
																			
																			
MEL844G																			
OK or NG																			
OK	▶ INSPECTION END																		
NG	▶ Replace ASCD pump.																		

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Electrical Component Inspection



Electrical Component Inspection


NBEL0100

ASCD MAIN SWITCH

NBEL0100S01

Check continuity between terminals by pushing switch to each position.

Switch position	Terminals	Illumination
ON	1 - 2 - 3 - 4	5 - 6
N	2 - 3 - 4	
OFF		




ASCD BRAKE SWITCH AND STOP LAMP SWITCH

NBEL0100S02

Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.




INHIBITOR SWITCH

NBEL0100S03

Selector lever position	Continuity	
	Between terminals 1 and 2	
"P"	Yes	
"N"	Yes	
Except "P" and "N"	No	

ASCD Wire Adjustment

NBEL0101



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

ASCD Wire Adjustment (Cont'd)

CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
3. Tighten adjusting nut just until throttle drum starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

System Description

NBEL0102

Power is supplied at all times

- from 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3.

GI

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to power window relay terminal 2.

MA

EM

Ground is supplied to power window relay terminal 1

- through body grounds M4 and M66.

LC

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to power window main switch terminal 1,
- to power window sub switch terminal 5.

EC

FE

MANUAL OPERATION

Front Door LH

NBEL0102S01

NBEL0102S0101

Ground is supplied

- to power window main switch terminal 3
- through body grounds M4 and M66.

AT

TF

WINDOW UP

When the front LH switch in the power window main switch is pressed in the up position, power is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

PD

AX

Ground is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

SU

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

BR

ST

Ground is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

RS

Then, the motor lowers the window until the switch is released.

Front Door RH

NBEL0102S0102

Ground is supplied

- to power window main switch terminal 3
- through body grounds M4 and M66.

BT

HA

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

SC

MAIN SWITCH OPERATION

Power is supplied

- through power window main switch (5, 6)
- to front power window sub-switch (4, 3).

EL

IDX

The subsequent operation is the same as the sub-switch operation.

SUB-SWITCH OPERATION

Power is supplied

- through front power window sub-switch (2, 1)

POWER WINDOW

System Description (Cont'd)

- to front power window regulator RH (2, 1).

Ground is supplied

- to front power window regulator RH (1, 2)
- through front power window sub-switch (1, 2)
- to front power window sub-switch (3, 4)
- through power window main switch (6, 5).

Then, the motor raises or lowers the window until the switch is released.

Rear Door

Rear door windows will raise and lower in the same manner as front door RH window.

NBEL0102S0103

AUTO OPERATION

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

NBEL0102S02

The AUTO feature only operates on the driver's window downward movement.

POWER WINDOW LOCK

The power window lock is designed to lock operation of all windows except for driver's door window.

NBEL0102S03


When the lock switch is pressed to lock position, ground of the sub-switches in the power window main switch is disconnected. This prevents the power window motors from operating.

POWER WINDOW

Schematic

Schematic

NBEL0103



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

MEL6121



POWER WINDOW

Wiring Diagram — WINDOW —

Wiring Diagram — WINDOW —

NBEL0104

EL-WINDOW-01



Refer to last page (Foldout page).


- (M1) (E1)
- (M2) (B1)
- (M10)

MEL842H




POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02









GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03






MEL611F




POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04



Refer to last page (Foldout page).
(M2), (B1)



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

MEL803G

POWER WINDOW

Trouble Diagnoses

Trouble Diagnoses

NBEL0105


Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> 1. 7.5A fuse, 40A fusible link and M21 circuit breaker 2. Grounds M4 and M77 3. Power window relay 4. Open/short in power window main switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 11, located in fuse block (J/B)] 40A fusible link (letter f, located in fuse and fusible link box) and M21 circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminal 1 of power window main switch and terminal 5 of sub-switch. 2. Check grounds M4 and M66. 3. Check power window relay. 4. Check W wire between power window relay and power window main switch for open/short circuit.
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> 1. Driver side power window regulator circuit 2. Driver side power window regulator 	<ol style="list-style-type: none"> 1. Check harness between power window main switch and power window regulator for open or short circuit. 2. Check driver side power window regulator.
Passenger power window cannot be operated.	<ol style="list-style-type: none"> 1. Power window sub-switches 2. Passenger side power window regulators 3. Power window main switch 4. Power window circuit 	<ol style="list-style-type: none"> 1. Check power window sub-switch. 2. Check passenger side power window regulator. 3. Check power window main switch. 4. Check the following. <ol style="list-style-type: none"> a. Check harnesses between power window main switch and power window sub-switch for open/short circuit. b. Check harnesses between power window sub-switch and power window regulator for open/short circuit.
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> 1. Power window main switch 	<ol style="list-style-type: none"> 1. Check power window main switch.
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> 1. Power window main switch 	<ol style="list-style-type: none"> 1. Check power window main switch.

POWER DOOR LOCK

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0106 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SEL331V

SC

NBEL0107

NBEL0107S04

EL

IDX

System Description

OPERATION

- The lock/unlock switch on driver's door trim can lock and unlock all doors.
- With the lock knob on front LH or RH door set to "LOCK", all doors are locked. (Signals from front door unlock sensor)
- With the door key inserted in the key cylinder on front LH, RH or back door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from door key cylinder switch)
- If the ignition key is in the ignition key cylinder and one or more of the front doors are open, setting the

POWER DOOR LOCK

System Description (Cont'd)

lock/unlock switch, lock knob, or the door key to "LOCK" locks the doors once but then immediately unlock them. (Combination signals from key switch, front LH or RH door switch and LH or RH door unlock sensor) - (KEY REMINDER DOOR SYSTEM)


POWER DOOR LOCK

Schematic

Schematic

NBEL0108

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX



MEL843H

POWER DOOR LOCK





Wiring Diagram — D/LOCK —

Wiring Diagram — D/LOCK —

NBEL0109

NBEL0109S01

FIG. 1



Refer to last page (Foldout page).

- (M1) (E1)
- (M2) (B1)
- (E3)

MEL844H



POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 2

NBEL0109S02

EL-D/LOCK-02



Refer to last page (Foldout page).
 (M2) . (B1)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX

MEL845H


POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 3







NBEL0109S03

EL-D/LOCK-03



Refer to last page (Foldout page).

(M2) . (B1)



MEL846H


POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


FIG. 4

NBEL0109S04

EL-D/LOCK-04



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT



Refer to last page (Foldout page).
M2, B1

HA
SC
EL
IDX

MEL847H

POWER DOOR LOCK


Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NBEL0110

NBEL0110S01

REFERENCE PAGE (EL-)	172	173	174	175	176	177	178	179
SYMPTOM	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	FRONT DOOR SWITCH CHECK	KEY SWITCH (INSERT) CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	FRONT DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	FRONT DOOR UNLOCK SENSOR CHECK	DOOR LOCK ACTUATOR CHECK
Key reminder door system does not operate properly.	X	X	X				X	X
Specific door lock actuator does not operate.	X							X
Power door lock does not operate with door lock and unlock switch on power window main switch.	X			X				
Power door lock does not operate with front door key cylinder operation.	X				X			
Power door lock does not operate with back door key cylinder operation.						X		
Power door lock does not operate with front door lock knob switch.	X						X	



MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main Power Supply Circuit Check

NBEL0110S02


NBEL0110S0201

Terminal		Ignition switch		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage

EL-172

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)



Ground Circuit Check

NBEL0110S0202

Terminals	Continuity
10 - Ground	Yes

FRONT DOOR SWITCH CHECK

NBEL0110S005

1	CHECK DOOR SWITCH INPUT SIGNAL																					
Check voltage between control unit terminals 15 or 35 and ground.																						
	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">15</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">Front RH door switch</td> <td rowspan="2">35</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> </tbody> </table>		Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door switch	15	ground	Open	0	Closed	Approx. 12	Front RH door switch	35	ground	Open	0	Closed	Approx. 12
	Terminals		Condition	Voltage [V]																		
	(+)	(-)																				
Front LH door switch	15	ground	Open	0																		
			Closed	Approx. 12																		
Front RH door switch	35	ground	Open	0																		
			Closed	Approx. 12																		
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>15 35</p> <p>G/R Y</p> <p>H.S.</p> <p>CONNECT</p> <p>OFF</p> <p>SEL332V</p> <p>Refer to wiring diagram in EL-168.</p> <p>OK or NG</p>																						
OK	▶ Door switch is OK.																					
NG	▶ GO TO 2.																					

2	CHECK DOOR SWITCH
Check continuity between terminals 1 and 2, 3 and ground.	
Continuity: Door switch is pushed. No Door switch is released. Yes	
<p>Door switch connector</p> <p>Front LH (B9)</p> <p>Front RH (B68)</p> <p>H.S.</p> <p>DISCONNECT</p> <p>SEL333V</p> <p>OK or NG</p>	
OK	▶ Check the following. <ul style="list-style-type: none"> • Door switch ground circuit • Harness for open or short between control unit and door switch
NG	▶ Replace door switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK

-NBEL0110S06

1	CHECK KEY SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 24 and ground. Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0</p> <p>Smart entrance control unit connector (M16)</p> <p style="text-align: right;">SEL234V</p>	
<p>Refer to wiring diagram in EL-168.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
<p>Check continuity between terminals 1 and 2. Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p> <p>Key switch connector (E5)</p> <p style="text-align: right;">SEL249V</p>	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between control unit and key switch
NG	▶ Replace key switch.

DOOR LOCK/UNLOCK SWITCH CHECK

-NBEL0110S03

1	CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL	
<ol style="list-style-type: none"> 1. Disconnect control unit connector. 2. Check continuity between control unit terminal 18 or 19 and ground. 		
Terminals	Door lock/unlock switch (LH or RH) condition	Continuity
18 - ground	Lock	Yes
	N and Unlock	No
19 - ground	Unlock	Yes
	N and Lock	No

MTBL0005

Smart entrance control unit connector (M16)

18 BR 19 LG/R

Refer to wiring diagram in EL-168.

SEL785UB

OK or NG	
OK	▶ Door lock/unlock switch is OK.
NG	▶ GO TO 2.

2	CHECK DOOR LOCK/UNLOCK SWITCH
<ol style="list-style-type: none"> 1. Disconnect door lock/unlock switch connector. 2. Check continuity between each door lock/unlock switch terminals. <ul style="list-style-type: none"> • Power window main switch (Door lock/unlock switch LH) 	
Condition	Terminals
	3 14 7
Lock	○ — ○ — ○
N	No continuity
Unlock	○ — ○ — ○

MTBL0045

Door lock/unlock switch driver side

DISCONNECT (T.S.)

P/W main switch connector (D6)

3 14 7

SEL626UA

OK or NG

OK	▶	Check the following. <ul style="list-style-type: none"> • Ground circuit for door lock/unlock switch • Harness for open or short between door lock/unlock switch and control unit connector
NG	▶	Replace door lock/unlock switch.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

FRONT DOOR KEY CYLINDER SWITCH CHECK

-NBEL0110S07

1	CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																		
Check voltage between control unit terminals 30 or 31 and ground.																			
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">30</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Lock</td> <td>0</td> </tr> <tr> <td rowspan="2">31</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>0</td> </tr> </tbody> </table>		Terminals		Key position	Voltage [V]	(+)	(-)	30	Ground	Neutral	Approx. 12	Lock	0	31	Ground	Neutral	Approx. 12	Unlock	0
Terminals		Key position	Voltage [V]																
(+)	(-)																		
30	Ground	Neutral	Approx. 12																
		Lock	0																
31	Ground	Neutral	Approx. 12																
		Unlock	0																
MTBL0041																			
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>30 31 Y LG</p> <p>V</p> <p>Neutral</p> <p>Lock Unlock</p> <p>Driver's side</p> <p>Neutral</p> <p>Unlock Lock</p> <p>Passenger side</p>																			
SEL614UB																			
Refer to wiring diagram in EL-169.																			
OK or NG																			
OK	▶ Door key cylinder switch is OK.																		
NG	▶ GO TO 2.																		

2	CHECK DOOR KEY CYLINDER SWITCH															
<ol style="list-style-type: none"> Disconnect door key cylinder switch connector. Check continuity between door key cylinder switch terminals. 																
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>LH: 3 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>RH: 1 - 2</td> <td>Lock</td> <td>Yes</td> </tr> <tr> <td>LH: 1 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>RH: 3 - 2</td> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table>		Terminals	Key position	Continuity	LH: 3 - 2	Neutral	No	RH: 1 - 2	Lock	Yes	LH: 1 - 2	Neutral	No	RH: 3 - 2	Unlock	Yes
Terminals	Key position	Continuity														
LH: 3 - 2	Neutral	No														
RH: 1 - 2	Lock	Yes														
LH: 1 - 2	Neutral	No														
RH: 3 - 2	Unlock	Yes														
MTBL0042																
<p>DISCONNECT</p> <p>Door key cylinder switch connector</p> <p>LH : (D9) RH : (D39)</p> <p>3 2 1</p>																
<ol style="list-style-type: none"> Door unlock switch terminal (LH) Door lock switch terminal (RH) Ground terminal Door lock switch terminal (LH) Door unlock switch terminal (RH) 																
SEL880U																
OK or NG																
OK	▶ Check the following. <ul style="list-style-type: none"> Door key cylinder switch ground circuit Harness for open or short between control unit and door key cylinder switch 															
NG	▶ Replace door key cylinder switch.															

BACK DOOR KEY CYLINDER SWITCH CHECK

=NBELO110508

1	CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																				
<p>Check voltage between control unit terminals 30 or 31 and ground.</p>																					
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="4">Back door</td> <td rowspan="2">30</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Between neutral and lock</td> <td>0</td> </tr> <tr> <td rowspan="2">31</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Between neutral and unlock</td> <td>0</td> </tr> </tbody> </table>			Terminals		Key position	Voltage [V]	(+)	(-)	Back door	30	Ground	Neutral	Approx. 12	Between neutral and lock	0	31	Ground	Neutral	Approx. 12	Between neutral and unlock	0
	Terminals		Key position	Voltage [V]																	
	(+)	(-)																			
Back door	30	Ground	Neutral	Approx. 12																	
			Between neutral and lock	0																	
	31	Ground	Neutral	Approx. 12																	
			Between neutral and unlock	0																	
MTBL0051																					
<p>Smart entrance control unit connector (MT6)</p>																					
SEL334V																					
Refer to wiring diagram in EL-169.																					
OK or NG																					
OK	▶ Back door key cylinder switch is OK.																				
NG	▶ GO TO 2.																				

2	CHECK BACK DOOR KEY CYLINDER SWITCH															
<p>1. Disconnect back door key cylinder switch connector. 2. Check continuity between back door key cylinder switch terminals.</p>																
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td>○</td> <td>—</td> <td>○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td>—</td> <td>○</td> <td>○</td> </tr> </tbody> </table>		Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○	—	○	Between neutral and unlock (Back door)	—	○	○
Key position	Terminals															
	1	2	4													
Between neutral and lock (Back door)	○	—	○													
Between neutral and unlock (Back door)	—	○	○													
MTBL0052																
<p>Back door key cylinder switch (D201)</p>																
SEL616U																
OK or NG																
OK	▶ Check the following. <ul style="list-style-type: none"> • Back door key cylinder switch ground circuit • Harness for open or short between control unit and back door key cylinder switch 															
NG	▶ Replace back door key cylinder switch.															

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

FRONT DOOR UNLOCK SENSOR CHECK

=NBEL0110S09

1	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL																					
<p>Check voltage between control unit terminals 12 or 13 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door</td> <td rowspan="2" style="text-align: center;">12</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2">Front RH door</td> <td rowspan="2" style="text-align: center;">13</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 50px;">MTBL0053</p> <div style="margin-top: 10px;"> <p style="text-align: right;">SEL335V</p> </div> <p style="margin-top: 10px;">Refer to wiring diagram in EL-170.</p> <p style="text-align: center; margin-top: 5px;">OK or NG</p>			Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door	12	Ground	Locked	Approx. 12	Unlocked	0	Front RH door	13	Ground	Locked	Approx. 12	Unlocked	0
	Terminals		Condition	Voltage [V]																		
	(+)	(-)																				
Front LH door	12	Ground	Locked	Approx. 12																		
			Unlocked	0																		
Front RH door	13	Ground	Locked	Approx. 12																		
			Unlocked	0																		
OK	▶	Door unlock sensor is OK.																				
NG	▶	GO TO 2.																				

2	CHECK DOOR UNLOCK SENSOR	
<ol style="list-style-type: none"> 1. Disconnect door unlock sensor connector. 2. Check continuity between door unlock sensor terminals 4 and 2. <p>Continuity: Condition: Locked No Condition: Unlocked Yes</p> <p>Door lock actuator connectors Front LH : (D7) Front RH : (D37)</p> <div style="text-align: right; margin-right: 50px;"> </div> <div style="text-align: center; margin-top: 10px;"> <p style="text-align: right;">SEL247VA</p> </div> <p style="text-align: center; margin-top: 5px;">OK or NG</p>		
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor
NG	▶	Replace door unlock sensor.

DOOR LOCK ACTUATOR CHECK

=NBEL0110S04

1 CHECK DOOR LOCK ACTUATOR CIRCUIT

Check voltage for door lock actuator.

- Door lock actuator front LH

Door lock/unlock switch condition	Terminal No.		Voltage (V)
	(+)	(-)	
Lock	4	ground	Approx. 12
Unlock	3	ground	

MTBL0006

SEL786U

- Door lock actuator front RH, rear and back

Door lock/unlock switch condition	Terminal No.		Voltage (V)
	(+)	(-)	
Lock	4	ground	Approx. 12
Unlock	2	ground	

MTBL0007

SEL787UB

Refer to wiring diagram in EL-170.

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace smart entrance control unit. (Before replacing control unit, perform "DOOR LOCK/UNLOCK SWITCH CHECK".)

2 CHECK DOOR LOCK ACTUATOR

- Disconnect door lock actuator connector.
- Apply 12V direct current to door lock actuator and check operation.

- Door lock actuator operation:
 - Terminals between (+): 3 and (-): 1
 Unlocked → Locked
 - Terminals between (+): 1 and (-): 3
 Locked → Unlocked
- Back door lock actuator operation:
 - Terminals between (+): 2 and (-): 1
 Unlocked → Locked
 - Terminals between (+): 1 and (-): 2
 Locked → Unlocked

SEL736U

SEL737U

OK or NG

OK	▶	Check harness for open or short between control unit connector and door lock actuator.
NG	▶	Replace door lock actuator.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

MULTI-REMOTE CONTROL SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0111



SEL303V

System Description

INPUTS

Power is supplied at all times

- to key switch terminal 1
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 24.

When the front door switch LH is OPEN, ground is supplied

- to smart entrance control unit terminal 15
- through front door switch LH terminal 1
- to front door switch LH terminal 2
- through body grounds B11, B22 and D210.

When the front door switch RH is OPEN, ground is supplied

- to smart entrance control unit terminal 35
- through front door switch RH terminal 1
- to front door switch RH terminal 2
- through body grounds B55 and B75.

When the each door switch is OPEN, ground is supplied

- to smart entrance control unit terminal 16

NBEL0112

NBEL0112S01

- through each door switch body ground or B11, B22 and D210.

When the front door lock actuator LH (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal 12
- through door lock actuator LH (door unlock sensor) terminal 4
- to door lock actuator LH (door unlock sensor) terminal 2
- through body grounds M4 and M77.

When the front door lock actuator RH (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 13 in the same manner as front door lock actuator LH.

When the rear or back door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 14 in the same manner as other door lock actuator.

Remote controller signal input

- through antenna
- to smart entrance control unit terminal 37.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard reminder

OPERATED PROCEDURE

Power Door Lock Operation

NBEL0112S02

NBEL0112S0201

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

The two above signals are already input into smart entrance control unit. At this point, smart entrance control unit receives a LOCK signal from remote controller. Smart entrance control unit locks all doors with input of LOCK signal from remote controller.

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from remote controller again within 5 seconds, all other door will be unlocked.

Hazard Reminder

NBEL0112S0204

Power is supplied at all times

- to multi-remote control relay terminal 1
- through 15A fuse [No. 20, located in the fuse block (J/B)].

When smart entrance control unit receives a LOCK signal from remote controller, ground is supplied

- to multi-remote control relay terminal 2
- through smart entrance control unit terminal 7.

Multi-remote control relays are now energized, and hazard warning lamp flash twice as a reminder. For detailed description, refer to "TURN SIGNAL AND HAZARD WARNING LAMPS" (EL-42).

Interior Lamp Operation

NBEL0112S0203

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

For detailed description, refer to "INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS" (EL-52).

Panic Alarm Operation

NBEL0112S0203

When key switch is OFF (when ignition key is not inserted in key cylinder), multi-remote control system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from remote controller.

For detailed description, refer to "THEFT WARNING SYSTEM" (EL-198).

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

MULTI-REMOTE CONTROL SYSTEM

Schematic

Schematic

NBEL0113



MEL468I

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —




Wiring Diagram — MULTI —

NBEL0114

NBEL0114S01

EL-MULTI-01

FIG. 1



Refer to last page (Foldout page).

(M1) (E1)

(M10)

(E3)

EL

IDX

MEL848H

MULTI-REMOTE CONTROL SYSTEM





Wiring Diagram — MULTI — (Cont'd)

NBEL0114502

FIG. 2

EL-MULTI-02

SMART
ENTRANCE
CONTROL UNIT
(M16)



Refer to last page (Foldout page).

(M2) (B1)

MEL849H



MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 3

NBEL0114S03

EL-MULTI-03



Refer to last page (Foldout page).

M2 B1

MEL448I




MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 4

NBEL0114SD4

EL-MULTI-04



Refer to last page (Foldout page).

(M1) (E1)
(M10)

MEL850H

Trouble Diagnoses SYMPTOM CHART

NBEL0115

NBEL0115S01

Symptom	Diagnoses/service procedure	Reference page (EL-)	
All function of multi-remote control system do not operate.	1. Remote controller battery check	188	GI
	2. Multi-remote control antenna check	188	MA
	3. Key switch (insert) check	191	EM
	4. Door switch check	190	LC
	5. Power supply and ground circuit for control unit check	189	EC
	6. Replace remote controller. Refer to ID Code Entry Procedure.	195	
The new ID of remote controller cannot entered.	1. Remote controller battery check	188	FE
	2. Multi-remote control antenna check	188	
	3. Key switch (insert) check	191	AT
	4. Door switch check	190	
	5. Door unlock sensor check	192	TF
	6. Power supply and ground circuit for control unit check	189	
	7. Replace remote controller. Refer to ID Code Entry Procedure.	195	PD
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to EL-172.)	1. Key switch (insert) input signal check	191	
	2. Door switch check	190	AX
	3. Door unlock sensor check	192	
	4. Replace remote controller. Refer to ID Code Entry Procedure.	195	SU
Hazard indicator does not flash twice when pressing lock button of remote controller.	1. Harzard reminder check	193	
	2. Replace remote controller. Refer to ID Code Entry Procedure.	195	BR
Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller.	1. Interior room lamp operation check	194	
	2. Replace remote controller. Refer to ID Code Entry Procedure.	195	ST
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed more than 1.5 seconds.	1. Theft warning operation check. Refer to "PRELIMINALY CHECK" in "THEFT WARNING SYSTEM".	210	RS
	2. Replace remote controller. Refer to ID Code Entry Procedure.	195	

NOTE:

- The unlock and panic alarm operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
- The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder or if one of the doors is opened.

EL


IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)


REMOTE CONTROLLER BATTERY CHECK


=NBEL0115S02

1	CHECK REMOTE CONTROLLER BATTERY	
<p>Remove battery (refer to EL-196) and measure voltage across battery positive and negative terminals, (+) and (-).</p> <p>Voltage [V]: 2.5 - 3.0</p> <p>NOTE: Remote controller does not function if battery is not set correctly.</p>		
		
SEL277V		
OK or NG		
OK	▶	Check remote controller battery terminals for corrosion or damage.
NG	▶	Replace battery.

MULTI-REMOTE CONTROL ANTENNA CHECK

NBEL0115S03

1	CHECK ANTENNA FEEDER CABLE	
<ol style="list-style-type: none"> 1. Disconnect feeder cable connector from control unit. 2. Remove LH rear pillar garnish and disconnect feeder cable connector from antenna. 3. Check continuity between the feeder cable connectors. Continuity should exist. 4. Check continuity between the feeder cable connector terminal 37 and body ground. Continuity should not exist. 		
		
MEL040GB		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace feeder cable.

2	CHECK ANTENNA	
<ol style="list-style-type: none"> 1. Remove rear pillar garnish and disconnect feeder cable connector from antenna. 2. Visually check film antenna. 		
		
SEL712U		
OK or NG		
OK	▶	Antenna of multi-remote control is OK.
NG	▶	Replace antenna.

POWER SUPPLY AND GROUND CIRCUIT CHECK

=NBEL0115504

1	CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT
<p>1. Disconnect connector from control unit. 2. Check voltage between control unit terminal 1 and ground.</p>	
SEL744U	
Refer to wiring diagram in EL-183.	
Does battery voltage exist?	
Yes	▶ GO TO 2.
No	▶ Check the following. <ul style="list-style-type: none"> • 40A fusible link (letter f, located in fuse and fusible link box) • M21 circuit breaker • Harness for open or short between control unit and circuit breaker

2	CHECK IGNITION SWITCH "ACC" CIRCUIT
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 17 and ground while ignition switch is "ACC".</p>	
MEL245H	
Refer to wiring diagram in EL-183.	
Does battery voltage exist?	
Yes	▶ GO TO 3.
No	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse [No. 10, located in fuse block (J/B)] • Harness for open or short between control unit and fuse

3	CHECK GROUND CIRCUIT FOR CONTROL UNIT
Check continuity between terminal 10 and ground.	
SEL363TB	
Refer to wiring diagram in EL-183.	
Does continuity exist?	
Yes	▶ Power supply and ground circuits are OK.
No	▶ Check ground harness.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DOOR SWITCH CHECK

-NBEL0115S05

1	CHECK DOOR SWITCH INPUT SIGNAL			
Check voltage between control unit terminals 15, 16 or 35 and ground.				
	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door switch	15	ground	Open	0
			Closed	Approx. 12
Front RH door switch	35	ground	Open	0
			Closed	Approx. 12
All door switches	16	ground	Open	0
			Closed	Approx. 12

MTBL0054

Smart entrance control unit connector (M16)

C/U CONNECTOR

15 16 35

G/R R/L Y

V

SEL336V

H.S. CONNECT

Refer to wiring diagram in EL-184.

OK or NG

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

2	CHECK DOOR SWITCH		
1. Disconnect door switch connector.			
2. Check continuity between door switch terminals.			
	Terminals	Condition	Continuity
Front door switch	1 - 2, 3 - ground	Closed	No
		Open	Yes
Back door switch	2 - 1	Closed	No
		Open	Yes
Rear door switch	1 - ground	Closed	No
		Open	Yes

MTBL0014

DISCONNECT T.S. Door switch connector

Front LH (B9)

Front RH (B6B)

DISCONNECT T.S. Back door switch

(D20B)

DISCONNECT T.S. Door switch connector

Rear LH : (B18)

Rear RH : (B71)

SEL124V

OK or NG

OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> Door switch ground circuit (Front, back door) or door switch ground condition Harness for open or short between control unit and door switch
NG	▶	Replace door switch.

KEY SWITCH (INSERT) CHECK

-NBEL0115S07

1	CHECK KEY SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 24 and ground.</p> <p>Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0</p> <p>Smart entrance control unit connector (M16)</p> <p>Refer to wiring diagram in EL-183.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
<p>Check continuity between terminals 1 and 2.</p> <p>Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is withdrawn. No</p> <p>Key switch connector (E5)</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between control unit and key switch
NG	▶ Replace key switch.


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DOOR UNLOCK SENSOR CHECK

-NBEL0115S06

1	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL																																		
<p>Check voltage between control unit terminals 12, 13 or 14 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door</td> <td rowspan="2" style="text-align: center;">12</td> <td rowspan="2" style="text-align: center;">Ground</td> <td>Locked</td> <td>Approx. 12</td> </tr> <tr> <td>Unlocked</td> <td>0</td> </tr> <tr> <td rowspan="2">Front RH door</td> <td rowspan="2" style="text-align: center;">13</td> <td rowspan="2" style="text-align: center;">Ground</td> <td>Locked</td> <td>Approx. 12</td> </tr> <tr> <td>Unlocked</td> <td>0</td> </tr> <tr> <td rowspan="2">Rear and back door</td> <td rowspan="2" style="text-align: center;">14</td> <td rowspan="2" style="text-align: center;">Ground</td> <td>Locked</td> <td>Approx. 12</td> </tr> <tr> <td>Unlocked</td> <td>0</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 5px;">MTBL0071</p> <div style="margin-top: 10px;">  <p style="text-align: center;">Smart entrance control unit connector (M16)</p> <p style="text-align: center;">C/U CONNECTOR</p> <p style="text-align: center;">12 13 14</p> <p style="text-align: center;">Y/G Y/L Y/R</p> <p style="text-align: center;">V</p> <p style="text-align: center;">Refer to wiring diagram in EL-185.</p> <p style="text-align: right;">SEL246V</p> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>Door unlock sensor is OK.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>			Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door	12	Ground	Locked	Approx. 12	Unlocked	0	Front RH door	13	Ground	Locked	Approx. 12	Unlocked	0	Rear and back door	14	Ground	Locked	Approx. 12	Unlocked	0	OK	▶	Door unlock sensor is OK.	NG	▶	GO TO 2.
	Terminals		Condition	Voltage [V]																															
	(+)	(-)																																	
Front LH door	12	Ground	Locked	Approx. 12																															
			Unlocked	0																															
Front RH door	13	Ground	Locked	Approx. 12																															
			Unlocked	0																															
Rear and back door	14	Ground	Locked	Approx. 12																															
			Unlocked	0																															
OK	▶	Door unlock sensor is OK.																																	
NG	▶	GO TO 2.																																	

2	CHECK DOOR UNLOCK SENSOR						
<p>1. Disconnect door unlock sensor connector. 2. Check continuity between door unlock sensor terminals.</p> <p>Continuity:</p> <p style="margin-left: 20px;">Condition: Locked No</p> <p style="margin-left: 20px;">Condition: Unlocked Yes</p> <p style="margin-left: 20px;">Door lock actuator connectors Front LH : (D7) Rear LH : (D54) Front RH : (D37) Rear RH : (D74)</p> <div style="margin-top: 10px;">  <p style="text-align: right;">SEL247V</p> </div> <div style="margin-top: 10px;"> <p style="margin-left: 20px;">Back door lock actuator connector (D207)</p>  <p style="text-align: right;">SEL352V</p> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td> <p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor </td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>Replace door unlock sensor.</td> </tr> </table>		OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor 	NG	▶	Replace door unlock sensor.
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor 					
NG	▶	Replace door unlock sensor.					

HAZARD REMINDER CHECK

-NBEL0115S06

1	CHECK HAZARD INDICATOR	
Check if hazard indicator flashes with hazard switch.		
Does hazard indicator operate?		
Yes	▶	GO TO 2.
No	▶	Check "hazard indicator" circuit.

2	CHECK HAZARD REMINDER OPERATION	
1. Disconnect control unit connector. 2. Apply ground to control unit terminal 7.		
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>7</p> <p>P</p> <p>SEL243V</p>		
Refer to wiring diagram in EL-186.		
Does hazard indicator illuminate?		
Yes	▶	Replace smart entrance control unit.
No	▶	GO TO 3.

3	CHECK MULTI-REMOTE CONTROL RELAY	
Check multi-remote control relay.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Replace.

4	CHECK POWER SUPPLY FOR MULTI-REMOTE CONTROL RELAY	
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminal 1 and ground.		
<p>Multi-remote control relay connector (E17)</p> <p>1</p> <p>OR</p> <p>V</p> <p>SEL244V</p>		
Does battery voltage exist?		
Yes	▶	GO TO 5.
No	▶	Check the following. <ul style="list-style-type: none"> • 15A fuse [No. 20, located in fuse block (J/B)] • Harness for open or short between multi-remote control relay and fuse

5	CHECK MULTI-REMOTE CONTROL RELAY CIRCUIT	
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminals 3 and 5. Battery voltage should exist. 3. Check voltage between terminals 6 and 7. Battery voltage should exist.		
<p>Multi-remote control relay connector (E17)</p> <p>GY/R 5 7 GY/L</p> <p>3 6</p> <p>OR</p> <p>V</p> <p>OR</p> <p>V</p> <p>SEL245V</p>		
OK or NG		
OK	▶	Check harness for open or short between control unit and multi-remote control relay.
NG	▶	Check the following. <ul style="list-style-type: none"> • Harness for open or short between multi-remote control relay and fuse • Harness for open or short between multi-remote control relay and turn signal lamps

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



MULTI-REMOTE CONTROL SYSTEM



Trouble Diagnoses (Cont'd)

INTERIOR ROOM LAMP OPERATION CHECK

=NBEL0115S09

1	CHECK INTERIOR ROOM LAMP	
Check if the interior room lamp switch is in the "DOOR" position and the lamp illuminates when a door is open.		
Does interior room lamp illuminate?		
Yes	▶	GO TO 2.
No	▶	Check "Interior room lamp" circuit.

2	CHECK INTERIOR ROOM LAMP CIRCUIT	
When interior room lamp switch is "DOOR" position, check voltage across control unit terminal 9 and ground.		
 <p>Smart entrance control unit connector (M16)</p>  <p style="text-align: right;">SEL749UB</p>		
Refer to wiring diagram in EL-183.		
Does battery voltage exist?		
Yes	▶	GO TO 3.
No	▶	Repair harness between control unit and interior room lamp.

3	CHECK CONTROL UNIT OUTPUT	
Push unlock button of remote controller and check voltage across control unit terminal 9 and ground.		
Voltage (V):		
Unlock button is pushed.		
0 (For approx. 30 seconds.)		
Unlock button is not pushed.		
Battery voltage		
 <p>Smart entrance control unit connector (M16)</p>  <p style="text-align: right;">SEL749UB</p>		
OK or NG		
OK	▶	Check system again.
NG	▶	Replace smart entrance control unit.


ID Code Entry Procedure

NBEL0117

Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

To enter the ID code, follow the procedures below.



MEL446H

NOTE:

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


MULTI-REMOTE CONTROL SYSTEM

Remote Controller Battery Replacement

Remote Controller Battery Replacement


NBEL0118

1.




Open the lid using a coin.

2.




Remove the battery.

3.



Insert the new battery.
Recommended battery: CR2025 or equivalent.

4.



Close the lid securely.


SEL126V

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NBEL0119 GI



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



MEL456I

THEFT WARNING SYSTEM

System Description

System Description


NBEL0120

NBEL0120S01

NBEL0120S0101

DESCRIPTION

1. Operation Flow



2. Setting The Theft Warning System

NBEL0120S0102

Initial condition

- 1) Close all doors.
- 2) Close hood and glass hatch.

Disarmed phase

The theft warning system is in the disarmed phase when any door(s), hood or glass hatch is opened. The security indicator lamp blinks every second.

Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when hood, glass hatch and all doors are closed and the doors are locked by key or multi-remote controller. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

3. Canceling The Set Theft Warning System

NBEL0120S0103

When the following 1) or 2) operation is performed, the armed phase is canceled.

- 1) Unlock the doors with the key or multi-remote controller.
- 2) Open the glass hatch with the key. When the glass hatch is closed after opening the glass hatch with the key, the system returns to the armed phase.

4. Activating The Alarm Operation of The Theft Warning System

NBEL0120S0104

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When the following operation 1) or 2) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. (At the same time, the system disconnects the starting system circuit.)

- 1) Engine hood, glass hatch or any door is opened before unlocking door with key or multi-remote controller.
- 2) Door is unlocked without using key or multi-remote controller.

POWER SUPPLY AND GROUND

NBEL0120S07

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to security indicator lamp terminal 1.

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box)

- to smart entrance control unit terminal 1.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 17.

Ground is supplied

- to smart entrance control unit terminal 10
- through body grounds M4 and M77.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

NBEL0120S02

The operation of the theft warning system is controlled by the doors, hood and glass hatch.

To activate the theft warning system, the smart entrance control unit must receive signals indicating the doors, hood and glass hatch are closed and the doors are locked.

When a door is open, smart entrance control unit terminal 15, 16 or 35 receives a ground signal from each door switch.

When a door is unlocked, smart entrance control unit terminal 12, 13 or 14 receives a ground signal from terminal 4 of each door unlock sensor or terminal 3 of back door unlock sensor.

When the hood is open, smart entrance control unit terminal 29 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E13 and E41.

When the glass hatch is open, smart entrance control unit terminal 26 receives a ground signal

- from terminal 1 of the glass hatch switch
- through body grounds D210, B11 and B22.

When the doors are locked with key or multi-remote controller and none of the described conditions exist, the theft warning system will automatically shift to armed mode.

THEFT WARNING SYSTEM ACTIVATION (WITH KEY OR REMOTE CONTROLLER USED TO LOCK DOORS)

NBEL0120S03

If the key is used to lock doors, terminal 30 receives a ground signal

- from terminal 3 of the key cylinder switch LH
- from terminal 1 of the door key cylinder switch RH
- through body grounds M4 and M77 or M4 and M66
- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

If this signal or lock signal from remote controller is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal 33 supplies ground to terminal 2 of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

THEFT WARNING SYSTEM ALARM OPERATION

NBEL0120S04

The theft warning system is triggered by

- opening a door without using the key
- opening the hood or the glass hatch
- unlocking door.

Once the theft warning system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 12, 13, 14 (door unlock sensor), 15, 16, 35 (door switch), 26 (glass hatch switch) or 29 (hood switch), the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

Power is supplied at all times

- through 10A fuse [No. 18, located in the fuse block (J/B)].
- to theft warning relay terminal 1.

If the theft warning system is triggered, ground is supplied

- from terminal 32 of the smart entrance control unit
- to theft warning relay terminal 2.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

THEFT WARNING SYSTEM

System Description (Cont'd)

With power and ground supplied, power to inhibitor switch is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 7.5A fuse (No. 52, located in fuse and fusible link box)
- to theft warning lamp relay terminal 1 and
- to theft warning horn relay terminal 1.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal 8 of the smart entrance control unit
- to theft warning lamp relay terminal 2 and
- to theft warning horn relay terminal 2.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

NBEL0120S05

To deactivate the theft warning system, a door, the back door or the glass hatch must be unlocked with the key or remote controller.

When the key is used to unlock the door, smart entrance control unit terminal 31 receives a ground signal

- from terminal 1 of the LH key cylinder switch
- from terminal 3 of the RH key cylinder switch
- from terminal 2 of the back door key cylinder switch.

When the key is used to open the glass hatch, smart entrance control unit terminal 27 receives a ground signal from terminal 3 of the back door key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

NBEL0120S06

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently.

- from smart entrance control unit terminal 8
- to theft warning lamp relay terminal 2 and
- to theft warning horn relay terminal 2.

The headlamp flashes and the horn sounds intermittently.


The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

THEFT WARNING SYSTEM

Schematic

Schematic


NBEL0121



MEL851H

THEFT WARNING SYSTEM

Schematic (Cont'd)



MEL852H

THEFT WARNING SYSTEM

Wiring Diagram — THEFT —


Wiring Diagram — THEFT —

NBEL0122

NBEL0122S01

FIG. 1


EL-THEFT-01



Refer to EL-POWER.

SMART
ENTRANCE
CONTROL
UNIT
(M16)

GLASS
HATCH
SWITCH
(D209)



Refer to last page (Foldout page).

- (M1), (E1)
- (M2), (B1)
- (M10)


THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 2

NBEL0122S02

EL-THEFT-02





GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT

24	25	26	27	28	29	30	31	32	33	34	35	36	6	7	8	9	10	(M16)
11	12	13	14	15	16	17	18	19	20	21	22	23	1	2	3	4	5	W

Refer to last page (Foldout page).

(M2), (B1)



HA
SC
EL
IDX

MEL854H



THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 3

NBEL0122S03

EL-THEFT-03



Refer to last page (Foldout page).

M2, B1

MEL449I








THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 4

NBEL0122S04

EL-THEFT-04



Refer to last page (Foldout page).



MEL817G

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 5

NBEL0122805

EL-THEFT-05




Refer to EL-POWER.

Refer to last page (Foldout page).

24	25	26	27	28	29	30	31	32	33	34	35	36	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20	21	22	23	1	2	3	4	5

(M16)
W



- (M1), (E1)
- (E3)

MEL855H





THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 6

NBEL0122S06

EL-THEFT-06



EL

IDX

MEL6131


THEFT WARNING SYSTEM

Trouble Diagnoses PRELIMINARY CHECK

NBEL0123

NBEL0123S01

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



MEL447H

After performing preliminary check, go to symptom chart in next page.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

NBEL0123502

REFERENCE PAGE (EL-)		210	212	213	216	217	218	219	220	221	222	187	
	SYMPTOM	PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND GLASS HATCH SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR UNLOCK SENSOR CHECK	DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	THEFT WARNING HORN ALARM CHECK	THEFT WARNING HEADLAMP ALARM CHECK	STARTER INTERRUPT SYSTEM CHECK	Check "MULTI-REMOTE CONTROL" system.	GI MA EM LC EC FE AT TF PD AX SU BR ST RS BT HA SC EL
1	Theft warning indicator does not turn "ON" or blinking.	X	X		X								
2	Theft warning system cannot be set by ...	All items	X	X	X		X						
		Door outside key	X	X				X					
		Back door key	X	X					X				
		Multi-remote control	X	X									X
3	*1 Theft warning system does not alarm when ...	Any door is opened.	X	X	X								
		Any door is unlocked without using key or multi-remote controller	X	X			X						
4	Theft warning alarm does not activate.	All function	X	X	X		X						
		Horn alarm	X	X					X				
		Headlamp alarm	X	X							X		
		Starter interrupt	X	X								X	
5	Theft warning system cannot be canceled by ...	Door outside key	X	X			X						
		Back door key	X	X					X				
		Multi-remote control	X	X									X

X : Applicable


*1: Make sure the system is in the armed phase.

Before starting trouble diagnoses above, perform preliminary check, EL-210.

Symptom numbers in the symptom chart correspond with those of preliminary check.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




POWER SUPPLY AND GROUND CIRCUIT CHECK

NBEL0123S03

Power Supply Circuit Check

NBEL0123S0301

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage
11	Ground	0V	0V	Battery voltage
17	Ground	0V	Battery voltage	Battery voltage



Ground Circuit Check

NBEL0123S0302

Terminals	Continuity
10 - Ground	Yes


DOOR, HOOD AND GLASS HATCH SWITCH CHECK


-NBEL0123304

Door Switch Check

NBEL012330401

1	PRELIMINARY CHECK
<ol style="list-style-type: none"> Turn ignition switch "OFF" and remove key from key cylinder. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off. Open any passenger door or back door. "SECURITY" indicator lamp should blink every second. <p style="text-align: center;">OK or NG</p>	
OK	▶ Door switch is OK.
NG	▶ GO TO 2.

2	CHECK DOOR SWITCH INPUT SIGNAL																												
<p>Check voltage between control unit terminals 15, 16 or 35 and ground.</p> <table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">15</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">Front RH door switch</td> <td rowspan="2">35</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">All door switches</td> <td rowspan="2">16</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0054</p>  <p style="text-align: right;">SEL336V</p> <p>Refer to wiring diagram in EL-205.</p> <p style="text-align: center;">OK or NG</p>			Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door switch	15	ground	Open	0	Closed	Approx. 12	Front RH door switch	35	ground	Open	0	Closed	Approx. 12	All door switches	16	ground	Open	0	Closed	Approx. 12
	Terminals		Condition	Voltage [V]																									
	(+)	(-)																											
Front LH door switch	15	ground	Open	0																									
			Closed	Approx. 12																									
Front RH door switch	35	ground	Open	0																									
			Closed	Approx. 12																									
All door switches	16	ground	Open	0																									
			Closed	Approx. 12																									
OK	▶ Door switch is OK.																												
NG	▶ GO TO 3.																												

3	CHECK DOOR SWITCH																						
<ol style="list-style-type: none"> Disconnect door switch connector. Check continuity between door switch terminals. 																							
<table border="1"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switch</td> <td rowspan="2">1 - 2, 3 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Back door switch</td> <td rowspan="2">2 - 1</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Rear door switch</td> <td rowspan="2">1 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0014</p>  <p style="text-align: center;">OK or NG</p>			Terminals	Condition	Continuity	Front door switch	1 - 2, 3 - ground	Closed	No	Open	Yes	Back door switch	2 - 1	Closed	No	Open	Yes	Rear door switch	1 - ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity																				
Front door switch	1 - 2, 3 - ground	Closed	No																				
		Open	Yes																				
Back door switch	2 - 1	Closed	No																				
		Open	Yes																				
Rear door switch	1 - ground	Closed	No																				
		Open	Yes																				
OK	▶ Check the following. <ul style="list-style-type: none"> Door switch ground circuit (Front, back door) or door switch ground condition Harness for open or short between control unit and door switch 																						
NG	▶ Replace door switch.																						

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Hood Switch Check

-NBEL0123S0402

1	PRELIMINARY CHECK	
1. Turn ignition switch "OFF" and remove key from key cylinder. 2. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off. 3. Open hood. "SECURITY" indicator lamp should blink every second. <p style="text-align: center;">OK or NG</p>		
OK	▶	Hood switch is OK.
NG	▶	GO TO 2.

2	CHECK HOOD SWITCH FITTING CONDITION	
OK or NG		
OK	▶	GO TO 3.
NG	▶	Adjust installation of hood switch or hood.

3	CHECK HOOD SWITCH INPUT SIGNAL	
Check voltage between control unit terminal 29 and ground. Voltage [V]: Hood is open. 0 Hood is closed. Approx. 12		
SEL608U		
Refer to wiring diagram in EL-204.		
OK or NG		
OK	▶	Hood switch is OK.
NG	▶	GO TO 4.

4	CHECK HOOD SWITCH	
1. Disconnect hood switch connector. 2. Check continuity between hood switch terminals 1 and 2. Continuity: Condition: Pushed No Condition: Released Yes		
SEL397TB		
OK or NG		
OK	▶	Check the following. <ul style="list-style-type: none"> ● Hood switch ground circuit ● Harness for open or short between control unit and hood switch
NG	▶	Replace hood switch.

Glass Hatch Switch Check

-NBEL0123S0403

1	PRELIMINARY CHECK	<ol style="list-style-type: none"> 1. Turn ignition switch "OFF" and remove key from key cylinder. 2. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off. 3. Open glass hatch. "SECURITY" indicator lamp should blink every second. <p style="text-align: center;">OK or NG</p>
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 2.

2	CHECK GLASS HATCH SWITCH INPUT SIGNAL	<p>Check voltage between control unit terminal 26 and ground.</p> <p>Voltage [V]:</p> <p>Glass hatch is open. Approx. 0</p> <p>Glass hatch is closed. Approx. 12</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL622U</p> <p>Refer to wiring diagram in EL-204.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 3.

3	CHECK GLASS HATCH SWITCH	<ol style="list-style-type: none"> 1. Disconnect glass hatch switch connector. 2. Check continuity between glass hatch switch terminals 1 and 2. <p>Continuity:</p> <p>Condition: Closed No</p> <p>Condition: Open Yes</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL609U</p> <p style="text-align: center;">OK or NG</p>
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Glass hatch switch ground circuit • Harness for open or short between control unit and glass hatch switch
NG	▶	Replace glass hatch switch.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

SECURITY INDICATOR LAMP CHECK

=NBEL0123S05

1	CHECK INDICATOR LAMP OUTPUT SIGNAL
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 33 and ground.</p>	
<p style="text-align: right;">SEL250V</p>	
<p>Refer to wiring diagram in EL-204.</p> <p style="text-align: center;">Does battery voltage exist?</p>	
Yes	▶ Security indicator lamp is OK.
No	▶ GO TO 2.

2	CHECK INDICATOR LAMP
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace indicator lamp.

3	CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP
<p>1. Disconnect security lamp connector. 2. Check voltage between indicator lamp terminal 1 and ground.</p>	
<p style="text-align: right;">SEL251V</p>	
Does battery voltage exist?	
Yes	▶ Check harness for open or short between security indicator lamp and control unit.
No	▶ Check the following. <ul style="list-style-type: none"> • 7.5A fuse [No. 24, located in fuse block (J/B)] • Harness for open or short between security indicator lamp and fuse

DOOR UNLOCK SENSOR CHECK

-NBEL0123S06

1	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL																																		
<p>Check voltage between control unit terminals 12, 13 or 14 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door</td> <td rowspan="2" style="text-align: center;">12</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2">Front RH door</td> <td rowspan="2" style="text-align: center;">13</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2">Rear door</td> <td rowspan="2" style="text-align: center;">14</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 5px;">MTBL0015</p> <div style="margin-top: 10px;"> <p style="text-align: center;">Smart entrance control unit connector (M16)</p> <p style="text-align: center;">C/U CONNECTOR</p> <p style="text-align: center;">12 13 14</p> <p style="text-align: center;">Y/G Y/L Y/R</p> <p style="text-align: center;">V</p> <p style="text-align: center;">+</p> <p style="text-align: center;">-</p> <p style="text-align: center;">H.S. CONNECT OFF</p> <p style="text-align: right; margin-top: 5px;">SEL246V</p> </div> <p>Refer to wiring diagram in EL-206.</p> <p style="text-align: center; margin-top: 5px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>Door unlock sensor is OK.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>			Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door	12	Ground	Locked	Approx. 12	Unlocked	0	Front RH door	13	Ground	Locked	Approx. 12	Unlocked	0	Rear door	14	Ground	Locked	Approx. 12	Unlocked	0	OK	▶	Door unlock sensor is OK.	NG	▶	GO TO 2.
	Terminals		Condition	Voltage [V]																															
	(+)	(-)																																	
Front LH door	12	Ground	Locked	Approx. 12																															
			Unlocked	0																															
Front RH door	13	Ground	Locked	Approx. 12																															
			Unlocked	0																															
Rear door	14	Ground	Locked	Approx. 12																															
			Unlocked	0																															
OK	▶	Door unlock sensor is OK.																																	
NG	▶	GO TO 2.																																	

2	CHECK DOOR UNLOCK SENSOR						
<p>1. Disconnect door unlock sensor connector.</p> <p>2. Check continuity between door unlock sensor terminals.</p> <p>Continuity:</p> <p style="margin-left: 20px;">Condition: Locked</p> <p style="margin-left: 40px;">No</p> <p style="margin-left: 20px;">Condition: Unlocked</p> <p style="margin-left: 40px;">Yes</p> <p style="margin-left: 20px;">Door lock actuator connectors</p> <p style="margin-left: 20px;">Front LH : (D7) Rear LH : (D54)</p> <p style="margin-left: 20px;">Front RH : (D37) Rear RH : (D74)</p> <div style="margin-top: 10px;"> <p style="text-align: right; margin-top: 5px;">SEL247V</p> </div> <p style="margin-top: 10px;">Back door lock actuator connector (D207)</p> <div style="margin-top: 10px;"> <p style="text-align: right; margin-top: 5px;">SEL352V</p> </div> <p style="text-align: center; margin-top: 5px;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td> <p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor </td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>Replace door unlock sensor.</td> </tr> </table>		OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor 	NG	▶	Replace door unlock sensor.
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor 					
NG	▶	Replace door unlock sensor.					

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DOOR KEY CYLINDER SWITCH CHECK


=NBEL0123507



1	CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																								
<p>Check voltage between control unit terminals 30 or 31 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">30</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Lock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">31</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0041</p> <div style="text-align: center; margin: 10px 0;"> <p>Smart entrance control unit connector (M16)</p> <p>Driver's side</p> <p>Passenger side</p> <p style="text-align: right;">SEL614UB</p> </div> <p>Refer to wiring diagram in EL-207.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="padding-left: 10px;">Door key cylinder switch is OK.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td style="padding-left: 10px;">GO TO 2.</td> </tr> </table>		Terminals		Key position	Voltage [V]	(+)	(-)	30	Ground	Neutral	Approx. 12	Lock	0	31	Ground	Neutral	Approx. 12	Unlock	0	OK	▶	Door key cylinder switch is OK.	NG	▶	GO TO 2.
Terminals		Key position	Voltage [V]																						
(+)	(-)																								
30	Ground	Neutral	Approx. 12																						
		Lock	0																						
31	Ground	Neutral	Approx. 12																						
		Unlock	0																						
OK	▶	Door key cylinder switch is OK.																							
NG	▶	GO TO 2.																							

2	CHECK DOOR KEY CYLINDER SWITCH																					
<p>1. Disconnect door key cylinder switch connector.</p> <p>2. Check continuity between door key cylinder switch terminals.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>LH: 3 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td>RH: 1 - 2</td> <td style="text-align: center;">Lock</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>LH: 1 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td>RH: 3 - 2</td> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0042</p> <div style="text-align: center; margin: 10px 0;"> <p>Door key cylinder switch connector</p> <p>LH : (D9) RH : (D39)</p> <p>① : Door unlock switch terminal (LH) Door lock switch terminal (RH)</p> <p>② : Ground terminal</p> <p>③ : Door lock switch terminal (LH) Door unlock switch terminal (RH)</p> <p style="text-align: right;">SEL880U</p> </div> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td style="padding-left: 10px;"> <p>Check the following.</p> <ul style="list-style-type: none"> • Door key cylinder switch ground circuit • Harness for open or short between control unit and door key cylinder switch </td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td style="padding-left: 10px;">Replace door key cylinder switch.</td> </tr> </table>		Terminals	Key position	Continuity	LH: 3 - 2	Neutral	No	RH: 1 - 2	Lock	Yes	LH: 1 - 2	Neutral	No	RH: 3 - 2	Unlock	Yes	OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door key cylinder switch ground circuit • Harness for open or short between control unit and door key cylinder switch 	NG	▶	Replace door key cylinder switch.
Terminals	Key position	Continuity																				
LH: 3 - 2	Neutral	No																				
RH: 1 - 2	Lock	Yes																				
LH: 1 - 2	Neutral	No																				
RH: 3 - 2	Unlock	Yes																				
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door key cylinder switch ground circuit • Harness for open or short between control unit and door key cylinder switch 																				
NG	▶	Replace door key cylinder switch.																				

BACK DOOR KEY CYLINDER SWITCH CHECK

-NBEL0123508

1	CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																											
<p>Check voltage between control unit terminals 30, 31 or 27 and ground.</p>																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="4" style="text-align: center;">Back door</td> <td rowspan="2" style="text-align: center;">30</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between neutral and lock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">31</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between neutral and unlock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">Glass hatch</td> <td rowspan="2" style="text-align: center;">27</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between lock and unlock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>			Terminals		Key position	Voltage [V]	(+)	(-)	Back door	30	Ground	Neutral	Approx. 12	Between neutral and lock	0	31	Ground	Neutral	Approx. 12	Between neutral and unlock	0	Glass hatch	27	Ground	Neutral	Approx. 12	Between lock and unlock	0
	Terminals		Key position	Voltage [V]																								
	(+)	(-)																										
Back door	30	Ground	Neutral	Approx. 12																								
			Between neutral and lock	0																								
	31	Ground	Neutral	Approx. 12																								
			Between neutral and unlock	0																								
Glass hatch	27	Ground	Neutral	Approx. 12																								
			Between lock and unlock	0																								
MTBL0016																												
																												
MEL101GA																												
<p>Refer to wiring diagram in EL-207.</p> <p style="text-align: center;">OK or NG</p>																												
OK	▶ Back door key cylinder switch is OK.																											
NG	▶ GO TO 2.																											

2	CHECK BACK DOOR KEY CYLINDER SWITCH																								
<p>1. Disconnect back door key cylinder switch connector.</p> <p>2. Check continuity between back door key cylinder switch terminals.</p>																									
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="4">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">Between neutral and unlock (Back door)</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">Between lock (Back door) and unlock (glass hatch)</td> <td style="text-align: center;">—</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table>		Key position	Terminals				1	2	3	4	Between neutral and lock (Back door)	○	—	—	○	Between neutral and unlock (Back door)	—	○	—	○	Between lock (Back door) and unlock (glass hatch)	—	—	○	○
Key position	Terminals																								
	1	2	3	4																					
Between neutral and lock (Back door)	○	—	—	○																					
Between neutral and unlock (Back door)	—	○	—	○																					
Between lock (Back door) and unlock (glass hatch)	—	—	○	○																					
MTBL0043																									
																									
SEL616U																									
																									
SEL613U																									
OK or NG																									
OK	▶ Check the following. <ul style="list-style-type: none"> • Back door key cylinder switch ground circuit • Harness for open or short between control unit and back door key cylinder switch 																								
NG	▶ Replace back door key cylinder switch.																								

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

THEFT WARNING HORN ALARM CHECK

-NBEL0123509

1	CHECK THEFT WARNING HORN ALARM OPERATION
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 8.</p>	
SEL529UA	
Refer to wiring diagram in EL-208.	
Does horn alarm activate?	
Yes	▶ Horn alarm is OK.
No	▶ GO TO 2.

2	CHECK THEFT WARNING HORN RELAY
Check theft warning horn relay.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace.

3	CHECK POWER SUPPLY FOR THEFT WARNING HORN RELAY
<p>1. Disconnect theft warning horn relay connector. 2. Check voltage between terminal 1 and ground.</p>	
SEL755UB	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check the following. <ul style="list-style-type: none"> • 7.5A fuse (No. 52, located in the fuse and fusible link box) • Harness for open or short between theft warning horn relay and fuse

4	CHECK THEFT WARNING HORN RELAY CIRCUIT
<p>1. Disconnect theft warning horn relay connector. 2. Check voltage between terminals 3 and 5. Battery voltage should exist. 3. Check voltage between terminals 6 and 7. Battery voltage should exist.</p>	
SEL756UB	
OK or NG	
OK	▶ Check harness for open or short between theft warning horn relay and control unit.
NG	▶ Check harness for open or short.

THEFT WARNING HEADLAMP ALARM CHECK

=NBEL0123510

1	CHECK THEFT WARNING HEADLAMP ALARM OPERATION
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 8.</p>	
SEL529UA	
Refer to wiring diagram in EL-208.	
Does headlamp alarm activate?	
Yes	▶ Headlamp alarm is OK.
No	▶ GO TO 2.

2	CHECK HEADLAMP OPERATION
Does headlamp come on when turning lighting switch "ON"?	
Yes	▶ GO TO 3.
No	▶ Check headlamp system. Refer to "HEADLAMP".

3	CHECK THEFT WARNING LAMP RELAY
Check theft warning lamp relay.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace.

4	CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminal 1 and ground.</p>	
SEL757U	
Refer to wiring diagram in EL-209.	
Does battery voltage exist?	
Yes	▶ GO TO 5.
No	▶ Check the following.
<ul style="list-style-type: none"> • 7.5A fuse (No. 52, located in the fuse and fusible link box) • Harness for open or short between theft warning lamp relay and fuse 	

5	CHECK THEFT WARNING LAMP RELAY CIRCUIT
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminals 3 and 5. Battery voltage should exist. 3. Check voltage between terminals 6 and 7. Battery voltage should exist.</p>	
SEL758U	
OK or NG	
OK	▶ Check harness for open or short between theft warning lamp relay and control unit.
NG	▶ Check the following.
<ul style="list-style-type: none"> • Harness for open or short between fuse and theft warning lamp relay • Harness for open or short between theft warning lamp relay and headlamps 	


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

STARTER INTERRUPT SYSTEM CHECK

=NBEL0123S11

1	CHECK STARTER MOTOR INTERRUPT SIGNAL
<p>1. Turn ignition switch "ON".</p> <p>2. Check voltage between control unit terminal 32 and ground.</p> <p>Voltage [V]: Except starter interrupted phase Approx. 12 Starter interrupted phase 0</p>  <p style="text-align: right;">SEL624U</p> <p>Refer to wiring diagram in EL-208.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse (No. 18, located in fuse block (J/B)) ● Harness for open or short between theft warning relay and fuse ● Harness for open or short between control unit and theft warning relay

2	CHECK THEFT WARNING RELAY
<p>Check theft warning relay.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check system again.
NG	▶ Replace relay.

SMART ENTRANCE CONTROL UNIT

Description

Description

NBEL0124

The following systems are controlled by the smart entrance control unit.

- Warning chime
- Rear window defogger timer
- Power door lock
- Multi-remote control system
- Theft warning system

For detailed description and wiring diagrams, refer to the relevant pages for the each system.

The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.

System	Input	Output
Power door lock	Door lock and unlock switch Key switch (Insert) Front door switch LH Front door switch RH Front door unlock sensor LH Front door unlock sensor RH Door key cylinder switches	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switches Door unlock sensors Antenna (remote controller signal)	Theft warning horn relay Theft warning lamp relay Interior lamp Multi-remote control relay Door lock actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch Front door switch LH	Warning chime
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Theft warning	Ignition switch (ACC, ON) Door switches Hood switch Glass hatch switch Door key cylinder switches (lock/unlock) Back door key cylinder switch (lock/unlock/glass hatch unlock) Door unlock sensor	Theft warning horn relay Theft warning lamp relay Theft warning relay (Starter interrupt) Security indicator

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

SMART ENTRANCE CONTROL UNIT

Schematic

Schematic


NBEL0125



MEL856H

SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)



MEL857H

SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

Smart Entrance Control Unit Inspection Table

NBEL0126

Terminal No.	Connections	Operated condition	Voltage (Approximate values)
1	Power source (C/B)	—	12V
2	Passenger door lock actuator	Door lock & unlock switch	Unlocked
3	Driver door lock actuator		Free
4	Driver and passenger door lock actuators	Door lock & unlock switch	Locked
			Free
7	Multi-remote control relay	When doors are locked using remote controller	12V → 0V
8	Theft warning horn/lamp relay	When panic alarm is operated using remote controller	12V → 0V
9	Interior lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V
10	Ground	—	—
11	Ignition switch (ON)	Ignition key is in "ON" position	12V
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V
14	Rear and back door unlock sensors	All doors are locked → One or more doors are unlocked	12V → 0V
15	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V
16	All door switches	OFF (Closed) → ON (Open)	12V → 0V
17	Ignition switch (ACC)	"ACC" position	12V
18	Door lock & unlock switches	Neutral → Locks	12V → 0V
19	Door lock & unlock switches	Neutral → Unlocks	12V → 0V
20	Rear window defogger switch	OFF → ON	12V → 0V
21	Seat belt buckle switch	Unfasten → Fasten (Ignition key is in "ON" position)	0V → 12V
23	Warning chime	OFF → ON	12V → 0V
24	Ignition key switch (Insert)	key inserted → key removed from IGN key cylinder	12V → 0V
25	Lighting switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V
26	Glass hatch switch	ON (Open) → OFF (Closed)	0V → 12V
27	Back door key unlock switch	OFF (Neutral) → ON (Unlock)	12V → 0V
29	Hood open signal	ON (Open) → OFF (Closed)	0V → 12V
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	12V → 0V
31	Door key cylinder lock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
32	Theft warning relay (Starter cut)	OFF → ON (Ignition key is in "ON" position)	12V → 0V
33	Theft warning indicator	Goes off → Illuminates	12V → 0V
35	Passenger door switch	OFF (Closed) → ON (Open)	12V → 0V
36	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)	12V → 0V
37	Multi-remote control antenna	—	—

INTEGRATED HOMELINK TRANSMITTER

Wiring Diagram — TRNSMT —

Wiring Diagram — TRNSMT —

NBEL0127

EL-TRNSMT-01 GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC


EL

IDX



Refer to last page (Foldout page).

M10



MEL858H

INTEGRATED HOMELINK TRANSMITTER

Trouble Diagnoses

Trouble Diagnoses

DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.

NBEL0128

NBEI 0128S01

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

1 PRELIMINARY CHECK	
1. Turn ignition switch "OFF". 2. Does red light (LED) of transmitter illuminate when any button is pressed?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2 CHECK TRANSMITTER FUNCTION	
Check transmitter with Tool. For details, refer to Technical Service Bulletin.	
OK or NG	
OK	▶ Receiver or handheld transmitter fault, not vehicle related.
NG	▶ Replace transmitter with sun visor assembly.

3 CHECK POWER SUPPLY	
1. Disconnect transmitter connector. 2. Turn ignition switch "OFF". 3. Check voltage between terminal 1 and body ground.	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check fuse (7.5A) and repair harness.


4 CHECK GROUND CIRCUIT	
Check continuity between terminal 2 and ground.	
Does continuity exist?	
Yes	▶ Replace transmitter with sun visor assembly.
No	▶ Repair harness.

ELECTRICAL UNITS LOCATION



Engine Compartment

Engine Compartment

NBEL0129



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX





MEL469I

ELECTRICAL UNITS LOCATION

Passenger Compartment

Passenger Compartment


NBEL0130



MEL247HA

ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MEL457I

HARNESS LAYOUT

How to Read Harness Layout

How to Read Harness Layout

NBEL0131



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

TO USE THE GRID REFERENCE

NBEL0131S01

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

NBEL0131S02

Main symbols of connector (in Harness Layout) are indicated in the below.


Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> • Ground terminal etc. 	—			

HARNESS LAYOUT

Outline

Outline

NBEL0132



MEL082H

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HARNESS LAYOUT


Main Harness

Main Harness


NBFI 0133



MEL859H




★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.




Diode (M108)




Diode (M109)



Diode (M65)



Diode (M7)




- GI
- MA
- EM
- LC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

HARNESS LAYOUT

Engine Room Harness

Engine Room Harness

NBFI 0134




★: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to **WORK FLOW of TROUBLE DIAGNOSES** in EC and AT sections.

MEL861H

HARNESS LAYOUT

Engine Room Harness (Cont'd)

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



D5	E30	GY/2	: Front turn signal lamp LH
D3	E31	GY/2	: Hood switch
C3	E32	B/2	: Ambient sensor
C4	E33	B/2	: Ambient air temperature sensor (For thermometer)
C4	E34	GY/2	: Ambient air temperature switch
C3	E35	B/1	: Horn (High)
B3	E36	B/1	: Horn (Low)
B3	E37	B/2	: Dual-pressure switch
A3	E38	B/3	: Headlamp RH
A4	E39	GY/2	: Front turn signal lamp RH
A2	E40	GY/2	: Parking lamp RH
A2	E41	—	: Body ground
B4	E42	BR/2	: Washer level switch
B4	E43	GY/2	: Rear washer motor
B4	E44	GY/2	: Front washer motor
B2	E45	GY/8	: Daytime light control unit
A2	E46	GY/6	: Daytime light control unit
B1	E47	GY/2	: A/T dropping resistor
B1	E48	GY/4	: To E102
C2	E49	GY/1	: To E104
B2	E50	B/1	: Theft warning horn
C3	E51	GY/2	: Front wheel sensor RH
D2	E52	B/1	: Battery
D2	E53	B/1	: Battery
B1	E54	L/4	: Fuel pump relay
B1	E56	GY/6	: Park/Neutral position relay
A1	E57	BR/6	: ECCS relay
C2	E59	GY/4	: ASCD pump
C1	E60	—	: Fuse and fusible link box
D5	E61	BR/2	: Front fog lamp LH
B4	E62	BR/2	: Front fog lamp RH
E3	E63	W/3	: Front fog lamp switch
E3	E88	GY/3	: Absolute pressure sensor
D3	E90	B/2	: MAP/BARO switch solenoid valve
B2	E91	GY/2	: Transfer dropping resistor
F2	E92	W/1	: Transfer motor relay
G2	E93	W/1	: Transfer motor relay
G2	E94	G/2	: Transfer motor relay
B1	E95	B/5	: Transfer indicator lamp relay (Relay box-2)
D1	E96	L/4	: Power socket relay (Relay box-1)

★	E1	SMJ	: To M1
	E2	B/2	: Fuse block (J/B)
	E3	W/16	: Fuse block (J/B)
	E4	W/4	: Fuse block (J/B)
	E5	W/2	: Key switch
★	E6	W/6	: Ignition switch
	E7	BR/4	: Combination switch (Lighting switch)
	E8	BR/8	: Combination switch (Lighting & turn signal switch)
	E9	GY/8	: Combination switch (Front wiper switch)
★	E10	GY/2	: Intake air temperature sensor
	E11	GY/2	: Parking lamp LH
★	E12	GY/2	: Parking lamp LH
	E13	—	: Body ground
	E14	BR/2	: Front wheel sensor LH
	E15	L/4	: Front fog lamp relay
	E16	BR/6	: Multi-remote control relay
	E17	BR/6	: Theft warning lamp relay
	E18	BR/6	: Theft warning lamp relay
	E19	L4	: Door mirror defogger relay
	F1	BR/5	: Theft warning relay
	F1	BR/6	: Rear window defogger relay
	E1	E22	: ASCD hold relay
	E1	E23	: Theft warning horn relay
	F1	E25	: Horn relay
	F1	E26	: A/C relay
	F2	E28	: Brake fluid level switch
	D4	E29	: Headlamp LH

CI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 PS
 BT
 HA
 SC
EL
 IDX


MEL862H

HARNESS LAYOUT

Engine Control Harness

Engine Control Harness

NBEL0135




* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

MEL863H

HARNESS LAYOUT

Engine Control Harness (Cont'd)

D1*	F1	GY/4	: Rear heated oxygen sensor RH
D1*	F2	GY/3	: Front heated oxygen sensor RH
D1*	F3	GY/4	: Rear heated oxygen sensor LH
D1*	F4	GY/3	: Front heated oxygen sensor LH
C2*	F5	GY/8	: To (F100)
C3*	F6	B/8	: To (F101)
C4*	F7	GY/6	: Distributor
E4*	F8	BR/3	: Throttle position sensor
F4*	F9	GY/3	: Throttle position switch
E3*	F10	BR/4	: Mass air flow sensor
C4*	F11	GY/2	: Ignition coil
C4*	F12	GY/2	: EGR temperature sensor
D5	F14	GY/2	: To (F200)
E4*	F15	G/2	: EGRC-solenoid valve
C3	F17	B/1	: Thermal transmitter
E1*	F18	B/2	: Resistor
E1*	F20	—	: Engine ground
F3	F21	L/12	: Joint connector
F2*	F22	GY/16	: To (M33)
F2*	F23	W/24	: To (M32)
F2*	F24	SMJ	: ECM (ECCS control module)
E1*	F25	—	: Engine ground
F3	F26	W/2	: Diode
F2*	F27	W/18	: To (M94)
C2	F28	B/4	: To (F112)
C2*	F100	GY/8	: To (F5)
C2*	F101	B/8	: To (F6)
E2*	F102	B/2	: Knock sensor
C3*	F103	B/2	: Injector No. 1
C4*	F104	B/2	: Injector No. 2
C3*	F105	B/2	: Injector No. 3
F4*	F106	B/2	: Injector No. 4
E2*	F107	B/2	: Injector No. 5
F3*	F108	B/2	: Injector No. 6
F2*	F109	BR/2	: IACV-AAC valve
F3*	F110	GY/2	: Crankshaft position sensor (OBD)
F3	F111	GY/2	: IACV-FICD solenoid valve
C2	F112	B/4	: To (F28)
F4	F113	L/2	: EVAP canister purge volume control solenoid valve
C3	F114	GY/2	: Engine coolant temperature sensor
D5	F200	GY/2	: To (F14)
E4	F201	B/1	: Oil pressure switch
D4	F202	B/1	: Compressor (Air conditioner)



* : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working
 according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


MEL864H

HARNESS LAYOUT


Body Harness LH

Body Harness LH

NBEL0136




- ★ B1 : To M2
- B3 : Parking brake switch
- B4 : To B40
- B5 : Heated seat LH
- B6 : Seat belt buckle switch
- B7 : Power seat LH
- B8 : Rear wheel sensor LH
- B9 : Front door switch LH
- B10 : To D50
- B11 : Body ground
- B12 : Fuel tank gauge unit
- B13 : Fuel pump
- B14 : Rear wiper amp.
- B15 : Rear wiper relay
- B16 : Rear door switch LH
- B22 : Body ground
- B23 : To D100
- B24 : To D101
- B25 : To D102
- B26 : Rear combination lamp LH
- B27 : Diode
- B40 : To B4
- B41 : Power socket
- B43 : To B101
- B44 : GY/1 : Smart entrance control unit
- B45 : B/1 : Antenna (For smart entrance control unit)
- B46 : W/26 : Rear speaker amp.
- B47 : W/4 : Audio amp. relay
- B49 : W/2 : Diode
- B101 : W/8 : To B43
- B102 : GY/3 : EVAP control system pressure sensor
- B103 : B/2 : EVAP canister vent control valve
- B104 : G/2 : Vacuum cut valve bypass valve
- B151 : GY/2 : To B152
- B152 : GY/2 : To B151
- B153 : L/4 : Glass hatch opener relay
- B154 : W/2 : Diode



★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Body Harness RH

NBEL0137



- ★ B50 W/20 : To (M70)
- ★ B51 W/24 : To (M71)
- ★ B52 W/16 : To (M72)
- ★ B55 — : Body ground
- B56 W/3 : Heated seat RH
- B57 W/2 : Power seat RH
- B58 GY/2 : G sensor
- B59 W/6 : A/T device
- ★ B63 GY/2 : Vehicle speed sensor
- ★ B64 BR/8 : Terminal cord assembly
- ★ B65 GY/8 : Inhibitor switch
- ★ B66 GY/2 : Inhibitor switch
- B67 GY/3 : Rear revolution sensor
- B68 B/3 : Front door switch RH
- B69 GY/2 : Rear wheel sensor RH
- B70 W/10 : To (D70)
- B71 BR/1 : Rear door switch RH
- B74 W/6 : Rear combination lamp RH
- ★ B75 — : Body ground
- B76 W/3 : Ashtray
- B77 W/12 : To (M99)
- B78 GY/8 : To (B206)
- B79 B/4 : To (B208)
- B80 B/8 : To (B207)
- B81 GY/2 : G sensor

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX


MEL866H

HARNESS LAYOUT

Back Door Harness

Back Door Harness

NBEL0138



- D300 : To D107
- D301 : To D108
- D302 : High-mounted stop lamp
- D303 : Rear window defogger
- D304 : Rear window defogger
- D305 : Body ground

- D200 : W/4 : Glass hatch opener actuator
- D201 : W/6 : Back door key cylinder switch
- D202 : B/2 : License plate lamp LH
- D205 : W/12 : To D105
- D206 : W/4 : To D106
- D207 : W/4 : Back door lock actuator
- D208 : W/2 : Back door switch
- D209 : W/2 : Glass hatch switch
- D210 : — : Body ground
- D211 : B/2 : License plate lamp RH
- D212 : W/8 : Rear wiper motor

- D100 : W/12 : To B23
- D101 : W/6 : To B24
- D102 : W/4 : To B25
- D103 : W/3 : Luggage room lamp
- D105 : W/12 : To D205
- D106 : W/4 : To D206
- D107 : W/2 : To D300
- D108 : W/1 : To D301


MEL091H

HARNESS LAYOUT

Engine and Transmission Harness


Engine and Transmission Harness

NBEL0139



- B206 GY/8 : To (B78)
- B207 B/8 : To (B80)
- B208 B/4 : To (B79)
- B209 GY/8 : Terminal cord assembly
- B210 GY/2 : ATP switch
- B211 B/2 : Wait detection switch
- B212 B/2 : Transfer motor
- B213 BR/2 : Neutral-4LO switch
- B214 GY/3 : Front revolution sensor

- E100 : Battery
- E101 : Body ground
- E102 GY/4 : To (E48)
- E103 : Fuse and fusible link box
- E104 GY/1 : To (E49)
- E105 : Alternator
- E106 GY/2 : Alternator
- E107 : Alternator
- E108 : Starter motor
- E109 GY/1 : Starter motor
- E110 GY/2 : Power steering oil pressure switch



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MEL092H

HARNESS LAYOUT

Room Lamp

Room Lamp

NBEL0140




- | | | |
|-----------|------|-----------------------------------|
| R1 | W/6 | : To M62 |
| R2 | W/6 | : To M63 |
| R3 | R/2 | : Vanity mirror RH (Illumination) |
| R4 | W/8 | : Compass and thermometer |
| R5 | R/2 | : Vanity mirror LH (Illumination) |
| R6 | W/2 | : Spot lamp |
| R7 | W/2 | : Interior lamp |
| R8 | W/1 | : Sunroof motor |
| | BR/6 | |

MEL867H

Air Bag Harness

NBEL0141



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HARNESS LAYOUT


Front Door Harness

Front Door Harness

NBEL0142


LH side

- D1** GY/5 : Door mirror defogger LH
- D2** BR/3 : Door mirror LH
- D3** W/16 : To **M5**
- D4** W/10 : To **M6**
- D5** B/2 : Front power window regulator LH
- D6** W/16 : Power window main switch
- D7** GY/4 : Front door lock actuator LH
- D9** BR/3 : Front door key cylinder switch LH
- D11** BR/4 : To **M97**
- D12** W/6 : Front door speaker LH



RH side

- D31** GY/5 : Door mirror defogger RH
- D32** BR/3 : Door mirror RH
- D33** W/12 : To **M67**
- D34** W/6 : To **M68**
- D35** B/2 : Power window regulator RH
- D36** W/8 : Front power window sub-switch
- D37** GY/4 : Front door lock actuator RH
- D39** BR/3 : Front door key cylinder switch RH
- D41** BR/6 : To **M107**
- D42** W/6 : Front door speaker RH



MEL869H


HARNESS LAYOUT

Rear Door Harness

Rear Door Harness

NBEL0143

LH side



- (D50) W/10 : To (B10)
- (D51) B/2 : Rear power window regulator LH
- (D52) W/8 : Rear power window sub-switch LH
- (D53) BR/2 : Rear door speaker LH
- (D54) GY/4 : Rear door lock actuator LH

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

RH side



- (D70) W/10 : To (B70)
- (D71) B/2 : Rear power window regulator RH
- (D72) W/8 : Rear power window sub-switch RH
- (D73) BR/2 : Rear door speaker RH
- (D74) GY/4 : Rear door lock actuator RH

MEL870H

BULB SPECIFICATIONS

Headlamp

Headlamp	
Item	Wattage (W)
High/Low (Semi-sealed beam)	65/45 (HB1)

NBEL0144S03

Exterior Lamp

Exterior Lamp		
Item	Wattage (W)	
Front fog lamp	55	
Front turn signal lamp	27	
Parking lamp	3.8	
Rear combination lamp	Turn signal lamp	27
	Stop/Tail lamp	27/8
Back-up lamp	27	
License plate lamp	5	
High-mounted stop lamp	5	

NBEL0144S01

Interior Lamp

Interior Lamp	
Item	Wattage (W)
Interior lamp	10
Spot lamp	8
Luggage room lamp	10

NBEL0144S02

WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C, A	HA	Auto Air Conditioner
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device
AT/C	EC	A/T Control
ATDIAG	EC	A/T Diagnosis Communication Line
AUDIO	EL	Audio
BA/FIS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Solenoid Valve
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor (OBD)
CMPS	EC	Camshaft Position Sensor
COMPAS	EL	Compass and Thermometer
D/LOCK	EL	Power Door Lock
DEF	EL	Rear Window Defogger
DTRL	EL	Headlamp — With Daytime Light System —
ECTS	EC	Engine Coolant Temperature Sensor
EGR/TS	EC	EGR Temperature Sensor
EGRC/V	EC	EGRC-solenoid Valve
EGRC1	EC	EGR Function
ENGSS	AT	Engine Speed Signal
F/FOG	EL	Front Fog Lamp
F/PUMP	EC	Fuel Pump Control

Code	Section	Wiring Diagram Name	
FICD	EC	IACV-FICD Solenoid Valve	GI
FO2H-L	EC	Front Heated Oxygen Sensor Heater (Left Bank)	MA
FO2H-R	EC	Front Heated Oxygen Sensor Heater (Right Bank)	EM
FRO2LH	EC	Front Heated Oxygen Sensor (Front HO2S) (Left Bank)	LC
FRO2RH	EC	Front Heated Oxygen Sensor (Front HO2S) (Right Bank)	EC
FTS	AT	A/T Fluid Temperature Sensor	FE
FUELLH	EC	Fuel Injection System Function (Left Bank)	AT
FUELRH	EC	Fuel Injection System Function (Right Bank)	TF
H/LAMP	EL	Headlamp	PD
HSEAT	EL	Heated Seat	AX
HORN	EL	Horn	SU
IATS	EC	Intake Air Temperature Sensor	BR
IGN/SG	EC	Ignition Signal	ST
ILL	EL	Illumination	RS
INH/SW	AT	Inhibitor Switch	BT
INJECT	EC	Injector	HA
INT/L	EL	Interior, Spot, Vanity Mirror, and Luggage Room Lamps	SC
KS	EC	Knock Sensor	EL
LPSV	AT	Line Pressure Solenoid Valve	IDX
MAFS	EC	Mass Air Flow Sensor	
MAIN	AT	Main Power Supply and Ground Circuit	
MAIN	EC	Main Power Supply and Ground Circuit	
METER	EL	Speedometer, Tachometer, Temp., Oil, and Fuel Gauges	
MIL/DL	EC	MIL and Data Link Connectors	
MIRROR	EL	Door Mirror	
MULTI	EL	Multi-remote Control System	
NONDTC	AT	Non-detectable Items	
OVRCSV	AT	Overrun Clutch Solenoid Valve	
P/ANT	EL	Power Antenna	
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve	
PNP/SW	EC	Park/Neutral Position Switch	

WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PST/SW	EC	Power Steering Oil Pressure Switch
RO2H-L	EC	Rear Heated Oxygen Sensor Heater LH
RO2H-R	EC	Rear Heated Oxygen Sensor Heater RH
RRO2LH	EC	Rear Heated Oxygen Sensor LH
RRO2RH	EC	Rear Heated Oxygen Sensor RH
S/SIG	EC	Start Signal
SEAT	EL	Power Seat
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop lamp
SW/V	EC	MAP/BARO Switch Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock up)
TCV	AT	Torque Converter Clutch Solenoid Valve
T/F	TF	Transfer
TFTS	EC	Tank Fuel Temperature Sensor
THEFT	EL	Theft Warning System
TLID	EL	Glass Hatch Opener
TP/SW	EC	Throttle Position Switch
TPS	AT	Throttle Position Sensor
TPS	EC	Throttle Position Sensor
TRNSMT	EL	Integrated HOMELINK [®] Transmitter
TURN	EL	Turn Signal and Hazard Warning Lamps
VENT/V	EC	EVAP Canister Vent Control Valve
VSS	EC	Vehicle Speed Sensor
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR

Code	Section	Wiring Diagram Name
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIP/R	EL	Rear Wiper and Washer
WIPER	EL	Front Wiper and Washer