

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

PRECAUTIONS	3	Front Air Control Circuit Check	47	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	ABS Actuator and Electric Unit (Control Unit) Circuit Check	47	G
Precautions When Using CONSULT-II	3	IPDM E/R Circuit Check	48	H
CHECK POINTS FOR USING CONSULT-II	3	CAN Communication Circuit Check	48	I
Precautions For Trouble Diagnosis	3	IPDM E/R Ignition Relay Circuit Check	49	J
CAN SYSTEM	3	Component Inspection	49	
Precautions For Harness Repair	4	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	49	
CAN SYSTEM	4	CAN SYSTEM (TYPE 2)	50	
CAN COMMUNICATION	5	System Description	50	
System Description	5	Component Parts and Harness Connector Location..	50	
CAN Communication Unit	5	Schematic	51	
TYPE1	5	Wiring Diagram - CAN -	52	
TYPE2	8	Work Flow	55	
TYPE 3	10	CHECK SHEET	57	
TYPE 4	13	CHECK SHEET RESULTS (EXAMPLE)	59	
CAN SYSTEM (TYPE 1)	16	Circuit Check Between TCM and ICC Sensor	78	
System Description	16	Circuit Check Between ICC Sensor and ICC Unit..	79	
Component Parts and Harness Connector Location..	16	Circuit Check Between ICC Unit and Driver Seat Control Unit	80	
Schematic	17	Circuit Check Between Driver Seat Control Unit and Data Link Connector	80	
Wiring Diagram - CAN -	18	Circuit Check Between Data Link Connector and IPDM E/R	81	
Work Flow	21	ECM Circuit Check	82	
CHECK SHEET	23	TCM Circuit Check	82	
CHECK SHEET RESULTS (EXAMPLE)	25	ICC Sensor Circuit Check	83	
Circuit Check Between TCM and Driver Seat Control Unit	40	ICC Unit Circuit Check	83	
Circuit Check Between Driver Seat Control Unit and Data Link Connector	41	Driver Seat Control Unit Circuit Check	84	
Circuit Check Between Data Link Connector and IPDM E/R	42	Combination Meter Circuit Check	84	
ECM Circuit Check	43	Display Control Unit Circuit Check	85	
TCM Circuit Check	43	BCM Circuit Check	85	
Driver Seat Control Unit Circuit Check	44	Data Link Connector Circuit Check	86	
Combination Meter Circuit Check	44	Steering Angle Sensor Circuit Check	86	
Display Control Unit Circuit Check	45	Front Air Control Circuit Check	87	
BCM Circuit Check	45	ABS Actuator and Electric Unit (Control Unit) Circuit Check	87	
Data Link Connector Circuit Check	46	IPDM E/R Circuit Check	88	
Steering Angle Sensor Circuit Check	46	CAN Communication Circuit Check	88	

F
G
H
I
J
K

LAN

L
M

IPDM E/R Ignition Relay Circuit Check	89	CAN SYSTEM (TYPE 4)	126
Component Inspection	89	System Description	126
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-		Component Parts and Harness Connector Location	126
TION	89	Schematic	127
CAN SYSTEM (TYPE 3)	90	Wiring Diagram - CAN -	128
System Description	90	Work Flow	131
Component Parts and Harness Connector Location..	90	CHECK SHEET	133
Schematic	91	CHECK SHEET RESULTS (EXAMPLE)	135
Wiring Diagram - CAN -	92	Circuit Check Between TCM and ICC Sensor	155
Work Flow	95	Circuit Check Between ICC Sensor and ICC Unit.	156
CHECK SHEET	97	Circuit Check Between ICC Unit and Driver Seat	
CHECK SHEET RESULTS (EXAMPLE)	99	Control Unit	157
Circuit Check Between TCM and Driver Seat Con-		Circuit Check Between Driver Seat Control Unit and	
trol Unit	115	Data Link Connector	157
Circuit Check Between Driver Seat Control Unit and		Circuit Check Between Data Link Connector and	
Data Link Connector	116	IPDM E/R	158
Circuit Check Between Data Link Connector and		ECM Circuit Check	159
IPDM E/R	117	TCM Circuit Check	159
ECM Circuit Check	118	ICC Sensor Circuit Check	160
TCM Circuit Check	118	ICC Unit Circuit Check	160
Driver Seat Control Unit Circuit Check	119	Driver Seat Control Unit Circuit Check	161
Combination Meter Circuit Check	119	Combination Meter Circuit Check	161
Display Control Unit Circuit Check	120	Display Control Unit Circuit Check	162
BCM Circuit Check	120	BCM Circuit Check	162
Data Link Connector Circuit Check	121	Data Link Connector Circuit Check	163
Steering Angle Sensor Circuit Check	121	Steering Angle Sensor Circuit Check	163
Front Air Control Circuit Check	122	Front Air Control Circuit Check	164
Transfer Control Unit Circuit Check	122	Transfer Control Unit Circuit Check	164
ABS Actuator and Electric Unit (Control Unit) Circuit		ABS Actuator and Electric Unit (Control Unit) Circuit	
Check	123	Check	165
IPDM E/R Circuit Check	123	IPDM E/R Circuit Check	165
CAN Communication Circuit Check	124	CAN Communication Circuit Check	166
IPDM E/R Ignition Relay Circuit Check	124	IPDM E/R Ignition Relay Circuit Check	166
Component Inspection	125	Component Inspection	167
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-		ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
TION	125	TION	167

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS0017I

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS0017J

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "CAN Communication Unit"](#) .

**Precautions For Trouble Diagnosis
CAN SYSTEM**

UKS0017K


- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M


LAN

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



CAN COMMUNICATION

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon			
Axle	2WD		4WD	
Engine	VK56DE			
Transmission	A/T			
Brake control	VDC			
ICC system		×		×
CAN system type	1	2	3	4
CAN system trouble diagnosis	LAN-16	LAN-50	LAN-90	LAN-126

×: Applicable

TYPE1

System diagram

- Type1



PKIA8173E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R				R	
Engine status signal	T					R		R		

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine coolant temperature signal	T	R		R				R		
A/T self-diagnosis signal	R	T								
Accelerator pedal position signal	T	R							R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Battery voltage signal	T	R								
Key switch signal			R			T				
Ignition switch signal			R			T				R
P range signal		T	R							
Stop lamp switch signal		R		T		R				
Parking brake switch signal				T		R				
Fuel consumption monitor signal	T			R						
				T	R					
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R					T				
A/C compressor request signal	T							R		R
Blower fan motor switch signal	R					T		R		
A/C switch/indicator signal					T			R		
					R			T		
Cooling fan speed request signal	T							R		R
Position light request signal				R		T				R
Low beam request signal						T				R
Low beam status signal	R									T
High beam request signal				R		T				R
High beam status signal	R									T
Front fog light request signal						T				R
Day time running light request signal						T				R
Vehicle speed signal				R				R	T	
	R	R	R	T	R	R		R		
Sleep wake up signal				R		T				R
Door switch signal			R	R	R	T				R
Turn indicator signal				R		T				
Key fob ID signal			R			T				
Key fob door unlock signal			R			T				
Buzzer output signal				R		T				
Fuel level sensor signal	R			T						
Fuel level low warning signal				T	R					
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						

CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Malfunction indicator lamp signal	T			R						
Front wiper request signal						T				R
Front wiper stop position signal						R				T
Rear window defogger switch signal						T		R		R
Rear window defogger control signal	R				R			R		T
Hood switch signal						R				T
Theft warning horn request signal						T				R
Horn chirp signal						T				R
Steering angle sensor signal							T		R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
System setting signal			R		T					
			T		R					
Distance to empty signal				T	R					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R						
Tire pressure signal				R		T				
Tire pressure data signal					R	T				
1st position switch signal		R		T						
4th position switch signal		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						

A
B
C
D
E
F
G
H
I
J
LAN
L
M

TYPE2

System diagram

- Type2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R		R	R				R	
Engine status signal	T							R		R		
Engine coolant temperature signal	T	R				R				R		
A/T self-diagnosis signal	R	T										
Accelerator pedal position signal	T	R		R							R	
Closed throttle position signal	T	R		R								
Wide open throttle position signal	T	R										
Battery voltage signal	T	R										
Key switch signal					R			T				
Ignition switch signal					R			T				R
P range signal		T		R	R							
Stop lamp switch signal		R				T		R				
Parking brake switch signal						T		R				
Fuel consumption monitor signal	T					R						
						T	R					
Turbine revolution signal	R	T		R								
Output shaft revolution signal	R	T		R								
A/C switch signal	R							T				
A/C compressor request signal	T									R		R
Blower fan motor switch signal	R							T		R		

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPD ME/R
A/C switch/indicator signal							T			R		
							R			T		
Cooling fan speed request signal	T									R		R
Position light request signal						R		T				R
Low beam request signal								T				R
Low beam status signal	R											T
High beam request signal						R		T				R
High beam status signal	R											T
Front fog light request signal								T				R
Day time running light request signal								T				R
Vehicle speed signal						R				R	T	
	R	R	R		R	T	R	R		R		
Sleep wake up signal						R		T				R
Door switch signal					R	R	R	T				R
Turn indicator signal						R		T				
Key fob ID signal					R			T				
Key fob door unlock signal					R			T				
Buzzer output signal						R		T				
				T		R						
Fuel level sensor signal	R					T						
Fuel level low warning signal						T	R					
Malfunction indicator lamp signal	T					R						
Front wiper request signal				R				T				R
Front wiper stop position signal								R				T
Rear window defogger switch signal								T		R		R
Rear window defogger control signal	R						R					T
Hood switch signal								R				T
Theft warning horn request signal								T				R
Horn chirp signal								T				R
Steering angle sensor signal									T		R	
ABS warning lamp signal						R					T	
VDC OFF indicator lamp signal				R		R					T	
SLIP indicator lamp signal						R					T	
Brake warning lamp signal						R					T	
VDC operation signal				R							T	
ABS malfunction signal				R							T	
TCS malfunction signal				R							T	
VDC malfunction signal				R							T	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPD M E/R
Brake pressure sensor signal				R							T	
System setting signal					R		T					
					T		R					
Distance to empty signal						T	R					
ASCD operation signal	T	R										
ASCD OD cancel request	T	R										
A/T CHECK indicator lamp signal		T				R						
A/T position indicator lamp signal		T		R		R						
Current gear position signal		T		R								
Tire pressure signal						R		T				
Tire pressure data signal							R	T				
1st position switch signal		R				T						
4th position switch signal		R				T						
Tow mode switch signal		R				T						
A/T fluid temperature sensor signal		T				R						
ICC operation signal	R	R		T								
ICC OD cancel request signal	R	R		T								
ICC sensor signal			T	R								
ICC system display signal				T		R						
ICC steering switch signal	T			R								

TYPE 3

System diagram

- Type3



PKIA8174E

CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T									
Stop lamp switch signal		R		T		R					
Parking brake switch signal				T		R					
Battery voltage signal	T	R									
Key switch signal			R			T					
Ignition switch signal			R			T					R
P range signal		T	R								
Closed throttle position signal	T	R									
Wide open throttle position signal	T	R									
Engine speed signal	T	R		R	R				R	R	
Engine status signal	T					R		R			
Engine coolant temperature signal	T	R		R				R			
Accelerator pedal position signal	T	R							R	R	
Fuel consumption monitor signal	T			R							
				T	R						
Turbine revolution signal	R	T									
Output shaft revolution signal	R	T							R		
A/C switch signal	R					T					
A/C compressor request signal	T							R			R
Blower fan motor switch signal	R					T		R			
A/C switch/indicator signal					T			R			
					R			T			
Cooling fan speed request signal	T							R			R
Position light request signal				R		T					R
Low beam request signal						T					R
Low beam status signal	R										T
High beam request signal				R		T					R
High beam status signal	R										T
Front fog light request signal						T					R
Day time running light request signal						T					R
Vehicle speed signal				R				R	R	T	
	R	R	R	T	R	R		R			
Sleep wake up signal				R		T					R
Door switch signal			R	R	R	T					R
Turn indicator signal				R		T					
Key fob ID signal			R			T					
Key fob door unlock signal			R			T					

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Buzzer output signal				R		T					
Fuel level sensor signal	R			T							
ASCD SET lamp signal	T			R							
ASCD CRUISE lamp signal	T			R							
Malfunction indicator lamp signal	T			R							
Fuel level low warning signal				T	R						
Front wiper request signal						T					R
Front wiper stop position signal						R					T
Rear window defogger switch signal						T		R			R
Rear window defogger control signal	R				R			R			T
Hood switch signal						R					T
Theft warning horn request signal						T					R
Horn chirp signal						T					R
Steering angle sensor signal							T			R	
ABS warning lamp signal				R						T	
VDC OFF indicator lamp signal				R						T	
SLIP indicator lamp signal				R						T	
Brake warning lamp signal				R						T	
System setting signal			R		T						
			T		R						
Distance to empty signal				T	R						
ASCD operation signal	T	R									
ASCD OD cancel request	T	R									
A/T CHECK indicator lamp signal		T		R							
A/T position indicator lamp signal		T		R					R		
Tire pressure signal				R		T					
Tire pressure data signal					R	T					
1st position switch signal		R		T							
4th position switch signal		R		T							
Tow mode switch signal		R		T							
A/T fluid temperature sensor signal		T		R							


CAN COMMUNICATION

[CAN]

TYPE 4

System diagram

- Type4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T											
Stop lamp switch signal		R				T		R					
Parking brake switch signal						T							R
Battery voltage signal	T	R											
Key switch signal					R			T					
Ignition switch signal					R			T					R
P range signal		T		R	R								
Closed throttle position signal	T	R		R									
Wide open throttle position signal	T	R											
Engine speed signal	T	R		R		R	R				R	R	
Engine status signal	T							R		R			
Engine coolant temperature signal	T	R				R				R			
Accelerator pedal position signal	T	R		R							R	R	
Fuel consumption monitor signal	T					R							
						T	R						
Turbine revolution signal	R	T		R									
Output shaft revolution signal	R	T		R							R		
A/C switch signal	R							T					
A/C compressor request signal	T									R			R
Blower fan motor switch signal	R							T		R			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPM E/R
A/C switch/indicator signal							T			R			
							R			T			
Cooling fan speed request signal	T									R			R
Position light request signal						R		T					R
Low beam request signal								T					R
Low beam status signal	R												T
High beam request signal						R		T					R
High beam status signal	R												T
Front fog light request signal								T					R
Day time running light request signal								T					R
Vehicle speed signal						R				R	R	T	
	R	R	R		R	T	R	R		R			
Sleep wake up signal						R		T					R
Door switch signal					R	R	R	T					R
Turn indicator signal						R		T					
Key fob ID signal					R			T					
Key fob door unlock signal					R			T					
Buzzer output signal						R		T					
				T		R							
Fuel level sensor signal	R					T							
Malfunction indicator lamp signal	T					R							
Fuel level low warning signal						T	R						
Front wiper request signal				R				T					R
Front wiper stop position signal								R					T
Rear window defogger switch signal								T		R			R
Rear window defogger control signal	R						R			R			T
Hood switch signal								R					T
Theft warning horn request signal								T					R
Horn chirp signal								T					R
Steering angle sensor signal									T			R	
ABS warning lamp signal						R						T	
VDC OFF indicator lamp signal				R		R						T	
SLIP indicator lamp signal						R						T	
Brake warning lamp signal						R						T	
VDC operation signal				R								T	
ABS malfunction signal				R								T	

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ICC sensor	ICC unit	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPD M E/R
TCS malfunction signal				R								T	
VDC malfunction signal				R								T	
Brake pressure sensor signal				R								T	
System setting signal					R		T						
					T		R						
Distance to empty signal						T	R						
ASCD operation signal	T	R											
ASCD OD cancel request	T	R											
A/T CHECK indicator lamp signal		T				R							
A/T position indicator lamp signal		T		R		R					R		
Current gear position signal		T		R									
Tire pressure signal						R		T					
Tire pressure data signal							R	T					
1st position switch signal		R				T							
4th position switch signal		R				T							
Tow mode switch signal		R				T							
A/T fluid temperature sensor signal		T				R							
ICC operation signal	R	R		T									
ICC OD cancel request signal	R	R		T									
ICC sensor signal			T	R									
ICC system display signal				T		R							
ICC steering switch signal	T			R									

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

UKS000P0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000P1




BKIA0118E

CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS000P2



A

B

C

D

E

F

G

H

I

J

LAN

L

M

BKWA0078E

CAN SYSTEM (TYPE 1)



[CAN]

UKS000P3

Wiring Diagram - CAN -

LAN-CAN-01

— : DATA LINE



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)


(E16) - ELECTRICAL UNITS

BKWA0079E

CAN SYSTEM (TYPE 1)


[CAN]

LAN-CAN-02






A
B
C
D
E
F
G
H
I
J
L
M

LAN



BKWA0080E

▬ : DATA LINE




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0081E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-23, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG" or "UNKWN" in the check sheet table. Refer to [LAN-23, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-131, "CAN Communication Line Check"](#) .

- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-23, "CHECK SHEET"](#) .

A
B
C
D
E
F
G
H
I
J
L
M



CAN SYSTEM (TYPE 1)

[CAN]

-
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-23, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-131, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-25, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

PKIA8048E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8049E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-40, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—

PKIA8050E



CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-41, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—

PKIA8051E




Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-42, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	—	UNKW	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	UNKW
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—

PKIA8052E



CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-43, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—

PKIA8053E



PKIA8145E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-43, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8054E



CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-44, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA8055E



PKIA8147E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-44, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5 ✓	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8056E



CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check display control unit circuit. Refer to [LAN-45, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN ✓/R 1	CAN ✓/R 3	—	CAN ✓/R 5	CAN ✓/R 2	—	CAN ✓/R 4	—	CAN ✓/R 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8057E



CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-45, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA8058E



CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-46, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA8059E



CAN SYSTEM (TYPE 1)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-46, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8060E



CAN SYSTEM (TYPE 1)


[CAN]

Case 12

Check front air control circuit. Refer to [LAN-47, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8061E




PKIA8153E

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-47, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8062E



CAN SYSTEM (TYPE 1)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-48, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8063E



CAN SYSTEM (TYPE 1)

[CAN]

Case 15

Check CAN communication circuit. Refer to [LAN-48, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	—
AUTO DRIVE POS.	No indication ✓	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓
BCM	No indication ✓	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG ✓	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—
IPDM E/R	No indication ✓	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA8064E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-49, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA8065E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-49, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA8066E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0018I

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).

24 (W) - 3 (W) : Continuity should exist.
23 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-21, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0018J

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-21, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS0018K

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-21, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and data link connector.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-21, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E125.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-49, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


UKS0018X

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

UKS0018Y

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 2)

PFP:23710


System Description

UKS001N3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS001N4




CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS001N5



A

B

C

D

E

F

G

H

I

J

LAN

L



M

BKWA0074E

Wiring Diagram - CAN -

LAN-CAN-04

— : DATA LINE





REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE JUNCTION (SMJ)
 (E16) - ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

CAN SYSTEM (TYPE 2)




[CAN]

LAN-CAN-05



BKWA0076E

▬ : DATA LINE




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0077E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ICC", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ICC", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG" or "UNKWN" in the check sheet table. Refer to [LAN-57, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-131, "CAN Communication Line Check"](#) .

- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

-
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-57, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-131, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-59, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ICC
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
ICC
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA8088E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and ICC sensor. Refer to [LAN-78, "Circuit Check Between TCM and ICC Sensor"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8089E



CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between ICC sensor and ICC unit. Refer to [LAN-79, "Circuit Check Between ICC Sensor and ICC Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8090E




PKIA8801E

Case 3

Check harness between ICC unit and driver seat control unit. Refer to [LAN-80, "Circuit Check Between ICC Unit and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	✓	—	—	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	✓	—	—	—	✓	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	✓	—	—	✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	—	UNKWN	—	—	—	—

PKIA8091E



CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check harness between driver seat control unit and data link connector. Refer to [LAN-80, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8092E




PKIA8803E

Case 5

Check harness between data link connector and IPDM E/R. Refer to [LAN-81, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8093E



CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check ECM circuit. Refer to [LAN-82. "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8094E



PKIA8805E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check TCM circuit. Refer to [LAN-82, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8095E



CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check ICC sensor circuit. Refer to [LAN-83, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8096E



PKIA8807E

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check ICC unit circuit. Refer to [LAN-83, "ICC Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8097E



CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check driver seat control unit circuit. Refer to [LAN-84, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8098E



PKIA8809E

CAN SYSTEM (TYPE 2)


[CAN]

Case 11

Check combination meter circuit. Refer to [LAN-84, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	✓	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	✓	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	✓	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—

PKIA8099E



CAN SYSTEM (TYPE 2)


[CAN]

Case 12

Check display control unit circuit. Refer to [LAN-85, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	—	—	CAN CRC 5 ✓	CAN CRC 2 ✓	—	CAN CRC 4 ✓	—	CAN CRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8100E



PKIA8811E

CAN SYSTEM (TYPE 2)


[CAN]

Case 13

Check BCM circuit. Refer to [LAN-85, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8101E



CAN SYSTEM (TYPE 2)


[CAN]

Case 14

Check data link connector circuit. Refer to [LAN-86, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8102E



PKIA8813E

CAN SYSTEM (TYPE 2)


[CAN]

Case 15

Check steering angle sensor circuit. Refer to [LAN-86. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8103E



CAN SYSTEM (TYPE 2)


[CAN]

Case 16

Check front air control circuit. Refer to [LAN-87, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8104E



PKIA8815E

CAN SYSTEM (TYPE 2)


[CAN]

Case 17

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-87, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8105E



PKIA8816E

CAN SYSTEM (TYPE 2)


[CAN]

Case 18

Check IPDM E/R circuit. Refer to [LAN-88, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8106E



CAN SYSTEM (TYPE 2)

[CAN]

Case 19

Check CAN communication circuit. Refer to [LAN-88, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	UNKW N	—
ICC	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—	—

PKIA8107E

Case 20

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-89, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	UNKW N	—
ICC	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—	—

PKIA8108E

Case 21

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-89, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIA8109E

Circuit Check Between TCM and ICC Sensor

UKS001N8

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).

3 (W) - 12 (W) : Continuity should exist.
8 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and ICC sensor connector E42 terminals 2 (W), 3 (R).

12 (W) - 2 (W) : Continuity should exist.
11 (R) - 3 (R) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#) .
 NG >> Repair harness.



UKS001PO

Circuit Check Between ICC Sensor and ICC Unit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector and harness connector E34.
2. Check continuity between ICC sensor connector E42 terminals 2 (W), 3 (R) and harness connector E34 terminals 24 (W), 23 (R).

2 (W) - 24 (W) : Continuity should exist.
3 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



PKIA8137E


3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and ICC unit connector B13 terminals 14 (W), 5 (R).

24 (W) - 14 (W) : Continuity should exist.
23 (R) - 5 (R) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#) .
 NG >> Repair harness.



PKIA8138E

Circuit Check Between ICC Unit and Driver Seat Control Unit

1. CHECK CONNECTOR


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ICC unit connector and driver seat control unit connector.
4. Check continuity between ICC unit connector B13 terminals 14 (W), 5 (R) and driver seat control unit connector P2 terminals 3 (W), 19 (R).

14 (W) - 3 (W) : Continuity should exist.

5 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.

19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS001NA

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-55, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
LAN
L
M

ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



PKIA0816E

TCM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F33.



SKIA6866E

ICC Sensor Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E42 terminals 2 (W) and 3 (R).

2 (W) - 3 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC sensor.
 NG >> Repair harness between ICC sensor and harness connector E34.

**ICC Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector B13 terminals 14 (W) and 5 (R).

14 (W) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC unit.
 NG >> Repair harness between ICC unit and harness connector B69.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and data link connector.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-55, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



UKS001NI

Steering Angle Sensor Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



PKIA6838E

Front Air Control Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E125.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - ICC sensor
 - ICC unit
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-89, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

**Component Inspection
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

PFP:23710


System Description

UKS000QY

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000QZ




CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS000R0



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0001E





CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08



BKWA0072E



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0073E


CAN SYSTEM (TYPE 3)

[CAN]


UKS0019V

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-97, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG" or "UNKWN" in the check sheet table. Refer to [LAN-97, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-131, "CAN Communication Line Check"](#) .
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-97, "CHECK SHEET"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]

-
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-97, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-131, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-99, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

PKIA8067E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

PKIA8068E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-115, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UN KN W N	UN KN W N	—	—	—	UN KN W N	UN KN W N	UN KN W N
A/T	—	NG	UNKWN	UNKWN	—	UN KN W N	—	—	—	—	UN KN W N	UN KN W N	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN KN W N	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UN KN W N	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UN KN W N	UN KN W N	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UN KN W N	UN KN W N	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UN KN W N	—	—	UNKWN	—	—	—	—	—	

PKIA8069E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-116, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	—	—	UNKWN	✓	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	UNKWN	✓	✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	—	—	—

PKIA8070E



PKIA8157E

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-117, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN ✓	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA8071E



CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-118, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	—

PKIA8072E



CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-118, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA8073E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-119, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA8074E



PKIA8161E

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-119, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA8075E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check display control unit circuit. Refer to [LAN-120, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	CAN CRC 5 ✓	CAN CRC 2 ✓	—	CAN CRC 4 ✓	—	—	CAN CRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA8076E



PKIA8163E

CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-120, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA8077E



CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-121, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA8078E



CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-121, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA8079E



CAN SYSTEM (TYPE 3)


[CAN]

Case 12

Check front air control circuit. Refer to [LAN-122, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA8080E



PKIA8167E

CAN SYSTEM (TYPE 3)


[CAN]

Case 13

Check transfer control unit circuit. Refer to [LAN-122, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA8081E



CAN SYSTEM (TYPE 3)


[CAN]

Case 14

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-123, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA8082E



CAN SYSTEM (TYPE 3)


[CAN]

Case 15

Check IPDM E/R circuit. Refer to [LAN-123, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA8083E



CAN SYSTEM (TYPE 3)

[CAN]

Case 16

Check CAN communication circuit. Refer to [LAN-124, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	—	—

PKIA8084E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-124, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	—	—

PKIA8085E

Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-124, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER/M&A	BCM/SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA8086E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0019W

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).

24 (W) - 3 (W) : Continuity should exist.
23 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-95, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0019X

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-95, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS0019Y

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-95, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and data link connector.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-95, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



Transfer Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (W) and 8 (R).

7 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
- NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness between IPDM E/R and harness connector E152.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-125, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
 NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


UKS001AD

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

PFP:23710


System Description

UKS001NP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS001NQ




BKIA0121E

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS001NR



A

B

C

D

E

F

G

H

I

J

LAN

L




M

BKWA0067E

Wiring Diagram - CAN -

LAN-CAN-10

— : DATA LINE



REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)


(E16) - ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

CAN SYSTEM (TYPE 4)


[CAN]

LAN-CAN-11







A
B
C
D
E
F
G
H
I
J
K
L
M

LAN



BKWA0069E



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0070E


CAN SYSTEM (TYPE 4)

[CAN]


UKS001NT

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ICC", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ICC", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-133, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG" or "UNKWN" in the check sheet table. Refer to [LAN-133, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-131, "CAN Communication Line Check"](#) .
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-133, "CHECK SHEET"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

-
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-133, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-131, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-135, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

PKIA8110E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of ICC SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS
Attach copy of BCM SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of ICC CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR
Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

PKIA8111E

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and ICC sensor. Refer to [LAN-155, "Circuit Check Between TCM and ICC Sensor"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8112E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between ICC sensor and ICC unit. Refer to [LAN-156, "Circuit Check Between ICC Sensor and ICC Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	✓	✓	✓	—	—	✓	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	—	—	—	✓	✓	—
ICC	—	NG	UNKWN	✓	✓	✓	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	✓	✓	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8113E




PKIA8819E

Case 3

Check harness between ICC unit and driver seat control unit. Refer to [LAN-157, "Circuit Check Between ICC Unit and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	✓	—	—	✓	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	✓	—	—	—	✓	✓	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	✓	—	—	—	✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8114E



CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check harness between driver seat control unit and data link connector. Refer to [LAN-157, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8115E




PKIA8821E

Case 5

Check harness between data link connector and IPDM E/R. Refer to [LAN-158, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8116E



CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check ECM circuit. Refer to [LAN-159, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8117E



CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check TCM circuit. Refer to [LAN-159, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8118E



CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check ICC sensor circuit. Refer to [LAN-160, "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8119E



PKIA8825E

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check ICC unit circuit. Refer to [LAN-160, "ICC Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8120E



CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check driver seat control unit circuit. Refer to [LAN-161, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8121E



CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check combination meter circuit. Refer to [LAN-161, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	

PKIA8122E



CAN SYSTEM (TYPE 4)


[CAN]

Case 12

Check display control unit circuit. Refer to [LAN-162, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	—	—	CAN CRC 5 ✓	CAN CRC 2 ✓	—	CAN CRC 4 ✓	—	—	—	CAN CRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8123E



PKIA8829E

CAN SYSTEM (TYPE 4)


[CAN]

Case 13

Check BCM circuit. Refer to [LAN-162, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8124E




Case 14

Check data link connector circuit. Refer to [LAN-163, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8125E




Case 15

Check steering angle sensor circuit. Refer to [LAN-163. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8126E




Case 16

Check front air control circuit. Refer to [LAN-164, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8127E




Case 17

Check transfer control unit circuit. Refer to [LAN-164, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN ✓	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	—	—	UNKWN ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8128E



CAN SYSTEM (TYPE 4)


[CAN]

Case 18

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-165, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIA8129E



PKIA8835E

CAN SYSTEM (TYPE 4)


[CAN]

Case 19

Check IPDM E/R circuit. Refer to [LAN-165, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8130E



CAN SYSTEM (TYPE 4)

[CAN]

Case 20

Check CAN communication circuit. Refer to [LAN-166, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—	UNKW N	UNKW N	—
ICC	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—	—	—	—

PKIA8131E

Case 21

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—	UNKW N	UNKW N	—
ICC	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—	UNKW N	—	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	—	UNKW N	—	—	—	—	—	—

PKIA8132E

Case 22

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	ICC SENSOR	ICC /e4WD	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	—	✓	✓	—	—	—	✓	UNKWN	—
ICC	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	—	—	✓	—	✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIA8133E

Circuit Check Between TCM and ICC Sensor

UKS001NU

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).

3 (W) - 12 (W) : Continuity should exist.
8 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and ICC sensor connector E42 terminals 2 (W), 3 (R).

12 (W) - 2 (W) : Continuity should exist.
11 (R) - 3 (R) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#) .
 NG >> Repair harness.



PKIA8171E

UKS001PS

Circuit Check Between ICC Sensor and ICC Unit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector and harness connector E34.
2. Check continuity between ICC sensor connector E42 terminals 2 (W), 3 (R) and harness connector E34 terminals 24 (W), 23 (R).

2 (W) - 24 (W) : Continuity should exist.
3 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



PKIA8137E


3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and ICC unit connector B13 terminals 14 (W), 5 (R).

24 (W) - 14 (W) : Continuity should exist.
23 (R) - 5 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#) .
 NG >> Repair harness.



PKIA8138E

Circuit Check Between ICC Unit and Driver Seat Control Unit


1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ICC unit connector and driver seat control unit connector.
4. Check continuity between ICC unit connector B13 terminals 14 (W), 5 (R) and driver seat control unit connector P2 terminals 3 (W), 19 (R).

14 (W) - 3 (W) : Continuity should exist.
5 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#) .
- NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS001NW

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F33.



ICC Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E42 terminals 2 (W) and 3 (R).

2 (W) - 3 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC sensor.
 NG >> Repair harness between ICC sensor and harness connector E34.



ICC Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ICC unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector B13 terminals 14 (W) and 5 (R).

14 (W) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ICC unit.
 NG >> Repair harness between ICC unit and harness connector B69.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
NG >> Repair harness between display control unit and data link connector.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-131, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



Transfer Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (W) and 8 (R).

7 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - ICC sensor
 - ICC unit
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-167, "ECM/ IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
 NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .

- Ignition power supply circuit. Refer to [PG-13. "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

UKS0010B

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

