

SECTION **RSU**
 REAR SUSPENSION

A
 B
 C
 D

RSU

CONTENTS

PRECAUTIONS	3	Circuit Inspection	20	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	TRUBLE DIAGNOSES FOR SYMPTOMS	23	
Precautions for Rear Suspension	3	Load Leveling Rear Air Suspension System Does Not Operate	23	G
Wiring Diagrams and Trouble Diagnosis	3	CK SUSP Indicator Lamp Stays On When Ignition Switch Is Turned On	24	H
PREPARATION	4	REAR SUSPENSION ASSEMBLY	25	
Commercial Service Tools	4	Components	25	H
NOISE, VIBRATION, AND HARSHNESS (NVH)		On-Vehicle Inspection and Service	26	I
TROUBLESHOOTING	5	SHOCK ABSORBER INSPECTION	26	I
NVH Troubleshooting Chart	5	Wheel Alignment Inspection	27	J
CAN COMMUNICATION	6	PRELIMINARY INSPECTION	27	J
System Description	6	GENERAL INFORMATION AND RECOMMENDATIONS	27	J
TROUBLE DIAGNOSIS	7	THE ALIGNMENT PROCESS	28	K
How to Perform Trouble Diagnoses for Quick and Accurate Repair	7	CAMBER	28	K
INTRODUCTION	7	TOE-IN	28	K
CLARIFY CONCERN	7	REAR SUSPENSION MEMBER	30	
WORK FLOW	8	Removal and Installation	30	L
Component Parts and Harness Connector Location	9	REMOVAL	31	L
Wiring Diagram — A/SUSP —	10	INSPECTION AFTER REMOVAL	32	L
Basic Inspection	12	INSTALLATION	33	M
AIR HOSES	12	SHOCK ABSORBER	34	
POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION	12	Removal and Installation	34	M
CK SUSP INDICATOR LAMP INSPECTION	12	REMOVAL	34	
CK SUSP Indicator Lamp Timing	12	INSTALLATION	34	
Control Unit Input/Output Signal Standard	12	INSPECTION AFTER INSTALLATION	34	
CONSULT-II Function (AIR LEVELIZER)	13	SUSPENSION ARM	35	
CONSULT-II OPERATION	13	Removal and Installation	35	
WORK SUPPORT	14	REMOVAL	35	
SELF-DIAGNOSIS	14	INSPECTION AFTER REMOVAL	35	
DATA MONITOR	15	INSTALLATION	36	
ACTIVE TEST	16	FRONT LOWER LINK	37	
TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS	17	Removal and Installation	37	
Height Sensor System Inspection	17	REMOVAL	37	
Exhaust Valve Solenoid System Inspection	19	INSPECTION AFTER REMOVAL	37	
Compressor Motor, Compressor Motor Relay and		INSTALLATION	38	

REAR LOWER LINK & COIL SPRING	39	HEIGHT SENSOR	44
Removal and Installation	39	Removal and Installation	44
REMOVAL	39	REMOVAL	44
INSPECTION AFTER REMOVAL	40	INSTALLATION	45
INSTALLATION	40	CONTROL UNIT	46
STABILIZER BAR	41	Removal and Installation	46
Removal and Installation	41	REMOVAL	46
REMOVAL	41	INSTALLATION	46
INSTALLATION	41	Initialization Procedure	46
Inspection	41	SERVICE DATA AND SPECIFICATIONS (SDS)	47
REAR LOAD LEVELING AIR SUSPENSION COM-		Wheel Alignment	47
PRESSOR ASSEMBLY	42	Ball Joint	47
Removal and Installation	42	Wheelarch Height (Unladen* ¹)	48
REMOVAL	42		
INSTALLATION	43		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EES0010X

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Rear Suspension

EES0010Y

- When installing the rubber bushings, the final tightening must be done under unladen condition and with the tires on level ground. Oil will shorten the life of the rubber bushings, so wipe off any spilled oil immediately.
- Unladen condition means the fuel tank, engine coolant and lubricants are at the full specification. The spare tire, jack, hand tools, and mats are in their designated positions.
- After installing suspension components, check the wheel alignment.
- Caulking nuts are not reusable. Always use new caulking nuts for installation. New caulking nuts are pre-oiled, do not apply any additional lubrication.

Wiring Diagrams and Trouble Diagnosis

EES0010Z

When you read wiring diagrams, refer to the following:

- [GI-15, "How to Read Wiring Diagrams"](#).
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- [GI-11, "How to Follow Trouble Diagnoses"](#).
- [GI-27, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).


PREPARATION

PREPARATION

PF0:00002

Commercial Service Tools

EES00110

Tool name	Description
<p>Power tool</p>  <p>PBIC0190E</p>	<ul style="list-style-type: none">● Removing wheel nuts● Removing brake caliper assembly● Removing rear suspension component parts

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PF0:0003

NVH Troubleshooting Chart

EES00111

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS										Reference page						
		Improper installation, looseness	Shock absorber deformation, damage or deflection	Bushing or mounting deterioration	Parts interference	Spring fatigue	Suspension looseness	Incorrect wheel alignment	Stabilizer bar fatigue	PROPELLER SHAFT	DIFFERENTIAL		FRONT AXLE AND FRONT SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	Noise	x	x	x	x	x	x			x	x	x	x	x	x	x		RSU-25
	Shake	x	x	x	x		x			x		x	x	x	x	x		RSU-34
	Vibration	x	x	x	x	x				x		x		x				—
	Shimmy	x	x	x	x			x				x	x			x	x	—
	Shudder	x	x	x								x	x	x			x	RSU-25
	Poor quality ride or handling	x	x	x	x	x		x	x				x	x				RSU-27
																		RSU-41
																		PR-3, "NVH Troubleshooting Chart"
																		RFD-5, "NVH Troubleshooting Chart"
																		FAX-4, "NVH Troubleshooting Chart" (FAX) FSU-4, "NVH Troubleshooting Chart" (FSU)
																		WT-3, "NVH Troubleshooting Chart"
																		WT-3, "NVH Troubleshooting Chart"
																		RAX-4, "NVH Troubleshooting Chart"
																		PS-5, "NVH Troubleshooting Chart"
																		BR-5, "NVH Troubleshooting Chart"

x: Applicable

A
B
C
D
RSU
F
G
H
I
J
K
L
M

CAN COMMUNICATION

CAN COMMUNICATION

PF2:23710

System Description

EES00112

Refer to [LAN-5, "CAN COMMUNICATION"](#) .

TROUBLE DIAGNOSIS


How to Perform Trouble Diagnoses for Quick and Accurate Repair

EES00113

INTRODUCTION


The rear load leveling air suspension system uses an electronic control unit to control major functions. The control unit accepts input signals from the height sensor and controls compressor and exhaust valve operation.

It is much more difficult to diagnose a rear load leveling air suspension system problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electrical connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.



Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with an air suspension system complaint. The customer is a very good source of information on such problems, especially intermittent ones. Through discussion with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for basic mechanical problems first. This is one of the best ways to troubleshoot concerns on an air suspension system equipped vehicle. Also check related Service Bulletins for information.



CLARIFY CONCERN

- A customer's description of a vehicle concern may vary depending on the individual. It is important to clarify the customer's concern.
- Ask the customer about what symptoms are present under what conditions. Use this information to reproduce the symptom.

KEY POINTS


- WHAT** Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SBR339B

A
B
C
D
RSU
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

WORK FLOW




WEIA0077E

TROUBLE DIAGNOSIS

Component Parts and Harness Connector Location

EES00114

A
B
C
D
RSU
F
G
H
I
J
K
L
M



<p>Fuse block (J/B) fuse layout</p> <p>10A 19</p> <p>10A 14</p> <p>10A 12</p>	<p>Fuse and fusible link box</p> <p>Front</p> <p>24 25 26 27</p> <p>20A 15A 10A 20A</p> <p>f g h i</p> <p>50A 30A 30A 40A</p> <p>2</p> <p>1 3</p> <p>H-1</p> <p>j k l m</p> <p>30A 40A 40A 40A</p> <p>28 29 30 31</p> <p>15A 10A 10A 20A</p> <p>24 - 31: FUSE f - m: FUSIBLE LINK</p>	<p>Suspension control unit (B3)</p>
<p>Front</p> <p>Suspension air compressor and compressor motor relay (C9, E130, E131)</p>	<p>Height sensor (C8)</p>	<p>Combination meter (M24)</p>
<p>View from under vehicle</p> <p>Front</p> <p>Generator (E205)</p>		



WEIA0140E

TROUBLE DIAGNOSIS

Wiring Diagram — A/SUSP —

EES00115

RSU-A/SUSP-01




REFER TO THE FOLLOWING.
 (M40), (C1) - SUPER MULTIPLE JUNCTION (SMJ)


WEWA0024E

TROUBLE DIAGNOSIS

RSU-A/SUSP-02



A
B
C
D
RSU
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (M31), (M40), (C1) - SUPER MULTIPLE JUNCTION (SMJ)

WEWA0042E

TROUBLE DIAGNOSIS

Basic Inspection

EES00116

AIR HOSES

1. Check for pinched or damaged air hoses between the suspension air reservoir and each load leveling rear air suspension shock absorber. Reposition, repair or replace hoses as necessary.
2. Check the air hose connections at the suspension air reservoir and at the shock absorbers for leaks. If connections are leaking, repair or replace hoses as necessary.

POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION

Make sure the battery positive cable, negative cable and ground connection are not loose. In addition, make sure the battery is sufficiently charged.

CK SUSP INDICATOR LAMP INSPECTION

1. Make sure the CK SUSP indicator lamp turns on for approximately 2 seconds when the ignition switch is turned ON. If it does not, check the combination meter. Refer to [DI-5, "COMBINATION METERS"](#) .
2. Make sure the lamp turns off approximately 2 seconds after the ignition switch is turned ON. If the lamp does not turn off, conduct self-diagnosis of the suspension control unit.
3. After conducting the self-diagnosis, be sure to erase the error memory. Refer to [RSU-13, "CONSULT-II Function \(AIR LEVELIZER\)"](#) .

CK SUSP Indicator Lamp Timing

EES00117

Condition	CK SUSP indicator lamp	Remarks
Ignition switch OFF	—	—
Ignition switch ON	X	Turns off after approximately 2 seconds.

X: ON

—: OFF

Control Unit Input/Output Signal Standard

EES00118

Terminal		Item	Condition	Voltage (V) (Approx.)
+	—			
1 (V)	Ground	Compressor relay output	Ignition switch ON or START	Battery voltage
3 (W)		Height sensor signal input		0.2V - 4.8V
5 (R)		Reference voltage		5V
6 (G/R)		Ignition power	—	Battery voltage
7 (W/L)		Battery power		
8 (G/W)		Diagnostic K-line	—	—
9 (SB)		Exhaust valve output	Ignition switch ON or START	Battery voltage
10 (BR)		Warning lamp output	—	—
14 (L)		Height sensor ground	—	—
15 (BR/W)		Alternator L signal input	Engine running	—
16 (B)		Suspension control unit ground	—	0V

(): Wire color

TROUBLE DIAGNOSIS

CONSULT-II Function (AIR LEVELIZER)

EES00119

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


AIR LEVELIZER diagnostic mode	Description
WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the suspension control unit for setting the status suitable for required operation, input/output signals are received from the suspension control unit and received data is displayed.
SELF-DIAG RESULTS	Displays suspension control unit self-diagnosis results.
DATA MONITOR	Displays suspension control unit input/output data in real time.
ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
ECU PART NUMBER	Suspension control unit part number can be read.

CONSULT-II OPERATION


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.
3. Turn ignition switch ON.



4. Touch "START (NISSAN BASED VHCL)".




5. Touch "AIR LEVELIZER" on the "SELECT SYSTEM" screen. If "AIR LEVELIZER" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



TROUBLE DIAGNOSIS

6. Select the required operation from the "SELECT DIAG MODE" screen.
For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT

Operation Procedure

1. Touch "AIR LEVELIZER" on "SELECT SYSTEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. The setting will be changed and "ADJUSTMENT COMPLETE" will be displayed.
6. Touch "END".

Display Item List

Item	Description
STANDARD HEIGHT LEVEL	This mode allows the vehicle height to be set to vehicle height specification within tolerance.
ADJUST HEIGHT INI	The initialization value and flag can be set in the suspension control unit in this mode.
CLEAR HEIGHT INI	This mode clears the initialization flag and value in the suspension control unit.

SELF-DIAGNOSIS

Description

If an error is detected in the system, perform self-diagnosis as follows:

Operation Procedure

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.
CAUTION:
If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.
3. Turn ignition switch ON.
4. After stopping the vehicle, with the engine running, touch "START (NISSAN BASED VHCL)", "AIR LEVELIZER", "SELF-DIAG RESULTS" in order on the CONSULT-II screen.
CAUTION:
If "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "AIR LEVELIZER" might not be displayed in the "SELECT SYSTEM" screen. In this case, repeat the operation from step 1.
5. The self-diagnostic results are displayed. (If necessary, the self-diagnostic results can be printed out by touching "COPY".)
 - When "NO DTC IS DETECTED" is displayed, check the CK SUSP indicator lamp.
6. Conduct the appropriate inspection from the display item list, and repair or replace the malfunctioning component.
7. Start and run the vehicle for approximately 1 minute.
8. Turn ignition switch OFF to prepare for erasing the memory.
9. Start the engine and touch "START (NISSAN BASED VHCL)", "AIR LEVELIZER", "SELF-DIAG RESULTS", "ERASE" in order on the CONSULT-II screen to erase the error memory.
If "AIR LEVELIZER" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .

TROUBLE DIAGNOSIS

CAUTION:

If the error memory is not erased, re-conduct the operation from step 7.

- For the final inspection, start and run the vehicle for approximately 1 minute and confirm that the CK SUSP indicator lamp is off.

Display Item List

Self-diagnostic item	Malfunction detecting condition	Check system
Vehicle height sensor [C1801]	Vehicle height sensor voltage is less than 0.2V or greater than 4.8V for more than 60 seconds.	Refer to RSU-17, "Height Sensor System Inspection" .
Compressor relay [C1802]	<ol style="list-style-type: none"> Driving transistor for compressor relay is off and monitor voltage continues high level for more than 10 seconds. Driving transistor for compressor relay is on and monitor voltage continues low level for more than 5 seconds. 	Refer to RSU-20, "Compressor Motor, Compressor Motor Relay and Circuit Inspection" .
Exhaust solenoid [C1803]	<ol style="list-style-type: none"> Driving transistor for exhaust solenoid is off and monitor voltage continues high level for more than 10 seconds. Driving transistor for exhaust solenoid is on and monitor voltage continues low level for more than 5 seconds. 	Refer to RSU-19, "Exhaust Valve Solenoid System Inspection" .
Vehicle height adjusting trouble (compressor) [C1804]	Continuous compressor relay ON time is more than 120 seconds.	Refer to RSU-20, "Compressor Motor, Compressor Motor Relay and Circuit Inspection" .
Vehicle height adjusting trouble (exhaust solenoid) [C1805]	Continuous exhaust solenoid ON time is more than 120 seconds.	Refer to RSU-19, "Exhaust Valve Solenoid System Inspection" .
Vehicle height sensor locking trouble [C1806]	Output sensor voltage variation $\pm 0.02V$ is more than 100 hour when vehicle height range is normal.	Refer to RSU-17, "Height Sensor System Inspection" .
Sensor 5V trouble [C1807]	Sensor reference voltage is less than 0.8V or more than 6V for 20 seconds.	Refer to RSU-17, "Height Sensor System Inspection" .
Integral time trouble by supplying air [C1808]	Integral discontinuous time on the compressor is more than 180 seconds.	Refer to RSU-20, "Compressor Motor, Compressor Motor Relay and Circuit Inspection" .

DATA MONITOR

Operation Procedure

- After turning OFF the ignition switch, connect CONSULT-II and the CONSULT-II CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

- Touch "START (NISSAN BASED VHCL)", "AIR LEVELIZER", "DATA MONITOR" in order on the CONSULT-II screen.
If "AIR LEVELIZER" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .

CAUTION:

When "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "AIR LEVELIZER" might not be displayed in the "SELECT SYSTEM" screen. In this case, repeat the operation from step 2.

- Return to the "SELECT MONITOR ITEM" screen, and touch "ALL SIGNALS" or "SELECTION FROM MENU". Refer to the following information.
- When "START" is touched, the data monitor screen is displayed.

TROUBLE DIAGNOSIS

Display Item List

Test Item	Data monitor item selection	
	ALL SIGNALS	SELECTION FROM MENU
HEIGT SEN	X	X
HEIGT CALC	X	X
SEN FIX TIME	X	X
HEIGT INI VAL	X	X
COMPRESSOR	X	X
EXH SOLENOID	X	X
ACG L	X	X

X: Applicable

–: Not applicable

ACTIVE TEST

CAUTION:

- Do not perform active test while driving.

Operation Procedure

1. Connect the CONSULT-II and CONSULT-II CONVERTER to the data link connector and start the engine.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

2. Touch "START (NISSAN BASED VHCL)" on the display screen.
3. Touch "AIR LEVELIZER".
If "AIR LEVELIZER" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
4. Touch "ACTIVE TEST".
5. The "SELECT TEST ITEM" screen is displayed.
6. Touch necessary test item.
7. With the "MAIN SIGNALS" display highlighted, touch "START".
8. The active test screen will be displayed.

Display Item List

Test Item	Description
COMPRESSOR	OFF/ON
EXHAUST SOLENOID	OFF/ON
WARNING LAMP	OFF/ON

CAUTION:

The "COMPRESSOR" active test will remain ON until it is turned off using CONSULT-II. Allowing the compressor to run for an extended period of time may cause damage to air suspension system components due to excessive pressure in the air suspension system.

NOTE:

- "TEST IS STOPPED" is displayed approximately 10 seconds after operation starts for all active test items except "COMPRESSOR".
- After "TEST IS STOPPED" is displayed, to perform test again, repeat Step 6.

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

PFP:00000

Height Sensor System Inspection

EES0011A

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
C1801
C1806
C1807

Is the above displayed in the self-diagnosis display items?

YES >> GO TO 3.

NO >> GO TO 2.

2. DATA MONITOR CHECK

Conduct data monitor of "HEIGT SEN" to check if the status is normal.

HEIGT SEN	0.2V - 4.8V
-----------	-------------

OK or NG

OK >> Inspection End.

NG >> GO TO 3.

3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect suspension control unit connector B3 and height sensor C8.
3. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace as necessary.

A

B

C

D

RSU

F

G

H

I

J

K

L


M

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

4. CHECK HEIGHT SENSOR POWER AND GROUND

1. Reconnect the suspension control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between height sensor connector C8 terminal 1 (R) and ground.

Voltage : Approx. 5V




4. Turn ignition switch OFF.
5. Check resistance between height sensor connector C8 terminal 3 (L) and ground.

Continuity should exist.

OK or NG


- OK >> GO TO 5.
NG >> Repair the circuit.



5. CHECK HEIGHT SENSOR SIGNAL CIRCUIT

1. Check resistance between height sensor connector C8 terminal 2 (W) and suspension control unit connector B3 terminal 3 (W).

Continuity should exist.




2. Disconnect suspension control unit connector.
3. Check resistance between height sensor connector C8 terminal 2 (W) and ground.

Continuity should not exist.

OK or NG

- OK >> Replace the height sensor. Refer to [RSU-44, "HEIGHT SENSOR"](#) .
NG >> Repair the circuit.



TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

EES0011B

Exhaust Valve Solenoid System Inspection

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
C1803
C1805

Is the above displayed in the self-diagnosis display items?

- YES >> If code C1803 was retrieved during self-diagnosis, GO TO 3. If code C1805 was retrieved during self-diagnosis, GO TO 2.
NO >> Inspection End.

2. CHECK SYSTEM OPERATION

1. Load vehicle to standard laden condition (with driver, front passenger, 2 passengers in second row seats and no cargo).
2. Conduct active test of "COMPRESSOR" to raise vehicle ride height to +20mm.

CAUTION:

The "COMPRESSOR" active test will remain ON until it is turned off using CONSULT-II. Allowing the compressor to run for an extended period of time may cause damage to air suspension system components due to excessive pressure in the air suspension system.

3. Return the rear load leveling air suspension system to normal operating mode.
4. Check self-diagnostic results.

Is code C1805 displayed again?

- YES >> GO TO 3.
NO >> Inspection End.

3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect suspension control unit connector B3 and suspension air compressor C9.
3. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> If code C1805 was retrieved during self-diagnosis, GO TO 4. If code C1803 was retrieved during self-diagnosis, GO TO 6.
NG >> Repair or replace as necessary.

4. AIR HOSE INSPECTION

Inspect for pinched or damaged air hoses between the suspension air reservoir and each load leveling rear air suspension shock absorber.

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace as necessary.

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

5. EXHAUST VALVE SOLENOID INSPECTION


Apply 12V to suspension air compressor C9 terminal 2 and body ground to suspension air compressor C9 terminal 1.

System air pressure should vent.

OK or NG

OK >> GO TO 6.


NG >> Replace the suspension air compressor. Refer to [RSU-42. "REAR LOAD LEVELING AIR SUSPENSION COMPRESSOR ASSEMBLY"](#) .



6. CHECK EXHAUST VALVE SOLENOID POWER AND GROUND

1. Reconnect the suspension control unit connector.
2. Turn the ignition switch ON.
3. Check voltage between suspension air compressor connector C9 terminal 2 (SB) and ground.

Voltage : Approx. 12V




4. Turn ignition switch OFF.
5. Check resistance between suspension air compressor connector C9 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Replace the suspension control unit. Refer to [RSU-46. "CONTROL UNIT"](#) .

NG >> Repair the circuit.



Compressor Motor, Compressor Motor Relay and Circuit Inspection

EES0011C

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
C1802
C1804
C1808

Is the above displayed in the self-diagnosis display items?

YES >> If code C1802 was retrieved during self-diagnosis, GO TO 3. If code C1804 or C1808 was retrieved during self-diagnosis, GO TO 2.

NO >> Inspection End.

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

2. CHECK SYSTEM OPERATION

1. Load vehicle to standard laden condition (with driver, front passenger, 2 passengers in second row seats and no cargo).
2. Conduct active test of "EXHAUST SOLENOID" to lower vehicle ride height to -20mm.
3. Return the rear load leveling air suspension system to normal operating mode.
4. Check self-diagnostic results.

Is code C1804 or C1808 displayed again?

YES >> GO TO 3.

NO >> Inspection End.

3. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect suspension control unit connector B3 and suspension air compressor C9.
3. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> If code C1804 or C1808 was retrieved during self-diagnosis, GO TO 4. If code C1802 was retrieved during self-diagnosis, GO TO 6.

NG >> Repair or replace as necessary.

4. AIR HOSE INSPECTION

Inspect for pinched or damaged air hoses between the suspension air reservoir and each load leveling rear air suspension shock absorber.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace as necessary.

5. SUSPENSION AIR COMPRESSOR INSPECTION


Apply 12V to suspension air compressor C9 terminal 2 and body ground to suspension air compressor C9 terminal 1.

System air pressure should vent.

OK or NG

OK >> GO TO 6.

NG >> Replace the suspension air compressor. Refer to [RSU-42, "REAR LOAD LEVELING AIR SUSPENSION COMPRESSOR ASSEMBLY"](#) .




TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

6. CHECK SUSPENSION AIR COMPRESSOR POWER AND GROUND

1. Turn the ignition switch ON.
2. Check voltage between suspension air compressor connector C9 terminal 2 (SB) and ground.

Voltage : **Approx. 12V**




3. Turn ignition switch OFF.
4. Check resistance between suspension air compressor connector C9 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Replace the suspension control unit. Refer to [RSU-46](#), "[CONTROL UNIT](#)".
- NG >> Repair the circuit.



TROUBLE DIAGNOSES FOR SYMPTOMS

TROUBLE DIAGNOSES FOR SYMPTOMS

PFP:99999

Load Leveling Rear Air Suspension System Does Not Operate

EES0011D

1. CHECK WARNING LAMP ACTIVATION

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [RSU-14, "SELF-DIAGNOSIS"](#) .

2. CHECK FUSES

- Check that the following fuses are not blown.

Unit	Terminals	Signal name	Fuse or Fusible Link
Suspension control unit	6	Ignition switch ON or START	12 (10A)
	7	Battery power	29 (10A)
Compressor motor relay	5		g (30A)
Combination meter	24	Ignition switch ON or START	14 (10A)
	8	Battery power	19 (10A)

OK or NG


OK >> GO TO 3.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

3. CHECK SUSPENSION CONTROL UNIT POWER AND GROUND

- Turn the ignition switch ON.
- Check voltage between suspension control unit connector B3 terminal 6 (G/R) and ground and between suspension control unit connector B3 terminal 7 (W/L) and ground.

Voltage : **Approx. 12V**




- Turn ignition switch OFF.
- Check resistance between suspension control unit connector B3 terminal 16 (B) and ground.

Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair the circuit.



TROUBLE DIAGNOSES FOR SYMPTOMS


4. CHECK GENERATOR SIGNAL INPUT

1. Start the engine.
2. Check voltage between suspension control unit connector B3 terminal 15 (BR/W) and ground.

Voltage : **Approx. 12V**

OK or NG

- OK >> Replace the suspension control unit. Refer to [RSU-46, "CONTROL UNIT"](#) .
- NG >> Repair the circuit.



CK SUSP Indicator Lamp Stays On When Ignition Switch Is Turned On

EES0011E

1. CARRY OUT SELF-DIAGNOSIS

Carry out self-diagnosis. Refer to [RSU-14, "SELF-DIAGNOSIS"](#) .

Are malfunctions detected in self-diagnosis?

- YES >> Refer to [RSU-16, "Display Item List"](#) .
- NO >> Refer to [DI-31, "WARNING LAMPS"](#) .

REAR SUSPENSION ASSEMBLY

REAR SUSPENSION ASSEMBLY


Components

PFP:55020

EES0011F

Rear Suspension

SEC. 431 • 432



N-m (kg-m, in-lb)


N-m (kg-m, ft-lb)

A
B
C
D
RSU
F
G
H
I
J
K
L
M

REAR SUSPENSION ASSEMBLY

- | | | |
|---------------------------|---------------------------|----------------------------|
| 1. Seat belt latch anchor | 2. Stabilizer bar bushing | 3. Stabilizer bar clamp |
| 4. Stabilizer bar | 5. Connecting rod | 6. Front lower link |
| 7. Knuckle | 8. Bushing | 9. Rear lower link |
| 10. Shock absorber | 11. Suspension arm | 12. Lower rubber seat |
| 13. Coil spring | 14. Upper rubber seat | 15. Rear suspension member |
| 16. Spare tire bracket | 17. Bound bumper | |

Rear Load Leveling Air Suspension System



- | | | |
|---|-----------------------|--|
| 1. Rear load leveling air suspension hose, RH | 2. Shock absorber, RH | 3. Height sensor |
| 4. Rear load leveling air suspension hose, LH | 5. Shock absorber, LH | 6. Rear load leveling air suspension compressor assembly |

On-Vehicle Inspection and Service

EES0011G

Check all of the component mountings for any excessive looseness, or back lash. Check the components for any excessive wear, damage, or abnormal conditions. Repair or replace the components as necessary.

SHOCK ABSORBER INSPECTION


- Check the shock absorbers for any air leaks or damage, and replace as necessary.
- Check the hoses for any air leaks or damage, and replace as necessary.

REAR SUSPENSION ASSEMBLY

Wheel Alignment Inspection

EES0011H

Rear Wheel Alignment Adjusting Bolts



1. Rear lower link adjusting bolt, LH
2. Front lower link adjusting bolt, LH
3. Front lower link adjusting bolt, RH
4. Rear lower link adjusting bolt, RH

PRELIMINARY INSPECTION

WARNING:

Always adjust the alignment with the vehicle on a flat surface. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.

NOTE:

If alignment is out of specification, inspect and replace any damaged or worn rear suspension parts before making any adjustments.

1. Check and adjust the wheel alignment with the vehicle under unladen conditions. "Unladen conditions" means that the fuel, coolant, and lubricant are full; and that the spare tire, jack, hand tools and mats are in their designated positions.
2. Check the tires for incorrect air pressure and excessive wear.
3. Check the wheels for runout and damage. Refer to [WT-4, "Inspection"](#) .
4. Check the wheel bearing axial end play.

Axial end play : 0 mm (0 in)

5. Check the shock absorbers. Refer to [RSU-26, "SHOCK ABSORBER INSPECTION"](#) .
6. Check each mounting point of the suspension components for any excessive looseness or damage.
7. Check each link, arm, and the rear suspension member for any damage.
8. Check the vehicle height. Refer to [RSU-48, "Wheelarch Height \(Unladen*¹\)"](#) .
 - Verify the vehicle height using Consult-II memory register 1103 and set to 0 ± 10 mm (0 ± 0.39 in) as necessary.

GENERAL INFORMATION AND RECOMMENDATIONS

1. A Four-Wheel Thrust Alignment should be performed.
 - This type of alignment is recommended for any NISSAN vehicle.
 - The four-wheel "thrust" process helps ensure that the vehicle is properly aligned and the steering wheel is centered.
 - The alignment machine itself should be capable of accepting any NISSAN vehicle.
 - The alignment machine should be checked to ensure that it is level.
2. Make sure the alignment machine is properly calibrated.
 - Your alignment machine should be regularly calibrated in order to give correct information.

REAR SUSPENSION ASSEMBLY

- Check with the manufacturer of your specific alignment machine for their recommended Service/Calibration Schedule.

THE ALIGNMENT PROCESS


IMPORTANT: Use only the alignment specifications listed in this Service Manual. Refer to [RSU-47, "Wheel Alignment"](#) .

1. When displaying the alignment settings, many alignment machines use "indicators": (Green/red, plus or minus, Go/No Go). **Do NOT use these indicators.**
 - The alignment specifications programmed into your alignment machine that operate these indicators may not be correct.
 - This may result in an ERROR.
2. Some newer alignment machines are equipped with an optional "Rolling Compensation" method to "compensate" the sensors (alignment targets or head units). **Do NOT use this "Rolling Compensation" method.**
 - Use the "Jacking Compensation" method. After installing the alignment targets or head units, raise the vehicle and rotate the wheels 1/2 turn both ways.
 - See Instructions in the alignment machine you are using for more information.

CAMBER

1. Measure camber of both the right and left wheels with a suitable alignment gauge and adjust as necessary to specification.

Camber : Refer to [RSU-47, "Wheel Alignment"](#) .



2. If outside of the specified value, adjust the camber using the adjusting bolt in the front lower link.


CAUTION:

After adjusting the camber then check the toe-in.

NOTE:


Camber changes about 5' minutes with each graduation of the adjusting bolt.

3. Tighten the adjusting bolt nuts to specification.



TOE-IN


1. Bounce the rear of the vehicle up and down two to three times to stabilize the vehicle height. Refer to [RSU-48, "Wheelarch Height \(Unladen*1\)"](#) .
2. Push the vehicle straight ahead about 5 m (16 ft).
3. Put a mark on the base line of the tread (rear side) of both of the tires at the same height as the center of the hub. This will be the measuring points.
4. Measure the distance "A" (rear side) across from tire to tire.



REAR SUSPENSION ASSEMBLY

5. Push the vehicle slowly ahead to rotate the wheels 180° degrees (a half turn).
If the wheels are rotated more than 180° degrees (a half turn), then repeat the above steps. Never push the vehicle backward.
6. Measure the distance "B" (front side) across from tire to tire.

Total toe-in : Refer to [RSU-47, "Wheel Alignment"](#) .



7. If the toe-in is outside the specified value, adjust the toe-in using the adjusting bolt in the rear lower link.


CAUTION:

Be sure to adjust equally on RH and LH sides using the adjusting bolt.

NOTE:

Toe changes about 1.5 mm (0.059 in) [one side] with each graduation of the adjusting bolt.

8. Tighten the adjusting bolt nuts to specification.



A
B
C
D
RSU
F
G
H
I
J
K
L
M

REAR SUSPENSION MEMBER

REAR SUSPENSION MEMBER


PFP:55501

Removal and Installation

EES00111

Rear Suspension

SEC. 431 • 432



N·m (kg·m, in·lb)


N·m (kg·m, ft·lb)

WEIA0092E

REAR SUSPENSION MEMBER

- | | | |
|---------------------------|---------------------------|----------------------------|
| 1. Seat belt latch anchor | 2. Stabilizer bar bushing | 3. Stabilizer bar clamp |
| 4. Stabilizer bar | 5. Connecting rod | 6. Front lower link |
| 7. Knuckle | 8. Bushing | 9. Rear lower link |
| 10. Shock absorber | 11. Suspension arm | 12. Lower rubber seat |
| 13. Coil spring | 14. Upper rubber seat | 15. Rear suspension member |
| 16. Spare tire bracket | 17. Bound bumper | |

Rear Load Leveling Air Suspension System



- | | | |
|---|-----------------------|--|
| 1. Rear load leveling air suspension hose, RH | 2. Shock absorber, RH | 3. Height sensor |
| 4. Rear load leveling air suspension hose, LH | 5. Shock absorber, LH | 6. Rear load leveling air suspension compressor assembly (includes the bracket and rubber cover) |

REMOVAL



1. Use the CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
2. Disconnect the electrical connectors for the height sensor and the rear load leveling air suspension compressor assembly.
3. Unclip the rubber cover to access the rear load leveling air suspension compressor assembly.

REAR SUSPENSION MEMBER


4. Disconnect the rear load leveling air suspension hoses at the rear load leveling air suspension compressor assembly.
 - To disconnect the hoses, push in on the lock ring using a suitable tool and pull the hose out.
5. Remove both of the rear wheel and tire assemblies using power tool.
6. Remove the brake caliper without disconnecting the brake hoses, using power tool. Reposition the brake caliper out of the way using a suitable wire. Refer to [BR-28, "Removal and Installation of Brake Caliper Assembly and Disc Rotor"](#) .

CAUTION:

- Do not crimp or stretch the brake hose when repositioning the brake caliper out of the way.
 - Do not press brake pedal while the brake caliper is removed.
7. Remove the spare tire.
 8. Disconnect the two rear ABS sensor electrical connectors.
 9. Remove the two rear drive shafts. Refer to [RAX-7, "Removal and Installation"](#) .
 10. Remove the rear final drive. Refer to [RFD-10, "REAR FINAL DRIVE ASSEMBLY"](#) .
 11. Remove the EVAP canister bolt from the top of the rear suspension member.
 12. Disconnect the parking brake cables from the brackets on the rear suspension member.
 13. Set a suitable jack to support each of the rear lower links and the coil spring tension.



14. Remove both of the rear lower link outer bolts and lower the jack to remove the rear coil springs.
15. Remove the two bolts to disconnect the seat belt latch anchor from the rear suspension member.
16. Disconnect both of the connecting rods from the rear stabilizer bar.
17. Set a suitable jack under the rear suspension member.
18. Remove the six rear suspension member bolts.
19. Slowly lower the jack to remove the rear suspension member, suspension arm, front and rear lower links and stabilizer bar as an assembly.
20. If necessary, remove the suspension arm, spare tire bracket, height sensor, rear load leveling air suspension hoses, stabilizer bar, knuckle, and front and rear lower links from the rear suspension member.



INSPECTION AFTER REMOVAL


Check the rear suspension member for deformation, cracks, and other damage and replace if necessary.

REAR SUSPENSION MEMBER


INSTALLATION

Installation is in the reverse order of removal.


- When raising the rear suspension member assembly, use the locating pins to align the rear suspension member to the vehicle body.



- When installing the upper and lower rubber seats for the rear coil springs, the arrow embossed on the rubber seats must point out toward the wheel and tire assembly.



- To connect the rear load leveling air suspension hoses, the lock ring must be fully seated in the fitting. Insert the hose "B" into the lock ring "A" until the lock ring "A" is touching the hose "B" as shown. Pull on the hose to check that it is securely inserted.



- Perform the final tightening of the nuts and bolts for the links (rubber bushing) under unladen condition with the tires on level ground.
- Check the wheel alignment. Refer to [RSU-47, "Wheel Alignment"](#) .

SHOCK ABSORBER

SHOCK ABSORBER


PFP:56210

Removal and Installation

EES0011J

REMOVAL


1. Remove the wheel and tire assembly using power tool. Refer to [WT-6, "Rotation"](#) .
2. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
3. Remove the four clips and remove the rear fender protector, front.
4. Disconnect the rear load leveling air suspension hose from the shock absorber.
 - To disconnect the hose, push in on the lock ring using a suitable tool and pull the air hose out.



5. Remove the shock absorber upper and lower end bolts using power tool.
6. Remove the shock absorber.

CAUTION:

Do not damage the rubber boot on the shock absorber.



INSTALLATION

Installation is in the reverse order of removal.

- Tighten the shock absorber bolts to specification. Refer to [RSU-25, "Components"](#) .

INSPECTION AFTER INSTALLATION

- Check the shock absorber for any air leaks or damage to the rubber boot.
- Check the shock absorber for smooth operation through a full stroke, both compression and extension.
- Check piston rod for cracks, deformation or other damage and replace if necessary.

SUSPENSION ARM

PFP:55501

SUSPENSION ARM

Removal and Installation


EES0011L

1. Remove the rear suspension member assembly using power tool. Refer to [RSU-30, "Removal and Installation"](#).

NOTE:

It is necessary to remove the rear suspension member to remove the front upper bolt from the suspension arm.

2. Remove the shock absorber upper end bolt.
3. Remove the suspension arm upper nuts and bolts on the suspension member side using power tool.




4. Remove the suspension arm pinch bolt and nut on the knuckle side using power tool.
5. Disconnect the suspension arm from the knuckle using a soft hammer.

CAUTION:

Do not damage the ball joint with the soft hammer.

6. Remove the suspension arm.



INSPECTION AFTER REMOVAL

- Check the suspension arm for damage, cracks, deformation and replace if necessary.
- Check the rubber bushing for damage, cracks and deformation. Replace suspension arm assembly if necessary.
- Before checking, turn the ball joint at least 10 revolutions so that the ball joint is properly broken in.

SUSPENSION ARM

- Check the ball joint. Replace the suspension arm assembly if any of the following conditions exist:
 - Ball stud is worn.
 - Joint is hard to swing.
 - Play in axial direction is excessive.


Swinging force "A" : Refer to [RSU-47, "Ball Joint"](#) .

Turning force "B" : Refer to [RSU-47, "Ball Joint"](#) .

Vertical end play "C" : Refer to [RSU-47, "Ball Joint"](#) .

NOTE:

Measurement point "A" is at the bolt groove of the ball stud.



INSTALLATION

Installation is in the reverse order of removal.

- Tighten the nuts and bolts to specification. Refer to [RSU-25, "Components"](#) .
- Perform the final tightening of the nuts and bolts for the links (rubber bushings) under unladen condition with the tires on level ground.
- Check the wheel alignment. Refer to [RSU-27, "Wheel Alignment Inspection"](#) .

FRONT LOWER LINK

PFP:55110


EES0011N

FRONT LOWER LINK


Removal and Installation

REMOVAL

1. Remove the wheel and tire assembly using power tool.
2. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
3. Remove the shock absorber lower end bolt.
4. Remove the adjusting bolt and nut, and the bolt and nut, from the front lower link and rear suspension member using power tool.



5. Remove the front lower link pinch bolt and nut on the knuckle side using power tool.
 6. Disconnect the front lower link from the knuckle using a soft hammer.
- CAUTION:**
Do not damage the ball joint with the soft hammer.
7. Remove the front lower link.




INSPECTION AFTER REMOVAL

- Check the front lower link and bushing for any deformation, crack, or damage. Replace if necessary.
- Check the rubber bushing for damage, cracks and deformation. Replace the front lower link and bushing if necessary.
- Before checking, turn the ball joint at least 10 revolutions so that the ball joint is properly broken in.
- Check the ball joint. Replace the front lower link if any of the following conditions exist:
 - Ball stud is worn.
 - Joint is hard to swing.
 - Play in axial direction is excessive.

Swinging force "A" : Refer to [RSU-47, "Ball Joint"](#) .

Turning force "B" : Refer to [RSU-47, "Ball Joint"](#) .

Vertical end play "C" : Refer to [RSU-47, "Ball Joint"](#) .



FRONT LOWER LINK

NOTE:

Measurement point “A” is at the bolt groove of the ball stud.

INSTALLATION

Installation is in the reverse order of removal.

- Tighten the nuts and bolts to specification. Refer to [RSU-25, "Components"](#) .
- Perform the final tightening of the front lower link nuts and bolts (with rubber bushings) under unladen condition with tires on level ground.
- Check the wheel alignment. Refer to [RSU-27, "Wheel Alignment Inspection"](#) .

REAR LOWER LINK & COIL SPRING


REAR LOWER LINK & COIL SPRING

PFP:551B0

Removal and Installation

EES0011P


1. Remove the wheel and tire assembly using power tool. Refer to [WT-6, "Rotation"](#) .
2. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
3. For removing the LH rear lower link and coil spring, remove the height sensor arm bracket bolt from the LH rear lower link.




4. Set a suitable jack to relieve the coil spring tension from the rear lower link.

WARNING:


Do not compress the coil spring when setting the jack.



5. Loosen the rear lower link adjusting bolt and nut connected to the rear suspension member, using power tool.



6. Remove the rear lower link bolt and nut from the knuckle using power tool.




7. Slowly lower the suitable jack to release the coil spring tension. Then remove the upper rubber seat, coil spring, and lower rubber seat from the rear lower link.

A
B
C
D
RSU
F
G
H
I
J
K
L
M

REAR LOWER LINK & COIL SPRING

8. Remove the rear lower link adjusting bolt and nut from the rear suspension member using power tool, then remove the rear lower link.




INSPECTION AFTER REMOVAL

Check the coil spring and rubber seats for deformation, cracks, or other damage and replace if necessary.

INSTALLATION

Installation is in the reverse order of removal.

- Tighten the nuts and bolts to specification. Refer to [RSU-25, "Components"](#) .
- When installing the upper and lower rubber seats for the rear coil springs, the arrow embossed on the rubber seats must point out toward the wheel and tire assembly.
- After installing the rear lower link and coil spring, check the wheel alignment and adjust if necessary. Refer to [RSU-27, "Wheel Alignment Inspection"](#) .



STABILIZER BAR


STABILIZER BAR

PFP:56230


Removal and Installation

EES0011R

1. Disconnect the stabilizer bar ends from the connecting rods using power tool.




2. Remove the stabilizer bar clamps using power tool, and remove the stabilizer bar bushings.
3. Remove the stabilizer bar.



INSTALLATION

Installation is in the reverse order of removal.

- Tighten the nuts and bolts to specification. Refer to [RSU-25, "Components"](#) .
- Install the stabilizer bar with the ball joint sockets properly aligned.
- Install the stabilizer bar bushing and clamp so they are positioned inside of the sideslip prevention clamp on the stabilizer bar.



Inspection

EES0011S

- Check stabilizer bar for any deformation, cracks, or damage and replace if necessary.
- Check rubber bushings for deterioration, or cracks and replace if necessary.

REAR LOAD LEVELING AIR SUSPENSION COMPRESSOR ASSEMBLY


REAR LOAD LEVELING AIR SUSPENSION COMPRESSOR ASSEMBLY

FPF:53400

Removal and Installation

EES0011T


Rear Load Leveling Air Suspension System



- | | | |
|---|-----------------------|--|
| 1. Rear load leveling air suspension hose, RH | 2. Shock absorber, RH | 3. Height sensor |
| 4. Rear load leveling air suspension hose, LH | 5. Shock absorber, LH | 6. Rear load leveling air suspension compressor assembly |


REMOVAL

1. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
2. Disconnect the electrical connectors for the rear load leveling air suspension compressor assembly.
3. Unclip the rubber cover to access the rear load leveling air suspension compressor assembly.
4. Disconnect the rear load leveling air suspension hoses at the rear load leveling air suspension compressor assembly.
 - To disconnect the hoses, push in on the lock ring using a suitable tool and pull the hose out.



REAR LOAD LEVELING AIR SUSPENSION COMPRESSOR ASSEMBLY


5. Remove the four bolts that mount the rear load leveling air suspension compressor assembly to the underbody.



INSTALLATION

Installation is in the reverse order of removal.

- To connect the rear load leveling air suspension hoses, the lock ring must be fully seated in the fitting. Insert the hose "B" into the lock ring "A" until the lock ring "A" is touching the hose "B" as shown. Pull on the hose to check that it is securely inserted.



A
B
C
D

RSU

F
G
H
I
J
K
L
M

HEIGHT SENSOR


PFP:53820

HEIGHT SENSOR

Removal and Installation

EES0011U


Rear Load Leveling Air Suspension System



- | | | |
|---|-----------------------|--|
| 1. Rear load leveling air suspension hose, RH | 2. Shock absorber, RH | 3. Height sensor |
| 4. Rear load leveling air suspension hose, LH | 5. Shock absorber, LH | 6. Rear load leveling air suspension compressor assembly |

REMOVAL

1. Use CONSULT-II "EXHAUST SOLENOID" active test to release the air pressure from the rear load leveling air suspension system.
2. Disconnect the electrical connector for the height sensor.
3. Remove the two height sensor bolts and height sensor arm bracket bolt.
4. Remove the height sensor.



HEIGHT SENSOR

INSTALLATION

Installation is in the reverse order of removal.

1. Start the engine.
2. Use CONSULT-II to perform "STANDARD HEIGHT LEVEL" work support function.
3. Using data monitor of CONSULT-II, verify "HEIGT CALC" is at 0 mm.
4. Check the vehicle height. Refer to [RSU-48, "Wheelarch Height \(Unladen*¹\)"](#) . If vehicle height is not within ± 10 mm (0 ± 0.39 in) of the specification, perform the initialization procedure. Refer to [RSU-46, "Initialization Procedure"](#) .

A

B

C

D

RSU

F

G

H

I

J

K

L

M

CONTROL UNIT

CONTROL UNIT


PFP:47850

Removal and Installation

EES0011V

REMOVAL

1. Remove the rear LH interior trim panel. Refer to [EI-34, "BODY SIDE TRIM"](#) .
2. Disconnect the battery negative terminal.
3. Disconnect the suspension control unit electrical connector.
4. Remove the two bolts and remove the suspension control unit.



INSTALLATION

Installation is in the reverse order of removal.

Suspension control unit bolts : 6 N·m (0.6 kg·m, 53 in·lb)

Initialization Procedure

EES0011W

1. If control unit has been replaced, proceed to step 2. If control unit has not been replaced, use CONSULT-II "CLEAR HEIGHT INI" work support function to clear initialization flag and value. The CK SUSP warning lamp should illuminate. Using CONSULT-II "EXHAUST SOLENOID" active test, release the air pressure from the rear load leveling air suspension system.
2. Roll vehicle forward and backward.
3. Use CONSULT-II "ADJUST HEIGHT INI" work support function to set initialization condition.
4. Confirm that CK SUSP warning lamp is OFF.

SERVICE DATA AND SPECIFICATIONS (SDS)


SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

Wheel Alignment

EES0011X


Camber Degree minute (decimal degree)	Minimum	0° 0' (0°)
	Nominal	- 0° 30' (-0.5°)
	Maximum	- 1° 0' (-1.0°)
	Cross camber	0° 45' (0.75°)



Toe-in	Distance (A - B)	Minimum	0 mm (0 in)
		Nominal	3.3 mm (0.130 in)
		Maximum	6.6 mm (0.260 in)
		Cross toe	2 mm (0.079 in)
	Angle (left and right) Degree minute (decimal degree)	Minimum	0° 0' (0°)
		Nominal	0° 7' (0.11°)
		Maximum	0° 14' (0.22°)
		Cross toe	0° 8' (0.14°)

Ball Joint

EES0011Y




Swinging force "A" (measurement point is at the bolt groove of the ball stud)	11.4 - 145.5 N (1.16 - 14.8 kg, 2.56 - 32.7 lb)
Turning torque "B"	0.5 - 6.4 N·m (0.06 - 0.65 kg·m, 5 - 56 in·lb)
Vertical end play "C"	0 mm (0 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

Wheelarch Height (Unladen*¹)

EES0011Z

Unit: mm (in)



LEIA0085E

Suspension type	Air leveling* ²	
	4x2	4x4
Applied model		
Front wheelarch height (Hf)	913 (35.94)	931 (36.65)
Rear wheelarch height (Hr)	912 (35.91)	932 (36.69)

*1: Fuel, engine coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: Verify the vehicle height using Consult-II memory register 1103 and set rear wheelarch height to 0 ± 10 mm (0 ± 0.39 in) as necessary.