

SECTION **BR**

CONTENTS

PRECAUTIONS AND PREPARATION	2	ANTI-LOCK BRAKE SYSTEM	34
Precautions	2	Purpose.....	34
Supplemental Restraint System (SRS) “Air Bag”	2	Operation	34
Brake System	2	System Components.....	35
Commercial Service Tools	3	System Description.....	35
CHECK AND ADJUSTMENT	4	Removal and Installation	36
Checking Brake Fluid Level.....	4	TROUBLE DIAGNOSES	41
Checking Brake Line.....	4	How to Perform Trouble Diagnoses for Quick and Accurate Repair	41
Changing Brake Fluid.....	4	Preliminary Check.....	42
AIR BLEEDING	5	Component Parts and Harness Connector Location.....	43
Bleeding Procedure	5	Schematic	44
BRAKE HYDRAULIC LINE	6	Wiring Diagram –ABS–.....	45
CONTROL VALVE	8	Self-diagnosis.....	49
Proportioning Valve.....	8	CONSULT	52
BRAKE PEDAL AND BRACKET	10	CONSULT Inspection Procedure.....	53
MASTER CYLINDER	11	Ground Circuit Check	58
BRAKE BOOSTER	14	Diagnostic Procedures.....	59
VACUUM HOSE	16	Electrical Components Inspection	76
FRONT DISC BRAKE	17	SERVICE DATA AND SPECIFICATIONS (SDS)	77
REAR DRUM BRAKE	21	General Specifications	77
REAR DISC BRAKE	24	Inspection and Adjustment.....	78
PARKING BRAKE CONTROL	32		

When you read wiring diagrams:

- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
- See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.

When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES” and “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PRECAUTIONS AND PREPARATION




Precautions

SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.



BRAKE SYSTEM



- Use brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean master cylinder parts, disc brake caliper parts or wheel cylinder parts, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of hydraulic system.
- Use flare nut wrench when removing and installing brake tubes.
- Always torque brake lines when installing.

WARNING:

- Clean brakes with a vacuum dust collector to minimize risk of health hazard from powder caused by friction.


PRECAUTIONS AND PREPARATION

Commercial Service Tools

Tool name	Description
<ul style="list-style-type: none"> ① Flare nut crowfoot ② Torque wrench 	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;">  </div> <div style="width: 35%; text-align: right;"> <p>Removing and installing brake tubes</p> </div> </div> <p style="margin-top: 10px;">NT360 a: 10 mm (0.39 in)</p>
<p>Brake fluid pressure gauge</p>	<div style="text-align: center;">  </div> <p style="margin-top: 10px;">NT151</p> <p style="text-align: right; margin-top: 10px;">Measuring brake fluid pressure</p>


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
BR
 ST
 RS
 BT
 HA
 EL
 IDX

CHECK AND ADJUSTMENT



Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max. and Min. lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.
- If the brake warning lamp comes on, check brake fluid level switch and parking brake switch.




Checking Brake Line

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

1. Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.



Changing Brake Fluid

CAUTION:



- Refill with new brake fluid "DOT 3".
- Always keep fluid level higher than minimum line on reservoir tank.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Clean inside of reservoir tank, and refill with new brake fluid.
2. Connect a vinyl tube to each air bleeder valve.
3. Drain brake fluid from each air bleeder valve by depressing brake pedal.
4. Refill until new brake fluid comes out of each air bleeder valve.

Use same procedure as in bleeding hydraulic system to refill brake fluid.

Refer to "Bleeding Procedure", BR-5.

AIR BLEEDING




Bleeding Procedure

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- If master cylinder is suspected to have air inside, bleed air from master cylinder first. Refer to "Installation", "MASTER CYLINDER", BR-13.
- Fill reservoir with new brake fluid "DOT 3". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.
- For models with ABS, turn ignition switch OFF and disconnect ABS actuator connector or battery cable.

- Bleed air in the following order:
Right rear brake → Left front brake → Left rear brake → Right front brake.

1. Connect a transparent vinyl tube to air bleeder valve.
2. Fully depress brake pedal several times.
3. With brake pedal depressed, open air bleeder valve to release air.
4. Close air bleeder valve.
5. Release brake pedal slowly.
6. Repeat steps 2. through 5. until clear brake fluid comes out of air bleeder valve.
7. Tighten air bleeder valve.

: 7 - 9 N·m (0.7 - 0.9 kg·m, 61 - 78 in·lb)

CI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

BRAKE HYDRAULIC LINE

Without anti-lock brake system
 (Models with dual proportioning valve built into master cylinder)
 (built-in type)




With anti-lock brake system



- == : Primary line
- : Secondary line
- : Flare nut
- : 15 - 18 (1.5 - 1.8, 11 - 13)
- : Connecting bolt
- : 17 - 20 (1.7 - 2.0, 12 - 14)
- ⊙ : N·m (kg·m, ft·lb)

SBR086D

BRAKE HYDRAULIC LINE



REMOVAL


CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- All hoses must be free from excessive bending, twisting and pulling.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Remove flare nut securing brake tube to hose, then withdraw lock spring.
4. Cover openings to prevent entrance of dirt whenever disconnecting hydraulic line.

INSPECTION

Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.



INSTALLATION

CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.

1. Tighten all flare nuts and connecting bolts.

Flare nut:

: 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

Connecting bolt:

: 17 - 20 N·m (1.7 - 2.0 kg-m, 12 - 14 ft-lb)





2. Refill until new brake fluid comes out of each air bleeder valve.
3. Bleed air. Refer to "Bleeding Procedure", BR-5.

Proportioning Valve

INSPECTION

CAUTION:

- Carefully monitor brake fluid level at master cylinder.
 - Use new brake fluid "DOT 3".
 - Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
 - Depress pedal slowly when raising front brake pressure.
 - Check rear brake pressure 2 seconds after front brake pressure reaches specified value.
 - For models with ABS, disconnect harness connectors from ABS actuator relay box before checking.
1. Connect Tool to air bleeders of front and rear brakes on either LH or RH side.
 2. Bleed air from the Tool.
 3. Check fluid pressure by depressing brake pedal.



REMOVAL (Separated type)

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
 - All hoses must be free from excessive bending, twisting and pulling.
1. Connect a vinyl tube to air bleeder valve.
 2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
 3. Loosen flare nut.
 4. Remove proportioning valve mounting bolt, then remove flare nut.

Applied model	GA16DE	SR20DE
Applied pressure (Front brake) kPa (kg/cm ² , psi)	7,355 (75, 1,067)	6,375 (65, 924)
Output pressure (Rear brake) kPa (kg/cm ² , psi)	5,100 - 5,492 (52 - 56, 739 - 796)	4,119 - 4,511 (42 - 46, 597 - 654)

If output pressure is out of specifications, replace dual proportioning valve (separated type) or master cylinder assembly (built-in type).

4. Bleed air after disconnecting the Tool. Refer to "Bleeding Procedure", BR-5.


CONTROL VALVE

Proportioning Valve (Cont'd) INSTALLATION (Separated type)

CAUTION:

- Refill with new brake fluid "DOT 3". GI
 - Never reuse drained brake fluid.
1. Temporarily fit flare nut to proportioning valve.
 2. Tighten proportioning valve mounting bolt, then tighten flare nut. MA

Flare nut:

: 15 - 18 N·m (1.5 - 1.8 kg·m, 11 - 13 ft·lb) EM

3. Refill until new brake fluid comes out of each air bleeder valve.
4. Bleed air. Refer to "Bleeding Procedure", BR-5. LC

REMOVAL AND INSTALLATION (Built-in type)

Always replace together with master cylinder as an assembly. EC

- Refer to "MASTER CYLINDER", BR-11. FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX


BRAKE PEDAL AND BRACKET

Removal and Installation

SEC. 465



ABR198



SBR997

Inspection

Check brake pedal for following items:

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion
- Crack or deformation of clevis pin stopper

Adjustment

Check brake pedal free height from floor panel.

H: Free height

Refer to SDS, BR-78.

D: Depressed height

Refer to SDS, BR-78.


Under force of 490 N (50 kg, 110 lb) with engine running

If necessary, adjust brake pedal free height.

1. Loosen lock nut and adjust pedal free height by turning brake booster input rod. Then tighten lock nut.
2. Check pedal free play.

Make sure that stop lamps go off when pedal is released.

3. Check brake pedal's depressed height while engine is running. If lower than specification, check for leaks, air in system, or damage to components (master cylinder, wheel cylinder, etc.). Then make necessary repairs.





ABR186

MASTER CYLINDER

Removal

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
 - In the case of brake fluid leakage from the master cylinder, disassemble the cylinder. Then check piston cups for deformation or scratches and replace necessary parts.
1. Connect a vinyl tube to air bleeder valve.
 2. Drain brake fluid from each air bleeder valve, depressing brake pedal to empty fluid from master cylinder.
 3. Remove brake line flare nuts.
 4. Remove master cylinder mounting nuts.




Disassembly

1. Bend claws of stopper cap outward.

MASTER CYLINDER

Disassembly (Cont'd)



2. Remove valve stopper while piston is pushed into cylinder (Models with ABS only).
3. Remove piston assemblies.

If it is difficult to remove secondary piston assembly, gradually apply compressed air through fluid outlet.




4. Remove reservoir tank.

Inspection

Check master cylinder inner wall for pin holes or scratches. Replace if damaged.

Assembly

1. Insert secondary piston assembly. Then insert primary piston assembly.
- **Pay attention to direction of piston cups in figure at left. Also, insert pistons squarely to avoid scratches on cylinder bore.**
- **Pay attention to alignment of secondary piston slit with valve stopper mounting hole of cylinder body (For models with ABS only).**




2. Install stopper cap.

Before installing stopper cap, ensure that claws are bent inward.


3. Push reservoir tank seals into cylinder body.
4. Push reservoir tank into cylinder body.

MASTER CYLINDER

Assembly (Cont'd)



5. Install valve stopper while piston is pushed into cylinder. (Models with ABS only)




Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Place master cylinder onto brake booster and secure mounting nuts lightly.
 2. Tighten mounting nuts.
⚙️: 11.7 - 17.6 N·m (1.2 - 1.8 kg-m, 9 - 13 ft-lb)
 3. Fill up reservoir tank with new brake fluid.
 4. Plug all ports on master cylinder with fingers to prevent air suction while releasing brake pedal.
 5. Have driver depress brake pedal slowly several times until no air comes out of master cylinder.
 6. Fit brake lines to master cylinder.
 7. Tighten flare nuts.
⚙️: 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)
 8. Bleed air. Refer to "Bleeding Procedure", BR-5.

CI
MA
EM
LC
EC
FE
CL
WT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

BRAKE BOOSTER



SBR002A


On-vehicle Service

OPERATING CHECK

- Depress brake pedal several times with engine off. After exhausting vacuum, make sure there is no change in pedal stroke.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.

AIRTIGHT CHECK

- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. Booster is airtight if pedal stroke is less each time.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. The pedal stroke should not change after holding pedal down for **30 seconds**.




SBR365AA

Removal

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- Be careful not to deform or bend brake tubes, during removal of booster.



SBR232CA

Inspection


OUTPUT ROD LENGTH CHECK

1. Apply vacuum of -66.7 kPa (-500 mmHg , -19.69 inHg) to brake booster with a hand vacuum pump.
2. Check output rod length.

Specified length:


M195, S205 OR C205

10.275 - 10.525 mm (0.4045 - 0.4144 in)



SBR281A

BRAKE BOOSTER



Installation

CAUTION:

- Be careful not to deform or bend brake tubes during installation of booster. GI
- Replace clevis pin if damaged. MA
- Refill with new brake fluid "DOT 3". EM
- Never reuse drained brake fluid. LC
- Take care not to damage brake booster mounting bolt thread when installing. Due to the narrow angle of installation, the threads can be damaged by the dash panel. EC

1. Before fitting booster, temporarily adjust clevis to dimension shown. (Does not apply to models with ABS). FE
 2. Fit booster, then secure mounting nuts (brake pedal bracket to brake booster) lightly. CL
 3. Connect brake pedal and booster input rod with clevis pin. MT
 4. Secure mounting nuts. AT
- : 13 - 16 N·m (1.3 - 1.6 kg-m, 9 - 12 ft-lb)
5. Install master cylinder. Refer to BR-11. FA
 6. Bleed air. Refer to "Bleeding Procedure", BR-5. RA

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

VACUUM HOSE




Removal and Installation

CAUTION:

When installing vacuum hoses, pay attention to the following points.

- Do not apply any oil or lubricants to vacuum hose and check valve.
- Insert vacuum tube into vacuum hose as shown.




- Install check valve, paying attention to its direction.

Inspection

HOSES AND CONNECTORS

Check vacuum lines, connections and check valve for airtightness, improper attachment, chafing or deterioration.



CHECK VALVE

Check vacuum with a vacuum pump.

Connect to booster side	Vacuum should exist.
Connect to engine side	Vacuum should not exist.

Pad Replacement

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:

- When cylinder body is open, do not depress brake pedal or caliper piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL

IDX



1. Remove master cylinder reservoir cap.
2. Remove lower pin bolt.



3. Open cylinder body upward. Then remove pad retainers, return spring and inner and outer shims.

Standard pad thickness:

11 mm (0.44 in)


Pad wear limit:

2.0 mm (0.079 in)

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.

FRONT DISC BRAKE



CL22VD and CL22VE
SEC. 440



ABR286

- | | | |
|-----------------------------|-------------------|---------------------|
| ① Main pin | ⑧ Pad retainer | ⑭ Bleed valve |
| ② Pin boot | ⑨ Outer pad | ⑮ Cylinder body |
| ③ Torque member fixing bolt | ⑩ Outer shim | ⑯ Piston seal |
| ④ Torque member | ⑪ Connecting bolt | ⑰ Piston |
| ⑤ Shim cover | ⑫ Copper washer | ⑱ Piston boot |
| ⑥ Inner shim | ⑬ Main pin bolt | ⑲ Pad return spring |
| ⑦ Inner pad | | |

FRONT DISC BRAKE



Removal

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:

Suspend caliper assembly with wire so as not to stretch brake hose.

Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

Disassembly

WARNING:

Do not place your fingers in front of piston.

CAUTION:

Do not scratch or score cylinder wall.

1. Push out piston and boot with compressed air.
2. Remove piston seal with a suitable tool.

Inspection — Caliper

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign objects. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign objects may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

CAUTION:

Use brake fluid to clean. Never use mineral oil.

PISTON

Check piston for score, rust, wear, damage or presence of foreign objects. Replace if any of the above conditions are observed.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign objects are stuck to sliding surface.

SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks or other damage. Replace if any of the above conditions are observed.

GI

MA

EM

LC

EC

FE

CL

WT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

FRONT DISC BRAKE



Inspection — Rotor


RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to FA section ("Front Wheel Bearing", "ON-VEHICLE SERVICE").

**Maximum runout:
0.07 mm (0.0028 in)**

3. If the runout is out of specification, find minimum runout position as follows:
 - a. Remove nuts and rotor from wheel hub.
 - b. Shift the rotor one hole and secure rotor to wheel hub with nuts.
 - c. Measure runout.
 - d. Repeat steps a. through c. so that minimum runout position can be found.
4. If the runout is still out of specification, turn rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).



THICKNESS


**Thickness variation (At least 8 positions):
Maximum 0.02 mm (0.0008 in)**

If thickness variation exceeds the specification, turn rotor with on-car brake lathe.

**Rotor repair limit:
16.0 mm (0.630 in)**

Assembly


1. Insert piston seal into groove on cylinder body.
2. With piston boot fitted to piston, insert piston boot into groove on cylinder body and install piston.
3. Properly secure piston boot.




Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install caliper assembly.
 2. Install brake hose to caliper securely.
 3. Install all parts and secure all bolts.
 4. Bleed air. Refer to "Bleeding Procedure", BR-5.



REAR DRUM BRAKE




Removal

WARNING:

Clean brake lining with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:


Make sure parking brake lever is completely released.




1. Release parking brake lever fully, then remove drum. If drum is hard to remove, the following procedures should be carried out.
 - a. Remove plug. Then shorten adjuster to make clearance between brake shoe and drum as shown.

REAR DRUM BRAKE


Removal (Cont'd)




- b. Install two bolts as shown. Tighten the two bolts gradually.



2. After removing retainer, remove spring by rotating shoes.
 - Be careful not to damage wheel cylinder piston boots.
 - Be careful not to damage parking brake cable when separating it.
3. Remove adjuster.
4. Disconnect parking brake cable from toggle lever.




5. Remove retainer ring with a suitable tool. Then separate toggle lever and brake shoe.



Inspection — Wheel Cylinder


- Check wheel cylinder for leakage.
- Check for wear, damage and loose conditions. Replace if any such condition exists.



Wheel Cylinder Overhaul

- Check all internal parts for wear, rust and damage. Replace if necessary.
- Pay attention so as not to scratch cylinder when installing pistons.

REAR DRUM BRAKE



Inspection — Drum

Maximum inner diameter:

181 mm (7.13 in)

Out-of-roundness:

0.03 mm (0.0012 in) or less

- Contact surface should be fine finished with No. 120 to 150 emery paper.
- Using a drum lathe, resurface brake drum if it shows score, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.

GI

MA

EM

LC

EC

FE

CL

WT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX



Inspection — Lining


Check lining thickness.

Standard lining thickness:

4.0 mm (0.16 in)

Lining wear limit:


1.5 mm (0.059 in)



Installation

Always perform shoe clearance adjustment. Refer to BR-33.

1. Fit toggle lever to brake shoe with retainer ring.
2. Apply brake grease to the contact areas shown at left.




3. Shorten adjuster by rotating it.
- Pay attention to direction of adjuster.

Wheel	Screw	Depression
Left	Left-hand thread	Yes
Right	Right-hand thread	No

4. Connect parking brake cable to toggle lever.
5. Install all parts.

Be careful not to damage wheel cylinder piston boots.



6. Check all parts are installed properly.

Pay attention to direction of adjuster assembly.

7. Install brake drum.
8. When installing new wheel cylinder or overhauling wheel cylinder, bleed air. Refer to "Bleeding Procedure", BR-5.
9. Adjust parking brake. Refer to BR-33.

REAR DISC BRAKE


Pad Replacement

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

CAUTION:

- When cylinder body is open, do not depress brake pedal, otherwise caliper piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.
- Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.




1. Remove master cylinder reservoir cap.
2. Remove brake cable lock spring.
3. Remove cable guide from caliper assembly.
4. Disconnect cable.
5. Remove lock spring from brake hose. Then remove brake hose from bracket.
6. Remove lower pin bolt.
7. Open cylinder body upward. Then remove pad retainers, and inner and outer shims.

Standard pad thickness:

10 mm (0.39 in)

Pad wear limit:

1.5 mm (0.059 in)





REAR DISC BRAKE

Pad Replacement (Cont'd)

- When installing new pads, push piston into cylinder body by turning piston clockwise.

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

REAR DISC BRAKE

CL7HB
SEC. 440

25 - 29 (2.5 - 3.0, 18 - 22)

26 - 36 (2.7 - 3.7, 20 - 27)

22 - 31 (2.2 - 3.2, 16 - 23)

4 P
to sliding portion

P
to pad contact area

Ⓜ: N·m (kg·m, ft·lb)

Ⓜ P: PBC (Poly Butyl Cuprysil) grease or silicone-based grease point

Ⓜ R: Rubber grease point

Ⓜ B: Brake fluid point


- ① Cable guide
- ② Cylinder
- ③ Toggle lever
- ④ Pin
- ⑤ Pin boot
- ⑥ Torque member
- ⑦ Retainer
- ⑧ Inner shim
- ⑨ Inner pad
- ⑩ Pad retainer
- ⑪ Outer pad

- ⑫ Outer shim
- ⑬ Strut
- ⑭ O-ring
- ⑮ Push rod
- ⑯ Key plate
- ⑰ Snap ring
- ⑱ Seat
- ⑲ Spring
- ⑳ Spring cover
- ㉑ Snap ring

- ㉒ Piston seal
- ㉓ Snap ring
- ㉔ Spacer
- ㉕ Wave washer
- ㉖ Spacer
- ㉗ Bearing
- ㉘ Adjuster
- ㉙ Cup
- ㉚ Piston
- ㉛ Piston boot

ABR288

REAR DISC BRAKE



Removal

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

1. Remove parking brake cable lock plate.
2. Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

GI
MA
EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA



EL

IDX




Disassembly

1. Remove piston by turning it counterclockwise with suitable long nose pliers or commercial service tool.



2. Remove snap ring from piston with suitable pliers and remove adjusting nut.





3. Disassemble cylinder body.
 - a. Pry off snap ring with suitable pliers, then remove spring cover, spring and seat.
 - b. Remove snap ring, then remove key plate, push rod and strut.

REAR DISC BRAKE

Disassembly (Cont'd)

- c. Remove piston seal.
Be careful not to damage cylinder body.



4. Remove return spring, toggle lever and cable guide.

Inspection — Caliper

CAUTION:

Use brake fluid to clean cylinder. Never use mineral oil.

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign objects. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign objects may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

TORQUE MEMBER

Check for wear, cracks or other damage. Replace if necessary.

PISTON

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign objects are stuck to sliding surface.

Check piston for score, rust, wear, damage or presence of foreign objects. Replace if any of the above conditions are observed.

SLIDE PIN, PIN BOLT, AND PIN BOOT

Check for wear, cracks or other damage.
Replace if any of the above conditions are observed.

REAR DISC BRAKE

Inspection — Rotor

RUBBING SURFACE

Check rotor for roughness, cracks or chips.

GI

MA

EM

LC

EC

FE

CL

WT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX




RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to RA section ("Rear Wheel Bearing", "ON-VEHICLE SERVICE").

3. Change relative positions of rotor and wheel hub so that runout is minimized.

**Maximum runout:
0.07 mm (0.0028 in)**




THICKNESS

**Rotor repair limit:
Minimum thickness
6.0 mm (0.236 in)**


**Thickness variation (At least 8 positions)
Maximum 0.02 mm (0.0008 in)**

Replace rotor if any of the above do not meet the specifications.



Assembly


1. Insert cam with depression facing towards open end of cylinder.




2. Generously apply rubber grease to strut and push rod to make insertion easy.

REAR DISC BRAKE


Assembly (Cont'd)




3. Match protrusion on key plate with depression in cylinder.




4. Install snap ring with a suitable tool.



5. Install seat, spring, spring cover and snap ring while depressing with suitable tool.




6. Install adjuster in the specified direction.





7. Install cup, adjuster, bearing, spacers, washer and snap ring with a suitable tool.

REAR DISC BRAKE

Assembly (Cont'd)



8. Insert piston seal into groove on cylinder body.
9. With piston boot fitted to piston, insert piston boot into groove on cylinder body and fit piston by turning it clockwise with long nose pliers, or suitable tool.



10. Fit toggle lever, return spring and cable guide.

Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install caliper assembly.
 2. Install brake hose to caliper securely.
 3. Install all parts and secure all bolts.
 4. Bleed air. Refer to "Bleeding Procedure", BR-5.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT




HA

EL

IDX

PARKING BRAKE CONTROL

SEC. 443






Removal and Installation

1. To remove parking brake cable, first remove center console.
2. Disconnect warning lamp connector.
3. Remove bolts, slacken off and remove adjusting nut.
4. Remove lock plate and disconnect cable (disc brake only). For drum brake models, refer to BR-21.

Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Check warning lamp and switch. Replace if necessary.
4. Check parts at each connecting portion and, if deformed or damaged, replace.

PARKING BRAKE CONTROL



Adjustment

Before or after adjustment, pay attention to the following points.

- For rear disc brake be sure toggle lever returns to stopper when parking brake lever is released.
- There is no drag when parking brake lever is released.

1. Adjust clearance between shoe and drum/pad and rotor as follows.

- a. Release parking brake lever and loosen adjusting nut.
- b. Depress brake pedal fully at least 10 times with engine running.

2. Pull control lever 4 - 5 notches. Then adjust control lever by turning adjusting nut.

3. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.

Number of notches:

Drum brake: 7 - 8

Disc brake: 8 - 9

4. Bend warning lamp switchplate to ensure:

- Warning lamp comes on when lever is lifted "A" notches.
- Warning lamp goes out when lever is fully released.

Number of "A" notches : 1 or less

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ANTI-LOCK BRAKE SYSTEM

Purpose

The Anti-Lock Brake System (ABS) consists of electronic and hydraulic components. It allows for control of braking force so locking of the wheels can be avoided.

The ABS:


- 1) Improves proper tracking performance through steering wheel operation.
- 2) Eases obstacle avoidance through steering wheel operation.
- 3) Improves vehicle stability.

Operation

- When the vehicle speed is less than 10 km/h (6 MPH) this system does not work.
- The Anti-Lock Brake System (ABS) has self-test capabilities. The system turns on the ABS warning lamp for 1 second each time the ignition switch is turned "ON". After the engine is started, the ABS warning lamp turns off. The system performs a test the first time the vehicle reaches 6 km/h (4 MPH). A mechanical noise may be heard as the ABS performs this self-test. This is a normal part of the self-test feature. If a malfunction is found during this check, the ABS warning lamp will stay on.
- While driving, a mechanical noise may be heard during ABS operation. This is a normal condition.


ANTI-LOCK BRAKE SYSTEM

System Components



ABR247


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



System Description


SENSOR

The sensor unit consists of a gear-shaped sensor rotor and a sensor element. The element contains a bar magnet around which a coil is wound. The sensor is installed on the back side of the brake rotor. Sine-wave current is generated by the sensor as the wheel rotates. The frequency and voltage increase(s) as the rotating speed increases.



CONTROL UNIT

The control unit computes the wheel rotating speed by the signal current sent from the sensor. Then it supplies a DC current to the actuator solenoid valve. It also controls ON-OFF operation of the valve relay and motor relay. If any electrical malfunction should be detected in the system, the control unit causes the warning lamp to light up. In this condition, the ABS will be deactivated by the control unit, and the vehicle's brake system reverts to normal operation.



ANTI-LOCK BRAKE SYSTEM

Removal and Installation


CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth.

When removing the front or rear wheel hub assembly, disconnect the ABS wheel sensor from the assembly and move it away.


FRONT WHEEL SENSOR

SEC. 476



REAR WHEEL SENSOR

SEC. 476



ANTI-LOCK BRAKE SYSTEM




Removal and Installation (Cont'd)

SENSOR ROTOR

Removal

1. Remove the drive shaft and rear wheel hub. Refer to FA section ("Drive Shaft", "FRONT AXLE.") and RA section ("Wheel Hub", "REAR AXLE.")
2. Remove the sensor rotor using suitable puller, drift and bearing replacer.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Installation

Install the sensor rotor. For front sensor rotor, use hammer and wooden block. For rear sensor rotor, use suitable drift and press.

- Always replace sensor rotor with new one.



- Pay attention to the dimension of rear sensor rotor as shown in figure.
h: 4.5 - 5.5 mm (0.177 - 0.217 in)



CONTROL UNIT


Location: Passenger side, behind dash side lower finisher.

- Make sure that the sensor shield ground cable is secured with mounting bolt.



ANTI-LOCK BRAKE SYSTEM

Removal and Installation (Cont'd)

ABS ACTUATOR




1. Disconnect battery cable.
2. Drain brake fluid. Refer to BR-4.
3. Discharge air conditioner refrigerant. Refer to HA section ("R-134a Service Procedure", "SERVICE PROCEDURES").
4. Disconnect all connectors from ABS relay bracket.



5. Remove mounting bolt for relay bracket.
6. Remove ABS relay box with bracket.
7. Remove air conditioner low-pressure tubes. Refer to HA section, ("Refrigerant Lines", "SERVICE PROCEDURES").

ANTI-LOCK BRAKE SYSTEM

Removal and Installation (Cont'd)



8. Disconnect and separate brake lines and move away from actuator.

It is not necessary to remove these lines from vehicle.

CI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL

IDX



9. Remove/loosen mounting nuts between actuator and bracket.




10. Remove ABS actuator as shown.

CAUTION:

After installation, pay attention to the following points:

- Refill brake fluid and bleed air. Refer to "CHECK AND ADJUSTMENT", BR-4 and "AIR BLEEDING", BR-5, respectively.
- Charge air conditioning with refrigerant. Refer to HA section, ("R-134a Service Procedure", "SERVICE PROCEDURES").




- The installation procedure is the reverse of removal.



ANTI-LOCK BRAKE SYSTEM

Removal and Installation (Cont'd)

ABS RELAYS

1. Disconnect negative battery cable.
2. Remove ABS relay cover.





How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The ABS system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and instantly drives the actuators. It is essential that both kinds of signals are present and stable. It is also important to check for conventional problems: such as air leaks in booster lines, lack of brake fluid, or other problems with the brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test should be performed.

Before performing actual checks, take a few minutes to talk with a customer who approaches with a ABS complaint. The customer is a very good source of information on such problems; especially intermittent ones. By talking to the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS controlled vehicle.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

TROUBLE DIAGNOSES


Preliminary Check




A
Check brake fluid level in reservoir tank.
 Low fluid level may indicate brake pad wear or leakage from brake line.



B
Check brake line for leakage. NG → Repair.
 OK → [Next Step]




C
Check brake booster for operation and air tightness. Refer to BR-14. NG → Replace.
 OK → [Next Step]



Check brake pads and rotor. Refer to BR-17, 24. NG → Replace.
 OK → [Next Step]

A
Check brake fluid level in reservoir tank. NG → Fill up brake fluid.
 OK → [Next Step]



D
Check warning lamp activation. When ignition switch is turned on, warning lamp turns on. NG → Check fuse, warning lamp bulb and warning lamp circuit.
 OK → [Next Step]

Check warning lamp for deactivation. When ignition switch is turned on, warning lamp turns on, then deactivates after one second. NG → Go to self-diagnosis, BR-49.
 OK → [Next Step]

E
Drive vehicle at 30 km/h (20 MPH) for at least one minute.










Ensure warning lamp remains off while driving. NG → Go to self-diagnosis, BR-49.
 OK → [Next Step]

END

TROUBLE DIAGNOSES


Component Parts and Harness Connector Location

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSES




Schematic



TROUBLE DIAGNOSES

Wiring Diagram -ABS-

BR-ABS-01








GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Wiring Diagram -ABS- (Cont'd)


BR-ABS-02



TROUBLE DIAGNOSES



Wiring Diagram -ABS- (Cont'd)

BR-ABS-03



Refer to last page (Foldout page).

(M16), (E101)





ABR173C

TROUBLE DIAGNOSES

Wiring Diagram -ABS- (Cont'd)

BR-ABS-04



Refer to last page (Foldout page).




M3

Self-diagnosis


FUNCTION

- When a problem occurs in the ABS, the warning lamp on the instrument panel comes on. To start the self-diagnostic results mode, ground the self-diagnostic (check) terminal located on "Data Link Connector for CONSULT". The location of the malfunction is indicated by the warning lamp flashing.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



SELF-DIAGNOSIS PROCEDURE




NOTE: The indication terminates after five minutes. However, when the ignition switch is turned from "OFF" to "ON", the indication starts flashing again.

A



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)



HOW TO READ SELF-DIAGNOSTIC RESULTS (Malfunction codes)

- Determine the code No. by counting the number of times the warning lamp flashes on and off.
- When several malfunctions occur at one time, up to three code numbers can be stored; the latest malfunction will be indicated first.
- The indication begins with the start code 12. After that a maximum of three code numbers appear in the order of the latest one first. The indication then returns to the start code 12 to repeat (the indication will stay on for a maximum of five minutes).
- The malfunction code chart is given on the next page.



HOW TO ERASE SELF-DIAGNOSTIC RESULTS (Malfunction codes)

1. Disconnect the check terminal from ground (ABS warning lamp will stay lit).
2. Within 12.5 seconds, ground the check terminal 3 times. Each terminal grounding must last more than 1 second. The ABS warning lamp goes out after the erase operation has been completed.
3. Perform self-diagnosis again. Refer to BR-49. Only the startcode should appear, no malfunction codes.

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

MALFUNCTION CODE/SYMP TOM CHART

Code No. (No. of LED flashes)	Malfunctioning part	Diagnostic procedure
45	Actuator front left outlet solenoid valve	3
46	Actuator front left inlet solenoid valve	3
41	Actuator front right outlet solenoid valve	3
42	Actuator front right inlet solenoid valve	3
51	Actuator rear right outlet solenoid valve	3
52	Actuator rear right inlet solenoid valve	3
55	Actuator rear left outlet solenoid valve	3
56	Actuator rear left inlet solenoid valve	3
25	Front left sensor (open-circuit)	4
26	Front left sensor (short-circuit)	4
21	Front right sensor (open-circuit)	4
22	Front right sensor (short-circuit)	4
35	Rear left sensor (open-circuit)	4
36	Rear left sensor (short-circuit)	4
31	Rear right sensor (open-circuit)	4
32	Rear right sensor (short-circuit)	4
18	Sensor rotor	4
61	Actuator motor or motor relay	5
63	Solenoid valve relay	6
57	Power supply (Low voltage)	7
71	Control unit	8
Warning lamp stays on when ignition switch is turned on	Control unit power supply circuit Warning lamp bulb circuit Control unit or control unit connector Solenoid valve relay stuck Power supply for solenoid valve relay coil	2
Warning lamp stays on, during self-diagnosis	Control unit	—
Warning lamp does not come on when ignition switch is turned on	Fuse, warning lamp bulb or warning lamp circuit Control unit	1
Warning lamp does not come on during self-diagnosis	Control unit	—
Pedal vibration and noise	—	9
Long stopping distance	—	10
Unexpected pedal action	—	11
ABS does not work	—	12
ABS works frequently	—	13

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES

CONSULT

CONSULT APPLICATION TO ABS






ITEM	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST
Front right wheel sensor	X	X	—
Front left wheel sensor	X	X	—
Rear right wheel sensor	X	X	—
Rear left wheel sensor	X	X	—
Stop lamp switch	—	X	—
Front right inlet solenoid valve	X	X	X
Front right outlet solenoid valve	X	X	X
Front left inlet solenoid valve	X	X	X
Front left outlet solenoid valve	X	X	X
Rear right inlet solenoid valve	X	X	X
Rear left inlet solenoid valve	X	X	X
Rear right outlet solenoid valve	X	X	X
Rear left outlet solenoid valve	X	X	X
Actuator solenoid valve relay	X	X	—
Actuator motor relay (ABS MOTOR is shown on the Data Monitor screen.)	X	X	X
ABS warning lamp	—	X	—
Battery voltage (SENSOR VOLT is shown on the Data Monitor screen.)	X	X	—

X: Applicable

—: Not applicable

ECU part number mode

Ignore the ECU part number displayed in the ECU PART NUMBER MODE. Refer to parts catalog to order the ECU.



CONSULT Inspection Procedure SELF-DIAGNOSIS PROCEDURE

A

1. Turn ignition switch OFF.
2. Connect CONSULT to Data Link Connector for CONSULT.

1. Start engine.
2. Drive vehicle over 30 km/h (20 MPH) for at least one minute.

B 1. Stop vehicle with engine running and touch "START" on CONSULT screen.

C 2. Touch "ABS".

D 3. Touch "SELF-DIAG RESULTS".

- The screen shows the detected malfunction and how many times the ignition switch has been turned ON since the malfunction.

Make the necessary repairs following the diagnostic procedures.

E After the malfunctions are repaired, erase the self-diagnostic results stored in the control unit by touching "ERASE".

Check warning lamp for deactivation after driving vehicle over 30 km/h (20 MPH) for at least one minute.

Test the ABS in a safe area to verify that it functions properly.

Note: "SELF-DIAG RESULTS" screen shows the detected malfunction and how many times the ignition switch has been turned ON since the malfunction.

CI

MA

EM

LC

EC

FE

CL

WT

AT

FA

RA

BR

ST

RS

BT

HA

FL

IDX

TROUBLE DIAGNOSES


CONSULT Inspection Procedure (Cont'd)

SELF-DIAGNOSTIC RESULTS MODE


Diagnostic item	Diagnostic item is detected when ...	Diagnostic procedure
FR RH SENSOR [OPEN]	● Circuit for front right wheel sensor is open. (An abnormally high input voltage is entered.)	4
FR LH SENSOR [OPEN]	● Circuit for front left wheel sensor is open. (An abnormally high input voltage is entered.)	4
RR RH SENSOR [OPEN]	● Circuit for rear right sensor is open. (An abnormally high input voltage is entered.)	4
RR LH SENSOR [OPEN]	● Circuit for rear left sensor is open. (An abnormally high input voltage is entered.)	4
FR RH SENSOR [SHORT]	● Circuit for front right wheel sensor is shorted. (An abnormally low input voltage is entered.)	4
FR LH SENSOR [SHORT]	● Circuit for front left wheel sensor is shorted. (An abnormally low input voltage is entered.)	4
RR RH SENSOR [SHORT]	● Circuit for rear right sensor is shorted. (An abnormally low input voltage is entered.)	4
RR LH SENSOR [SHORT]	● Circuit for rear left sensor is shorted. (An abnormally low input voltage is entered.)	4
ABS SENSOR [ABNORMAL SIGNAL]	● Teeth damage on sensor rotor or improper installation of wheel sensor. (Abnormal wheel sensor signal is entered.)	4
FR RH IN ABS SOL [OPEN]	● Circuit for front right inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR LH IN ABS SOL [OPEN]	● Circuit for front left inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR RH IN ABS SOL [OPEN]	● Circuit for rear right inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR LH IN ABS SOL [OPEN]	● Circuit for rear left inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR RH IN ABS SOL [SHORT]	● Circuit for front right inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR LH IN ABS SOL [SHORT]	● Circuit for front left inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR RH IN ABS SOL [SHORT]	● Circuit for rear right inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR LH IN ABS SOL [SHORT]	● Circuit for rear left inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR RH OUT ABS SOL [OPEN]	● Circuit for front right outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR LH OUT ABS SOL [OPEN]	● Circuit for front left outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR RH OUT ABS SOL [OPEN]	● Circuit for rear right outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR LH OUT ABS SOL [OPEN]	● Circuit for rear left outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR RH OUT ABS SOL [SHORT]	● Circuit for front right outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR LH OUT ABS SOL [SHORT]	● Circuit for front left outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR RH OUT ABS SOL [SHORT]	● Circuit for rear right outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR LH OUT ABS SOL [SHORT]	● Circuit for rear left outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
ABS ACTUATOR RELAY [FAILURE]	● Actuator solenoid valve relay is ON, even if control unit sends off signal. ● Actuator solenoid valve relay is OFF, even if control unit sends on signal.	6
ABS MOTOR [FAILURE]	● Circuit for actuator motor is open or shorted. ● Actuator motor relay is stuck.	5
BATTERY VOLT [VB-LOW]	● Power source voltage supplied to ABS control unit is abnormally low.	7
CONTROL UNIT	● Function of calculation in ABS control unit has failed.	8

TROUBLE DIAGNOSES


CONSULT Inspection Procedure (Cont'd) DATA MONITOR PROCEDURE





1. Turn ignition switch OFF.
2. Connect CONSULT to Data Link Connector for CONSULT.
3. Turn ignition switch ON.



- A** 1. Touch "START" on CONSULT screen.
- B** 2. Touch "ABS".
- C** 3. Touch "DATA MONITOR".



- D** 1. Touch "SETTING" on "SELECT MONITOR ITEM" screen.
- E** 2. Touch "LONG TIME" on "SET RECORDING COND" screen.
- D** 3. Touch "START" on "SELECT MONITOR ITEM" screen.



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

CONSULT Inspection Procedure (Cont'd)

ACTIVE TEST PROCEDURE






- When conducting Active test, vehicle must be stationary.
- When ABS warning lamp stays on, never conduct Active test.

1. Turn ignition switch OFF.
2. Connect CONSULT to Data Link Connector for CONSULT.
3. Start engine.

1. Touch "START" on CONSULT screen.
2. Touch "ABS".
3. Touch "ACTIVE TEST".

1. Select active test item by touching screen.
2. Touch "START".

Carry out the active test by touching screen key.



TROUBLE DIAGNOSES

CONSULT Inspection Procedure (Cont'd)

DATA MONITOR MODE


MONITOR ITEM	CONDITION	SPECIFICATION
FR RH SENSOR FR LH SENSOR REAR RH SENSOR REAR LH SENSOR	Drive vehicle. (Each wheel is rotating.)	Almost the same speed as speedometer.
STOP LAMP SW	Brake is depressed.	Depress the pedal: ON Release the pedal: OFF
FR RH IN SOL FR RH OUT SOL FR LH IN SOL FR LH OUT SOL RR RH IN SOL RR RH OUT SOL RR LH IN SOL RR LH OUT SOL	Engine is running.	Operating conditions for each solenoid valve are indicated. ABS is not operating: OFF
ACTUATOR RLY	Ignition switch is ON or engine is running.	Ignition switch ON (Engine stops): OFF Engine running: ON
MOTOR RELAY		ABS is not operating: OFF ABS is operating: ON
WARNING LAMP		Warning lamp is turned on: ON Warning lamp is turned off: OFF
SENSOR VOLT		Power supply voltage for control unit

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT												
FR RH SOLENOID FR LH SOLENOID RR RH SOLENOID RR LH SOLENOID	Engine is running.	Brake fluid pressure control operation <table style="width: 100%; border-collapse: collapse;"> <tr> <td></td> <td style="text-align: center;">IN SOL</td> <td style="text-align: center;">OUT SOL</td> </tr> <tr> <td>UP (Increase):</td> <td style="text-align: center;">OFF</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>KEEP (Hold):</td> <td style="text-align: center;">ON</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>DOWN (Decrease):</td> <td style="text-align: center;">ON</td> <td style="text-align: center;">ON</td> </tr> </table>		IN SOL	OUT SOL	UP (Increase):	OFF	OFF	KEEP (Hold):	ON	OFF	DOWN (Decrease):	ON	ON
		IN SOL	OUT SOL											
UP (Increase):	OFF	OFF												
KEEP (Hold):	ON	OFF												
DOWN (Decrease):	ON	ON												
ABS MOTOR		ABS actuator motor ON: Motor runs OFF: Motor stops												

Note: Active test will automatically stop ten seconds after the test starts. (LIMIT SIGNAL monitor shows ON.)


TROUBLE DIAGNOSES



Ground Circuit Check


ACTUATOR MOTOR GROUND

- Check resistance between actuator motor ground terminal and body ground.
Resistance: 0Ω



CONTROL UNIT GROUND




- Check resistance between the terminals and ground.
Resistance: 0Ω



ABS RELAY BOX GROUND

- Check resistance between ABS relay box harness 6-pin connector (body side) terminal ⑧ and ground.
Resistance: 0Ω

TROUBLE DIAGNOSES



Diagnostic Procedure 1 (Not self-diagnostic item)

Warning lamp does not come on when ignition switch is turned on.

WARNING LAMP CIRCUIT CHECK NG → Replace fuse.

Check 10A fuse **8** for warning lamp. For fuse layout, refer to BR-48.

↓ OK

Check warning lamp bulb. NG → Replace bulb.

↓ OK

A

1. Install 10A fuse and bulb.
2. Disconnect connectors from control unit and ABS relay box.
3. Check voltage between control unit connector terminal **30** and ground after turning ignition switch "ON". **Battery voltage should exist after turning ignition switch "ON"**.

NG → Repair harness and connectors.

↓ OK

B

Check continuity between ABS relay box 6-pin connector (body side) and control unit terminal.

ABS relay box	Control unit
10	30
8	Ground

Continuity should exist.

NG → Repair harness and connectors.

↓ OK

C

1. Remove solenoid valve relay.
2. Check continuity between ABS relay box 6-pin connector (ABS relay box side) and ABS relay box terminals.

ABS relay box connector	ABS relay box terminals
10 ⊕	30 ⊖
8	87a

Continuity should exist.

Note: Specifications may vary depending on tester type. Before performing this inspection, be sure to refer to the instruction manual for tester being used.

NG → Replace ABS relay box.

↓ OK

SOLENOID VALVE RELAY CHECK NG → Replace solenoid valve relay.

Refer to "SOLENOID VALVE RELAY" in Electrical Components Inspection.

↓ OK


Go to diagnostic procedure 7.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 2 (Not Self-diagnostic item)

Warning light stays on when ignition switch is turned on.



CONTROL UNIT POWER SUPPLY CIRCUIT


Check 7.5A fuse 12 for control unit. For fuse layout, refer to BR-48.

NG → (Go to (B) on BR-62.)

A

1. Disconnect connector from control unit.
2. Check voltage between control unit connector terminal ① and ground after turning ignition switch "ON".
Battery voltage should exist.

NG → Repair harness and connector.



B


SOLENOID VALVE RELAY COIL POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF". Disconnect ABS relay box 6-pin connector.
2. Check continuity between control unit connector terminals and ABS relay box 6-pin connector (body side) terminals.

NG → Repair harness and connector.

Control box	ABS relay box
②	②
③⑦	⑥

Continuity should exist.



C

CIRCUIT CHECK

1. Disconnect solenoid valve relay.
2. Check continuity between ABS relay box 6-pin connector (ABS relay box side) terminals and solenoid valve relay box terminals.

NG → Replace ABS relay box.

ABS relay box connector	ABS relay box terminals
②	⑧⑥
⑥	⑧⑤

Continuity should exist.

SOLENOID VALVE RELAY CHECK

Refer to "SOLENOID VALVE RELAY" in Electrical Components Inspection.

NG → Replace solenoid valve relay.


OK

A


(Go to next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 2 (Not Self-diagnostic item) (Cont'd)




ABR211



ABR212






ABR213



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 2 (Not Self-diagnostic item) (Cont'd)





TROUBLE DIAGNOSES

Diagnostic Procedure 3

ABS ACTUATOR SOLENOID VALVE

(Malfunction code No. 41, 45, 51, 55, 42, 46, 52, 56)



1. Disconnect connectors from control unit, ABS actuator and ABS relay box. Check terminals for damage or loose connections. Then reconnect connectors.
2. Carry out self-diagnosis again.

Does warning lamp activate again?

No → Inspection end

Yes

A

ABS ACTUATOR SOLENOID VALVE CHECK

1. Disconnect connectors from control unit and ABS relay box.
2. Check resistance between control unit connector terminals and ABS actuator 2-pin connector (ABS actuator side) terminal.

Code No.	Control unit	ABS actuator	Resistance
41	(26)	(18)	4.4 - 6.0Ω
45	(33)	(18)	
51	(34)	(18)	
55	(25)	(18)	
42	(54)	(18)	8.5 - 11.0Ω
46	(5)	(18)	
52	(6)	(18)	
56	(53)	(18)	

OK → (Go to next page.)

NG

B

1. Disconnect ABS actuator 8-pin connector.
2. Check resistance between ABS actuator 8-pin connector (ABS actuator side) terminals and ABS actuator 2-pin connector (ABS actuator side) terminal.

Code No.	ABS actuator	ABS actuator	Resistance
41	(15)	(18)	4.4 - 6.0Ω
45	(14)	(18)	
51	(17)	(18)	
55	(16)	(18)	
42	(3)	(18)	8.5 - 11.0Ω
46	(1)	(18)	
52	(7)	(18)	
56	(5)	(18)	

OK → Repair harness and connector between control unit connector terminal and ABS actuator 8-pin connector terminal.





NG

Replace ABS actuator.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 3 (Cont'd)



TROUBLE DIAGNOSES



Diagnostic Procedure 4

WHEEL SENSOR OR ROTOR

(Malfunction code No. 21, 22, 25, 26, 31, 32, 35, 36 or 18)

1. Disconnect connectors from control unit and wheel sensor of malfunction code No. Check terminals for damage or loose connections. Then reconnect connectors.
2. Carry out self-diagnosis again.
Does warning lamp activate again?

No → Inspection end

Yes

A

WHEEL SENSOR ELECTRICAL CHECK

OK → (A) (See next page.)

1. Disconnect control unit connector.
2. Check resistance between control unit connector terminals.
Code No. 21 or 22 (Front RH wheel) Terminals (14) and (15)
Code No. 25 or 26 (Front LH wheel) Terminals (9) and (10)
Code No. 31 or 32 (Rear RH wheel) Terminals (11) and (38)
Code No. 35 or 36 (Rear LH wheel) Terminals (12) and (13)
Resistance: 0.8 - 1.2 kΩ

NG

Note

CHECK WHEEL SENSOR.

Refer to "WHEEL SENSOR" in Electrical Components Inspection, BR-76.

NG → Replace wheel sensor.

OK

Note




Repair harness and connectors between control unit connector and wheel sensor connector.

Note: Wheel position should be distinguished by code No. except code No. 18 (sensor rotor).


CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 4 (Cont'd)



TROUBLE DIAGNOSES




Diagnostic Procedure 5 MOTOR RELAY OR MOTOR (Malfunction code No. 61)

MOTOR POWER SUPPLY CIRCUIT

Check fusible link **d** for ABS relay box. For fusible link layout, refer to POWER SUPPLY ROUTING in EL section.

NG → (Go to **B**) on BR-69.)

OK



1. Disconnect connectors from control unit and ABS actuator. Check terminals for damage or loose connections. Then reconnect connectors.
2. Carry out self-diagnosis again.
Does warning lamp activate again?

No → Inspection end

Yes

A

1. Disconnect ABS relay box 2-pin connector.
2. Check voltage between connector (body side) terminal **13** and ground.
Battery voltage should exist.

NG → Repair harness and connectors.

OK

B

CIRCUIT CHECK

1. Disconnect ABS relay box 6-pin connector and control unit connector.
2. Check continuity between control unit connector terminals and ABS relay box 6-pin connector (body side) terminals.

NG → Repair harness and connectors.

Control unit	ABS relay box
⑦	⑪
⑲	⑨
②	②

Continuity should exist.

OK

MOTOR RELAY CHECK

Refer to "ACTUATOR MOTOR RELAY" in Electrical Components Inspection, BR-76.

NG → Replace motor relay.

OK

MOTOR GROUND CHECK

Refer to "ACTUATOR MOTOR GROUND" in Ground Circuit Check, BR-58.

NG → Repair harness and terminals.







OK

(Go to next page.)

GI
MA
EM
LG
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES





Diagnostic Procedure 5 (Cont'd)



Go to diagnostic procedure 7, BR-72.

TROUBLE DIAGNOSES

Diagnostic Procedure 5 (Cont'd)



B

Replace fusible link.
Does the fusible link blow out when ignition switch is turned "ON"?

No → Inspection end

Yes →

F **MOTOR POWER SUPPLY CIRCUIT**

1. Disconnect battery cable and ABS relay box 2-pin connector.
2. Check continuity between ABS relay box 2-pin connector (body side) terminal (13) and ground.
Continuity should not exist.

NG → Repair harness and connector.

OK →

G

1. Disconnect ABS relay box 6-pin connector and control unit connector.
2. Check continuity between ABS relay box 6-pin connector (body side) terminal (9) and ground.
Continuity should not exist.

NG → Repair harness and connector.

OK →

H

Check continuity between ABS relay box 6-pin connector (ABS relay box side) terminal (9) and ground, ABS relay box 2-pin connector (ABS relay box side) terminal (13) and ground.
Continuity should not exist.

NG → Replace ABS relay box.

OK →

I

1. Remove motor ground.
2. Check continuity between ABS actuator 2-pin connector (ABS actuator side) terminal (20) and ground.
Continuity should not exist.

NG → Replace ABS actuator.

OK →

MOTOR CHECK



Go to **E** in diagnostic procedure 5, BR-68.

OK →

Check control unit pin terminals for damage or the connection of control unit harness connector.
Reconnect control unit harness connector.
Then retest.

GI
MA
EM
LC
EC
FE
CL
WT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 6 SOLENOID VALVE RELAY (Malfunction code No. 63)



SOLENOID VALVE POWER SUPPLY CHECK

Check fusible link **C**. For fusible link layout, refer to BR-45.

NG → **A** (See next page.)

OK

1. Disconnect connectors from control unit and ABS actuator. Check terminals for damage or loose connections. Then reconnect connectors.
2. Carry out self-diagnosis again.
Does warning lamp activate again?

No → Inspection end

Yes

GROUND CIRCUIT CHECK

Refer to "CONTROL UNIT GROUND" and "ACTUATOR MOTOR GROUND" in Ground Circuit Check, BR-58.

NG → Repair harness and connectors.

OK

A

SOLENOID VALVE POWER SUPPLY CHECK

1. Disconnect connector from ABS relay box.
2. Check voltage between ABS relay box 2-pin connector (body side) terminal **4** and ground.
Battery voltage should exist.

NG → Repair harness and connector.

OK

B

CIRCUIT CHECK

1. Disconnect control unit connector.
2. Check continuity between control unit connector terminals and ABS relay box 6-pin connector (body side) terminals.

Control unit	ABS relay box
37	6
2	2
30	10

Continuity should exist.

NG → Repair harness and connectors.

OK

SOLENOID VALVE RELAY CHECK

Refer to "SOLENOID VALVE RELAY" in Electrical Components Inspection, BR-76.






NG → Replace solenoid valve relay.

OK

B
(Go to next page.)


TROUBLE DIAGNOSES

Diagnostic Procedure 6 (Cont'd)



GI
MA
EM
LC
EC
FE
CL
WT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES



Diagnostic Procedure 7 POWER SUPPLY (Low voltage) (Malfunction code No. 57)

1. Disconnect control unit connectors. Check terminals for damage or loose connections. Then reconnect connectors.
2. Carry out self-diagnosis again.
Does warning lamp activate again?

No → Inspection end

Yes

A
CONTROL UNIT POWER SUPPLY CHECK
1. Disconnect control unit connector.
2. Check voltage between control unit connector terminal ① and ground.
Battery voltage should exist when ignition switch is turned ON.

NG → (A) (See below.)

OK

CONTROL UNIT GROUND CHECK
Refer to "CONTROL UNIT GROUND" in Ground Circuit Check, BR-58.

NG → Repair harness and connectors.

OK

Check control unit pin terminals for damage or the connection of control unit harness connector.
Reconnect control unit harness connector.
Then retest.

(A)

Check 7.5A fuse ⑫. Refer to EL section "POWER SUPPLY ROUTING".

NG → Replace fuse.

OK

Check continuity between battery and control unit connector terminal ①.

NG → Repair harness and connectors.

OK

Check battery. Refer to EL section "BATTERY".

Diagnostic Procedure 8 CONTROL UNIT (Malfunction code No. 71)


Carry out self-diagnosis after erasing self-diagnostic results, BR-49.

Does warning lamp indicate code No. 71 again?

Yes → Replace control unit.


No

Inspect the system according to the code No.



Diagnostic Procedure 9

SYMPTOM: Pedal vibration and noise




Note: ABS may operate and cause vibration under any of the following conditions.

- Applying brake gradually when shifting or operating clutch.
- Low friction (slippery) road.
- High speed cornering.
- Driving over bumps and pot holes.
- Engine speed is over 5,000 rpm with vehicle stopped.


CI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

Diagnostic Procedure 10

SYMPTOM: Long stopping distance





Note: Stopping distance may be larger than vehicles without ABS when road condition is slippery.



Diagnostic Procedure 11


SYMPTOM: Unexpected pedal action



TROUBLE DIAGNOSES

Diagnostic Procedure 12


SYMPTOM: ABS does not work.



Note: ABS does not work when vehicle speed is under 10 km/h (6 MPH).

Diagnostic Procedure 13

SYMPTOM: ABS works frequently.




TROUBLE DIAGNOSES

Electrical Components Inspection

WHEEL SENSOR

Check resistance for each sensor.


Resistance: 0.8 - 1.2 k Ω



ACTUATOR MOTOR RELAY

Condition	Continuity existence between terminals (30) and (87)
Battery voltage not applied between terminals (85) and (86).	No
Battery voltage applied between terminals (85) and (86).	Yes

While applying battery voltage to relay terminals, insert fuse into the circuit.



SOLENOID VALVE RELAY

Condition	Continuity existence between terminals (30) and (87a)	Continuity existence between terminals (30) and (87)
Battery voltage not applied between terminals (85) and (86).	Yes	No
Battery voltage applied between terminals (85) and (86).	No	Yes

While applying battery voltage to relay terminals, insert fuse into the circuit.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

BRAKE UNIT

Applied model	Without ABS		With ABS	
	GA16DE	SR20DE	GA16DE	SR20DE
	Standard	Standard	Option*	Option
Front brake				
Brake model	CL22VD	CL22VE	CL22VD	CL22VE
Cylinder bore diameter mm (in)	54.0 (2.126)			
Pad length x width x thickness mm (in)	106 x 39.5 x 11.0 (4.17 x 1.555 x 0.433)			
Rotor outer diameter x thickness mm (in)	232 x 18 (9.13 x 0.71)	247 x 18 (9.72 x 0.71)	232 x 18 (9.13 x 0.71)	247 x 18 (9.72 x 0.71)
Rear brake				
Brake model	LT18C	CL7HB		
Cylinder bore diameter mm (in)	15.87 (5/8)	30.23 (1-1/4)		
Lining or pad length x width x thickness mm (in)	172.8 x 30 x 4 (6.80 x 1.18 x 0.16)	94 x 29 x 10 (3.70 x 1.14 x 0.39)		
Drum inner diameter or rotor outer diameter x thickness mm (in)	180 (7.09)	234 x 7 (9.21 x 0.28)		
Master cylinder				
Cylinder bore diameter mm (in)	20.64 (13/16)	22.22 (7/8)		
Control valve				
Valve model	Dual proportioning valve built into master cylinder		Dual proportioning valve separated from master cylinder	
Split point [kPa (kg/cm ² , psi)] x reducing ratio	3,923 (40, 569) x 0.4	2,942 (30, 427) x 0.4	3,923 (40, 569) x 0.4	2,942 (30, 427) x 0.4
Brake booster				
Booster model	S205 or C205	M195T		
Diaphragm diameter mm (in)	205 (8.07)	Primary: 205 (8.07) Secondary: 180 (7.09)		
Recommended brake fluid	DOT 3			

*: Except E, XE models

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

DISC BRAKE

Unit: mm (in)

Brake model	Front	Rear
	CL22VD, CL22VE	CL7HB
Pad wear limit		
Minimum thickness	2.0 (0.079)	1.5 (0.059)
Rotor repair limit		
Minimum thickness	16.0 (0.630)	6.0 (0.236)
Maximum runout	0.07 (0.0028)	
Maximum thickness variation	0.02 (0.0008)	

DRUM BRAKE

Unit: mm (in)

Brake model	Rear
	LT18C
Lining wear limit	
Minimum thickness	1.5 (0.059)
Drum repair limit	
Maximum inner diameter	181 (7.13)
Out-of-round	0.03 (0.0012) or less

BRAKE PEDAL

Unit: mm (in)

Free height	
M/T	148 - 158 (5.83 - 6.22)
A/T	157 - 167 (6.18 - 6.57)
Depressed height	
[under force of 490 N (50 kg, 110 lb) with engine running]	See below.
Clearance between switches and pedal stopper bracket	0.3 - 1.0 (0.012 - 0.039)

Depressed height [Under force of 490 N (50 kg, 110 lb) with engine running]

Unit: mm (in)

M/T	75 (2.95) or more
A/T	85 (3.35) or more

PARKING BRAKE CONTROL

Brake type	Drum	Disc
Control type	Center lever	
Number of notches		
[under force of 196 N (20 kg, 44 lb)]	7 - 8	8 - 9
Number of notches when warning switch comes on	1 or less	