

SECTION **ST**

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS

PRECAUTIONS AND PREPARATION	2	Steering Wheel	10
Supplemental Restraint System (SRS)		Steering Column	11
“Air Bag”	2	MANUAL STEERING GEAR AND LINKAGE	
Precautions for Steering System	2	(Model R24N)	14
Special Service Tools	2	Removal and Installation	14
Commercial Service Tools	4	Disassembly	15
NOISE, VIBRATION AND HARSHNESS (NVH)		Inspection	15
TROUBLESHOOTING	5	Assembly and Adjustment	16
NVH Troubleshooting Chart	5	POWER STEERING GEAR AND LINKAGE	
ON-VEHICLE SERVICE	6	(Model PR24T)	19
Checking and Adjusting Drive Belts (For power		Removal and Installation	19
steering)	6	Disassembly	22
Checking Fluid Level	6	Inspection	22
Checking Fluid Leakage	6	Assembly	22
Bleeding Hydraulic System	7	POWER STEERING PUMP	24
Checking Steering Wheel Turning Force (For		Pre-disassembly Inspection	24
power steering)	7	Disassembly	25
Checking Steering Wheel Play	8	Inspection	25
Checking Neutral Position on Steering Wheel	8	Assembly	26
Front Wheel Turning Angle	8	SERVICE DATA AND SPECIFICATIONS (SDS)	27
Checking Gear Housing Movement	8	General Specifications	27
Checking Hydraulic System	9	Inspection and Adjustment	27
STEERING WHEEL AND STEERING COLUMN	10		

PRECAUTIONS AND PREPARATION

Supplemental Restraint System (SRS) "Air Bag"

The Supplemental Restraint System "AIR BAG", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision, which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.



Precautions for Steering System

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- For easier and proper assembly, place disassembled parts in order on a parts rack.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended ATF* to hydraulic parts. Petroleum jelly may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

*: Automatic Transmission Fluid type DEXRON™III or equivalent.







Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	Unit application		
		Manual steering	Power steering	
KV48102000 (J28822) End cover socket wrench	 NT168	Removing and installing rear cover	X	—
KV48100700 (J26364) Torque adapter	 NT169	Measuring pinion rotating torque	—	X

PRECAUTIONS AND PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Unit application			
		Manual steering	Power steering		
KV48101100 (J26364) Torque adapter	 NT169	Measuring pinion rotating torque	X	—	GI MA EM
ST27180001 (J25726-A) Steering wheel puller	 NT544	Removing and installing steering wheel	X	X	LC EC FE
HT72520000 (J25730-B) Ball joint remover	 NT546	Removing tie-rod and lower ball joint	X	X	CL MT AT
ST27091000 (J26357 and J26357-10) Pressure gauge	 NT547	Measuring oil pressure	—	X	FA RA
KV48102500 (J33914) Pressure gauge adapter	 NT542	Measuring oil pressure	—	X	BR ST RS
ST3127S000 ① GG91030000 (See J25765-A) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter	 NT541	Measuring turning torque	X	X	BT HA EL IDX

PRECAUTIONS AND PREPARATION

Commercial Service Tools

Tool name	Description	Unit application	
		Manual steering	Power steering
Power steering pump attachment	<p>Disassembling and assembling power steering pump</p> <p>Unit: mm (in)</p>	—	— (For power steering pump)

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the problem. If necessary, repair or replace these parts.

Symptom		POSSIBLE CAUSE AND SUSPECTED PARTS	Reference page																				
			ST-6	ST-7	ST-16, 27	ST-16, 27	ST-16, 22, 27	ST-6	ST-8	ST-7	ST-6	—	ST-13	ST-14	ST-13, 27	ST-11	ST-14	NVH in FA, RA section	NVH in FA section	NVH in FA section	NVH in FA section	NVH in BR section	
STEERING	Noise		X	X	X	X	X	X	X	X	X							X	X	X	X	X	
	Shake											X	X	X				X	X	X	X	X	
	Vibration											X	X	X	X	X		X	X		X		
	Shimmy											X	X	X		X	X	X	X	X			X
	Judder													X			X	X	X	X			X


GI
 MA
 EM
 LC
 EC
 EF
 CL
 MT
 AT
 FA
 RA
 BR

ST

RS
 BT
 HA
 EL
 IDX

Checking and Adjusting Drive Belts (For power steering)

Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").



Checking Fluid Level

Check fluid level with engine OFF.


Check fluid level referring to the scale on reservoir tank.

Use HOT range for fluid temperatures of 50 to 80°C (122 to 176°F).

Use COLD range for fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Automatic Transmission Fluid type DEXRON™III or equivalent.



Checking Fluid Leakage

Check the lines for improper attachment, leaks, cracks, damage, chafing or deterioration.

1. Run engine between idle speed and 1,000 rpm.

• Make sure fluid temperature in reservoir tank rises to 60 to 80°C (140 to 176°F).

2. Turn steering wheel right-to-left several times.

3. Hold steering wheel at each lock position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

4. If fluid leakage at any line is noticed, loosen flare nut and then retighten or tighten hose clamps.

• Do not overtighten flare nut as this can damage O-ring, washer and threads.



5. Check rack boots for accumulation of power steering fluid.

Bleeding Hydraulic System

1. Raise front end of vehicle until wheels are clear of the ground.
2. Add fluid into reservoir tank to specified level. Then quickly turn steering wheel fully to the right and left, lightly touch steering stoppers.
Repeat steering wheel operation until fluid level no longer decreases.
3. Start engine.
Repeat step 2.

- Incomplete air bleeding will cause the following to occur:
 - a. Air bubbles in reservoir tank
 - b. Clicking noise in power steering pump
 - c. Excessive buzzing in power steering pump

Fluid noise may occur in the valve or power steering pump. This is common when the vehicle is stationary or while turning the steering wheel slowly. This does not affect the performance or durability of the system.



Checking Steering Wheel Turning Force (For power steering)

1. Park vehicle on a level, dry surface and set parking brake.
2. Run engine at idle speed or 1,000 RPM.
3. Bring power steering fluid up to adequate operating temperature.
- **Make sure fluid temperature in reservoir tank reaches 60° to 80°C (140° to 176°F).**
- **Tires need to be inflated to normal pressure.**
4. Check steering wheel turning force when steering wheel has been turned 360° from the neutral position.

Steering wheel turning force:

39 N (4 kg, 9 lb) or less

5. If steering wheel turning force is out of specification, check rack sliding force.
 - a. Disconnect steering column lower joint and knuckle arms from the gear.
 - b. Start and run engine at idle to make sure steering fluid has reached normal operating temperature.
 - c. Pull tie-rod slowly to move it from neutral position to ± 11.5 mm (± 0.453 in) at speed of 3.5 mm (0.138 in)/s. Check that rack sliding force is within specification.


Average rack sliding force:

108 - 245 N (11 - 25 kg, 24 - 55 lb)

Maximum rack sliding force:

294 N (30 kg, 66 lb)

6. If rack sliding force is not within specification, refer to "Checking Hydraulic System", ST-9.
7. If rack sliding force is OK, inspect steering column. Refer to ST-13.




AST106

Checking Steering Wheel Play

- With wheels in a straight-ahead position, check steering wheel play.

Steering wheel play:
35 mm (1.38 in) or less

- If it is not within specification, check the following for loose or worn components.
 - a. Steering gear assembly
 - b. Steering column
 - c. Front suspension and axle



AST107

Checking Neutral Position on Steering Wheel

Pre-checking

- Make sure that wheel alignment is correct.


Wheel alignment:

Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").

- Verify that the steering gear is centered before removing the steering wheel.

Checking

1. Check that the steering wheel is in the neutral position when driving straight ahead.
2. If it is not in the neutral position, remove the steering wheel and reinstall it correctly.
3. If the neutral position is still not correct:
 - a. Loosen tie-rod lock nuts.
 - b. Move tie-rods in the opposite direction by the same amount on both left and right sides.
 This will compensate for error in the neutral position.



SMA127

Front Wheel Turning Angle

1. Rotate steering wheel all the way right and left; measure turning angle.


Turning angle of full turns:

Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").

2. If it is not within specification, check rack stroke.

Rack stroke "S":

Refer to SDS, ST-28.



SST663B

Checking Gear Housing Movement


1. Check the movement of steering gear housing during stationary steering on a dry paved surface.

- Apply a force of 49 N (5 kg, 11 lb) to steering wheel to check the gear housing movement.

Turn ignition key OFF while checking.

Movement of gear housing:
±2 mm (±0.08 in) or less

2. If movement exceeds the limit, replace mounting insulator after confirming proper installation of gear housing mounting brackets.



Checking Hydraulic System

Before starting, check belt tension, drive pulley and tire pressure.

1. Set Tool. Open shut-off valve. Then bleed air. Refer to "Bleeding Hydraulic System", ST-7.
2. Run engine at idle speed or 1,000 RPM.

Make sure fluid temperature in reservoir tank reaches 60 to 80°C (140 to 176°F).

WARNING:

Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, fluid pressure in the power steering pump will increase to maximum. This will raise the fluid temperature abnormally.

3. Check pressure with steering wheel fully turned to left and right positions with engine idling at 1,000 rpm.

CAUTION:

Do not hold the steering wheel in a locked position for more than 15 seconds.

Power steering pump maximum operating pressure:

**7,159 - 7,748 kPa
(73 - 79 kg/cm², 1,038 - 1,123 psi)**

- If pressure reaches maximum operating pressure, system is OK.
- If pressure increases above maximum operating pressure, check power steering pump flow control valve. Refer to ST-25.
- If power steering pressure is below maximum operating pressure, slowly close shut-off valve and check pressure.

CAUTION:

Do not close shut-off valve for more than 15 seconds.

- If pressure increases to maximum operating pressure, gear is damaged. Refer to "Removal and Installation", ST-19.
 - If pressure remains below maximum operating pressure, pump is damaged. Refer to "Disassembly", ST-25.
4. After checking hydraulic system, remove Tool and add fluid as necessary. Then completely bleed air out of system. Refer to "Bleeding Hydraulic System", ST-7.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX


STEERING WHEEL AND STEERING COLUMN

SEC. 484-488



AST201


- ① Air bag module
- ② Steering wheel
- ③ Spiral cable
- ④ Combination switch
- ⑤ Column covers
- ⑥ Steering column assembly
- ⑦ Lower joint




Steering Wheel

REMOVAL AND INSTALLATION

1. Remove driver air bag module.
Refer to RS section ["Driver Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].
2. Disconnect horn connector and remove steering wheel nut.



3. Remove steering wheel with Tool.
 - For installation, refer to RS section ["Driver Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].




Steering Column

REMOVAL

CAUTION:


- The rotation of the spiral cable (SRS "Air bag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.
- Remove the steering wheel before removing the steering lower joint to avoid damaging the SRS spiral cable. Refer to ST-10.

1. Remove steering wheel, refer to ST-10.
2. Remove instrument lower panel and dash lower reinforcement panel.
3. Remove steering column covers.
4. Disconnect electrical connectors from the ignition switch and combination switch.
5. Remove three screws securing combination switch and remove combination switch.
6. Remove key interlock cable (A/T models).
7. Remove the hole cover then remove bolt from lower joint.
8. Remove the steering column lower cover.
9. Remove four nuts securing steering column and remove steering column.



INSTALLATION

- When installing steering column, fingertighten all lower bracket and clamp retaining bolts; then tighten them securely. Do not apply undue stress to steering column.
- When attaching coupling joint, be sure tightening bolt faces cutout portion.



- Align slit of lower joint with projection on dust cover. Insert joint until surface A contacts surface B.


CAUTION:

After installation, turn steering wheel to make sure it moves smoothly. Ensure that the number of turns from the straight forward position to left and right locks are the same. Be sure that the steering wheel is in a neutral position when driving straight ahead.

STEERING WHEEL AND STEERING COLUMN

Steering Column (Cont'd)


SEC. 487-488



- ① Snap ring
- ② Washer
- ③ O-ring

- ④ Steering column shaft
- ⑤ Steering column lower cover
- ⑥ Jacket tube assembly

- ⑦ Spring
- ⑧ Combination switch




DISASSEMBLY AND ASSEMBLY


- When disassembling and assembling, unlock steering lock with key.
- Remove combination switch.
- Ensure that rounded surface of snap ring faces toward bearing when snap ring is installed.
- Install snap ring on upper shaft with a suitable tool.

STEERING WHEEL AND STEERING COLUMN


Steering Column (Cont'd)



- Steering lock
- a. Break self-shear type screws with a drill or other appropriate tool.




- b. Install self-shear type screws, then tighten until screw heads break off.



Tilt mechanism

- After installing steering column, check tilt mechanism operation.



INSPECTION

- When steering wheel does not turn smoothly, check the steering column as follows and replace damaged parts.
 - a. Check column bearings for damage or unevenness. Lubricate with recommended multi-purpose grease or replace steering column as an assembly, if necessary.
 - b. Check jacket tube for deformation or breakage.
- When the vehicle is involved in a light collision, check column length "L". If it is not within specifications, replace steering column as an assembly.

Column length "L":

535.9 - 538.1 mm (21.10 - 21.18 in)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

MANUAL STEERING GEAR AND LINKAGE (Model R24N)

Removal and Installation




- | | | |
|---------------|---------------------------------|---------------------------|
| ① Hole cover | ③ Manual steering gear assembly | ⑤ Rack mounting insulator |
| ② Lower joint | ④ Steering gear mounting clamp | ⑥ Cotter pin |



CAUTION:

The rotation of the spiral cable (SRS "Airbag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.

- Detach tie-rod outer sockets from knuckle arms with Tool.




- Initially, tighten nut on tie-rod outer socket and knuckle arm to 29 to 39 N·m (3 to 4 kg-m, 22 to 29 ft-lb).
- Tighten nut further to align nut groove with the first pin hole so cotter pin can be installed.

CAUTION:

Tightening torque must not exceed 49 N·m (5 kg-m, 36 ft-lb).

Disassembly

SEC. 480



- | | | |
|-----------------------|-------------------------|------------------------|
| ① Guide chip | ⑩ Wave washer | ⑱ Tie-rod inner socket |
| ② Rear cover lock nut | ⑪ Adjusting screw | ⑲ Lock plate |
| ③ Dust seal | ⑫ Adjusting lock nut | ⑳ Spacer |
| ④ Rear cover | ⑬ Gear housing assembly | ㉑ Rack |
| ⑤ Pinion bearing | ⑭ Boot clamp | ㉒ Spacer |
| ⑥ Pinion assembly | ⑮ Boot | ㉓ Lock plate |
| ⑦ Retainer | ⑯ Boot band | ㉔ Tie-rod inner socket |
| ⑧ Retaining spring | ⑰ Boot clamp | ㉕ Tie-rod outer socket |
| ⑨ Plain washer | | |

Inspection

BOOT

Check condition of boot. If it is cracked excessively, replace it.


RACK

Thoroughly examine rack gear. If rack gear is damaged, cracked or worn, replace.

PINION ASSEMBLY

- Thoroughly examine pinion gear. If pinion gear is damaged, cracked or worn, replace.
- Check that all bearings roll freely. Ensure that balls, rollers and races in the bearing assemblies are not cracked, pitted or worn. Replace if necessary.

MANUAL STEERING GEAR AND LINKAGE (Model R24N)



Inspection (Cont'd)

TIE-ROD OUTER AND INNER SOCKETS


- Check outer and inner ball joints for swinging force "A" and axial end play "C".

Refer to SDS, ST-27.

- Check outer ball joint for rotating torque "B".

Refer to SDS, ST-27.


- Check condition of dust cover. If excessively cracked, replace it.




Assembly and Adjustment

STEERING GEAR

1. Insert rack gear from gear housing side.
2. Set rack gear in neutral position.



3. Insert pinion assembly, then set guide chip at neutral position as shown in figure. Pinion rack gear should be held in place.




4. Install rear cover with Tool and secure with lock nut.

Tool number: KV48102000 (J28822)

- Before installing rear cover, apply locking sealant to threaded areas. Do not allow sealant to get into pinion bearing.
- Apply a coat of multi-purpose grease to sealing lips of dust seal.

CAUTION:

Wrap cellophane tape around pinion gear end when installing dust seal.





5. Insert retainer, spring, plain washer and wave washer. Then, install adjusting screw.

- Apply a coat of locking sealant to threaded areas of retainer cover.

MANUAL STEERING GEAR AND LINKAGE (Model R24N)

Assembly and Adjustment (Cont'd)



6. Adjust pinion rotating torque as follows:
 - a. Set gears to neutral position.
 - b. Loosen lock nut.
 - c. Tighten adjusting screw to a torque of 9.8 N·m (100 kg-cm, 87 in-lb).
 - d. Loosen adjusting screw and retighten it to a torque of 9.8 N·m (100 kg-cm, 87 in-lb).
 - e. Loosen adjusting screw within 60° until specified pinion torque is obtained. Ensure that pinion-to-rack play is less than 0.1 mm (0.004 in) when 15 N·m (1.5 kg-m, 11 ft-lb) torque is applied to pinion.
 - f. Prevent adjusting nut from rotating and tighten lock nut to specified torque 39 to 59 N·m (4 to 6 kg-m, 29 to 43 ft-lb), while holding adjusting screw in place.
 - g. While slowly rotating pinion in the ±100° range from neutral position, make sure its rotating torque is within the specifications.

Within ±100° from the neutral position:

Average rotating torque

0.7 - 1.2 N·m (7 - 12 kg-cm, 6.1 - 10.4 in-lb)

Maximum torque deviation

0.3 N·m (3 kg-cm, 2.6 in-lb)

Except for above measuring range:


Maximum rotating torque

1.5 N·m (15 kg-cm, 13 in-lb)

Maximum force deviation

0.5 N·m (5 kg-cm, 4.3 in-lb)


- h. If pinion rotating torque is not within the specifications, readjust.
- If pinion rotating torque is outside the specifications after adjustment has been made, replace retainer spring.
- If pinion rotating torque is still out of specifications after replacing retainer spring, replace gear assembly.



7. Install new lock plate.
 - Attach lock plate (2) to side rod inner socket (1).
 - Apply locking sealant to inner socket threads (3). Screw inner socket into rack (4) and tighten to specified torque.
 - Clinch two places of lock plate at rack's groove.

CAUTION:

To prevent scratching the boot, remove burrs from lock plate.



TIE-ROD AND BOOT


1. Install boot on tie-rod inner socket.
2. Apply locking sealant to threaded portion of inner socket. Install tie-rod inner socket to rack end together with new lock plate.
3. Install lock nut and outer socket to inner socket. Adjust tie-rod length "L" and tighten lock nut.

Tie-rod length "L": Refer to SDS, ST-27.


Screwed length "l": 32 mm (1.26 in) or more

MANUAL STEERING GEAR AND LINKAGE (Model R24N)


Assembly and Adjustment (Cont'd)




4. Measure rack stroke.
Measure stroke "S":
Refer to SDS, ST-28.



5. Before installing boot, coat the contact surfaces between boot and tie-rod with grease.



6. Install boot clamps.
- To install, wrap boot clamp around boot groove twice. Use a screwdriver to tighten clamps. Twist rings at both ends 4 to 4-1/2 turns while pulling them with a force of approx. 98 N (10 kg, 22 lb).
 - Do not cross wire on boot.




- Bend twisted end of boot clamp as shown at left. (This will prevent interference with other parts.)

POWER STEERING GEAR AND LINKAGE (Model PR24T)

Removal and Installation

SEC. 492




AST147

- ① Hole cover
- ② Gear and linkage assembly
- ③ Cotter pin
- ④ Rack mounting insulator
- ⑤ Gear housing mounting bracket

CAUTION:

The rotation of the spiral cable (SRS "Air bag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead position. Do not rotate the steering column while the steering gear is removed.


- Loosen upper clamp on dust boot in engine compartment.
- Remove lower bolt from coupling joint.
- Detach tie-rod outer sockets from knuckle arms with Tool.




AFA089

POWER STEERING GEAR AND LINKAGE (Model PR24T)

Removal and Installation (Cont'd)



- After removing steering gear from vehicle, mark pinion shaft and pinion housing to record neutral position.
- To install, set left and right dust boots to equal deflection. Align matching marks on pinion shaft and pinion housing.



- The O-ring in the low-pressure line ① is larger than that in the high-pressure line ②. Take care to install the proper O-ring.
- Observe specified tightening torque when tightening high-pressure and low-pressure line flare nuts. Excessive tightening can damage threads or O-ring.


Flare nut tightening torque:

Low-pressure side ①

27 - 39 N·m (2.8 - 4.0 kg·m, 20 - 29 ft·lb)

High-pressure side ②


15 - 25 N·m (1.5 - 2.5 kg·m, 11 - 18 ft·lb)



- Initially, tighten nut on tie-rod outer socket and knuckle arm to 29 to 39 N·m (3 to 4 kg·m, 22 to 29 ft·lb). Then tighten further to align nut groove with first pin hole so that cotter pin can be installed.

CAUTION:


Tightening torque must not exceed 49 N·m (5 kg·m, 36 ft·lb).



- Tighten gear housing mounting bracket bolts in the order shown.

POWER STEERING GEAR AND LINKAGE (Model PR24T)

SEC. 492



- ① Steering gear
- ② Gear housing tube
- ③ Boot clamp


- ④ Dust boot
- ⑤ Boot band
- ⑥ Tie-rod inner socket

- ⑦ Tie-rod
- ⑧ Tie-rod outer socket
- ⑨ Cotter pin

AST192

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER STEERING GEAR AND LINKAGE (Model PR24T)



Disassembly


1. Prior to disassembling, measure pinion rotating torque.
Within $\pm 100^\circ$ from the neutral position:
Average rotating torque
0.3 - 1.3 N·m (3 - 13 kg·cm, 2.6 - 11.3 in·lb)
Maximum torque deviation
0.6 N·m (6 kg·cm, 5.2 in·lb)
Except for above measuring range:
Maximum rotating torque
1.9 N·m (19 kg·cm, 16 in·lb)
Maximum force deviation
0.6 N·m (6 kg·cm, 5.2 in·lb)
 - If pinion rotating torque is not within the specifications, replace steering gear assembly.
 - Before measuring, disconnect gear housing tube and drain fluid.
 - Use soft jaws when holding steering gear housing. Handle gear housing carefully, as it is made of aluminum. Do not grip cylinder in a vise.
2. Remove tie-rod outer sockets and boots.
3. Remove tie-rod inner sockets.

Inspection

Thoroughly clean all parts in cleaning solvent or automatic transmission fluid type DEXRON™III or equivalent. Blow dry with compressed air, if available.

BOOT

- Check condition of boot. If cracked excessively, replace it.
- Check boots for accumulation of power steering fluid.



TIE-ROD OUTER AND INNER SOCKETS


- Check outer and inner ball joints for swinging force "A" and axial end play "C".
Refer to SDS, ST-27.
- Check outer ball joint for rotating torque "B".
Refer to SDS, ST-27.
- Check condition of dust cover. If excessively cracked, replace outer tie-rod.

Assembly


1. Install tie-rod inner sockets, dust boots and outer sockets.
Apply locking sealant to inner socket threads.

POWER STEERING GEAR AND LINKAGE (Model PR24T)


Assembly (Cont'd)




2. Tighten outer socket lock nut.
Tie-rod length "L":
Refer to SDS, ST-27.



3. Measure rack stroke.
Rack stroke "S":
Refer to SDS, ST-28.



4. Before installing boot, coat the contact surfaces between boot and tie-rod with grease.



5. Install boot clamps.
 - Install large boot clamp using suitable tool and crimp securely.
 - Install small boot clamp as shown.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX

POWER STEERING PUMP



- | | | |
|-----------------|--------------------|-------------------------------|
| ① Pulley | ⑩ Connector | ⑱ Vane |
| ② Snap ring | ⑪ Washer | ⑲ Rotor |
| ③ Drive shaft | ⑫ Joint | ⑳ Pin |
| ④ Oil seal | ⑬ Connector bolt | ㉑ Cam ring |
| ⑤ Suction pipe | ⑭ Front housing | ㉒ Gasket |
| ⑥ O-ring | ⑮ O-ring | ㉓ Rear housing |
| ⑦ Spring | ⑯ O-ring | ㉔ Mounting bracket |
| ⑧ Control valve | ⑰ Front side plate | ㉕ Power steering pump bracket |
| ⑨ O-ring | | |



Pre-disassembly Inspection

Disassemble the power steering pump only if the following items are found:


- Fluid leak from any point shown in the figure.
- Deformed or damaged pulley.
- Poor performance.

POWER STEERING PUMP


Disassembly

CAUTION:


- Parts which can be disassembled are strictly limited. Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- When disassembling and reassembling, do not let foreign matter enter or contact the parts.



- Remove snap ring, then remove drive shaft.
- Be careful not to drop drive shaft.



- Remove oil seal.
- Be careful not to damage front housing.



- Remove connector and flow control valve with spring.
- Be careful not to drop flow control valve.

Inspection

- If pulley is cracked or deformed, replace it.
- If an oil leak is found around pulley shaft oil seal, replace the seal.
- If serration on pulley or pulley shaft is deformed or worn, replace it.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX


POWER STEERING PUMP




Assembly

Assemble power steering pump, noting the following instructions:


- Make sure O-rings and oil seal are properly installed.
- Always install new O-rings and oil seal.
- Be careful of oil seal direction.
- Cam ring, rotor and vanes must be replaced as a set if necessary.
- Coat each part with ATF when assembling.



- Pay attention to the direction of rotor.



- When assembling vanes to rotor, rounded surfaces of vanes must face cam ring side.



- Insert pin ② into pin groove ① of front housing and front side plate. Then install cam ring ③ as shown at left.

Cam ring:

D_1 is less than D_2

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Steering model	Manual steering	Power steering
Steering gear type	R24N	PR24T
Steering overall gear ratio	23.2	17.5
Turns of steering wheel (Lock to lock)	4.24 - 4.37	3.02
Steering column type	Collapsible, tilt	

GI

MA

EM

LC


Inspection and Adjustment

GENERAL

Steering wheel axial play mm (in)	0 (0)
Steering wheel play limit mm (in)	35 (1.38)
Maximum movement of gear housing mm (in)	±2 (±0.08)

STEERING COLUMN

Steering column length "L" mm (in)	Airbag
	535.9 - 538.1 (21.10 - 21.18)



STEERING GEAR AND LINKAGE

Steering gear type	R24N	PR24T
Tie-rod outer ball joint		
Swinging force "A" at cotter pin hole N (kg, lb)	6.9 - 64.7 (0.7 - 6.6, 1.5 - 14.6)	
Rotating torque "B" N-m (kg-cm, in-lb)	0.3 - 2.9 (3 - 30, 2.6 - 26.0)	
Axial end play limit "C" mm (in)	Less than 0.5 (0.020)	
Tie-rod inner ball joint		
Swinging force*1 "A" N (kg, lb)	0.2 - 215.8 (0.02 - 22, 0.04 - 48.5)	
Axial end play limit "C" mm (in)	0.4 (0.016)	
Tie-rod standard length "L" mm (in)	187 (7.36)	140.6 (5.54)

EC

FE

CL

MT


AT

FA

RA

BR

ST



*1: Measuring point of swing force

RS

BT

HA

EL


IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

STEERING GEAR AND LINKAGE (Cont'd)

Steering gear type	R24N	PR24T
Rack stroke "S" mm (in)	69-71 (2.72 - 2.80)	65 (2.56)



AST132

Steering gear type	R24N	PR24T
Retainer adjustment		
Adjusting screw		
Initial tightening torque N-m (kg-cm, in-lb)	9.8 (100, 87)	No adjustment
Retightening torque after loosening N-m (kg-cm, in-lb)	—	No adjustment
Tightening torque after gear has settled N-m (kg-cm, in-lb)	—	No adjustment
Returning angle degree	Less than 60° [Within play of 0.1 mm (0.004 in)/15 N-m (1.5 kg-m, 11 ft-lb)]	No adjustment
Pinion gear preload without gear oil N-m (kg-cm, in-lb)		
Within ±100° from the neu- tral position		
Average rotating torque	0.7 - 1.2 (7 - 12, 6.1 - 10.4)	0.3 - 1.3 (3 - 13, 2.6 - 11.3)
Maximum torque deviation	0.3 (3, 2.6)	0.6 (6, 5.2)
Except above range		
Maximum rotating torque	1.5 (15, 13)	1.9 (19, 16)
Maximum torque deviation	0.5 (5, 4.3)	0.6 (6, 5.2)

POWER STEERING

Steering gear type	PR24T
Rack sliding force N (kg, lb)	
Under normal operating oil pressure	
Range within ±11.5 mm (±0.453 in) from the neutral position	108 - 245 (11 - 25, 24 - 55)
Except above range	Not more than 294 (30, 66)
Steering wheel turning force (Measured at one full turn from the neutral position) N (kg, lb)	39 (4, 9) or less
Fluid capacity (Approximate) ℓ (US qt, Imp qt)	1 (1-1/8, 7/8)
Power steering pump maximum pressure kPa (kg/cm ² , psi)	7,649 - 8,238 (78 - 84, 1,109 - 1,194)