

SECTION **MT**

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX








CONTENTS

PREPARATION	2	DISASSEMBLY	13
Special Service Tools.....	2	REPAIR FOR COMPONENT PARTS	16
Commercial Service Tools.....	4	Input Shaft and Gears.....	16
NOISE, VIBRATION AND HARSHNESS (NVH)		Mainshaft and Gears.....	19
TROUBLESHOOTING	5	Final Drive.....	25
NVH Troubleshooting Chart.....	5	Shift Control Components.....	27
ON-VEHICLE SERVICE	6	Case Components.....	29
Replacing Oil Seal.....	6	ADJUSTMENT	31
Position Switch Check.....	7	Differential Side Bearing Preload.....	31
REMOVAL AND INSTALLATION	8	ASSEMBLY	33
TRANSAXLE GEAR CONTROL	9	SERVICE DATA AND SPECIFICATIONS (SDS)	37
MAJOR OVERHAUL	10	General Specifications.....	37
Case Components.....	10	Inspection and Adjustment.....	38
Gear Components.....	11		
Shift Control Components.....	12		

PREPARATION








Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV38107700 (J39027) Preload adapter		Measuring turning torque of final drive assembly Selecting differential side bearing adjusting shim (Use with KV38106000.) NT087
KV38106000 (J34291-A) Height gauge adapter (differential side bearing)		Selecting differential side bearing adjusting shim (Use with KV38107700.) NT089
KV32101000 (J25689-A) Pin punch		Removing and installing retaining pin NT410 a: 4 mm (0.16 in) dia.
ST22730000 (J25681) Puller		Removing 5th main gear NT411 a: 82 mm (3.23 in) dia. b: 30 mm (1.18 in) dia.
ST30031000 (J22912-01) Puller		Removing 3rd and 4th synchronizer Measuring wear of 2nd & 3rd baulk ring NT411 a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia.
ST30021000 (J22912-01) Puller		Removing 5th synchronizer NT411 a: 110 mm (4.33 in) dia. b: 68 mm (2.68 in) dia.
ST33290001 (J34286) Puller		Removing differential oil seal Removing differential side bearing outer race NT414 a: 250 mm (9.84 in) b: 160 mm (6.30 in)



PREPARATION

Special Service Tools (Cont'd)




Tool number (Kent-Moore No.) Tool name	Description	
KV31103000 (—) Drift	 <p style="text-align: center;">NT106</p>	GI MA EM
ST35325000 (—) Drift handle	 <p style="text-align: center;">NT416</p>	LC EC FE
KV38102100 (J25803-01) Drift	 <p style="text-align: center;">NT084</p>	CL MT
ST33200000 (J26082) Drift	 <p style="text-align: center;">NT091</p>	AT FA
ST22350000 (J25678-01) Drift	 <p style="text-align: center;">NT065</p>	RA BR ST
ST22452000 (—) Drift	 <p style="text-align: center;">NT065</p>	RS BT
ST37750000 (J25863-01) Drift	 <p style="text-align: center;">NT065</p>	HA EL IDX

PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
ST30621000 (J25742-5) Drift	<div style="text-align: center;">  </div> <p style="text-align: center;">NT073</p> <p style="text-align: right;">Installing differential side bearing outer race (Use with ST30611000.)</p> <p style="text-align: right;">a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.</p>
ST30611000 (J25742-1) Drift handle	<div style="text-align: center;">  </div> <p style="text-align: center;">NT419</p> <p style="text-align: right;">(Use with ST30621000.)</p> <p style="text-align: right;">a: 15 mm (0.59 in) b: 335 mm (13.19 in) c: 25 mm (0.98 in) dia. d: M12 x 1.5P</p>

Commercial Service Tools

Tool name	Description
Puller	<div style="text-align: center;">  </div> <p style="text-align: center;">NT077</p> <p style="text-align: right;">Removing input shaft front bearing Removing mainshaft rear bearing</p>
Drift	<div style="text-align: center;">  </div> <p style="text-align: center;">NT065</p> <p style="text-align: right;">Installing differential side bearing inner race</p> <p style="text-align: right;">a: 56 mm (2.20 in) dia. b: 50.5 mm (1.988 in) dia.</p>
Drift	<div style="text-align: center;">  </div> <p style="text-align: center;">NT065</p> <p style="text-align: right;">Installing striking rod oil seal</p> <p style="text-align: right;">a: 38 mm (1.50 in) dia. b: 32 mm (1.26 in) dia.</p>

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the problem. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

MANUAL TRANSAXLE

Reference page		Refer to MA section ("Checking M/T Oil", "CHASSIS AND BODY MAINTENANCE").												
SUSPECTED PARTS (Possible cause)		Oil (Level low)	Oil (Wrong)	Oil (Level too high)	Gasket (Damaged)	Oil seal (Worn or damaged)	O-ring (Worn or damaged)	Control rod (Worn)	Check plug return spring and check ball (Worn or damaged)	Shift fork (Worn)	Gear (Worn or damaged)	Bearing (Worn or damaged)	Baulk ring (Worn or damaged)	Insert spring (Damaged)
Symptom	Noise	1	2								3	3		
	Oil leakage		3	1	2	2	2							
	Hard to shift or will not shift		1	1				2					3	3
	Jumps out of gear							1	2	3	3			

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL


IDX





Replacing Oil Seal

DIFFERENTIAL OIL SEAL

1. Drain gear oil from transaxle.
2. Remove drive shafts. Refer to FA section ("Removal", "FRONT AXLE — Drive Shaft").
3. Remove differential oil seal with Tool.




4. Install differential oil seal.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts. Refer to FA section ("Installation", "FRONT AXLE — Drive Shaft").



STRIKING ROD OIL SEAL


1. Remove transaxle control rod from yoke.
2. Remove retaining pin.
 - **Be careful not to damage boot.**



3. Remove striking rod oil seal.

ON-VEHICLE SERVICE

Replacing Oil Seal (Cont'd)



4. Install striking rod oil seal.

- Apply multi-purpose grease to seal lip of oil seal before installing.

GI

MA

EM

LC

Position Switch Check


- Check continuity.

EC

Switch	Gear position	Continuity
Back-up lamp switch	Reverse	Yes
	Except reverse	No
Neutral position switch	Neutral	Yes
	Except neutral	No

FE

CL



MT

AT

FA

RA

BR

SI

RS

BT

HA

EL

IDX

REMOVAL AND INSTALLATION



Removal

CAUTION:

Before separating transaxle from engine, remove the crankshaft position sensor (OBD) from transaxle.

Be careful not to damage sensor edge or ring gear teeth.


1. Remove battery negative terminal.
2. Remove air cleaner housing.
3. Disconnect clutch control cable.
4. Disconnect back-up lamp switch, neutral position switch, vehicle speed sensor and ground harness connectors.
5. Remove starter motor from transaxle.
6. Remove crankshaft position sensor (OBD) from transaxle.
- Be careful not to damage sensor tip.



7. Remove shift control rod from transaxle.
8. Drain gear oil from transaxle.
9. Remove drive shafts from transaxle. Refer to FA section ("Removal", "FRONT AXLE — Drive Shaft").
10. Support the transaxle with a jack.
11. Remove LH and rear mounts.
12. Remove bolts securing transaxle.
13. Lower transaxle.

SR engine models

- ⊙ M/T to engine
- ⊗ Engine to M/T




Installation

- Tighten starter motor to transaxle.
⊙: 41 - 52 N·m (4.2 - 5.3 kg-m, 30 - 38 ft-lb)
- Tighten LH and rear mounts to the specified torque. Refer to EM section ("ENGINE REMOVAL").
- Install transaxle and any part removed.
- Check clutch cable adjustment. Refer to CL section ("Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT").

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	"l" mm (in)
①	70 - 79 (7.1 - 8.1, 51 - 59)	55 (2.17)
②	70 - 79 (7.1 - 8.1, 51 - 59)	65 (2.56)
③	31 - 42 (3.2 - 4.3, 23 - 31)	35 (1.38)
④	31 - 42 (3.2 - 4.3, 23 - 31)	45 (1.77)

TRANSAXLE GEAR CONTROL

SEC. 341



- ① Shift lever knob
- ② Boot
- ③ Shift lever socket
- ④ Shift lever
- ⑤ Bearing seat spring
- ⑥ Seat
- ⑦ Bushing
- ⑧ O-ring

- ⑨ Hand lever socket
- ⑩ Plate bolt
- ⑪ Transaxle hole cover
- ⑫ Support rod
- ⑬ Plate
- ⑭ Collar
- ⑮ Bushing
- ⑯ Support rod bracket

- ⑰ Collar
- ⑱ Bushing
- ⑲ Shift control rod
- ⑳ Return spring
- ㉑ Return spring rubber
- ㉒ Holder bracket

MT-9

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

AMT124


EL

IDX

MAJOR OVERHAUL

Gear Components


SEC. 322




- | | | |
|-----------------------------|--|---|
| ① Reverse idler gear | ②② 1st main gear | ④③ 5th main gear |
| ② Reverse idler bushing | ②③ Baulk ring | ④④ Spacer |
| ③ Reverse idler spacer | ②④ 1st gear needle bearing | ④⑤ Mainshaft rear bearing |
| ④ Snap ring | ②⑤ Reverse main gear (Coupling sleeve) | ④⑥ Mainshaft C-ring |
| ⑤ Spacer | ②⑥ Insert spring | ④⑦ C-ring holder |
| ⑥ Input shaft front bearing | ②⑦ 1st & 2nd synchronizer hub | ④⑧ Snap ring |
| ⑦ Input shaft | ②⑧ 2nd outer baulk ring | ④⑨ Snap ring |
| ⑧ 5th gear needle bearing | ②⑨ 2nd synchronizer cone | ⑤① Differential side bearing |
| ⑨ 5th input gear | ②⑩ 2nd inner baulk ring | ⑤② Speedometer stopper |
| ⑩ Baulk ring | ③① 2nd main gear | ⑤③ Speedometer drive gear |
| ⑪ Coupling sleeve | ③② 2nd & 3rd bushing | ⑤④ Differential case |
| ⑫ Spread spring | ③③ 3rd main gear | ⑤⑤ Differential side bearing adjusting shim |
| ⑬ Shifting insert | ③④ 3rd inner baulk ring | ⑤⑥ Final gear |
| ⑭ 5th synchronizer hub | ③⑤ 3rd synchronizer cone | ⑤⑦ Lock pin |
| ⑮ Spread spring | ③⑥ 3rd outer baulk ring | ⑤⑧ Pinion mate thrust washer |
| ⑯ 5th stopper | ③⑦ Coupling sleeve | ⑤⑨ Pinion mate gear |
| ⑰ Snap ring | ③⑧ 3rd & 4th synchronizer hub | ⑥① Side gear thrust washer |
| ⑱ Input shaft rear bearing | ③⑨ Insert spring | ⑥② Side gear |
| ⑲ Mainshaft front bearing | ④① Baulk ring | ⑥③ Pinion mate shaft |
| ⑳ Steel ball | ④② 4th main gear | |
| ㉑ Mainshaft | ④③ 4th bushing | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


DISASSEMBLY




1. Remove case cover.




2. Remove mainshaft bearing snap ring.



3. Remove transmission case while slightly tilting it to prevent 5th shift fork from interfering with transmission case.



4. Draw out reverse idler spacer and fork shaft.



5. Remove 5th and 3rd & 4th shift forks.
● Be careful not to lose shifter caps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX

DISASSEMBLY




6. Remove control bracket with 1st & 2nd shift fork.



7. Remove gear components from clutch housing.

a. Remove input shaft front bearing retainer securing bolts.




b. Remove input shaft with bearing retainer, mainshaft assembly and reverse idler gear.

- **Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.**


- **Do not draw out reverse idler shaft from clutch housing because these fittings will be loose.**

- **When removing input shaft, be careful not to scratch oil seal lip with shaft spline.**

c. Remove final drive assembly.





8. Remove oil pocket, shift check ball, shift check spring and check ball plug.



9. Drive retaining pin out of striking lever. Remove striking rod, striking lever and striking interlock.

- **Select a position where retaining pin does not interfere with clutch housing when removing retaining pin.**

DISASSEMBLY



- Be careful not to damage oil seal lip when removing striking rod. If necessary, tape edges of striking rod.

10. Remove reverse check plug, then detach reverse check spring and check balls.

- If the smaller ball does not come out, remove it together with check sleeve assembly.

11. Remove check sleeve assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears


DISASSEMBLY

1. Before disassembly, check 5th input gear end play.


Gear end play:

0.18 - 0.31 mm (0.0071 - 0.0122 in)


- If not within specification, disassemble and check contact surface of gear, shaft and hub. Check clearance of snap ring groove. Refer to "ASSEMBLY", MT-17.




2. Remove snap ring and 5th stopper.




3. Remove 5th synchronizer, 5th input gear and 5th gear needle bearing.



4. Remove snap ring of input shaft front bearing and spacer.



5. Remove input shaft front bearing.
6. Remove bearing retainer.



REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)

INSPECTION

Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST



RS

BT

HA


EL

IDX



5th synchronizer

- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.



- Measure clearance between baulk ring and gear.


Clearance between baulk ring and gear:

Standard

0.9 - 1.5 mm (0.035 - 0.059 in)


Wear limit

0.7 mm (0.028 in)



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.




ASSEMBLY


1. Assemble 5th synchronizer.

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)



- Be careful not to hook front and rear ends of spread spring to the same insert.



2. Install bearing retainer.
3. Press on input shaft front bearing.
4. Install spacer.




5. Select and install snap ring that gives proper clearance of input shaft groove.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Snap rings of input shaft front bearing:

Refer to SDS, MT-38.




- Be sure to replace 5th gear synchronizer hub with new one when it is removed.

6. Install 5th gear needle bearing, 5th input gear, 5th synchronizer and 5th stopper.

- Input shaft must be vertical to press on synchronizer hub.

7. Measure gear end play as a final check. Refer to "DISASSEMBLY", MT-16.




8. Select and install snap ring that gives proper clearance of input shaft groove.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Snap ring of 5th synchronizer:

Refer to SDS, MT-38.



Mainshaft and Gears

DISASSEMBLY

1. Before disassembly, measure gear end play.

Gear end play:

1st main gear

0.18 - 0.31 mm (0.0071 - 0.0122 in)

2nd, 3rd, 4th main gear

0.20 - 0.30 mm (0.0079 - 0.0118 in)

- If end play is not within the specified limit, disassemble and check the parts. Refer to "ASSEMBLY", MT-22.
2. Remove mainshaft rear bearing snap ring, C-ring holder and mainshaft C-rings.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST




RS

BT


HA

EL

IDX




3. Remove mainshaft rear bearing and spacer.




4. Remove 5th main gear.

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




- Remove 4th main gear, 4th bushing and steel ball.
 - Be careful not to lose steel ball.




- Remove 3rd & 4th synchronizer and 3rd main gear.



- Remove 2nd & 3rd bushing and 2nd main gear.
 - Be careful not to lose the steel ball.



- Remove 1st & 2nd synchronizer hub and 1st main gear.



INSPECTION


Gear and shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.


REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)

Synchronizer



- Check spline portion of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for deformation.



- Measure clearance between baulk ring and gear.
Clearance between baulk rings and gears, for 1st and 4th gear only:

Standard


1st 0.95 - 1.45 mm (0.0374 - 0.0571 in)

4th 0.9 - 1.45 mm (0.0354 - 0.0571 in)

Wear limit

0.7 mm (0.028 in)

- 2nd and 3rd gears have inner and outer baulk rings and so have different measurements.



- Measure wear of 2nd and 3rd baulk rings.
 - Place inner baulk ring in position on synchronizer cone.
 - Hold baulk ring evenly against synchronizer cone and measure distance "A".
 - Place outer baulk ring in position on synchronizer cone.
 - Hold baulk ring evenly against synchronizer cone and measure distance "B".

Standard:

Inner-A 0.7 - 0.9 mm (0.028 - 0.035 in)

Outer-B 0.6 - 1.1 mm (0.024 - 0.043 in)

Wear limit:

0.2 mm (0.008 in)


- If distance "A" or "B" is smaller than the wear limit, replace baulk ring.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)


Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **The mainshaft front bearing cannot be reused. It must be replaced once removed.**




ASSEMBLY


1. Install 1st gear needle bearing, 1st main gear and baulk ring.
2. Press on 1st & 2nd synchronizer hub.




- **Ensure correct fitting of 1st & 2nd synchronizer hub.**



3. Install 2nd synchronizer cone, outer & inner baulk ring and reverse main gear (coupling sleeve).







4. Install steel ball, 2nd main gear, 2nd & 3rd bushing.
 - **Apply gear oil to 2nd & 3rd bushing before installing it.**
 - **Apply multi-purpose grease to steel ball before installing it.**
 - **2nd & 3rd bushing has a groove in which steel ball fits.**



REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



5. Install 3rd main gear, synchronizer cone, outer & inner baulk ring.
6. Press on 3rd & 4th synchronizer hub.

- Ensure correct fitting of 3rd & 4th synchronizer hub.
7. Install 3rd & 4th coupling sleeve and 4th baulk ring.

8. Install steel ball, 4th bushing and 4th main gear.
- Apply multi-purpose grease to steel ball before installing it.
 - 4th bushing has a groove in which steel ball fits.

9. Press on 5th main gear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)





10. Select proper mainshaft bearing spacer to give correct bearing distance.

Bearing distance "C":


230.15 - 230.25 mm (9.0610 - 9.0649 in)

Spacers available:

Refer to SDS, MT-39.



11. Press on mainshaft rear bearing.




12. Select and install mainshaft C-ring that gives proper clearance of groove in mainshaft.

Allowable clearance of groove:

0 - 0.1 mm (0 - 0.004 in)

Mainshaft C-rings:


Refer to SDS, MT-38.



13. Install C-ring holder and snap ring.

14. Measure gear end play as the final check. Refer to "DISASSEMBLY", MT-19.

REPAIR FOR COMPONENT PARTS



Final Drive

DISASSEMBLY

1. Remove final gear.
2. Remove speedometer drive gear by cutting it.
3. Press out differential side bearings.

GI

MA


EM

LC

EC


FE

CL



4. Drive out retaining pin and draw out pinion mate shaft.
5. Remove pinion mate gears and side gears.

MT



INSPECTION

Gear, washer, shaft and case


- Check mating surfaces of differential case, side gears and pinion mate gears.
- Check washers for wear.

AT

FA

RA

BR



Bearing


- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing tapered roller bearing, replace outer and inner race as a set.**

ST

RS

BT

HA



ASSEMBLY


1. Attach side gear thrust washer to side gear and install both of them in differential case.
2. Install pinion mate washers and pinion mate gears in place.

EL


IDX

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)



3. Insert pinion mate shaft.
 - **When inserting, be careful not to damage pinion mate thrust washers.**




4. Measure clearance between side gear and differential case with washers following the procedure below:
 - a. Set Tool and dial indicator on side gear.
 - b. Move side gear up and down to measure dial indicator deflection.

Clearance between side gear and differential case with washers:


0.1 - 0.2 mm (0.004 - 0.008 in)

- c. If not within specification, adjust clearance by changing thickness of side gear thrust washers.

**Side gear thrust washers for differential case side:
Refer to SDS, MT-39.**



5. Install retaining pin.
 - **Make sure that retaining pin is flush with case.**




6. Install final gear.
 - **Apply locking sealant to final gear fixing bolts before installing them.**
7. Install speedometer drive gear.

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)

8. Press on differential side bearings.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL



IDX



Shift Control Components

INSPECTION

- Check contact surface and sliding surface for wear, scratches, projections or other damage.




ADJUSTMENT OF INPUT SHAFT BRAKING MECHANISM

1. Install striking lever and rod, striking interlock assembly and control bracket on clutch housing as shown.
- When installing control bracket on clutch housing, assure protrusion beneath bracket is correctly seated.

REPAIR FOR COMPONENT PARTS


Shift Control Components (Cont'd)



2. Measure maximum height "H" while shifting from neutral to reverse position.

Maximum height "H":

67.16 - 67.64 mm (2.6441 - 2.6630 in)



3. Measure clearance "C" between reverse brake cam and striking lever while shifting to reverse position.


Clearance "C":

0.05 - 0.125 mm (0.0020 - 0.0049 in)

If "H" or "C" is not within specification, replace the following parts as a set.

- Striking lever assembly
- Striking interlock assembly (This includes reverse brake cam.)
- Control bracket assembly

REPAIR FOR COMPONENT PARTS



Case Components

REMOVAL AND INSTALLATION

Input shaft oil seal

1. Drive out input shaft oil seal.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA


EL

IDX




2. Install input shaft oil seal.

- **Apply multi-purpose grease to seal lip of oil seal before installing.**




Input shaft rear bearing

1. Remove welch plug from transmission case.



2. Remove input shaft rear bearing by tapping it from welch plug hole.




3. Install welch plug.
 - **Apply recommended sealant to mating surface of transmission case.**

REPAIR FOR COMPONENT PARTS


Case Components (Cont'd)

4. Install input shaft rear bearing.




Mainshaft front bearing and oil channel


1. Remove mainshaft front bearing retainer.




2. Remove mainshaft front bearing.
3. Remove oil channel.



4. Install oil channel.
 - Ensure that the oil groove faces the oil pocket.



5. Install mainshaft front bearing.
6. Install mainshaft front bearing retainer.
 - Apply locking sealant to thread of screw before installation.



ADJUSTMENT

Differential Side Bearing Preload

If any of the following parts are replaced, adjust differential side bearing preload.

- Differential case
- Differential side bearing
- Clutch housing
- Transmission case

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST




RS

BT

HA

EL

IDX



1. Remove differential side bearing outer race (transmission case side) and shim.

2. Install differential side bearing outer race without shim.
 3. Install final drive assembly on clutch housing.
 4. Install transmission case on clutch housing.
- Tighten transmission case fixing bolts to the specified torque. Refer to MT-10.

5. Set dial indicator on front end of differential case.
6. Insert Tool all the way into differential side gear.
7. Move Tool up and down and measure dial indicator deflection.

8. Select shim considering bearing preload.

- Suitable shim thickness = dial indicator deflection + specified bearing preload

Differential side bearing adjusting shims:

Refer to SDS, MT-40.

Bearing preload:

0.25 - 0.30 mm (0.0098 - 0.0118 in)

9. Install selected shim and differential side bearing outer race on transmission case.


10. Check differential side bearing turning torque.

- a. Install final drive assembly on clutch housing.
- b. Install transmission case on clutch housing.

- Tighten transmission case fixing bolts to the specified torque. Refer to MT-10.

ADJUSTMENT

Differential Side Bearing Preload (Cont'd)



c. Measure turning torque of final drive assembly.






Turning torque of final drive assembly

(New bearing):

2.9 - 6.9 N·m (30 - 70 kg-cm, 26 - 61 in-lb)

- When old bearing is reused, turning torque will be slightly less than the above.
- Make sure torque is close to the specified range.
- Changes in turning torque of final drive assembly per revolution should be within 1.0 N·m (10 kg-cm, 8.7 in-lb) without binding.

ASSEMBLY



1. Install striking rod, lever and interlock.
 - **Tape edges of striking rod to avoid damaging oil seal lip during installation. When taped edges of striking rod are past the oil seal, remove tape.**

2. Install reverse check sleeve assembly.
3. Install check balls, reverse check spring and reverse check plug.

4. Check reverse turning torque (at striking rod).

Reverse check turning torque (at striking rod):
4.9 - 7.4 N·m (50 - 75 kg·cm, 43 - 65 in·lb)

 - If not within specification, select another check plug having a different length and reinstall it.

- **Reverse check plugs:**
Refer to SDS, MT-38.
5. Install selected reverse check plug.
 - **Apply locking sealant to thread of plug before installing it.**

6. Install check ball plug, shift check ball and shift check spring.
7. Install oil pocket.

8. Install gear components onto clutch housing.
 - a. Install final drive assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA


EL

IDX


ASSEMBLY




- b. Install input shaft assembly with bearing retainer, mainshaft assembly and reverse idler gear.
 - Be careful not to damage oil seal lip with splines of input shaft.
 - Be careful not to damage oil channel when inserting mainshaft into clutch housing.




- c. Install input shaft front bearing retainer.



9. Apply grease to shifter caps and install to control bracket. Install control bracket with 1st & 2nd shift fork.




- When installing control bracket on clutch housing, ensure bracket is correctly seated.
10. Install 3rd & 4th and 5th shift forks.




11. Insert fork shaft.
 - Apply multi-purpose grease to support spring before installing.
12. Install reverse idler spacer.


ASSEMBLY




13. Apply recommended sealant to mating surface of clutch housing. Refer to MT-10.



14. Install transmission case on clutch housing.



15. Install mainshaft front bearing snap ring.



16. Tap mainshaft with a soft hammer to ensure mainshaft is properly seated.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

ASSEMBLY



17. Check mainshaft bearing end play.


Mainshaft bearing end play:

0 - 0.1 mm (0 - 0.004 in)

- If not within specification, select another case cover having a different thickness.

Available case covers:

Refer to SDS, MT-38.




18. Install O-ring and case cover on transmission case.

- **Apply recommended sealant to mating surface of transmission case.**

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

TRANSAXLE

Engine		SR20DE	
Transaxle model		RS5F32A	
Synchronesh type		Warner	
Shift pattern			
Gear ratio	1st	3.063	
	2nd	1.826	
	3rd	1.286	
	4th	0.975	
	5th	0.756	
	Reverse	3.153	
Number of teeth	Input gear	1	16
		2	23
		3	28
		4	40
		5	45
		Rev.	13
	Main gear	1	49
		2	42
		3	36
		4	39
		5	34
		Rev.	41
Reverse idler gear		31	
Oil level*	mm (in)	40 - 45 (1.57 - 1.77)	
Oil capacity (Reference)	(ℓ) (US pt, Imp pt)	3.6 - 3.8 (7-5/8 - 8, 6-3/8 - 6-3/4)	
Remarks		2nd and 3rd double baulk ring type synchronizer	

*Refer to MA section ("Checking M/T Oil" - "CHASSIS AND BODY MAINTENANCE").

FINAL GEAR

Engine		SR20DE
Final gear ratio		4.176
Number of teeth	Final gear/Pinion	71/17
	Side gear/Pinion mate gear	14/10

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

GEAR END PLAY

Gear	End play mm (in)
1st main gear	0.18 - 0.31 (0.0071 - 0.0122)
2nd main gear	0.20 - 0.30 (0.0079 - 0.0118)
3rd main gear	0.20 - 0.30 (0.0079 - 0.0118)
4th main gear	0.20 - 0.30 (0.0079 - 0.0118)
5th input gear	0.18 - 0.31 (0.0071 - 0.0122)

CLEARANCE BETWEEN BAULK RING AND GEAR


1st, 4th, 5th baulk ring

Unit: mm (in)

	Standard	Wear limit
1st	0.95 - 1.45 (0.0374 - 0.0571)	0.7 (0.028)
4th	0.9 - 1.45 (0.0354 - 0.0571)	
5th	0.9 - 1.5 (0.035 - 0.059)	

2nd and 3rd baulk ring

Unit: mm (in)



AMT141

Dimension	Standard	Wear limit
A	0.7 - 0.9 (0.028 - 0.035)	0.2 (0.008)
B	0.6 - 1.1 (0.024 - 0.043)	

AVAILABLE REVERSE CHECK PLUGS AND CASE COVERS

Reverse check plug

Reverse check turning torque (At striking rod)	4.9 - 7.4 N-m (50 - 75 kg-cm, 43 - 65 in-lb)
Length mm (in)	Part number
7.1 (0.280)	32188-M8002
7.7 (0.303)	32188-M8003
8.3 (0.327)	32188-M8001*
8.9 (0.350)	32188-M8004

* Standard size check plug

Case cover

Main shaft bearing end play	0 - 0.1 mm (0 - 0.004 in)
Thickness mm (in)	Part number
10.78 (0.4244)	32131-50J00
10.83 (0.4264)	32131-50J01
10.88 (0.4283)	32131-50J02
10.93 (0.4303)	32131-50J03
10.98 (0.4323)	32131-50J04
11.03 (0.4343)	32131-50J05

AVAILABLE SNAP RINGS

Input shaft front bearing

Allowable clearance	0 - 0.1 mm (0 - 0.004 in)
Thickness mm (in)	Part number
1.27 (0.0500)	32204-M8004
1.33 (0.0524)	32204-M8005
1.39 (0.0547)	32204-M8006
1.45 (0.0571)	32204-M8007

Input shaft 5th synchronizer hub

Allowable clearance	0 - 0.1 mm (0 - 0.004 in)
Thickness mm (in)	Part number
2.00 (0.0787)	32311-M8812
2.05 (0.0807)	32311-M8813
2.10 (0.0827)	32311-M8814
2.15 (0.0846)	32311-M8815
2.20 (0.0866)	32311-M8816
2.25 (0.0886)	32311-M8817
2.30 (0.0906)	32311-M8818


MAINSHAFT C-RING

Allowable clearance	0 - 0.1 mm (0 - 0.004 in)
Thickness mm (in)	Part number
4.45 (0.1752)	32348-50J00
4.52 (0.1780)	32348-50J01
4.59 (0.1807)	32348-50J02
4.66 (0.1835)	32348-50J03
4.73 (0.1862)	32348-50J04
4.80 (0.1890)	32348-50J05
4.87 (0.1917)	32348-50J06
4.94 (0.1945)	32348-50J07

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

MAINSHAFT BEARING ADJUSTING SPACER



SMT716C

Bearing distance "C"	230.15 - 230.25 mm (9.0610 - 9.0649 in)
Thickness mm (in)	Part number
18.91 (0.7445)	32347-50J00
18.98 (0.7472)	32347-50J01
19.05 (0.7500)	32347-50J02
19.12 (0.7528)	32347-50J03
19.19 (0.7555)	32347-50J04
19.26 (0.7583)	32347-50J05
19.33 (0.7610)	32347-50J06
19.40 (0.7638)	32347-50J07
19.47 (0.7665)	32347-50J08

DIFFERENTIAL SIDE GEAR THRUST WASHER

Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number
0.75 - 0.80 (0.0295 - 0.0315)	38424-D2111
0.80 - 0.85 (0.0315 - 0.0335)	38424-D2112
0.85 - 0.90 (0.0335 - 0.0354)	38424-D2113
0.90 - 0.95 (0.0354 - 0.0374)	38424-D2114
0.95 - 1.00 (0.0374 - 0.0394)	38424-D2115

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)


INPUT SHAFT BRAKING MECHANISM

Reverse brake cam



SMT735B

Maximum height "H" between the control bracket fitting surface and 1-2 shifter	67.16 - 67.64 (2.6441 - 2.6630)
mm (in)	



SMT736B

Clearance "C" between reverse brake cam and striking lever	0.05 - 0.125 (0.0020 - 0.0049)
mm (in)	

AVAILABLE SHIMS

— DIFFERENTIAL SIDE BEARING PRELOAD AND ADJUSTING SHIM

Bearing preload (Reused bearing)

Unit: mm (in)

Differential side bearing	0.25 - 0.30 (0.0098 - 0.0118)
---------------------------	-------------------------------

Turning torque (New bearing)

Unit: N-m (kg-cm, in-lb)

Final drive	2.9 - 6.9 (30 - 70, 26 - 61)
-------------	------------------------------

Differential side bearing adjusting shims

Thickness mm (in)	Part number
0.44 (0.0173)	38454-M8000
0.48 (0.0189)	38454-M8001
0.56 (0.0220)	38454-M8003
0.60 (0.0236)	38454-M8004
0.64 (0.0252)	38454-M8005
0.68 (0.0268)	38454-M8006
0.72 (0.0283)	38454-M8007
0.76 (0.0299)	38454-M8008
0.80 (0.0315)	38454-M8009
0.84 (0.0331)	38454-M8010
0.88 (0.0346)	38454-M8011