

# ENGINE LUBRICATION & COOLING SYSTEMS

## SECTION LC

GI

MA

EM

**LC**

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA



EL

IDX

## CONTENTS

<b>PRECAUTIONS</b> .....	2	System Check .....	8
Liquid Gasket Application Procedure .....	2	Water Pump .....	9
<b>PREPARATION</b> .....	3	Thermostat .....	11
Special Service Tools .....	3	Water Outlet .....	12
<b>ENGINE LUBRICATION SYSTEM</b> .....	4	Radiator .....	13
Lubrication Circuit .....	4	<b>ENGINE COOLING SYSTEM</b> .....	14
Oil Pressure Check .....	4	Overheating Cause Analysis .....	14
Oil Pump .....	5	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	15
Oil Filter .....	7	Engine Lubrication System .....	15
<b>ENGINE COOLING SYSTEM</b> .....	8	Engine Cooling System .....	15
Cooling Circuit .....	8		

## PRECAUTIONS








### Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. **(Use Genuine RTV silicone sealant Part No. 999 MP-A7007 or equivalent.)**
  - For oil pan, be sure liquid gasket diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
  - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
- Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.

# PREPARATION

## Special Service Tools


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge	 <p style="text-align: center;">NT050</p>	GI  MA  EM  <b>LC</b>
ST25052000 (J25695-2) Hose	 <p style="text-align: center;">NT559</p>	EC  FE  CL
KV10115801 (J38956) Oil filter wrench	 <p style="text-align: center;">NT362</p>	MT  AT
WS39930000 ( — ) Tube presser	 <p style="text-align: center;">NT052</p>	FA  RA
EG17650301 (J33984-A) Radiator cap tester adapter	 <p style="text-align: center;">NT564</p>	BR  ST  RS


GI  
 MA  
 EM  
**LC**  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# ENGINE LUBRICATION SYSTEM


## Lubrication Circuit



SLC024B



SLC025B



SLC518A

## Oil Pressure Check


### WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- For M/T models, put gearshift lever in Neutral "N" position. For A/T models, put selector lever in Park "P" position.

1. Check oil level.
2. Remove oil pressure switch.

# ENGINE LUBRICATION SYSTEM

## Oil Pressure Check (Cont'd)



3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed rpm	Approximate discharge pressure kPa (kg/cm <sup>2</sup> , psi)
Idle speed	More than 78 (0.8, 11)
3,200	314 - 392 (3.2 - 4.0, 46 - 57)


- If difference is extreme, check oil passage and oil pump for oil leaks.
6. Install oil pressure switch with sealant.

## Oil Pump

### REMOVAL

1. Remove drive belts.
2. Remove cylinder head. Refer to EM section ("Removal", "CYLINDER HEAD").
3. Remove oil pans. Refer to EM section ("Removal", "OIL PAN").
4. Remove oil strainer and baffle plate.
5. Remove front cover assembly.

### DISASSEMBLY AND ASSEMBLY



- |                  |                   |                            |
|------------------|-------------------|----------------------------|
| ① Oil pump cover | ④ Outer gear      | ⑦ Shim                     |
| ② Front cover    | ⑤ Regulator valve | ⑧ Plug                     |
| ③ Inner gear     | ⑥ Spring          | ⑨ Regulator valve assembly |
|                  |                   | ⑩ Oil strainer             |

# ENGINE LUBRICATION SYSTEM

## Oil Pump (Cont'd)

### INSPECTION




Using a feeler gauge, check the following clearances:

#### Standard clearance:

Unit: mm (in)

Body to outer gear radial clearance ①	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance ②	Below 0.18 (0.0071)
Body to inner gear clearance ③	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance ④	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance ⑤	0.045 - 0.091 (0.0018 - 0.0036)

- If the tip clearance ( ② ) exceeds the limit, replace gear set.
- If body to gear clearances ( ① , ③ , ④ or ⑤ ) exceed the limit, replace front cover assembly.





SLC854A

# ENGINE LUBRICATION SYSTEM

## Oil Pump (Cont'd)

### REGULATOR VALVE INSPECTION



1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.

- If damaged, replace regulator valve set or oil pump assembly.

4. Check regulator valve to oil pump cover clearance.



#### Clearance:

⑥ : 0.040 - 0.097 mm (0.0016 - 0.0038 in)

- If it exceeds the limit, replace oil pump cover.

### INSTALLATION

- Always replace oil seal and O-ring with new ones. Refer to EM section ("OIL SEAL REPLACEMENT").
- When installing oil pump, apply engine oil to gears.
- Be sure that O-rings are properly fitted.
- Use a scraper to remove old liquid gasket from mating surface of front cover.
- Also remove traces of liquid gasket from mating surface of cylinder block.




1. Apply a continuous bead of liquid gasket to mating surface of front cover assembly.
- Use Genuine RTV silicone sealant Part No. 999 MP-A7007 or equivalent.
2. Installation is the reverse order of removal.

### Oil Filter


The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- The new and previous oil filter designs differ from each other and are not interchangeable.
- Use Tool KV10115801 (J38956) for removing oil filter.



# ENGINE COOLING SYSTEM

## Cooling Circuit



## System Check

### WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

## CHECKING COOLING SYSTEM HOSES

Check hoses for the following:

- Improper attachment
- Leaks
- Cracks
- Damage
- Chafing
- Deterioration

## CHECKING COOLING SYSTEM FOR LEAKS


To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:

157 kPa (1.6 kg/cm<sup>2</sup>, 23 psi)

### CAUTION:

Higher pressure than specified may cause radiator damage.





# ENGINE COOLING SYSTEM

## System Check (Cont'd)

### CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.



**Radiator cap relief pressure:**

**Standard**

78 - 98 kPa (0.8 - 1.0 kg/cm<sup>2</sup>, 11 - 14 psi)


**Limit**

59 - 98 kPa (0.6 - 1.0 kg/cm<sup>2</sup>, 9 - 14 psi)



Pull the negative pressure valve to open it.

Check that it closes completely when released.




## Water Pump

### REMOVAL

1. Drain coolant from radiator and cylinder block. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
2. Loosen water pump pulley bolts.
3. Remove drive belts.
4. Remove front RH wheel, engine side cover and front cover.
5. Remove three lower water pump bolts.
6. Position jack to support engine and remove front engine mount.
7. Remove remaining water pump bolt to remove water pump.

### CAUTION:

- When removing water pump assembly, be careful not to get coolant on drive belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.
- Use Genuine RTV silicone sealant Part No. 999 MP-A7007 or equivalent.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

## ENGINE COOLING SYSTEM

### Water Pump (Cont'd)


#### INSPECTION

- Check body assembly for rust or corrosion.
- Check for rough operation due to excessive end play.




#### INSTALLATION

1. Use a scraper to remove liquid gasket from water pump.
  - Also remove traces of liquid gasket from mating surface of cylinder block.




2. Apply a continuous bead of liquid gasket to mating surface of water pump.
  - Use Genuine RTV silicone sealant Part No. 999 MP-A7007 or equivalent.

When filling radiator with coolant, refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").  
When installing drive belts, refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").



# ENGINE COOLING SYSTEM


## Thermostat



**Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.**

### REMOVAL AND INSTALLATION

1. Drain engine coolant.
2. Remove lower radiator hose.
3. Remove water inlet, then take out thermostat.



4. Install thermostat with jiggle valve or air bleeder at upper side.
- **Apply a continuous bead of liquid gasket to mating surface of water inlet.**
  - **After installation, run engine for a few minutes, and check for leaks.**

# ENGINE COOLING SYSTEM


## Thermostat (Cont'd)

### INSPECTION

1. Check for valve seating condition at normal room temperature. It should seat tightly.
2. Check valve opening temperature and valve lift.

Valve opening temperature	°C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 8/90 (0.31/194)


3. Then check if valve closes at 5°C (9°F) below valve opening temperature.



## Water Outlet

### INSPECTION


Visually inspect for water leaks. If there is leakage, apply liquid gasket.



### INSTALLATION


1. Use a scraper to remove old liquid gasket from water outlet.
  - Also remove traces of liquid gasket from mating surface of cylinder head.
2. Apply a continuous bead of liquid gasket to mating surface of water outlet.
  - Use Genuine RTV silicone sealant Part No. 999 MP-A7007 or equivalent.
  - When installing, tighten water outlet bolts to the specified torque.

: 6.3 - 8.3 N·m (0.64 - 0.85 kg·m, 55.6 - 73.8 in-lb)



## Radiator

SEC. 214



: N·m (kg·m, in·lb)

ALC093

- |                       |                                 |                            |
|-----------------------|---------------------------------|----------------------------|
| ① Reservoir tank      | ⑥ Oil cooler hoses (A/T models) | ⑪ Cooling fan              |
| ② Radiator cap        | ⑦ Lower radiator hose           | ⑫ Shield spacer            |
| ③ Upper radiator hose | ⑧ Cooling fan motor-1           | ⑬ Cooling fan motor shield |
| ④ Radiator drain plug | ⑨ Cooling fan motor-2           | ⑭ Reservoir tank bracket   |
| ⑤ Radiator            | ⑩ Radiator shroud               |                            |

### Cooling fan control system

Cooling fans are controlled by the ECM. For details, refer to EC section ("Cooling Fan", "TROUBLE DIAGNOSIS FOR DTC P1900").

### Refilling engine coolant

For details on refilling engine coolant, refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").

# ENGINE COOLING SYSTEM

## Overheating Cause Analysis

		Symptom	Check items		
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	
		Thermostat stuck closed	—		
		Damaged fins	Dust contamination or paper clogging		—
			Mechanical damage		
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)		
	Reduced air flow	Cooling fan does not operate	—	—	
		High resistance to fan rotation			
		Damaged fan blades			
		Damaged radiator shroud	—	—	
		Improper coolant mixture ratio	—	—	
		Poor coolant quality	—	—	
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	
				Cracked hose	
			Water pump	Poor sealing	
Radiator cap			Loose		
			Poor sealing		
Radiator			O-ring for damage, deterioration or improper fitting		
		Cracked radiator tank			
		Cracked radiator core			
	Reservoir tank	Cracked reservoir tank			
	Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration		
			Cylinder head gasket deterioration		
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load	
				Driving in low gear for extended time	
				Driving at extremely high speed	
			Powertrain system malfunction	—	
			Installed improper size wheels and tires		
		Dragging brakes			
		Improper ignition timing			
	Blocked or restricted air flow	Blocked bumper	—	—	
		Blocked radiator grille	Installed car brassiere		
			Mud contamination or paper clogging		
Blocked radiator		—			
Blocked condenser		—			
	Installed large fog lamp	—			

# SERVICE DATA AND SPECIFICATIONS (SDS)

## Engine Lubrication System

### Oil pressure check

Engine speed rpm	Approximate discharge pressure kPa (kg/cm <sup>2</sup> , psi)
Idle speed 3,200	More than 78 (0.8, 11) 314 - 392 (3.2 - 4.0, 46 - 57)

### Regulator valve inspection

Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
--	---------------------------------

### Oil pump inspection

Unit: mm (in)

Body to outer gear radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance	Below 0.18 (0.0071)
Body to inner gear clearance	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

## Engine Cooling System

### Thermostat

Valve opening temperature	°C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 8/90 (0.31/194)

### Radiator

Unit: kPa (kg/cm<sup>2</sup>, psi)

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure		157 (1.6, 23)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX