

STARTING & CHARGING SYSTEM

SECTION SC

CONTENTS

PRECAUTIONS	2	
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	
Wiring Diagrams and Trouble Diagnosis	2	
BATTERY	3	
How to Handle Battery	3	
METHODS OF PREVENTING OVER-DISCHARGE	3	
CHECKING ELECTROLYTE LEVEL	3	
SPECIFIC GRAVITY CHECK	4	
CHARGING THE BATTERY	5	
STARTING SYSTEM	6	
System Description	6	
M/T MODEL	6	
A/T MODEL	6	
Wiring Diagram - START -	7	
M/T MODEL	7	
A/T MODEL	8	
Construction	10	
Removal and Installation	11	
QG18DE	11	
SR20DE	12	
Pinion/Clutch Check	12	
CHARGING SYSTEM	14	
System Description	14	
Wiring Diagram - CHARGE -	15	
Trouble Diagnoses	16	
WITH IC REGULATOR	16	
MALFUNCTION INDICATOR	16	
Construction	17	
Removal and Installation	17	
QG18DE	17	
SR20DE	18	
SERVICE DATA AND SPECIFICATIONS (SDS)	19	
Battery	19	
Starter	19	
Generator	19	

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NISC0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL B15 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), front seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), side air bag (satellite) sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") covered with yellow insulation either just before the harness connectors or for the complete harness are related to the SRS.**

Wiring Diagrams and Trouble Diagnosis

NISC0002

When you read wiring diagrams, refer to the following:

- **GI-11**, "HOW TO READ WIRING DIAGRAMS".
- **EL-9**, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- **GI-36**, "How To Follow Test Groups In Trouble Diagnosis".
- **GI-25**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

BATTERY




How to Handle Battery

How to Handle Battery

NISC0003

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



METHODS OF PREVENTING OVER-DISCHARGE

NISC0003S01

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
 - The terminal connections should be clean and tight.
 - At every routine maintenance, check the electrolyte level. This also applies to batteries designated as “low maintenance” and “maintenance-free”.
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal.

- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL

NISC0003S02

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

BATTERY

How to Handle Battery (Cont'd)



- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




Sulphation

NISC0003S0201

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

NISC0003S03

1. Read hydrometer and thermometer indications at eye level.

2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer Temperature Correction

NISC0003S0301

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012

BATTERY

How to Handle Battery (Cont'd)

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

NISC0003S04

CAUTION:

- Do not “quick charge” a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging Rates

NISC0003S0401

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

Do not charge at more than 50 ampere rate.

NOTE:

The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

STARTING SYSTEM

System Description

System Description

NISC0004

NISC0004S01

M/T MODEL

Power is supplied at all times:

- through 40A fusible link (letter **c**, located in the fuse and fusible link box)
- to ignition switch terminal B.

With the ignition switch in the START position, power is supplied:

- from ignition switch terminal St
- to clutch interlock relay terminal 5.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 20, located in the fuse block (J/B)]
- to clutch interlock relay terminal 1.

When the clutch pedal is depressed, ground is supplied to clutch interlock relay terminal 2 through the clutch interlock switch and body grounds E7 and E37.

The clutch interlock relay is energized and power is supplied:

- from terminal 3 of the clutch interlock relay
- to terminal + of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

A/T MODEL

NISC0004S02

Power is supplied at all times:

- through 40A fusible link (letter **c**, located in the fuse and fusible link box)
- to ignition switch terminal B.

With the ignition switch in the START position, power is supplied:

- from ignition switch terminal St
- to park/neutral position relay terminal 5 (without ASCD) or terminal 6 (with ASCD)

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 20, located in the fuse block (J/B)]
- to park/neutral position relay terminal 1.

Ground is supplied, with the selector lever in the P or N position:

- to park/neutral position relay terminal 2
- through park/neutral position switch.

The park/neutral position relay is energized and power is supplied:

- from ignition switch terminal St
- through park/neutral position relay terminals 5 and 3 (without ASCD) or terminals 6 and 7 (with ASCD)
- to terminal + of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

STARTING SYSTEM

Wiring Diagram — START —


Wiring Diagram — START —

M/T MODEL

NISC0005

NISC0005S01

SC-START-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS







BT

HA

SC

EL

IDX



WSC003






STARTING SYSTEM

Wiring Diagram — START — (Cont'd)

A/T MODEL

NISC0005S02


SC-START-02



STARTING SYSTEM

Wiring Diagram — START — (Cont'd)

SC-START-03



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



WSC005


STARTING SYSTEM

Construction

Construction

NISC0006

SEC. 233
QG18DE
6 004 AAO 004



 (H): High temperature grease point


LSC021

- | | | |
|-----------------------------|--------------------------|---------------------------|
| 1. Solenoid through bolts | 8. Seal | 15. Yoke assembly |
| 2. Drive end shield | 9. Locking washers | 16. Armature assembly |
| 3. Retainers | 10. Intermediate bearing | 17. Brush holder |
| 4. Pinion assembly | 11. Internal gear | 18. Commutator end shield |
| 5. Fork lever | 12. Cover disc | 19. Closure cap |
| 6. Bearing pedestal | 13. Drive shaft | 20. Starter through bolts |
| 7. Solenoid switch assembly | 14. Planetary gears | 21. Closure cap screws |

STARTING SYSTEM

Construction (Cont'd)


SEC. 233
SR20DE
S114 - 831



(H): High temperature grease point

LSC022

- | | | |
|-------------------------------|-----------------------------|----------------------------|
| 1. Solenoid through bolts | 10. Rear cover assembly | 18. Pinion shaft |
| 2. Gear case assembly | 11. Thrust washer | 19. Packing |
| 3. Connector stay | 12. Brush holder assembly | 20. Armature thrust washer |
| 4. Connector stay screw | 13. Armature assembly | 21. Pinion center bracket |
| 5. Shift lever set | 14. Yoke assembly | 22. E-ring |
| 6. Dust cover kit | 15. Armature center bracket | 23. Pinion assembly |
| 7. Magnetic switch assembly | 16. Internal gear | 24. Pinion stopper |
| 8. Through bolts | 17. Planet gears | 25. Pinion stopper clip |
| 9. Rear cover assembly screws | | |



Removal and Installation

QG18DE

Removal

1. Disconnect the negative battery terminal.
2. Remove the upper starter mounting bolt.
3. Remove the harness protector from the starter engine room harness.
4. Disconnect the starter harness connectors.
5. Remove the lower starter mounting bolt.
6. Remove the starter.

NISC0007

NISC0007S01

NISC0007S0101

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

STARTING SYSTEM

Removal and Installation (Cont'd)



Installation

To install, reverse the removal procedure.

NISC0007S0102


SR20DE

NISC0007S02

Removal

NISC0007S0201

1. Disconnect the negative battery terminal.
2. Remove the air cleaner cover and the air cleaner to intake manifold collector duct.
3. Remove the intake manifold support.
4. Remove the harness protector from the starter engine room harness.
5. Disconnect the starter harness connectors.
6. Remove the two starter mounting bolts.
7. Remove the starter.



Installation

To install, reverse the removal procedure.

NISC0007S0202

Pinion/Clutch Check

NISC0008

1. Inspect pinion assembly teeth.
 - Replace pinion assembly if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect planetary gears/planet gears' teeth.
 - Replace planetary gears/planet gears if teeth are worn or damaged. (Also check condition of pinion shaft/drive shaft gear teeth.)
3. Check to see if pinion assembly locks in one direction and rotates smoothly in the opposite direction.

STARTING SYSTEM

Pinion/Clutch Check (Cont'd)

- If it locks or rotates in both directions, or unusual resistance is evident, replace.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CHARGING SYSTEM

System Description

System Description

NISC0009

The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to generator terminal B through:

- 100A fusible link (letter **a**, located in the fuse and fusible link box).

Power is supplied at all times to generator terminal S through:

- 10A fuse (No. 33, located in the fuse and fusible link box).

Terminal B supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal S detecting the input voltage. The charging circuit is protected by the 100A fusible link.

The generator is grounded to the engine block.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 30, located in the fuse block (J/B)]
- to combination meter terminal 26 (without tachometer) or 41 (with tachometer) for the charge warning lamp.

Ground is supplied to terminal 13 (without tachometer) or 19 (with tachometer) of the combination meter through terminal L of the generator. With power and ground supplied, the charge warning lamp will illuminate. When the generator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

CHARGING SYSTEM


Wiring Diagram — CHARGE —

Wiring Diagram — CHARGE —


NISC0010

SC-CHARGE-01

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



TK : WITH TACHOMETER
EK : WITHOUT TACHOMETER



WSC006

CHARGING SYSTEM

Trouble Diagnoses

Trouble Diagnoses


NISC0011

Before conducting a generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The generator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

WITH IC REGULATOR

NISC0011S01



Warning lamp: "CHARGE" warning lamp in combination meter

SEL338V

NOTE:

- If the inspection result is OK even though the charging system is malfunctioning, check the B terminal connection. Check the tightening torque.

B terminal tightening torque:

7.84 - 10.78 N·m (0.8 - 1.0 kg·m, 70 - 95 in·lb)

- When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

MALFUNCTION INDICATOR


NISC0011S02

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while generator is operating:


- Excessive voltage is produced.
- No voltage is produced.

Construction

NISC0012



- | | | |
|--------------------|--------------|--------------------------|
| 1. Pulley assembly | 5. Rotor | 9. IC regulator assembly |
| 2. Front cover | 6. Slip ring | 10. Diode assembly |
| 3. Front bearing | 7. Stator | 11. Packing |
| 4. Retainer | 8. Fan guide | 12. Rear cover |



Removal and Installation

QG18DE

Removal

1. Disconnect the negative battery terminal.
2. Remove the front/right-side splash undercover.
3. Remove the drive belt.
4. Disconnect the A/C compressor harness connector.
5. Remove the four A/C compressor mounting bolts.
6. Slide the A/C compressor forward and support it.
7. Remove the two generator lower mounting bolts.

NISC0013

NISC0013S01

NISC0013S0101

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

CHARGING SYSTEM

Removal and Installation (Cont'd)


8. Disconnect the generator harness connectors.
9. Remove the generator upper bracket.
10. Remove the generator.



Installation

To install, reverse the removal procedure.

NISC0013S0102




SR20DE

Removal

1. Disconnect the negative battery terminal.
2. Remove the generator adjustable top mount.
3. Disconnect the generator harness connectors.
4. Remove the front/right-side splash undercover.
5. Remove the drive belt.
6. Disconnect the A/C compressor harness connector.
7. Remove the four A/C compressor mounting bolts.
8. Slide the A/C compressor forward and support it.
9. Remove the generator lower mount bolt and nuts.
10. Remove the generator lower front bracket bolt.
11. Slide the generator out and remove.

NISC0013S02

NISC0013S0201



Installation

To install, reverse the removal procedure.

NISC0013S0202

SERVICE DATA AND SPECIFICATIONS (SDS)

Battery

Battery

NISC0014

Type	GR.21R (BCI)
Capacity (20 HR) minimum V-AH	12-49
Cold cranking current A (For reference value)	356 @ -18°C (0°F)

Starter

NISC0015

Application		QG18DE	SR20DE
Manufacturer		Bosch 6 004 AA0 004	Hitachi S114-831
Type		Reduction gear type	Reduction gear type
System voltage		12V	12V
No-load	Terminal voltage	11V	11V
	Current	90A Max.	90A Max.
	Revolution	3,500 rpm Min.	2,700 rpm Min.
Minimum diameter of commutator		32.1 mm	28 mm
Minimum length of brush		10.7 mm	10.5 mm
Brush spring tension		11.5 N (1.17 kg, 2.58 lb)	16.2 N (1.65 kg, 3.64 lb)
Clearance between pinion front edge and pinion stopper		1.8 mm	0.3 - 2.5 mm

Generator

NISC0016

Application		QG18DE	SR20DE
Type		LR1100-722	LR1100-723
		HITACHI	
Nominal rating		12V-100A	
Ground polarity		Negative	
Minimum revolution under no-load (When 13.5 volts is applied)		Less than 1000 rpm	
Hot output current (When 13.5 volts is applied)		More than 24A/1,300 rpm More than 71A/2,500 rpm More than 98A/5,000 rpm	
Regulated output voltage		14.1 - 14.7V	
Minimum length of brush		6 mm (0.236 in)	
Brush spring pressure		1.000 - 3.432 N (0.102 - 0.350 kg, 0.225 - 0.772 lbs)	
Slip ring minimum outer diameter		26.0 mm (1.024 in)	
Rotor (Field coil) resistance		1.9 - 2.2 ohms	

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES