

SECTION **DI**

DRIVER INFORMATION SYSTEM

CONTENTS

METERS AND GAUGES	3	(QR25DE)	22	A
Component Parts and Harness Connector Location...	3	INSPECTION/FUEL LEVEL SENSOR UNIT		B
System Description	4	AND FUEL PUMP	23	C
UNIFIED CONTROL METER	4	INSPECTION/WATER TEMPERATURE		D
HOW TO CHANGE THE DISPLAY FOR ODO/		GAUGE (QG18DE MODELS)	24	E
TRIP METER	4	INSPECTION/WATER TEMPERATURE		F
POWER SUPPLY AND GROUND CIRCUIT	4	GAUGE (QR25DE MODELS)	25	G
WATER TEMPERATURE GAUGE	4	Electrical Components Inspection	26	H
TACHOMETER	5	FUEL LEVEL SENSOR UNIT CHECK	26	I
FUEL GAUGE	5	VEHICLE SPEED SENSOR SIGNAL CHECK ...	26	J
SPEEDOMETER	5	WARNING LAMPS	27	DI
CAN Communication	5	Schematic	27	L
CAN COMMUNICATION UNIT	5	WITHOUT TACHOMETER	27	M
TYPE 1	6	WITH TACHOMETER	28	
TYPE 2	6	Wiring Diagram — WARN —	29	
TYPE 3	7	WITHOUT TACHOMETER	29	
Combination Meter	8	WITH TACHOMETER	32	
WITHOUT TACHOMETER	8	Electrical Components Inspection	36	
WITH TACHOMETER (QG18DE MODELS)	9	FUEL WARNING LAMP OPERATION CHECK... 36		
WITH TACHOMETER (QR25DE MODELS)	10	OIL PRESSURE SWITCH CHECK	36	
Schematic	11	DIODE CHECK	36	
WITHOUT TACHOMETER	11	WARNING CHIME	37	
WITH TACHOMETER	12	Component Parts and Harness Connector Location..	37	
Wiring Diagram — METER —	13	System Description	38	
WITHOUT TACHOMETER	13	WITHOUT POWER DOOR LOCKS	38	
WITH TACHOMETER (QG18DE MODELS)	14	WITH POWER DOOR LOCKS	38	
WITH TACHOMETER (QR25DE MODELS)	15	Wiring Diagram — CHIME —	40	
Meter/Gauge Operation and Odo/Trip Meter Seg-		WITHOUT POWER DOOR LOCKS	40	
ment Check in Diagnosis Mode	16	WITH POWER DOOR LOCKS	41	
DIAGNOSIS FUNCTION	16	CONSULT-II Inspection Procedure (With Power		
HOW TO ALTERNATE DIAGNOSIS MODE	16	Door Locks)	42	
Trouble Diagnoses	17	“KEY WARN ALM”/“LIGHT WARN ALM”/“SEAT		
PRELIMINARY CHECK	17	BELT ALM”	42	
SYMPTOM CHART	18	CONSULT-II Application Items (With Power Door		
POWER SUPPLY AND GROUND CIRCUIT		Locks)	43	
CHECK	19	“KEY WARN ALARM”	43	
INSPECTION/VEHICLE SPEED SENSOR	21	“LIGHT WARN ALM”	43	
INSPECTION/ENGINE REVOLUTION SIGNAL		“SEAT BELT ALM”	43	
(QG18DE)	21	Trouble Diagnoses (Without Power Door Locks) ...	44	
INSPECTION/ENGINE REVOLUTION SIGNAL		SYMPTOM CHART	44	

POWER SUPPLY AND GROUND CIRCUIT	CHECK	49
CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING	
DIAGNOSTIC PROCEDURE 1 (LIGHTING	SWITCH INPUT SIGNAL CHECK)	50
SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH	
DIAGNOSTIC PROCEDURE 2 (KEY SWITCH	INSERT SIGNAL CHECK)	51
INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT	
DIAGNOSTIC PROCEDURE 3 (SEAT BELT	BUCKLE SWITCH LH CHECK)	52
BUCKLE SWITCH LH CHECK)	DIAGNOSTIC PROCEDURE 4	53
DIAGNOSTIC PROCEDURE 4		
Trouble Diagnoses (With Power Door Locks)		49
SYMPTOM CHART		49
POWER SUPPLY AND GROUND CIRCUIT		







METERS AND GAUGES

METERS AND GAUGES

PF24814

Component Parts and Harness Connector Location

EKS00399



WKIA1045E

A
B
C
D
E
F
G
H
I
J
DI
L
M


METERS AND GAUGES

EKS0039A

System Description UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer (if equipped), fuel gauge and water temperature gauge are controlled totally by control unit built-in combination meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER



NOTE:

Turn ignition switch to the ON position to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times:

- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to combination meter terminal 25 (without tachometer) or 42 (with tachometer).

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 30, located in the fuse block (J/B)]
- to combination meter terminal 26 (without tachometer), or
- to combination meter terminals 41 and 6 (with tachometer).

Ground is supplied:

- to combination meter terminal 27 (without tachometer) or 48 (with tachometer)
- through body grounds M28 and M54.

WATER TEMPERATURE GAUGE

QG18DE

The water temperature gauge indicates the engine coolant temperature.

ECM provides a water temperature signal to combination meter for water temperature gauge with CAN communication line.

QR25DE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the signal from the ECM.

The water temperature gauge is regulated by a signal:

- from terminal 32 of the ECM

METERS AND GAUGES

- to combination meter terminal 43 for the water temperature gauge.

TACHOMETER

QG18DE Models

The tachometer indicates engine speed in revolutions per minute (rpm).

ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

QR25DE Models

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal:

- from terminal 36 of the ECM
- to combination meter terminal 45 for the tachometer.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied:

- to combination meter terminal 30 (without tachometer) or 44 (with tachometer) for the fuel gauge
- from terminal 2 of the fuel level sensor unit and fuel pump
- through terminal 5 of the fuel level sensor unit and fuel pump, and
- through body grounds B13 and B19.

SPEEDOMETER

The combination meter receives a voltage signal from the vehicle speed sensor for the speedometer.

The voltage is supplied:

- to combination meter terminal 29 (without tachometer) or 47 (with tachometer) for the speedometer
- from terminal 1 (with QG18DE), or terminal + (with QR25DE) of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

CAN Communication

EKS003LD

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN COMMUNICATION UNIT


Body type	Sedan		
Axle	2WD		
Engine	QG18DE		QR25DE
Transmission	A/T	M/T	A/T
CAN communication unit			
ECM	×	×	×
TCM	×		×
Combination meter	×	×	
CAN communication type	DI-6. "TYPE 1"	DI-6. "TYPE 2"	DI-7. "TYPE 3"

x: Applicable

METERS AND GAUGES

TYPE 1

System Diagram




Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Combination Meter
Accelerator pedal position signal	T	R	
Output shaft revolution signal	R	T	
A/T self-diagnosis signal	R	T	
Closed throttle position signal	T	R	
Wide open throttle position signal	T	R	
Stop lamp switch signal		R	T
Overdrive control switch signal		R	T
O/D OFF indicator signal		T	R
Engine speed signal	T		R
Engine coolant temperature signal	T		R
Vehicle speed signal	R		T
Fuel level sensor signal	R		T
Malfunction indicator lamp signal	T		R
ASCD SET lamp signal	T		R
ASCD CRUISE lamp signal	T		R

TYPE 2

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	Combination Meter
Engine speed signal	T	R
Engine coolant temperature signal	T	R
Vehicle speed signal	R	T

METERS AND GAUGES

Signals	ECM	Combination Meter
Fuel level sensor signal	R	T
Malfunction indicator lamp signal	T	R
ASCD SET lamp signal	T	R
ASCD CRUISE lamp signal	T	R

TYPE 3

System Diagram



Input/Output Signal Chart

Signals	ECM	TCM
Accelerator pedal position signal	T	R
Output shaft revolution signal	R	T
A/T self-diagnosis signal	R	T
Wide open throttle position signal	T	R
Overdrive cancel signal	T	R

T: Transmit R: Receive



A
B
C
D
E
F
G
H
I
J
L
M

DI

METERS AND GAUGES

Combination Meter WITHOUT TACHOMETER

EKS0039B



- U : For U.S.A
- N : For Canada
- A : With A/T



Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W

(): Bulb socket color

WKIA0289E

METERS AND GAUGES

WITH TACHOMETER (QG18DE MODELS)



- (U) : For USA
- (N) : For Canada
- (A) : With A/T
- (AB) : With ABS



Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W

() : Bulb socket color

WKIA0006E

METERS AND GAUGES

WITH TACHOMETER (QR25DE MODELS)



- U** : For USA
- N** : For Canada
- A** : With A/T
- AB** : With ABS

Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W


(): Bulb socket color

WKIA0007E

METERS AND GAUGES

Schematic WITHOUT TACHOMETER

EKS0039C




(A) : With A/T

(WF) : With washer fluid lever switch

WKWA0513E

METERS AND GAUGES

WITH TACHOMETER



(A) : With A/T

(QG) : With QG18DE

(QR) : With QR25DE



WKWA0506E

METERS AND GAUGES




Wiring Diagram — METER — WITHOUT TACHOMETER

EKS0039D

DI-METER-01



REFER TO THE FOLLOWING.
F59 - ELECTRICAL UNITS






WKWA0507E

METERS AND GAUGES

WITH TACHOMETER (QG18DE MODELS)

DI-METER-02







REFER TO THE FOLLOWING.
F59 - ELECTRICAL UNITS

WKWA0508E

METERS AND GAUGES

WITH TACHOMETER (QR25DE MODELS)

DI-METER-03



WKWA0586E

METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

EKS0039E

DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.


HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Release odo/trip meter switch 1 second after ignition switch is turned ON.
5. Push odo/trip meter switch three times within 7 seconds.
6. All odo/trip meter segments should be turned on.

NOTE:

If some segments are not turned on, combination meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.




7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown in figure during pushing odo/trip meter switch.

NOTE:

It takes a few seconds for indication of fuel gauge and water temperature gauge to become stable.


8. Turn ignition switch to OFF or start engine to cancel diagnosis mode.



METERS AND GAUGES

Trouble Diagnoses PRELIMINARY CHECK

EKS0039F



*1: [DI-16](#)

*2: [DI-19](#)

*3: [DI-18](#)

WKIA0159E

A
B
C
D
E
F
G
H
I
J
DI
L
M

METERS AND GAUGES

SYMPTOM CHART

Symptom	Possible causes	Repair order
One meter/gauge (speedometer/tachometer/fuel gauge/water temp. gauge) is malfunctioning.	1. Sensor signal <ul style="list-style-type: none"> - Vehicle speed signal - Engine revolution signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. DI-21. "INSPECTION/VEHICLE SPEED SENSOR" DI-22. "INSPECTION/ENGINE REVOLUTION SIGNAL (QR25DE)" DI-23. "INSPECTION/FUEL LEVEL SENSOR UNIT AND FUEL PUMP" DI-24. "INSPECTION/WATER TEMPERATURE GAUGE (QG18DE MODELS)" DI-25. "INSPECTION/WATER TEMPERATURE GAUGE (QR25DE MODELS)"
Multiple meters/gauges (except odo/trip meter) are malfunctioning.		2. Replace combination meter assembly.

Before starting trouble diagnoses below, perform "PRELIMINARY CHECK", [DI-17. "PRELIMINARY CHECK"](#) .


METERS AND GAUGES

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power Supply Circuit Check


WITHOUT TACHOMETER

Terminals			Ignition switch position		
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M30	25 (R/B)	Ground	Battery voltage	Battery voltage	Battery voltage
M30	26 (Y)	Ground	0V	0V	Battery voltage



WITH TACHOMETER

Terminals			Ignition switch position		
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M29	6 (Y)	Ground	0V	0V	Battery voltage
M30	41 (Y)	Ground	0V	0V	Battery voltage
M30	42 (R/B)	Ground	Battery voltage	Battery voltage	Battery voltage



If NG, check the following.

- 10A fuse [No. 12, located in fuse block (J/B)]
- 10A fuse [No. 30, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter

A
B
C
D
E
F
G
H
I
J
DI
L
M


METERS AND GAUGES

Ground Circuit Check WITHOUT TACHOMETER

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M30	27 (B)	Ground	Yes

WITH TACHOMETER

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M30	48 (B)	Ground	Yes




METERS AND GAUGES

INSPECTION/VEHICLE SPEED SENSOR

1. CHECK VEHICLE SPEED SENSOR OUTPUT

1. Remove vehicle speed sensor from transmission.
2. Check voltage between combination meter terminal 29 (without tachometer) or 47 (with tachometer) and ground while quickly turning speed sensor pinion.



OK or NG

- OK >> Vehicle speed sensor is OK.
NG >> GO TO 2.


2. CHECK VEHICLE SPEED SENSOR

Check resistance between vehicle speed sensor connector F43 terminals 1 and 2 (with QG18DE), or connector F36 terminals + and - (with QR25DE).

Resistance **Approx. 250Ω**

OK or NG

- OK >> Check the following.
- Harness between combination meter and vehicle speed sensor.
 - Vehicle speed sensor ground circuit.
- NG >> Replace vehicle speed sensor.



INSPECTION/ENGINE REVOLUTION SIGNAL (QG18DE)

1. CHECK ECM SELF-DIAGNOSIS

Perform ECM self diagnosis. Refer to [EC-113](#) (ULEV Models), [EC-694](#) (SULEV Models).

OK or NG


- OK >> Replace combination meter.
NG >> Go to ECM trouble diagnosis. Refer to [EC-113](#) (ULEV Models), [EC-694](#) (SULEV Models).

METERS AND GAUGES

INSPECTION/ENGINE REVOLUTION SIGNAL (QR25DE)

1. CHECK ECM OUTPUT

1. Start engine.
2. Check voltage between combination meter terminal 45 and ground at idle and 2,000 rpm.



OK or NG

- OK >> Engine revolution signal is OK.
- NG >> Harness for open or short between ECM and combination meter.

METERS AND GAUGES

INSPECTION/FUEL LEVEL SENSOR UNIT AND FUEL PUMP

1. CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT


Check harness continuity between fuel level sensor unit and fuel pump connector terminal 5 and ground.

Terminals		(-)	Continuity
(+) (+)			
Connector	Terminal (Wire color)		
MB25	5 (B/R)	Ground	Yes

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



2. CHECK FUEL LEVEL SENSOR UNIT

Refer to [DI-26, "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG

OK >> GO TO 3.


NG >> Replace fuel level sensor unit.

3. CHECK HARNESS FOR OPEN OR SHORT

1. Disconnect combination meter connector and fuel level sensor unit and fuel pump connector.
2. Check continuity between combination meter terminal 30 (without tachometer) or terminal 44 (with tachometer) and fuel level sensor unit and fuel pump connector terminal 2.

Continuity should exist.

3. Check continuity between combination meter terminal 30 (without tachometer) or terminal 44 (with tachometer) and ground.



Continuity should not exist.

OK or NG

OK >> Fuel level sensor unit is OK.

NG >> Repair harness or connector.

METERS AND GAUGES

INSPECTION/WATER TEMPERATURE GAUGE (QG18DE MODELS)

1. CHECK ECM SELF-DIAGNOSIS

Perform ECM self diagnosis. Refer to [EC-113](#) (ULEV Models), [EC-694](#) (SULEV Models).

OK or NG

OK >> Replace combination meter.

NG >> Go to ECM trouble diagnosis. Refer to [EC-113](#) (ULEV Models), [EC-694](#) (SULEV Models).

METERS AND GAUGES

INSPECTION/WATER TEMPERATURE GAUGE (QR25DE MODELS)


1. CHECK ECM OUTPUT

1. Disconnect combination meter.
2. Check voltage between combination meter harness connector M30 terminal 43 (PU/W) and ground.

Battery voltage should exist.

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. CHECK HARNESS FOR OPEN OR SHORT

1. Disconnect ECM connector.
2. Check continuity between combination meter harness connector M30 terminal 43 (PU/W) and ECM harness connector F54 terminal 32 (PU).


Continuity should exist.

3. Check continuity between combination meter harness connector M30 terminal 43 (PU/W) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair harness or connector.




3. CHECK WATER TEMPERATURE OUTPUT SIGNAL

1. Connect combination meter connector and ECM connector.
2. Start engine.
3. Check output signal between combination meter harness connector M30 terminal 43 (PU/W) and ground. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)

Reading should be as shown.

OK or NG

- OK >> Replace combination meter.
NG >> Check ECM.



METERS AND GAUGES


EKS0039G

Electrical Components Inspection FUEL LEVEL SENSOR UNIT CHECK

- For removal, refer to [FL-3, "Removal and Installation"](#) .
Check the resistance between terminals 2 and 5.


Ohmmeter		Float position		mm (in)	Resistance (Approximate)
(+)	(-)				
2	5	*1	Full	136.1 (5.358)	4.5 - 5.5 Ω
		*2	1/2	89.8 (3.535)	31.5 - 33.5 Ω
		*3	Empty	31.3 (1.232)	80 - 83 Ω

*1 and *3: When float rod is in contact with stopper.



VEHICLE SPEED SENSOR SIGNAL CHECK

- Remove vehicle speed sensor from transmission.
- Turn vehicle speed sensor pinion quickly and measure voltage across terminals 1 and 2 (with QG18DE), or terminals + and - (with QR25DE).



WARNING LAMPS


WARNING LAMPS

Schematic WITHOUT TACHOMETER

PF24814

EKS0039H

(A) : WITH A/T
(U) : USA
(N) : CANADA




A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING LAMPS

WITH TACHOMETER

- (A) : WITH A/T
- (U) : USA
- (N) : CANADA
- (QR) : WITH QR25DE
- (QG) : WITH QG18DE
- (WF) : WITH WASHER FLUID LEVEL SWITCH





WKWA0510E

WARNING LAMPS

Wiring Diagram — WARN — WITHOUT TACHOMETER



EKS0039I

DI-WARN-01



WARNING LAMPS

DI-WARN-02









WKWA0238E

WARNING LAMPS

DI-WARN-03

CANADA






WKWA0239E

WARNING LAMPS

WITH TACHOMETER

DI-WARN-04



REFER TO THE FOLLOWING.



(F54) - ELECTRICAL UNITS

(F59) - ELECTRICAL UNITS

WKWA0512E



WARNING LAMPS

DI-WARN-05



WARNING LAMPS

DI-WARN-06





WKWA0242E

WARNING LAMPS

DI-WARN-07

WF : With washer fluid level switch



WKWA0585E

WARNING LAMPS

EKS0039J

Electrical Components Inspection FUEL WARNING LAMP OPERATION CHECK

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector B25.
3. Connect a resistor (80Ω) between fuel level sensor unit and fuel pump harness connector terminal 2 (G) and 5 (B/R).
4. Turn ignition switch ON.


The fuel warning lamp should come on.

NOTE:

ECM might store the 1st trip DTC P0180 and the 1st trip DTC P0464 during this inspection.

If the DTC is stored in ECM memory, erase the DTC after reconnecting fuel level sensor unit and fuel pump harness connector.


Refer to [EC-71, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) [QG18DE (ULEV Model)], [EC-651, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) [QG18DE (SULEV Model)], or [EC-1273, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) (QR25DE).



OIL PRESSURE SWITCH CHECK

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine running	More than 10 - 20 (0.1 - 0.2, 1 - 3)	No
Engine not running	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	Yes

Check the continuity between the terminals of oil pressure switch and body ground.




DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure.
- Check diodes at the combination meter harness connector instead of on the combination meter assembly. Refer to [DI-29, "Wiring Diagram — WARN —"](#).

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.










WARNING CHIME

WARNING CHIME

PF:24814

Component Parts and Harness Connector Location

EKS0039K



WKIA0160E

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING CHIME

EKS0039L

System Description WITHOUT POWER DOOR LOCKS

The warning chime is controlled by the time control unit.

The warning chime is located in the time control unit.

Power is supplied at all times:

- through 10A fuse [No. 13, located in fuse block (J/B)]
- to time control unit terminal 7
- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to key switch terminal 2, and
- through 10A fuse (No. 38, located in the fuse and fusible link box)
- to lighting switch terminal 11.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to time control unit terminal 9.

Ground is supplied to time control unit terminal 8 through body grounds M28 and M54.

When a signal, or combination of signals, is received by the time control unit, the warning chime will sound.

Ignition Key Warning Chime

With the key in the ignition switch, the ignition switch in the OFF position, and the driver door open, the warning chime will sound.

Power is supplied:

- from key switch terminal 1
- to time control unit terminal 4.

Ground is supplied:

- from front door switch LH terminal 2
- to time control unit terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B13 and B19.

Light Warning Chime

With ignition switch OFF, driver door open, and lighting switch in parking lamp (1ST) or ON (2ND) position, warning chime will sound.

Power is supplied:

- from lighting switch terminal 12
- to time control unit terminal 5.

Ground is supplied:

- from front door switch LH terminal 2
- to time control unit terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B13 and B19.

Seat Belt Warning Chime

With ignition switch turned ON and seat belt unfastened (seat belt buckle switch LH ON), warning chime will sound for approximately 6 seconds.

Ground is supplied:

- from seat belt buckle switch LH terminal 1
- to time control unit terminal 1.

Seat belt buckle switch LH terminal 2 is grounded through body grounds B13 and B19.

WITH POWER DOOR LOCKS

The warning chime is controlled by the smart entrance control unit.

The warning chime is located in the smart entrance control unit.

Power is supplied at all times:

- through 10A fuse (No. 37, located in fuse and fusible link box)
- to smart entrance control unit terminal 10,
- through 10A fuse [No. 12, located in the fuse block (J/B)]

WARNING CHIME

- to key switch terminal 2, and
- through 10A fuse (No. 38, located in the fuse and fusible link box)
- to lighting switch terminal 11.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 33.

Ground is supplied to smart entrance control unit terminal 16 through body grounds M28 and M54.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

Ignition Key Warning Chime

With the key in the ignition switch, the ignition switch in the OFF position, and the driver door open, the warning chime will sound.

Power is supplied:

- from key switch terminal 1
- to smart entrance control unit terminal 32.

Ground is supplied:

- from front door switch LH terminal 2
- to smart entrance control unit terminal 29.

Front door switch LH terminal 3 is grounded through body grounds B13 and B19.

Light Warning Chime

With ignition switch OFF, driver door open, and lighting switch in parking lamp (1ST) or ON (2ND) position, warning chime will sound.

Power is supplied:

- from lighting switch terminal 12
- to smart entrance control unit terminal 34.

Ground is supplied:

- from front door switch LH terminal 2
- to smart entrance control unit terminal 29.

Front door switch LH terminal 3 is grounded through body grounds B13 and B19.

Seat Belt Warning Chime

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied:

- from seat belt buckle switch LH terminal 1
- to smart entrance control unit terminal 22.

Seat belt buckle switch LH terminal 2 is grounded through body grounds B13 and B19.

A

B

C

D

E

F

G

H

I

J

DI

L



M

WARNING CHIME

EKS0039M

Wiring Diagram — CHIME — WITHOUT POWER DOOR LOCKS

DI-CHIME-01



WKWA0244E




TIME CONT. UNIT (WITHOUT POWER DOOR LOCKS) TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	W/B	SEAT BELT BUCKLE SWITCH LH	UNFASTEN (IGNITION KEY IN ON POSITION)	0V
			FASTEN (IGNITION SWITCH IN ON POSITION)	5V
2	R	FRONT DOOR SWITCH LH	OFF (CLOSED)	5V
			ON (OPEN)	0V
4	L/W	IGNITION KEY SWITCH (INSERT)	IGNITION KEY IS INSERTED	12V
			IGNITION KEY IS REMOVED	0V
5	R/G	COMBINATION SWITCH (LIGHTING SWITCH)	1ST, 2ND POSITIONS: ON	12V
			OFF	0V
7	PU	POWER SOURCE (FUSE)	—	12V
8	B	GROUND	—	—
9	G	IGNITION SWITCH (ON)	IGNITION KEY IS IN ON POSITION	12V
			IGNITION SWITCH (START)	12V

LEL597

WARNING CHIME

WITH POWER DOOR LOCKS



WKWA0245E

SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	PU	POWER SOURCE (FUSE)	—	12V
16	B	GROUND	—	—
22	W/B	SEAT BELT BUCKLE SWITCH LH	UNFASTEN (IGNITION KEY IN ON POSITION)	0V
			FASTEN (IGNITION KEY IN ON POSITION)	5V
29	R	FRONT DOOR SWITCH LH	OFF (CLOSED)	5V
			ON (OPEN)	0V
32	L/W	IGNITION KEY SWITCH (INSERT)	IGNITION KEY IS INSERTED	12V
			IGNITION KEY IS REMOVED	0V
33	G	IGNITION SWITCH (START)	IGNITION KEY IS IN ON POSITION	12V
			IGNITION KEY IS IN START POSITION	12V
34	R/G	COMBINATION SWITCH (LIGHTING SWITCH)	1ST, 2ND POSITIONS: ON	12V
			OFF	0V


LEL599

WARNING CHIME


EKS0039N

CONSULT-II Inspection Procedure (With Power Door Locks) “KEY WARN ALM”/“LIGHT WARN ALM”/“SEAT BELT ALM”


1. Turn ignition switch OFF.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch ON.
4. Touch “START”.



5. Touch “SMART ENTRANCE”.




6. Touch “KEY WARN ALM”, “LIGHT WARN ALM” or “SEAT BELT ALM”.



WARNING CHIME

7. Select diagnosis mode. "DATA MONITOR" and "ACTIVE TEST" are available for the warning chime.



CONSULT-II Application Items (With Power Door Locks) "KEY WARN ALARM"

EKS00390

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

Active Test

Test Item	Description
CHIME	This test is able to check key warning chime operation. Key warning chime sounds after touching "ON" on CONSULT-II screen.

"LIGHT WARN ALM"

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
HD/LMP 1ST SW	Indicates [ON/OFF] condition of lighting switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

Active Test

Test Item	Description
CHIME	This test is able to check light warning chime operation. Light warning chime sounds after touching "ON" on CONSULT-II screen.

"SEAT BELT ALM"

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt buckle switch LH.

Active Test

Test Item	Description
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds after touching "ON" on CONSULT-II screen.

WARNING CHIME

Trouble Diagnoses (Without Power Door Locks) SYMPTOM CHART

EKS0039P


REFERENCE PAGE	DI-44	DI-45	DI-45	DI-46	DI-47
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH LH CHECK)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X	X			X
Ignition key warning chime does not activate.	X		X		X
Seat belt warning chime does not activate.	X			X	X
All warning chimes do not activate.	X				X

X: Applicable

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power Supply Circuit Check


Terminals		(-)	Ignition switch position		
(+)	OFF		ACC	ON	
Connector	Terminal (Wire color)				
M40	7 (PU)	Ground	Battery voltage	Battery voltage	Battery voltage
M40	9 (G)	Ground	0V	0V	Battery voltage



WARNING CHIME

Ground Circuit Check

Terminals		(-)	Continuity
(+) Terminal (Wire color)			
Connector	Terminal (Wire color)		
M40	8 (B)	Ground	Yes




DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)

1. CHECK LIGHTING SWITCH INPUT SIGNAL

Check voltage between time control unit terminal 5 and ground.

Terminals		(-)	Condition of lighting switch		
(+) Terminal (Wire color)			1st position	2nd position	OFF
Connector	Terminal (Wire color)				
M40	5 (R/G)	Ground	Battery voltage	Battery voltage	0V



OK or NG

OK >> Lighting switch is OK.

NG >> Check the following.


- 10A fuse (No. 38, located in the fuse and fusible link box)
- Harness for open or short between control unit and lighting switch

DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)

1. CHECK KEY SWITCH INPUT SIGNAL

Check voltage between time control unit terminal 4 and ground.

Terminals		(-)	Condition of key switch	
(+) Terminal (Wire color)			Key inserted	Key removed
Connector	Terminal (Wire color)			
M40	4 (L/W)	Ground	Battery voltage	0V



OK or NG


OK >> Key switch is OK.

NG >> GO TO 2.

WARNING CHIME

2. CHECK KEY SWITCH

Check continuity between terminals 1 and 2.



OK or NG

OK >> Check the following.

- 10A fuse [No. 12, located in fuse block (J/B)]
- Harness for open or short between key switch and fuse
- Harness for open or short between time control unit and key switch

NG >> Replace key switch.

DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH LH CHECK)

1. CHECK SEAT BELT BUCKLE SWITCH LH INPUT SIGNAL


1. Turn ignition switch ON.
2. Check voltage between time control unit terminal 1 and ground.

Terminals		Condition of seat belt buckle switch LH		
(+)		(-)	Fastened	Unfastened
Connector	Terminal (Wire color)			
M40	1 (W/B)	Ground	Approx. 5V	0V

OK or NG

OK >> Seat belt buckle switch LH is OK.


NG >> GO TO 2.



WARNING CHIME

2. CHECK SEAT BELT BUCKLE SWITCH LH

Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.



OK or NG

OK >> Check the following.

- Seat belt buckle switch LH ground circuit
- Harness for open or short between time control unit and seat belt buckle switch LH

NG >> Replace seat belt buckle switch LH.

DIAGNOSTIC PROCEDURE 4

1. CHECK IGNITION ON SIGNAL

Check voltage between time control unit terminal 9 and ground.


Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
9 (G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between time control unit and fuse



2. CHECK FRONT DOOR SWITCH LH INPUT SIGNAL


With ignition switch OFF, check voltage between time control unit terminal 2 and ground.

Terminals		Condition of driver's door		
(+) Connector		(-)	Closed	Open
M40	Terminal (Wire color) 2 (R)	Ground	Approx. 5V	0V

OK or NG

OK >> System is OK.


NG >> GO TO 3.



WARNING CHIME

3. CHECK FRONT DOOR SWITCH LH

Check continuity between terminals 2 and 3.



OK or NG

OK >> Check the following.

- Front door switch LH ground circuit and condition
- Harness for open or short between time control unit and front door switch LH

NG >> Replace front door switch LH.

WARNING CHIME

Trouble Diagnoses (With Power Door Locks) SYMPTOM CHART

EKS0039Q


REFERENCE PAGE	DI-49	DI-50	DI-51	DI-52	DI-53
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH LH CHECK)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X	X			X
Ignition key warning chime does not activate.	X		X		X
Seat belt warning chime does not activate.	X			X	X
All warning chimes do not activate.	X				X

X: Applicable

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power Supply Circuit Check


Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
10	Ground	Battery voltage	Battery voltage	Battery voltage



WARNING CHIME

Ground Circuit Check

Terminals		(-)	Continuity
(+) Connector			
Terminal (Wire color)			
M38	16 (B)	Ground	Yes



DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)

1. CHECK LIGHTING SWITCH INPUT SIGNAL

With CONSULT-II

Check lighting switch ("HD/LMP 1ST SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
HD/LMP 1ST SW	OFF

When lighting switch is in 1st or 2nd position:
HD/LMP 1ST SW ON

When lighting switch is in OFF position:
HD/LMP 1ST SW OFF

SEL316W

Without CONSULT-II

Check voltage between smart entrance control unit terminal 34 and ground.

Smart entrance control unit connector (M39)

34

R/G

V

H.S.

CONNECT

OFF

Voltage [V]:
Condition of lighting switch:
Parking lamp (1ST) or ON (2ND)
Approx. 12
Condition of lighting switch: OFF
0

WEL468

OK or NG

OK >> Lighting switch is OK.

NG >> Check the following.

- 10A fuse (No. 38, located in the fuse and fusible link box)
- Harness for open or short between smart entrance control unit and lighting switch

WARNING CHIME

DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)

1. CHECK KEY SWITCH INPUT SIGNAL

With CONSULT-II

Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY ON SW	ON


When key is inserted to ignition key cylinder:
KEY ON SW ON

When key is removed from ignition key cylinder:
KEY ON SW OFF

SEL315W

Without CONSULT-II

Check voltage between smart entrance control unit terminal 32 and ground.



Smart entrance control unit connector (M39)

Voltage [V]:
Condition of key switch: Key is inserted.
Approx. 12
Condition of key switch: Key is removed.
0


WEL469

OK or NG

- OK >> Key switch is OK.
- NG >> GO TO 2.

2. CHECK KEY SWITCH

Check continuity between terminals 1 and 2.



Key switch connector (E113)

Continuity:
Condition of key switch: Key is inserted.
Yes
Condition of key switch: Key is removed.
No

LEL449

OK or NG

- OK >> Check the following.
 - 10A fuse [No. 12, located in fuse block (J/B)]
 - Harness for open or short between key switch and fuse
 - Harness for open or short between smart entrance control unit and key switch
- NG >> Replace key switch.

WARNING CHIME

DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH LH CHECK)

1. CHECK SEAT BELT BUCKLE SWITCH LH INPUT SIGNAL

④ With CONSULT-II

Check seat belt buckle switch LH ("SEAT BELT SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
SEAT BELT SW	ON

When seat belt is fastened:
SEAT BELT SW OFF

When seat belt is released:
SEAT BELT SW ON

LEL658

⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between smart entrance control unit terminal 22 and ground.

Smart entrance control unit connector (M39)

22

W/B

V

H.S.

CONNECT

ON

Voltage [V]:
Condition of seat belt buckle switch LH: Fastened
Approx. 5
Condition of seat belt buckle switch LH: Unfastened
0

WEL470

OK or NG

- OK >> Seat belt buckle switch LH is OK.
NG >> GO TO 2.

2. CHECK SEAT BELT BUCKLE SWITCH LH

Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.

Seat belt buckle switch LH connector (B8)

1

2

Ω

I.S.

DISCONNECT

Continuity:
Seat belt is fastened.
No
Seat belt is unfastened.
Yes

LEL462

OK or NG

- OK >> Check the following.
- Seat belt buckle switch LH ground circuit
 - Harness for open or short between smart entrance control unit and seat belt buckle switch LH
- NG >> Replace seat belt buckle switch LH.

WARNING CHIME

DIAGNOSTIC PROCEDURE 4

1. CHECK IGNITION ON SIGNAL

With CONSULT-II

Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
IGN ON SW	ON


When ignition switch is ON:
IGN ON SW ON

When ignition switch is OFF:
IGN ON SW OFF

SEL318W

Without CONSULT-II

Check voltage between smart entrance control unit terminal 33 and ground.



Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
33	Ground	0V	0V	Battery voltage

WEL471

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

WARNING CHIME

2. CHECK FRONT DOOR SWITCH LH INPUT SIGNAL

With CONSULT-II

Check front door switch LH signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF


When driver's door is open:
DOOR SW-DR ON

When driver's door is closed:
DOOR SW-DR OFF

SEL319W

Without CONSULT-II

Check voltage between smart entrance control unit terminal 29 and ground.



Smart entrance control unit connector (M39)

H.S.
CONNECT

Voltage [V]:
Condition of driver's door: **CLOSED**
Approx. 5
Condition of driver's door: **OPENED**
0


WEL472

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.

3. CHECK FRONT DOOR SWITCH LH

Check continuity between terminals 2 and 3.



Front door switch LH connector (B23)

T.S.
DISCONNECT

Continuity:
Door switch is pushed.
No
Door switch is released.
Yes

LEL465

OK or NG


- OK >> Check the following.
- Front door switch LH ground circuit and condition
 - Harness for open or short between smart entrance control unit and front door switch LH
- NG >> Replace front door switch LH.

WARNING CHIME

4. CHECK WARNING CHIME

With CONSULT-II

Perform "CHIME" in "ACTIVE TEST" mode with CONSULT-II.



OK or NG

- OK >> System is OK.
- NG >> Replace smart entrance control unit.

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING CHIME
