

SECTION **RFD**
REAR FINAL DRIVE

A
B
C

RFD

CONTENTS

PRECAUTIONS	2	CARRIER COVER	12	F
Precautions for Servicing Rear Final Drive	2	Removal and Installation	12	
PREPARATION	3	REMOVAL	12	
Special Service Tools	3	INSTALLATION	12	G
Commercial Service Tools	5	REAR FINAL DRIVE ASSEMBLY	13	
NOISE, VIBRATION, AND HARSHNESS (NVH)		Removal and Installation	13	
TROUBLESHOOTING	7	REMOVAL	13	H
NVH Troubleshooting Chart	7	INSTALLATION	14	
DIFFERENTIAL GEAR OIL	8	Disassembly and Assembly	15	
Changing Differential Gear Oil	8	COMPONENTS	15	I
DRAINING	8	ASSEMBLY INSPECTION AND ADJUSTMENT..	16	
FILLING	8	DISASSEMBLY	19	
Checking Differential Gear Oil	8	INSPECTION AFTER DISASSEMBLY	23	J
OIL LEAKAGE AND OIL LEVEL	8	ADJUSTING AND SELECTING WASHERS	24	
FRONT OIL SEAL	9	ASSEMBLY	26	
Removal and Installation	9	SERVICE DATA AND SPECIFICATIONS (SDS)	32	K
REMOVAL	9	General Specifications	32	
INSTALLATION	9	Inspection and Adjustment	32	
SIDE OIL SEAL	11	DRIVE GEAR RUNOUT	32	L
Removal and Installation	11	SIDE GEAR CLEARANCE	32	
REMOVAL	11	PRELOAD TORQUE	32	
INSTALLATION	11	BACKLASH	32	
		COMPANION FLANGE RUNOUT	32	M
		SELECTIVE PARTS	32	

PRECAUTIONS

PRECAUTIONS

PF:00001

Precautions for Servicing Rear Final Drive

EDS0044G

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

PREPARATION

PREPARATION

PF0:00002

Special Service Tools







EDS003WM

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool name Tool number (Kent-Moore No.)	Description
KV40104000 (—) Flange wrench	Removing and installing drive pinion nut a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia.
KV381054S0 (J-34286) Puller	Removing front oil seal
ST15310000 (—) Drift	<ul style="list-style-type: none"> ● Installing front oil seal ● Installing drive pinion rear bearing outer race. a: 96 mm (3.77 in) dia. b: 84 mm (3.30 in) dia.
ST36230000 (J-25840-A) Slide hammer	Removing side flange
KV40104100 (—) Axle stand	Removing side flange
ST35271000 (—) Drift	Installing side oil seal a: 72 mm (2.83 in) dia. b: 63 mm (2.48 in) dia.
KV38107900 (J-39352) Protector	Installing side flange

A
B
C
RFD
E
F
G
H
I
J
K
L
M

PREPARATION

Tool name Tool number (Kent-Moore No.)	Description
KV38100800 (J-25604-01) Attachment <div style="text-align: center;">  <p style="text-align: right; font-size: small;">SDIA0267E</p> </div>	Securing unit assembly a: 541 mm (21.30 in) dia. b: 200 mm (7.87 in) dia.
ST3127S000 (J-25765-A) Preload gauge 1. GG91030000 (J-25765) Torque wrench 2. HT62940000 (—) Socket adapter (1/2 in) 3. HT62900000 (—) Socket adapter (3/8 in) <div style="text-align: center;">  <p style="text-align: right; font-size: small;">NT124</p> </div>	Measuring drive pinion bearing preload torque and total preload torque
KV10111100 (J-37228) Seal cutter <div style="text-align: center;">  <p style="text-align: right; font-size: small;">S-NT046</p> </div>	Removing carrier cover
ST3306S001 (—) Differential side bearing puller set 1. ST33051001 (—) Puller 2. ST33061000 (J-8107-2) Base <div style="text-align: center;">  <p style="text-align: right; font-size: small;">NT072</p> </div>	Removing side bearing inner race a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.
ST30021000 (—) Bearing puller <div style="text-align: center;">  <p style="text-align: right; font-size: small;">ZZA0700D</p> </div>	Removing drive pinion rear bearing inner race
KV38100200 (J-26233) Drift <div style="text-align: center;">  <p style="text-align: right; font-size: small;">ZZA1143D</p> </div>	Installing side bearing inner race a: 65 mm (2.55 in) dia. b: 49 mm (1.92 in) dia.

PREPARATION


Tool name Tool number (Kent-Moore No.)	Description
ST33081000 (—) Drift	Installing side bearing inner race a: 43 mm (1.69 in) dia. b: 33.5 mm (1.31 in) dia.
ST35325000 (—) Drift	Installing drive pinion front bearing outer race (use with ST30621000)
ST30621000 (—) Drift	Installing drive pinion front bearing outer race a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.
ST30022000 (—) Drift	Installing drive pinion rear bearing inner race a: 110 mm (4.33 in) dia. b: 46 mm (1.81 in) dia.
HT72400000 (—) Slide hammer	Removing differential case assembly
— (J-8129) Spring gauge	Measuring turning torque
KV10112100 (BT-8653-A) Angle wrench	Tightening bolts for drive gear

A
B
C
RFD
E
F
G
H
I
J
K
L
M

Commercial Service Tools

EDS003WN

PREPARATION

Tool name	Description
<p data-bbox="147 197 261 222">Power tool</p>  <p data-bbox="862 415 935 432">PBIC0190E</p>	<p data-bbox="1003 197 1255 222">Loosening nuts and bolts</p>

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PF0:0003

NVH Troubleshooting Chart

EDS003WO

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

			Reference page													
			RFD-23	RFD-17	RFD-17	RFD-18	RFD-18	RFD-8	PR-3, "NVH Troubleshooting Chart"	RAX-4, "NVH Troubleshooting Chart"	RSU-5, "NVH Troubleshooting Chart"	WT-4, "NVH Troubleshooting Chart"	WT-4, "NVH Troubleshooting Chart"	RAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	PS-5, "NVH Troubleshooting Chart"
Possible cause and SUSPECTED PARTS			Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	REAR AXLE	REAR SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	FINAL DRIVE	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x

x: Applicable

A
B
C
RFD
E
F
G
H
I
J
K
L
M

DIFFERENTIAL GEAR OIL

PPF:KLD30


EDS0044H

DIFFERENTIAL GEAR OIL

Changing Differential Gear Oil DRAINING

1. Stop the engine.
2. Remove the drain plug and gasket from the rear final drive assembly to drain the differential gear oil.
3. Install the drain plug with a new gasket to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

CAUTION:
Do not reuse gasket.




FILLING

1. Remove the filler plug and gasket from the rear final drive assembly.
2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil grade and capacity : Refer to [MA-11, "Fluids and Lubricants"](#).

3. Install the filler plug with a new gasket on it to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

CAUTION:
Do not reuse gasket.



Checking Differential Gear Oil OIL LEAKAGE AND OIL LEVEL


EDS0044I

1. Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.

CAUTION:
Do not start engine while checking differential gear oil level.

3. Install the filler plug with a new gasket on it to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

CAUTION:
Do not reuse gasket.



FRONT OIL SEAL

PFP:38189

FRONT OIL SEAL

Removal and Installation

EDS003WP

REMOVAL

1. Remove the drive shafts from the rear final drive assembly. Refer to [RAX-7, "Removal and Installation"](#) .
2. Remove the side flanges and side oil seals. Refer to [RFD-11, "Removal and Installation"](#) .
3. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
4. Measure the total preload torque. Refer to [RFD-16, "Total Preload Torque"](#) .

NOTE:

Record the total preload torque measurement.


5. Remove the drive pinion lock nut using Tool.

Tool number : KV40104000 (—)


6. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.




7. Remove the companion flange using suitable tool.



8. Remove the front oil seal using Tool.

Tool number : KV381054S0 (J-34286)




INSTALLATION

1. Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : ST15310000 (—)

CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips of the new front oil seal.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

FRONT OIL SEAL

2. Install the companion flange to the drive pinion while aligning the matching marks.
3. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

Tool number **A: KV40104000 (—)**
 B: ST3127S000 (J-25765-A)

Total preload torque: Refer to [RFD-16, "Total Preload Torque"](#) .


- The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg-m, 5 in-lb).
- If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg-m, 5ft-lb) increments until the total preload torque is met.

CAUTION:

- Do not reuse drive pinion lock nut.
 - Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
 - Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-15, "COMPONENTS"](#) .
 - Do not loosen drive pinion lock nut to adjust the total preload torque. If the total preload torque exceeds the specifications, replace the collapsible spacer and tighten it again to adjust. Refer to [RFD-15, "Disassembly and Assembly"](#) .
 - After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
4. Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to [RFD-8, "Checking Differential Gear Oil"](#) .



SIDE OIL SEAL

PFP:33142

EDS003WQ


SIDE OIL SEAL

Removal and Installation

REMOVAL


1. Remove the drive shaft from the rear final drive assembly. Refer to [RAX-7, "Removal and Installation"](#).
2. Remove the side flange using Tools.

Tool numbers **A: KV40104100 (—)**
 B: ST36230000 (J-25840-A)



3. Remove the side oil seal using suitable tool.

CAUTION:
Do not to damage gear carrier.




INSTALLATION

1. Apply multi-purpose grease to the lips of the new side oil seal. Then drive the new side oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : **ST35271000 (—)**

CAUTION:

- Do not reuse side oil seal.
- Do not incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips of the new side oil seal.



2. Install the side flange using Tool.
 - a. Install the Tool to the side oil seal as shown.

Tool number : **KV38107900 (J-39352)**

- b. Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the Tool.
- c. Drive in the side flange using suitable tool.


NOTE:

Installation is completed when the driving sound of the side flange turns into a sound which seems to affect the whole rear final drive assembly.

3. Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to [RFD-8, "Checking Differential Gear Oil"](#).



A
B
C
RFD
E
F
G
H
I
J
K
L
M

CARRIER COVER

PF3:38351

EDS0044J

CARRIER COVER

Removal and Installation


REMOVAL

1. Remove the rear final drive assembly. Refer to [RFD-13, "Removal and Installation"](#).
2. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



INSTALLATION

1. Apply a 3 mm (0.12 in) bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to [GI-45, "Recommended Chemical Products and Sealants"](#).


CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).
3. Install the rear final drive assembly. Refer to [RFD-13, "Removal and Installation"](#).

CAUTION:

Fill the rear final drive assembly with recommended differential gear oil. Refer to [RFD-8, "DIFFERENTIAL GEAR OIL"](#).




REAR FINAL DRIVE ASSEMBLY

PF3:38300

REAR FINAL DRIVE ASSEMBLY

Removal and Installation


EDS003WR



- | | | |
|------------------------------|------------------------------|-------------------------|
| 1. Breather hose | 2. Rear final drive assembly | 3. Rear propeller shaft |
| 4. Washer | 5. Lower stopper | 6. Rear drive shaft |
| 7. Rear final drive assembly | 8. Upper stopper | ← Vehicle front |

REMOVAL

1. Remove the spare tire.
2. Drain the differential gear oil. Refer to [FFD-7, "DIFFERENTIAL GEAR OIL"](#).
3. Remove the rear stabilizer bar. Refer to [RSU-42, "Removal and Installation"](#).
4. Remove the rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#).
5. Remove the rear drive shafts from the rear final drive assembly and support them using suitable wire. Refer to [RAX-7, "Removal and Installation"](#).



6. Disconnect the breather hose from the rear final drive assembly.

REAR FINAL DRIVE ASSEMBLY

- Place a suitable jack under the rear final drive assembly.


CAUTION:

Do not place the jack on the carrier cover.

- Remove the nuts and bolts and remove the rear final drive assembly.

CAUTION:

Secure rear final drive assembly to the jack while removing it.



WDIA0117E

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:


- When installing the breather hose make sure the painted marking on the metal end of breather hose is to the front of the vehicle and there are no pinched or restricted areas on the breather hose caused by folding or bending when installing it.
- When installing the breather hose insert the plastic end of the breather hose into the hole in the suspension member.
- Fill the front final drive assembly with differential gear oil after installation. Refer to [RFD-8, "DIFFERENTIAL GEAR OIL"](#).

REAR FINAL DRIVE ASSEMBLY

EDS003WU

Disassembly and Assembly COMPONENTS

SEC.380



- : Lubricate with new gear oil
- : Apply genuine medium strength locking sealant or equivalent. Refer to GI section.
- : N•m (kg-m, ft-lb)
- : Apply genuine thread sealant or equivalent. Refer to GI section.
- ☆ : Adjustment is required.
- : Always replace after every disassembly.
- : Lubricate with grease.

WDIA0191E

REAR FINAL DRIVE ASSEMBLY

- | | | |
|---|-------------------------------|------------------------------|
| 1. Drive pinion lock nut | 2. Companion flange | 3. Front oil seal |
| 4. Drive pinion front bearing | 5. Collapsible spacer | 6. Drive pinion rear bearing |
| 7. Drive pinion height adjusting washer | 8. Drive pinion | 9. Gear carrier |
| 10. Drive gear | 11. Pinion mate shaft | 12. Lock pin |
| 13. Pinion mate gear | 14. Pinion mate thrust washer | 15. Side gear |
| 16. Side gear thrust washer | 17. Differential case | 18. Side bearing |
| 19. Side bearing adjusting washer | 20. Bearing cap | 21. Carrier cover |
| 22. Filler plug | 23. Drain plug | 24. Side oil seal |

ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to [RFD-8, "DIFFERENTIAL GEAR OIL"](#).
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to [RFD-12, "CARRIER COVER"](#).

Total Preload Torque

1. Remove the side flanges if necessary. Refer to [RFD-19, "Side Flange"](#).

CAUTION:

The side flanges shaft must removed in order to measure total preload torque.

2. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
3. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
4. Measure the total preload torque using Tool.


Tool number : ST3127S000 (J-25765-A)

Total preload torque:

2.05 - 4.11 N·m (0.21 - 0.42 kg·m, 19 - 36 in·lb)

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque



- If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

If the total preload torque is greater than specification

On drive pinion bearings: Replace the collapsible spacer.

On side bearings: Use thinner side bearing adjusting washers by the same amount on each side. Refer to [RFD-33, "Side Bearing Adjusting Washer"](#).

If the total preload torque is less than specification

On drive pinion bearings: Tighten the drive pinion lock nut.

On side bearings: Use thicker side bearing adjusting washers by the same amount on each side. Refer to [RFD-33, "Side Bearing Adjusting Washer"](#).

CAUTION:

Select a side bearing adjusting washer for right and left individually.

REAR FINAL DRIVE ASSEMBLY

Drive Gear Runout


1. Fit a dial indicator to the drive gear back face.
2. Rotate the drive gear to measure runout.

Runout limit : 0.05 mm (0.0020 in) or less

- If the runout is outside of the limit, check the condition of the drive gear assembly. Foreign material may be caught between the drive gear and differential case, or the differential case or drive gear may be deformed.

CAUTION:

Replace drive gear and drive pinion as a set.




A
B
C
RFD

Tooth Contact

1. Apply red lead to the drive gear.

NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.




E
F
G
H

2. Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown.


CAUTION:

Check tooth contact on drive side and reverse side.



I
J
K
L


3. If the tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height (dimension X).




M

REAR FINAL DRIVE ASSEMBLY

- If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washers to move the drive pinion closer to the drive gear. Refer to [RFD-33, "Drive Pinion Height Adjusting Washer"](#) .



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washers to move the drive pinion farther from the drive gear. Refer to [RFD-33, "Drive Pinion Height Adjusting Washer"](#) .



Backlash

1. Fit a dial indicator to the drive gear face to measure the backlash.

Backlash : 0.13 - 0.18 mm (0.0051 - 0.0070 in)


- If the backlash is outside of the specification, change the thickness of the side bearing adjusting washers.

If the backlash is greater than specification:

Make side bearing adjusting washer thicker on drive gear back side, and side bearing adjusting washer thinner on drive gear tooth side by the same amount. Refer to [RFD-33, "Side Bearing Adjusting Washer"](#) .

If the backlash is less than specification:

Make side bearing adjusting washer thinner on drive gear back side, and side bearing adjusting washer thicker on drive gear tooth side by the same amount. Refer to [RFD-33, "Side Bearing Adjusting Washer"](#) .



CAUTION:


Do not change the total thickness of side bearing adjusting washers as it will change the side bearing preload torque.

Companion Flange Runout

1. Rotate companion flange and check for runout on the outer face of the companion flange using suitable tool.

Runout limit : 0.08 mm (0.0031 in) or less

2. If the runout is outside of the runout limit, follow the procedure below to adjust.
 - a. Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
 - b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause



REAR FINAL DRIVE ASSEMBLY

could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.

- c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.

DISASSEMBLY

Side Flange

1. Drain the differential gear oil if necessary.
2. Remove the side flange using Tools.

Tool numbers **A:** KV40104100 (—)
 B: ST36230000 (J-25840-A)

3. Remove the side oil seal using suitable tool.


CAUTION:
Do not to damage gear carrier.

Differential Assembly

1. Remove the side flanges. Refer to [RFD-19, "Side Flange"](#).
2. Remove the carrier cover bolts.
3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.


Tool number : KV10111100 (J-37228)

- CAUTION:**
- Do not damage the mating surface.
 - Do not insert flat-bladed screwdriver, this will damage the mating surface.




4. Mount the carrier on the Tool using two 45 mm (1.77 in) spacers.

Tool number : KV38100800 (J-25604-01)




5. For proper reinstallation, paint matching marks on one side of the side bearing cap and gear carrier.

- CAUTION:**
- For matching marks, use paint. Do not damage side bearing cap or gear carrier.
 - Side bearing caps are line-board during manufacture. The matching marks are used to reinstall them in their original positions.




REAR FINAL DRIVE ASSEMBLY

6. Remove the side bearing caps.




7. Lift the differential case assembly out using Tool.

Tool number : HT72400000 (—)



CAUTION:

- Keep side bearing outer races together with inner race. Do not mix them up.
- Keep side bearing adjusting washers together with side bearings.




REAR FINAL DRIVE ASSEMBLY

8. Remove the side bearing inner races using Tools.

Tool number **A: ST3306S001 (—)**
 B: ST33061000 (J-8107-2)

CAUTION:

- Engage Tool jaws in bearing groove to prevent damage.
- Place copper plates between the side bearing and drive gear and the vise to prevent damage.
- Do not remove side bearing inner race unless it is being replaced.



9. For proper reinstallation, paint matching marks on the differential case and drive gear.

CAUTION:


Use paint for matching marks. Do not damage differential case or drive gear.

10. Remove the drive gear bolts.


11. Tap the drive gear off the differential case using suitable tool.

CAUTION:


Tap evenly all around to keep drive gear from bending.



12. Remove the lock pin of the pinion mate shaft from the drive gear side using suitable tool.




13. Remove the pinion mate shaft.



A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY

14. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from the differential case.



Drive Pinion Assembly


1. Remove the differential assembly. Refer to [RFD-19, "Differential Assembly"](#).
2. Remove the drive pinion lock nut using Tool.

Tool number : KV40104000 (—)


3. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.



4. Remove the companion flange using suitable tool.



5. Press the drive pinion assembly (with rear inner bearing race and collapsible spacer) out of the gear carrier.

CAUTION:


Do not drop drive pinion assembly.

6. Remove the front oil seal.

CAUTION:

Do not damage gear carrier.


7. Remove the drive pinion front bearing inner race.



REAR FINAL DRIVE ASSEMBLY

8. Remove the drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.


Tool number: : ST30021000 (—)



9. Remove the drive pinion front and rear bearing outer races by tapping them uniformly using suitable tool.

CAUTION:

Do not damage gear carrier.



INSPECTION AFTER DISASSEMBLY

Clean the disassembled parts. Then inspect the parts for wear or damage. If wear or damage are found, follow the measures below.

Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

- If any chips (by friction), damage, or unusual wear are found, replace with new one.

Gear Carrier

- If any wear or cracks are found on the contact sides of gear carrier, replace with new one.

Companion Flange


- If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

REAR FINAL DRIVE ASSEMBLY

ADJUSTING AND SELECTING WASHERS

Side Gear Back Clearance

- Assemble the differential parts if they are disassembled. Refer to [RFD-28, "Differential Assembly"](#).
- Place the differential case straight up so that the side gear to be measured is upward.



- Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

Side gear back clearance: 0.20 mm (0.0079 in) or less.

- If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to [RFD-32, "Side Gear Thrust Washer"](#).

If the side gear back clearance is greater than specification:

Use a thicker side gear thrust washer.

If the side gear back clearance is less than specification:


Use a thinner side gear thrust washer.

CAUTION:

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- Select a side gear thrust washer for right and left individually.

NOTE:

Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.




Side Bearing Preload Torque

- A selection of side bearing adjusting washers is required for successful completion of this procedure.
- Apply differential gear oil to the side bearings, and install the differential case assembly with the side bearing outer races into the gear carrier.


CAUTION:

Do not reuse side bearing outer race when replacing side bearing inner race (replace as a set).




REAR FINAL DRIVE ASSEMBLY

- Insert the left and right original side bearing adjusting washers in place between side bearings and gear carrier.



- Align the matching mark on the side bearing cap with the matching mark on the gear carrier.
- Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).
- Turn the differential assembly several times to seat the side bearings.




- To determine side bearing preload torque, measure the pulling force of the differential assembly at the drive gear bolt using Tool.

Tool number : — (J-8129)

Specification : 34.2 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb)
of pulling force at the drive gear bolt

NOTE:

If pulling force of the differential assembly at the drive gear bolt is within specification, side bearing preload torque will also be within specification. Refer to [RFD-32, "PRELOAD TORQUE"](#).



- If the pulling force is outside the specification, use a thicker or thinner side bearing adjusting washer to adjust. Refer to [RFD-33, "Side Bearing Adjusting Washer"](#).

If the pulling force is less than the specification:


Use a thicker side bearing adjusting washer.

If the pulling force is greater than the specification:

Use a thinner side bearing adjusting washer.

CAUTION:

Select a side bearing adjusting washer for right and left individually.



- Record the total amount of washer thickness required for the correct side bearing preload torque.

A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY

ASSEMBLY


Drive Pinion Assembly

1. Install the drive pinion front and rear bearing outer races using Tools.

Tool number **A:** ST15310000 (—)
 B: ST35325000 (—)
 C: ST30621000 (—)

CAUTION:

Do not reuse drive pinion front and rear bearing outer race.




2. Select a drive pinion height adjusting washer. Refer to [RFD-33, "Drive Pinion Height Adjusting Washer"](#).
3. Install the selected drive pinion height adjusting washer to the drive pinion. Press the drive pinion rear bearing inner race to it using Tool.

Tool number : ST30022000 (—)

CAUTION:

- Install the drive pinion height adjusting washer in the proper direction as shown.
- Do not reuse drive pinion rear bearing inner race.



4. Assemble the collapsible spacer to the drive pinion.


CAUTION:

Do not reuse collapsible spacer.

5. Apply differential gear oil to the drive pinion rear bearing, and install the drive pinion assembly to the gear carrier.
6. Apply differential gear oil to the drive pinion front bearing, and install the drive pinion front bearing inner race to the drive pinion assembly.


CAUTION:

Do not reuse drive pinion front bearing inner race.



REAR FINAL DRIVE ASSEMBLY

7. Press the drive pinion front bearing inner race to the drive pinion as far as drive pinion lock nut can be tightened using suitable spacer.




8. Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : ST15310000 (—)

CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips of the new front oil seal.



9. Install the companion flange to the drive pinion while aligning the matching marks.

10. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

Tool number A: KV40104000 (—)


B: ST3127S000 (J-25765-A)

Drive pinion bearing preload torque:

1.77 - 2.64 N·m (0.18 - 0.26 kg·m, 16 - 23 in·lb)

CAUTION:

- Do not reuse drive pinion lock nut.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-15, "COMPONENTS"](#).
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.




11. Check companion flange runout. Refer to [RFD-18, "Companion Flange Runout"](#).

12. Install the differential case assembly. Refer to [RFD-28, "Differential Assembly"](#).

REAR FINAL DRIVE ASSEMBLY

Differential Assembly

1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly, or reinstall the old ones on the side gears.




2. Install the side gears and side gear thrust washers into the differential case.


CAUTION:

Make sure that the circular clip is installed to side gears.

3. Install the pinion mate thrust washers to the two pinion mate gears. Then install the pinion mate gears with the pinion mate thrust washers by aligning them in diagonally opposite positions and rotating them into the differential case.




4. Align the lock pin hole on the differential case with the lock pin hole on the pinion mate shaft, and install the pinion mate shaft.
5. Measure the side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to [RFD-24, "Side Gear Back Clearance"](#).



6. Drive a new lock pin into the pinion mate shaft until it is flush with the differential case using suitable tool.


CAUTION:

Do not reuse lock pin.



REAR FINAL DRIVE ASSEMBLY


7. Align the matching mark of the differential case with the mark of the drive gear, then place the drive gear onto the differential case.



8. Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.
- Use Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to [GI-45, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Make sure the drive gear back and threaded holes are clean.




9. Tighten the drive gear bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#). After tightening the drive gear bolts to the specified torque, tighten an additional 34° using Tool.

Tool number : KV10112100-A (BT-8653-A)

CAUTION:

- Always use Tool. Avoid tightening based on visual check alone.
- Tighten drive gear bolts in a crisscross pattern.




10. Press the side bearing inner races into the differential case using Tools.

Tool number A: KV38100200 (J-26233)


B: ST33081000 (—)

CAUTION:

Do not reuse side bearing inner race.




11. Install the differential case assembly with the side bearing outer races into the gear carrier.
12. Measure the side bearing preload torque. If necessary, select the appropriate side bearing adjusting washers. Refer to [RFD-24, "Side Bearing Preload Torque"](#).




A
B
C
RFD
E
F
G
H
I
J
K
L
M

REAR FINAL DRIVE ASSEMBLY

13. Insert the selected left and right side bearing adjusting washers in place between the side bearings and gear carrier.



14. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



15. Check and adjust the drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [RFD-17, "Drive Gear Runout"](#), [RFD-17, "Tooth Contact"](#), [RFD-18, "Backlash"](#) and [RFD-16, "Total Preload Torque"](#).
Recheck the above items.

16. Install the side flanges. Refer to [RFD-30, "Side Flange"](#).

17. Apply a 3.2mm (0.126 in) bead of sealant to the mating surface of the carrier cover.


- Use Genuine Silicone RTV or equivalent. Refer to [GI-45, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

18. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

19. Install the side flange. Refer to [RFD-30, "Side Flange"](#).




Side Flange

1. Apply multi-purpose grease to the lips of the new side oil seal. Then drive the new side oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : ST35271000 (—)

CAUTION:

- Do not reuse side oil seal.
- Do not incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips of the new side oil seal.



REAR FINAL DRIVE ASSEMBLY


2. Install the side flange using Tool.
- a. Install the Tool to the side oil seal as shown.

Tool number : KV38107900 (J-39352)

- b. Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the Tool.
- c. Drive in the side flange using suitable tool.

NOTE:

Installation is completed when the driving sound of the side flange turns into a sound which seems to affect the whole rear final drive assembly.



A

B

C

RFD

E

F

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

General Specifications

EDS003WV

Applied model	VK56DE	
	2WD	4WD
Final drive model	R230	
Gear ratio	2.937	3.357
Number of teeth (Drive gear/Drive pinion)	47 / 16	47 / 14
Oil capacity (Approx.)	1.75 ℓ (3 3/4 US pt, 3 1/8 Imp pt)	
Number of pinion gears	2	
Drive pinion adjustment spacer type	Collapsible	

Inspection and Adjustment DRIVE GEAR RUNOUT

EDS003WW

Unit: mm (in)

Item	Runout limit
Drive gear back face	0.05 (0.0020) or less

SIDE GEAR CLEARANCE

Unit: mm (in)

Item	Specification
Side gear back clearance (Clearance limit between side gear and differential case for adjusting side gear backlash)	0.20 (0.0079) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

PRELOAD TORQUE

Unit: N·m (kg·m, in·lb)

Item	Specification
Drive pinion bearing preload torque	1.77 – 2.64 N·m (0.18 – 0.26 kg·m, 16 – 23 in·lb)
Side bearing preload torque (reference value determined by drive gear bolt pulling force)	0.20 – 0.52 N·m (0.02 – 0.05 kg·m, 2 – 4 in·lb)
Drive gear bolt pulling force (by spring gauge)	34.2 – 39.2 N (3.5 – 4 kg, 7.7 – 8.8 lb)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.05 – 4.11 N·m (0.21 – 0.42 kg·m, 19 – 36 in·lb)

BACKLASH

Unit: mm (in)

Item	Specification
Drive gear to drive pinion gear	0.13 – 0.18 (0.0051 – 0.0070)

COMPANION FLANGE RUNOUT

Unit: mm (in)

Item	Runout limit
Outer side of the companion flange	0.08 (0.0031) or less

SELECTIVE PARTS

Side Gear Thrust Washer

Unit: mm (in)

Thickness	Part number*
1.75 (0.0688)	38424 7S000
1.80 (0.0708)	38424 7S001
1.85 (0.0728)	38424 7S002

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Drive Pinion Height Adjusting Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
2.59 (0.1020)	38154 40P00	2.79 (0.1098)	38154 40P10
2.61 (0.1028)	38154 40P01	2.81 (0.1106)	38154 40P11
2.63 (0.1035)	38154 40P02	2.83 (0.1114)	38154 40P12
2.65 (0.1043)	38154 40P03	2.85 (0.1122)	38154 40P13
2.67 (0.1051)	38154 40P04	2.87 (0.1130)	38154 40P14
2.69 (0.1059)	38154 40P05	2.89 (0.1138)	38154 40P15
2.71 (0.1067)	38154 40P06	2.91 (0.1146)	38154 40P16
2.73 (0.1075)	38154 40P07	2.93 (0.1154)	38154 40P17
2.75 (0.1083)	38154 40P08	2.95 (0.1161)	38154 40P18
2.77 (0.1091)	38154 40P09	2.97 (0.1169)	38154 40P19

*: Always check with the Parts Department for the latest parts information.

Side Bearing Adjusting Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
2.00 (0.0787)	38453 40P00	2.35 (0.0925)	38453 40P07
2.05 (0.0807)	38453 40P01	2.40 (0.0945)	38453 40P08
2.10 (0.0827)	38453 40P02	2.45 (0.0965)	38453 40P09
2.15 (0.0846)	38453 40P03	2.50 (0.0984)	38453 40P10
2.20 (0.0866)	38453 40P04	2.55 (0.1004)	38453 40P11
2.25 (0.0886)	38453 40P05	2.60 (0.1024)	38453 40P12
2.30 (0.0906)	38453 40P06		

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)
