

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

<p>PRECAUTIONS 5</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 5</p> <p>Precautions When Using CONSULT-II 5</p> <p style="padding-left: 20px;">CHECK POINTS FOR USING CONSULT-II 5</p> <p>Precautions For Trouble Diagnosis 5</p> <p style="padding-left: 20px;">CAN SYSTEM 5</p> <p>Precautions For Harness Repair 6</p> <p style="padding-left: 20px;">CAN SYSTEM 6</p> <p>TROUBLE DIAGNOSES WORK FLOW 7</p> <p>When Displaying CAN Communication System Errors 7</p> <p style="padding-left: 20px;">WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM 7</p> <p style="padding-left: 20px;">WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM 7</p> <p style="padding-left: 20px;">TROUBLE DIAGNOSIS FLOW CHART 8</p> <p>Diagnosis Procedure 9</p> <p style="padding-left: 20px;">SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) 9</p> <p style="padding-left: 20px;">ACQUISITION OF DATA BY CONSULT-II 10</p> <p style="padding-left: 20px;">HOW TO USE CHECK SHEET TABLE 11</p> <p>CAN Diagnostic Support Monitor 17</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM 17</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM 18</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT 18</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM 19</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TRANSFER CONTROL UNIT 19</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND</p>	<p>ELECTRIC UNIT (CONTROL UNIT) 20</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R 20</p> <p>CAN COMMUNICATION 22</p> <p style="padding-left: 20px;">System Description 22</p> <p style="padding-left: 20px;">CAN Communication Unit 22</p> <p style="padding-left: 40px;">TYPE 1/ TYPE 3 23</p> <p style="padding-left: 40px;">TYPE 2/ TYPE 5 25</p> <p style="padding-left: 40px;">TYPE 4 27</p> <p style="padding-left: 40px;">TYPE 6/ TYPE 7 29</p> <p style="padding-left: 40px;">TYPE 8 31</p> <p style="padding-left: 40px;">TYPE 9/ TYPE 10 32</p> <p style="padding-left: 40px;">TYPE 11 34</p> <p style="padding-left: 40px;">TYPE 12/ TYPE 13 36</p> <p style="padding-left: 40px;">TYPE 14/ TYPE 15 38</p> <p>CAN SYSTEM (TYPE 1) 41</p> <p style="padding-left: 20px;">System Description 41</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 41</p> <p style="padding-left: 20px;">Schematic 42</p> <p style="padding-left: 20px;">Wiring Diagram — CAN — 43</p> <p style="padding-left: 20px;">CHECK SHEET 46</p> <p style="padding-left: 40px;">CHECK SHEET RESULTS (EXAMPLE) 48</p> <p style="padding-left: 20px;">Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit 55</p> <p style="padding-left: 20px;">ECM Circuit Inspection 56</p> <p style="padding-left: 20px;">Data Link Connector Circuit Inspection 57</p> <p style="padding-left: 20px;">BCM Circuit Inspection 57</p> <p style="padding-left: 20px;">Combination Meter Circuit Inspection 58</p> <p style="padding-left: 20px;">ABS Actuator and Electric Unit (Control Unit) Circuit Inspection 58</p> <p style="padding-left: 20px;">IPDM E/R Circuit Inspection 59</p> <p style="padding-left: 20px;">CAN Communication Circuit Inspection 60</p> <p style="padding-left: 20px;">IPDM E/R Ignition Relay Circuit Inspection 63</p> <p>CAN SYSTEM (TYPE 2) 64</p> <p style="padding-left: 20px;">System Description 64</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 64</p> <p style="padding-left: 20px;">Schematic 65</p> <p style="padding-left: 20px;">Wiring Diagram — CAN — 66</p> <p style="padding-left: 20px;">CHECK SHEET 69</p> <p style="padding-left: 40px;">CHECK SHEET RESULTS (EXAMPLE) 71</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

F
G
H
I
J
K



L
M

Inspection Between TCM and Data Link Connector Circuit	80	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	154
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	81	ECM Circuit Inspection	155
ECM Circuit Inspection	82	TCM Circuit Inspection	156
TCM Circuit Inspection	83	Data Link Connector Circuit Inspection	156
Data Link Connector Circuit Inspection	83	BCM Circuit Inspection	157
BCM Circuit Inspection	84	Combination Meter Circuit Inspection	157
Combination Meter Circuit Inspection	84	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	158
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	85	IPDM E/R Circuit Inspection	158
IPDM E/R Circuit Inspection	85	CAN Communication Circuit Inspection	159
CAN Communication Circuit Inspection	86	IPDM E/R Ignition Relay Circuit Inspection	163
IPDM E/R Ignition Relay Circuit Inspection	90	CAN SYSTEM (TYPE 6)	164
CAN SYSTEM (TYPE 3)	91	System Description	164
System Description	91	Component Parts and Harness Connector Location	164
Component Parts and Harness Connector Location	91	Schematic	165
Schematic	92	Wiring Diagram — CAN —	166
Wiring Diagram — CAN —	93	CHECK SHEET	169
CHECK SHEET	96	CHECK SHEET RESULTS (EXAMPLE)	171
CHECK SHEET RESULTS (EXAMPLE)	98	Inspection Between TCM and Data Link Connector Circuit	180
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	105	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	181
ECM Circuit Inspection	106	ECM Circuit Inspection	182
Data Link Connector Circuit Inspection	107	TCM Circuit Inspection	183
BCM Circuit Inspection	107	Data Link Connector Circuit Inspection	183
Combination Meter Circuit Inspection	108	BCM Circuit Inspection	184
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	108	Combination Meter Circuit Inspection	184
IPDM E/R Circuit Inspection	109	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	185
CAN Communication Circuit Inspection	110	IPDM E/R Circuit Inspection	185
IPDM E/R Ignition Relay Circuit Inspection	113	CAN Communication Circuit Inspection	186
CAN SYSTEM (TYPE 4)	114	IPDM E/R Ignition Relay Circuit Inspection	190
System Description	114	CAN SYSTEM (TYPE 7)	191
Component Parts and Harness Connector Location	114	System Description	191
Schematic	115	Component Parts and Harness Connector Location	191
Wiring Diagram — CAN —	116	Schematic	192
CHECK SHEET	119	Wiring Diagram — CAN —	193
CHECK SHEET RESULTS (EXAMPLE)	121	CHECK SHEET	196
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	128	CHECK SHEET RESULTS (EXAMPLE)	198
ECM Circuit Inspection	129	Inspection Between TCM and Data Link Connector Circuit	208
Data Link Connector Circuit Inspection	130	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	209
BCM Circuit Inspection	130	ECM Circuit Inspection	210
Combination Meter Circuit Inspection	131	TCM Circuit Inspection	211
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	131	Differential Lock Control Unit Circuit Inspection ...	211
IPDM E/R Circuit Inspection	132	Data Link Connector Circuit Inspection	212
CAN Communication Circuit Inspection	133	BCM Circuit Inspection	212
IPDM E/R Ignition Relay Circuit Inspection	136	Combination Meter Circuit Inspection	213
CAN SYSTEM (TYPE 5)	137	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	213
System Description	137	IPDM E/R Circuit Inspection	214
Component Parts and Harness Connector Location	137	CAN Communication Circuit Inspection	215
Schematic	138	IPDM E/R Ignition Relay Circuit Inspection	219
Wiring Diagram — CAN —	139	CAN SYSTEM (TYPE 8)	220
CHECK SHEET	142	System Description	220
CHECK SHEET RESULTS (EXAMPLE)	144	Component Parts and Harness Connector Location	220
Inspection Between TCM and Data Link Connector Circuit	153	Schematic	221

Wiring Diagram — CAN —	222	CHECK SHEET	299	
CHECK SHEET	225	CHECK SHEET RESULTS (EXAMPLE)	301	A
CHECK SHEET RESULTS (EXAMPLE)	227	Inspection Between TCM and Data Link Connector		
Inspection Between Data Link Connector and ABS		Circuit	311	
Actuator and Electric Unit (Control Unit) Circuit ..	235	Inspection Between Data Link Connector and ABS		B
ECM Circuit Inspection	236	Actuator and Electric Unit (Control Unit) Circuit ..	312	
Data Link Connector Circuit Inspection	237	ECM Circuit Inspection	313	
BCM Circuit Inspection	237	TCM Circuit Inspection	314	C
Combination Meter Circuit Inspection	238	Data Link Connector Circuit Inspection	314	
Transfer Control Unit Circuit Inspection	238	BCM Circuit Inspection	315	
ABS Actuator and Electric Unit (Control Unit) Circuit		Combination Meter Circuit Inspection	315	
Inspection	239	Transfer Control Unit Circuit Inspection	316	D
IPDM E/R Circuit Inspection	239	ABS Actuator and Electric Unit (Control Unit) Circuit		
CAN Communication Circuit Inspection	240	Inspection	316	
IPDM E/R Ignition Relay Circuit Inspection	243	IPDM E/R Circuit Inspection	317	E
CAN SYSTEM (TYPE 9)	244	CAN Communication Circuit Inspection	318	
System Description	244	IPDM E/R Ignition Relay Circuit Inspection	322	
Component Parts and Harness Connector Location	244	CAN SYSTEM (TYPE 12)	323	F
Schematic	245	System Description	323	
Wiring Diagram — CAN —	246	Component Parts and Harness Connector Location	323	
CHECK SHEET	249	Schematic	324	
CHECK SHEET RESULTS (EXAMPLE)	251	Wiring Diagram — CAN —	325	G
Inspection Between Data Link Connector and ABS		CHECK SHEET	328	
Actuator and Electric Unit (Control Unit) Circuit ..	259	CHECK SHEET RESULTS (EXAMPLE)	330	
ECM Circuit Inspection	260	Inspection Between TCM and Data Link Connector		H
Data Link Connector Circuit Inspection	261	Circuit	340	
BCM Circuit Inspection	261	Inspection Between Data Link Connector and ABS		
Combination Meter Circuit Inspection	262	Actuator and Electric Unit (Control Unit) Circuit ..	341	I
Transfer Control Unit Circuit Inspection	262	ECM Circuit Inspection	342	
ABS Actuator and Electric Unit (Control Unit) Circuit		TCM Circuit Inspection	343	
Inspection	263	Data Link Connector Circuit Inspection	343	J
IPDM E/R Circuit Inspection	263	BCM Circuit Inspection	344	
CAN Communication Circuit Inspection	264	Combination Meter Circuit Inspection	344	
IPDM E/R Ignition Relay Circuit Inspection	267	Transfer Control Unit Circuit Inspection	345	
CAN SYSTEM (TYPE 10)	268	ABS Actuator and Electric Unit (Control Unit) Circuit		LAN
System Description	268	Inspection	345	
Component Parts and Harness Connector Location	268	IPDM E/R Circuit Inspection	346	
Schematic	269	CAN Communication Circuit Inspection	347	L
Wiring Diagram — CAN —	270	IPDM E/R Ignition Relay Circuit Inspection	351	
CHECK SHEET	273	CAN SYSTEM (TYPE 13)	352	
CHECK SHEET RESULTS (EXAMPLE)	275	System Description	352	M
Inspection Between Data Link Connector and ABS		Component Parts and Harness Connector Location	352	
Actuator and Electric Unit (Control Unit) Circuit ..	284	Schematic	353	
ECM Circuit Inspection	285	Wiring Diagram — CAN —	354	
Differential Lock Control Unit Circuit Inspection ..	286	CHECK SHEET	357	
Data Link Connector Circuit Inspection	286	CHECK SHEET RESULTS (EXAMPLE)	359	
BCM Circuit Inspection	287	Inspection Between TCM and Data Link Connector		
Combination Meter Circuit Inspection	287	Circuit	370	
Transfer Control Unit Circuit Inspection	288	Inspection Between Data Link Connector and ABS		
ABS Actuator and Electric Unit (Control Unit) Circuit		Actuator and Electric Unit (Control Unit) Circuit ..	371	
Inspection	288	ECM Circuit Inspection	372	
IPDM E/R Circuit Inspection	289	TCM Circuit Inspection	373	
CAN Communication Circuit Inspection	290	Differential Lock Control Unit Circuit Inspection ..	373	
IPDM E/R Ignition Relay Circuit Inspection	293	Data Link Connector Circuit Inspection	374	
CAN SYSTEM (TYPE 11)	294	BCM Circuit Inspection	374	
System Description	294	Combination Meter Circuit Inspection	375	
Component Parts and Harness Connector Location	294	Transfer Control Unit Circuit Inspection	375	
Schematic	295	ABS Actuator and Electric Unit (Control Unit) Circuit		
Wiring Diagram — CAN —	296	Inspection	376	

IPDM E/R Circuit Inspection	376	CAN SYSTEM (TYPE 15)	412
CAN Communication Circuit Inspection	377	System Description	412
IPDM E/R Ignition Relay Circuit Inspection	381	Component Parts and Harness Connector Location	412
CAN SYSTEM (TYPE 14)	382	Schematic	413
System Description	382	Wiring Diagram — CAN —	414
Component Parts and Harness Connector Location	382	CHECK SHEET	417
Schematic	383	CHECK SHEET RESULTS (EXAMPLE)	419
Wiring Diagram — CAN —	384	Inspection Between TCM and Data Link Connector	
CHECK SHEET	387	Circuit	431
CHECK SHEET RESULTS (EXAMPLE)	389	Inspection Between Data Link Connector and ABS	
Inspection Between TCM and Data Link Connector		Actuator and Electric Unit (Control Unit) Circuit ...	432
Circuit	400	ECM Circuit Inspection	433
Inspection Between Data Link Connector and ABS		TCM Circuit Inspection	434
Actuator and Electric Unit (Control Unit) Circuit ...	401	Differential Lock Control Unit Circuit Inspection ...	434
ECM Circuit Inspection	402	Steering Angle Sensor Circuit Inspection	435
TCM Circuit Inspection	403	Data Link Connector Circuit Inspection	435
Steering Angle Sensor Circuit Inspection	403	BCM Circuit Inspection	436
Data Link Connector Circuit Inspection	404	Combination Meter Circuit Inspection	436
BCM Circuit Inspection	404	Transfer Control Unit Circuit Inspection	437
Combination Meter Circuit Inspection	405	ABS Actuator and Electric Unit (Control Unit) Circuit	
Transfer Control Unit Circuit Inspection	405	Inspection	437
ABS Actuator and Electric Unit (Control Unit) Circuit		IPDM E/R Circuit Inspection	438
Inspection	406	CAN Communication Circuit Inspection	439
IPDM E/R Circuit Inspection	406	IPDM E/R Ignition Relay Circuit Inspection	443
CAN Communication Circuit Inspection	407		
IPDM E/R Ignition Relay Circuit Inspection	411		

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS003L0

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS003L1

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM

UKS003L2


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M


LAN

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



TROUBLE DIAGNOSES WORK FLOW

PFP:00004

When Displaying CAN Communication System Errors

UKS003L4

WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.


WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts : When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage : If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSIS FLOW CHART



PKIB6519E

- Step 1 : Refer to [LAN-9, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2 : Refer to [LAN-10, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3 : Refer to [LAN-11, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4 : Refer to [LAN-12, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5 : Check and repair according to system diagnosis.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003L5

Diagnosis Procedure

SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Truck/4WD/VQ40DE/AT/VDC/Without electronic locking rear differential

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Truck														
Axle	2WD							4WD							
Engine	QR25DE				VQ40DE										
Transmission	M/T	A/T	M/T		A/T		M/T		A/T				VDC		
Brake control	ABS		ABS	ABLS	VDC										
Electronic locking rear differential							x			x			x		x
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CAN system trouble diagnosis	XX: XX														

Check basic specification of the vehicle.

Select "x" if it is model with electronic locking rear differential.

Which number is selected when sequentially selecting from the top of the specification table?
The number is "CAN system type" of the applicable vehicle.

In the case of this example:
It corresponds to type 14.

x : Applicable

PKIB6530E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.



HOW TO USE CHECK SHEET TABLE

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7197E

1. Unit names displayed on CONSULT-II.
2. “No indication” : Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)
“—” : Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. “NG” : Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.
“—” : Column not used (Initial diagnosis is not performed.)
4. “UNKWN” : Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (Transmit diagnosis is not performed.)
5. “UNKWN” : Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (It is not necessary for CAN communication trouble diagnosis.)

NOTE:

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-12, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced. Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Reproduced

The diagram illustrates the process of filling a check sheet based on diagnostic information. It consists of several key components:

- CAN DIAG SUPPORT MNTR (Left):** A diagnostic screen showing 'ENGINE' status. 'UNKWN' is displayed for 'ICC', 'BCM/SEC', and 'EPS'. 'BCM/SEC' is highlighted with a dashed box.
- CAN DIAG SUPPORT MNTR (Right):** A diagnostic screen showing 'ENGINE' status. 'UNKWN' is displayed for 'METER/M&A', 'BCM/SEC', and 'EPS'.
- Check sheet table:** A table with columns for 'SELECT SYSTEM screen', 'Initial diagnosis', 'Transmit diagnosis', 'Receive diagnosis' (ECM, TCM, STRG, BCM/SEC, METER/M&A, AWD/4WD/e4WD, VDC/TCS/ABS, IPDM E/R), and 'SELF-DIAG RESULTS'. The 'BCM' row has 'No indication' in the 'SELECT SYSTEM screen' column and 'UNKWN' in the 'BCM/SEC' column of 'Receive diagnosis'. The 'BCM' row is highlighted with a dashed box.
- SELECT SYSTEM (Left):** A list of system names: ENGINE, A/T, ABS, AIR BAG, IPDM E/R, METER. 'BCM' is not present in this list.
- SELECT SYSTEM (Right):** A list of system names: A/T, ABS, AIR BAG, IPDM E/R, METER, ALL MODE AWD/4WD.

PKIB7198E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

NOTE:

Put a check mark to "No indication" of BCM because BCM is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

NOTE:

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "ICC", "BCM/SEC" and "EPS". But put a check mark to "BCM/SEC" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]



- Confirm the unit name that “UNKWN” is displayed on the copy of “CAN DIAG SUPPORT MNTR” screen of “A/T”, “ALL MODE AWD/4WD”, “ABS” and “IPDM E/R” as well as “ENGINE”. And then, put a check mark to the check sheet table.

NOTE:

- For “A/T”, “UNKWN” is displayed on “ICC/e4WD”. But, do not put a check mark to their columns of reception diagnosis of the check sheet table because “UNKWN” is not listed.
- For “ALL MODE AWD/4WD”, “UNKWN” is not displayed. Do not put a check mark to it.
- For “ABS”, “UNKWN” is displayed on “ICC”. But, do not put a check mark to their columns of reception diagnosis of the check sheet table because “UNKWN” is not listed.
- For “IPDM E/R”, “UNKWN” is displayed on “BCM/SEC”. Put a check mark to it.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table


SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 7
Check BCM circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—



PKIB7200E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "—". Then, ignore check marks on the check sheet table.

4. Perform system diagnosis for possible causes identified.
5. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-22, "CAN Communication Unit"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SYSTEM ENGINE

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1001] 1t

SYSTEM A/T

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM BCM

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM METER

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1000] 2

SYSTEM ALL MODE AWD/4WD

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM ABS

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM IPDM E/R

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1000] PAST

PKIB7201E

- See “SELF-DIAG RESULTS” of all units attached to the check sheet. If “CAN COMM CIRCUIT”, “CAN COMM CIRCUIT [U1000]” or “CAN COMM CIRCUIT [U1001]” is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

NOTE:

- For “ENGINE”, “CAN COMM CIRCUIT [U1001]” are displayed. Put a check mark to it.
- For “A/T”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “BCM”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “METER”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “ALL MODE AWD/4WD”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “ABS”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “IPDM E/R”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			ECM	TCM	STRG	BCM /SEC	METER /M/A	METER /V/A	VOIC/CS /ABS	IPDM /E/R	IPDM /E/R	IPDM /E/R			
ENGINE	--	NG	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	--	--	--	--	--	--	--	--	--	--	--	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD4WD	--	NG	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--



When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 7
Check BCM circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			ECM	TCM	STRG	BCM /SEC	METER /M/A	METER /V/A	VOIC/CS /ABS	IPDM /E/R	IPDM /E/R	IPDM /E/R			
ENGINE	--	NG	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	--	--	--	--	--	--	--	--	--	--	--	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD4WD	--	NG	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--

Case 11
Check IPDM E/R circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			ECM	TCM	STRG	BCM /SEC	METER /M/A	METER /V/A	VOIC/CS /ABS	IPDM /E/R	IPDM /E/R	IPDM /E/R			
ENGINE	--	NG	UNKWN	--	UNKWN	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	--	NG	UNKWN	UNKWN	--	--	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	--
BCM	No indication	NG	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
METER	No indication	--	--	--	--	--	--	--	--	--	--	--	--	CAN COMM CIRCUIT [U1000]	--
ALL MODE AWD4WD	--	NG	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--
ABS	--	NG	UNKWN	UNKWN	UNKWN	UNKWN	--	--	UNKWN	--	UNKWN	--	--	CAN COMM CIRCUIT [U1000]	--
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	UNKWN	--	UNKWN	--	CAN COMM CIRCUIT [U1000]	--



PKIB7202E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "--". Then, ignore check marks on the check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003L6

CAN Diagnostic Support Monitor

DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR	CAN DIAG SUPPORT MNTR																																																			
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: center;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TCM</td><td style="text-align: center;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td>ICC</td><td style="text-align: center;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: center;">UNKWN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Down</td></tr> <tr><td>MODE</td><td>BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE	BACK LIGHT COPY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: center;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TCM</td><td style="text-align: center;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td>ICC</td><td style="text-align: center;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: center;">UNKWN</td></tr> <tr><td>EPS</td><td style="text-align: center;">UNKWN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Up</td></tr> <tr><td>MODE</td><td>BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	EPS	UNKWN	PRINT	Scroll Up	MODE
ENGINE																																																					
	PRSNT																																																				
INITIAL DIAG	OK																																																				
TRANSMIT DIAG	OK																																																				
TCM	OK																																																				
VDC/TCS/ABS	OK																																																				
METER/M&A	OK																																																				
ICC	UNKWN																																																				
BCM/SEC	OK																																																				
IPDM E/R	OK																																																				
AWD/4WD/e4WD	UNKWN																																																				
PRINT	Scroll Down																																																				
MODE	BACK LIGHT COPY																																																				
ENGINE																																																					
	PRSNT																																																				
TRANSMIT DIAG	OK																																																				
TCM	OK																																																				
VDC/TCS/ABS	OK																																																				
METER/M&A	OK																																																				
ICC	UNKWN																																																				
BCM/SEC	OK																																																				
IPDM E/R	OK																																																				
AWD/4WD/e4WD	UNKWN																																																				
EPS	UNKWN																																																				
PRINT	Scroll Up																																																				
MODE	BACK LIGHT COPY																																																				
		SKIB0591E																																																			

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN
EPS	EPS is not diagnosed.	UNKWN	

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example) CAN DIAG SUPPORT MNTR

A/T	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC/e4WD	UNKW
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKW
	ECM	Make sure of normal reception from ECM.	OK/UNKW
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKW
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKW
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKW
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKW

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKW : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT

(Example) CAN DIAG SUPPORT MNTR

DIFF LOCK	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

PKIB7196E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
DIFF LOCK	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKW
	ECM	Make sure of normal reception from ECM.	OK/UNKW
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKW
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKW

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKW : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
IPDM E/R	OK		
METER/M&A	UNKWN		
I-KEY	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0593E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	I-KEY	I-KEY is not diagnosed.	OK

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TRANSFER CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
VDC/TCS/ABS	OK		
TCM	UNKWN		
METER/M&A	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB5232E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/ 4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

(Example) CAN DIAG SUPPORT MNTR

ABS			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
METER/M&A	UNKWN		
STRG	OK		
ICC	UNKWN		
AWD/4WD	OK		
DIFF LOCK	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB7433E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	METER/M&A is not diagnosed.	UNKWN
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN
	DIFF LOCK	Make sure of normal reception from differential lock control unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example) CAN DIAG SUPPORT MNTR

IPDM E/R			
		PRSNT	PAST
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/–	OK/0/1~39/–
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/–	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/–	

Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- – : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- - : Undiagnosed

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN COMMUNICATION

PFP:23710

System Description

UKS0030X

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

UKS003GN

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Truck														
Axle	2WD							4WD							
Engine	QR25DE				VQ40DE										
Transmission	M/T	A/T	M/T		A/T		M/T		A/T						
Brake control	ABS		ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	ABS	ABLS	VDC		
Electronic locking rear differential							×			×			×		×
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CAN system trouble diagnosis	LAN-41	LAN-64	LAN-91	LAN-114	LAN-137	LAN-164	LAN-191	LAN-220	LAN-244	LAN-268	LAN-294	LAN-323	LAN-352	LAN-382	LAN-412

×: Applicable


NOTE:

Confirming the presence of the following items helps to identify CAN system type.


- Models with 4WD




- Models with VDC



- Models with ABLs




- Models with electronic locking rear differential



TYPE 1/ TYPE 3 System diagram

- Type 1




A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN COMMUNICATION

[CAN]

● Type 3



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R		
Engine status signal	T	R			
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				
A/C switch signal	R	T			
A/C compressor request signal	T				R
Blower fan motor switch signal	R	T			
Cooling fan speed request signal*	T				R
Low beam request signal		T			R
Low beam status signal	R				T
High beam request signal		T	R		R
High beam status signal	R				T
Position light request signal		T			R
Front fog light request signal		T	R		R
Day time running light request signal		T			R
Sleep wake up signal		T	R		R
Door switch signal		T	R		R
Seat belt buckle switch signal		R	T		
Ignition switch signal		T			R
Theft warning horn request signal		T			R
Horn chirp signal		T			R
Front wiper request signal		T			R
Front wiper stop position signal		R			T
Rear window defogger switch signal		T			R
Rear window defogger control signal*	R				T
Buzzer output signal		T	R		
Fuel consumption monitor signal	T		R		

CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Fuel level sensor signal	R		T		
Turn indicator signal		T	R		
Brake warning lamp signal			R	T	
ABS warning lamp signal			R	T	
Malfunction indicator lamp signal	T		R		
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Stop lamp switch signal		R	T		
Vehicle speed signal	R		R	T	
	R	R	T		
Power generation command value signal	T				R


*: VQ engine models only.

TYPE 2/ TYPE 5 System diagram

- Type 2



- Type 5



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R		
Engine status signal	T		R			
Engine coolant temperature signal	T			R		
Accelerator pedal position signal	T	R				
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Battery voltage signal	T	R				
A/T self-diagnosis signal	R	T				
Turbine revolution signal	R	T				
Output shaft revolution signal	R	T				
A/C switch signal	R		T			
A/C compressor request signal	T	R				R
Blower fan motor switch signal	R		T			
Cooling fan speed request signal	T					R
Low beam request signal			T			R
Low beam status signal	R					T
High beam request signal			T	R		R
High beam status signal	R					T
Position light request signal			T			R
Front fog light request signal			T	R		R
Day time running light request signal			T			R
Sleep wake up signal			T	R		R
Door switch signal			T	R		R
Seat belt buckle switch signal			R	T		
Ignition switch signal			T			R
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Front wiper request signal			T			R
Front wiper stop position signal			R			T
Rear window defogger switch signal			T			R
Rear window defogger control signal*	R					T
Buzzer output signal			T	R		
Fuel consumption monitor signal	T			R		
Fuel level sensor signal	R			T		
Turn indicator signal			T	R		
Brake warning lamp signal				R	T	
ABS warning lamp signal				R	T	
Malfunction indicator lamp signal	T			R		
ASCD CRUISE lamp signal	T			R		
ASCD SET lamp signal	T			R		
ASCD operation signal	T	R				

CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
ASCD OD cancel request	T	R				
A/T fluid temperature sensor signal	R	T		R		
A/T position indicator lamp signal	R	T		R		
O/D OFF indicator signal		T		R		
Overdrive control switch signal		R		T		
1st position switch signal		R		T		
Stop lamp switch signal		R	R	T		
Vehicle speed signal	R			R	T	
	R	R	R	T		
Power generation command value signal	T					R

*: VQ engine models only.

TYPE 4

System diagram

- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R	R	
Engine status signal	T	R			
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T			R	
A/C switch signal	R	T			
A/C compressor request signal	T				R
Blower fan motor switch signal	R	T			
Cooling fan speed request signal	T				R
Low beam request signal		T			R
Low beam status signal	R				T

CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
High beam request signal		T	R		R
High beam status signal	R				T
Position light request signal		T			R
Front fog light request signal		T	R		R
Day time running light request signal		T			R
Sleep wake up signal		T	R		R
Door switch signal		T	R		R
Seat belt buckle switch signal		R	T		
Ignition switch signal		T			R
Theft warning horn request signal		T			R
Horn chirp signal		T			R
Front wiper request signal		T			R
Front wiper stop position signal		R			T
Rear window defogger switch signal		T			R
Rear window defogger control signal	R				T
Buzzer output signal		T	R		
Fuel consumption monitor signal	T		R		
Fuel level sensor signal	R		T		
Turn indicator signal		T	R		
Brake warning lamp signal			R	T	
ABS warning lamp signal			R	T	
SLIP indicator lamp signal			R	T	
Malfunction indicator lamp signal	T		R		
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Stop lamp switch signal		R	T		
Vehicle speed signal	R		R	T	
	R	R	T		
Power generation command value signal	T				R


TYPE 6/ TYPE 7

System diagram

- Type 6



- Type 7



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R			R	R	
Engine status signal	T			R			
Engine coolant temperature signal	T				R		
Accelerator pedal position signal	T	R				R	
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
A/T self-diagnosis signal	R	T					
Turbine revolution signal	R	T					

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Output shaft revolution signal	R	T					
A/C switch signal	R			T			
A/C compressor request signal	T	R					R
Blower fan motor switch signal	R			T			
Cooling fan speed request signal	T						R
Low beam request signal				T			R
Low beam status signal	R						T
High beam request signal				T	R		R
High beam status signal	R						T
Position light request signal				T			R
Front fog light request signal				T	R		R
Day time running light request signal				T			R
Sleep wake up signal				T	R		R
Door switch signal				T	R		R
Seat belt buckle switch signal				R	T		
Ignition switch signal				T			R
Theft warning horn request signal				T			R
Horn chirp signal				T			R
Front wiper request signal				T			R
Front wiper stop position signal				R			T
Rear window defogger switch signal				T			R
Rear window defogger control signal	R						T
Buzzer output signal				T	R		
Fuel consumption monitor signal	T				R		
Fuel level sensor signal	R				T		
Turn indicator signal				T	R		
Brake warning lamp signal					R	T	
ABS warning lamp signal					R	T	
SLIP indicator lamp signal					R	T	
Malfunction indicator lamp signal	T				R		
ASCD CRUISE lamp signal	T				R		
ASCD SET lamp signal	T				R		
ASCD operation signal	T	R					
ASCD OD cancel request	T	R					
A/T fluid temperature sensor signal	R	T			R		
A/T position indicator lamp signal	R	T			R	R	
P range signal		T				R	
O/D OFF indicator signal		T			R		
Overdrive control switch signal		R			T	R	
1st position switch signal		R			T		
Stop lamp switch signal		R		R	T		

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Differential lock control unit	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Vehicle speed signal	R				R	T	
	R	R		R	T		
Differential lock switch signal			T			R	
Differential lock indicator signal			T			R	
Power generation command value signal	T						R

TYPE 8

System diagram

- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R	R		
Engine status signal	T	R				
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
A/C switch signal	R	T				
A/C compressor request signal	T					R
Blower fan motor switch signal	R	T				
Cooling fan speed request signal	T					R
Low beam request signal		T				R
Low beam status signal	R					T
High beam request signal		T	R			R
High beam status signal	R					T
Position light request signal		T				R
Front fog light request signal		T	R			R

CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Day time running light request signal		T				R
Sleep wake up signal		T	R			R
Door switch signal		T	R			R
Seat belt buckle switch signal		R	T			
Ignition switch signal		T				R
Theft warning horn request signal		T				R
Horn chirp signal		T				R
Front wiper request signal		T				R
Front wiper stop position signal		R				T
Rear window defogger switch signal		T				R
Rear window defogger control signal	R					T
Buzzer output signal		T	R			
Fuel consumption monitor signal	T		R			
Fuel level sensor signal	R		T			
Turn indicator signal		T	R			
Brake warning lamp signal			R		T	
ABS warning lamp signal			R		T	
Malfunction indicator lamp signal	T		R			
ASCD CRUISE lamp signal	T		R			
ASCD SET lamp signal	T		R			
Stop lamp switch signal				R	T	
		R	T			
Vehicle speed signal	R		R		T	
	R	R	T	R		
Power generation command value signal	T					R

TYPE 9/ TYPE 10

System diagram


- Type 9



CAN COMMUNICATION

[CAN]

● Type 10



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Differential lock control unit	BCM	Combina-tion meter	Transfer control unit	ABS actua-tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T			R	R	R	
Engine status signal	T		R				
Engine coolant temperature signal	T			R			
Accelerator pedal position signal	T					R	
A/C switch signal	R		T				
A/C compressor request signal	T						R
Blower fan motor switch signal	R		T				
Cooling fan speed request signal	T						R
Low beam request signal			T				R
Low beam status signal	R						T
High beam request signal			T	R			R
High beam status signal	R						T
Position light request signal			T				R
Front fog light request signal			T	R			R
Day time running light request signal			T				R
Sleep wake up signal			T	R			R
Door switch signal			T	R			R
Seat belt buckle switch signal			R	T			
Ignition switch signal			T				R
Theft warning horn request signal			T				R
Horn chirp signal			T				R
Front wiper request signal			T				R
Front wiper stop position signal			R				T
Rear window defogger switch signal			T				R
Rear window defogger control signal	R						T
Buzzer output signal			T	R			

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	Differential lock control unit	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Fuel consumption monitor signal	T			R			
Fuel level sensor signal	R			T			
Turn indicator signal			T	R			
Brake warning lamp signal				R		T	
ABS warning lamp signal				R		T	
SLIP indicator lamp signal				R		T	
Malfunction indicator lamp signal	T			R			
ASCD CRUISE lamp signal	T			R			
ASCD SET lamp signal	T			R			
Stop lamp switch signal					R	T	
Vehicle speed signal	R			R		T	
	R		R	T	R		
Differential lock switch signal		T				R	
Differential lock indicator signal		T				R	
4WD shift switch signal	R	R			T	R	
Power generation command value signal	T						R

TYPE 11

System diagram

- Type 11



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R		
Engine status signal	T		R				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
Engine coolant temperature signal	T			R			
Accelerator pedal position signal	T	R					
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
A/T self-diagnosis signal	R	T					
Turbine revolution signal	R	T					
Output shaft revolution signal	R	T			R		
A/C switch signal	R		T				
A/C compressor request signal	T	R					R
Blower fan motor switch signal	R		T				
Cooling fan speed request signal	T						R
Low beam request signal			T				R
Low beam status signal	R						T
High beam request signal			T	R			R
High beam status signal	R						T
Position light request signal			T				R
Front fog light request signal			T	R			R
Day time running light request signal			T				R
Sleep wake up signal			T	R			R
Door switch signal			T	R			R
Seat belt buckle switch signal			R	T			
Ignition switch signal			T				R
Theft warning horn request signal			T				R
Horn chirp signal			T				R
Front wiper request signal			T				R
Front wiper stop position signal			R				T
Rear window defogger switch signal			T				R
Rear window defogger control signal	R						T
Buzzer output signal			T	R			
Fuel consumption monitor signal	T			R			
Fuel level sensor signal	R			T			
Turn indicator signal			T	R			
Brake warning lamp signal				R		T	
ABS warning lamp signal				R		T	
Malfunction indicator lamp signal	T			R			
ASCD CRUISE lamp signal	T			R			
ASCD SET lamp signal	T			R			
ASCD operation signal	T	R					
ASCD OD cancel request	T	R					
A/T fluid temperature sensor signal	R	T		R			
A/T position indicator lamp signal	R	T		R	R		

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
O/D OFF indicator signal		T		R			
Overdrive control switch signal		R		T			
1st position switch signal		R		T			
Stop lamp switch signal		R	R	T			
					R	T	
Vehicle speed signal	R			R		T	
	R	R	R	T	R		
Power generation command value signal	T						R


TYPE 12/ TYPE 13

System diagram

- Type 12



- Type 13



CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R			R	R	R	
Engine status signal	T			R				
Engine coolant temperature signal	T				R			
Accelerator pedal position signal	T	R					R	
Closed throttle position signal	T	R						
Wide open throttle position signal	T	R						
Battery voltage signal	T	R						
A/T self-diagnosis signal	R	T						
Turbine revolution signal	R	T						
Output shaft revolution signal	R	T				R		
A/C switch signal	R			T				
A/C compressor request signal	T	R						R
Blower fan motor switch signal	R			T				
Cooling fan speed request signal	T							R
Low beam request signal				T				R
Low beam status signal	R							T
High beam request signal				T	R			R
High beam status signal	R							T
Position light request signal				T				R
Front fog light request signal				T	R			R
Day time running light request signal				T				R
Sleep wake up signal				T	R			R
Door switch signal				T	R			R
Seat belt buckle switch signal				R	T			
Ignition switch signal				T				R
Theft warning horn request signal				T				R
Horn chirp signal				T				R
Front wiper request signal				T				R
Front wiper stop position signal				R				T
Rear window defogger switch signal				T				R
Rear window defogger control signal	R							T
Buzzer output signal				T	R			
Fuel consumption monitor signal	T				R			
Fuel level sensor signal	R				T			
Turn indicator signal				T	R			
Brake warning lamp signal					R		T	
ABS warning lamp signal					R		T	
SLIP indicator lamp signal					R		T	
Malfunction indicator lamp signal	T				R			

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Differential lock control unit	BCM	Combina-tion meter	Transfer control unit	ABS actuator and elec-tric unit (control unit)	IPDM E/R
ASCD CRUISE lamp signal	T				R			
ASCD SET lamp signal	T				R			
ASCD operation signal	T	R						
ASCD OD cancel request	T	R						
A/T fluid temperature sensor signal	R	T			R			
A/T position indicator lamp signal	R	T			R	R	R	
O/D OFF indicator signal		T			R			
Overdrive control switch signal		R			T		R	
1st position switch signal		R			T			
Stop lamp switch signal		R		R	T			
						R	T	
Vehicle speed signal	R				R		T	
	R	R		R	T	R		
Differential lock switch signal			T				R	
Differential lock indicator signal			T				R	
4WD shift switch signal	R	R	R			T	R	
Power generation command value signal	T							R

TYPE 14/ TYPE 15

System diagram


- Type 14



CAN COMMUNICATION

[CAN]

● Type 15



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R				R	R	R	
Engine status signal	T				R				
Engine coolant temperature signal	T					R			
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
A/T self-diagnosis signal	R	T							
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T					R		
A/C switch signal	R				T				
A/C compressor request signal	T	R							R
Blower fan motor switch signal	R				T				
Cooling fan speed request signal	T								R
Low beam request signal					T				R
Low beam status signal	R								T
High beam request signal					T	R			R
High beam status signal	R								T
Position light request signal					T				R
Front fog light request signal					T	R			R
Day time running light request signal					T				R
Sleep wake up signal					T	R			R
Door switch signal					T	R			R
Seat belt buckle switch signal					R	T			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Ignition switch signal					T				R
Theft warning horn request signal					T				R
Horn chirp signal					T				R
Front wiper request signal					T				R
Front wiper stop position signal					R				T
Rear window defogger switch signal					T				R
Rear window defogger control signal	R								T
Buzzer output signal					T	R			
Fuel consumption monitor signal	T					R			
Fuel level sensor signal	R					T			
Turn indicator signal					T	R			
Brake warning lamp signal						R		T	
ABS warning lamp signal						R		T	
VDC OFF indicator lamp signal						R		T	
SLIP indicator lamp signal						R		T	
HDC indicator lamp signal						R		T	
Malfunction indicator lamp signal	T					R			
ASCD CRUISE lamp signal	T					R			
ASCD SET lamp signal	T					R			
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
A/T fluid temperature sensor signal	R	T				R			
A/T position indicator lamp signal	R	T				R	R	R	
O/D OFF indicator signal		T				R			
Overdrive control switch signal		R				T		R	
1st position switch signal		R				T			
Stop lamp switch signal		R			R	T			
							R	T	
Vehicle speed signal	R					R		T	
	R	R			R	T	R		
Steering angle sensor signal				T			R	R	
Differential lock switch signal			T					R	
Differential lock indicator signal			T					R	
4WD shift switch signal	R	R	R				T		
Power generation command value signal	T								R

CAN SYSTEM (TYPE 1)

PF2:23710


System Description

UKS003R0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003RP



BKIA0157E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS003RQ



BKWA0479E


Wiring Diagram — CAN —

UKS003RR


LAN-CAN-01

▬ : DATA LINE

A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)





BKWA0480E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02

▬ : DATA LINE





BKWA0481E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-03

▬ : DATA LINE



LAN

BKWA0482E

CAN SYSTEM (TYPE 1)

[CAN]

UKS003RS

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6516E

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

PKIB6517E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-55, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7252E



CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-56, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7253E



PKIB7059E

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-57, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7254E




PKIB7060E

Case 4

Check BCM circuit. Refer to [LAN-57, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7255E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check combination meter circuit. Refer to [LAN-58, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7256E




Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-58, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7257E




Case 7

Check IPDM E/R circuit. Refer to [LAN-59, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7258E



Case 8

Check CAN communication circuit. Refer to [LAN-60, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW ✓	—	UNKW ✓	UNKW ✓	UNKW ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKW ✓	UNKW ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7259E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-63, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7260E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-63, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7261E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003RT

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003RU


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS003RV

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS003RW

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003RX

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003RY

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003RZ

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

UKS003S1

IPDM E/R Ignition Relay Circuit Inspection

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 2)

PF2:23710


System Description

UKS003R8

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003R9




CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS003RA



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0483E

CAN SYSTEM (TYPE 2)





[CAN]

Wiring Diagram — CAN —

UKS003RB

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0484E

CAN SYSTEM (TYPE 2)


[CAN]

LAN-CAN-05

— — — — : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0485E

▬ : DATA LINE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91)
W

37	38	39	40	41	42
43	44	45	46	47	48

(E122)
W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125)
B

CAN SYSTEM (TYPE 2)

[CAN]

UKS003RC

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6518E

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5017E

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-80, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7272E



PKIB7128E

CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-81, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7273E



PKIB7129E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-82, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUI T (U100)	CAN COMM CIRCUI T (U101)
A/T	—	NG	UNKW N	UNKW N	—	—	UNKW N	—	CAN COMM CIRCUI T (U100)	—
BCM	No indication	NG	UNKW N	UNKW N	—	—	UNKW N	UNKW N	CAN COMM CIRCUI T (U100)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUI T (U100)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	—	CAN COMM CIRCUI T (U100)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	UNKW N	—	—	CAN COMM CIRCUI T (U100)	—

PKIB7274E



CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-83, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7275E



PKIB7131E

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-83, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7276E



PKIB7132E

A
B
C
D
E
F
G
H
I
J
K
L
M


LAN

Case 6

Check BCM circuit. Refer to [LAN-84, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7277E




Case 7

Check combination meter circuit. Refer to [LAN-84, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7278E



PKIB7134E

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-85, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7279E




PKIB7135E

Case 9

Check IPDM E/R circuit. Refer to [LAN-85, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	UNKW	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7280E



Case 10

Check CAN communication circuit. Refer to [LAN-86, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	✓	—	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	✓	—	—	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7281E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-90, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7282E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-90, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7283E

Inspection Between TCM and Data Link Connector Circuit

UKS003RD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003RE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003RF


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003RG

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003RH

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS003RI

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003RJ

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003RK

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003RL

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003RM

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



A
B
C
D
E
F
G
H
I
J
L
M

LAN

6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

- Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003RN

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 3)

PF2:23710


System Description

UKS003QT

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003QU



BKIA0157E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS003QV



BKWA0479E

CAN SYSTEM (TYPE 3)

[CAN]


Wiring Diagram — CAN —

UKS003QW


LAN-CAN-07

▬ : DATA LINE

A
B
C
D
E
F
G
H
I
J
L
M



LAN







REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0487E

LAN-CAN-08

— : DATA LINE




BKWA0488E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-09

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M

LAN

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91)
W

37	38	39	40	41	42
43	44	45	46	47	48

(E122)
W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	
47	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	32
	46	45	44	43	42	41	40	39	38	37	36	35	34	33		

(E125)
B

BKWA0489E

CAN SYSTEM (TYPE 3)

[CAN]

UKS003R7

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6516E

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6517E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-105, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW	UNKW	—	UNKW	UNKW ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW ✓	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7252E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-106, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7253E



PKIB7059E

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-107, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7254E




PKIB7060E

Case 4

Check BCM circuit. Refer to [LAN-107, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7255E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check combination meter circuit. Refer to [LAN-108, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7256E




PKIB7062E

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-108, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7257E




Case 7

Check IPDM E/R circuit. Refer to [LAN-109, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7258E



Case 8

Check CAN communication circuit. Refer to [LAN-110, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7259E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-113, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7260E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-113, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7261E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003QY

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003QZ


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS003R0

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS003R1

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003R2

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003R3

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003R4

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 4)


System Description

UKS003QF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003QG




CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS003QH





A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0479E

Wiring Diagram — CAN —

LAN-CAN-10

▬ : DATA LINE






REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-11


▬ : DATA LINE



BKWA0491E

LAN-CAN-12

▬ : DATA LINE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91) W

37	38	39	40	41	42
43	44	45	46	47	48

(E122) W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	32
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	B

(E125) B

CAN SYSTEM (TYPE 4)

[CAN]

UKS003QJ

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table										
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6520E

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6517E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-128, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7262E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-129, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7263E



CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-130, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7264E



CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check BCM circuit. Refer to [LAN-130, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7265E



CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-131, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7266E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-131, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7267E



PKIB7126E

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check IPDM E/R circuit. Refer to [LAN-132, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7268E



Case 8

Check CAN communication circuit. Refer to [LAN-133, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW N	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7269E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-136, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7270E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-136, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7271E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003QK

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003QL

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS003QM

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS003QM

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003QO

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003QP

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003QQ

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003QS

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 5)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

UKS003PY



BKWA0483E

CAN SYSTEM (TYPE 5)



[CAN]

Wiring Diagram — CAN —

UKS003PZ

LAN-CAN-13

▬ : DATA LINE




REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0493E

CAN SYSTEM (TYPE 5)

[CAN]

LAN-CAN-14



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M18)
W



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M24)
W


BKWA0494E

CAN SYSTEM (TYPE 5)


[CAN]

LAN-CAN-15

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0495E

CAN SYSTEM (TYPE 5)

[CAN]

UKS003QE

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :


Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6518E

CAN SYSTEM (TYPE 5)

[CAN]



A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB5017E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-153, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7272E



PKIB7128E

CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-154, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7273E



CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-155, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB7274E




PKIB7130E

Case 4

Check TCM circuit. Refer to [LAN-156, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7275E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-156, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7276E




PKIB7132E

Case 6

Check BCM circuit. Refer to [LAN-157, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB727E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 7

Check combination meter circuit. Refer to [LAN-157, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7278E




Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-158, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7279E



CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-158, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7280E



Case 10

Check CAN communication circuit. Refer to [LAN-159, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	✓	—	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	✓	—	—	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7281E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-163, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7282E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-163, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7283E

Inspection Between TCM and Data Link Connector Circuit

UKS003Q1

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003Q2

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003Q3

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003Q4

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003Q5

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS003Q6

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003Q7

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003Q8

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003Q9

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003QA

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.


**8. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003QB

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 6)

PFP:23710


System Description

UKS003PG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003PH




BKIA0158E

CAN SYSTEM (TYPE 6)

[CAN]

Schematic

UKS003PI



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0483E

CAN SYSTEM (TYPE 6)



[CAN]

UKS003PJ

Wiring Diagram — CAN —

LAN-CAN-16

— : DATA LINE



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0497E

CAN SYSTEM (TYPE 6)

[CAN]

LAN-CAN-17

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M18)
W



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1



(M22)
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M24)
W

BKWA0498E

▬ : DATA LINE



CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5017E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-180, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7284E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-181, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7285E




Case 3

Check ECM circuit. Refer to [LAN-182, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (J100) ✓	CAN COMM CIRCUIT (J101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (J100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (J1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (J100) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (J100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (J100) ✓	—

PKIB7286E



CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-183, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7287E



CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-183, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7288E



CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-184, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7289E




Case 7

Check combination meter circuit. Refer to [LAN-184, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	✓ indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7290E



CAN SYSTEM (TYPE 6)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-185, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7291E




Case 9

Check IPDM E/R circuit. Refer to [LAN-185, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7292E



Case 10

Check CAN communication circuit. Refer to [LAN-186, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7293E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7294E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7295E

Inspection Between TCM and Data Link Connector Circuit

UKS003PL

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003PM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003PN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003PO

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003PP

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .
- NG >> Repair harness between data link connector and BCM.



SKIA6868E

UKS003PQ

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
- NG >> Repair harness between BCM and data link connector.



SKIA6869E

UKS003PR

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003PS

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003PT

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003PU

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003PV

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 7)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location




CAN SYSTEM (TYPE 7)

[CAN]

Schematic

UKS003P2



BKWA0496E

CAN SYSTEM (TYPE 7)


[CAN]

Wiring Diagram — CAN —

UKS003P3

LAN-CAN-19


▬ : DATA LINE



NEXT PAGE

A
B
C
D
E
F
G
H
I
J
L
M

LAN



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)






BKWA0500E

CAN SYSTEM (TYPE 7)

[CAN]

LAN-CAN-20

— : DATA LINE





BKWA0501E

CAN SYSTEM (TYPE 7)

[CAN]

LAN-CAN-21

▬ : DATA LINE



BKWA0502E

CAN SYSTEM (TYPE 7)

[CAN]

UKS003P4

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table													
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6522E

CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of METER SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6523E

CAN SYSTEM (TYPE 7)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-208, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7296E



PKIB7137E

CAN SYSTEM (TYPE 7)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-209, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7297E



PKIB7138E

CAN SYSTEM (TYPE 7)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-210, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB7298E



CAN SYSTEM (TYPE 7)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-211, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
AT	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7299E



CAN SYSTEM (TYPE 7)


[CAN]

Case 5

Check differential lock control unit circuit. Refer to [LAN-211, "Differential Lock Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7300E



CAN SYSTEM (TYPE 7)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-212, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7301E



PKIB7142E

CAN SYSTEM (TYPE 7)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-212, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7302E



CAN SYSTEM (TYPE 7)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-213, "Combination Meter Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	✓ No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7303E



CAN SYSTEM (TYPE 7)


[CAN]

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-213, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7304E



CAN SYSTEM (TYPE 7)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-214, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7305E



PKIB7146E

Case 11

Check CAN communication circuit. Refer to [LAN-215, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7306E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-219, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7307E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-219, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7308E

Inspection Between TCM and Data Link Connector Circuit

UKS003P5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003P6

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).

11 (L) – 11 (L) : Continuity should exist.
10 (P) – 15 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



ECM Circuit Inspection

UKS003P7

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003P8

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003QC

Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



UKS003P9

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



UKS003PA

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003PB

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003PC

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - Differential lock control unit
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.**86 (P) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



SKIB0571E


4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Differential lock control unit connector
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Differential lock control unit
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003PF

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

LAN

CAN SYSTEM (TYPE 8)

PF2:23710


System Description

UKS0030K

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0030L




CAN SYSTEM (TYPE 8)

[CAN]

Schematic

UKS0030M



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0503E

Wiring Diagram — CAN —

LAN-CAN-22

▬ : DATA LINE





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

CAN SYSTEM (TYPE 8)

[CAN]



LAN-CAN-23



BKWA0505E

LAN-CAN-24

▬ : DATA LINE



BKWA0506E

CAN SYSTEM (TYPE 8)

[CAN]

UKS0030Z

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table											
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6524E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6525E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-235, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7309E




Case 2

Check ECM circuit. Refer to [LAN-236, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7310E




Case 3

Check data link connector circuit. Refer to [LAN-237, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7311E




Case 4

Check BCM circuit. Refer to [LAN-237, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7312E




Case 5

Check combination meter circuit. Refer to [LAN-238, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7313E



CAN SYSTEM (TYPE 8)


[CAN]

Case 6

Check transfer control unit circuit. Refer to [LAN-238, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7314E



CAN SYSTEM (TYPE 8)


[CAN]

Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-239, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7315E




Case 8

Check IPDM E/R circuit. Refer to [LAN-239, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7316E



Case 9

Check CAN communication circuit. Refer to [LAN-240, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7317E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-243, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7318E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-243, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7319E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS0030P

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS00300


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS0030T

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS0030U

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS0030V

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS0030X

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS0030Y

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

LAN

CAN SYSTEM (TYPE 9)

PF2:23710


System Description

UKS00305

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS00306




CAN SYSTEM (TYPE 9)

[CAN]

Schematic

UKS00307



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0503E

Wiring Diagram — CAN —


LAN-CAN-25

▬ : DATA LINE




REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)





A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0508E

▬ : DATA LINE



CAN SYSTEM (TYPE 9)

[CAN]

UKS00309

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6526E

CAN SYSTEM (TYPE 9)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6525E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on “NG” on “INITIAL DIAG (Initial diagnosis)”, replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-259, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7320E




Case 2

Check ECM circuit. Refer to [LAN-260, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7321E



CAN SYSTEM (TYPE 9)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-261, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7322E




Case 4

Check BCM circuit. Refer to [LAN-261, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN KN [✓] WN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No ✓ indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UN KN [✓] WN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7323E




Case 5

Check combination meter circuit. Refer to [LAN-262, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7324E



CAN SYSTEM (TYPE 9)


[CAN]

Case 6

Check transfer control unit circuit. Refer to [LAN-262, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7325E



CAN SYSTEM (TYPE 9)


[CAN]

Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-263, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7326E




Case 8

Check IPDM E/R circuit. Refer to [LAN-263, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7327E



Case 9

Check CAN communication circuit. Refer to [LAN-264, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7328E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-267, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7329E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-267, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7330E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS0030A

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

UKS0030B

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS0030C

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS0030D

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS0030E

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS0030F

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS0030G

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS0030H

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS00301

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF. A
2. Disconnect the battery cable from the negative terminal. B
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.) C
6. Make sure that the same symptom is reproduced. D
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R F

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit. G

IPDM E/R Ignition Relay Circuit Inspection

UKS0030J

Check the following. If no malfunction is found, replace the IPDM E/R. H

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#). I

J

LAN

L

M

CAN SYSTEM (TYPE 10)


System Description

UKS003NP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003NQ




BKIA0161E

CAN SYSTEM (TYPE 10)

[CAN]

Schematic

UKS003NR



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0510E

Wiring Diagram — CAN —

LAN-CAN-28

▬ : DATA LINE



REFER TO THE FOLLOWING.






(M31) - SUPER MULTIPLE JUNCTION (SMJ)

CAN SYSTEM (TYPE 10)

[CAN]



LAN-CAN-29

— : DATA LINE



BKWA0592E

▬ : DATA LINE



CAN SYSTEM (TYPE 10)

[CAN]

UKS003NT

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 10)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
DIFF LOCK
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
DIFF LOCK
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6528E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-284, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7331E




Case 2

Check ECM circuit. Refer to [LAN-285, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	✓	—	—	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	✓	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7332E




Case 3

Check differential lock control unit circuit. Refer to [LAN-286, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7333E




Case 4

Check data link connector circuit. Refer to [LAN-286, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7334E




Case 5

Check BCM circuit. Refer to [LAN-287, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7335E




Case 6

Check combination meter circuit. Refer to [LAN-287, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7336E




Case 7

Check transfer control unit circuit. Refer to [LAN-288, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	—	—	✓	—	✓	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7337E




Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-288, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7338E



CAN SYSTEM (TYPE 10)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-289, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7339E



Case 10

Check CAN communication circuit. Refer to [LAN-290, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7340E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-293, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7341E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-293, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7342E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003NU

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003NV

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS00300

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS00301

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS00302

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Differential lock control unit connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS00304

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

LAN

CAN SYSTEM (TYPE 11)

PFP:23710


System Description

UKS003N7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003N8




CAN SYSTEM (TYPE 11)

[CAN]

Schematic

UKS003N9



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0514E

CAN SYSTEM (TYPE 11)



[CAN]

Wiring Diagram — CAN —

UKS003NA

LAN-CAN-31

▬ : DATA LINE



REFER TO THE FOLLOWING.



(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0515E

CAN SYSTEM (TYPE 11)



[CAN]

LAN-CAN-32



BKWA0516E

▬ : DATA LINE



CAN SYSTEM (TYPE 11)

[CAN]

UKS003NO

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table												
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 11)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-311, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	—	✓	CAN COMM CIRCUIT (U1000)	✓
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7045E




PKIB7164E

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-312, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7046E




Case 3

Check ECM circuit. Refer to [LAN-313, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUI (U100) ✓	CAN COMM CIRCUI (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUI (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUI (U100) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUI (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUI (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	—	CAN COMM CIRCUI (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUI (U100) ✓	—

PKIB7047E




Case 4

Check TCM circuit. Refer to [LAN-314, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7048E



CAN SYSTEM (TYPE 11)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-314, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7049E



PKIB7168E

CAN SYSTEM (TYPE 11)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-315, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7050E




Case 7

Check combination meter circuit. Refer to [LAN-315, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	✓	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	—

PKIB7051E



CAN SYSTEM (TYPE 11)


[CAN]

Case 8

Check transfer control unit circuit. Refer to [LAN-316, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	✓	—	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7052E




Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-316, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7053E



CAN SYSTEM (TYPE 11)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-317, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7054E



Case 11

Check CAN communication circuit. Refer to [LAN-318, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7055E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-322, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7056E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-322, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7057E

Inspection Between TCM and Data Link Connector Circuit

UKS003NC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003ND

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003NE

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003NF

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003NG

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



SKIA6868E

UKS003NH

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



SKIA6869E

UKS003NI

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS003NJ

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS003NK

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003NL

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.




4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003NN

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 12)

PFP:23710


System Description

UKS003MQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003MR



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 12)

[CAN]

Schematic

UKS003MS



BKWA0514E

CAN SYSTEM (TYPE 12)



[CAN]

Wiring Diagram — CAN —

UKS003MT

LAN-CAN-34

▬ : DATA LINE





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0519E

LAN-CAN-35





BKWA0520E

CAN SYSTEM (TYPE 12)

[CAN]

LAN-CAN-36

— : DATA LINE



BKWA0521E

CAN SYSTEM (TYPE 12)

[CAN]

UKS003MU

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6531E

CAN SYSTEM (TYPE 12)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB5022E

CAN SYSTEM (TYPE 12)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-340, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	

PKIB7032E




PKIB7164E

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-341, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7033E



CAN SYSTEM (TYPE 12)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-342, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7034E




PKIB7166E

Case 4

Check TCM circuit. Refer to [LAN-343, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7035E




Case 5

Check data link connector circuit. Refer to [LAN-343, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7036E




Case 6

Check BCM circuit. Refer to [LAN-344, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7037E



CAN SYSTEM (TYPE 12)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-344, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7038E




Case 8

Check transfer control unit circuit. Refer to [LAN-345, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7039E




Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-345, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7040E




Case 10

Check IPDM E/R circuit. Refer to [LAN-346, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7041E



Case 11

Check CAN communication circuit. Refer to [LAN-347, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7042E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-351, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7043E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-351, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7044E

Inspection Between TCM and Data Link Connector Circuit

UKS003MV

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003MW

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003MX


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003MY

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003MZ

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .
- NG >> Repair harness between data link connector and BCM.



SKIA6868E

UKS003N0

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
- NG >> Repair harness between BCM and data link connector.



SKIA6869E

UKS003N1

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS003N2

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS003N3

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003N4

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.**86 (P) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.

- BCM connector
- Combination meter connector
- Transfer control unit connector
- Harness connector M91

2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



A
B
C
D
E
F
G
H
I
J
L
M

LAN

10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



PKIA8141E

11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



SKIB2821E

12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



LKIA0037E

13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003N6

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 13)

PFP:23710


System Description

UKS003M8

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003M9




BKIA0163E

CAN SYSTEM (TYPE 13)

[CAN]

Schematic

UKS003MA



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0518E

CAN SYSTEM (TYPE 13)



[CAN]

Wiring Diagram — CAN —

UKS003MB

LAN-CAN-37

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)







BKWA0522E

CAN SYSTEM (TYPE 13)

[CAN]



LAN-CAN-38

— : DATA LINE



BKWA0523E

▬ : DATA LINE



BKWA0524E

CAN SYSTEM (TYPE 13)

[CAN]

UKS003MC

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6532E

CAN SYSTEM (TYPE 13)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
DIFF LOCK
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
DIFF LOCK
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6533E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-370, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7018E




Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-371, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7019E




Case 3

Check ECM circuit. Refer to [LAN-372, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB7020E




Case 4

Check TCM circuit. Refer to [LAN-373, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓	
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7021E




Case 5

Check differential lock control unit circuit. Refer to [LAN-373, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	✓UNKWN	✓UNKWN	—	—	—	—	✓UNKWN	✓UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	✓UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7022E



CAN SYSTEM (TYPE 13)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-374, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7023E



CAN SYSTEM (TYPE 13)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-374, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7024E




Case 8

Check combination meter circuit. Refer to [LAN-375, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7025E




Case 9

Check transfer control unit circuit. Refer to [LAN-375, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7026E



CAN SYSTEM (TYPE 13)


[CAN]

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-376, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	✓	✓	✓	✓	✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7027E




Case 11

Check IPDM E/R circuit. Refer to [LAN-376, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7028E



Case 12

Check CAN communication circuit. Refer to [LAN-377, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	✓	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7029E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-381, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓	
AT	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7030E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-381, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7031E

Inspection Between TCM and Data Link Connector Circuit

UKS003MD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003ME

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).

11 (L) – 11 (L) : Continuity should exist.
10 (P) – 15 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003MG

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003MH

Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



UKS003MJ

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



UKS003MJ

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003MK

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003ML

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003MM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003MN

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003MO

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.


**8. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect following connectors.
 - Differential lock control unit connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and differential lock control unit
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and transfer control unit
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - TCM
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003MP

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 14)

PFP:23710


System Description

UKS003L7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003L8




BKIA0164E

CAN SYSTEM (TYPE 14)

[CAN]

Schematic

UKS003L9



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0593E

CAN SYSTEM (TYPE 14)


[CAN]

UKS003LA


Wiring Diagram — CAN —

LAN-CAN-40

▬ : DATA LINE



NEXT PAGE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0526E

CAN SYSTEM (TYPE 14)


[CAN]

LAN-CAN-41

— : DATA LINE





A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0594E

▬ : DATA LINE



CAN SYSTEM (TYPE 14)

[CAN]

UKS003LB

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5021E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 14)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-400, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5127E




Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-401, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS				
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							VDC/TCS /ABS			IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD							
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5128E




PKIB7186E

Case 3

Check ECM circuit. Refer to [LAN-402, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW [√] N	—	UNKW [√] N	—	UNKW [√] N	CAN COMM CIRCUIT (U1000) [√]	CAN COMM CIRCUIT (U1001) [√]				
A/T	—	NG	UNKW [√] N	UNKW [√] N	—	—	—	UNKW [√] N	UNKW [√] N	UNKW [√] N	—	CAN COMM CIRCUIT (U1000) [√]	—
BCM	No indication	NG	UNKW [√] N	UNKW [√] N	—	—	—	UNKW [√] N	—	—	UNKW [√] N	CAN COMM CIRCUIT (U1000) [√]	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) [√]	—
ALL MODE AWD/4WD	—	NG	UNKW [√] N	UNKW [√] N	—	—	—	UNKW [√] N	—	UNKW [√] N	—	CAN COMM CIRCUIT (U1000) [√]	—
ABS	—	NG	UNKW [√] N	UNKW [√] N	UNKW [√] N	—	—	UNKW [√] N	—	—	—	CAN COMM CIRCUIT (U1000) [√]	—
IPDM E/R	No indication	—	UNKW [√] N	UNKW [√] N	—	—	UNKW [√] N	—	—	—	—	CAN COMM CIRCUIT (U1000) [√]	—

PKIB5129E




Case 4

Check TCM circuit. Refer to [LAN-403, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN KN W N	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UN KN W N	—	—	—	UN KN W N	UN KN W N	UN KN W N	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UN KN W N	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UN KN W N	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5130E




Case 5

Check steering angle sensor circuit. Refer to [LAN-403, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5131E




Case 6

Check data link connector circuit. Refer to [LAN-404, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	N indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	N indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	N indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5132E




Case 7

Check BCM circuit. Refer to [LAN-404, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5133E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 8

Check combination meter circuit. Refer to [LAN-405, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5134E




Case 9

Check transfer control unit circuit. Refer to [LAN-405, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5135E




Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-406, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5136E



CAN SYSTEM (TYPE 14)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-406, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5137E



Case 12

Check CAN communication circuit. Refer to [LAN-407, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5138E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-411, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5139E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-411, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5140E

Inspection Between TCM and Data Link Connector Circuit

UKS003LC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003LD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003LE


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003LF

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003LG

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS003LH

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



UKS003LI

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003LJ

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003LK

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003LL

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003LM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003LN

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.


**8. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and transfer control unit
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003LO

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 15)

PFP:23710


System Description

UKS003LP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003LQ




BKIA0165E

CAN SYSTEM (TYPE 15)

[CAN]

Schematic

UKS003LR



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0595E

CAN SYSTEM (TYPE 15)



[CAN]

UKS003LS

Wiring Diagram — CAN —

LAN-CAN-43

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)



BKWA0530E

CAN SYSTEM (TYPE 15)

[CAN]



LAN-CAN-44

▬ : DATA LINE



BKWA0596E

▬ : DATA LINE



CAN SYSTEM (TYPE 15)

[CAN]

UKS003LT

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6535E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 15)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
DIFF LOCK
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
DIFF LOCK
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6533E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-431, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7003E




Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-432, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—

PKIB7004E



PKIB6588E

CAN SYSTEM (TYPE 15)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-433, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—	

PKIB7005E




Case 4

Check TCM circuit. Refer to [LAN-434, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTNR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U100)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB9491E




Case 5

Check differential lock control unit circuit. Refer to [LAN-434, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7007E



CAN SYSTEM (TYPE 15)


[CAN]

Case 6

Check steering angle sensor circuit. Refer to [LAN-435, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNT R											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7008E



CAN SYSTEM (TYPE 15)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-435, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	NG indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	NG indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	NG indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7009E



CAN SYSTEM (TYPE 15)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-436, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7010E




PKIB6594E

Case 9

Check combination meter circuit. Refer to [LAN-436, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7011E



CAN SYSTEM (TYPE 15)


[CAN]

Case 10

Check transfer control unit circuit. Refer to [LAN-437, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTN											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7012E




PKIB6596E

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-437, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7013E



CAN SYSTEM (TYPE 15)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-438, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7014E



Case 13

Check CAN communication circuit. Refer to [LAN-439, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7015E

CAN SYSTEM (TYPE 15)

[CAN]

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-443, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7016E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-443, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7017E

Inspection Between TCM and Data Link Connector Circuit

UKS003LU

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003LV

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003LX

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003LY

Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



UKS003LZ

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS003M0

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-7, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



SKIA6868E

UKS003M1

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



SKIA6869E

UKS003M2

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS003M3

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS003M4

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003M5

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E2.



SKIB0571E

4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.

**8. CHECK HARNESS FOR SHORT CIRCUIT**

- Disconnect following connectors.
 - Differential lock control unit connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - TCM
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003M7

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

