

# SECTION RFD

## REAR FINAL DRIVE

A  
B  
C

RFD

### CONTENTS

E

#### C200

<b>PRECAUTIONS</b> .....	<b>4</b>
Service Notice or Precautions .....	4
<b>PREPARATION</b> .....	<b>5</b>
Special Service Tools .....	5
Commercial Service Tools .....	7
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>	
<b>TROUBLESHOOTING</b> .....	<b>8</b>
NVH Troubleshooting Chart .....	8
<b>DESCRIPTION</b> .....	<b>9</b>
Cross-Sectional View .....	9
<b>DIFFERENTIAL GEAR OIL</b> .....	<b>10</b>
Changing Differential Gear Oil .....	10
DRAINING .....	10
FILLING .....	10
Checking Differential Gear Oil .....	10
OIL LEAKAGE AND OIL LEVEL .....	10
<b>FRONT OIL SEAL</b> .....	<b>11</b>
Removal and Installation .....	11
REMOVAL .....	11
INSTALLATION .....	12
<b>CARRIER COVER</b> .....	<b>13</b>
Removal and Installation .....	13
REMOVAL .....	13
INSTALLATION .....	13
<b>REAR FINAL DRIVE ASSEMBLY</b> .....	<b>14</b>
Removal and Installation .....	14
REMOVAL .....	14
INSTALLATION .....	14
Disassembly and Assembly .....	15
COMPONENTS .....	15
ASSEMBLY INSPECTION AND ADJUSTMENT..	17
DISASSEMBLY .....	20
INSPECTION AFTER DISASSEMBLY .....	23
ADJUSTING AND SELECTING WASHERS .....	24
ASSEMBLY .....	29
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>35</b>
General Specifications .....	35
2WD MODELS .....	35

4WD MODELS .....	35
Inspection and Adjustment .....	35
DRIVE GEAR RUNOUT .....	35
DIFFERENTIAL SIDE GEAR CLEARANCE .....	35
PRELOAD TORQUE .....	35
BACKLASH .....	35
COMPANION FLANGE RUNOUT .....	36
SELECTIVE PARTS .....	36

F  
G  
H

#### M226 WITHOUT ELECTRONIC LOCKING DIFFERENTIAL

<b>PRECAUTIONS</b> .....	<b>37</b>
Precautions for Servicing Rear Final Drive .....	37
<b>PREPARATION</b> .....	<b>38</b>
Special Service Tools .....	38
Commercial Service Tools .....	41
<b>NOISE, VIBRATION, AND HARSHNESS (NVH)</b>	
<b>TROUBLESHOOTING</b> .....	<b>42</b>
NVH Troubleshooting Chart .....	42
<b>DESCRIPTION</b> .....	<b>43</b>
Cross-Sectional View .....	43
<b>DIFFERENTIAL GEAR OIL</b> .....	<b>44</b>
Changing Differential Gear Oil .....	44
DRAINING .....	44
FILLING .....	44
Checking Differential Gear Oil .....	44
OIL LEAKAGE AND OIL LEVEL .....	44
<b>FRONT OIL SEAL</b> .....	<b>45</b>
Removal and Installation .....	45
REMOVAL .....	45
INSTALLATION .....	45
<b>CARRIER COVER</b> .....	<b>47</b>
Removal and Installation .....	47
REMOVAL .....	47
INSTALLATION .....	47
<b>REAR FINAL DRIVE ASSEMBLY</b> .....	<b>48</b>
Removal and Installation .....	48
REMOVAL .....	48

I  
J  
K  
L  
M

INSTALLATION .....	48	How to Perform Trouble Diagnosis .....	81
Disassembly and Assembly .....	49	BASIC CONCEPT .....	81
COMPONENTS .....	49	Location of Electrical Parts .....	82
ASSEMBLY INSPECTION AND ADJUSTMENT..	50	Wiring Diagram — DIFLOC — .....	83
DISASSEMBLY .....	53	Trouble Diagnosis Chart for Symptoms .....	85
INSPECTION AFTER DISASSEMBLY .....	57	Differential Lock Control Unit Input/Output Signal	
SELECTION ADJUSTING WASHERS .....	58	Reference Values .....	85
ASSEMBLY .....	61	DIFFERENTIAL LOCK CONTROL UNIT	
<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>67</b>	INSPECTION TABLE .....	85
General Specifications .....	67	CONSULT-II Function (DIFF LOCK) .....	87
Inspection and Adjustment .....	67	FUNCTION .....	87
DIFFERENTIAL SIDE GEAR CLEARANCE .....	67	CONSULT-II SETTING PROCEDURE .....	87
PRELOAD TORQUE .....	67	SELF-DIAG RESULTS MODE .....	88
BACKLASH .....	67	DATA MONITOR MODE .....	90
COMPANION FLANGE RUNOUT .....	67	<b>TROUBLE DIAGNOSIS FOR SYSTEM .....</b>	<b>91</b>
SELECTIVE PARTS .....	68	Power Supply Circuit For Differential Lock Control	
<b>M226 WITH ELECTRONIC LOCKING DIFFERENTIAL</b>		Unit .....	91
		DIAGNOSTIC PROCEDURE .....	91
<b>PRECAUTIONS .....</b>	<b>69</b>	Differential Lock Control Unit .....	92
Precautions for Supplemental Restraint System		DIAGNOSTIC PROCEDURE .....	92
(SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER” .....	69	Differential Lock Mode Switch .....	93
Precautions for Differential Case Assembly and Dif-		DIAGNOSTIC PROCEDURE .....	93
ferential Lock Control Unit Replacement. ....	69	COMPONENT INSPECTION .....	95
CHECK DIFF LOCK INDICATOR LAMP .....	69	Differential Lock Position Switch .....	96
METHOD FOR ADJUSTMENT .....	70	DIAGNOSTIC PROCEDURE .....	96
Precautions .....	70	Differential Lock Solenoid Relay .....	98
Precautions for Servicing Rear Final Drive .....	70	DIAGNOSTIC PROCEDURE .....	98
<b>PREPARATION .....</b>	<b>72</b>	Differential Lock Solenoid .....	99
Special Service Tools .....	72	DIAGNOSTIC PROCEDURE .....	99
Commercial Service Tools .....	75	COMPONENT INSPECTION .....	102
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>		ABS System .....	102
<b>TROUBLESHOOTING .....</b>	<b>76</b>	DIAGNOSTIC PROCEDURE .....	102
NVH Troubleshooting Chart .....	76	CAN Communication Line .....	103
<b>DIFFERENTIAL GEAR OIL .....</b>	<b>77</b>	DIAGNOSTIC PROCEDURE .....	103
Changing Differential Gear Oil .....	77	<b>TROUBLE DIAGNOSIS FOR SYMPTOMS .....</b>	<b>104</b>
DRAINING .....	77	DIFF LOCK Indicator Lamp Does Not Turn ON ...	104
FILLING .....	77	DIAGNOSTIC PROCEDURE .....	104
Checking Differential Gear Oil .....	77	DIFF LOCK Indicator Lamp Does Not Change ...	107
DIFFERENTIAL GEAR OIL LEAKAGE AND		DIAGNOSTIC PROCEDURE .....	107
LEVEL .....	77	DIFF LOCK Indicator Lamp Sometimes Flashes .	108
<b>DIFFERENTIAL LOCK SYSTEM .....</b>	<b>78</b>	DIAGNOSTIC PROCEDURE .....	108
Cross-sectional View .....	78	<b>DIFFERENTIAL LOCK CONTROL UNIT .....</b>	<b>110</b>
Differential Lock Operation .....	79	Removal and Installation .....	110
System Description .....	79	REMOVAL .....	110
DIFFERENTIAL LOCK SOLENOID .....	79	INSTALLATION .....	110
DIFFERENTIAL LOCK POSITION SWITCH .....	79	<b>FRONT OIL SEAL .....</b>	<b>111</b>
DIFFERENTIAL LOCK CONTROL UNIT .....	79	Removal and Installation .....	111
DIFFERENTIAL LOCK MODE SWITCH .....	79	REMOVAL .....	111
DIFF LOCK INDICATOR LAMP .....	79	INSTALLATION .....	112
System Diagram .....	80	<b>CARRIER COVER .....</b>	<b>113</b>
COMPONENTS FUNCTION DESCRIPTION .....	80	Removal and Installation .....	113
CAN Communication .....	80	REMOVAL .....	113
SYSTEM DESCRIPTION .....	80	INSTALLATION .....	113
<b>TROUBLE DIAGNOSIS .....</b>	<b>81</b>	<b>REAR FINAL DRIVE ASSEMBLY .....</b>	<b>114</b>
Fail-safe Function .....	81	Removal and Installation .....	114
		REMOVAL .....	114

INSTALLATION .....	114
Disassembly and Assembly .....	115
COMPONENTS .....	115
ASSEMBLY INSPECTION AND ADJUSTMENT .....	116
DISASSEMBLY .....	119
INSPECTION AFTER DISASSEMBLY .....	123
SELECTION ADJUSTING WASHERS .....	124
ASSEMBLY .....	126

<b>SERVICE DATA AND SPECIFICATIONS (SDS) ...</b>	<b>131</b>
General Specifications .....	131
Inspection and Adjustment .....	131
PRELOAD TORQUE .....	131
BACKLASH .....	131
COMPANION FLANGE RUNOUT .....	131
SELECTIVE PARTS .....	131

A  
B  
C

**RFD**

E  
F  
G  
H  
I  
J  
K  
L  
M

---

## PRECAUTIONS

### Service Notice or Precautions

EDS0026E

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dust proof area.
- Before disassembly completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Do not damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new differential gear oil, petroleum jelly, or multi-purpose grease as specified.

# PREPARATION

[C200]

PF0:00002

EDS0026F

## PREPARATION

### Special Service Tools








The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV38108300 (J-44195) Flange wrench	Removing and installing drive pinion lock nut
KV38100500 (J-25273) Drift	Installing front oil seal <b>a: 80 mm (3.15 in) dia.</b> <b>b: 60 mm (2.36 in) dia.</b>
ST3127S000 (J-25765-A) Preload gauge 1: GG91030000 (J-25765) Torque wrench 2: HT62940000 ( — ) Socket adapter (1/2") 3: HT62900000 ( — ) Socket adapter (3/8")	Measuring pinion bearing preload and total preload
KV10111100 (J-37228) Seal cutter	Removing rear cover
ST3306S001 ( — ) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2) Base	Removing and installing side bearing inner race <b>a: 28.5 mm (1.122 in) dia.</b> <b>b: 38 mm (1.50 in) dia.</b>
ST30031000 (J-22912-01) Puller	Removing pinion rear bearing inner race

A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M



# PREPARATION

**[C200]**

Tool number (Kent-Moore No.) Tool name	Description
KV38100600 (J-25267) Drift	Installing side bearing adjusting washer <b>a: 8 mm (0.31 in)</b> <b>b: R42.5 mm (1.673 in)</b>
 <p style="text-align: center;">NT528</p>	
ST30621000 (J-25742-5) Drift	Installing pinion rear bearing outer race <b>a: 79 mm (3.11 in) dia.</b> <b>b: 59 mm (2.32 in) dia.</b>
 <p style="text-align: center;">ZZA1000D</p>	
ST30613000 (J-25742-3) Drift	Installing pinion front bearing outer race <b>a: 72 mm (2.83 in) dia.</b> <b>b: 48 mm (1.89 in) dia.</b>
 <p style="text-align: center;">ZZA1000D</p>	
ST30611000 (J-25742-1) Drift bar	Installing pinion front bearing outer race [Use with ST30613000 (J-25742-3) and ST30621000 (J-25742-5)]
 <p style="text-align: center;">S-NT090</p>	
ST30901000 (J-26010-01) Drift	Installing pinion rear bearing inner race <b>a: 79 mm (3.11 in) dia.</b> <b>b: 45 mm (1.77 in) dia.</b> <b>c: 35.2 mm (1.386 in) dia.</b>
 <p style="text-align: center;">ZZA0978D</p>	
ST3323 0000 (J-25805-01) Drift	Installing side bearing inner race <b>a: 51 mm (2.01 in) dia.</b> <b>b: 41 mm (1.61 in) dia.</b> <b>c: 28.5 mm (1.122 in) dia.</b>
 <p style="text-align: center;">NT085</p>	
— (J-8129) Spring gauge	Measuring turning torque
 <p style="text-align: center;">NT127</p>	



# PREPARATION

[C200]

Tool number (Kent-Moore No.) Tool name	Description	
— (J-34309) Differential shim selector tool	 NT134	A B C
— (J-25269-4) Side bearing disc (2 Req'd)	 NT136	RFD E

## Commercial Service Tools

EDS0026G

Tool name	Description	
Spacer	 ZZA1133D	F G H I
Power tool	 PBIC0190E	J K L M





# DESCRIPTION


[C200]

PF0:00000

EDS0026I

## DESCRIPTION

### Cross-Sectional View



- |                        |                         |                       |
|------------------------|-------------------------|-----------------------|
| 1. Companion flange    | 2. Pinion front bearing | 3. Collapsible spacer |
| 4. Pinion rear bearing | 5. Differential case    | 6. Side bearing       |
| 7. Drive gear          | 8. Pinion mate gear     | 9. Side gear          |
| 10. Pinion mate shaft  | 11. Drive pinion        |                       |

A

B

C

RFD

E

F

G

H

I

J

K

L


M

## DIFFERENTIAL GEAR OIL

### Changing Differential Gear Oil DRAINING

1. Stop engine.
2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
3. Install the drain plug with a new gasket to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

**CAUTION:**  
Do not reuse gasket.




### FILLING

1. Remove the filler plug from the rear final drive assembly.
2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

**Differential gear oil grade and capacity** : Refer to [MA-11, "Fluids and Lubricants"](#).

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).




### Checking Differential Gear Oil OIL LEAKAGE AND OIL LEVEL

1. Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.

**CAUTION:**  
Do not start engine while checking differential gear oil level.

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).



## FRONT OIL SEAL

### Removal and Installation

#### REMOVAL


1. Remove the propeller shaft. Refer to [PR-5, "Removal and Installation"](#) .
2. Put matching mark on the end of the drive pinion. The matching mark should be in line with the matching mark A on companion flange.

**CAUTION:**

**For matching mark, use paint. Do not damage drive pinion.**


**NOTE:**

The matching mark A on the final drive companion flange indicates the maximum vertical runout position.




3. Remove the drive pinion lock nut using Tool.


**Tool number : KV38108300 (J-44195)**



4. Remove the companion flange using suitable tool.



5. Remove the front oil seal using suitable tool.



A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M


## INSTALLATION

1. Apply multi-purpose grease to the front oil seal lips.
2. Install the front oil seal using Tool.


**Tool number : KV38100500 (J-25273)**

**CAUTION:**

- Do not reuse oil seal.
- Do not incline oil seal when installing.



3. Align the matching mark of drive pinion with the matching mark A of companion flange, then install the companion flange.




4. Apply gear oil on the screw part of drive pinion and the seating surface of drive pinion lock nut.
5. Install the drive pinion lock nut and tighten to the specified torque using Tool. Refer to [RFD-15, "COMPONENTS"](#) .

**Tool number : KV38108300 (J-44195)**

**CAUTION:**

**Do not reuse drive pinion lock nut.**

6. Install the propeller shaft. Refer to [PR-5, "Removal and Installation"](#) .



## CARRIER COVER


Removal and Installation  
REMOVAL

1. Drain the differential gear oil. Refer to [RFD-10, "DRAINING"](#) .
2. Disconnect the parking brake cable from the carrier cover.
3. Remove the carrier cover bolts. Then separate the carrier cover from the gear carrier using Tool.

**Tool number** : KV10111100 (J-37228)


**CAUTION:**

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



## INSTALLATION

1. Apply a bead of sealant to the mating surface of the carrier cover as shown.
  - Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .
2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#) .
3. Connect the parking brake cable to the carrier cover.
4. Fill the rear final drive assembly with recommended differential gear oil. Refer to [RFD-10, "DIFFERENTIAL GEAR OIL"](#) .



## REAR FINAL DRIVE ASSEMBLY


PF3:38300

### Removal and Installation REMOVAL

EDS0028E

**CAUTION:**

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
  - Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
1. Drain the differential gear oil. Refer to [RFD-44, "DRAINING"](#) .
  2. Remove the rear propeller shaft. Refer to [PR-10, "Removal and Installation"](#) .
  3. Remove the axle shaft. Refer to [RAX-7, "Removal and Installation"](#) .
  4. Disconnect the following components from the rear final drive.
    - ABS sensor wire harness
    - Parking brake cable
    - Brake hoses



5. Support rear final drive assembly using a suitable jack.
6. Remove rear shock absorber lower bolts. Refer to [RSU-7, "Removal and Installation"](#) .
7. Remove leaf spring U-bolt nuts. Refer to [RSU-8, "Removal and Installation"](#) .
8. Remove rear final drive assembly.

**CAUTION:**

Secure rear final drive assembly to the jack while removing it.

### INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**

- Fill the rear final drive assembly with differential gear oil after installation. Refer to [RFD-10, "DIFFERENTIAL GEAR OIL"](#) .
- Bleed the air from brake system. Refer to [BR-10, "Bleeding Brake System"](#) .


# REAR FINAL DRIVE ASSEMBLY

[C200]

## Disassembly and Assembly COMPONENTS

EDS00260

SEC. 380



A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## REAR FINAL DRIVE ASSEMBLY

[C200]

- 
- |  |                               |                              |
|--|-------------------------------|------------------------------|
| 1. Gear carrier                          | 2. Drive pinion lock nut      | 3. Companion flange          |
| 4. Front oil seal                        | 5. Drive pinion front bearing | 6. Drain plug                |
| 7. Collapsible spacer                    | 8. Side bearing cap           | 9. Drive pinion rear bearing |
| 10. Drive pinion height adjusting washer | 11. Drive pinion              | 12. Drive gear               |
| 13. Differential case                    | 14. Carrier cover             | 15. Filler plug              |
| 16. Pinion mate shaft                    | 17. Lock pin                  | 18. Side bearing             |
| 19. Side bearing adjusting washer        | 20. Side gear thrust washer   | 21. Side gear                |
| 22. Pinion mate gear                     | 23. Pinion mate thrust washer | 24. Gasket                   |
| 25. Breather                             |                               |                              |



## ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to [RFD-10, "DIFFERENTIAL GEAR OIL"](#) .
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to [RFD-13, "CARRIER COVER"](#) .

### Total Preload Torque

1. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
2. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
3. Measure total preload torque using Tool.

**Tool number** : ST3127S000 (J-25765-A)

#### Total preload torque

: 1.4 - 2.9 N·m (0.15 - 0.29 kg·m, 13 - 25 in·lb)

#### NOTE:

**Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque**

- If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

#### If the total preload torque is greater than specification

**On drive pinion bearings:** Replace the collapsible spacer.

**On side bearings:** Use thinner side bearing adjusting washers by the same amount to each side. Refer to [RFD-36, "Side Bearing Adjusting Washer"](#) .

#### If the total preload torque is less than specification

**On drive pinion bearings:** Tighten the drive pinion nut.

**On side bearings:** Use thicker side bearing adjusting washers by the same amount to each side. Refer to [RFD-36, "Side Bearing Adjusting Washer"](#) .

### Drive Gear Runout



1. Fit a dial indicator to the drive gear back face.
2. Rotate the drive gear to measure runout.

**Runout limit** : 0.08 mm (0.0031 in) or less

- If the runout is outside of the limit, check the condition of the drive gear assembly. Foreign material may be caught between the drive gear and differential case, or the differential case or drive gear may be deformed.

#### CAUTION:

**Replace drive gear and drive pinion as a set.**



### Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.


# REAR FINAL DRIVE ASSEMBLY

[C200]

1. Apply red lead to drive gear.

**NOTE:**


Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.




2. Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown.

**CAUTION:**


**Check tooth contact on drive side and reverse side.**




3. If the tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height (dimension X).



- If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washers to move the drive pinion closer to the drive gear. Refer to [RFD-36, "Drive Pinion Height Adjusting Washer"](#).



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washers to move the drive pinion farther from the drive gear. Refer to [RFD-36, "Drive Pinion Height Adjusting Washer"](#).



## Backlash

1. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash:**            **0.10 - 0.15 mm (0.0039 - 0.0059 in)**


- If the backlash is outside of the specification, change the thickness of each side bearing adjusting washer.

**If the backlash is greater than specification:**

**Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. Refer to [RFD-36, "Side Bearing Adjusting Washer"](#) .**

**If the backlash is less than specification:**

**Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. Refer to [RFD-36, "Side Bearing Adjusting Washer"](#) .**



### CAUTION:


**Do not change the total thickness of side bearing adjusting washers as it will change the side bearing preload torque.**

## Companion Flange Runout

1. Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.

**Runout limit:**    **0.08 mm (0.0031 in) or less**

2. If the runout is outside the runout limit, follow the procedure below to adjust.
  - a. Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
  - b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
  - c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.



A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## DISASSEMBLY


### Differential Assembly

1. Remove carrier cover bolts.
2. Remove carrier cover using Tool.

**Tool number** : KV10111100 (J-37228)

**CAUTION:**


- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




3. For proper reinstallation, paint matching marks on one side of side bearing cap.

**CAUTION:**


- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.



4. Remove side bearing caps.




5. Remove differential case assembly using suitable tool.



# REAR FINAL DRIVE ASSEMBLY

[C200]

- Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusting washers together with bearings.




6. Remove side bearing inner race using Tools.

**Tool number A: ST33051001 (J-22888-20)**

**B: ST33061000 (J-8107-2)**

**CAUTION:**

- Engage puller jaws in groove to prevent damage.
- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except if it is replaced.



7. For proper reinstallation, paint matching mark on one differential case assembly.


**CAUTION:**

**Use paint for matching marks. Do not damage differential case or drive gear.**


8. Remove drive gear bolts.  
9. Tap the drive gear off the differential case assembly using suitable tool.

**CAUTION:**

**Tap evenly all around to keep drive gear from binding.**



10. Remove the lock pin of pinion mate shaft from the drive gear side using suitable tool.




A  
B  
C  
RFD

E  
F  
G  
H  
I  
J  
K  
L  
M


# REAR FINAL DRIVE ASSEMBLY

[C200]

11. Remove pinion mate shaft.



12. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.



## Drive Pinion Assembly


1. Remove differential case assembly. Refer to [RFD-20, "Differential Assembly"](#).
2. Remove drive pinion lock nut using Tool.

**Tool number** : KV38108300 ( — )


3. Put matching marks on the companion flange and drive pinion using paint.

**CAUTION:**

**Use paint to make the matching marks. Do not damage the companion flange or drive pinion.**



4. Remove companion flange using suitable Tool.



# REAR FINAL DRIVE ASSEMBLY


[C200]

5. Remove drive pinion assembly from gear carrier using suitable tool.

**CAUTION:**


**Do not drop drive pinion assembly.**

6. Remove front oil seal.
7. Remove drive pinion front bearing inner race.
8. Remove collapsible spacer.



9. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.


**Tool number : ST30031000 (J-22912-01)**



10. Tap drive pinion front and rear bearing outer races uniformly with a brass bar or equivalent to remove.

**CAUTION:**

**Do not damage gear carrier.**



## INSPECTION AFTER DISASSEMBLY

Clean up the disassembled parts. Then, inspect if the parts are worn or damaged. If so, follow the measures below.

### Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

### Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

### Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

A  
B  
C  
RFD

E  
F  
G

H  
I  
J  
K

L  
M



## Side Gear Thrust Washer and Pinion Mate Thrust Washer

- If any chips (by friction), damage, or unusual wear are found, replace with new one.

## Gear Carrier

- If any wear or cracks are found on the contact sides of gear carrier, replace with new one.

## Companion Flange


- If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

## ADJUSTING AND SELECTING WASHERS

### Side Gear Back Clearance

- Assemble the differential parts if they are disassembled. Refer to [RFD-31, "Differential Assembly"](#).

1. Place the differential case straight up so that the side gear to be measured is upward.



2. Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

**Side gear back clearance: 0.1 - 0.2 mm (0.004 - 0.008 in) or less.**

- If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to [RFD-36, "Side Gear Thrust Washer"](#).

**If the side gear back clearance is greater than specification:**

**Use a thicker side gear thrust washer.**

**If the side gear back clearance is less than specification:**


**Use a thinner side gear thrust washer.**

**CAUTION:**

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- Select a side gear thrust washer for right and left individually.

**NOTE:**

Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.






## Side Bearing Preload Torque

- A selection of side bearing adjusting washers is required for successful completion of this procedure.

- Apply differential gear oil to the side bearings, and install the differential case assembly with the side bearing outer races into the gear carrier.


**CAUTION:**

**Do not reuse side bearing outer race when replacing side bearing inner race (replace as a set).**




- Insert the left and right original side bearing adjusting washers in place between side bearings and gear carrier using Tool.

**Tool number : KV38100600 (J-25267)**




- Align the matching mark on the side bearing cap with the matching mark on the gear carrier.
- Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).
- Turn the differential assembly several times to seat the side bearings.



- To determine side bearing preload torque, measure the pulling force of the differential assembly at the drive gear bolt using Tool.

**Tool number : — (J-8129)**

**Specification : 34.2 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb) of pulling force at the drive gear bolt**



**NOTE:**

If pulling force of the differential assembly at the drive gear bolt is within specification, side bearing preload torque will also be within specification. Refer to [RFD-17, "Total Preload Torque"](#).

A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

# REAR FINAL DRIVE ASSEMBLY

[C200]

7. If the pulling force is outside the specification, use a thicker or thinner side bearing adjusting washer to adjust. Refer to [RFD-36, "Side Bearing Adjusting Washer"](#) .

**If the pulling force is less than the specification:**


**Use a thicker side bearing adjusting washer.**

**If the pulling force is greater than the specification:**

**Use a thinner side bearing adjusting washer.**

**CAUTION:**

**Select a side bearing adjusting washer for right and left individually.**




8. Record the total amount of washer thickness required for the correct side bearing preload torque.


## Drive Pinion Height

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the drive pinion bearings onto the Tool.


**Tool number : — (J-34309)**



- **Drive pinion front bearing;** make sure the J-34309-3 drive pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the J-34309-5 drive pinion front bearing pilot to secure the drive pinion bearing in its proper position.
- **Drive pinion rear bearing;** the J-34309-8 drive pinion rear bearing pilot is used to center the drive pinion rear bearing only. The J-34309-4 drive pinion rear bearing locking seat is used to lock the drive pinion rear bearing to the assembly.
- **Installation of J-34309-9 and J-34309-16;** place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).




3. Install the drive pinion rear bearing inner race into the gear carrier. Then insert the drive pinion height adjusting washer selector tool, J-34309-1, gauge screw assembly.




# REAR FINAL DRIVE ASSEMBLY

[C200]

4. Assemble the drive pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in the gear carrier. Make sure that the drive pinion height gauge plate, J-34309-16, will turn a full 360°. Tighten the two sections together by hand.




5. Turn the assembly several times to seat the drive pinion bearings.



6. Measure the turning torque at the end of the J-34309-2 gauge anvil using Tool.

**Tool number** : ST3127S000 (J-25765- A)


**Turning torque:** 1.0 - 1.3 N-m (0.11 - 0.13 kg-m,  
9 - 11 in-lb)



7. Place the J-34309-11 drive pinion height adapter onto the gauge plate and tighten it by hand.


**CAUTION:**

**Make sure all machined surfaces are clean.**



8. Position the side bearing discs, Tool, and arbor firmly into the side bearing bores. Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).

**Tool number** : — (J-25269-4)




A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M


# REAR FINAL DRIVE ASSEMBLY

[C200]

9. Select the correct standard drive pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and your J-34309-101 feeler gauge. Measure the distance between the J-34309-11 drive pinion height adapter, including the standard gauge and the arbor.




10. Write down the exact measurement (the value of feeler gauge).



11. Correct the drive pinion height adjusting washer size by referring to the drive pinion "head number".

**There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the drive pinion "head number". It refers to the ideal drive pinion height from standard for quietest operation. Use the following chart to determine the correct drive pinion height adjusting washer.**



Head number	Add or remove from the standard drive pinion height adjusting washer thickness measurement
- 6	Add 0.06 mm (0.0024 in)
- 5	Add 0.05 mm (0.0020 in)
- 4	Add 0.04 mm (0.0016 in)
- 3	Add 0.03 mm (0.0012 in)
- 2	Add 0.02 mm (0.0008 in)
- 1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)


12. Select the correct drive pinion height adjusting washer. Refer to [RFD-36, "Drive Pinion Height Adjusting Washer"](#).

# REAR FINAL DRIVE ASSEMBLY

[C200]

13. Remove the Tool from the gear carrier and disassemble to retrieve the drive pinion bearings.

Tool number : — (J-34309)



## ASSEMBLY

### Drive Pinion Assembly

1. Install the new drive pinion front and rear bearing outer races using Tools.


Tool number A: ST30611000 (J-25742-1)

B: ST30621000 (J-25742-5)

C: ST30613000 (J-25742-3)

#### CAUTION:

- First tap the drive pinion bearing outer race until it becomes flush with the gear carrier.
- Do not reuse drive pinion front and rear bearing outer race.




2. Select a drive pinion height adjusting washer. Refer to [RFD-26, "Drive Pinion Height"](#).
3. Install the selected drive pinion height adjusting washer to the drive pinion. Press the new drive pinion rear bearing inner race to it using Tool.

Tool number : ST30901000 (J-26010-01)

#### CAUTION:

- Install the drive pinion height adjusting washer in the proper direction as shown.
- Do not reuse drive pinion rear bearing inner race.



# REAR FINAL DRIVE ASSEMBLY

[C200]

4. Assemble the new collapsible spacer to the drive pinion.


**CAUTION:**

**Do not reuse collapsible spacer.**


5. Apply differential gear oil to the drive pinion rear bearing, and install the drive pinion assembly to the gear carrier.
6. Apply differential gear oil to the drive pinion front bearing, and install the new drive pinion front bearing inner race to the drive pinion assembly.

**CAUTION:**

**Do not reuse drive pinion front bearing inner race.**



7. Press the drive pinion front bearing inner race to the drive pinion as far as drive pinion lock nut can be tightened using suitable spacer.




8. Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

**Tool number : KV38100500 (J-25273)**

**CAUTION:**

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



9. Install the companion flange to the drive pinion while aligning the matching marks.

# REAR FINAL DRIVE ASSEMBLY

[C200]

10. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

**Tool number**    **A:** KV38108300 ( — )  
                          **B:** ST3127S000 (J-25765-A)

**Drive pinion bearing preload torque:**  
1.1 - 1.4 N·m (0.12 - 0.14 kg·m, 10 - 12 in·lb)


**CAUTION:**

- Do not reuse drive pinion lock nut.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-15, "COMPONENTS"](#).
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

11. Check companion flange runout. Refer to [RFD-19, "Companion Flange Runout"](#).
12. Install differential case assembly. Refer to [RFD-31, "Differential Assembly"](#).

## Differential Assembly

1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly, or reinstall the old ones on the side gears.





2. Install the side gears and side gear thrust washers into the differential case.

**CAUTION:**

**Make sure that the circular clip is installed to side gears.**

3. Install the pinion mate thrust washers to the two pinion mate gears. Then install the pinion mate gears with the pinion mate thrust washers by aligning them in diagonally opposite positions and rotating them into the differential case.




A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M



# REAR FINAL DRIVE ASSEMBLY


[C200]

- Align the lock pin hole on the differential case with the lock pin hole on the pinion mate shaft, and install the pinion mate shaft.
- Measure the side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to [RFD-24, "Side Gear Back Clearance"](#).




- Drive a new lock pin into the pinion mate shaft until it is flush with the differential case using suitable tool.

**CAUTION:**  
Do not reuse lock pin.




- Align the matching mark of the differential case with the mark of the drive gear, then place the drive gear onto the differential case.



- Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.
  - Use Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**  
Make sure the drive gear back and threaded holes are clean.




- Tighten the drive gear bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#). After tightening the drive gear bolts to the specified torque, tighten an additional 31° to 36° using Tool.

**Tool number** : KV10112100-A (BT-8653-A)

**CAUTION:**

- Always use Tool. Avoid tightening based on visual check alone.
- Tighten drive gear bolts in a crisscross pattern.





# REAR FINAL DRIVE ASSEMBLY


[C200]

10. Press the new side bearing inner races to the differential case using Tools.


**Tool number**     **A: ST33230000 (J-25805-01)**  
                          **B: ST33061000 (J-8107-2)**

**CAUTION:**

**Do not reuse side bearing inner race.**




11. Install the differential case assembly with the side bearing outer races into gear carrier.
12. Measure the side bearing preload torque. If necessary, select the appropriate side bearing adjusting washers. Refer to [RFD-25, "Side Bearing Preload Torque"](#).




13. Insert the selected left and right side bearing adjusting washers in place between the side bearings and gear carrier using Tool.

**Tool number**     **: KV38100600 (J-25267)**



14. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).




15. Check and adjust the drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [RFD-17, "Drive Gear Runout"](#), [RFD-17, "Tooth Contact"](#), [RFD-19, "Backlash"](#) and [RFD-17, "Total Preload Torque"](#).  
Recheck above items.

A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## REAR FINAL DRIVE ASSEMBLY

[C200]

16. Apply sealant to the mating surface of the carrier cover.
  - Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).
- CAUTION:**  
Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.
17. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-15, "COMPONENTS"](#).



# SERVICE DATA AND SPECIFICATIONS (SDS)

**[C200]**

## SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

### General Specifications 2WD MODELS

EDS0026P

Applied model	QR25DE		VQ40DE	
	King cab		King cab	Crew cab
	M/T	A/T	A/T	
Final drive model	C200			
Gear ratio	4.083	3.692	2.937	3.133
Number of teeth (Drive gear/Drive pinion)	49/12	48/13	47/16	47/15
Oil capacity (Approx.)	1.6 ℓ (3-3/8 US pt, 2-7/8 Imp pt)			
Number of pinion gears	2			
Drive pinion adjustment spacer type	Collapsible			

### 4WD MODELS

Applied model	VQ40DE	
	King cab	Crew cab
	A/T	
Final drive model	C200	
Gear ratio	3.133	3.357
Number of teeth (Drive gear/Drive pinion)	47/15	47/14
Oil capacity (Approx.)	1.6 ℓ (3-3/8 US pt, 2-7/8 Imp pt)	
Number of pinion gears	2	
Drive pinion adjustment spacer type	Collapsible	

### Inspection and Adjustment DRIVE GEAR RUNOUT

EDS0026Q

Unit: mm (in)

Item	Runout limit
Drive gear back face	0.08 (0.0031) or less

### DIFFERENTIAL SIDE GEAR CLEARANCE

Unit: mm (in)

Item	Specification
Side gear back clearance (Clearance between side gear and differential case for adjusting side gear backlash)	0.1 - 0.2 (0.004 - 0.008) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

### PRELOAD TORQUE

Unit: N-m (kg-m, in-lb)

Item	Specification
Drive pinion bearing preload torque	1.1 - 1.4 (0.12 - 0.14, 10 - 12)
Side bearing preload torque (reference value determined by drive gear bolt pulling force)	0.3 - 1.5 (0.03 - 0.15, 3 - 13)
Drive gear bolt pulling force (by spring gauge)	34.2 - 39.2 N (3.5 - 4 kg, 7.7 - 8.8 lb)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	1.4 - 2.9 (0.15 - 0.29, 13 - 25)

### BACKLASH

Unit: mm (in)

Item	Specification
Drive gear to drive pinion gear	0.10 - 0.15 (0.0039 - 0.0059)

# SERVICE DATA AND SPECIFICATIONS (SDS)

[C200]

## COMPANION FLANGE RUNOUT

Unit: mm (in)

Item	Runout limit
Companion flange face	0.08 (0.0031) or less
Companion flange inner side	0.08 (0.0031) or less

## SELECTIVE PARTS

### Side Gear Thrust Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
0.75 (0.0295)	38424 EC000	0.87 (0.0343)	38424 EC004
0.78 (0.0307)	38424 EC001	0.90 (0.0350)	38424 EC005
0.81 (0.0319)	38424 EC002	0.93 (0.0366)	38424 EC006
0.84 (0.0331)	38424 EC003		

\*: Always check with the Parts Department for the latest parts information.

### Drive Pinion Height Adjusting Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
3.05 (0.1201)	38154 0C000	3.29 (0.1295)	38154 0C008
3.08 (0.1213)	38154 0C001	3.32 (0.1307)	38154 0C009
3.11 (0.1224)	38154 0C002	3.35 (0.1319)	38154 0C010
3.14 (0.1236)	38154 0C003	3.38 (0.1331)	38154 0C011
3.17 (0.1248)	38154 0C004	3.41 (0.1343)	38154 0C012
3.20 (0.1260)	38154 0C005	3.44 (0.1354)	38154 0C013
3.23 (0.1272)	38154 0C006	3.47 (0.1366)	38154 0C014
3.26 (0.1283)	38154 0C007	3.50 (0.1378)	38154 0C015

\*: Always check with the Parts Department for the latest parts information.

### Side Bearing Adjusting Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
2.00 (0.0787)	38453 N3100	2.35 (0.0925)	38453 N3107
2.05 (0.0807)	38453 N3101	2.40 (0.0945)	38453 N3108
2.10 (0.0827)	38453 N3102	2.45 (0.0965)	38453 N3109
2.15 (0.0846)	38453 N3103	2.50 (0.0984)	38453 N3110
2.20 (0.0866)	38453 N3104	2.55 (0.1004)	38453 N3111
2.25 (0.0886)	38453 N3105	2.60 (0.1024)	38453 N3112
2.30 (0.0906)	38453 N3106	2.65 (0.1043)	38453 N3113

\*: Always check with the Parts Department for the latest parts information.

# PRECAUTIONS

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

### PRECAUTIONS

PFP:00001

#### Precautions for Servicing Rear Final Drive

EDS0046Q

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

A

B

C

RFD

E

F

G

H

I

J

K

L

M

# PREPARATION

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-







PFP:00002

### PREPARATION

### Special Service Tools








EDS0026S

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description
KV40104000 ( — ) Flange wrench		Removing and installing drive pinion nut <b>a: 85 mm (3.35 in) dia.</b> <b>b: 65 mm (2.56 in) dia.</b>
ST33290001 (J-34286) Puller		Removing front oil seal
ST15310000 ( — ) Drift		Installing front oil seal <b>a: 96mm (3.77 in) dia.</b> <b>b: 84 mm (3.30 in) dia.</b>
ST3127S000 (J-25765-A) Preload gauge set 1. GG91030000 (J-25765) Torque wrench 2. HT62940000 (1/2") ( — ) Socket adapter 3. HT62900000 (3/8") ( — ) Socket adapter		Inspecting drive pinion bearing preload and total preload
— (C - 4164) Adjuster tool		Removing and installing side bearing ad- juster
KV10111100 (J-37228) Seal cutter		Removing carrier cover

# PREPARATION







## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

Tool number (Kent-Moore No.) Tool name	Description	
ST30021000 (J-22912-01) Puller <div style="text-align: center;">  <p>ZZA0700D</p> </div>	Removing drive pinion rear bearing inner race	A B C
ST33081000 ( — ) Adapter <div style="text-align: center;">  <p>ZZA1000D</p> </div>	Removing and installing side bearing inner race <b>a: 43 mm (1.69 in) dia.</b> <b>b: 33.5 mm (1.32 in) dia.</b>	RFD E
ST23550000 ( — ) Pin punch <div style="text-align: center;">  <p>NT410</p> </div>	Removing and installing lock pin <b>a: 4.5 mm (0.177 in) dia.</b>	F G
— (8144) Pinion block <div style="text-align: center;">  <p>SDIA2599E</p> </div>	Adjusting pinion gear height	H I J
— (6740) Cone <div style="text-align: center;">  <p>SDIA2601E</p> </div>	Adjusting pinion gear height	K L
— (6741) Screw <div style="text-align: center;">  <p>SDIA2602E</p> </div>	Adjusting pinion gear height	M
— (6739) Pinion height lock <div style="text-align: center;">  <p>SDIA2603E</p> </div>	Adjusting pinion gear height	

# PREPARATION

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-



Tool number (Kent-Moore No.) Tool name	Description
— (D-115-2) Scooter block	Adjusting pinion gear height
— (8541A-1) Arbor disc	Adjusting pinion gear height
— (D-115-3) Arbor	Adjusting pinion gear height
ST01500001 ( — ) Drift	Installing drive pinion rear bearing outer race <b>a: 89mm (3.50 in) dia.</b> <b>b: 79 mm (3.11 in) dia.</b>
ST30022000 ( — ) Drift	Installing drive pinion rear bearing outer race <b>a: 46 mm (1.81 in) dia.</b> <b>b: 110 mm (4.33 in) dia.</b>
ST33022000 ( — ) Drift	Installing drive pinion front bearing outer race <b>a: 49 mm (1.92 in) dia.</b> <b>b: 67 mm (2.63 in) dia.</b>








# PREPARATION

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

Tool number (Kent-Moore No.) Tool name	Description	
— (C-4040) Installer	 SDIA2607E	Installing drive pinion rear bearing inner race  B  C
KV38100300 (J-25523) Drift	 ZZA1046D	Installing side bearing inner race <b>a: 54 mm (2.13 in) dia.</b> <b>b: 46 mm (1.81 in) dia.</b> <b>c: 32mm (1.26 in) dia.</b>  RFD  E

### Commercial Service Tools

EDS0026T

Tool name	Description	
Puller	 NT077	Removing companion flange and side bearing inner race  G  H
Puller	 ZZB0823D	Removing side bearing inner race  I  J  K
Power tool	 PBIC0190E	Loosening bolts and nuts  L  M

# NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

## [M226 WITHOUT ELECTRONIC LOCKING DIFFERENTIAL]

### NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PF0:00003

#### NVH Troubleshooting Chart

EDS0026U

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS												
Noise		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	AXLE SHAFT	BRAKES	STEERING
Reference page		—	<a href="#">RFD-50, "Tooth Contact"</a>	—	<a href="#">RFD-51, "Backlash"</a>	<a href="#">RFD-52, "Companion Flange Runout"</a>	<a href="#">RFD-44, "Checking Differential Gear Oil"</a>	<a href="#">PR-3, "NVH Troubleshooting Chart"</a>	<a href="#">RAX-5, "NVH Troubleshooting Chart"</a> , <a href="#">RSU-4, "NVH Troubleshooting Chart"</a>	<a href="#">WT-4, "NVH Troubleshooting Chart"</a>	<a href="#">RAX-5, "NVH Troubleshooting Chart"</a>	<a href="#">BR-5, "NVH Troubleshooting Chart"</a>	<a href="#">PS-5, "NVH Troubleshooting Chart"</a>	
		x	x	x	x	x	x	x	x	x	x	x	x	x

x: Applicable


**DESCRIPTION**  
**[M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-**

**DESCRIPTION**

PF0:0000

**Cross-Sectional View**

EDS0026V



- 1. Companion flange
- 4. Differential case
- 7. Side gear

- 2. Drive pinion
- 5. Pinion mate gear
- 8. Pinion mate shaft

- 3. Drive gear
- 6. Axle shaft

SDIA2636E

A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

# DIFFERENTIAL GEAR OIL

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-


PF:KLD30

### DIFFERENTIAL GEAR OIL

#### Changing Differential Gear Oil DRAINING

EDS0026W

1. Stop engine.
2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
3. Install the drain plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).




#### FILLING

1. Remove the filler plug from the rear final drive assembly.
2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

**Differential gear oil grade and capacity** : Refer to [MA-11, "Fluids and Lubricants"](#).

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).



#### Checking Differential Gear Oil OIL LEAKAGE AND OIL LEVEL


EDS0026X

1. Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.

#### **CAUTION:**

**Do not start engine while checking differential gear oil level.**

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).



# FRONT OIL SEAL [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

PFP:38189

## FRONT OIL SEAL

EDS0026Y

### Removal and Installation

#### REMOVAL

1. Remove rear propeller shaft. Refer to [PR-10, "Removal and Installation"](#) .
2. Remove brake calipers and rotors. Refer to [BR-29, "Removal and Installation of Brake Caliper and Disc Rotor"](#) .
3. Measure the total preload torque. Refer to [RFD-50, "Total Preload Torque"](#) .

#### NOTE:

Record the total preload torque measurement.

4. Remove the drive pinion lock nut using Tool.

**Tool number** : KV40104000 ( — )

5. Put matching marks on the companion flange and drive pinion using paint.

#### CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.

6. Remove the companion flange using suitable tool.

7. Remove the front oil seal using Tool.

**Tool number** : ST33290001 (J-34286)





#### INSTALLATION

1. Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

**Tool number** : ST15310000 ( — )

#### CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## FRONT OIL SEAL [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

2. Install the companion flange to the drive pinion while aligning the matching marks.
3. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

**Tool number**            **A: KV40104000 ( — )**  
                                 **B: ST3127S000 (J-25765-A)**

**Total preload torque:** Refer to [RFD-50, "Total Preload Torque"](#) .


- The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg-m, 5 in-lb).
- If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg-m, 5ft-lb) increments until the total preload torque is met.

### **CAUTION:**

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
  - Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
  - Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-49, "COMPONENTS"](#) .
  - Do not loosen drive pinion lock nut to adjust the total preload torque. If the total preload torque exceeds the specifications, replace the collapsible spacer and tighten it again to adjust. Refer to [RFD-49, "Disassembly and Assembly"](#) .
  - After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
4. Installation of the remaining components is in the reverse order of removal.

### **CAUTION:**

Check the differential gear oil level after installation. Refer to [RFD-44, "DIFFERENTIAL GEAR OIL"](#) .



# CARRIER COVER

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

PF3:38351

### CARRIER COVER

#### Removal and Installation

##### REMOVAL


EDS0026Z

1. Drain the differential gear oil. Refer to [RFD-44, "DRAINING"](#) .
2. Disconnect the parking brake cable from the carrier cover.
3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

**Tool number** : KV10111100 (J-37228)

#### **CAUTION:**

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



##### INSTALLATION


1. Apply a bead of sealant to the mating surface of the carrier cover as shown.

- Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .

#### **CAUTION:**

**Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.**

2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-49, "COMPONENTS"](#) .
3. Connect the parking brake cable and brake tube to the carrier cover.
4. Fill the rear final drive assembly with recommended differential gear oil. Refer to [RFD-44, "Checking Differential Gear Oil"](#) .



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

### REAR FINAL DRIVE ASSEMBLY

PFP:38300


#### Removal and Installation

##### REMOVAL

EDS00270

##### CAUTION:

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
  - Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
1. Drain the differential gear oil. Refer to [RFD-44, "DRAINING"](#) .
  2. Remove the rear propeller shaft. Refer to [PR-10, "Removal and Installation"](#) .
  3. Remove the axle shaft. Refer to [RAX-7, "Removal and Installation"](#) .
  4. Disconnect the following components from the rear final drive assembly.
    - ABS sensor wire harness. Refer to [BRC-36, "Removal and Installation"](#) (ABS), [BRC-80, "Removal and Installation"](#) (ABLS/ABS) or [BRC-147, "Removal and Installation"](#) (HDC/HSA/VDC/TCS/ABS).
    - Parking brake cable
    - Brake hoses



5. Support rear final drive assembly using a suitable jack.
6. Remove rear shock absorber lower bolts. Refer to [RSU-7, "Removal and Installation"](#) .
7. Remove leaf spring U-bolt nuts. Refer to [RSU-8, "Removal and Installation"](#) .
8. Remove rear final drive assembly.

##### CAUTION:

Secure rear final drive assembly to the jack while removing it.

#### INSTALLATION

Installation is in the reverse order of removal.

##### CAUTION:

- Fill the rear final drive assembly with differential gear oil after installation. Refer to [RFD-44, "Checking Differential Gear Oil"](#) .
- Bleed the air from brake system. Refer to [BR-10, "Bleeding Brake System"](#) .




# REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

EDS00271

## Disassembly and Assembly COMPONENTS

SEC.380



- |                             |   |                                      |
|-----------------------------|---|--------------------------------------|
| 1. Drive pinion lock nut    | 2. Drive pinion nut washer                  | 3. Companion flange                  |
| 4. Front oil seal           | 5. Drive pinion front bearing thrust washer | 6. Drive pinion front bearing washer |
| 7. Gear carrier             | 8. Drain plug                               | 9. Side bearing cap                  |
| 10. Adjuster lock plate     | 11. Carrier cover                           | 12. Filler plug                      |
| 13. Drive pinion            | 14. Drive pinion height adjusting washer    | 15. Drive pinion rear bearing        |
| 16. Collapsible spacer      | 17. Side bearing adjuster                   | 18. Side bearing                     |
| 19. Differential case       | 20. Drive gear                              | 21. Pinion mate thrust washer        |
| 22. Pinion mate gear        | 23. Pinion mate shaft                       | 24. Lock pin                         |
| 25. Side gear thrust washer | 26. Side gear                               | 27. Breather                         |

WDIA0347E

# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

### ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to [RFD-44, "DIFFERENTIAL GEAR OIL"](#) .
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to [RFD-47, "CARRIER COVER"](#) .

#### Total Preload Torque

1. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
2. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
3. Measure total preload torque using Tool.

**Tool number** : ST3127S000 (J-25765-A)


#### Total preload torque

**Gear ratio 3.538 Type:**

2.49 - 4.57 N·m (0.26 - 0.46 kg·m, 22 - 40 in·lb)

**Gear ratio 3.692 Type:**

2.38 - 4.46 N·m (0.25 - 0.45 kg·m, 21 - 39 in·lb)



#### NOTE:

**Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque**

- If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

#### If the total preload torque is greater than specification

**On drive pinion bearings:** Replace collapsible spacer.

**On side bearings:** Loosen side bearing adjuster.

#### If the total preload torque is less than specification

**On drive pinion bearings:** Tighten drive pinion lock nut.

**On side bearings:** Tighten side bearing adjuster.


#### Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

1. Thoroughly clean drive gear and drive pinion teeth.
2. Apply red lead to drive gear.


#### NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.



# REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

3. Hold companion flange steady by hand and rotate drive gear in both directions.



A  
B  
C  
RFD

Usually the pattern will be correct if washers are correctly calculated and the backlash is correct. However, in rare cases, trial and error processes may be employed to obtain a correct pattern. The tooth pattern is the best indication of how well a differential has been set up.

**Heel contact**

**Face contact**

**Toe contact**

**Flank contact**

To correct, increase thickness of drive pinion height adjusting washer in order to bring drive pinion close to drive gear.

To correct, reduce thickness of drive pinion height adjusting washer in order to make drive pinion go away from drive gear.

**Correct tooth contact**

When adjustment is completed, be sure to wipe off completely the red lead and oil or their equivalent.

SDIA2591E

E  
F  
G  
H  
I  
J


4. If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to [RFD-59, "Drive Pinion Height Adjusting Washer"](#) and [RFD-51, "Backlash"](#).

### Backlash

1. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash:**            **0.08 - 0.13 mm (0.0031 - 0.0051 in)**


2. If the backlash is outside of the specification, adjust each side bearing side bearing adjuster.
  - a. Remove adjuster lock plate.
  - b. Loosen side bearing cap bolts.



K  
L  
M

- c. Tighten or loosen each side bearing adjuster using Tool.

**Tool number**        :        —        **(C - 4164)**



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

If the backlash is greater than specification:

Loosen side bearing adjuster A and tighten side bearing adjuster B by the same amount.

If the backlash is less than specification:

Loosen side bearing adjuster B and tighten side bearing adjuster A by the same amount.



**CAUTION:**

Do not change the side bearing side bearing adjusters by different amounts as it will change the side bearing preload torque.

- d. Tighten side bearing cap bolts to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).
- e. Install adjuster lock plate and tighten to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).

**CAUTION:**

Check tooth contact and total preload torque after adjusting side bearing adjuster. Refer to [RFD-50, "Tooth Contact"](#) and [RFD-50, "Total Preload Torque"](#).



### Companion Flange Runout


1. Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.

**Runout limit**

**Companion flange face: 0.10 mm (0.0039 in)**

**Companion flange inner side: 0.13 mm (0.0051 in)**

2. If the runout is outside the runout limit, follow the procedure below to adjust.
  - a. Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
  - b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
  - c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFERENTIAL]

### DISASSEMBLY


#### Differential Assembly

1. Remove carrier cover bolts.
2. Separate carrier cover using Tool.

**Tool number** : KV10111100 (J-37228)

**CAUTION:**

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




3. For proper reinstallation, paint matching mark on one side of side bearing cap.


**CAUTION:**

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.

4. Remove adjuster lock plates.




5. Remove side bearing caps.



6. Remove side bearing adjusters using Tool.


**Tool number** : — (C-4164)



A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-


7. Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
8. Remove side bearing adjusters from gear carrier.



9. Remove side bearing inner races using Tool.

Tool number : ST33081000 ( — )

**CAUTION:**  
Do not damage differential case.




10. For proper reinstallation, paint matching mark on differential case and drive gear.

**CAUTION:**  
Use paint for matching marks. Do not damage differential case or drive gear.


11. Remove drive gear bolts.
12. Tap the drive gear off the differential case using suitable tool.

**CAUTION:**  
Tap evenly all around to keep drive gear from binding.




13. Remove the lock pin of the pinion mate shaft from the drive gear side using Tool.

Tool number : ST23550000 ( — )




14. Remove pinion mate shaft.



# REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

15. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.



A  
B  
C

RFD

## Drive Pinion Assembly


1. Remove differential case assembly. Refer to [RFD-53, "Differential Assembly"](#).
2. Remove drive pinion lock nut and washer using Tool.

**Tool number** : KV40104000 ( — )

3. Put matching marks on the companion flange and drive pinion using paint.


### CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.



E  
F  
G

4. Remove companion flange using suitable tool.



H  
I  
J  
K


5. Remove front oil seal using Tool.

**Tool number** : ST33290001 (J-34286)

### CAUTION:

Do not damage gear carrier.

6. Remove drive pinion front bearing thrust washer.



L  
M


## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

7. Remove drive pinion assembly (with rear inner bearing race and collapsible spacer) out of gear carrier.

**CAUTION:**

**Do not drop drive pinion assembly.**

8. Remove drive pinion front bearing inner race from gear carrier.



9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.


**CAUTION:**

**Do not damage gear carrier.**

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.


**CAUTION:**

**Do not damage gear carrier.**



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

**Tool number : ST30021000 (J-22912-01)**





# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

### INSPECTION AFTER DISASSEMBLY

#### Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

#### Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

#### Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

#### Side Gear Thrust Washer and Pinion Mate Thrust Washer

- If any chips (by friction), damage, or unusual wear are found, replace with new one.

#### Gear Carrier

- If any wear or cracks are found on the contact sides of gear carrier, replace with new one.

#### Companion Flange

- If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

A

B

C

RFD

E

F

G

H

I

J

K

L

M


# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

### SELECTION ADJUSTING WASHERS

#### Side Gear Back Clearance

- Assemble the differential parts if they are disassembled. Refer to [RFD-63, "Differential Assembly"](#).
- Place the differential case straight up so that the side gear to be measured is upward.



- Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

**Side gear back clearance: 0.305 mm (0.0120 in) or less.**

- If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to [RFD-58, "Side Gear Back Clearance"](#).

**If the side gear back clearance is greater than specification:**

**Use a thicker side gear thrust washer.**

**If the side gear back clearance is less than specification:**


**Use a thinner side gear thrust washer.**

#### CAUTION:

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- Select a side gear thrust washer for right and left individually.

#### NOTE:


Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.



# REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

## Drive Pinion Height Adjusting Washer

- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.




- The mounting distance from the center line of drive gear to the back face of drive pinion for the Model 226 final drive assembly is 109.5 mm (4.312 in). On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion inner bearing race and drive pinion. For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what m-8 (-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washers which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.

OLD DRIVE PINION MARKING	NEW DRIVE PINION MARKING mm (in)								
	-10 (-4)	-8 (-3)	-5 (-2)	-3 (-1)	0 (0)	+3 (+1)	+5 (+2)	+8 (+3)	+10 (+4)
+10 (+4)	+0.20 (+0.008)	+0.18 (+0.007)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)
+8 (+3)	+0.18 (+0.007)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)
+5 (+2)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)
+3 (+1)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)
0 (0)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)
-3 (-1)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)
-5 (-2)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)
-8 (-3)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)
-10 (-4)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)	-0.20 (-0.008)


## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

1. Make sure all parts are clean and that drive pinion bearings are well lubricated.
2. Assemble drive pinion bearings into Tools.


<b>Tool number</b>	<b>A:</b>	—	<b>(8144)</b>
	<b>B:</b>	—	<b>(6740)</b>
	<b>C:</b>	—	<b>(6741)</b>



3. Install drive pinion bearing inner race and drive pinion height adjusting washer to gear carrier using Tool as shown.



4. Turn the assembly several times to seat drive pinion bearings.




5. Measure the turning torque using Tool.

**Tool number : ST3127S000 (J-25765-A)**


**Turning torque specification:**

**1.2 - 2.8 N-m (0.13 - 0.28 kg-m, 11 - 24 in-lb)**



6. Tighten side bearing caps to the specified torque installing Tools as shown.

<b>Tool number</b>	<b>A:</b>	—	<b>(6739)</b>
	<b>B:</b>	—	<b>(D-115-2)</b>
	<b>C:</b>	—	<b>(8541A-1)</b>
	<b>D:</b>	—	<b>(D-115-3)</b>






## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

8. Apply multi-purpose grease to new front oil seal lip. Install front oil seal into gear carrier using Tool.

**Tool number** : ST15310000 ( — )

**CAUTION:**


- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lip of the new front oil seal.



9. Install new collapsible spacer to drive pinion. And then install drive pinion assembly in gear carrier.

**CAUTION:**


- Do not reuse collapsible spacer.
- Do not damage front oil seal.



10. Install the companion flange onto the drive pinion while aligning the matching marks. Then tap the companion flange using suitable tool.

**CAUTION:**

**Do not damage companion flange or front oil seal.**



11. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

**Tool number** A: KV40104000 ( — )


B: ST3127S000 (J-25765-A)

**Drive pinion bearing preload torque:**

**1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)**

**CAUTION:**

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-49. "COMPONENTS"](#).
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.




# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-


- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

### Differential Assembly


1. Assemble side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on side gears.
2. Assemble side gear and side gear thrust washer into differential case.



3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and assemble them into differential case after assembling pinion mate thrust washer to pinion mate gear.




4. Align lock pin holes on differential case and shaft, and assemble pinion mate shaft.
5. Measure side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to [RFD-58, "Side Gear Back Clearance"](#).



6. Drive a new lock pin into pinion mate shaft, using Tool.


**Tool number** : ST23550000 ( — )

**CAUTION:**  
Do not reuse lock pin.



## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-

7. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




8. Apply thread locking sealant to the back face of drive gear as shown.


- Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

**Make sure the drive gear back and threaded holes are clean.**



9. Align the matching mark of differential case with the mark of drive gear, then install drive gear.




10. Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.

- Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**


**Make sure the drive gear back and threaded holes are clean.**



11. Install new drive gear bolts, and then tighten to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).

**CAUTION:**

- Do not reuse the bolts.
- Tighten bolts in a crisscross fashion.






# REAR FINAL DRIVE ASSEMBLY

## [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-


12. Press new side bearing inner races to differential case using Tools.

**Tool number**     **A: KV38100300 (J-25523)**  
                              **B: ST33081000 ( — )**


**CAUTION:**  
**Do not reuse side bearing.**



13. Install side bearing adjusters into gear carrier.




14. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into gear carrier.



15. Align paint matching mark on side bearing caps with that on gear carrier and install side bearing caps on gear carrier.

**CAUTION:**  
**Do not tighten at this point. This allows further tightening of side bearing adjusters.**




16. Tighten each side bearing adjusters using Tool.

**Tool number**     :     —     **(C - 4164)**

17. Adjusting backlash of drive gear and drive pinion. Refer to [RFD-51, "Backlash"](#) .

18. Check total preload. Refer to [RFD-50, "Total Preload Torque"](#) .

19. Check tooth contact. Refer to [RFD-50, "Tooth Contact"](#) .



## REAR FINAL DRIVE ASSEMBLY [M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-


20. Apply a bead of sealant to the mating surface of the carrier cover as shown.

- Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

**Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.**

21. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-49, "COMPONENTS"](#).



**SERVICE DATA AND SPECIFICATIONS (SDS)**  
**[M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-**

**SERVICE DATA AND SPECIFICATIONS (SDS)**

PF0:00030

**General Specifications**

EDS00272

Applied model	VQ40DE		
	2WD	4WD	
		King cab	Double cab
Final drive model	6M/T M226		
Gear ratio	3.538	3.692	
Number of pinion gears	2		
Number of teeth (Drive gear / drive pinion)	46/13	48/13	
Oil capacity (Approx.)	2.01 ℓ (4-1/4 US pt, 3-1/2 Imp pt)		
Drive pinion adjustment spacer type	Collapsible		

**Inspection and Adjustment**  
**DIFFERENTIAL SIDE GEAR CLEARANCE**

EDS00273

Unit: mm (in)

Item	Standard
Side gear back clearance (Clearance between side gear and differential case for adjusting side gear backlash)	0.305 (0.0120) or less. (Each gear should rotate smoothly without excessive resistance during differential motion.)

**PRELOAD TORQUE**

Unit: N-m (kg-m, in-lb)

Item	Specification	
	Gear ratio 3.538 type	Gear ratio 3.692 type
Drive pinion bearing preload torque	1.7 - 3.1 (0.18 - 0.31, 15 - 27)	
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.49 - 4.57 (0.26 - 0.46, 22 - 40)	2.38 - 4.46 (0.25 - 0.45, 21 - 39)

**BACKLASH**

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.08 - 0.13 (0.0031 - 0.0051)

**COMPANION FLANGE RUNOUT**

Unit: mm (in)

Item	Runout limit
Companion flange face	0.10 (0.0039) or less
Companion flange inner side	0.13 (0.0051) or less

**SERVICE DATA AND SPECIFICATIONS (SDS)**  
**[M226 WITHOUT ELECTRONIC LOCKING DIFFEREN-**

**SELECTIVE PARTS**

**Drive Pinion Height Adjusting Washer**

Unit: mm (in)

Thickness	Package part number*
0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034)	38151 8S101
0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039)	38151 8S102
0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044)	38151 8S103
0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049)	38151 8S104
0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054)	38151 8S105

\*Always check with the Parts Department for the latest parts information.

**Side Gear Thrust Washer**

Unit: mm (in)

Thickness	Package part number*
0.76 (0.030) 0.79 (0.031) 0.81 (0.032) 0.84 (0.033) 0.86 (0.034)	38424 8S101
0.89 (0.035) 0.91 (0.036) 0.94 (0.037) 0.97 (0.038) 0.99 (0.039)	38424 8S102

\*Always check with the parts department for the latest parts information.

# PRECAUTIONS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EDS00274

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions for Differential Case Assembly and Differential Lock Control Unit Replacement.

EDS003LG

- When replacing differential case assembly or differential lock control unit, check the DIFF LOCK indicator pattern and adjustment of the position between differential case assembly and differential lock control unit if necessary.

### CHECK DIFF LOCK INDICATOR LAMP

1. Start engine. Run engine for at least 10 seconds.
2. Turn 4WD shift switch to "4LO" and confirm 4LO indicator lamp is turned on. Refer to [TF-16, "4WD SHIFT SWITCH AND INDICATOR LAMP"](#).
3. Stop vehicle and turn differential lock mode switch to "ON".
4. Drive vehicle at 7 km/h (4MPH) or less.

**NOTE:**

Differential case assembly must be given a rotation from rear left wheel and rear right wheel.

5. Check if DIFF LOCK indicator lamp flashes to turn on.
6. Check if DIFF LOCK indicator lamp and 4LO indicator lamp are changed properly as follows.

Differential lock mode switch	4LO indicator lamp	Vehicle speed (VSS)	Differential case assembly state	DIFF LOCK indicator lamp
ON	OFF	7km/h (4 MPH) < VSS	Disengage	Flash
		VSS ≤ 7 km/h (4 MPH)		
	ON	7km/h (4 MPH) < VSS	Disengage → Engage	Flash → ON
		VSS ≤ 7 km/h (4 MPH)		
OFF	OFF	7km/h (4 MPH) < VSS	Disengage	OFF
		VSS ≤ 7 km/h (4 MPH)		
	ON	7km/h (4 MPH) < VSS	Disengage	OFF
		VSS ≤ 7 km/h (4 MPH)		

- If each indication and state is OK, rear final drive assembly and differential lock control unit is working correctly.
- If each indication and state is NG, rear final drive assembly and differential lock control unit is not working correctly. Refer to [RFD-70, "METHOD FOR ADJUSTMENT"](#).

# PRECAUTIONS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


### METHOD FOR ADJUSTMENT

1. Perform erase self-diagnosis with differential lock control unit. Refer to [RFD-89, "How to Erase Self-diagnostic Results"](#) .
2. Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .
3. Check DIFF LOCK indicator lamp. Refer to [RFD-79, "DIFF LOCK INDICATOR LAMP"](#) .
  - If DIFF LOCK indicator lamp is not proper according to the above patterns.  
Install new differential lock control unit or check for mechanical malfunction of rear final drive assembly and retry the above (DIFF LOCK indicator lamp) check.  
(If differential lock control unit or rear final drive assembly is replaced from another vehicle, the new differential control unit must be replaced first.)


### Precautions

EDS00275


- **Before connecting or disconnecting differential lock control unit harness connector, turn ignition switch "OFF" and disconnect the battery cable from the negative terminal. Because battery voltage is applied to differential lock control unit even if ignition switch is turned "OFF".**



- **When connecting or disconnecting pin connectors into or from differential lock control unit, take care not to damage pin terminals (bend or break). When connecting pin connectors make sure that there are not any bends or breaks on differential lock control unit pin terminal.**



- **Before replacing differential lock control unit, perform differential lock control unit input/output signal inspection and make sure whether differential lock control unit functions properly or not. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .**



### Precautions for Servicing Rear Final Drive

EDS0046R

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.

## PRECAUTIONS

### [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

---

- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

A

B

C

RFD

E

F

G

H

I

J

K

L

M

# PREPARATION [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]







PFP:00002

## PREPARATION

### Special Service Tools

EDS00278








The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV40104000 ( — ) Flange wrench <div style="text-align: center;">  <p style="text-align: center;">NT659</p> </div>	Removing and installing drive pinion nut <b>a: 85 mm (3.35 in) dia.</b> <b>b: 65 mm (2.56 in) dia.</b>
ST33290001 (J-34286) Puller <div style="text-align: center;">  <p style="text-align: center;">ZZA0601D</p> </div>	Removing front oil seal
ST15310000 ( — ) Drift <div style="text-align: center;">  <p style="text-align: center;">NT115</p> </div>	Installing front oil seal <b>a: 96mm (3.77 in) dia.</b> <b>b: 84 mm (3.30 in) dia.</b>
ST3127S000 (J-25765-A) Preload gauge set 1. GG91030000 (J-25765) Torque wrench 2. HT62940000 (1/2") ( — ) Socket adapter 3. HT62900000 (3/8") ( — ) Socket adapter <div style="text-align: center;">  <p style="text-align: center;">NT124</p> </div>	Inspecting drive pinion bearing preload and total preload
— (C - 4164) Adjuster tool <div style="text-align: center;">  <p style="text-align: center;">WDIA0192E</p> </div>	Removing and installing side bearing ad- juster
KV10111100 (J-37228) Seal cutter <div style="text-align: center;">  <p style="text-align: center;">S-NT046</p> </div>	Removing carrier cover










# PREPARATION

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Tool number (Kent-Moore No.) Tool name	Description	
ST30021000 (J-22912-01) Puller	 ZZA0700D	A B C
ST33081000 ( — ) Adapter	 ZZA1000D	<b>RFD</b> E
— (8144) Pinion block	 SDIA2599E	F G
— (6740) Cone	 SDIA2601E	H I J
— (6741) Screw	 SDIA2602E	K L
— (6739) Pinion height lock	 SDIA2603E	M
— (D-115-2) Scooter block	 SDIA2604E	




# PREPARATION [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Tool number (Kent-Moore No.) Tool name	Description
<p>— (8541A-1) Arbor disc</p>  <p style="text-align: right;">SDIA2605E</p>	Adjusting pinion gear height
<p>— (D-115-3) Arbor</p>  <p style="text-align: right;">SDIA2606E</p>	Adjusting pinion gear height
<p>ST01500001 ( — ) Drift</p>  <p style="text-align: right;">ZZA0811D</p>	Installing drive pinion rear bearing outer race <b>a: 89mm (3.50 in) dia.</b> <b>b: 79 mm (3.11 in) dia.</b>
<p>ST30022000 ( — ) Drift</p>  <p style="text-align: right;">NT660</p>	Installing drive pinion rear bearing outer race <b>a: 46 mm (1.81 in) dia.</b> <b>b: 110 mm (4.33 in) dia.</b>
<p>ST33022000 ( — ) Drift</p>  <p style="text-align: right;">NT660</p>	Installing drive pinion front bearing outer race <b>a: 49 mm (1.92 in) dia.</b> <b>b: 67 mm (2.63 in) dia.</b>
<p>— (C-4040) Installer</p>  <p style="text-align: right;">SDIA2607E</p>	Installing drive pinion rear bearing inner race
<p>KV38100300 (J-25523) Drift</p>  <p style="text-align: right;">ZZA1046D</p>	Installing side bearing inner race <b>a: 54 mm (2.13 in) dia.</b> <b>b: 46 mm (1.81 in) dia.</b> <b>c: 32mm (1.26 in) dia.</b>

# PREPARATION [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## Commercial Service Tools

EDS00279

Tool name	Description
Puller   NT077	Removing companion flange and side bearing inner race
Puller   ZZB0823D	Removing side bearing inner race
Power tool   PBIC0190E	Loosening bolts and nuts

A  
B  
C  
**RFD**  
E  
F  
G  
H  
I  
J  
K  
L  
M

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PF0:00003

### NVH Troubleshooting Chart

EDS0027A

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS												
		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	AXLE SHAFT	BRAKES	STEERING
Reference page	Noise	×	×	×	×	×	×	×	×	×	×	×	×	×
		—	<a href="#">RFD-116, "Tooth Contact"</a>	—	<a href="#">RFD-117, "Backlash"</a>	<a href="#">RFD-118, "Companion Flange Runout"</a>	<a href="#">RFD-77, "Checking Differential Gear Oil"</a>	<a href="#">PR-3, "NVH Troubleshooting Chart"</a>	<a href="#">RAX-5, "NVH Troubleshooting Chart", RSU-4, "NVH Troubleshooting Chart"</a>	<a href="#">WT-4, "NVH Troubleshooting Chart"</a>	<a href="#">RAX-5, "NVH Troubleshooting Chart"</a>	<a href="#">BR-5, "NVH Troubleshooting Chart"</a>	<a href="#">PS-5, "NVH Troubleshooting Chart"</a>	

×: Applicable

# DIFFERENTIAL GEAR OIL

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


### DIFFERENTIAL GEAR OIL

PPF:KLD30

### Changing Differential Gear Oil DRAINING

EDS0027B

1. Stop engine.
2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
3. Install the drain plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).




### FILLING

1. Remove the filler plug from the rear final drive assembly.
2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

**Differential gear oil grade and capacity** : Refer to [MA-11, "Fluids and Lubricants"](#).

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).



### Checking Differential Gear Oil DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL


EDS0027C

1. Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.

#### **CAUTION:**

**Do not start engine while checking differential gear oil level.**

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).
  - Use High Performance Thread Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).




# DIFFERENTIAL LOCK SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## DIFFERENTIAL LOCK SYSTEM

PF2:28496

### Cross-sectional View

EDS0027D



SDIA2519E


- |                       |                     |                                       |
|-----------------------|---------------------|---------------------------------------|
| 1. Companion flange   | 2. Drive pinion     | 3. Drive gear                         |
| 4. Differential case  | 5. Pinion mate gear | 6. Axle shaft                         |
| 7. Side gear          | 8. Spring           | 9. Differential lock solenoid         |
| 10. Pinion mate shaft | 11. Pressure plate  | 12. Differential lock position switch |
| 13. Cam ring          |                     |                                       |

# DIFFERENTIAL LOCK SYSTEM

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### Differential Lock Operation

EDS0027E



1. Differential lock solenoid operates pressure plate.
2. Pressure plate presses cam ring.
3. Engage cam ring and side gear, and then differential is locked.

### System Description

EDS0027F

#### DIFFERENTIAL LOCK SOLENOID

It is operated by signal from differential lock control unit, and it operates pressure plate so as to switch lock/unlock.

#### DIFFERENTIAL LOCK POSITION SWITCH

It detects that differential is in lock or unlock by pressure plate position, and sends it to differential lock control unit.

#### DIFFERENTIAL LOCK CONTROL UNIT

- Differential lock control unit controls differential lock solenoid by input signals of each sensor and each switch.
- As a fail-safe function, differential lock disengages, if malfunction is detected in differential lock system.
- Self-diagnosis can be done with CONSULT-II.

#### DIFFERENTIAL LOCK MODE SWITCH

Able to select differential lock and unlock.

#### DIFF LOCK INDICATOR LAMP

The following is the indications of indicator lamp.

Condition	DIFF LOCK indicator lamp
Differential lock/unlock	ON/OFF
Differential lock standby condition	Flashing: 1 time/2 seconds
Differential lock system malfunction	OFF (Even if differential lock mode switch is turned ON)
Lamp check	Turns ON when ignition switch is turned ON. Turns OFF after engine start.


#### NOTE:

Differential lock standby condition is the condition that differential lock mode switch is ON and differential is unlocked.

# DIFFERENTIAL LOCK SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## System Diagram

EDS0027G



## COMPONENTS FUNCTION DESCRIPTION

Component parts	Function
Differential lock control unit	<ul style="list-style-type: none"> <li>● Controls differential lock solenoid and switches differential lock/unlock.</li> <li>● As a fail-safe function, differential lock disengages, if malfunction is detected in differential lock system.</li> </ul>
Differential lock solenoid	Controls pressure plate by current from differential lock control unit.
Differential lock position switch	Detects that differential is lock or unlock condition.
Differential lock mode switch	Able to select differential lock or unlock.
DIFF LOCK indicator lamp	Illuminates that differential is in lock or lock standby condition.
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication to differential lock control unit. <ul style="list-style-type: none"> <li>● Vehicle speed signal</li> <li>● VDC operation signal</li> </ul>
Transfer control unit	Transmits the following signal via CAN communication to differential lock control unit. <ul style="list-style-type: none"> <li>● 4WD shift switch signal</li> </ul>

## CAN Communication SYSTEM DESCRIPTION

EDS0027H

Refer to [LAN-4, "SYSTEM DESCRIPTION"](#) .



# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

PFP:00004

### TROUBLE DIAGNOSIS

#### Fail-safe Function

EDS0027I

If any malfunction occurs in the differential lock system, and the control unit detects the malfunction, the DIFF LOCK indicator lamp on the combination meter does not turn ON to indicate system malfunction. The differential lock control unit turns the differential lock solenoid OFF.

#### How to Perform Trouble Diagnosis

EDS0027J


##### BASIC CONCEPT

- To perform trouble diagnosis, it is most important to have understanding about the vehicle systems (control and mechanism) thoroughly.
- It is also important to clarify customer complaints before inspection.


First of all, reproduce symptoms, and understand them fully. Ask customer about his/her complaints carefully. In some cases, it will be necessary to check symptoms by driving vehicle with customer.

##### CAUTION:

**Customers are not professional. It is dangerous to make an easy guess like "maybe the customer means that...," or "maybe the customer mentions this symptom".**



- It is essential to check symptoms right from the beginning in order to repair malfunctions completely. For intermittent malfunctions, reproduce symptoms based on interview with customer and past examples. Do not perform inspection on ad hoc basis. Most intermittent malfunctions are caused by poor contacts. In this case, it will be effective to shake suspected harness or connector by hand. When repairing without any symptom diagnosis, you cannot judge if malfunctions have actually been eliminated.
- After completing diagnosis, always erase diagnostic memory. Refer to [RFD-89, "How to Erase Self-diagnostic Results"](#).
- For intermittent malfunctions, move harness or harness connector by hand. Then check for poor contact or reproduced open circuit.





A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### Location of Electrical Parts

EDS0027K





# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027L

### Wiring Diagram — DIFLOC —

### RFD-DIFLOC-01





REFER TO THE FOLLOWING.

- M31 - SUPER MULTIPLE JUNCTION (SMJ)
- E125 - ELECTRICAL UNITS


BDWA0078E

# TROUBLE DIAGNOSIS [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


RFD-DIFLOC-02



M22  
W



M70  
W



REFER TO THE FOLLOWING.  
 (M31), (C1) - SUPER  
 MULTIPLE JUNCTION (SMJ)

BDWA0054E

# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### Trouble Diagnosis Chart for Symptoms

EDS0027M

With the Differential Mode Switch in the ON position, if the DIFF LOCK indicator lamp does not turn ON after the engine starts, perform self-diagnosis. Refer to [RFD-88, "SELF-DIAG RESULTS MODE"](#).

Symptom	Condition	Check item	Reference page
DIFF LOCK indicator lamp does not turn ON. (DIFF LOCK indicator lamp check)	Ignition switch: ON	CAN communication line	<a href="#">RFD-104</a>
		Power supply and ground for differential lock control unit	
		Combination meter	
DIFF LOCK indicator lamp does not change.	<ul style="list-style-type: none"> <li>● Engine running</li> <li>● Differential lock mode switch: ON</li> </ul>	Combination meter	<a href="#">RFD-107</a>
		Differential lock mode switch	
		CAN communication line	
DIFF LOCK indicator lamp sometimes flashes.	<ul style="list-style-type: none"> <li>● Engine running</li> <li>● Differential lock mode switch: ON</li> </ul>	Combination meter	<a href="#">RFD-108</a>
		Differential lock mode switch	
		Differential lock position switch	
		Differential inner parts	

### Differential Lock Control Unit Input/Output Signal Reference Values

#### DIFFERENTIAL LOCK CONTROL UNIT INSPECTION TABLE

EDS0027N

#### Specifications with CONSULT-II


Monitor item [Unit]	Content	Condition	Display value
BATTERY VOLT [V]	Power supply voltage for differential lock control unit	Ignition switch: ON	Battery voltage
4WD MODE [2H/4H/4Lo]	Condition of 4WD shift switch	4WD shift switch (Engine running)	2WD
			4H
			4Lo
VHCL S/SEN-R [km/h] or [mph]	Wheel speed (Rear wheel right)	Vehicle stopped	0 km/h (0 mph)
		Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approximately equal to the indication on speedometer (Inside of ±10%)
VHCL S/SEN-L [km/h] or [mph]	Wheel speed (Rear wheel left)	Vehicle stopped	0 km/h (0 mph)
		Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approximately equal to the indication on speedometer (Inside of ±10%)
VHCL S/SEN-RL [km/h] or [mph]	Wheel speed (Average value of rear wheel right and left)	Vehicle stopped	0 km/h (0 mph)
		Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approximately equal to the indication on speedometer (Inside of ±10%)
D-LOCK SW SIG [ON/OFF]	Condition of differential lock mode switch	Differential lock mode switch: ON	ON
		Differential lock mode switch: OFF	OFF
D-LOCK SIG [ON/OFF]	Control status of differential lock	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON
		Differential lock mode switch: OFF	OFF

## TROUBLE DIAGNOSIS [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Monitor item [Unit]	Content	Condition		Display value
RELAY ON [ON/OFF]	Operating condition of differential lock solenoid relay (integrated in differential lock control unit)	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	ON
			Differential lock mode switch: OFF	OFF
RELAY MTR [ON/OFF]	Control status of differential lock solenoid relay (integrated in differential lock control unit)	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	ON
			Differential lock mode switch: OFF	OFF
SOL MTR [ON/OFF]	Control status of differential lock solenoid	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	ON
			Differential lock mode switch: OFF	OFF
IND MTR [ON/OFF]	Control status of DIFF LOCK indicator lamp		DIFF LOCK indicator lamp: ON	ON
			DIFF LOCK indicator lamp: OFF	OFF
D-LOCK POS SW [ON/OFF]	Condition of differential lock position switch	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON (DIFF LOCK indicator lamp: ON)	ON
			Differential lock mode switch: OFF (DIFF LOCK indicator lamp: OFF)	OFF

### Specifications Between Differential Lock Control Unit Terminals

#### DIFFERENTIAL LOCK CONTROL UNIT TERMINAL CONNECTOR LAYOUT



Data are reference value and are measured between each terminal and ground.

Terminal	Wire color	Item	Condition		Data (Approx.)
1	W/G	Power supply	Ignition switch: ON		Battery voltage
			Ignition switch: OFF		0V
2	W/G	Power supply	Ignition switch: ON		Battery voltage
			Ignition switch: OFF		0V
3	B	Ground	Always		0V
4	P	CAN-L	-		-
5	L	CAN-H	-		-
9	Y	Differential lock mode switch (ON)	Ignition switch: ON	Differential lock mode switch: ON	Battery voltage
				Differential lock mode switch: OFF	0V

# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Terminal	Wire color	Item	Condition	Data (Approx.)	
10	B	Ground	Always	0V	
11	GR	Differential lock solenoid (-)	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	0V
				Differential lock mode switch: OFF	Battery voltage
12	L	Differential lock solenoid (+)	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	Battery voltage
				Differential lock mode switch: OFF	0V
13	SB	K-LINE (CONSULT-II signal)	-	-	
15	R/Y	Power supply (Memory back-up)	Ignition switch: ON	Battery voltage	
			Ignition switch: OFF	Battery voltage	
20	BR	Differential lock position switch	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON (DIFF LOCK indicator lamp: ON)	0V
				Differential lock mode switch: OFF (DIFF LOCK indicator lamp: OFF)	Battery voltage
21	SB	DIFF LOCK indicator lamp	Ignition switch: ON	DIFF LOCK indicator lamp: ON	0V
				DIFF LOCK indicator lamp: OFF	Battery voltage
22	G	Differential lock mode switch (OFF)	Ignition switch: ON	Differential lock mode switch: ON	0V
				Differential lock mode switch: OFF	Battery voltage

**CAUTION:**

When using a circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.

### CONSULT-II Function (DIFF LOCK) FUNCTION

EDS00270

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


DIFF LOCK diagnostic mode	Description
SELF-DIAG RESULTS	Displays differential lock control unit self-diagnosis results.
DATA MONITOR	Displays differential lock control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

### CONSULT-II SETTING PROCEDURE

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


- For details, refer to the separate "CONSULT-II Operations Manual".
1. Turn ignition switch OFF.
  2. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector on vehicle.
  3. Turn ignition switch ON.




# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

4. Touch "START (NISSAN BASED VHCL)".



5. Touch "DIFF LOCK".  
If "DIFF LOCK" is not indicated, go to [GI-40, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
6. Perform each diagnostic test mode according to each service procedure.




### SELF-DIAG RESULTS MODE

#### Operation Procedure

- Perform "CONSULT-II SETTING PROCEDURE". Refer to [RFD-87, "CONSULT-II SETTING PROCEDURE"](#).
- With engine at idle, touch "SELF-DIAG RESULTS".  
Display shows malfunction experienced since the last erasing operation.

**NOTE:**

- The details for "TIME" are as follow:
  - "0": Error currently detected with differential lock control unit.
  - Except for "0": Error detected in the past and memorized with differential lock control unit.  
Detects frequency of driving after DTC occurs (frequency of turning ignition switch "ON/OFF").



#### Display Item List

Items (CONSULT-II screen terms)	Diagnostic item is detected when...	Check item
*INITIAL START* [P1833]	● Due to removal of battery which cuts off power supply to differential control unit, self-diagnosis memory function is suspended.	<a href="#">RFD-91, "Power Supply Circuit For Differential Lock Control Unit"</a>
CONTROL UNIT 1 [P1834]	● Malfunction is detected in the memory (RAM) system of differential lock control unit.	<a href="#">RFD-92, "Differential Lock Control Unit"</a>
CONTROL UNIT 2 [P1835]	● Malfunction is detected in the memory (ROM) system of differential lock control unit.	<a href="#">RFD-92, "Differential Lock Control Unit"</a>
CONTROL UNIT 3 [P1836]	● Malfunction is detected in the memory (EEPROM) system of differential lock control unit.	<a href="#">RFD-92, "Differential Lock Control Unit"</a>
CONTROL UNIT 4 [P1837]	● AD converter system of differential lock control unit is malfunctioning.	<a href="#">RFD-92, "Differential Lock Control Unit"</a>
ON SW [P1838]	● More than two switch inputs are simultaneously detected due to short circuit of differential lock mode switch.	<a href="#">RFD-93, "Differential Lock Mode Switch"</a>



## TROUBLE DIAGNOSIS

### [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Items (CONSULT-II screen terms)	Diagnostic item is detected when...	Check item
POSI SW ON [P1839]	<ul style="list-style-type: none"> <li>When differential lock position switch is ON, rotation difference occurs in wheel speed (rear wheel right and left).</li> </ul>	<a href="#">RFD-96, "Differential Lock Position Switch"</a>
RELAY [P1844]	<ul style="list-style-type: none"> <li>Differential lock control unit detects as irregular by comparing target value with monitor value.</li> </ul>	<a href="#">RFD-98, "Differential Lock Solenoid Relay"</a> , <a href="#">RFD-99, "Differential Lock Solenoid"</a>
SOL CIRCUIT [P1847]	<ul style="list-style-type: none"> <li>Malfunction is detected in differential lock control unit internal circuit.</li> </ul>	<a href="#">RFD-99, "Differential Lock Solenoid"</a>
SOL DISCONNECT [P1848]	<ul style="list-style-type: none"> <li>Differential lock solenoid internal circuit or harness is open.</li> <li>Differential lock solenoid relay does not switch to ON position.</li> </ul>	<a href="#">RFD-99, "Differential Lock Solenoid"</a>
SOL SHORT [P1849]	<ul style="list-style-type: none"> <li>Differential lock solenoid internal circuit or harness is shorted.</li> </ul>	<a href="#">RFD-99, "Differential Lock Solenoid"</a>
SOL CURRENT [P1850]	<ul style="list-style-type: none"> <li>Differential lock solenoid relay does not switch to OFF position.</li> </ul>	<a href="#">RFD-99, "Differential Lock Solenoid"</a>
ABS SYSTEM [C1203]	<ul style="list-style-type: none"> <li>Malfunction related to wheel sensor has been detected by ABS actuator and electric unit (control unit).</li> </ul>	<a href="#">RFD-102, "ABS System"</a>
CAN COMM CIRCUIT [U1000]	<ul style="list-style-type: none"> <li>Malfunction has been detected from CAN communication line.</li> </ul>	<a href="#">RFD-103, "CAN Communication Line"</a>
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	<ul style="list-style-type: none"> <li>No NG item has been detected.</li> </ul>	—

**CAUTION:**

If "CAN COMM CIRCUIT [U1000]" is displayed with other DTCs, first perform the trouble diagnosis for CAN communication line.

#### How to Erase Self-diagnostic Results

1. Perform inspection of malfunctioning item and then repair or replace.
2. Start engine and select "SELF-DIAG RESULTS" mode for "DIFF LOCK" with CONSULT-II.
3. Touch "ERASE" on CONSULT-II screen to erase DTC memory.

**CAUTION:**

If memory cannot be erased, perform diagnosis.

# TROUBLE DIAGNOSIS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### DATA MONITOR MODE

#### Operation Procedure

1. Perform "CONSULT-II SETTING PROCEDURE". Refer to [RFD-87, "CONSULT-II SETTING PROCEDURE"](#).
2. Touch "DATA MONITOR".
3. Select from "SELECT MONITOR ITEM", screen of data monitor mode is displayed.

**NOTE:**

**When malfunction is detected, CONSULT-II performs REAL-TIME DIAGNOSIS.  
Also, any malfunction detected while in this mode will be displayed at real time.**

#### Display Item List

×: Standard    -: Not applicable

Monitor item (Unit)	SELECT MONITOR ITEM			Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
BATTERY VOLT [V]	×	×	×	Power supply voltage for differential lock control unit.
4WD MODE [2H/4H/4Lo]	×	×	×	4WD shift switch signal status via CAN communication line is displayed.
VHCL S/SEN-R [km/h] or [mph]	×	-	×	Wheel speed calculated by rear wheel sensor right signal is displayed.
VHCL S/SEN-L [km/h] or [mph]	×	-	×	Wheel speed calculated by rear wheel sensor left signal is displayed.
VHCL S/SEN-RL [km/h] or [mph]	×	×	×	Average value between wheel speed calculated by rear wheel sensor right signal and rear wheel sensor left signal is displayed.
D-LOCK SW SIG [ON/OFF]	×	×	×	Condition of differential lock mode switch is displayed.
D-LOCK SIG [ON/OFF]	×	×	×	Control status of differential lock is displayed.
RELAY ON [ON/OFF]	×	×	×	Operating condition of differential lock solenoid relay is displayed (integrated in differential lock control unit).
RELAY MTR [ON/OFF]	×	×	×	Control status of differential lock solenoid relay is displayed (integrated in differential lock control unit).
SOL MTR [ON/OFF]	×	×	×	Control status of differential lock solenoid is displayed.
IND MTR [ON/OFF]	×	×	×	Control status of DIFF LOCK indicator lamp is displayed.
D-LOCK POS SW [ON/OFF]	×	×	×	Condition of differential lock position switch is displayed.
Voltage [V]	-	-	×	The value measured by the voltage probe is displayed.
Frequency [Hz]	-	-	×	The value measured by the pulse probe is displayed.
DUTY-HI (high) [%]	-	-	×	
DUTY-LOW (low) [%]	-	-	×	
PLS WIDTH-HI [msec]	-	-	×	
PLS WIDTH-LOW [msec]	-	-	×	

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## TROUBLE DIAGNOSIS FOR SYSTEM

PFP:00000


### Power Supply Circuit For Differential Lock Control Unit DIAGNOSTIC PROCEDURE

EDS0027P

#### 1. CHECK POWER SUPPLY


1. Turn ignition switch OFF.
2. Disconnect differential lock control unit harness connector.
3. Check voltage between differential lock control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M70	1 - Ground	0V
	2 - Ground	0V
	15 - Ground	Battery voltage



4. Turn ignition switch ON. (Do not start engine.)
5. Check voltage between differential lock control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M70	1 - Ground	Battery voltage
	2 - Ground	
	15 - Ground	



#### OK or NG

OK >> GO TO 2.

NG >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuse [No. 3 or 19, located in fuse block (J/B)]
- Harness for short or open between battery and differential lock control unit harness connector terminal 15
- Harness for short or open between ignition switch and differential lock control unit harness connector terminals 1 and 2
- Battery and ignition switch. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

#### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between differential lock control unit harness connector M70 terminals 3, 10 and ground.


**Continuity should exist.**

Also check harness for short to ground and short to power.

#### OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



# TROUBLE DIAGNOSIS FOR SYSTEM

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

---

### 3. CHECK DIFFERENTIAL LOCK CONTROL UNIT

---

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

#### OK or NG

- OK >> GO TO 4.
- NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

### 4. CHECK DTC

---

Perform the self-diagnosis, after driving the vehicle for a while.

#### OK or NG

- OK >> Inspection End.
- NG >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#) .

## Differential Lock Control Unit DIAGNOSTIC PROCEDURE

EDS00270

### 1. PERFORM SELF-DIAGNOSIS

---

#### Ⓟ With CONSULT-II

1. Turn ignition switch ON. (Do not start engine.)
2. Select "SELF-DIAG RESULTS" mode for "DIFF LOCK" with CONSULT-II.
3. Touch "ERASE".
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Perform the self-diagnosis again.

Is the "CONTROL UNIT 1 [P1834]", "CONTROL UNIT 2 [P1835]", "CONTROL UNIT 3 [P1836]" or "CONTROL UNIT 4 [P1837]" displayed?

- YES >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#) .
- NO >> Inspection End.

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027R


## Differential Lock Mode Switch DIAGNOSTIC PROCEDURE

### 1. CHECK DIFFERENTIAL LOCK MODE SWITCH SIGNAL

#### Ⓜ With CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode for "DIFF LOCK" with CONSULT-II.
3. Read out ON/OFF switching action of "D-LOCK SW SIG".


Monitor item	Condition		Display value
D-LOCK SW SIG	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> </ul>	Differential lock mode switch: ON	ON
		Differential lock mode switch: OFF	OFF



#### ⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between differential lock control unit harness connector terminals and ground.

Connector	Terminal	Condition	Voltage (Approx.)
M70	9 - Ground	Differential lock mode switch: ON	Battery voltage
		Differential lock mode switch: OFF	0V
	22 - Ground	Differential lock mode switch: ON	0V
		Differential lock mode switch: OFF	Battery voltage



#### OK or NG


- OK >> GO TO 5.  
NG >> GO TO 2.

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## 2. CHECK DIFFERENTIAL LOCK MODE SWITCH SUPPLY CIRCUIT


1. Turn ignition switch ON.
2. Disconnect differential lock mode switch harness connector.
3. Check voltage between differential lock mode switch harness connector terminal 3 and ground.

Connector	Terminal	Voltage (Approx.)
M149	3 - Ground	Battery voltage



4. Turn ignition switch OFF.
5. Check voltage between differential lock mode switch harness connector terminal 3 and ground.

Connector	Terminal	Voltage (Approx.)
M149	3 - Ground	0V



### OK or NG

OK >> GO TO 3.

NG >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuse [No. 3, located in fuse block (J/B)]
- Harness for short or open between ignition switch and differential lock mode switch harness connector terminal 3
- Ignition switch. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

## 3. CHECK DIFFERENTIAL LOCK MODE SWITCH


1. Turn ignition switch OFF.
2. Operate differential lock mode switch and check continuity between differential lock mode switch terminals.

Terminal	Condition	Continuity
1 - 3	Differential lock mode switch: ON	No
	Differential lock mode switch: OFF	Yes
2 - 3	Differential lock mode switch: ON	Yes
	Differential lock mode switch: OFF	No

### OK or NG

OK >> GO TO 4.

NG >> Replace differential lock mode switch.



# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## 4. CHECK HARNESS BETWEEN DIFFERENTIAL LOCK CONTROL UNIT AND DIFFERENTIAL LOCK MODE SWITCH


1. Disconnect differential lock control unit harness connector.
2. Check continuity between the following terminals.
  - Differential lock control unit harness connector M70 terminal 9 and differential lock mode switch harness connector M149 terminal 2.
  - Differential lock control unit harness connector M70 terminal 22 and differential lock mode switch harness connector M149 terminal 1.

**Continuity should exist.**

Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.  
 NG >> Repair or replace damaged parts.



## 5. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 6.  
 NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

## 6. CHECK DTC

Perform the self-diagnosis, after driving the vehicle for a while.

OK or NG


- OK >> Inspection End.  
 NG >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#).

## COMPONENT INSPECTION

1. Turn ignition switch OFF.
2. Operate differential lock mode switch and check continuity between differential lock mode switch terminals.

Terminal	Condition	Continuity
1 - 3	Differential lock mode switch: ON	No
	Differential lock mode switch: OFF	Yes
2 - 3	Differential lock mode switch: ON	Yes
	Differential lock mode switch: OFF	No

3. If NG, replace differential lock mode switch.



# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027S


## Differential Lock Position Switch DIAGNOSTIC PROCEDURE

### 1. CHECK DIFFERENTIAL LOCK POSITION SWITCH SIGNAL

#### Ⓟ With CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode for "DIFF LOCK" with CONSULT-II.
3. Read out ON/OFF switching action of "D-LOCK POS SW SIG".


Monitor item	Condition	Display value
D-LOCK POS SW SIG	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> </ul>	Differential lock mode switch: ON (DIFF LOCK indicator lamp: ON)
	<ul style="list-style-type: none"> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: OFF (DIFF LOCK indicator lamp: OFF)



#### ⓧ Without CONSULT-II

1. Start engine.
2. Check voltage between differential lock control unit harness connector terminal and ground.

Connector	Terminal	Condition	Voltage (Approx.)
M70	20 - Ground	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> </ul>	0V
		<ul style="list-style-type: none"> <li>● 4WD shift switch: 4LO</li> </ul>	Battery voltage



OK or NG

- OK    >> GO TO 5.  
NG    >> GO TO 2.

### 2. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect differential lock position switch harness connector.
3. Check continuity between differential lock position switch harness connector C116 terminal 1 and ground.

**Continuity should exist.**

Also check harness for short to ground and short to power.

OK or NG

- OK    >> GO TO 3.  
NG    >> Repair open circuit or short to ground or short to power in harness or connectors.






# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## 3. CHECK DIFFERENTIAL LOCK POSITION SWITCH

### With CONSULT-II

- Turn ignition switch ON.
- Select "DATA MONITOR" mode for "DIFF LOCK" with CONSULT-II.
- Read out ON/OFF switching action of "D-LOCK POS SW SIG" while connecting and disconnecting jumper wire between differential lock position switch harness connector C116 terminals 1 and 3.


Monitor item	Condition	Display value
D-LOCK POS SW SIG	Jumper wire connected	ON
	Jumper wire disconnected	OFF



### Without CONSULT-II

- Turn ignition switch ON.
- Check voltage between differential lock control unit harness connector terminal and ground while connecting and disconnecting jumper wire between differential lock position switch harness connector C116 terminals 1 and 3.

Connector	Terminal	Condition	Voltage (Approx.)
M70	20 - Ground	Jumper wire connected	0V
		Jumper wire disconnected	Battery voltage



#### OK or NG

- OK >> Replace differential lock position switch.  
 NG >> GO TO 4.

## 4. CHECK HARNESS BETWEEN DIFFERENTIAL LOCK CONTROL UNIT AND DIFFERENTIAL LOCK POSITION SWITCH


- Turn ignition switch OFF.
- Disconnect differential lock control unit harness connector.
- Check continuity between differential lock control unit harness connector M70 terminal 20 and differential lock position switch harness connector C116 terminal 3.

**Continuity should exist.**

Also check harness for short to ground and short to power.

#### OK or NG

- OK >> GO TO 5.  
 NG >> Repair or replace damaged parts.



# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## 5. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

### OK or NG

- OK >> GO TO 6.
- NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

## 6. CHECK DTC

Perform the self-diagnosis, after driving the vehicle for a while.

### OK or NG

- OK >> Inspection End.
- NG >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#) .

## Differential Lock Solenoid Relay DIAGNOSTIC PROCEDURE

EDS0027T

### 1. CHECK DIFFERENTIAL LOCK SOLENOID SYSTEM

Perform self-diagnosis. Refer to [RFD-88, "SELF-DIAG RESULTS MODE"](#) .

Is "RELAY [P1844]" displayed?


- YES >> Perform trouble diagnosis for differential lock solenoid. Refer to [RFD-99, "Differential Lock Solenoid"](#) .
- NO >> GO TO 2.

### 2. CHECK DIFFERENTIAL LOCK SOLENOID RELAY SIGNAL

#### Ⓟ With CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode for "DIFF LOCK" with CONSULT-II.
3. Read out ON/OFF switching action of "RELAY ON".

Monitor item	Condition	Display value
RELAY ON	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> </ul> Differential lock mode switch: ON	ON
	<ul style="list-style-type: none"> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul> Differential lock mode switch: OFF	OFF



### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

## 3. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

### OK or NG

- OK >> GO TO 4.
- NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any item is damaged, repair or replace damaged parts.

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## 4. CHECK DTC

Perform the self-diagnosis, after driving the vehicle for a while.

OK or NG

- OK >> Inspection End.
- NG >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#).

## Differential Lock Solenoid DIAGNOSTIC PROCEDURE

EDS0027U

### 1. CHECK DIFFERENTIAL SOLENOID SIGNAL

#### Ⓜ With CONSULT-II

- Start engine.
- Select "DATA MONITOR" mode for "DIFF LOCK" with CONSULT-II.
- Read out ON/OFF switching action of "RELAY ON", "RELAY MTR", "SOL MTR".

Monitor item	Condition		Display value
RELAY ON	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	ON
		Differential lock mode switch: OFF	OFF
RELAY MTR		Differential lock mode switch: ON	ON
		Differential lock mode switch: OFF	OFF
SOL MTR		Differential lock mode switch: ON	ON
		Differential lock mode switch: OFF	OFF


DATA MONITOR	
MONITOR	NO DTC
RELAY ON	OFF
RELAY MTR	OFF
SOL MTR	OFF

SDIA2539E

#### ⓧ Without CONSULT-II

- Start engine.
- Check voltage between differential lock control unit harness connector terminal and ground.

Connector	Terminal	Condition		Data (Approx.)
M70	11 - Ground	<ul style="list-style-type: none"> <li>● Vehicle stopped</li> <li>● Engine running</li> <li>● VDC OFF switch (if equipped): ON</li> <li>● 4WD shift switch: 4LO</li> </ul>	Differential lock mode switch: ON	0V
			Differential lock mode switch: OFF	Battery voltage
	12 - Ground		Differential lock mode switch: ON	Battery voltage
			Differential lock mode switch: OFF	0V



OK or NG

- OK >> GO TO 6.
- NG >> GO TO 2.

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


## 2. CHECK DIFFERENTIAL LOCK SOLENOID CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect differential lock control unit harness connector.
3. Check resistance between differential lock control unit harness connector terminals 11 and 12.

Connector	Terminal	Resistance (Approx.)
M70	11 - 12	3.4 Ω

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 3.




## 3. CHECK DIFFERENTIAL LOCK SOLENOID RESISTANCE

1. Disconnect differential lock solenoid harness connector.
2. Check resistance between differential lock solenoid terminals 2 and 4.

2 - 4 : Approx. 3.4Ω

OK or NG

- OK >> GO TO 4.  
 NG >> Replace differential lock solenoid. Refer to [RFD-119](#), "[Differential Assembly](#)".



## 4. CHECK DIFFERENTIAL LOCK SOLENOID OPERATION

1. Check operation of differential lock solenoid by applying battery voltage to differential lock solenoid terminals.


**CAUTION:**

**Be sure to apply the voltage of the correct polarity to the respective terminals. Otherwise, the part may be damaged.**

Terminal
4 (Battery voltage) - 2 (Ground)

Does solenoid operate?

- YES >> GO TO 5.  
 NO >> Replace differential lock solenoid. Refer to [RFD-119](#), "[Differential Assembly](#)".



# TROUBLE DIAGNOSIS FOR SYSTEM

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### 5. CHECK HARNESS BETWEEN DIFFERENTIAL LOCK CONTROL UNIT AND DIFFERENTIAL LOCK SOLENOID

1. Check continuity between the following terminals.
  - Differential lock control unit harness connector M70 terminal 11 and differential lock solenoid harness connector C117 terminal 4.
  - Differential lock control unit harness connector M70 terminal 12 and differential lock solenoid harness connector C17 terminal 2.


**11 - 4 : Continuity should exist.**

**12 - 2 : Continuity should exist.**

Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.



### 6. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

### 7. CHECK DTC

Perform the self-diagnosis, after driving the vehicle for a while.

OK or NG

- OK >> Inspection End.
- NG >> Replace differential lock control unit. Refer to [RFD-110, "DIFFERENTIAL LOCK CONTROL UNIT"](#) .


# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## COMPONENT INSPECTION

1. Turn ignition switch OFF.
2. Disconnect differential lock solenoid harness connector.
3. Check resistance between differential lock solenoid terminals 2 and 4.

**2 - 4 : Approx. 3.4Ω**

4. If NG, replace differential lock solenoid. Refer to [RFD-119, "Differential Assembly"](#).




5. Check operation by applying battery voltage to differential lock solenoid terminals.

**CAUTION:**

**Be sure to apply the voltage of the correct polarity to the respective terminals. Otherwise, the part may be damaged.**

Terminal
4 (Battery voltage) - 2 (Ground)

6. If NG, replace differential lock solenoid.



EDS0027V

## ABS System DIAGNOSTIC PROCEDURE

### 1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform self-diagnosis with ABS actuator and electric unit (control unit). Refer to [BRC-22, "SELF-DIAGNOSIS"](#).

Is any malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.
- NO >> GO TO 2.

### 2. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

### 3. CHECK DTC

Perform the self-diagnosis, after driving the vehicle for a while.

OK or NG

- OK >> Inspection End.
- NG >> Perform self-diagnosis with ABS actuator and electric unit (control unit) again. Refer to [BRC-60, "SELF-DIAGNOSIS"](#) (with ABLs) or [BRC-111, "SELF-DIAGNOSIS"](#) (with VDC).

# TROUBLE DIAGNOSIS FOR SYSTEM [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027W

## CAN Communication Line DIAGNOSTIC PROCEDURE

### 1. CHECK CAN COMMUNICATION CIRCUIT

#### Ⓜ With CONSULT-II

1. Turn ignition switch ON and start engine.
2. Select "SELF-DIAG RESULTS" mode for "DIFF LOCK" with CONSULT-II.
3. Perform the self-diagnosis.

Is the "CAN COMM CIRCUIT [U1000]" displayed?

- YES >> Go to [LAN-3, "Precautions When Using CONSULT-II"](#) .  
NO >> Inspection End.

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]	0
ERASE	PRINT

SDIA1850E

A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

PF0:00007

EDS0027X

### TROUBLE DIAGNOSIS FOR SYMPTOMS

#### DIFF LOCK Indicator Lamp Does Not Turn ON

##### SYMPTOM:

DIFF LOCK indicator lamp does not turn ON for approx. 1 second when turning ignition switch to "ON".

##### DIAGNOSTIC PROCEDURE

### 1. CHECK SYSTEM FOR CAN COMMUNICATION LINE

Perform self-diagnosis. Refer to [RFD-88, "SELF-DIAG RESULTS MODE"](#) .

Is "CAN COMM CIRCUIT" displayed?


YES >> Perform trouble diagnosis for CAN communication line. Refer to [RFD-103, "CAN Communication Line"](#)

NO >> GO TO 2.

### 2. CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER SUPPLY


1. Turn ignition switch OFF.
2. Disconnect differential lock control unit harness connector.
3. Check voltage between differential lock control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M70	1 - Ground	0V
	2 - Ground	0V
	15 - Ground	Battery voltage



4. Turn ignition switch ON. (Do not start engine.)
5. Check voltage between differential lock control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M70	1 - Ground	Battery voltage
	2 - Ground	
	15 - Ground	



OK or NG

OK >> GO TO 3.

NG >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuse [No. 3 or 19, located in fuse block (J/B)]
- Harness for short or open between battery and differential lock control unit harness connector terminal 15
- Harness for short or open between ignition switch and differential lock control unit harness connector terminals 1 and 2
- Battery and ignition switch. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .



# TROUBLE DIAGNOSIS FOR SYMPTOMS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### 3. CHECK DIFFERENTIAL LOCK CONTROL UNIT GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between differential lock control unit harness connector M70 terminals 3, 10 and ground.

**Continuity should exist.**

Also check harness for short to ground and short to power.

**OK or NG**


- OK >> GO TO 4.  
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



### 4. CHECK COMBINATION METER POWER SUPPLY CIRCUIT

1. Disconnect combination meter harness connector.
2. Check voltage between combination meter harness connector terminal 16 and ground

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	0V




3. Turn ignition switch ON. (Do not start engine.)
4. Check voltage between combination meter harness connector terminal and ground.

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	Battery voltage

**OK or NG**

- OK >> GO TO 5.  
 NG >> Check the following. If any items are damaged, repair or replace damaged parts.
- 10A fuse [No.14, located in the fuse block (J/B)]
  - Harness for short or open between ignition switch and combination meter harness connector terminal 16.
  - Ignition switch. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .



## TROUBLE DIAGNOSIS FOR SYMPTOMS [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### 5. CHECK HARNESS BETWEEN DIFFERENTIAL LOCK CONTROL UNIT AND COMBINATION METER


1. Turn ignition switch OFF.
2. Check continuity between differential lock control unit harness connector M70 terminal 21 and combination meter harness connector M24 terminal 25.

**Continuity should exist.**

Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.  
NG >> Repair or replace damaged parts.



### 6. CHECK DIFF LOCK INDICATOR LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Check combination meter. Refer to [DI-7, "Arrangement of Combination Meter"](#).

OK or NG

- OK >> GO TO 7.  
NG >> Replace combination meter. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).

### 7. CHECK SYMPTOM

Check again.

OK or NG

- OK >> Inspection End.  
NG >> GO TO 8.

### 8. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#).

OK or NG

- OK >> Inspection End.  
NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027Y

### DIFF LOCK Indicator Lamp Does Not Change

#### SYMPTOM:

DIFF LOCK indicator lamp does not change when turning differential lock mode switch to "ON" after engine start.

#### DIAGNOSTIC PROCEDURE

#### 1. CHECK DIFF LOCK INDICATOR LAMP

Confirm DIFF LOCK indicator lamp when ignition switch is turned to ON.

Does DIFF LOCK indicator lamp turn on?

YES >> GO TO 2.

NO >> Go to [RFD-104, "DIFF LOCK Indicator Lamp Does Not Turn ON"](#) .

#### 2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [RFD-88, "SELF-DIAG RESULTS MODE"](#) .

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 3.

#### 3. CHECK SYSTEM FOR DIFFERENTIAL LOCK MODE SWITCH

Perform trouble diagnosis for differential lock mode switch system. Refer to [RFD-93, "Differential Lock Mode Switch"](#) .

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

#### 4. CHECK DIFF LOCK INDICATOR LAMP CIRCUIT

1. Turn ignition switch OFF.

2. Check combination meter. Refer to [DI-7, "Arrangement of Combination Meter"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace combination meter. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .

#### 5. CHECK SYMPTOM

Check again.

OK or NG

OK >> Inspection End.

NG >> GO TO 6.

#### 6. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

OK or NG

OK >> Inspection End.

NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

# TROUBLE DIAGNOSIS FOR SYMPTOMS

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS0027Z

### DIFF LOCK Indicator Lamp Sometimes Flashes

#### SYMPTOM:

DIFF LOCK indicator lamp sometimes flashes when it turns ON or OFF during driving.

#### DIAGNOSTIC PROCEDURE

#### 1. CHECK DIFF LOCK INDICATOR LAMP

Confirm DIFF LOCK indicator lamp when ignition switch is turned to ON.

Does DIFF LOCK indicator lamp turn on?

YES >> GO TO 2.

NO >> Go to [RFD-104, "DIFF LOCK Indicator Lamp Does Not Turn ON"](#) .

#### 2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [RFD-88, "SELF-DIAG RESULTS MODE"](#) .

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 3.

#### 3. CHECK SYSTEM FOR DIFFERENTIAL LOCK MODE SWITCH

Perform trouble diagnosis for differential lock mode switch system. Refer to [RFD-93, "Differential Lock Mode Switch"](#) .

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

#### 4. CHECK SYSTEM FOR DIFFERENTIAL POSITION SWITCH

Perform trouble diagnosis for differential lock position switch system. Refer to [RFD-96, "Differential Lock Position Switch"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

#### 5. CHECK SYMPTOM

Check again.

OK or NG

OK >> Inspection End.

NG >> GO TO 6.

#### 6. CHECK DIFFERENTIAL LOCK CONTROL UNIT

Check differential lock control unit input/output signal. Refer to [RFD-85, "Differential Lock Control Unit Input/Output Signal Reference Values"](#) .

OK or NG

OK >> GO TO 7.

NG >> Check differential lock control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

**TROUBLE DIAGNOSIS FOR SYMPTOMS**  
**[M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]**

---

**7. CHECK DIFFERENTIAL INNER PARTS**

---

1. Disassemble rear final drive assembly. Refer to [RFD-115, "Disassembly and Assembly"](#) .
2. Check differential inner parts.

OK or NG

OK >> Inspection End.

NG >> Repair or replace damaged parts.

A

B

C

**RFD**

E

F

G

H

I

J

K

L

M

# DIFFERENTIAL LOCK CONTROL UNIT

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### DIFFERENTIAL LOCK CONTROL UNIT


PFP:28496

#### Removal and Installation

EDS00280

##### REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Disconnect the differential lock control unit connector.
3. Remove the two bolts and remove the differential lock control unit.



##### INSTALLATION

Installation is in the reverse order of removal.

- When installing differential lock control unit, tighten bolts to the specified torque.

**Differential lock control unit bolts : 5.1 N-m (0.52 kg-m, 45 in-lb)**

- After installation, check DIFF LOCK indicator lamp. Refer to [RFD-69, "Precautions for Differential Case Assembly and Differential Lock Control Unit Replacement."](#)

# FRONT OIL SEAL [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

PFP:38189

EDS0028B

## FRONT OIL SEAL

### Removal and Installation REMOVAL

1. Remove the rear propeller shaft. Refer to [PR-10, "Removal and Installation"](#) .
2. Remove the brake calipers and rotors. Refer to [BR-29, "Removal and Installation of Brake Caliper and Disc Rotor"](#) .
3. Measure the total preload torque. Refer to [RFD-116, "Total Preload Torque"](#) .

#### NOTE:

Record the total preload torque measurement.

4. Remove the drive pinion nut using Tool.

**Tool number** : KV40104000 ( — )

5. Put matching marks on the companion flange and drive pinion using paint.




#### CAUTION:

**Use paint to make the matching marks. Do not damage the companion flange or drive pinion.**

6. Remove the companion flange using suitable tool.

7. Remove the front oil seal using Tool.

**Tool number** : ST33290001 (J-34286)



A  
B  
C  
RFD

E  
F  
G  
H  
I  
J  
K  
L  
M

# FRONT OIL SEAL

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


### INSTALLATION

1. Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

**Tool number** : ST15310000 ( — )

#### CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



2. Install the companion flange to the drive pinion while aligning the matching marks.
3. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

**Tool number** A: KV40104000 ( — )

B: ST3127S000 (J-25765-A)

**Total preload torque:** Refer to [RFD-116, "Total Preload Torque"](#) .

- The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg·m, 5 in·lb).
- If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg·m, 5ft·lb) increments until the total preload torque is met.


#### CAUTION:

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-115, "COMPONENTS"](#) .
- Do not loosen drive pinion lock nut to adjust the total preload torque. If the total preload torque exceeds the specifications, replace the collapsible spacer and tighten it again to adjust. Refer to [RFD-115, "Disassembly and Assembly"](#) .
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

4. Installation of the remaining components is in the reverse order of removal.

#### CAUTION:

Check the differential gear oil level after installation. Refer to [RFD-77, "DIFFERENTIAL GEAR OIL"](#)





# CARRIER COVER [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

PF3:38351

EDS0028C

## CARRIER COVER


### Removal and Installation REMOVAL

1. Remove the drain plug and drain the gear oil. Refer to [RFD-77, "DRAINING"](#) .
2. Disconnect the parking brake cable from the carrier cover.
3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

**Tool number** : KV10111100 (J-37228)


#### **CAUTION:**

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



### INSTALLATION

1. Apply a bead of sealant to the mating surface of the carrier cover as shown.
  - Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .
2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-49, "COMPONENTS"](#) .
3. Connect the parking brake cable to the carrier cover.
4. Fill the rear final drive assembly with recommended differential gear oil. Refer to [RFD-44, "Checking Differential Gear Oil"](#) .



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### REAR FINAL DRIVE ASSEMBLY

PF3:38300

#### Removal and Installation

##### REMOVAL


EDS0028D

##### CAUTION:

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
- Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.

1. Drain the differential gear oil. Refer to [RFD-77, "DRAINING"](#) .
2. Remove the rear propeller shaft. Refer to [PR-10, "Removal and Installation"](#) .
3. Remove the axle shaft. Refer to [RAX-19, "Removal and Installation"](#) .
4. Disconnect the following components from the rear final drive assembly.

- ABS sensor wire harness
- Brake hoses
- Parking brake cable
- Differential lock solenoid connector
- Differential lock position switch connector



5. Support the rear final drive assembly using a suitable jack.
6. Remove rear shock absorber lower bolts. Refer to [RSU-7, "Removal and Installation"](#) .
7. Remove leaf spring U-bolt nuts. Refer to [RSU-8, "Removal and Installation"](#) .
8. Remove rear final drive assembly.

##### CAUTION:

Secure rear final drive assembly to the jack while removing it.

#### INSTALLATION

Installation is in the reverse order of removal.

##### CAUTION:


- Fill the rear final drive assembly with differential gear oil after installation. Refer to [RFD-77, "DIFFERENTIAL GEAR OIL"](#) .
- Bleed the air from brake system. Refer to [BR-10, "Bleeding Brake System"](#) .
- After the installation, check DIFF LOCK indicator lamp. Refer to [RFD-69, "Precautions for Differential Case Assembly and Differential Lock Control Unit Replacement."](#) .

# REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

EDS00284

## Disassembly and Assembly COMPONENTS

SEC.380



- |                                |   |                                |
|--------------------------------|---|--------------------------------|
| 1. Drive pinion lock nut       | 2. Drive pinion lock nut washer             | 3. Companion flange            |
| 4. Front oil seal              | 5. Drive pinion front bearing thrust washer | 6. Drive pinion front bearing  |
| 7. Gear carrier                | 8. Differential lock position switch        | 9. Breather                    |
| 10. Sensor connector           | 11. Drain plug                              | 12. Side bearing cap           |
| 13. Adjuster lock plate        | 14. Carrier cover                           | 15. Filler plug                |
| 16. Drive pinion               | 17. Drive pinion height adjusting washer    | 18. Drive pinion rear bearing  |
| 19. Collapsible spacer         | 20. Side bearing adjuster                   | 21. Side bearing               |
| 22. Differential case assembly | 23. Drive gear                              | 24. Differential lock solenoid |
| 25. Solenoid washer            |   |                                |

WDIA0346E

# REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to [RFD-77, "DIFFERENTIAL GEAR OIL"](#).
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to [RFD-113, "CARRIER COVER"](#).

### Total Preload Torque

1. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
2. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
3. Measure total preload torque using Tool.

**Tool number** : ST3127S000 (J-25765-A)

**Total preload torque:**

**2.38 - 4.46 N·m (0.25 - 0.45 kg·m, 21 - 39 in·lb)**

#### NOTE:

**Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque**

- If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

**If the total preload torque is greater than specification**


**On drive pinion bearings:** Replace collapsible spacer.

**On side bearings:** Loosen side bearing adjuster.

**If the total preload torque is less than specification**

**On drive pinion bearings:** Tighten drive pinion lock nut.

**On side bearings:** Tighten side bearing adjuster.




### Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.


1. Thoroughly clean drive gear and drive pinion teeth.
2. Apply red lead to the drive gear.

#### NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.




3. Hold companion flange steady by hand and rotate drive gear in both directions.




# REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

Usually the pattern will be correct if washers are correctly calculated and the backlash is correct. However, in rare cases, trial and error processes may be employed to obtain a correct pattern. The tooth pattern is the best indication of how well a differential has been set up.



To correct, increase thickness of drive pinion height adjusting washer in order to bring drive pinion close to drive gear.

To correct, reduce thickness of drive pinion height adjusting washer in order to make drive pinion go away from drive gear.



When adjustment is completed, be sure to wipe off completely the red lead and oil or their equivalent.

SDIA2591E


4. If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to [RFD-124, "Drive Pinion Height Adjusting Washer"](#) and [RFD-117, "Backlash"](#).

## Backlash

1. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash: 0.08 - 0.13 mm (0.0031 - 0.0051 in)**


2. If the backlash is outside of the specification, adjust each side bearing side bearing adjuster.
  - a. Remove adjuster lock plate.
  - b. Loosen side bearing cap bolts.



SDIA2640E

- c. Tighten or loosen each side bearing adjusters using Tool.

**Tool number : — (C - 4164)**




PDIA0337E

**If the backlash is greater than specification:**

**Loosen side bearing adjuster A and tighten side bearing adjuster B by the same amount.**

**If the backlash is less than specification:**

**Loosen side bearing adjuster B and tighten side bearing adjuster A by the same amount.**



PDIA0330E

## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


### CAUTION:

Do not change the side bearing side bearing adjusters by different amounts as it will change the side bearing preload torque.

- d. Tighten side bearing cap bolts to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).
- e. Install adjuster lock plate and tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).

### CAUTION:

Check tooth contact and total preload torque after adjusting side bearing adjuster. Refer to [RFD-116, "Tooth Contact"](#) and [RFD-116, "Total Preload Torque"](#).



### Companion Flange Runout


1. Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.

#### Runout limit

**Companion flange face: 0.10 mm (0.0039 in)**

**Companion flange inner side: 0.13 mm (0.0051 in)**

2. If the runout is outside the runout limit, follow the procedure below to adjust.
  - a. Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
  - b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
  - c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### DISASSEMBLY


#### Differential Assembly

1. Remove carrier cover bolts.
2. Remove carrier cover using Tool.


**Tool number** : KV10111100 (J-37228)

**CAUTION:**

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



3. Remove differential sensor connector bolt and differential lock solenoid connector.




4. For proper reinstallation, paint matching mark on one side of side bearing cap.


**CAUTION:**

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.

5. Remove adjuster lock plates.



6. Remove side bearing caps.




A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M


## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

7. Remove side bearing adjusters using Tool.

**Tool number** : — (C - 4164)



8. Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
9. Remove side bearing adjusters from gear carrier.




10. Remove bracket of differential lock position switch connector and bolts.
11. Remove differential lock position switch.
12. Remove side bearing inner race and washer using Tool.

**Tool number** : ST33081000 ( — )

**CAUTION:**

**Do not damage differential case assembly and differential lock solenoid.**

13. Remove differential lock solenoid and solenoid washer.




14. Remove side bearing inner race using Tool.

**Tool number** : ST33081000 ( — )

**CAUTION:**

**Do not damage differential case assembly.**





## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

15. For proper reinstallation, paint matching mark on differential case and drive gear.

**CAUTION:**


**Use paint for matching marks. Do not damage differential case or drive gear.**

16. Remove drive gear bolts.

17. Tap the drive gear off the differential case using suitable tool.

**CAUTION:**

**Tap evenly all around to keep drive gear from binding.**



### Drive Pinion Assembly


1. Remove differential case assembly. Refer to [RFD-119, "Differential Assembly"](#) .
2. Remove drive pinion lock nut and washer using Tool.

**Tool number** : KV40104000 ( — )


3. Put matching marks on the companion flange and drive pinion using paint.

**CAUTION:**

**Use paint to make the matching marks. Do not damage the companion flange or drive pinion.**



4. Remove companion flange using suitable tool.




5. Remove front oil seal using Tool.

**Tool number** : ST33290001 (J-34286)

**CAUTION:**

**Do not damage gear carrier.**

6. Remove drive pinion front bearing thrust washer.



A  
B  
C  
RFD

E  
F  
G  
H  
I  
J  
K  
L  
M


## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

7. Remove drive pinion assembly (with rear inner bearing race and collapsible spacer) out of gear carrier.

**CAUTION:**

**Do not drop drive pinion assembly.**

8. Remove drive pinion front bearing inner race from gear carrier.



9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.


**CAUTION:**

**Do not damage gear carrier.**

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.


**CAUTION:**

**Do not damage gear carrier.**



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

**Tool number : ST30021000 (J-22912-01)**



# REAR FINAL DRIVE ASSEMBLY

## [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

### INSPECTION AFTER DISASSEMBLY

#### Drive Pinion and Drive Gear

- If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new gears.
- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each pinion gear and drive gear before proceeding with assembly.

#### Bearing

- If found any chipped (by friction), pitted, worn, rusted, scratched mark, or unusual noise from the bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

#### Differential Case Assembly

- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new differential case assembly.
- If the movement is not smooth when pushing cam ring of differential case assembly with a hand.

#### Differential Lock Solenoid

- If the operating part of differential lock solenoid is not smooth, perform component inspection. Refer to [RFD-95, "COMPONENT INSPECTION"](#).


A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

# REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

## SELECTION ADJUSTING WASHERS

### Drive Pinion Height Adjusting Washer

- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.




- The mounting distance from the center line of drive gear to the back face of drive pinion for the Model 226 final drive assembly is 109.5 mm (4.312 in).  
On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion inner bearing race and drive pinion. For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what m-8 (a-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washers which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.

OLD DRIVE PINION MARKING	NEW DRIVE PINION MARKING mm (in)								
	-10 (-4)	-8 (-3)	-5 (-2)	-3 (-1)	0 (0)	+3 (+1)	+5 (+2)	+8 (+3)	+10 (+4)
+10 (+4)	+0.20 (+0.008)	+0.18 (+0.007)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)
+8 (+3)	+0.18 (+0.007)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)
+5 (+2)	+0.15 (+0.006)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)
+3 (+1)	+0.13 (+0.005)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)
0 (0)	+0.10 (+0.004)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)
-3 (-1)	+0.08 (+0.003)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)
-5 (-2)	+0.05 (+0.002)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)
-8 (-3)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)
-10 (-4)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)	-0.20 (-0.008)


## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

1. Make sure all parts are clean and that drive pinion bearings are well lubricated.
2. Assemble drive pinion bearings into the tools.


<b>Tool number</b>	<b>A:</b>	—	<b>(8144)</b>
	<b>B:</b>	—	<b>(6740)</b>
	<b>C:</b>	—	<b>(6741)</b>



3. Install drive pinion bearing inner race and drive pinion height adjusting washer to gear carrier using tool as shown.



4. Turn the assembly several times to seat drive pinion bearings.




5. Measure the turning torque, using Tool.

**Tool number : ST3127S000 (J-25765-A)**


**Turning torque specification:**

**1.2 - 2.8 N-m (0.13 - 0.28 kg-m, 11 - 24 in-lb)**




6. Tighten side bearing caps to the specified torque installing Tools as shown.

<b>Tool number</b>	<b>A:</b>	—	<b>(6739)</b>
	<b>B:</b>	—	<b>(D-115-2)</b>
	<b>C:</b>	—	<b>(8541A-1)</b>
	<b>D:</b>	—	<b>(D-115-3)</b>



## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

7. Put scooter block on pinion height block. Make sure that dial indicator is level adjusting pressure with a hand. Dial indicator indicates "0".
8. Slide dial indicator along arbor. Record the maximum.
9. Adjust drive pinion height adjusting washer so that the maximum will be "0".




### ASSEMBLY

#### Drive Pinion Assembly

1. Press a drive pinion rear bearing outer race into gear carrier using Tool.

**Tool number**     **A: ST01500001 ( — )**  
                           **B: ST30022000 ( — )**

**CAUTION:**  
**Do not reuse drive pinion rear bearing.**




2. Press a drive pinion front bearing outer race into gear carrier using Tool.

**Tool number**     **: ST33022000 ( — )**

**CAUTION:**  
**Do not reuse drive pinion front bearing.**

3. Select drive pinion height adjusting washer. Refer to [RFD-131, "Drive Pinion Height Adjusting Washer"](#) .




4. Press a drive pinion rear bearing inner race and drive pinion height adjusting washer to drive pinion, using Tool.

**Tool number**     **: — (C - 4040)**

**CAUTION:**  
**Do not reuse drive pinion rear bearing.**

5. Apply gear oil to the drive pinion rear bearing and drive pinion front bearing.
6. Install drive pinion front bearing inner race in gear carrier.
7. Install drive pinion front bearing thrust washer to gear carrier.




## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

8. Apply multi-purpose grease to new front oil seal lip. Install new front oil seal into gear carrier using Tool.

**Tool number** : ST15310000 ( — )

**CAUTION:**


- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lip of the new front oil seal.



9. Install new collapsible spacer to drive pinion. And then install drive pinion assembly in gear carrier.

**CAUTION:**


- Do not reuse collapsible spacer.
- Do not damage front oil seal.



10. Install the companion flange onto the drive pinion while aligning the matching marks. Then tap the companion flange using suitable tool.

**CAUTION:**

**Do not damage companion flange or front oil seal.**



11. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

**Tool number** A: KV40104000 ( — )


B: ST3127S000 (J-25765-A)

**Drive pinion bearing preload torque:**

**1.7 - 3.1 N·m (0.18 - 0.31 kg·m, 15 - 27 in·lb)**

**CAUTION:**

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to [RFD-115. "COMPONENTS"](#).
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.



## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

### Differential Assembly


1. Apply thread locking sealant to back face of drive gear.
  - Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .

**CAUTION:**

Make sure the drive gear back and threaded holes are clean.




2. Align the matching mark of differential case assembly with the mark of drive gear, then install drive gear.



3. Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.
  - Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .

**CAUTION:**


Make sure the drive gear back and threaded holes are clean.



4. Install new drive gear bolts, and then tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#) .

**CAUTION:**

- Do not reuse the bolts.
- Tighten bolts in a crisscross fashion.






## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]

5. Press side bearing inner races to differential case assembly using Tool.

**Tool number** : ST33081000 ( — )


**CAUTION:**

**Do not reuse side bearing.**



6. Install differential lock solenoid and washer.  
7. Press side bearing inner races to differential case assembly using Tool.

**Tool number**    **A:** KV38100300 (J-25523)  
                          **B:** ST33081000 ( — )




8. Apply sealant to threads of differential lock position switch.  
● Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).


**CAUTION:**

**Remove old sealant adhering to gear carrier and differential lock position switch. Also remove any moisture, oil, or foreign material adhering to application and gear carrier and differential lock position switch.**

9. Install differential lock position switch on gear carrier and tighten differential lock position switch bolts with the specified torque. Refer to [RFD-115, "COMPONENTS"](#).



10. Install side bearing adjusters into gear carrier.




A  
B  
C  
RFD  
E  
F  
G  
H  
I  
J  
K  
L  
M

## REAR FINAL DRIVE ASSEMBLY [M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]


11. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into gear carrier.
12. Apply multi-purpose grease to sensor connector.

**CAUTION:**

**Do not reuse sensor connector.**




13. Connect differential lock solenoid harness and sensor connector. Then install it to gear carrier, tighten to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).



14. Align paint matching mark on side bearing caps with that on gear carrier and install side bearing caps on gear carrier.

**CAUTION:**


**Do not tighten at this point. This allows further tightening of side bearing adjusters.**



15. Tighten each side bearing adjusters using adjuster tool.

**Tool number** : — (C - 4164)

16. Adjusting backlash of drive gear and drive pinion. Refer to [RFD-117, "Backlash"](#).
17. Check total preload. Refer to [RFD-116, "Total Preload Torque"](#).
18. Check tooth contact. Refer to [RFD-116, "Tooth Contact"](#).




19. Apply a bead of sealant to the mating surface of the carrier cover as shown.

- Use Genuine Silicone RTV or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

**Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.**

20. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to [RFD-115, "COMPONENTS"](#).



**SERVICE DATA AND SPECIFICATIONS (SDS)**  
**[M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]**

**SERVICE DATA AND SPECIFICATIONS (SDS)**

PF0:00030

**General Specifications**

EDS00285

Applied model	VQ40DE		
	2WD	4WD	
	5A/T		6M/T
Final drive model	M226		
Gear ratio	3.133	3.357	3.692
Number of pinion gears	2		
Number of teeth (Drive gear / drive pinion)	47/15	47/14	48/13
Oil capacity (Approx.)	2.01 ℓ (4-1/4 US pt, 3-1/2 Imp pt)		
Drive pinion adjustment spacer type	Collapsible		

**Inspection and Adjustment**  
**PRELOAD TORQUE**

EDS00286

Unit: N·m (kg·m, in·lb)

Item	Specification
Drive pinion bearing preload torque	1.7 - 3.1 (0.18 - 0.31, 15 - 27)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.38 - 4.46 (0.25 - 0.45, 21 - 39)

**BACKLASH**

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.08 - 0.13 (0.0031 - 0.0051)

**COMPANION FLANGE RUNOUT**

Unit: mm (in)

Item	Runout limit
Companion flange face	0.10 (0.0039) or less
Companion flange inner side	0.13 (0.0051) or less

**SELECTIVE PARTS**

**Drive Pinion Height Adjusting Washer**

Unit: mm (in)

Thickness	Package part number*
0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034)	38151 8S101
0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039)	38151 8S102
0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044)	38151 8S103

**SERVICE DATA AND SPECIFICATIONS (SDS)**  
**[M226 WITH ELECTRONIC LOCKING DIFFERENTIAL]**

Thickness	Package part number*
0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049)	38151 8S104
0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054)	38151 8S105

\*Always check with the Parts Department for the latest parts information.