

DLN

Е

CONTENTS

TRANSFER: TX15B	DTC Logic26
BASIC INSPECTION8	Diagnosis Procedure26
DASIC INSPECTION	P1808 VEHICLE SPEED SENSOR (ABS)27
DIAGNOSIS AND REPAIR WORKFLOW 8	Description27
Work Flow8	DTC Logic27
FUNCTION DIA ONGOIO	Diagnosis Procedure27
FUNCTION DIAGNOSIS10	DAGAGA LO CIVITOLI
4WD SYSTEM10	P1810 4 LO SWITCH28
System Diagram	Description
System Description11	DTC Logic
Component Parts Location13	Diagnosis Procedure
CAN Communication14	Component Inspection30
Cross-Sectional View14	P1813 4WD SHIFT SWITCH31
Power Transfer15	Description31
	DTC Logic31
DIAGNOSIS SYSTEM (TRANSFER CON-	Diagnosis Procedure31
TROL UNIT)17	Component Inspection33
CONSULT-III Function (ALL MODE AWD/4WD) 17	·
NOISE VIDEATION AND HADOUNESS	P1814 WAIT DETECTION SWITCH34
NOISE, VIBRATION AND HARSHNESS	Description34
(NVH) TROUBLESHOOTING20	DTC Logic34
NVH Troubleshooting Chart20	Diagnosis Procedure34
COMPONENT DIAGNOSIS21	Component Inspection36
COMI ONLINI DIAGNOSIS21	P1816 PNP SWITCH (A/T)37
P1801, P1811 POWER SUPPLY CIRCUIT	Description37
FOR TRANSFER CONTROL UNIT21	DTC Logic37
Description21	Diagnosis Procedure37
DTC Logic21	
Diagnosis Procedure21	P1816 PNP SWITCH (M/T)38
Component Inspection23	Description38
· · · · · · · · · · · · · · · · · · ·	DTC Logic38
P1802 – P1804, P1809 TRANSFER CON-	Diagnosis Procedure38
TROL UNIT24	Component Inspection39
Description24	P1817 ACTUATOR MOTOR40
DTC Logic24	Description40
Diagnosis Procedure24	
P1807 VEHICLE SPEED SENSOR (A/T)26	DTC Logic40 Diagnosis Procedure40
Description	Component Inspection45
D00011pti01120	Ouriportorit inopoditori40

P1818 ACTUATOR POSITION SWITCH	47	Precaution for Supplemental Restraint System	
Description		(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	
DTC Logic		SIONER"	84
Diagnosis Procedure	47	Precaution for Transfer Assembly and Transfer	
P1819 TRANSFER CONTROL DEVICE	5 0	Control Unit Replacement	
Description		Precaution	
DTC Logic		Service Notice	86
Diagnosis Procedure		PREPARATION	88
DAGOS ENGINE CREED CIONAL			
P1820 ENGINE SPEED SIGNAL Description		PREPARATION	
DTC Logic		Commercial Service Tool	
Diagnosis Procedure			
-		ON-VEHICLE MAINTENANCE	91
ECU DIAGNOSIS	54	TRANSFER FLUID	01
TRANSFER CONTROL UNIT	54	Replacement	
Reference Value		Inspection	
Wiring Diagram	_		
DTC Index		ON-VEHICLE REPAIR	92
SYMPTOM DIAGNOSIS	70	TRANSFER CONTROL UNIT	92
31WF10W DIAGNOSIS	70	Removal and Installation	
4WD SYSTEM SYMPTOMS	70		
Symptom Table	70	FRONT OIL SEAL	
AWD WARNING LAMP DOES NOT TURN O	NI 74	Removal and Installation	93
4WD WARNING LAMP DOES NOT TURN O		REAR OIL SEAL	95
Diagnosis Procedure		Removal and Installation	
-		TRANSFER CONTROL DEVICE	
4WD SHIFT INDICATOR LAMP AND 4LO I		TRANSFER CONTROL DEVICE Removal and Installation	
DICATOR LAMP DO NOT TURN ON		Removal and installation	97
Description		AIR BREATHER HOSE	99
Diagnosis Procedure	/3	Removal and Installation	99
4WD SHIFT INDICATOR LAMP OR 4LO INI	DI-	PLANETARY CARRIER	101
CATOR LAMP DO NOT CHANGE	75	Disassembly and Assembly	
Description		•	
Diagnosis Procedure	75	FRONT DRIVE SHAFT	
ATP WARNING LAMP DOES NOT TURN O	N 77	Disassembly and Assembly	105
Description		SHIFT CONTROL	107
Diagnosis Procedure		Disassembly and Assembly	
AWD SHIET INDICATOR LAMP KEEPS		·	
4WD SHIFT INDICATOR LAMP KEEPS FLASHING	70	REMOVAL AND INSTALLATION	109
Description		TRANSFER ASSEMBLY	109
Diagnosis Procedure		Removal and Installation	
		DICACCEMBLY AND ACCEMBLY	
4WD WARNING LAMP FLASHES SLOWLY		DISASSEMBLY AND ASSEMBLY	110
Description		TRANSFER ASSEMBLY	110
Diagnosis Procedure	80	Disassembly and Assembly	
ATP SWITCH		•	
Description		SERVICE DATA AND SPECIFICATIONS	
Diagnosis Procedure		(SDS)	126
Component Inspection	82	SERVICE DATA AND SPECIFICATIONS	
PRECAUTION	84	(SDS)	126
		General Specification	
PRECAUTIONS	84	Inspection and Adjustment	

PROPELLER SHAFT: 2F1310	SERVICE DATA AND SPECIFICATIONS
PREPARATION127	(SDS)142 A
PREPARATION127	SERVICE DATA AND SPECIFICATIONS
Commercial Service Tool127	(SDS)
FUNCTION DIAGNOSIS128	Snap Ring142 PROPELLER SHAFT: 3S1310
NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING128	PREPARATION143
NVH Troubleshooting Chart128	PREPARATION143 DL
ON-VEHICLE REPAIR129	Commercial Service Tool143
PROPELLER SHAFT	FUNCTION DIAGNOSIS144
On-Vehicle Service	NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING144 NVH Troubleshooting Chart144
PROPELLER SHAFT130	-
Removal and Installation130	ON-VEHICLE REPAIR145
DISASSEMBLY AND ASSEMBLY132	REAR PROPELLER SHAFT145 On-Vehicle Service145
PROPELLER SHAFT132 Disassembly and Assembly132	REMOVAL AND INSTALLATION146
SERVICE DATA AND SPECIFICATIONS (SDS)134	REAR PROPELLER SHAFT146 Removal and Installation146
SERVICE DATA AND SPECIFICATIONS	DISASSEMBLY AND ASSEMBLY148
(SDS)134	REAR PROPELLER SHAFT148
General Specification	Disassembly and Assembly148
Snap Ring134 PROPELLER SHAFT: 2S1330	SERVICE DATA AND SPECIFICATIONS
PREPARATION135	(SDS)150 K
PREPARATION135	SERVICE DATA AND SPECIFICATIONS
Commercial Service Tool135	(SDS)
FUNCTION DIAGNOSIS136	Snap Ring150
NOISE, VIBRATION, AND HARSHNESS	PROPELLER SHAFT: 3S1350
(NVH) TROUBLESHOOTING136	PREPARATION151
NVH Troubleshooting Chart136	PREPARATION151
ON-VEHICLE REPAIR137	Commercial Service Tool151
PROPELLER SHAFT137	FUNCTION DIAGNOSIS152
On-Vehicle Service	NOISE, VIBRATION, AND HARSHNESS
REMOVAL AND INSTALLATION138	(NVH) TROUBLESHOOTING152 NVH Troubleshooting Chart152
PROPELLER SHAFT138	
Removal and Installation138	ON-VEHICLE REPAIR153
DISASSEMBLY AND ASSEMBLY140	PROPELLER SHAFT
PROPELLER SHAFT140	REMOVAL AND INSTALLATION154
Disassembly and Assembly140	

PROPELLER SHAFT 154 Removal and Installation	FUNCTION DIAGNOSIS172
Removal and installation154	NOISE, VIBRATION AND HARSHNESS
DISASSEMBLY AND ASSEMBLY156	(NVH) TROUBLESHOOTING172
DDODELLED CHAFT	NVH Troubleshooting Chart 172
PROPELLER SHAFT 156 Disassembly and Assembly	DESCRIPTION
Disassembly and Assembly156	DESCRIPTION173 Cross-Sectional View173
SERVICE DATA AND SPECIFICATIONS	Closs-Sectional view173
(SDS)158	ON-VEHICLE MAINTENANCE174
SERVICE DATA AND SPECIFICATIONS	DIFFERENTIAL GEAR OIL174
(SDS) 158	Changing Differential Gear Oil174
General Specification158	Checking Differential Gear Oil174
Snap Ring158	ON-VEHICLE REPAIR175
PROPELLER SHAFT: 3S1330-2BJ100	
PREPARATION159	FRONT OIL SEAL175
	Removal and Installation 175
PREPARATION159	SIDE OIL SEAL177
Commercial Service Tool159	Removal and Installation 177
FUNCTION DIAGNOSIS160	OARDIED OOVED
	CARRIER COVER178 Removal and Installation178
NOISE, VIBRATION AND HARSHNESS	Removal and Installation178
(NVH) TROUBLESHOOTING 160	REMOVAL AND INSTALLATION179
NVH Troubleshooting Chart160	EDON'T FINAL DRIVE ACCEMBLY
ON-VEHICLE REPAIR161	FRONT FINAL DRIVE ASSEMBLY179
	Removal and Installation 179
REAR PROPELLER SHAFT 161	DISASSEMBLY AND ASSEMBLY181
On-Vehicle Service161	EDON'T FINAL DRIVE
REMOVAL AND INSTALLATION162	FRONT FINAL DRIVE181 Disassembly and Assembly181
	Disassembly and Assembly181
REAR PROPELLER SHAFT 162	SERVICE DATA AND SPECIFICATIONS
Removal and Installation162	(SDS)200
DISASSEMBLY AND ASSEMBLY164	
	SERVICE DATA AND SPECIFICATIONS
REAR PROPELLER SHAFT 164	(SDS)200 General Specification
Disassembly and Assembly164	Inspection and Adjustment
SERVICE DATA AND SPECIFICATIONS	C200
(SDS)166	
•	PRECAUTION202
SERVICE DATA AND SPECIFICATIONS	PRECAUTIONS202
(SDS)	Precaution for Servicing Rear Final Drive 202
General Specification	<u>-</u>
Snap Ring166 FRONT FINAL DRIVE: R180A	PREPARATION203
TRONT TIMAL BRIVE. R 100A	PREPARATION203
PRECAUTION167	Special Service Tool
	Commercial Service Tool
PRECAUTIONS	
Precaution for Servicing Front Final Drive167	FUNCTION DIAGNOSIS206
PREPARATION168	NOISE, VIBRATION AND HARSHNESS
	(NVH) TROUBLESHOOTING206
PREPARATION	NVH Troubleshooting Chart
Special Service Tool168 Commercial Service Tool170	•
Commercial Service 1001170	DESCRIPTION 207

Cross-Sectional View207	ON-VEHICLE REPAIR242
ON-VEHICLE MAINTENANCE208	FRONT OIL SEAL242
DIFFERENTIAL GEAR OIL208	Removal and Installation242
Changing Differential Gear Oil	CARRIER COVER244
Checking Differential Gear Oil	Removal and Installation244
ON-VEHICLE REPAIR	REMOVAL AND INSTALLATION245
	REMOVAL AND INSTALLATION245
FRONT OIL SEAL209	REAR FINAL DRIVE ASSEMBLY245
Removal and Installation209	Removal and Installation245
CARRIER COVER211	DISASSEMBLY AND ASSEMBLY 246
Removal and Installation211	REAR FINAL DRIVE ASSEMBLY246
REMOVAL AND INSTALLATION212	Disassembly and Assembly246
REAR FINAL DRIVE212	SERVICE DATA AND SPECIFICATIONS
Removal and Installation212	
	(SDS)262
DISASSEMBLY AND ASSEMBLY213	SERVICE DATA AND SPECIFICATIONS
REAR FINAL DRIVE213	(SDS)262
Disassembly and Assembly213	General Specification
CEDVICE DATA AND ODECIFICATIONS	Inspection and Adjustment262
SERVICE DATA AND SPECIFICATIONS	REAR FINAL DRIVE: M226 (ELD)
(SDS)232	BASIC INSPECTION264
SERVICE DATA AND SPECIFICATIONS	
(SDS)232	DIAGNOSIS AND REPAIR WORKFLOW 264
General Specification232	Work Flow264
Inspection and Adjustment232	FUNCTION DIAGNOSIS266
REAR FINAL DRIVE: M226	
DDECALITION	DIFFERENTIAL LOCK SYSTEM266
PRECAUTION234	Cross-Sectional View266
PRECAUTIONS234	System Diagram
Precaution for Servicing Rear Final Drive234	System Description
	Component Description
PREPARATION235	
PREPARATION235	DIAGNOSIS SYSTEM (DIFFERENTIAL
Special Service Tool	LOCK CONTROL UNIT)270
Commercial Service Tool238	DIFFERENTIAL LOCK CONTROL UNIT270
FUNCTION DIA ONOGIO	DIFFERENTIAL LOCK CONTROL UNIT : CON-
FUNCTION DIAGNOSIS239	SULT-III Function (DIFF LOCK)270
DESCRIPTION239	NOISE VIRPATION AND HAPSHNESS
Cross-Sectional View239	NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING271
CVMPTOM DIA ONOCIO	` ND #1 =
SYMPTOM DIAGNOSIS240	NVH Troubleshooting Chart271 (
NOISE, VIBRATION AND HARSHNESS	COMPONENT DIAGNOSIS272
(NVH) TROUBLESHOOTING240	U1000 CAN COMM CIRCUIT272
NVH Troubleshooting Chart240	Description272
•	DTC Logic272
ON-VEHICLE MAINTENANCE241	Diagnosis Procedure272
DIFFERENTIAL GEAR OIL241	•
Changing Differential Gear Oil241	P1833 INITIAL START273
Checking Differential Gear Oil241	Description273
3	DTC Logic

Diagnosis Procedure	273	DIFFERENTIAL LOCK CONTROL UNIT	292
DAGGA CONTROL LINET A		Reference Value	292
P1834 CONTROL UNIT 1		Wiring Diagram	293
Description		DTC Index	298
DTC Logic	274	OVERTON DIA ONOGIO	
P1835 CONTROL UNIT 2	275	SYMPTOM DIAGNOSIS	299
Description		DIFF LOCK INDICATOR LAMP INOPERA-	
DTC Logic		TIVE	299
P1836 CONTROL UNIT 3		Inspection Procedure	
Description	276	DIFF LOCK INDICATOR LAMP DOES NOT	
DTC Logic	276	TURN ON WITH DIFFERENTIAL LOCK	
D4000 00NTD 01 11NUT 4		SWITCHED ON	300
P1837 CONTROL UNIT 4		Inspection Procedure	
Description		inspection i locedure	500
DTC Logic	277	DIFF LOCK INDICATOR LAMP FLASHES	
P1838 ON SWITCH	270	WHILE DRIVING	301
Description		Description	
DTC Logic		Inspection Procedure	
Diagnosis Procedure	270		
Diagnosis Flocedure	270	PRECAUTION	302
P1839 POSITION SWITCH ON	280	PRESAUTIONS	
Description	280	PRECAUTIONS	302
DTC Logic	280	Precaution for Supplemental Restraint System	
Diagnosis Procedure		(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	
		SIONER"	
P1844 RELAY		Precaution	
Description		Precaution for Servicing Rear Final Drive	303
DTC Logic		PREPARATION	304
Diagnosis Procedure	282		
P1847 SOLENOID CIRCUIT	283	PREPARATION	304
Description		Special Service Tool	304
DTC Logic		Commercial Service Tool	307
DTO Logio	200		
P1848 SOLENOID DISCONNECT	284	ON-VEHICLE MAINTENANCE	308
Description		DIFFERENTIAL GEAR OIL	308
DTC Logic	284	Changing Differential Gear Oil	
Diagnosis Procedure	284	Checking Differential Gear Oil	
D4040 COLENOID CHORT	200	Checking billerential Geal Oil	500
P1849 SOLENOID SHORT		ON-VEHICLE REPAIR	309
Description			
DTC Logic		DIFFERENTIAL LOCK CONTROL UNIT	
Diagnosis Procedure	286	Removal and Installation	309
P1850 SOLENOID CURRENT	288	DIECEDENTIAL LOCK DOSITION SWITCH	240
Description		DIFFERENTIAL LOCK POSITION SWITCH.	
DTC Logic		Removal and Installation	310
Diagnosis Procedure		FRONT OIL SEAL	314
		Removal and Installation	
C1203 ABS SYSTEM			
Description		CARRIER COVER	
DTC Logic	290	Removal and Installation	316
LOCK INDICATOR LAMP	204	DEMOVAL AND INSTALLATION	.
		REMOVAL AND INSTALLATION	317
Description Component Function Check		REAR FINAL DRIVE ASSEMBLY	317
Diagnosis Procedure		Removal and Installation	
Diagnosis i Tocedule	231	Tomoval and motalization	517
ECU DIAGNOSIS	292	DISASSEMBLY AND ASSEMBLY	319

REAR FINAL DRIVE319 Disassembly and Assembly319	SERVICE DATA AND SPECIFICATIONS (SDS)	334
SERVICE DATA AND SPECIFICATIONS (SDS)	General Specification Inspection and Adjustment	334
		,


< BASIC INSPECTION > [TRANSFER: TX15B]

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

WORK FLOW



DETAILED FLOW

1. CUSTOMER INFORMATION

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2

2. INITIAL INSPECTION

Perform an initial inspection of all accessible transfer case harnesses and connectors under the vehicle.

>> GO TO 3

3. SELF-DIAGNOSIS

Perform self-diagnosis. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >	[TRANSFER: TX15B]
C DAGIO INGI ECTION >	
>> GO TO 4	
4.SYMPTOM	
Check for symptoms. Refer to <u>DLN-70, "Symptom Table"</u> .	
>> GO TO 5	
5.MALFUNCTIONING PARTS	
Repair or replace the applicable parts.	
repair of replace the applicable parts.	D
>> GO TO 6	
6.SYSTEM OPERATION	_
Check system operation.	
>> GO TO 7	
7.self-diagnosis	
Perform self-diagnosis.	
Are any DTC's displayed?	
YES >> GO TO 5 NO >> Inspection End	
NO >> Inspection End	
	I


FUNCTION DIAGNOSIS

4WD SYSTEM

System Diagram

INFOID:0000000003296921

[TRANSFER: TX15B]



COMPONENT DESCRIPTION

Components	Function	
Transfer control unit	Controls transfer control device and controls shifts between 2WD/4WD and 4H/4LO.	
Transfer control device	Integrates actuator motor and actuator position switch.	
Actuator motor	Moves shift rods when signaled by transfer control unit.	
Actuator position switch	Detects actuator motor position.	
Wait detection switch	Detects if transfer case is in 4WD.	
4LO switch	Detects if transfer case is in 4LO.	
ATP switch (A/T models)	Detects if transfer case is in neutral.	
4WD shift switch	Allows driver to select from 2WD/4WD and 4H/4LO.	
4WD warning lamp	 Illuminates if malfunction is detected in 4WD system. Flashes (1 flash / 2 seconds) if rotation difference of front wheels and rear wheels is large. 	
ATP warning lamp (A/T models)	Indicates that A/T parking mechanism does not operate when A/T selector lever is in "P" position because transfer case is in neutral.	
4WD shift indicator lamp	Displays driving range selected by 4WD shift switch.	
4LO indicator lamp	Displays 4LO range.	
PNP switch (M/T models)	Detects if manual transmission is under neutral condition.	
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication to transfer control unit. • Vehicle speed signal • Stop lamp switch signal (brake signal)	

4WD SYSTEM

< FUNCTION DIAGNOSIS >

Components	Function	
TCM (A/T models)	Transmits the following signal via CAN communication to transfer control unit. Output shaft revolution signal A/T position indicator signal (PNP switch signal)	
ECM	Transmits engine speed signal via CAN communication to transfer control unit.	

System Description

INFOID:0000000003296922

[TRANSFER: TX15B]

TRANSFER CONTROL DEVICE

Integrates actuator motor and actuator position switch.

Actuator Motor

Moves shift rods when signaled by transfer control unit.

Actuator Position Switch

Detects actuator motor position and then sends signal to transfer control unit.

WAIT DETECTION SWITCH

Detects if transfer case is in 4WD by the 2-4 shift fork position.

NOTE:

If 4WD shift switch is switched to 4H or 4LO and the transfer case is not in 4WD completely, the wait detection system will operate.

4LO SWITCH

4LO switch detects if the transfer case is in 4LO by the position of the L-H shift fork.

ATP SWITCH (A/T MODELS)

ATP switch detects if transfer case is in neutral by the position of the L-H shift fork.

NOTE:

Transfer case may be in neutral when shifting between 4H-4LO.

PNP SWITCH (M/T models)

PNP switch detects if manual transmission is under neutral condition.

TRANSFER CONTROL UNIT

Transfer control unit controls transfer control device and it directs shifts from 4H-4LO and 2WD-4WD.

Self-diagnosis can be done.

TRANSFER SHIFT HIGH AND LOW RELAYS

Transfer shift high and low relays apply power supply to transfer control device (actuator motor).

TRANSFER SHUT OFF RELAYS

Transfer shut off relays 1 and 2 apply power supply to transfer control unit.

4WD SHIFT SWITCH AND INDICATOR LAMP

Е

DLN

Α

В

F

G

Н

K

IVI

Ν

O

AMD at its audit to	Indicator	lamp			
4WD shift switch	4WD shift	4LO	Operation of 4WD shift switch	Use condition	
2WD		OFF	2WD⇔4H switching can be done while driving. The indicator lamp will change when the driving mode is changed. Gear shift in between 2WD⇔4H position	For driving on dry, paved roads.	
4H		OFF	must be performed at speeds below 100 km/h (60 MPH). For driving on rough, sandy or snow-covered roads.	, ,	
		Flashing	For M/T models, to shift between 4H⇔4LO, stop the vehicle and shift the transmission shift lever to the Neutral position with the clutch pedal depressed. For A/T models, to shift between 4H⇔4LO, stop the vehicle and shift the transmission selector to the "N"	The 4LO indicator lamp flashes when shifting between 4LO⇔4H.	
4LO	O _T O	ON	position with the brake pedal depressed. Depressed and turn the 4WD shift switch. For use when maximum por traction is required at low sp	For use when maximum power and traction is required at low speeds (for example on step grades or rockey, sandy, muddy roads.).	

SDIA3290E

[TRANSFER: TX15B]

4WD Shift Switch

4WD shift switch is able to select from 2WD, 4H or 4LO.

4WD Shift Indicator Lamp

- Displays driving conditions selected by the 4WD shift switch while engine is running. When the 4WD warning lamp is turned on, all 4WD shift indicator lamps will turn off.
- Turns ON when ignition switch is turned ON, for purpose of lamp check. Turns OFF approximately for 1 second after the engine starts if system is normal.

4LO Indicator Lamp

- Displays 4LO while engine is running. 4LO indicator lamp flashes if transfer gear does not shift completely into 4H⇔4LO. In this condition, the transfer case may be in neutral and the A/T parking mechanism may not operate.
- Turns ON when ignition switch is turned ON, for purpose of lamp check. Turns OFF approximately for 1 second after the engine starts if system is normal.

4WD WARNING LAMP

Turns on or flashes when there is a malfunction in 4WD system.

Also turns on when ignition switch is turned ON, for purpose of lamp check. Turns OFF approximately for 1 second after the engine starts if system is normal.

4WD Warning Lamp Indication

Condition	4WD warning lamp	
System normal	OFF	
Lamp check	Turns ON when ignition switch is turned ON. Turns OFF after engine start.	
4WD system malfunction	ON	
During self-diagnosis	Flashes malfunction mode.	
Large difference in diameter of front/ rear tires	Flashes slow (1 flash / 2 seconds) (Continues to flash until the ignition switch is turned OFF)	

ATP WARNING LAMP (A/T MODELS)

[TRANSFER: TX15B]

When the A/T selector lever is in "P" position, the vehicle may move if the transfer case is in neutral. ATP warning lamp is turned on to indicate this condition to the driver.

Component Parts Location

INFOID:0000000003297018

8 (7)1

2 1 7 8 ©

WDIA0345E

- Fuse and relay box
 - A: Transfer shut off relay 1 E156
 - B: Transfer shift high relay E46
 - C: Transfer shift low relay E47
 - D: Transfer shut off relay 2 E157
- A: ATP switch F55 (A/T models) B: 4 LO switch F60 (View with front propeller shaft removed.)
- Wait detection switch F59

DLN-13

DLN

Α

В

C

Е

Н

K

M

Ν

0

- [TRANSFER: TX15B]
- - Combination meter M24 A: 4WD warning lamp
 - B: 4LO indicator lamp
 - C: 4WD shift indicator lamp

Transfer control device F58

- D: ATP warning lamp (A/T models)
- Transfer control unit M152, M153 (View with lower instrument panel LH removed.)
- 8. 4WD shift switch M141
- Park/neutral position switch F66 (M/T models)


CAN Communication

Refer to LAN-4, "System Description".

Cross-Sectional View

INFOID:0000000003296925

INFOID:0000000003296924



SDIA3418E


- Mainshaft 1.
- Clutch gear 4.
- 7. Drive chain
- 10. L-H sleeve
- 13. Planetary carrier assembly
- Control shift rod A/T
- 19. Control shift rod M/T

- 2. Rear case
- 2-4 shift fork
- Sprocket
- 11. Internal gear
- Sun gear assembly
- 17. Companion flange
- 20. Transfer control device

- Oil pump assembly
- 2-4 sleeve 6.
- L-H shift fork
- 12. Front case
- 15. L-H shift rod
- 18. Front drive shaft

[TRANSFER: TX15B] Power Transfer

POWER TRANSFER DIAGRAM



- Mainshaft
- Drive chain 4.
- Planetary carrier assembly
- 2. Clutch gear
- 5. Sprocket
- Sun gear assembly
- 2-4 sleeve 3.
- L-H sleeve 6.
- Front drive shaft

POWER TRANSFER FLOW

Н

G

INFOID:0000000003296926

Α

В

C

DLN

Е

F


Κ

M

Ν

0

[TRANSFER: TX15B]



DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

CONSULT-III Function (ALL MODE AWD/4WD)

INFOID:0000000003296927

[TRANSFER: TX15B]

FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

ALL MODE AWD/4WD diagnostic mode	Description
SELF-DIAG RESULTS	Displays transfer control unit self-diagnosis results.
DATA MONITOR	Displays transfer control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
ECU PART NUMBER	Transfer control unit part number can be read.

DLN

Е

F

Н

Α

В

SELF-DIAG RESULT MODE

Operation Procedure

- 1. Connect "CONSULT-III".
- With engine at idle, touch "SELF-DIAG RESULTS".
 Display shows malfunction experienced since the last erasing operation.

NOTE:

The details for "TIME" are as follows:

- "0": Error currently detected with transfer control unit.
- Except for "0": Error detected in the past and memorized with transfer control unit.
 Detects frequency of driving after DTC occurs (frequency of turning ignition switch "ON/OFF").

How to Erase Self-diagnostic Results

- 1. Perform applicable inspection of malfunctioning item and then repair or replace.
- 2. Start engine and select "SELF-DIAG RESULTS" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Touch "ERASE" on CONSULT-III screen to erase DTC memory. CAUTION:

If memory cannot be erased, perform applicable diagnosis.

K

Description

If the engine starts when there is something wrong with the 4WD system, the 4WD warning lamp turns ON or flickers in the combination meter. When the system functions properly, the warning lamp turns ON when the ignition switch is turned to "ON", and it turns OFF after engine starts. To locate the cause of a problem, start the self-diagnosis function. The 4WD warning lamp in the combination meter will indicate the problem area by flickering according to the self-diagnostic results. Refer to DLN-67, "DTC Index".

Diagnostic Procedure (A/T models)

- 1. Warm up engine.
- 2. Turn ignition switch "ON" and "OFF" at least twice, and then turn ignition switch "OFF".
- 3. Move A/T selector lever to "P" position.
- 4. Turn 4WD shift switch to "2WD" position.
- 5. Turn ignition switch "ON". (Do not start engine.)
- 4WD warning lamp should turn ON.
 If 4WD warning lamp does not turn ON, refer to <u>DLN-71, "Diagnosis Procedure"</u>.
- 7. Move A/T selector lever to "R" position.
- 8. Turn 4WD shift switch to "2WD", "4H" and "2WD" in order.
- 9. Move A/T selector lever to "P" position.
- 10. Turn 4WD shift switch to "4H", "2WD" and "4H" in order.
- 11. Move A/T selector lever to "N" position.
- 12. Turn 4WD shift switch to "2WD" position.
- 13. Move A/T selector lever to "P" position.

M

N

Р

DLN-17

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)


< FUNCTION DIAGNOSIS >

14. Read the flickering of 4WD warning lamp. Refer to "Judgement Self-diagnosis".

Diagnostic Procedure (M/T models)

- Warm up engine.
- Turn ignition switch "ON" and "OFF" at least twice, and then turn ignition switch "OFF".
- 3. Move M/T shift lever to neutral position.
- 4. Turn 4WD shift switch to "2WD" position.
- 5. Turn ignition switch "ON". (Do not start engine.)
- 4WD warning lamp should turn ON.
 If 4WD warning lamp does not turn ON, refer to <u>DLN-71, "Diagnosis Procedure"</u>.
- 7. Move M/T shift lever to any position other than neutral.
- 8. Turn 4WD shift switch to "2WD", "4H" and "2WD" in order.
- Move M/T shift lever to neutral position.
- 10. Turn 4WD shift switch to "4H", "2WD" and "4H" in order.
- 11. Move M/T shift lever to any position other than neutral.
- 12. Turn 4WD shift switch to "2WD" position.
- Move M/T shift lever to neutral position.
- 14. Read the flickering of 4WD warning lamp. Refer to "Judgement Self-diagnosis".

Self-diagnosis example



DATA MONITOR MODE

Operation Procedure

- 1. Connect "CONSULT-III."
- Touch "DATA MONITOR".
- 3. Select from "SELECT MONITOR ITEM", screen of data monitor mode is displayed.

NOTE:

When malfunction is detected, CONSULT-III performs REAL-TIME DIAGNOSIS. Also, any malfunction detected while in this mode will be displayed at real time.

Display Item List

x: Standard -: Not applicable

[TRANSFER: TX15B]

	Monitor item selection			_
Monitored item (Unit)	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	Remarks
VHCL/S SEN-FR [km/h] or [mph]	×	_	×	Wheel speed calculated by ABS actuator and electric unit (control unit). Signal input with CAN communication line.
VHCL/S SEN-RR [km/h] or [mph]	×	_	×	Wheel speed calculated by TCM. Signal input with CAN communication line.
ENGINE SPEED [rpm]	×	_	×	Engine speed is displayed. Signal input with CAN communication line.

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT) [TRANSFER: TX15B]

< FUNCTION DIAGNOSIS >

	Me	onitor item select	tion	
Monitored item (Unit)	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	Remarks
BATTERY VOLT [V]	×	-	×	Power supply voltage for transfer control unit.
2WD SWITCH [ON/OFF]	×	-	×	
4H SWITCH [ON/OFF]	×	-	×	4WD shift switch signal status is displayed (4L means 4LO of 4WD shift switch.)
4L SWITCH [ON/OFF]	×	-	×	(12 means 128 of 1112 drink simoni,
4L POSI SW [ON/OFF]	×	_	×	4LO switch signal status is displayed.
ATP SWITCH [ON/OFF]	×	-	×	ATP switch signal status is displayed.
WAIT DETCT SW [ON/OFF]	×	-	×	Wait detection switch signal status is displayed.
4WD MODE [2H/4H/4L]	_	×	×	Control status of 4WD recognized by transfer control unit. (2WD, 4H or 4LO)
VHCL/S COMP [km/h] or [mph]	_	×	×	Vehicle speed recognized by transfer control unit.
SHIFT ACT 1 [ON/OFF]	-	×	×	Output condition to actuator motor (clockwise)
SHIFT AC MON 1 [ON/OFF]	_	-	×	Check signal for transfer control unit signa output
SHIFT ACT 2 [ON/OFF]	_	×	×	Output condition to actuator motor (counterclockwise)
SHIFT AC MON 2 [ON/OFF]	_	-	×	Check signal for transfer control unit signa output
SFT ACT/R MON [ON/OFF]	_	-	×	Operating condition of actuator motor relay (integrated in transfer control unit)
SHIFT POS SW 1 [ON/OFF]	×	_	×	Condition of actuator position switch 1
SHIFT POS SW 2 [ON/OFF]	×	-	×	Condition of actuator position switch 2
SHIFT POS SW 3 [ON/OFF]	×	-	×	Condition of actuator position switch 3
SHIFT POS SW 4 [ON/OFF]	×	-	×	Condition of actuator position switch 4
4WD FAIL LAMP [ON/OFF]	-	×	×	Control status of 4WD warning lamp is dis played.
2WD IND [ON/OFF]	-	-	×	Control status of 4WD shift indicator lamp (rear) is displayed.
4H IND [ON/OFF]	-	-	×	Control status of 4WD shift indicator lamp (front and center) is displayed.
4L IND [ON/OFF]	_	-	×	Control status of 4LO indicator lamp is displayed.

Α

В

С

DLN

Е

F

G

Н

J

Κ

L

 \mathbb{N}

Ν

0

Ρ

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[TRANSFER: TX15B]

INFOID:0000000003296928

< FUNCTION DIAGNOSIS >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference page	•		DLN-91			DLN-110		DLN-110	DLN-110	DLN-110
SUSPECTED F (Possible cause		TRANSFER FLUID (Level low)	TRANSFER FLUID (Wrong)	TRANSFER FLUID (Level too high)	LIQUID GASKET (Damaged)	O-RING (Worn or damaged)	OIL SEAL (Worn or damaged)	SHIFT FORK (Worn or damaged)	GEAR (Worn or damaged)	BEARING (Worn or damaged)
	Noise	1	2						3	3
Symptom	Transfer fluid leakage		3	1	2	2	2			
	Hard to shift or will not shift		1	1				2		

P1801, P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

P1801, P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

Description

The transfer control unit controls the transfer control device which controls shifts between 4H and 4LO and between 2WD and 4WD. When the vehicle battery is removed, the power supply to the transfer control unit is interupted, and self-diagnosis memory function is suspended. These DTC's may also set when the power supply voltage for the transfer control unit is abnormally low while driving.

DTC Logic

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1801]	*INITIAL START*	Due to removal of battery which cuts off power supply to transfer control unit, self-diagnosis memory function is suspended.	DLN-21
[P1811]	BATTERY VOLTAGE	Power supply voltage for transfer control unit is abnormally low while driving.	

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- 2. Perform self-diagnosis.

Are DTC's "P1801 or P1811 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-21, "Diagnosis Procedure"</u>.


NO >> Inspection End.

Diagnosis Procedure

1. CHECK POWER SUPPLY

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect transfer control unit harness connector.
- Check voltage between transfer control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M152	19 - Ground	Battery voltage
WIJZ	25 - Ground	0V
	40 - Ground	Battery voltage
M153	44 - Ground	0V
	45 - Ground	UV



DLN

Е

F

Α

В

[TRANSFER: TX15B]

Н

. .

INFOID:0000000003296931

L

K

M

. .


Ν

P1801, P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< COMPONENT DIAGNOSIS >

- 4. Turn ignition switch "ON". (Do not start engine.)
- 5. Check voltage between transfer control unit harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M152	19 - Ground	
101132	25 - Ground	
	40 - Ground	Battery voltage
M153	44 - Ground	
	45 - Ground	



ITRANSFER: TX15B1

Is there voltage?

YES >> GO TO 2.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

- 40A fuse (No. j, located in the fuse and fusible link box).
 - 10A fuses (No. 21, located in the fuse block (J/B) and Nos. 60 and 61 located in the fuse and relay box).
 - Harness for short or open between battery and transfer control unit harness connector M152 terminal 19.
 - Harness for short or open between battery and transfer shut off relay 2 harness connector E157 terminal 1 and 3.
 - Harness for short or open between battery and transfer shut off relay 1 harness connector E156 terminal 3.
 - Harness for short or open between ignition switch and transfer control unit harness connector M152 terminal 25.
 - Harness for short or open between ignition switch and transfer shut off relay 1 harness connector E156 terminal 1.
 - Harness for short or open between transfer shut off relay 2 harness connector E157 terminal 5 and transfer control unit harness connector M153 terminals 44, 45.
 - Harness for short or open between transfer shut off relay 1 harness connector E156 terminal 5 and transfer control unit harness connector M153 terminals 44, 45.
 - Harness for short or open between transfer shut off relay 2 harness connector E157 terminal 2 and transfer control unit harness connector M153 terminal 40.
 - Harness for open between transfer shut off relay 1 harness connector E156 terminal 2 and ground.
 - Battery and ignition switch.
 - Transfer shut off relay 1, 2. Refer to <u>DLN-23, "Component Inspection"</u>.

2.CHECK GROUND CIRCUIT

- 1. Turn ignition switch "OFF".
- Disconnect transfer control unit harness connector.
- Check continuity between transfer control unit harness connector M152 terminals 6 (M/T models) and 18, and M153 terminal 32 and ground.

Continuity should exist.

Also check harness for short to power.

Do you have continuity?

YES >> GO TO 3.


NO >> Repair open circuit or short to power in harness or connectors.

3. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 4.



P1801, P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< COMPONENT DIAGNOSIS >

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

4.CHECK DTC

Drive vehicle and then perform Self-diagnosis.

Do DTC's P1801 or P1811 display?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".

NO >> Inspection End.

Component Inspection


INFOID:0000000003296932

[TRANSFER: TX15B]

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Remove transfer shut off relay 1 and transfer shut off relay 2. Refer to <u>DLN-23, "Component Inspection"</u>.
- Apply 12V direct current between transfer shut off relay terminals 1 and 2.
- 4. Check continuity between relay terminals 3 and 5.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

5. If inspection results are not normal, replace the transfer shut off relay 1 or 2.



DLN

Α

В

Е

F

G

Н

J

K

L

M

Ν

0

P1802 – P1804, P1809 TRANSFER CONTROL UNIT

[TRANSFER: TX15B]

< COMPONENT DIAGNOSIS >

P1802 - P1804, P1809 TRANSFER CONTROL UNIT

Description INFOID:0000000003296933

The transfer control unit controls the transfer control device which controls shifts between 4H and 4LO and between 2WD and 4WD. A DTC may set when any of the following occur:

- Malfunction is detected in the memory (RAM) system of transfer control unit.
- Malfunction is detected in the memory (ROM) system of transfer control unit.
- Malfunction is detected in the memory (EEPROM) system of transfer control unit.
- AD converter system of transfer control unit is malfunctioning.

DTC Logic INFOID:0000000003296934

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1802]	CONTROL UNIT 1	Malfunction is detected in the memory (RAM) system of transfer control unit.	
[P1803]	CONTROL UNIT 2	Malfunction is detected in the memory (ROM) system of transfer control unit.	
[P1804]	CONTROL UNIT 3	Malfunction is detected in the memory (EEPROM) system of transfer control unit.	DLN-24
[P1809]	CONTROL UNIT 4	AD converter system of transfer control unit is malfunctioning.	

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Are DTC's "P1802 - P1804 or P1809 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-24, "Diagnosis Procedure"</u>.

NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000003296935

1.INSPECTION START

Do you have CONSULT-III?

YES or NO

YES >> GO TO 2.

NO >> GO TO 3.

2.perform self-diagnosis (with consult-iii)

- Turn ignition switch "ON".
- Select "SELF-DIAG RESULTS" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Touch "ERASE".
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Perform the self-diagnosis again.

Is the "CONTROL UNIT 1 [P1802]", "CONTROL UNIT 2 [P1803]", "CONTROL UNIT 3 [P1804]" or CONTROL UNIT 4 [P1809]" displayed?

>> Replace transfer control unit. Refer to DLN-92, "Removal and Installation".

NO >> Inspection End.

3.perform self-diagnosis (without consult-iii)

- Perform the self-diagnosis and then erase self-diagnostic results. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".
- Perform the self-diagnosis again.

P1802 - P1804, P1809 TRANSFER CONTROL UNIT

< COMPONENT DIAGNOSIS > [TRANSFER: TX15B]

Do the self-diagnostic results indicate AD converter?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".

NO >> Inspection End.

Α

В

С

DLN

Е

F

G

Н

1

J

Κ

L

M

Ν

0

P1807 VEHICLE SPEED SENSOR (A/T)

[TRANSFER: TX15B]

INFOID:0000000003296938

< COMPONENT DIAGNOSIS >

P1807 VEHICLE SPEED SENSOR (A/T)

Description INFOID:000000003296936

The transmission control module (TCM) transmits the output shaft revolution signal via CAN communication to Transfer control unit. DTC P1807 will set when a malfunction is detected in the output shaft revolution signal or an improper signal is input while driving.

DTC Logic

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1807]	VHCL SPEED SEN-AT	 Malfunction is detected in output shaft revolution signalthat is output from TCM through CAN communication. Improper signal is input while driving. 	DLN-26

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- 2. Perform self-diagnosis.

Is DTC P1807 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-26, "Diagnosis Procedure"</u>.

NO >> Inspection End.

Diagnosis Procedure

1. CHECK DTC WITH TCM

Perform self-diagnosis with TCM. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 2.

2. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 3.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

3.CHECK DTC

Drive vehicle and then perform Self-diagnosis.

Is DTC P1807 displayed?

YES >> Perform self-diagnosis with TCM again.

NO >> Inspection End.

P1808 VEHICLE SPEED SENSOR (ABS)

< COMPONENT DIAGNOSIS >

P1808 VEHICLE SPEED SENSOR (ABS)

Description

The ABS actuator and electric unit (control unit) transmits a vehicle speed signal via CAN communication to the transfer control unit. DTC P1808 sets when a malfunction is detected in the vehicle speed signal that is output from the ABS actuator and electric unit (control unit) or an improper signal is input while driving.

DTC Logic

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1808]	VHCL SPEED SEN-ABS	 Malfunction is detected in vehicle speed signal that is output from ABS actuator and electric unit (control unit) through CAN communication. Improper signal is input while driving. 	DLN-27

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- 2. Perform self-diagnosis.

Is DTC "P1808 displayed?

YES >> Perform diagnosis procedure. Refer to <u>DLN-27</u>, "<u>Diagnosis Procedure</u>".

NO >> Inspection End.

Diagnosis Procedure

1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform self-diagnosis with ABS actuator and electric unit (control unit) for specific BRC system type.

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 2.

2. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to <u>DLN-54</u>, "Reference Value".

Are the inspection results normal?

YES >> GO TO 3.

>> Check transfer control unit pin terminals for damage or loose connection with harness connector.

If any items are damaged, repair or replace damaged parts.

3.CHECK DTC

NO

Drive vehicle and then perform Self-diagnosis.

Is DTC P1808 displayed?

YES >> Perform self-diagnosis with ABS actuator and electric unit (control unit) for specific BRC system type.

NO >> Inspection End.

Р

Ν

[TRANSFER: TX15B]

Α

DLN

Е

Н

INFOID:000000000329694

P1810 4 LO SWITCH

Description INFOID:0000000003296942

The 4LO switch detects that the transfer case is in 4LO range. DTC P1810 will set when an improper signal from the 4LO switch is input due to an open or short circuit.

DTC Logic INFOID:0000000003296943

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1810]	4L POSI SW TF	Improper signal from 4LO switch is input due to open or short circuit.	DLN-28

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Is DTC P1810 displayed?

YES >> Perform diagnosis procedure. Refer to <u>DLN-28</u>, "<u>Diagnosis Procedure</u>".

NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000003296944

[TRANSFER: TX15B]

${f 1}$.CHECK 4LO POSITION SWITCH SIGNAL

With CONSULT-III 1. Start engine.


- Start engine.
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Read out the value of "4L POSI SW".

Condition	Display value	
Vehicle stopped	4WD shift switch: 4LO	ON
Engine runningA/T selector lever "N" positionBrake pedal depressed	Except the above	OFF

Without CONSULT-III

- 1. Start engine.
- 2. Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Condition		Voltage (Approx.)
		Vehicle stopped	4WD shift switch: 4LO	0V
M152	24 - Ground	 Engine running A/T selector lever "N" position Brake pedal depressed 	Except the above	Battery voltage



Are the inspection results normal?

YES >> GO TO 5.

NO >> GO TO 2.

2.check harness between transfer control unit and 4Lo switch

Turn ignition switch "OFF". (Stay for at least 5 seconds.)

- Disconnect transfer control unit harness connector and the 4LO switch harness connector.
- 3. Check continuity between transfer control unit harness connector M152 terminal 24 and 4LO switch harness connector F60 terminal 13.

Continuity should exist.

Also check harness for short to ground and short to power.

Is there continuity?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK GROUND CIRCUIT

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect 4LO switch harness connector.
- 3. Check continuity between 4LO switch harness connector F60 terminal 12 and ground.

Continuity should exist.

Also check harness for short to power.

Is there continuity?

YES >> GO TO 4.

NO >> Repair open circuit or short to power in harness or connectors.

4LO switch connector PDIA0203E

4LO switch connector

Ω

4.CHECK 4LO SWITCH

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect 4LO switch harness connector.
- 3. Remove 4LO switch. Refer to DLN-13, "Component Parts Location".
- 4. Push and release 4LO switch and check continuity between 4LO switch terminals 12 and 13.

Terminal	Condition	Continuity
12 - 13	Push 4LO switch	Yes
12 - 13	Release 4LO switch	No

Are the inspection results normal?

YES >> GO TO 5.

NO >> Replace 4LO switch.

${f 5}$.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54. "Reference Value".

Are the inspection results normal?

YES >> GO TO 6.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.


6.check dtc

Drive the vehicle and then perform self-diagnosis.

Is DTC P1810 displayed?

YES >> Replace transfer control unit. Refer to DLN-13, "Component Parts Location".

NO >> Inspection End.



4LO switch connector

[TRANSFER: TX15B]

Transfer control unit connector

Α

В

DLN

Е

F

Н

SDIA3364E

K

M

Component Inspection


INFOID:0000000003296945

[TRANSFER: TX15B]

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect 4LO switch harness connector.
- 3. Remove 4LO switch. Refer to DLN-13, "Component Parts Location".
- 4. Push and release 4LO switch and check continuity between 4LO switch terminals 12 and 13.

Terminal	Condition	Continuity
12 - 13	Push 4LO switch	Yes
12 - 13	Release 4LO switch	No

5. If the inspection results are not normal replace the 4LO switch.



P1813 4WD SHIFT SWITCH

< COMPONENT DIAGNOSIS >

P1813 4WD SHIFT SWITCH

Description INFOID:0000000003296946

The 4WD shift switch allows the driver to select 2WD or 4WD and 4H or 4LO. DTC P1813 will set if more than two switch inputs are simultaneously detected by the transfer control unit due to a short circuit in the 4WD shift switch.

DTC Logic INFOID:0000000003296947

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1813]	4WD MODE SW	More than two switch inputs are simultaneously detected due to short circuit of 4WD shift switch.	DLN-31

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis. 2.

Is DTC P1813 displayed?

>> Perform diagnosis procedure. Refer to <u>DLN-31, "Diagnosis Procedure"</u>. YES

NO >> Inspection End.

Diagnosis Procedure

1. CHECK 4WD SHIFT SWITCH SIGNAL


With CONSULT-IIITurn ignition sv

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Read out ON/OFF switching action of the "2WD SWITCH", "4H SWITCH", "4L SWITCH" with operating 4WD shift switch.

Without CONSULT-III

- Turn ignition switch "ON".
- 2. Check voltage between transfer control unit harness connector terminals and ground.

Connector	Terminal	Condition	Voltage (Approx.)
	14 - Ground	4WD shift switch: 2WD	Battery voltage
	14 - Ground	4WD shift switch: 4H and 4LO	0V
M152	15 - Ground	4WD shift switch: 4H	Battery voltage
W1132	15 - Glound	4WD shift switch: 2WD and 4LO	0V
	16 - Ground	4WD shift switch: 4LO	Battery voltage
	16 - Giodila	4WD shift switch: 2WD and 4H	0V



Are the inspection results normal?

YES >> GO TO 5. NO >> GO TO 2.

2.CHECK 4WD SHIFT SWITCH POWER SUPPLY CIRCUIT

Turn ignition switch "OFF". (Stay for at least 5 seconds.)

Α

DLN

F

Н

K

M

Ν

Р

INFOID:0000000003296948


[TRANSFER: TX15B]

DLN-31

< COMPONENT DIAGNOSIS >

- 2. Disconnect 4WD shift switch harness connector.
- Check voltage between 4WD shift switch harness connector terminal 1 and ground.

Connector	Terminal	Voltage (Approx.)
M141	1 - Ground	0V



[TRANSFER: TX15B]

- 4. Turn ignition switch "ON". (Do not start engine.)
- Check voltage between 4WD shift switch harness connector terminal 1 and ground.


Connector	Terminal	Voltage (Approx.)
M141	1 - Ground	Battery voltage

Is there voltage?

YES >> GO TO 3.

NO >

>> 1. Check harness for short or open between 4WD shift switch harness connector terminal 1 and transfer shut off relay 2 harness connector E157 terminal 5



Perform trouble diagnosis for power supply circuit. Refer to <u>DLN-21</u>, "<u>Diagnosis Procedure</u>".

3.check harness between 4wd shift switch and transfer control unit

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect transfer control unit harness connector and the 4WD shift switch harness connector.
- 3. Check continuity between the following terminals.
- Transfer control unit harness connector M152 terminal 14 and 4WD shift switch harness connector M141 terminal 3.
- Transfer control unit harness connector M152 terminal 15 and 4WD shift switch harness connector M141 terminal 5.
- Transfer control unit harness connector M152 terminal 16 and 4WD shift switch harness connector M141 terminal 6.

Continuity should exist.

Also check harness for short to ground and short to power.


Is there continuity?


YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK 4WD SHIFT SWITCH

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Remove 4WD shift switch harness connector.






P1813 4WD SHIFT SWITCH

< COMPONENT DIAGNOSIS >

Operate 4WD shift switch and check continuity between 4WD shift switch terminals.

Terminal	Condition	Continuity
1 - 3	4WD shift switch: 2WD	Yes
1-3	4WD shift switch: 4H and 4LO	No
1 - 5	4WD shift switch: 4H	Yes
1-3	4WD shift switch: 2WD and 4LO	No
1 - 6	4WD shift switch: 4LO	Yes
1-0	4WD shift switch: 2WD and 4H	No



[TRANSFER: TX15B]

Are the inspection results normal?

YES >> GO TO 5.

NO >> Replace 4WD shift switch.

CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 6.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

6.CHECK DTC

Drive the vehicle and then perform self-diagnosis.

Is DTC P1813 displayed?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".


NO >> Inspection End.

Component Inspection

1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)

- 2. Remove 4WD shift switch harness connector.
- Operate 4WD shift switch and check continuity between 4WD shift switch terminals.

Terminal	Condition	Continuity
1 - 3	4WD shift switch: 2WD	Yes
1-3	4WD shift switch: 4H and 4LO	No
1 - 5	4WD shift switch: 4H	Yes
1-3	4WD shift switch: 2WD and 4LO	No
1 - 6	4WD shift switch: 4LO	Yes
1 - 0	4WD shift switch: 2WD and 4H	No



4. If the inspection results are abnormal replace the 4WD shift switch.

Α

В

C

DLN

Е

1

INFOID:0000000003296949

K

L

M

Ν

0

P1814 WAIT DETECTION SWITCH

< COMPONENT DIAGNOSIS >

P1814 WAIT DETECTION SWITCH

Description INFOID:0000000003296950

The wait detection switch detects if the transfer case is in 4WD. DTC P1814 will set if an improper signal from the wait detection switch is input due to open or short circuit.

DTC Logic INFOID:0000000003296951

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1814]	4WD DETECT SWITCH	Improper signal from wait detection switch is input due to open or short circuit.	<u>DLN-34</u>

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Is DTC P1814 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-34, "Diagnosis Procedure"</u>.

>> Inspection End. NO

Diagnosis Procedure

INFOID:0000000003296952

${f 1}$.CHECK WAIT DETECTION SWITCH SIGNAL

With CONSULT-III 1. Start engine.


- Start engine.
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Read out the value of "WAIT DETCT SW".

Cond	Display value	
Vehicle stopped	4WD shift switch: 4H and 4LO	ON
Engine runningA/T selector lever "N" positionBrake pedal depressed	4WD shift switch: 2WD	OFF

Without CONSULT-III 1. Start engine.

- 2. Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Condition		Voltage (Approx.)
M152	17 - Ground	 Vehicle stopped Engine running A/T selector lever "N" position Brake pedal depressed 	4WD shift switch : 4H and 4LO	0V
			4WD shift switch: 2WD	Battery voltage



[TRANSFER: TX15B]

Are the inspection results normal?

YES >> GO TO 5. NO >> GO TO 2.

2.CHECK HARNESS BETWEEN TRANSFER CONTROL UNIT AND WAIT DETECTION SWITCH

P1814 WAIT DETECTION SWITCH

< COMPONENT DIAGNOSIS >

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect transfer control unit harness connector and the wait detection switch harness connector.
- 3. Check continuity between transfer control unit harness connector M152 terminal 17 and wait detection switch harness connector F59 terminal 10.

Continuity should exist.

Also check harness for short to ground and short to power.

Is there continuity?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK GROUND CIRCUIT

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect wait detection switch harness connector. 2.
- 3. Check continuity between wait detection switch harness connector F59 terminal 11 and ground.

Continuity should exist.

Also check harness for short to power.

Is there continuity?

>> GO TO 4. YES

NO >> Repair open circuit or short to power in harness or con-

Wait detection switch connector PDIA0207E

4. CHECK WAIT DETECTION SWITCH

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect wait detection switch harness connector.
- 3. Remove wait detection switch. Refer to DLN-13, "Component Parts Location".
- 4. Push and release wait detection switch and check continuity between wait detection switch terminals 10 and 11.

Terminal	Condition	Continuity
10 - 11	Push wait detection switch	Yes
10 - 11	Release wait detection switch	No

Are the inspection results normal?

YES >> GO TO 5.

NO >> Replace wait detection switch.

Wait detection switch connector PDIA0208F

5. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 6.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

6.CHECK DTC

Drive the vehicle and then perform self-diagnosis.

Is DTC P1814 displayed?

YES >> Replace transfer control unit. Refer to DLN-92, "Removal and Installation".

NO >> Inspection End. Transfer control unit connector Wait detection switch connector

[TRANSFER: TX15B]

Α

В

DLN

Н

M

Ν

Ρ

P1814 WAIT DETECTION SWITCH

< COMPONENT DIAGNOSIS >

Component Inspection


INFOID:0000000003296953

[TRANSFER: TX15B]

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect wait detection switch harness connector.
- 3. Remove wait detection switch. Refer to <u>DLN-13</u>, "Component Parts Location".
- 4. Push and release wait detection switch and check continuity between wait detection switch terminals 10 and 11.

Terminal	Condition	Continuity
10 - 11	Push wait detection switch	Yes
	Release wait detection switch	No

5. If the inspection results are abnormal replace the wait detection switch.



P1816 PNP SWITCH (A/T)

< COMPONENT DIAGNOSIS >

P1816 PNP SWITCH (A/T)

Description INFOID:0000000003296954

The A/T PNP switch transmits the A/T position indicator signal (PNP switch signal) via CAN communication to the transfer control unit. DTC P1816 will set when the A/T PNP switch signal is malfunctioning or there is a communication error.

DTC Logic INFOID:0000000003296955

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1816]	PNP SW/CIRC	When A/T PNP switch signal is malfunction or communication error between the vehicles.	

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- Perform self-diagnosis. 2.

Is DTC P1816 displayed?

>> Perform diagnosis procedure. Refer to <u>DLN-37</u>, "<u>Diagnosis Procedure</u>". YES

NO >> Inspection End.

Diagnosis Procedure

1. CHECK DTC WITH TCM

Perform self-diagnosis with TCM. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 2.

2.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

DLN-37

3. CHECK DTC

Drive the vehicle and then perform self-diagnosis.

Is DTC P1816 displayed?

YES >> Perform self-diagnosis with TCM again.

NO >> Inspection End.

Α

[TRANSFER: TX15B]

DLN

F

Н

INFOID:0000000003296956

K

M

Ν

P1816 PNP SWITCH (M/T)

Description INFOID:0000000003296957

The M/T PNP switch signals neutral position to the transfer control unit. DTC P1816 will set when the M/T PNP switch signal is malfunctioning.

DTC Logic INFOID:0000000003296958

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1816]	PNP SW/CIRC	When M/T PNP switch signal is malfunction.	DLN-38

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Is DTC P1816 displayed?

YES >> Perform diagnosis procedure. Refer to DLN-38, "Diagnosis Procedure".


NO >> Inspection End.

Diagnosis Procedure

1. CHECK PARK/NEUTRAL POSITION SWITCH SIGNAL

- Turn ignition switch ON.
- Check voltage between transfer control unit harness connector M152 terminal 33 and ground.

Connector	Terminal	Condition		Voltage (Approx.)
M152	52 33 - Ignition switch: ON	Ignition quitable ON	M/T shift lever neutral position	0V
W1132		Except the above	Battery voltage	



INFOID:0000000003296959

[TRANSFER: TX15B]

Is the inspection result normal?

YES >> GO TO 5. NO >> GO TO 2.

2.check harness between transfer control unit and park/neutral position switch

- Turn ignition switch OFF. (Stay for at least 5 seconds.)
- 2. Disconnect transfer control unit harness connector and the park/neutral position switch harness connec-
- Check continuity between transfer control unit harness connector M152 terminal 33 and park/neutral position switch harness connector F66 terminal 1.

Continuity should exist.


Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK GROUND CIRCUIT



P1816 PNP SWITCH (M/T)

< COMPONENT DIAGNOSIS >

- Turn ignition switch OFF. (Stay for at least 5 seconds.)
- Disconnect park/neutral position switch harness connector.
- Check continuity between park/neutral position switch harness connector F66 terminal 2 and ground.


Continuity should exist.

Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to power in harness or connectors.



[TRANSFER: TX15B]

DLN

4. CHECK PARK/NEUTRAL POSITION SWITCH

- Turn ignition switch OFF. (Stay for at least 5 seconds.)
- Remove park/neutral position switch. Refer to DLN-13, "Component Parts Location". 2.
- Push and release park/neutral position switch and check continuity between park/neutral position switch terminals 1 and 2.

Terminal	Condition	Continuity
	Push park/neutral position switch	Yes
1 - 2	Release park/neutral position switch	No

Park/neutral position switch 2 Ω WDIA0273E

Is the inspection result normal?

YES >> GO TO 5.

>> Replace park/neutral position switch. Refer to DLN-13, NO "Component Parts Location".

CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Is the inspection result normal?

YES >> Inspection End.


NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

Component Inspection

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect neutral position switch harness connector.
- Remove neutral position switch. Refer to <u>DLN-13, "Component Parts Location"</u>.
- Push and release neutral position switch and check continuity between neutral position switch terminals 1 and 2.

Terminal	Condition	Continuity
1 - 2	Push neutral position switch	Yes
1-2	Release neutral position switch	No

If NG, replace the neutral position switch.



В

Α

Н

INFOID:0000000003296960

N

M

< COMPONENT DIAGNOSIS >

P1817 ACTUATOR MOTOR

Description INFOID:0000000003296961

The actuator motor receives signals from the transfer control unit and controls shift rods which shift the transfer case. DTC P1817 will set when any of the following occur:

- Motor does not operate properly due to open or short circuit in actuator motor.
- Malfunction is detected in the actuator motor. (When 4WD shift switch is operated and actuator motor does not operate)
- Malfunction is detected in transfer shift high relay or transfer shift low relay.

DTC Logic

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1817]	SHIFT ACTUATOR	 Motor does not operate properly due to open or short circuit in actuator motor. Malfunction is detected in the actuator motor. (When 4WD shift switch is operated and actuator motor is not operated) Malfunction is detected in transfer shift high relay or transfer shift low relay. 	DLN-40

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

- 1. Turn ignition switch ON.
- 2. Perform self-diagnosis.

Is DTC P1817 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-40, "Diagnosis Procedure"</u>.

NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000003296963

[TRANSFER: TX15B]

${f 1}$.CHECK ACTUATOR MOTOR SIGNAL

(II) With CONSULT-III

- Start engine.
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- 3. Read out the value of "SHIFT ACT1", "SHIFT AC MON1", "SHIFT ACT2", "SHIFT AC MON2".


[TRANSFER:	TX15B]
------------	--------

Monitored item	Condition		Display value
SHIFT ACT1	4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO		ON
		Except the above	OFF
SHIFT AC MON1	Vehicle stoppedEngine run-	4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO	ON
	ning • A/T selector lever "N" position • Brake pedal	Except the above	OFF
SHIFT ACT2		4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD	ON
	depressed	Except the above	OFF
SHIFT AC MON2		4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD	ON
		Except the above	OFF

Without CONSULT-III 1. Start engine.

- 2. Depress brake pedal and stop vehicle.
- Set A/T selector lever to "N" position.
 Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal		Condition	Voltage (Approx.)
	28 - Ground	When 4WD shift switch is operated (While actuator motor is operating.)		Battery voltage → 0V
		When 4WD shift switch is not operated		0V
	31 - Ground	Always		0V
M153		Vehicle stopped Engine run-	4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO	0V
	42 - Ground ning A/T selector lever "N" position Brake pedal depressed	Except the above	Battery voltage	
	47 - Ground		4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO	Battery voltage → 0V
		Vehicle stopped	Except the above	0V
M153	• Engine run- ning • A/T selector lever "N" po-	4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD	Battery voltage → 0V	
		lever "N" po-	Except the above	0V
	50 -	Brake pedal depressed	4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD	0V
	Ground		Except the above	Battery voltage



Α

В

С

DLN

Е

G

L

M

Ν

0

< COMPONENT DIAGNOSIS >

Are the inspection results normal?


YES >> GO TO 9.

NO >> GO TO 2.

2.CHECK ACTUATOR MOTOR POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF". (Stay for at least 5 seconds.) Disconnect transfer control unit harness connector.
- 2.
- Check voltage between transfer control unit harness connector terminal 27 and ground.

Connector	Terminal	Voltage (Approx.)
M153	27 - Ground	0V



[TRANSFER: TX15B]

- Turn ignition switch "ON".
- Check voltage between transfer control unit harness connector terminal 27 and ground.

Connector	Terminal	Voltage (Approx.)
M153	27 - Ground	Battery voltage

Are the inspection results normal?

YES >> GO TO 3.

NO >> 1. Check harness for short or open between transfer control unit harness connector M153 terminal 27 and transfer shut off relay 2 harness connector


> E157 terminal 5 and 10A fuse (No. 57, located in the fuse and relay block). If any items are damaged, repair or replace damaged parts.


2. Perform trouble diagnosis for power supply circuit. Refer to <u>DLN-21, "Diagnosis Procedure"</u>.

3.check transfer relay power supply circuit

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Remove transfer shift high relay and transfer shift low relay. Refer to DLN-13, "Component Parts Loca-2. tion".
- Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Voltage (Approx.)
E46	2 - Ground	0V
E47	2 - Ground	0V





< COMPONENT DIAGNOSIS >

- Turn ignition switch "ON". (Do not start engine.)
- Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Voltage (Approx.)
E46	2 - Ground	Battery voltage
E47	2 - Ground	Battery voltage

E\$7 Transfer shift Transfer shift high relay low relay SDIA3385E

[TRANSFER: TX15B]

Are the inspection results normal?

YES >> GO TO 4.


NO

- >> Check the following. If any items are damaged, repair or replace damaged parts.
 - Harness for short or open between transfer control unit harness connector terminal 27 and transfer shift high relay harness connector E46 terminal 2.
 - · Harness for short or open between transfer control unit harness connector terminal 27 and transfer shift low relay harness connector terminal E47 terminal 2.

4.CHECK TRANSFER RELAY

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Remove transfer shift high relay and transfer shift low relay.
- 3. Apply 12V direct current between transfer shift high and low relay terminals 1 and 2.
- Check continuity between relay terminals 3 and 4, 3 and 5.

Terminal	Condition	Continuity
3 - 4	12V direct current supply between terminals 1 and 2	No
3-4	OFF	Yes
3 - 5	12V direct current supply between terminals 1 and 2	Yes
3-5	OFF	No



Are the inspection results normal?

YES >> GO TO 5.

NO >> Replace the transfer shift high or low relay.

${f 5.}$ CHECK (1): HARNESS BETWEEN TRANSFER CONTROL UNIT AND TRANSFER SHIFT RELAY

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector. 2.
- 3. Remove transfer shift high relay and transfer shift low relay.
- 4. Check continuity between the following terminals.
- Transfer control unit harness connector M153 terminal 42 and transfer shift high relay harness connector E46 terminal 1.
- Transfer control unit harness connector M153 terminal 50 and transfer shift low relay harness connector E47 terminal 1.

Continuity should exist.

Also check harness for short to ground and short to power.


Is there continuity?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

$oldsymbol{6}$.CHECK (2): HARNESS BETWEEN TRANSFER CONTROL UNIT AND TRANSFER SHIFT RELAY

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector. 2.
- Remove transfer shift high relay and transfer shift low relay.



Transfer control unit Transfer shift Transfer shift connector low relay high relay Ω SDIA3386E

Α

В

DLN

Е

K

L

N

< COMPONENT DIAGNOSIS >

- 4. Check continuity between the following terminals.
- Transfer control unit harness connector M153 terminal 28 and transfer shift high relay harness connector E46 terminal 5.
- Transfer control unit harness connector M153 terminal 28 and transfer shift low relay harness connector E47 terminal 5.
- Transfer control unit harness connector M153 terminal 31 and transfer shift high relay harness connector E46 terminal 4.
- Transfer control unit harness connector M153 terminal 31 and transfer shift low relay harness connector E47 terminal 4.

Transfer control unit connector high relay low relay SDIA3387E

[TRANSFER: TX15B]

Continuity should exist.

Also check harness for short to ground and short to power.


Is there continuity?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.

7.CHECK ACTUATOR MOTOR OPERATION CIRCUIT

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector and the transfer control device (actuator motor) harness connector.
- 3. Check continuity between the following terminals.
- Transfer control unit harness connector M153 terminal 47 and transfer control device (actuator motor) harness connector F58 terminal 23.
- Transfer control unit harness connector M153 terminal 48 and transfer control device (actuator motor) harness connector F58 terminal 24.



- Transfer control device (actuator motor) harness connector F58 terminal 24 and transfer shift high relay harness connector E46 terminal 3.
- Transfer control device (actuator motor) harness connector F58 terminal 23 and transfer shift low relay harness connector E47 terminal 3.

Continuity should exist.

Also check harness for short to ground and short to power.


Is there continuity?

YES >> GO TO 8.

NO >> Repair or replace damaged parts.

8. CHECK ACTUATOR MOTOR

1. Remove transfer control device. Refer to DLN-97, "Removal and Installation".



< COMPONENT DIAGNOSIS >

Check operation by applying battery voltage to transfer control device (actuator motor) terminals 23 and 24.

CAUTION:

Be careful not to overheat the harness.

Terminal	Actuator motor
24 (Battery voltage) - 23 (Ground)	Clockwise rotate
23 (Battery voltage) - 24 (Ground)	Counterclockwise rotate

Transfer control device (actuator motor) connector FUSE BAI SDIA2386E

[TRANSFER: TX15B]

Does actuator motor rotate?

YES >> GO TO 9.

NO >> Replace transfer control device (actuator motor).

9. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 10.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

10.CHECK DTC

Perform the self-diagnosis, after driving a vehicle for a while.

Is DTC P1817 displayed?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".

NO >> Inspection End.

Component Inspection

ACUTATOR MOTOR

- Remove transfer control device. Refer to DLN-97. "Removal and Installation".
- 2. Check operation by applying battery voltage to transfer control device (actuator motor) terminals 23 and 24.

CAUTION:

Be careful not to overheat the harness.

Terminal	Actuator motor
24 (Battery voltage) - 23 (Ground)	Clockwise rotate
23 (Battery voltage) - 24 (Ground)	Counterclockwise rotate

If the inspection results are abnormal replace the transfer control device (actuator motor).

TRANSFER RELAY

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Remove transfer shift high relay and transfer shift low relay 2. Refer to <u>DLN-13</u>, "Component Parts Location".
- Apply 12V direct current between transfer shift high and low relay terminals 1 and 2.

Transfer control device

FUSE

BAT

(actuator motor) connector

DLN

Α

В

Е

Н

INFOID:0000000003296964

M

SDIA2386E


Ν

< COMPONENT DIAGNOSIS >

4. Check continuity between relay terminals 3 and 4, and 3 and 5.

Terminal	Condition	Continuity
2.4	12V direct current supply between terminals 1 and 2	No
3 - 4	OFF	Yes
3 - 5	12V direct current supply between terminals 1 and 2	Yes
3-5	OFF	No

5. If the inspection results are abnormal replace the transfer shift high or low relay.



[TRANSFER: TX15B]

P1818 ACTUATOR POSITION SWITCH

< COMPONENT DIAGNOSIS >

P1818 ACTUATOR POSITION SWITCH

Description INFOID:0000000003296965

The actuator position switch detects the current actuator motor range. DTC P1818 will set if either of the following occur:

- Improper signal from actuator position switch is input due to open or short circuit.
- Malfunction is detected in actuator position switch.

DTC Logic INFOID:0000000003296966

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1818]	SHIFT ACT POSI SW	 Improper signal from actuator position switch is input due to open or short cir- cuit. Malfunction is detected in actuator po- sition switch. 	<u>DLN-47</u>

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Is DTC P1818 detected?

YES >> Perform diagnosis procedure. Refer to DLN-47, "Diagnosis Procedure".

>> Inspection End. NO

Diagnosis Procedure

 ${f 1}$.CHECK ACTUATOR POSITION SWITCH SIGNAL

With CONSULT-III 1. Start engine.

- Start engine.
- 2. Depress brake pedal and stop vehicle.
- Set A/T selector lever to "N" position.
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Read out the value of "SHIFT POS SW1", "SHIFT POS SW2", "SHIFT POS SW3", "SHIFT POS SW4".

Monitored item	Condition	Display value
SHIFT POS SW1	4WD shift switch: 2WD and 4LO	ON
3HIFT FO3 3WT	4WD shift switch: 4H	OFF
SHIFT POS SW2	4WD shift switch: 4LO	ON
	4WD shift switch: 2WD and 4H	OFF
SHIFT POS SW3	4WD shift switch: 2WD and 4H	ON
31111 1 1 0 3 3 W 3	4WD shift switch: 4LO	OFF
SHIFT POS SW4	4WD shift switch: 4H and 4LO	ON
Jilli 1 1 03 3 W4	4WD shift switch: 2WD	OFF

Without CONSULT-III

- Start engine.
- 2. Depress brake pedal and stop vehicle.
- Set A/T selector lever to "N" position.

Н

K

Α

В

INFOID:0000000003296967

[TRANSFER: TX15B]

M


Ν

P1818 ACTUATOR POSITION SWITCH

< COMPONENT DIAGNOSIS >

 Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Condition	Voltage (Approx.)
	10 - Ground	4WD shift switch: 2WD and 4LO	0V
		4WD shift switch: 4H	Battery voltage
	11 - Ground	4WD shift switch: 4LO	0V
M152		4WD shift switch: 2WD and 4H	Battery voltage
	12 - Ground	4WD shift switch: 2WD and 4H	0V
		4WD shift switch: 4LO	Battery voltage
	13 - Ground	4WD shift switch: 4H and 4LO	0V
		4WD shift switch: 2WD	Battery voltage



Are the inspection results normal?

YES >> GO TO 4. NO >> GO TO 2.

2.CHECK HARNESS BETWEEN TRANSFER CONTROL UNIT AND ACTUATOR POSITION SWITCH

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect transfer control unit harness connector and the transfer control device (actuator position switch) harness connector.
- 3. Check continuity between the following terminals.
- Transfer control unit harness connector M152 terminal 10 and transfer control device (actuator position switch) harness connector F58 terminal 26.
- Transfer control unit harness connector M152 terminal 11 and transfer control device (actuator position switch) harness connector F58 terminal 20.
- Transfer control unit harness connector M152 terminal 12 and transfer control device (actuator position switch) harness connector F58 terminal 21.
- Transfer control unit harness connector M152 terminal 13 and transfer control device (actuator position switch) harness connector F58 terminal 25.

Transfer control unit connector (actuator position switch) connector 131211110 26 25 2120 20, 21, 25, 26

Continuity should exist.

Also check harness for short to ground and short to power.

Is there continuity?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)

P1818 ACTUATOR POSITION SWITCH

< COMPONENT DIAGNOSIS >

Check continuity between transfer control device (actuator position switch) harness connector F58 terminal 22 and ground.


Continuity should exist.

Also check harness for short to power.

Is there continuity?

YES >> GO TO 4.

NO >> Repair open circuit or short to power in harness or connectors.



[TRANSFER: TX15B]

4. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 5.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

5. CHECK DTC

Perform the self-diagnosis, after driving a vehicle for a while.

Is DTC P1818 displayed?

YES >> Replace transfer control device. Refer to <u>DLN-97</u>, "Removal and Installation".

NO >> Inspection End. DLN

Α

В

Е

F

Н

K

M

Ν

P1819 TRANSFER CONTROL DEVICE

Description INFOID:0000000003296968

The transfer control device integrates the actuator motor and actuator position switch. DTC P1819 will set if either of the following conditions exist:

- Malfunction occurs in transfer control device drive circuit.
- Malfunction is detected in transfer shut off relay 1 and transfer shut off relay 2.

DTC Logic INFOID:0000000003296969

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1819]	SHIFT ACT CIR	 Malfunction is detected in transfer shut off relay 1 and transfer shut off re- lay 2. Malfunction occurs in transfer control device drive circuit. 	<u>DLN-50</u>

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Perform self-diagnosis.

Is DTC P1819 detected?

YES >> Perform diagnosis procedure. Refer to DLN-50, "Diagnosis Procedure".

>> Inspection End. NO


Diagnosis Procedure

INFOID:0000000003296970

1. CHECK POWER SUPPLY

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector.
- Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Voltage (Approx.)	
M152	25 - Ground	- OV	
M153	27 - Ground	O V	



[TRANSFER: TX15B]

- Turn ignition switch "ON". (Do not start engine.)
- Check voltage between transfer control unit harness connector terminals and ground.


Connector	Terminal	Voltage (Approx.)	
M152	25 - Ground	- Battery voltage	
M153	27 - Ground	Dattery voltage	

Are the inspection results normal?

YES >> GO TO 2.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

• 10A fuse (No. 57, located in the fuse and relay box).



P1819 TRANSFER CONTROL DEVICE

< COMPONENT DIAGNOSIS >

- 40A fuse (No. J, located in the fuse and fusible link box).
- Harness for short or open between battery and transfer shut off relay 1 harness connector E156 terminal 3.
- Harness for short or open between transfer control unit harness connector M153 terminal 27 and transfer shut off relay 1 harness connector E156 terminal 5.
- Harness for short or open between ignition switch and transfer shut off relay 1 harness connector E156 terminal 1.
- Harness for short or open between transfer shut off relay 1 harness connector E156 terminal 2 and ground.
- · Harness for short or open between ignition switch and transfer control unit harness connector M152 terminal 25.
- · Battery and ignition switch.
- Transfer shut off relay 1. Refer to <u>DLN-23</u>, "Component Inspection".

2.check ground circuit

- Turn ignition switch "OFF".
- Disconnect transfer control unit harness connector.
- Check continuity between transfer control unit harness connector M153 terminal 32 and ground.

Continuity should exist.

Also check harness for short to power.

Is there continuity?

YES >> GO TO 3.


NO >> Repair open circuit or short to power in harness or connectors.

Transfer control unit connector

3.CHECK POWER SUPPLY SIGNAL

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Connect transfer control unit harness connector.
- Check voltage between transfer control unit harness connector terminal and ground.

_	Connector	Terminal	Voltage (Approx.)
	M153	40 - Ground	Battery voltage



- 4. Turn ignition switch "ON". (Do not start engine.)
- 5. Check voltage between transfer control unit harness connector terminal and ground.


Connector	Terminal	Voltage (Approx.)
M153	40 - Ground	OV

Are the inspection results normal?

YES >> GO TO 4.

NO

- >> Check the following. If any items are damaged, repair or replace damaged parts.
 - · Harness for short or open between battery and transfer shut off relay 2 harness connector E157 terminal 1.
 - Harness for short or open between transfer shut off relay 2 harness connector E157 terminal 2 and transfer control unit harness connector M153 terminal 40.
 - Transfer shut off relay 2.



[TRANSFER: TX15B]

В

DLN

Н

Transfer control unit connector

M

N

Р

SDIA2820E

P1819 TRANSFER CONTROL DEVICE

[TRANSFER: TX15B]

< COMPONENT DIAGNOSIS >

4. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 5 (With CONSULT-III) or GO TO 6 (Without CONSULT-III).

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

5. PERFORM SELF-DIAGNOSIS (WITH CONSULT-III)

(I) With CONSULT-III

- 1. Turn ignition switch "ON". (Do not start engine.)
- 2. Select "SELF-DIAG RESULTS" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Touch "ERASE".
- 4. Turn ignition switch "OFF" and wait at least 10 seconds.
- 5. Perform the self-diagnosis again.

Is the "SHIFT ACT CIR [P1819]" displayed?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".

NO >> Inspection End.

6.PERFORM SELF-DIAGNOSIS (WITHOUT CONSULT-III)

Without CONSULT-III 1. Perform the self-consultry.

- Perform the self-diagnosis and then erase self-diagnostic results. Refer to <u>DLN-17</u>, "<u>CONSULT-III Func-tion (ALL MODE AWD/4WD)</u>".
- 2. Perform the self-diagnosis again.

Do the self-diagnostic results indicate transfer control device?

YES >> Replace transfer control unit. Refer to <u>DLN-92</u>, "Removal and Installation".

NO >> Inspection End.

P1820 ENGINE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

P1820 ENGINE SPEED SIGNAL

Description INFOID:000000003296971

The ECM transmits the engine speed signal via CAN communication to the transfer control unit. DTC P1820 will set when either of the following occur:

- Malfunction is detected in engine speed signal that is output from the ECM.
- · Improper signal is input while driving.

DTC Logic

DTC DETECTION LOGIC

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1820]	ENGINE SPEED SIG	 Malfunction is detected in engine speed signal that is output from ECM through CAN communication. Improper signal is input while driving. 	DLN-53

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- 2. Perform self-diagnosis.

Is DTC P1820 detected?

YES >> Perform diagnosis procedure. Refer to <u>DLN-53, "Diagnosis Procedure"</u>.

NO >> Inspection End.

Diagnosis Procedure

1. CHECK DTC WITH ECM

Perform self-diagnosis with ECM. Refer to EC-63, "CONSULT-III Function (ENGINE)".

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 2.

2.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 3.

>> Check transfer control unit pin terminals for damage or loose connection with harness connector.

If any items are damaged, repair or replace damaged parts.

3. CHECK DTC

NO

Perform the self-diagnosis, after driving a vehicle for a while.

Is DTC P1820 displayed?

YES >> Perform self-diagnosis with ECM again.

NO >> Inspection End.

Р

Ν

[TRANSFER: TX15B]

Α

В

DLN

Е

Н

INFOID:0000000003296973

ECU DIAGNOSIS

TRANSFER CONTROL UNIT

Reference Value

VALUE ON THE DIAGNOSIS TOOL

CONSULT-III data monitor item


Monitored item [Unit]	Content	Con	dition	Display value			
		Vehicle stopped		0 km/h (0 mph)			
VHCL/S SEN·FR [km/h] or [mph]	Wheel speed (Front wheel)	Vehicle running CAUTION: Check air pressure of tire tion.	CAUTION: Check air pressure of tire under standard condi-				
		Vehicle stopped		0 km/h (0 mph)			
VHCL/S SEN·RR [km/h] or [mph]	Wheel speed (Rear wheel)	CAUTION: Check air pressure of tire under standard condi-		Approximately equal to the indication on speedometer (Inside of ±10%)			
		Engine stopped (Engine speed: Less than	400 rpm)	0 rpm			
ENGINE SPEED [rpm]	Engine speed	Engine running (Engine speed: 400 rpm or	more)	Approximately equal to the indication on tachometer			
BATTERY VOLT [V]	Power supply voltage for transfer control unit	Ignition switch: ON	Battery voltage				
OWD CWITCH ION/OFFI	Input condition from 4WD	4WD shift switch: 2WD	ON				
2WD SWITCH [ON/OFF]	shift switch	4WD shift switch: 4H and 4	OFF				
ALL CWITCH ION/OFFI	Input condition from 4WD	4WD shift switch: 4H	ON				
4H SWITCH [ON/OFF]	shift switch	4WD shift switch: 2WD and	4WD shift switch: 2WD and 4LO				
4L SWITCH [ON/OFF]	Input condition from 4WD	4WD shift switch: 4LO		ON			
4L 3WITCH [ON/OFF]	shift switch	4WD shift switch: 2WD and	d 4H	OFF			
		Vehicle stopped	4WD shift switch: 4LO	ON			
4L POSI SW [ON/OFF]	Condition of 4LO switch	Engine runningA/T selector lever "N" positionBrake pedal depressed	Except the above	OFF			
ATP SWITCH [ON/OFF]	Condition of ATP switch	Vehicle stoppedEngine runningA/T selector lever "N" position	4WD shift switch : 4H to 4LO or 4LO to 4H (While actuator motor is operating.)	ON			
		Brake pedal depressed	Except the above	OFF			
WAIT DETCT SW [ON/	Condition of wait detection	Vehicle stopped Engine running	4WD shift switch : 4H and 4LO	ON			
OFF]	switch	A/T selector lever "N" positionBrake pedal depressed	4WD shift switch: 2WD	OFF			
	Control status of 4WD	AMD all for the last	2WD	2H			
4WD MODE [2H/4H/4L]	(Output condition of 4WD shift indicator lamp and	4WD shift switch (Engine running)	4H	4H			
	4LO indicator lamp)		4LO	4L			

< ECU DIAGNOSIS > [TRANSFER: TX15B]

Monitored item [Unit]	Content	Con	dition	Display value	
		Vehicle stopped	0 km/h (0 mph)	1	
VHCL/S COMP [km/h] or [mph]	Vehicle speed	Vehicle running CAUTION: Check air pressure of tire tion.	e under standard condi-	Approximately equal to the indication on speedometer (Inside of ±10%)	[
SHIFT ACT 1 [ON/OFF]	Output condition to actuator motor (clockwise)	 Vehicle stopped Engine running A/T selector lever "N"	4WD shift switch : 2WD to 4H or 4H to 4LO or 2WD to 4LO	ON	(
	(positionBrake pedal depressed	Except the above	OFF	
SHIFT AC MON1 [ON/ OFF]	Check signal for transfer control unit signal output	Vehicle stoppedEngine runningA/T selector lever "N" position	4WD shift switch : 2WD to 4H or 4H to 4LO or 2WD to 4LO	ON	D
		Brake pedal depressed	Except the above	OFF	
SHIFT ACT 2 [ON/OFF]	Output condition to actuator motor (counterclock-	Vehicle stopped Engine running A/T selector lever "N"	4WD shift switch : 4LO to 4H or 4H to 2WD or 4LO to 2WD	ON	I
	wise)	positionBrake pedal depressed	Except the above	OFF	
SHIFT AC MON2 [ON/ OFF]	Check signal for transfer control unit signal output	 Vehicle stopped Engine running A/T selector lever "N"	4WD shift switch : 4LO to 4H or 4H to 2WD or 4LO to 2WD	ON	(
•	3	positionBrake pedal depressed	Except the above	OFF	
SHIFT ACT/R MON [ON/	Operating condition of ac-	Vehicle stopped Engine running A/T selector lever "N"	When 4WD shift switch is operated	ON	
OFF]	tuator motor relay (integrated in transfer control unit)	A/T selector lever "N" positionBrake pedal depressed	When 4WD shift switch is not operated	OFF	
SHIFT POS SW1 [ON/ OFF]	Condition of actuator position switch 1		4WD shift switch: 2WD and 4LO	ON	,
			4WD shift switch: 4H	OFF	
SHIFT POS SW2 [ON/	Condition of actuator posi-	Mal Sala area and	4WD shift switch: 4LO	ON	
OFF]	tion switch 2	Vehicle stoppedEngine runningA/T selector lever "N"	4WD shift switch: 2WD and 4H	OFF	
SHIFT POS SW3 [ON/ OFF]	Condition of actuator position switch 3	position • Brake pedal depressed	4WD shift switch: 2WD and 4H	ON	
	uon omion o		4WD shift switch: 4LO	OFF	
SHIFT POS SW4 [ON/ OFF]	Condition of actuator position switch 4		4WD shift switch: 4H and 4LO	ON	ľ
	uon ownon n		4WD shift switch: 2WD	OFF	
4WD FAIL LAMP [ON/	4WD warning lamp condi-	4WD warning lamp: ON		ON	1
OFF]	tion	4WD warning lamp: OFF	OFF		
2WD IND [ON/OFF]	Rear indicator of 4WD shift	Rear indicator of 4WD shif	ON	(
<u> </u>	indicator lamp condition	Rear indicator of 4WD shif	·	OFF	
4H IND [ON/OFF]	Front and center indicator of 4WD shift indicator lamp	Front and center indicator : ON	ON		
	condition	Front and center indicator : OFF	OFF		
4L IND [ON/OFF]	4LO indicator lamp condi-	4LO indicator lamp: ON	ON		
1	tion	4LO indicator lamp: OFF	OFF		

PHYSICAL VALUES

Terminal Layout



Terminal	Wire color	Item		Condition	Data (Approx.)			
1	L	CAN-H		-				
2	Р	CAN-L		_				
3	SB	K-LINE (CONSULT-III signal)		-				
6	В	Ground (M/T models)		0V				
10	LG	Actuator position quitab 1		4WD shift switch: 2WD and 4LO	0V			
10	LG	Actuator position switch 1		4WD shift switch: 4H	Battery voltage			
44	10/	Actuator position quitab 2	Vehicle stopped Fraince supplies	4WD shift switch: 4LO	0V			
11	W	Actuator position switch 2	Engine runningA/T selector le-	4WD shift switch: 2WD and 4H	Battery voltage			
40	DD	A-turtan a sitian suitab O	ver "N" position	4WD shift switch: 2WD and 4H	0V			
12	BR	Actuator position switch 3	 Brake pedal de- pressed 	4WD shift switch: 4LO	Battery voltage			
40			, , , , , , , , , , , , , , , , , , , ,	4WD shift switch: 4H and 4LO	0V			
13	L	Actuator position switch 4		4WD shift switch: 2WD	Battery voltage			
4.4		4)4/5 -1 :((- ':-1 (0)4/5)		4WD shift switch: 2WD	Battery voltage			
14	G	4WD shift switch (2WD)		4WD shift switch: 4H and 4LO	0V			
		0.415 1.77 1.7 (41.1)		4WD shift switch: 4H	Battery voltage			
15	0	4WD shift switch (4H)	Ignition switch: ON	4WD shift switch: 2WD and 4LO	0V			
				4WD shift switch: 4LO	Battery voltage			
16	W	4WD shift switch (4LO)		4WD shift switch: 2WD and 4H	0V			
			Vehicle stopped	4WD shift switch: 4H and 4LO	0V			
17	0	Wait detection switch	 Engine running A/T selector lever "N" position Brake pedal depressed 	4WD shift switch: 2WD	Battery voltage			
18	В	Ground		Always	0V			
10	Б	Power supply	Ignition switch: ON		Battery voltage			
19	R	(Memory back-up)	Ignition switch: OFF	•	Battery voltage			
23	R	ATP switch (A/T models)	Vehicle stopped Engine running A/T selector le-	4WD shift switch : 4H to 4LO or 4LO to 4H (While actuator motor is operating.)	OV			
		, ,	ver "N" • Brake pedal depressed	Except the above	Battery voltage			
			Vehicle stopped	4WD shift switch: 4LO	0V			
24	24 Y 4LO switch		Engine running A/T selector lever "N" position Brake pedal depressed	Except the above	Battery voltage			

< ECU DIAGNOSIS > [TRANSFER: TX15B]

Terminal	Wire color	Item		Condition	Data (Approx.)		
	COIOI		Ignition switch: ON	Ignition switch: ON			
25	W/G	Ignition switch monitor	Ignition switch: OFF	Battery voltage 0V			
			Ignition switch: ON	Battery voltage			
27	L	Actuator motor power supply	Ignition switch: OFF OFF)	Ignition switch: OFF (5 seconds after ingnition switch is turned			
28	SB	Actuator motor (+)	Vehicle stoppedEngine running				
			 A/T selector le- ver "N" position 	When 4WD shift switch is not operated	0V		
31	G	Actuator motor (-)	Brake pedal de- pressed	Always	0V		
32	В	Ground		Always	0V		
00	Р	Park/Neutral position switch	In airie a conitate ON	M/T shift lever neutral position	0V		
33	Р	(M/T models)	Ignition switch:ON	Except the above	Battery voltage		
25	V	4WD shift indicator lamp		Rear indicator of 4WD shift indicator lamp : ON	OV		
35	V	(Rear indicator)		Rear indicator of 4WD shift indicator lamp : OFF	Battery voltage		
36	BR	4WD shift indicator lamp		Front and center indicator of 4WD shift indicator lamp: ON	0V		
(Front and center ind	(Front and center indicator)	Engine running	Front and center indicator of 4WD shift indicator lamp: OFF	Battery voltage			
27	_	4LO indicator lamp		4LO indicator lamp: ON	0V		
37	0	4LO indicator lamp	4LO indicator lamp: OFF		Battery voltage		
20	OD	AMD	4WD warning lamp: ON		0V		
38	GR	4WD warning lamp		4WD warning lamp: OFF			
			Vehicle stoppedEngine running	4WD shift switch: 4H to 4LO or 4LO to 4H (While actuator motor is operating.)	Battery voltage		
39	LG	ATP warning lamp (A/T models)	A/T selector lever "P" position Brake pedal depressed	Except the above	0V		
			Ignition switch: ON		0V		
40	V	Transfer shut off relay	Ignition switch: OFF OFF)	(5 seconds after ingnition switch is turned	Battery voltage		
			Vehicle stoppedEngine running	4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO	0V		
42	LG	Transfer shift high relay	A/T selector lever "N" positionBrake pedal depressed	Except the above	Battery voltage		
			Ignition switch: ON		Battery voltage		
44	Υ	Power supply	Ignition switch: OFF OFF)	(5 seconds after ingnition switch is turned	OV		
			Ignition switch: ON		Battery voltage		
45	GR	Power supply	Ignition switch: OFF OFF)	(5 seconds after ingnition switch is turned	0V		

< ECU DIAGNOSIS > [TRANSFER: TX15B]

Terminal	Wire color	Item		Condition				
47	0	Transfer shift high relay monitor		4WD shift switch: 2WD to 4H or 4H to 4LO or 2WD to 4LO (while actuator motor is operating)	Battery voltage → 0V			
			Vehicle stopped	Except the above	0V			
48	R	Transfer shift low relay monitor	Engine runningA/T selector lever "N" positionBrake pedal de-	4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD (while actuator motor is operating)	Battery voltage → 0V			
			pressed	Except the above	0V			
50	Υ	Transfer shift low relay		4WD shift switch: 4LO to 4H or 4H to 2WD or 4LO to 2WD	0V			
				Except the above	Battery voltage			

CAUTION

When using a circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals. NOTE:

Data are reference value and are measured between each terminal and ground.


[TRANSFER: TX15B] < ECU DIAGNOSIS > Wiring Diagram

INFOID:0000000003296975

Α

В С DLN Е F G , M153 TRANSFER CONTROL UNIT (M152), Н E10 M6 J (E10) (M6) Κ DATA LINK CONNECTOR (M22) 216 9 L 10A 57 PART TIME 4WD SYSTEM 36 \mathbb{N} TRANSFER SHUT OFF RELAY 2 Ν E152 0 AWDWA0045G Р

AWDWA0046G



DLN

Е

F

G

Н

J


K

L

M

N

0



Connector Name DATA LINK CONNECTOR

M22

Connector No.

Connector Color | WHITE


[TRANSFER: TX15B]

PART TIME 4WD SYSTEM CONNECTORS


e 2	Connector Name FUSE BLOCK (J/B)	Connector No. M4
-----	---------------------------------	------------------


Connector Name | WIRE TO WIRE Connector Color WHITE

Connector No.










Signal Name

Color of Wire W/G Q

Terminal No. N 4


≯	
7	



W/G

<u>6</u>

Signal Name	ATP-	RUN START	ATP+	4WD FAIL	4WD (LOCK) INPUT	4WD (4LO) INPUT	4WD (2WD)INPUT
Color of Wire	ш	W/G	LG	GR	BR	0	^
Terminal No.	-	16	21	26	27	29	30



AWDIA0269GB


< ECU DIAGNOSIS > [TRANSFER: TX15B]

Signal Name	ı	ı	ı	I	
Color of Wire	0	œ	g	SB	
Terminal No.	24G	25G	71G	72G	

	_				_				_		_		_			_
Signal Name	ACTR SW2	ACTR SW3	ACTR SW4	WS DWS	WS H4	4L SW	4WD_POSITION_SW	GND	MEMOR B/U	=	=	-	MS-d1A	4L_POSITION_SW	MS_NDI	_
Color of Wire	M	BR	٦	G	0	>	0	В	В	_	_	-	В	Υ	W/G	ı
Terminal No.	11	12	13	14	15	16	17	18	19	50	21	22	23	24	25	56

			_											
52	TRANSFER CONTROL UNIT	WHITE	4 1 3 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Signal Name	CAN-H	CAN-L	K-LINE	ı	_	_	ı	ı	1	ACTR SW1
. M152			6 5 4 17 16 15 14 13 26 25 24 23 22	Color of Wire	_	Ь	SB	ı	I	I	ı	ı	ı	LG
Connector No.	Connector Name	Connector Color	斯 H.S.	Terminal No.	-	2	က	4	5	9	7	80	6	10

Signal Name	ı	1	ı	1	1	1	1	1	1	1	1	ı	1	
Color of Wire	٦	GR		BR	8	LG	>	0	В	Ь	>	\	ГG	
Terminal No.	36	12G	13G	14G	15G	16G	17G	18G	19G	20G	21G	22G	23G	



Connector No. M141 Connector Name AWD SHIET SWITCH	ΔΥ ΔΥ	45678	Signal Name	+	2WD	LOCK	4LO
. M141	lor GRAY	123	Color of Wire	>	G	0	×
Connector No.	Connector Color	H.S.	Terminal No.	-	က	2	9

AWDIA0270GB

Α

В

С

DLN

Е

F

G

Н

Κ

L

M

Ν

0

< ECU DIAGNOSIS >

[TRANSFER: TX15B]

Connector No.). E2	
Connector Name	ame WIRE	WIRE TO WIRE
Connector Color WHITE	olor WHIT	ш
H.S.	8 9 10 11 1	3
Terminal No.	Color of Wire	Signal Name
14	0	_
15	GR	-


Signal Name	-	_
Color of Wire	0	GR
Terminal No.	14	15

]									
	WIRE TO WIRE	<u> </u>	4 5 6 7 8 12 13 14 15 16	Signal Name	_	ı	ı	ı	I	ı	l	1
. E19		lor WHITE	9 10 11	Color of Wire	В	В	0	T	BR	8	LG	٨
Connector No.	Connector Name	Connector Color	南 H.S.	Terminal No.	9	7	80	12	13	14	15	16
			·									

Signal Name	4HIND	4LOIND	4WD_FAIL	ATP IND	SSOF	1	MTR_RLY_1	1	VIGN	VIGN	ı	MTR_MONITOR_1	MTR_MONITOR_2	1	MTR_RELAY_2
Color of Wire	BR	0	GR	LG	>	ı	LG	ı	Υ	GR	ı	0	В	-	\
Terminal No.	36	37	38	39	40	41	42	43	44	45	46	47	48	49	20

Connector No.	. E10	
Connector Name		WIRE TO WIRE
Connector Color	lor WHITE	ITE
明.S.	- 4 2 2 5 8 0	
Terminal No.	Color of Wire	Signal Name
2	W/G	I
4	G	I

M153	Connector Name TRANSFER CONTROL UNIT	WHITE	
Connector No.	Connector Name	Connector Color	




RE TO WIRE	ITE	11 10 9 8 7 6 5 4 3 2 1 1 23 22 21 20 19 18 17 16 15 14 13	Signal Name	ı	1
me WIF	lor WH	24 23 22 21 2	Color of Wire	В/Υ	0
Connector Name WIRE TO WIRE	Connector Color WHITE	H.S. 24	Terminal No.	4	5

AWDIA0271GB

Connector No.

< ECU DIAGNOSIS >



Connector No. E46 Connector Name TRANS Connector Color BLACK	Connector No. E46 Connector Name TRANSFER SHIFT HIGH RELAY Connector Color BLACK


Connector Name TRANSFER SHIFT LOW RELAY

E47

Connector No.

Connector Color BLACK





Signal Name

Color of Wire

Terminal No.

1 I 1

m 0 Q

0 က 4 SB


2

1

SB

മ

4 2 Connector No.



AWDIA0272GB

Ν


0

Ρ


DLN-65


< ECU DIAGNOSIS >

[TRANSFER: TX15B]




Signal Name	-	I
Color of Wire	В/У	0
erminal No.	4	5





Connector No	F157
00111001140:	Ž.
Connector Name	Connector Name TRANSFER SHUT OFF
	RELAY2
Connector Color	BLUE





F33	WIRE TO WIRE	WHITE	
Connector No.	Connector Name WIRE TO WIRE	Connector Color WHITE	


	12 11 10 9	Signal Name	-	ı	I	I	ı	1	1	Ī
\ 	8 7 6 5 4 3 2 16 15 14 13 12 11 10	Color of Wire	В	В	0	٦	BR	>	LG	>
E	H.S.	Terminal No.	9	7	8	12	13	14	15	16


В


6

E156	
TRANSFER SHUT OFF RELAY1	
BLUE	











Connector Color Connector Name

Connector No.

AWDIA0273GB

[TRANSFER: TX15B]

0

Р

AWDIA0274GB

INFOID:0000000003296976

< ECU DIAGNOSIS >

Α В Signal Name C Connector Name 4LO SWITCH 13 | 12 Connector Color | GRAY Color of Wire DLN В > Connector No. Terminal No. 12 13 Е F Connector Name WAIT DETECTION SWITCH Signal Name G Н Connector Color GRAY Color of Wire 0 0 Connector No. Terminal No. 10 7 J K Connector Name PARK NEUTRAL POSITION (PNP) SWITCH TRANSFER CONTROL DEVICE (ACTUATOR MOTOR) Signal Name Signal Name 1 26 24 23 25 22 21 20 M Connector Color | BLACK BLACK Color of Wire Color of Wire ₽ HH. GR. 9 0 ≥ 0 ш _ Connector Name Connector Color Ν Connector No. Connector No. Terminal No. Terminal No. 20 22 23 22 24 25 25 25 26 26 7 H.S.

DTC Index

DTC CHART

[TRANSFER: TX15B]

DTC	CONSULT-III	Diagnostic item is detected when	Reference
[P1801]	*INITIAL START*	Due to removal of battery which cuts off power supply to transfer control unit, self-diagnosis memory function is suspended.	DLN-21
[P1802]		Malfunction is detected in the memory (RAM) system of transfer control unit.	
[P1803]	CONTROL UNIT (1,2,3)	Malfunction is detected in the memory (ROM) system of transfer control unit.	<u>DLN-24</u>
[P1804]		Malfunction is detected in the memory (EEPROM) system of transfer control unit.	
[P1807]	VHCL SPEED SEN-AT	 Malfunction is detected in output shaft revolution signal that is output from TCM through CAN communication. Improper signal is input while driving. 	DLN-26
[P1808]	VHCL SPEED SEN-ABS	 Malfunction is detected in vehicle speed signal that is output from ABS actuator and electric unit (control unit) through CAN communication. Improper signal is input while driving. 	DLN-27
[P1809]	CONTROL UNIT 4	AD converter system of transfer control unit is mal- functioning.	DLN-24
[P1810]	4L POSI SW TF	Improper signal from 4LO switch is input due to open or short circuit.	DLN-28
[P1811]	BATTERY VOLTAGE	Power supply voltage for transfer control unit is abnormally low while driving.	DLN-21
[P1813]	4WD MODE SW	More than two switch inputs are simultaneously detected due to short circuit of 4WD shift switch.	DLN-31
[P1814]	4WD DETECT SWITCH	Improper signal from wait detection switch is input due to open or short circuit.	DLN-34
[P1816]	PNP SW/CIRC	When PNP switch signal is malfunctioning.	DLN-37 (A/T models), DLN-38 (M/T models)
[P1817]	SHIFT ACTUATOR	 Motor does not operate properly due to open or short circuit in actuator motor. Malfunction is detected in the actuator motor. (When 4WD shift switch is operated and actuator motor is not operated) Malfunction is detected in transfer shift high relay or transfer shift low relay. 	DLN-40
[P1818]	SHIFT ACT POSI SW	 Improper signal from actuator position switch is input due to open or short circuit. Malfunction is detected in actuator position switch. 	DLN-47
[P1819]	SHIFT ACT CIR	 Malfunction is detected in transfer shut off relay 1 and transfer shut off relay 2. Malfunction occurs in transfer control device drive circuit. 	DLN-50
[P1820]	ENGINE SPEED SIG	 Malfunction is detected in engine speed signal that is output from ECM through CAN communi- cation. Improper signal is input while driving. 	DLN-53

NOTE:

If "SHIFT ACT POSI SW [P1818]" or "SHIFT ACT CIR [P1819]" is displayed, first erase self-diagnostic results. ("SHIFT ACT POSI SW [P1818]" or "SHIFT ACT CIR [P1819]" may be displayed after installing transfer control unit or transfer assembly.)

FLASH CODE CHART

[TRANSFER: TX15B]

Item Reference Flashing pattern Diagnostic item is detected when... Α · Malfunction is detected in output shaft revo-Output shaft revolution lution signal that is output from TCM through 2 **DLN-26** signal (from TCM) CAN communication. В Improper signal is input while driving. Malfunction is detected in vehicle speed signal that is output from ABS actuator and Vehicle speed signal 3 electric unit (control unit) through CAN com-**DLN-27** (from ABS) munication. · Improper signal is input while driving. Malfunction has been detected from CAN DLN 4 **DLN-14** CAN communication communication. AD converter system of transfer control unit is 5 AD converter **DLN-24** malfunctioning. Improper signal from 4LO switch is input due 6 4LO switch **DLN-28** to open or short circuit. · Malfunction is detected in engine speed signal that is output from ECM through CAN 7 Engine speed signal **DLN-53** communication. Improper signal is input while driving. Power supply voltage for transfer control unit is 8 Power supply **DLN-21** abnormally low while driving. More than two switch inputs are simultaneous-Н 9 4WD shift switch ly detected due to short circuit of 4WD shift **DLN-31** switch. Improper signal from wait detection switch is 10 Wait detection switch **DLN-34** input due to open or short circuit. Motor does not operate properly due to open or short circuit in actuator motor. · Malfunction is detected in the actuator mo-11 Actuator motor tor. (When 4WD shift switch is operated and **DLN-40** actuator motor is not operated.) · Malfunction is detected in transfer shift high relay or transfer shift low relay. Improper signal from actuator position Actuator position switch is input due to open or short circuit. **DLN-47** 12 switch Malfunction is detected in the actuator position switch. Malfunction is detected in transfer shut off relay 1 and transfer shut off 2. 13 Transfer control device **DLN-50** M Malfunction occurs in transfer control device drive circuit. DLN-37 (A/T models), DLN-38 (M/T 14 PNP switch signal When PNP switch signal is malfunctioning. models) Ν • Power supply failure of memory back-up. Repeats flickering Battery is disconnected for a long time. Data erase display DLN-21 every 0.25 sec. · Battery performance is poor. Repeats flickering Circuits that the self-diagnosis covers have no every 2 to 5 sec. malfunction. PNP switch or 4WD PNP switch or 4WD shift switch circuit is short-Р No flickering **DLN-37** or **DLN-31** shift switch ed or open.

NOTE:

If actuator position switch" or transfer control device" is displayed, first erase self-diagnostic results. (They may be displayed after installing transfer control unit or transfer assembly.)

4WD SYSTEM SYMPTOMS

[TRANSFER: TX15B]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

4WD SYSTEM SYMPTOMS

Symptom Table

Symptom	Condition	Reference page
4WD shift indicator lamp and 4LO indicator lamp do not turn ON (lamp check)	Ignition switch: ON	<u>DLN-73</u>
4WD warning lamp does not turn ON (lamp check)	ignition switch. ON	<u>DLN-71</u>
4WD shift indicator lamp or 4LO indicator lamp does not change		<u>DLN-75</u>
ATP warning lamp does not turn ON	Engine running	<u>DLN-77</u>
ATP switch is malfunctioning		<u>DLN-81</u>
4WD shift indicator lamp repeats flashing	While driving	<u>DLN-79</u>
4WD warning lamp flashes slowly (1 time/2 seconds)	wrille driving	<u>DLN-80</u>

4WD WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

4WD WARNING LAMP DOES NOT TURN ON

Description

4WD warning lamp does not turn ON when turning ignition switch to ON.

Diagnosis Procedure

1. CHECK TRANSFER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUITS

Refer to DLN-21, "Diagnosis Procedure".

Are the inspection results normal?


YES >> GO TO 2.

NO >> Perform repairs as necessary.

2.CHECK COMBINATION METER POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect combination meter harness connector.
- Check voltage between combination meter harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	0V



Combination meter connector

[TRANSFER: TX15B]

INFOID:0000000003296979

- 4. Turn ignition switch "ON". (Do not start engine.)
- Check voltage between combination meter harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	Battery voltage

Are the inspection results normal?

YES >> GO TO 3.

NO

>> Check the following. If any items are damaged, repair or replace damaged parts.

• 10A fuse [No. 14, located in the fuse block (J/B)] or ignition switch.

 Harness for short or open between ignition switch and combination meter harness connector terminal 16

${f 3.}$ CHECK HARNESS BETWEEN TRANSFER CONTROL UNIT AND COMBINATION METER

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Check continuity between transfer control unit harness connector M153 terminal 38 and combination meter harness connector M24 terminal 26.


Continuity should exist.

Also check harness for short to ground and short to power.

Is there continuity?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.



DLN

Α

В

_

G

Н

J

K

L

M

WDIA0179F

Ν

 \circ

4WD WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >


4. CHECK INDICATOR LAMP CIRCUIT

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Connect combination meter harness connector.
- Disconnect transfer control unit harness connector.
- 4. Turn ignition switch "ON". (Do not start engine.)
- 5. Ground the following terminal using suitable wiring.
- Transfer control unit harness connector M153 terminal 38 and ground.

Does the indicator lamp turn on?

YES >> GO TO 5.

NO >> Replace the combination meter. Refer to <u>MWI-91</u>. "Removal and Installation".



[TRANSFER: TX15B]

5.SYMPTOM CHECK

Check again.

Does the symptom still occur?

YES >> GO TO 6.

NO >> Inspection End.

6. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> Inspection End.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

4WD SHIFT INDICATOR LAMP AND 4LO INDICATOR LAMP DO NOT TURN ON

< SYMPTOM DIAGNOSIS >

4WD SHIFT INDICATOR LAMP AND 4LO INDICATOR LAMP DO NOT TURN ON

Description

4WD shift indicator lamp and 4LO indicator lamp do not turn ON for approx. 1 second when turning ignition switch to ON.

Diagnosis Procedure

1. CHECK TRANSFER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUITS

Refer to DLN-21, "Diagnosis Procedure".

Are the inspection results normal?


YES >> GO TO 2.

NO >> Perform repairs as necessary.

2.CHECK COMBINATION METER POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect combination meter harness connector.
- Check voltage between combination meter harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	0V



[TRANSFER: TX15B]

INFOID:0000000003296981

Α

В

DLN

Е

Н

K

- 4. Turn ignition switch "ON". (Do not start engine.)
- 5. Check voltage between combination meter harness connector terminals and ground.

Connector	Terminal	Voltage (Approx.)
M24	16 - Ground	Battery voltage

Are the inspection results normal?


YES >> GO TO 3.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuse [No. 14, located in the fuse block (J/B) or] ignition switch.
- Harness for short or open between ignition switch and combination meter harness connector terminal 16

3.check harness between transfer control unit and combination meter

1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)



Ν

M

4WD SHIFT INDICATOR LAMP AND 4LO INDICATOR LAMP DO NOT TURN ON

< SYMPTOM DIAGNOSIS >

- Check continuity between the following terminals.
- Transfer control unit harness connector M153 terminal 35 and combination meter harness connector M24 terminal 30.
- Transfer control unit harness connector M153 terminal 36 and combination meter harness connector M24 terminal 27.
- Transfer control unit harness connector M153 terminal 37 and combination meter harness connector M24 terminal 29.

Continuity should exist.

Also check harness for short to ground and short to power.

Does continuity exist?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK INDICATOR LAMP CIRCUIT

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Connect combination meter harness connector.
- 3. Disconnect transfer control unit harness connector.
- 4. Turn ignition switch "ON". (Do not start engine.)
- 5. Ground the following terminals using suitable wiring.
- Transfer control unit harness connector M153 terminal 35 and ground.
- Transfer control unit harness connector M153 terminal 36 and ground.
- Transfer control unit harness connector M153 terminal 37 and ground.

Do indicator lamps turn on?

YES >> GO TO 5.

NO >> Replace the combination meter. Refer to <u>MWI-91</u>, <u>"Removal and Installation"</u>.

5.SYMPTOM CHECK

Check again.

NO

Does the symptom still occur?

YES >> GO TO 6.

NO >> Inspection End.


6.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".


Are the inspection results normal?

YES >> Inspection End.

>> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.



[TRANSFER: TX15B]



4WD SHIFT INDICATOR LAMP OR 4LO INDICATOR LAMP DO NOT CHANGE [TRANSFER: TX15B] < SYMPTOM DIAGNOSIS > 4WD SHIFT INDICATOR LAMP OR 4LO INDICATOR LAMP DO NOT Α CHANGE Description INFOID:0000000003296982 В 4WD shift indicator lamp or 4LO indicator lamp do not change when switching the 4WD shift switch. Diagnosis Procedure INFOID:0000000003296983 1.CONFIRM THE SYMPTOM Confirm 4WD shift indicator lamp and 4LO indicator lamp when ignition switch is turned to ON. DLN Do 4WD shift indicator lamp and 4LO indicator lamp turn on? YES >> GO TO 2. NO >> Go to DLN-73, "Diagnosis Procedure". Е 2.CHECK SYSTEM FOR 4WD SHIFT SWITCH Perform trouble diagnosis for 4WD shift switch system. Refer to DLN-31, "Diagnosis Procedure". F Are the inspection results normal? YES >> GO TO 3. NO >> Repair or replace damaged parts. 3.CHECK SYSTEM FOR WAIT DETECTION SWITCH Perform trouble diagnosis for wait detection switch system. Refer to <u>DLN-34</u>, "<u>Diagnosis Procedure</u>". Н Are the inspection results normal? YES >> GO TO 4. NO >> Repair or replace damaged parts. 4.CHECK SYSTEM FOR 4LO SWITCH Perform trouble diagnosis for 4LO switch system. Refer to <u>DLN-28</u>, "Diagnosis Procedure". Are the inspection results normal? YES >> GO TO 5. NO >> Repair or replace damaged parts. ${f 5.}$ CHECK SYSTEM FOR ATP SWITCH K Perform trouble diagnosis for ATP switch system. Refer to <u>DLN-81</u>, "<u>Diagnosis Procedure</u>". Are the inspection results normal? YES >> GO TO 6. NO >> Repair or replace damaged parts. **6.**SYMPTOM CHECK Check again. Does the symptom still occur? N YES >> GO TO 7. NO >> Inspection End 7.CHECK TRANSFER CONTROL UNIT Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value". Are the inspection results normal? YES >> GO TO 8. NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. 8. CHECK TRANSFER INNER PARTS Disassemble transfer assembly. Refer to DLN-110, "Disassembly and Assembly". Check transfer inner parts.

Are the inspection results normal?

4WD SHIFT INDICATOR LAMP OR 4LO INDICATOR LAMP DO NOT CHANGE

< SYMPTOM DIAGNOSIS > [TRANSFER: TX15B]

YES >> Inspection End.

NO >> Repair or replace damaged parts.

ATP WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS > [TRANSFER: TX15B]

ATP WARNING LAMP DOES NOT TURN ON

Description

ATP warning lamp does not turn ON when the transfer case is switched in or out of 4LO with the A/T selector lever in N position.

Diagnosis Procedure

INFOID:0000000003296985

1. CHECK SYSTEM FOR CAN COMMUNICATION LINE

Perform self-diagnosis. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".

Do the self-diagnostic results indicate CAN communication?

YES >> Perform trouble diagnosis for CAN communication line. Refer to DLN-67, "DTC Index".

NO >> GO TO 2.

2.CHECK SYSTEM FOR 4WD SHIFT SWITCH

Perform trouble diagnosis for 4WD shift switch system. Refer to DLN-31, "Diagnosis Procedure".

Are the inspection results normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

 ${f 3.}$ CHECK SYSTEM FOR PNP SWITCH SIGNAL

Perform trouble diagnosis for PNP switch signal system. Refer to DLN-37, "Diagnosis Procedure".

Are the inspection results normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4. CHECK SYSTEM FOR ATP SWITCH

Perform trouble diagnosis for ATP switch system. Refer to DLN-81, "Diagnosis Procedure".

Are the inspection results normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.


5. CHECK ATP WARNING LAMP CIRCUIT

- 1. Disconnect ATP switch harness connector.
- 2. Turn ignition switch "ON". (Do not start engine.)
- Ground terminal 8 on ATP switch connector F55 using suitable wiring.
- 4. Turn ignition switch "OFF". (Stay for at least 5 seconds.)

Does ATP warning lamp turn on?

YES >> GO TO 9.

NO >> GO TO 6.



6. CHECK HARNESS BETWEEN TRANSFER CONTROL UNIT AND COMBINATION METER

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector and combination meter harness connector.

DLN

Α

Е

F

G

Н

J

Κ

L

M

Ν

ATP WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

 Check continuity between transfer control unit harness connector tor M153 terminal 39 and combination meter harness connector M24 terminal 21.


Continuity should exist.

Also check harness for short to ground and short to power.

Does continuity exist?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.



[TRANSFER: TX15B]

7.CHECK HARNESS BETWEEN COMBINATION METER AND ATP SWITCH

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- 2. Disconnect ATP switch harness connector.
- Check continuity between combination meter harness connector M24 terminal 1 and ATP switch harness connector F55 terminal 8.

Continuity should exist.

Also check harness for short to ground and short to power.

Does continuity exist?

YES >> GO TO 8.

NO >> Repair or replace damaged parts.

Combination meter connector ATP switch connector O SDIA2833E

8.SYMPTOM CHECK

Check again.

Does the symptom still occur?

YES >> GO TO 9.

NO >> Inspection End.

9. CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 10.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

10. CHECK TRANSFER INNER PARTS

- 1. Disassemble transfer assembly. Refer to DLN-110, "Disassembly and Assembly".
- Check transfer inner parts.

Are the inspection results normal?

YES >> Inspection End.

NO >> Repair or replace damaged parts.

4WD SHIFT INDICATOR LAMP KEEPS FLASHING

[TRANSFER: TX15B] < SYMPTOM DIAGNOSIS > 4WD SHIFT INDICATOR LAMP KEEPS FLASHING Α Description INFOID:0000000003296986 The 4WD shift indicator lamp keeps flashing. В Diagnosis Procedure INFOID:0000000003296987 1.CONFIRM THE SYMPTOM Set 4WD shift switch to "2WD". Drive the vehicle straight forward and backward keeping speed under 20 km/h (12 MPH). DLN Does 4WD shift indicator lamp keep flashing? YES >> GO TO 2. NO >> Inspection End. Е 2.check system for wait detection switch Perform trouble diagnosis for wait detection switch system. Refer to <u>DLN-34</u>, "Diagnosis Procedure". Are the inspection results normal? F YES >> GO TO 3. NO >> Repair or replace damaged parts. 3.CHECK SYSTEM FOR 4LO SWITCH Perform trouble diagnosis for 4LO switch. Refer to DLN-28, "Diagnosis Procedure". Are the inspection results normal? Н YES >> GO TO 4. NO >> Repair or replace damaged parts. 4.SYMPTOM CHECK Check again. Does the symptom still occur? YES >> GO TO 5. NO >> Inspection End. ${f 5.}$ CHECK TRANSFER CONTROL UNIT Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value". Are the inspection results normal? YES >> GO TO 6. NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. 6.CHECK TRANSFER INNER PARTS M Disassemble transfer assembly. Refer to DLN-110, "Disassembly and Assembly". Check transfer inner parts. N Are the inspection results normal? YES >> Inspection End. NO >> Repair or replace damaged parts.

4WD WARNING LAMP FLASHES SLOWLY

< SYMPTOM DIAGNOSIS >

4WD WARNING LAMP FLASHES SLOWLY

Description INFOID:0000000003296988

The 4WD warning lamp flashes slowly while driving (1 time / 2 seconds). The lamp continues to flash until the ignition switch is turned OFF.

Diagnosis Procedure

INFOID:0000000003296989

[TRANSFER: TX15B]

1. CHECK TIRES

Check the following. Refer to WT-39, "Tire".

- · Tire size
- Tire wear
- · Tire pressure

Are the inspection results normal?

YES >> GO TO 2.

NO >> Repair or replace damaged parts.

2.SYMPTOM CHECK

Check again.

Does the symptom still occur?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> Inspection End.

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

ATP SWITCH

Description INFOID:0000000003296990

The ATP indicator does not come on when the transfer is in neutral and the A/T lever is in neutral or, the ATP indicator stays on when the transfer case is not in neutral.

Diagnosis Procedure

INFOID:0000000003296991

[TRANSFER: TX15B]

DIAGNOSTIC PROCEDURE

1. CHECK ATP SWITCH SIGNAL

(P)With CONSULT-III


- Start engine.
- Select "DATA MONITOR" mode for "ALL MODE AWD/4WD" with CONSULT-III.
- Read out the value of "ATP SWITCH".

Condition		Display value
Vehicle stopped Engine running	4WD shift switch: 4H to 4LO or 4LO to 4H (While actuator motor is operating.)	ON
A/T selector lever "N" positionBrake pedal de- pressed	Except the above	OFF

(N)Without CONSULT-III

- Start engine.
- Check voltage between transfer control unit harness connector terminal and ground.

Connector	Terminal	Condition		Voltage (Approx.)
M152	23 - Ground	Vehicle stoppedEngine runningA/T selector lever "N" position	4WD shift switch: 4H to 4LO or 4LO to 4H (While actuator motor is operating.)	0V
		Brake pedal de- pressed	Except the above	Battery voltage



Are the inspection results normal?

>> GO TO 5. YES NO >> GO TO 2.

2.CHECK HARNESS BETWEEN TRANSFER CONTROL UNIT AND ATP SWITCH

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect transfer control unit harness connector and the ATP switch harness connector.
- Check continuity between transfer control unit harness connector M152 terminal 23 and ATP switch harness connector F55 terminal 8.


Continuity should exist.

Also check harness for short to ground and short to power.

Does continuity exist?

YES >> GO TO 3.

>> Repair or replace damaged parts. NO



DLN

Е

Α

В

Н

Ν

3. CHECK GROUND CIRCUIT

- Turn ignition switch "OFF". (Stay for at least 5 seconds.) 1.
- Disconnect ATP switch harness connector.
- Check continuity between ATP switch harness connector F55 terminal 9 and ground.

Continuity should exist.

Also check harness for short to power.

Does continuity exist?

YES >> GO TO 4.

NO >> Repair open circuit or short to power in harness or connectors.

T.S. ATP switch connector **(10)** SDIA2394E

[TRANSFER: TX15B]

4. CHECK ATP SWITCH

- Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Remove ATP switch. Refer to DLN-13, "Component Parts Location".
- Push and release ATP switch and check continuity between ATP switch terminals 8 and 9.

Terminal	Condition	Continuity
8 - 9	Push ATP switch	Yes
	Release ATP switch	No

Are the inspection results normal?

YES >> GO TO 5.

NO >> Replace ATP switch.

ATP switch connector SDIA2395E

INFOID:0000000003296992

5.CHECK TRANSFER CONTROL UNIT

Check transfer control unit input/output signal. Refer to DLN-54, "Reference Value".

Are the inspection results normal?

YES >> GO TO 6.

>> Check transfer control unit pin terminals for damage or loose connection with harness connector. NO If any items are damaged, repair or replace damaged parts.

6. CHECK ATP WARNING LAMP

- Turn ignition switch "ON". (Do not start engine.)
- A/T selector lever "N" position and engage the parking brake.
- Switch 4WD shift switch from 4H to 4LO or 4LO to 4H.

Does the ATP warning lamp turn ON while the actuator motor is operating?

YES >> Inspection End.

NO >> Refer to <u>DLN-77</u>, "<u>Diagnosis Procedure</u>".

Component Inspection

- 1. Turn ignition switch "OFF". (Stay for at least 5 seconds.)
- Disconnect ATP switch harness connector.
- Remove ATP switch. Refer to DLN-13, "Component Parts Location".


ATP SWITCH

< SYMPTOM DIAGNOSIS >

4. Push and release ATP switch and check continuity between ATP switch terminals 8 and 9.

Terminal	Condition	Continuity
8 - 9	Push ATP switch	Yes
	Release ATP switch	No

5. If the inspection results are abnormal replace the ATP switch.



[TRANSFER: TX15B]

А

В

С

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

< PRECAUTION > [TRANSFER: TX15B]

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal
 injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag
 Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Transfer Assembly and Transfer Control Unit Replacement INFOID:000000003296994

When replacing transfer assembly or transfer control unit, check the 4WD shift indicator pattern and adjustment of the position between transfer assembly and transfer control unit if necessary.

CHECK 4WD SHIFT INDICATOR PATTERN

- 1. Set 4WD shift switch to "2WD", "4H", "4LO", "4H" and "2WD" in order. Stay at each switch position for at least 2 seconds.
- Confirm 4WD shift indicator lamp and 4LO indicator lamp change properly as follows.

4WD shift switch	Indicator lamp		Operation of 4WD shift switch	
4WD SIIII SWIICII	4WD shift	4LO	Operation of 4WD shift switch	
2WD		OFF	2WD ⇔ 4H switching can be done while driving. The indicator lamp will change when	
4H		OFI	the driving mode is changed. Gear shifting between 2WD ⇔ 4H position must be performed at speeds below 100 km/h (60MPH).	
		Flashing	For M/T models, to shift between 4H⇔4LO, stop the vehicle and shift the transmission shift lever to the Neutral position with the clutch pedal depressed. For A/T models, to shift between 4H⇔4LO, stop the vehicle and shift the transmission selector to the "N" with the brake pedal depressed.	
4LO		ON	Depress and turn the 4WD shift switch. The 4WD shift switch will not shift to the desired mode if the transmission is not in "N" or the vehicle is moving. You must wait for the 4LO indicator lamp to stop flashing and remain lit or turned off before shifting your transmission into gear or releasing the clutch pedal.	

SDIA3289E

- If OK, the position between transfer assembly and transfer control unit is correct.
- If NG, the position is different between transfer assembly and transfer control unit.
 Adjust the position between transfer assembly and transfer control unit. Refer to pattern table below.

PRECAUTIONS

[TRANSFER: TX15B] < PRECAUTION >

Transfer position adjustment pattern		
4WD shift switch condition	Refer procedure	
4WD shift switch is in "2WD" when engine is stopped.	"METHOD FOR ADJUSTMENT WITH 4WD SHIFT SWITCH AT "2WD""	
4WD shift switch is in "4H" or "4LO" when engine is stopped.	"METHOD FOR ADJUSTMENT WITH 4WD SHIFT SWITCH AT "4H" OR "4LO""	

NOTE:

Method of adjustment can be chosen voluntarily, according to location of 4WD shift switch.

METHOD FOR ADJUSTMENT WITH 4WD SHIFT SWITCH AT "2WD"

Select Adjustment Pattern

- Start engine. Run engine for at least 10 seconds.
- Check 4WD shift indicator lamp and 4LO indicator lamp.

Indicator lamp condition	Refer procedure
When 4WD shift indicator lamp or 4LO indicator lamp is flashing.	"Pattern A"
Except for above.	"Pattern B"

Pattern A

- Shift the transmission according to the directions below, and stay in "N" for at least 2 seconds.
- For A/T models, stop vehicle and move A/T selector lever to "N" position with brake pedal depressed.
- For M/T models, stop vehicle and move M/T shift lever to the neutral position with brake and clutch pedal depressed.
- Turn 4WD shift switch to "4LO" position. Stay in "4LO" for at least 2 seconds.
- Turn ignition switch "OFF".
- Start engine.
- Erase self-diagnosis. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".
- Check 4WD shift indicator lamp and 4LO indicator lamp again. Refer to "CHECK 4WD SHIFT INDICATOR PATTERN".

If 4WD shift indicator lamp and 4LO indicator lamp do not indicate proper pattern, install new transfer control unit and retry the above check.

Pattern B

- Shift the transmission according to the directions below, and stay in "N" for at least 2 seconds.
- For A/T models, stop vehicle and move A/T selector lever to "N" position with brake pedal depressed.
- For M/T models, stop vehicle and move M/T shift lever to the neutral position with brake and clutch pedal depressed.
- Turn ignition switch "OFF". 2.
- 3. Start engine.
- Erase self-diagnosis. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".
- Check 4WD shift indicator lamp and 4LO indicator lamp again. Refer to "CHECK 4WD SHIFT INDICATOR PATTERN".

If 4WD shift indicator lamp and 4LO indicator lamp do not indicate proper pattern, install new transfer control unit and retry the above check.

METHOD FOR ADJUSTMENT WITH 4WD SHIFT SWITCH AT "4H" OR "4LO"

- Start engine. Run the engine for at least 10 seconds.
- Shift the transmission according to the directions below, and stay in "N" for at least 2 seconds.
- For A/T models, stop vehicle and move A/T selector lever to "N" position with brake pedal depressed.
- For M/T models, stop vehicle and move M/T shift lever to the neutral position with brake and clutch pedal depressed.
- Turn 4WD shift switch to "2WD" position. Stay in "2WD" for at least 2 seconds. 3.
- 4. Turn ignition switch "OFF".
- Start engine.

DLN

Α

В

Н

K

M

Р

DLN-85


< PRECAUTION > [TRANSFER: TX15B]

- Erase self-diagnosis. Refer to DLN-17, "CONSULT-III Function (ALL MODE AWD/4WD)".
- 7. Check 4WD shift indicator lamp and 4LO indicator lamp again. Refer to "CHECK 4WD SHIFT INDICATOR PATTERN".

If 4WD shift indicator lamp and 4LO indicator lamp do not indicate proper pattern, install new transfer control unit and retry the above check.


Precaution

 Before connecting or disconnecting the transfer control unit harness connector, turn ignition switch "OFF" and disconnect the battery cables. Battery voltage is applied to transfer control unit even if ignition switch is turned "OFF".




 When connecting or disconnecting pin connectors into or from transfer control unit, take care not to damage pin terminals (bend or break).

When connecting pin connectors make sure that there are not any bends or breaks on transfer control unit pin terminals.



Before replacing transfer control unit, perform transfer control unit input/output signal inspection and make sure transfer control unit functions properly. Refer to <u>DLN-54</u>, "<u>Reference Value</u>".



Service Notice

- After overhaul refill the transfer with new transfer fluid.
- Check the fluid level or replace the fluid only with the vehicle parked on level ground.
- During removal or installation, keep inside of transfer clear of dust or dirt.
- Disassembly should be done in a clean work area.
- Before proceeding with disassembly, thoroughly clean the transfer. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Check for the correct installation status prior to removal or disassembly. If matchmarks are required, be certain they do not interfere with the function of the parts when applied.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new ones if necessary.
- Gaskets, seals and O-rings should replaced any time the transfer is disassembled.

PRECAUTIONS

< PRECAUTION > [TRANSFER: TX15B]

• In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.

- Observe the specified torque when assembling.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transfer.

Α

В

DLN

С

Е

F

G

Н

1

J

Κ

L

M

Ν

0

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000003220771

[TRANSFER: TX15B]

Tool number (Kent-Moore No.) Tool name		Description
KV40104000 (—) Flange wrench		Removing self-lock nut Installing self-lock nut a: 85 mm (3.35 in) b: 65 mm (2.56 in)
ST33290001 (J-34286) Puller	NT659	 Removing front oil seal Removing rear oil seal Removing metal bushing
KV38100500 (—) Drift	a b MAY	 Installing front oil seal Installing rear oil seal Installing rear bearing Installing front bearing a: 80 mm (3.15 in) dia. b: 60 mm (2.36 in) dia.
(V40105310 (—) Orift	2ZA0811D	Installing dust cover a: 89 mm (3.50 in) dia. b: 80.7 mm (3.17 in) dia.
KV38100200 (—) Drift	ZZA1003D	 Removing sun gear assembly and planetar carrier assembly Removing input bearing Installing sun gear assembly and planetar carrier assembly a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.
ST30720000 (J-25405) Drift	ZZA1143D	 Installing input bearing Installing input oil seal Installing carrier bearing a: 77 mm (3.03 in) dia. b: 55 mm (2.17 in) dia.

PREPARATION

< PREPARATION > [TRANSFER: TX15B]

PREPARATION >		[TRANSFER: TX15B]
Tool number (Kent-Moore No.) Tool name		Description
KV32102700 (—) Drift		Installing mainshaft rear bearing a: 48 mm (1.89 in) dia. b: 41 mm (1.61 in) dia.
(V40104830 —) Drift	ZZA0534D	Installing input oil seal a: 70 mm (2.76 in) dia. b: 63.5 mm (2.50 in) dia.
ST35300000 —)	ZZA1003D	Removing carrier bearing Installing metal bushing
Orift	NT073	 Removing front bearing a: 59 mm (2.32 in) dia. b: 45 mm (1.77 in) dia.
5T30021000 J-22912-01) Puller	ZZA0537D	 Removing carrier bearing Removing front bearing Removing rear bearing
T33710000 —) Prift	ZZA1057D	 Removing needle bearing Removing metal bushing Removing rear bearing a: 89 mm (3.5 in) b: 30 mm (1.18 in) dia. c: 24 mm (0.94 in) dia.
T35325000 —) Orift bar	a a b NT663	• Removing metal bushing a: 215 mm (8.46 in) b: 25 mm (0.98 in) dia. c: M12 × 1.5P
ST33220000 —) Drift	c a b	 Installing needle bearing a: 37 mm (1.46 in) dia. b: 31 mm (1.22 in) dia. c: 22 mm (0.87 in) dia.

PREPARATION

< PREPARATION > [TRANSFER: TX15B]

Tool number (Kent-Moore No.) Tool name		Description
ST27863000 (—) Drift	ZZA1003D	Installing carrier bearing a: 75 mm (2.95 in) dia. b: 62 mm (2.44 in) dia.
ST30901000 (J-26010-01) Drift	a b c ZZA0978D	 Installing rear bearing Installing front bearing a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.38 in) dia.

Commercial Service Tool

INFOID:0000000003220772

Tool name		Description
Puller	NT077	Removing companion flange Removing mainshaft rear bearing
Puller	ZZB0823D	Removing mainshaft rear bearing
Pin punch	A NT410	Removing retaining pin a: 6 mm (0.24 in) dia.
Power tool	PBIC0190E	Loosening bolts and nuts

ON-VEHICLE MAINTENANCE

TRANSFER FLUID

Replacement

CAUTION:


If using the vehicle for towing, the transfer fluid must be replaced as specified. Refer to MA-6, "Introduction of Periodic Maintenance".

DRAINING

- 1. Stop engine.
- Remove the drain plug and gasket and drain the fluid.
- Install the drain plug with a new gasket to the transfer. Tighten to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly and Assembly</u>".

CAUTION:

Do not reuse gasket.



[TRANSFER: TX15B]

FILLING

- 1. Remove the filler plug and gasket.
- 2. Fill the transfer with new fluid until the fluid level reaches the specified limit near the filler plug hole.

Fluid grade and capacity: Refer to MA-12, "Fluids and Lubricants".

CAUTION:

Carefully fill fluid. (Fill up for approx. 3 minutes.)

- 3. Leave the vehicle for 3 minutes, and check fluid level again.
- Install the filler plug with a new gasket to the transfer. Tighten to the specified torque. Refer to <u>DLN-110</u>. "<u>Disassembly</u> and Assembly".

CAUTION:

Do not reuse gasket.

Inspection INFOID:0000000003220774

CAUTION:

If using the vehicle for towing, the transfer fluid must be replaced as specified. Refer to MA-6, "Introduction of Periodic Maintenance".

FLUID LEAKAGE AND FLUID LEVEL


- 1. Make sure that fluid is not leaking from the transfer assembly or around it.
- Check fluid level from the filler plug hole as shown. CAUTION:

Do not start engine while checking fluid level.

 Install the filler plug with a new gasket to the transfer. Tighten to the specified torque. Refer to <u>DLN-110</u>. "<u>Disassembly</u> and <u>Assembly</u>".

CAUTION:

Do not reuse gasket.



ound it.

Fluid level

Filler plug

Front

SDIA3287E

DLN

Α

В

Е

F

G

Н

J

K

N

С

ON-VEHICLE REPAIR

TRANSFER CONTROL UNIT

Removal and Installation

INFOID:0000000003220775


[TRANSFER: TX15B]

REMOVAL

 Switch 4WD shift switch to 2WD and set transfer assembly to 2WD. CAUTION:

When removing transfer control unit, transfer state must be at 2WD.

- 2. Turn the ignition switch OFF and disconnect negative battery terminal.
- 3. Remove the lower instrument panel LH. Refer to IP-10, "Removal and Installation".
- 4. Disconnect the two transfer control unit connectors.
- 5. Remove the transfer control unit bolts.
- 6. Remove the transfer control unit.



INSTALLATION

Installation is in the reverse order of removal.

• When installing the transfer control unit, tighten bolts to the specified torque.

Transfer control unit bolts : 3.4 N·m (0.35 kg-m, 30 in-lb)

 After the installation, check 4WD shift indicator pattern. If NG, adjust position between transfer assembly and transfer control unit. Refer to <u>DLN-84</u>, "<u>Precaution for Transfer Assembly and Transfer Control Unit Replace-ment</u>".

FRONT OIL SEAL

Removal and Installation

INFOID:0000000003220776

Α

В

C

DLN

Е

F

Н

K

L

M

Ν

0


Р

[TRANSFER: TX15B]

REMOVAL

- 1. Partially drain the transfer fluid. Refer to DLN-91, "Replacement".
- 2. Remove the front propeller shaft. Refer to DLN-130, "Removal and Installation".
- 3. Remove the companion flange self-lock nut using Tool.


Tool number : KV40104000 (—)




4. Put a matching mark on top of the front drive shaft in line with the mark on the companion flange.

CAUTION:

Use paint to make the matching mark on the front drive shaft. Do not damage the front drive shaft.



5. Remove the companion flange using suitable tool.




6. Remove the front oil seal from the front case using Tool.

Tool number : ST33290001 (J-34286)

CAUTION:

Do not damage front case.



INSTALLATION


[TRANSFER: TX15B] < ON-VEHICLE REPAIR >

Install the new front oil seal until it is flush with the end face of the front case using Tool.


> : KV38100500 (—) **Tool number**

CAUTION:

- Do not reuse oil seal.
- Apply petroleum jelly to oil seal.



2. Align the matching mark of the front drive shaft with the matching mark of the companion flange, then install the companion flange.




Install the new self-lock nut and tighten to the specified torque using Tool. Refer to DLN-110, "Disassembly and Assembly".

> : KV40104000 (—) **Tool number**

CAUTION:

Do not reuse self-lock nut.

- Install the front propeller shaft. Refer to DLN-130, "Removal and Installation".
- Refill the transfer with fluid and check for fluid leakage and fluid level. Refer to <u>DLN-91</u>, "Inspection".




REAR OIL SEAL

Removal and Installation

REMOVAL

- 1. Partially drain the transfer fluid. Refer to DLN-91, "Replacement".
- 2. Remove the rear propeller shaft. Refer to <u>DLN-138</u>, "Removal and Installation".
- Remove the dust cover from the rear case. CAUTION:

Do not damage the rear case.




[TRANSFER: TX15B]

INFOID:0000000003220777

 Remove the rear oil seal from the rear case using Tool. CAUTION:

Do not damage the rear case.

Tool number : ST33290001 (J-34286)




INSTALLATION

1. Install the new rear oil seal until it is flush with the end face of the rear case using Tool.

Tool number : KV38100500 (—)

CAUTION:


- · Do not reuse oil seal.
- Apply petroleum jelly to oil seal.



Apply petroleum jelly to the circumference of the new dust cover. Position the new dust cover using the identification mark as shown.

CAUTION:

- Do not reuse dust cover.
- Position the identification mark at the position shown.



DLN

C

Α

Е

G

Н

K

L

M

Ν

0

Ρ


[TRANSFER: TX15B] < ON-VEHICLE REPAIR >

Install the new dust cover to the rear case using Tool.

Tool number : KV40105310 (—)

CAUTION:

- Do not reuse dust cover.
- Apply petroleum jelly to dust cover.
- 4. Install the rear propeller shaft. Refer to DLN-138, "Removal and Installation".
- 5. Refill the transfer with fluid and check for fluid leakage and fluid level. Refer to DLN-91, "Inspection".




TRANSFER CONTROL DEVICE

Removal and Installation

REMOVAL

- 1. Switch the 4WD shift switch to 2WD and set the transfer assembly to 2WD.
- 2. Disconnect the transfer control device connector.
- 3. Remove the breather hose from the transfer control device.
- 4. Remove the bolts and detach the transfer control device.




[TRANSFER: TX15B]


INFOID:0000000003220778

INSTALLATION

- Install the new O-ring to the transfer control device. CAUTION:
 - Do not reuse O-ring.
 - Apply petroleum jelly to O-ring.




- Install the transfer control device.
- a. Turn the control shift rod fully counterclockwise using a flatbladed screwdriver, and then put a mark on the control shift rod.



b. Align the transfer control device shaft cutout with the mark on the control shift rod, and install.

NOTE:

Turn the transfer control device when the transfer control device connection does not match.



DLN

Α

Е

Н

K

L


M

Ν

TRANSFER CONTROL DEVICE

< ON-VEHICLE REPAIR >

- c. Tighten the bolts to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly</u> and <u>Assembly</u>".
- 3. Install the breather hose to the transfer control device.
- 4. Connect the transfer control device connector.
- 5. After the installation, check the 4WD shift indicator pattern. If NG, adjust the position between the transfer assembly and transfer control unit. Refer to DLN-84, "Precaution for Transfer Assembly and Transfer Control Unit Replacement".



[TRANSFER: TX15B]

AIR BREATHER HOSE


Removal and Installation

- 1. Breather tube
- 4. Clip C
- 7. Air breather hose clamp
- 2. Clip A
- 5. Clip D
- Transfer control device
- 3. Clip B
- 6. Breather tube (transfer)


CAUTION:

 Make sure there are no pinched or restricted areas on each air breather hose caused by folding or bending when installing it.

 Install each air breather hose into the breather tube (metal connector) until the hose end reaches the end of the curved section. Set each air breather hose with paint mark facing upward.



 Install transfer control device air breather hose and transfer air breather hose on clip A and clip B with the paint mark facing upward.



Α

В

[TRANSFER: TX15B]

INFOID:0000000003220779

DLN

Е

Г

G

Н

J

Κ

L


M

Ν


 \cap

[TRANSFER: TX15B]


• Install clip C on transfer control device air breather hose and transfer air breather hose with the paint mark matched.




 Install transfer control device air breather hose and transfer air breather hose on clip D with the paint mark facing upward.



Install transfer air breather hose into the breather tube (transfer, metal connector) until the hose end reaches the base of the tube. Set transfer air breather hose with paint mark facing upward.



 Install transfer control device air breather hose into transfer control device (case connector) until the hose end reaches the base of the tube. Set transfer control device air breather hose with paint mark facing forward.



PLANETARY CARRIER


Disassembly and Assembly

INFOID:0000000003220780


[TRANSFER: TX15B]

DISASSEMBLY

- 1. Remove the snap ring.
- 2. Remove the sun gear assembly from the planetary carrier assembly using suitable tool.




Remove the snap ring from the sun gear assembly using suitable tool.



4. Remove the carrier bearing from the sun gear using Tools.


Tool number A: ST35300000 (—)

B: ST30021000 (J-22912-01)



5. Remove the needle bearing from the sun gear using Tool.

Tool number : ST33710000 (—)



Α

В

DLN

Е

G

Н

J

K

M

Ν

 \circ


< ON-VEHICLE REPAIR >

6. Remove the metal bushing from the sun gear using Tools.

Tool number A: ST33710000 (—)

B: ST35325000 (—)

C: ST33290001 (J-34286)




[TRANSFER: TX15B]

INSPECTION AFTER DISASSEMBLY

Bearing

Check the bearing for damage and rough rotation. If necessary, replace the bearing with a new one.




Planetary Carrier

 Measure the end play of each pinion gear. If it is out of specification, replace the planetary carrier assembly with new one.


Pinion gear end play : 0.1 - 0.7 mm (0.004 - 0.028 in)

• Check the working face of each gear and bearing for damage, burrs, partial wear, dents and other abnormality. If any is found, replace the planetary carrier assembly with a new one.



Sun Gear

- Check if the oil passage of the sun gear assembly is clogged. For this, try to pass a 3.6 mm (0.142 in) dia. wire through the oil passage as shown.
- Check the sliding and contact surface of each gear and bearing for damage, burrs, partial wear, dents and other abnormality. If any is found, replace the sun gear assembly with a new one.




Internal Gear

PLANETARY CARRIER

< ON-VEHICLE REPAIR >

Check the internal gear teeth for damage, partial wear, dents or other abnormality. If any is found, replace the internal gear with a new one.



[TRANSFER: TX15B]

DLN

Е

Н

K

M

Ν

Р

Α

В

ASSEMBLY


1. Apply ATF to the new metal bushing, then install the new metal bushing until it becomes "Dimension A" using Tool.

Tool number : ST35300000 (—)

Dimension A : 7.7 - 8.3mm (0.303 - 0.327in)

CAUTION:

Do not reuse metal bushing.




2. Apply ATF to the new needle bearing, then install the new needle bearing until it becomes "Dimension B" using Tool.

Tool number : ST33220000 (—)

Dimension B : 62.5 - 63.1mm (2.461 - 2.484in)

CAUTION:


Do not reuse needle bearing.



3. Install the carrier bearing to the sun gear using Tools.

Tool number A: ST30720000 (J-25405)


B: ST27863000 (—)



 Install the new snap ring to the sun gear assembly using suitable tool.

CAUTION:


Do not reuse snap ring.



[TRANSFER: TX15B]

- 5. Install the sun gear assembly to the planetary carrier assembly.
- 6. Install the new snap ring to the planetary carrier assembly. **CAUTION:**

Do not reuse snap ring.



FRONT DRIVE SHAFT

Disassembly and Assembly

DISASSEMBLY

Remove the front bearing using Tools.

Tool number A: ST35300000 (—)

B: ST30021000 (J-22912-01)

Press 仝 Tool A Tool B SDIA2106E


[TRANSFER: TX15B]

INFOID:0000000003220781

Remove the rear bearing using Tools.

Tool number A: ST33710000 (—)

B: ST30021000 (J-22912-01)




INSPECTION AFTER DISASSEMBLY

Front Drive Shaft


Check the items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear and bending of the shaft.
- · Excessive wear, damage and peeling of the gear.



Bearing

Check the bearing for damage and rough rotation. If necessary, replace the bearing with a new one.



ASSEMBLY

DLN

C

Α

В

Е

Н

K

Ν


FRONT DRIVE SHAFT

< ON-VEHICLE REPAIR >

1. Install the rear bearing using Tools.

Tool number A: KV38100500 (—)


B: ST30901000 (J-26010-01)



2. Install the front bearing using Tools.

Tool number A: KV38100500 (—)

B: ST30901000 (J-26010-01)



SHIFT CONTROL

Disassembly and Assembly

INFOID:0000000003220782

Α

В

DLN

Е

Н

M


Ν

Р


[TRANSFER: TX15B]

DISASSEMBLY


- 1. Remove the snap ring.
- 2. Remove the retaining pin.
- 3. Remove the drum cam from the control shift rod.



- 4. Remove the retaining pin from the L-H shift rod.
- 5. Remove the 2-4 shift bracket.



- Remove the retaining ring from the 2-4 shift fork using suitable tool.
- 7. Remove the fork guide collar and 2-4 shift fork spring from the 2-4 shift fork.




INSPECTION AFTER DISASSEMBLY

Shift Fork

 Measure the clearance between the shift fork and sleeve. If it is out of specification, replace it with a new one.

Standard value


2-4 : Less than 0.46 mm (0.018 in) L-H : Less than 0.46 mm (0.018 in)



Shift Rod and Fork Components

< ON-VEHICLE REPAIR >

 Check the working face of the shift rod and fork for wear, partial wear, abrasion, bending and other abnormality. If any is found, replace with a new one.



[TRANSFER: TX15B]

ASSEMBLY

1. Install clevis pin and shift collar to L-H shift fork after assembling them.

CAUTION:


Use caution when installing L-H shift fork, clevis pin or shift collar.

2. Install clevis pin and shift collar to 2-4 shift bracket after assembling them.

CAUTION:


Use caution when installing 2-4 shift bracket.

- Install guide fork collar and 2-4 shift fork spring to the 2-4 shift fork, and then secure it with the new retaining ring. CAUTION:
 - Do not reuse retaining ring.
 - Be careful with orientation.



- 4. Install the 2-4shift bracket to the L-H shift rod.
- Install the new retaining pin evenly to the L-H shift rod. CAUTION:

Do not reuse retaining pin.



6. Install the drum cam to the control shift rod, and then secure it with the new retaining pin.


CAUTION:

Do not reuse retaining pin.

7. Install the new snap ring to the control shift rod.

CAUTION:

Do not reuse snap ring.



< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

TRANSFER ASSEMBLY

Removal and Installation

REMOVAL

- 1. Switch 4WD shift switch to 2WD and set transfer assembly to 2WD.
- 2. Remove the undercovers using power tool.
- Drain the transfer fluid. Refer to DLN-91.
- 4. Remove the center exhaust tube and main muffler. Refer to EX-6, "Removal and Installation".
- 5. Remove the front and rear propeller shafts. Refer to <u>DLN-130, "Removal and Installation"</u> (front), <u>DLN-138, "Removal and Installation"</u> (rear).

CAUTION:

Do not damage spline, sleeve yoke and rear oil seal when removing rear propeller shaft. NOTE:

Insert a plug into the rear oil seal after removing the rear propeller shaft.

- Remove the A/T nuts from the A/T crossmember. Refer to <u>TM-380, "Component"</u>.
- 7. Position two suitable jacks under the A/T and transfer assembly.
- 8. Remove the A/T crossmember. Refer to TM-380, "Component".

WARNING:

Support A/T and transfer assembly using two suitable jacks while removing A/T crossmember.

- 9. Disconnect the electrical connectors from the following:
 - ATP switch
 - 4LO switch
 - · Wait detection switch
 - Transfer control device
- 10. Disconnect each air breather hose from the following. Refer to TM-376, "Removal and Installation for QR25DE Engine".
 - Transfer control device
 - Breather tube (transfer)
- 11. Remove the transfer to A/T and A/T to transfer bolts.
- 12. Remove the transfer assembly.

WARNING:

support transfer assembly with suitable jack while removing it. CAUTION:

Do not damage rear oil seal (A/T).


INSTALLATION

Installation is in the reverse order of removal.

Tighten the bolts to specification.

Tightening torque : 36 N·m (3.7kg-m, 27 ft-lb)

- Fill the transfer with new fluid and check for fluid leakage and fluid level. Refer to <u>DLN-91</u>, "<u>Inspection</u>".
- Start the engine for one minute. Then stop the engine and recheck the transfer fluid. Refer to <u>DLN-91</u>, "Inspection".
- After the installation, check the 4WD shift indicator pattern. If NG, adjust the position between the transfer assembly and transfer control unit. Refer to <u>DLN-84</u>, "<u>Precaution for Transfer Assembly</u> and <u>Transfer Control Unit Replacement</u>".



DLN

Α

В

[TRANSFER: TX15B]

INFOID:0000000003220783

Е

Г

G

G

Н

Κ

ı

M

Ν


0

DISASSEMBLY AND ASSEMBLY

TRANSFER ASSEMBLY

Disassembly and Assembly

COMPONENTS



- 1. Baffle plate
- 4. Snap ring
- 7. Companion flange
- 10. ATP switch (black)
- 13. Gasket
- 16. O-ring
- 19. Dust cover
- 22. Retainer bolt
- B. Apply Genuine Silicone RTV or equivalent.


- 2. Breather tube
- 5. Input oil seal
- 8. Front oil seal
- 11. Rear case
- 14. Filler plug
- 17. Transfer control device
- 20. Rear oil seal
- 23. Gasket

- 3. Front case
- 6. Self-lock nut
- 9. 4LO switch (gray with green paint)

[TRANSFER: TX15B]

INFOID:0000000003220784

- 12. Wait detection switch (gray)
- 15. Drain plug
- 18. Harness bracket
- 21. Air breather hose clamp
- A. Apply Genuine Anaerobic Liquid Gasket or equivalent.



1.	Input	bearing
١.	IIIput	bearing

- 4. Carrier bearing
- 7. Metal bushing
- 10. Drive chain
- 13. 2-4 sleeve
- 16. Retainer
- 19. Front drive shaft
- 22. L-H shift rod
- 25. 2-4 shift fork
- 28. Retaining ring
- 31. Clevis pin
- 34. Spacer

- 2. Snap ring
- Sun gear
- 8. Planetary carrier assembly
- 11. Mainshaft
- 14. Clutch gear
- 17. Mainshaft rear bearing
- 20. Rear bearing
- 23. Retaining pin
- 26. Fork guide collar
- 29. Snap ring
- 32. Drum cam

- 3. Internal gear
- 6. Needle bearing
- 9. L-H sleeve
- 12. Sprocket
- 15. Oil pump assembly
- 18. Front bearing
- 21. L-H shift fork
- 24. 2-4 shift bracket
- 27. 2-4 shift fork spring
- 30. Shift collar
- 33. Control shift rod

DISASSEMBLY

1. Remove the drain plug and filler plug.

Α

В

С

DLN

Е

F

G

Н

1

J

K

L


M

Ν

1


0

- 2. Remove the transfer control device from the rear case.
- 3. Remove the O-ring from the transfer control device.



4. Remove the self-lock nut from the companion flange using Tool.


Tool number : KV40104000 (—)




5. Put a matching mark on top of the front drive shaft in line with the mark on the companion flange.

CAUTION:

Use paint to make the matching mark on the front drive shaft. Do not damage the front drive shaft.



6. Remove the companion flange using suitable tool.




7. Remove the front oil seal from the front case using Tool.

Tool number : ST33290001 (J-34286)


CAUTION:

Do not damage front case or front drive shaft.




< DISASSEMBLY AND ASSEMBLY >

8. Remove the 4LO switch [gray (with green paint)] and ATP switch (black) from the front case.




[TRANSFER: TX15B]

9. Remove the wait detection switch (gray) from the rear case.



Remove the dust cover from the rear case using suitable tool.CAUTION:

Do not damage rear case.




11. Remove the rear oil seal from the rear case using Tool.

Tool number : ST33290001 (J-34286)


CAUTION:

Do not damage rear case or mainshaft.



12. Remove the input oil seal from the front case using suitable tool. CAUTION:

Do not damage front case, sun gear or input bearing.



Α

В

С

DLN

Е

F

G

Н

Κ

ı


В. Л

Ν

0


Р

13. Remove the retainer bolts and gaskets.



[TRANSFER: TX15B]

14. Remove the rear case bolts, harness bracket and air breather hose clamp from the rear case.




15. Separate the front case from the rear case. Then remove the rear case by prying it up using suitable tool.

CAUTION:


Do not damage the mating surface.

16. Remove the spacer from the control shift rod. **CAUTION:**


Do not drop spacer.



17. Remove the snap ring from the mainshaft using suitable tool.




- 18. Remove the mainshaft rear bearing from the mainshaft using suitable tool.
- 19. Remove the retainer from the mainshaft.




< DISASSEMBLY AND ASSEMBLY >

- 20. Remove the snap ring from the mainshaft using suitable tool.
- 21. Remove the oil pump assembly from the mainshaft.




[TRANSFER: TX15B]


- 22. Remove the snap ring from the mainshaft using suitable tool.
- 23. Remove the clutch gear from the mainshaft.



- Remove the snap ring from the L-H shift rod assembly using suitable tool.
- 25. Remove the 2-4 sleeve and 2-4 shift fork assembly from the mainshaft.




- 26. Remove the drive chain together with the sprocket and front drive shaft from the front case.
- 27. Remove the mainshaft from the sun gear assembly.
- 28. Remove the L-H shift rod assembly and control shift rod assembly from the front case.
- 29. Remove the L-H sleeve together with the L-H shift fork from the planetary carrier assembly.



30. Remove the snap ring from the sun gear.

CAUTION:

Do not damage sun gear or input bearing.



Α

DLN

Е

F

G

Н

I

J

K

L

M


Ν

0


[TRANSFER: TX15B]

31. Press the sun gear assembly and planetary carrier assembly from the front case using Tool.


Tool number : KV38100200 (—)




32. Remove the snap ring from the front case.



33. Remove the internal gear from the front case.




34. Remove the snap ring from the front case.




35. Remove the input bearing from the front case using Tool.

Tool number : KV38100200 (—)



< DISASSEMBLY AND ASSEMBLY >

- 36. Remove the baffle plate from the front case.
- 37. Remove the breather tube from the front case.




[TRANSFER: TX15B]

INSPECTION AFTER DISASSEMBLY

Case


Check the contact surfaces of the shift rod and bearing for wear and damage. If any is found, replace with a new one.



Sleeve

Check the items below. If necessary, replace them with new ones.


- Damage and excessive wear of the contact surfaces of the sprocket, mainshaft and sleeve.
- Sleeve must move smoothly.



Gear, Shaft and Drive Chain

Check the items below. If necessary, replace them with new ones.

- Damage, peeling, uneven wear and bending of the shaft.
- Excessive wear, damage and peeling of the gear.



Bearing

Α

В

C

DLN

Н


M

K

Ν

0

Check the bearing for damage and rough rotation. If necessary, replace it with a new one.




ASSEMBLY

Install the breather tube.

CAUTION:


Install breather tube in the direction shown.



2. Install the baffle plate to the front case. Tighten the bolt to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly and Assembly</u>".


CAUTION:

Install baffle plate by pushing it in the direction shown while tightening the bolt.



Install the input bearing to the front case using Tool.


Tool number : ST30720000 (J-25405)



4. Install the new snap ring to the front case.


CAUTION:

Do not reuse snap ring.



< DISASSEMBLY AND ASSEMBLY >

Install the internal gear with the groove facing up into the front case.



[TRANSFER: TX15B]

DLN

Е


Α

В

6. Install the new snap ring to the front case.

CAUTION:


Do not reuse snap ring.



F

Install the planetary carrier assembly and sun gear assembly to the front case using Tool.

Tool number : KV38100200 (—)




Н

8. Install the new snap ring to the sun gear.

CAUTION:

- Do not reuse snap ring.
- Do not damage sun gear.




 \mathbb{N}

Ν

0

Ρ


9. Set the L-H sleeve together with the L-H shift fork assembly onto the planetary carrier assembly.



10. Install the control shift rod assembly to the front case. **CAUTION:**

Set pin of L-H shift fork assembly into the groove of drum cam.

11. Turn the control shift rod assembly fully counterclockwise.




[TRANSFER: TX15B]

12. Install the L-H shift rod assembly through the L-H shift fork assembly opening to the front case.

CAUTION:


Set pin of L-H shift rod assembly into the groove of drum cam.

13. Install the mainshaft to the sun gear assembly.




14. Install the drive chain to the front drive shaft and sprocket. **CAUTION:**

Install with the Identification mark of drive chain on the side of the rear bearing of front drive shaft.




15. Install the drive chain together with the front drive shaft and sprocket to the front case.



16. Install the 2-4 sleeve and 2-4 shift fork assembly to the main-shaft.

CAUTION:

- Install with proper orientation of 2-4 sleeve.
- Install 2-4 shift fork with engaging the grooves of 2-4 shift fork in the retaining pin of 2-4 shift bracket.




< DISASSEMBLY AND ASSEMBLY >

 Install the new snap ring to the L-H shift rod assembly using suitable tool.

CAUTION:

Do not reuse snap ring.

18. Install the clutch gear to the mainshaft.




[TRANSFER: TX15B]

Install the new snap ring to the mainshaft using suitable tool.CAUTION:


Do not reuse snap ring.

20. Install the oil pump assembly to the mainshaft.



Install the new snap ring to the mainshaft using suitable tool.CAUTION:


Do not reuse snap ring.



22. Install the retainer to the mainshaft.

CAUTION:

Set the projection of oil pump assembly to the identification hole, and then align locating hole of retainer to the L-H shift rod assembly.




23. Install the mainshaft rear bearing to the mainshaft using Tool.

Tool number : KV32102700 (—)

CAUTION:

Do not push too hard in order to avoid snap rings becoming dislodged from mainshaft.



В

Α

DLN

Е

F

Н

K

L

M


Ν

0

24. Install the new snap ring to the mainshaft using suitable tool. **CAUTION:**

Do not reuse snap ring.

25. Install the spacer to the control shift rod.



[TRANSFER: TX15B]

- 26. Apply liquid gasket to the mating surface of the front case.
 - Use Genuine Anaerobic Liquid Gasket or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".


CAUTION:

Remove old sealant adhering to mating surfaces. Also remove any moisture, oil, or foreign material adhering to application and mating surfaces.

- 27. Install the rear case to the front case.
- 28. Tighten the bolts to the specified torque. Refer to <u>DLN-110</u>, "Disassembly and Assembly".

CAUTION:

Be sure to install the harness brackets and air breather hose clamp.




: Apply Genuine Anaerobic Liquid Gasket.

Refer to GI section.

29. Install the retainer bolts with new gaskets. Tighten the bolts to the specified torque. Refer to DLN-110, "Disassembly and Assembly".

CAUTION:

- · Do not reuse gasket.
- Tighten them to the specified torque again.



30. Apply petroleum jelly to the circumference of the new oil seal, and install it to the front case using Tools.


> Tool number A: ST30720000 (J-25405)


> > B: KV40104830 (—)

: 4.0 - 4.6 mm (0.157 - 0.181 in) **Dimension A**

CAUTION:

- · Do not reuse oil seal.
- · Apply petroleum jelly to oil seal.





Spacer


< DISASSEMBLY AND ASSEMBLY >

31. Install the new rear oil seal until it is flush with the end face of the rear case using Tool.

Tool number : KV38100500 (—)

CAUTION:

- · Do not reuse oil seal.
- · Apply petroleum jelly to oil seal.




[TRANSFER: TX15B]

32. Apply petroleum jelly to the circumference of the new dust cover. Position the new dust cover using the identification mark as shown.

CAUTION:

- Do not reuse dust cover.
- Position the identification mark at the position shown.




33. Install the new dust cover to the rear case using Tool.

Tool number : KV40105310 (—)

CAUTION:


- Do not reuse dust cover.
- Apply petroleum jelly to dust cover.



- 34. Apply sealant to the threads of the wait detection switch (gray). Then install it to the rear case and tighten to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly and Assembly</u>".
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, <u>"Recommended Chemical Products and Sealants"</u>.

CAUTION:

Remove old sealant and oil adhering to threads.



Α

В

DLN

Е

F

G

Н

|

L

M


Ν

O

Ρ

- 35. Apply sealant to the threads of the 4LO switch (gray with green paint) and ATP switch (black). Then install them to the front case and tighten to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly</u>".
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, <u>"Recommended Chemical Products and Sealants"</u>.

Remove old sealant and oil adhering to threads.




[TRANSFER: TX15B]

36. Install the new front oil seal until it is flush with the end face of the front case using Tool.


Tool number : KV38100500 (—)

CAUTION:

- Do not reuse oil seal.
- · Apply petroleum jelly to oil seal.



37. Align the matching mark on the front drive shaft with the mark on the companion flange, then install the companion flange.




38. Install the new companion flange self-lock nut. Tighten to the specified torque using Tool. Refer to DLN-110. "Disassembly and Assembly".

Tool number : KV40104000 (—)

CAUTION:


Do not reuse self-lock nut.



39. Install the new O-ring to the transfer control device.


CAUTION:

- Do not reuse O-ring.
- · Apply petroleum jelly to O-ring.



< DISASSEMBLY AND ASSEMBLY >

- 40. Install the transfer control device to the rear case.
- a. Turn the control shift rod fully counterclockwise using a flatbladed screwdriver, and then put a mark on the control shift rod.



[TRANSFER: TX15B]

Α

В

C

DLN


Е

Н


b. Align the transfer control device shaft cutout with the mark on the control shift rod, and install it.

NOTE:

Turn the transfer control device when the transfer control device connection does not match.



c. Tighten the bolts to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly and Assembly</u>".



41. Install the drain plug and filler plug with new gaskets to the rear case. Tighten to the specified torque. Refer to <u>DLN-110</u>, "<u>Disassembly</u> and <u>Assembly</u>".

CAUTION:

Do not reuse gaskets.

M

L

Ν

0

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003220785

[TRANSFER: TX15B]

Applied model		VQ40DE	
Transfer model			TX15B
Gear ratio	High		1.000
Geal Tallo	Low		2.625
	Planetary gear	Sun gear	56
Number of teeth	Flanetary gear	Internal gear	91
Number of teeth	Front drive sproc	ket	38
Front drive shaft			38
Fluid Capacity (Approx) ℓ (U		ℓ (US qt, Imp qt)	2.0 (2 1/8, 1 3/4)

Inspection and Adjustment

INFOID:0000000003220786

PINION GEAR END PLAY

Unit: mm (in)

Item	Standard			
Pinion gear end play	0.1 - 0.7 (0.004 - 0.028)			

CLEARANCE BETWEEN SHIFT FORK AND SLEEVE

Unit: mm (in)

Item	Standard
2-4 shift fork to 2-4 sleeve	Less than 0.46 (0.018)
L-H shift fork to L-H sleeve	Less than 0.46 (0.018)

PREPARATION

< PREPARATION >

[PROPELLER SHAFT: 2F1310]

PREPARATION

PREPARATION

Commercial Service Tool

Tool name		Description
Power tool		Loosening bolts and nuts
	PBIC0190E	

В

INFOID:0000000003220787

Α

DLN

С

Е

F

G

Н

ı

J

Κ

L

M

Ν

0

Ρ

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000003220788

[PROPELLER SHAFT: 2F1310]

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		<u>DLN-129</u>	<u>DLN-129</u>	<u>DLN-129</u>	DLN-172, "NVH Troubleshooting Chart" DLN-206, "NVH Troubleshooting Chart" DLN-240, "NVH Troubleshooting Chart" DLN-271, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart" RAX-6, "NVH Troubleshooting Chart" RAX-18, "NVH Troubleshooting Chart"	ESU-4, "NVH Troubleshooting Chart" RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	DLN-128, "NVH Troubleshooting Chart" DLN-136, "NVH Troubleshooting Chart" DLN-144, "NVH Troubleshooting Chart" DLN-152, "NVH Troubleshooting Chart" DLN-160, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and su	uspected parts	Uneven rotation torque	Rotation imbalance	Excessive run out	Differential	Axle	Suspension	Tires	Road wheel	Drive shaft	Brakes	Steering
	Noise	×	×	×	×	×	×	×	×	×	×	×
Symptom	Shake					×	×	×	×	×	×	×
	Vibration	×	×	×		×	×	×		×		×

^{×:} Applicable

[PROPELLER SHAFT: 2F1310]

ON-VEHICLE REPAIR

PROPELLER SHAFT

On-Vehicle Service


APPEARANCE AND NOISE INSPECTION


- Check the propeller shaft tube surface for dents or cracks. If damaged, replace the propeller shaft assembly.
- Check the bearings for noise and damage. Repair or replace the bearings as necessary.

PROPELLER SHAFT VIBRATION


If a vibration is present at high speed, inspect the propeller shaft runout first.

- Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands. Refer to <u>DLN-134</u>, "General Specification".
- If the runout exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180° and 270° and reconnect the propeller shaft.





4. After installation, check for vibration by driving the vehicle.



DLN

Α

В

INFOID:0000000003220789

F

Е

G

Н

I

IZ.

L

M

Ν

0

[PROPELLER SHAFT: 2F1310]

INFOID:0000000003220790


REMOVAL AND INSTALLATION

PROPELLER SHAFT

Removal and Installation

COMPONENTS

Model 2F1310



- 1. Propeller shaft tube
- 2. Snap ring

4. Journal

5. Flange yoke

- 3. Journal bearing
- ⇐: Front

REMOVAL

1. Put matching marks on the front propeller shaft flange yoke and the front final drive companion flange as shown.

CAUTION:


For matching marks, use paint. Never damage the flange yoke and companion flange of the front final drive.

2. Put matching marks on the front propeller shaft flange yoke and the transfer companion flange.

CAUTION:

For matching marks, use paint. Never damage the flange yoke and companion flange of the front final drive.

3. Remove the bolts and then remove the front propeller shaft from the front final drive and transfer.




INSPECTION

PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[PROPELLER SHAFT: 2F1310]

 Inspect the propeller shaft runout. If runout exceeds the limit, replace the propeller shaft assembly. Refer to <u>DLN-134</u>, "General <u>Specification</u>".



- While holding the flange yoke on one side, check axial play of the joint as shown. If the journal axial play exceeds the specification, repair or replace the journal parts. Refer to <u>DLN-134</u>, "General <u>Specification"</u>.
- Check the propeller shaft tube surface for dents or cracks. If damage is detected, replace the propeller shaft assembly.



INSTALLATION

Installation is in the reverse order of removal.

After installation, check for vibration by driving the vehicle. Refer to <u>DLN-152</u>, "<u>NVH Troubleshooting Chart"</u>.
 CAUTION:

Do not reuse the bolts and nuts. Always install new ones.

DLN

C

Α

В

Е

F

G

Н

Κ

L

M

Ν

0

[PROPELLER SHAFT: 2F1310]

INFOID:0000000003220791

DISASSEMBLY AND ASSEMBLY

PROPELLER SHAFT

Disassembly and Assembly


DISASSEMBLY

Journal


1. Put matching marks on the front propeller shaft and flange yoke as shown.

CAUTION:

For matching marks, use paint. Never damage the front propeller shaft or flange yoke.




2. Remove the snap rings.



Push out and remove the journal bearings by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:


Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



4. Push out and remove the remaining journal bearings at the opposite side by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:

Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.




ASSEMBLY

Journal

1. Assemble the journal bearings. Apply multipurpose grease on the bearing inner surface.

NOTE:

During assembly, use caution so that the needle bearings do not fall down.



DLN

Е

F

Н

K

M

Ν

Α

В


2. Select new snap rings that will provide the specified play in an axial direction of the journal, and install them. Refer to DLN-134, <a href=""Snap Ring".

CAUTION:


Do not reuse snap rings

NOTE:


Select snap rings with a difference in thickness at both sides within 0.02 mm (0.0008 in).



3. Adjust the thrust clearance between the bearing and snap ring to zero by tapping the yoke.



4. Make sure that the journal moves smoothly and is below the joint flex effort specification. Refer to <u>DLN-134</u>, "General Specification".



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003303378

[PROPELLER SHAFT: 2F1310]

4WD Model

Applied model			VQ40DE	
		M/T	A/T	
Front	Propeller shaft model	2F1310		
	Number of joints	2		
	Coupling method with front final drive	e Flange type		
	Coupling method with transfer	Flange type		
	Shaft length (Spider to spider)	696	mm (27.40 in)	
	Shaft outer diameter	63.	5 mm (2.5 in)	
	Journal axial play	0.02 mm (0.0008 in) or less		
	Propeller shaft runout limit	0.6 mm (0.024 in) or less		
	Propeller shaft joint flex effort	1.96 N·m (0.2	20 kg-m, 17 in-lb) or less	

Snap Ring

Model 2F1310

Unit: mm (in)

Thickness	Color	Part Number*
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

^{*}Always check with the Parts Department for the latest parts information.

PREPARATION

< PREPARATION >

[PROPELLER SHAFT: 2S1330]

PREPARATION

PREPARATION

Commercial Service Tool

Tool name	Description	
Power tool	Loosening bolts and nuts	
	PBIC0190E	

С

Α

В

INFOID:0000000003220794

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[PROPELLER SHAFT: 2S1330]

INFOID:0000000003220795

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		DLN-137	<u>DLN-137</u>	<u>DLN-142</u>	DLN-172, "NVH Troubleshooting Chart" DLN-206, "NVH Troubleshooting Chart" DLN-240, "NVH Troubleshooting Chart" DLN-271, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart" RAX-6, "NVH Troubleshooting Chart" RAX-18, "NVH Troubleshooting Chart"	FSU-4, "NVH Troubleshooting Chart" RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	DLN-128, "NVH Troubleshooting Chart" DLN-136, "NVH Troubleshooting Chart" DLN-152, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and suspect	ed parts	Uneven rotation torque	Rotation imbalance	Excessive run out	Differential	Axle	Suspension	Tires	Road wheel	Drive shaft	Brakes	Steering
	Noise	×	×	×	×	×	×	×	×	×	×	×
Symptom	Shake					×	×	×	×	×	×	×
	Vibration	×	×	×		×	×	×		×		×

^{×:} Applicable

[PROPELLER SHAFT: 2S1330]

ON-VEHICLE REPAIR

PROPELLER SHAFT

On-Vehicle Service


APPEARANCE AND NOISE INSPECTION


- Check the propeller shaft tube surface for dents or cracks. If damaged, replace the propeller shaft assembly.
- Check the bearings for noise and damage. Repair or replace the bearings as necessary.

PROPELLER SHAFT VIBRATION


If a vibration is present at high speed, inspect the propeller shaft runout first.

- Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands. Refer to <u>DLN-142</u>, "<u>General Specification</u>".
- If the runout exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180° and 270° and reconnect the propeller shaft.





4. After installation, check for vibration by driving vehicle.



DLN

Α

В

INFOID:0000000003220796

Е

F

Н

ı,

L

M

Ν

0

[PROPELLER SHAFT: 2S1330]


INFOID:0000000003220797

REMOVAL AND INSTALLATION

PROPELLER SHAFT

Removal and Installation

COMPONENTS



- 1. Propeller shaft tube
- 4. Sleeve yoke
- ⇐: Front

- 2. Snap ring
- 5. Journal


- 3. Journal bearing
- 6. Flange yoke

REMOVAL

- 1. Move the A/T select lever to the N position and release the parking brake.
- Put matching marks on the rear propeller shaft flange yoke and the rear final drive companion flange as shown. CAUTION:

For matching marks, use paint. Never damage the rear propeller shaft flange yoke or the companion flange.

3. Remove the bolts, then remove the propeller shaft from the rear final drive and A/T or transfer.




INSPECTION

PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[PROPELLER SHAFT: 2S1330]

 Inspect the propeller shaft runout. If runout exceeds the limit, replace the propeller shaft assembly. Refer to <u>DLN-142</u>, "General <u>Specification</u>".



 While holding the flange yoke on one side, check axial play of the joint as shown. If the journal axial play exceeds the specification, repair or replace the journal parts. Refer to <u>DLN-142</u>, "General <u>Specification"</u>.

 Check the propeller shaft tube for dents or cracks. If damage is detected, replace the propeller shaft assembly.




INSTALLATION

Installation is in the reverse order of removal.

- After installation, check for vibration by driving the vehicle. Refer to <u>DLN-152, "NVH Troubleshooting Chart"</u>.
- If propeller shaft assembly or final drive assembly has been replaced, connect them as follows:
- Face companion flange mark (A) of the final drive (1) upward. With the mark (A) faced upward, couple the propeller shaft and the final drive so that the matching mark (B) of the propeller shaft (2) can be positioned as closest as possible with the matching mark (C) of the final drive companion flange.
- Tighte propeller shaft and final drive bolts and nuts to specifications. Refer to <u>DLN-138</u>, "<u>Removal and Installation</u>".

CAUTION:

Do not reuse the bolts and nuts. Always install new ones.



Α

В

DLN

Е

F

G

Н

I

J

K

N

0

[PROPELLER SHAFT: 2S1330]

INFOID:0000000003220798

DISASSEMBLY AND ASSEMBLY

PROPELLER SHAFT

Disassembly and Assembly


DISASSEMBLY

Journal


1. Put matching marks on the rear propeller shaft and flange yoke as shown.

CAUTION:

For matching marks use paint. Never damage the rear propeller shaft or flange yoke.




2. Remove the snap rings.



3. Push out and remove the journal bearings by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:


Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



4. Push out and remove the remaining journal bearings at the opposite side by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:

Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.




ASSEMBLY

Journal

1. Assemble the journal bearings. Apply multipurpose grease on the bearing inner surface.

NOTE:

During assembly, use caution so that the needle bearings do not fall down.



DLN

Е

F

Н

K

M

Ν

Α

В


 Select new snap rings that will provide the specified play in an axial direction of the journal, and install them. Refer to <u>DLN-142</u>, <u>"Snap Ring"</u>.

CAUTION:


Do not reuse snap rings

NOTE:


Select snap rings with a difference in thickness at both sides within 0.02 mm (0.0008 in).



3. Adjust the thrust clearance between the bearing and snap ring to zero by tapping the yoke.



4. Make sure that the journal moves smoothly and is below the propeller joint flex effort specification. Refer to DLN-142, "General Specification".



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003304391

[PROPELLER SHAFT: 2S1330]

	VQ4	40DE	
Applied model	2WD	4	1WD
Applied model		King cab	Double cab
	61	M/T	
Final drive model	M	226	
Gear ratio	3.538		3.692
Number of pinion gears		2	
Number of teeth (Drive gear / drive pinion)	46/13	48/13	
Oil capacity (Approx.) ℓ (US pt, Imp pt)	2.01 (4-	1/4, 3-1/2)	
Drive pinion adjustment spacer type	Colla	psible	

Snap Ring

Model 2S1330 (4WD)

Unit: mm (in)

Thickness	Color	Part Number*
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

^{*}Always check with the Parts Department for the latest parts information.

Model 2S1330 (2WD)

Unit: mm (in)

Thickness	Color	Part Number*
1.600 - 1.638 (0.0630 - 0.0645)	Black	37146-EA500
1.549 - 1.588 (0.0610 - 0.0625)	Black	37147-EA500
1.524 - 1.562 (0.0600 - 0.0615)	Black	37148-EA500
1.499 - 1.537 (0.0590 - 0.0605)	Black	37149-EA500

^{*}Always check with the Parts Department for the latest parts information.

PREPARATION

< PREPARATION >

[PROPELLER SHAFT: 3S1310]

PREPARATION

PREPARATION

Commercial Service Tool

Tool name		Description	
Power tool		Loosening bolts and nuts	
	PBIC0190E		

Α

С

В

INFOID:0000000003303282

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[PROPELLER SHAFT: 3S1310]

INFOID:0000000003303283

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		<u>DLN-145</u> (front) <u>DLN-145</u> (rear)	<u>DLN-145</u> (front) <u>DLN-145</u> (rear)	<u>DLN-145</u> (front) <u>DLN-145</u> (rear)	DLN-172, "NVH Troubleshooting Chart" DLN-206, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart" RAX-6, "NVH Troubleshooting Chart" RAX-18, "NVH Troubleshooting Chart"	FSU-4, "NVH Troubleshooting Chart" RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	DLN-172, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and suspected parts		Uneven rotation torque	Rotation imbalance	Excessive run out	Differential	Axle	Suspension	Tires	Road wheel	Drive shaft	Brakes	Steering
Symptom	Noise	×	×	×	×	×	×	×	×	×	×	×
	Shake					×	×	×	×	×	×	×
	Vibration	×	×	×		×	×	×		×		×

^{×:} Applicable

[PROPELLER SHAFT: 3S1310]

ON-VEHICLE REPAIR

REAR PROPELLER SHAFT

On-Vehicle Service

APPEARANCE AND NOISE INSPECTION

Check the propeller shaft tube surface for dents or cracks. If damaged, replace the propeller shaft assembly.

PROPELLER SHAFT VIBRATION


If a vibration is present at high speed, inspect the propeller shaft runout first.


1. Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands.

Propeller shaft runout limit

2WD : 0.6 mm (0.024 in) or less 4WD : 1.02 mm (0.0402 in) or less

- If the runout exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180° and 270° and reconnect the propeller shaft.
- 3. Check the runout again. If the runout still exceeds specifications, replace the propeller shaft assembly.
- 4. After installation, check for vibration by driving vehicle.





DLN

Α

В

C

Е

F

G

Н

K

L

M

Ν

0

[PROPELLER SHAFT: 3S1310]

INFOID:0000000003303311


REMOVAL AND INSTALLATION

REAR PROPELLER SHAFT

Removal and Installation

COMPONENTS

Model 3S1310



- Propeller shaft (1st shaft)
- 4. Sleeve yoke (5A/T)
- Flange yoke 7.


- 2. Snap ring
- 5. Journal
- 8. Sleeve yoke (5M/T)
- Journal bearing 3.
- Propeller shaft (2nd shaft)
- ←: Front

REMOVAL

- 1. Put the transmission in neutral and release the parking brake.
- Put matching marks on the rear propeller shaft flange yoke and the rear final drive companion flange as shown. **CAUTION:**

For matching marks, use paint. Never damage the rear propeller shaft flange yoke or the companion flange.

Remove the bolts, then remove the propeller shaft from the rear final drive and transmission or transfer.



INSPECTION

REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[PROPELLER SHAFT: 3S1310]

• Inspect the propeller shaft runout. If runout exceeds the limit, replace the propeller shaft assembly.

Propeller shaft runout limit


2WD : 0.6 mm (0.024 in) or less 4WD : 1.02 mm (0.0402 in) or less



• While holding the flange yoke on one side, check axial play of the joint as shown. If the journal axial play exceeds the specification, repair or replace the journal parts.

Journal axial play : 0.02 mm (0.0008 in) or less

· Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.



INSTALLATION

Installation is in the reverse order of removal.

• After installation, check for vibration by driving the vehicle. Refer to DLN-144, "NVH Troubleshooting Chart". **CAUTION:**

Do not reuse the bolts and nuts. Always install new ones.

Α

В

DLN

Е

F

Н

K

L

M

Ν

[PROPELLER SHAFT: 3S1310]

INFOID:0000000003303312

DISASSEMBLY AND ASSEMBLY

REAR PROPELLER SHAFT

Disassembly and Assembly


DISASSEMBLY

Journal


1. Put matching marks on the rear propeller shaft and flange yoke as shown.

CAUTION:

For matching marks use paint. Never damage the rear propeller shaft or flange yoke.




2. Remove the snap rings.



3. Push out and remove the journal bearings by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:


Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



4. Push out and remove the remaining journal bearings at the opposite side by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:

Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



ASSEMBLY

REAR PROPELLER SHAFT

< DISASSEMBLY AND ASSEMBLY >


[PROPELLER SHAFT: 3S1310]

Journal

1. Assemble the journal bearings. Apply multipurpose grease on the bearing inner surface.

NOTE:

During assembly, use caution so that the needle bearings do not fall down.



DLN

Е

F

Н

K

M

Ν


Α

В


 Select snap rings that will provide the specified play in an axial direction of the journal, and install them. Refer to <u>DLN-150</u>, <u>"Snap Ring"</u>.

NOTE:

Select snap rings with a difference in thickness at both sides within 0.02 mm (0.0008 in).




3. Adjust the thrust clearance between the bearing and snap ring to zero by tapping the yoke.



4. Make sure that the journal moves smoothly and is below the joint flex effort specification.

Joint flex effort : 2.26 N·m (0.23 kg-m, 20 in-lb) or less



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003303291

[PROPELLER SHAFT: 3S1310]

014		B 4		_
ZV	٧U	IV	lod	е

Applied model	QR25DE
	M/T A/T
Propeller shaft model	3S1310
Number of joints	3
Coupling method with rear final drive	Flange type
Coupling method with transmission	Sleeve type
1st Shaft length (Center bearing to spider)	741.5 mm (29.19 in)
2nd Shaft length (Spider to spider)	779.8 mm (30.70 in)
Shaft outer diameter	76.2 mm (3.00 in)
Journal axial play	0.02 mm (0.0008 in) or less
Propeller shaft runout limit	0.6 mm (0.024 in) or less
Propeller shaft joint flex effort	2.26 N⋅m (0.23 kg-m, 20 in-lb) or less

Snap Ring

Unit: mm (in)

Thickness	Color	Part Number*
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

^{*}Always check with the Parts Department for the latest parts information.

PREPARATION

< PREPARATION >

[PROPELLER SHAFT: 3S1350]

PREPARATION

PREPARATION

Commercial Service Tool

Tool name	Description
Power tool	Loosening bolts and nuts

PBIC0190E

В

INFOID:0000000003220801

Α

DLN

С

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[PROPELLER SHAFT: 3S1350]

INFOID:0000000003220802

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		<u>DLN-158</u>	<u>DLN-158</u>	<u>DLN-158</u>	DLN-172, "NVH Troubleshooting Chart" DLN-240, "NVH Troubleshooting Chart" DLN-240, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart" RAX-6, "NVH Troubleshooting Chart" RAX-18, "NVH Troubleshooting Chart"	FSU-4, "NVH Troubleshooting Chart" RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5. "NVH Troubleshooting Chart"
Possible cause and suspected parts		Uneven rotation torque	Rotation imbalance	Excessive run out	Differential	Axle	Suspension	Tires	Road wheel	Drive shaft	Brakes	Steering
	Noise	×	×	×	×	×	×	×	×	×	×	×
Symptom	Shake					×	×	×	×	×	×	×
	Vibration	×	×	×		×	×	×		×		×

^{×:} Applicable

[PROPELLER SHAFT: 3S1350]

ON-VEHICLE REPAIR

PROPELLER SHAFT

On-Vehicle Service


APPEARANCE AND NOISE INSPECTION

- Check the propeller shaft tube surface for dents or cracks. If damaged, replace the propeller shaft assembly.
- Check the bearings for noise and damage. Repair or replace the bearings as necessary.


PROPELLER SHAFT VIBRATION

If a vibration is present at high speed, inspect the propeller shaft runout first.

- Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands. Refr to DLN-158, "General Specification".
- If the runout exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180° and 270° and reconnect the propeller shaft.



- 3. Check the runout again. If the runout still exceeds specifications, replace the propeller shaft assembly.
- 4. After installation, check for vibration by driving vehicle.



DLN

Α

В

Е

F

Н

.

K

L

M

Ν

0

[PROPELLER SHAFT: 3S1350]

REMOVAL AND INSTALLATION


PROPELLER SHAFT

Removal and Installation

INFOID:0000000003303293

COMPONENTS

Model 3S1330



- 1. Propeller shaft (1st shaft)
- 4. Sleeve yoke
- 7. Flange yoke

- 2. Snap ring
- 5. Journal
- ←: Front

- 3. Journal bearing
- 6. Propeller shaft (2nd shaft)


REMOVAL

- 1. Put the transmission in neutral and release the parking brake.
- Put matching marks on the rear propeller shaft flange yoke and the rear final drive companion flange as shown.

CAUTION:

For matching marks, use paint. Never damage the rear propeller shaft flange yoke or the companion flange.

Remove the bolts, then remove the propeller shaft from the rear final drive and transmission or transfer.



INSPECTION

PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[PROPELLER SHAFT: 3S1350]

• Inspect the propeller shaft runout. If runout exceeds the limit, replace the propeller shaft assembly.

Propeller shaft runout limit


2WD : 0.6 mm (0.024 in) or less 4WD : 1.02 mm (0.0402 in) or less



• While holding the flange yoke on one side, check axial play of the joint as shown. If the journal axial play exceeds the specification, repair or replace the journal parts.

Journal axial play : 0.02 mm (0.0008 in) or less

· Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.



INSTALLATION

Installation is in the reverse order of removal.

• After installation, check for vibration by driving the vehicle. Refer to DLN-152, "NVH Troubleshooting Chart". **CAUTION:**

Do not reuse the bolts and nuts. Always install new ones.

В

Α

DLN

Е

F

Н

K

L

M

Ν

[PROPELLER SHAFT: 3S1350]

INFOID:0000000003220805

DISASSEMBLY AND ASSEMBLY

PROPELLER SHAFT

Disassembly and Assembly


DISASSEMBLY

Journal


1. Put matching marks on the rear propeller shaft and flange yoke as shown.

CAUTION:

For matching marks use paint. Never damage the rear propeller shaft or flange yoke.




2. Remove the snap rings.



Push out and remove the journal bearings by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:


Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



4. Push out and remove the remaining journal bearings at the opposite side by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:

Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.




ASSEMBLY

Journal

1. Assemble the journal bearings. Apply multipurpose grease on the bearing inner surface.

NOTE:

During assembly, use caution so that the needle bearings do not fall down.



DLN

Е

F

Н

K

M

Ν

Α

В


2. Select new snap rings that will provide the specified play in an axial direction of the journal, and install them. Refer to <u>DLN-158</u>, "Snap Ring".

CAUTION:


Do not reuse snap rings

NOTE:


Select snap rings with a difference in thickness at both sides within 0.02 mm (0.0008 in).



3. Adjust the thrust clearance between the bearing and snap ring to zero by tapping the yoke.



4. Make sure that the journal moves smoothly and is below the joint flex effort specification. Refer to <u>DLN-158</u>, "General Specification".



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003303369

[PROPELLER SHAFT: 3S1350]

Applied model	VQ40DE	
	M/T	
Propeller shaft model	3S1330 (steel tube)	
Number of joints	3	
Coupling method with rear final drive	Flange type	
Coupling method with transmission	Sleeve type	
1st Shaft length (Center bearing to spider)	674.5 mm (26.56)	
2nd Shaft length (Spider to spider)	783.8 mm (30.86 in)	
Shaft outer diameter	76.2 mm (3.00 in)	
Journal axial play	0.02 mm (0.0008 in) or less	
Propeller shaft runout limit	0.6 mm (0.024 in) or less	
Propeller shaft joint flex effort	2.26 N·m (0.23 kg-m, 20 in-lb) or less	

^{*} Option (With electronic locking differential)

Snap Ring

Model 3S1330 (steel tube)

Unit: mm (in)

Thickness	Color	Part Number*
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

^{*}Always check with the Parts Department for the latest parts information.

PREPARATION

< PREPARATION >

[PROPELLER SHAFT: 3S1330-2BJ100]

PREPARATION

PREPARATION

Commercial Service Tool

Tool name		Description
Power tool		Loosening bolts and nuts
	PBIC0190E	

С

Α

В

INFOID:0000000003303297

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

Ρ

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000003303298

[PROPELLER SHAFT: 3S1330-2BJ100]

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		<u>DLN-128</u> (front) <u>DLN-160</u> (rear)	<u>DLN-128</u> (front) <u>DLN-160</u> (rear)	<u>DLN-128</u> (front) <u>DLN-153</u> (rear)	DLN-172, "NVH Troubleshooting Chart" DLN-206, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart" RAX-6, "NVH Troubleshooting Chart"	FSU-4, "NVH Troubleshooting Chart" RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and suspected parts		Uneven rotation torque	Rotation imbalance	Excessive run out	Differential	Axle	Suspension	Tires	Road wheel	Drive shaft	Brakes	Steering
	Noise	×	×	×	×	×	×	×	×	×	×	×
Symptom	Shake					×	×	×	×	×	×	×
	Vibration	×	×	×		×	×	×		×		×

 $[\]times$: Applicable

[PROPELLER SHAFT: 3S1330-2BJ100]

ON-VEHICLE REPAIR

REAR PROPELLER SHAFT

On-Vehicle Service

APPEARANCE AND NOISE INSPECTION

Check the propeller shaft tube surface for dents or cracks. If damaged, replace the propeller shaft assembly.

PROPELLER SHAFT VIBRATION


If a vibration is present at high speed, inspect the propeller shaft runout first.


1. Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands.

Propeller shaft runout limit

2WD : 0.6 mm (0.024 in) or less 4WD : 1.02 mm (0.0402 in) or less

- If the runout exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180° and 270° and reconnect the propeller shaft.
- 3. Check the runout again. If the runout still exceeds specifications, replace the propeller shaft assembly.
- 4. After installation, check for vibration by driving vehicle.





DLN

Α

В

C

Е

F

G

Н

K

L

M

Ν

0

[PROPELLER SHAFT: 3S1330-2BJ100]

INFOID:0000000003303303


REMOVAL AND INSTALLATION

REAR PROPELLER SHAFT

Removal and Installation

COMPONENTS

Model 3S1330-2BJ100



- 1. Propeller shaft (1st shaft)
- 2. Snap ring

4. Sleeve yoke

5. Journal

- 3. Journal bearing
- 6. Propeller shaft (2nd shaft)


REMOVAL

⇐: Front

- 1. Put the transmission in neutral and release the parking brake.
- Put matching marks on the rear propeller shaft flange yoke and the rear final drive companion flange as shown. CAUTION:

For matching marks, use paint. Never damage the rear propeller shaft flange yoke or the companion flange.

3. Remove the bolts, then remove the propeller shaft from the rear final drive and transmission or transfer.



INSPECTION

REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[PROPELLER SHAFT: 3S1330-2BJ100]

• Inspect the propeller shaft runout. If runout exceeds the limit, replace the propeller shaft assembly.

Propeller shaft runout limit


2WD : 0.6 mm (0.024 in) or less 4WD : 1.02 mm (0.0402 in) or less



• While holding the flange yoke on one side, check axial play of the joint as shown. If the journal axial play exceeds the specification, repair or replace the journal parts.

Journal axial play : 0.02 mm (0.0008 in) or less

· Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.



INSTALLATION

Installation is in the reverse order of removal.

• After installation, check for vibration by driving the vehicle. Refer to DLN-160, "NVH Troubleshooting Chart". **CAUTION:**

Do not reuse the bolts and nuts. Always install new ones.

DLN

Е

F

Α

В

Н

K

L

M

Ν

[PROPELLER SHAFT: 3S1330-2BJ100]

INFOID:0000000003303307

DISASSEMBLY AND ASSEMBLY

REAR PROPELLER SHAFT

Disassembly and Assembly


DISASSEMBLY

Journal


1. Put matching marks on the rear propeller shaft and flange yoke as shown.

CAUTION:

For matching marks use paint. Never damage the rear propeller shaft or flange yoke.




2. Remove the snap rings.



Push out and remove the journal bearings by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:


Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



4. Push out and remove the remaining journal bearings at the opposite side by lightly tapping the flange yoke with a hammer, taking care not to damage the journal or flange yoke hole.

NOTE:

Put marks on the disassembled parts so that they can be reinstalled in their original positions from which they were removed.



ASSEMBLY

REAR PROPELLER SHAFT

< DISASSEMBLY AND ASSEMBLY >


[PROPELLER SHAFT: 3S1330-2BJ100]

Journal

1. Assemble the journal bearings. Apply multipurpose grease on the bearing inner surface.

NOTE:

During assembly, use caution so that the needle bearings do not fall down.



DLN

Е

F

Н

K

M

Ν


Α

В


2. Select snap rings that will provide the specified play in an axial direction of the journal, and install them. Refer to <u>DLN-166</u>, "Snap Ring".

NOTE:

Select snap rings with a difference in thickness at both sides within 0.02 mm (0.0008 in).




3. Adjust the thrust clearance between the bearing and snap ring to zero by tapping the yoke.



4. Make sure that the journal moves smoothly and is below the joint flex effort specification.

Joint flex effort : 2.26 N·m (0.23 kg-m, 20 in-lb) or less



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[PROPELLER SHAFT: 3S1330-2BJ100]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003303308

2V	۱/I ۱	N/	\sim	

Applied model	VQ40DE
	A/T
Propeller shaft model	3S1330-2BJ100
Number of joints	3
Coupling method with rear final drive	Flange type
Coupling method with transmission	Sleeve type
1st Shaft length (Center bearing to spider)	741.5 mm (29.19 in)
2nd Shaft length (Spider to spider)	813.6 mm (32.03 in) [783.8 mm (30.86 in)*]
Shaft outer diameter	76.2 mm (3.00 in)
Journal axial play	0.02 mm (0.0008 in) or less
Propeller shaft runout limit	0.6 mm (0.024 in) or less
Propeller shaft joint flex effort	2.26 N·m (0.23 kg-m, 20 in-lb) or less

^{*} Option (With electronic locking differential)

Snap Ring

Model 3S1330-2B100

Unit: mm (in)

Thickness	Color	Part Number*
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

^{*}Always check with the Parts Department for the latest parts information.

PRECAUTIONS

< PRECAUTION >

[FRONT FINAL DRIVE: R180A]

PRECAUTION

PRECAUTIONS

Precaution for Servicing Front Final Drive

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

DLN

Α

INFOID:0000000003220808

Е

F

Н

K

L

N

[FRONT FINAL DRIVE: R180A]

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000003220809

Tool number (Kent-Moore No.) Tool name		Description
KV38108300 (J-44195) Flange wrench		Removing and installing drive pinion lock nut
KV381054S0 (J-34286) Puller	NT771	Removing front oil seal
ST30720000 (J-25405) Drift	a b ZZAO811D	Installing front oil seal Installing side oil seal a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.
ST27863000 (—) Drift	ZZA1003D	Installing front oil seal Installing side oil seal a: 74.5 mm (2.933 in) dia. b: 62.5 mm (2.461 in) dia.
ST3127S000 (J-25765-A) Preload gauge 1: GG91030000 (J-25765) Torque wrench 2: HT62940000 (—) Socket adapter (1/2") 3: HT62900000 (—) Socket adapter (3/8")	1 2 0 NT124	Measuring drive pinion bearing preload torque and total preload torque

	[FRONT FINAL DRIVE: R180A]
	Description
	Removing carrier cover
5-N1U46	Removing and installing side bearing inner
2 nto72	race a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.
	Removing drive pinion rear bearing inner race
Z7A0700D	
	Installing side bearing adjusting washer
SDIA0429J	Installing drive pinion rear bearing outer race
ZZA1000D	a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.
	Installing drive pinion rear bearing outer race
S-NT090	(Use with ST30613000)
0.11000	Installing drive pinion front bearing outer race
ab	a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.
ZZA1143D	
	SDIA0429J ZZA1000D ZZA1000D

PREPARATION

<	Р	R	F	P	Δ	R	Δ٦	ГΙ	\cap	N	`
٠.					_	1 N	$\boldsymbol{-}$		v	ıvı	_

[FRONT FINAL DRIVE: R180A]

Tool number (Kent-Moore No.)		Description
Tool name ST30901000 (J-26010-01) Drift	a b c	Installing drive pinion rear bearing inner race a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.
ST33200000 (J-26082) Drift	a b ZZA1002D	Installing drive pinion front bearing inner race a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.
ST33230000 (J-35867) Drift	a b	Installing side bearing inner race a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia. c: 28 mm (1.10 in) dia.
(—) (J-34309) Differential shim selector tool	ZZA1046D	Adjusting bearing preload and drive pinion height
(—) (J-25269-18) Side bearing disc (2 Req'd)		Selecting drive pinion height adjusting washe
KV10112100 (BT-8653-A) Angle wrench	NT135	Tightening bolts for drive gear

Commercial Service Tool

INFOID:0000000003220810

PREPARATION

< PREPARATION >

[FRONT FINAL DRIVE: R180A]

Tool name		Description	Λ
Power tool		Loosening nuts and bolts	A
			В
	PBIC0190E		C

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[FRONT FINAL DRIVE: R180A]

INFOID:0000000003220811

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		DLN-181	DLN-181	<u>DLN-181</u>	<u>DLN-181</u>	DLN-181	<u>DLN-174</u>	DLN-152, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	FSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart."
Possible cause and SUSPECTED PARTS		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	FRONT AXLE	FRONT SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom Noise		×	×	×	×	×	×	×	×	×	×	×	×	×	×

^{×:} Applicable

DESCRIPTION

Cross-Sectional View

DIAGSSEE

- 1. Differential side shaft
- 4. Drive gear
- 7. Side bearing
- 10. Collapsible spacer
- 13. Drive pinion rear bearing
- 2. Differential side shaft bearing
- 5. Pinion mate shaft
- 8. Pinion mate gear
- 11. Companion flange
- 14. Housing spacer

- 3. Side gear
- 6. Differential case
- 9. Drive pinion
- 12. Drive pinion front bearing

INFOID:0000000003220812

Α

В

C

DLN

Е

F

G

Н

Κ

L

M

Ν

0

Ρ

[FRONT FINAL DRIVE: R180A]

INFOID:0000000003220813

ON-VEHICLE MAINTENANCE

DIFFERENTIAL GEAR OIL


Changing Differential Gear Oil

DRAINING

- 1. Stop the engine.
- Remove the drain plug and gasket from the front final drive assembly to drain the differential gear oil.
- 3. Install the drain plug with a new gasket to the front final drive assembly. Tighten to the specified torque. Refer to DLN-181, "Disassembly and Assembly".

CAUTION:

Do not reuse gasket.



FILLING

- Remove the filler plug and gasket from the front final drive assembly.
- 2. Fill the front final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil grade and capacity

: Refer to MA-12, "Fluids and Lubricants".

3. Install the filler plug with a new gasket on it to the front final drive assembly. Tighten to the specified torque. Refer to DLN-181, "Disassembly and Assembly".

CAUTION:

Do not reuse gasket.

Checking Differential Gear Oil

INFOID:0000000003220814

LDIA0176E

DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

- Make sure that differential gear oil is not leaking from the front final drive assembly or around it.
- Check the differential gear oil level from the filler plug hole as shown.


CAUTION:


Do not start engine while checking differential gear oil level.

Install the filler plug with a new gasket on it to the front final drive assembly. Tighten to the specified torque. Refer to DLN-181, "Disassembly and Assembly".

CAUTION:

Do not reuse gasket.





Filler plug

Oil level

[FRONT FINAL DRIVE: R180A]

ON-VEHICLE REPAIR

FRONT OIL SEAL

Removal and Installation

REMOVAL

- 1. Remove the drive shafts from the front final drive assembly. Refer to FAX-6, "Removal and Installation".
- Remove the front propeller shaft from the front final drive assembly. Refer to <u>DLN-130</u>, "<u>Removal and Installation</u>".
- Measure the total preload torque. Refer to <u>DLN-181, "Disassembly and Assembly"</u>.
 NOTE:

Record the total preload torque measurement.

4. Remove the drive pinion lock nut using Tool.

Tool number : KV38108300 (—)

5. Put matching marks on the companion flange and drive pinion using paint.


CAUTION:


Use paint to make the matching marks. Do not damage the companion flange or drive pinion.


6. Remove the companion flange using suitable tool.

Remove the front oil seal using Tool.

Tool number : KV381054S0 (J-34286)







INSTALLATION

DLN

Α

В

C

INFOID:0000000003220815

Е

F

G

Н

K

L

M

Ν

0

< ON-VEHICLE REPAIR >


 Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tools.

Tool number A: ST30720000 (J-25405)

B: ST27863000 (—)

CAUTION:

- · Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



[FRONT FINAL DRIVE: R180A]

- 2. Install the companion flange to the drive pinion while aligning the matching marks.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

Tool number A: KV38108300 (—)

B: ST3127S000 (J-25765-A)

Total preload torque: Refer to <u>DLN-181, "Disassembly and Assembly".</u>

- The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg-m, 5 in-lb).
- If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg-m, 5ft-lb) increments until the total preload torque is met.

CAUTION:

- Do not reuse drive pinion lock nut.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to <u>DLN-181</u>, "<u>Disassembly and Assembly</u>".
- Do not loosen drive pinion lock nut to adjust the total preload torque. If the drive pinion lock nut
 torque or the total preload torque exceeds the specifications, replace the collapsible spacer and
 tighten it again to adjust. Refer to <u>DLN-181</u>, "<u>Disassembly and Assembly</u>".
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 4. Install new side oil seals into the front final drive assembly. Refer to DLN-177, "Removal and Installation".
- 5. Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to <u>DLN-174, "Checking Differential Gear</u> Oil".

SIDE OIL SEAL


Removal and Installation

REMOVAL

1. Remove the drive shafts from the front final drive assembly. Refer to FAX-6, "Removal and Installation".

Remove the side oil seal using suitable tool. CAUTION:

Do not reuse the side oil seal.



INSTALLATION


 Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal. Then drive the new side oil seal in evenly until it becomes flush with the gear carrier using Tools.

Tool number A: ST30720000 (J-25405)

B: ST27863000 (—)

CAUTION:

- Do not reuse side oil seal.
- · Do not incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal.



2. Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to <u>DLN-174, "Checking Differential Gear Oil".</u>

L

M

K

J

Α

DLN

Е

Н

INFOID:0000000003220816

Ν

[FRONT FINAL DRIVE: R180A]

INFOID:0000000003220817

CARRIER COVER

Removal and Installation


REMOVAL

- 1. Remove the front final drive assembly. Refer to <u>DLN-179</u>, "Removal and Installation".
- 2. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



INSTALLATION

- 1. Apply a 3 mm (0.12 in) bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, <u>"Recommended Chemical Products and Sealants"</u>.


CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to <u>DLN-181</u>, "<u>Disassembly and Assembly</u>".
- 3. Install the front final drive assembly. Refer to <u>DLN-179</u>, <u>"Removal and Installation"</u>.



Fill the front final drive assembly with recommended differential gear oil. Refer to <u>DLN-174</u>.




[FRONT FINAL DRIVE: R180A]

REMOVAL AND INSTALLATION

FRONT FINAL DRIVE ASSEMBLY

Removal and Installation



- 1. Breather hose

- 2. Front final drive assembly
- 3. Front crossmember

REMOVAL

- 1. Drain the differential gear oil. Refer to <u>DLN-174</u>.
- 2. Remove the drive shafts from the front final drive assembly. Refer to FAX-6, "Removal and Installation".
- 3. Remove the front crossmember.
- Remove the front propeller shaft from the front final drive assembly. Refer to <u>DLN-130</u>, "<u>Removal and Installation</u>".
- 5. Disconnect the vent hose from the front final drive assembly.

С

Α

В

INFOID:0000000003220818

DLN

Г

G

Н

K

VI

Ν

 \bigcirc

FRONT FINAL DRIVE ASSEMBLY


< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

- 6. Support the front final drive assembly using a suitable jack.
- 7. Remove the front final drive assembly bolts, then remove the front final drive assembly.

CAUTION:

Support the front final drive assembly while removing using a suitable jack.



INSTALLATION

Installation is in the reverse order of removal.

- Install new side oil seals into the front final drive assembly. Refer to DLN-177, "Removal and Installation".
- Make sure there are no pinched or restricted areas on the breather hose caused by folding or bending when installing it.
- Fill the front final drive assembly with differential gear oil after installation. Refer to <u>DLN-174</u>.


DISASSEMBLY AND ASSEMBLY

FRONT FINAL DRIVE

Disassembly and Assembly

COMPONENTS

SEC. 380



Drive pinion lock nut 1.

Drive pinion front bearing 4.

Bushing 7.

10. Snap ring

Drain plug 13.

Drive pinion height adjusting washer 17. 16.

19. Side bearing

22. Pinion mate shaft

Pinion mate thrust washer

Companion flange 2.

5. Gear carrier

Differential side shaft 8.

Snap ring 11.

14. Collapsible spacer

Drive pinion

20. Side gear thrust washer

23. Lock pin

26. Drive gear

3. Front oil seal

6. Side oil seal

9. Differential side shaft bearing

12. Gasket

15. Drive pinion rear bearing

Side bearing adjusting washer 18.

21. Side gear

24. Pinion mate gear

27. Differential case

DLN

Α

В

INFOID:0000000003220819

F

Н

K

M

Ν

28. Housing spacer

29. Side bearing cap

30. Filler plug

31. Carrier cover

ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to <u>DLN-174</u>.
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to <u>DLN-178</u>.

Total Preload Torque

Install the differential side shaft if necessary. Refer to <u>DLN-177, "Removal and Installation"</u>.
 CAUTION:

The differential side shaft must be installed in order to measure total preload torque.

- 2. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- 3. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
- 4. Measure total preload torque using Tool.


Tool number : ST3127S000 (J-25765-A)

Total preload torque:

1.67 - 2.74 N·m (0.17 - 0.27 kg-m, 15 - 24 in-lb)

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque



 If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

If the total preload torque is greater than specification

On drive pinion bearings: Replace the collapsible spacer.

On side bearings: Use thinner side bearing adjusting washers by the same

amount on each side. Refer to DLN-200, "Inspection and Adjust-

ment".

If the total preload torque is less than specification

On drive pinion bearings: Tighten the drive pinion lock nut.

On side bearings: Use thicker side bearing adjusting washers by the same

amount on each side. Refer to DLN-200, "Inspection and Adjust-

ment".

CAUTION:

Select a side bearing adjusting washer for right and left individually.

Drive Gear Runout

- 1. Fit a dial indicator to the drive gear back face.
- 2. Rotate the drive gear to measure runout.


Runout limit: 0.08 mm (0.0031 in) or less

 If the runout is outside of the limit, check the condition of the drive gear assembly. Foreign material may be caught between the drive gear and differential case, or the differential case or drive gear may be deformed.

CAUTION:

Replace drive gear and drive pinion as a set.

Tooth Contact



FRONT FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

1. Apply red lead to the drive gear.


NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.




Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown. CAUTION:


Check tooth contact on drive side and reverse side.



• If the tooth contact is improperly adjusted, adjust the drive pinion height (dimension X).



 If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washer to move drive pinion closer to the drive gear.
 Refer to <u>DLN-200</u>, "Inspection and Adjustment".



Α

В

С

DLN

Е

F

G

|

Н

J

K

L


M

Ν

 \cap

Ρ

 If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washer to move the drive pinion farther from the drive gear.
 Refer to DLN-200, "Inspection and Adjustment".



Backlash

 Fit a dial indicator to the drive gear face to measure the backlash

Backlash: 0.10 - 0.15 mm (0.0039 - 0.0059 in)


If the backlash is outside of the specification, change the thickness of the side bearing adjusting washers.

If the backlash is greater than specification:

Make side bearing adjusting washer thicker on drive gear back side, and side bearing adjusting washer thinner on drive gear tooth side by the same amount. Refer to <u>DLN-200</u>, "<u>Inspection and Adjustment</u>".

If the backlash is less than specification:

Make side bearing adjusting washer thinner on drive gear back side, and side bearing adjusting washer thicker on drive gear tooth side by the same amount. Refer to <u>DLN-200</u>, "<u>Inspection and Adjustment</u>".



CAUTION

Do not change the total thickness of side bearing adjusting washers as it will change the side bearing preload torque.

Companion Flange Runout

Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.


Runout limit: 0.1 mm (0.004 in) or less

- 2. If the runout is outside the runout limit, follow the procedure below to adjust.
- Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
- If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
- c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.

DISASSEMBLY

Differential side shaft

Drain the differential gear oil if necessary.



FRONT FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >


[FRONT FINAL DRIVE: R180A]

Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:


- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




Remove side oil seal.

CAUTION:

Do not damage gear carrier.



4. Remove snap ring (hole side) using suitable tool.




Remove differential side shaft assembly out of gear carrier using suitable tool.

NOTE:


Tap on differential side shaft assembly from side gear side.

6. Remove snap ring (differential side shaft side).



Press differential side shaft out of differential side shaft bearing. CAUTION:

Do not drop differential side shaft.



В

Α

C

DLN

Е

F

G

Н

J

,

L


M

Ν


0

Differential Assembly


- 1. Remove differential side shaft assembly. Refer to <u>DLN-177</u>, "Removal and Installation".
- 2. Remove side seal from gear carrier using suitable tool.
- For proper reinstallation, paint matching marks on one side of the side bearing cap and gear carrier.
 CAUTION:
 - For matching marks, use paint. Do not damage side bearing cap or gear carrier.
 - Side bearing caps are line-board during manufacture. The matching marks are used to reinstall them in their original positions.



4. Remove the side bearing caps.



- Lift the differential case assembly out of the gear carrier.CAUTION:
 - Keep side bearing outer races together with side bearing inner races. Do not mix them up.
 - Keep side bearing adjusting washers together with side bearings.




- 6. Remove housing spacer.
- 7. Remove side bearing inner race using Tools as shown.

Tool number A: ST33051001 (J-22888-20)


B: ST33061000 (J-8107-2)

CAUTION:

- Do not remove side bearing inner race unless it is being replaced.
- Place copper plates between the vise and the side bearing inner race and drive gear to prevent damage.



 Keep side bearing outer races together with side bearing inner races. Do not mix them up.




8. For proper reinstallation, paint matching marks on the differential case and drive gear.

CAUTION:


Use paint for matching marks. Do not damage differential case or drive gear.

- 9. Remove the drive gear bolts.
- 10. Tap the drive gear off the differential case using suitable tool.


Tap evenly all around to keep drive gear from bending.




11. Remove the lock pin of the pinion mate shaft from the drive gear side using suitable tool.



12. Remove the pinion mate shaft.



13. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from the differential case.



Α

В

DLN

F

Н

M

Ν

0

Drive Pinion Assembly


- Remove the differential assembly. Refer to <u>DLN-181</u>, "<u>Disassembly and Assembly</u>".
- 2. Remove the drive pinion lock nut using Tool.

Tool number : KV38108300 (J-44195)


3. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.




4. Remove the companion flange using suitable tool.




Press the drive pinion assembly (with rear inner bearing race and collapsible spacer) out of the gear carrier.CAUTION:

Do not drop drive pinion assembly.




6. Remove the drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

Tool number : ST30031000 (J-22912-01)



Remove the front oil seal using suitable tool. CAUTION:


Do not damage gear carrier.



8. Remove the drive pinion front bearing inner race.

Remove the drive pinion front and rear bearing outer races by tapping them uniformly using suitable tool. CAUTION:

Do not damage gear carrier.



INSPECTION AFTER DISASSEMBLY

Clean the disassembled parts. Then inspect the parts for wear or damage. If wear or damage are found, follow the measures below.

Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

If any chips (by friction), damage, or unusual wear are found, replace with new one.

Gear Carrier

If any wear or cracks are found on the contact sides of gear carrier, replace with new one.

Companion Flange

• If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

ADJUSTING AND SELECTING WASHERS

Side Gear Back Clearance

Assemble the differential parts if they are disassembled. Refer to "<u>DLN-181, "Disassembly and Assembly"</u>.

Α

DLN

Е

F

G


Н

M

N

0

1. Place the differential case straight up so that the side gear to be measured is upward.



 Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

Side gear back clearance: 0.1 mm (0.004 in) or less.

 If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to <u>DLN-200</u>, "<u>Inspection and Adjustment</u>".

If the side gear back clearance is greater than specification:

Use a thicker side gear thrust washer.

If the side gear back clearance is less than specification:

Use a thinner side gear thrust washer.

CAUTION:

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- Select a side gear thrust washer for right and left individually.


NOTE:


Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.

Drive Pinion Height

- 1. Make sure all parts are clean and that the bearings are well lubricated.
- 2. Assemble the drive pinion bearings onto the Tool.

Tool number : — (J-34309)






FRONT FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


- **Drive pinion front bearing**; make sure the J-34309-3 drive pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the J-34309-7 drive pinion front bearing pilot to secure the drive pinon front bearing in its proper position.
- **Drive pinion rear bearing**; the J-34309-8 drive pinion rear bearing pilot is used to center the drive pinion rear bearing only. The J-34309-4 drive pinion rear bearing locking seat is used to lock the drive pinion rear bearing to the assembly.
- Installation of J-34309-9 and J-34309-16; place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).
- Install the drive pinion rear bearing inner race into the gear carrier. Then insert the drive pinion height adjusting washer selector tool, J-34309-1, gauge screw assembly.



DLN

Α


В



Е

G


4. Assemble the drive pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in the gear carrier. Make sure that the drive pinion height gauge plate, J-34309-16, will turn a full 360°. Tighten the two sections together by hand.



Н

Κ

Turn the assembly several times to seat the drive pinon bearings.



Ν


M

6. Measure the turning torque at the end of the J-34309-2 gauge anvil using Tool.

Tool number : ST3127S000 (J-25765- A)

Turning torque specification:


1.0 - 1.6 N·m (0.11 - 0.16 kg-m, 9 - 14 in-lb)



7. Place the J-34309-10 "R180A" drive pinion height adapter onto the gauge plate and tighten it by hand.


CAUTION:

Make sure all machined surfaces are clean.




 Position the side bearing discs, Tool, and arbor firmly into the side bearing bores. Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to <u>DLN-181</u>, <u>"Disassembly and Assembly"</u>.


Tool number : — (J-25269-18)



9. Select the correct standard drive pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and your J-34309-101 feeler gauge. Measure the distance between the J-34309-10 drive pinion height adapter, including the standard gauge and the arbor.



10. Write down the exact measurement (the value of feeler gauge).




FRONT FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

11. Correct the drive pinion height adjusting washer size by referring to the drive pinion "head number".

There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the drive pinion "head number". It refers to the ideal drive pinion height from standard for quietest operation. Use the following chart to determine the correct drive pinion height adjusting washer.




Head number	Add or remove from the standard drive pinion height adjusting washer thickness measurement
- 6	Add 0.06 mm (0.0024 in)
- 5	Add 0.05 mm (0.0020 in)
- 4	Add 0.04 mm (0.0016 in)
- 3	Add 0.03 mm (0.0012 in)
- 2	Add 0.02 mm (0.0008 in)
- 1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

12. Select the correct drive pinion height adjusting washer. Refer to DLN-200, "Inspection and Adjustment".

13. Remove the Tool from the gear carrier and disassemble to retrieve the drive pinion bearings.

Tool number : — (J-34309)



ASSEMBLY

Drive Pinion Assembly

M

K

L

Α

В

DLN

Е

F

Н

Ν

0


1. Install drive pinion rear bearing outer race and drive pinion front bearing outer race using Tools.

Tool number A: ST30611000 (J-25742-1)

B: ST30613000 (J-25742-3) C: KV38100200 (J-26233)

CAUTION:

- First tap the drive pinion bearing outer race until it becomes flush with the gear carrier.
- Do not reuse drive pinion front and rear bearing outer race.




- 2. Select drive pinion height adjusting washer. Refer to DLN-200, "Inspection and Adjustment".
- 3. Install the selected drive pinion height adjusting washer to the drive pinion. Press the drive pinion rear bearing inner race to it using Tool.

Tool number : ST30901000 (J-26010-01)

CAUTION:

- Install the drive pinion height adjusting washer in the proper direction as shown.
- Do not reuse drive pinion rear bearing inner race.



Press

4. Install the collapsible spacer to the drive pinion.


CAUTION:

Do not reuse collapsible spacer.

- 5. Apply differential gear oil to the drive pinion rear bearing, and install the drive pinion assembly to the gear carrier.
- Apply differential gear oil to the drive pinion front bearing, and install the drive pinion front bearing inner race to the drive pinion assembly.

CAUTION:

Do not reuse drive pinion front bearing inner race.




FRONT FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

7. Press the drive pinion front bearing inner race to the drive pinion as far as drive pinion lock nut can be tightened using Tool.

Tool number : ST33200000 (J-26082)



[FRONT FINAL DRIVE: R180A]


8. Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tools.

Tool number A: ST30720000 (J-25405)

B: ST27863000 (—)

CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



9. Install the companion flange to the drive pinion while aligning the matching marks.

10. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

Tool number A: KV38108300 (J-44195)

B: ST3127S000 (J-25765-A)


Drive pinion bearing preload torque:

1.08 - 1.66 N·m (0.11 - 0.16 kg-m, 10 - 14 in-lb)

CAUTION:

- Do not reuse drive pinion lock nut.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to <u>DLN-181</u>, "<u>Disassembly</u> and Assembly".
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 11. Check companion flange runout. Refer to <u>DLN-200, "Inspection and Adjustment"</u>.
- 12. Install the differential case assembly. Refer to DLN-181, "Disassembly and Assembly".

Differential Assembly



В

Α

DLN

_

F

G

Н

|

J

Κ

L


M

Ν


0

WDIA0382E


1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly, or reinstall the old ones on the side gears.



- Install the side gears and side gear thrust washers into the differential case.
- 3. Install the pinion mate thrust washers to the two pinion mate gears. Then install the pinion mate gears with the pinion mate thrust washers by aligning them in diagonally opposite positions and rotating them into the differential case.




- 4. Install the pinion mate shaft and align the lock pin hole on the pinion mate shaft with the lock pin hole on the differential case.
- 5. Measure the side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to <u>DLN-200</u>, "Inspection and Adjustment".




6. Drive a new lock pin into the pinion mate shaft until it is flush with the differential case using suitable tool.

CAUTION:

Do not reuse lock pin.



 Align the matching mark of the differential case with the mark of the drive gear, then place the drive gear onto the differential case.



FRONT FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

8. Apply thread locking sealant into the threaded holes of the drive gear and install the new drive gear bolts.

Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

CAUTION:

Make sure the drive gear back and threaded holes are clean.




[FRONT FINAL DRIVE: R180A]

9. Tighten the new drive gear bolts to the specified torque. Refer to <u>DLN-181</u>, "<u>Disassembly and Assembly</u>". After tightening the new drive gear bolts to the specified torque, tighten an additional 34° to 39° using Tool.

Tool number : KV10112100-A (BT-8653-A)

CAUTION:

- Always use Tool. Avoid tightening based on visual check alone.
- Tighten new drive gear bolts in a crisscross pattern.




Tool number A: ST33230000 (J-35867)

B: ST33061000 (J-8107-2)

CAUTION:


Do not reuse side bearing inner races.



- 11. Install housing spacer into gear carrier.
- 12. Apply differential gear oil to the side bearings, and install the differential case assembly with the side bearing outer races into the gear carrier.

CAUTION:

Do not reuse side bearing outer race when replacing side bearing inner race (replace as a set).



Α

В

C

DLN

Е

F

Н

-


0

M


Ν

13. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier using Tool.

Tool number : KV38100600 (J-25267)



14. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque. Refer to <u>DLN-181</u>. "<u>Disassembly and Assembly</u>".



Tool B

Tool A


15. Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal. Then drive the new side oil seal in evenly until it becomes flush with the gear carrier using Tools.

Tool number A: ST30720000 (J-25405)

B: ST27863000 (—)

CAUTION:

- · Do not reuse side oil seal.
- Do not incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal.




Recheck above items.

- 17. Apply a 3 mm (0.12 in) bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, <u>"Recommended Chemical Products and Sealants"</u>.

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

18. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-181, "Disassembly and <a href="Assembly".



Differential side shaft

FRONT FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

Press differential side shaft bearing to differential side shaft.
 CAUTION:

Do not reuse differential side shaft bearing.

- 2. Install snap ring (differential side shaft side).
- 3. Install differential side shaft assembly into gear carrier.
- 4. Install snap ring (hole side).




 Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal. Then drive the new side oil seal in evenly until it becomes flush with the gear carrier using Tools.

Tool number A: ST30720000 (J-25405)

B: ST27863000 (—)

CAUTION:

- · Do not reuse side oil seal.
- Do not incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal.



Α

В

C

DLN

Е

F

G

Н

ı

J

Κ

L

M

Ν

C

SERVICE DATA AND SPECIFICATIONS (SDS) D SPECIFICATIONS (SDS) [FRONT FINAL DRIVE: R180A]

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003304395

Body type	King cab Crew		v cab			
Engine type	VQ40DE					
Transmission type	6M/T 5A/T 6M/T		5A/T			
Electronic locking differential	N/A	Applicable	N/A	Applicable	Not-applicab	le/Applicable
Final drive model	R180A					
Gear ratio	3.538	3.692	3.133	3.357	3.692	3.357
Number of teeth (Drive gear/Drive pinion)	46/13	48/13	47/15	47/14	48/13	47/14
Oil capacity (Approx.) ℓ (US pt, Imp pt)	0.85 (1-3/4, 1-1/2)			ı		
Number of pinion gears	2					
Drive pinion adjustment spacer type	Collapsible					

Inspection and Adjustment

INFOID:0000000003220821

DRIVE GEAR RUNOUT

Unit: mm (in)

Item	Runout limit
Drive gear back face	0.08 (0.0031) or less

SIDE GEAR CLEARANCE

Unit: mm (in)

Item	Specification
Side gear back clearance (Clearance between side gear and differential case for adjusting side gear backlash)	0.1 (0.004) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

PRELOAD TORQUE

Unit: N·m (kg-m, in-lb)

Item	Specification
Drive pinion bearing preload torque	1.08 - 1.66 (0.11 - 0.16, 10 - 14)
Side bearing preload torque	0.59 - 1.08 (0.06 - 0.11, 6 - 9)
Total preload torque (Total preload torque = drive pinion bearing preload torque + side bearing preload torque).	1.67 - 2.74 (0.17 - 0.27, 15 - 24)

BACKLASH

Unit: mm (in)

Item	Specification
Drive gear to drive pinion backlash	0.10 - 0.15 (0.0039 - 0.0059)

COMPANION FLANGE RUNOUT

Unit: mm (in)

Item	Runout limit
Companion flange face	0.1 (0.004) or less
Companion flange inner side	0.1 (0.004) or less

SELECTIVE PARTS

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT FINAL DRIVE: R180A]

Drive Pinion Height Adjusting Washer

Unit: mm (in)	Unit:	mm	(in)
---------------	-------	----	------

Α

Е

F

	Part number*	Thickness	Part number*	Thickness
	38154 EA010	3.39 (0.1335)	38154 EA000	3.09 (0.1217)
	38154 EA011	3.42 (0.1346)	38154 EA001	3.12 (0.1228)
	38154 EA012	3.45 (0.1358)	38154 EA002	3.15 (0.1240)
	38154 EA013	3.48 (0.1370)	38154 EA003	3.18 (0.1252)
	38154 EA014	3.51 (0.1382)	38154 EA004	3.21 (0.1264)
	38154 EA015	3.54 (0.1394)	38154 EA005	3.24 (0.1276)
	38154 EA016	3.57 (0.1406)	38154 EA006	3.27 (0.1287)
	38154 EA017	3.60 (0.1417)	38154 EA007	3.30 (0.1299)
D	38154 EA018	3.63 (0.1429)	38154 EA008	3.33 (0.1311)
	38154 EA019	3.66 (0.1441)	38154 EA009	3.36 (0.1323)

^{*:} Always check with the Parts Department for the latest parts information.

Side Gear Thrust Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
0.75 (0.0295)	38424 W2010	0.87 (0.0343)	38424 W2014
0.78 (0.0307)	38424 W2011	0.90 (0.0354)	38424 W2015
0.81 (0.0319)	38424 W2012	0.93 (0.0366)	38424 W2016
0.84 (0.0331)	38424 W2013	0.96 (0.0378)	38424 W2017

^{*:} Always check with the Parts Department for the latest parts information.

Side Bearing Adjusting Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
1.95 (0.0768)	38453 EA000	2.35 (0.0925)	38453 EA008
2.00 (0.0787)	38453 EA001	2.40 (0.0945)	38453 EA009
2.05 (0.0807)	38453 EA002	2.45 (0.0965)	38453 EA010
2.10 (0.0827)	38453 EA003	2.50 (0.0984)	38453 EA011
2.15 (0.0846)	38453 EA004	2.55 (0.1004)	38453 EA012
2.20 (0.0866)	38453 EA005	2.60 (0.1024)	38453 EA013
2.25 (0.0886)	38453 EA006	2.65 (0.1043)	38453 EA014
2.30 (0.0906)	38453 EA007	, ,	

^{*:} Always check with the Parts Department for the latest parts information.

Ν

< PRECAUTION > [C200]

PRECAUTION

PRECAUTIONS

Precaution for Servicing Rear Final Drive

INFOID:0000000003303018

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- · Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

< PREPARATION > [C200]

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000003303019

Α

peciai Service 100i		INFOID:0000000003303019
ne actual shapes of Kent-Moore tools may differ Tool number (Kent-Moore No.) Tool name	from those of special service tools illustra	ated here. Description
KV38108300 (—) Flange wrench		Removing and installing drive pinion lock nut
KV38100500 (J-25273) Drift	NT771	Installing front oil seal a: 80 mm (3.15 in) dia. b: 60 mm (2.36 in) dia.
ST3127S000 (J-25765-A) Preload gauge 1: GG91030000 (J-25765) Torque wrench 2: HT62940000 (—) Socket adapter (1/2") 3: HT62900000	2ZA0811D 1 2 NT124	Measuring drive pinion bearing preload torque and total preload torque
Socket adapter (3/8") KV10111100 (J-37228) Seal cutter		Removing carrier cover
ST3306S001 (—) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2)	S-NT046	Removing and installing side bearing inner race a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.

< PREPARATION > [C200]

Tool number (Kent-Moore No.) Tool name		Description
ST30031000 (J-22912-01) Puller		Removing drive pinion rear bearing inner race
KV38100600 (J-25267) Drift	a a	Installing side bearing adjusting washer a: 8 mm (0.31 in) b: R42.5 mm (1.673 in)
ST30621000 (J-25742-5) Drift	NT528	Installing drive pinion rear bearing outer race a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.
ST30613000 (J-25742-3) Drift	ZZA1000D	Installing drive pinion front bearing outer race a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.
ST30611000 (J-25742-1) Drift bar	ZZA1000D	Installing drive pinion front bearing outer race [Use with ST30613000 (J-25742-3) and ST30621000 (J-25742-5)]
ST30901000 (J-26010-01) Drift	S-NT090 a b c	Installing drive pinion rear bearing inner race a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.
ST3323 0000 (J-25805-01) Drift	a b c	Installing side bearing inner race a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia. c: 28.5 mm (1.122 in) dia.

PREPARATION

[C200] < PREPARATION > Tool number Description Α (Kent-Moore No.) Tool name Measuring turning torque (J-8129) В Spring gauge E DE LA COMPANIE DE L С NT127 DLN Adjusting bearing preload and pinion gear (J-34309) height Differential shim selector tool Е F Selecting pinion height adjusting washer (J-25269-4) Side bearing disc (2 Req'd) G Н NT136 **Commercial Service Tool** INFOID:0000000003303020

Tool name		Description
Spacer	b c c zzanisad	Installing pinion front bearing inner race a: 60 mm (2.36 in) dia. b: 36 mm (1.42 in) dia. c: 30 mm (1.18 in)
Power tool		Loosening nuts and bolts
	PBIC0190E	

Κ

M

Ν

0

[C200]

INFOID:0000000003303021

FUNCTION DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart


Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		DLN-213, "Disassembly and Assembly"	DLN-213, "Disassembly and Assembly"	DLN-213, "Disassembly and Assembly".	DLN-213, "Disassembly and Assembly"	DLN-213, "Disassembly and Assembly".	MA-12, "Fluids and Lubricants"	DLN-160, "NVH Troubleshooting Chart"	DLN-160, "NVH Troubleshooting Chart"	RAX-18, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and SUSPECTED PARTS		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	REAR AXLE	REAR SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	Noise	×	×	×	×	×	×	×		×	×	×	×	×	×

^{×:} Applicable

DESCRIPTION

Cross-Sectional View



- 1. Companion flange
- 4. Pinion rear bearing
- 7. Drive gear
- 10. Pinion mate shaft
- 2. Pinion front bearing
- 5. Differential case
- 8. Pinion mate gear
- 11. Drive pinion

- 3. Collapsible spacer
- 6. Side bearing
- 9. Side gear

В

INFOID:0000000003303022

Α

С

DLN

Е

F

G

Н

- 1

Κ

L

M

Ν

0

INFOID:0000000003303023

ON-VEHICLE MAINTENANCE

DIFFERENTIAL GEAR OIL


Changing Differential Gear Oil

DRAINING

- 1. Stop engine.
- 2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
- 3. Install the drain plug with a new gasket to the rear final drive assembly. Tighten to the specified torque. Refer to DLN-213, <a href=""Disassembly and Assembly".

CAUTION:

Do not reuse gasket.




FILLING

- 1. Remove the filler plug from the rear final drive assembly.
- 2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil : Refer to MA-12, "Fluids grade and capacity and Lubricants".

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-213</u>. "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



INFOID:0000000003303024

Checking Differential Gear Oil


DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

- Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
- 2. Check the differential gear oil level from the filler plug hole as shown.

CAUTION:

Do not start engine while checking differential gear oil level.

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



< ON-VEHICLE REPAIR > [C200]

ON-VEHICLE REPAIR

FRONT OIL SEAL

Removal and Installation


REMOVAL

- 1. Remove the propeller shaft. Refer to <u>DLN-138</u>, "Removal and Installation".
- Put matching mark on the end of the drive pinion. The matching mark should be in line with the matching mark A on companion flange.

CAUTION:

For matching mark, use paint. Do not damage drive pinion. NOTE:

The matching mark A on the final drive companion flange indicates the maximum vertical runout position.



Α

В

C

DLN

Е


F

M


INFOID:0000000003303025

3. Remove the drive pinion lock nut using Tool.


Tool number : KV38108300 (—)



4. Remove the companion flange using suitable tool.



5. Remove the front oil seal using suitable tool.



INSTALLATION

1. Apply multi-purpose grease to the front oil seal lips.




< ON-VEHICLE REPAIR > [C200]

2. Install the new front oil seal using Tool.


Tool number : KV38100500 (J-25273)

CAUTION:

- · Do not reuse oil seal.
- · Do not incline oil seal when installing.



3. Align the matching mark of drive pinion with the matching mark A of companion flange, then install the companion flange.




- 4. Apply gear oil on the screw part of drive pinion and the seating surface of drive pinion lock nut.
- Install the new drive pinion lock nut and tighten to the specified torque using Tool. Refer to <u>DLN-213</u>, "<u>Disassembly and Assem-blv</u>".

Tool number : KV38108300 (—)

CAUTION:

Do not reuse drive pinion lock nut.

Install the propeller shaft. Refer to <u>DLN-138</u>, "<u>Removal and Installation</u>".



CARRIER COVER

Removal and Installation

REMOVAL В


1. Drain the differential gear oil. Refer to DLN-208, "Changing Differential Gear Oil".

- 2. Disconnect the parking brake cable and brake tube from the carrier cover.
- 3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

: KV10111100 (J-37228) Tool number

CAUTION:

- · Do not damage the mating surface.
- · Do not insert flat-bladed screwdriver, this will damage the mating surface.




INSTALLATION

- 1. Apply a bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to GI-26. "Recommended Chemical Products and Sealants".

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- 2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-213, "Disassembly and Assembly".
- 3. Connect the parking brake cable and brake tube to the carrier cover.
- 4. Fill the rear final drive assembly with recommended differential gear oil. Refer to DLN-208, "Checking Differential Gear Oil".



Α

DLN

INFOID:0000000003303026

Н

PDIA1061E

M

L

Ν

REMOVAL AND INSTALLATION

REAR FINAL DRIVE


Removal and Installation

INFOID:0000000003303027

REMOVAL

CAUTION:

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
- Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
- 1. Drain the differential gear oil. Refer to <u>DLN-208</u>, "Changing Differential Gear Oil".
- 2. Remove the rear propeller shaft. Refer to <u>DLN-138</u>, "Removal and Installation" (2S1330) or <u>DLN-162</u>, "Removal and Installation" (2S1330-BJ100).
- 3. Remove the axle shaft. Refer to <u>RAX-8</u>, "<u>Removal and Installation</u>" (C200), <u>RAX-20</u>, "<u>Removal and Installation</u>" (M226) with or without (M226ELD).
- 4. Remove the stabilizer bar. Refer to FSU-14, "Removal and Installation".
- 5. Disconnect the following components from the rear final drive.
 - · ABS sensor wire harness
 - · Parking brake cable
 - Brake hoses and tubes



- 6. Support rear final drive assembly using a suitable jack.
- 7. Remove rear shock absorber lower bolts. Refer to FSU-13, "Removal and Installation".
- 8. Remove leaf spring U-bolt nuts. Refer to RSU-9, "Removal and Installation".
- 9. Remove rear final drive assembly

CAUTION:

Secure rear final drive assembly to the jack while removing it.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Fill the rear final drive assembly with differential gear oil after installation. Refer to <u>DLN-208</u>, "<u>Checking Differential Gear Oil</u>".
- Bleed the air from brake system. Refer to <u>BR-9</u>, "<u>Bleeding Brake System</u>".

INFOID:0000000003303028

Α

В


C

DISASSEMBLY AND ASSEMBLY

REAR FINAL DRIVE

Disassembly and Assembly

COMPONENTS



WDIA0281E

1. Gear carrier Drive pinion lock nut 3. Companion flange 4. Front oil seal 5. Drive pinion front bearing 6. Drain plug 7. Collapsible spacer Side bearing cap Drive pinion rear bearing 10. Drive pinion height adjusting washer 11. Drive pinion 12. Drive gear 13. Differential case 14. Carrier cover 15. Filler plug 16. Pinion mate shaft 17. Lock pin 18. Side bearing 19. Side bearing adjusting washer 20. Side gear thrust washer 21. Side gear 22. Pinion mate gear 23. Pinion mate thrust washer 24. Gasket

25. Breather

ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to <u>DLN-208</u>. "Changing <u>Differential</u> Gear Oil".
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to <u>DLN-211</u>, <u>"Removal and Installation"</u>.

Total Preload Torque

- Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- 2. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
- 3. Measure total preload torque using Tool.

Tool number : ST3127S000 (J-25765-A)


Total preload torque

: 1.4 - 2.9 N·m (0.15 - 0.29 kg-m, 13 - 25 in-lb)

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque

 If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.



If the total preload torque is greater than specification

On drive pinion bearings: Replace the collapsible spacer.

On side bearings: Use thinner side bearing adjusting washers by the same

amount to each side. Refer to DLN-232, "Inspection and Adjust-

ment".

If the total preload torque is less than specification

On drive pinion bearings: Tighten the drive pinion nut.

On side bearings: Use thicker side bearing adjusting washers by the same

amount to each side. Refer to DLN-232, "Inspection and Adjust-

ment".

Drive Gear Runout

[C200]

- 1. Fit a dial indicator to the drive gear back face.
- 2. Rotate the drive gear to measure runout.

Runout limit : 0.05 mm (0.0020 in) or less

 If the runout is outside of the limit, check the condition of the drive gear assembly. Foreign material may be caught between the drive gear and differential case, or the differential case or drive gear may be deformed.

CAUTION:

Replace drive gear and drive pinion as a set.


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

1. Apply red lead to drive gear.


NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.




Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown. CAUTION:

Check tooth contact on drive side and reverse side.



3. If the tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height (dimension X).



Α

В

DLN

Е

F

Н

J

K


M

Ν


0

Ρ

 If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washers to move the drive pinion closer to the drive gear.
 Refer to DLN-232, "Inspection and Adjustment".



 If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washers to move the drive pinion farther from the drive gear.
 Refer to <u>DLN-232</u>, "Inspection and Adjustment".



Backlash

 Fit a dial indicator to the drive gear face to measure the backlash.

Backlash: 0.10 - 0.15 mm (0.0039 - 0.0059 in)


 If the backlash is outside of the specification, change the thickness of each side bearing adjusting washer.

If the backlash is greater than specification:

Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. Refer to <u>DLN-232</u>, "<u>Inspection and Adjustment</u>".



Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. Refer to DLN-232, "Inspection and <a href="Adjustment".



CAUTION:

Do not change the total thickness of side bearing adjusting washers as it will change the side bearing preload torque.


Companion Flange Runout

[C200]

Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.

Runout limit: 0.08 mm (0.0031 in) or less

- 2. If the runout is outside the runout limit, follow the procedure below to adjust.
- Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
- b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
- c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.



DLN

DISASSEMBLY


Differential Assembly

- Remove carrier cover bolts.
- 2. Remove carrier cover using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:


- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




For proper reinstallation, paint matching marks on one side of side bearing cap.

CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.



Remove side bearing caps.



Α

В

. . . .

F

Е

G

Н

Κ


L

M


Ν

0

5. Remove differential case assembly using suitable tool.



 Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusting washers together with bearings.




6. Remove side bearing inner race using Tools.

Tool number A: ST33051001 (J-22888-20)

B: ST33061000 (J-8107-2)

CAUTION:

- Engage puller jaws in groove to prevent damage.
- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except if it is replaced.



7. For proper reinstallation, paint matching mark on one differential case assembly.


CAUTION:

Use paint for matching marks. Do not damage differential case or drive gear.

- 8. Remove drive gear bolts.
- Tap the drive gear off the differential case assembly using suitable tool.


CAUTION:

Tap evenly all around to keep drive gear from binding.




[C200]


10. Remove the lock pin of pinion mate shaft from the drive gear side using suitable tool.



11. Remove pinion mate shaft.



12. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.



Drive Pinion Assembly


- 1. Remove differential case assembly. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".
- 2. Remove drive pinion lock nut using Tool.

Tool number : KV38108300 (—)

3. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.



Α

В

0

DLN

Е

F

G

Н

1

K


L

M

Ν

Ρ

Remove companion flange using suitable Tool.




Remove drive pinion assembly from gear carrier using suitable tool.

CAUTION:


Do not drop drive pinion assembly.

- 6. Remove front oil seal.
- 7. Remove drive pinion front bearing inner race.
- 8. Remove collapsible spacer.



9. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.


Tool number : ST30031000 (J-22912-01)



10. Tap drive pinion front and rear bearing outer races uniformly with a brass bar or equivalent to remove.

CAUTION:

Do not damage gear carrier.



INSPECTION AFTER DISASSEMBLY

Clean up the disassembled parts. Then, inspect if the parts are worn or damaged. If so, follow the measures below.

Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

• If any chips (by friction), damage, or unusual wear are found, replace with new one.

Gear Carrier

If any wear or cracks are found on the contact sides of gear carrier, replace with new one.


Companion Flange

• If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

ADJUSTING AND SELECTING WASHERS

Side Gear Back Clearance

- Assemble the differential parts if they are disassembled. Refer to "Differential Assembly".
- Place the differential case straight up so that the side gear to be measured is upward.



Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

Side gear back clearance: 0.1 - 0.2 mm (0.004 - 0.008 in) or less.

 If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".

If the side gear back clearance is greater than specification:


Use a thicker side gear thrust washer.

If the side gear back clearance is less than specification:

Use a thinner side gear thrust washer.

CAUTION:

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- · Select a side gear thrust washer for right and left individually.



DLN

В

F

G

Н

1

K

L

M

Ν

0

NOTE:


Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.

Side Bearing Preload Torque

- A selection of side bearing adjusting washers is required for successful completion of this procedure.
- Apply differential gear oil to the side bearings, and install the differential case assembly with the side bearing outer races into the gear carrier.


CAUTION:

Do not reuse side bearing outer race when replacing side bearing inner race (replace as a set).




2. Insert the left and right original side bearing adjusting washers in place between side bearings and gear carrier using Tool.

Tool number : KV38100600 (J-25267)



- 3. Align the matching mark on the side bearing cap with the matching mark on the gear carrier.
- 4. Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to DLN-213, "Disassembly and Assembly".
- Turn the differential assembly several times to seat the side bearings.



6. To determine side bearing preload torque, measure the pulling force of the differential assembly at the drive gear bolt using Tool.


Tool number : — (J-8129)

Specification : 34.2 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb)

of pulling force at the drive gear bolt

NOTE:

If pulling force of the differential assembly at the drive gear bolt is within specification, side bearing preload torque will also be within specification. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".



7. If the pulling force is outside the specification, use a thicker or thinner side bearing adjusting washer to adjust. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly"</u>.

If the pulling force is less than the specification:

Use a thicker side bearing adjusting washer.

If the pulling force is greater than the specification:

Use a thinner side bearing adjusting washer.

CAUTION:


Select a side bearing adjusting washer for right and left individually.

8. Record the total amount of washer thickness required for the correct side bearing preload torque.


Drive Pinion Height


- Make sure all parts are clean and that the bearings are well lubricated.
- Assemble the drive pinion bearings onto the Tool.

Tool number : — (J-34309)



- **Drive pinion front bearing**; make sure the J-34309-3 drive pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the J-34309-5 drive pinion front bearing pilot to secure the drive pinion bearing in its proper position.
- **Drive pinion rear bearing**; the J-34309-8 drive pinion rear bearing pilot is used to center the drive pinion rear bearing only. The J-34309-4 drive pinion rear bearing locking seat is used to lock the drive pinion rear bearing to the assembly.
- Installation of J-34309-9 and J-34309-16; place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).
- Install the drive pinion rear bearing inner race into the gear carrier. Then insert the drive pinion height adjusting washer selector tool, J-34309-1, gauge screw assembly.





Α

В

С

DLN

Е

G

Н


K

N


M

O

4. Assemble the drive pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in the gear carrier. Make sure that the drive pinion height gauge plate, J-34309-16, will turn a full 360°. Tighten the two sections together by hand.



5. Turn the assembly several times to seat the drive pinion bearings.




6. Measure the turning torque at the end of the J-34309-2 gauge anvil using Tool.

Tool number : ST3127S000 (J-25765- A)

Turning torque: 1.0 - 1.3 N·m (0.11 - 0.13 kg-m,


9 - 11 in-lb)



7. Place the J-34309-11 drive pinion height adapter onto the gauge plate and tighten it by hand.


CAUTION:

Make sure all machined surfaces are clean.




8. Position the side bearing discs, Tool, and arbor firmly into the side bearing bores. Install the side bearing caps and tighten the side bearing cap bolts to the specified torque. Refer to "DLN-213, "Disassembly and Assembly".

Tool number : — (J-25269-4)




[C200]

9. Select the correct standard drive pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and your J-34309-101 feeler gauge. Measure the distance between the J-34309-11 drive pinion height adapter, including the standard gauge and the arbor.




10. Write down the exact measurement (the value of feeler gauge).



11. Correct the drive pinion height adjusting washer size by referring to the drive pinion "head number".

There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the drive pinion "head number". It refers to the ideal drive pinion height from standard for quietest operation. Use the following chart to determine the correct drive pinion height adjusting washer.



Head number	Add or remove from the standard drive pinion height adjusting washer thickness measurement
- 6	Add 0.06 mm (0.0024 in)
- 5	Add 0.05 mm (0.0020 in)
- 4	Add 0.04 mm (0.0016 in)
- 3	Add 0.03 mm (0.0012 in)
- 2	Add 0.02 mm (0.0008 in)
- 1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

12. Select the correct drive pinion height adjusting washer. Refer to DLN-213, "Disassembly and Assembly".

Α

В

С

DLN

Е

F

Н

L


N/I

Ν

Ρ

13. Remove the Tool from the gear carrier and disassemble to retrieve the drive pinion bearings.

Tool number : — (J-34309)



ASSEMBLY

Drive Pinion Assembly


1. Install the new drive pinion front and rear bearing outer races using Tools.

Tool number A: ST30611000 (J-25742-1)

B: ST30621000 (J-25742-5) C: ST30613000 (J-25742-3)

CAUTION:

- First tap the drive pinion bearing outer race until it becomes flush with the gear carrier.
- Do not reuse drive pinion front and rear bearing outer race.




- Select a drive pinion height adjusting washer. Refer to <u>DLN-213, "Disassembly and Assembly"</u>.
- 3. Install the selected drive pinion height adjusting washer to the drive pinion. Press the new drive pinion rear bearing inner race to it using Tool.

Tool number : ST30901000 (J-26010-01)

CAUTION:

- Install the drive pinion height adjusting washer in the proper direction as shown.
- Do not reuse drive pinion rear bearing inner race.



 Assemble the new collapsible spacer to the drive pinion. CAUTION:


Do not reuse collapsible spacer.


- 5. Apply differential gear oil to the drive pinion rear bearing, and install the drive pinion assembly to the gear carrier.
- Apply differential gear oil to the drive pinion front bearing, and install the new drive pinion front bearing inner race to the drive pinion assembly.

CAUTION:

Do not reuse drive pinion front bearing inner race.

 Press the drive pinion front bearing inner race to the drive pinion as far as drive pinion lock nut can be tightened using suitable spacer.






 Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : KV38100500 (J-25273)

CAUTION:

- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



9. Install the companion flange to the drive pinion while aligning the matching marks.

А

В

C

DLN

Е

F

G

Н

I

J

Κ

L

M

Ν

0

10. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

Tool number A: KV38108300 (—)

B: ST3127S000 (J-25765-A)

Drive pinion bearing preload torque:


1.1 - 1.4 N·m (0.12 - 0.14 kg-m, 10 - 12 in-lb)

CAUTION:

- Do not reuse drive pinion lock nut.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 11. Check companion flange runout. Refer to DLN-213, "Disassembly and Assembly".
- 12. Install differential case assembly. Refer to DLN-213, "Disassembly and Assembly".

Differential Assembly

 Install side gear thrust washers with the same thickness as the ones installed prior to disassembly, or reinstall the old ones on the side gears.





2. Install the side gears and side gear thrust washers into the differential case.

CAUTION:

Make sure that the circular clip is installed to side gears.


3. Install the pinion mate thrust washers to the two pinion mate gears. Then install the pinion mate gears with the pinion mate thrust washers by aligning them in diagonally opposite positions and rotating them into the differential case.





[C200]


- 4. Align the lock pin hole on the differential case with the lock pin hole on the pinion mate shaft, and install the pinion mate shaft.
- Measure the side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to <u>DLN-213</u>, "<u>Disassembly</u> and Assembly".




6. Drive a new lock pin into the pinion mate shaft until it is flush with the differential case using suitable tool.

CAUTION:

Do not reuse lock pin.




 Align the matching mark of the differential case with the mark of the drive gear, then place the drive gear onto the differential case.



- 8. Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.
 - Use Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to <u>GI-26</u>, "Recommended Chemical Products and Sealants".

CAUTION:

Make sure the drive gear back and threaded holes are clean.




 Tighten the drive gear bolts to the specified torque. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>". After tightening the drive gear bolts to the specified torque, tighten an additional 31° to 36° using Tool.

Tool number : KV10112100-A (BT-8653-A)

CAUTION:

- Always use Tool. Avoid tightening based on visual check alone.
- Tighten drive gear bolts in a crisscross pattern.



В

Α

DLN

F

G

Н

J

K

L

M

N

0


10. Press the new side bearing inner races to the differential case using Tools.

Tool number A: ST33230000 (J-25805-01)


B: ST33061000 (J-8107-2)

CAUTION:

Do not reuse side bearing inner race.




- 11. Install the differential case assembly with the side bearing outer races into gear carrier.
- 12. Measure the side bearing preload torque. If necessary, select the appropriate side bearing adjusting washers. Refer to <u>DLN-213</u>, "Disassembly and Assembly".




13. Insert the selected left and right side bearing adjusting washers in place between the side bearings and gear carrier using Tool.

Tool number : KV38100600 (J-25267)



14. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque. Refer to <u>DLN-213</u>, "<u>Disassembly and Assembly</u>".




 Check and adjust the drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to "<u>DLN-213, "Disassembly and Assembly"</u>. Recheck above items.

[C200]

- 16. Apply sealant to the mating surface of the carrier cover.
 - Use Genuine Silicone RTV or equivalent. Refer to GI-26. "Recommended Chemical Products and Sealants". CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

17. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-213, "Disassembly and Assembly".



Α

В

C

DLN

Е

F

Н

K

L

M

Ν

0

[C200]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003304393

2WD MODELS

	QR2	5DE	VQ4	IODE
Applied model	King	cab	King cab	Crew cab
	M/T	A/T	A	/T
Final drive model		C	200	
Gear ratio	4.083	3.692	2.937	3.133
Number of teeth (Drive gear/Drive pinion)	49/12	48/13	47/16	47/15
Oil capacity (Approx.) ℓ (US pt, Imp pt)		1.6 (3-3	/8, 2-7/8)	
Number of pinion gears			2	
Drive pinion adjustment spacer type		Colla	psible	

4WD MODELS

		VQ4	0DE
Applied model		King cab	Crew cab
		A	/T
Final drive model		C2	00
Gear ratio		3.133	3.357
Number of teeth (Drive gear/Drive pinion)		47/15	47/14
Oil capacity (Approx.)	ℓ (US pt, Imp pt)	1.6 (3-3/	8, 2-7/8)
Number of pinion gears		2	2
Drive pinion adjustment spacer type		Colla	osible

Inspection and Adjustment

INFOID:0000000003303030

DRIVE GEAR RUNOUT

	Unit: mm (in)
Item	Runout limit
Drive gear back face	0.08 (0.0031) or less

SIDE GEAR CLEARANCE

Unit: mm (in)

Item	Specification
Side gear back clearance (Clearance between side gear and differential case for adjusting side gear backlash)	0.1 - 0.2 (0.004 - 0.008) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

PRELOAD TORQUE

Unit: N·m (kg-m, in-lb)

Item	Specification
Drive pinion bearing preload torque	1.1 - 1.4 (0.12 - 0.14, 10 - 12)
Side bearing preload torque (reference value determined by drive gear bolt pulling force)	0.3 - 1.5 (0.03 - 0.15, 3 - 13)

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[C200]

Item	Specification
Drive gear bolt pulling force (by spring gauge)	34.2 – 39.2 N (3.5 – 4 kg, 7.7 – 8.8 lb)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	1.4 - 2.9 (0.15 - 0.29, 13 - 25)

BACKLASH

Unit: mm (in)

Item	Specification
Drive gear to drive pinion gear	0.10 - 0.15 (0.0039 - 0.0059)

COMPANION FLANGE RUNOUT

Unit: mm (in)

ltem	Runout limit
Companion flange face	0.08 (0.0031) or less
Companion flange Inner side	0.08 (0.0031) or less

SELECTIVE PARTS

Side Gear Thrust Washer

Unit: mm (in)

Thickness	Part number*	Thickness	Part number*
0.75 (0.0295)	38424 EC000	0.87 (0.0343)	38424 EC004
0.78 (0.0307)	38424 EC001	0.90 (0.0350)	38424 EC005
0.81 (0.0319) 0.84 (0.0331)	38424 EC002 38424 EC003	0.93 (0.0366)	38424 EC006

^{*:} Always check with the Parts Department for the latest parts information.

Drive Pinion Height Adjusting Washer

Unit: mm (in)

			• · · · · · · · · · · · · · · · · · · ·	,
Thickness	Part number*	Thickness	Part number*	
3.05 (0.1201)	38154 0C000	3.29 (0.1295)	38154 0C008	
3.08 (0.1213)	38154 0C001	3.32 (0.1307)	38154 0C009	
3.11 (0.1224)	38154 0C002	3.35 (0.1319)	38154 0C010	
3.14 (0.1236)	38154 0C003	3.38 (0.1331)	38154 0C011	
3.17 (0.1248)	38154 0C004	3.41 (0.1343)	38154 0C012	
3.20 (0.1260)	38154 0C005	3.44 (0.1354)	38154 0C013	
3.23 (0.1272)	38154 0C006	3.47 (0.1366)	38154 0C014	
3.26 (0.1283)	38154 0C007	3.50 (0.1378)	38154 0C015	
	38154 0C007	,	38154 0C015	

^{*:} Always check with the Parts Department for the latest parts information.

Side Bearing Adjusting Washer

Unit: mm (in)

()	OTHE THE			
	Part number*	Thickness	Part number*	Thickness
	38453 N3107	2.35 (0.0925)	38453 N3100	2.00 (0.0787)
	38453 N3108	2.40 (0.0945)	38453 N3101	2.05 (0.0807)
	38453 N3109	2.45 (0.0965)	38453 N3102	2.10 (0.0827)
	38453 N3110	2.50 (0.0984)	38453 N3103	2.15 (0.0846)
	38453 N3111	2.55 (0.1004)	38453 N3104	2.20 (0.0866)
	38453 N3112	2.60 (0.1024)	38453 N3105	2.25 (0.0886)
	38453 N3113	2.65 (0.1043)	38453 N3106	2.30 (0.0906)

^{*:} Always check with the Parts Department for the latest parts information.

N IC

Е

Α

В

Н

M

Ν

0

K

[REAR FINAL DRIVE: M226]

PRECAUTION

PRECAUTIONS

Precaution for Servicing Rear Final Drive

INFOID:0000000003303031

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- · Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

[REAR FINAL DRIVE: M226]

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000003303032

Α

pediai Service 100i		INFOID:000000003303032	В
ne actual shapes of Kent-Moore tools m Tool number (Kent-Moore No.) Tool name	ay differ from those of special service tools illustrat	ed here. Description	C
KV40104000 (—) Flange wrench		Removing and installing drive pinion nut a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia.	DI
	(b) a		Е
ST33290001 (J-34286)	NT659	Removing front oil seal	F
Puller			(
	ZZA0601D		ŀ
ST15310000 (—) Drift		Installing front oil seal a: 96mm (3.77 in) dia. b: 84 mm (3.30 in) dia.	ĺ
	a b		
ST3127S000 (J-25765-A) Preload gauge set	NT115	Inspecting drive pinion bearing preload and total preload	ŀ
1. GG91030000 (J-25765) Torque wrench			L
2. HT62940000 (1/2") (—) Socket adapter 3. HT62900000 (3/8")	②—————————————————————————————————————		N
(—) Socket adapter	N1124		N
— (C-4164) Adjuster tool		Removing and installing side bearing adjuster	
	WDIA0192E		F

Tool mumb or		Description
Tool number (Kent-Moore No.) Tool name		Description
KV10111100 (J-37228) Seal cutter		Removing carrier cover
	S-NT046	
ST30021000 (J-22912-01) Puller		Removing drive pinion rear bearing inne race
ST33081000 (—) Adapter	ZZA0700D	Removing and installing side bearing in ner race a: 43 mm (1.69 in) dia. b: 33.5 mm (1.32 in) dia.
ST23550000 (—)	ZZA1000D	Removing and installing lock pin a: 4.5 mm (0.177 in) dia.
Pin punch Ó	a	
 (8144) Pinion block	NT410	Adjusting pinion gear height
r illion block	SDIA2599E	
(6740) Cone		Adjusting pinion gear height
 (6741) Screw	SDIA2601E	Adjusting pinion gear height
Colow		
	SDIA2602E	

PREPARATION

[REAR FINAL DRIVE: M226]

ool number Kent-Moore No.)		Description
ool name		
— 6739) Pinion height lock		Adjusting pinion gear height
	SDIA2603E	
		Adjusting pinion gear height
D-115-2) cooter block		
	SDIA2604E	
		Adjusting pinion gear height
3541A-1) rbor disc		
_	SDIA2605E	Adjusting pinion gear height
O-115-3) rbor		, ajasmig pinon gasi nagin
T01500001	SDIA2606E	Installing drive pinion rear bearing outer
—) rift		race a: 89mm (3.50 in) dia.
		b: 79 mm (3.11 in) dia.
	ZZA0811D	
T30022000 —) rift	ba	Installing drive pinion rear bearing outer race a: 46 mm (1.81 in) dia. b: 110 mm (4.33 in) dia.
	NT660	
T33022000 —) rift	ba	Installing drive pinion front bearing outer race a: 49 mm (1.92 in) dia. b: 67 mm (2.63 in) dia.

PREPARATION

[REAR FINAL DRIVE: M226]

Tool number (Kent-Moore No.) Tool name		Description
(C-4040) Installer	SDIA2607E	Installing drive pinion rear bearing inner race
KV38100300 (J-25523) Drift	ZZA1046D	Installing side bearing inner race a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32mm (1.26 in) dia.

Commercial Service Tool


INFOID:0000000003303033

Tool name		Description
Puller	NT077	Removing companion flange and side bearing inner race
Puller	ZZB0823D	Removing side bearing inner race
Power tool	PBIC0190E	Loosening bolts and nuts

FUNCTION DIAGNOSIS

DESCRIPTION

Cross-Sectional View



- 1. Companion flange
- 4. Differential case
- 7. Side gear

- 2. Drive pinion
- 5. Pinion mate gear
- 8. Pinion mate shaft
- 3. Drive gear
- 6. Axle shaft

Α

В

INFOID:0000000003303034

С

DLN

Е

F

G

Н

ı

J

Κ

L

M

Ν

0

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[REAR FINAL DRIVE: M226]

INFOID:0000000003303035

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		I	<u>DLN-246</u>	I	<u>DLN-246</u>	<u>DLN-246</u>	<u>DLN-241</u>	DLN-128, "NVH Troubleshooting Chart" DLN-152, "NVH Troubleshooting Chart"	RAX-18, "NVH Troubleshooting Chart", RSU-4, "NVH Troubleshooting Chart"	"##OH O Protection Of TAX		RAX-18, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and SUSPEC	TED PARTS	Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	AXLE SHAFT	BRAKES	STEERING
Symptom	Noise	×	×	×	×	×	×	×	×	×	×	×	×	×

^{×:} Applicable

[REAR FINAL DRIVE: M226]


ON-VEHICLE MAINTENANCE

DIFFERENTIAL GEAR OIL

Changing Differential Gear Oil

DRAINING

- 1. Stop engine.
- 2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
- Install the drain plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



FILLING

- 1. Remove the filler plug from the rear final drive assembly.
- Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil : Refer to MA-12, "Fluids grade and capacity and Lubricants".

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-246</u>. "Disassembly and Assembly".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

Filler opening Oil level

Checking Differential Gear Oil


DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

- Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
- 2. Check the differential gear oil level from the filler plug hole as shown.

CAUTION:

Do not start engine while checking differential gear oil level.

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



DLN

Α

В

INFOID:0000000003303036

Е

F

G

Н

I

J

K

INFOID:0000000003303037

L

M

Ν

0

Ρ

[REAR FINAL DRIVE: M226]

ON-VEHICLE REPAIR

FRONT OIL SEAL

Removal and Installation

INFOID:0000000003303038

REMOVAL

- Remove rear propeller shaft. Refer to <u>DLN-138</u>, "<u>Removal and Installation</u>" (2S1330) or <u>DLN-162</u>, "<u>Removal and Installation</u>" (2S1330-BJ100).
- 2. Remove brake calipers and rotors. Refer to <u>BR-29</u>, "Removal and Installation of Brake Caliper and <u>Disc Rotor"</u>.
- Measure the total preload torque. Refer to <u>DLN-262, "Inspection and Adjustment"</u>. NOTE:

Record the total preload torque measurement.


4. Remove the drive pinion lock nut using Tool.

Tool number : KV40104000 (—)


5. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.




Remove the companion flange using suitable tool.



7. Remove the front oil seal using Tool.

Tool number : ST33290001 (J-34286)



INSTALLATION

FRONT OIL SEAL


< ON-VEHICLE REPAIR >

Apply multi-purpose grease to the lips of the new front oil seal.
 Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

Tool number : ST15310000 (—)

CAUTION:

- · Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



[REAR FINAL DRIVE: M226]

2. Install the companion flange to the drive pinion while aligning the matching marks.

 Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

Tool number A: KV40104000 (—)

B: ST3127S000 (J-25765-A)

Total preload torque: Refer to <u>DLN-262, "Inspection</u>

and Adjustment".

 The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg-m, 5 in-lb).


• If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg-m, 5ft-lb) increments until the total preload torque is met.


CAUTION:

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly and Assembly"</u>.
- Do not loosen drive pinion lock nut to adjust the total preload torque. If the total preload torque exceeds the specifications, replace the collapsible spacer and tighten it again to adjust. Refer to <u>DLN-246, "Disassembly and Assembly"</u>.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 4. Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to <u>DLN-241, "Checking Differential Gear Oil"</u>.





ı

K

Α

В

C

DLN

F

Н

M

Ν

0

[REAR FINAL DRIVE: M226]

INFOID:0000000003303039

CARRIER COVER

Removal and Installation


REMOVAL

- 1. Drain the differential gear oil. Refer to DLN-241, "Changing Differential Gear Oil".
- Disconnect the parking brake cable and brake tube from the carrier cover.
- 3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




INSTALLATION

- 1. Apply a bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26.</u> "Recommended Chemical Products and Sealants".

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- 2. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-246, "Disassembly and Assembly".
- 3. Connect the parking brake cable and brake tube to the carrier cover.
- 4. Fill the rear final drive assembly with recommended differential gear oil. Refer to <u>DLN-241</u>, "Checking <u>Differential Gear Oil"</u>.



REAR FINAL DRIVE ASSEMBLY

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

REAR FINAL DRIVE ASSEMBLY

Removal and Installation


INFOID:0000000003303040

[REAR FINAL DRIVE: M226]

REMOVAL

CAUTION:

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
- Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
- 1. Drain the differential gear oil. Refer to <u>DLN-241</u>, "Changing <u>Differential Gear Oil"</u>.
- 2. Remove the rear propeller shaft. Refer to <u>DLN-138</u>, "Removal and Installation" (2S1330) or <u>DLN-162</u>, "Removal and Installation" (3S1330-2BJ100).
- 3. Remove the axle shaft. Refer to RAX-20, "Removal and Installation".
- 4. Disconnect the following components from the rear final drive assembly.
 - ABS sensor wire harness. Refer to <u>BRC-70</u>, "Removal and Installation" (Type 1) or <u>BRC-154</u>, "Removal and Installation" (Type 2) or <u>BRC-272</u>, "Removal and Installation" (Type 3).
 - · Parking brake cable
 - Brake hoses and tubes



- 5. Support rear final drive assembly using a suitable jack.
- 6. Remove rear shock absorber lower bolts. Refer to RSU-8, "Removal and Installation".
- 7. Remove leaf spring U-bolt nuts. Refer to RSU-9, "Removal and Installation".
- 8. Remove rear final drive assembly.

CAUTION:

Secure rear final drive assembly to the jack while removing it.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Fill the rear final drive assembly with differential gear oil after installation. Refer to <u>DLN-241, "Checking Differential Gear Oil"</u>.
- Bleed the air from brake system. Refer to BR-9, "Bleeding Brake System".

DLN

Α

Ε

Н

.

L

K

N

C

INFOID:0000000003303041


DISASSEMBLY AND ASSEMBLY

REAR FINAL DRIVE ASSEMBLY

Disassembly and Assembly

COMPONENTS

SEC.380



WDIA0347E

- Drive pinion lock nut
- Front oil seal 4.
- 7. Gear carrier
- 10. Adjuster lock plate
- 13. Drive pinion
- Collapsible spacer 16.
- 19. Differential case
- 22. Pinion mate gear
- Side gear thrust washer

- Drive pinion nut washer
- Drive pinion front bearing thrust 5. washer
- 8. Drain plug
- 11. Carrier cover
- 14. Drive pinion height adjusting washer 15.
- 17. Side bearing adjuster
- 20. Drive gear
- 23. Pinion mate shaft
- 26. Side gear

- Companion flange
- Drive pinion front bearing 6.
- 9. Side bearing cap
- 12. Filler plug
- Drive pinion rear bearing
- Side bearing
- Pinion mate thrust washer
- 24. Lock pin
- 27. Breather

REAR FINAL DRIVE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226]

ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to <u>DLN-241</u>.
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to DLN-244.

Total Preload Torque

- 1. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
- 3. Measure total preload torque using Tool.

Tool number : ST3127S000 (J-25765-A)

Total preload torque : 2.49 - 4.57 N-m (0.26 - 0.46 kg-m,

22- 40 in-lb)

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque

• If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

Tool PDIA0309E

If the total preload torque is greater than specification

On drive pinion bearings: Replace collapsible spacer.
On side bearings: Loosen side bearing adjuster.

If the total preload torque is less than specification

On drive pinion bearings: Tighten drive pinion lock nut.
On side bearings: Tighten side bearing adjuster.

Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.

1. Thoroughly clean drive gear and drive pinion teeth.


2. Apply red lead to drive gear.

NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.

PDIA0321E

3. Hold companion flange steady by hand and rotate drive gear in both directions.



DLN

Α


_

K

L

M

Ν




If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to <u>DLN-246</u>, "<u>Dis-assembly and Assembly</u>" and <u>DLN-262</u>, "<u>Inspection and Adjustment</u>".

Backlash

 Fit a dial indicator to the drive gear face to measure the backlash.


Backlash: 0.08 - 0.13 mm (0.0031 - 0.0051 in)

- 2. If the backlash is outside of the specification, adjust each side bearing side bearing adjuster.
- a. Remove adjuster lock plate.
- b. Loosen side bearing cap bolts.



Tighten or loosen each side bearing adjuster using Tool.

Tool number : — (C - 4164)



If the backlash is greater than specification:


Loosen side bearing adjuster A and tighten side bearing adjuster B by the same amount.

If the backlash is less than specification:

Loosen side bearing adjuster B and tighten side bearing adjuster A by the same amount.

CAUTION:

Do not change the side bearing side bearing adjusters by different amounts as it will change the side bearing preload torque.




REAR FINAL DRIVE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

- d. Tighten side bearing cap bolts to the specified torque. Refer to <u>DLN-246, "Disassembly and Assembly"</u>.
- e. Install adjuster lock plate and tighten to the specified torque. Refer to DLN-246. "Disassembly and Assembly".

CAUTION:

Check tooth contact and total preload torque after adjusting side bearing adjuster. Refer to "Tooth Contact" and "Total Preload Torque".



[REAR FINAL DRIVE: M226]

Companion Flange Runout

Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool.

Runout limit

Companion flange face: 0.10 mm (0.0039 in) Companion flange inner side: 0.13 mm (0.0051 in)

- 2. If the runout is outside the runout limit, follow the procedure below to adjust.
- a. Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
- b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
- c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.

DISASSEMBLY


Differential Assembly

- Remove carrier cover bolts.
- 2. Remove carrier cover using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:


- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



3. For proper reinstallation, paint matching mark on one side of side bearing cap.

CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.
- 4. Remove adjuster lock plates.



PDIA0331E

Н

SDIA2078E

Α

В

DLN


J

K

M


Ν

5. Remove side bearing caps.




Remove side bearing adjusters using Tool.

Tool number : — (C - 4164)



- Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
- 8. Remove side bearing adjusters from gear carrier.




9. Remove side bearing inner races using Tool.

Tool number : ST33081000 (—)

CAUTION:

Do not damage differential case.




10. For proper reinstallation, paint matching mark on differential case and drive gear.

CAUTION:

Use paint for matching marks. Do not damage differential case or drive gear.

- 11. Remove drive gear bolts.
- 12. Tap the drive gear off the differential case using suitable tool. **CAUTION:**

Tap evenly all around to keep drive gear from binding.




REAR FINAL DRIVE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: M226]

13. Remove the lock pin of the pinion mate shaft from the drive gear side using Tool.


Tool number : ST23550000 (—)



14. Remove pinion mate shaft.



15. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.



Drive Pinion Assembly


- 1. Remove differential case assembly. Refer to <u>DLN-246, "Disassembly and Assembly"</u>.
- 2. Remove drive pinion lock nut and washer using Tool.

Tool number : KV40104000 (—)

3. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.



Α

В

С

DLN

Е

F

G

Н

J

K

L


M

Ν

C

Ρ

4. Remove companion flange using suitable tool.




Remove front oil seal using Tool.

Tool number : ST33290001 (J-34286)

CAUTION:

Do not damage gear carrier.

6. Remove drive pinion front bearing thrust washer.




7. Remove drive pinion assembly (with rear inner bearing race and collapsible spacer) out of gear carrier.

CAUTION:

Do not drop drive pinion assembly.

8. Remove drive pinion front bearing inner race from gear carrier.



9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.


CAUTION:

Do not damage gear carrier.

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.


CAUTION:

Do not damage gear carrier.



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

Tool number : ST30021000 (J-22912-01)



< DISASSEMBLY AND ASSEMBLY >

INSPECTION AFTER DISASSEMBLY

Drive Pinion and Drive Gear

- If the drive pinion and drive gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the drive pinion or drive gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive pinion and drive gear.
- Drive pinion and drive gear are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new drive pinion and drive gear set are being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.

Bearing

- If bearings are chipped (by friction), pitted, worn, rusted, scratched, or unusual noise is coming from bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Side Gear and Pinion Mate Gear

- If any cracks or damage are found on the surface of the teeth, replace with new one.
- If any worn or chipped marks are found on the side of the side gear and pinion mate gear which contact the thrust washer, replace with new one.
- Replace both side gear and pinion mate gear as a set when replacing side gear or pinion mate gear.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

If any chips (by friction), damage, or unusual wear are found, replace with new one.

Gear Carrier

• If any wear or cracks are found on the contact sides of gear carrier, replace with new one.


Companion Flange

• If any chips (about 0.1mm, 0.004 in) or other damage on the companion flange surface which contacts the front oil seal lips are found, replace with new one.

SELECTION ADJUSTING WASHERS

Side Gear Back Clearance

- Assemble the differential parts if they are disassembled. Refer to <u>DLN-246, "Disassembly and Assembly"</u>.
- Place the differential case straight up so that the side gear to be measured is upward.



[REAR FINAL DRIVE: M226]

DLN

Α

Е

Н

K

M

N

0

 Using feeler gauges, measure the clearance between the side gear back and differential case at three different points, while rotating the side gear. Average the three readings to calculate the clearance. (Measure the clearance of the other side as well.)

Side gear back clearance: 0.305 mm (0.0120 in) or less.

• If the side gear back clearance is outside of the specification, use a thicker or thinner side gear thrust washer to adjust. Refer to <u>DLN-262</u>, "Inspection and Adjustment".

If the side gear back clearance is greater than specification:

Use a thicker side gear thrust washer.

If the side gear back clearance is less than specification:

Use a thinner side gear thrust washer.


CAUTION:

- Insert feeler gauges with the same thickness on both sides to prevent side gear from tilting.
- Each gear should rotate smoothly without excessive resistance during differential motion.
- Select a side gear thrust washer for right and left individually.
 NOTE:


Side gear back clearance is clearance between side gear and differential case for adjusting side gear backlash.

Drive Pinion Height Adjusting Washer

Drive gear and drive pinion are supplied in matched sets only.
 Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.



- The mounting distance from the center line of drive gear to the back face of drive pinion for the Model 226 final drive assembly is 109.5 mm (4.312 in).
 - On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion inner bearing race and drive pinion.
 - For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what m-8 (a-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washers which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.



< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226]

OLD DRIVE	NEW DRIVE PINION MARKING mm (in)						•	•	
PINION MARKING	-10 (-4)	-8 (-3)	-5 (-2)	-3 (-1)	0 (0)	+3 (+1)	+5 (+2)	+8 (+3)	+10 (+4)
+10 (+4)	+0.20	+0.18	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0
	(+0.008)	(+0.007)	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)
+8 (+3)	+0.18	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02
	(+0.007)	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)
+5 (+2)	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05
	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)
+3 (+1)	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08
	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)
0 (0)	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10
	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)
-3 (-1)	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10	-0.13
	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)
-5 (-2)	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10	-0.13	-0.15
	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)	(-0.006)
-8 (-3)	+0.02 (+0.001)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)
-10 (-4)	0 (0)	-0.02 (-0.001)	-0.05 (-0.002)	-0.08 (-0.003)	-0.10 (-0.004)	-0.13 (-0.005)	-0.15 (-0.006)	-0.18 (-0.007)	-0.20 (-0.008)

 Make sure all parts are clean and that drive pinion bearings are well lubricated.

Assemble drive pinion bearings into Tools.


2.


Tool number A: — (8144)

B: — (6740)


C: — (6741)

3. Install drive pinion bearing inner race and drive pinion height adjusting washer to gear carrier using Tool as shown.





4. Turn the assembly several times to seat drive pinion bearings.



Α

В

DLN

Е

F

G

Н

K

L

N./I

Ν

0

< DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: M226]

5. Measure the turning torque using Tool.

Tool number : ST3127S000 (J-25765-A)

Turning torque specification:


1.2 - 2.8 N-m (0.13 - 0.28 kg-m, 11 - 24 in-lb)




6. Tighten side bearing caps to the specified torque installing Tools as shown.

Tool number A: — (6739)

B: — (D-115-2) C: — (8541A-1) D: — (D-115-3)



- 7. Put scooter block on pinion height block. Make sure that dial indicator is level adjusting pressure with a hand. Dial indicator indicates "0".
- 8. Slide dial indicator along arbor. Record the maximum.
- 9. Adjust drive pinion height adjusting washer so that the maximum will be "0".



ASSEMBLY

Drive Pinion Assembly


 Press a new drive pinion rear bearing outer race into gear carrier using Tools.

Tool number A: ST01500001 (—)

B: ST30022000 (—)

CAUTION:

Do not reuse drive pinion rear bearing.



< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226]


Press a new drive pinion front bearing outer race into gear carrier using Tool.

> Tool number : ST33022000 (—)

CAUTION:

Do not reuse drive pinion front bearing.

Select drive pinion height adjusting washer. Refer to DLN-246. "Disassembly and Assembly".



Press a new drive pinion rear bearing inner race and drive pinion height adjusting washer to drive pinion using Tool.

> **Tool number** (C - 4040)

CAUTION:


Do not reuse drive pinion rear bearing.

- 5. Apply gear oil to drive pinon rear bearing and drive pinon front bearing.
- Install a new drive pinion front bearing inner race in gear carrier.
- Install drive pinion front bearing thrust washer to gear carrier.
- Apply multi-purpose grease to new front oil seal lip. Install new front oil seal into gear carrier using Tool.

: ST15310000 (—) **Tool number**

CAUTION:


- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lip of the new front oil seal.



9. Install new collapsible spacer to drive pinion. And then install drive pinion assembly in gear carrier.

CAUTION:


- Do not reuse collapsible spacer.
- · Do not damage front oil seal.




10. Install the companion flange onto the drive pinion while aligning the matching marks. Then tap the companion flange using suitable tool.

CAUTION:

Do not damage companion flange or front oil seal.





Préss

Tool

DLN

Α

В

Е

Drive pinion height

adjusting washer

F

Н

M

Ν

[REAR FINAL DRIVE: M226]

11. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B.

Tool number A: KV40104000 (—)

B: ST3127S000 (J-25765-A)

Drive pinion bearing preload torque:


1.7 - 3.1 N·m (0.18 - 0.31 kg-m, 15 - 27 in-lb)

CAUTION:


- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly</u> and <u>Assembly</u>".
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.


Differential Assembly

- Assemble side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on side gears.
- 2. Assemble side gear and side gear thrust washer into differential case.



3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and assemble them into differential case after assembling pinion mate thrust washer to pinion mate gear.






< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226]

- 4. Align lock pin holes on differential case and shaft, and assemble pinion mate shaft.
- Measure side gear end play. If necessary, select the appropriate side gear thrust washers. Refer to <u>DLN-246</u>, "<u>Disassembly and</u> Assembly".




6. Drive a new lock pin into pinion mate shaft, using Tool.


Tool number : ST23550000 (—)

CAUTION:

Do not reuse lock pin.




7. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




- Apply thread locking sealant to the back face of drive gear as shown.
 - Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

CAUTION:

Make sure the drive gear back and threaded holes are clean.



9. Align the matching mark of differential case with the mark of drive gear, then install drive gear.



DLN

Α

В

Е

G

Н

K

L

M

Ν

0


Ρ

[REAR FINAL DRIVE: M226]


- 10. Apply thread locking sealant into the threaded holes of the drive gear and install the bolts.
 - Use Genuine High Strength Thread Locking Sealant, Loctite 648 or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

CAUTION:

Make sure the drive gear back and threaded holes are clean.



- Install new drive gear bolts, and then tighten to the specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly and Assembly</u>". <u>CAUTION</u>:
 - · Do not reuse the bolts.
 - Tighten bolts in a crisscross fashion.




12. Press new side bearing inner races to differential case using Tools.

Tool number A: KV38100300 (J-25523)


B: ST33081000 (—)

CAUTION:


Do not reuse side bearing.



13. Install side bearing adjusters into gear carrier.



14. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into gear carrier.




< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226]

15. Align paint matching mark on side bearing caps with that on gear carrier and install side bearing caps on gear carrier.
CAUTION:


Do not tighten at this point. This allows further tightening of side bearing adjusters.



16. Tighten each side bearing adjusters using Tool.

Tool number : — (C - 4164)

- 17. Adjusting backlash of drive gear and drive pinion. Refer to <u>DLN-246, "Disassembly and Assembly"</u>.
- 18. Check total preload. Refer to <u>DLN-246, "Disassembly and Assembly".</u>
- 19. Check tooth contact. Refer to DLN-246, "Disassembly and Assembly".





• Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26.</u> "Recommended Chemical Products and Sealants".

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

 Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to <u>DLN-246</u>, "<u>Disassembly</u> and <u>Assembly</u>".





DLN

Α

В

Е

F

Н

J

K

M

Ν

0

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003303042

[REAR FINAL DRIVE: M226]

Applied model	VQ40DE
Applied model	6M/T
Final drive model	M226
Gear ratio	3.538
Number of pinion gears	2
Number of teeth (Drive gear / drive pinion)	46/13
Oil capacity (Approx.)	2.01 ℓ (4-1/4 US pt, 3-1/2 Imp pt)
Drive pinion adjustment spacer type	Collapsible

Inspection and Adjustment

INFOID:0000000003303043

DIFFERENTIAL SIDE GEAR CLEARANCE

Unit: mm (in)

Item	Standard
Side gear back clearance (Clearance between side gear and differential case for adjusting side gear backlash)	0.305 (0.0120) or less. (Each gear should rotate smoothly without excessive resistance during differential motion.)

PRELOAD TORQUE

Unit: N·m (kg-m, in-lb)

Item	Specification
Drive pinion bearing preload torque	1.7 - 3.1 (0.18 - 0.31, 15 - 27)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.49 - 4.57 (0.26 - 0.46, 22 - 40)

BACKLASH

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.12 - 0.20 (0.0050 - 0.0079)

COMPANION FLANGE RUNOUT

Unit: mm (in)

Item	Runout limit
Companion flange face	0.10 (0.0039) or less
Companion flange inner side	0.13 (0.0051) or less

SELECTIVE PARTS

Drive Pinion Height Adjusting Washer

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR FINAL DRIVE: M226]

	Unit: mm (in)			
Thickness	Package part number*			
0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034)	38151 8S101			
0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039)	38151 8S102			
0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044)	38151 8S103			
0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049)	38151 8S104			
0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054)	38151 8S105			

^{*}Always check with the Parts Department for the latest parts information.

Side Gear Thrust Washer

Unit: mm (in)

Thickness	Package part number*
0.76 (0.030)	
0.79 (0.031)	
0.81 (0.032)	38424 8S101
0.84 (0.033)	
0.86 (0.034)	
0.89 (0.035)	
0.91 (0.036)	
0.94 (0.037)	38424 8S102
0.97 (0.038)	
0.99 (0.039)	

^{*}Always check with the parts department for the latest parts information.

Р

Ν


K

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

OVERALL SEQUENCE



DIAGNOSIS AND REPAIR WORKFLOW


< BASIC INSPECTION > [REAR FINAL DRIVE: M226 (ELD)]	
1.INTERVIEW FOR MALFUNCTION	٨
Interview the customer about the symptom.	Α
>> GO TO 2	В
2.SYMPTOM CHECK	
Verify the symptom from the customer's information.	С
>> GO TO 3	
	DLN
Check the operation of each part. Check that no symptoms occur other than those specified by the customer.	
>> GO TO 4	Е
4.self-diagnosis with consult-iii	
Perform the self diagnosis with CONSULT-III. Check that any DTC is detected.	F
Is any DTC detected?	
YES >> GO TO 5 NO >> GO TO 6	G
5. TROUBLE DIAGNOSIS BY DTC	
Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.	Н
>> GO TO 7	
6.SYMPTOM DIAGNOSIS	-
Perform the symptom diagnosis. Specify the malfunctioning part.	
>> GO TO 7	J
7. MALFUNCTIONING PART REPAIR	
Repair or replace the malfunctioning part.	K
>> GO TO 8	
8. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)	L
Perform the self diagnosis with CONSULT-III. Verfied that no DTCs are detected. Erase all DTCs detected	
prior to the repair. Verify that DTC is not detected again. <u>Is any DTC detected?</u>	M
YES >> GO TO 5	
NO >> GO TO 9	Ν
9. REPAIR CHECK (OPERATION CHECK)	
Check the operation of each part.	0
<u>Does it operate normally?</u> YES >> Inspection End.	
NO >> GO TO 3	Р

INFOID:0000000003229730

FUNCTION DIAGNOSIS

DIFFERENTIAL LOCK SYSTEM


Cross-Sectional View



- 1. Companion flange
- 4. Differential case
- 7. Side gear
- 10. Pinion mate shaft
- 13. Cam ring

- 2. Drive pinion
- 5. Pinion mate gear
- 8. Spring
- 11. Pressure plate

- 3. Drive gear
- 6. Axle shaft
- 9. Differential lock solenoid
- 12. Differential lock position switch



System Description

INFOID:0000000003229680

Α

M

N

The differential lock system consists of the following components


- Differential lock control unit
- · Differential lock mode switch
- Differential lock position switch
- · Differential lock solenoid
- ABS actuator and electric unit (control unit)
- Transfer control unit

DIFFERENTIAL LOCK SYSTEM OPERATION

When the differential lock mode switch is in the LOCK position, a signal is sent to the differential lock control unit. The differential lock control unit monitors input from the ABS actuator and electric unit (vehicle speed and VDC operation) and the transfer control unit (4WD shift switch). If conditions are set, the differential lock control unit provides power and ground to the differential lock solenoid to lock the differential. The differential lock position switch provides feedback to the differential lock control unit as to whether the lock is engaged based on pressure plate position. The differential lock control unit provides ground to the DIFF LOCK indicator lamp to activate the lamp. Refer to the Owner's Manual for differential lock system operating instructions.

As a fail-safe function, the differential lock disengages when a malfunction is detected in the differential lock system. Self-diagnostics can be performed using CONSULT-III. Refer to DLN-270, "DIFFERENTIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)".

DIFFERENTIAL LOCK OPERATION



DLN-267

- Differential lock solenoid operates pressure plate.
- Pressure plate presses cam ring.
- Engage cam ring and side gear, and the differential is locked.

DIFFERENTIAL LOCK INDICATOR LAMP OPERATION

Condition	DIFF LOCK indicator lamp
Differential lock/unlock	ON/OFF
Differential lock standby condition	Flashing once every 2 seconds
Differential lock system malfunction	OFF (even if differential lock mode switch is in LOCK position)
Lamp check	Turns ON when ignition switch is turned ON. Turns OFF after engine start.


NOTE:

The differential lock standby condition is the time where the differential lock mode switch is in the LOCK position and the differential is unlocked.

Component Parts Location

INFOID:0000000003229681

[REAR FINAL DRIVE: M226 (ELD)]



DIFFERENTIAL LOCK SYSTEM

< FUNCTION DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

1.	Combination meter M24	2.	Differential lock mode switch M149	3.	Differential lock control unit M70	Α	
					(view with lower instrument panel LH		
					removed)		
4.	Steering column	5.	Differential lock position switch C116	6.	Differential lock solenoid C117	В	

Component Description

INFOID:0000000003229682

Component	Function
Differential lock control unit	 Controls differential lock solenoid to lock/unlock the differential. As a fail-safe function, the differential lock disengages when a malfunction is detected within the differential lock system.
Differential lock solenoid	Controls pressure plate operation when provided power and ground from the differential lock control unit.
Differential lock position switch	Detects differential lock/unlock condition based on the position of the pressure plate.
Differential lock mode switch	Allows driver input for differential LOCK/UNLOCK to the differential lock control unit.
DIFF LOCK indicator lamp	Illuminates to indicate the differential lock is locked or in standby condition.
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication to the differential lock control unit. • Vehicle speed signal • VDC operation signal (A/T models)
Transfer control unit (with 4-wheel drive)	Transmits the 4WD shift switch signal via CAN communication to the differential lock control unit.

DLN

LIN

Е

F

G

-

J

Κ

L

пл

Ν

0

DIAGNOSIS SYSTEM (DIFFERENTIAL LOCK CONTROL UNIT) [REAR FINAL DRIVE: M226 (ELD)]

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (DIFFERENTIAL LOCK CONTROL UNIT) DIFFERENTIAL LOCK CONTROL UNIT

DIFFERENTIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)

INFOID:0000000003229683

CONSULT-III can display each diagnostic item using the following diagnostic test modes

DIFF LOCK Diagnostic test mode	Function
SELF-DIAGNOSTIC RESULTS	Displays differential lock control unit self-diagnostic results.
DATA MONITOR	Displays differential lock control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
ECU PART NUMBER	The part number of the differential lock control unit can be checked

SELF-DIAGNOSTIC RESULTS

Display Item List

Refer to DLN-298, "DTC Index".

DATA MONITOR

Display Item List

Monitor item [Unit]	Description
BATTERY VOLT [V]	Displays power supply voltage for the differential lock control unit.
4WD MODE [2H/4H/4Lo]	Displays 4WD shift switch position.
VHCL S/SEN-RL [km/h] or [mph]	Displays average of rear wheel speed sensors (left and right). Value is approximately equal to the indication of vehicle speed on the speedometer (inside $\pm 10\%$).
D-LOCK SW SIG [ON/OFF]	Displays differential lock mode switch position.
D-LOCK SIG [ON/OFF]	Displays control status of differential lock.
RELAY ON [ON/OFF]	Displays operating condition of differential lock solenoid relay (integrated in differential lock control unit).
RELAY MTR [ON/OFF]	Displays control status of differential lock solenoid relay (integrated in differential differential lock control unit).
SOL MTR [ON/OFF]	Displays control status of differential lock solenoid.
IND MTR [ON/OFF]	Displays control status of DIFF LOCK indicator lamp.
D-LOCK POS SW [ON/OFF]	Displays condition of differential lock position switch

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

[REAR FINAL DRIVE: M226 (ELD)]

Α

В

C

DLN

Е

F

Н

K

M

Ν

0

Р

INFOID:0000000003229684

< FUNCTION DIAGNOSIS >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page	<u>DLN-319</u>	<u>DLN-319</u>	<u>DLN-319</u>	<u>DLN-317</u>	DLN-319	<u>MA-12</u>	DLN-128, "NVH Troubleshooting Chart" DLN-160, "NVH Troubleshooting Chart" DLN-152, "NVH Troubleshooting Chart"	RAX-18, "NVH Troubleshooting Chart"	RSU-4, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	WT-30, "NVH Troubleshooting Chart"	RAX-18, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"	ST-5, "NVH Troubleshooting Chart"
Possible cause and SUSPECTED PARTS	Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	REAR AXLE	REAR SUSPENSION	TIRES	ROAD WHEEL	AXLE SHAFT	BRAKES	STEERING
Symptom Noise	×	×	×	×	×	×	×	×	×	×	×	×	×	×

x: Applicable

DLN-271

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description INFOID:000000003292898

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to LAN-55, "CAN Communication Signal Chart".

DTC Logic

DTC DETECTION LOGIC

DTC	Display contents of CON- SULT-III	Diagnostic item is detected when	Probable malfunction location
U1000	CAN COMM CIRCUIT	When differential lock control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	

Diagnosis Procedure

INFOID:0000000003292900

1.PERFORM SELF DIAGNOSTIC

- 1. Turn ignition switch ON and wait for 2 seconds or more.
- 2. Check "Self Diagnostic Result" of differential lock control unit.

Is "CAN COMM CIRCUIT" displayed?

YES >> Refer to LAN-14, "Trouble Diagnosis Flow Chart".

NO >> Refer to GI-51, "Intermittent Incident".

P1833 INITIAL START

Description

Self-diagnosis memory function was suspended due to low battery voltage at the differential lock control unit.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1833	INITIAL START [P1833]	Low battery voltage available to the differential lock control unit.	Check differential lock control unit power supply and ground circuit. Refer to DLN-273. "Diagnosis Procedure"

DLN

Е

INFOID:0000000003292903


Α

Diagnosis Procedure

1. CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER SUPPLY

- 1. Turn ignition switch OFF.
- 2. Disconnect differential lock control unit harness connector.
- 3. Turn ignition switch ON.
- 4. Check voltage between differential lock control unit harness connector M70 terminals 1, 2, 15 and ground.

(+)	(-)	Voltage (Approx.)	
Connector	Connector Terminal		Voltage (Approx.)	
	1			
M70	2	Ground	Battery voltage	
	15			



Is the inspection result normal?

YES >> GO TO 2.

NO >> Check fuse. Repair harness or connectors.

2.check differential lock control unit ground circuit

- 1. Turn ignition switch OFF.
- Check continuity between differential lock control unit harness connector M70 terminals 3, 10 and ground.

Connector	Terminal	_	Continuity	
M70	3	Ground	Yes	
	10	Ground		

Disconnect Hs. Differential lock control unit connector Ω SDIA2564E

Is the inspection result normal?

YES >> Power and ground supply is normal.

NO >> Repair harness or connectors.

Р

K

L

M

Ν

P1834 CONTROL UNIT 1

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

P1834 CONTROL UNIT 1

Description INFOID:000000003292904

Replace the differential lock control unit if this DTC is displayed. Refer to <u>DLN-309</u>, "Removal and Installation".

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1834	CONTROL UNIT 1 [P1834]	A malfunction is detected in the memory (RAM) of the differential lock control unit.	Replace differential lock control unit. Refer to <u>DLN-309</u> , "Removal and Installation".

P1835 CONTROL UNIT 2

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

P1835 CONTROL UNIT 2

Description

 $Replace \ the \ differential \ lock \ control \ unit \ if \ this \ DTC \ is \ displayed. \ Refer \ to \ \underline{DLN-309. \ "Removal \ and \ Installation"}.$

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1835	CONTROL UNIT 2 [P1835]	A malfunction is detected in the memory (ROM) of the differential lock control unit.	Replace differential lock control unit. Refer to DLN-309, "Removal and Installation".

DLN

C

Α

Е

F

G

Н

K

L

M

Ν

0

P1836 CONTROL UNIT 3

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

P1836 CONTROL UNIT 3

Description INFOID:000000003292908

Replace the differential lock control unit if this DTC is displayed. Refer to <u>DLN-309</u>, "Removal and Installation".

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1836	CONTROL UNIT 3 [P1836]	A malfunction is detected in the memory (EEPROM) of the differential lock control unit.	Replace differential lock control unit. Refer to <u>DLN-309</u> , "Removal and Installation".

P1837 CONTROL UNIT 4

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

P1837 CONTROL UNIT 4

Description INFOID:000000003292910

Replace the differential lock control unit if this DTC is displayed. Refer to <u>DLN-309</u>. "Removal and Installation".

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1837	CONTROL UNIT 4 [P1837]	The AD converter system of the differential lock control unit is malfunctioning.	Replace differential lock control unit. Refer to <u>DLN-309</u> , "Removal and Installation".

DLN

C

Α

Е

F

G

Н

1

K

L

M

Ν

0

P1838 ON SWITCH

Description INFOID:000000003292912

The differential lock mode switch sends differential lock ON/OFF request signals to the differential lock control unit.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1838	ON SW [P1838]	Two switch inputs were simultaneously detected due to a short circuit in the differential lock mode switch.	Inspect the differential lock mode switch. Refer to DLN-278. "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003292914

1. CHECK DIFFERENTIAL LOCK MODE SWITCH OPERATION

- Turn ignition switch ON.
- 2. Using CONSULT-III, select "D-LOCK SW SIG" of DIFF LOCK data monitor items.
- While operating the differential lock mode switch, check that the display value changes between ON/OFF.

Switch ON Display item ON
Switch OFF Display item OFF

Is the inspection result normal?


YES >> Differential lock mode switch is operating properly.

NO >> GO TO 2.

2.CHECK DIFFERENTIAL LOCK MODE SWITCH POWER SUPPLY CIRCUIT

- 1. Disconnect differential lock mode switch harness connector.
- 2. Turn ignition switch ON.
- Check voltage between differential lock mode switch harness connector M149 terminal 3 and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal	()	vollago (Approx.)
M149	3	Ground	Battery voltage



Is the inspection result normal?


YES >> GO TO 3.

NO >> Repair harness or connector.

${f 3.}$ CHECK DIFFERENTIAL LOCK MODE SWITCH SIGNAL

- Turn ignition switch OFF.
- Connect differential lock mode switch harness connector.
- 3. Check voltage between differential lock control unit harness connector M70 terminals 9, 22 and ground.

(+)	(-)	Differential lock mode	Voltage (Approx.)
Connector	Terminal	()	switch	voltage (Approx.)



P1838 ON SWITCH

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

	9		ON	Battery voltage
M70	9	Ground	OFF	0V
	22		ON	0V
		OFF	Battery voltage	

Is the inspection result normal?


YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NO >> GO TO 4.

4. CHECK DIFFERENTIAL LOCK MODE SWITCH

- 1. Turn ignition switch OFF.
- 2. Disconnect differential lock mode switch harness connector.
- 3. Operate differential lock mode switch and check continuity between differential lock mode switch terminals.

Terminals	Differential lock mode switch	Continuity
1 - 3	ON	No
1-3	OFF	Yes
2 - 3	ON	Yes
2-3	OFF	No



Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace differential lock mode switch.


5.check harness between differential lock control unit and differential lock mode switch

 Check continuity between differential lock control unit harness connector M70 (A) terminals 9, 22 and differential lock mode switch harness connector M149 (B) terminals 2, 1.

Connector	Terminal	Connector	Terminal	Continuity
M70 (A)	9	M149 (B)	2	Yes
	22	W1149 (D)	1	165

2. Check continuity between differential lock control unit harness connector M70 (A) terminals 9, 22 and ground.

Connector	Terminal		Continuity	
M70 (A)	9	Ground	No	
M70 (A)	22		No	



Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NO >> Repair harness or connector.

DLN

Α

В

Е

F

G

Н

K

L

M

Ν

P1839 POSITION SWITCH ON

Description INFOID:000000003292915

The differential lock position switch sends a signal to the differential lock control unit when the differential lock is engaged. The differential lock control unit monitors the left and right rear wheel speed sensor signals to determine wheel slippage. When the differential lock is engaged the left and right rear wheel speed sensor signals should match.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1839	POSI SW ON [P1839]	The differential lock position switch is ON indicating the differential is locked, but the differential lock control unit detects a difference between left and right rear wheel speeds.	Inspect the differential lock position switch. Refer to DLN-280, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:0000000003292917

1. CHECK DIFFERENTIAL LOCK POSITION SWITCH SIGNAL

- Start engine.
- 2. Using CONSULT-III, select "D-LOCK POS SW SIG" of DIFF LOCK data monitor.
- 3. Activate the differential lock according to the directions listed in the table and monitor the display value.

Monitor item	Condition		Display value
	Vehicle stopped Engine running	Differential lock mode switch: ON (DIFF LOCK indicator lamp: ON)	ON
D-LOCK POS SW SIG	VDC OFF switch (A/T models): ON WD shift switch: 4LO	Differential lock mode switch: OFF (DIFF LOCK indicator lamp: OFF)	OFF

Is the inspection result normal?


YES >> Differential lock position switch is operating normally.

NO >> GO TO 2.

2. CHECK DIFFERENTIAL LOCK POSITION SWITCH

- 1. Disconnect differential lock position switch harness connector.
- 2. Turn ignition switch ON.
- 3. Select "D-LOCK POS SW SIG" of DIFF LOCK data monitor.
- Monitor the display value while connecting and disconnecting a jumper wire between differential lock position switch harness connector C116 terminals 1 and 3.

Monitor item	Condition	Display value
D-LOCK POS SW SIG	Jumper wire connected	ON
	Jumper wire disconnected	OFF



Is the inspection result normal?

YES >> Check the mechanical operation of the differential lock. Replace the differential lock position switch. Refer to DLN-310, "Removal and Installation".

NO >> GO TO 3.

3.CHECK DIFFERENTIAL LOCK POSITION SWITCH VOLTAGE

P1839 POSITION SWITCH ON

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Check voltage between differential lock position switch harness connector C116 terminal 3 and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal	(-)	voltage (Approx.)
C116	3	Ground	Battery voltage

DISCONNECT T.S. AWDIA0306ZZ

Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 5.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.


2. Check continuity between differential lock position switch harness connector C116 terminal 1 and ground.

_	Connector	Terminal	_	Continuity
	C116	1	Ground	Yes

Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to <u>DLN-309</u>, "Removal and Installation".

NO >> Repair harness or connector.



5. CHECK HARNESS BETWEEN DIFFERENTIAL LOCK CONTROL UNIT AND DIFFERENTIAL LOCK PO-SITION SWITCH

- 1. Turn ignition switch OFF.
- Disconnect differential lock control unit harness connector.
- 3. Check continuity between differential lock control unit harness connector M70 (A) terminal 20 and differential lock position switch harness connector C116 (B) terminal 3.

Connector	Terminal	Connector	Terminal	Continuity
M70 (A)	20	C116 (B)	3	Yes

 Check continuity between differential lock control unit harness connector M70 (A) terminal 20 and ground.

Connector	Terminal	Ground	Continuity
M70 (A)	20	Glound	No

Is the inspection result normal?

YES >> Replace differential lock control unit. Refer to <u>DLN-309</u>, "Removal and Installation".

NO >> Repair harness or connector.

Ν

M

Α

В

DLN

F

Н

P1844 RELAY

Description INFOID:0000000003292918

The differential lock solenoid relay is an integral part of the differential lock control unit.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1844	RELAY [P1844]	The differential lock control unit relay monitor did not detect expected voltage at the relay.	Inspect differential lock control unit relay power and ground supply circuit. Refer to <u>DLN-282</u> , " <u>Diagnosis Procedure"</u> .


Diagnosis Procedure

INFOID:0000000003292920

1. CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER SUPPLY

- 1. Turn ignition switch OFF.
- 2. Disconnect differential lock control unit harness connector.
- 3. Turn ignition switch ON.
- 4. Check voltage between differential lock control unit harness connector M70 terminals 1, 2, 15 and ground.

(+)		(-)	Voltago (Approx.)
Connector	Terminal	(-)	Voltage (Approx.)
	1	Ground	Battery voltage
M70	2		
	15		



Is the inspection result normal?


YES >> GO TO 2.

NO >> Check fuse. Repair harness or connectors.

2.check differential lock control unit ground circuit

- Turn ignition switch OFF.
- 2. Check continuity between differential lock control unit harness connector M70 terminals 3, 10 and ground.

Connector	Terminal	_	Continuity
M70	3	Ground	Yes
IVI7 O	10	Giodila	163



Is the inspection result normal?

YES >> Power and ground supply is normal.

NO >> Repair harness or connectors.

P1847 SOLENOID CIRCUIT

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

P1847 SOLENOID CIRCUIT

Description INFOID:000000003292921

Replace the differential lock control unit if this DTC is displayed. Refer to <u>DLN-309</u>, "Removal and Installation"

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1847	SOL CIRCUIT [P1847]	A malfunction is detected in the differential lock control unit internal circuit.	Replace differential lock control unit. Refer to <u>DLN-309</u> , "Removal and Installation".

DLN

C

Α

Е

F

G

Н

,

K

L

M

Ν

0

P1848 SOLENOID DISCONNECT

Description INFOID:000000003292923

When power and ground is supplied from the differential lock control unit, the differential lock solenoid will actuate to move the pressure plate against the cam ring to lock the differential. By reversing polarity at the differential lock control unit, the differential lock solenoid moves the pressure plate away from the cam ring to unlock the differential.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1848	SOL DISCONNECT [P1848]	An open was detected in the differential lock solenoid or circuit.	Inspect differential lock sole- noid. Refer to <u>DLN-284, "Di-agnosis Procedure"</u> .

Diagnosis Procedure

INFOID:0000000003292925

DIAGNOSTIC PROCEDURE

1. CHECK DIFFERENTIAL SOLENOID CONTROL

- Start engine.
- 2. Using CONSULT-III, select "RELAY ON", "RELAY MTR", "SOL MTR" of DIFF LOCK data monitor.
- 3. Observe the display values while operating the differential lock system.

Monitor item	Condition	Differential lock mode switch	Display value
RELAY ON		ON	ON
RELATION	• Vahiala stannad	OFF	OFF
Vehicle stopped Engine running VDC OFF switch: ON		ON	ON
	 VDC OFF switch: ON 4WD shift switch: 4LO 	OFF	OFF
SOL MTR	400D Shift Switch: 4LO	ON	ON
		OFF	OFF

Is the inspection result normal?

YES >> Differential lock solenoid control system is operating normally.

NO >> GO TO 2.

2.CHECK DIFFERENTIAL LOCK SOLENOID RESISTANCE

- 1. Turn ignition switch OFF.
- 2. Disconnect differential lock solenoid harness connector C117.
- 3. Check resistance between differential lock solenoid terminals 2 and 4.


2 - 4 : Approx. 3.4Ω

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace differential solenoid. Refer to <u>DLN-319</u>, "<u>Disassembly</u>".

3.check differential lock solenoid operation



P1848 SOLENOID DISCONNECT

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Check operation by applying power and ground to the differential lock solenoid terminals.

Component	(+)	(-)	Solenoid operation	
Сотронен	Terminal	Terminal	Objetiona operation	
Differential lock solenoid	4	2	Yes	

Fuse AWDIA0310ZZ

Is the inspection result normal?

YES >> GO TO 4.


NO

>> Check for a mechanical malfunction with the differential lock system. Replace differential solenoid. Refer to DLN-319, "Disassembly and Assembly".

4. CHECK DIFFERENTIAL LOCK SOLENOID CIRCUIT

- Disconnect differential lock control unit harness connector.
- Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and differential lock solenoid harness connector C117 (B) terminals 4, 2.

	А		В	
Connector	Terminal	Connector	Terminal	Continuity
M70	11	C117	4	Yes
IVI7 O	12	CIII	2	165



Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and ground.

А		_	Continuity	
Connector	Terminal		Continuity	
M70	11	Ground	No	
IVI7 O	12	Ground	No	

Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NG >> Repair harness or connector.

Α

В

DLN

Е

Н

K

L

Ν

M

P1849 SOLENOID SHORT

Description INFOID:000000003292926

When power and ground is supplied from the differential lock control unit, the differential lock solenoid will actuate to move the pressure plate against the cam ring to lock the differential. By reversing polarity at the differential lock control unit, the differential lock solenoid moves the pressure plate away from the cam ring to unlock the differential.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1849	SOL SHORT [P1849]	A short was detected in the differential lock solenoid internal circuit or in the harness.	Inspect the differential lock solenoid. Refer to <u>DLN-286</u> . " <u>Diagnosis Procedure"</u> .

Diagnosis Procedure

INFOID:0000000003292928

DIAGNOSTIC PROCEDURE

1. CHECK DIFFERENTIAL SOLENOID CONTROL

- Start engine.
- 2. Using CONSULT-III, select "RELAY ON", "RELAY MTR", "SOL MTR" of DIFF LOCK data monitor.
- 3. Observe the display values while operating the differential lock system.

Monitor item	Condition	Differential lock mode switch	Display value
RELAY ON		ON	ON
ILLAI ON	Vehicle stopped	OFF	OFF
RELAY MTR • Engine running • VDC OFF switch: ON		ON	ON
	OFF	OFF	
SOL MTR	4WD shift switch: 4LO	ON	ON
		OFF	OFF

Is the inspection result normal?

YES >> Differential lock solenoid control system is operating normally.

NO >> GO TO 2.

2.CHECK DIFFERENTIAL LOCK SOLENOID RESISTANCE

- Turn ignition switch OFF.
- 2. Disconnect differential lock solenoid harness connector C117.
- 3. Check resistance between differential lock solenoid terminals 2 and 4.


2 - 4 : Approx. 3.4Ω

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace differential solenoid. Refer to <u>DLN-319</u>, "<u>Disassembly</u>".

3.check differential lock solenoid operation



P1849 SOLENOID SHORT

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Check operation by applying power and ground to the differential lock solenoid terminals.

Component	(+)	(-)	Solenoid operation	
Component	Terminal	Terminal		
Differential lock solenoid	4	2	Yes	

Fuse

Is the inspection result normal?

YES >> GO TO 4.


NO

>> Check for a mechanical malfunction with the differential lock system. Replace differential solenoid. Refer to DLN-319, "Disassembly and Assembly".

4. CHECK DIFFERENTIAL LOCK SOLENOID CIRCUIT

- Disconnect differential lock control unit harness connector.
- Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and differential lock solenoid harness connector C117 (B) terminals 4, 2.

А		В		Continuity	
Connector	Terminal	Connector	Terminal	Continuity	
M70	11	C117	4	Yes	
IVI7O	12	CIII	2	163	




Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and ground.

Α			Continuity
Connector	Terminal		Continuity
M70	11	Ground	No
IVI7 U	12	Giouna	INO

Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NG >> Repair harness or connector.



Α

В

DLN

AWDIA0310ZZ

Е

Н

K

L

M

Ν

P1850 SOLENOID CURRENT

Description INFOID:000000003292929

The differential lock control unit supplies power and ground to the differential lock solenoid via the differential lock solenoid relay (integral to the differential lock control unit).

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
P1850	SOL CURRENT [P1850]	The differential lock relay does not switch to OFF or there is a short to power in the harness.	Inspect the differential lock solenoid. Refer to <u>DLN-288</u> , " <u>Diagnosis Procedure"</u> .

Diagnosis Procedure

INFOID:0000000003292931

DIAGNOSTIC PROCEDURE

1. CHECK DIFFERENTIAL SOLENOID CONTROL

- 1. Start engine.
- 2. Using CONSULT-III, select "RELAY ON", "RELAY MTR", "SOL MTR" of DIFF LOCK data monitor.
- 3. Observe the display values while operating the differential lock system.

Monitor item	Condition	Differential lock mode switch	Display value
RELAY ON	Vehicle stopped Engine running	ON	ON
		OFF	OFF
RELAY MTR		ON	ON
RELATIVITY	VDC OFF switch: ON 4WD shift switch: 4LO	OFF	OFF
SOL MTR	4WD SHIR SWITCH, 4EO	ON	ON
		OFF	OFF

Is the inspection result normal?

YES >> Differential lock solenoid control system is operating normally.

NO >> GO TO 2.

2.CHECK DIFFERENTIAL LOCK SOLENOID RESISTANCE

- 1. Turn ignition switch OFF.
- Disconnect differential lock solenoid harness connector C117.
- Check resistance between differential lock solenoid terminals 2 and 4.


2 - 4 : Approx. 3.4Ω

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace differential solenoid. Refer to <u>DLN-319</u>, "<u>Disassembly</u> and <u>Assembly</u>".

3.check differential lock solenoid operation



P1850 SOLENOID CURRENT

< COMPONENT DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Check operation by applying power and ground to the differential lock solenoid terminals.

Component	(+)	(-)	Solenoid operation
Component	Terminal	Terminal	Colonola operation
Differential lock solenoid	4	2	Yes

Fuse AWDIA0310ZZ

Is the inspection result normal?

YES >> GO TO 4.


NO

>> Check for a mechanical malfunction with the differential lock system. Replace differential solenoid. Refer to DLN-319, "Disassembly and Assembly".

4. CHECK DIFFERENTIAL LOCK SOLENOID CIRCUIT

- Disconnect differential lock control unit harness connector.
- Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and differential lock solenoid harness connector C117 (B) terminals 4, 2.

	A		B Continu	
Connector	Terminal	Connector	Terminal	Continuity
M70	11	C117	4	Yes
IVI7 O	12	CIII	2	165



Check continuity between differential lock control unit harness connector M70 (A) terminals 11, 12 and ground.

	A	_	Continuity	
Connector	Terminal		Continuity	
M70	11	Ground	No	
WITO	12	Giodila	No	

Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NG >> Repair harness or connector.

Α

В

DLN

Е

Н

K

L

M

Ν

C1203 ABS SYSTEM

[REAR FINAL DRIVE: M226 (ELD)]

< COMPONENT DIAGNOSIS >

C1203 ABS SYSTEM

Description INFOID:000000003292932

The differential lock control unit and the ABS actuator and electric unit (control unit) are in communication via the CAN communication network. Vehicle speed and wheel slippage information is used by the differential lock control unit to determine if conditions are met to actuate the differential lock solenoid.

DTC Logic

DTC	Display contents of CONSULT-III	DTC Detection Condition	Action to take
C1203	ABS SYSTEM [C1203]	A malfunction related to wheel speed sensors has been detected by the ABS actuator and electric unit (control unit).	Check for proper ABS operation. Refer to BRC-88, "CONSULT-III Function (ABS)" (Type 2) or BRC- 186, "CONSULT-III Function (ABS)" (Type 3).

LOCK INDICATOR LAMP

Description INFOID:000000003292934

The DIFF LOCK indicator lamp has power available to it any time the ignition switch is in the ON or START position. The differential lock control unit supplies ground to activate the DIFF LOCK indicator lamp. The DIFF LOCK indicator lamp will go through a prove out at initial key ON. The DIFF LOCK will flash while the differential lock system is activating or while waiting for conditions to be met to activate. Once the differential lock has been engaged, the DIFF LOCK indicator lamp will remain ON. For more information about the DIFF LOCK indicator lamp, refer to the Owner's Manual.

Component Function Check

INFOID:0000000003292935

Α

DLN

Н

Ν

Р

1. CHECK DIFF LOCK INDICATOR LAMP OPERATION

- 1. Turn the ignition switch ON.
- 2. Observe the DIFF LOCK indicator lamp.

Ignition switch ON

Indicator prove out

Does the DIFF LOCK indicator lamp prove out normally?

YES >> DIFF LOCK indicator lamp is operating normally.

NO, ALWAYS ON>> Perform self diagnostics on differential lock control unit. Refer to DLN-270, "DIFFEREN-TIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)".

NO, ALWAYS OFF>>Check DIFF LOCK indicator lamp control circuit. Refer to <u>DLN-291, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:0000000003292936

1.CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER AND GROUND SUPPLY

Check the differential lock control unit power and ground supply. Refer to <u>DLN-273, "Diagnosis Procedure"</u>. <u>Is the inspection result normal?</u>

YES >> GO TO 2.

NO >> Repair or replace malfunctioning component.

2.check harness between differential lock control unit and combination meter

- 1. Turn ignition switch OFF.
- 2. Disconnect differential lock control unit harness connector and combination meter harness connector.
- 3. Check continuity between differential lock control unit harness connector M70 (A) terminal 21 and combination meter harness connector M24 (B) terminal 25.

	A		В	Continuity
Connector	Terminal	Connector	Terminal	Continuity
M70	21	M24	25	Yes

 Check continuity between differential lock control unit harness connector M70 (A) terminal 21 and ground.

DISCONNECT H.S. B
25
A "
Ω

	A		Continuity
Connector	Terminal		Continuity
M70	21	Ground	No

Is the inspection result normal?

YES >> Replace combination meter. Refer to MWI-91, "Removal and Installation".


NO >> Repair harness or connector.

[REAR FINAL DRIVE: M226 (ELD)] **ECU DIAGNOSIS**

DIFFERENTIAL LOCK CONTROL UNIT

Reference Value INFOID:0000000003292937


DIFFERENTIAL LOCK CONTROL UNIT TERMINAL CONNECTOR LAYOUT



ta are refe	rence value	and are measured between each	terminal and	ground.	SDIA2373E
Termi	nal No. color)	Description	ar arre	V	V. II
+	-	Signal name	Input/ Output	Condition	Voltage (V) (Approx.)
1 (W/G)	Ground	Ign power supply	Input	Ignition ON or START	Battery voltag
2 (W/G)	Ground	Ign power supply	Input	Ignition ON or START	Battery voltag
3 (B)	Ground	Ground	Input	Ignition ON	Less than 0.2
4 (P)	_	CAN-L	-		-
5 (L)	-	CAN-H	-		_
9	Ground	Differential lock mode switch	Input	Differential lock mode switch: ON	Battery voltag
(Y)	Ground	(ON)	input	Differential lock mode switch: OFF	0V
10 (B)	Ground	Ground	Input	Ignition ON	Less than 0.2
11	Cround	Differential lock solenoid	Output	Differential lock mode switch: ON	0V
(GR)	Ground	(LO)	Output	Differential lock mode switch: OFF	Battery voltag
12	Ground	Differential lock solenoid	Output	Differential lock mode switch: ON	0V
(L)	Ground	(HIGH)	Output	Differential lock mode switch: OFF	Battery voltag
13 (SB)	_	K-LINE	-	-	-
15 (R/Y)	Ground	Battery power supply (Memory back-up)	Input	Ignition OFF	Battery voltag
20	0	Differential lock position	la aut	Differential lock mode switch: ON (DIFF LOCK indicator lamp: ON)	0V
(BR)	Ground	switch	Input	Differential lock mode switch: OFF (DIFF LOCK indicator lamp: OFF)	Battery voltag
21	0	DIFF LOOK in Production	Out :	DIFF LOCK indicator lamp: ON	0V
(SB)	Ground	DIFF LOCK indicator lamp	Output	DIFF LOCK indicator lamp: OFF	Battery voltag
22	0	Differential lock mode switch	land t	Differential lock mode switch: ON	0V
(G)	Ground	(OFF)	Input	Differential lock mode switch: OFF	Battery voltag

CAUTION:

When using a circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.



Connector Name | COMBINATION METER


M24

Connector No.

Connector Color WHITE

[REAR FINAL DRIVE: M226 (ELD)]

REAR FINAL DRIVE CONNECTORS



Signal Name


Signal Name


Color of Wire Œ SB

Terminal No. 16 25

DIFF LOCK ATP-

X		Terminal No.	Color of Wire	Signal Name
		11	GR	DIFF_LOCK_LOW
		12	٦	DIFF_LOCK_HIGH
		13	SB	SSS
3 2 1		14	I	1
7 16 15 14 13		15	R/Υ	DIFF_LOCK_CU (BACK_UP)
ame		16	ı	1
2		17	I	1
K_CU	J	18	1	1
00		19	1	1
		20	BR	DIFF_LOCK_SW
		21	SB	DIFF_LOCK_IND
		22	5	DIFF_LOCK_SW(OFF)
		23	ı	ı
		24	1	I
		25	ı	ı
SW(ON)		26	1	ı
	_	1		





AWDIA0275GB

Connector Name | WIRE TO WIRE

M31

Connector No.

Connector Color | WHITE

< ECU DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Α

В

С

DLN

Е

F

G

Н

J

Κ

L

 \mathbb{N}

Ν

0


Ρ


Connector Name TRANSFER CONTROL Connector Color WHITE MH 3 2 1 H.S. 17/16/15/16/14/13/12/11/19/9/8/7	al V C	Connector No. E125
WHITE	Signal Name	E41 WIRE TO WIRE BLACK BLACK SIGNED
1 1 1 1 1 1 1 1 1	Color of Wire	
Connector Name DIFFER SWITCI Connector Color WHITE	Terminal No.	Connector No. Connector Name Connector Color H.S. BERRIERER BERRIE
Connector Name WIRE TO WIRE Connector Color WHITE To 5 4	Signal Name - -	E26 WIRE TO WIRE WHITE 2 3


AWDIA0276GB


[REAR FINAL DRIVE: M226 (ELD)]


Signal Name	ı	1	1	I
Color of Wire	GR	_	BR	В
Terminal No.	86	96	35G	36G











AWDIA0277GB

< ECU DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

Α

В

С

DLN

Е

F

G

Н

K

L

M

Ν

0

AWDIA0278GB

Connector No.	. C117	17
Connector Na	me DIF	Connector Name DIFFERENTIAL LOCK SOLENOID
Connector Color		BLACK
品.S.		2 4
Terminal No.	Color of Wire	Signal Name
2	_	ı
,	0	

Connector No.		C116
Connector Na	ame DI	Connector Name DIFFERENTIAL LOCK POSITION SWITCH
Connector Color GRAY	olor GF	SAY
H.S.		3 1
Terminal No.	Color of Wire	ار Signal Name
-	В	-
8	BR	ı

< ECU DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)]

DTC Index INFOID:0000000003229729

Items (CONSULT-III screen terms)	Diagnostic item is detected when	Check item
INITIAL START [P1833]	Due to removal of battery which cuts off power supply to differential control unit, self-diagnosis memory function is suspended.	DLN-273, "Description"
CONTROL UNIT 1 [P1834]	Malfunction is detected in the memory (RAM) system of differential lock control unit.	DLN-274, "Description"
CONTROL UNIT 2 [P1835]	Malfunction is detected in the memory (ROM) system of differential lock control unit.	DLN-275, "Description"
CONTROL UNIT 3 [P1836]	Malfunction is detected in the memory (EEPROM) system of differential lock control unit.	DLN-276, "Description"
CONTROL UNIT 4 [P1837]	AD converter system of differential lock control unit is malfunctioning.	DLN-277, "Description"
ON SW [P1838]	More than two switch inputs are simultaneously detected due to short circuit of differential lock mode switch.	DLN-278, "Description"
POSI SW ON [P1839]	When differential lock position switch is ON, rotation difference occurs in wheel speed (rear wheel right and left).	DLN-280, "Description"
RELAY [P1844]	Differential lock control unit detects as irregular by comparing target value with monitor value.	DLN-282, "Description"
SOL CIRCUIT [P1847]	Malfunction is detected in differential lock control unit internal circuit.	DLN-283, "Description"
SOL DISCONNECT [P1848]	 Differential lock solenoid internal circuit or harness is open. Differential lock solenoid relay does not switch to ON position. 	DLN-284, "Description"
SOL SHORT [P1849]	Differential lock solenoid internal circuit or harness is shorted.	DLN-286, "Description"
SOL CURRENT [P1850]	Differential lock solenoid relay does not switch to OFF position.	DLN-288, "Description"
ABS SYSTEM [C1203]	Malfunction related to wheel sensor has been detected by ABS actuator and electric unit (control unit).	DLN-290, "Description"
CAN COMM CIRCUIT [U1000]	Malfunction has been detected from CAN communication line.	DLN-272, "Description"
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No malfunction has been detected.	

If "CAN COMM CIRCUIT [U1000]" is displayed with other DTCs, first perform the trouble diagnosis for CAN communication line.

DIFF LOCK INDICATOR LAMP INOPERATIVE [REAR FINAL DRIVE: M226 (ELD)] < SYMPTOM DIAGNOSIS > SYMPTOM DIAGNOSIS Α DIFF LOCK INDICATOR LAMP INOPERATIVE Inspection Procedure INFOID:0000000003229731 В SYMPTOM: DIFF LOCK indicator lamp does not turn ON for approx. 1 second when turning ignition switch to "ON". DIAGNOSTIC PROCEDURE ${f 1}$.PERFORM DIFFERENTIAL LOCK CONTROL UNIT SELF DIAGNOSIS DLN Perform self-diagnosis. Refer to DLN-270, "DIFFERENTIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)". Е Were any DTC's displayed? >> Refer to DLN-298, "DTC Index". YES NO >> GO TO 2. F 2.CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT Check the differential lock control unit for proper power and ground. Refer to DLN-273, "Diagnosis Procedure". Is the inspection result normal? YES >> GO TO 3. NO >> Repair harness or connector. 3.CHECK DIFF LOCK INDICATOR LAMP POWER SUPPLY Н Check power supply to the combination meter (DIFF LOCK indicator lamp). Refer to MWI-29, "COMBINATION METER: Diagnosis Procedure". Is the inspection result normal? YES >> GO TO 4. NO >> Repair harness or connectors. 4. CHECK DIFF LOCK INDICATOR LAMP CONTROL Check the DIFF LOCK indicator lamp control circuit. Refer to DLN-291, "Diagnosis Procedure". K

Is the inspection result normal?

YES >> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation".

NG >> Repair malfunctioning component.

Р

L

M

N

DIFF LOCK INDICATOR LAMP DOES NOT TURN ON WITH DIFFERENTIAL **LOCK SWITCHED ON**

< SYMPTOM DIAGNOSIS >

[REAR FINAL DRIVE: M226 (ELD)] DIFF LOCK INDICATOR LAMP DOES NOT TURN ON WITH DIFFEREN-

TIAL LOCK SWITCHED ON

Inspection Procedure

SYMPTOM:

DIFF LOCK indicator lamp does not turn ON when turning differential lock mode switch to "ON" after engine start.

DIAGNOSTIC PROCEDURE

1. CHECK DIFF LOCK INDICATOR LAMP

Confirm the DIFF LOCK indicator lamp proves out when ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to DLN-299, "Inspection Procedure".

2.CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to DLN-270, "DIFFERENTIAL LOCK CONTROL UNIT : CONSULT-III Function (DIFF LOCK)".

Is any DTC detected by self-diagnosis?

YES >> Check the malfunctioning system. Refer to DLN-298, "DTC Index".

NO

3.CHECK DIFFERENTIAL LOCK MODE SWITCH OPERATION

Check differential lock mode switch, Refer to DLN-280, "Diagnosis Procedure",

Is the inspection result normal?

YFS >> GO TO 4.

NO >> Repair component, harness or connector.

4. CHECK DIFFERENTIAL LOCK CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check differential lock control unit power supply and ground circuit. Refer to DLN-273, "Diagnosis Procedure". Is the inspection result normal?

>> Replace the differential lock control unit. Refer to DLN-309, "Removal and Installation". YES

NO >> Repair harness or connector.

DIFF LOCK INDICATOR LAMP FLASHES WHILE DRIVING

< SYMPTOM DIAGNOSIS >

DIFF LOCK INDICATOR LAMP FLASHES WHILE DRIVING

Description INFOID:0000000003229733

The DIFF LOCK indicator lamp will flash once every 2 seconds when the differential lock system is in standby condition. Standby condition is the time between when the differential lock mode switch is turned ON and when the differential lock control unit see's all conditions are met to engage the differential lock. The DIFF LOCK indicator lamp should be OFF if there has been a malfunction detected. For more information regarding the differential lock system operation, refer to the Owner's Manual.

Inspection Procedure

INFOID:0000000003229734

[REAR FINAL DRIVE: M226 (ELD)]

SYMPTOM:

DIFF LOCK indicator lamp sometimes flashes while driving.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to DLN-270, "DIFFERENTIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)".

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system. Refer to <u>DLN-298, "DTC Index"</u>.

NO >> GO TO 2.

2.CHECK DIFFERENTIAL LOCK MODE SWITCH

Perform trouble diagnosis for differential lock mode switch. Refer to <u>DLN-278</u>, "Diagnosis Procedure".

Is the inspection result normal?

YES >> Condition is intermittent. Refer to GI-51, "Intermittent Incident".

NO >> Repair or replace malfunctioning component. DLN

Е

F

Α

Н

K

L

N

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"


The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution INFOID:000000003226158


 Before connecting or disconnecting differential lock control unit harness connector, turn ignition switch "OFF" and disconnect the battery cable from the negative terminal. Because battery voltage is applied to differential lock control unit even if ignition switch is turned "OFF".



- When connecting or disconnecting pin connectors into or from differential lock control unit, take care not to damage pin terminals (bend or break).
 - When connecting pin connectors make sure that there are not any bends or breaks on differential lock control unit pin terminal.



Before replacing differential lock control unit, perform differential lock control unit input/output signal inspection and make sure whether differential lock control unit functions properly or not. Refer to <u>DLN-270</u>, "<u>DIFFERENTIAL LOCK CONTROL UNIT</u>: CONSULT-III Function (DIFF LOCK)".



INFOID:0000000003226159

Precaution for Servicing Rear Final Drive

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them
 with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

Α

DLN

F

Н

K

M

L

N

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000003226160

Tool number (Kent-Moore No.) Tool name	ay differ from those of special service tools illustrated	Description
KV40104000 (—) Flange wrench		Removing and installing drive pinion lock nut a: 85 mm (3.35 in) dia. b: 65 mm (2.56 in) dia.
ST33290001 (J-34286) Puller	NT659	Removing front oil seal
ST15310000 (—) Drift	ZZA0601D	Installing front oil seal a: 96mm (3.77 in) dia. b: 84 mm (3.30 in) dia.
ST3127S000 (J-25765-A) Preload gauge set 1. GG91030000 (J-25765)	NT115 1 2 3 NT124	Inspecting drive pinion bearing preload torque and total preload torque
(C-4164) Adjuster tool	WDIA0192E	Removing and installing side bearing ac juster

PREPARATION

[REAR FINAL DRIVE: M226 (ELD)]

	REAR FINAL DRIVE: M226 (ELD)
	Description
	Removing carrier cover
S-NT046	Removing drive pinion rear bearing inner
	race
ZZA0700D	Removing and installing side bearing inner race a: 43 mm (1.69 in) dia. b: 33.5 mm (1.32 in) dia.
ZZA1000D	Adjusting drive pinion height
SDIA2599E	Adjusting drive pinion height
SDIA2601E	
	Adjusting drive pinion height
SDIA2602E	Adjusting drive pinion height
	, , , , , , , , , , , , , , , , , , , ,
	S-NT046 S-NT046 ZZA0700D ZZA1000D SDIA2599E

Tool number (Kent-Moore No.) Tool name		Description
— (D-115-2) Scooter block	SDIA2604E	Adjusting drive pinion height
 (8541A-1) Arbor disc	SDIA2605E	Adjusting drive pinion height
 (D-115-3) Arbor	SDIA2606E	Adjusting drive pinion height
ST01500001 (—) Drift	a b ZZAO811D	Installing drive pinion rear bearing outer race a: 89mm (3.50 in) dia. b: 79 mm (3.11 in) dia.
ST30022000 (—) Drift	NT660	Installing drive pinion rear bearing oute race a: 46 mm (1.81 in) dia. b: 110 mm (4.33 in) dia.
ST33022000 (—) Drift	NT660	Installing drive pinion front bearing outer race a: 49 mm (1.92 in) dia. b: 67 mm (2.63 in) dia.

PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: M226 (ELD)]

Tool number (Kent-Moore No.) Tool name		Description	
— (C-4040) Installer	SDIA2607E	Installing drive pinion rear bearing inner race	
KV38100300 (J-25523) Drift	ZZA1046D	Installing side bearing inner race a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32mm (1.26 in) dia.	

Commercial Service Tool

INFOID:00000000003226161	

Tool name		Description
Puller		Removing companion flange and side bearing inner race
	NT077	
Puller		Removing side bearing inner race
	ZZB0823D	
Power tool		Loosening bolts and nuts
	PBIC0190E	


ON-VEHICLE MAINTENANCE

DIFFERENTIAL GEAR OIL

Changing Differential Gear Oil

DRAINING

- 1. Stop engine.
- 2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
- Install the drain plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-319</u>, "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26. "Recommended Chemical Products and Sealants"




FILLING

- 1. Remove the filler plug from the rear final drive assembly.
- 2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil : Refer to MA-12, "Fluids grade and capacity and Lubricants".

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-319</u>. "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



INFOID:0000000003226163

INFOID:0000000003226162

Checking Differential Gear Oil


DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

- Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
- Check the differential gear oil level from the filler plug hole as shown.

CAUTION:

Do not start engine while checking differential gear oil level.

- Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to <u>DLN-319</u>, "<u>Disassembly and Assembly</u>".
 - Use High Performance Thread Sealant or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".



< ON-VEHICLE REPAIR >

[REAR FINAL DRIVE: M226 (ELD)]


ON-VEHICLE REPAIR

DIFFERENTIAL LOCK CONTROL UNIT

Removal and Installation

REMOVAL

- 1. Disconnect the battery cable from the negative terminal.
- 2. Remove jack and tools.
- 3. Remove upper bracket of center seat belt retractor and belt assembly. Refer to <u>SB-10, "Removal and Installation"</u>.
- 4. Remove the necessary push pins and reposition rear panel out of the way. Refer to INT-17, "Removal and Installation".
- Reposition the carpet to access differential lock control unit to disconnect connector.
- 6. Remove the two nuts and remove differential lock control unit.



INSTALLATION

Note the following, and installation is in the reverse order of removal.

When installing differential lock control unit, tighten nuts to the specified torque.

Differential lock control unit nuts : 5.1 N·m (0.52 kg-m, 45 in-lb)

DLN

Α

В

C

INFOID:0000000003226164

Е

F

Н

J

K

L

M

Ν

0

< ON-VEHICLE REPAIR >

DIFFERENTIAL LOCK POSITION SWITCH


Removal and Installation

Differential Lock Position Switch

REMOVAL

CAUTION:

- Be careful not to damage spline, companion flange and front oil seal when removing propeller shaft.
- Before removing rear final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from rear final drive assembly/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
- 1. Drain rear final drive gear oil. Refer to <u>DLN-308</u>, "Changing Differential Gear Oil".
- 2. Remove rear propeller shaft. Refer to <u>DLN-162</u>, "Removal and Installation".
- 3. Remove both RH and LH axle shafts. Refer to RAX-20, "Removal and Installation".
- 4. Remove the carrier cover. Refer to <u>DLN-316</u>, "Removal and Installation".
- 5. Remove differential lock solenoid connector (B) bolt and disconnect differential lock position connector (A).




[REAR FINAL DRIVE: M226 (ELD)]


INFOID:0000000003226165

6. For installation, apply a paint matching mark on one side of side bearing cap.

CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to install them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.
- 7. Remove adjuster lock plates.
- 8. Remove side bearing caps.






< ON-VEHICLE REPAIR >


[REAR FINAL DRIVE: M226 (ELD)]

9. Loosen the side bearing adjusters using Tool.


Tool number : — (C - 4164)



 Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.



11. Remove side bearing adjusters from gear carrier.



- 12. Remove bracket for the differential lock position switch connector and bolts.
- 13. Remove differential lock position switch.


INSTALLATION

- 1. Apply sealant to threads of differential lock position switch.
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, "Recommended Chemical Products and Sealants".

CAUTION:

Remove old sealant adhering to gear carrier and differential lock position switch. Also remove any moisture, oil, or foreign material adhering to application and gear carrier and differential lock position switch.

 Install differential lock position switch on gear carrier and tighten differential lock position switch bolts with the specified torque. Refer to <u>DLN-319</u>. "<u>Disassembly and Assembly"</u>.



Α

В

DLN

Е

Г

G

Н

|

J


<

L

M

< ON-VEHICLE REPAIR >


3. Install side bearing adjusters into gear carrier.




- 4. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into gear carrier.
- Apply multi-purpose grease to differential lock position connector.

CAUTION:

Do not reuse sensor connector.




 Connect differential lock solenoid harness (B) and differential lock position switch connector (A). Then install it to gear carrier, tighten to the specified torque. Refer to <u>DLN-319</u>, "<u>Disassembly</u> and <u>Assembly</u>".



7. Align paint matching mark on side bearing caps with that on gear carrier and install side bearing caps on gear carrier without tightening to specification.

CAUTION:


Do not tighten at this point. This allows further tightening of side bearing adjusters.



8. Tighten each side bearing adjusters using adjuster tool.

Tool number : — (C - 4164)

- Adjusting backlash of drive gear and drive pinion. Refer to <u>DLN-319</u>. "<u>Disassembly and Assembly"</u>.
- 10. Check total preload torque. Refer to DLN-319, "Disassembly and Assembly".
- 11. Check tooth contact. Refer to <u>DLN-319</u>, "<u>Disassembly</u> and <u>Assembly</u>".



< ON-VEHICLE REPAIR >

[REAR FINAL DRIVE: M226 (ELD)]

- 12. Apply a bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to GI-26. "Recommended Chemical Products and Sealants".


CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- 13. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-316, "Removal and Installation".
- 14. Installation of the remaining components is in the reverse order of removal.

CAUTION:





Α

В

DLN

F

Е

Н

K

M

L

Ν

INFOID:0000000003226166

FRONT OIL SEAL

Removal and Installation

REMOVAL

- 1. Remove rear propeller shaft. Refer to DLN-162, "Removal and Installation".
- 2. Remove brake calipers and rotors. Refer to <u>BR-29</u>, "Removal and Installation of Brake Caliper and <u>Disc Rotor"</u>.
- Measure the total preload torque. Refer to <u>DLN-334, "Inspection and Adjustment"</u>. NOTE:

Record the total preload torque measurement.


4. Remove the drive pinion nut using Tool.

Tool number : KV40104000 (—)


5. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.




6. Remove the companion flange using suitable tool.



7. Remove the front oil seal using Tool.

Tool number : ST33290001 (J-34286)



INSTALLATION

FRONT OIL SEAL

< ON-VEHICLE REPAIR >


[REAR FINAL DRIVE: M226 (ELD)]

Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using Tool.

> : ST15310000 (—) Tool number

CAUTION:

- · Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new front oil seal.



Install the companion flange to the drive pinion while aligning the matching marks.

3. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the total preload torque using Tool B.

> **Tool number** A: KV40104000 (—)

> > B: ST3127S000 (J-25765-A)

Total preload torque: Refer to DLN-319, "Disassembly and Assembly".


- The total preload torque should be within the total preload torque specification. When not replacing the collapsible spacer, it should also be equal to the measurement taken during removal plus an additional 0.56 N·m (0.06 Kg-m, 5 in-lb).
- If the total preload torque is low, tighten the drive pinion lock nut in 6.8 N·m (0.69 Kg-m, 5ft-lb) increments until the total preload torque is met.

CAUTION:

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to DLN-319, "Disassembly and Assembly".
- Do not loosen drive pinion lock nut to adjust the total preload torque. If the total preload torque exceeds the specifications, replace the collapsible spacer and tighten it again to adjust. Refer to DLN-319, "Disassembly and Assembly".
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- Installation of the remaining components is in the reverse order of removal.

CAUTION:

Check the differential gear oil level after installation. Refer to DLN-308, "Checking Differential Gear Oil".



Α

В

C

DLN

F

Н

K

M

Ν

INFOID:0000000003226167

CARRIER COVER

Removal and Installation


REMOVAL

- 1. Drain the differential gear oil. Refer to <u>DLN-308</u>.
- 2. Disconnect the parking brake cable (A) and brake tube (B) from the carrier cover.
- 3. Remove the carrier cover bolts and separate the carrier cover from the gear carrier using Tool.

Tool number : KV10111100 (J-37228)

CAUTION:

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.




INSTALLATION

- Apply a bead of sealant to the mating surface of the carrier cover as shown.
 - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26.</u> "Recommended Chemical Products and Sealants".

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to <u>DLN-319</u>, "<u>Disassembly and Assembly</u>".
- Connect the parking brake cable and brake tube to the carrier cover.
- 4. Fill the rear final drive assembly with recommended differential gear oil. Refer to <u>DLN-308</u>, "Changing <u>Differential Gear Oil"</u>.



REMOVAL AND INSTALLATION


REAR FINAL DRIVE ASSEMBLY

Removal and Installation

REMOVAL


CAUTION:

- Do not damage spline, companion flange and front oil seal when removing propeller shaft.
- Before removing final drive assembly or rear axle assembly, disconnect ABS sensor harness connector from the assembly and move it away from final drive/rear axle assembly area. Failure to do so may result in sensor wires being damaged and sensor becoming inoperative.
- 1. Drain the differential gear oil. Refer to DLN-308, "Changing Differential Gear Oil".
- Remove the rear propeller shaft. Refer to <u>DLN-162, "Removal and Installation"</u>.
- Remove the axle shaft, Refer to RAX-20, "Removal and Installation".
- 4. Disconnect the following components from the rear final drive assembly.
 - Brake tube block connectors. Refer to BR-29, "Removal and Installation of Brake Caliper and Disc Rotor".
 - ABS sensor wire harness. Refer to BRC-272, "Removal and Installation".
 - Parking brake cable (A).
 - Brake tube (B).



[REAR FINAL DRIVE: M226 (ELD)]

- Differential lock position switch harness connector (A).
- Differential lock solenoid harness connector (B).



- 5. Disconnect brake hose from brake tube at the mounting clip on top of rear final drive assembly. Then remove the metal clip to disconnect brake line from the mounting clip on top of the rear final drive assembly.
- 6. Support rear final drive using a suitable jack.
- Remove rear shock absorber lower bolts. Refer to RSU-8, "Removal and Installation".
- 8. Remove leaf spring U-bolt nuts. Refer to RSU-9, "Removal and Installation".
- 9. Remove rear final drive assembly.

Secure rear final drive assembly to the jack while removing it.

INSTALLATION

CAUTION:

Installation is in the reverse order of removal.

CAUTION:

 Fill the front final drive assembly with differential gear oil after installation. Refer to <u>DLN-308</u>. "Changing Differential Gear Oil".

INFOID:0000000003226168

Α

В

DLN

Е

L

M

REAR FINAL DRIVE ASSEMBLY

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: M226 (ELD)]


• Bleed the air from brake system. Refer to BR-9, "Bleeding Brake System".

DISASSEMBLY AND ASSEMBLY

REAR FINAL DRIVE

Disassembly and Assembly

COMPONENTS



- Drive pinion lock nut 1.
- Front oil seal 4.
- Gear carrier 7.
- 10. Sensor connector
- Adjuster lock plate 13.
- **Bracket** 16.
- 19. Drive pinion rear bearing
- Side bearing 22.
- 25. Differential lock solenoid

- Drive pinion lock nut washer 2.
- Drive pinion front bearing thrust 5. washer
- Differential lock position switch 8.
- Drain plug 11.
- Carrier cover 14.
- Drive pinion 17.
- 20. Collapsible spacer
- 23. Differential case assembly
- 26. Solenoid washer

- Companion flange 3.
- Drive pinion front bearing 6.
- Breather 9.
- 12. Side bearing cap
- 15. Filler plug
- 18. Drive pinion height adjusting washer
- 24. Drive gear

DLN

Α

В

C

INFOID:0000000003226169

Е

F

Н

K

L

M

Ν

Р

21. Side bearing adjuster

ASSEMBLY INSPECTION AND ADJUSTMENT

- Drain the differential gear oil before inspection and adjustment. Refer to <u>DLN-308</u>, <u>"Changing Differential Gear Oil"</u>.
- Remove and install the carrier cover as necessary for inspection and adjustment. Refer to <u>DLN-316.</u> "Removal and Installation".

Total Preload Torque


- 1. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- 2. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
- 3. Measure total preload torque using Tool. Refer to <u>DLN-334</u>. "Inspection and Adjustment".

Tool number : ST3127S000 (J-25765-A)

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque

• If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.



If the total preload torque is greater than specification

On drive pinion bearings: Replace collapsible spacer.
On side bearings: Loosen side bearing adjuster.

If the total preload torque is less than specification

On drive pinion bearings: Tighten drive pinion lock nut.
On side bearings: Tighten side bearing adjuster.


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between drive gear and drive pinion. Gears which are not positioned in proper arrangement may be noisy and/or have a short life. Check gear tooth contact pattern to obtain the best contact for low noise and long life.


- 1. Thoroughly clean drive gear and drive pinion teeth.
- 2. Apply red lead to the drive gear.


NOTE:

Apply red lead to both faces of three to four gears, at four locations evenly spaced on the drive gear.



3. Hold companion flange steady by hand and rotate drive gear in both directions.





 If outside the standard, adjust drive pinion height adjusting washer and backlash. Refer to <u>DLN-334</u>, <u>"Inspection and Adjustment"</u>, "Backlash".


Backlash


 Fit a dial indicator to the drive gear face to measure the backlash.

Backlash: 0.12 - 0.20 mm (0.0050 - 0.0078 in)

- 2. If the backlash is outside of the specification, adjust each side bearing side bearing adjuster.
- a. Remove adjuster lock plate.
- b. Loosen side bearing cap bolts.
- c. Tighten or loosen each side bearing adjusters using Tool.

Tool number : — (C - 4164)





If the backlash is greater than specification:


Loosen side bearing adjuster A and tighten side bearing adjuster B by the same amount.

If the backlash is less than specification:

Loosen side bearing adjuster B and tighten side bearing adjuster A by the same amount.

CAUTION:

Do not change the side bearing side bearing adjusters by different amounts as it will change the side bearing preload torque.



Α

В

C

DLN

Е

Н

J

K

L

M


. .

C

- d. Tighten side bearing cap bolts to the specified torque. Refer to DLN-319, "Disassembly and Assembly".
- e. Install adjuster lock plate and tighten to the specified torque. Refer to <u>DLN-319</u>, "<u>Disassembly and Assembly</u>".

CAUTION:

Check tooth contact and total preload torque after adjusting side bearing adjuster. Refer to "Tooth Contact" and "Total Preload Torque".



Companion Flange Runout

- Rotate companion flange and check for runout on the companion flange face (inner side of the bolt holes) and companion flange inner side (socket diameter) using suitable tool. Refer to <u>DLN-334</u>, "General Specification".
- 2. If the runout is outside the runout limit, follow the procedure below to adjust.
- Rotate the companion flange on the drive pinion by 90°, 180° and 270° while checking for the position where the runout is minimum.
- b. If the runout is still outside of the runout limit after the companion flange has been rotated on the drive pinion, possible cause could be an assembly malfunction of drive pinion and drive pinion bearing or a malfunctioning drive pinion bearing.
- c. If the runout is still outside of the runout limit after repair of the assembly of drive pinion and drive pinion bearing or drive pinion bearing, replace the companion flange.




Differential Assembly

- 1. Remove carrier cover bolts.
- 2. Remove carrier cover using Tool.


Tool number : KV10111100 (J-37228)


CAUTION:

- Do not damage the mating surface.
- Do not insert flat-bladed screwdriver, this will damage the mating surface.



Remove differential sensor connector bolts and differential lock solenoid connector.





REAR FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: M226 (ELD)]

For proper reinstallation, paint matching mark on one side of side bearing cap.

CAUTION:

- Side bearing caps are line-board for initial assembly. The matching marks are used to reinstall them in their original positions.
- For matching mark, use paint. Do not damage side bearing cap.
- Remove adjuster lock plates.






DLN

Α

В


Remove side bearing caps.




Н

Remove side bearing adjusters using Tool.

(C - 4164)**Tool number**



- 8. Keep side bearing outer races together with inner races. Do not mix them up. Also, keep side bearing adjusters together with bearing.
- 9. Remove side bearing adjusters from gear carrier.



- 10. Remove bracket of differential lock position switch connector and bolts.
- 11. Remove differential lock position switch.

Р

M

Ν


12. Remove side bearing inner race and washer using Tool.

Tool number : ST33081000 (—)

CAUTION:

Do not damage differential case assembly and differential lock solenoid.

13. Remove differential lock solenoid and solenoid washer.




14. Remove side bearing inner race using Tool.

Tool number : ST33081000 (—)

CAUTION:

Do not damage differential case assembly.




15. For proper reinstallation, paint matching mark on differential case and drive gear.

CAUTION:

Use paint for matching marks. Do not damage differential case or drive gear.

- 16. Remove drive gear bolts.
- 17. Tap the drive gear off the differential case using suitable tool. **CAUTION:**

Tap evenly all around to keep drive gear from binding.



Drive Pinion Assembly


- 1. Remove differential case assembly. Refer to "Differential Assembly".
- 2. Remove drive pinion lock nut and washer using Tool.

Tool number : KV40104000 (—)

3. Put matching marks on the companion flange and drive pinion using paint.

CAUTION:

Use paint to make the matching marks. Do not damage the companion flange or drive pinion.




REAR FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226 (ELD)]

4. Remove companion flange using a suitable tool.




Remove front oil seal using Tool.

Tool number : ST33290001 (J-34286)

CAUTION:

Do not damage gear carrier.

6. Remove drive pinion front bearing thrust washer.




7. Remove drive pinion assembly (with rear inner bearing race and collapsible spacer) out of gear carrier.

CAUTION:

Do not drop drive pinion assembly.

8. Remove drive pinion front bearing inner race from gear carrier.



9. Tap drive pinion front bearing outer race uniformly with a brass bar or equivalent to remove.


CAUTION:

Do not damage gear carrier.

10. Tap drive pinion rear bearing outer race uniformly with a brass bar or equivalent for removal.


CAUTION:

Do not damage gear carrier.



11. Remove drive pinion rear bearing inner race and drive pinion height adjusting washer using Tool.

Tool number : ST30021000 (J-22912-01)



Α

В

С

DLN

Е

Г

G

Н

|

M

Ν

0

INSPECTION AFTER DISASSEMBLY

Drive Pinion and Drive Gear

- If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new gears.
- Drive gear and drive pinion are supplied in matched sets only. Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each pinion gear and drive gear before proceeding with assembly.

Bearing

- If found any chipped (by friction), pitted, worn, rusted, scratched mark, or unusual noise from the bearing, replace with new bearing assembly (as a new set).
- Bearing must be replaced with a new one whenever disassembled.

Differential Case Assembly

- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new differential case assembly.
- If the movement is not smooth when pushing cam ring of differential case assembly with a hand.


Differential Lock Solenoid

• If the operating part of differential lock solenoid is not smooth, perform component inspection. Refer to <u>DLN-270</u>, "DIFFERENTIAL LOCK CONTROL UNIT: CONSULT-III Function (DIFF LOCK)".

SELECTION ADJUSTING WASHERS

Drive Pinion Height

Drive gear and drive pinion are supplied in matched sets only.
 Matching numbers on both drive pinion and drive gear are etched for verification. If a new gear set is being used, verify the numbers of each drive pinion and drive gear before proceeding with assembly.



- The mounting distance from the center line of drive gear to the back face of drive pinion for the Model 226 final drive assembly is 109.5 mm (4.312 in).
 - On the button end of each drive pinion, there is etched a plus (+) number, a minus (-) number, or a zero (0), which indicates the best running position for each particular gear set. This dimension is controlled by a selective drive pinion height adjusting washer between drive pinion inner bearing race and drive pinion.
 - For example: If a drive pinion is etched m+8 (+3), it would require 0.08 mm (0.003 in) less drive pinion height adjusting washer than a drive pinion etched "0". This means decreasing drive pinion height adjusting washer thickness; increases the mounting distance of drive pinion to 109.6 mm (4.315 in). If a drive pinion is etched m-8 (-3), it would require adding 0.08 mm (0.003 in) more to drive pinion height adjusting washer than would be required if drive pinion were etched "0". By adding 0.08 mm (0.003 in), the mounting distance of drive pinion was decreased to 109.4 mm (4.309 in) which is just what m-8 (a-3) etching indicated.
- To change drive pinion adjustment, use different drive pinion height adjusting washers which come in different thickness.
- Use the following tables as a guide for selecting the correct drive pinion height adjusting washer thickness to add or subtract from the old drive pinion height adjusting washer.

OLD DRIVE				NEW DRIVE	PINION MAR	KING mm (in)		
PINION MARKING	-10 (-4)	-8 (-3)	-5 (-2)	-3 (-1)	0 (0)	+3 (+1)	+5 (+2)	+8 (+3)	+10 (+4)
+10 (+4)	+0.20	+0.18	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0
	(+0.008)	(+0.007)	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)
+8 (+3)	+0.18	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02
	(+0.007)	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)

REAR FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226 (ELD)]


OLD DRIVE		NEW DRIVE PINION MARKING mm (in)							
PINION MARKING	-10 (-4)	-8 (-3)	-5 (-2)	-3 (-1)	0 (0)	+3 (+1)	+5 (+2)	+8 (+3)	+10 (+4)
+5 (+2)	+0.15	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05
	(+0.006)	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)
+3 (+1)	+0.13	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08
	(+0.005)	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)
0 (0)	+0.10	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10
	(+0.004)	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)
-3 (-1)	+0.08	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10	-0.13
	(+0.003)	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)
-5 (-2)	+0.05	+0.02	0	-0.02	-0.05	-0.08	-0.10	-0.13	-0.15
	(+0.002)	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)	(-0.006)
-8 (-3)	+0.02	0	-0.02	-0.05	-0.08	-0.10	-0.13	-0.15	-0.18
	(+0.001)	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)	(-0.006)	(-0.007)
-10 (-4)	0	-0.02	-0.05	-0.08	-0.10	-0.13	-0.15	-0.18	-0.20
	(0)	(-0.001)	(-0.002)	(-0.003)	(-0.004)	(-0.005)	(-0.006)	(-0.007)	(-0.008)

 Make sure all parts are clean and that drive pinion bearings are well lubricated.


2. Assemble drive pinion bearings into the tools.

Tool number A: — (8144)


B: — (6740) C: — (6741)



3. Install drive pinion bearing inner race and drive pinion height adjusting washer to gear carrier using tool as shown.



4. Turn the assembly several times to seat drive pinion bearings.



Α

В

C

DLN

Е

F

G

Н

ı

K

L

M

Ν

0

< DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: M226 (ELD)]

5. Measure the turning torque, using Tool.

Tool number : ST3127S000 (J-25765-A)

Turning torque specification:

1.2 - 2.8 N-m (0.13 - 0.28 kg-m, 11 - 24 in-lb)




6. Tighten side bearing caps to the specified torque installing tools as shown.

Tool number A: — (6739)


B: — (D-115-2)

C: — TBD

D: — (D-115-3)



- 7. Put scooter block on pinion height block. Make sure that dial indicator is level adjusting pressure with a hand. Dial indicator indicates "0".
- 8. Slide dial indicator along arbor. Record the maximum.
- 9. Adjust drive pinion height adjusting washer so that the maximum will be "0".



ASSEMBLY

Drive Pinion Assembly


1. Press a drive pinion rear bearing outer race into gear carrier using Tool.

Tool number A: ST01500001 (—)

B: ST30022000 (—)

CAUTION:

Do not reuse drive pinion rear bearing.



REAR FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226 (ELD)]


Press a drive pinion front bearing outer race into gear carrier using Tool.

Tool number : ST33022000 (—)

CAUTION:

Do not reuse drive pinion front bearing.

Select drive pinion height adjusting washer. Refer to "Drive Pinion Height".



Préss

Tool

4. Press a drive pinion rear bearing inner race and drive pinion height adjusting washer to drive pinion, using Tool.

Tool number : — (C - 4040)

CAUTION:


Do not reuse drive pinion rear bearing.

- 5. Apply gear oil to drive pinon rear bearing and drive pinon front bearing.
- 6. Install drive pinion front bearing inner race in gear carrier.
- 7. Install drive pinion front bearing thrust washer to gear carrier.
- 8. Apply multi-purpose grease to front oil seal lip. Install front oil seal into gear carrier using Tool.

Tool number : ST15310000 (—)

CAUTION:


- Do not reuse front oil seal.
- Do not incline the new front oil seal when installing.
- Apply multi-purpose grease to the lips of the new front oil seal.



Install collapsible spacer to drive pinion. And then install drive pinion assembly in gear carrier.

CAUTION:

- Do not reuse collapsible spacer.
- · Do not damage front oil seal.



10. Install the companion flange to the drive pinion while aligning the matching marks.

Α

В

С

DLN

Е

Drive pinion height

adjusting washer

F

G

Н

ı

K

L


M

Ν

11. Install the companion flange onto the drive pinion while aligning the matching marks. Then tap the companion flange using suitable tool.

CAUTION:

Do not damage companion flange or front oil seal.



12. Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut and new drive pinion lock nut washer. Then adjust the drive pinion lock nut tightening torque using Tool A, and check the drive pinion bearing preload torque using Tool B. Refer to <u>DLN-334</u>, "General Specification".

Tool number A: KV40104000 (—)


B: ST3127S000 (J-25765-A)


CAUTION:

- Do not reuse drive pinion lock nut or drive pinion lock nut washer.
- Apply anti-corrosive oil to the threads of the drive pinion and the seating surface of the new drive pinion lock nut.
- Adjust the drive pinion lock nut tightening torque to the lower limit first. Do not exceed the drive pinion lock nut specified torque. Refer to "COMPONENTS".
- If the drive pinion bearing preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Do not loosen drive pinion lock nut to adjust the drive pinion bearing preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

Differential Assembly

1. Align the matching mark of differential case assembly with the mark of drive gear, then install drive gear.






REAR FINAL DRIVE

< DISASSEMBLY AND ASSEMBLY >

- [REAR FINAL DRIVE: M226 (ELD)] Apply thread locking sealant into the threaded holes of the drive
- gear and install the bolts. • Use Genuine Medium Strength Thread Locking Sealant or
 - equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

CAUTION:


Make sure the drive gear back and threaded holes are clean.



Install new drive gear bolts, and then tighten to the specified torque. Refer to "COMPONENTS".

CAUTION:

- · Do not reuse the bolts.
- Tighten bolts in a crisscross fashion.




Press side bearing inner races to differential case assembly using Tool.

> **Tool number** : ST33081000 (—)

CAUTION:


Do not reuse side bearing.



- Install differential lock solenoid and washer.
- 6. Press side bearing inner races to differential case assembly using Tool.

Tool number A: KV38100300 (J-25523)

B: ST33081000 (—)



- 7. Apply sealant to threads of differential lock position switch.
 - Use Genuine Silicone RTV or equivalent. Refer to GI-26, "Recommended Chemical Products and Sealants".

CAUTION:

Remove old sealant adhering to gear carrier and differential lock position switch. Also remove any moisture, oil, or foreign material adhering to application and gear carrier and differential lock position switch.

В

Α

DLN


F

Н


M

Ν

 Install differential lock position switch on gear carrier and tighten differential lock position switch bolts with the specified torque. Refer to "COMPONENTS".




9. Install side bearing adjusters into gear carrier.




- 10. Apply gear oil to side bearings. Install differential case assembly with side bearing outer races into gear carrier.
- Apply multi-purpose grease to sensor connector. CAUTION:

Do not reuse sensor connector.




12. Connect differential lock solenoid harness and sensor connector. Then install it to gear carrier, tighten to the specified torque. Refer to "COMPONENTS".



13. Align paint matching mark on side bearing caps with that on gear carrier and install side bearing caps on gear carrier.

CAUTION:

Do not tighten at this point. This allows further tightening of side bearing adjusters.



REAR FINAL DRIVE


< DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: M226 (ELD)]

14. Tighten each side bearing adjusters using adjuster tool.

Tool number : — (C - 4164)

- 15. Adjusting backlash of drive gear and drive pinion. Refer to "Backlash".
- 16. Check total preload. Refer to "Total Preload Torque".
- 17. Check tooth contact. Refer to "Tooth Contact".




18. Apply a bead of sealant to the mating surface of the carrier cover as shown.

• Use Genuine Silicone RTV or equivalent. Refer to <u>GI-26</u>, <u>"Recommended Chemical Products and Sealants"</u>.

CAUTION:

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

19. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque. Refer to DLN-319, "Disassembly and <a href="Assembly".



Α

В

C

DLN

Е

F

G

Н

K

L

M

Ν

0

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000003304390

[REAR FINAL DRIVE: M226 (ELD)]

	VQ40DE			
Applied model	2WD	/D		
	5A/T		6M/T	
Final drive model		M226		
Gear ratio	3.133	3.357	3.692	
Number of pinion gears	2			
Number of teeth (Drive gear / drive pinion)	47/15	47/14	48/13	
Oil capacity (Approx.) ℓ (US pt, Imp pt)	2.01 (4-1/4, 3-1/2)			
Drive pinion adjustment spacer type		Collapsible		

Inspection and Adjustment

INFOID:0000000003226171

PRELOAD TORQUE

Unit: N·m (kg-m, in-lb)

Item	Specification
Drive pinion bearing preload torque	1.7 - 3.1 (0.18 - 0.31, 15 - 27)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.38 - 4.46 (0.25 - 0.45, 21 - 39)

BACKLASH

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.12 - 0.20 (0.0050 - 0.0078)

COMPANION FLANGE RUNOUT

Unit: mm (in)

Item	Limit
Companion flange face	0.13 (0.0051) or less
Companion flange inner side	

SELECTIVE PARTS

Drive Pinion Height Adjusting Washer

Unit: mm (in)

Thickness	Package part number*
0.076 (0.030) 0.079 (0.031) 0.081 (0.032) 0.084 (0.033) 0.086 (0.034)	38151 8S101
0.089 (0.035) 0.091 (0.036) 0.094 (0.037) 0.097 (0.038) 0.099 (0.039)	38151 8S102

SERVICE DATA AND SPECIFICATIONS (SDS)

Α

В

С

DLN

Е

F

G

Н

Κ

L

M

Ν

0

Р

< SERVICE DATA AND SPECIFICATIONS (SDS)	[REAR FINAL DRIVE: M226 (ELD)]
Thickness	Package part number*
0.102 (0.040) 0.104 (0.041) 0.107 (0.042) 0.109 (0.043) 0.112 (0.044)	38151 8S103
0.114 (0.045) 0.117 (0.046) 0.119 (0.047) 0.122 (0.048) 0.124 (0.049)	38151 8S104
0.127 (0.050) 0.130 (0.051) 0.132 (0.052) 0.135 (0.053) 0.137 (0.054)	38151 8S105

^{*}Always check with the Parts Department for the latest parts information.

DLN-335