SECTION WHEELS & TIRES

А

В

С

D

WΤ

CONTENTS

BASIC INSPECTION3
DIAGNOSIS AND REPAIR WORKFLOW
INSPECTION AND ADJUSTMENT5
TRANSMITTER WAKE UP OPERATION
ID REGISTRATION PROCEDURE
FUNCTION DIAGNOSIS7
TPMS 7System Diagram7System Description7Component Parts Location9Component Description9
DIAGNOSIS SYSTEM (BCM)10
COMMON ITEM
AIR PRESSURE MONITOR
COMPONENT DIAGNOSIS15
C1704, C1705, C1706, C1707 LOW TIRE PRESSURE15 Description

DTC Logic1 Diagnosis Procedure1	5 F
C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)1 Description1 DTC Logic1 Diagnosis Procedure1 Special Repair Requirement1	7 7 7 7 H 8
C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)	20
Description	20 20 J 20 22
C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)	K 23
Description	23 23 ∟ 23 24 24
C1720, C1721, C1722, C1723 TRANSMITTER (CODE)	25
Description	25 N 25 25 27 O
C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)	28
Description	28 P 28 28 30
C1729 VEHICLE SPEED SIG ERR	81 81

DTC Logic	
C1734 CONTROL UNIT 32	
Description	
DTC Logic	
Special Repair Requirement	
POWER SUPPLY AND GROUND CIRCUIT 34	
BCM (BODY CONTROL MODULE)	
Procedure	
BCM (BODY CONTROL MODULE) : Special Repair Requirement	
UNIFIED METER AND A/C AMP. : Description 34 UNIFIED METER AND A/C AMP. : Diagnosis Pro-	
cedure	
TPMS	
Description	
WIRING DIAGRAM - TIRE PRESSURE MONITOR- ING SYSTEM - 38	
IRE PRESSURE RECEIVER	
Diagnosis Procedure	
TIRE PRESSURE WARNING CHECK	
SWITCH	
Diagnosis Procedure	
ECU DIAGNOSIS 45	
BCM (BODY CONTROL MODULE)	
Reference Value	
Wiring Diagram - BCM 68	
Fail Safe	
DTC Index	
SYMPTOM DIAGNOSIS	
TPMS	
Symptom Table	
LOW TIRE PRESSURE WARNING LAMP	
Description	
Diagnosis Procedure	
I OW TIRE PRESSURE WARNING I AMP	
STAYS ON	

31 31	Description82 Diagnosis Procedure82
31	LOW TIRE PRESSURE WARNING LAMP
32	BLINKS 84
32	Description
32	Diagnosis Procedure
32	g
33	TURN SIGNAL LAMP BLINKS 86
00	Description 86
34	Diagnosis Procedure 86
• •	
34	ID REGISTRATION CANNOT BE COMPLET-
	ED 87
34	Description 07
•	Description
31	Diagnosis Procedure87
34	
34	
3/	Description88
04	NOISE VIBRATION AND HARSHNESS
25	
35	
37	NVH Troubleshooting Chart
97	
51	PRECAUTION
20	
38	PRECAUTIONS
12	Service Notice or Precautions
42 40	
42 10	
42	PREPARATION 91
	Special Service Tools 01
	Commercial Service Tools
44	
44	ON-VEHICLE MAINTENANCE
44	
45	ROAD WHEEL
43	Inspection 92
45	
15	ON-VEHICLE REPAIR
-0 68	
00 72	ROAD WHEEL TIRE ASSEMBLY
73	Adiustment93
75 77	,
//	REMOVAL AND INSTALLATION
79	
13	IRANSMITTER96
79	Exploded View96
70	Removal and Installation96
13	
	SERVICE DATA AND SPECIFICATIONS
81	(SDS)
81	
91 81	SERVICE DATA AND SPECIFICATIONS
01	(SDS)
	Road Wheel
02	Tire 98
σz	

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >	
BASIC INSPECTION	Δ
DIAGNOSIS AND REPAIR WORKFLOW	A
Repair Work Flow	В
DETAILED FLOW	
1.VERIFY COSTOMER COMPLAINTS	С
Interview the customer to obtain detailed information about the symptom.	D
>> GO TO 2	D
2. DETERMINE REFERENCE ITEM RELATED TO SYMPTOM	wт
Check the symptom on the vehicle from the information obtained.	VVI
(cruise test, warning lamp illumination or blinking, etc.)	_
YES >> GO TO 3	Γ
NO >> GO TO 4.	
3. PRELIMINARY INSPECTION	G
 Perform basic inspection. Check all tire pressures. Refer to <u>WT-98, "Tire"</u>. Check the low tire pressure warning lamp for illumination or blinking. Refer to <u>WT-79, "Symptom Table"</u>. 	Н
Is the malfunction corrected?	
YES >> INSPECTION END NO >> GO TO 4.	I
4.PERFORM SELF-DIAGNOSIS	
 Perform self-diagnosis. Record any DTCs and data displayed on CONSULT-III. Perform inspection according to the displayed DTC. Refer to WT-77, "DTC Index". 	J
Is the causal factor identified from DTC?	
YES >> GO TO 6. NO >> GO TO 5.	Κ
5. снеск зумртом	
Perform troubleshooting by symptom. Refer to WT-79, "Symptom Table".	L
Is the causal factor identified?	
YES >> GO TO 6. NO >> GO TO 4.	M
6. REPAIR OR REPLACE MULFUNCTIONING PARTS	
Repair or replace the applicable part.	Ν
>> GO TO 7. 7 CHECK SELE DIACNOSIS DESULT	0
Frase DTCs: Refer to WT-11 "AIR PRESSURE MONITOR : Diagnosis Description"	
2. Perform self-diagnosis again.	Ρ
Is any DTC displayed?	
YES >> GO TO 4. NO >> GO TO 8.	
8. FINAL CHECK	

1. Perform a cruise test.

2. Check the warning lamp for illumination or blinking.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Is the malfunction corrected?

YES >> INSPECTION END NO >> GO TO 4.

INSPECTION AND ADJUSTMENT < BASIC INSPECTION > INSPECTION AND ADJUSTMENT А TRANSMITTER WAKE UP OPERATION TRANSMITTER WAKE UP OPERATION : Description INFOID:000000001686944 В This procedure must be done after replacement of a transmitter, BCM, or rotating wheels. TRANSMITTER WAKE UP OPERATION : Special Repair Requirement INFOID:000000001686945 **1.**TRANSMITTER WAKE UP OPERATION 1. With the activation tool (J-45295) pushed against the front-left D transmitter, press and hold the button 5 seconds. WΤ F SEIA0460E When ignition switch ON, as the low tire pressure warning lamp blinks per the follow diagram, the respec-2. tive transmitter then must be woken up. Н Low tire pressure warning lamp blinking timing Activation tire position ON a : 0.3 sec. а Front LH b b:1.3 sec. OFF ON а a : 0.3 sec. a

	b : 1.3 sec.	Front RH	J
ON a a a b	a : 0.3 sec. b : 1.3 sec.	Rear RH	
ON a a a a a b	a : 0.3 sec. b : 1.3 sec.	Rear LH	K
ON a b	a : 2 sec. b : 0.2 sec.	All tires	L

- Register the ID of wheel that low tire pressure warning lamp blinks. When wake up of registered wheel has been completed, turn signal lamp blinks two times.
- 4. After completing wake up all transmitters, check that the low tire pressure warning lamp goes out.

		Ν
>> Perform ID registration procedure. Refer to <u>WT-5, "ID REGISTRATION PROCED</u> <u>Repair Requirement"</u> . ID REGISTRATION PROCEDURE	OURE : Special	0
ID REGISTRATION PROCEDURE : Description	INFOID:000000001686946	D
This procedure must be done after replacing or rotating wheels, replacing transmitter or BCM. ID REGISTRATION PROCEDURE : Special Repair Requirement	INFOID:000000001686947	Г
1.ID REGISTRATION PREPARATION		
1. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen, and select "ID REGIST". Is the transmitter activation tool used for ID registration?		

Μ

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

YES >> GO TO 2. NO >> GO TO 3.

2. ID REGISTRATION (WITH TRANSMITTER ACTIVATION TOOL)

1. With the transmitter activation tool (J-45295) pushed against the front-left transmitter position of the air valve, press and hold the button for 5 seconds.

 Register the IDs in order from FR LH, FR RH, RR RH, to RR LH. When ID registration of each wheel has been completed, turn signal lamp blinks.

	Activation tire position	Turn signal lamp	CONSULT-III
1	Front LH		
2	Front RH	2 times blinks	"Red"
3	Rear RH		"Green"
4	Rear LH		

3. After completing all ID registrations, press "END" to complete the procedure.

NOTE:

Be sure to register the IDs in order from FR LH, FR RH, RR RH, to RR LH, or the self-diagnostic results display will not function properly.

Can ID registration of all transmitters be completed?

YES >> ID registration END

NO >> Inspect the tire pressure monitoring system. Refer to WT-17, "Diagnosis Procedure".

3. ID REGISTRATION (WITHOUT TRANSMITTER ACTIVATION TOOL)

- Adjust the tire pressure to the values shown in the table below for ID registration, and drive the vehicle at 40 km/h (25 MPH) or more for several minutes.
 NOTE:
 - NOTE:

If ID registration is unable, buzzer beeps.

Tire position	Tire pressure kPa (kg/cm ² , psi)
Front LH	240 (2.4, 34)
Front RH	220 (2.2, 31)
Rear RH	200 (2.0, 29)
Rear LH	180 (1.8, 26)

2. After completing all ID registrations, press "END" to complete procedure.

Activation tire position	CONSULT-III
Front LH	
Front RH	"Red"
Rear RH	"Green"
Rear LH	

3. Inflate all tires to proper pressure. Refer to WT-98, "Tire".

Can ID registration of all transmitters be completed?

YES >> ID registration END

NO >> Inspect the tire pressure monitoring system. Refer to WT-17, "Diagnosis Procedure".

< FUNCTION DIAGNOSIS > FUNCTION DIAGNOSIS TPMS

System Diagram



System Description

INFOID:000000001686949

INFOID:000000001686948

А

В

DISCRIPTION

During driving, the TPMS (Tire Pressure Monitoring System) receives the signal transmitted from transmitter installed in each wheel, when the tire pressure becomes low. The BCM (Body Control Module) of this system has pressure judgment and trouble diagnosis functions. When the tire pressure monitoring system detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

TRANSMITTER

A sensor-transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.



TIRE PRESSURE RECEIVER

The tire pressure receiver (1) receives the air pressure signal transmitted by the transmitter in each wheel.



BCM (BODY CONTROL MODULE)

< FUNCTION DIAGNOSIS >

The BCM (1) reads the air pressure signal received by the tire pressure receiver, and controls the low tire pressure warning lamp and the buzzer operations. It also has a judgment function to detect a system malfunction.



LOW TIRE PRESSURE WARNING LAMP

The unified meter and A/C amp receives tire pressure status from the BCM using CAN communication. When BCM judges from a transmitter signal that tire pressure is insufficient, BCM transmits a signal to unified meter and A/C amp through CAN communication. unified meter and A/C amp turns on the low tire pressure warning lamp mounted on the Combination meter.



Low tire pressure warning lamp indication

Condition	Low tire pressure warning lamp
Less than 182.7 kPa (1.9 kg/cm ² , 26 psi) [NOTE1]	ON
Less than 189.6 kPa (1.9 kg/cm ² , 27 psi) [NOTE2]	Civ.
Low tire pressure warning system malfunction [Other diagnostic item]	Warning lamp blinks 1 min, then turns ON.

NOTE1: Standard air pressure is for 230 kPa (2.3 kg/cm², 33 psi) vehicles.

NOTE2: Standard air pressure is for 240 kPa (2.4 kg/cm², 35 psi) vehicles.

TIRE PRESSURE WARNING CHECK SWITCH

The following item can be checked by grounding the tire pressure warning check switch (1) harness connector terminal.

• The low tire pressure warning lamp in the combination meter will blinks according to the self-diagnostic results.



< FUNCTION DIAGNOSIS >

Component Parts Location

А

В

С

D

WT

F

Н

J

Κ

INFOID:000000001686951



Component Description

1.

4.

Α.

D.

Component parts	Function	L
BCM (Body Control Module)	WT-32, "Description".	
Transmitter	WT-17, "Description".	N
Tire pressure receiver	WT-42, "Description".	
Tire pressure warning check switch	WT-44, "Description".	
Turn signal lamp	ID registration of each wheel has been completed, turn signal lamp flashes.	Ν
Combination meter	Controls a low tire pressure warning lamp, turn signal lamp, and buzzer by signals from the unified meter and A/C amp.	
Low tire pressure warning lamp	Illuminates if malfunction is detected in electrical system of TPMS.	С
Unified meter and A/C amp.	Transmits the vehicle speed signal via CAN communication to BCM. Receives the tire pressure signal via CAN communication to BCM.	

DIAGNOSIS SYSTEM (BCM) COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000001903111

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III opera- tion manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	This function is not used even though it is displayed.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
System		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
Air conditioner*	AIR CONDITONER		×	
Intelligent Key system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
BCM	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD) AND IGN COUNTER

Freeze Frame Data

The BCM records the following condition at the moment a particular DTC is detected.

- Vehicle Speed
- Odd Trip Meter

< FUNCTION DIAGNOSIS >

Vehicle Condition (BCM detected condition)

CONSULT screen terms	Description	
SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")	
SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)	
LOCK>ACC	While turning power supply position from "LOCK" to "ACC"	
ACC>ON	While turning power supply position from "ACC" to "IGN"	
RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)	
CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the en- gine to run it)	
RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)	
ACC>OFF	While turning power supply position from "ACC" to "OFF"	
OFF>LOCK	While turning power supply position from "OFF" to "LOCK"	
OFF>ACC	While turning power supply position from "OFF" to "ACC"	
ON>CRANK	While turning power supply position from "IGN" to "CRANKING"	
OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode	
LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low pow- er consumption mode	
LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)	
OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)	
ACC	Power supply position is "ACC" (Ignition switch ACC)	
ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)	
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)	
CRANKING	Power supply position is "CRANKING" (At engine cranking)	

IGN Counter

IGN counter indicates the number of times that ignition switch is turned ON after DTC is detected.

• The number is 0 when a malfunction is detected now.

• The number increases like 1 \rightarrow 2 \rightarrow 3...38 \rightarrow 39 after returning to the normal condition whenever ignition switch OFF \rightarrow ON.

• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR : Diagnosis Description

DESCRIPTION

During driving, the TPMS receives the signal transmitted from the transmitter installed in each wheel, when the tire pressure becomes low. The control unit (BCM) of this system has pressure judgment and trouble diagnosis functions.

When the TPMS detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

SELF DIAGNOSTIC PROCEDURE (WITH CONSULT-III)

(I) With CONSULT-III

Touch "SELF-DIAG RESULT" display shows malfunction experienced since the last erasing operation. Refer to <u>WT-77, "DTC Index"</u>.

SELF DIAGNOSTIC PROCEDURE (WITHOUT CONSULT-III)

Without CONSULT-III

To start the self-diagnostic results mode, ground terminal of the tire pressure warning check connector. The malfunction location is indicated by the low tire pressure warning lamp blinking.

WT-11

Κ

L

Μ

Ρ

INFOID:000000001686953

< FUNCTION DIAGNOSIS >



NOTE:

When the low tire pressure warning lamp blinks 5 Hz and continues repeating it, the system is normal.

Blinking pattern	Items Diagnostic items detected when		Check item
15	Tire pressure value (Front LH)	Front LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	
16	Tire pressure value (Front RH)	Front RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	+
17	Tire pressure value (Rear RH)	Rear RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	_
18	Tire pressure value (Rear LH)	ar LH) Rear LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	
21	Transmitter no data (Front LH)	Data from front LH transmitter can not be receive.	
22	Transmitter no data (Front RH)	Data from front RH transmitter can not be receive.	
23	Transmitter no data (Rear RH)	Data from Rear RH transmitter can not be receive.	<u>VVI-17</u>
24	Transmitter no data (Rear LH)	Data from Rear LH transmitter can not be receive.	+
31	Transmitter checksum error (Front LH)	Checksum data from front LH transmitter is malfunctioning.	
32	Transmitter checksum error (Front RH)	Checksum data from front RH transmitter is malfunctioning.	WT 00
33	Transmitter checksum error (Rear RH)	Checksum data from rear RH transmitter is malfunctioning.	<u>vv1-20</u>
34	Transmitter checksum error (Rear LH)	Checksum data from rear RH transmitter is malfunctioning.	+
35	Transmitter pressure data error (Front LH)	Air pressure data from front LH transmitter is malfunction.	
36	Transmitter pressure data error (Front RH)	Air pressure data from front RH transmitter is malfunction.	WT 00
37	Transmitter pressure data error (Rear RH)	Air pressure data from rear RH transmitter is malfunction.	<u>vv1-23</u>
38	Transmitter pressure data error (Rear LH)	Air pressure data from rear LH transmitter is malfunction.	+
41	Transmitter function code error (Front LH)	Function code data from front LH transmitter is malfunction.	
42	Transmitter function code error (Front RH)	Function code data from front RH transmitter is malfunction.	WT OF
43	Transmitter function code error (Rear RH)	Function code data from rear RH transmitter is malfunction.	<u>vv1-25</u>
44	Transmitter function code error (Rear LH)	Function code data from rear LH transmitter is malfunction.	1

< FUNCTION DIAGNOSIS >

Items	Diagnostic items detected when	Check item	А
Transmitter battery voltage low (Front LH)	Battery voltage of front LH transmitter drops.		
Transmitter battery voltage low (Front RH)	Battery voltage of front RH transmitter drops.	W/T-28	В
Transmitter battery voltage low (Rear RH)	Battery voltage of rear RH transmitter drops.	<u>W1-20</u>	С
Transmitter battery voltage low (Rear LH)	Battery voltage of rear LH transmitter drops.		
Vehicle speed signal error	Speed signal is not detected.	<u>WT-31</u>	D
BCM failure about TPMS	Tire pressure monitoring system malfunction in BCM	<u>WT-32</u>	
Tire pressure warning check switch	Tire pressure warning switch circuit is open.	-	WT
	Items Transmitter battery voltage low (Front LH) Transmitter battery voltage low (Front RH) Transmitter battery voltage low (Rear RH) Transmitter battery voltage low (Rear LH) Vehicle speed signal error BCM failure about TPMS Tire pressure warning check switch	ItemsDiagnostic items detected whenTransmitter battery voltage low (Front LH)Battery voltage of front LH transmitter drops.Transmitter battery voltage low (Front RH)Battery voltage of front RH transmitter drops.Transmitter battery voltage low (Rear RH)Battery voltage of rear RH transmitter drops.Transmitter battery voltage low (Rear LH)Battery voltage of rear LH transmitter drops.Vehicle speed signal errorSpeed signal is not detected.BCM failure about TPMSTire pressure monitoring system malfunction in BCMTire pressure warning check switchTire pressure warning switch circuit is open.	ItemsDiagnostic items detected whenCheck itemTransmitter battery voltage low (Front LH)Battery voltage of front LH transmitter drops.Transmitter battery voltage low (Front RH)Battery voltage of front RH transmitter drops.Transmitter battery voltage low (Rear RH)Battery voltage of rear RH transmitter drops.Transmitter battery voltage low (Rear LH)Battery voltage of rear LH transmitter drops.WT-28Vehicle speed signal errorSpeed signal is not detected.WT-31BCM failure about TPMSTire pressure monitoring system malfunction in BCMWT-32Tire pressure warning check switchTire pressure warning switch circuit is open

NOTE:

• 182.7 kPa (1.9 kg/cm², 26 psi): Standard air pressure is for 230 kPa (2.3 kg/cm²,33 psi) vehicles.

• 189.6 kPa (1.9 kg/cm², 27 psi): Standard air pressure is for 240 kPa (2.4 kg/cm², 35 psi) vehicles.

ERASE SELF-DIAGNOSIS

(D)With CONSULT-III

- 1. Perform applicable inspection of malfunctioning item and then repair or replace.
- 2. Turn ignition switch "ON" and select "SELF-DIĂG RESULTS" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
- 3. Touch "ERASE" on CONSULT-III screen to erase memory.

Without CONSULT-III

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned "ON" and "OFF".
- However, this information is erased by turning ignition switch "OFF" after performing self-diagnostic or by erasing the memory using the CONSULT-III.

AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONI-TOR)

F

Κ

< FUNCTION DIAGNOSIS >

Display item list		
Monitor	Condition	Specification
AIR PRESS FL AIR PRESS FR AIR PRESS RR AIR PRESS RL	 Drive vehicle for a few minutes. or Ignition switch ON and activation tool is transmitting activation signals. 	Tire pressure (kPa or Psi)
ID REGST FL ID REGST FR ID REGST RR ID REGST RL	Ignition switch ON	Registration ID : Green No registration : Red
WARNING LAMP		Low tire pressure warning lamp on: ON Low tire pressure warning lamp off: OFF
BUZZER		Buzzer in combination meter on: ON Buzzer in combination meter off: OFF

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction location may be different from that displayed on CONSULT-III.

ACTIVE TEST MODE

NOTE:

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction may be different from that displayed on CONSULT-III.

TEST ITEM LIST

Test item	Content
WARNING LAMP	This test is able to check to check that the low tire pressure warning lamp turns on.
ID REGIST WARNING	This test is able to check to check that the buzzer sounds or the low tire pressure warning lamp turns on.
RUN FLAT/T WARN BUZZER	This test is able to check to check that the buzzer sounds.
FLASHER	This test is able to check to check that each turn signal lamp turns on.
HORN	This test is able to check to check that the horn sounds.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

Description

When the tire pressure monitoring system detects low inflation pressure, the low tire pressure warning lamps in the combination meter comes on.

DTC Logic

INFOID:000000001686956

INFOID:000000001686955

А

В

D

Н

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible cause	WT
C1704	LOW PRESSURE FL	Front LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]		
C1705	LOW PRESSURE FR	Front RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	Tiro prossuro is low	_
C1706	LOW PRESSURE RR	Rear RH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	The pressure is low	F
C1707	LOW PRESSURE RL	Rear LH tire pressure drops to * kPa (* kg/cm ² , * psi) or less. [NOTE]	1	

NOTE:

• 182.7 kPa (1.9 kg/cm², 26 psi): Standard air pressure is for 230 kPa (2.3 kg/cm², 33 psi) vehicles.

• 189.6 kPa (1.9 kg/cm², 27 psi): Standard air pressure is for 240 kPa (2.4 kg/cm², 35 psi) vehicles.

DTC CONFIRMATION PROCEDURE

1.CHECK ID REGISTRATION AND VEHICLE DRIVING

(With CONSULT-III

Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value	
AIR PRESS FL			1
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle	ſ
AIR PRESS RR	several minutes.	information display.	
AIR PRESS RL	1		

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to <u>WT-15, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:000000001686957

Μ

Ν

Ρ

1.ADJUST TIRE AIR PRESSURE

1. Adjust all tire air pressures. Refer to WT-98, "Tire".

2. Check all tire air pressures.
Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or replace the tire or wheels and adjust the tire pressure to the specification.

2.CHECK AIR PRESSURE SIGNAL

Drive at a speed of 40 km/h (25 MPH) or more 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< COMPONENT DIAGNOSIS >

Monitored item	Condition	Display value
AIR PRESS FL		
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for several minutes.	Approximately equal to the indication on vehicle information display.
AIR PRESS RR		
AIR PRESS RL	*	

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Inspect or replace the tire or wheels. Refer to <u>WT-90, "Service Notice or Precautions"</u>.

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< COMPONENT DIAGNOSIS >

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

Description

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

DTC Logic

INFOID:000000001686959

INFOID:000000001686958

А

Н

L

M

Ν

INFOID:000000001686960

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible cause	D
C1708	[NO DATA] FL	Data from front-LH transmitter can not receive.	Harpess or connector	
C1709	[NO DATA] FR	Data from front-RH transmitter can not receive.	(Tire pressure receiver, BCM)	WT
C1710	[NO DATA] RR	Data from rear-RH transmitter can not receive.	ID registration is not finished Transmitter malfunction	
C1711	[NO DATA] RL	Data from rear-LH transmitter can not receive.		F

DTC CONFIRMATION PROCEDURE

1.CHECK ID REGISTRATION AND VEHICLE DRIVING

With CONSULT-III

- 1. Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value	
AIR PRESS FL			
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle	
AIR PRESS RR	several minutes.	information display.	
AIR PRESS RL			

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON? K

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to <u>WT-17, "Diagnosis Procedure"</u>.

Diagnosis Procedure

1.CHECK AIR PRESSURE SIGNAL

With CONSULT-III

- 1. Start engine
- 2. Select "ĎATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
- 3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", "AIR PRESS RL".

Monitored item	Condition	Display value	
AIR PRESS FL			0
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for several	Approximately equal to the indication on	
AIR PRESS RR	minutes.	vehicle information display.	Ρ
AIR PRESS RL			

Are all tire pressures displayed 0 kPa?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn ignition switch "OFF".

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< COMPONENT DIAGNOSIS >

- 2. Disconnect BCM harness connector and tire pressure receiver harness connector.
- 3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

B	СМ	Tire pressu	ure receiver	Continuity
Connector	Terminal	Connector	Terminal	Continuity
M123 13 13	137	M101	1	
	138		4	Existed
	139		2	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to WT-42, "Diagnosis Procedure".

Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damage parts.
- NO >> Replace the tire pressure receiver.

4.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair</u> Requirement".

Can ID registration of all transmitters be completed?

YES >> GO TO 5.

NO >> Replace malfunctioning transmitter, then GO TO 6.

5.CHECK TIRE PRESSURE MONITORING SYSTEM

With CONSULT-III

- 1. Drive at a speed 40 km/h (25 MPH) or more for several minutes without stopping.
- 2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END
- NO >> Replace BCM. Refer to <u>BCS-79</u>, "Removal and Installation".

6.CHECK ID REGISTRATION

(B) With CONSULT-III

- 1. Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Perform the self-diagnosis, inspect detected malfunction.

Special Repair Requirement

INFOID:000000001686961

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to WT-98, "Tire".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< COMPONENT DIAGNOSIS >

Perform ID registration. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"</u>. Can ID registration of all transmitters be completed?

YES >> END NO >> GO TO 1.

F

G

Н

J

Κ

L

Μ

Ν

Ο

Ρ

А

В

С

D

C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

< COMPONENT DIAGNOSIS >

C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

Description

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

DTC Logic

INFOID:000000001686963

INFOID:000000001686962

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible case
C1712	[CHECKSUM ERR] FL	Checksum data from front-LH transmitter is malfunction.	• Tire pressure receiver malfunc-
C1713	[CHECKSUM ERR] FR	Checksum data from front-RH transmitter is malfunction.	tion
C1714	[CHECKSUM ERR] RR	Checksum data from rear-RH transmitter is malfunction.	Transmitter malfunction RCM malfunction
C1715	[CHECKSUM ERR] RL	Checksum data from rear-LH transmitter is malfunction.	

DTC CONFIRMATION PROCEDURE

1.VEHICLE DRIVING

With CONSULT-III

- 1. Driving at a speed 40 km/h (25 MPH) or more for 3 minutes, and then driving the vehicle at any speed for 10 minutes.
- 2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value
AIR PRESS FL		
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle
AIR PRESS RR	several minutes.	information display.
AIR PRESS RL		

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to <u>WT-20, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:000000001686964

1.CHECK ID REGISTRATION

With CONSULT-III

- 1. Perform the ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6. NO >> GO TO 2.

- **2.**CHECK AIR PRESSURE SIGNAL
- (I) With CONSULT-III
- 1. Start engine.
- 2. Select "ĎATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
- 3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

< COMPONENT DIAGNOSIS >

Monitored item	C	Condition		lay value
AIR PRESS FL				
AIR PRESS FR	Start engine and drive at	40 km/h (25 MPH) or more for	ore for Approximately equal to the indication on information display	
AIR PRESS RR	several minutes.			
AIR PRESS RL				
Are all tire pressures o	lisplayed 0 kPa?			
YES >> GO TO 3.				
3 CHECK HADNESS				
 Turn ignition switc Disconnect BCM I Check continuity b 	n OFF : narness connector and between BCM harness	d tire pressure receiver has connector and tire press	arness connector. sure receiver harne	ess connector.
BC	M	Tire pressure r	eceiver	
Connector	Terminal	Connector	Terminal	Continuity
	137		1	
M123	138	M101	4	Existed
-	139		2	
Also check harnes	ss for short to ground	and short to power.		
<u>s the inspection result</u> YES >> Check BC are damag NO >> Replace th D.CHECK ID REDGIS Perform ID registration <u>Requirement</u> ". Can ID registration of a	<u>t normal?</u> M pin terminals for d ged, repair or replace ne tire pressure receiv STRATION of all transmitters. Re all transmitters be con	amage or loose connect damaged parts. rer. efer to <u>WT-5, "ID REGIST</u> npleted?	ion with harness c	onnector. If any items
YES >> GO TO 6.	after malfunctioning tr	ansmitter replacement		
6 .CHECK TIRE PRE	SSURE MONITORIN	G SYSTEM		
 With CONSULT-III Drive at a speed of Check all tire prebecomes 17 km/h Does "DATA MONITO YES >> INSPECT 	of 40 km/h (25 MPH) o essure with CONSUL (11 MPH). R" displayed the stand ION END	r more for several minute T-III "DATA MONITOR"	es without stopping within 15 minutes ning low tire pressu	s after vehicle speed ire warning lamp ON?
NO >> Replace E	SCM. Refer to <u>BCS-79</u> FRATION	, "Removal and Installation	<u>on"</u> .	
Perform ID registi <u>Repair Requireme</u>	ration of all transmitte	ers. Refer to <u>WT-5, "ID F</u>	REGISTRATION PR	ROCEDURE : Special

2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

< COMPONENT DIAGNOSIS >

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON? YES >> INSPECTION END

NO >> GO TO 2.

Special Repair Requirement

INFOID:000000001686965

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to WT-98, "Tire".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"</u>. Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< COMPONENT DIAGNOSIS >

C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

Description

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

DTC Logic

INFOID:000000001686967

INFOID:000000001686966

А

Н

Κ

L

Μ

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible case	D
C1716	[PRESSDATA ERR] FL	Air pressure data from front-LH transmitter malfunction		
C1717	[PRESSDATA ERR] FR	Air pressure data from front-RH transmitter malfunction	 ID registration is not fin- ished 	WT
C1718	[PRESSDATA ERR] RR	Air pressure data from rear-RH transmitter malfunction	Transmitter malfunction	
C1719	[PRESSDATA ERR] RL	Air pressure data from rear-LH transmitter malfunction		F

DTC CONFIRMATION PROCEDURE

1.VEHICLE DRIVING

With CONSULT-III

1. Drive at a speed 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value
AIR PRESS FL		
AIR PRESS FR	Start engine and drive at 40 km/h (25MPH) or more for	Approximately equal to the indication on vehi-
AIR PRESS RR	several minutes.	cle information display.
AIR PRESS RL		

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to Diagnosis procedure. Refer to WT-23, "Diagnosis Procedure".

Diagnosis Procedure

INFOID:000000001686968

1.CHECK TIRE PRESSURE

With CONSULT-III

- 1. Adjust tire pressure to specified value. Refer to WT-98, "Tire".
- Perform the ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 3. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
- Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Monitored item	Condition	Display value	0
AIR PRESS FL			
AIR PRESS FL	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on	D
AIR PRESS FL	several minutes.	vehicle information display.	Γ
AIR PRESS FL			

Is tire pressure indicated as 438.60 kPa (4.47kg/cm², 63.60 psi) on the "DATA MONITOR" screen?

YES >> Replace malfunctioning transmitter.

NO >> GO TO 2.

C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< COMPONENT DIAGNOSIS >

2. CHECK TIRE PRESSURE MONITORING SYSTEM

With CONSULT-III

- 1. Perform the ID registration of all transmitters. Refer to <u>WT-5. "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END
- NO >> Perform the self-diagnosis, inspect detected malfunction. Refer to <u>WT-11, "AIR PRESSURE</u> <u>MONITOR : Diagnosis Description"</u>.

Component Inspection

INFOID:000000001686969

1.CHECK TRANSMITTER

With CONSULT-III

- 1. Adjust tire pressure to specified value. Refer to <u>WT-98, "Tire"</u>.
- 2. Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 3. Drive at a 40 km/h (25 MPH) or more for several minutes without stopping.
- 4. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Is tire pressure indicated as 438.60 kPa (4.47 kg/cm², 63.60 psi) on the "DATA MONITOR" screen?

- YES >> Replace malfunctioning transmitter.
- NO >> Check BCM and tire pressure receiver.

Special Repair Requirement

INFOID:000000001686970

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to WT-98, "Tire".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2. PERFORM ID REGISTRATION

Perform ID registration. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"</u>. Can ID registration of all transmitters be completed?

- YES >> END
- NO >> GO TO 1.

C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

< COMPONENT DIAGNOSIS >

C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

Description

A sensor-transmitter integrated with a valve is installed on a wheel, and detected air pressure signal by radio wave.

DTC Logic

INFOID:000000001686972

INFOID:00000000168697

А

Н

Κ

Μ

Ν

P

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible case	D
C1720	[CODE ERR] FL	function code data from front-LH transmitter is malfunction.	Tiro prossuro rocoivor mal-	
C1721	[CODE ERR] FR	function code data from front-RH transmitter is malfunction.	function	WT
C1722	[CODE ERR] RR	function code data from rear-RH transmitter is malfunction.	Transmitter malfunction PCM malfunction	
C1723	[CODE ERR] RL	function code data from rear-LH transmitter is malfunction.		F

DTC CONFIRMATION PROCEDURE

1.VEHICLE DRIVING

With CONSULT-III

- 1. Driving at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
- 2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value	
AIR PRESS FL			
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle	
AIR PRESS RR	several minutes.	information display.	
AIR PRESS RL			

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to <u>WT-25, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:000000001686973

1.CHECK ID REGISTRATION

With CONSULT-III

- 1. Perform the ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6. NO >> GO TO 2.

2.CHECK ALL TIRE PRESSURE SIGNAL

With CONSULT-III

- 1. Start engine.
- 2. Select "ĎATA MONITOR" mode for "AIR PRESSUR MONITOR" with CONSULT-III.
- 3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

< COMPONENT DIAGNOSIS >

Monitored item	Condition	Display value
AIR PRESS FL		
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for several	Approximately equal to the indication on
AIR PRESS RR	minutes.	vehicle information display.
AIR PRESS RL		

Are all tire pressure displayed 0 kPa?

YES >> GO TO 3. NO >> GO TO 5.

$\mathbf{3}$.check harness between BCM and tire pressure receiver

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector and tire pressure receiver harness connector.
- 3. Check continuity between BCM harness connector and tire pressure receiver harness connector.

BCM		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	Continuity
M123	137	M101	1	Existed
	138		4	
	139		2	

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damage parts.

4.CHECK TIRE PRESSURE RECEIVER

Check tire pressure receiver. Refer to WT-42, "Diagnosis Procedure".

Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.
- NO >> Replace the tire pressure receiver.

5.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair</u> Requirement".

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 7 after malfunctioning transmitter replacement.

6.CHECK TIRE PRESSURE MONITORING SYSTEM

With CONSULT-III

- 1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
- 2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END.
- NO >> Replace BCM. Refer to <u>BCS-79. "Removal and Installation"</u>.

7.CHECK ID REGISTRATION

BWith CONSULT-III

- 1. Perform ID registration of all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

WT-26

C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

< COMPONENT DIAGNOSIS >

< COMPONENT DIAGNOSIS >	
Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON? YES >> INSPECTION END. NO >> GO TO 2.	А
Special Repair Requirement	В
1. CHECK TIRE AIR PRESSURE	
Check all tire air pressures. Refer to <u>WT-98, "Tire"</u> .	С
YES $>>$ GO TO 2.	
NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.	D
Perform ID registration. Refer to WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement".	
Can ID registration of all transmitters be completed?	WT
YES >> END NO >> GO TO 1.	_
	F
	G
	G
	Н
	I
	J
	Κ
	L
	Ъ.Л
	IVI
	N
	0
	Ρ

C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

< COMPONENT DIAGNOSIS >

C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

Description

A sensor -transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

DTC Logic

INFOID:000000001686976

INFOID:000000001686975

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible case
C1724	[BATT VOLT LOW] FL	Battery voltage of front-LH transmitter drops.	Transmitter malfunction
C1725	[BATT VOLT LOW] FR	Battery voltage of front-RH transmitter drops.	Tire pressure receiver
C1726	[BATT VOLT LOW] RR	Battery voltage of rear-RH transmitter drops.	malfunction
C1727	[BATT VOLT LOW] RL	Battery voltage of rear-LH transmitter drops.	

DTC CONFIRMATION PROCEDURE

1.VEHICLE DRIVING

With CONSULT-III

Driving at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed 10minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value
AIR PRESS FL		
AIR PRESS FL	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle in-
AIR PRESS FL	several minutes.	formation display.
AIR PRESS FL		

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to <u>WT-28, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:000000001686977

1.CHECK ID REGISTRATION

(D)With CONSULT-III

- 1. Perform the ID registration of all transmitters. Refer to <u>WT-5. "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6. NO >> GO TO 2.

2. CHECK AIR PRESSURE SIGNAL

With CONSULT-III

- 1. Start engine.
- 2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
- 3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

< COMPONENT DIAGNOSIS >

Monitored item	Conditi	on	Display	y value
AIR PRESS FL				
AIR PRESS FR	Start engine and drive at 40 km	/h (25 MPH) or more for	Approximately equal to the	e indication on vehicle in-
AIR PRESS RR	several minutes.	·	formation display	
AIR PRESS RL				
Are all tire pressu	ures displayed 0 kPa?			
YES >> GO	TO 3. TO 5			
	NESS BETWEEN BOM AN			
		DTIKETEROOOKE		
 Disconnect E Check contir 	BCM harness connector an nuity between BCM harness	d tire pressure receiv s connector and tire p	er harness connector. pressure receiver harne	ss connector.
	BCM	Tire press	sure receiver	0
Connector	Terminal	Connector	Terminal	Continuity
	137		1	
M123	138	M101	4	Existed
	139		2	
Also check h	arness for short to ground	and short to power.		
s the inspection	result normal?			
YES >> GO	TO 4.			
NO >> Repa	air or replace damaged par	ts.		
4. CHECK TIRE	PRESSURE RECEIVER			
Check tire pressu	ure receiver. Refer to WT-4	2, "Diagnosis Proced	ure".	
Is the inspection	result normal?			
YES >> Cheo	ck BCM pin terminals for d	lamage or loose con	nection with harness co	onnector. If any items
NO >> Repl	amaged, repair or replace	damage parts. /er		
	GISTRATION			
	tration of all transmitters P	ofer to WT-5 "ID RE		
<u>Requirement"</u> .				
Can ID registration	on of all transmitters be cor	npleted?		
YES >> GO	TO 6.			
NO >> GO	TO 7 after malfunctioning tr	ansmitter replaceme	nt.	
D. CHECK TIRE	PRESSURE MONITORIN	G SYSTEM		
With CONSUL	.T-III			
1. Drive at a sp	eed for 40 km/h (25 MPH)		Ites without stopping.	ofter vehicle anead
 becomes 17 	km/h (11 MPH).			alter vehicle speed
Does <u>"DATA M</u> O	NITOR" displayed the stand	<u>dardized value withou</u>	<u>it turning low tire pre</u> ssu	ire warning lamp ON?
YES >> INSP	PECTION END			
NO >> Repl	ace BCM. Refer to <u>BCS-79</u>), "Removal and Insta	<u>Illation"</u> .	
7. CHECK ID RE	EGISTRATION			
With CONSUL	.T-III			
1. Perform ID r	egistration of all transmitte	ers. Refer to <u>WT-5, "</u>	ID REGISTRATION PR	ROCEDURE : Special
Repair Requ	irement".			

2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

< COMPONENT DIAGNOSIS >

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON? YES >> INSPECTION END

NO >> GO TO 2.

Special Repair Requirement

INFOID:000000001686978

1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to WT-98, "Tire".

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

2.PERFORM ID REGISTRATION

Perform ID registration. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"</u>. Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

< COMPONENT DIAGNOSIS >

C1729 VEHICLE SPEED SIG ERR

Description

BCM detects no vehicle speed signal.

DTC Logic

INFOID:000000001686980

INFOID:000000001686979

А

В

С

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible case	D		
C1729	VHCL SPEED SIG ERR	Vehicle speed signal error	 CAN communication error Unified meter and A/C amp mal- function Refer to <u>MWI-47,</u> <u>"Diagnosis Procedure"</u>. 	WT		
DTC CONF 1.VEHICLI	FIRMATION PROCE E DRIVING	DURE		F		
With CON Drive at spe Does "DATA	NSULT-III eed 40 km/h (25 MPH) <u>A MONITOR" displayee</u>	or more for several minutes without stopping. I the standardized value without turning low p	ressure warning lamp ON?	G		
YES >> NO >>	INSPECTION END Go to diagnosis proce	dure. Refer to <u>WT-31, "Diagnosis Procedure"</u>		Н		
Diagnosis	s Procedure		INFOID:000000001686981			
1.снеск	SELF-DIAGNOSTIC R	ESULTS		I		
With COM 1. On "SE 2. Check	NSULT-III LECT DIAG MODE", s display contents in self	elect the "SELF-DIAG RESULT" screen. -diagnostic results.		J		
<u>Is the "CAN</u> YES >>	COMM CIRCUIT" disp Perform trouble diagn Flow Chart".	blayed in the self-diagnosis display? osis for CAN communication system. Refer t	o LAN-16, "Trouble Diagnosis	K		
NO >>	Check unified meter a	nd A/C amp. Refer to MWI-83, "Reference Va	alue".			
Special R	epair Requireme	nt	INFOID:000000001686982	L		
1.снеск	TIRE AIR PRESSURE			NЛ		
Check all tir	e air pressures. Refer	to <u>WT-98, "Tire"</u> .		1 V I		
Does all tire pressure data meet the specification?YES>> GO TO 2.NO>> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.						
2.PERFOF	RM ID REGISTRATION	I				
Perform ID	registration.Refer to <u>V</u>	/T-5, "ID REGISTRATION PROCEDURE : Sp	ecial Repair Requirement".	0		
Can ID regi	stration of all transmitte	ers be completed?				
1ES >> NO >>	GO TO 1.			Ρ		

C1734 CONTROL UNIT

Description

INFOID:000000001686983

The BCM reads the air pressure signal received by the tire pressure receiver, and controls the low tire pressure warning lamp and the buzzer operations. It also has a judgment function to detect a system malfunction.

DTC Logic

INFOID:000000001686984

DTC DETECTION LOGIC

DTC number	Trouble diagnosis name	DTC detecting condition	Possible case
C1734	CONTROL UNIT	Tire pressure monitoring system in BCM is malfunctioning	BCM malfunction

DTC CONFIRMATION PROCEDURE

1.VEHICLE DRIVING

With CONSULT-III

- 1. Drive at a speed 40 km/h (25 MPH) or more for several minutes without stopping.
- 2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to <u>WT-32, "Diagnosis Procedure"</u>.

Diagnosis Procedure

INFOID:000000001686985

1.CHECK SELF-DIAGNOSTIC RESULTS

With CONSULT-III

- i. On "SELECT DIAG" mode, select the "SELF-DIAG RESULT" screen.
- 2. Check display contents in self-diagnostic results.

Does self-diagnostic results indicate any malfunction?

- YES >> Perform trouble diagnosis. Refer to <u>WT-77, "DTC Index"</u>.
- NO >> GO TO 2.

2. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".

- 2. Disconnect BCM harness connector.
- 3. Check voltage between BCM harness connector terminals and ground.

(+)		(-)	
BCM		,	Voltage (Approx.)
Connector	Terminal	Ground	
M118	1	Ground	Batteny voltage
M119	11		Dattery voltage

Is the power supply normal?

YES >> GO TO 3. NO >> Check the second second

- >> Check the following. If any items are damaged, repair or replace damage parts.
 - 40A fusible link [No. K located in the fuse block]. Refer to <u>PG-92, "Fuse and Fusible Link</u> <u>Arrangement"</u>.
 - 10A fuse [No. 10 located in the fuse block (J/B)]. Refer to <u>PG-91, "Fuse, Connector and Termi-nal Arrangement"</u>.
 - Harness for short or open between battery and BCM harness connector M118 terminal 1.
 - Harness for short or open between battery and BCM harness connector M119 terminal 11.
 - Check Battery voltage.

3.CHECK GROUND CIRCUIT

C1734 CONTROL UNIT

< COMPONENT DIAGNOSIS >

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector.
- 3. Check continuity between BCM harness connector M119 terminal 13 and ground.
- 4. Also check harness for short to ground.

	BCM				Continuity
Connector	Termina	nal Ground		Ground	Existed
M119	13		-		Existed
<u>ls the inspection resul</u> YES >> GO TO 4. NO >> Repair op 4 СНЕСК НАРМЕЗЗ	t normal? en circuit or short to p	ower in har	ness or cor	nnectors.	
 Turn ignition switc Disconnect BCM Check continuity I 	ch "OFF" harness connector an between BCM harness	d tier press	ure receive and tire pr	r harness conne	ctor. narness connector.
BC	CM		Tire pressu	re receiver	
Connector	Terminal	Conn	ector	Terminal	Continuity
	137			1	
M123	138	M1	01	4	Existed
	139			2	
Is the inspection resul YES >> INSPECT NO >> GO TO 6. 6.CHECK BCM HAR	<u>t normal?</u> ION END NESS CONNECTOR				
Check BCM pin termir Is the inspection resul YES >> Replace E NO >> Repair or	nals for damage or loo <u>t normal?</u> 3CM. Refer to <u>BCS-79</u> replace damaged par	se connect) <u>, "Removal</u> ts.	ion with hai and Install	mess connector. ation".	
Special Repair Re	equirement				INFOID:000000001686986
1.CHECK TIRE AIR	PRESSURE				
Check all tire air press	sures. Refer to <u>WT-98</u>	"Tire".			
Does all tire pressureYES>> GO TO 2.NO>> Inspect orParametersParameters	data meet the specific	<u>ation?</u> eels and ad	just the tire	pressure to the	specification.
∠.PERFORM ID REC	JISTRATION				
Perform ID registration	n. Refer to <u>WT-5, "ID F</u>	REGISTRA		CEDURE : Speci	al Repair Requirement".

NO >> GO TO 1.

А

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000001903113

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.	
Battony power supply	К	
Ballery power supply	10	

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.

- 2. Disconnect BCM connectors.
- 3. Check voltage between BCM harness connector and ground.

(+)	(-)	Voltage
B	CM		(Approx.)
Connector	Terminal	Ground	
M118	1	Giouna	Pottony voltago
M119	11	*	Ballery Vollage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

 ${f 3.}$ CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

B	CM		Continuity
Connector	Connector Terminal		Continuity
M119	13	Ť	Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE) : Special Repair Requirement

1.REQUIRED WORK WHEN REPLACING BCM

Initialize control unit. Refer to CONSULT-III operation manual NATS-IVIS/NVIS.

>> Work end. UNIFIED METER AND A/C AMP.

UNIFIED METER AND A/C AMP. : Description

COMPONENT DESCRIPTION

INFOID-000000001903114

INFOID-000000001686988

POWER SUPPLY AND GROUND CIRCUIT

C

BATTERY

54

অক্ষম

IGNITION

ON or START

53

Unified meter and A/C amp.

71

55

o-

< COMPONENT DIAGNOSIS >

Unified Meter and A/C Amp. (Automatic Amplifier)

The unified meter and A/C amp. (1) has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The air mix door motor(s), mode door motor, intake door motor, blower motor and compressor are then controlled.

When the various switches and temperature control dial are operated, data is input to the unified meter and A/C amp. from the AV control unit using CAN communication.

Self-diagnosis functions are also built into unified meter and A/C amp. to provide quick check of malfunctions in the auto air conditioner system.

Power Supply and Ground Circuit for Unified Meter and A/C Amp.

Potentio Temperature Control (PTC)

The PTC (1) is built into the preset switch. It can be set at an interval of 0.5°C (1.0°F) in the 18°C (60°F) to 32°C (90°F) temperature range by turning temperature control dial. The set temperature is displayed. Without left and right ventilation temperature separately system

With left and right ventilation temperature separately system



UNIFIED METER AND A/C AMP. : Diagnosis Procedure

1.CHECK POWER SUPPLY CIRCUIT FOR UNIFIED METER AND A/C AMP.

1. Disconnect unified meter and A/C amp. connector.

2. Check voltage between unified meter and A/C amp. harness connector and ground.



А

В

D

WT

Н

JSIIA0014GB

IGNITION

ACC or ON

41

RJIA4049E

INFOID:000000001903115

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

(+)		(–)	Voltage		
Unified meter and A/C amp.			Ignition switch position		
Connector	Terminal	—	OFF	ACC	ON
M67	41	Ground	Approx. 0 V	Battery voltage	Battery voltage
	53		Approx. 0 V	Approx. 0 V	Battery voltage
	54		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

2.CHECK FUSE

Check 10A fuses [Nos. 3, 6 and 19, located in the fuse block (J/B)]. Refer to <u>PG-91, "Fuse, Connector and Ter-</u> minal <u>Arrangement"</u>.

Is the inspection result normal?

YES >> Check harness for open circuit. Repair or replace if necessary.

NO >> Check harness for short circuit and replace fuse.

3.CHECK GROUND CIRCUIT FOR UNIFIED METER AND A/C AMP.

1. Turn ignition switch OFF.

2. Check continuity between unified meter and A/C amp. harness connector and ground.

Unified meter and A/C amp.			Continuity	
Connector	Terminal	—	Continuity	
M67	55	Groupd	Evistod	
	71	Glouid	Existed	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4.CHECK PRESET SWITCH

Check preset switch. Refer to <u>AV-103, "Symptom Table"</u> (BASE AUDIO WITHOUT NAVIGATION), <u>AV-335,</u> "<u>Symptom Table</u>" (BOSE AUDIO WITHOUT NAVIGATION) or <u>AV-596, "Symptom Table"</u> (BOSE AUDIO WITH NAVIGATION).

Is the inspection result normal?

- YES >> Replace unified meter and A/C amp.
- NO >> Repair or replace malfunctioning part(s).
TPMS

Description

INFOID:000000001686991

During driving, the TPMS receives the signal transmitted from the transmitter installed in each wheel, when the tire pressure becomes low. The control unit (BCM) of this system has pressure judgment and trouble diagnosis functions.

When the TPMS detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

D

С

А

WT

F

Н

J

Κ

L

Μ

Ν

Ο

Ρ

Wiring Diagram - TIRE PRESSURE MONITORING SYSTEM -

INFOID:000000001686992

Click here to view the eWD.



PTIA4	R AND A/C AMP. AND A/C AMP.	A
meetor No. M6 meetor Name wife To Wife meetor Type TH60MW CSITE 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5	Immetor No. M86 ormector Name UNIFIED METE ormector Type TH40FW-NH ormector Type Ormector ormector Type	C
	A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A A	W
No. M2 Name EUSE BLOCK (J/B) Type NS10FW-CS (10B9B8B77B6 (10B9B8B77B6 (10B9B8B77B6 (10B9B817B6 (10B9B817B6)	No. Miss Name COMBINATION METEF Type SAE40FW Type SAE40FW Tiggad Electron Color Signal Name of Wre Signal Name V CoMM (ME V COMM (ME	F
Commettor Commettor Annettor Romettor B	Commettor Commettor Mb. 23	Н
(J/B)	OWNECTOR 2113141516 15678 I Mame [Specification]	1
A iometer No. MI iometer No.	American M24 Connector Name DATA LINK C Connector Type BD16FW Connector Type BD16FW Image: Second Sec	J
		L
	RE WARNING CHECK	M
		Ν
TIRE PR Gommeter Nam Commeter Nam Commeter Type 1.5 1.5 1.5 1.5 1.5 1.5 1.5 1.5	Connector No. Connector Type Connector Type A.S. A.S.	0

Р



TPMS

9 8





JCEWA0011GB



TPMS

TIRE PRESSURE RECEIVER

< COMPONENT DIAGNOSIS >

TIRE PRESSURE RECEIVER

Description

INFOID:000000001686993

The tire pressure receiver receives the air pressure signal transmitted by the transmitter in each wheel.

Diagnosis Procedure

INFOID:000000001686994

1.CHECK TIRE PRESSURE RECEIVER

1. Turn ignition OFF.

2. Check tire pressure receiver connector M101 terminal 2 and ground signal with oscilloscope.

Connector	Terr	minal	Condition	Voltage (Approx.)
M101	2	Cround	Standby state	(V) 6 2 0 • 0.2s OCC3879D
	2	Giound	When receiving signal from transmitter	(V) 6 4 2 0 • • 0.2s OCC3880D

Is the reference signal inputted?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK TIRE PRESSURE RECEIVER INPUT VOLTAGE

1. Disconnect tire pressure receiver connector.

2. Check voltage between tire pressure receiver connector M101 terminal 4 and ground.

(+)		(-)	
Tire pressu	re receiver		Voltage (Approx.)
Connector	Terminal	Ground	
M101	4		5.0 V

Is the reference voltage inputted?

YES >> GO TO 3.

NO >> Check BCM harness and connector.

 $\mathbf{3}$.check tire pressure receiver ground circuit

- 1. Disconnect BCM harness connector and tire pressure receiver connector.
- 2. Check continuity between BCM harness connector M123 terminal 137 and tire pressure receiver connector M101 terminal 1.

B	BCM		Tire pressure receiver		
Connector	Terminal	Connector	Terminal	Continuity	
M123	137	M101	1	Existed	

Also check harness for short to ground. <u>Is the inspection result normal?</u>

TIRE PRESSURE RECEIVER

< COMP	PONENT DIAGNOSIS >	
YES NO	>> GO TO 4. >> Repair or replace damaged parts.	А
4.CHEC	CK BCM CIRCUIT	
Inspect th	he BCM circuit. Refer to BCS-38, "Diagnosis Procedure".	R
Is the BC	CM circuit normal?	D
YES NO	>> Replace tire pressure receiver. >> Repair or replace BCM circuit. Replace BCM. Refer to <u>BCS-79, "Removal and Installation"</u> .	С
		D

WT

F

G

Н

J

Κ

L

M

Ν

Ο

Ρ

TIRE PRESSURE WARNING CHECK SWITCH

< COMPONENT DIAGNOSIS >

TIRE PRESSURE WARNING CHECK SWITCH

Description

INFOID:000000001686995

The following item can be checked by grounding the tire pressure warning check switch harness connector terminal.

• The low tire pressure warning lamp in the combination meter blink according to the self-diagnostic results. **NOTE:**

If low tire pressure warning lamp blinks below, the system is normal.

 This mode shows transmitter status is in OFF-mode.
 Perform transmitter wake up operation. Refer to <u>WT-5</u>, <u>"TRANS-</u> MITTER WAKE UP OPERATION : Special Repair Requirement".



Diagnosis Procedure

INFOID:000000001686996

1.CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- 1. Turn ignition switch "ON".
- 2. Check voltage between tire pressure warning check switch connector M23 terminal 1 and ground.

(+)		(-)	
Tire pressure warn	ing check switch		Voltage (Approx.)
Connector	Terminal	Ground	
M23	1	_	5.0 V

Is the reference voltage outputted?

YES >> Repair or replace BCM circuit. Replace BCM. Refer to <u>BCS-79. "Removal and Installation"</u>.

NO >> GO TO 2.

2.CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector
- 3. Check continuity between BCM harness connector M123 terminal 149 and tire pressure warning check switch connector M23 terminal 1.
- 4. Check harness for short to ground.

BCM Tire pressure warning check switch		Continuity		
Connector	Terminal	Connector	Terminal	Evistod
M123	149	M23	1	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. СНЕСК ВСМ

Check BCM input/output signal. Refer to WT-45, "Reference Value".

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. Replace BCM Refer to <u>BCS-79. "Removal and Installation"</u>.

< ECU DIAGNOSIS >

ECU DIAGNOSIS BCM (BODY CONTROL MODULE)

Reference Value

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

CONSULT-III MONITOR I	TEM		С
Monitor Item	Condition	Value/Status	
	Other than front wiper switch HI	Off	_
	Front wiper switch HI	On	D
	Other than front wiper switch LO	Off	
FR WIFER LOW	Front wiper switch LO	On	WT
	Front washer switch OFF	Off	
FR WASHER SW	Front washer switch ON	On	
	Other than front wiper switch INT	Off	F
	Front wiper switch INT	On	
	Front wiper is not in STOP position	Off	G
FR WIFER STOP	Front wiper is in STOP position	On	_ 0
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position	
	Other than turn signal switch RH	Off	Н
IURIN SIGNAL R	Turn signal switch RH	On	
	Other than turn signal switch LH	Off	
TURIN SIGNAL L	Turn signal switch LH	On	
	Other than lighting switch 1ST and 2ND	Off	
TAIL LAWP SW	Lighting switch 1ST or 2ND	On	J
	Other than lighting switch HI	Off	
	Lighting switch HI	On	
	Other than lighting switch 2ND	Off	— K
HEAD LAIVIP SVV I	Lighting switch 2ND	On	
	Other than lighting switch 2ND	Off	L
HEAD LAWF SW 2	Lighting switch 2ND	On	
DASSING SW	Other than lighting switch PASS	Off	
FASSING SW	Lighting switch PASS	On	M
	Other than lighting switch AUTO	Off	
AUTO LIGHT SW	Lighting switch AUTO	On	N
	Front fog lamp switch OFF	Off	
111106.50	Front fog lamp switch ON	On	
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off	0
	Driver door closed	Off	
DOOR SW-DR	Driver door opened	On	Р
	Passenger door closed	Off	
DOOR SW-AS	Passenger door opened	On	
DOOR SW-RR	NOTE: The item is indicated, but not monitored.	Off	
DOOR SW-RL	NOTE: The item is indicated, but not monitored.	Off	

Revision: 2007 June

А

INFOID:000000001903106 В

Monitor Item	Condition	Value/Status
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
	Other than power door lock switch LOCK	Off
CDL LOCK SW	Power door lock switch LOCK	On
	Other than power door lock switch UNLOCK	Off
CDL UNLOCK SW	Power door lock switch UNLOCK	On
	Other than driver door key cylinder LOCK position	Off
KEY CYLLK-SW	Driver door key cylinder LOCK position	On
	Other than driver door key cylinder UNLOCK position	Off
KEY CYL UN-SW	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
	Hazard switch is not pressed	Off
HAZARD SW	Hazard switch is pressed	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
H/L WASH SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
IN ONNOLL OW	Trunk lid opener cancel switch ON	On
	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
	UNLOCK button of Intelligent Key is not pressed	Off
INE ONEOON	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of Intelligent Key is not pressed	Off
	TRUNK OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On
	LOCK/UNLOCK button of Intelligent Key is not pressed and held si- multaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simul- taneously	On
	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REO SW-DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REO SW-AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
	Trunk request switch is not pressed	Off
REQ SW-BD/TR	Trunk request switch is pressed	On

Monitor Item	Condition	Value/Status	
	Push-button ignition switch (push switch) is not pressed	Off	A
P05H 5W	Push-button ignition switch (push switch) is pressed	On	
	Ignition switch in OFF or ACC position	Off	В
IGN RLY2 -F/B	Ignition switch in ON position	On	
	Ignition switch in OFF position	Off	
ACC RLY -F/B	Ignition switch in ACC or ON position	On	С
	The clutch pedal is not depressed	Off	
CLUCH SVV	The clutch pedal is depressed	On	D
	The brake pedal is not depressed	On	
BRARE SW 1	The brake pedal is depressed	Off	
	Selector lever in P position	Off	WT
DETE/CANCE SW	Selector lever in any position other than P	On	
	Selector lever in any position other than P and N	Off	
SFT FININ SVV	Selector lever in P or N position	On	
S/L L OCK	Steering is locked	Off	
S/L-LUCK	Steering is unlocked	On	G
	Steering is unlocked	Off	
S/L-UNLOCK	Steering is locked	On	
	Ignition switch in OFF or ACC position	Off	Η
S/L RELAY-F/B	Ignition switch in ON position	On	
	Driver door is unlocked	Off	
UNER SEN-DR	Driver door is locked	On	
	Push-button ignition switch (push-switch) is not pressed	Off	
F USI I SW -IF DIW	Push-button ignition switch (push-switch) is pressed	On	J
	Ignition switch in OFF or ACC position	Off	
IGN KLTT-F/B	Ignition switch in ON position	On	K
	Selector lever in P position	Off	
	Selector lever in any position other than P	On	
	Selector lever in any position other than P and N	Off	L
SFT PN -IPDM	Selector lever in P or N position	On	
SET D MET	Selector lever in any position other than P	Off	M
SFTF-WET	Selector lever in P position	On	
SET NI MET	Selector lever in any position other than N	Off	
SFT IN -IVIET	Selector lever in N position	On	N
	Engine stopped	Stop	
ENGINE STATE	While the engine stalls	Stall	0
	At engine cranking	Crank	0
	Engine running	Run	
	Steering is locked	Off	Р
	Steering is unlocked	On	
	Steering is unlocked	Off	
	Steering is locked	On	
	Ignition switch in OFF or ACC position	Off	
S/L RELAY-REQ	Ignition switch in ON position	On	

Monitor Item	Condition	Value/Status
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
	Driver door is locked	LOCK
DR DOOR STATE	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLK
	Passenger door is locked	LOCK
AR DOOR STATE	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLK
	Ignition switch in ACC or ON position	Reset
ID OK FLAG	Ignition switch in OFF position	Set
	The engine start is prohibited	Reset
FRIMITEING STRT	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SWI SLOT	Intelligent Key is not inserted into key slot	Off
KET SW-SLUT	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	_
	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
CONFRM ID ALL	The key ID that the key slot receives accords with any key ID registered to BCM.	DONE
	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
CONFIRM ID4	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	DONE
	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
CONFIRM ID3	The key ID that the key slot receives accords with the third key ID registered to BCM.	DONE
	The key ID that the key slot receives does not accord with the sec- ond key ID registered to BCM.	Yet
CONFIRM ID2	The key ID that the key slot receives accords with the second key ID registered to BCM.	DONE
	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
CONFIRMID	The key ID that the key slot receives accords with the first key ID registered to BCM.	DONE
	The ID of fourth Intelligent Key is not registered to BCM	Yet
IP 4	The ID of fourth Intelligent Key is registered to BCM	DONE
	The ID of third Intelligent Key is not registered to BCM	Yet
143	The ID of third Intelligent Key is registered to BCM	DONE
	The ID of second Intelligent Key is not registered to BCM	Yet
182	The ID of second Intelligent Key is registered to BCM	DONE
	The ID of first Intelligent Key is not registered to BCM	Yet
TP 1	The ID of first Intelligent Key is registered to BCM	DONE

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	– A
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	В
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	С
	ID of front LH tire transmitter is registered	Green	_
ID REGST FL1	ID of front LH tire transmitter is not registered	Red	D
	ID of front RH tire transmitter is registered	Green	_
ID REGST FRT	ID of front RH tire transmitter is not registered	Red	WT
	ID of rear RH tire transmitter is registered	Green	
ID REGST RRT	ID of rear RH tire transmitter is not registered	Red	_
	ID of rear LH tire transmitter is registered	Green	F
ID REGST RET	ID of rear LH tire transmitter is not registered	Red	
	Tire pressure indicator OFF	Off	G
	Tire pressure indicator ON	On	
	Tire pressure warning alarm is not sounding	Off	
BUZZER	Tire pressure warning alarm is sounding	On	Н

J

Κ

L

M

Ν

Ο

Ρ

< ECU DIAGNOSIS >

TERMINAL LAYOUT



PHYSICAL VALUES

< ECU DIAGNOSIS >

Term	inal No.	Description					А
(Wir	e color)	Signal name	Input/ Output		Condition	Value (Approx.)	
1 (W)	Ground	Battery power supply	Input	Ignition switch OF	F	Battery voltage	В
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage	C
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage	0
4	Cround	Interior room lamp	Quitout	After passing the ir er operation time	nterior room lamp battery sav-	0 V	D
(LG)	Ground	power supply	Output	Any other time after lamp battery save	er passing the interior room r operation time	Battery voltage	WT
5	Ground	Passenger door UN-	Output	Passangar door	UNLOCK (Actuator is activated)	Battery voltage	
(P)	Ground	LOCK	Output	Fassenger door	Other than UNLOCK (Actuator is not activated)	0 V	F
7	Ground	Step Jamp	Output	Sten Jamp	ON	0 V	
(Y)	Ground		Output	Step lamp	OFF	Battery voltage	G
8	Ground	All doors, fuel lid	Output	All doors fuel lid	LOCK (Actuator is activat- ed)	Battery voltage	
(V)	(V) Ground LOC	LOCK	Output		Other than LOCK (Actuator is not activated)	0 V	Н
9	Ground	Driver door, fuel lid	Output	Driver door, fuel	UNLOCK (Actuator is activated)	Battery voltage	
(G)	Ground	UNLOCK	Output	lid	Other than UNLOCK (Actuator is not activated)	0 V	
11 (R)	Ground	Battery power supply	Input	Ignition switch OF	F	Battery voltage	J
13 (B)	Ground	Ground	_	Ignition switch ON		0 V	K
					OFF	0 V	
		Push-button ignition				NOTE: When the illumination brighten- ing/dimming level is in the neutral position	L
14 (W)	Ground	Pusn-button Ignition switch illumination ground	Output	Tail lamp	ON		Μ
						2 ms JSNIA0010GB	Ν
15	Ground	ACC indicator lamp	Outout	Ignition switch	OFF	Battery voltage	0
(O)	Croand		Caput	-gritter owned	ACC or ON	0 V	

Ρ

Term	Terminal No. Description				Value	
(Wire +	e color) –	Signal name	Input/ Output		Condition	(Approx.)
					Turn signal switch OFF	0 V
17 (V)	Ground	Turn signal (front RH)	Output	lgnition switch ON	Turn signal switch RH	(V) 15 10 5 0 1 s PKID0926E 6.5 V
					Turn signal switch OFF	0 V
18 (G)	Ground	Turn signal (front LH)	Output	Ignition switch ON	Turn signal switch LH	(V) 15 0 10 10 10 10 10 10 10 10 10
19		Room Jamp timer		Interior room	OFF	Battery voltage
(V)	Ground	control	Output	lamp	ON	0 V
					Turn signal switch OFF	0 V
20 (V)	Ground	Turn signal (rear RH)	Output	Ignition switch ON	Turn signal switch RH	(V) 15 10 5 0 1 s PKID0926E 6.5 V
23					Open (Trunk lid opener ac- tuator is activated)	Battery voltage
(G)	Ground	Trunk lid opening.	Output	Trunk lid	Close (Trunk lid opener ac- tuator is not activated)	0 V
					Turn signal switch OFF	0 V
25 (G)	Ground	Turn signal (rear LH)	Output	Ignition switch ON	Turn signal switch LH	(V) 15 10 50 1 s PKID0926E 6.5 V
30	Groupe	Trupk room lown	Outrout	Trupk nom long	ON	0 V
(R)	Ground	папк тоотпаттр	Output	типк тоотп татпр	OFF	Battery voltage

Terminal No.		Description				Value	
(Wire	e color)	Signal name	Input/	-	Condition	Value (Approx.)	A
+	-	Signal name	Output			(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
34 (SB) Grour		Trunk room antenna		Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	(V) 15 10 5 0 1 s JMKIA0062GB	B C D
	Ground	1 (-)			When Intelligent Key is not in the passenger compart- ment	(V) 15 10 5 0 1 s JMKIA0063GB	WT F
35 (V) Ground	Ground	Trunk room antenna 1 (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	(V) 15 10 50 1 s JMKIA0062GB	H
	Clound				When Intelligent Key is not in the passenger compart- ment	(V) 15 0 1 s JMKIA0063GB	J K L
38 (B) Gro	Ground	Rear bumper anten- na (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0 1 s JMKIA0062GB	M
					When Intelligent Key is not in the antenna detection area	(V) 15 0 15 0 15 0 15 15 15 15 15 15 15 15 15 15	P

Terminal No.		Description				Value	
(Wire +	e color) –	Signal name	Input/ Output		Condition	(Approx.)	
39	Ground	Rear humper anten-		When the trunk lid request switch	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0 1 s JMKIA0062GB	
(W)	Clound	na (+)	Gutput	OFF	When Intelligent Key is not in the antenna detection area	(V) 15 0 15 0 15 15 15 15 15 15 15 15 15 15	
47	Ground	Ignition relay (IPDM	Output	Ignition switch	OFF or ACC	Battery voltage	
(Y)	Croana	E/R) control	output		ON	0 V	
50 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	OFF (Trunk is closed)	(V) 15 10 5 0 10 ms JPMIA0011GB 11.8 V	
					ON (Trunk is open)	0 V	
				Ignition switch	When the clutch pedal is depressed	Battery voltage	
				els)	When the clutch pedal is not depressed	0 V	
52 (SB)	Ground	Starter relay control	Output	Ignition switch	When selector lever is in P or N position and the brake is depressed	Battery voltage	
				ON (A/T models)	When selector lever is in P or N position and the brake is not depressed	0 V	
					ON (Pressed)	0 V	
61 (SB)	Ground	Trunk request switch	Input	Trunk request switch	OFF (Not pressed)	(V) 15 10 5 10 10 ms JPMIA0016GB 1.0 V	
64	Ground	Request switch buzz-	Output	Request switch	Sounding	0 V	
(L)	Ground	er	Output	buzzer	Not sounding	Battery voltage	

< ECU DIAGNOSIS >

Terminal No.		Description				Volue	
(Wire	e color)	Signal name	Input/	-	Condition	(Approx.)	A
+	-	Signal name	Output			(, + +)	
					Pressed	0 V	D
67 (GR)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Not pressed	(V) 15 10 5 0 10 ms JPMIA0011GB	C
						11.8 V	WT
72 (R) Ground				When Intelligent Key is in the passenger compart- ment		F	
	Ground	Room antenna 2 (-) (center console)	Output	Ignition switch OFF		JMKIA0062GB	G
					When Intelligent Key is not in the passenger compart- ment	(V) 15 10 5 0 W	Н
						JMKIA0063GB	1
							J
					When Intelligent Key is in the passenger compart-		K
73		Room antenna 2 (+)		Ignition switch	ment	1 s JMKIA0062GB	L
(G)	Ground	(center console)	Output	OFF		(V)	M
					When Intelligent Key is not in the passenger compart- ment		Ν
						JMKIA0063GB	0

Ρ

Term	inal No.	Description				
(Wire	e color)	Signal name	Input/		Condition	(Approx.)
+	-	oignarhaine	Output		Γ	· · · · ·
74 (SB)	Ground	Passenger door an-		When the pas- senger door re-	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0 1 s JMKIA0062GB
(SB)	(SB) tenna (-)	tenna (-)		operated with ig- nition switch OFF	When Intelligent Key is not in the antenna detection area	(V) 15 0 5 0 1 s JMKIA0063GB
75	Ground	nd Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area	(V) 15 0 1 1 1 1 1 1 1 1 1 1 1 1 1
(BR) Gro					When Intelligent Key is not in the antenna detection area	(V) 15 0 5 0 1 s JMKIA0063GB
76 (V) Grou	Ground	ound Driver door antenna (-)	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0 1 s JMKIA0062GB
	Ground				When Intelligent Key is not in the antenna detection area	(V) 15 0 1 s JMKIA0063GB

Terminal No.		Description				Value	
(Wire	e color)	Signal name	Input/		Condition	Value (Approx.)	A
+	-	olghar hame	Output		I		
77 (LG) Ground		Driver door antenna	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	(V) 15 10 5 0 1 s JMKIA0062GB	B C D
	Ground	(+)			When Intelligent Key is not in the antenna detection area	(V) 15 0 5 0 1 s JMKIA0063GB	WT F
78 (Y) Ground	Room antenna (-) (in-		Ignition switch	When Intelligent Key is in the passenger compart- ment	(V) 15 10 50 1 s JMKIA0062GB	H	
	Clound	strument panel)		OFF	When Intelligent Key is not in the passenger compart- ment	(V) 15 0 1 1 1 1 1 1 1 1 1 1 1 1 1	J K L
79 (BR) Grou	Ground	Room antenna (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	(V) 15 10 5 0 1 s JMKIA0062GB	M
	Ground	a (instrument panel)			When Intelligent Key is not in the passenger compart- ment	(V) 15 10 5 0 1 s JMKIA0063GB	O

Termi	inal No.	Description				Velue
(Wire	e color)	Signal name	Input/		Condition	(Approx.)
+	_	Signal name	Output			
80 (GR)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC ON	0 V Battery voltage
83 (Y) Ground	Ground	Remote keyless entry receiver signal	Input/	During waiting		(V) 15 10 5 1 1 1 1 1 1 1 1 1 1 1 1 1
			Output	When operating ei	ther button on Intelligent Key	(V) 15 10 5 0 1 1 1 1 1 1 1 1 1 1 1 1 1
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	(V) 15 0 2 ms 1.4 V
					Front fog lamp switch ON (Wiper intermittent dial 4)	(V) 15 0 2 ms JPMIA0037GB 1.3 V
					Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7	(V) 15 0 2 ms JPMIA0040GB 1.3 V

Terminal No.		Description				Value	
(Wire +	e color) –	Signal name	Input/ Output		Condition	value (Approx.)	А
							В
					All switch OFF (Wiper intermittent dial 4)		С
						JPMIA0041GB 1.4 V	D
88 (O) Ground					Lighting switch HI (Wiper intermittent dial 4)		WT
		Combination switch				JPMIA0036GB	F
	INPUT 3	Input	switch			G	
					Lighting switch 2ND (Wiper intermittent dial 4)		Н
						2 ms JPMIA0037GB 1.3 V	
							J
					 Any of the conditions below with all switch OFF Wiper intermittent dial 1 Wiper intermittent dial 2 Wiper intermittent dial 3 	10 5 0 2 ms	K
						1.3 V	L
89	Ground	Push-button ignition	Input	Push-button igni- tion switch (push	Pressed	0 V	
(BR)	Cround	switch (push switch)	mput	switch)	Not pressed	Battery voltage	M
90 (P)	Ground	CAN - L	Input/ Output		_	_	
91 (L)	Ground	CAN - H	Input/ Output		_	_	Ν
					OFF	0 V	0
92 (LG)	Ground	Key slot illumination	Output	Key slot illumina- tion	Blinking	(V) 15 0 0 1 s JPMIA0015GB	P
					ON	6.5 V	
					Dattery voltage		

Term	inal No.	Description				
(Wire	e color)	Cignel neme	Input/		Condition	(Approx.)
+	-	Signal name	Output			(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
93	Cround	ON indicator lamp	Output	Ignition owitch	OFF or ACC	0 V
(V)	Ground		Output	Ignition switch	ON	Battery voltage
95					OFF	0 V
(O)	Ground	ACC relay control	Output	Ignition switch	ACC or ON	Battery voltage
96 (Y)	Ground	A/T device (detention switch) power supply	Output			Battery voltage
97	Oracial	Steering lock condi-	Increase	Ota a rizz ra la alt	LOCK status	0 V
(L)	Ground	tion No. 1	input	Steering lock	UNLOCK status	Battery voltage
98	Ground	Steering lock condi-	المحمد	Stearing look	LOCK status	Battery voltage
(P)	Ground	tion No. 2	input	Steering lock	UNLOCK status	0 V
		Selector lever P posi-			P position	0 V
		tion switch (Except M/T models)		Selector lever	Any position other than P	Battery voltage
99 (R) Ground	ASCD clutch switch			OFF (Clutch pedal is de- pressed)	0 V	
	Ground	(M/T models with ICC)	Input	switch	ON (Clutch pedal is not depressed)	Battery voltage
		ICC clutch switch			OFF (Clutch pedal is de- pressed)	0 V
		(M/T models without ICC)		ICC clutch switch	ON (Clutch pedal is not de- pressed)	Battery voltage
					ON (Pressed)	0 V
100 (Y)	Ground	Passenger door re- quest switch	Input	Passenger door request switch	OFF (Not pressed)	(V) 15 10 5 10 10 ms JPMIA0016GB 1.0 V
					ON (Pressed)	0 V
101 (P)	Ground	Driver door request switch	Input	Driver door re- quest switch	OFF (Not pressed)	(V) 15 10 10 ms JPMIA0016GB 1.0 V
102	Ground	Blower fan motor re-	Output	Ignition switch	OFF or ACC	0 V
(O)		lay control		3	ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power sup- ply	Output	Ignition switch OFI	=	Battery voltage
106	Ground	Steering wheel lock	Output	Ignition switch	OFF or ACC	Battery voltage
(W)	Cround	unit power supply	Cuipui	ignition switch	ON	0 V

< ECU DIAGNOSIS >

Terminal No.		Description				Value	
(Wire	e color)	Signal name	Input/	1	Condition	(Approx.)	А
+	_		Output		All switch OFF	(V) 15 10 5 0 	B
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermit- tent dial 4)	Turn signal switch LH	UPMIA0041GB	D
						(V) 1.3 V (V) 15 10 5	F G H
					Turn signal switch RH	0 2 ms JPMIA0036GB 1.3 V	I
					Front wiper switch LO	(V) 15 10 5 0 2 ms JPMIA0038GB 1.3 V	K
					Front washer switch ON	(V) 15 10 5 0 •••••••••••••••••••••••••••••	M
						јрміа0039GB 1.3 V	0

Ρ

Term	inal No.	Description				Value	
+	-	Signal name	Input/ Output		Condition	(Approx.)	
	Ground	d Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	(V) 15 10 5 0 2.ms JPMIA0041GB 1.4 V	
108					Lighting switch AUTO (Wiper intermittent dial 4)	(V) 15 0 2 ms JPMIA0038GB 1.3 V	
(R)					Lighting switch 1ST (Wiper intermittent dial 4)	(V) 15 0 2.ms. JPMIA0036GB 1.3 V	
					Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	(V) 15 0 2 ms JPMIA0039GB 1.3 V	

Terminal No.		Description) (alua	
(Wire +	e color) –	Signal name	Input/ Output	Condition		Value (Approx.)	A
109 (W)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	(V) 15 0 2 ms JPMIA0041GB 1.4 V	B C D
					Lighting switch PASS	(V) 15 0 2 ms 1.3 V	WT F
					Lighting switch 2ND	(V) 15 10 5 0 2 ms JPMIA0036GB 1.3 V	G H I
					Front wiper switch INT	(V) 15 10 5 0 2 ms JPMIA0038GB 1.3 V	J K L
					Front wiper switch HI	(V) 15 0 2 ms JPMIA0040GB 1.3 V	M
					Pressed	0 V	0
110 (G)	Ground	Hazard switch	Input	Hazard switch	Not pressed	(V) 15 10 10 10 10 1.1 V JPMIA0012GB	Ρ

Terminal No.		Description				Value
(Wire	e color)	Signal name	Input/		Condition	(Approx.)
+	_	olgha hamo	Output		Γ	,
					LOCK status	Battery voltage
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK or UNLOCK	(V) 15 10 50 50 ms JMKIA0066GB
					For 15 seconds after UN- LOCK	Battery voltage
					15 seconds or later after UNLOCK	0 V
113 (P)	Ground	Optical sensor signal	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
114 (R)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V
					ON (Clutch pedal is de- pressed)	Battery voltage
116 (SB)	Ground	Stop lamp switch 1	Input		_	Battery voltage
	Ground	Stop lamp switch 2	Input	Stop lamp switch ICC brake hold relay (With ICC)	OFF (Brake pedal is not depressed)	0 V
118 (BR)					ON (Brake pedal is de- pressed)	Battery voltage
					OFF	0 V
					ON	Battery voltage
119 (SB)	Ground	Front door lock as- sembly driver side (unlock sensor)	Input	Driver door	LOCK status	(V) 15 0 10 ms JPMIA0011GB 11.8 V
					UNLOCK status	0 V
121	Ground	Key slot switch	Innut	When Intelligent K	ey is inserted into key slot	Battery voltage
(SB)	Ground	NEY SIDE SWILCH	input	When Intelligent Key is not inserted into key slot		0 V
122	Ground	ACC feedback signal	Input	Ignition switch	OFF	0 V
(P)					ACC or ON	Battery voltage
123	Ground	Ind IGN feedback signal	Input	Ignition switch	OFF or ACC	0 V
(W)					ON	Battery voltage

Terminal No.		Description				Value	Λ
(Wire +	e color) –	Signal name	Input/ Output	Condition		(Approx.)	A
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closes)	(V) 15	В
						JPMIA0011GB	С
					ON (When passenger door opens)	0 V	
129 (O)	Ground	Trunk lid opener can- cel switch	Input	Trunk lid opener cancel switch	CANCEL	(V) 15 10 5 0 •••••••••••••••••••••••••••••	F
					ON	JPMIA0012GB 1.1 V	G
							Н
132 (V) Groun		Power window switch communication	Input/ Output	Ignition switch ON		(V) 15 10 5 0 10 10 10 10 10 10 10 10 10	I
						JPMIA0013GB 10.2 V	
				Ignition switch OFF or ACC		0 V	LZ.
					ON (When tail lamps OFF)	5.5 V	K
133 (L)						NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.	L
	GroundPush-button ignition switch illuminationOutputPush tion s nationGroundLOCK indicator lampOutputLOCH lamp	Push-button igni- tion switch illumi- nation	ON (When tail lamps ON)		Μ		
		LOCK indicator lamp	Output	LOCK indicator lamp		JPMIA0159GB	Ν
					OFF	0 V	
134					ON	0 V	0
(LG)					OFF	Battery voltage	
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V	Ρ
138	Ground	Ground Receiver and sensor power supply output	Output	Ignition switch	OFF	0 V	
(V)					ACC or ON	5.0 V	

Terminal No.		Description				Value	
(Wire color) + –		Signal name	Input/	Condition		(Approx.)	
+	-	olgharnamo	Output		Γ	,	
139 (L)	Ground	Tire pressure receiv- er signal	Input/ Output	Ignition switch ON	Standby state	(V) 6 4 2 0 • • 0.2s OCC3881D	
					When receiving the signal from the transmitter	(V) 4 2 0 4 0 1 1 1 1 1 1 1 1 1 1 1 1 1	
140	0 -	Selector lever P/N			P or N position	12.0 V	
(GR)	Ground	position signal	Input	Selector lever	Except P and N positions	0 V	
					ON	0 V	
141 (R)	Ground	Security indicator sig- nal	Output	Security indicator	Blinking	(V) 15 10 5 0 1 s JPMIA0014GB 11.3 V	
					OFF	Battery voltage	
					All switch OFF	0 V	
	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermit- tent dial 4)	Lighting switch 1ST		
					Lighting switch HI	(V) <mark></mark>	
142					Lighting switch 2ND		
(BR)							
					Turn signal switch RH	2 ms	
						10.7 V	
	Ground	d Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V	
143 (V)					Front wiper switch HI (Wiper intermittent dial 4)	(V)	
					Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7	10 5 0 2 ms JPMIA0032GB 10.7 V	

< ECU DIAGNOSIS >

(Wire color) Signal name Input/ Output Condition Value (Approx.) + - Signal name Input/ Output All switch OFF (Wiper intermittent dial 4) 0 V 144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Combination switch All switch OFF (Wiper intermittent dial 4) 0 V 144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Combination switch Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 1 • Wiper intermittent dial 6	А
+ - Signal name Output 144 Ground Combination switch OUTPUT 2 Output All switch OFF (Wiper intermittent dial 4) 0 V 144 Ground Combination switch OUTPUT 2 Output Combination switch Combination switch All switch OFF (Wiper intermittent dial 4) 0 V 144 Ground Combination switch OUTPUT 2 Output Combination switch Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 10	
144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Combination switch Combination Switch All switch OFF (Wiper intermittent dial 4) 0 V 144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 0 V	
144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Combination switch Front washer switch ON (Wiper intermittent dial 4) 144 (G) Combination switch OUTPUT 2 Output Combination switch Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 (V)	В
144 (G) Ground Combination switch OUTPUT 2 Output Combination switch Any of the conditions below with all switch OFF 10	C
10.7.V	D
All switch OFF 0 V	WT
Front wiper switch INT	
Front wiper switch I Q	_
145 Combination switch	F
(L) Ground OUTPUT 3 Output (Wiper intermit-	
tent dial 4)	G
	0
JPMIA0034GB	
All switch OFF 0 V	Н
Front fog lamp switch ON	
Lighting switch 2ND	
146 Combination switch switch Switch PASS	1
(SB) Ground OUTPUT 4 Output (Wiper intermit-	
tent dial 4)	J
Turn signal switch LH 2 ms	
JPMIA0035GB 10.7 V	
149 Tire pressure warn-	Κ
(W) Ground ing check switch Input – 5 V	
	1
150 (R) Ground Driver door switch Input Driver door switch OFF (When driver door closes) OFF (When driver door closes) Input Input	M
11.8 V	IN
ON (When driver door opens) 0 V	\cap
151 Ground Rear window defog- Output Rear window de- Output Control Co	<u> </u>
(G) ger relay ' togger Not activated Battery voltage	

Ρ

< ECU DIAGNOSIS >

Wiring Diagram - BCM -

*: This connector is not shown in "Harness Layout".



2007/05/18

< ECU DIAGNOSIS >



٢







JCMWA0838GE
	A
	В
	С
	D
	WT
	F
	G
	Н
VLED LED R PORE R PORE R PORE R PORE SIGNAL VITPOT 1 VITPOT 2 VITPOT 2 VITPO	I
RING./25 ERNSOR ERNSOR RECEIVEN	J
31 32 33 33 33 32 33 34 35 10 31 32 33 10 10 32 33 33 10 10 33 34 35 10 10	К
	L
(OL MODU) HRoL MODU) HRoL MODULE) HRoL MODULE) HROL MODULE) HROL MODULE) HROL MODULE) HROL MODULE) HROL	Μ
DY CONTF BEAM GROY CON BEAM GROY CON AUTO LI BEAM GROY CON AUTO LI BEAM GROY CON AUTO LI BEAM GROY CON AUTO LI BEAM GROY CON BEAM GROY CON BEAM GROY CON AUTO LI BEAM GROY CON BEAM GROY	Ν
BCM (BO Connector Name Connector Name Connector Name Connector Type Connector Type Connector Type Connector Type Connector Name Connector Nam	0
	39GE
	:0000000001903108 P

Ρ INFOID:000000001903108

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTTENA AMP	Inhibit engine cranking	Erase DTC



< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals have been received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	 500 ms after the following CAN signal communication status has become consistent Starter control relay signal Starter relay status signal
B2563: HI VOLTAGE	Inhibit engine crankingInhibit steering lock	500 ms after the power supply voltage decreases to less than 18 V
B2601: SHIFT POSITION	Inhibit steering lock	 500 ms after the following signal reception status becomes consistent Selector lever P position switch signal P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	 5 seconds after the following BCM recognition conditions are fulfilled Ignition switch is in the ON position Selector lever P position switch signal: Except P position (battery voltage) Vehicle speed: 4 /h or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	 500 ms after the following BCM recognition conditions are fulfilled Ignition switch is in the ON position Selector lever P position switch signal: Except P position (battery voltage) Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	 500 ms after any of the following BCM recognition conditions is fulfilled Status 1 Ignition switch is in the ON position Selector lever P/N position signal: P and N position (battery voltage) P range signal or N range signal (CAN): ON Status 2 Ignition switch is in the ON position Selector lever P/N position signal: Except P and N positions (0 V) P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	 500 ms after any of the following BCM recognition conditions is fulfilled Ignition switch is in the ON position Power position: IGN Selector lever P/N position signal: Except P and N positions (0 V) Interlock/PNP switch signal (CAN): OFF Status 2 Ignition switch is in the ON position Selector lever P/N position signal: P or N position (battery voltage) PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	 500 ms after the following CAN signal communication status has become consistent Steering lock relay signal (Request signal) Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	 500 ms after the following CAN signal communication status has become consistent Steering lock relay signal (Request signal) Steering lock relay signal (Condition signal)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation	0
B2608: STARTER RELAY	Inhibit engine cranking	 500 ms after the following signal communication status becomes consistent Starter motor relay control signal Starter relay status signal (CAN) 	B
B2609: S/L STATUS	Inhibit engine crankingInhibit steering lock	 When the following steering lock conditions agree BCM steering lock control status Steering lock condition No. 1 signal status Steering lock condition No. 2 signal status 	С
B260A: IGNITION RELAY	Inhibit engine cranking	 500 ms after the following conditions are fulfilled IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) 	D
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilledPower position changes to ACCReceives engine status signal (CAN)	WT
B2612: S/L STATUS	 Inhibit engine cranking Inhibit steering lock 	 When any of the following conditions is fulfilled Steering lock unit status signal (CAN) is received normally The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R) 	F
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal	G
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM be- comes normal	Н
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control in- side BCM becomes normal	
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization	
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilledPower position changes to ACCReceives engine status signal (CAN)	J

DTC Inspection Priority Chart

INFOID:000000001903109

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC	L
1	B2562: LOW VOLTAGE B2563: HI VOLTAGE	
2	U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)	M
3	 B2190: NATS ANTTENA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM 	Ν

0

< ECU DIAGNOSIS >

Priority	DTC
4	 B2013: ID DISCORD BCM-S/L B2014: CHAIN OF S/L-BCM B2553: IGNITION RELAY B2555: STOP LAMP B2555: STOP LAMP B2555: STARTER CONT RELAY B2601: SHIFT POSITION B2602: SHIFT POSI TATUS B2603: SHIFT POSI STATUS B2604: PNP SW B2606: S/L RELAY B2606: S/L RELAY B2607: S/L RELAY B2608: STARTER RELAY B2609: S/L STATUS B2609: STEERING LOCK UNIT B2600: STEERING LOCK UNIT B2601: GN RELAY CIRC B2611: ACC RELAY CIRC B2616: IGN RELAY CIRC B2616: BLOWER RELAY CIRC B2616: BCM B2616: BCM B2619: BCM B2619: BCM B2619: BCM B2611: VEHICLE TYPE B2611: VEHICLE SPEED SIG ERR U0415: VEHICLE SPEED SIG ERR
5	 C1704: LOW PRESSURE FL C1705: LOW PRESSURE FR C1706: LOW PRESSURE RR C1707: LOW PRESSURE RL C1708: [NO DATA] FL C1709: [NO DATA] FR C1710: [NO DATA] RR C1711: [NO DATA] RR C1712: [CHECKSUM ERR] FL C1713: [CHECKSUM ERR] FR C1714: [CHECKSUM ERR] RR C1715: [CHECKSUM ERR] RR C1716: [PRESSDATA ERR] FL C1717: [PRESSDATA ERR] FR C1719: [PRESSDATA ERR] RR C1720: [CODE ERR] FR C1721: [CODE ERR] FR C1722: [CODE ERR] FR C1723: [CODE ERR] RR C1724: [BATT VOLT LOW] FL C1725: [BATT VOLT LOW] FR C1726: [BATT VOLT LOW] RR C1727: [BATT VOLT LOW] RL C1724: CONTROL UNIT
6	 B2621: INSIDE ANTENNA B2622: INSIDE ANTENNA B2623: INSIDE ANTENNA

< ECU DIAGNOSIS >

DTC Index

INFOID:000000001903110

А

В

NOTE:

The details of time display are as follows.

CRNT: A malfunction is detected now

• PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. The details of Freeze Frame Data and IGN Counter. Refer to BCS-13, "COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)".

						С
CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page	D
No DTC is detected. further testing may be required.	_	_	_	_	_	\\/T
U1000: CAN COMM CIRCUIT	—	_	—	—	BCS-33	
U1010: CONTROL UNIT (CAN)	—	-	—	—	BCS-34	-
U0415: VEHICLE SPEED SIG	—	—	—	—	BCS-35	F
B2013: ID DISCORD BCM-S/L	×	×	—	—	<u>SEC-54</u>	-
B2014: CHAIN OF S/L-BCM	×	×	—	—	<u>SEC-55</u>	
B2190: NATS ANTTENA AMP	×	_	_		<u>SEC-46</u>	G
B2191: DIFFERENCE OF KEY	×	_	_	_	<u>SEC-49</u>	-
B2192: ID DISCORD BCM-ECM	×	_	_	_	<u>SEC-50</u>	Н
B2193: CHAIN OF BCM-ECM	×	_	_		<u>SEC-52</u>	-
B2553: IGNITION RELAY	_	×	_	_	PCS-50	-
B2555: STOP LAMP		×	_	_	<u>SEC-58</u>	·
B2556: PUSH-BTN IGN SW	—	×	×	—	<u>SEC-60</u>	-
B2557: VEHICLE SPEED	×	×	×	—	<u>SEC-62</u>	J
B2560: STARTER CONT RELAY	×	×	×	—	<u>SEC-63</u>	
B2562: LOW VOLTAGE	—	×	—	—	BCS-36	-
B2563: HI VOLTAGE	×	×	×	—	BCS-37	K
B2601: SHIFT POSITION	×	×	×	—	<u>SEC-64</u>	-
B2602: SHIFT POSITION	×	×	×	—	<u>SEC-67</u>	
B2603: SHIFT POSI STATUS	×	×	×	—	<u>SEC-69</u>	- L
B2604: PNP SW	×	×	×	_	<u>SEC-72</u>	-
B2605: PNP SW	×	×	×	_	<u>SEC-74</u>	M
B2606: S/L RELAY	×	×	×	—	<u>SEC-76</u>	-
B2607: S/L RELAY	×	×	×	—	<u>SEC-77</u>	NI
B2608: STARTER RELAY	×	×	×	—	<u>SEC-79</u>	N
B2609: S/L STATUS	×	×	×	_	<u>SEC-81</u>	-
B260A: IGNITION RELAY	×	×	×	_	PCS-52	0
B260B: STEERING LOCK UNIT		×	×	—	<u>SEC-85</u>	-
B260C: STEERING LOCK UNIT	_	×	×	_	<u>SEC-86</u>	-
B260D: STEERING LOCK UNIT		×	×		<u>SEC-87</u>	Р
B260F: ENG STATE SIG LOST	×	×	×	—	<u>SEC-88</u>	-
B2611: ACC RELAY	—	×	_	—	PCS-54	
B2612: S/L STATUS	×	×	×	—	<u>SEC-90</u>	
B2614: ACC RELAY CIRC	—	×	×	_	PCS-57	•
B2615: BLOWER RELAY CIRC	—	×	×		PCS-60	-

Revision: 2007 June

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2616: IGN RELAY CIRC	—	×	×	_	PCS-63
B2617: STARTER RELAY CIRC	×	×	×	—	<u>SEC-94</u>
B2618: BCM	×	×	×	_	PCS-66
B2619: BCM	×	×	×	_	<u>SEC-96</u>
B261A: PUSH-BTN IGN SW	—	×	×	_	<u>SEC-97</u>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<u>SEC-100</u>
B2621: INSIDE ANTENNA	—	×	—	_	DLK-59
B2622: INSIDE ANTENNA	—	×	—	_	DLK-61
B2623: INSIDE ANTENNA	—	×	—	_	DLK-63
B26E1: ENG STATE NO RES	×	×	×	_	<u>SEC-89</u>
C1704: LOW PRESSURE FL	—	—	—	×	<u>WT-15</u>
C1705: LOW PRESSURE FR	—	—	—	×	<u>WT-15</u>
C1706: LOW PRESSURE RR	—	—	—	×	<u>WT-15</u>
C1707: LOW PRESSURE RL	_	_	—	×	<u>WT-15</u>
C1708: [NO DATA] FL	—	—	—	×	<u>WT-17</u>
C1709: [NO DATA] FR	—	—	—	×	<u>WT-17</u>
C1710: [NO DATA] RR	—	—	—	×	<u>WT-17</u>
C1711: [NO DATA] RL	_	—	—	×	<u>WT-17</u>
C1712: [CHECKSUM ERR] FL	_	—	—	×	<u>WT-20</u>
C1713: [CHECKSUM ERR] FR	_	—	—	×	<u>WT-20</u>
C1714: [CHECKSUM ERR] RR	_	_	—	×	<u>WT-20</u>
C1715: [CHECKSUM ERR] RL	_	_	—	×	<u>WT-20</u>
C1716: [PRESSDATA ERR] FL	_	_	—	×	<u>WT-23</u>
C1717: [PRESSDATA ERR] FR	—	_	—	×	<u>WT-23</u>
C1718: [PRESSDATA ERR] RR	_	_	—	×	<u>WT-23</u>
C1719: [PRESSDATA ERR] RL	_	_	—	×	<u>WT-23</u>
C1720: [CODE ERR] FL	_	_	—	×	<u>WT-25</u>
C1721: [CODE ERR] FR	_	_	—	×	<u>WT-25</u>
C1722: [CODE ERR] RR	_	—	—	×	<u>WT-25</u>
C1723: [CODE ERR] RL	_	_	_	×	<u>WT-25</u>
C1724: [BATT VOLT LOW] FL	_	—	—	×	<u>WT-28</u>
C1725: [BATT VOLT LOW] FR			_	×	<u>WT-28</u>
C1726: [BATT VOLT LOW] RR	_	_	_	×	<u>WT-28</u>
C1727: [BATT VOLT LOW] RL	_	—	-	×	<u>WT-28</u>
C1729: VHCL SPEED SIG ERR	_	_	_	×	<u>WT-31</u>
C1734: CONTROL UNIT			_	×	<u>WT-32</u>

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS TPMS

Symptom Table

INFOID:000000001687002

А

Symptom	Reference	
Low tire pressure warning lamp does not turn on for approx.1 second when ignition switch is turned on.	<u>WT-81</u>	_ 0
Low tire pressure warning lamp stays on when ignition switch is turned on.	<u>WT-82</u>	_
Low tire pressure warning lamp blinks when ignition switch is turned on.	<u>WT-84</u>	D
Turn signal lamp blinks when ignition switch is turned on.	<u>WT-86</u>	_
ID registration can not be completed.	<u>WT-87</u>	10/-
		- V

LOW TIRE PRESSURE WARNING LAMP SYMPTOM CHART

Diagnosis Item	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action	F
	Low tire pressure warning lamp comes on immediately and turns off after 1 sec- ond.	ON 1 sec > stays OFF SEIA0592E	All wheel transmit- ters are "activated" (working).	None (system OK)	G
	Low tire pressure warning lamp blinks on for 2 seconds, then turns off for 0.2 seconds-repeats.	ON 2 sec > OFF 0.2 sec	All wheel transmit- ters are not activat- ed.	Activate all wheel tire pressure transmitters. Refer to <u>WT-5,</u> <u>"TRANSMITTER WAKE UP</u> <u>OPERATION : Special Repair</u> <u>Requirement</u> ".	I J K
Low tire pres- sure warning lamp	Low tire pressure warning lamp blinks 1 time.	Blinks 1 time ON 0.3 sec > OFF 1.3 sec SEIA0594E	Tire pressure trans- mitter front LH is not activated.	Activate tire pressure transmit- ter front LH. Refer to <u>WT-5,</u> <u>"TRANSMITTER WAKE UP</u> <u>OPERATION : Special Repair</u> <u>Requirement</u> ".	L
	Low tire pressure warning lamp blinks 2 times.	Blinks 2 times ON 0.3 sec > OFF 0.3 sec	Tire pressure trans- mitter front RH is not activated.	Activate tire pressure transmit- ter front RH. Refer to <u>WT-5.</u> <u>"TRANSMITTER WAKE UP</u> <u>OPERATION : Special Repair</u> <u>Requirement"</u> .	N
	Low tire pressure warning lamp blinks 3 times.	Blinks 3 times ON 0.3 sec > OFF 0.3 sec	Tire pressure trans- mitter rear RH is not activated.	Activate tire pressure transmit- ter rear RH. Refer to <u>WT-5.</u> <u>"TRANSMITTER WAKE UP</u> <u>OPERATION : Special Repair</u> <u>Requirement"</u> .	Ρ

TPMS

< SYMPTOM DIAGNOSIS >

Diagnosis Item	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
	Low tire pressure warning lamp blinks 4 times.	Blinks 4 times ON 0.3 sec > OFF 0.3 sec SEIA0597E	Tire pressure trans- mitter rear LH is not activated.	Activate tire pressure transmit- ter rear LH. Refer to <u>WT-5.</u> <u>"TRANSMITTER WAKE UP</u> <u>OPERATION : Special Repair</u> <u>Requirement"</u> .
Low tire pres-	Low tire pressure warning lamp comes on and does not turn off.	Comes ON and stays ON	Tire pressure is low.	Check tire pressure with CON- SULT-III. Refer to <u>WT-13. "AIR</u> <u>PRESSURE MONITOR :</u> <u>CONSULT-III Function (BCM -</u> <u>AIR PRESSURE MONITOR)"</u> .
lamp			The fuse for combi- nation meter from battery is pulled out.	Check the fuse for combina- tion meter from battery. Install or replace (if needed).
			BCM connector pulled out.	Check BCM connector. Re- connect if needed.
	warning lamp blinks on for 0.5 seconds then turns off for 0.5 seconds-repeats for 1 minute, and then stays on.	Blinks 1 min ON 0.5 sec > OFF 0.5 sec and stays ON SEIA0788E	Low tire pressure or tire pressure moni- toring system mal- function.	 Perform CONSULT-III Self- Diagnosis. Refer to <u>WT-13</u>, <u>"AIR PRESSURE MONI- TOR : CONSULT-III Func- tion (BCM - AIR <u>PRESSURE MONITOR)"</u>.</u> Perform ID Registration if needed. Refer to <u>WT-5</u>, <u>"ID</u> <u>REGISTRATION PROCE- DURE : Special Repair Re- quirement"</u>.
Turn signal lamp	Turn signal lamp does not blink 2 times or buzzer does not sound after trans- mitter activation.		 Tool J-45295 [SST] Ignition OFF during activa- tion. Tool J-45295 [SST] not posi- tioned correct- ly. Transmitters already activat- ed. 	 Install new battery. Check ignition is ON during activation. Position tool correctly during activation. Nothing.

NOTE:

If more than one wheel transmitter is NOT activated, the low tire pressure warning lamp blinking patterns for those wheels will combine. (Example: one blink/OFF/three blinks = Tire pressure transmitter rear LH and rear RH are not activated.)

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

Descri

Description
DESCRIPTION
The low tire pressure warning lamp illuminates for approximately 1 second and then turns OFF when the igni tion switch is turned ON. This is to check that no abnormal condition is present in the tire pressure monitoring system.
The lamp bulb may be burnt out or the tire pressure monitoring system may be malfunctioning if the low tire pressure warning lamp does not illuminate when the ignition switch is turned ON.
Diagnosis Procedure
1.CHECK SELF-DIAGNOSIS RESULTS
 With CONSULT-III On the "SELECT DIAG" mode, select the "SELF-DIAG RESULTS" screen. Check display contents in self-diagnostic results.
Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?
 YES >> Perform trouble diagnosis for CAN communication system. Refer to <u>LAN-16, "Trouble Diagnosis</u> <u>Flow Chart"</u>. NO >> GO TO 2.
2. CHECK COMBINATION METER
Check unified meter function. Refer to MWI-37, "CONSULT-III Function (METER/M&A)".
Is the inspection result normal?
YES >> GO TO 3.
NO >> Repair or replace damaged parts.
${f 3.}$ CHECK LOW TIRE PRESSURE WARNING LAMP

1. Turn ignition switch "OFF". 2. Disconnect BCM harness connectors.

Turn ignition switch "ON". (Do not start engine.) 3.

Does low tire pressure warning lamp turn on?

YES >> GO TO 4.

NO >> Check combination meter and repair or replace. Refer to MWI-35, "Diagnosis Description".

4.CHECK SYMPTOM

Check again.

Is the inspection result normal?

YES >> INSPECTION END NO >> GO TO 5.

5.CHECK BCM

Check BCM input/output signal. Refer to WT-45, "Reference Value". Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 6.

6.CHECK BCM HARNESS CONNECTOR

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

>> Replace BCM. Refer to BCS-79, "Removal and Installation". YES

NO >> Repair or replace damaged parts. А

В

D

WT

F

Н

Κ

L

Μ

Ν

Ρ

LOW TIRE PRESSURE WARNING LAMP STAYS ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP STAYS ON

Description

INFOID:000000001687005

DESCRIPTION

The tire pressure monitoring system is checked and the warning lamp is illuminated for approximately 1 second when the ignition switch is turned ON. The low tire pressure warning lamp turns OFF after the system check finishes.

The system may be malfunctioning if the low tire pressure warning lamp does not turn off approximately 1 second after the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000001687006

1.CHECK SYSTEM FOR BCM

With CONSULT-III

1. On "SELF-DIAG" mode, select the "SELF-DIAG RESULTS" screen.

2. Check display contents in self-diagnostic results.

Does self-diagnostic results indicate any malfunction?

YES >> Perform trouble diagnosis. Refer to <u>WT-13, "AIR PRESSURE MONITOR : CONSULT-III Function</u> (<u>BCM - AIR PRESSURE MONITOR)</u>".

NO >> GO TO 2.

2. CHECK ID REGISTRATION

Perform ID registration all transmitters. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special Repair</u> <u>Requirement"</u>.

Does low tire pressure warning lamp turn OFF?

YES >> INSPECTION END

NO >> GO TO 3.

3.CHECK POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector.
- 3. Check voltage between BCM and harness connector terminals and ground.

(+) BCM		(-)	
			Voltage (Approx.)
Connector	Terminal	Ground	
M118	1	Crodina	Battony voltago
M119	11		Dattery voltage

Is the power supply normal?

YES >> GO TO 4.

- NO >> Check the following. If any items are damaged, repair or replace damage parts.
 - 40 A fusible link [No. K located in the fuse block]. Refer to <u>PG-92, "Fuse and Fusible Link</u> <u>Arrangement"</u>.
 - 10 A fuse [No. 10 located in the fuse block (J/B)]. Refer to <u>PG-91, "Fuse, Connector and Termi-nal Arrangement"</u>.
 - Harness for short or open between battery and BCM harness connector M118 terminal 1.
 - Harness for short or open between battery and BCM harness connector M119 terminal 11.
 - Check battery voltage.

4.CHECK GROUND CIRCUIT

1. Turn ignition switch "OFF".

- 2. Disconnect BCM harness connector.
- 3. Check continuity between BCM harness connector M119 terminal 13 and ground.

LOW TIRE PRESSURE WARNING LAMP STAYS ON

< SYMPTOM DIAGNOSIS >

BCM			Continuity
Connector	Terminal	Ground	Continuity
M119	13		Existed
Also check harness for sh	ort to power.		
	<u> </u>		
NO >> Repair open circui	t or short to power in ha	rness or connectors.	
5. CHECK SYMPTOM			
Check again.			
Is the inspection result normal	<u>?</u>		r
YES >> INSPECTION EN	2		
NO $>>$ GO 10 6.			
Check BCM input/output signa	I. Refer to <u>WT-45, "Refe</u> 2	erence Value".	
YES >> GO TO 5	<u>'</u>		
NO >> GO TO 7.			
7. CHECK BCM HARNESS C	ONNECTOR		
Check BCM pin terminals for c	lamage or loose connec	tion with harness connector.	
Is the inspection result normal	<u>?</u>		
YES >> Replace BCM. Re	fer to <u>BCS-79, "Remova</u>	al and Installation".	
	uamageu parts.		

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP BLINKS

Description

INFOID:000000001687007

DESCRIPTION

The low tire pressure warning lamp illuminates or blinks.

However, a check is necessary because the symptom may not be caused by a system malfunction. For example, the transmitter may not be initialized.

NOTE:

If low tire pressure warning lamp blinks below, the system is normal.

Blink Mode A
This mode shows transmitter status is in OFF- mode.
Perform transmitter wake up operation. Refer to <u>WT-5</u>, <u>"TRANS-MITTER WAKE UP OPERATION : Special Repair Requirement"</u>.



Diagnosis Procedure

INFOID:000000001687008

1.CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- 1. Turn ignition switch "ON".
- 2. Check voltage between tire pressure warning check switch connector M23 terminal 1 and ground.

(+)		(-)		
Tire pressure warning check switch			Voltage (Approx.)	
Connector	terminal	Ground		
M23	1		5.0V	

Is the reference voltage outputted?

YES >> Repair or replace BCM circuit. Replace BCM. Refer to <u>BCS-79, "Removal and Installation"</u>. NO >> GO TO 2.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector.
- 3. Check continuity between BCM harness connector M123 terminal 149 and tire pressure warning check switch connector M23 terminal 1.
- 4. Check harness for short to ground.

BCM		Tire pressure warning check switch		Continuity	
Connector	terminal	Connector	terminal	Continuity	
M123	149	M23	1	Existed	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

```
3. СНЕСК ВСМ
```

Check BCM input/output signal. Refer to WT-45, "Reference Value".

Is the inspection result normal?

YES >> GO TO 1.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >	
NO >> GO TO 4.	
4. CHECK BCM HARNESS CONNECTOR	
Check BCM pin terminals for damage or loose connection with harness connector.	
Is the inspection result normal?	В
 YES >> Replace BCM. Refer to <u>BCS-79, "Removal and Installation"</u>. NO >> repair or replace damaged parts. 	
	С
	D
	WT
	F
	G
	Н
	I

J

Κ

L

M

0

Ρ

< SYMPTOM DIAGNOSIS >

TURN SIGNAL LAMP BLINKS

Description

DESCRIPTION

The turn signal lamp blinks when the ignition switch is turned ON. The BCM connector or circuit may have a malfunction.

Diagnosis Procedure

INFOID:000000001687010

INFOID:000000001687009

1.CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- 1. Turn ignition switch "ON".
- 2. Check voltage between tire pressure warning check switch connector M23 terminal 1 and ground.

(+)		(-)	
Tire pressure warning check switch			Voltage (Approx.)
Connector	Terminal	Ground	
M23 1			5 V

Is the reference voltage outputted?

YES >> Repair or replace BCM circuit. Replace BCM. Refer to <u>BCS-79. "Removal and Installation"</u>. NO >> GO TO 2.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect BCM harness connector.
- 3. Check continuity between BCM harness connector M123 terminal 149 and tire pressure warning check switch connector M23 terminal 1. Also check harness for short to ground.

BCM		Tire pressure warning check switch		Continuity
Connector	Terminal	Connector	Terminal	Existed
M123	149	M23	1	LAISIEU

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK SYMPTOM

Check again.

Does the turn signal lamp remain blinking?

YES >> Check turn signal lamp operation. Refer to <u>BCS-21, "FLASHER : CONSULT-III Function (BCM - FLASHER)"</u>.

NO >> INSPECTION END

ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

Description

DESCRIPTION	
The ID of the transmitter installed in each wheel cannot be registered in the tire p Inspect the transmitter or the tire pressure monitoring system circuit.	ressure monitoring system.
Diagnosis Procedure	INFOID:000000001687012

1.CHECK ID REGISTRATION

- Perform ID registration of all transmitter. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.
- 2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Monitored item	Condition	Display value	
AIR PRESS FL			F
AIR PRESS FR	Start engine and drive at 40 km/h (25 MPH) or more for	Approximately equal to the indication on vehicle	
AIR PRESS RR	several minutes.	information display.	G
AIR PRESS RL			9
Does "DATA MONITO	R" displayed the standardized value without tu	rning low tire pressure warning lamp ON?	
YES >> INSPECT	ON END		Н

NO >> GO TO 2.

2. CHECK TRANSMITTER

1. Perform trouble diagnosis for transmitter. Refer to <u>WT-17, "Diagnosis Procedure"</u>.

 Perform ID registration of all transmitter. Refer to <u>WT-5, "ID REGISTRATION PROCEDURE : Special</u> <u>Repair Requirement"</u>.

Can ID registration of all transmitters be completed?

- YES >> INSPECTION END
- NO >> Repair or replace the malfunctioning connector. Repair or replace the malfunctioning part. GO TO 1.

А

В

D

Κ

L

Μ

Ν

Ρ

INFOID:000000001687011

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

LOW TIRE PRESSURE WARNING LAMP BLINKS

The tire pressure monitoring system is not malfunctioning if the low tire pressure warning lamp blinks in the pattern as shown in the figure.

The incident occurs because the transmitter of each wheel is not wake up.

Perform transmitter wake up operation. Refer to <u>WT-5</u>, <u>"TRANSMIT-TER WAKE UP OPERATION : Special Repair Requirement"</u>.



INFOID:000000001687013

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING < SYMPTOM DIAGNOSIS >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000001687014

А

В

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Beteresterion* 2WD models: FSU-23, FSU-24. WT-92, "Inspection* WT-92, "Inspection* WT-93, "Adjustment* WT-93, "Adjustment* WT-93, "Adjustment* WT-93, "Tire* WT-93, "Adjustment* NUT-93, "Tire* WT-93, "Tire* NVH in DLN section. NVH in PLN section. NVH in PLN section. NVH in RAX and FSU sections. NVH in RAX and RSU sections.	Refer to TIRES in this chart. Refer to ROAD WHEEL in this cha	NVH in FAX, RAX section.	NVH in BR section.	NVH in ST section.	C D WT
March State Improper installation, looseness Improper installation, looseness Out-of-round Improper installation, looseness Out-of-round Improper installation, looseness Improper installation, looseness Improper installation, looseness Out-of-round Improper installation, looseness Improper installation, looseness Improper installation, looseness Incorrect tire pressure Improper installation, looseness Incorrect tire size Improper installation, loosenes Incorrect tire size Improper installatins <	TIRES ROAD WHEELS	DRIVE SHAFT	BRAKE	STEERING	G H J
Noise x <td>×</td> <td>< ×</td> <td>×</td> <td>×</td> <td>-</td>	×	< ×	×	×	-
Shake x x x x x x x x x x x x	×	< ×	×	×	- K
Vibration × × × ×		×		×	
TIRES Shimmy ×	×	<	×	×	_
Judder x x x x x x x x x x x	×	<	×	×	L
Symptom Poor quality ride or handling × × × × × × ×	× ×	<			_
Noise x <td>×</td> <td>×</td> <td>×</td> <td>×</td> <td>- M</td>	×	×	×	×	- M
Shake x x x x x x x x x x	×	×	×	×	_
ROAD Shimmy, Judder × × ×	×		×	×	- N
Poor quality ride or handling × × × × × × ×	×				

×: Applicable

Ρ

< PRECAUTION > PRECAUTION PRECAUTIONS

Service Notice or Precautions

INFOID:000000001687015

- Low tire pressure warning lamp blinks 1min, then turns ON when occurring any malfunction except low tire
 pressure. Delete the memory with CONSULT-III, or register the ID to turn low tire pressure warning lamp
 OFF. Refer to <u>WT-11, "AIR PRESSURE MONITOR : Diagnosis Description"</u>, <u>WT-5, "ID REGISTRATION
 PROCEDURE : Special Repair Requirement"</u>.
- ID registration is required when replacing or rotating wheels, replacing transmitter or BCM. Refer to
- Replace grommet seal, valve core and cap of transmitter in TPMS every tire replacement by reaching wear limit of tire. Refer to <u>WT-96, "Exploded View"</u>.

PREPARATION

< PREPARATION >		
PREPARATI	Ο	N

PREPARATION

Power tool

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description	С
_ (J-45295)	2	ID registration	D
Transmitter activation tool			WT
	SEIA0462E		F
Commercial Service Tools		INFOID:000000001687017	
			G
Tool name		Description	

Loosening bolts and nuts

А

В

Н

J

Κ

L

Μ

Ν

Ο

Ρ

INFOID:000000001687016

<u>< ON-VEHICLE MAINTENANCE ></u> ON-VEHICLE MAINTENANCE > ROAD WHEEL

Inspection

INFOID:000000001687018

ALUMINUM WHEEL

- 1. Check tires for wear and improper inflation.
- 2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
- a. Remove tire from aluminum wheel and mount on a tire balance machine.
- b. Set dial indicator as shown in the figure.
- c. If the total runout value exceeds the limit, replace aluminum wheel.

Lateral runout limit (A) Refer to <u>WT-98, "Road Wheel"</u>. Vertical runout limit (B) Refer to <u>WT-98, "Road Wheel"</u>.



ON-VEHICLE REPAIR ROAD WHEEL TIRE ASSEMBLY

Adjustment

BARANCING WHEELS (BONDING WEIGHT TYPE)

Preparation Before Adjustment

Using releasing agent, remove double-faced adhesive tape from the road wheel. **CAUTION:**

- Be careful not scratch the road wheel during removal.
- After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.

Wheel Balance Adjustment

- If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for road wheels.
- 1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
- 2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by 5/3 to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install in to the designated outer position of, or at the designated angle in relation to the road wheel. CAUTION:

• Do not install the inner balance weight before installing the outer balance weight.

- Before installing the balance weight, be sure to clean the mating surface of the road wheel.
- a. Indicated un balance value \times 5/3 = balance weight to be installed

Calculation example:

23 g $(0.81 \text{ oz}) \times 5/3 = 38.33$ g $(1.35 \text{ oz}) \Rightarrow 37.5$ g (1.32 oz) balance weight (closer to calculated balance weight value) **NOTE:** Note that balance weight value must be closer to the calculated balance weight value. **Example:**

 $\begin{array}{l} 36.2 \Rightarrow 35 \text{ g} (1.23 \text{ oz}) \\ 36.3 \Rightarrow 37.5 \text{ g} (1.32 \text{ oz}) \end{array}$

b. Installed balance weight in the position.



А

В

D

WT

E

Н

L

M

Ν

Ρ

INFOID:000000001687019

ROAD WHEEL TIRE ASSEMBLY

< ON-VEHICLE REPAIR >

• When installing balance weight (1) to road wheels, set it into the grooved area (A) on the inner wall of the road wheel as shown in the figure so that the balance weight center (B) is aligned with the tire balance machine indication position (angle)(C).

CAUTION:

- Always use genuine NISSAN adhesion balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



 c. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.
 CAUTION:

Do not install one balance weight sheet on top another.

- 3. Start tire balance machine again.
- Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).
 CAUTION:



Do not install more than two balance weight.

- 5. Start tire balance machine. Make sure that inner and outer residual unbalance values are 5 g (0.17 oz) each or below.
- 6. If either residual unbalance value exceeds 5 g (0.17 oz), repeat installation procedures.

Wheel balance	Dynamic (At flange)	Static (At flange)
Maximum allowable un- balance	Refer to <u>WT-98, "Road Wheel"</u> .	

TIRE ROTATION (for 18 inch wheel models)

- Follow the maintenance schedule for tire rotation service intervals. Refer to <u>MA-6, "Schedule 1"</u>.
- When installing the wheel, tighten wheel nuts to the specified torque.

CAUTION:

- Do not include the T-type spare tire when rotating the tires.
- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.
- Use NISSAN genuine wheel nuts for aluminum wheels.

Wheel nuts tighting torque : Refer to <u>WT-98, "Road</u> Wheel".



ROAD WHEEL TIRE ASSEMBLY

< ON-VEHICLE REPAIR >

 Perform the ID registration, after tire rotation. Refer to WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement".

TIRE ROTATION (for 19 inch wheel models)

• Tire cannot be rotated in vehicle, as front tire are different size from rear tire and the direction of wheel rota-В tion is fixed in each tire.



- Do not include the T-type spare tire when rotating the tires.
- Use NISSAN genuine wheel nuts for aluminum wheels.

Safety Device Preventing from Being Incorrectly installed

FRONT BRAKE DISC ROTOR AND FRONT WHEEL

 Front and rear wheel size for this model differs, therefore special pin (1) has been installed on the front brake disc rotor (2). To accommodate this pin a hole (3) has been provided on the front wheel (4) (the rear wheel does not have this hole.) and in some case the rear wheel is being mistakenly installed on the front.



T-TYPE SPARE TIRE WHEEL

• Regarding spare tire (for emergency) wheel, wrong assembly protection pin through hole (1) has been set in addition to regular bolt holes (2) in order to enable installation to front wheel. NOTE:

Protection pin through hole of 18 inch spare wheel is non-through type.



А

D

WΤ

F

Н

Κ

TRANSMITTER

< REMOVAL AND INSTALLATION > **REMOVAL AND INSTALLATION** TRANSMITTER

Exploded View



Removal and Installation

INFOID:000000001687021

REMOVAL

- 1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
- 2. Gently bounce tire so that transmitter falls to bottom of tire. Place on tire changing machine and break both tire beads ensuring that the transmitter remains at the bottom of the tire.



- 3. Turn tire so that valve hole is at bottom and bounce so that transmitter (1) is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270 degree from mounting/dismounting head (2).
- 4. Lubricate tire well and remove first side of the tire. Reach inside the tire and remove the transmitter.



INSTALLATION

TRANSMITTER

< REMOVAL AND INSTALLATION >

1. Put first side of tire onto rim.



- 2. Mount transmitter on rim and tighten nut. **CAUTION:** Speed for tightening nut should be less than 15 rpm.
- 3. Place wheel on turntable of tire machine. Ensure that transmitter (1) is 270 degree from mounting head (2) when second side of tire is fitted. NOTE:

Do not touch transmitter at mounting head.

- 4. Lubricate tire well and fit second side of tire as normal. Ensure that tire does not rotate relative to rim.
- 5. Inflate tire and fit to appropriate wheel position.



F

J

Κ

L

Μ

Ν

Ο

Ρ

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS) SERVICE DATA AND SPECIFICATIONS (SDS)

Road Wheel

INFOID:000000001685883

Kind of wheel		Aluminum	
Maximum radial runout limit	Lateral deflection	Less than 0.3 mm (0.012 in)	
	Vertical deflection		
Maximum allowable unbalance limit	Dynamic (At flange)	Less than 5 g (0.17 oz) (one side)	
	Static (At flange)	Less than 10 g (0.35 oz)	
Wheel nuts tighting torque		108 N·m (11 kg-m, 80 ft-lb)	

Tire

INFOID:000000001685884

Unit: kPa (kg/cm², psi)

Tire size	Air pressure		
	Front	Rear	
P225/50R18 94V	230 (2.3, 33)	230 (2.3, 33)	
225/45R19 92W	240 (2.4, 35)	_	
245/40R19 94W	-	240 (2.4, 35)	
T145/80D17	420 (4.2, 60)	420 (4.2, 60)	
T145/70R18	420 (4.2, 60)	420 (4.2, 60)	