

ELECTRICAL SYSTEM

SECTION **EL**

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

CONTENTS

PRECAUTIONS	3	EXTERIOR LAMP	34	FE
Supplemental Restraint System "AIR BAG".....	3	Clearance, License, Tail and Stop		
HARNES CONNECTOR	4	Lamps/Wiring Diagram.....	34	CL
Description.....	4	Back-up Lamp/Wiring Diagram.....	35	
STANDARDIZED RELAY	5	Front Fog Lamp/Wiring Diagram.....	36	
Description.....	5	Turn Signal and Hazard Warning		MT
POWER SUPPLY ROUTING	8	Lamps/Wiring Diagram.....	37	
Wiring Diagram.....	8	Cornering Lamp/Wiring Diagram.....	38	
Fuse.....	12	Combination Flasher Unit Check.....	39	AT
Fusible Link.....	12	Bulb Specifications.....	39	
BATTERY	13	INTERIOR LAMP	40	FA
How to Handle Battery.....	13	Illumination/Wiring Diagram.....	40	
Service Data and Specifications (SDS).....	16	Interior, Spot, Step and Trunk Room Lamps/		
STARTING SYSTEM	17	Wiring Diagram.....	42	RA
Wiring Diagram.....	17	Illuminated Entry System and Key		
Construction.....	19	Illumination/Wiring Diagram.....	43	
Service Data and Specifications (SDS).....	20	METER AND GAUGES — Needle Type —	44	BR
CHARGING SYSTEM	21	Combination Meter.....	44	
Wiring Diagram.....	21	Speedometer, Tachometer, Temp., and Fuel		
Construction.....	23	Gauges/Wiring Diagram.....	45	ST
Service Data and Specifications (SDS).....	24	Inspection/Fuel Gauge and Water		
COMBINATION SWITCH	25	Temperature Gauge.....	46	BF
Combination Switch/Check.....	25	Fuel Tank Gauge Unit Check.....	47	
Combination Switch/Replacement.....	26	Fuel Warning Lamp Sensor Check.....	47	
Steering Switch/Check.....	27	Thermal Transmitter Check.....	47	HA
HEADLAMP	29	Oil Pressure Switch Check.....	48	
Wiring Diagram (For U.S.A.).....	29	Vehicle Speed Sensor Signal Check.....	48	
Operation (Daytime light system for Canada).....	30	METER AND GAUGES — Digital Type —	49	EL
Schematic (Daytime light system for Canada).....	30	Combination Meter.....	49	
Wiring Diagram (For Canada).....	31	Schematic.....	52	IDX
Bulb Replacement.....	32	Wiring Diagram.....	53	
Aiming Adjustment.....	32	Trouble Diagnoses.....	54	

CONTENTS (Cont'd)

Connector and Harness Check	76	Window Antenna Repair	111
Self-check	76	AUTOMATIC SPEED CONTROL DEVICE (ASCD)	113
Fuel Tank Gauge Unit Check	78	Schematic	113
Fuel Warning Lamp Sensor Check	78	Wiring Diagram	114
Thermal Transmitter Check	78	ASCD Wire Adjustment.....	118
Oil Pressure Switch Check	79	Trouble Diagnoses.....	119
Vehicle Speed Sensor Signal Check	79	Actuator Check.....	123
WARNING LAMPS AND CHIME	80	THEFT WARNING SYSTEM	125
Warning Lamps/Schematic.....	80	Component Parts and Harness Connector	
Warning Lamps/Wiring Diagram	81	Location	125
Warning Chime/Wiring Diagram	83	Wiring Diagram	126
Diode Check	84	Trouble Diagnoses.....	128
Warning Chime Check	84	DIGITAL TOUCH ENTRY SYSTEM	145
TIME CONTROL SYSTEM	85	Component Parts and Harness Connector	
Description	85	Location	145
Wiring Diagram	86	Wiring Diagram	146
Trouble Diagnoses.....	87	Trouble Diagnoses.....	148
WIPER AND WASHER	100	LOCATION OF ELECTRICAL UNITS	166
Front Wiper and Washer/Wiring Diagram	100	Engine Compartment	166
Installation.....	101	Passenger Compartment.....	167
Washer Nozzle Adjustment	102	Luggage Compartment.....	168
HORN, CIGARETTE LIGHTER, CLOCK	103	HARNESS LAYOUT	169
Wiring Diagram	103	Outline	169
REAR WINDOW DEFOGGER	104	Engine Room Harness.....	170
Wiring Diagram	104	Air Bag Harness	173
Filament Check	105	Main Harness	174
Filament Repair.....	106	Engine Control Harness	178
AUDIO AND POWER ANTENNA	107	Instrument Harness.....	182
Audio/Wiring Diagram	107	Room Lamp and Sun Roof Harness	182
Power Antenna/Wiring Diagram	109	Door Harness (LH side).....	183
Location of Antenna.....	109	Door Harness (RH side)	184
Antenna Rod Replacement.....	110	SUPER MULTIPLE JUNCTION (SMJ)	Foldout page
Radio Fuse Check.....	110	JOINT CONNECTOR (J/C)	Foldout page

WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system)	EF & EC SECTION
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM	AT SECTION
ANTI-LOCK BRAKE SYSTEM	BR SECTION
TRUNK LID OPENER, POWER WINDOW, POWER DOOR LOCK, AUTOMATIC	
SEAT BELT SYSTEM, POWER SEAT, SUN ROOF, DOOR MIRROR	BF SECTION
HEATER AND AIR CONDITIONER	HA SECTION

PRECAUTIONS

Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- a. To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- b. Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- c. All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental loosening or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]




SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



GI

MA

EM

LC

EF &
EC

FE

CL

SEL881H

MT


TYPE OF STANDARDIZED RELAYS

1M ... 1 Make

2M 2 Make

1T 1 Transfer

1M·1B 1 Make 1 Break



FA

RA

BR

ST

BF

HA













EL

SEL882H

IDX

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M-1B				GRAY

STANDARDIZED RELAY

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

POWER SUPPLY ROUTING


Wiring Diagram

VG ENGINE



POWER SUPPLY ROUTING

Wiring Diagram (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram (Cont'd)


VE ENGINE

- (MU) : M/T model for U.S.A.
- (EX) : Except M/T model for U.S.A.
- J/C : Joint connector [Refer to last page (Foldout page).]



POWER SUPPLY ROUTING


Wiring Diagram (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
WT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


SEL690S

POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not install fuse in oblique direction; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.



Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.




CAUTION:

- If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.
- Never wrap periphery of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness, or vinyl or rubber parts.

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level.

- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)

- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

BATTERY

How to Handle Battery (Cont'd)


- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



SULPHATION

When a battery has been left unattended for a long period of time and has a specific gravity of less than 1.100, it will be completely discharged, resulting in sulphation on the cell plates.

Compared with a battery discharged under normal conditions, the current flow in a "sulphated" battery is not as smooth although its voltage is high during the initial stage of charging, as shown in the figure at the left.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.

BATTERY

How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

BATTERY

How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.


Service Data and Specifications (SDS)

Applied area	U.S.A.	Optional for U.S.A. & Canada	Optional for Canada
Type	55D23L	80D26L	95D31L
Capacity V-AH	12-50	12-65	12-80
Cold cranking current (For reference value) A	356	582	622

STARTING SYSTEM

Wiring Diagram

M/T MODEL FOR U.S.A.




J/C : Joint connector
(Refer to last page
(Foldout page).)

- GI
- MA
- EM
- LC
- FF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**
- IDX

STARTING SYSTEM

Wiring Diagram (Cont'd)



EXCEPT M/T MODEL FOR U.S.A.



SEL692S

STARTING SYSTEM

Construction



- ① Pinion stopper
- ② Pinion gear
- ③ Gear case
- ④ Clutch assembly
- ⑤ Thrust washer
- ⑥ Center bracket (P)
- ⑦ Pinion shaft

- ⑧ Planetary gear
- ⑨ Internal gear
- ⑩ Shift lever
- ⑪ Dust cover
- ⑫ Return spring
- ⑬ Adjusting plate

- ⑭ Magnetic switch assembly
- ⑮ Center bracket (A)
- ⑯ Yoke assembly
- ⑰ Armature assembly
- ⑱ Brush holder
- ⑲ Rear cover

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

STARTING SYSTEM

Service Data and Specifications (SDS)


STARTER

		S114-461A	S114-756
Type		HITACHI make	
		Reduction gear type	
Applied model		VG30E	VE30DE
		A/T	M/T A/T
System voltage	V	12	
No-load			
Terminal voltage	V	11.0	
Current	A	Less than 100	Less than 90
Revolution	rpm	More than 3,000	More than 2,950
Minimum diameter of commutator	mm (in)	32.0 (1.260)	
Minimum length of brush	mm (in)	12.0 (0.472)	11.0 (0.433)
Brush spring tension	N (kg, lb)	17.7 - 21.6 (1.8 - 2.2, 4.0 - 4.9)	
Movement in height of pinion assembly	mm (in)	0.05 - 0.8 (0.0020 - 0.0315)	—
Clearance of bearing metal and armature shaft	mm (in)	—	0.03 - 0.3 (0.0012 - 0.0118)
Clearance between pinion front edge and pinion stopper	mm (in)	—	0.05 - 1.5 (0.0020 - 0.0591)

CHARGING SYSTEM

Wiring Diagram

VG ENGINE




- GI
- MA
- EM
- LC
- FF & EC
- FE
- CL
- WT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**
- IDX

(DM) : Digital type meter
 (NM) : Needle type meter
 J/C : Joint connector [Refer to last page (Foldout page).]

CHARGING SYSTEM

Wiring Diagram (Cont'd)



VE ENGINE



J/C : Joint connector (Refer to last page (Foldout page).)

CHARGING SYSTEM

Construction



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

CHARGING SYSTEM







Service Data and Specifications (SDS)

ALTERNATOR

Type	LR190-711	LR195-701
	HITACHI make	
Applied model	VG30E	VE30DE
Nominal rating	V-A	12-90
Ground polarity	Negative	
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 950
Hot output current (When 13.5 volts is applied)	A/rpm	More than 23/1,300 More than 63/2,500 More than 84/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	7.0 (0.276)
Brush spring pressure	N (g, oz)	1.079 - 2.550 (110 - 260, 3.88 - 9.17)
Slip ring minimum diameter	mm (in)	30.6 (1.205)
Rotor (Field coil) resistance	Ω	—

COMBINATION SWITCH

Combination Switch/Check






LIGHTING SWITCH

	OFF	1ST	2ND
	A	B	C
5		○	○
6		○	○
7		○	○
8		○	○
9		○	○
10		○	○
11		○	○
12		○	○


WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○	○		
15		○			
16		○		○	
17		○	○	○	
18				○	○




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

COMBINATION SWITCH



Combination Switch/Replacement

- Each switch can be replaced without removing combination switch base.






- To remove combination switch base, remove base attaching screw and turn after pushing on it.

COMBINATION SWITCH

Steering Switch/Check

WITHOUT AIR BAG SYSTEM



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

COMBINATION SWITCH


Steering Switch/Check (Cont'd)

WITH AIR BAG SYSTEM



HEADLAMP

Wiring Diagram (For U.S.A.)



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX

HEADLAMP

Operation (Daytime light system for Canada)

After starting the engine with the lighting switch in the "OFF" position or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	○	X
Clearance and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

○ : Lamp "ON"

X : Lamp "OFF"


△ : Lamp dims.

□ : Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.


Schematic (Daytime light system for Canada)



SEL696S


HEADLAMP

Wiring Diagram (For Canada)



GI
MA
EM
LC
EF
EC
FF
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HEADLAMP



Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

- **Do not leave the bulb out of the headlamp reflector for a long period of time as dust, moisture, smoke, etc. may enter the headlamp body and affect the performance of the headlamp. Thus, the headlamp bulb should not be removed from the headlamp reflector until just before a replacement bulb is to be installed.**


Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. For operating instructions of any aimer, it should be in good repair, calibrated and used according to respective operation manuals supplied with the unit.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.


- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**



AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Example:





HEADLAMP

Aiming Adjustment (Cont'd)

LOW BEAM

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**



- **Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown at left.**
 - **Dotted lines in illustration show center of headlamp.**
- "H": Horizontal center line of headlamps
 "W_L": Distance between each headlamp center

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX


EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram




EXTERIOR LAMP

Back-up Lamp/Wiring Diagram




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
DX

Front Fog Lamp/Wiring Diagram



Turn Signal and Hazard Warning Lamps/Wiring Diagram




GI
MA
EM
LC
EF
FC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

(VG : VG engine model
VE : VE engine model
DM : Digital meter
NM : Needle meter

SEL701S


EXTERIOR LAMP

Cornering Lamp/Wiring Diagram



SEL702S

EXTERIOR LAMP



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

GI

MA

EM

Bulb Specifications

	Wattage (12 volt)	
Headlamp (Semi-sealed beam)		LC
High/low	65/45	EF & EC
Front turn signal lamp	27	
Front combination lamp		FE
Cornering/Front clearance	27/8	
Front side marker	3.8	CL
Front fog lamp	55	
Rear combination lamp		MT
Turn signal	27	
Stop/Tail	27/8	AT
Back-up	27	
Rear side marker lamp	3.8	FA
License plate lamp	7.5	
High-mounted stop lamp	18	
Interior lamp	10	RA
Spot lamp	10	
Step lamp	3.4	BR
Trunk room lamp	3.4	

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

INTERIOR LAMP

Illumination/Wiring Diagram


DIGITAL TYPE COMBINATION METER



INTERIOR LAMP

Illumination/Wiring Diagram (Cont'd)


NEEDLE TYPE COMBINATION METER



CI
MA
EM
LC
FC
FC
FF
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


INTERIOR LAMP

Interior, Spot, Step and Trunk Room Lamps/Wiring Diagram




SEL705S



Illuminated Entry System and Key Illumination/ Wiring Diagram



Combination Meter




- (AB) : With air bag model
- (EA) : Without air bag model
- * (AB) : 2
- (EA) : 35




SEL707S


Speedometer, Tachometer, Temp., and Fuel Gauges/Wiring Diagram




GI
MA
FW
LC
EF &
FC
FE
CL
MT
AT
FA
BA
BR
ST
BF
HA
EL
IDX



SEL891L





SEL892L



SEL893L

Inspection/Fuel Gauge and Water Temperature Gauge






SEL873L

Fuel Tank Gauge Unit Check

- For removal, refer to FE section.
- Check the resistance between terminals **G** and **E**.

Ohmmeter		Float position		Resistance Ω
(+)	(-)	mm (in)		
G	E	*3	Full	48 (1.89)
		*2	1/2	112 (4.41)
		*1	Empty	172 (6.77)


*1 and *3: When float rod is in contact with stopper.



SEL107M

Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.




SEL698F

Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90Ω
100°C (212°F)	Approx. 21 - 24Ω


GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.




Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.
2. Turn speedometer pinion quickly and measure voltage across **a** and **b**.

Combination Meter


CAUTION:
No electrical terminal should be touched with bare hands.





SEL059N

CI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
EA
EL
IDX

METER AND GAUGES — Digital Type — Combination Meter (Cont'd)




METER AND GAUGES — Digital Type — Combination Meter (Cont'd)




GI
VA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Schematic



SEL759R

Wiring Diagram



- GI
- MA
- FM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- FA
- EL
- IDX

Trouble Diagnoses

SYMPTOM CHART

Reference page	EL-55	EL-55	EL-56	EL-57	EL-57	EL-57	EL-58	EL-59	EL-60	EL-61	EL-62	EL-63	EL-64	EL-65	EL-66	EL-66	EL-67	EL-68	EL-69	EL-70	EL-71	EL-71	EL-72	EL-73	EL-74	EL-76	EL-77
Symptom	Preliminary check 1	Preliminary check 2	Preliminary check 3	Preliminary check 4	Preliminary check 5	Preliminary check 6	Preliminary check 7	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	Diagnostic procedure 7	Diagnostic procedure 8	Diagnostic procedure 9	Diagnostic procedure 10	Diagnostic procedure 11	Diagnostic procedure 12	Diagnostic procedure 13	Diagnostic procedure 14	Diagnostic procedure 15	Diagnostic procedure 16	Diagnostic procedure 17	Diagnostic procedure 18	Segment check	Self-check
Speedometer indicates zero ("0") even when driving.	<input type="radio"/>							<input type="radio"/>	<input type="radio"/>																<input type="radio"/>		
Illumination control for head-up display fails to function.		<input type="radio"/>									<input type="radio"/>	<input type="radio"/>															
Illumination control for combination meter fails to function.			<input type="radio"/>										<input type="radio"/>	<input type="radio"/>													
All segments of combination meter remain illuminated.				<input type="radio"/>												<input type="radio"/>	<input type="radio"/>										
Some combination meter segments remain illuminated, illuminate dimly, do not illuminate or blink.					<input type="radio"/>											<input type="radio"/>	<input type="radio"/>									<input type="radio"/>	
Some head-up display segments remain illuminated, illuminate dimly, do not illuminate or blink.						<input type="radio"/>									<input type="radio"/>							<input type="radio"/>				<input type="radio"/>	
Segments fail to illuminate.							<input type="radio"/>												<input type="radio"/>	<input type="radio"/>			<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	
Indicated value of speedometer changes irregularly or is incorrect.								<input type="radio"/>																			
Indicated value of water temperature gauge is incorrect.									<input type="radio"/>																	<input type="radio"/>	
Indicated value of fuel gauge is incorrect.											<input type="radio"/>															<input type="radio"/>	<input type="radio"/>
Trip meter does not maintain memory.																		<input type="radio"/>									
Indicated value of odometer changes irregularly or is incorrect.																							<input type="radio"/>				


METER AND GAUGES — Digital Type —

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK

Preliminary check 1


Speedometer indicates zero ("0") even when driving.



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA

Preliminary check 2

Illumination control for head-up display fails to function.




RA
BR
ST
BF
HA
EL

IDX

Trouble Diagnoses (Cont'd)

Preliminary check 3


Illumination control for combination meter fails to function.



Trouble Diagnoses (Cont'd)

Preliminary check 4


All segments of combination meter remain illuminated.



GI
MA
EM

Preliminary check 5


Some combination meter segments remain illuminated, illuminate dimly, do not illuminate or blink.



LC
EF & EC
FE
CL
MT
AT

Preliminary check 6

Some head-up display segments remain illuminated, illuminate dimly, do not illuminate or blink.



FA
RA
BR
ST
BF
HA


EL

IDX

METER AND GAUGES — Digital Type —
Trouble Diagnoses (Cont'd)

Preliminary check 7

Segments fail to illuminate.






Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

Diagnostic procedure 1

SYMPTOM: Speedometer always indicates zero ("0") when driving.



A
Check voltage between control unit harness terminals No. ①①, ①② and body ground.

Terminal No.		Voltage V
⊕	⊖	3 - 5*
①①	Body ground	0
①②		0

*: When disconnecting vehicle speed sensor

OK → Check control unit connector. Refer to "Connector and Harness Check" (EL-76).
NG → (Go to B below.)

NG → Check installation and signals of vehicle speed sensor. Refer to "Vehicle Speed Sensor Signal Check" (EL-79).
OK → (Go to B below.)

NG → Reinstall or replace vehicle speed sensor.
B → (Go to B below.)

B
Check continuity between control unit harness terminals and vehicle speed sensor terminals.

Terminal No.		Continuity
Control unit	Vehicle speed sensor	
①①	a	Yes
①②	b	

Check connectors (①⑥, ①①, M22, M37, F53 and F24) and harness. Refer to "Connector and Harness Check" (EL-76).
OK → (Go to C below.)
NG → Repair harness or connector.


C
Check control unit by imitative signals. Disconnect vehicle speed sensor connector. Connect suitable jumper wires to control unit harness terminals No. ①① and ①②, and ground jumper wires alternately and quickly. Speedometer should indicate several numbers.
OK → Repair harness or connector.
NG → Replace control unit.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 2

SYMPTOM: Indicated value of speedometer changes irregularly or is incorrect.



Check installation and signals of vehicle speed sensor.
Refer to "Vehicle Speed Sensor Signal Check" (EL-79).

NG → Reinstall or replace vehicle speed sensor.

OK

Check continuity between control unit harness terminals and vehicle speed sensor terminals.

NG → Repair harness or connector .

Terminal No.		Continuity
Control unit	Vehicle speed sensor	
(11)	(a)	Yes
(12)	(b)	

Check connectors (16), (11), (M22), (M37), (F53) and (F24) and harness.
Refer to "Connector and Harness Check" (EL-76).


OK

Replace control unit.

Trouble Diagnoses (Cont'd)


Diagnostic procedure 3

SYMPTOM: Indicated value of water temperature gauge is incorrect.



A
Check continuity between control unit harness terminals No. ①, ⑩ and body ground.
Continuity should exist.


NG → Repair harness, connector or body ground (M1).



B
Disconnect connector from control unit, and measure resistance between control unit harness terminal No. ⑰ and ① (or ⑩). Compare measured resistance with gauge indication (before disconnecting connector). Gauge indication is swayed by water temperature.

Segment	Resistance Ω
7	Less than 17
4	18 - 119
1	More than 189

NG →



C
While making segment checks (Refer to "Self-check" EL-76.), lightly tap on corner of control unit with screwdriver to see if display changes.

Yes → Check connector (16). Refer to "Connector and Harness Check" (EL-76).

NG → Repair harness or connector.

OK → (Go to A below.)

No → Check thermal transmitter. Refer to "Thermal Transmitter Check" (EL-78).

NG → Replace thermal transmitter.

OK → Check continuity between control unit harness terminal No. ⑰ and thermal transmitter harness terminal No. ①. **Continuity should exist.**

NG → Repair harness or connector.

Check connectors (16, 11, M22, M37, F53 and F34) and harness. Refer to "Connector and Harness Check" (EL-76).

OK → Replace control unit.




← (A)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 4

SYMPTOM: Indicated value of fuel gauge is incorrect.



A
Check continuity between control unit harness terminal No. ①, ⑩ and body ground.
Continuity should exist.

NG → Repair harness, connector or body ground (M1).

B
Disconnect connector from control unit, and measure resistance between control unit harness terminal No. ⑩ and ① (or ⑩). Compare measured resistance with gauge indication (before disconnecting connector). Gauge indication is swayed by the amount of fuel.

Segment	Resistance Ω
14	Less than 23
7	120 - 365
1	More than 581

NG → Check connector ⑩. Refer to "Connector and Harness Check" (EL-76).
OK → (Go to A below.)

While making fuel quick check (Refer to "Self-check" EL-77.), lightly tap on corner of control unit with screwdriver to see if display changes.

Yes → Check connector ⑩. Refer to "Connector and Harness Check" (EL-76).
NG → Repair harness or connector.
OK → (Go to A below.)

Check fuel tank gauge unit. Refer to "Fuel Tank Gauge Unit Check" (EL-78).

NG → Replace fuel tank gauge unit.

C
Check continuity between control unit harness terminal No. ⑩ and fuel tank gauge unit harness terminal No. ⑥. **Continuity should exist.**

Check connectors (⑩, ⑪, M22 and M117) and harness. Refer to "Connector and Harness Check" (EL-76).

NG → Repair harness or connector.


Replace control unit.

← A

Trouble Diagnoses (Cont'd)

Diagnostic procedure 5

SYMPTOM: Illumination control for head-up display sometimes fail to function.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 6

SYMPTOM: Illumination control for head-up display always fails to function.



A

Measure voltage between terminal No. ⑥ and ④ of head-up display control unit connector using a circuit tester (set in AC range).

Illumination control switch	Lighting switch OFF		Lighting switch ON	
	Duty (%)	Voltage (V)	Duty (%)	Voltage (V)
Step 1	100	0	35	Approx. 5.6
Step 2	60	Approx. 5.7	0.45	Approx. 1.3
15	0.3	Approx. 0.6	0.115	Approx. 0.6
16	0.2	Approx. 0.4	0.11	Approx. 0.5

OK

NG

Replace head-up display control unit.

Check head-up display control unit connector. Refer to "Connector and Harness Check" (EL-76).

OK

NG



Replace control unit.

Repair harness or connector.

Trouble Diagnoses (Cont'd)

Diagnostic procedure 7

SYMPTOM: Illumination control for combination meter always fails to function.



A Measure voltage between control unit connector terminals (indicated in table below) and ground.

Ignition switch	Voltage V			
	ACC		ON	
Lighting switch	OFF	ON	OFF	ON
Terminal No. ③	0	12	0	12
⑬	0	Less than 12	0	Less than 12
⑭	*1	0	0	0
	*2	0	12	More than 3
⑮	*3	0	0	0
	*2	0	12	More than 3

- *1: Illumination control switch is turned ON to "BRIGHTEN" side.
- *2: Illumination control switch is OFF.
- *3: Illumination control switch is turned ON to "DARKEN" side.

B Check continuity between control unit terminals No. ③, ⑬, ⑭, ⑮ and each units' terminal.

Terminal No.	Continuity
③	⑮ *1
⑬	⑭ *2
⑭	① *3
⑮	② *3

Yes

- *1: Lighting switch
- *2: Time control unit
- *3: Illumination control switch

Check connectors (⑬, ⑭, ⑮, ⑯, ⑰, ⑱, ⑲, ⑳, ㉑, ㉒, ㉓, ㉔, ㉕, ㉖, ㉗, ㉘, ㉙, ㉚, ㉛, ㉜, ㉝, ㉞, ㉟, ㊱, ㊲, ㊳, ㊴, ㊵, ㊶, ㊷, ㊸, ㊹, ㊺, ㊻, ㊼, ㊽, ㊾, ㊿) and harness. Refer to "Connector and Harness Check" (EL-76).

```


    graph TD
        A[Measure voltage between control unit connector terminals (indicated in table below) and ground.] -- NG --> B[Check continuity between control unit terminals No. ③, ⑬, ⑭, ⑮ and each units' terminal.]
        B -- Yes --> C[Check connectors (⑬, ⑭, ⑮, ⑯, ⑰, ⑱, ⑲, ⑳, ㉑, ㉒, ㉓, ㉔, ㉕, ㉖, ㉗, ㉘, ㉙, ㉚, ㉛, ㉜, ㉝, ㉞, ㉟, ㊱, ㊲, ㊳, ㊴, ㊵, ㊶, ㊷, ㊸, ㊹, ㊺, ㊻, ㊼, ㊽, ㊾, ㊿) and harness. Refer to "Connector and Harness Check" (EL-76).]
        C -- NG --> D[Repair harness or connector.]
        C -- OK --> E[Check control unit connector. Refer to "Connector and Harness Check" (EL-76).]
        E -- NG --> D
        E -- OK --> F{Is brightness of any segments controlled properly?}
        F -- No --> G[Replace control unit.]
        F -- Yes --> H[Replace display unit.]
    
```

GI
MA
EM
LC
FF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 8

SYMPTOM: Illumination control for combination meter sometimes fails to function.



A Check continuity between control unit terminals No. ③, ⑭, ⑮ and each unit's terminal.

Terminal No.	Continuity
③	⑫ *1
⑭	① *2
⑮	② *2

*1: Lighting switch
*2: Illumination control switch


Check connectors (⑩, ⑪, ⑫, ⑬, ⑭, ⑮, ⑯, ⑰, ⑱, ⑲, ⑳) and harness.

Refer to "Connector and Harness Check" (EL-76).

NG → Repair harness or connector.

OK

Replace control unit.



Diagnostic procedure 9

SYMPTOM: All head-up display segments always illuminate, or some segments remain illuminated, illuminate dimly, do not illuminate or blink at all times.

A Measure voltage between head-up display control unit connector terminals (indicated in table below.)

Voltmeter range	Terminal No.	Voltage V
DC	①	Approx. 12
	⑤	Approx. 1.3
AC	⑦	Approx. 1.5
	⑧	Approx. 1
	*1 ② ③	Approx. 1.7
	*2 ② ③	0

*1: Head-up display switch ON
*2: Head-up display switch OFF

NG → Check head-up display control unit connector. Refer to "Connector and Harness Check" (EL-76).



NG → Repair harness or connector.

OK → Replace control unit.

Trouble Diagnoses (Cont'd)

Diagnostic procedure 10

SYMPTOM: All segments of combination meter illuminate, or some segments remain illuminated, illuminate dimly, do not illuminate or blink at all times.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 11





SYMPTOM: All segments of combination meter sometimes illuminate, or some segments remain illuminated, illuminate dimly, blink or do not illuminate occasionally.



Trouble Diagnoses (Cont'd)

Diagnostic procedure 12

SYMPTOM: Trip meter does not maintain memory.






GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 13




SYMPTOM: Head-up display segments do not illuminate.



Trouble Diagnoses (Cont'd)


Diagnostic procedure 14

SYMPTOM: All segments sometimes do not illuminate.



Diagnostic procedure 15

SYMPTOM: All head-up display segments sometimes illuminate, or some segments remain illuminated, illuminate dimly, do not illuminate or blink occasionally.







GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 16

SYMPTOM: All segments always do not illuminate.



A

Check voltage between control unit harness terminals and body ground.

Terminal No.	⊖	Voltage V
①		0
②	Body ground	Approx. 12
④		Approx. 12
⑨		Approx. 12
⑩		0

B

Check continuity between control unit harness terminals and fuse block or body ground.

Terminal No.	⊕	⊖	Continuity
⊕	⊖		Yes
⊕	②		
⊕	④		
⊕	⑨		
⊕	⑩		
⊕	Body ground		

C

Check voltage between select switch connector terminals (indicated in table below).

		Terminal No.	⊖	Voltage V
Trip or Total	Trip	①	⑦	0
		③		5
	Total	①		5
		③		0
Reset	OFF	②		5
	ON	②		0
MPH or km/h	MPH	④		0
		⑥		5
	km/h	④	5	
		⑥	0	
Head-up display	OFF	⑤	5	
	ON	⑤	0	

Repair harness, connector or body ground (M1).

Check and repair power supply circuit. Refer to "POWER SUPPLY ROUTING" (EL-8).

D



Disconnect fuel tank gauge unit. Check voltage (AC range) between control unit harness terminal No. ⑩ and body ground.

Voltage: Approx. 1V

(Go to A on next page.)


METER AND GAUGES — Digital Type —

Trouble Diagnoses (Cont'd)



Diagnostic procedure 17

SYMPTOM: Indicated value of odometer changes irregularly or is incorrect.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 18


SYMPTOM: Particular segments always or sometimes do not illuminate.



While making segment checks several times (Refer to "Self-check" EL-76.), lightly tap on corner of control unit with screwdriver to see if display changes.

Changes → (Go to **B** on next page.)

Does not change



A Measure voltage between select switch connector terminals (indicated in table below.)

NG → (Go to **B** on next page.)

		Terminal No.		Voltage V
		⊕	⊖	
Trip or Total	Trip	①	⑦	0
		③		5
	Total	①		5
		③		0
Reset	OFF	②		5
	ON	②		0
MPH or km/h	MPH	④		0
		⑥		5
	km/h	④	5	
		⑥	0	
Head-up display	OFF	⑤	5	
	ON	⑤	0	

OK


B Disconnect fuel tank gauge unit. Check voltage (AC range) between control unit harness terminal No. ⑯ and body ground.
Voltage: Approx. 1V

NG → (Go to **B** on next page.)

OK

(Go to **A** on next page.)

Trouble Diagnoses (Cont'd)



(A)

Measure voltage between head-up display control unit connector terminals (indicated in table below.)

Voltmeter range		Terminal No.		Voltage V
DC		①	④	Approx. 12
AC	*1	②	③	Approx. 1.7
	*2	②	③	0

*1: Head-up display switch ON
*2: Head-up display switch OFF

NG → (Go to (B) below.)

OK

Extract display unit from control unit. Check display unit connector terminals for bends. Straighten bent terminals as necessary. Re-connect control unit to display unit and turn ignition switch ON.

NG → Replace display unit.


OK

Replace control unit. ← (B)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Connector and Harness Check

1. Checks while monitoring meter indication (with unit connected and ignition switch ON).
 - (a) Connector
 - While holding harness close to connector, twist connector
 - Lightly pull or push harness corresponding with terminal affected.
 - Lightly tap on harness.
 - (b) Harness
 - Lightly tap on harness.
 - Move harness up and down, and left and right.
- If poor contact exists, indication value will change or disappear.
2. Check terminals for bends.



Self-check

SEGMENT CHECK

Turn ignition switch from "OFF" to "ON" while pushing trip reset switch. Release this switch after segment check operation starts.

Sequence of segment check

Segments of central speedometer

↓
Index segments of speedometer (Mile → km)

↓
Numbers of circular speedometer (Mile → km)

↓
Frames and index segments of tachometer

↓
Scale segments of speedometer (in turn)

↓
Segments of odometer

↓
Scale segments and numbers of tachometer (in turn)

↓
Water temperature gauge

↓
Fuel gauge


↓
Head-up display

↓
Normal display condition (End of self-check)

Self-check (Cont'd)

FUEL GAUGE QUICK CHECK

In this mode, fuel gauge indication responds to signals from fuel tank gauge without delay. During display check, push trip reset switch again, and fuel gauge quick check mode will start.



	Float position mm (in)		Number of lighted segments
*3	Full	47 (1.85)	14
*2	1/2	121 (4.76)	7
*1	Empty	172 (6.77)	0

Full

1/2

Empty

CONNECT

LON

SEL190N

Remove fuel tank gauge unit from fuel tank. Refer to FE section ("FUEL SYSTEM"). Connect connector (M11) and move float as shown in the figure.

Fuel gauge indication should change in proportion to the movement of fuel tank gauge.

WARNING:

- When ignition switch is turned on, fuel pump works for a short time. If fuel hoses are disconnected from fuel tubes in this operation, put fuel hoses in a container in order not to spill fuel from fuel pump.
- Do not work fuel pump in the air repeatedly. Otherwise it will be broken due to lack of lubrication.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

IDX




SEL873L

Fuel Tank Gauge Unit Check

- For removal, refer to FE section.
Check the resistance between terminals **G** and **E**.

Ohmmeter		Float position		Resistance Ω	
(+)	(-)	mm (in)			
G	E	*3	Full	47 (1.85)	15 - 18
		*2	1/2	121 (4.76)	178 - 195
		*1	Empty	172 (6.77)	929 - 1,009


*1 and *3: When float rod is in contact with stopper.



SEL107M

Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.




SEL698F

Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.
2. Turn speedometer pinion quickly and measure voltage across **a** and **b**.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

WARNING LAMPS AND CHIME

Warning Lamps/Schematic




SEL711S

WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram

DIGITAL TYPE COMBINATION METER




GI
MA
EM
LC
FC
FC
FC
FC
CL
MT
AT
FA
BA
BR
ST
BF
HA
EL
IDX


WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram (Cont'd)

NEEDLE TYPE COMBINATION METER



Warning Chime/Wiring Diagram



DM : Digital type combination meter
 NM : Needle type combination meter
 U : For U. S. A.
 N : For Canada
 J/C : Joint connector (Refer to last page (Foldout page).)

TIME CONTROL UNIT
 (Refer to "TIME CONTROL SYSTEM".)

IGNITION SWITCH
 ON or START

BATTERY

FUSE BLOCK
 (Refer to "POWER SUPPLY ROUTING".)

UP

J/C-5

KEY SWITCH

ENGINE ROOM HARNESS

SMJ

J/C-8

J/C-9

SEAT BELT SWITCH

AUTOMATIC SEAT BELT CONTROL UNIT
 (Refer to "AUTOMATIC SEAT BELT SYSTEM" in BF section.)

FRONT DOOR SWITCH
 (DRIVER SIDE)

BODY GROUND


COMBINATION METER

WARNING CHIME 31

WARNING CHIME 17

GI
 WA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 SA
 BR
 ST
 BF
 HA
 EL
 IDX


WARNING LAMPS AND CHIME



Diode Check


- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual of your tester.



- Diodes for warning lamps are built into the combination meter printed circuit.

Refer to "Combination Meter" (EL-44).



Warning Chime Check

TIME CONTROL SYSTEM

Description

FUNCTION

- Time control unit has the following functions.

	Item	Details of control
1,2	Intermittent wiper control	Regulates intermittent time from approximately 3 to 23 seconds depending on the intermittent wiper volume setting.
3	Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
4	Light warning chime timer	When driver's door is opened with light switch ON and ignition switch OFF, warning chime sounds.
5	Ignition key warning chime timer	When driver's door is opened with ignition switch OFF, warning chime sounds.
6	Seat belt warning chime timer	Sounds warning chime for about 7 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).
7	Seat belt warning lamp timer	Seat belt warning lamp blinks for about 7 seconds when ignition switch is turned to "ON".
8	Rear defogger timer	Rear defogger operates for about 15 minutes when defogger switch is ON.
9	Interior lamp timer	Fades out interior lamp when driver's side door is opened and closed.
10	Door key hole illumination	Illuminates for about 7 seconds when door outside handle is pulled.
11	Illumination control	The brightness of the instrument panel light can be adjusted.

GI

MA

EM

I.C

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

TIME CONTROL SYSTEM

Wiring Diagram



TIME CONTROL SYSTEM

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	Preliminary Check			Main power Supply and Ground Circuit Check	Diagnostic Procedure											
	EL-88	EL-88	EL-88		EL-89	EL-91	EL-92	EL-92	EL-93	EL-94	EL-95	EL-96	EL-96	EL-97	EL-98	EL-99
REFERENCE PAGE																
SYMPTOM	Procedure 1	Procedure 2	Procedure 3	Main power supply and Ground circuit	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	Diagnostic procedure 7	Diagnostic procedure 8	Diagnostic procedure 9	Diagnostic procedure 10	Diagnostic procedure 11	
Wiper & washer	Intermittent wiper does not operate.			○	○											
	Intermittent time of wiper cannot be adjusted.					○										
	Wiper and washer activate individually but not in combination.						○									
Warning	Light warning chime does not activate.	○		○				○								
	Ignition key warning chime does not activate.		○	○					○							
	Seat belt warning chime does not activate.			○	○					○						
	Seat belt warning lamp does not come on, or does not go off after coming on.				○						○					
Rear defogger	Rear defogger does not activate, or go off after activating.			○								○				
Illumination	Interior lamp does not fade out after driver's door is closed.			○									○			
	Door key hole illumination does not come on even if door handle is pulled.				○									○		
	Illumination control does not actuate.															○

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX


TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3

- Seat belt warning chime does not activate.




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)


MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply



Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑨ - ⑮	Yes	Yes	Yes
⑤ - ⑮	No	No	Yes
② - ⑮	No	Yes	Yes

GI
MA
EM



Ground circuit


Terminals	Continuity
⑮ - Ground	Yes

LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK





SEL628N

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1


SYMPTOM: Intermittent wiper does not operate.



A

WIPER RELAY OUTPUT SIGNAL CHECK
 1) Turn ignition switch to "ACC".
 2) Turn wiper switch to "INT" or "OFF".
 3) Measure voltage between control unit harness terminals ① and ⑮.



Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	Pointer swings from 0 to 12 every 3 to 23 seconds



B

INTERMITTENT SWITCH INPUT SIGNAL CHECK
 Measure voltage between control unit harness terminals ⑫ and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	0





GI
 MA
 EV
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

TIME CONTROL SYSTEM



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.




OK → Replace control unit.





DIAGNOSTIC PROCEDURE 3


SYMPTOM: Wiper and washer activate individually but not in combination.



NG → Check harness continuity between TCU and washer switch.



NG → Replace control unit.







TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Light warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 1" before referring to the following flow chart.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Ignition key warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 2" before referring to the following flow chart.



A Step 3

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑱ and ⑮.

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	0

NG → Check door switch.
Check harness continuity between TCU and door switch.

B Step 2

CHIME OUTPUT SIGNAL CHECK
Measure voltage between control unit harness between ⑲ and ⑮.

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	Pointer deflects intermittently

OK → Check chime.
Check harness continuity between TCU and chime.

C Step 1

IGNITION KEY SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑩ and ⑮.

Condition	Voltage [V]
Key is inserted	Approx. 12
Key is pulled	0

NG → Check ignition key switch.
Check harness continuity between TCU and ignition key switch.

OK → Replace control unit.




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Seat belt warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 3" before referring to the following flow chart.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7


SYMPTOM: Seat belt warning lamp does not come on, or does not go off after coming on.



Yes → Check warning lamp.
Check harness continuity between TCU and warning lamp.


No

Replace control unit.





DIAGNOSTIC PROCEDURE 8

SYMPTOM: Rear defogger does not activate, or does not go off after activating.



OK → Check rear window defogger relay.
Check rear window defogger circuit.

NG



NG → Check rear window defogger switch.
Check harness continuity between TCU and rear window defogger switch.

OK



Replace control unit.

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

SYMPTOM: Interior lamp does not fade out after driver's door is closed.



A

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑱ and ⑮.

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	0

NG → Check door switch.
Check harness continuity between TCU and door switch.

B

INTERIOR LAMP SIGNAL CHECK
Measure voltage between control unit harness terminals ⑳ and ⑮.

Condition of driver's door	Voltage [V]
Door is closed	0 → Approx. 12
Door is open	0

OK → Check interior lamp and harness between TCU and interior lamp.

NG → Replace control unit.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



IDX

TIME CONTROL SYSTEM



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 10


SYMPTOM: Door key hole illumination does not come on even if door handle is pulled.



NG → Check door handle switch.
Check harness continuity between TCU and door handle switch.



OK → Check key hole illumination and harness between TCU and key hole illumination.





TIME CONTROL SYSTEM



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 11



SYMPTOM: Illumination control does not actuate.



NG → Check light switch.
Check harness continuity between TCU and light switch.



NG → Check meter illumination.
Check harness continuity of illumination circuit.




NG → Check illumination control switch.
Check harness continuity between TCU and illumination switch.

OK → Replace TCU.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
DX

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram



WIPER AND WASHER

Installation

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" or "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".



Clearance "L₁": 22 - 32 mm (0.87 - 1.26 in)

Clearance "L₂": 43 - 53 mm (1.69 - 2.09 in)

- Tighten windshield wiper arm nuts to specified torque.


Windshield wiper:

17 - 23 N·m (1.7 - 2.3 kg·m, 12 - 17 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER AND WASHER




Washer Nozzle Adjustment

- Using Tool J36126, adjust windshield washer nozzle to correct its spray pattern.


Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle.

This will prevent "rounding out" the small female square in the center of the nozzle.



HORN, CIGARETTE LIGHTER, CLOCK


Wiring Diagram







GI
MA
EM
LC
EF &
FC
FF
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

REAR WINDOW DEFOGGER

Wiring Diagram



REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.
2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.

- When measuring voltage, wind a piece of tin foil around the top of the negative probe and press the foil against the wire with your finger as shown.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

REPAIRING PROCEDURE




1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.


5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



AUDIO AND POWER ANTENNA

Audio/Wiring Diagram

BOSE SYSTEM




GI
MA
EM
LC
FF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

AUDIO AND POWER ANTENNA


Audio/Wiring Diagram (Cont'd)

EXCEPT BOSE SYSTEM




AUDIO AND POWER ANTENNA


Power Antenna/Wiring Diagram



Location of Antenna




AUDIO AND POWER ANTENNA



Antenna Rod Replacement



REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.




Radio Fuse Check


Window Antenna Repair

ELEMENT CHECK


1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.



2. If an element is broken, no continuity will exist.



3. To locate broken point, move probe to left and right along element to determine point where tester needle swings abruptly.



ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-106).

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

NOTE

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic




GI
 MA
 EM
 LC
 FF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Wiring Diagram

VG ENGINE



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram (Cont'd)




GI
MA
EM
IC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram (Cont'd)

VE ENGINE




AUTOMATIC SPEED CONTROL DEVICE (ASCD) Wiring Diagram (Cont'd)



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RF
 HA
 EL
 IDX

ASCD Wire Adjustment



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

After confirming that accelerator wire is properly adjusted, adjust the tension of ASCD wire in the following manner.

- (1) After adjusting the length of the accelerator wire, turn a securing nut by 1/2 to 1 turn from throttle open starting position to the wire loosening direction to fix. (Must be securing carried out to prevent response delay of operation of the ASCD.)
 - (2) Securely tighten lock nut to hold adjusting nut in place.
- For ASCD cancel switch and clutch switch adjustment, refer to BR and CL sections.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

Symptom	DIAGNOSTIC PROCEDURE
ASCD control unit cannot be set properly.	1
Resume switch will not operate.	2
Cancel switch will not operate.	3
Set speed cannot be canceled.	4
Engine hunts.	5
Large difference between set vehicle and actual speed.	6

GI

MA

EV

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

PREPARATION FOR TROUBLE-DIAGNOSIS

1. Remove lower trim.
2. Remove ASCD control unit with harness connected.
3. Perform check from harness side using circuit tester, with harness connector connected.



GROUND CIRCUIT CHECK

- Check continuity between ③ and body ground.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE-1

ASCD control unit cannot be set properly.



POWER SUPPLY CIRCUIT CHECK

1. Turn ASCD main switch to "ON".
2. Check voltage between ④ and ③.



CUT-OFF CIRCUIT CHECK



1. Step on brake pedal.
2. Turn ASCD main switch to "ON".
3. Check voltage between ① and ③.



SEL640QA



SET SWITCH CIRCUIT CHECK

1. Push ASCD set switch.
2. Check voltage between ② and ③.




VEHICLE SPEED SENSOR CIRCUIT CHECK

1. Disconnect vehicle speed sensor from transmission.
 2. Connect a voltmeter between ⑦ and ③.
 3. Slowly turn vehicle speed sensor by hand to make sure voltmeter pointer deflects.
- Voltmeter pointer deflects twice per rotation of pinion.



SEL641QA





AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

RESUME SWITCH CIRCUIT CHECK


1. Turn resume switch to "ON".
2. Check voltage between ① and ③



SEL549R

CANCEL SWITCH CIRCUIT CHECK



1. Turn cancel switch to "ON".
2. Check voltage between ② and ③ or ① and ③.



SEL550R



CUT-OFF CIRCUIT CHECK

1. Turn ASCD main switch to "ON".
2. Turn ASCD main switch to "ON" again.
3. Step on brake pedal.
4. Step on clutch pedal (M/T) or shift in "N" range (A/T).
5. Check voltage between ⑤ and ③.



STOP LAMP CIRCUIT CHECK


1. Step on brake pedal.
2. Check voltage between ① and ③.



SEL644QA


DIAGNOSTIC PROCEDURE-2

Resume switch will not operate.




DIAGNOSTIC PROCEDURE-3

Cancel switch will not operate.



DIAGNOSTIC PROCEDURE-4

Set speed cannot be canceled.




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE-5

Engine hunts.




DIAGNOSTIC PROCEDURE-6

Large difference between set vehicle speed and actual speed.







AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Actuator Check

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL











IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

NOTE

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location




SEL674Q

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


THEFT WARNING SYSTEM

Wiring Diagram



THEFT WARNING SYSTEM

Wiring Diagram (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
WT
AT
FA
RA
BR
ST
DF
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses


SYSTEM OPERATION CHECK

If ignition switch is set in the "ACC" position in the step of START to ARMED or in the ARMED state shown in this flow chart, the system operation is canceled.



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

GL

MT

AT

FA

RA

BR

ST

BF

HA

EL


IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)


POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply circuit check




Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑯	Battery voltage	Battery voltage	Battery voltage

Power supply circuit check for system cancel



Terminals	Ignition switch position		
	OFF	ACC	ON
③ - ⑯	0V	Battery voltage	Battery voltage

Ground circuit check



Terminals	Continuity
⑯ - Ground	Yes




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




DIAGNOSTIC PROCEDURE 1

SYMPTOM: ● Indicator lamp does not blink.
● Indicator lamp remains blinking.

Diagnostic procedure 1-(1)



Condition	Continuity
All doors are closed	No
At least one door is open	Yes



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

THEFT WARNING SYSTEM



Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(2)




OK → Go to Diagnostic Procedure 2 (EL-137).

NG




NG → Adjust installation of hood switch or hood.

OK



NG → Replace hood switch.

OK



NG → Repair harness or connectors.




OK

CHECK THE CONNECTIONS AT EACH CONNECTOR.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)









THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Indicator lamp does not blink.






GI
MA
EM
LC
EF & EC
FE
CL
WT
AT
FA
RA
BR
ST
BF
HA
EL
DX



DIAGNOSTIC PROCEDURE 3

SYMPTOM: STARTER MOTOR can be operated. (Starter killed phase)






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.









THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Indicator lamp does not come on.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL











IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Alarm does not operate.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.



A

DOOR UNLOCK SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)
Check continuity between control unit harness terminals ⑪ and ⑯.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

OK

Replace control unit.

NG

DOOR UNLOCK SWITCH CHECK
Refer to "Electrical Components Inspection" (EL-144).

NG

Replace key cylinder switch.

OK

B

DOOR UNLOCK SWITCH CIRCUIT CHECK


- Check harness continuity between control unit harness terminal ⑪ and door unlock switch terminal.
 - Check harness continuity between door unlock switch terminal and body ground.
- Continuity should exist.**

NG

Repair harness or connectors.

OK

CHECK THE CONNECTIONS AT EACH CONNECTOR.





THEFT WARNING SYSTEM



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8


SYMPTOM: Alarm does not stop even if stop signal is given.




OK → Replace control unit.



NG → Replace key cylinder switch.



NG → Repair harness or connectors.





THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches


Check continuity between terminal and switch body.



Hood switch

Check continuity between terminals when hood switch is pushed and released.

Terminal	Pushed	Released
a		○
b		○



Trunk room lamp switch

Terminal	Trunk lid	
	Closed	Open
a		○
b		○

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL




IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Key cylinder tamper switch, door lock switch and door unlock switch


● Door



	TAMPER SWITCH		DOOR LOCK SWITCH		DOOR UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral	Between full stroke and neutral	Full stroke
1				○			
2						○	
3		○					
4		○		○		○	

● Trunk lid


	TAMPER SWITCH		Trunk lid unlock switch		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral
1				○	
2		○			
3		○		○	



Door unlock sensor

	LOCK	UNLOCK
1		○
2		○


Component Parts and Harness Connector Location



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


DIGITAL TOUCH ENTRY SYSTEM

Wiring Diagram



DIGITAL TOUCH ENTRY SYSTEM




Wiring Diagram (Cont'd)



GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IX

Trouble Diagnoses

CONTENTS


HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR	EL-149
PRELIMINARY CHECK	EL-150
Preliminary check 1	
(Key pad function check)	EL-150
Preliminary check 2	
(Power door lock system check)	EL-150
Preliminary check 3	
(Power window system check)	EL-150
Preliminary check 4	
(Sun roof system check)	EL-151
Preliminary check 5	
(Trunk lid opener system check)	EL-151
MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	EL-151
CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK	EL-152
SYMPTOM CHART	EL-154
DIAGNOSTIC PROCEDURE	EL-155
Diagnostic procedure 1	
(SYMPTOM: When key pad is pressed, it does not beep and light does not glow.)	EL-155
Diagnostic procedure 2	
(SYMPTOM: When key pad is pressed, it beeps but light does not glow.)	EL-156
Diagnostic procedure 3	
(SYMPTOM: When key pad is pressed, it does not beep but light glows.)	EL-157
Diagnostic procedure 4	
(SYMPTOM: When a fixed number is entered, a long beep is not heard.)	EL-158
Diagnostic procedure 5	
[SYMPTOM: After a fixed number has been entered, registration sound (repeated beeps) is not heard even if code number is entered.]	EL-158
Diagnostic procedure 6	
(SYMPTOM: Both door lock and unlock functions do not work with key pad operation.)	EL-159
Diagnostic procedure 7	
(SYMPTOM: Doors do not lock when key pad () is pressed.)	EL-159
Diagnostic procedure 8	
(SYMPTOM: Doors do not unlock when code number is entered.)	EL-160
Diagnostic procedure 9	
(SYMPTOM: Driver side window does not open with key pad operation.)	EL-161
Diagnostic procedure 10	
(SYMPTOM: Passenger side window does not open with key pad operation.)	EL-161
Diagnostic procedure 11	
(SYMPTOM: Sun roof does not open with key pad operation.)	EL-162
Diagnostic procedure 12	
(SYMPTOM: Trunk lid does not open with key pad operation.)	EL-162
Diagnostic procedure 13	
(SYMPTOM: Door locks if key pad () is pressed when key is inserted in steering lock.)	EL-163
Diagnostic procedure 14	
(SYMPTOM: Door locks if key pad () is pressed when door is left ajar.)	EL-163
ELECTRICAL COMPONENTS INSPECTION	EL-164

DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

Work flow




DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK


Preliminary check 1

- Door lock system does not work normally with key pad operation.
- Front windows do not open with key pad operation.
- Sun roof does not open with key pad operation.
- Trunk lid does not open with key pad operation.




Preliminary check 2

Power door lock system does not work with key pad operation.



Preliminary check 3

Front windows do not open with key pad operation.




DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Preliminary check 4

Sun roof does not open with key pad operation.




GI

MA

EM

Preliminary check 5

Trunk lid does not open with key pad operation.




LC

EF &
EC

FE

CL



MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check for digital touch entry control unit


Check if 12V exists across digital touch entry control unit harness connector terminals ① and ⑯.

MT

AT

FA

RA



Ground circuit check for digital touch entry control unit

Check for continuity between digital touch entry control unit harness connector terminal ⑯ and body.

BR

ST

BF

HA


EL

IDX

DIGITAL TOUCH ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)



GI
MA
EM
LC
EF & EC
FE
CL
WT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

SEL727S

DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Preliminary Check					Main Power Supply and Ground Circuit Check	Diagnostic Procedure														Electrical Components Inspection							
	EL-150	EL-150	EL-150	EL-151	EL-151		EL-151	EL-151	EL-155	EL-156	EL-157	EL-158	EL-158	EL-159	EL-159	EL-160	EL-161	EL-161	EL-162	EL-162	EL-163	EL-163	EL-164	EL-164	EL-164	EL-165		
REFERENCE PAGE	EL-150	EL-150	EL-150	EL-151	EL-151	EL-151	EL-151	EL-155	EL-156	EL-157	EL-158	EL-158	EL-159	EL-159	EL-160	EL-161	EL-161	EL-162	EL-162	EL-163	EL-163	EL-164	EL-164	EL-164	EL-165			
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Preliminary check 4	Preliminary check 5	Power supply circuit	Ground circuit	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	Diagnostic procedure 7	Diagnostic procedure 8	Diagnostic procedure 9	Diagnostic procedure 10	Diagnostic procedure 11	Diagnostic procedure 12	Diagnostic procedure 13	Diagnostic procedure 14	Key board	Beeper	Key switch	Door switch			
When key pad is pressed, it does not beep and light does not glow.						<input type="radio"/>	<input type="radio"/>	<input type="radio"/>															<input type="radio"/>	<input type="radio"/>				
When key pad is pressed, it beeps but light does not glow.						<input type="radio"/>			<input type="radio"/>														<input type="radio"/>					
When key pad is pressed, it does not beep but light glows.							<input type="radio"/>			<input type="radio"/>													<input type="radio"/>	<input type="radio"/>				
When a fixed number is entered, a long beep is not heard.	<input type="radio"/>										<input type="radio"/>												<input type="radio"/>	<input type="radio"/>				
After a fixed number has been entered, registration sound (repeated beeps) is not heard even if code number entered.	<input type="radio"/>											<input type="radio"/>																
Both door lock and unlock functions do not work with key pad operation.	①	②											<input type="radio"/>															
Doors do not lock when key pad (<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>LCK</td></tr><tr><td>9 0</td></tr></table>) is pressed.	LCK	9 0	①	②													<input type="radio"/>										<input type="radio"/>	<input type="radio"/>
LCK																												
9 0																												
Doors do not unlock when code number is entered.	①	②														<input type="radio"/>												
Driver side window does not open with key pad operation.	①		②														<input type="radio"/>											
Passenger side window does not open with key pad operation.	①		②															<input type="radio"/>										
Sun roof does not open with key pad operation	①			②															<input type="radio"/>									
Trunk lid does not open with key pad operation.	①				②															<input type="radio"/>								
Door locks if key pad (<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>LCK</td></tr><tr><td>9 0</td></tr></table>) is pressed when key is inserted in steering lock.	LCK	9 0																						<input type="radio"/>			<input type="radio"/>	
LCK																												
9 0																												
Door locks if key pad (<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>LCK</td></tr><tr><td>9 0</td></tr></table>) is pressed when door left ajar.	LCK	9 0														<input type="radio"/>												<input type="radio"/>
LCK																												
9 0																												

①, ②: The number means checking order.







DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 2

SYMPTOM: When key pad is pressed, it beeps but light does not glow.

- Perform Main power supply circuit check before referring to the following flow chart.




C

Check circuit continuity between each terminal on keyboard and control unit.

Terminal No.		Continuity
Keyboard	Control unit	
④	⑯	Yes

Repair harness and connector.



Replace control unit.






DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 3

SYMPTOM: When key pad is pressed, it does not beep but light glows.

- Perform Ground circuit check before referring to the following flow chart.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX


DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 4

SYMPTOM: When a fixed number is entered, a long beep is not heard.


- Perform Preliminary check 1 before referring to the following flow chart.



Diagnostic procedure 5

SYMPTOM: After a fixed number has been entered, registration sound (repeated beeps) is not heard even if code number is entered.

- Perform Preliminary check 1 before referring to the following flow chart.




DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)


Diagnostic procedure 6

SYMPTOM: Both door lock and unlock functions do not work with key pad operation.

Perform Preliminary check 1 and 2 before referring to the following flow chart.





A




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
DX

Diagnostic procedure 7

SYMPTOM: Door locks if key pad () is pressed when door is left ajar.



A






DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 8

SYMPTOM: Doors do not lock when key pad ($\begin{matrix} \text{LOCK} \\ 9/10 \end{matrix}$) is pressed.

- Perform Preliminary check 1 and 2 before referring to the following flow chart.






DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 9

SYMPTOM: Doors do not unlock when code number is entered.



- Perform Preliminary check 1 and 2 before referring to the following flow chart.



Diagnostic procedure 10

SYMPTOM: Driver side window does not open with key pad operation.

- Perform Preliminary check 1 and 3 before referring to the following flow chart.







Trouble Diagnoses (Cont'd)

Diagnostic procedure 11

SYMPTOM: Passenger side window does not open with key pad operation.


- Perform Preliminary check 1 and 3 before referring to the following flow chart.



Diagnostic procedure 12

SYMPTOM: Sun roof does not open with key pad operation.

- Perform Preliminary check 1 and 4 before referring to the following flow chart.








DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 13


SYMPTOM: Trunk lid does not open with key pad operation.

- Perform Preliminary check 1 and 5 before referring to the following flow chart.



Diagnostic procedure 14

SYMPTOM: Door locks if key pad (LOK 910) is pressed when key is inserted in steering lock.



DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION


Keyboard

Check continuity between terminals by pushing each key pad.

Pushed keypad	One terminal	Other terminals			
		⑤	①	⑥	②
	③	○			○
			○		○
				○	○
		○	○		
			○	○	
		○		○	

Beeper


Check if it beeps when 12V is supplied.



Key switch

Check continuity between terminals when key is inserted in, and removed from key cylinder.

KEY	INSERT	DRAW
1	○	
2	○	




DIGITAL TOUCH ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

Door switches

Check continuity between terminal and switch body.



GI

WA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Engine Compartment



LOCATION OF ELECTRICAL UNITS

Passenger Compartment



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Luggage Compartment



HARNESS LAYOUT

Outline



GI

WA

EM

LC

EF &
EC

FE

CL

WT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

HARNESS LAYOUT

Engine Room Harness

ENGINE COMPARTMENT



HARNESS LAYOUT

Engine Room Harness (Cont'd)

- (E1) : Hood switch
- (E2) : To (E1)
- (E3) : To (E2)
- (E4) : ASCD pump
- (E5) : Actuator (For anti-lock brake system)
- (E6) : Washer sensor
- (E7) : Washer motor
- (E8) : Front combination lamp RH
- (E9) : Headlamp RH
- (E10) : Front turn signal lamp RH
- (E11) : Front fog lamp RH (SE model)
- (E12) : Body ground
- (E13) : Horn RH
- (E14) : Horn ground
- (E15) : Ambient sensor (Auto A/C)
- (E16) : Horn LH
- (E17) : To alternator harness (VG engine model)
- (E18) : Alternator (VG engine model)
- (E19) : Cooling fan motor-1
- (E20) : Cooling fan motor-2
- (E21) : To battery cable
- (E22) : Battery (VE engine model)
- (E23) : Fusible link (VG engine model)
- (E24) : Battery
- (E25) : ASCD hold relay
- (E26) : Air conditioner relay
- (E27) : Bulb check relay
- (E28) : Horn relay

- (E29) : Wiper relay
- (E30) : Fog lamp relay (SE model)
- (E31) : Inhibitor relay (A/T model)
- (E32) : Interlock relay (M/T model for U.S.A.)
- (E33) : Cooling fan relay-3
- (E34) : Cooling fan relay-2
- (E35) : Cooling fan relay-1
- (E36) : Headlamp LH
- (E37) : Dual-pressure switch
- (E38) : Front turn signal lamp LH
- (E39) : Front fog lamp LH (SE model)
- (E40) : Front combination lamp LH
- (E41) : Body ground
- (E42) : ECCS relay
- (E43) : Theft warning relay
- (E44) : Fusible link box-1
- (E46) : Body ground (For anti-lock brake system)
- (E47) : Brake fluid level switch
- (E49) : Front sensor LH
(For anti-lock brake system)
- (E50) : Joint connector-1
- (E51) : Joint connector-2
- (E52) : Joint connector-3
- (E53) : FICD relay
- (E54) : Ignition coil relay
- (E55) : Cornering lamp relay
- (E56) : Fusible link box-2
- (E57) : To alternator harness
(VE engine model)
- (E58) : Alternator
- (E59) : Check connector
(For tachometer)
- (E60) : Check connector
(For timing light)





GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX

HARNESS LAYOUT


Engine Room Harness (Cont'd)

PASSENGER COMPARTMENT

- (E101) : To (M12) (SM4)
- (E102) : To (M10)
- (E103) : To (M11) (For anti-lock brake system)
- (E104) : Clutch interlock switch (M/T model for U.S.A.)
- (E105) : ASCD clutch switch (M/T model)
- (E106) : Fuse block
- (E107) : Daytime light unit (For Canada)
- (E108) : Body ground
- (E109) : Key-in switch
- (E110) : Ignition switch
- (E111) : Key illumination
- (E112) : Key lock solenoid (A/T model)
- (E113) : Lighting switch




- (E114) : ASCD steering switch-Horn switch (Model without air bag)
- (E117) : Joint connector-4
- (E118) : Joint connector-5
- (E119) : Joint connector-6
- (E121) : Joint connector-7
- (E122) : Diode (VE engine model with manual A/C)
- (E123) : To (A3) (Model with air bag)
- (E124) : Cornering lamp switch
- (E125) : Resistor (VE engine model)



HARNESS LAYOUT

Air Bag Harness




- A1 : Front crash zone sensor
- A2 : To spiral cable
- A3 : To E12
- A4 : To H44
- A5 : Air bag control unit
- A6 : Air bag control unit
- A7 : Tunnel sensor and safing sensor

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNESS LAYOUT

Main Harness



HARNES LAYOUT


Main Harness (Cont'd)

- (N1) : Body ground
- (N2) : Ignition relay-2
- (N3) : Switching relay (BOSE type)
- (N4) : Cornering lamp relay (VG engine)
- (N5) : To (N1) (Without digital touch entry system)
- (N6) : To (N1) (With digital touch entry system)
- (N7) : To (N1)
- (N8) : To (N1)
- (N9) : To (E102)
- (N10) : To (E103) (For anti-lock braking system)
- (N11) : To (E10) (SMJ)
- (N12) : To (E10) (SMJ)
- (N13) : Data link connector for CONSULT
- (N14) : Check connector (VG engine model)
- (N15) : Circuit breaker-2
- (N16) : Fuse block
- (N17) : Theft warning control unit
- (N18) : Time control unit
- (N19) : Stop lamp switch
- (N20) : ASCD cancel switch
- (N21) : Rear window defogger relay
- (N22) : To (L1) (SMJ)
- (N23) : Circuit breaker-1
- (N24) : Interrupt relay
- (N25) : Door lock timer
- (N26) : Front limit switch LH (For U.S.A.)
- (N27) : Mode door motor
- (N28) : ASCD control unit
- (N29) : Combination flasher unit
- (N30) : Hazard switch
- (N31) : In-vehicle sensor (Auto A/C)
- (N32) : Cigarette lighter (For Canada)
- (N33) : Cigarette lighter (For U.S.A.)
- (N34) : To (F51) (A/T model)
- (N35) : To (F52)
- (N36) : To (F53)
- (N37) : Body ground
- (N38) : Automatic seat belt control unit (For U.S.A.)
- (N39) : A/T mode switch (A/T model)
- (N40) : Ash tray illumination
- (N41) : To (M) (Model with air bag)
- (N42) : Radio
- (N43) : Full cold switch and fresh vent control illumination (Manual A/C)
- (N44) : Push control unit (Manual A/C)
- (N45) : Fan switch (Manual A/C)
- (N46) : Fresh vent control illumination (Auto A/C)
- (N47) : Auto air conditioner amp. (Auto A/C)


- (N63) : Air mix door motor (Auto A/C)
- (N62) : Intake sensor (Auto A/C)
- (N61) : Fan control amp. (Auto A/C)
- (N60) : Resistor (Manual A/C)
- (N59) : Blower motor
- (N58) : Blower HI relay (Auto A/C)
- (N57) : Shift lock control unit (A/T model)
- (N56) : Digital touch entry control unit (GXE model)
- (N55) : To (B3) (With BOSE type speaker without digital touch entry system)
- (N54) : To (B3) (With digital touch entry system)
- (N53) : To (D12)
- (N52) : To (D11)
- (N51) : Body ground
- (N50) : To (R1)
- (N49) : Intake door motor

- (N65) : Joint connector-8
 - (N64) : Joint connector-9
 - (N63) : Blower relay (Manual A/C)
 - (N62) : Diode
 - (N61) : Vent mode switch (Manual A/C)
 - (N60) : Maximum cold door motor (Manual A/C)
 - (N59) : Maximum cold relay (Manual A/C)
 - (N58) : Thermo control amplifier
 - (N57) : Daytime light relay (For Canada)
- Engine compartment**
- (N66) : Front sensor RH (For anti-lock brake system)
 - (N65) : Body ground (For anti-lock brake system)
 - (N64) : Wiper motor

Diode (In joint connector-8 (N65), in joint connector-9 (N66))



Diode (N68)




- (U) : For U.S.A.
- (N) : For Canada
- (S) : M/T model for U.S.A.
- (C) : M/T model for Canada

EL
 IDX
 HA
 BT
 ST
 BR
 FA
 AT
 MT
 CL
 FF
 FF
 LC
 EM
 MA
 GI

HARNESS LAYOUT

Main Harness (Cont'd)



HARNES LAYOUT

Main Harness (Cont'd)

- (M11) : Rear limit switch and shoulder belt buckle switch RH
(For U.S.A.)
- (M12) : To (072)
- (M13) : To (071)
- (M14) : Drive motor RH (For U.S.A.)
- (M15) : Front door switch RH
- (M16) : To power seat harness RH
- (M17) : Shift lock solenoid and detention switch (A/T model)
- (M18) : Overdrive switch and A/T indicator illumination
(A/T model)
- (M19) : Parking brake switch
- (M20) : Lap belt buckle switch (For U.S.A.)
Seat belt switch (For Canada)
- (M21) : To power seat harness LH
- (M22) : Front door switch LH
- (M23) : Drive motor LH (For U.S.A.)
- (M24) : To (061)
- (M25) : To (062)
- (M26) : Rear limit switch and shoulder belt buckle switch LH
(For U.S.A.)
- (M27) : Fuel tank gauge unit
- (M28) : To (M16) (For anti-lock brake system)
- (M29) : Rear door switch LH
- (M30) : Rear speaker LH (Active speaker type)
- (M31) : Rear speaker LH (BOSE type)
- (M32) : License lamp LH
- (M33) : License lamp RH
- (M34) : Rear amplifier (Active speaker type)
- (M35) : Trunk lid opener relay (With digital touch entry system)

- (M37) : Anti-lock braking system control unit
- (M38) : Power antenna timer
- (M39) : Power antenna motor
- (M40) : Rear door switch RH
- (M41) : Body ground (For anti-lock brake system)
- (M42) : Rear speaker RH (Active speaker type)
- (M43) : Rear speaker RH (BOSE type)
- (M44) : Rear side marker lamp RH
- (M45) : Rear combination lamp RH
- (M46) : High-mounted stop lamp
(Without rear air spoiler)
- (M47) : Trunk lid unlock switch
- (M48) : Trunk room lamp
- (M49) : High-mounted stop lamp (With rear air spoiler)
- (M50) : Trunk room lamp switch
- (M51) : Rear window defogger
- (M52) : Trunk lid opener solenoid
- (M53) : Body ground
- (M54) : Fuel pump relay
- (M55) : Safety relay (VG engine model)
- (M56) : Rear combination lamp LH
- (M57) : Rear side marker LH
- (M58) : Body ground

Rear sensor harness (For anti-lock brake system)


- (M59) : To (M18)
- (M60) : Rear sensor RH
- (M61) : Rear sensor LH

GF
 MA
 EW
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX

HARNESS LAYOUT

Engine Control Harness

VG ENGINE



HARNESS LAYOUT


Engine Control Harness (Cont'd)

- (F1) : To (E2)
- (F2) : To (E3)
- (F3) : Camshaft position sensor
- (F4) : Resistor and condenser
- (F5) : Compressor
- (F6) : Ignition coil
- (F7) : Power transistor
- (F8) : To knock sensor sub-harness
- (F9) : Not used
- (F10) : Throttle position switch
- (F11) : Throttle position sensor
- (F12) : Heated oxygen sensor
- (F13) : EGR temperature sensor
(For California)
- (F14) : EGRC-solenoid valve
- (F15) : IACV-AAC valve
- (F16) : To injector sub-harness
- (F17) : Power valve control solenoid valve
- (F18) : Revolution sensor
- (F19) : To terminal cord assembly
- (F21) : Inhibitor switch
- (F22) : Dropping resistor
- (F23) : Mass air flow sensor
- (F24) : Vehicle speed sensor
- (F25) : To oil pressure switch sub harness
- (F26) : To water cock solenoid sub-harness

- (F27) : Injector No. 5
- (F28) : Engine ground
- (F29) : Injector No. 3
- (F30) : Injector No. 1
- (F31) : Engine ground
- (F32) : Power steering oil pressure switch
- (F33) : Engine coolant temperature sensor
- (F34) : Thermal transmitter

Passenger compartment

- (F41) : To (M5)
- (F42) : To (M6)
- (F43) : To (M7)
- (F44) : ECM (ECCS control module)
- (F45) : A/T control unit




Gf
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX




HARNESS LAYOUT

Engine Control Harness (Cont'd)

VE ENGINE



Passenger compartment



HARNESS LAYOUT

Engine Control Harness (Cont'd)

- (F1) : To (E1)
- (F2) : To (E2)
- (F3) : Ignition coil No. 2
- (F4) : Ignition coil No. 4
- (F5) : Compressor
- (F6) : Ignition coil No. 6
- (F7) : Camshaft position sensor
- (F8) : To knock sensor sub-harness
- (F9) : Engine ground
- (F10) : Throttle position switch
- (F11) : Throttle position sensor
- (F12) : Power transistor unit
- (F13) : EGR temperature sensor
(For California)
- (F14) : EGRC-solenoid valve
- (F15) : IACV-AAC valve
- (F16) : IACV-FICD solenoid valve
- (F17) : Power valve control solenoid valve (M/T model)
- (F18) : Revolution sensor (A/T model)
- (F19) : To terminal cord assembly (A/T model)
- (F20) : Neutral and reverse position switch (M/T model)
- (F21) : Inhibitor switch (A/T model)
- (F22) : Dropping resistor (A/T model)
- (F23) : Mass air flow sensor
- (F24) : Vehicle speed sensor
- (F25) : Heated oxygen sensor
- (F26) : To water cock solenoid sub-harness

- (F27) : Injector No. 6
- (F28) : Engine ground
- (F29) : Injector No. 4
- (F30) : Injector No. 2
- (F31) : Engine ground
- (F32) : Power steering oil pressure switch
- (F33) : Engine coolant temperature sensor
- (F34) : Thermal transmitter
- (F35) : VTC solenoid valve-LH
- (F36) : VTC solenoid valve-RH
- (F37) : To injector sub-harness
- (F38) : Engine ground
- (F39) : Ignition coil No. 1
- (F40) : Ignition coil No. 3
- (F41) : Ignition coil No. 5

Passenger compartment

- (F51) : To (M35) (A/T model)
- (F52) : To (M36)
- (F53) : To (M37)
- (F54) : ECM (ECCS control module)
- (F55) : A/T control unit (A/T model)

GI

MA

EM

LC

FF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


FDX

HARNESS LAYOUT

Instrument Harness




Room Lamp and Sun Roof Harness




HARNESS LAYOUT

Door Harness (LH side)

FRONT DOOR HARNESS



REAR DOOR HARNESS



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

HARNESS LAYOUT

Door Harness (RH side)


FRONT DOOR HARNESS



- | | |
|---|--|
| D31 : To M61 | D41 : Keyboard and LED
(For digital touch entry system) |
| D32 : To M60 | D42 : Beeper (For digital touch entry system) |
| D33 : To M59 (With digital touch entry system) | D43 : Door latch switch |
| D34 : To M58 (With BOSE type speaker, without digital touch entry system) | D44 : Door lock knob switch |
| D35 : Door speaker (BOSE type) | D45 : Key cylinder switch |
| D36 : Door speaker (Active speaker type) | D46 : Step lamp |
| D37 : Door mirror defogger | D47 : Door actuator |
| D38 : Door mirror | |
| D39 : Sub-switch | |
| D40 : Power window regulator | |

SEL662QA

REAR DOOR HARNESS



- | |
|------------------------------|
| D71 : To M103 |
| D72 : To M102 |
| D73 : Power window regulator |
| D74 : Sub-switch |
| D75 : Step lamp |
| D76 : Door actuator |

SEL647N