

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN		
PRECAUTIONS	5	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	
Precautions When Using CONSULT-II	5	
CHECK POINTS FOR USING CONSULT-II	5	
Precautions for CAN System	5	
Wiring Diagrams and Trouble Diagnosis	6	
CAN COMMUNICATION	7	
System Description	7	
CAN Communication Unit	7	
Input/Output Signal Chart	8	
TYPE 1/TYPE 2/TYPE 3	8	
TYPE 4/TYPE 5/TYPE 6	10	
TYPE 7/TYPE 8/TYPE 9/TYPE 10	13	
TYPE 11/TYPE 12/TYPE 13/TYPE 14	16	
TYPE 15/TYPE 16	19	
CAN SYSTEM (TYPE 1)	23	
System Description	23	
Component Parts and Harness Connector Location	23	
Schematic	24	
Wiring Diagram - CAN -	25	
Work Flow	27	
CHECK SHEET RESULTS (EXAMPLE)	29	
Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)	37	
ECM Circuit Check	38	
Display Unit Circuit Check	38	
Data Link Connector Circuit Check	39	
Unified Meter and A/C Amp. Circuit Check	39	
BCM Circuit Check	40	
ABS Actuator and Electric Unit (Control Unit) Circuit Check	40	
IPDM E/R Circuit Check	41	
CAN Communication Circuit Check	41	
IPDM E/R Ignition Relay Circuit Check	42	
Component Inspection	42	
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	42	
CAN SYSTEM (TYPE 2)	43	
System Description	43	
Component Parts and Harness Connector Location	43	
Schematic	44	
Wiring Diagram - CAN -	45	
Work Flow	47	
CHECK SHEET RESULTS (EXAMPLE)	49	
Circuit Check Between Data Link Connector and Driver Seat Control Unit	59	
Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	60	
ECM Circuit Check	60	
Display Unit Circuit Check	61	
Data Link Connector Circuit Check	61	
Unified Meter and A/C Amp. Circuit Check	62	
BCM Circuit Check	62	
Driver Seat Control Unit Circuit Check	63	
ABS Actuator and Electric Unit (Control Unit) Circuit Check	63	
IPDM E/R Circuit Check	64	
CAN Communication Circuit Check	64	
IPDM E/R Ignition Relay Circuit Check	65	
Component Inspection	65	
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	65	
CAN SYSTEM (TYPE 3)	66	
System Description	66	
Component Parts and Harness Connector Location	66	
Schematic	67	
Wiring Diagram - CAN -	68	
Work Flow	70	
CHECK SHEET RESULTS (EXAMPLE)	72	
Circuit Check Between Data Link Connector and Driver Seat Control Unit	82	
Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	83	
ECM Circuit Check	83	
Display Control Unit Circuit Check	84	
Data Link Connector Circuit Check	84	
Unified Meter and A/C Amp. Circuit Check	85	

F
G
H
I
J
LAN
L
M

BCM Circuit Check	85	Component Parts and Harness Connector Location	132
Driver Seat Control Unit Circuit Check	86	Schematic	133
ABS Actuator and Electric Unit (Control Unit) Circuit Check	86	Wiring Diagram - CAN -	134
IPDM E/R Circuit Check	87	Work Flow	136
CAN Communication Circuit Check	87	CHECK SHEET RESULTS (EXAMPLE)	138
IPDM E/R Ignition Relay Circuit Check	88	Circuit Check Between Data Link Connector and Driver Seat Control Unit	148
Component Inspection	88	Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	149
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	88	ECM Circuit Check	149
CAN SYSTEM (TYPE 4)	89	Display Control Unit Circuit Check	150
System Description	89	Data Link Connector Circuit Check	150
Component Parts and Harness Connector Location	89	Unified Meter and A/C Amp. Circuit Check	151
Schematic	90	BCM Circuit Check	151
Wiring Diagram - CAN -	91	Driver Seat Control Unit Circuit Check	152
Work Flow	93	ABS Actuator and Electric Unit (Control Unit) Circuit Check	152
CHECK SHEET RESULTS (EXAMPLE)	95	IPDM E/R Circuit Check	153
Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)	103	CAN Communication Circuit Check	153
ECM Circuit Check	104	IPDM E/R Ignition Relay Circuit Check	154
Display Unit Circuit Check	104	Component Inspection	154
Data Link Connector Circuit Check	105	ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	154
Unified Meter and A/C Amp. Circuit Check	105	CAN SYSTEM (TYPE 7)	155
BCM Circuit Check	106	System Description	155
ABS Actuator and Electric Unit (Control Unit) Circuit Check	106	Component Parts and Harness Connector Location	155
IPDM E/R Circuit Check	107	Schematic	156
CAN Communication Circuit Check	107	Wiring Diagram - CAN -	157
IPDM E/R Ignition Relay Circuit Check	108	Work Flow	160
Component Inspection	108	CHECK SHEET RESULTS (EXAMPLE)	162
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	108	Circuit Check Between TCM and Data Link Connector	173
CAN SYSTEM (TYPE 5)	109	Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)	173
System Description	109	ECM Circuit Check	174
Component Parts and Harness Connector Location	109	TCM Circuit Check	174
Schematic	110	Display Unit Circuit Check	175
Wiring Diagram - CAN -	111	Data Link Connector Circuit Check	175
Work Flow	113	Unified Meter and A/C Amp. Circuit Check	176
CHECK SHEET RESULTS (EXAMPLE)	115	BCM Circuit Check	176
Circuit Check Between Data Link Connector and Driver Seat Control Unit	125	ABS Actuator and Electric Unit (Control Unit) Circuit Check	177
Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	126	IPDM E/R Circuit Check	177
ECM Circuit Check	126	CAN Communication Circuit Check	178
Display Unit Circuit Check	127	IPDM E/R Ignition Relay Circuit Check	178
Data Link Connector Circuit Check	127	Component Inspection	179
Unified Meter and A/C Amp. Circuit Check	128	ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	179
BCM Circuit Check	128	CAN SYSTEM (TYPE 8)	180
Driver Seat Control Unit Circuit Check	129	System Description	180
ABS Actuator and Electric Unit (Control Unit) Circuit Check	129	Component Parts and Harness Connector Location	180
IPDM E/R Circuit Check	130	Schematic	181
CAN Communication Circuit Check	130	Wiring Diagram - CAN -	182
IPDM E/R Ignition Relay Circuit Check	131	Work Flow	185
Component Inspection	131	CHECK SHEET RESULTS (EXAMPLE)	187
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	131	Circuit Check Between TCM and Data Link Connector	200
CAN SYSTEM (TYPE 6)	132	Circuit Check Between Data Link Connector and Driver Seat Control Unit	200
System Description	132		

Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	201	Unified Meter and A/C Amp. Circuit Check	256	
ECM Circuit Check	201	BCM Circuit Check	257	A
TCM Circuit Check	202	Driver Seat Control Unit Circuit Check	257	
Display Unit Circuit Check	202	ABS Actuator and Electric Unit (Control Unit) Circuit Check	258	B
Data Link Connector Circuit Check	203	IPDM E/R Circuit Check	258	
Unified Meter and A/C Amp. Circuit Check	203	CAN Communication Circuit Check	259	
BCM Circuit Check	204	IPDM E/R Ignition Relay Circuit Check	259	C
Driver Seat Control Unit Circuit Check	204	Component Inspection	260	
ABS Actuator and Electric Unit (Control Unit) Circuit Check	205	ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	260	
IPDM E/R Circuit Check	205	CAN SYSTEM (TYPE 11)	261	D
CAN Communication Circuit Check	206	System Description	261	
IPDM E/R Ignition Relay Circuit Check	206	Component Parts and Harness Connector Location	261	
Component Inspection	207	Schematic	262	E
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	207	Wiring Diagram - CAN -	263	
CAN SYSTEM (TYPE 9)	208	Work Flow	266	
System Description	208	CHECK SHEET RESULTS (EXAMPLE)	268	F
Component Parts and Harness Connector Location	208	Circuit Check Between TCM and Data Link Con- nector	279	
Schematic	209	Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)	279	G
Wiring Diagram - CAN -	210	ECM Circuit Check	280	
Work Flow	213	TCM Circuit Check	280	
CHECK SHEET RESULTS (EXAMPLE)	215	Display Unit Circuit Check	281	H
Circuit Check Between TCM and Data Link Con- nector	226	Data Link Connector Circuit Check	281	
Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)	226	Unified Meter and A/C Amp. Circuit Check	282	
ECM Circuit Check	227	BCM Circuit Check	282	I
TCM Circuit Check	227	ABS Actuator and Electric Unit (Control Unit) Circuit Check	283	
Display Control Unit Circuit Check	228	IPDM E/R Circuit Check	283	J
Data Link Connector Circuit Check	228	CAN Communication Circuit Check	284	
Unified Meter and A/C Amp. Circuit Check	229	IPDM E/R Ignition Relay Circuit Check	284	
BCM Circuit Check	229	Component Inspection	285	
ABS Actuator and Electric Unit (Control Unit) Circuit Check	230	ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	285	LAN
IPDM E/R Circuit Check	230	CAN SYSTEM (TYPE 12)	286	
CAN Communication Circuit Check	231	System Description	286	L
IPDM E/R Ignition Relay Circuit Check	231	Component Parts and Harness Connector Location	286	
Component Inspection	232	Schematic	287	
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION	232	Wiring Diagram - CAN -	288	M
CAN SYSTEM (TYPE 10)	233	Work Flow	291	
System Description	233	CHECK SHEET RESULTS (EXAMPLE)	293	
Component Parts and Harness Connector Location	233	Circuit Check Between TCM and Data Link Con- nector	306	
Schematic	234	Circuit Check Between Data Link Connector and Driver Seat Control Unit	306	
Wiring Diagram - CAN -	235	Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	307	
Work Flow	238	ECM Circuit Check	307	
CHECK SHEET RESULTS (EXAMPLE)	240	TCM Circuit Check	308	
Circuit Check Between TCM and Data Link Con- nector	253	Display Unit Circuit Check	308	
Circuit Check Between Data Link Connector and Driver Seat Control Unit	253	Data Link Connector Circuit Check	309	
Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)	254	Unified Meter and A/C Amp. Circuit Check	309	
ECM Circuit Check	254	BCM Circuit Check	310	
TCM Circuit Check	255	Driver Seat Control Unit Circuit Check	310	
Display Control Unit Circuit Check	255	ABS Actuator and Electric Unit (Control Unit) Circuit Check	311	
Data Link Connector Circuit Check	256	IPDM E/R Circuit Check	311	

CAN Communication Circuit Check	312	CAN SYSTEM (TYPE 15)	367
IPDM E/R Ignition Relay Circuit Check	312	System Description	367
Component Inspection	313	Component Parts and Harness Connector Location	367
ECM AND IPDM E/R INTERNAL CIRCUIT		Schematic	368
INSPECTION	313	Wiring Diagram - CAN -	369
CAN SYSTEM (TYPE 13)	314	Work Flow	372
System Description	314	CHECK SHEET RESULTS (EXAMPLE)	374
Component Parts and Harness Connector Location	314	Circuit Check Between TCM and Data Link Con-	
Schematic	315	connector	388
Wiring Diagram - CAN -	316	Circuit Check Between Data Link Connector and	
Work Flow	319	Driver Seat Control Unit	388
CHECK SHEET RESULTS (EXAMPLE)	321	Circuit Check Between Driver Seat Control Unit and	
Circuit Check Between TCM and Data Link Con-		ABS Actuator and Electric Unit (Control Unit)	389
connector	332	ECM Circuit Check	389
Circuit Check Between Data Link Connector and		TCM Circuit Check	390
ABS Actuator and Electric Unit (Control Unit)	332	Display Unit Circuit Check	390
ECM Circuit Check	333	Data Link Connector Circuit Check	391
TCM Circuit Check	333	Unified Meter and A/C Amp. Circuit Check	391
Display Control Unit Circuit Check	334	Steering Angle Sensor Circuit Check	392
Data Link Connector Circuit Check	334	BCM Circuit Check	392
Unified Meter and A/C Amp. Circuit Check	335	Driver Seat Control Unit Circuit Check	393
BCM Circuit Check	335	ABS Actuator and Electric Unit (Control Unit) Circuit	
ABS Actuator and Electric Unit (Control Unit) Circuit		Check	393
Check	336	IPDM E/R Circuit Check	394
IPDM E/R Circuit Check	336	CAN Communication Circuit Check	394
CAN Communication Circuit Check	337	IPDM E/R Ignition Relay Circuit Check	395
IPDM E/R Ignition Relay Circuit Check	337	Component Inspection	395
Component Inspection	338	ECM AND IPDM E/R INTERNAL CIRCUIT	
ECM AND IPDM E/R INTERNAL CIRCUIT		INSPECTION	395
INSPECTION	338	CAN SYSTEM (TYPE 16)	396
CAN SYSTEM (TYPE 14)	339	System Description	396
System Description	339	Component Parts and Harness Connector Location	396
Component Parts and Harness Connector Location	339	Schematic	397
Schematic	340	Wiring Diagram - CAN -	398
Wiring Diagram - CAN -	341	Work Flow	401
Work Flow	344	CHECK SHEET RESULTS (EXAMPLE)	403
CHECK SHEET RESULTS (EXAMPLE)	346	Circuit Check Between TCM and Data Link Con-	
Circuit Check Between TCM and Data Link Con-		connector	417
connector	359	Circuit Check Between Data Link Connector and	
Circuit Check Between Data Link Connector and		Driver Seat Control Unit	417
Driver Seat Control Unit	359	Circuit Check Between Driver Seat Control Unit and	
Circuit Check Between Driver Seat Control Unit and		ABS Actuator and Electric Unit (Control Unit)	418
ABS Actuator and Electric Unit (Control Unit)	360	ECM Circuit Check	418
ECM Circuit Check	360	TCM Circuit Check	419
TCM Circuit Check	361	Display Control Unit Circuit Check	419
Display Control Unit Circuit Check	361	Data Link Connector Circuit Check	420
Data Link Connector Circuit Check	362	Unified Meter and A/C Amp. Circuit Check	420
Unified Meter and A/C Amp. Circuit Check	362	Steering Angle Sensor Circuit Check	421
BCM Circuit Check	363	BCM Circuit Check	421
Driver Seat Control Unit Circuit Check	363	Driver Seat Control Unit Circuit Check	422
ABS Actuator and Electric Unit (Control Unit) Circuit		ABS Actuator and Electric Unit (Control Unit) Circuit	
Check	364	Check	422
IPDM E/R Circuit Check	364	IPDM E/R Circuit Check	423
CAN Communication Circuit Check	365	CAN Communication Circuit Check	423
IPDM E/R Ignition Relay Circuit Check	365	IPDM E/R Ignition Relay Circuit Check	424
Component Inspection	366	Component Inspection	424
ECM AND IPDM E/R INTERNAL CIRCUIT		ECM AND IPDM E/R INTERNAL CIRCUIT	
INSPECTION	366	INSPECTION	424

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS0025K

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS002MT

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-7, "CAN Communication Unit"](#) .


Precautions for CAN System

UKS0025L

- Do not apply voltage of 7.0 V or higher to terminal to be measured.
- Maximum open terminal voltage of tester in use must be less than 7.0 V.
- Before checking harnesses, turn ignition switch OFF and disconnect battery negative cable.
- Area to be repaired must be soldered and wrapped with tape. Make sure that fraying of twisted wire is within 110 mm (4.33 in).



- Do not make a bypass connection to repaired area. (If the circuit is bypassed, characteristics of twisted wire will be lost.)



UKS0025M

Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-13, "How to Read Wiring Diagrams"](#)
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

CAN COMMUNICATION

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan															
Axle	2WD															
Engine	VQ35DE															
Transmission	M/T						5A/T									
Brake control	ABS			TCS			ABS				TCS				VDC	
Navigation system			x			x			x	x			x	x		x
Automatic drive positioner		x	x		x	x		x		x		x		x	x	x
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
CAN system trouble diagnosis	LA N- 23	LA N- 43	LA N- 66	LA N- 89	LA N- 109	LA N- 132	LA N- 155	LA N- 180	LA N- 208	LA N- 233	LA N- 261	LA N- 286	LA N- 314	LA N- 339	LA N- 367	LA N- 396

x: Applicable

NOTE:

Confirming the presence of the following items helps to identify CAN system type.




CAN COMMUNICATION

[CAN]


UKS0025P

Input/Output Signal Chart TYPE 1/TYPER 2/TYPER 3


- Type 1



- Type 2



- Type 3



CAN COMMUNICATION

[CAN]

T: Transmit R: Receive

Signals	ECM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R	R				
Engine status signal	T				R			
Engine coolant temperature signal	T			R				
Key switch signal					T	R		
Ignition switch signal					T	R		R
Fuel consumption monitor signal	T			R				
		R	R	T				
A/C switch signal	R				T			
A/C compressor request signal	T							R
Blower fan motor switch signal	R				T			
A/C control signal		T	T	R				
		R	R	T				
Cooling fan speed request signal	T							R
Cooling fan speed signal	R							T
Position light request signal				R	T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal				R	T			R
High beam status signal	R							T
Front fog light request signal					T			R
Day time running light request signal				R	T			
Vehicle speed signal				R			T	
	R		R	T	R	R		
Sleep wake up signal				R	T	R		
Door switch signal		R	R	R	T	R		R
Trunk switch signal				R	T			
Turn indicator signal				R	T			
Cornering lamp request signal					T			R
Key fob ID signal					T	R		
Key fob door unlock signal					T	R		
Oil pressure switch signal					R			T
				R	T			
Buzzer output signal				R	T			
Fuel level sensor signal	R			T				
ASCD SET indicator signal	T			R				
ASCD CRUISE indicator signal	T			R				
Malfunction indicator lamp signal	T			R				
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R

A

B

C

D

E

F

G

H

I

J

LAN

L

M


CAN COMMUNICATION

[CAN]


Signals	ECM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Rear window defogger control signal	R	R	R					T
Hood switch signal					R			T
Theft warning horn request signal					T			R
Horn chirp signal					T			R
ABS warning lamp signal				R			T	
Brake warning lamp signal				R			T	
System setting signal		T	T		R	R		
		R	R		T	T		
Distance to empty signal		R	R	T				
Seat belt buckle switch signal				T	R			
Parking brake switch signal				T	R	R		

TYPE 4/TYPER 5/TYPER 6

- Type 4




- Type 5



CAN COMMUNICATION

[CAN]

● Type 6



T: Transmit R: Receive

Signals	ECM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R	R			R	
Engine status signal	T				R			
Engine coolant temperature signal	T			R				
Key switch signal					T	R		
Ignition switch signal					T	R		R
Fuel consumption monitor signal	T			R				
		R	R	T				
A/C switch signal	R				T			
A/C compressor request signal	T							R
Blower fan motor switch signal	R				T			
A/C control signal		T	T	R				
		R	R	T				
Cooling fan speed request signal	T							R
Cooling fan speed signal	R							T
Position light request signal				R	T			R
Low beam request signal					T			R
Low beam status signal	R							T
High beam request signal				R	T			R
High beam status signal	R							T
Front fog light request signal					T			R
Day time running light request signal				R	T			
Vehicle speed signal				R			T	
	R		R	T	R	R		
Sleep wake up signal				R	T	R		R
Door switch signal		R	R	R	T	R		R
Trunk switch signal				R	T			

CAN COMMUNICATION

[CAN]


Signals	ECM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Turn indicator signal				R	T			
Cornering lamp request signal					T			R
Key fob ID signal					T	R		
Key fob door unlock signal					T	R		
Oil pressure switch signal					R			T
				R	T			
Buzzer output signal				R	T			
Fuel level sensor signal	R			T				
ASCD SET indicator signal	T			R				
ASCD CRUISE indicator signal	T			R				
Malfunction indicator lamp signal	T			R				
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Rear window defogger switch signal					T			R
Rear window defogger control signal	R	R	R					T
Hood switch signal					R			T
Theft warning horn request signal					T			R
Horn chirp signal					T			R
ABS warning lamp signal				R			T	
Brake warning lamp signal				R			T	
SLIP indicator lamp signal				R			T	
Accelerator pedal position signal	T						R	
System setting signal		T	T		R	R		
		R	R		T	T		
Distance to empty signal		R	R	T				
Seat belt buckle switch signal				T	R			
Parking brake switch signal				T	R	R		

CAN COMMUNICATION


[CAN]

TYPE 7/TYPE 8/TYPE 9/TYPE 10


- Type 7



- Type 8



- Type 9




A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION

[CAN]

● Type 10



T: Transmit R: Receive

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R				
Engine status signal	T					R			
Engine coolant temperature signal	T	R			R				
Key switch signal						T	R		
Ignition switch signal						T	R		R
Closed throttle position signal	T	R							
ABS operation signal		R						T	
Fuel consumption monitor signal	T				R				
			R	R	T				
A/C switch signal	R					T			
A/C compressor request signal	T								R
Blower fan motor switch signal	R					T			
A/C control signal			T	T	R				
			R	R	T				
Cooling fan speed request signal	T								R
Cooling fan speed signal	R								T
Position light request signal					R	T			R
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal					R	T			R
High beam status signal	R								T
Front fog light request signal						T			R
Day time running light request signal					R	T			
Vehicle speed signal					R			T	
	R	R		R	T	R	R		

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Sleep wake up signal					R	T	R		
Door switch signal			R	R	R	T	R		R
Trunk switch signal					R	T			
Turn indicator signal					R	T			
Cornering lamp request signal						T			R
Key fob ID signal						T	R		
Key fob door unlock signal						T	R		
Oil pressure switch signal					R	T			T
Buzzer output signal					R	T			
Fuel level sensor signal	R				T				
ASCD SET indicator signal	T				R				
ASCD CRUISE indicator signal	T				R				
Malfunction indicator lamp signal	T				R				
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R		R	R					T
Hood switch signal						R			T
Theft warning horn request signal						T			R
Horn chirp signal						T			R
ABS warning lamp signal					R			T	
Brake warning lamp signal					R			T	
System setting signal			T	T		R	R		
			R	R		T	T		
Distance to empty signal			R	R	T				
Seat belt buckle switch signal					T	R			
Parking brake switch signal					T	R	R		
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
A/T CHECK indicator lamp signal		T			R				
A/T position indicator lamp signal		T			R				
Manual mode indicator signal		T			R				
A/T self-diagnosis signal	R	T							
Electric throttle control signal	T	R							
Engine and A/T integrated control signal	T	R							
	R	T							
P range signal		T					R	R	
R range signal		T					R		
Stop lamp switch signal		R			T				

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN


CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Input shaft revolution signal	R	T							
Output shaft revolution signal	R	T							

TYPE 11/TYPE 12/TYPE 13/TYPE 14

- Type 11




- Type 12




CAN COMMUNICATION

[CAN]

● Type 13



● Type 14



T: Transmit R: Receive

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			R	
Engine status signal	T					R			
Engine coolant temperature signal	T	R			R				
Key switch signal						T	R		
Ignition switch signal						T	R		R
Closed throttle position signal	T	R							
ABS operation signal		R						T	
Fuel consumption monitor signal	T				R				
			R	R	T				
A/C switch signal	R					T			
A/C compressor request signal	T								R

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Blower fan motor switch signal	R					T			
A/C control signal			T	T	R				
			R	R	T				
Cooling fan speed request signal	T								R
Cooling fan speed signal	R								T
Position light request signal					R	T			R
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal					R	T			R
High beam status signal	R								T
Front fog light request signal						T			R
Day time running light request signal					R	T			
Vehicle speed signal					R			T	
	R	R		R	T	R	R		
Sleep wake up signal					R	T	R		R
Door switch signal			R	R	R	T	R		R
Trunk switch signal					R	T			
Turn indicator signal					R	T			
Cornering lamp request signal						T			R
Key fob ID signal						T	R		
Key fob door unlock signal						T	R		
Oil pressure switch signal						R			T
					R	T			
Buzzer output signal					R	T			
Fuel level sensor signal	R				T				
ASCD SET indicator signal	T				R				
ASCD CRUISE indicator signal	T				R				
Malfunction indicator lamp signal	T				R				
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R		R	R					T
Hood switch signal						R			T
Theft warning horn request signal						T			R
Horn chirp signal						T			R
ABS warning lamp signal					R			T	
Brake warning lamp signal					R			T	
System setting signal			T	T		R	R		
			R	R		T	T		
Distance to empty signal			R	R	T				


CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Seat belt buckle switch signal					T	R			
Parking brake switch signal					T	R	R		
A/T self-diagnosis signal	R	T							
Electric throttle control signal	T	R							
Engine and A/T integrated control signal	T	R							
	R	T							
Accelerator pedal position signal	T							R	
P range signal		T					R	R	
R range signal		T					R		
Stop lamp switch signal		R			T				
TCS operation signal	R	R						T	
Input shaft revolution signal	R	T							
Output shaft revolution signal	R	T							
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
SLIP indicator lamp signal					R			T	
A/T CHECK indicator lamp signal		T			R				
A/T position indicator lamp signal		T			R				
A/T shift schedule change demand signal		R						T	
Manual mode indicator signal		T			R				

TYPE 15/TYPE 16


- Type 15



CAN COMMUNICATION

[CAN]

● Type 16



PKIB1723E

T: Transmit R: Receive

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	Steering angle sensor	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R				R	
Engine status signal	T						R			
Engine coolant temperature signal	T	R			R					
Key switch signal							T	R		
Ignition switch signal							T	R		R
Closed throttle position signal	T	R								
ABS operation signal		R							T	
Fuel consumption monitor signal	T				R					
			R	R	T					
A/C switch signal	R						T			
A/C compressor request signal	T									R
Blower fan motor switch signal	R						T			
A/C control signal			T	T	R					
			R	R	T					
Cooling fan speed request signal	T									R
Cooling fan speed signal	R									T
Position light request signal					R		T			R
Low beam request signal							T			R
Low beam status signal	R									T
High beam request signal					R		T			R
High beam status signal	R									T
Front fog light request signal							T			R
Day time running light request signal					R		T			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display unit	Display control unit	Unified meter and A/C amp.	Steering angle sensor	BCM	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Vehicle speed signal					R				T	
	R	R		R	T		R	R		
Sleep wake up signal					R		T	R		R
Door switch signal			R	R	R		T	R		R
Trunk switch signal					R		T			
Turn indicator signal					R		T			
Cornering lamp request signal							T			R
Key fob ID signal							T	R		
Key fob door unlock signal							T	R		
Oil pressure switch signal							R			T
					R		T			
Buzzer output signal					R		T			
Fuel level sensor signal	R				T					
ASCD SET indicator signal	T				R					
ASCD CRUISE indicator signal	T				R					
Malfunction indicator lamp signal	T				R					
Front wiper request signal							T			R
Front wiper stop position signal							R			T
Rear window defogger switch signal							T			R
Rear window defogger control signal	R		R	R						T
Hood switch signal							R			T
Theft warning horn request signal							T			R
Horn chirp signal							T			R
ABS warning lamp signal					R				T	
Brake warning lamp signal					R				T	
System setting signal			T	T			R	R		
			R	R			T	T		
Distance to empty signal			R	R	T					
Seat belt buckle switch signal					T		R			
Parking brake switch signal					T		R	R		
A/T self-diagnosis signal	R	T								
Electric throttle control signal	T	R								
Engine and A/T integrated control signal	T	R								
	R	T								
Accelerator pedal position signal	T								R	
P range signal		T						R	R	
R range signal		T						R		
Stop lamp switch signal		R			T					
TCS operation signal	R	R							T	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Dis- play unit	Dis- play con- trol unit	Uni- fied meter and A/ C amp.	Steer- ing angle sensor	BCM	Driver seat con- trol unit	ABS actua- tor and elec- tric unit (con- trol unit)	IPDM E/R
VDC operation signal	R	R							T	
Input shaft revolution signal	R	T								
Output shaft revolution signal	R	T								
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
Steering angle sensor signal						T			R	
VDC OFF indicator lamp signal					R				T	
SLIP indicator lamp signal					R				T	
A/T CHECK indicator lamp signal		T			R					
A/T position indicator lamp signal		T			R					
A/T shift schedule change demand sig- nal		R							T	
Manual mode indicator signal		T			R					

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

UKS0025Q

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0025R



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS0025S



BKWA0258E

CAN SYSTEM (TYPE 1)


[CAN]

Wiring Diagram - CAN -

UKS0025T


LAN-CAN-01

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.
M82 - ELECTRICAL UNITS

BKWA0260E

LAN-CAN-02



REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS

BKWA0261E


CAN SYSTEM (TYPE 1)

[CAN]


UKS0025U

Work Flow


- When there are no indications of "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					IPDM E/R
	ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS			
ENGINE	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN
Display unit	CAN COMM	CAN 1	CAN 3	CAN 5	CAN 2	-	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-

BKIA0054E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-37, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						
			Receive diagnosis						
			ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2124E



CAN SYSTEM (TYPE 1)

[CAN]


Case 2

Check ECM circuit. Refer to [LAN-38, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	UNKWN	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2125E

//// : Malfunctioning part




PKIB1816E

Case 3

Check display unit circuit. Refer to [LAN-38, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						
			ECM			DISPLAY			
			ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	✓1	✓3	✓5	✓2	-	✓7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2126E



PKIB1817E

A
B
C
D
E
F
G
H
I
J

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 4

Check data link connector circuit. Refer to [LAN-39, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No notification ✓	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No notification ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No notification ✓	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2127E

//// : Malfunctioning part



PKIB1818E

CAN SYSTEM (TYPE 1)

[CAN]


Case 5

Check unified meter and A/C amp. circuit. Refer to [LAN-39, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	UNKWN	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2129E

//// : Malfunctioning part



PKIB1819E

A
B
C
D
E
F
G
H
I
J
L
M

LAN


Case 6

Check BCM circuit. Refer to [LAN-40, "BCM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
			ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	UNKWN	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2823E

//// : Malfunctioning part



PKIB1820E

CAN SYSTEM (TYPE 1)

[CAN]


Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-40, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2130E

//// : Malfunctioning part



PKIB1821E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check IPDM E/R circuit. Refer to [LAN-41, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2131E



Case 9

Check CAN communication circuit. Refer to [LAN-41, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2132E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-42, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2134E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-42, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2133E

Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS0025V

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

6 (L) - 20 (L) : Continuity should exist.

14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-27, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and data link connector M22.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-27, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-42, "Component Inspection"](#).

NG >> Repair the harness.



UKS00264

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : Approx. 108 - 132 Ω

UKS00265




CAN SYSTEM (TYPE 2)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS00268



BKWA0262E

CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram - CAN -

UKS00269


LAN-CAN-03

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.
M82 - ELECTRICAL UNITS

BKWA0263E

LAN-CAN-04



REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS

BKWA0265E


CAN SYSTEM (TYPE 2)

[CAN]


UKS0026A

Work Flow


- When there are no indications of "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

BKIA0055E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and driver seat control unit. Refer to [LAN-59, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ MSA	BCM/SEC	VDC/CSI/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2194E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 2

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-60, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	UNKWN	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2200E

//// : Malfunctioning part




PKIB1824E

Case 3

Check ECM circuit. Refer to [LAN-60, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VIC/TCU/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	CAN 1	✓	✓	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2203E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check display unit circuit. Refer to [LAN-61, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	✓1	✓3	-	✓5	✓2	-	✓7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2207E




PKIB1826E

Case 5

Check data link connector circuit. Refer to [LAN-61, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No malfunction	✓	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No malfunction	✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	
AUTO DRIVE POS.	No malfunction	✓	NG	UNKWN	-	-	UNKWN	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No malfunction	✓	-	UNKWN	UNKWN	-	UNKWN	-	-	

WKIA2209E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-62, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	UNKWN	CAN 2	-	CAN 7
METER/A/C AMP	No indication ✓	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2211E



PKIB1828E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-62, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	✓ CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2210E



A
B
C
D
E
F
G
H
I
J
L
M

LAN


Case 8

Check driver seat control unit circuit. Refer to [LAN-63, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2212E

//// : Malfunctioning part




PKIB1830E

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-63, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDCTCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2213E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 10

Check IPDM E/R circuit. Refer to [LAN-64, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	✓✓7	
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2214E



Case 11

Check CAN communication circuit. Refer to [LAN-64, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display unit	-	CAN COMM	✓✓1	✓✓3	-	✓✓5	✓✓2	-	✓✓7	
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2215E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-65, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	-	UNKW	UNKW	-	UNKW
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	UNKW	-	-	UNKW
AUTO DRIVE POS.	No indication	NG	UNKW	-	-	UNKW	UNKW	-	-
ABS	-	NG	UNKW	UNKW	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	UNKW	-	-

WKIA2220E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-65, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	-	UNKW	UNKW	-	UNKW
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	UNKW	-	-	UNKW
AUTO DRIVE POS.	No indication	NG	UNKW	-	-	UNKW	UNKW	-	-
ABS	-	NG	UNKW	UNKW	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	UNKW	-	-

WKIA2217E

Circuit Check Between Data Link Connector and Driver Seat Control Unit

UKS0026B

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
- 14 (P) - 19 (Y/G) : Continuity should exist.**

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

UKS0026C

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#).
 NG >> Repair harness.



UKS0026D

ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and data link connector M22.



Display Unit Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-47, "Work Flow"](#).
NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : **Continuity should not exist.**

14 (P) - Ground : **Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-65, "Component Inspection"](#).

NG >> Repair the harness.



UKS0026M

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : **Approx. 108 - 132 Ω**
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : **Approx. 108 - 132 Ω**

UKS0026N



LKIA0037E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


System Description

UKS00260

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0026P




BKIA0087E

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS0026Q



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0270E

CAN SYSTEM (TYPE 3)



[CAN]

Wiring Diagram - CAN -

UKS0026R

LAN-CAN-05

— : DATA LINE








REFER TO THE FOLLOWING.
M82 - ELECTRICAL UNITS

BKWA0271E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-06



REFER TO THE FOLLOWING.
(E125) - ELECTRICAL UNITS

BKWA0273E


CAN SYSTEM (TYPE 3)

[CAN]


UKS0026S

Work Flow


- When there are no indications of "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

BKIA0056E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 3)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table. A
 - 5. Check CAN communication line of the navigation system. B
 - 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet. C
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 - 7. According to the Check Sheet Results, start inspection. D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and driver seat control unit. Refer to [LAN-82, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ MSA	BCM/SEC	VIX/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2271E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-83, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTFR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VIDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2279E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-83, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VIX/TCU/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2283E




PKIB1835E

Case 4

Check display control unit circuit. Refer to [LAN-84, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display control unit	-	CAN COMM	CAN TRC 1	CAN TRC 3	-	CAN TRC 5	CAN TRC 2	-	CAN TRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2291E



PKIB1836E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-84, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No malfunction	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No malfunction	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No malfunction	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2297E




PKIB1837E

Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-85, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	-
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

WKIA2314E



PKIB1838E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-85, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2307E




PKIB1839E

Case 8

Check driver seat control unit circuit. Refer to [LAN-86, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIDZ/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2322E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-86, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2326E



PKIB1841E

CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-87, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIDC/ICSI/ ABS	IPDM E/R	
ENGINE	-	NG	UNKW N	-	-	UNKW N	UNKW N	-	-	UNKW N
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKW N	UNKW N	UNKW N	-	UNKW N	UNKW N	-	UNKW N
BCM	No indication	NG	UNKW N	UNKW N	-	UNKW N	-	-	-	UNKW N
AUTO DRIVE POS.	No indication	NG	UNKW N	-	-	UNKW N	UNKW N	-	-	-
ABS	-	NG	UNKW N	UNKW N	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKW N	UNKW N	-	-	UNKW N	-	-	-

WKIA2333E



Case 11

Check CAN communication circuit. Refer to [LAN-87, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIDC/ICSI/ ABS	IPDM E/R	
ENGINE	-	NG	UNKW N	-	-	UNKW N	UNKW N	-	-	UNKW N
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKW N	UNKW N	UNKW N	-	UNKW N	UNKW N	-	UNKW N
BCM	No indication	NG	UNKW N	UNKW N	-	UNKW N	-	-	-	UNKW N
AUTO DRIVE POS.	No indication	NG	UNKW N	-	-	UNKW N	UNKW N	-	-	-
ABS	-	NG	UNKW N	UNKW N	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKW N	UNKW N	-	-	UNKW N	-	-	-

PKIB2824E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-88, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2346E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-88, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2343E

Circuit Check Between Data Link Connector and Driver Seat Control Unit

UKS0026T

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-70, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-70, "Work Flow"](#).
NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM connector M82 and data link connector M22.



Display Control Unit Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



UKS0026X

Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-70, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-88, "Component Inspection"](#).

NG >> Repair the harness.



UKS00274

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : Approx. 108 - 132 Ω

UKS00275



CAN SYSTEM (TYPE 4)

PFP:23710


System Description

UKS00276

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS00277



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS00278



BKWA0258E

CAN SYSTEM (TYPE 4)


[CAN]

Wiring Diagram - CAN -

UKS00279


LAN-CAN-07

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.
M82 - ELECTRICAL UNITS

BKWA0274E

LAN-CAN-08




REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS


BKWA0276E

Work Flow


- When there are no indications of "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
		ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	

PKIB2825E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 4)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-103, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNT'R						
			ECM	DISPLAY	Receive diagnosis				
					METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2826E



CAN SYSTEM (TYPE 4)

[CAN]


Case 2

Check ECM circuit. Refer to [LAN-104, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	UNKWN	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2827E

//// : Malfunctioning part



PKIB1816E

CAN SYSTEM (TYPE 4)

[CAN]


Case 3

Check display unit circuit. Refer to [LAN-104, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	✓1	✓3	-	✓5	✓2	-	✓7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2828E

//// : Malfunctioning part



PKIB1817E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]


Case 4

Check data link connector circuit. Refer to [LAN-105, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	ECM	DISPLAY	Receive diagnosis			
						METER/M&A	BCM/SFC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No notification	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No notification	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No notification	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2829E

//// : Malfunctioning part



PKIB1818E

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check unified meter and A/C amp. circuit. Refer to [LAN-105, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	UNKWN	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2830E



A
B
C
D
E
F
G
H
I
J
L
M

LAN


Case 6

Check BCM circuit. Refer to [LAN-106, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	✓ CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2831E

//// : Malfunctioning part



PKIB1820E

CAN SYSTEM (TYPE 4)

[CAN]


Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-106, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2832E

//// : Malfunctioning part



PKIB1821E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]


Case 8

Check IPDM E/R circuit. Refer to [LAN-107, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR					
				ECM	DISPLAY	Receive diagnosis			
					METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2833E

//// : Malfunctioning part



PKIB1822E

Case 9

Check CAN communication circuit. Refer to [LAN-107, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR					
				ECM	DISPLAY	Receive diagnosis			
					METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2834E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-108, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

PKIB2835E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-108, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISP LAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

PKIB2836E

Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

JKU002ME

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

6 (L) - 20 (L) : Continuity should exist.

14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-93, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and data link connector M22.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-93, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-108, "Component Inspection"](#).

NG >> Repair the harness.



UKS002MO

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : Approx. 108 - 132 Ω

UKS002MP



CAN SYSTEM (TYPE 5)

PFP:23710


System Description

UKS00270

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0027P



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

UKS0027Q



BKWA0262E

CAN SYSTEM (TYPE 5)


[CAN]

Wiring Diagram - CAN -

UKS0027R


LAN-CAN-09

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.
M82 - ELECTRICAL UNITS

BKWA0277E

LAN-CAN-10




REFER TO THE FOLLOWING.
E125 - ELECTRICAL UNITS


BKWA0279E

Work Flow


- When there are no indications of "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
			ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS			
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2837E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 5)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and driver seat control unit. Refer to [LAN-125, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ MSA	BCM/SEC	VDC/HCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2838E




Case 2

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-126, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2839E




PKIB1824E

Case 3

Check ECM circuit. Refer to [LAN-126, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VIC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	✓ CAN 3	-	CAN 5	CAN 2	-	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2840E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check display unit circuit. Refer to [LAN-127, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TC/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	✓1	✓3	-	✓5	✓2	-	-	✓7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2841E




PKIB1826E

Case 5

Check data link connector circuit. Refer to [LAN-127, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7	
METER A/C AMP	No malfunction	✓	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No malfunction	✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	
AUTO DRIVE POS.	No malfunction	✓	NG	UNKWN	-	-	UNKWN	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No malfunction	✓	-	UNKWN	UNKWN	-	UNKWN	-	-	

PKIB2842E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]


Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-128, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWVN	-	-	UNKWVN	UNKWVN	UNKWVN	UNKWVN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	✓ CAN 5	CAN 2	-	CAN 7
METER/A/C AMP	No indication ✓	-	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
BCM	No indication	NG	UNKWVN	UNKWVN	-	UNKWVN	-	-	UNKWVN
AUTO DRIVE POS.	No indication	NG	UNKWVN	-	-	UNKWVN	UNKWVN	-	-
ABS	-	NG	UNKWVN	UNKWVN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWVN	UNKWVN	-	-	UNKWVN	-	-

PKIB2843E

//// : Malfunctioning part




PKIB1828E

Case 7

Check BCM circuit. Refer to [LAN-128, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIC/TCU/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	✓ CAN 2	-	CAN 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB284E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 8

Check driver seat control unit circuit. Refer to [LAN-129, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TC/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2845E




PKIB1830E

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-129, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VID/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	-	UNKW	UNKW	UNKW	UNKW
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	UNKW	-	-	UNKW
AUTO DRIVE POS.	No indication	NG	UNKW	-	-	UNKW	UNKW	-	-
ABS	-	NG	UNKW	UNKW	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	UNKW	-	-

PKIB2846E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-130, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	✓✓✓	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

PKIB2847E



Case 11

Check CAN communication circuit. Refer to [LAN-130, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	✓✓✓ 1	✓✓✓ 3	-	✓✓✓ 5	✓✓✓ 2	-	✓✓✓ 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

PKIB2848E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-131, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2849E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-131, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTNR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2850E

Circuit Check Between Data Link Connector and Driver Seat Control Unit

UKS002LX

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-113, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-113, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and data link connector M22.



Display Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.

**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-113, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : **Continuity should not exist.**

14 (P) - Ground : **Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-131, "Component Inspection"](#).

NG >> Repair the harness.



IPDM E/R Ignition Relay Circuit Check

UKS002M9

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


UKS002MA

ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : **Approx. 108 - 132 Ω**
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : **Approx. 108 - 132 Ω**



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)


System Description

UKS00288

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS00289




BKIA0087E

CAN SYSTEM (TYPE 6)

[CAN]

Schematic

UKS0028A



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0270E

Wiring Diagram - CAN -


LAN-CAN-11

— : DATA LINE




REFER TO THE FOLLOWING.
 (M82) - ELECTRICAL UNITS

LAN-CAN-12



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
E125 - ELECTRICAL UNITS

BKWA0285E


CAN SYSTEM (TYPE 6)

[CAN]


UKS002LD

Work Flow


- When there are no indications of "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2851E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 6)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the navigation system.
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.


Case 1

Check harness between data link connector and driver seat control unit. Refer to [LAN-148, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receptive diagnosis					
				ECM	DISPLAY	METER/ MSA	BCM/SEC	VIX/TCSI/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2852E

//// : Malfunctioning part




PKIB1833E

Case 2

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-149, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKW	-	-	UNKW	UNKW	UNKW	UNKW
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	UNKW	-	-	UNKW
AUTO DRIVE POS.	No indication	NG	UNKW	-	-	UNKW	UNKW	-	-
ABS	-	NG	UNKW	UNKW	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	UNKW	-	-

PKIB2853E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]


Case 3

Check ECM circuit. Refer to [LAN-149, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2854E

//// : Malfunctioning part




PKIB1835E

Case 4

Check display control unit circuit. Refer to [LAN-150, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN VRC 1	CAN VRC 3	-	CAN VRC 5	CAN VRC 2	-	CAN VRC 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2855E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]


Case 5

Check data link connector circuit. Refer to [LAN-150, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No malfunction	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No malfunction	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No malfunction	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2856E

//// : Malfunctioning part




PKIB1837E

Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-151, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	-
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2857E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-151, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIX/TCU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2858E



PKIB1839E

CAN SYSTEM (TYPE 6)


[CAN]

Case 8

Check driver seat control unit circuit. Refer to [LAN-152, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VIDZ/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	

PKIB2859E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-152, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2860E




PKIB1841E

Case 10

Check IPDM E/R circuit. Refer to [LAN-153, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2861E



Case 11

Check CAN communication circuit. Refer to [LAN-153, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	UNKWN
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

PKIB2862E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-154, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2863E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-154, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB2864E

Circuit Check Between Data Link Connector and Driver Seat Control Unit

UKS002LG

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
- 14 (P) - 19 (Y/G) : Continuity should exist.**

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-136, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-136, "Work Flow"](#).
NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM connector M82 and data link connector M22.



Display Control Unit Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-136, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-154, "Component Inspection"](#).

NG >> Repair the harness.



UKS002LS

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection


ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : Approx. 108 - 132 Ω

UKS002LT



LKIA0037E

CAN SYSTEM (TYPE 7)

PFP:23710


System Description

UKS0028S

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0028T



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 7)

[CAN]

Schematic

UKS0028U




BKWA0286E

Wiring Diagram - CAN -




UKS0028V

LAN-CAN-13

— : DATA LINE





A
B
C
D
E
F
G
H
I
J
LAN
L
M





BKWA0287E

LAN-CAN-14



BKWA0288E

LAN-CAN-15



REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS

BKWA0289E


CAN SYSTEM (TYPE 7)

[CAN]


UKS002KY

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
			ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

BKIA0062E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 7)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#).
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-173, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/MKA	BCM/SEC	VDC/TCS/AHS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2903E




Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-173](#), "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/MMA	BCM/SEC	VDD/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	UNKWN
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2542E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 3

Check ECM circuit. Refer to [LAN-174, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISP LAY	METER/MKA	BCM/SEC	VDGTCS/AHS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2865E



PKIB1845E

CAN SYSTEM (TYPE 7)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-174, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/MKA	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN ✓	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2544E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]


Case 5

Check display unit circuit. Refer to [LAN-175, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISP LAY	METER/ M/A	BCM/SEC	VDGTCS/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	✓1	✓3	-	-	✓5	✓2	-	✓7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	✓4	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2545E

//// : Malfunctioning part



PKIB1847E

CAN SYSTEM (TYPE 7)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-175, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDT/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No malfunction ✓	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No malfunction ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2546E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-176, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS/ABS	IPDM E/R
				ECM	TCM	DISPLAY	METER/MKA	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	5	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2548E



PKIB1849E

CAN SYSTEM (TYPE 7)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-176, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDDTCS/ABS	IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 7	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2547E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)


[CAN]

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-177, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M/A	BCM/SEC	VDC/TC/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	✓	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2549E



PKIB1851E

CAN SYSTEM (TYPE 7)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-177, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	UNKWN
METER/ A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2550E



Case 11

Check CAN communication circuit. Refer to [LAN-178, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display unit	-	CAN COMM	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
METER/ A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2866E

CAN SYSTEM (TYPE 7)

[CAN]

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-178, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TER/MKA	BCM/SEC	VDC/TCR/AHS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
ME-TER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2553E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-178, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TER/MKA	BCM/SEC	VDC/TCR/AHS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
ME-TER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2552E

Circuit Check Between TCM and Data Link Connector

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-160, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 6 (L) - 20 (L) : Continuity should exist.**
14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-160, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.

**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.



Display Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.

**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-160, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-179, "Component Inspection"](#) .
 NG >> Repair the harness.




IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 8)

PFP:23710


System Description

UKS0029D

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0029E




CAN SYSTEM (TYPE 8)

[CAN]

Schematic

UKS0029F



A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0290E

Wiring Diagram - CAN -

UKS0029G

LAN-CAN-16

— : DATA LINE





BKWA0291E

CAN SYSTEM (TYPE 8)



[CAN]

LAN-CAN-17



BKWA0292E

LAN-CAN-18



REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS

BKWA0293E


CAN SYSTEM (TYPE 8)

[CAN]


UKS002KH

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
			ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	NG	UNKWVN	-	UNKWVN	-	UNKWVN	UNKWVN	-	UNKWVN
TRANSMISSION	No indication	NG	UNKWVN	UNKWVN	-	UNKWVN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication		UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
BCM	No indication	NG	UNKWVN	UNKWVN	-	UNKWVN	-	-	UNKWVN
AUTO DRIVE POS.	No indication	NG	UNKWVN	-	UNKWVN	-	UNKWVN	-	-
ABS		NG	UNKWVN	UNKWVN	-	-	-	-	-
IPDM E/R	No indication		UNKWVN	UNKWVN	-	-	UNKWVN	-	-

BKIA0063E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 8)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-200, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
				ECM	TCM	DISPLAY	M/THR M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	✓	✓	✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	✓	-	-
Display unit		CAN COMM	CAN 1	✓	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication		UNKWN	UNKWN	✓	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	✓	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	✓	-	-	UNKWN	-	-

WKIA2150E



CAN SYSTEM (TYPE 8)


[CAN]

Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-200, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-T/R/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2151E



PKIB1855E

CAN SYSTEM (TYPE 8)


[CAN]

Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-201, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MINER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2152E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check ECM circuit. Refer to [LAN-201, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	✓	✓	UNKWN	UNKWN	✓	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	✓	-	UNKWN	UNKWN	-	-
Display unit		CAN COMM	CAN 1	✓	✓	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	✓	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2154E




Case 5

Check TCM circuit. Refer to [LAN-202, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-IF-R/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER/A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2155E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 6

Check display unit circuit. Refer to [LAN-202, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	-	-
Display unit		CAN COMM	✓1	✓3	-	✓5	✓2	-	-	✓7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	✓4	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2156E




PKIB1859E

Case 7

Check data link connector circuit. Refer to [LAN-203, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	Not operation ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER/A/C AMP	Not operation ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	Not operation ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	Not operation ✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	Not operation ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2157E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 8)


[CAN]

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-203, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	UNKWN	CAN 2	-	CAN 7
METER A/C AMP	No indication ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2160E




Case 9

Check BCM circuit. Refer to [LAN-204, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	ME-IF-R/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	CAN 7	
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	

PKIB2867E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 10

Check driver seat control unit circuit. Refer to [LAN-204, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE		NG	UNKWN		UNKWN		UNKWN	UNKWN		UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN			-
Display unit		CAN COMM	CAN 1	CAN 3			CAN 5	CAN 2		CAN 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN			UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-			
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN		

WKIA2161E



PKIB1863E

CAN SYSTEM (TYPE 8)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-205, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2162E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 12

Check IPDM E/R circuit. Refer to [LAN-205, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/TCU/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	UNKWN
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2163E



Case 13

Check CAN communication circuit. Refer to [LAN-206, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/TCU/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display unit		CAN COMM	UNKWN 1	UNKWN 3	-	-	UNKWN 5	UNKWN 2	-	UNKWN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2164E

CAN SYSTEM (TYPE 8)

[CAN]

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-206, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2166E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-206, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2166E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between TCM and Data Link Connector

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-185, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and Driver Seat Control Unit

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-185, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-185, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-185, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-207, "Component Inspection"](#).

NG >> Repair the harness.




IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 9)


System Description

UKS0029Y

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS0029Z




CAN SYSTEM (TYPE 9)

[CAN]

Schematic

UKS002A0



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0294E

Wiring Diagram - CAN -

LAN-CAN-19


— : DATA LINE




CAN SYSTEM (TYPE 9)

[CAN]

LAN-CAN-20




A
B
C
D
E
F
G
H
I
J
LAN
L
M




BKWA0296E

LAN-CAN-21



PRECEDING PAGE




REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS


BKWA0297E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR							
			ECM	TCM	DISPLAY	Receive diagnosis		VDC/TCS/ABS	IPDM E/R	
					MI-TH/M&A	BCM/SEC	CAN CIRC 5			CAN CIRC 2
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2868E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 9)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.

5. Check CAN communication line of the navigation system.
6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-226, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2869E



CAN SYSTEM (TYPE 9)

[CAN]


Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-226, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MONTR							
			ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VIDEO/CSI/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2870E

//// : Malfunctioning part



PKIB1867E

CAN SYSTEM (TYPE 9)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-227, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	ME-TR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2871E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check TCM circuit. Refer to [LAN-227, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MONITOR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2872E




PKIB1869E

Case 5

Check display control unit circuit. Refer to [LAN-228, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	MFTR/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display control unit		CAN COMM	CAN/RRC 1 ✓	CAN/RRC 3 ✓	-	-	CAN/RRC 5 ✓	CAN/RRC 2 ✓	-	CAN/RRC 7 ✓
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN ✓	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2873E



A
B
C
D
E
F
G
H
I
J

LAN

CAN SYSTEM (TYPE 9)

[CAN]


Case 6

Check data link connector circuit. Refer to [LAN-228, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MONITOR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
							ME-T/H/ M&A	BCM/SEC	VIDO/CSI/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	Notification ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	Notification ✓	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	Notification ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	Notification ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2874E

//// : Malfunctioning part



PKIB1871E

CAN SYSTEM (TYPE 9)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-229, "Unified Meter and A/C Amp. Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2875E



CAN SYSTEM (TYPE 9)

[CAN]


Case 8

Check BCM circuit. Refer to [LAN-229, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTFR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
							ME-THR/M&A	BCM/SEC	VDC/TCI/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2876E

//// : Malfunctioning part



PKIB1873E

CAN SYSTEM (TYPE 9)


[CAN]

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-230, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TR/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2877E



CAN SYSTEM (TYPE 9)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-230, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2878E



Case 11

Check CAN communication circuit. Refer to [LAN-231, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TC/ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2879E

CAN SYSTEM (TYPE 9)

[CAN]

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-231, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
				TCM	DISPLAY	ME-TH-R/ M&A	BCM/SEC	VDC/CS/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	

PKIB280E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-231, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
				TCM	DISPLAY	ME-TH-R/ M&A	BCM/SEC	VDC/CS/ ABS		
ENGINE	-	NG	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	

PKIB281E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-213, "Work Flow"](#).
 NG >> Repair harness.



SKIB1815E

Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 6 (L) - 20 (L) : Continuity should exist.**
14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-213, "Work Flow"](#).
 NG >> Repair harness.



SKIB1809E

ECM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.

**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.



Display Control Unit Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-213, "Work Flow"](#).
NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.

**3. CHECK HARNESS FOR SHORT TO GROUND**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-232. "Component Inspection"](#).
 NG >> Repair the harness.


**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25. "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12. "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



CAN SYSTEM (TYPE 10)

PFP:23710


System Description

UKS002AG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS002AH



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 10)

[CAN]

Schematic

UKS002AI



BKWA0298E

CAN SYSTEM (TYPE 10)


[CAN]

Wiring Diagram - CAN -


UKS002AJ

LAN-CAN-22

— : DATA LINE





A
B
C
D
E
F
G
H
I
J
LAN
L
M





BKWA0299E

LAN-CAN-23



BKWA0300E

LAN-CAN-24




REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS


BKWA0301E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis	ME1/R/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

BKIA0064E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 10)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the navigation system.
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-253, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			
				ECM	TCM	DISPLAY	METER M&A	BCM/SEC	VDC/TCU/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2189E




Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-253, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MINER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
ABS	No indication	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2190E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-254](#), "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/CS/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2192E




PKIB1878E

Case 4

Check ECM circuit. Refer to [LAN-254, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	UNKWN	CAN CIRC 5	CAN CIRC 2	UNKWN	CAN CIRC 7	
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
ABS		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
IPDM E/R	No indication		UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	

WKIA2193E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check TCM circuit. Refer to [LAN-255, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2195E




PKIB1880E

Case 6

Check display control unit circuit. Refer to [LAN-255, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	ME/FR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit		CAN COMM	CAN RRC 1	CAN RRC 3	UNKWN	CAN RRC 5	CAN RRC 2	UNKWN	CAN RRC 7	
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
ABS		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
IPDM E/R	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	

WKIA2196E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 7

Check data link connector circuit. Refer to [LAN-256, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CSI/ABS	IPDM E/R
ENGINE	✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	Not operation	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit	✓	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	Not operation	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	Not operation	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	Not operation	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	✓	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	Not operation	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2197E



PKIB1882E

CAN SYSTEM (TYPE 10)


[CAN]

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-256, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication ✓	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB282E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check BCM circuit. Refer to [LAN-257, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	✓	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	✓	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	✓	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	✓	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	✓	-	-

WKIA2198E




PKIB1884E

Case 10

Check driver seat control unit circuit. Refer to [LAN-257, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-IF-R/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2201E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 10)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-258, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2202E




PKIB1886E

Case 12

Check IPDM E/R circuit. Refer to [LAN-258, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2204E



Case 13

Check CAN communication circuit. Refer to [LAN-259, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2205E

CAN SYSTEM (TYPE 10)

[CAN]

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-259, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VID/ICSI/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2208E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-259, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VID/ICSI/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2206E

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-238, "Work Flow"](#).
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and Driver Seat Control Unit****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-238, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-238, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-238, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



UKS002JV

IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



WKIA0956E

CAN Communication Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.



SKIA6868E

3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-260, "Component Inspection"](#).

NG >> Repair the harness.



PKIA2079E


IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



CAN SYSTEM (TYPE 11)

PFP:23710


System Description

UKS002B0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS002B1



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 11)

[CAN]

Schematic

UKS002B2



BKWA0302E

CAN SYSTEM (TYPE 11)


[CAN]

Wiring Diagram - CAN -


UKS002B3

LAN-CAN-25

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M





BKWA0303E

CAN SYSTEM (TYPE 11)


[CAN]

LAN-CAN-26




BKWA0304E

LAN-CAN-27



A
B
C
D
E
F
G
H
I
J
LAN
L
M




REFER TO THE FOLLOWING.
E125 - ELECTRICAL UNITS


BKWA0305E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
			ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS		
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

BKIA0067E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 11)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#).
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-279, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/MKA	BCM/SEC	VDC/TCS/AHS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	✓	✓	✓	CAN 5	CAN 2	✓	CAN 7	✓
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2308E




Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-279](#), "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDDTCS/ABS	IPDM E/R
				ECM	TCM	DISPLAY	METER/MMA	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	UNKWN	
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2309E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 3

Check ECM circuit. Refer to [LAN-280, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	TCM	DISP LAY	METER/MKA	BCM/SEC	VDGTCS/AHS		
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7	-
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2310E




PKIB1845E

Case 4

Check TCM circuit. Refer to [LAN-280, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN ✓	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN ✓	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2311E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check display unit circuit. Refer to [LAN-281, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISP LAY	METER/ M/A	BCM/SEC	VDGTCS/ AHS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	✓1	✓3	-	-	✓5	✓2	-	✓7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	✓4	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2312E



PKIB1847E

CAN SYSTEM (TYPE 11)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-281, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	Not location	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7	-
METER A/C AMP	Not location	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	-
BCM	Not location	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	-
IPDM E/R	Not location	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2313E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-282, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	TCM	DISP LAY	METER/ MKA	BCM/SEC	VDGTCS/ AHS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	UNKWN	CAN 2	-	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2316E



PKIB1849E

CAN SYSTEM (TYPE 11)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-282, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDDTCS/ ABS	IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	UNKN		
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	CAN 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2315E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-283, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M/A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2317E



CAN SYSTEM (TYPE 11)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-283, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	UNKWN
METER/ A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2318E



Case 11

Check CAN communication circuit. Refer to [LAN-284, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/ MKA	BCM/SEC	VDC/CS/ ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	UNKWN
METER/ A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2319E

CAN SYSTEM (TYPE 11)

[CAN]

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-284, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TER/MKA	BCM/SEC	VDC/CS/AHS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	CAN 7
ME-TER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2321E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-284, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TER/MKA	BCM/SEC	VDC/CS/AHS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	CAN 7
ME-TER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2320E

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

3 (L) - 6 (L) : Continuity should exist.

4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-266, "Work Flow"](#).
 NG >> Repair harness.



SKIB1815E

Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

6 (L) - 20 (L) : Continuity should exist.

14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-266, "Work Flow"](#).
 NG >> Repair harness.



SKIB1809E

ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
- NG >> Repair harness between TCM connector F56 and ECM connector M82.



Display Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.

**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-266, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.

**3. CHECK HARNESS FOR SHORT TO GROUND**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-285, "Component Inspection"](#) .
 NG >> Repair the harness.


**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 12)

PFP:23710


System Description

UKS002BK

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS002BL




CAN SYSTEM (TYPE 12)

[CAN]

Schematic

UKS002BM





A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0290E

Wiring Diagram - CAN -

LAN-CAN-28



— : DATA LINE



CAN SYSTEM (TYPE 12)



[CAN]

LAN-CAN-29



BKWA0307E

LAN-CAN-30



REFER TO THE FOLLOWING.
 (E125) - ELECTRICAL UNITS

BKWA0308E


CAN SYSTEM (TYPE 12)

[CAN]


UKS002IN

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R	
	ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/TCS/ABS	CAN				
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3			CAN 5	CAN 7			CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN				UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-				
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN			

BKIA0068E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 12)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#) .
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-306, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
				ECM	TCM	DISPLAY	M/THR M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	✓	✓	✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	✓	UNKWN	UNKWN
Display unit		CAN COMM	CAN 1	✓	-	-	CAN 5	CAN 2	UNKWN	CAN 7
METER A/C AMP	No indication		UNKWN	UNKWN	✓	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	✓	UNKWN	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	✓	-	-	UNKWN	-	-

WKIA2340E




Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-306, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VID/ICS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication ✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication ✓	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2341E




Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-307, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MINER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	UNKWN
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2342E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check ECM circuit. Refer to [LAN-307, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	✓	✓	-	UNKWN	✓	✓	✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display unit		CAN COMM	CAN 1	✓	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication		UNKWN	✓	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2344E




PKIB1857E

Case 5

Check TCM circuit. Refer to [LAN-308, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-IF-R/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2345E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 6

Check display unit circuit. Refer to [LAN-308, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN		UNKWN		UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN				UNKWN		UNKWN	
Display unit		CAN COMM	✓1	✓13			✓5	✓2		✓7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	✓		UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN		UNKWN		UNKWN	UNKWN		
ABS		NG	UNKWN	UNKWN	UNKWN					
IPDM E/R	No indication		UNKWN	UNKWN				UNKWN		

WKIA2347E




PKIB1859E

Case 7

Check data link connector circuit. Refer to [LAN-309, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER/A/C AMP	No malfunction ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No malfunction ✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No malfunction ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2348E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-309, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	UNKWN	CAN 2	UNKWN	CAN 7
METER A/C AMP	No indication ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2350E




PKIB1861E

Case 9

Check BCM circuit. Refer to [LAN-310, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	ME-IF-R/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R	
ENGINE		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	UNKWN	CAN 7	-
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	UNKWN	-	-	-

WKIA2349E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 10

Check driver seat control unit circuit. Refer to [LAN-310, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN		UNKWN		UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN		UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3			CAN 5	CAN 2		CAN 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN			UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-			
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN		

WKIA2351E




PKIB1863E

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-311, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MINER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2352E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 12

Check IPDM E/R circuit. Refer to [LAN-311, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/TCM/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	UNKWN	UNKWN
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2353E



Case 13

Check CAN communication circuit. Refer to [LAN-312, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/TCM/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display unit		CAN COMM	UNKWN 1	UNKWN 3	-	-	UNKWN 5	UNKWN 2	UNKWN	UNKWN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

PKIB2883E

CAN SYSTEM (TYPE 12)

[CAN]

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-312, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2356E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-312, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display unit		CAN COMM	CAN 1	CAN 3	-	-	CAN 5	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2884E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between TCM and Data Link Connector

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-291, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and Driver Seat Control Unit

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-291, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-291, "Work Flow"](#).
NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-291, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-313, "Component Inspection"](#).

NG >> Repair the harness.




IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 13)

PFP:23710


System Description

UKS002C5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS002C6




CAN SYSTEM (TYPE 13)

[CAN]

Schematic

UKS002C7



A
B
C
D
E
F
G
H
I
J
L
M



LAN

BKWA0624E

Wiring Diagram - CAN -

LAN-CAN-31


▬ : DATA LINE




CAN SYSTEM (TYPE 13)

[CAN]



LAN-CAN-32



A
B
C
D
E
F
G
H
I
J
LAN
L
M




BKWA0313E




Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR							
			ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4267E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 13)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the navigation system.
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-332, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4268E



CAN SYSTEM (TYPE 13)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-332](#), "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4269E




PKIB1867E

Case 3

Check ECM circuit. Refer to [LAN-333, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTH								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4270E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 4

Check TCM circuit. Refer to [LAN-333, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'H								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4271E




PKIB1869E

Case 5

Check display control unit circuit. Refer to [LAN-334, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTH								
			ECM					Receive diagnosis			IPDM E/R
			TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS				
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	
Display control unit	-	CAN COMM	CAN/R/C 1	CAN/R/C 3	-	-	CAN/R/C 5	CAN/R/C 2	-	CAN/R/C 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA4272E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 13)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-334, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'H								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication ✓	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4274E



PKIB1871E

CAN SYSTEM (TYPE 13)


[CAN]

Case 7

Check unified meter and A/C amp. circuit. Refer to [LAN-335, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTH								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4275E



PKIB1872E

A
B
C
D
E
F
G
H
I
J


LAN

Case 8

Check BCM circuit. Refer to [LAN-335, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'H								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKW N	-	UNKW N	-	UNKW N	✓	UNKW N	UNKW N
TRANSMISSION	No indication	NG	UNKW N	UNKW N	-	-	UNKW N	-	UNKW N	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKW N	UNKW N	UNKW N	UNKW N	-	✓	UNKW N	UNKW N
BCM	No indication	NG	UNKW N	UNKW N	-	-	UNKW N	-	-	UNKW N
ABS	-	NG	UNKW N	UNKW N	UNKW N	-	-	-	-	-
IPDM E/R	No indication	-	UNKW N	UNKW N	-	-	-	✓	-	-

WKIA4276E




Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-336, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4277E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 13)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-336, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR							
				ECM	TCM	DISPLAY	Receive diagnosis			IPDM E/R	
				METER/ M&A	BCM/SEC	VDC/TCS/ ABS					
ENGINE	-	NG	UNKW	-	UNKW	-	UNKW	UNKW	UNKW	UNKW	UNKW
TRANSMISSION	No indication	NG	UNKW	UNKW	-	-	UNKW	-	UNKW	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	UNKW
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	-	UNKW	-	-	-	UNKW
ABS	-	NG	UNKW	UNKW	UNKW	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	-	UNKW	-	-	-

WKIA4278E



Case 11

Check CAN communication circuit. Refer to [LAN-337, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR							
				ECM	TCM	DISPLAY	Receive diagnosis			IPDM E/R	
				METER/ M&A	BCM/SEC	VDC/TCS/ ABS					
ENGINE	-	NG	UNKW	-	UNKW	-	UNKW	UNKW	UNKW	UNKW	UNKW
TRANSMISSION	No indication	NG	UNKW	UNKW	-	-	UNKW	-	UNKW	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7	UNKW
METER A/C AMP	No indication	-	UNKW	UNKW	UNKW	UNKW	-	UNKW	UNKW	UNKW	UNKW
BCM	No indication	NG	UNKW	UNKW	-	-	UNKW	-	-	-	UNKW
ABS	-	NG	UNKW	UNKW	UNKW	-	-	-	-	-	-
IPDM E/R	No indication	-	UNKW	UNKW	-	-	-	UNKW	-	-	-

WKIA4279E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-337, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4280E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-337, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VDC/TCS/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA4281E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-319, "Work Flow"](#).
 NG >> Repair harness.



SKIB1815E

Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 6 (L) - 20 (L) : Continuity should exist.**
14 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-319, "Work Flow"](#).
 NG >> Repair harness.



SKIB1809E

ECM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.

**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.



Display Control Unit Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-319, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



UKS002II

IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair the harness.

**3. CHECK HARNESS FOR SHORT TO GROUND**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-338, "Component Inspection"](#) .
 NG >> Repair the harness.


**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



CAN SYSTEM (TYPE 14)

PF:23710


System Description

EKS00FRX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00FRY



BKIA0092E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 14)

[CAN]

Schematic

EKS00FRZ



BKWA0298E

CAN SYSTEM (TYPE 14)


[CAN]

Wiring Diagram - CAN -


EKS00FS0

LAN-CAN-34

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M





BKWA0626E

CAN SYSTEM (TYPE 14)

[CAN]

LAN-CAN-35




BKWA0627E


CAN SYSTEM (TYPE 14)

[CAN]

LAN-CAN-36




A
B
C
D
E
F
G
H
I
J
LAN
L
M




BKWA0628E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis	METER/M&A	BCM/SEC	VDC/TCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	CAN CIRC 2	-	-	CAN CIRC 7
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

BKIA0069E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 14)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the navigation system.
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-359, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	ECM			Receive diagnosis			IPDM E/R
				ECM	TCM	DISPLAY	METER M&A	BCM/SEC	VID/TCU/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2371E




Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-359, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MINER								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	ME-TRU M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	✓	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication ✓		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2372E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-360, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2373E




Case 4

Check ECM circuit. Refer to [LAN-360, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis ME/FR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3			CAN CIRC 5	CAN CIRC 2		CAN CIRC 7
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN			UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN		
ABS		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN			
IPDM E/R	No indication		UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN		

WKIA2374E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check TCM circuit. Refer to [LAN-361, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE		NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2375E




PKIB1880E

Case 6

Check display control unit circuit. Refer to [LAN-361, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	ME/FR/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
Display control unit		CAN COMM	CAN R/C 1	CAN R/C 3	UNKWN	CAN R/C 5	CAN R/C 2	UNKWN	CAN R/C 7	
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
ABS		NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
IPDM E/R	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	

WKIA2376E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 14)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-362, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No malfunction ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No malfunction ✓	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No malfunction ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2377E



PKIB1882E

CAN SYSTEM (TYPE 14)


[CAN]

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-362, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication ✓	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2379E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check BCM circuit. Refer to [LAN-363, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	✓	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	✓	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	✓	UNKWN	UNKWN	UNKWN	UNKWN	-	✓	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	✓	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	✓	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	✓	-	-

WKIA2378E




PKIB1884E

Case 10

Check driver seat control unit circuit. Refer to [LAN-363, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	ME-IF-R/M&A	BCM/SEC	VDC/CS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	CAN CIRC 7	
METER/A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	
IPDM E/R	No indication		UNKWN	UNKWN	-	-	UNKWN	-	-	

WKIA2380E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-364, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/ M&A	BCM/SEC	VID/ICSI/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2381E




PKIB1886E

Case 12

Check IPDM E/R circuit. Refer to [LAN-364, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2382E



Case 13

Check CAN communication circuit. Refer to [LAN-365, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	Receive diagnosis METER/ M&A	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2383E

CAN SYSTEM (TYPE 14)

[CAN]

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-365, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VID/ICSI/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2385E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-365, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	DISPLAY	METER/M&A	BCM/SEC	VID/ICSI/ABS	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit		CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS		NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2384E

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-344, "Work Flow"](#).
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and Driver Seat Control Unit****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-344, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

EKS00FS4

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 20 (L), 23 (P).

- 3 (BR) - 20 (L) : Continuity should exist.**
19 (Y/G) - 23 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-344, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check

EKS00FS5

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-344, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.

**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

20 (L) - 23 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.



CAN Communication Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display control unit
 - Unified meter and A/C amp.
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.

**3. CHECK HARNESS FOR SHORT TO GROUND**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-366, "Component Inspection"](#).

NG >> Repair the harness.


**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection**ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



CAN SYSTEM (TYPE 15)

PFP:23710


System Description

EKS00FRC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00FRD



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 15)

[CAN]

Schematic

EKS00FRE



BKWA0640E

CAN SYSTEM (TYPE 15)


[CAN]

Wiring Diagram - CAN -


EKS00FRF

LAN-CAN-37



— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0629E







BKWA0630E

CAN SYSTEM (TYPE 15)

[CAN]

LAN-CAN-39


— : DATA LINE




BKWA0631E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/TCS/ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	-	CAN 2	-	CAN 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

BKIA0065E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 15)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the integrated display system. Refer to [AV-90, "AV Communication Line Check"](#).
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.
NOTE:
If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 7. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-388, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	DISPLAY	METER/ MSA	STRG	BCM/SEC	VDC/CS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	
Display unit	-	CAN COMM	CAN 1	OK ✓	-	CAN 5	-	CAN 2	-	CAN 7	
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	-	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-	
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2232E



CAN SYSTEM (TYPE 15)


[CAN]

Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-388, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	-	CAN 2	-	UNKWN	UNKWN
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2233E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 15)


[CAN]

Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-389, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/IGSI/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN		UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-		CAN 5		CAN 2	UNKWN	UNKWN
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN			UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN		UNKWN		UNKWN		UNKWN		
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN			
IPDM E/R	No indication	NG	UNKWN	UNKWN					UNKWN		

WKIA2234E




PKIB1890E

Case 4

Check ECM circuit. Refer to [LAN-389, "ECM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICSI/ABS	IPDM E/R
ENGINE	-	NG	✓	✓	✓	✓	✓	✓	✓	✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	✓	UNKWN	✓
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	-	CAN 2	-	CAN 7
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2235E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 5

Check TCM circuit. Refer to [LAN-390, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/CS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	-	CAN 2	-	CAN 7	-
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

PKIB2885E




PKIB1892E

Case 6

Check display unit circuit. Refer to [LAN-390, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICSI/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN	
Display unit	-	CAN COMM	OK ¹	OK ³			OK ⁵		OK ²		OK ⁷
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN				UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN		UNKWN		UNKWN		UNKWN		
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN			
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2237E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 7

Check data link connector circuit. Refer to [LAN-391, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	ME-ER/ M&A	STRG	BCM/SEC	VDC/ESC/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	-	CAN 2	-	CAN 7
METER A/C AMP*	No malfunction ✓	-	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No malfunction ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No malfunction ✓	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No malfunction ✓	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2238E




PKIB1894E

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-391, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICSI/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	UNKWN	CAN 2	-	CAN 7	UNKWN
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2240E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 9

Check steering angle sensor circuit. Refer to [LAN-392, "Steering Angle Sensor Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/LCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	-	CAN 2	-	CAN 7
METER A/C AMP*	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2241E




PKIB1896E

Case 10

Check BCM circuit. Refer to [LAN-392, "BCM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 5	-	SW 2	-	CAN 7
METER/A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2239E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 11

Check driver seat control unit circuit. Refer to [LAN-393, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ESC/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN		UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-		CAN 5		CAN 2	-	CAN 7
METER/A/C AMP	No indication		UNKWN	UNKWN	UNKWN		UNKWN			UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN		UNKWN		UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN			
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2242E



PKIB1898E

CAN SYSTEM (TYPE 15)


[CAN]

Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-393, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-		CAN 5		CAN 2	-	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN		UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN		UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN			
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

PKIB2886E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 13

Check IPDM E/R circuit. Refer to [LAN-394, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/ECU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	CAN 5	-	CAN 2	-	OK 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No indication	NG	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2244E



Case 14

Check CAN communication circuit. Refer to [LAN-394, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/ECU/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	OK 1	OK 3	-	CAN 5	-	OK 2	-	OK 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No indication	NG	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2245E

CAN SYSTEM (TYPE 15)

[CAN]

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-395, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		✓		UNKWN		UNKWN	✓	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN			UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-		CAN 5		CAN 2	-	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	✓	UNKWN	UNKWN		UNKWN	✓	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	✓		UNKWN		UNKWN		
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN			
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2247E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-395, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	✓			✓			UNKWN	
Display unit	-	CAN COMM	CAN 1	CAN 3	-		CAN 5		CAN 2	-	CAN 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN		UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN		UNKWN		UNKWN		
ABS	-	NG	UNKWN	✓	UNKWN			✓			
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2246E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-372, "Work Flow"](#).
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and Driver Seat Control Unit****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-372, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

EKS00FRJ

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 7 (L), 9 (P).

- 3 (BR) - 7 (L) : Continuity should exist.**
19 (Y/G) - 9 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-372, "Work Flow"](#).
NG >> Repair harness.



EKS00FRK

ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

14 (L) - 16 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display unit.
 NG >> Repair harness between display unit connector M93 and data link connector M22.



Data Link Connector Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-372, "Work Flow"](#) .
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**Unified Meter and A/C Amp. Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Steering Angle Sensor Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect steering angle sensor connector M47.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between steering angle sensor connector M47 terminal 4 (L) and terminal 5 (P).

4 (L) - 5 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor connector M47 and data link connector M22.



EKS00FRP

BCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 7 (L) and terminal 9 (P).

7 (L) - 9 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display unit
 - Unified meter and A/C amp.
 - Steering angle sensor
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-395, "Component Inspection"](#)
NG >> Repair the harness.



IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection

ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 - 86 : Approx. 108 - 132 Ω
- Check resistance between IPDM E/R terminals 48 and 49.
48 - 49 : Approx. 108 - 132 Ω



CAN SYSTEM (TYPE 16)


System Description

EKS00FQP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00FQQ




CAN SYSTEM (TYPE 16)

[CAN]

Schematic

EKS00FQR



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN



BKWA0327E

Wiring Diagram - CAN -

EKS00FQS

LAN-CAN-40

— : DATA LINE





BKWA0632E

CAN SYSTEM (TYPE 16)



[CAN]

LAN-CAN-41



BKWA0633E


LAN-CAN-42




BKWA0634E

Work Flow


- When there are no indications of "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "METER A/C AMP", "BCM", "AUTO DRIVE POS.", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICSI/ABS	IPDM E/R
ENGINE	-	NG	UNKWVN	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
TRANSMISSION	No indication	NG	UNKWVN	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
BCM	No indication	NG	UNKWVN	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN
AUTO DRIVE POS.	No indication	NG	UNKWVN	-	UNKWVN	-	UNKWVN	UNKWVN	-	-
ABS	-	NG	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	-	-	-
IPDM E/R	No indication	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN	UNKWVN

BKIA0066E

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

CAN SYSTEM (TYPE 16)

[CAN]

-
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
5. Check CAN communication line of the navigation system.
 6. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

7. According to the Check Sheet Results, start inspection.

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-417, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNT'R										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VID/HCS/ ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7	
METER A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	-	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2275E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 2

Check harness between data link connector and driver seat control unit. Refer to [LAN-417, "Circuit Check Between Data Link Connector and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDG/CS/ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN

WKIA2276E




PKIB1902E

Case 3

Check harness between driver seat control unit and ABS actuator and electric unit (control unit). Refer to [LAN-418, "Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNT R									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN

WKIA2277E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 16)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-418, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/ESC/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	✓	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP*	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2278E



PKIB1904E

CAN SYSTEM (TYPE 16)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-419, "TCM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/ICS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-

WKIA2280E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 6

Check display control unit circuit. Refer to [LAN-419, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ESC/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN/RRC 1	CAN/RRC 3	-	-	CAN/RRC 5	-	CAN/RRC 2	-	CAN/RRC 7
METER A/C AMP*	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2281E




PKIB1906E

Case 7

Check data link connector circuit. Refer to [LAN-420, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
TRANSMISSION	No illumination ✓	NG	UNKWN	UNKWN	-	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No illumination ✓	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	-	-
BCM	No illumination ✓	NG	UNKWN	UNKWN	-	-	-	-	-	-
AUTO DRIVE POS	No illumination ✓	NG	UNKWN	-	UNKWN	-	-	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-
IPDM E/R	No illumination ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2282E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 16)


[CAN]

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-420, "Unified Meter and A/C Amp. Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/LCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN		-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP*	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN		-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN		-	-	-	UNKWN	-	-

WKIA2285E




PKIB1908E

Case 9

Check steering angle sensor circuit. Refer to [LAN-421, "Steering Angle Sensor Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICSI/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2286E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 10

Check BCM circuit. Refer to [LAN-421, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT METER									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/ M&A	STRG	BCM/SEC	VDC/LCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP*	No indication	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2284E




Case 11

Check driver seat control unit circuit. Refer to [LAN-422, "Driver Seat Control Unit Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT METER										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER/A/C AMP	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2287E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-422, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MONTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
ENGINE	-	NG	UNKWN	ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/CS/ABS	IPDM E/R
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-

WKIA2288E




Case 13

Check IPDM E/R circuit. Refer to [LAN-423, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN		UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN			UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2289E



Case 14

Check CAN communication circuit. Refer to [LAN-423, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/HCS/ABS	IPDM E/R
ENGINE	-	NG	✓		✓		✓		✓	✓	✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN		UNKWN	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 7
METER A/C AMP	No indication		UNKWN	UNKWN	UNKWN	UNKWN			UNKWN	UNKWN	UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN				UNKWN
AUTO DRIVE POS	No indication	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	-
ABS	-	NG	✓	✓	✓	-	-	✓	-	-	-
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN		

WKIA2290E

CAN SYSTEM (TYPE 16)

[CAN]

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-424, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICS/ABS	IPDM E/R		
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN		UNKWN		UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN		UNKWN		UNKWN		UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3			CAN CIRC 5		CAN CIRC 2				CAN CIRC 7
METER A/C AMP*	No indication	NG	UNKWN	UNKWN	UNKWN		UNKWN		UNKWN		UNKWN		UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN						UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN		UNKWN		UNKWN		UNKWN				
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN					
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN				

WKIA2293E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-424, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DISPLAY	METER/M&A	STRG	BCM/SEC	VDC/ICS/ABS	IPDM E/R		
ENGINE	-	NG	UNKWN		UNKWN		UNKWN		UNKWN		UNKWN		UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN			UNKWN		UNKWN		UNKWN		UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3			CAN CIRC 5		CAN CIRC 2				CAN CIRC 7
METER A/C AMP*	No indication	NG	UNKWN	UNKWN	UNKWN		UNKWN		UNKWN		UNKWN		UNKWN
BCM	No indication	NG	UNKWN	UNKWN			UNKWN						UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN		UNKWN		UNKWN		UNKWN				
ABS	-	NG	UNKWN	UNKWN	UNKWN			UNKWN					
IPDM E/R	No indication		UNKWN	UNKWN					UNKWN				

WKIA2292E

Circuit Check Between TCM and Data Link Connector**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector F56 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**
4 (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-401, "Work Flow"](#).
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and Driver Seat Control Unit****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G).

- 6 (L) - 3 (BR) : Continuity should exist.**
14 (P) - 19 (Y/G) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-401, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and ABS Actuator and Electric Unit (Control Unit)

EKS00FQW

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2, ABS actuator and electric unit (control unit) connector E125 and ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between driver seat control unit connector P2 terminals 3 (BR), 19 (Y/G) and ABS actuator and electric unit (control unit) connector E125 terminals 7 (L), 9 (P).

- 3 (BR) - 7 (L) : Continuity should exist.**
19 (Y/G) - 9 (P) : Continuity should exist.

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-401, "Work Flow"](#).
 NG >> Repair harness.



ECM Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector M82.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector M82 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM connector M82 and TCM connector F56.



TCM Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector F56.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between TCM connector F56 terminal 3 (L) and terminal 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between TCM connector F56 and ECM connector M82.

**Display Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



Data Link Connector Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-401, "Work Flow"](#).
 NG >> Repair harness between data link connector M22 and BCM connector M18.



Unified Meter and A/C Amp. Circuit Check

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect unified meter and A/C amp. connector M49.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between unified meter and A/C amp. connector M49 terminal 1 (L) and terminal 11 (P).

1 (L) - 11 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. connector M49 and data link connector M22.



Steering Angle Sensor Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect steering angle sensor connector M47.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between steering angle sensor connector M47 terminal 4 (L) and terminal 5 (P).

4 (L) - 5 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor connector M47 and data link connector M22.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM connector M18 and data link connector M22.



Driver Seat Control Unit Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between driver seat control unit connector P2 terminal 3 (BR) and terminal 19 (Y/G).

3 (BR) - 19 (Y/G) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 7 (L) and terminal 9 (P).

7 (L) - 9 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and IPDM E/R connector E121.



IPDM E/R Circuit Check**1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

48 (L) - 49 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R connector E121 and ABS actuator and electric unit (control unit) connector E125.

**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - TCM (Transmission control module)
 - Display control unit
 - Unified meter and A/C amp.
 - Steering angle sensor
 - BCM (Body control module)
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair the harness.



3. CHECK HARNESS FOR SHORT TO GROUND


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-424, "Component Inspection"](#).
NG >> Repair the harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection

ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.

94 - 86 : Approx. 108 - 132 Ω

- Check resistance between IPDM E/R terminals 48 and 49.

48 - 49 : Approx. 108 - 132 Ω

