

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# SECTION AT

## CONTENTS

<b>PREPARATION AND PRECAUTIONS</b> .....3	Diagnostic Procedure 14.....93
Special Service Tools.....3	Diagnostic Procedure 15.....94
Service Notice.....4	Diagnostic Procedure 16.....95
Supplemental Restraint System (SRS) "AIR BAG".....5	Diagnostic Procedure 17.....95
<b>DESCRIPTION</b> .....6	Diagnostic Procedure 18.....96
Cross-sectional View.....6	Diagnostic Procedure 19.....96
Hydraulic Control Circuit.....7	Diagnostic Procedure 20.....96
Shift Mechanism.....8	Electrical Components Inspection.....97
Control System.....10	Final Check.....103
<b>TROUBLE DIAGNOSES</b> .....13	Symptom Chart.....109
How to Perform Trouble Diagnoses for Quick and Accurate Repair.....13	<b>TROUBLE DIAGNOSES — A/T Shift Lock     System</b> .....112
Remarks.....17	Description.....112
Diagnostic Trouble Code (DTC) Chart.....18	Wiring Diagram — SHIFT —.....113
Diagnosis by CONSULT.....20	Diagnostic Procedure.....114
Preliminary Check.....23	Key Interlock Cable.....116
A/T Electrical Parts Location.....34	Component Check.....117
Circuit Diagram for Quick Pinpoint Check.....35	<b>ON-VEHICLE SERVICE</b> .....119
Wiring Diagram — AT —.....36	Control Valve Assembly and Accumulators Inspection.....119
Self-diagnosis.....41	Revolution Sensor Replacement.....120
Diagnostic Procedure 1.....82	Rear Oil Seal Replacement.....120
Diagnostic Procedure 2.....83	Parking Components Inspection.....120
Diagnostic Procedure 3.....83	Inhibitor Switch Adjustment.....121
Diagnostic Procedure 4.....84	Manual Control Linkage Adjustment.....121
Diagnostic Procedure 5.....85	<b>REMOVAL AND INSTALLATION</b> .....122
Diagnostic Procedure 6.....86	Removal.....122
Diagnostic Procedure 7.....87	Installation.....123
Diagnostic Procedure 8.....88	<b>MAJOR OVERHAUL</b> .....126
Diagnostic Procedure 9.....89	Oil Channel.....128
Diagnostic Procedure 10.....90	Locations of Needle Bearings, Thrust Washers and Snap Rings.....129
Diagnostic Procedure 11.....91	<b>DISASSEMBLY</b> .....130
Diagnostic Procedure 12.....92	Disassembly.....130
Diagnostic Procedure 13.....93	

# CONTENTS (Cont'd)

<b>REPAIR FOR COMPONENT PARTS</b> .....	141	Band Servo Piston Assembly .....	177
Oil Pump .....	141	Parking Pawl Components .....	181
Control Valve Assembly .....	145	<b>ASSEMBLY</b> .....	183
Control Valve Upper Body .....	151	Assembly (1) .....	183
Control Valve Lower Body .....	156	Adjustment .....	187
Reverse Clutch .....	158	Assembly (2) .....	191
High Clutch .....	162	<b>A/T FLUID COOLER SYSTEM</b> .....	201
Forward and Overrun Clutches .....	164	A/T Fluid Cooler .....	201
Low & Reverse Brake .....	168	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	202
Forward Clutch Drum Assembly .....	172	General Specifications .....	202
Rear Internal Gear and Forward Clutch Hub .....	174	Specifications and Adjustment .....	202

**When you read wiring diagrams:**






- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

**When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".**

# PREPARATION AND PRECAUTIONS



## Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST2505S001 (J34301-C) Oil pressure gauge set ① ST25051001 ( — ) Oil pressure gauge ② ST25052000 ( — ) Hose ③ ST25053000 ( — ) Joint pipe ④ ST25054000 ( — ) Adapter ⑤ ST25055000 ( — ) Adapter	 <p>Measuring line pressure</p> <p>NT097</p>	GI MA EM LC EC FE CL MT
ST07870000 (J37068) Transmission case stand	 <p>Disassembling and assembling A/T</p> <p>NT421</p> <p> <b>a: 182 mm (7.17 in)</b>  <b>b: 282 mm (11.10 in)</b>  <b>c: 230 mm (9.06 in)</b>  <b>d: 100 mm (3.94 in)</b> </p>	AT TF PD
KV31102100 (J37065) Torque converter one-way clutch check tool	 <p>NT098</p>	FA RA
ST25850000 (J25721-A) Sliding hammer	 <p>Removing oil pump assembly</p> <p>NT422</p> <p> <b>a: 179 mm (7.05 in)</b>  <b>b: 70 mm (2.76 in)</b>  <b>c: 40 mm (1.57 in) dia.</b>  <b>d: M12 x 1.75P</b> </p>	BR ST RS
KV31102400 (J34285 and J34285-87) Clutch spring compressor	 <p>Removing and installing clutch return springs</p> <p>NT423</p> <p> <b>a: 320 mm (12.60 in)</b>  <b>b: 174 mm (6.85 in)</b> </p>	BT HA EL IDX


## PREPARATION AND PRECAUTIONS

### Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	
ST33200000 (J26082) Drift		Installing oil pump housing oil seal Installing rear oil seal
	NT091	<b>a: 60 mm (2.36 in) dia.</b> <b>b: 44.5 mm (1.752 in) dia.</b>
(J34291) Shim setting gauge set		Selecting oil pump cover bearing race and oil pump thrust washer
	NT101	

### Service Notice

- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transmission is disassembled.
- When connecting A/T control unit harness connector, tighten bolt until red projection is in line with connector.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place removed parts in a parts rack in order to replace them in correct positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, and to hold bearings and washers in place during assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer. Refer to TROUBLE DIAGNOSES Remarks, AT-17.
- After overhaul, refill the transmission with new ATF.
- When the A/T drain plug is removed, only some of the fluid is drained. Old A/T fluid will remain in torque converter and ATF cooling system. Always follow the procedures under "Changing A/T Fluid" in the MA section when changing A/T fluid.



- It is very important to perform functional tests whenever they are indicated.

## Supplemental Restraint System (SRS) “AIR BAG”

The Supplemental Restraint System “Air Bag”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.


### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

GI  
MA  
EM  
LC  
EC  
FE  
GI  
WT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# DESCRIPTION


## Cross-sectional View



SAT125BA

# DESCRIPTION

## Hydraulic Control Circuit



GI

MA

EM

LC

EC

TF

CL

MT

**AT**

TF

PD

FA

RA

BR

ST

RS

BT


FA

EL

IDX

# DESCRIPTION

## Shift Mechanism CONSTRUCTION



SAT214H

- |                     |                           |                       |
|---------------------|---------------------------|-----------------------|
| ① Torque converter  | ⑨ Front internal gear     | ⑰ Overrun clutch      |
| ② Oil pump          | ⑩ Front planetary carrier | ⑱ Low one-way clutch  |
| ③ Input shaft       | ⑪ Rear sun gear           | ⑲ Low & reverse brake |
| ④ Brake band        | ⑫ Rear pinion gear        | ⑳ Parking pawl        |
| ⑤ Reverse clutch    | ⑬ Rear internal gear      | ㉑ Parking gear        |
| ⑥ High clutch       | ⑭ Rear planetary carrier  | ㉒ Output shaft        |
| ⑦ Front sun gear    | ⑮ Forward clutch          | ㉓ Idle gear           |
| ⑧ Front pinion gear | ⑯ Forward one-way clutch  | ㉔ Output gear         |

### FUNCTION OF CLUTCH AND BRAKE

Clutch and brake components	Abbr.	Function
⑤ Reverse clutch	R/C	To transmit input power to front sun gear ⑦.
⑥ High clutch	H/C	To transmit input power to front planetary carrier ⑩.
⑮ Forward clutch	F/C	To connect front planetary carrier ⑩ with forward one-way clutch ⑯.
⑰ Overrun clutch	O/C	To connect front planetary carrier ⑩ with rear internal gear ⑬.
④ Brake band	B/B	To lock front sun gear ⑦.
⑯ Forward one-way clutch	F/O.C	When forward clutch ⑮ is engaged, to stop rear internal gear ⑬ from rotating in opposite direction against engine revolution.
⑱ Low one-way clutch	L/O.C	To stop front planetary carrier ⑩ from rotating in opposite direction against engine revolution.
⑲ Low & reverse brake	L & R/B	To lock front planetary carrier ⑩.



# DESCRIPTION

## Shift Mechanism (Cont'd)

### OPERATION OF CLUTCH AND BRAKE

Shift position	Reverse clutch	High clutch	Forward clutch	Overrun clutch	Band servo			Forward one-way clutch	Low one-way clutch	Low & reverse brake	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK POSITION
R	○									○		REVERSE POSITION
N												NEUTRAL POSITION
D*4	1st		○	*1⊗				●	●			Automatic shift 1 ↔ 2 ↔ 3 ↔ 4
	2nd		○	*1⊙	○			●				
	3rd		○	○	*1⊙	*2⊗	⊗				*5○	
	4th		○	⊗		*3⊗	⊗	○			○	
2	1st		○	⊗				●	●			Automatic shift 1 ↔ 2 ↔ 3
	2nd		○	⊙	○			●				
1	1st		○	○				●		○		Locks (held stationary) in 1st speed 1 ↔ 2 ↔ 3
	2nd		○	○	○			●				

\*1: Operates when overdrive control switch is being set in "OFF" position.

\*2: Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

\*3: Oil pressure is applied to 4th "apply" side in condition \*2 above, and brake band contracts.

\*4: A/T will not shift to 4th when overdrive control switch is set in "OFF" position.

\*5: Operates when overdrive control switch is off.

○ : Operates

⊙ : Operates when throttle opening is less than 1/16, activating engine brake.

● : Operates during "progressive" acceleration.

⊗ : Operates but does not affect power transmission.


⊘ : Operates when throttle opening is less than 1/16, but does not affect engine brake.

# DESCRIPTION


## Control System

### OUTLINE

The RE4R01A automatic transmission senses vehicle operating conditions through various sensors. It always controls the optimum shaft position and reduces shifting and lock-up shocks.



### CONTROL SYSTEM



## DESCRIPTION

### Control System (Cont'd)

#### A/T CONTROL UNIT FUNCTION

The function of the A/T control unit is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

#### INPUT/OUTPUT SIGNAL OF A/T CONTROL UNIT

	Sensors and solenoid valves	Function	
Input	Inhibitor switch	Detects select lever position and sends a signal to A/T control unit.	GI
	Throttle position sensor	Detects throttle valve position and sends a signal to A/T control unit.	MA
	Closed throttle position switch	Detects throttle valve's fully-closed position and sends a signal to A/T control unit.	EM
	Wide open throttle position switch	Detects a throttle valve position of greater than 1/2 of full throttle and sends a signal to A/T control unit.	LC
	Engine speed signal	From ECM (ECCS control module).	EC
	Fluid temperature sensor	Detects transmission fluid temperature and sends a signal to A/T control unit.	FE
	Revolution sensor	Detects output shaft rpm and sends a signal to A/T control unit.	CL
	Vehicle speed sensor	Used as an auxiliary vehicle speed sensor. Sends a signal when revolution sensor (installed on transmission) malfunctions.	MT
	Overdrive control switch	Sends a signal, which prohibits a shift to D <sub>4</sub> (OD) position, to the A/T control unit.	AT
Output	Shift solenoid valve A/B	Selects shifting point suited to driving conditions in relation to a signal sent from A/T control unit.	TF
	Line pressure solenoid valve	Regulates (or decreases) line pressure suited to driving conditions in relation to a signal sent from A/T control unit.	PD
	Torque converter clutch solenoid valve	Regulates (or decreases) lock-up pressure suited to driving conditions in relation to a signal sent from A/T control unit.	FA
	Overrun clutch solenoid valve	Controls an "engine brake" effect suited to driving conditions in relation to a signal sent from A/T control unit.	RA
	OD OFF indicator lamp	Shows A/T control unit faults, when A/T control components malfunction.	BR

**DESCRIPTION**

---


**NOTE**

## How to Perform Trouble Diagnoses for Quick and Accurate Repair

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Make good use of the two sheets provided, "INFORMATION FROM CUSTOMER" and "DIAGNOSTIC WORKSHEET", to perform the best troubleshooting possible.

### WORK FLOW



# TROUBLE DIAGNOSES

## How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

### INFORMATION FROM CUSTOMER

#### KEY POINTS

**WHAT** ..... Vehicle & A/T model

**WHEN** ..... Date, Frequencies

**WHERE** ..... Road conditions

**HOW** ..... Operating conditions, Symptoms

Customer name MR/MS	Model & Year	VIN
Trans. model	Engine	Mileage
Incident Date	Manuf. Date	In Service Date
Frequency	<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent ( times a day)	
Symptoms	<input type="checkbox"/> Vehicle does not move. ( <input type="checkbox"/> Any position <input type="checkbox"/> Particular position)	
	<input type="checkbox"/> No up-shift ( <input type="checkbox"/> 1st → 2nd <input type="checkbox"/> 2nd → 3rd <input type="checkbox"/> 3rd → O/D)	
	<input type="checkbox"/> No down-shift ( <input type="checkbox"/> O/D → 3rd <input type="checkbox"/> 3rd → 2nd <input type="checkbox"/> 2nd → 1st)	
	<input type="checkbox"/> Lockup malfunction	
	<input type="checkbox"/> Shift point too high or too low.	
	<input type="checkbox"/> Shift shock or slip ( <input type="checkbox"/> N → D <input type="checkbox"/> Lockup <input type="checkbox"/> Any drive position)	
	<input type="checkbox"/> Noise or vibration	
	<input type="checkbox"/> No kickdown	
	<input type="checkbox"/> No pattern select	
	<input type="checkbox"/> Others ( )	
OD OFF indicator lamp	Blinks for about 8 seconds.	
	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit
Malfunction indicator lamp (MIL)	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit

# TROUBLE DIAGNOSES

## How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

### DIAGNOSTIC WORKSHEET

1.	<input type="checkbox"/> Read the Fail-safe Remarks and listen to customer complaints.	AT-17
2.	<input type="checkbox"/> CHECK A/T FLUID <input type="checkbox"/> Leakage (Follow specified procedure) <input type="checkbox"/> Fluid condition <input type="checkbox"/> Fluid level	AT-23
3.	<input type="checkbox"/> Perform all ROAD TEST and mark required procedures.	AT-23
	3-1. Check before engine is started. <input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items. <ul style="list-style-type: none"> <li><input type="checkbox"/> Revolution sensor</li> <li><input type="checkbox"/> Vehicle speed sensor</li> <li><input type="checkbox"/> Throttle position sensor</li> <li><input type="checkbox"/> Shift solenoid valve A</li> <li><input type="checkbox"/> Shift solenoid valve B</li> <li><input type="checkbox"/> Overrun clutch solenoid valve</li> <li><input type="checkbox"/> Torque converter clutch solenoid valve</li> <li><input type="checkbox"/> Fluid temperature sensor and A/T control unit power source</li> <li><input type="checkbox"/> Engine speed signal</li> <li><input type="checkbox"/> Line pressure solenoid valve</li> <li><input type="checkbox"/> Battery</li> <li><input type="checkbox"/> Others</li> </ul>	AT-24
	3-2. Check at idle <ul style="list-style-type: none"> <li><input type="checkbox"/> Diagnostic Procedure 1 (OD OFF indicator lamp come on for 2 seconds.)</li> <li><input type="checkbox"/> Diagnostic Procedure 2 (Engine starts only in P and N position)</li> <li><input type="checkbox"/> Diagnostic Procedure 3 (In P position, vehicle does not move when pushed)</li> <li><input type="checkbox"/> Diagnostic Procedure 4 (In N position, vehicle moves when pushed)</li> <li><input type="checkbox"/> Diagnostic Procedure 5 (Select shock. N → R position)</li> <li><input type="checkbox"/> Diagnostic Procedure 6 (Vehicle creeps backward in R position)</li> <li><input type="checkbox"/> Diagnostic Procedure 7 (Vehicle creeps forward in D, 2 or 1 position)</li> </ul>	AT-25
	3-3. Cruise test Part-1 <ul style="list-style-type: none"> <li><input type="checkbox"/> Diagnostic Procedure 8 (Vehicle starts from D<sub>1</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 9</li> <li><input type="checkbox"/> Diagnostic Procedure 10</li> <li><input type="checkbox"/> Diagnostic Procedure 11</li> </ul> <div style="margin-left: 40px;">             } (A/T shift schedule: D<sub>1</sub> → D<sub>2</sub>/D<sub>2</sub> → D<sub>3</sub>/D<sub>3</sub> → D<sub>4</sub>/D<sub>4</sub> → D<sub>2</sub>)           </div> <ul style="list-style-type: none"> <li><input type="checkbox"/> Diagnostic Procedure 12 (Shift schedule: Lock-up)</li> <li><input type="checkbox"/> Diagnostic Procedure 13 (Lock-up condition more than 30 seconds)</li> <li><input type="checkbox"/> Diagnostic Procedure 14 (Lock-up released)</li> <li><input type="checkbox"/> Diagnostic Procedure 15 (Engine speed return to idle. Light braking D<sub>4</sub> → D<sub>3</sub>)</li> </ul>	AT-26, AT-29

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## TROUBLE DIAGNOSES

### How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

3.	<p><b>Part-2</b></p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Diagnostic Procedure 16 (Vehicle starts from D<sub>1</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 9 (Kickdown: D<sub>4</sub> → D<sub>2</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 10 (Shift schedule: D<sub>2</sub> → D<sub>3</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 11 (Shift schedule: D<sub>3</sub> → D<sub>4</sub> and engine brake)</li> </ul>	AT-31		
	<p><b>Part-3</b></p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Diagnostic Procedure 17 (D<sub>4</sub> → D<sub>3</sub> when OD OFF switch ON → OFF)</li> <li><input type="checkbox"/> Diagnostic Procedure 15 (Engine brake in D<sub>3</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 18 (D<sub>3</sub> → 2<sub>2</sub> when selector lever D → 2 position)</li> <li><input type="checkbox"/> Diagnostic Procedure 15 (Engine brake in 2<sub>2</sub>)</li> <li><input type="checkbox"/> Diagnostic Procedure 19 (2<sub>2</sub> → 1<sub>1</sub>, when selector lever 2 → 1 position)</li> <li><input type="checkbox"/> Diagnostic Procedure 20 (Engine brake in 1<sub>1</sub>)</li> <li><input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items.             <ul style="list-style-type: none"> <li><input type="checkbox"/> Revolution sensor</li> <li><input type="checkbox"/> Vehicle speed sensor</li> <li><input type="checkbox"/> Throttle position sensor</li> <li><input type="checkbox"/> Shift solenoid valve A</li> <li><input type="checkbox"/> Shift solenoid valve B</li> <li><input type="checkbox"/> Overrun clutch solenoid valve</li> <li><input type="checkbox"/> Torque converter clutch solenoid valve</li> <li><input type="checkbox"/> Fluid temperature sensor and A/T control unit power source</li> <li><input type="checkbox"/> Engine speed signal</li> <li><input type="checkbox"/> Line pressure solenoid valve</li> <li><input type="checkbox"/> Battery</li> <li><input type="checkbox"/> Others</li> </ul> </li> </ul>	AT-32		
4.	<input type="checkbox"/> For self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-41		
5.	<input type="checkbox"/> Perform all ROAD TEST and re-mark required procedures.	AT-23		
6.	<p><input type="checkbox"/> Perform SELF-DIAGNOSIS for following MIL indicating items and check out NG items. Refer to EC section ["Diagnostic Trouble Code (DTC)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION].</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> DTC (P0731, 1103) Improper shifting to 1st gear position</li> <li><input type="checkbox"/> DTC (P0732, 1104) Improper shifting to 2nd gear position</li> <li><input type="checkbox"/> DTC (P0733, 1105) Improper shifting to 3rd gear position</li> <li><input type="checkbox"/> DTC (P0734, 1106) Improper shifting to 4th gear position or TCC</li> </ul>	EC section		
7.	<p><input type="checkbox"/> Perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged parts. Refer to the Symptom Chart when you perform the procedures. (The chart also shows some other possible symptoms and the component inspection orders.)</p>	AT-97, AT-109		
8.	<input type="checkbox"/> Erase DTC from A/T control unit and ECM memories.	AT-46		
9.	<p>Perform FINAL CHECK.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Stall test — Mark possible damaged components/others.             <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> <li><input type="checkbox"/> Torque converter one-way clutch</li> <li><input type="checkbox"/> Reverse clutch</li> <li><input type="checkbox"/> Forward clutch</li> <li><input type="checkbox"/> Overrun clutch</li> <li><input type="checkbox"/> Forward one-way clutch</li> </ul> </td> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> <li><input type="checkbox"/> Low &amp; reverse brake</li> <li><input type="checkbox"/> Low one-way clutch</li> <li><input type="checkbox"/> Engine</li> <li><input type="checkbox"/> Line pressure is low</li> <li><input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK</li> </ul> </td> </tr> </table> </li> <li><input type="checkbox"/> Pressure test — Suspected parts:</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Torque converter one-way clutch</li> <li><input type="checkbox"/> Reverse clutch</li> <li><input type="checkbox"/> Forward clutch</li> <li><input type="checkbox"/> Overrun clutch</li> <li><input type="checkbox"/> Forward one-way clutch</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Low &amp; reverse brake</li> <li><input type="checkbox"/> Low one-way clutch</li> <li><input type="checkbox"/> Engine</li> <li><input type="checkbox"/> Line pressure is low</li> <li><input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK</li> </ul>	AT-103
<ul style="list-style-type: none"> <li><input type="checkbox"/> Torque converter one-way clutch</li> <li><input type="checkbox"/> Reverse clutch</li> <li><input type="checkbox"/> Forward clutch</li> <li><input type="checkbox"/> Overrun clutch</li> <li><input type="checkbox"/> Forward one-way clutch</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Low &amp; reverse brake</li> <li><input type="checkbox"/> Low one-way clutch</li> <li><input type="checkbox"/> Engine</li> <li><input type="checkbox"/> Line pressure is low</li> <li><input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK</li> </ul>			



## Remarks

### FAIL-SAFE

The A/T control unit has an electronic Fail-Safe (limp home mode). This allows the vehicle to be driven even if a major electrical input/output device circuit is damaged.

Under Fail-Safe, the vehicle always runs in third gear with shift lever position of 1, 2 or D. Customer may say "Sluggish, poor acceleration".

When Fail-Safe operation occurs the next time the key is turned to the ON position, the OD OFF indicator lamp will blink for about 8 seconds. (For diagnosis, refer to AT-24.)

Fail-Safe may activate without electrical circuit damages if the vehicle is driven under extreme conditions (such as excessive wheel spins and emergency braking immediately afterwards). In this case, turn key OFF for 5 seconds and then ON to recover normal shift pattern.

The blinking of the OD OFF indicator lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions by chance.

Always follow the "WORK FLOW" (Refer to AT-13).

The SELF-DIAGNOSIS results will be as follows:

The first SELF-DIAGNOSIS will indicate the damage of the vehicle speed sensor or the revolution sensor.

During the next SELF-DIAGNOSIS performed after checking the sensor, no damages will be indicated.

### ATF COOLER SERVICE

Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer.

VG33E engine (with RE4R01A) ... fin type cooler

Replace radiator lower tank (which includes ATF cooler) with a new one and flush cooler line using cleaning solvent and compressed air.

### OBD-II SELF-DIAGNOSIS

- A/T self-diagnosis is performed by the A/T control unit in combination with the ECM. The results can be read through the blinking pattern of the OD OFF indicator or the malfunction indicator lamp (MIL). Refer to the table on AT-41 for the indicator used to display each self-diagnostic result.

- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and A/T control unit memories.

**Always perform the procedure "HOW TO ERASE DTC" on AT-46 to complete the repair and avoid unnecessary blinking of the MIL.**

- The following self-diagnostic items can be detected using ECM self-diagnostic results mode\* only when the OD OFF indicator lamp does not indicate any malfunctions.

–Improper shifting to 1st, 2nd, 3rd, or 4th gear position

–Improper torque converter clutch operation.

\*: Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
**AT**  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# TROUBLE DIAGNOSES

## Diagnostic Trouble Code (DTC) Chart

### A/T RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0705	1101	Inhibitor switch circuit (INHIBITOR SWITCH)	<ul style="list-style-type: none"> <li>• A/T control unit does not receive the correct voltage signal from the switch based on the gear position.</li> </ul>
P0710	1208	Fluid temperature sensor (FLUID TEMP SENSOR)	<ul style="list-style-type: none"> <li>• A/T control unit receives an excessively low or high voltage from the sensor.</li> </ul>
P0720	1102	Revolution sensor (VHCL SPEED SEN·A/T)	<ul style="list-style-type: none"> <li>• A/T control unit does not receive the proper voltage signal from the sensor.</li> </ul>
P0725	1207	Engine speed signal (ENGINE SPEED SIG)	<ul style="list-style-type: none"> <li>• A/T control unit does not receive the proper voltage signal from the ECM.</li> </ul>
P0731	1103	Improper shifting to 1st gear position (A/T 1ST SIGNAL)	<ul style="list-style-type: none"> <li>• A/T cannot be shifted to the 1st gear position even if electrical circuit is good.</li> </ul>
P0732	1104	Improper shifting to 2nd gear position (A/T 2ND SIGNAL)	<ul style="list-style-type: none"> <li>• A/T cannot be shifted to the 2nd gear position even if electrical circuit is good.</li> </ul>
P0733	1105	Improper shifting to 3rd gear position (A/T 3RD SIGNAL)	<ul style="list-style-type: none"> <li>• A/T cannot be shifted to the 3rd gear position even if electrical circuit is good.</li> </ul>
P0734	1106	Improper shifting to 4th gear position or TCC (A/T 4TH SIGNAL OR TCC)	<ul style="list-style-type: none"> <li>• A/T cannot be shifted to the 4th gear position or perform lock-up even electrical circuit is good.</li> </ul>
P0740	1204	T/C clutch solenoid valve (TOR CONV CLUTCH SV)	<ul style="list-style-type: none"> <li>• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.</li> </ul>
P0745	1205	Line pressure solenoid valve (LINE PRESSURE S/V)	<ul style="list-style-type: none"> <li>• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.</li> </ul>
P0750	1108	Shift solenoid valve A (SHIFT SOLENOID/V A)	<ul style="list-style-type: none"> <li>• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.</li> </ul>
P0755	1201	Shift solenoid valve B (SHIFT SOLENOID/V B)	<ul style="list-style-type: none"> <li>• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.</li> </ul>
P1705	1206	Throttle position sensor Throttle position switch (THRTL POSI SEN·A/T)	<ul style="list-style-type: none"> <li>• A/T control unit receives an excessively low or high voltage from the sensor.</li> </ul>
P1760	1203	Overrun clutch solenoid valve (OVERRUN CLUTCH S/V)	<ul style="list-style-type: none"> <li>• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.</li> </ul>

# TROUBLE DIAGNOSES

## Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable  
—: Not applicable

Check Items (Possible Cause)	DTC *1 Confirmation Procedure Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> <li>• Harness or connectors (The switch circuit is open or shorted.)</li> <li>• Inhibitor switch</li> </ul>	DRIVING (pattern 1)	—	2 trip	AT-68	GI MA EM
<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Fluid temperature sensor</li> </ul>	DRIVING (pattern 6)	X	2 trip	AT-61	LC
<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Revolution sensor</li> </ul>	DRIVING (pattern 2)	X	2 trip	AT-47	EC
<ul style="list-style-type: none"> <li>• Harness or connectors (The signal circuit is open or shorted.)</li> </ul>	DRIVING (pattern 5)	X	2 trip	AT-64	FE
<ul style="list-style-type: none"> <li>• Shift solenoid valve A</li> <li>• Shift solenoid valve B</li> <li>• Overrun clutch solenoid valve</li> <li>• Line pressure solenoid valve</li> <li>• Each clutch</li> <li>• Hydraulic control circuit</li> </ul> <p style="text-align: center;">.....</p> <ul style="list-style-type: none"> <li>• T/C clutch solenoid valve</li> </ul>	DRIVING (pattern 3)	—	2 trip	AT-72	CL
				AT-74	MT
				AT-76	<b>AT</b>
				AT-78	TF
<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• T/C clutch solenoid valve</li> </ul>	IGN: ON	X	2 trip	AT-59	PD
<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Line pressure solenoid valve</li> </ul>	IGN: ON	X	2 trip	AT-66	FA
<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Shift solenoid valve A</li> </ul>	IGN: ON	X	2 trip	AT-53	RA
<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Shift solenoid valve B</li> </ul>	IGN: ON	X	2 trip	AT-55	BR
<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Throttle position sensor</li> </ul>	DRIVING (pattern 4)	X	2 trip	AT-51	ST
<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Overrun clutch solenoid valve</li> </ul>	IGN: ON	X	2 trip	AT-57	RS BT

\*1: DRIVING pattern 1-6 means as follows:  
 Pattern 1 should meet b and c.  
 Pattern 2 should meet a and c.  
 Pattern 3 should meet a through e.  
 Pattern 4 should meet a and b.  
 Pattern 5 should meet a through c.  
 Pattern 6 should meet a through d.

a: Selector lever is in "D" position.  
 b: Vehicle speed is over 10 km/h (6 MPH).  
 c: Throttle opening is over 1/8.  
 d: Engine speed is over 450 rpm.  
 e: A/T fluid temperature is 20 - 120°C (68 - 248°F).

# TROUBLE DIAGNOSES

## Diagnosis by CONSULT

### NOTICE

- The CONSULT electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).  
Check for time difference between actual shift timing and the CONSULT display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- Shift schedule (which implies gear position) displayed on CONSULT and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
  - Actual shift schedule has more or less tolerance or allowance,
  - Shift schedule indicated in Service Manual refers to the point where shifts start. Gear position displayed on CONSULT indicates the point where shifts are completed.
- Shift solenoid valve "A" or "B" is displayed on CONSULT at the start of shifting. Gear position is displayed upon completion of shifting (which is computed by A/T control unit).
- Additional CONSULT information can be found in the Operation Manual supplied with the CONSULT unit.

### SELF-DIAGNOSTIC RESULT TEST MODE

Refer to AT-41.

### DATA MONITOR DIAGNOSTIC TEST MODE

Item	Display	Monitor item		Description	Remarks
		ECU input signals	Main signals		
Vehicle speed sensor 1 (A/T) (Revolution sensor)	VHCL/S SE-A/T [km/h] or [mph]	X	—	• Vehicle speed computed from signal of revolution sensor is displayed.	When revving engine in N or P position with vehicle stationary, CONSULT data may not indicate 0 km/h (0 mph).
Vehicle speed sensor 2 (Meter)	VHCL/S SE-MTR [km/h] or [mph]	X	—	• Vehicle speed computed from signal of vehicle speed sensor is displayed.	Vehicle speed display may not be accurate under approx. 10 km/h (6 mph). It may not indicate 0 km/h (0 mph) when vehicle is stationary.
Throttle position sensor	THRTL POS SEN [V]	X	—	• Throttle position sensor signal voltage is displayed.	
Fluid temperature sensor	FLUID TEMP SEN [V]	X	—	• Fluid temperature sensor signal voltage is displayed. • Signal voltage lowers as fluid temperature rises.	
Battery voltage	BATTERY VOLT [V]	X	—	• Source voltage of control unit is displayed.	
Engine speed	ENGINE SPEED [rpm]	X	X	• Engine speed, computed from engine speed signal, is displayed.	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.
Overdrive control switch	OVERDRIVE SW [ON/OFF]	X	—	• ON/OFF state computed from signal of overdrive control SW is displayed.	
P/N position switch	P/N POSI SW [ON/OFF]	X	—	• ON/OFF state computed from signal of P/N position SW is displayed.	
R position switch	R POSITION SW [ON/OFF]	X	—	• ON/OFF state computed from signal of R position SW is displayed.	
D position switch	D POSITION SW [ON/OFF]	X	—	• ON/OFF state computed from signal of D position SW is displayed.	
2 position switch	2 POSITION SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of 2 position SW, is displayed.	

# TROUBLE DIAGNOSES

## Diagnosis by CONSULT (Cont'd)

Item	Display	Monitor item		Description	Remarks
		ECU input signals	Main signals		
1 position switch	1 POSITION SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of 1 position SW, is displayed.	
ASCD-cruise signal	ASCD-CRUISE [ON/OFF]	X	—	• Status of ASCD cruise signal is displayed. ON ... Cruising state OFF ... Normal running state	• This is displayed even when no ASCD is mounted.
ASCD-OD cut signal	ASCD-OD CUT [ON/OFF]	X	—	• Status of ASCD-OD release signal is displayed. ON ... OD released OFF ... OD not released	• This is displayed even when no ASCD is mounted.
Kickdown switch	KICKDOWN SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of kickdown SW, is displayed.	• This is displayed even when no kickdown switch is equipped.
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of closed throttle position SW, is displayed.	
Wide open throttle position switch	W/O THRL/P-SW [ON/OFF]	X	—	• ON/OFF status, computed from signal of wide open throttle position SW, is displayed.	
Gear position	GEAR	—	X	• Gear position data used for computation by control unit, is displayed.	
Selector lever position	SLCT LVR POSI	—	X	• Selector lever position data, used for computation by control unit, is displayed.	• A specific value used for control is displayed if fail-safe is activated due to error.
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	—	X	• Vehicle speed data, used for computation by control unit, is displayed.	
Throttle position	THROTTLE POSI [°]	—	X	• Throttle position data, used for computation by control unit, is displayed.	• A specific value used for control is displayed if fail-safe is activated due to error.
Line pressure duty	LINE PRES DTY [%]	—	X	• Control value of line pressure solenoid valve, computed by control unit from each input signal, is displayed.	
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	—	X	• Control value of torque converter clutch solenoid valve, computed by control unit from each input signal, is displayed.	
Shift solenoid valve A	SHIFT S/V A [ON/OFF]	—	X	• Control value of shift solenoid valve A, computed by control unit from each input signal, is displayed.	Control value of solenoid is displayed even if solenoid circuit is disconnected. The "OFF" signal is displayed if solenoid circuit is shorted.
Shift solenoid valve B	SHIFT S/V B [ON/OFF]	—	X	• Control value of shift solenoid valve B, computed by control unit from each input signal, is displayed.	
Overrun clutch solenoid valve	OVERRUN/C S/V [ON/OFF]	—	X	• Control value of overrun clutch solenoid valve computed by control unit from each input signal is displayed.	
Self-diagnosis display lamp (OD OFF indicator lamp)	SELF-D DP LMP [ON/OFF]	—	X	• Control status of OD OFF indicator lamp is displayed.	

X: Applicable  
—: Not applicable

# TROUBLE DIAGNOSES

## Diagnosis by CONSULT (Cont'd)

### DATA ANALYSIS

Item	Display form	Meaning
Torque converter clutch solenoid valve duty	Approximately 4%	Lock-up "OFF"
	↓	↓
	Approximately 94%	Lock-up "ON"
Line pressure solenoid valve duty	Approximately 0%	Low line-pressure (Small throttle opening)
	↓	↓
	Approximately 95%	High line-pressure (Large throttle opening)
Throttle position sensor	Approximately 0.5V	Fully-closed throttle
	↓	↓
	Approximately 4V	Fully-open throttle
Fluid temperature sensor	Approximately 1.5V	Cold [20°C (68°F)]
	↓	↓
	Approximately 0.5V	Hot [80°C (176°F)]

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

## Preliminary Check

### A/T FLUID CHECK

#### Fluid leakage check

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in "D" position and wait a few minutes.
3. Stop engine.
4. Check for fresh leakage.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



SAT638A

#### Fluid condition check

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling, — Overheating

**Fluid level check — Refer to MA section (CHASSIS AND BODY MAINTENANCE).**

### ROAD TEST PROCEDURE

1. Check before engine is started.



2. Check at idle.




3. Cruise test.

SAT786A

### ROAD TEST

#### Description

- The purpose of the test is to determine overall performance of A/T and analyze causes of problems.
- The road test consists of the following three parts:
  1. Check before engine is started
  2. Check at idle
  3. Cruise test
- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test. Refer to "Self-diagnosis" and "Diagnostic Procedure", AT-41, 82.




SAT496G

# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)

### 1. Check before engine is started



**A B**

1. Park vehicle on flat surface.
2. Turn ignition switch to "OFF" position.
3. Move selector lever to "P" position.
4. Set overdrive control switch to "ON" position.
5. Turn ignition switch to "ON" position. (Do not start engine.)
6. Does OD OFF indicator lamp come on for about 2 seconds?

No → Go to Diagnostic Procedure 1, AT-82.

Yes


**C**

- Does OD OFF indicator lamp flicker for about 8 seconds?

Yes → Perform self-diagnosis. Refer to SELF-DIAGNOSIS PROCEDURE, AT-41.

No



1. Turn ignition switch to "OFF" position.
2. Perform self-diagnosis and note NG items. Refer to SELF-DIAGNOSIS PROCEDURE, AT-41.
3. Go to "2. Check at idle", AT-25.






# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)



### 2. Check at idle



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)



### 3. Cruise test

- Check all items listed in Parts 1 through 3.




#### With CONSULT

- Using CONSULT, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per "Shift Schedule".




### CONSULT setting procedure


1. Turn off ignition switch.
2. Connect "CONSULT" to Data link connector for CONSULT. Data link connector for CONSULT is located in left side dash panel.



3. Turn on ignition switch.
4. Touch "START".




5. Touch "A/T".



6. Touch "DATA MONITOR".

# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)



7. Touch "SETTING" to set recording condition.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX




8. Touch "LONG TIME" and "ENTER" key.




9. Go back to SELECT MONITOR ITEM and touch "MAIN SIGNALS".

10. Touch "START".




11. When performing cruise test, touch "RECORD".




12. After finishing cruise test part 1, touch "STOP".

# TROUBLE DIAGNOSES


## Preliminary Check (Cont'd)




13. Touch "DISPLAY".



14. Touch "PRINT".




15. Touch "PRINT" again.



16. Check the monitor data printed out.

17. Continue cruise test part 2 and 3.




Without CONSULT

- Throttle position can be checked by voltage across terminals ③④ and ③⑤ of A/T control unit.


# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)

### Cruise test — Part 1




1. Drive vehicle for approx. 10 minutes to warm engine oil and ATF up to operating temperature.  
**ATF operating temperature:**  
50 - 80°C (122 - 176°F)



- A B**
1. Park vehicle on flat surface.
  2. Set overdrive control switch to "ON" position.
  3. Move selector lever to "P" position.
  4. Start engine.


**C**  
Move selector lever to "D" position.

**D**  
Accelerate vehicle by constantly depressing accelerator pedal halfway.



Does vehicle start from D<sub>1</sub>?  
**Read gear position.**  
No → Go to Diagnostic Procedure 8, AT-88.

**E**  
Does A/T shift from D<sub>1</sub> to D<sub>2</sub> at the specified speed?  
**Read gear position, throttle opening and vehicle speed.**  
Specified speed when shifting from D<sub>1</sub> to D<sub>2</sub>:  
**Refer to Shift schedule, AT-33.**  
No → Go to Diagnostic Procedure 9, AT-89.






**F**  
Does A/T shift from D<sub>2</sub> to D<sub>3</sub> at the specified speed?  
**Read gear position, throttle position and vehicle speed.**  
Specified speed when shifting from D<sub>2</sub> to D<sub>3</sub>:  
**Refer to Shift schedule, AT-33.**  
No → Go to Diagnostic Procedure 10, AT-90.

Yes  
A

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES


## Preliminary Check (Cont'd)



# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)

### Cruise test — Part 2




1. Confirm overdrive control switch is in "ON" position.
2. Confirm selector lever is in "D" position.

**A**

1. Accelerate vehicle by half throttle again.
2. Does vehicle start from D<sub>1</sub>?

**Read gear position.**

No → Go to Diagnostic Procedure 16, AT-95.




**B**

1. Accelerate vehicle to 80 km/h (50 MPH) as shown in illustration.
2. Release accelerator pedal and then quickly depress it fully.
3. Does A/T shift from D<sub>4</sub> to D<sub>2</sub> as soon as accelerator pedal is depressed fully?

**Read gear position and throttle position.**

No → Go to Diagnostic Procedure 9, AT-89.



**C**

Does A/T shift from D<sub>2</sub> to D<sub>3</sub> at the specified speed?

**Read gear position, throttle position and vehicle speed.**

**Specified speed when shifting from D<sub>2</sub> to D<sub>3</sub>:**  
Refer to Shift schedule, AT-33.

No → Go to Diagnostic Procedure 10, AT-90.

**D**

Release accelerator pedal after shifting from D<sub>2</sub> to D<sub>3</sub>. Does A/T shift from D<sub>3</sub> to D<sub>4</sub> and does vehicle decelerate by engine brake?

**Read gear position, throttle position and vehicle speed.**

No → Go to Diagnostic Procedure 11, AT-91.


1. Stop vehicle.
2. Go to "Cruise test — Part 3", AT-32.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
TDX

# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)


### Cruise test — Part 3



1. Confirm overdrive control switch is in "ON" position.
2. Confirm selector lever is in "D" position.

**A**  
Accelerate vehicle using half-throttle to D<sub>4</sub>.

**B**  
Release accelerator pedal.





**C**  
Set overdrive control switch to "OFF" position while driving in D<sub>4</sub>.

**D**  
Does A/T shift from D<sub>4</sub> to D<sub>3</sub>?  
**Read gear position and vehicle speed.**

No → Go to Diagnostic Procedure 17, AT-95.

**E**  
Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 15, AT-94.



**F**  
Move selector lever from "D" to "2" position while driving in D<sub>3</sub>.



**G**  
Does A/T shift from D<sub>3</sub> to 2<sub>2</sub>?  
**Read gear position.**



No → Go to Diagnostic Procedure 18, AT-96.

**H**  
Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 15, AT-94.



**I J**  
1. Move selector lever from "2" to "1" position while driving in 2<sub>2</sub>.  
2. Does A/T shift from 2<sub>2</sub> to 1<sub>1</sub> position?  
**Read gear position.**

No → Go to Diagnostic Procedure 19, AT-96.



**K**  
Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 20, AT-96.

1. Stop vehicle.
2. Perform self-diagnosis. Refer to SELF-DIAGNOSTIC PROCEDURE, AT-41.



# TROUBLE DIAGNOSES

## Preliminary Check (Cont'd)

### SHIFT SCHEDULE

#### Vehicle speed when shifting gears

2WD, 4WD (Final gear ratio: 4.363) and 4WD (Final gear ratio: 4.636)

Throttle position	Vehicle speed km/h (MPH)						
	D <sub>1</sub> → D <sub>2</sub>	D <sub>2</sub> → D <sub>3</sub>	D <sub>3</sub> → D <sub>4</sub>	D <sub>4</sub> → D <sub>5</sub>	D <sub>5</sub> → D <sub>2</sub>	D <sub>2</sub> → D <sub>1</sub>	1 <sub>2</sub> → 1 <sub>1</sub>
Full throttle	48 - 52 (30 - 32)	93 - 101 (58 - 63)	148 - 158 (92 - 98)	143 - 153 (89 - 95)	88 - 96 (55 - 60)	43 - 47 (27 - 29)	44 - 48 (27 - 30)
Half throttle	35 - 39 (22 - 24)	61 - 67 (38 - 42)	134 - 142 (83 - 88)	85 - 93 (53 - 58)	32 - 38 (20 - 24)	10 - 14 (6 - 9)	44 - 48 (27 - 30)

#### Vehicle speed when performing and releasing lock-up

2WD, 4WD (Final gear ratio: 4.363) and 4WD (Final gear ratio: 4.636)

Throttle position	Overdrive control switch [Shift position]	Vehicle speed km/h (MPH)	
		Lock-up "ON"	Lock-up "OFF"
Full throttle	ON [D <sub>4</sub> ]	149 - 157 (93 - 98)	144 - 152 (89 - 94)
	OFF [D <sub>3</sub> ]	93 - 101 (58 - 63)	88 - 96 (55 - 60)
Half throttle	ON [D <sub>4</sub> ]	141 - 149 (88 - 93)	85 - 93 (53 - 58)
	OFF [D <sub>3</sub> ]	74 - 82 (46 - 51)	71 - 79 (44 - 49)

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL


LDX

## A/T Electrical Parts Location



# TROUBLE DIAGNOSES

## Circuit Diagram for Quick Pinpoint Check




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES






## Wiring Diagram — AT —

AT-A/T-01

Refer to EL-POWER.




Refer to last page (Foldout page).







# TROUBLE DIAGNOSES

## Wiring Diagram — AT — (Cont'd)

AT-A/T-02



Refer to last page (Foldout page).








(M10)  
(M13)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Wiring Diagram — AT — (Cont'd)

AT-A/T-03








Refer to last page (Foldout page).

- (M10)
- (M13)
- (F24)

# TROUBLE DIAGNOSES

## Wiring Diagram — AT — (Cont'd)





Refer to last page (Foldout page).  
M13

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT**
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX


# TROUBLE DIAGNOSES

## Wiring Diagram — AT — (Cont'd)

AT-A/T-05








## Self-diagnosis

After performing this procedure, place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-15. Reference pages are provided following the items.

### SELF-DIAGNOSTIC PROCEDURE (With CONSULT)



1. Turn on CONSULT and touch "A/T".  
If A/T is not displayed, check A/T control unit power supply and ground circuit. Refer to AT-97. If result is NG, refer to EL section ("POWER SUPPLY ROUTING").
2. Touch "SELF-DIAG RESULTS".  
Display shows malfunction experienced since the last erasing operation.  
CONSULT performs REAL-TIME SELF-DIAGNOSIS.  
Also, any malfunction detected while in this mode will be displayed at real time.



Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...	Indicator for Diagnostic Results	
		 OD OFF indicator lamp (Available when "A/T" on CONSULT is touched.)	 HCHECK indicator lamp*2 (Available when "ENGINE" on CON- SULT is touched.)
Inhibitor switch circuit (INHIBITOR SWITCH)	• A/T control unit does not receive the correct voltage signal (based on the gear position) from the switch.	—	X
Revolution sensor (VHCL SPEED SEN-A/T)	• A/T control unit does not receive the proper voltage signal from the sensor.	X	X
Vehicle speed sensor (Meter) (VHCL SPEED SEN-MTR)	• A/T control unit does not receive the proper voltage signal from the sensor.	X	—
Improper shifting to 1st gear position (A/T 1ST SIGNAL)	• A/T cannot be shifted to the 1st gear position even when electrical circuit is good.	—	X*1
Improper shifting to 2nd gear position (A/T 2ND SIGNAL)	• A/T cannot be shifted to the 2nd gear position even when electrical circuit is good.	—	X*1
Improper shifting to 3rd gear position (A/T 3RD SIGNAL)	• A/T cannot be shifted to the 3rd gear position even when electrical circuit is good.	—	X*1
Improper shifting to 4th gear position or TCC (A/T 4TH SIG OR TCC)	• A/T cannot be shifted to the 4th gear position or can not perform lock-up, even when electrical circuit is good.	—	X*1
Shift solenoid valve A (SHIFT SOLENOID/V A)	• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	X	X
Shift solenoid valve B (SHIFT SOLENOID/V B)	• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	X	X
Overrun clutch solenoid valve (OVERRUN CLUTCH SV)	• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	X	X
T/C clutch solenoid valve (TOR CONV CLUTCH SV)	• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	X	X
Line pressure solenoid valve (LINE PRESSURE S/V)	• A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	X	X
Throttle position sensor Throttle position switch (THRTL POSI SEN-A/T)	• A/T control unit receives an excessively low or high voltage from the sensor.	X	X
Engine speed signal (ENGINE SPEED SIG)	• A/T control unit does not receive the proper voltage signal from the ECM.	X	X


# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...	Indicator for Diagnostic Results	
		 OD OFF indicator lamp (Available when "A/T" on CONSULT is touched.)	 Malfunction indicator lamp*2 (Available when "ENGINE" on CON- SULT is touched.)
Fluid temperature sensor (FLUID TEMP SENSOR)	<ul style="list-style-type: none"> <li>A/T control unit receives an excessively low or high voltage from the sensor.</li> </ul>	X	X
Initial start INITIAL START	<ul style="list-style-type: none"> <li>This is not a malfunction message (Whenever shutting off a power supply to the control unit, this message appears on the screen.)</li> </ul>	X	—
No failure (NO SELF DIAGNOSTIC FAILURE INDICATED FURTHER TESTING MAY BE REQUIRED**)	<ul style="list-style-type: none"> <li>No failure has been detected.</li> </ul>	X	X


X : Applicable

— : Not applicable

\*1 : These malfunctions cannot be displayed by MIL  if another malfunction is assigned to the OD OFF indicator lamp




\*2 : Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].





### SELF-DIAGNOSTIC PROCEDURE [With Generic Scan Tool (GST)]

Refer to EC section ["Generic Scan Tool (GST)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].




### SELF-DIAGNOSTIC PROCEDURE (No Tools)




# TROUBLE DIAGNOSES


## Self-diagnosis (Cont'd)



- A**
- D E**
1. Turn ignition switch to "OFF" position.
  2. Turn ignition switch to "ACC" position.
  3. Move selector lever to "D" position.
  4. Set overdrive control switch to "OFF" position.
  5. Turn ignition switch to "ON" position (Do not start engine.)
- Wait for more than 2 seconds after ignition switch "ON".



- F G**
1. Move selector lever to "2" position.
  2. Set overdrive control switch in "ON" position.





- H I**
- Move selector lever to "1" position.  
Set overdrive control switch in "OFF" position.

- J**
- Depress accelerator pedal fully and release it.

- K**
- Check OD OFF indicator lamp.  
Refer to JUDGEMENT OF SELF-DIAGNOSIS CODE on next page.

DIAGNOSIS END



CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
BS  
BT  
HA  
EL  
LDX


# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### JUDGEMENT OF SELF-DIAGNOSIS CODE

OD OFF indicator lamp:


All judgement flickers are same.



SAT369I

All circuits that can be confirmed by self-diagnosis are OK.

4th judgement flicker is longer than others.




SAT370I

Shift solenoid valve A circuit is short-circuited or disconnected.

➡ Go to **SHIFT SOLENOID VALVE A CIRCUIT CHECK, AT-53.**

1st judgement flicker is longer than others.




SAT437F

Revolution sensor circuit is short-circuited or disconnected.

➡ Go to **REVOLUTION SENSOR CIRCUIT CHECK, AT-47.**

5th judgement flicker is longer than others.




SAT445F

Shift solenoid valve B circuit is short-circuited or disconnected.

➡ Go to **SHIFT SOLENOID VALVE B CIRCUIT CHECK, AT-55.**

2nd judgement flicker is longer than others.




SAT439F

Vehicle speed sensor circuit is short-circuited or disconnected.

➡ Go to **VEHICLE SPEED SENSOR CIRCUIT CHECK, AT-49.**

6th judgement flicker is longer than others.




SAT447F

Overrun clutch solenoid valve circuit is short-circuited or disconnected.

➡ Go to **OVERRUN CLUTCH SOLENOID VALVE CIRCUIT CHECK, AT-57.**

3rd judgement flicker is longer than others.




SAT441F

Throttle position sensor circuit is short-circuited or disconnected.

➡ Go to **THROTTLE POSITION SENSOR CIRCUIT CHECK, AT-51.**

7th judgement flicker is longer than others.



SAT449F

Torque converter clutch solenoid valve circuit is short-circuited or disconnected.

➡ Go to **TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT CHECK, AT-59.**


$t_1 = 2.5$  seconds     $t_2 = 2.0$  seconds     $t_3 = 1.0$  second

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

OD OFF indicator lamp:


8th judgement flicker is longer than others.



SAT3711

Fluid temperature sensor is disconnected or A/T control unit power source circuit is damaged.  
 ➔ Go to **FLUID TEMPERATURE SENSOR AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS, AT-61.**


Flickers as shown below.



SAT3721

Battery power is low.  
 Battery has been disconnected for a long time.  
 Battery is connected conversely.  
 (When reconnecting A/T control unit connectors. — This is not a problem.)


9th judgement flicker is longer than others.



SAT453F

Engine speed signal circuit is short-circuited or disconnected.  
 ➔ Go to **ENGINE SPEED SIGNAL CIRCUIT CHECK, AT-64.**


Does not come on.



SAT3731

Inhibitor switch, overdrive control switch or throttle position switch circuit is disconnected or A/T control unit is damaged.  
 ➔ Go to **INHIBITOR, OVERDRIVE CONTROL AND THROTTLE POSITION SWITCH CIRCUIT CHECKS, AT-68.**

10th judgement flicker is longer than others.



SAT455F

Line pressure solenoid valve circuit is short-circuited or disconnected.  
 ➔ Go to **LINE PRESSURE SOLENOID VALVE CIRCUIT CHECK, AT-66.**

$t_4 = 1.0$  second

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
**AT**  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



### HOW TO ERASE DTC (With CONSULT)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Turn CONSULT "ON", and touch "A/T".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the A/T control unit will be erased.) Then touch "BACK" twice.
5. Touch "ENGINE".
6. Touch "SELF-DIAG RESULTS".
7. Touch "ERASE". (The DTC in the ECM will be erased.)

#### How to erase DTC (With CONSULT)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
ENGINE
A/T


2. Turn CONSULT "ON", and touch "A/T".

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
ECU PART NUMBER

3. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS	
FAILURE DETECTED	
SHIFT SOLENOID/V A	
ERASE	PRINT

4. Touch "ERASE". (The DTC in the A/T control unit will be erased.)



SELECT SYSTEM
ENGINE
A/T

5. Touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
FUNCTION TEST
FREEZE FRAME DATA

6. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS	
FAILURE DETECTED	TIME
SHIFT SOLENOID/V A	0
[P0750]	
ERASE	PRINT

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SEF338QA



### HOW TO ERASE DTC [With Generic Scan Tool (GST)]

Select Mode 4 with Generic Scan Tool. For details, refer to EC section, "Generic Scan Tool (GST)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION".







### HOW TO ERASE DTC (No Tools)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (No Tools)" on AT-42. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. Refer to EC section ["HOW TO SWITCH DIAGNOSTIC TEST MODES", "Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### VEHICLE SPEED SENSOR·A/T (REVOLUTION SENSOR) CIRCUIT CHECK



#### Description

The revolution sensor detects the revolution of the out put shaft parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the A/T control unit which converts it into vehicle speed.

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: VHCL SPEED SEN·A/T : P0720 : 1st judgement flicker	A/T control unit does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Revolution sensor</li> </ul>

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.  
 2) Select "SELF-DIAG RESULTS" mode with CONSULT.  
 3) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.

OR


- 1) Start engine.  
 2) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.  
 3) Select "MODE 3" with GST.

OR

- 1) Start engine.  
 2) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 30 km/h (19 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 5 seconds.  
 3) Perform self-diagnosis.  
 Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



### CHECK REVOLUTION SENSOR.

Refer to "Electrical Components Inspection", AT-103.

NG

Repair or replace revolution sensor.

OK

**A**

### CHECK INPUT SIGNAL.



1. Start engine.
2. Select "ECU INPUT SIGNALS" in Data Monitor.
3. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed.

NG

Check the following items:

- Harness for short or open between A/T control unit and revolution sensor (Main harness)
- Harness for short or open between revolution sensor and ECM (Main harness)
- Ground circuit for ECM Refer to EC section ("TROUBLE DIAGNOSIS FOR POWER SUPPLY").

OR



1. Start engine.
2. Check voltage between A/T control unit terminal (25) and ground while driving. (Measure in AC range.)

#### Voltage:

At 0 km/h (0 MPH):

0V

At 30 km/h (19 MPH):

1V or more

(Voltage rises gradually in response to vehicle speed.)

OK

Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-47.

NG

1. Perform A/T control unit input/output signal inspection.

2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK


INSPECTION END

**A**

☆ MONITOR	☆ NO FAIL	
VHCL/S SE-A/T	0km/h	
VHCL/S SE-MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
OVERDRIVE SW	O N	
P/N POSI SW	O N	
R POSITION SW	OFF	

RECORD

SAT076H








# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### VEHICLE SPEED SENSOR-MTR CIRCUIT CHECK

#### Description

The vehicle speed sensor-MTR is built into the speedometer assembly. The sensor functions as an auxiliary device to the revolution sensor when it is malfunctioning. The A/T control unit will then use a signal sent from the vehicle speed sensor-MTR.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: VHCL SPEED SEN-MTR	A/T control unit does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or short.)</li> <li>• Vehicle speed sensor</li> </ul>
: 2nd judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode with CONSULT.
- 3) Drive vehicle under the following conditions:  
Selector lever in D and vehicle speed higher than 20 km/h (12 MPH).

OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D and vehicle speed higher than 20 km/h (12 MPH).
- 3) Perform self-diagnosis.  
Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

### CHECK INPUT SIGNAL.

1. Start engine.
2. Select "ECU INPUT SIGNALS" in Data Monitor.
3. Read out the value of "VHCL/S SE-MTR" while driving. Check the value changes according to driving speed.

OR

1. Start engine.
2. Check voltage between A/T control unit terminal (27) and ground.
3. Jack up vehicle. Turn ignition switch to "ON" with selector lever in "N" position, then rotate one of the rear tires. (Measure in DC range.)


### Voltage:

**Varies between less than 1V and more than 4.5V**

NG

Check the following items:

- Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL section ("METERS AND GAUGES").
- Harness for short or open between A/T control unit and vehicle speed sensor (Main harness)



OK


Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-49.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

**INSPECTION END**







# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### THROTTLE POSITION SENSOR CIRCUIT CHECK

#### Description

The throttle position sensor detects the throttle valve position and sends a signal to the A/T control unit.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
<ul style="list-style-type: none"> <li> : THROTTLE POSI- TION SEN</li> <li> : P1705</li> <li> : 3rd judgement flicker</li> </ul>	A/T control unit receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Throttle position sensor</li> </ul>

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode with CONSULT.
- 3) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.

OR


- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.
- 3) Select "MODE 3" with GST.

OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 3 seconds.
- 3) Perform self-diagnosis.  
Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)




**A**

☆MONITOR	☆NO FAIL	
VHCL/S SE-A/T	0km/h	
VHCL/S SE-MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
OVERDRIVE SW	O N	
P/N POSI SW	O N	
R POSITION SW	OFF	

RECORD

SAT076H



Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

NG → Check throttle position sensor circuit for engine control. Refer to EC section ["Throttle Position Sensor (DTC : 0403)", "TROUBLE DIAGNOSIS FOR DTC P0120"].

**A**

**CHECK INPUT SIGNAL.**

1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Select "ECU INPUT SIGNALS" in Data Monitor.
3. Read out the value of "THRTL POS SEN".

**Voltage:**  
**Fully-closed throttle:**  
 Approximately 0.5V  
**Fully-open throttle:**  
 Approximately 4V

NG → Check harness for short or open between ECM and A/T control unit regarding throttle position sensor circuit. (Main harness)

OR

1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Check voltage between A/T control unit terminals (34) and (35) while accelerator pedal is depressed slowly.

**Voltage:**  
**Fully-closed throttle valve:**  
 Approximately 0.5V  
**Fully-open throttle valve:**  
 Approximately 4V  
 (Voltage rises gradually in response to throttle position)

**CHECK THROTTLE POSITION SWITCH.** Refer to "Self-diagnosis", "CHECK THROTTLE POSITION SWITCH CIRCUIT", AT-68.

NG → Repair or replace damaged parts.

Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-51.





NG → 1. Perform A/T control unit input/output signal inspection.  
 2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

**INSPECTION END**

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### SHIFT SOLENOID VALVE A CIRCUIT CHECK



#### Description

Shift solenoid valves A and B are turned ON or OFF by the A/T control unit in response to signals sent from the inhibitor switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
SHIFT SOLENOID/V-A	A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> <li>Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>Shift solenoid valve A</li> </ul>
P0750		
4th judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.  
 2) Select "SELF-DIAG RESULTS" mode with CONSULT.  
 3) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> position.
- OR


- 1) Start engine.  
 2) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> position.  
 3) Select "MODE 3" with GST.
- OR

- 1) Start engine.  
 2) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> position.  
 3) Perform self-diagnosis.  
 Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

**CHECK GROUND CIRCUIT.**


1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑥ and ground.

**Resistance: 20 - 40Ω**

NG

1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check the following items:
  - Shift solenoid valve A (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

OK



**B**

**CHECK POWER SOURCE CIRCUIT.**

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between terminal ⑥ and A/T control unit harness connector terminal ⑥.


**Resistance: Approximately 0Ω**

4. Reinstall any part removed.

NG

Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

OK



Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-53.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.





OK

**INSPECTION END**

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### SHIFT SOLENOID VALVE B CIRCUIT CHECK



#### Description

Shift solenoid valves A and B are turned ON or OFF by the A/T control unit in response to signals sent from the inhibitor switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

Gear position	1	2	3	4
Shift solenoid valve A	ON	OFF	OFF	ON
Shift solenoid valve B	ON	ON	OFF	OFF

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
CONSULT : SHIFT SOLENOID/V-B	A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Shift solenoid valve B</li> </ul>
CONSULT : P0755		
NO TOOLS : 5th judgement flicker		


#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- |  |    |  |
|--|----|--|
| <p>CONSULT</p> <ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Select "SELF-DIAG RESULTS" mode with CONSULT.</li> <li>3) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> position.</li> </ol> | OR | <p>CONSULT</p> <ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> position.</li> <li>3) Select "MODE 3" with GST.</li> </ol> |
| OR   |    |  |
| <p>NO TOOLS</p> <ol style="list-style-type: none"> <li>1) Start engine.</li> <li>2) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> position.</li> <li>3) Perform self-diagnosis.</li> </ol>                      |    | <p>Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.</p>   |

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

**CHECK GROUND CIRCUIT.**


1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑦ and ground.

**Resistance: 20 - 40Ω**

NG

1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check the following items:
  - Shift solenoid valve B (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

OK



**B**

**CHECK POWER SOURCE CIRCUIT.**

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between terminal ⑦ and A/T control unit harness connector terminal ⑦.


**Resistance: Approximately 0Ω**

4. Reinstall any part removed.

NG

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

OK



Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-55.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

**INSPECTION END**







# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### OVERRUN CLUTCH SOLENOID VALVE CIRCUIT CHECK

#### Description

The overrun clutch solenoid valve is activated by the A/T control unit in response to signals sent from the inhibitor switch, vehicle speed and throttle position sensors. The overrun clutch operation will then be controlled.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: OVERRUN CLUTCH S/V	A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Overrun clutch solenoid valve</li> </ul>
: P1760		
: 6th judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode with CONSULT.
- 3) Drive vehicle under the following conditions: Selector lever in D position and vehicle speed higher than 10 km/h (6 MPH).

OR


- 1) Start engine.
- 2) Drive vehicle under the following conditions: Selector lever in D position and vehicle speed higher than 10 km/h (6 MPH).
- 3) Select "MODE 3" with GST.

OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions: Selector lever in D position and vehicle speed higher than 10 km/h (6 MPH).
- 3) Perform self-diagnosis. Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

### CHECK GROUND CIRCUIT.


1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑧ and ground.

**Resistance: 20 - 40Ω**

NG

1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check the following items:
  - Overrun clutch solenoid valve. (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

OK



**B**

### CHECK POWER SOURCE CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between terminal ⑧ and A/T control unit harness connector terminal ⑧.

**Resistance:**


**Approximately 0Ω**

4. Reinstall any part removed.

NG

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

OK



Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-57.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK


**INSPECTION END**

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### TORQUE CONVERTER CLUTCH SOLENOID VALVE CIRCUIT CHECK


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



#### Description

The torque converter clutch solenoid valve is activated, with the gear in D<sub>4</sub>, by the A/T control unit in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled.

Lock-up operation, however, is prohibited when ATF temperature is too low.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: T/C CLUTCH SOL/V	A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• T/C clutch solenoid valve</li> </ul>
: P0740		
: 7th judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.



- 1) Start engine.  
2) Select "SELF-DIAG RESULTS" mode with CONSULT.  
3) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up position.

OR

- 1) Start engine.  
2) Select "MODE 3" with GST.  
3) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up position.


OR

- 1) Start engine.  
2) Perform self-diagnosis. Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.  
3) Drive vehicle in D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up position.



# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

### CHECK GROUND CIRCUIT.


1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ⑤ and ground.

**Resistance: 10 - 20Ω**

NG

1. Remove oil pan. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check the following items:
  - Torque converter clutch solenoid valve (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

OK



**B**

### CHECK POWER SOURCE CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between terminal ⑤ and A/T control unit harness connector terminal ⑤.


**Resistance:**

**Approximately 0Ω**

NG

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

OK



Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-59.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

**INSPECTION END**





# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS

#### Description

The fluid temperature sensor detects the ATF temperature and sends a signal to the A/T control unit.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: BATT/FLUID TEMP SEN	A/T control unit receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> <li>• Harness or connectors (The sensor circuit is open or shorted.)</li> <li>• Fluid temperature sensor</li> </ul>
: P0710		
: 8th judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.  
 2) Select "SELF-DIAG RESULTS" mode with CONSULT.  
 3) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.

OR

- 1) Start engine.  
 2) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.  
 3) Select "MODE 3" with GST.


OR

- 1) Start engine.  
 2) Drive vehicle under the following conditions:  
 Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full open position, engine speed higher than 450 rpm and driving for more than 10 minutes.  
 3) Perform self-diagnosis.  
 Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

### CHECK A/T CONTROL UNIT POWER SOURCE.


1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Check voltage between A/T control unit terminals (4), (9) and ground. **Battery voltage should exist.**

NG

Check the following items:

- Harness for short or open between ignition switch and A/T control unit (Main harness)
- Ignition switch and fuse  
Refer to EL section ("POWER SUPPLY ROUTING").

OK



**B**

### CHECK FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY.

1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminals (33) and (35) when A/T is cold.

NG

1. Remove oil pan.
2. Check the following items:
  - Fluid temperature sensor (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

**Resistance:**


**Cold [20°C (68°F)]**

**Approximately 2.5 kΩ**

4. Reinstall any part removed.

OK

(A)



# TROUBLE DIAGNOSES



## Self-diagnosis (Cont'd)

**C**

☆ MONITOR	☆ NO FAIL	
VHCL/S SE-A/T	0km/h	
VHCL/S SE-MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
OVERDRIVE SW	O N	
P/N POSI SW	O N	
R POSITION SW	OFF	

RECORD

SAT076H



GI

MA

EM

IC

EC

FE

CL

MT

AT

TF

FD

FA

RA

BR

ST

RS

BT

HA

EL




DX




# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd) ENGINE SPEED SIGNAL CIRCUIT CHECK

### Description

The engine speed signal is sent from the ECM to the A/T control unit.

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
 : ENGINE SPEED SIG  : P0725  : 9th judgement flicker	A/T control unit does not receive the proper voltage signal from ECM.	<ul style="list-style-type: none"> <li>Harness or connectors (The signal circuit is open or shorted.)</li> </ul>



### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode with CONSULT.
- 3) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.

OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.
- 3) Select "MODE 3" with GST.


OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/8 of the full throttle position and driving for more than 10 seconds.
- 3) Perform self-diagnosis.  
Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.



# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)




**A**

☆ MONITOR	☆ NO FAIL	
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
OVERDRIVE SW	O N	
P/N POSI SW	O N	
R POSITION SW	OFF	

RECORD

SAT076H



Perform diagnostic test mode II (self-diagnostic results) for engine control. Check ignition signal circuit condition.

NG

Check ignition signal circuit for engine control. Refer to EC section ["Ignition Signal (DTC: 0201)", TROUBLE DIAGNOSIS FOR DTC P1320"].

OK

**A**

### CHECK INPUT SIGNAL.



1. Start engine.
2. Select "ECU INPUT SIGNALS" in Data Monitor.
3. Read out the value of "ENGINE SPEED".  
Check engine speed changes according to throttle position.

OR



1. Start engine.
2. Check voltage between A/T control unit terminal (24) and ground.  
**Voltage: Approximately 1.3 - 6V**

NG

Check the following items:

- Harness for short or open between A/T control unit and ignition coil.
- Resistor
- Ignition coil

Refer to EC section ["Ignition Signal (DTC: 0201)", "TROUBLE DIAGNOSIS FOR DTC P1320"].

OK

Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-64.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

INSPECTION END

GI

MA

EM

LC

EC

FE

CL

MF

**AT**

TF

PD

EA

RA

BR

ST

RS

BT

HA

EL

IDX





# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### LINE PRESSURE SOLENOID VALVE CIRCUIT CHECK

#### Description

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the A/T control unit.



Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: LINE PRESSURE S/V	A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> <li>• Harness or connectors (The solenoid circuit is open or shorted.)</li> <li>• Line pressure solenoid valve</li> </ul>
: P0745		
: 10th judgement flicker		

#### Diagnostic Trouble Code (DTC) confirmation procedure

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine.  
2) Select "SELF-DIAG RESULTS" mode with CONSULT.  
3) With brake pedal depressed, shift the lever from P → N → D → N → P.

OR




- 1) Start engine.  
2) With brake pedal depressed, shift the lever from P → N → D → N → P.  
3) Select "MODE 3" with GST.

OR

- 1) Start engine.  
2) With brake pedal depressed, shift the lever from P → N → D → N → P.  
3) Perform self-diagnosis.  
Refer to SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-42.

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

**CHECK GROUND CIRCUIT.**

1. Turn ignition switch to "OFF" position.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ① and ground.

**Resistance: 2.5 - 5Ω**

NG

1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check the following items:
  - Line pressure solenoid valve (Refer to "Electrical Components Inspection", AT-101.)
  - Harness of terminal cord assembly for short or open

OK

**B**

**CHECK POWER SOURCE CIRCUIT.**

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between terminal ① and A/T control unit harness connector terminal ②.

**Resistance: 11.2 - 12.8Ω**

NG

Check the following items:

- Dropping resistor (Refer to "Electrical Components Inspection", AT-103.)
- Harness for short or open between A/T control unit terminal ② and terminal cord assembly (Main harness)

OK

**C**

**CHECK POWER SOURCE CIRCUIT.**

1. Turn ignition switch to "OFF" position.
2. Check resistance between terminal ① and A/T control unit harness connector terminal ①.

**Resistance: Approximately 0Ω**

3. Reinstall any part removed.

NG

Repair or replace harness between A/T control unit terminal ① and terminal cord assembly.

OK

Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-66.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

**INSPECTION END**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### INHIBITOR, OVERDRIVE CONTROL AND THROTTLE POSITION SWITCH CIRCUIT CHECKS

#### Parts description

- Inhibitor switch  
Detects the selector lever position and sends a signal to the A/T control unit.
- Overdrive control switch  
Detects the overdrive control switch position (ON or OFF) and sends a signal to the A/T control unit.
- Throttle position switch  
Consists of a wide-open throttle position switch and a closed throttle position switch.  
The wide-open position switch sends a signal to the A/T control unit when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the A/T control unit when the throttle valve is fully closed.

#### Overall function check

After the repair, perform the following procedure to confirm the malfunction is eliminated.






- 1) Start engine.
- 2) Select "SELF-DIAG RESULTS" mode for ECM with CONSULT.
- 3) Drive vehicle under the following conditions:  
Selector lever in D, OD control switch in "OFF" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 5 seconds.

OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, OD control switch in "OFF" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 5 seconds.
- 3) Select "MODE 3" with GST.


OR

- 1) Start engine.
- 2) Drive vehicle under the following conditions:  
Selector lever in D, OD control switch in "OFF" position, vehicle speed higher than 10 km/h (6 MPH), throttle opening greater than 1/2 of the full throttle position and driving for more than 5 seconds.
- 3) Perform self-diagnosis for ECM.  
Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].



# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)




**A**

☆ MONITOR	☆ NO FAIL	
R POSITION SW	OFF	
D POSITION SW	OFF	
4 POSITION SW	OFF	
3 POSITION SW	OFF	
2 POSITION SW	OFF	
1 POSITION SW	OFF	
ASCD•CRUISE	OFF	
ASCD•OD CUT	OFF	
KICKDOWN SW	OFF	

**RECORD**

SAT118G



**A**

### CHECK INHIBITOR SWITCH CIRCUIT.

- 1.** Turn ignition switch to "ON" position. (Do not start engine.)
- 2.** Select "ECU INPUT SIGNALS" in Data Monitor.
- 3.** Read out "R, N, D, 1 & 2 position switches" moving selector lever to each position. Check the signal of the selector lever position is indicated properly.

NG

- Check the following items:
- Inhibitor switch (Refer to "Electrical Components Inspection", AT-102.)
  - Harness for short or open between ignition switch and inhibitor switch (Main harness)
  - Harness for short or open between inhibitor switch and A/T control unit (Main harness)

OR

- 1.** Turn ignition switch to "ON" position. (Do not start engine.)
- 2.** Check voltage between A/T control unit terminals (16), (17), (18), (19), (20) and ground while moving selector lever through each position.

#### Voltage:

**B: Battery voltage**  
**0: 0V**

Lever position	Terminal No.				
	(19)	(20)	(18)	(17)	(16)
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

OK

**A**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES


## Self-diagnosis (Cont'd)

**B**

☆MONITOR	☆NO FAIL	
VHCL/S SE•A/T	0km/h	
VHCL/S SE•MTR	5km/h	
THRTL POS SEN	0.4V	
FLUID TEMP SE	1.2V	
BATTERY VOLT	13.4V	
ENGINE SPEED	1024rpm	
OVERDRIVE SW	O N	
P/N POSI SW	O N	
R POSITION SW	OFF	

**RECORD**

SAT076H



A

**B**

**CHECK OVERDRIVE CONTROL SWITCH CIRCUIT.**

1. Turn ignition switch to "ON" position.  
(Do not start engine.)

2. Select "ECU INPUT SIGNALS" in Data Monitor.

3. Read out "OVERDRIVE SWITCH".  
Check the signal of the overdrive control switch is indicated properly.  
(Overdrive control switch "ON" displayed on CONSULT means overdrive "OFF".)

OR

1. Turn ignition switch to "ON" position.  
(Do not start engine.)

2. Check voltage between A/T control unit terminal 39 and ground when overdrive control switch is "ON" and "OFF".

Switch position	Voltage
ON	Battery voltage
OFF	1V or less

NG

Check the following items.

- Overdrive control switch  
Refer to "Electrical Components Inspection", AT-102.
- Harness for short or open between A/T control unit and overdrive control switch (Main harness)
- Harness for short or open of ground circuit for overdrive control switch (Main harness)


OK

B

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

**C**





☆ MONITOR	☆ NO FAIL
POWERSHIFT SW	OFF
CLOSED THL/SW	ON
W/O THRL/P-SW	OFF
HOLD SW	OFF

**RECORD**

SAT0521

**C**

A/T control unit terminal

C/UNIT 14 21 CONNECTOR

OR/W OR/B

V

SAT964HG

**B**

**C**

**CHECK THROTTLE POSITION SWITCH CIRCUIT.**

- Turn ignition switch to "ON" position. (Do not start engine.)
- Select "ECU INPUT SIGNALS" in Data Monitor.
- Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly.

Accelerator pedal condition	Data monitor	
	CLOSED THL/SW	W/O THRL/P-SW
Released	ON	OFF
Fully depressed	OFF	ON

OR

- Turn ignition switch to "ON" position. (Do not start engine.)
- Check voltage between A/T control unit terminals (14), (21) and ground while depressing, and releasing accelerator pedal slowly. (after warming up engine)

Accelerator pedal condition	Voltage	
	Terminal No. (14)	Terminal No. (21)
Released	Battery voltage	1V or less
Fully depressed	1V or less	Battery voltage

Check the following items:

- Throttle position switch Refer to "Electrical Components Inspection", AT-103.
- Harness for short or open between ignition switch and throttle position switch (Main harness)
- Harness for short or open between throttle position switch and A/T control unit (Main harness)

Perform self-diagnosis again after driving for a while.

**INSPECTION END**

1. Perform A/T control unit input/output signal inspection.  
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES


## Self-diagnosis (Cont'd) IMPROPER SHIFTING TO 1ST GEAR POSITION

### Description


- This is one of the items indicated by the MIL.
- This malfunction will not be detected while the OD OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into first gear position as instructed by the A/T control unit. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

### Overall function check


After the repair, perform the following procedure to confirm the malfunction is eliminated.






-  1) Start engine and warm up ATF.  
2) Select "SELF-DIAG RESULTS" mode for ECM with CONSULT.  
3) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.

OR

-  1) Start engine and warm up ATF.  
2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.  
3) Select "MODE 3" with GST.

OR



-  1) Start engine and warm up ATF.  
2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.  
3) Perform self-diagnosis for ECM.  
Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].





# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



**A**

**CHECK SHIFT SOLENOID VALVE.**

1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.
2. Check shift solenoid valve operation.
  - Shift solenoid valve A
  - Shift solenoid valve B
 Refer to "Electrical Components Inspection", AT-101.

NG → Repair or replace shift solenoid valve assembly.

OK ↓

**B**

**CHECK CONTROL VALVE.**

1. Disassemble control valve assembly. Refer to "Control Valve Assembly", "REPAIR FOR COMPONENT PARTS", AT-145.
2. Check to ensure that:
  - Valve, sleeve and plug slide along valve bore under their own weight.
  - Valve, sleeve and plug are free from burrs, dents and scratches.
  - Control valve springs are free from damage, deformation and fatigue.
  - Hydraulic line is free from obstacles.

NG → Repair control valve assembly.

OK ↓

Perform Overall function check, AT-72.

NG → Check control valve again. Repair or replace control valve assembly.

OK ↓

**INSPECTION END**

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### IMPROPER SHIFTING TO 2ND GEAR POSITION

#### Description

- This is one of the items indicated by the MIL.
- This malfunction will not be detected while the OD OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into second gear position as instructed by the A/T control unit. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

#### Overall function check

After the repair, perform the following procedure to confirm the malfunction is eliminated.






- 1) Start engine and warm up ATF.
- 2) Select "SELF-DIAG RESULTS" mode for ECM with CONSULT.
- 3) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of  $D_1 \rightarrow D_2 \rightarrow D_3 \rightarrow D_4$ , in accordance with shift schedule. Refer to shift schedule, AT-33.

OR

- 1) Start engine and warm up ATF.
- 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of  $D_1 \rightarrow D_2 \rightarrow D_3 \rightarrow D_4$ , in accordance with shift schedule. Refer to shift schedule, AT-33.
- 3) Select "MODE 3" with GST.




OR

- 1) Start engine and warm up ATF.
- 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of  $D_1 \rightarrow D_2 \rightarrow D_3 \rightarrow D_4$ , in accordance with shift schedule. Refer to shift schedule, AT-33.
- 3) Perform self-diagnosis for ECM. Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].



# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
OL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
DX

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)


### IMPROPER SHIFTING TO 3RD GEAR POSITION

#### Description


- This is one of the items indicated by the MIL.
- This malfunction will not be detected while the OD OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into third gear position as instructed by the A/T control unit. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning servo piston or brake band, etc.

#### Overall function check


After the repair, perform the following procedure to confirm the malfunction is eliminated.






-  1) Start engine and warm up ATF.  
 2) Select "SELF-DIAG RESULTS" mode for ECM with CONSULT.  
 3) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.

OR

-  1) Start engine and warm up ATF.  
 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.  
 3) Select "MODE 3" with GST.




OR

-  1) Start engine and warm up ATF.  
 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub>, in accordance with shift schedule. Refer to shift schedule, AT-33.  
 3) Perform self-diagnosis for ECM.  
 Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].








# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES



## Self-diagnosis (Cont'd)

### IMPROPER SHIFTING TO 4TH GEAR POSITION OR IMPROPER TORQUE CONVERTER CLUTCH OPERATION

#### Description

- This is one of the items indicated by the MIL.
- This malfunction will not be detected while the OD OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the A/T control unit. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

#### Overall function check

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- 1) Start engine and warm up ATF.
- 2) Select "SELF-DIAG RESULTS" mode for ECM with CONSULT.
- 3) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up, in accordance with shift schedule. Refer to shift schedule, AT-33.

OR


- 1) Start engine and warm up ATF.
- 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up, in accordance with shift schedule. Refer to shift schedule, AT-33.
- 3) Select "MODE 3" with GST.

OR

- 1) Start engine and warm up ATF.
- 2) Start vehicle with selector lever in D and throttle opening halfway. Check that vehicle runs through gear shift of D<sub>1</sub> → D<sub>2</sub> → D<sub>3</sub> → D<sub>4</sub> → D<sub>4</sub> lock-up, in accordance with shift schedule. Refer to shift schedule, AT-33.
- 3) Perform self-diagnosis for ECM.
- Refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)




During "Cruise test - Part 1" (AT-29), does A/T shift from D<sub>3</sub> to D<sub>4</sub> at the specified speed?

Yes → Go to **(B)** and check for proper lock-up.

No  
Perform pressure test. Refer to AT-107.

NG → Go to **(A)**.

OK →



**A**  
**CHECK SOLENOID VALVES.**  
1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-119.  
2. Check solenoid valve assembly operation. Refer to AT-101.

NG → Replace solenoid valve assembly.


OK →

**B**  
**CHECK CONTROL VALVE.**  
1. Disassemble control valve assembly. Refer to AT-145.  
2. Check to ensure that:

- Valve, sleeve and plug slide along valve bore under their own weight.
- Valve, sleeve and plug are free from burrs, dents and scratches.
- Control valve springs are free from damage, deformation and fatigue.
- Hydraulic line is free from obstacles.

NG → Repair control valve.

OK →



Does A/T shift from D<sub>3</sub> to D<sub>4</sub> at the specified speed?

NG → Check control valve again. Repair or replace control valve assembly.

OK →

Perform Overall function check procedure (AT-78).

NG → Go to **(B)** and check for proper lock-up.




OK →

**INSPECTION END**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES





## Self-diagnosis (Cont'd)





# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 1

### SYMPTOM:

OD OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".



**A**

### CHECK A/T CONTROL UNIT POWER SOURCE.

1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Check voltage between A/T control unit terminals ④, ⑨ and ground. **Battery voltage should exist.**

NG

Check the following items:

- Harness for short or open between ignition switch and A/T control unit (Main harness)
- Ignition switch and fuse Refer to EL section ("POWER SUPPLY ROUTING").

OK

**B**

### CHECK A/T CONTROL UNIT GROUND CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Disconnect A/T control unit harness connector.
3. Check resistance between A/T control unit terminals ⑮, ④⑧ and ground. **Resistance: Approximately 0Ω**

NG

Check harness for short or open between A/T control unit and ground.

OK

**C**

### CHECK LAMP CIRCUIT.

1. Turn ignition switch to "OFF" position.
2. Check resistance between A/T control unit terminals ③ and ④. **Resistance: 50 - 100Ω**
3. Reinstall any part removed.

NG

Check the following items:

- OD OFF indicator lamp Refer to EL section.
- Harness for short or open between ignition switch and OD OFF indicator lamp (Main harness)
- Harness for short or open between OD OFF indicator lamp and A/T control unit

OK


Check again.

NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK




INSPECTION END



## Diagnostic Procedure 2

### SYMPTOM:


- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D", "2", "1" or "R" position.







## Diagnostic Procedure 3

### SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in "P" position.










## Diagnostic Procedure 4

### SYMPTOM:

Vehicle moves forward or backward when selecting "N" position.






## Diagnostic Procedure 5

### SYMPTOM:

There is large shock when changing from "N" to "R" position.









GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## Diagnostic Procedure 6

### SYMPTOM:

Vehicle does not creep backward when selecting "R" position.









## Diagnostic Procedure 7

### SYMPTOM:

Vehicle does not creep forward when selecting "D", "2" or "1" position.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA






EL

DX

## Diagnostic Procedure 8

### SYMPTOM:

Vehicle cannot be started from **D<sub>1</sub>** on Cruise test — Part 1.













GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 WT  
**AT**  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

## Diagnostic Procedure 9

### SYMPTOM:

**A/T does not shift from D<sub>1</sub> to D<sub>2</sub> at the specified speed.**  
**A/T does not shift from D<sub>4</sub> to D<sub>2</sub> when depressing accelerator pedal fully at the specified speed.**









## Diagnostic Procedure 10

### SYMPTOM:

**A/T does not shift from D<sub>2</sub> to D<sub>3</sub> at the specified speed.**






## Diagnostic Procedure 11

### SYMPTOM:

- A/T does not shift from D<sub>3</sub> to D<sub>4</sub> at the specified speed.
- A/T must be warm before D<sub>3</sub> to D<sub>4</sub> shift will occur.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 12

**SYMPTOM:**

**A/T does not perform lock-up at the specified speed.**



**A**

Does self-diagnosis show damage to torque converter clutch solenoid valve circuit after cruise test?

Yes

Check torque converter clutch solenoid valve circuit. Refer to "Self-diagnosis", AT-59.

No

**B**

Check throttle position sensor. Refer to EC section ["Throttle Position Sensor (DTC: 0403)", "TROUBLE DIAGNOSIS FOR DTC P0120"].

NG

Repair or replace throttle position sensor.

OK

1. Remove control valve. Refer to "ON-VEHICLE SERVICE", AT-119.

2. Check following items:

- Torque converter clutch control valve
- Torque converter relief valve
- Torque converter clutch solenoid valve
- Pilot valve
- Pilot filter

NG

Repair or replace damaged parts.

OK

Check again.



NG

1. Perform A/T control unit input/output signal inspection.
2. If NG, recheck A/T control unit pin terminals for damage or loose connection with harness connector.

OK

**INSPECTION END**



# TROUBLE DIAGNOSES



## Diagnostic Procedure 13

### SYMPTOM:


A/T does not hold lock-up condition for more than 30 seconds.



## Diagnostic Procedure 14

### SYMPTOM:





Lock-up is not released when accelerator pedal is released.




## Diagnostic Procedure 15

### SYMPTOM:

- Engine speed does not smoothly return to idle when A/T shifts from D<sub>4</sub> to D<sub>3</sub>.
- Vehicle does not decelerate by engine brake when turning overdrive control switch OFF.
- Vehicle does not decelerate by engine brake when shifting A/T from "D" to "2" position.







### Diagnostic Procedure 16

**SYMPTOM:**

Vehicle does not start from D<sub>1</sub> on Cruise test — Part 2.




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT



### Diagnostic Procedure 17


**SYMPTOM:**

A/T does not shift from D<sub>4</sub> to D<sub>3</sub> when changing overdrive control switch to "OFF" position.



AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



# TROUBLE DIAGNOSES



## Diagnostic Procedure 18

### SYMPTOM:



A/T does not shift from  $D_3$  to  $2_2$  when changing selector lever from "D" to "2" position.



## Diagnostic Procedure 19

### SYMPTOM:


A/T does not shift from  $2_2$  to  $1_1$  when changing selector lever from "2" to "1" position.



## Diagnostic Procedure 20


### SYMPTOM:

Vehicle does not decelerate by engine brake when shifting from  $2_2$  ( $1_2$ ) to  $1_1$ .





# TROUBLE DIAGNOSES




## Electrical Components Inspection

### INSPECTION OF A/T CONTROL UNIT

- Measure voltage between each terminal and terminal ⑮ or ④⑧ by following "A/T CONTROL UNIT INSPECTION TABLE".
- Pin connector terminal layout

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT



SAT2071

## A/T CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	Line pressure solenoid valve	When releasing accelerator pedal after warming up engine.	1.5 - 2.5V
		When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	Line pressure solenoid valve (with dropping resistor)	When releasing accelerator pedal after warming up engine.	5 - 14V
		When depressing accelerator pedal fully after warming up engine.	0.5V or less
3	OD OFF indicator lamp	When setting overdrive control switch in "OFF" position.	1V or less
		When setting overdrive control switch in "ON" position.	Battery voltage
4	Power source	When turning ignition switch to "ON".	Battery voltage
		When turning ignition switch to "OFF".	1V or less

TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT

HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Electrical Components Inspection (Cont'd)










Terminal No.	Item	Condition	Judgement standard
5	Torque converter clutch solenoid valve	When A/T performs lock-up.	8 - 15V
		When A/T does not perform lock-up.	1V or less
6	Shift solenoid valve A	When shift solenoid valve A operates. (When driving in "D <sub>1</sub> " or "D <sub>4</sub> ".)	Battery voltage
		When shift solenoid valve A does not operate. (When driving in "D <sub>2</sub> " or "D <sub>3</sub> ".)	1V or less
7	Shift solenoid valve B	When shift solenoid valve B operates. (When driving in "D <sub>1</sub> " or "D <sub>2</sub> ".)	Battery voltage
		When shift solenoid valve B does not operate. (When driving in "D <sub>3</sub> " or "D <sub>4</sub> ".)	1V or less
8	Overrun clutch solenoid valve	When overrun clutch solenoid valve operates. (When driving in "D <sub>3</sub> " or "D <sub>4</sub> ".)	Battery voltage
		When overrun clutch solenoid valve does not operate. (When driving in "1" or "2".)	1V or less
9	Power source	Same as No. 4	
10*	DT1	—	—
11*	DT2	—	—
12*	DT3	—	—
13	—	—	—
14	Closed throttle position switch (in throttle position switch)	When releasing accelerator pedal after warming up engine.	Battery voltage
		When depressing accelerator pedal after warming up engine.	1V or less
15	Ground	—	—
16	Inhibitor "1" position switch	When setting selector lever to "1" position.	Battery voltage
		When setting selector lever to other positions.	1V or less
17	Inhibitor "2" position switch	When setting selector lever to "2" position.	Battery voltage
		When setting selector lever to other positions.	1V or less
18	Inhibitor "D" position switch	When setting selector lever to "D" position.	Battery voltage
		When setting selector lever to other positions.	1V or less



\*: These terminals are connected to the ECM (ECCS control module).

# TROUBLE DIAGNOSES











## Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard		
19	Inhibitor "N" or "P" position switch		When setting selector lever to "N" or "P" position.	Battery voltage	GI
			When setting selector lever to other positions.	1V or less	MA
20	Inhibitor "R" position switch		When setting selector lever to "R" position.	Battery voltage	EM
			When setting selector lever to other positions.	1V or less	LC
21	Wide open throttle position switch (in throttle position switch)		When depressing accelerator pedal more than half-way after warming up engine.	Battery voltage	EC
			When releasing accelerator pedal after warming up engine.	1V or less	FE
22	—	—	—	—	—
23	Power source (Back-up)		When turning ignition switch to "OFF".	Battery voltage	CL
			When turning ignition switch to "ON".	Battery voltage	MT
24	Engine speed signal		When engine runs at idle speed.	Approximately 1.3V	AT
			When engine runs at 4,000 rpm.	Approximately 6V	
25	Revolution sensor (Measure in AC range)		When vehicle cruises at 30 km/h (19 MPH).	1V or more Voltage rises gradually in response to vehicle speed.	TF
			When vehicle parks.	0V	PD
26	—	—	—	—	—
27	Vehicle speed sensor (Measure in DC range)		Jack up vehicle. Turn ignition switch to "ON" with selector lever in "N" position, then rotate one of the rear tires.	Voltage varies between less than 1V and more than 4.5V.	FA RA
28*	—	—	—	—	RS
29*	—		—	—	BT
30*	—	—	—	—	HA
31	Throttle position sensor (Power source)		—	4.5 - 5.5V	EL
32	—	—	—	—	IDX

\*: These terminals are connected to the Data link connector for CONSULT.

## TROUBLE DIAGNOSES

### Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
33	Fluid temperature sensor		When ATF temperature is 20°C (68°F).	Approximately 1.56V
			When ATF temperature is 80°C (176°F).	Approximately 0.45V
34	Throttle position sensor		When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V
35	Throttle position sensor (Ground)	 	When engine runs at idle speed.	Approximately 0V
36	---	---	---	---
37	ASCD cruise signal		When ASCD cruise is being performed. ("CRUISE" light comes on.)	Battery voltage
			When ASCD cruise is not being performed. ("CRUISE" light does not come on.)	1V or less
38	---	---	---	---
39	Overdrive control switch	 	When setting overdrive control switch in "ON" position	Battery voltage
			When setting overdrive control switch in "OFF" position	1V or less
40	ASCD OD cut signal		When "ACCEL" set switch on ASCD cruise is released.	5 - 8V
			When "ACCEL" set switch on ASCD cruise is applied.	1V or less
41	---	---	---	---
42	---	---	---	---
43	---		---	---
44	---		---	---
45*	OBD-II (OUTPUT)	---	---	---
46	---		---	---
47	---		---	---
48	Ground		---	---

\* This terminal is connected to the ECM (ECCS control module).

# TROUBLE DIAGNOSES

## Electrical Components Inspection (Cont'd)




### SOLENOID VALVES

- For removal and installation, refer to "ON-VEHICLE SERVICE", AT-119.

#### Resistance check

- Check resistance between two terminals.

Solenoid valve	Terminal No.	Resistance (Approx.)
Shift solenoid valve A	③	20 - 40Ω
Shift solenoid valve B	②	
Overrun clutch solenoid valve	④	
Line pressure solenoid valve	⑥	2.5 - 5Ω
Torque converter clutch solenoid valve	⑦	10 - 16Ω



#### Operation check

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

### FLUID TEMPERATURE SENSOR

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between two terminals while changing temperature as shown at left.


Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

## TROUBLE DIAGNOSES

### Electrical Components Inspection (Cont'd) OVERDRIVE CONTROL SWITCH

- Check continuity between two terminals.




OD control switch position	Continuity
ON	No
OFF	Yes




### INHIBITOR SWITCH

1. Check continuity between terminals ① and ② and between terminals ③ and ④, ⑤, ⑥, ⑦, ⑧, ⑨ while moving manual shaft through each position.

Lever position	Terminal No.	
P	① — ②	③ — ④
R	③ — ⑤	
N	① — ②	③ — ⑥
D	③ — ⑦	
2	③ — ⑧	
1	③ — ⑨	



2. If NG, check again with manual control linkage disconnected from manual shaft of A/T assembly. Refer to step 1.
3. If OK on step 2, adjust manual control linkage. Refer to "ON-VEHICLE SERVICE", AT-121.



4. If NG on step 2, remove inhibitor switch from A/T and check continuity of inhibitor switch terminals. Refer to step 1.
5. If OK on step 4, adjust inhibitor switch. Refer to "ON-VEHICLE SERVICE", AT-121.
6. If NG on step 4, replace inhibitor switch.



# TROUBLE DIAGNOSES

## Electrical Components Inspection (Cont'd)

### REVOLUTION SENSOR


- For removal and installation, refer to "ON-VEHICLE SERVICE", AT-120.
- Check resistance between terminals ①, ② and ③.

Terminal No.		Resistance
①	②	500 - 650Ω
②	③	No continuity
①	③	No continuity



### DROPPING RESISTOR

- Check resistance between two terminals.  
**Resistance: 11.2 - 12.8Ω**




### THROTTLE POSITION SWITCH

#### Closed throttle position switch (idle position)

- Check continuity between terminals ② and ③.

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No


- To adjust closed throttle position switch, perform "Basic Inspection", "TROUBLE DIAGNOSIS — Basic Inspection" in EC section.



#### Wide open throttle position switch

- Check continuity between terminals ① and ③.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes



### Final Check

#### STALL TESTING


##### Stall test procedure

1. Check A/T and engine fluid levels. If necessary, add.
2. Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.


**ATF operating temperature:**  
50 - 80°C (122 - 176°F)

## TROUBLE DIAGNOSES

### Final Check (Cont'd)




3. Set parking brake and block wheels.
4. Install a tachometer where it can be seen by driver during test.
  - It is good practice to put a mark on point of specified engine rpm on indicator.



5. Start engine, apply foot brake, and place selector lever in "D" position.
6. Accelerate to wide-open throttle gradually while applying foot brake.
7. Quickly note the engine stall revolution and immediately release throttle.
  - During test, never hold throttle wide-open for more than 5 seconds.

Stall revolution:  
2,050 - 2,250 rpm



8. Move selector lever to "N" position.
9. Cool off ATF.
  - Run engine at idle for at least one minute.
10. Repeat steps 5 through 9 with selector lever in "2", "1" and "R" positions.



# TROUBLE DIAGNOSES

## Final Check (Cont'd)

### JUDGEMENT OF STALL TEST

The test result and possible damaged components relating to each result are shown in the illustration. In order to pinpoint the possible damaged components, follow the WORK FLOW shown in AT-13.

#### Note

#### Stall revolution is too high in "D" or "2" position:

- Slippage occurs in 1st gear but not in 2nd and 3rd gears. .... Low one-way clutch slippage
- Slippage occurs at the following gears:
  - 1st through 3rd gears in "D" position and engine brake functions.
  - 1st and 2nd gears in "2" position and engine brake functions with accelerator pedal released (fully closed throttle). .... Forward clutch or forward one-way clutch slippage

#### Stall revolution is too high in "R" position:

- Engine brake does not function in "1" position. .... Low & reverse brake slippage
- Engine brake functions in "1" position. .... Reverse clutch slippage

#### Stall revolution within specifications:

- Vehicle does not achieve speed of more than 80 km/h. .... One-way clutch seizure in torque converter housing

#### CAUTION:

#### Be careful since automatic fluid temperature increases abnormally.

- Slippage occurs in 3rd and 4th gears in "D" position. .... High clutch slippage
- Slippage occurs in 2nd and 4th gear in "D" position. .... Brake band slippage

#### Stall revolution less than specifications:

- Poor acceleration during starts. .... One-way clutch seizure in torque converter

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


# TROUBLE DIAGNOSES

## Final Check (Cont'd)

### Judgement of stall test

Selector lever position	Judgement		
D	L	O	H
2	L	O	H
1	L	O	O
R	L	H	H

- O : Stall revolution is normal.
- H : Stall revolution is higher than specified.
- L : Stall revolution is lower than specified.



D	H	H	H	O
2	H	H	H	O
1	O	H	H	O
R	O	O	H	O
Selector lever position	Judgement			

# TROUBLE DIAGNOSES

## Final Check (Cont'd)

### PRESSURE TESTING

- Location of pressure test ports.
- **Always replace line pressure plugs as they are self-sealing bolts.**

GI

MA

EM

LC

EC

FE

CL

MT

**AT**

TF

PD

FA

RA

BR

ST



RS

BT

HA

EL


IDX





### Line pressure test procedure

1. Check A/T and engine fluid levels. If necessary, add fluid.
2. Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

**ATF operating temperature:**  
50 - 80°C (122 - 176°F)




3. Install pressure gauge to corresponding line pressure port.



4. Set parking brake and block wheels.
  - **Continue to depress brake pedal fully while line pressure test is being performed at stall speed.**

## TROUBLE DIAGNOSES

### Final Check (Cont'd)



5. Start engine and measure line pressure at idle and stall speed.
  - **When measuring line pressure at stall speed, follow the stall test procedure.**  
**Line pressure:**  
**Refer to SDS, AT-202.**

### JUDGEMENT OF LINE PRESSURE TEST

Judgement		Suspected parts
At idle	Line pressure is low in all positions.	<ul style="list-style-type: none"> <li>• Oil pump wear</li> <li>• Control piston damage</li> <li>• Pressure regulator valve or plug sticking</li> <li>• Spring for pressure regulator valve damaged</li> <li>• Fluid pressure leakage between oil strainer and pressure regulator valve</li> <li>• Clogged strainer</li> </ul>
	Line pressure is low in particular position.	<ul style="list-style-type: none"> <li>• Fluid pressure leakage between manual valve and particular clutch</li> <li>• For example, line pressure is:                             <ul style="list-style-type: none"> <li>— Low in "R" and "1" positions, but</li> <li>— Normal in "D" and "2" positions.</li> </ul>                             Then, fluid leakage exists at or around low and reverse brake circuit.                         </li> </ul>
	Line pressure is high.	<ul style="list-style-type: none"> <li>• Mal-adjustment of throttle position sensor</li> <li>• Fluid temperature sensor damaged</li> <li>• Line pressure solenoid valve sticking</li> <li>• Short circuit of line pressure solenoid valve circuit</li> <li>• Pressure modifier valve sticking</li> <li>• Pressure regulator valve or plug sticking</li> <li>• Open in dropping resistor circuit</li> </ul>
At stall speed	Line pressure is low.	<ul style="list-style-type: none"> <li>• Mal-adjustment of throttle position sensor</li> <li>• Line pressure solenoid valve sticking</li> <li>• Short circuit of line pressure solenoid valve circuit</li> <li>• Pressure regulator valve or plug sticking</li> <li>• Pressure modifier valve sticking</li> <li>• Pilot valve sticking</li> </ul>

# TROUBLE DIAGNOSES

## Symptom Chart

		ON vehicle										OFF vehicle																						
—	Reference page (AT- )	23, 121	121	47, 49, 64	107	53, 119	55, 66	57, 59	61, 119	119	119	130, 141	158, 162	164	164, 173	168, 177	181																	
Reference page (AT- )	Numbers are arranged in order of probability. Perform inspections starting with number one and work up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level	Control linkage	Inhibitor switch	Throttle position sensor (Adjustment)	Revolution sensor and speed sensor	Engine speed signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid valve A	Shift solenoid valve B	Line pressure solenoid valve	Torque converter clutch solenoid valve	Overrun clutch solenoid valve	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components		
83	Engine does not start in "N", "P" positions.	2	3																	1														
83	Engine starts in position other than "N" and "P" positions.	1	2																															
—	Transmission noise in "P" and "N" positions.	1		3	4	5		2														7	6											
83	Vehicle moves when changing into "P" position or parking gear does not disengage when shifted out of "P" position.	1																														2		
84	Vehicle runs in "N" position.	1																						4		3		5						
86	Vehicle will not run in "R" position (but runs in "D", "2" and "1" positions). Clutch slips. Very poor acceleration.	1					2	4			3													5	6	7		8		9				
—	Vehicle braked when shifting into "R" position.	1	2				3	5		4															6	8		9			7			
—	Sharp shock in shifting from "N" to "D" position.			2		5	1	3	7		6			4	8											9								
—	Vehicle will not run in "D" and "2" positions (but runs in "1" and "R" positions).	1																													2			
87	Vehicle will not run in "D", "1", "2" positions (but runs in "R" position). Clutch slips. Very poor acceleration.	1					2	4			3														6	7	8	9		10				
—	Clutches or brakes slip somewhat in starting.	1	2		3			4	6		5													13	12	10		9			11			
—	Excessive creep.					1																												
86, 87	No creep at all.	1					2	3															6	5			4							
—	Failure to change gear from "D <sub>1</sub> " to "D <sub>2</sub> ".	2	1		5			4	3																							6		
—	Failure to change gear from "D <sub>2</sub> " to "D <sub>3</sub> ".	2	1		5			4	3																6							7		
—	Failure to change gear from "D <sub>3</sub> " to "D <sub>4</sub> ".	2	1		4				3							5																6		
89, 90, 91	Too high a gear change point from "D <sub>1</sub> " to "D <sub>2</sub> ", from "D <sub>2</sub> " to "D <sub>3</sub> ", from "D <sub>3</sub> " to "D <sub>4</sub> ".			1	2				3	4																								
—	Gear change directly from "D <sub>1</sub> " to "D <sub>3</sub> " occurs.	1															2														3			
—	Engine stops when shifting lever into "R", "D", "2" and "1".					1		3					2									4												
—	Too sharp a shock in change from "D <sub>1</sub> " to "D <sub>2</sub> ".			1			2	4							5		3															6		
—	Too sharp a shock in change from "D <sub>2</sub> " to "D <sub>3</sub> ".			1			2	4										3														6		

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
**AT**  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# TROUBLE DIAGNOSES

## Symptom Chart (Cont'd)

Reference page (AT- )	Reference page (AT- )	ON vehicle										OFF vehicle																					
		23, 121	121	47, 49, 64	107	53, 119	55, 66	57, 59	61, 119	119	119	130, 141	158, 162	164	164, 173	168, 177	181																
		Fluid level	Control linkage	Inhibitor switch	Throttle position sensor (Adjustment)	Revolution sensor and speed sensor	Engine speed signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid valve A	Shift solenoid valve B	Line pressure solenoid valve	Torque converter clutch solenoid valve	Overrun clutch solenoid valve	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components	
—	Too sharp a shock in change from "D <sub>3</sub> " to "D <sub>4</sub> ".			1			2		4											3								6			5		
—	Almost no shock or clutches slipping in change from "D <sub>1</sub> " to "D <sub>2</sub> ".	1		2			3		5										4												6		
—	Almost no shock or slipping in change from "D <sub>2</sub> " to "D <sub>3</sub> ".	1		2			3		5											4											7		
—	Almost no shock or slipping in change from "D <sub>3</sub> " to "D <sub>4</sub> ".	1		2			3		5											4											7		
—	Vehicle braked by gear change from "D <sub>1</sub> " to "D <sub>2</sub> ".	1																					2	4				5	3				
—	Vehicle braked by gear change from "D <sub>2</sub> " to "D <sub>3</sub> ".	1																													2		
—	Vehicle braked by gear change from "D <sub>3</sub> " to "D <sub>4</sub> ".	1																					4			3	2						
—	Maximum speed not attained. Acceleration poor.	1	2						5	3	4											11	10	6	7				9	8			
—	Failure to change gear from "D <sub>4</sub> " to "D <sub>3</sub> ".	1		2					6	4		5	3														8		7				
—	Failure to change gear from "D <sub>3</sub> " to "D <sub>2</sub> " or from "D <sub>4</sub> " to "D <sub>2</sub> ".	1		2					5	3	4													6						7			
—	Failure to change gear from "D <sub>2</sub> " to "D <sub>1</sub> " or from "D <sub>3</sub> " to "D <sub>1</sub> ".	1		2					5	3	4													7			6		8				
—	Gear change shock felt during deceleration by releasing accelerator pedal.			1			2		4					3																			
—	Too high a change point from "D <sub>4</sub> " to "D <sub>3</sub> ", from "D <sub>3</sub> " to "D <sub>2</sub> ", from "D <sub>2</sub> " to "D <sub>1</sub> ".			1	2																												
—	Kickdown does not operate when depressing pedal in "D <sub>4</sub> " within kickdown vehicle speed.			1	2					3	4																						
—	Kickdown operates or engine overruns when depressing pedal in "D <sub>4</sub> " beyond kickdown vehicle speed limit.			2	1					3	4																						
—	Races extremely fast or slips in changing from "D <sub>4</sub> " to "D <sub>3</sub> " when depressing pedal.	1		2			3	5		4														6	7								
—	Races extremely fast or slips in changing from "D <sub>4</sub> " to "D <sub>2</sub> " when depressing pedal.	1		2			3	6	5	4															8					7			
—	Races extremely fast or slips in changing from "D <sub>3</sub> " to "D <sub>2</sub> " when depressing pedal.	1		2			3	5		4					6		7							10	9					8			
—	Races extremely fast or slips in changing from "D <sub>4</sub> " or "D <sub>3</sub> " to "D <sub>1</sub> " when depressing pedal.	1		2			3	5		4															6	7	8						
—	Vehicle will not run in any position.	1	2				3			4												9	5	6					8	7	10		
—	Transmission noise in "D", "2", "1" and "R" positions.	1																				2											

# TROUBLE DIAGNOSES


## Symptom Chart (Cont'd)

Reference page (AT- )	Reference page (AT- )	ON vehicle										OFF vehicle																						
		23, 121	121	47, 49, 64	107	53, 119	55, 66	57, 59	61, 119	119	119	130, 141	158, 162	164	164, 173	168, 177	181																	
Reference page (AT- )	Numbers are arranged in order of probability. Perform inspections starting with number one and work up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level	Control linkage	Inhibitor switch	Throttle position sensor (Adjustment)	Revolution sensor and speed sensor	Engine speed signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid valve A	Shift solenoid valve B	Line pressure solenoid valve	Torque converter clutch solenoid valve	Overrun clutch solenoid valve	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components		
94	Failure to change from "D <sub>3</sub> " to "2" when changing lever into "2" position.	7	1	2					6	5	4		3																					
—	Gear change from "2 <sub>2</sub> " to "2 <sub>3</sub> " in "2" position.		1																															
95	Engine brake does not operate in "1" position.	2	1	3	4				6	5			7																					
—	Gear change from "1 <sub>1</sub> " to "1 <sub>2</sub> " in "1" position.	2	1																															
—	Does not change from "1 <sub>2</sub> " to "1 <sub>1</sub> " in "1" position.		1	2					4	3			5																					
—	Large shock changing from "1 <sub>2</sub> " to "1 <sub>1</sub> " in "1" position.								1																									
—	Transmission overheats.	1		3			2	4	6			5										14	7	8	9	11	12	13	10					
—	ATF shoots out during operation. White smoke emitted from exhaust pipe during operation.	1																					2	3	5		6		7	4				
—	Offensive smell at fluid charging pipe.	1																				2	3	4	5	7		8		9	6			
—	Torque converter is not locked up.		3	1	2	4		6	8				7	5								9												
—	Torque converter clutch piston slip.	1		2				3	6		5	4										7												
92	Lock-up point is extremely high or low.			1	2				4				3																					
—	A/T does not shift to "D <sub>4</sub> " when driving with overdrive control switch "ON".		2	1	3			8	6	4			5	7														10			9			
—	Engine is stopped at "R", "D", "2" and "1" positions.	1							5	4	3	2																						

CI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

## Description


- The mechanical key interlock mechanism also operates as a shift lock:  
With the key switch turned to "ON", the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.  
With the key removed, the selector lever cannot be shifted from "P" to any other position.  
The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder, respectively.





Wiring Diagram — SHIFT —

AT-SHIFT-01







AS : Models with ASCD  
OS : Models without ASCD

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

Refer to last page (Foldout page).

(M10)






## Diagnostic Procedure

### SYMPTOM 1:

- Selector lever cannot be moved from "P" position with key in "ON" position and brake pedal applied.
- Selector lever can be moved from "P" position with key in "ON" position and brake pedal released.
- Selector lever can be moved from "P" position when key is removed from key cylinder.

### SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to "P" position. It can be removed when selector lever is set to any position except "P".



**B**



**CHECK INPUT SIGNAL (BRAKE SWITCH).**  
Turn ignition switch to "ON" position. (Do not start engine.)

- Check voltage between A/T device harness terminal ⑤ and ground.

Brake pedal	Voltage
Depressed	0V
Released	Battery voltage

# TROUBLE DIAGNOSES — A/T Shift Lock System

## Diagnostic Procedure (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

**Key Interlock Cable**



**CAUTION:**

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap can be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.



**REMOVAL**

Unlock slider from adjuster holder and remove rod from cable.






# TROUBLE DIAGNOSES — A/T Shift Lock System

## Key Interlock Cable (Cont'd)

### INSTALLATION

1. Set key interlock cable to steering lock assembly and install lock plate.
2. Clamp cable to steering column and fix to control cable with band.
3. Set selector lever to P position.
4. Insert interlock rod into adjuster holder.
5. Install casing cap to bracket.
6. Move slider in order to fix adjuster holder to interlock rod.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT



### Component Check

#### SHIFT LOCK SOLENOID

- Check operation by applying battery voltage between shift lock solenoid harness connector terminal ② and A/T device harness connector terminal ⑤.

AT  
TF  
PD  
FA  
RA  
BR  
ST


#### PARK POSITION SWITCH

- Check continuity between park position switch harness connector terminal ② and A/T device harness connector terminal ⑥.

Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	No
Except above	Yes

RS  
BT  
HA  
EL  
IDX

## TROUBLE DIAGNOSES — A/T Shift Lock System







### Component Check (Cont'd)

#### ASCD CANCEL SWITCH (SHIFT LOCK BRAKE SWITCH FOR MODELS WITHOUT ASCD)

- Check continuity between ASCD cancel (shift lock brake) switch harness connector terminals ① and ②.

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No

**Check ASCD cancel (shift lock brake) switch after adjusting brake pedal — refer to BR section.**



### Control Valve Assembly and Accumulators Inspection


1. Remove exhaust front tube.
2. Remove oil pan and gasket and drain ATF.
3. Remove fluid temperature sensor-1 if necessary.
4. Remove oil strainer.
5. Remove control valve assembly by removing fixing bolts and disconnecting harness connector.
6. Remove solenoids and valves from valve body if necessary.
7. Remove terminal cord assembly if necessary.
8. Remove accumulator (A), (B), (C) and (D) by applying compressed air if necessary.
9. Reinstall any part removed.

#### Bolt length and location

Bolt symbol	ℓ mm (in)
(A)	33 (1.30)
(B)	45 (1.77)

- **Hold each piston with rag.**
- **Always use new sealing parts.**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
FA  
EL  
IDX



## Revolution Sensor Replacement


### — 4WD model —

1. Remove rear engine mounting member from side member while supporting A/T with transfer case with jack.
2. Lower A/T with transfer case as much as possible.
3. Remove revolution sensor from A/T.
4. Reinstall any part removed.

- **Always use new sealing parts.**

### — 2WD model —

- Remove revolution sensor from A/T.
- **Always use new sealing parts.**




## Rear Oil Seal Replacement

### — 4WD model —

1. Remove transfer case from vehicle. Refer to TF section ("Removal", "REMOVAL AND INSTALLATION").
2. Remove rear oil seal.
3. Install rear oil seal.

- **Apply ATF before installing.**

4. Reinstall any part removed.




### — 2WD model —

1. Remove propeller shaft from vehicle. Refer to PD section ("Removal", "PROPELLER SHAFT").
2. Remove rear oil seal.
3. Install rear oil seal.

- **Apply ATF before installing.**


4. Reinstall any part removed.



## Parking Components Inspection


### — 4WD model —

1. Remove propeller shaft. Refer to PD section ("Removal", "PROPELLER SHAFT").
2. Remove transfer case from vehicle. Refer to TF section ("Removal", "REMOVAL AND INSTALLATION").
3. Remove manual control linkage bracket from adapter case.





## Parking Components Inspection (Cont'd)



4. Support A/T assembly with a jack.
  5. Remove adapter case from transmission case.
  6. Replace parking components if necessary.
  7. Reinstall any part removed.
- **Always use new sealing parts.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX




### — 2WD model —

1. Remove propeller shaft from vehicle. Refer to PD section ("Removal", "PROPELLER SHAFT").
  2. Support A/T assembly with a jack.
  3. Remove rear engine mounting member.
  4. Remove rear extension from transmission case.
  5. Replace parking components if necessary.
  6. Reinstall any part removed.
- **Always use new sealing parts.**



## Inhibitor Switch Adjustment

1. Remove manual control linkage from manual shaft of A/T assembly.
2. Set manual shaft of A/T assembly in "N" position.
3. Loosen inhibitor switch fixing bolts.
4. Insert pin into adjustment holes in both inhibitor switch and manual shaft of A/T assembly as near vertical as possible.
5. Reinstall any part removed.
6. Check continuity of inhibitor switch. Refer to "Electrical Components Inspection", AT-102.




## Manual Control Linkage Adjustment

Move selector lever from "P" position to "1" position. You should be able to feel the detents in each position.

If the detents cannot be felt or the pointer indicating the position is improperly aligned, the linkage needs adjustment.

1. Place selector lever in "P" position.
2. Loosen lock nuts.



3. Tighten turn buckle until aligns with inner cable, pulling selector lever toward "R" position side without pushing button.
4. Back off turn buckle 1 turn and tighten lock nuts to the specified torque.


### Lock nut

: 4.4 - 5.9 N·m

(0.45 - 0.60 kg-m, 3.3 - 4.3 ft-lb)

5. Move selector lever from "P" position to "1" position. Make sure that selector lever can move smoothly.

## REMOVAL AND INSTALLATION



### Removal


#### CAUTION:

When removing the A/T assembly from engine, first remove the crankshaft position sensor (OBD) from the A/T assembly upper side.

Be careful not to damage sensor edge.

#### — 4WD and 2WD model —

- Remove exhaust front and rear tubes (4WD model).
- Remove fluid charging pipe from A/T assembly.
- Remove oil cooler pipe from A/T assembly.
- Plug up openings such as the fluid charging pipe hole, etc.
- Remove propeller shaft. Refer to PD section ("Removal", "PROPELLER SHAFT").
- Remove transfer control linkage from transfer.
- **Insert plug into rear oil seal after removing rear propeller shaft.**
- **Be careful not to damage spline, sleeve yoke and rear oil seal.**
- Remove speedometer cable from transfer assembly or A/T assembly.
- Remove A/T control cable from A/T assembly.
- Disconnect A/T harness connectors.



- Remove starter motor.
- Remove gusset and rear plate cover securing engine to A/T assembly.
- Remove bolts securing torque converter to drive plate.
- **Remove the bolts by turning crankshaft.**

# REMOVAL AND INSTALLATION

## Removal (Cont'd)

### — 4WD model —

- Support A/T and transfer assembly with a jack.
- Remove rear mounting bracket from body and A/T assembly.
- Remove bolts securing A/T assembly to engine.
- Lower A/T assembly with transfer.

GI

MA

EM

LC

### — 2WD model —

- Support A/T assembly with a jack.
- Remove rear mounting bracket from body and A/T assembly.
- Remove bolts securing A/T assembly to engine.
- Pull A/T assembly backwards.
- **Secure torque converter to prevent it from dropping.**
- **Secure A/T assembly to a jack.**
- Lower A/T assembly.

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST





RS

BT

HA

EL

IDX



## Installation



- Drive plate runout  
**Maximum allowable runout:  
0.5 mm (0.020 in)**  
If this runout is out of specification, replace drive plate with ring gear.

- When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled.  
**Distance "A":  
26.0 mm (1.024 in) or more**

- Install converter to drive plate.
- **After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.**

# REMOVAL AND INSTALLATION

## Installation (Cont'd)



- Tighten bolts securing transmission.

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	Bolt length "l" mm (in)
①	39 - 49 (4.0 - 5.0, 29 - 36)	47.5 (1.870)
②	39 - 49 (4.0 - 5.0, 29 - 36)	58.0 (2.283)
③	29 - 39 (3.0 - 4.0, 22 - 29)	25.0 (0.984)
Gusset to engine	29 - 39 (3.0 - 4.0, 22 - 29)	20.0 (0.787)

- Reinstall any part removed.
- Check fluid level in transmission.
- Move selector lever through all positions to be sure that transmission operates correctly.  
With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R" positions. A slight shock should be felt by hand gripping selector each time transmission is shifted.
- Perform road test. Refer to "ROAD TEST", AT-23.

# REMOVAL AND INSTALLATION

---

NOTE

GI

MA

EM

LC

EC

FE

CL

MT

**AT**

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# MAJOR OVERHAUL

## SEC. 311-313-315



N·m (kg·m, ft·lb)



Apply recommended sealant (Nissan genuine part: KP610-00250) or equivalent.




Apply ATF.



Apply petroleum jelly.

★ : Select with proper thickness.



SAT680HA

# MAJOR OVERHAUL

## SEC. 311•315•317

: N•m (kg-m, in-lb)


: N•m (kg-m, ft-lb)

: Apply ATF.

: Apply petroleum jelly.

★ : Select with proper thickness.







☆ : Adjustment is required.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
**AT**  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
FDX

# MAJOR OVERHAUL

## Oil Channel





Locations of Needle Bearings, Thrust Washers and Snap Rings

Outer diameter of snap rings

Item number	Outer diameter mm (in)
②	161.0 (6.34)
③	140.1 (5.52)
④	156.4 (6.16)
⑥	142.0 (5.59)
⑦	159.2 (6.27)

Thrust washers

Item number	Color
①	Black
⑤	White

Outer diameter of needle bearings


Item number	Outer diameter mm (in)
⑧	47 (1.85)
⑨	53 (2.09)
⑩	53 (2.09)
⑪	78 (3.07)
⑫	53 (2.09)
⑬	78 (3.07)
⑭	57 (2.24)
⑮	78 (3.07)
⑯	64 (2.52)

Installation of one-piece bearings

Item number	Bearing race (black) location
⑫	Front
⑮	Rear side
⑯	Rear side


Inner diameter of bearing races

Item number	Outer diameter mm (in)
⑪	58 (2.28)
⑬	58.8 (2.315)




CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# DISASSEMBLY




## Disassembly


1. Drain ATF through drain plug.
2. Remove torque converter by holding it firmly and turning while pulling straight out.




3. Check torque converter one-way clutch.
  - a. Insert Tool into spline of one-way clutch inner race.
  - b. Hook bearing support unitized with one-way clutch outer race with suitable wire.
  - c. Check that one-way clutch inner race rotates only clockwise with Tool while holding bearing support with wire.



4. Remove inhibitor switch from transmission case.








5. Remove oil pan.
  - Always place oil pan straight down so that foreign particles inside will not move.



6. Place transmission into Tool with the control valve facing up.

# DISASSEMBLY

## Disassembly (Cont'd)



7. Check foreign materials in oil pan to help determine cause of malfunction. If the fluid is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and may inhibit pump pressure.

- If frictional material is detected, replace radiator after repair of A/T. Refer to LC section ("Radiator", "ENGINE COOLING SYSTEM").

8. Remove torque converter clutch solenoid valve and fluid temperature sensor connectors.

- Be careful not to damage connector.

9. Remove oil strainer.

- a. Remove oil strainer from control valve assembly. Then remove O-ring from oil strainer.

- b. Check oil strainer screen for damage.

10. Remove control valve assembly.

- a. Straighten terminal clips to free terminal cords then remove terminal clips.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

## DISASSEMBLY


### Disassembly (Cont'd)

- b. Remove bolts (A) and (B), and remove control valve assembly from transmission.


Bolt symbol	Length mm (in)
(A)	33 (1.30)
(B)	45 (1.77)




- c. Remove solenoid connector.
- **Be careful not to damage connector.**



- d. Remove manual valve from control valve assembly.




11. Remove terminal cord assembly from transmission case while pushing on stopper.
- **Be careful not to damage cord.**
  - **Do not remove terminal cord assembly unless it is damaged.**




# DISASSEMBLY

## Disassembly (Cont'd)




12. Remove converter housing from transmission case.

- **Be careful not to scratch converter housing.**




13. Remove O-ring from input shaft.



14. Remove oil pump assembly.


- a. Attach Tool to oil pump assembly and extract it evenly from transmission case.



b. Remove O-ring from oil pump assembly.

c. Remove traces of sealant from oil pump housing.

- **Be careful not to scratch pump housing.**




d. Remove needle bearing and thrust washer from oil pump assembly.


RI  
NA  
EM  
LG  
EC  
FE  
GL  
MT  
AT  
TF  
PD  
FA  
HA  
BR  
ST  
RS  
BT  
HA  
HL  
ILX

## DISASSEMBLY


### Disassembly (Cont'd)




15. Remove input shaft and oil pump gasket.




16. Remove brake band and band strut.  
a. Loosen lock nut and remove band servo anchor end pin from transmission case.



b. Remove brake band and band strut from transmission case.




c. Hold brake band in a circular shape with clip.




17. Remove front side clutch and gear components.  
a. Remove clutch pack (reverse clutch, high clutch and front sun gear) from transmission case.

# DISASSEMBLY


## Disassembly (Cont'd)




- b. Remove front bearing race from clutch pack.
- c. Remove rear bearing race from clutch pack.



- d. Remove front planetary carrier from transmission case.



- e. Remove front needle bearing from front planetary carrier.
- f. Remove rear bearing from front planetary carrier.



- g. Remove rear sun gear from transmission case.

GI

MA

EM

LG

EC

FE

CL

MT

**AT**

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

## DISASSEMBLY


### Disassembly (Cont'd)




18. Remove rear extension or adapter case.
  - a. Remove rear extension or adapter case from transmission case.
  - b. Remove rear extension or adapter case gasket from transmission case.



- c. Remove oil seal from rear extension or adapter case.
- **Do not remove oil seal unless it is to be replaced.**



- d. Remove revolution sensor from rear extension or adapter case.
  - e. Remove O-ring from revolution sensor.




19. Remove output shaft and parking gear.
  - a. Remove rear snap ring from output shaft.



# DISASSEMBLY

## Disassembly (Cont'd)



- b. Slowly push output shaft all the way forward.
  - **Do not use excessive force.**
- c. Remove snap ring from output shaft.

GI

MA

EM

LC

EC

FE

CL

MT

**AT**

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL


IDX




- d. Remove output shaft and parking gear as a unit from transmission case.
- e. Remove parking gear from output shaft.



- f. Remove needle bearing from transmission case.



- 20. Remove rear side clutch and gear components.
  - a. Remove front internal gear.




- b. Remove bearing race from front internal gear.


## DISASSEMBLY

### Disassembly (Cont'd)


- c. Remove needle bearing from rear internal gear.




- d. Remove rear internal gear, forward clutch hub and overrun clutch hub as a set from transmission case.




- e. Remove needle bearing from overrun clutch hub.  
f. Remove overrun clutch hub from rear internal gear and forward clutch hub.



- g. Remove thrust washer from overrun clutch hub.




- h. Remove forward clutch assembly from transmission case.




# DISASSEMBLY


## Disassembly (Cont'd)



21. Remove band servo and accumulator components.  
 a. Remove band servo retainer from transmission case.




- b. Apply compressed air to oil hole until band servo piston comes out of transmission case.  
 • **Hold piston with a rag and gradually direct air to oil hole.**  
 c. Remove return springs.




- d. Remove springs from accumulator pistons (B), (C) and (D).  
 e. Apply compressed air to each oil hole until piston comes out.  
 • **Hold piston with a rag and gradually direct air to oil hole.**

Identification of accumulator pistons	(A)	(B)	(C)	(D)
Identification of oil holes	(a)	(b)	(c)	(d)



- f. Remove O-ring from each piston.




22. Remove manual shaft components, if necessary.  
 a. Hold width across flats of manual shaft (outside the transmission case) and remove lock nut from shaft.


## DISASSEMBLY

### Disassembly (Cont'd)


- b. Remove retaining pin from transmission case.




- c. While pushing detent spring down, remove manual plate and parking rod from transmission case.




- d. Remove manual shaft from transmission case.





- e. Remove spacer and detent spring from transmission case.



- f. Remove oil seal from transmission case.




Oil Pump




DISASSEMBLY

- Loosen bolts in numerical order and remove oil pump cover.




- Remove rotor, vane rings and vanes.
  - Inscribe a mark on back of rotor for identification of fore-aft direction when reassembling rotor. Then remove rotor.




- While pushing on cam ring remove pivot pin.
  - Be careful not to scratch oil pump housing.

## REPAIR FOR COMPONENT PARTS


### Oil Pump (Cont'd)




4. While holding cam ring and spring lift out cam ring spring.
  - Be careful not to damage oil pump housing.
  - Hold cam ring spring to prevent it from jumping.




5. Remove cam ring and cam ring spring from oil pump housing.



6. Remove pivot pin from control piston and remove control piston assembly.



7. Remove oil seal from oil pump housing.
  - Be careful not to scratch oil pump housing.



### INSPECTION

Oil pump cover, rotor, vanes, control piston, side seals, cam ring and friction ring

- Check for wear or damage.

# REPAIR FOR COMPONENT PARTS

## Oil Pump (Cont'd)

### Side clearances

- Measure side clearances between end of oil pump housing and cam ring, rotor, vanes and control piston. Measure in at least four places along their circumferences. Maximum measured values should be within specified positions.
- **Before measurement, check that friction rings, O-ring, control piston side seals and cam ring spring are removed.**

**Standard clearance (Cam ring, rotor, vanes and control piston):**

**Refer to SDS, AT-205.**

- If not within standard clearance, replace oil pump assembly except oil pump cover assembly.

### Seal ring clearance

- Measure clearance between seal ring and ring groove.






**Standard clearance:**

**0.10 - 0.25 mm (0.0039 - 0.0098 in)**

**Wear limit:**

**0.25 mm (0.0098 in)**

- If not within wear limit, replace oil pump cover assembly.




### ASSEMBLY

1. Drive oil seal into oil pump housing.
  - **Apply ATF to outer periphery and lip surface.**
2. Install cam ring in oil pump housing by the following steps.
  - a. Install side seal on control piston.
    - **Pay attention to its direction — Black surface goes toward control piston.**
    - **Apply petroleum jelly to side seal.**
  - b. Install control piston on oil pump.
  - c. Install O-ring and friction ring on cam ring.
    - **Apply petroleum jelly to O-ring.**


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## REPAIR FOR COMPONENT PARTS


### Oil Pump (Cont'd)




- d. Assemble cam ring, cam ring spring and spring seat. Install spring by pushing it against pump housing.




- e. While pushing on cam ring install pivot pin.



3. Install rotor, vanes and vane rings.
- **Pay attention to direction of rotor.**



4. Install oil pump housing and oil pump cover.
- a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly in oil pump housing assembly, then remove masking tape.
- b. Tighten bolts in a criss-cross pattern.




5. Install new seal rings carefully after packing ring grooves with petroleum jelly. Press rings down into jelly to a close fit.
- **Seal rings come in two different diameters. Check fit carefully in each groove.**
    - Small dia. seal ring:**  
No mark
    - Large dia. seal ring:**  
Yellow mark in area shown by arrow
  - **Do not spread gap of seal ring excessively while installing. It may deform ring.**



Control Valve Assembly

SEC. 317




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX


## REPAIR FOR COMPONENT PARTS

### Control Valve Assembly (Cont'd)


#### DISASSEMBLY




1. Remove solenoids.
  - a. Remove torque converter clutch solenoid valve and side plate from lower body.
  - b. Remove O-ring from solenoid.




- c. Remove line pressure solenoid valve from upper body.
    - d. Remove O-ring from solenoid.



- e. Remove 3-unit solenoid assembly from upper body.
    - f. Remove O-rings from solenoids.



2. Disassemble upper and lower bodies.
  - a. Place upper body facedown, and remove bolts, reamer bolts and support plates.
  - b. Remove lower body, separator plate and separate gasket as a unit from upper body.
    - **Be careful not to drop pilot filter, orifice check valve, spring and steel balls.**








- c. Place lower body facedown, and remove separate gasket and separator plate.
      - d. Remove pilot filter, orifice check valve and orifice check spring.

# REPAIR FOR COMPONENT PARTS

## Control Valve Assembly (Cont'd)

- e. Check to see that steel balls are properly positioned in upper body. Then remove them from upper body.



## INSPECTION

### Lower and upper bodies

- Check to see that there are pins and retainer plates in lower body.

- Check to see that there are pins and retainer plates in upper body.

- **Be careful not to lose these parts.**

- Check to make sure that oil circuits are clean and free from damage.
- Check tube brackets and tube connectors for damage.

### Separator plates

- Make sure that separator plate is free of damage and not deformed and oil holes are clean.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

## REPAIR FOR COMPONENT PARTS

### Control Valve Assembly (Cont'd)

#### Pilot filter

- Check to make sure that filter is not clogged or damaged.




#### Torque converter clutch solenoid valve

- Check that filter is not clogged or damaged.
- Measure resistance. Refer to "Electrical Components Inspection", AT-101.


#### Line pressure solenoid valve

- Check that filter is not clogged or damaged.
- Measure resistance. Refer to "Electrical Components Inspection", AT-101.




#### 3-unit solenoid assembly (Overrun clutch solenoid valve and shift solenoid valves A and B)

- Measure resistance of each solenoid. Refer to "Electrical Components Inspection", AT-101.




#### Fluid temperature sensor

- Measure resistance. Refer to "Electrical Components Inspection", AT-101.




#### ASSEMBLY

1. Install upper and lower bodies.
  - a. Place oil circuit of upper body face up. Install steel balls in their proper positions.



# REPAIR FOR COMPONENT PARTS

## Control Valve Assembly (Cont'd)




- b. Install reamer bolts from bottom of upper body and install separate gaskets.

GI

MA

EM

LC



- c. Place oil circuit of lower body face up. Install orifice check spring, orifice check valve and pilot filter.

EC

FE

CL


MT

AT

TF

PD

FA




- d. Install lower separate gaskets and separator plates on lower body.
- e. Install and temporarily tighten support plates, fluid temperature sensor and tube brackets.

RA

BR

ST

RS



- f. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.
- Be careful not to dislocate or drop steel balls, orifice check spring, orifice check valve and pilot filter.

BT

HA

EL

IDX




## REPAIR FOR COMPONENT PARTS

### Control Valve Assembly (Cont'd)

- g. Install and temporarily tighten bolts and tube brackets in their proper locations.

#### Bolt length and location:

Bolt symbol	a	b	c	d
Bolt length	70 (2.76)	50 (1.97)	33 (1.30)	27 (1.06)



2. Install solenoids.


- a. Attach O-ring and install torque converter clutch solenoid valve and side plates onto lower body.

- b. Attach O-rings and install 3-unit solenoids assembly onto upper body.

- c. Attach O-ring and install line pressure solenoid valve onto upper body.

3. Tighten all bolts.

Control Valve Upper Body



SEC. 317


Apply ATF to all components before their installation.  
 Numbers preceding valve springs correspond with those shown in SDS on page AT-203.

CI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
**AT**  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX


## REPAIR FOR COMPONENT PARTS

### Control Valve Upper Body (Cont'd)


#### DISASSEMBLY




1. Remove valves at parallel pins.
  - Do not use a magnetic hand.




- a. Use a wire paper clip to push out parallel pins.



- b. Remove parallel pins while pressing their corresponding plugs and sleeves.
  - Remove plug slowly to prevent internal parts from jumping out.



- c. Place mating surface of valve facedown, and remove internal parts.
  - If a valve is hard to remove, place valve body facedown and lightly tap it with a soft hammer.
  - Be careful not to drop or damage valves and sleeves.




2. Remove valves at retainer plates.
  - a. Pry out retainer plate with wire paper clip.



## REPAIR FOR COMPONENT PARTS

### Control Valve Upper Body (Cont'd)



b. Remove retainer plates while holding spring.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX




c. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.



• 4-2 sequence valve and relay valve are located far back in upper body. If they are hard to remove, carefully push them out using stiff wire.

- Be careful not to scratch sliding surface of valve with wire.



### INSPECTION

#### Valve springs

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.


**Inspection standard:**

**Refer to SDS, AT-203.**

- Replace valve springs if deformed or fatigued.

#### Control valves

- Check sliding surfaces of valves, sleeves and plugs.




### ASSEMBLY

1. Lubricate the control valve body and all valves with ATF. Install control valves by sliding them carefully into their bores.


- Be careful not to scratch or damage valve body.

## REPAIR FOR COMPONENT PARTS

### Control Valve Upper Body (Cont'd)




- Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.




### Pressure regulator valve

- If pressure regulator plug is not centered properly, sleeve cannot be inserted into bore in upper body. If this happens, use vinyl tape wrapped screwdriver to center sleeve until it can be inserted.
- Turn sleeve slightly while installing.




### Accumulator control plug

- Align protrusion of accumulator control sleeve with notch in plug.
- Align parallel pin groove in plug with parallel pin, and install accumulator control valve.



2. Install parallel pins and retainer plates.



- While pushing plug, install parallel pin.

## REPAIR FOR COMPONENT PARTS

### Control Valve Upper Body (Cont'd)

#### 4-2 sequence valve and relay valve

- Push 4-2 sequence valve and relay valve with wire wrapped in vinyl tape to prevent scratching valve body. Install parallel pins.

CI

MA

EM

LC

EC

FE

CL

MT

**AT**

TF

PD

FA

RA

BR

ST



RS

BT

HA


EL

IDX



- Insert retainer plate while pushing spring.

Control Valve Lower Body



SEC. 317

Apply ATF to all components before their installation.  
 Numbers preceding valve springs correspond with those shown in SDS on page AT-203.

# REPAIR FOR COMPONENT PARTS

## Control Valve Lower Body (Cont'd)

### DISASSEMBLY

1. Remove valves at parallel pins.
2. Remove valves at retainer plates.  
For removal procedures, refer to "DISASSEMBLY" of Control Valve Upper Body.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST




RS

BT

HA

EL

IDX



### INSPECTION

#### Valve springs

- Check each valve spring for damage or deformation. Also measure free length and outer diameter.

#### Inspection standard:

Refer to SDS, AT-203.

- Replace valve springs if deformed or fatigued.

#### Control valves

- Check sliding surfaces of control valves, sleeves and plugs for damage.


### ASSEMBLY

- Install control valves.  
For installation procedures, refer to "ASSEMBLY" of Control Valve Upper Body, AT-153.


## Reverse Clutch

SEC. 315

(ATF) : Apply ATF.  
 ★ : Select with proper thickness.




SAT082EB



SAT841A

### DISASSEMBLY


1. Check operation of reverse clutch.
  - a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
  - b. Check to see that retaining plate moves to snap ring.
  - c. If retaining plate does not contact snap ring,
    - D-ring might be damaged.
    - Oil seal might be damaged.
    - Fluid might be leaking past piston check ball.
2. Remove drive plates, driven plates, retaining plate, dish plate and snap ring.



SAT842A

# REPAIR FOR COMPONENT PARTS

## Reverse Clutch (Cont'd)



3. Remove snap ring from clutch drum while compressing clutch springs.
  - **Do not expand snap ring excessively.**
4. Remove spring retainer and return spring.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




5. Install seal ring onto oil pump cover and install reverse clutch drum. While holding piston, gradually apply compressed air to oil hole until piston is removed.
  - **Do not apply compressed air abruptly.**
6. Remove D-ring and oil seal from piston.

## INSPECTION

### Reverse clutch snap ring and spring retainer

- Check for deformation, fatigue or damage.




### Reverse clutch return springs

- Check for deformation or damage. Also measure free length and outside diameter.

**Inspection standard:**

**Refer to SDS, AT-203.**



### Reverse clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

**Thickness of drive plate:**

**Standard value: 1.90 - 2.05 mm (0.0748 - 0.0807 in)**

**Wear limit: 1.80 mm (0.0709 in)**

- If not within wear limit, replace.

### Reverse clutch dish plate






- Check for deformation or damage.

## REPAIR FOR COMPONENT PARTS

### Reverse Clutch (Cont'd)

#### Reverse clutch piston

- Shake piston to assure that balls are not seized.
- Apply compressed air to check ball oil hole opposite the return spring. Make sure there is no air leakage.
- Also apply compressed air to oil hole on return spring side to assure that air leaks past ball.



#### ASSEMBLY

1. Install D-ring and oil seal on piston.
  - Apply ATF to both parts.
2. Install piston assembly by turning it slowly and evenly.
  - Apply ATF to inner surface of drum.
3. Install return springs and spring retainer.
4. Install snap ring while compressing clutch springs.







# REPAIR FOR COMPONENT PARTS

## Reverse Clutch (Cont'd)

- Do not align snap ring gap with spring retainer stopper.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



5. Install drive plates, driven plates, retaining plate and dish plate.
6. Install snap ring.

7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

**Specified clearance:**

**Standard**

0.5 - 0.8 mm (0.020 - 0.031 in)

**Allowable limit**

1.2 mm (0.047 in)

**Retaining plate:**


Refer to SDS, AT-204.

8. Check operation of reverse clutch.  
Refer to "DISASSEMBLY" of Reverse Clutch, AT-158.

High Clutch


SEC. 315

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.




(ATF) : Apply ATF.  
 ★ : Select with proper thickness.

SAT576HB



SAT853A



SAT854A


DISASSEMBLY AND ASSEMBLY

Service procedures for high clutch are essentially the same as those for reverse clutch, with the following exception:


- Check of high clutch operation

# REPAIR FOR COMPONENT PARTS


## High Clutch (Cont'd)




- Removal and installation of return spring



- Inspection of high clutch return springs  
**Inspection standard:**  
Refer to SDS, AT-203.



- Inspection of high clutch drive plate  
**Thickness of drive plate:**  
**Standard**  
1.52 - 1.67 mm (0.0598 - 0.0657 in)  
**Wear limit**  
1.40 mm (0.0551 in)



- Measurement of clearance between retaining plate and snap ring  
**Specified clearance:**  
**Standard**  
1.8 - 2.2 mm (0.071 - 0.087 in)  
**Allowable limit**  
2.8 mm (0.110 in)  
**Retaining plate:**  
Refer to SDS, AT-204.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Forward and Overrun Clutches

SEC. 315



(ATF) : Apply ATF.  
 ★ : Select with proper thickness.

## REPAIR FOR COMPONENT PARTS

### Forward and Overrun Clutches (Cont'd)

#### DISASSEMBLY AND ASSEMBLY

Forward and overrun clutches are serviced essentially the same way as reverse clutch is serviced. However, note the following exceptions.

- Check of forward clutch operation.

GI

MA

EM

LC

EG

FE

CL

MT

- Check of overrun clutch operation.

AT

- Removal of forward clutch drum

Remove forward clutch drum from transmission case by holding snap ring.

TF

PD

FA

- Removal of forward clutch and overrun clutch pistons

1. While holding overrun clutch piston, gradually apply compressed air to oil hole.

RA

BR

ST

RS






2. Remove overrun clutch from forward clutch.

BT

HA


EL

IDX




## REPAIR FOR COMPONENT PARTS


### Forward and Overrun Clutches (Cont'd)




- Removal and installation of return springs




- Inspection of forward clutch and overrun clutch return springs  
**Inspection standard:**  
Refer to SDS, AT-203.



- Inspection of forward clutch drive plates  
**Thickness of drive plate:**  
**Standard**  
1.90 - 2.05 mm (0.0748 - 0.0807 in)  
**Wear limit**  
1.80 mm (0.0709 in)



- Inspection of overrun clutch drive plates  
**Thickness of drive plate:**  
**Standard**  
1.90 - 2.05 mm (0.0748 - 0.0807 in)  
**Wear limit**  
1.80 mm (0.0709 in)




- Installation of forward clutch piston and overrun clutch piston

  1. Install forward clutch piston by turning it slowly and evenly.

- **Apply ATF to inner surface of clutch drum.**

# REPAIR FOR COMPONENT PARTS

## Forward and Overrun Clutches (Cont'd)




- Align notch in forward clutch piston with groove in forward clutch drum.

GI

MA

EM

LC




- Install overrun clutch by turning it slowly and evenly.
- Apply ATF to inner surface of forward clutch piston.

EC

FE

CL

MT



- Measurement of clearance between retaining plate and snap ring of overrun clutch

**Specified clearance:**

**Standard**

1.0 - 1.4 mm (0.039 - 0.055 in)

**Allowable limit**

2.0 mm (0.079 in)

**Retaining plate:**


Refer to SDS, AT-204.

AT

TF

PD

FA



- Measurement of clearance between retaining plate and snap ring of forward clutch

**Specified clearance:**

**Standard**

0.45 - 0.85 mm (0.0177 - 0.0335 in)

**Allowable limit**

1.85 mm (0.0728 in)

**Retaining plate:**

Refer to SDS, AT-204.

RA

BR

ST

RS



BT

HA

EL


IDX

## Low & Reverse Brake



### DISASSEMBLY

1. Check operation of low and reverse brake.
  - a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
  - b. Check to see that retaining plate moves to snap ring.
  - c. If retaining plate does not contact snap ring,
    - D-ring might be damaged.
    - Oil seal might be damaged.
    - Fluid might be leaking past piston check ball.




2. Remove snap ring, low and reverse brake drive plates, driven plates and dish plate.



## REPAIR FOR COMPONENT PARTS

### Low & Reverse Brake (Cont'd)



3. Remove low one-way clutch inner race, spring retainer and return spring from transmission case.
4. Remove seal rings from low one-way clutch inner race.
5. Remove needle bearing from low one-way clutch inner race.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




6. Remove low and reverse brake piston using compressed air.
7. Remove oil seal and D-ring from piston.

### INSPECTION

#### Low and reverse brake snap ring and spring retainer

- Check for deformation, or damage.




#### Low and reverse brake return springs

- Check for deformation or damage. Also measure free length and outside diameter.

**Inspection standard:**

**Refer to SDS, AT-203.**



#### Low and reverse brake drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

**Thickness of drive plate:**

**Standard value**

**1.90 - 2.05 mm (0.0748 - 0.0807 in)**

**Wear limit**

**1.80 mm (0.0709 in)**



- If not within wear limit, replace.

## REPAIR FOR COMPONENT PARTS

### Low & Reverse Brake (Cont'd)

#### Low one-way clutch inner race

- Check frictional surface of inner race for wear or damage.



- Install a new seal rings onto low one-way clutch inner race.
- **Be careful not to expand seal ring gap excessively.**
- Measure seal ring-to-groove clearance.

#### Inspection standard:


Standard value: 0.10 - 0.25 mm (0.0039 - 0.0098 in)

Allowable limit: 0.25 mm (0.0098 in)


- If not within allowable limit, replace low one-way clutch inner race.

### ASSEMBLY


1. Install needle bearing onto one-way clutch inner race.
  - **Pay attention to its direction — Black surface goes to rear side.**
  - **Apply petroleum jelly to needle bearing.**



2. Install oil seal and D-ring onto piston.
  - **Apply ATF to oil seal and D-ring.**




3. Install piston by rotating it slowly and evenly.
  - **Apply ATF to inner surface of transmission case.**



## REPAIR FOR COMPONENT PARTS

### Low & Reverse Brake (Cont'd)



4. Install return springs, spring retainer and low one-way clutch inner race onto transmission case.
5. Install dish plate, low and reverse brake drive plates, driven plates and retaining plate.
6. Install snap ring on transmission case.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX



7. Check operation of low and reverse brake clutch piston. Refer to "DISASSEMBLY", AT-168.



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

**Specified clearance:**

**Standard**


0.7 - 1.1 mm (0.028 - 0.043 in)

**Allowable limit**

2.3 mm (0.091 in)

**Retaining plate:**


Refer to SDS, AT-204.



9. Install low one-way clutch inner race seal ring.
  - Apply petroleum jelly to seal ring.
  - Make sure seal rings are pressed firmly into place and held by petroleum jelly.

## Forward Clutch Drum Assembly


SEC. 315




SAT211GA

### DISASSEMBLY


1. Remove snap ring from forward clutch drum.
2. Remove side plate from forward clutch drum.
3. Remove low one-way clutch from forward clutch drum.
4. Remove snap ring from forward clutch drum.
5. Remove needle bearing from forward clutch drum.



SAT212G



SAT213G




SAT891A

### INSPECTION

#### Forward clutch drum

- Check spline portion for wear or damage.
- Check frictional surfaces of low one-way clutch and needle bearing for wear or damage.








SAT892A

## REPAIR FOR COMPONENT PARTS

### Forward Clutch Drum Assembly (Cont'd)

#### Needle bearing and low one-way clutch

- Check frictional surface for wear or damage.



#### ASSEMBLY

1. Install needle bearing in forward clutch drum.
2. Install snap ring onto forward clutch drum.

3. Install low one-way clutch onto forward clutch drum by pushing the roller in evenly.

- Install low one-way clutch with flange facing rearward.

4. Install side plate onto forward clutch drum.
5. Install snap ring onto forward clutch drum.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Rear Internal Gear and Forward Clutch Hub


SEC. 315



SAT896AA


DISASSEMBLY

1. Remove rear internal gear by pushing forward clutch hub forward.




SAT897A

2. Remove thrust washer from rear internal gear.



SAT898A


3. Remove snap ring from forward clutch hub.




SAT899A

## REPAIR FOR COMPONENT PARTS


### Rear Internal Gear and Forward Clutch Hub (Cont'd)




4. Remove end bearing.



5. Remove forward one-way clutch and end bearing as a unit from forward clutch hub.




6. Remove snap ring from forward clutch hub.



#### INSPECTION

##### Rear internal gear and forward clutch hub

- Check gear for excessive wear, chips or cracks.
- Check frictional surfaces of forward one-way clutch and thrust washer for wear or damage.
- Check spline for wear or damage.



##### Snap ring and end bearing

- Check for deformation or damage.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


## REPAIR FOR COMPONENT PARTS

### Rear Internal Gear and Forward Clutch Hub (Cont'd)


#### ASSEMBLY




1. Install snap ring onto forward clutch hub.
2. Install end bearing.




3. Install forward one-way clutch onto clutch hub.
  - **Install forward one-way clutch with flange facing rearward.**
4. Install end bearing.
5. Install snap ring onto forward clutch hub.



6. Install thrust washer onto rear internal gear.
  - **Apply petroleum jelly to thrust washer.**
  - **Securely insert pawls of thrust washer into holes in rear internal gear.**





7. Position forward clutch hub in rear internal gear.



8. After installing, check to assure that forward clutch hub rotates clockwise.




Band Servo Piston Assembly




**DISASSEMBLY**

1. Block one oil hole in OD servo piston retainer and the center hole in OD band servo piston.
2. Apply compressed air to the other oil hole in piston retainer to remove OD band servo piston from retainer.
3. Remove D-ring from OD band servo piston.



4. Remove band servo piston assembly from servo piston retainer by pushing it forward.



5. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

## REPAIR FOR COMPONENT PARTS


### Band Servo Piston Assembly (Cont'd)




6. Remove servo piston spring retainer, return spring C and piston stem from band servo piston.



7. Remove E-ring from band servo piston.




8. Remove servo cushion spring retainer from band servo piston.
9. Remove D-rings from band servo piston.
10. Remove O-rings from servo piston retainer.



### INSPECTION

#### Pistons, retainers and piston stem

- Check frictional surfaces for abnormal wear or damage.



#### Return springs

- Check for deformation or damage. Measure free length and outer diameter.


#### Inspection standard:

Refer to SDS, AT-203.

# REPAIR FOR COMPONENT PARTS

## Band Servo Piston Assembly (Cont'd)

### ASSEMBLY




1. Install O-rings onto servo piston retainer.
  - Apply ATF to O-rings.
  - Pay attention to position of each O-ring.

GI

MA

EM

LC




2. Install servo cushion spring retainer onto band servo piston.

EC

FE

CL

MT




3. Install E-ring onto servo cushion spring retainer.

AT

TF

PD

FA




4. Install D-rings onto band servo piston.
  - Apply ATF to D-rings.

RA

BR

ST

RS



5. Install servo piston spring retainer, return spring C and piston stem onto band servo piston.

BT


HA

EL


IDX

## REPAIR FOR COMPONENT PARTS


### Band Servo Piston Assembly (Cont'd)




6. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.



7. Install band servo piston assembly onto servo piston retainer by pushing it inward.






8. Install D-ring on OD band servo piston.
- **Apply ATF to D-ring.**



9. Install OD band servo piston onto servo piston retainer by pushing it inward.

Parking Pawl Components



**DISASSEMBLY**


1. Slide return spring to the front of rear extension case flange or adapter case flange.
2. Remove return spring, pawl spacer and parking pawl from rear extension or adapter case.
3. Remove parking pawl shaft from rear extension or adapter case.
4. Remove parking actuator support from rear extension or adapter case.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX  
643


## REPAIR FOR COMPONENT PARTS

### Parking Pawl Components (Cont'd)

#### ASSEMBLY








1. Install parking actuator support onto rear extension or adapter case.
2. Insert parking pawl shaft into rear extension or adapter case.
3. Install return spring, pawl spacer and parking pawl onto parking pawl shaft.



4. Bend return spring upward and install it onto rear extension or adapter case.

# ASSEMBLY



## Assembly (1)

1. Install manual shaft components.
  - a. Install oil seal onto manual shaft.
    - **Apply ATF to oil seal.**
    - **Wrap threads of manual shaft with masking tape.**
  - b. Insert manual shaft and oil seal as a unit into transmission case.
  - c. Remove masking tape.
- d. Push oil seal evenly and install it onto transmission case.
- e. Align groove in shaft with drive pin hole, then drive pin into position as shown in figure at left.
- f. Install detent spring and spacer.
- g. While pushing detent spring down, install manual plate onto manual shaft.
- h. Install lock nuts onto manual shaft.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT






HA

EL

IDX

# ASSEMBLY

## Assembly (1) (Cont'd)



2. Install accumulator piston.
  - a. Install O-rings onto accumulator piston.
    - **Apply ATF to O-rings.**

### Accumulator piston O-rings

Unit: mm (in)

Accumulator	(A)	(B)	(C)	(D)
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

- b. Install return spring for accumulator A onto transmission case.
  - **Free length of return spring:  
Refer to SDS, AT-203.**

- c. Install accumulator pistons (A), (B), (C) and (D).
  - **Apply ATF to transmission case.**






3. Install band servo piston.
  - a. Install return springs onto servo piston.

- b. Install band servo piston onto transmission case.
  - **Apply ATF to O-ring of band servo piston and transmission case.**
- c. Install gasket for band servo onto transmission case.



# ASSEMBLY

## Assembly (1) (Cont'd)



d. Install band servo retainer onto transmission case.

4. Install rear side clutch and gear components.  
a. Place transmission case in vertical position.

b. Slightly lift forward clutch drum assembly. Then slowly rotate it clockwise until its hub passes fully over clutch inner race inside transmission case.

c. Check to be sure that rotation direction of forward clutch assembly is correct.

d. Install thrust washer onto front of overrun clutch hub.  
• Apply petroleum jelly to the thrust washer.  
• Insert pawls of thrust washer securely into holes in overrun clutch hub.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


## ASSEMBLY

### Assembly (1) (Cont'd)


- e. Install overrun clutch hub onto rear internal gear assembly.




- f. Install needle bearing onto rear of overrun clutch hub.  
• Apply petroleum jelly to needle bearing.




- g. Check that overrun clutch hub rotates as shown while holding forward clutch hub.



- h. Place transmission case into horizontal position.




- i. Install rear internal gear, forward clutch hub and overrun clutch hub as a unit onto transmission case.




## ASSEMBLY


### Assembly (1) (Cont'd)



- j. Install needle bearing onto rear internal gear.
- Apply petroleum jelly to needle bearing.



- k. Install bearing race onto rear of front internal gear.
- Apply petroleum jelly to bearing race.
  - Securely engage pawls of bearing race with holes in front internal gear.



- l. Install front internal gear on transmission case.






### Adjustment

When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.

Part name	Total end play	Reverse clutch end play
Transmission case	•	•
Low one-way clutch inner race	•	•
Overrun clutch hub	•	•
Rear internal gear	•	•
Rear planetary carrier	•	•
Rear sun gear	•	•
Front planetary carrier	•	•
Front sun gear	•	•
High clutch hub	•	•
High clutch drum	•	•
Oil pump cover	•	•
Reverse clutch drum	—	•

## ASSEMBLY


### Adjustment (Cont'd)



1. Install front side clutch and gear components.
  - a. Install rear sun gear on transmission case.
    - **Pay attention to its direction.**
  - b. Install needle bearing on front of front planetary carrier.
    - **Apply petroleum jelly to needle bearing.**
  - c. Install needle bearing on rear of front planetary carrier.
    - **Apply petroleum jelly to bearing.**
    - **Pay attention to its direction — Black side goes to front.**
  - d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.
    - **Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.**
  - e. Install bearing races on rear of clutch pack.
    - **Apply petroleum jelly to bearing races.**
    - **Securely engage pawls of bearing race with hole in clutch pack.**

# ASSEMBLY

## Adjustment (Cont'd)



- f. Place transmission case in vertical position.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL


IDX




- g. Install clutch pack into transmission case.



2. Adjust total end play.  
**Total end play "T<sub>1</sub>":**  
0.25 - 0.55 mm (0.0098 - 0.0217 in)




- a. With needle bearing installed, place J34291-1 (bridge), J34291-2 (legs) and the J34291-5 (gauging cylinder) onto oil pump. The long ends of legs should be placed firmly on machined surface of oil pump assembly. The gauging cylinder should rest on top of the needle bearing. Lock gauging cylinder in place with set screw.




- b. Install J34291-23 (gauging plunger) into gauging cylinder.

## ASSEMBLY

### Adjustment (Cont'd)



- c. Install original bearing race inside reverse clutch drum. Place shim selecting gauge with its legs on machined surface of transmission case (no gasket). Allow gauging plunger to rest on bearing race. Lock gauging plunger in place with set screw.



- d. Remove Tool and use feeler gauge to measure gap between gauging cylinder and gauging plunger. This measurement should give exact total end play.


**Total end play "T<sub>1</sub>":**

**0.25 - 0.55 mm (0.0098 - 0.0217 in)**

- If end play is out of specification, decrease or increase thickness of oil pump cover bearing race as necessary.

**Available oil pump cover bearing race:**


**Refer to SDS, AT-205.**




3. Adjust reverse clutch drum end play.

**Reverse clutch drum end play "T<sub>2</sub>":**

**0.55 - 0.90 mm (0.0217 - 0.0354 in)**




- a. Place J34291-1 (bridge), J34291-2 (legs) and J34291-5 (gauging cylinder) on machined surface of transmission case (no gasket). Allow gauging cylinder to rest on front thrust surface of reverse clutch drum. Lock cylinder in place with set screw.



- b. Install J34291-23 (gauging plunger) into gauging cylinder.

## ASSEMBLY

### Adjustment (Cont'd)



- c. Install original thrust washer on oil pump. Place shim setting gauge legs onto machined surface of oil pump assembly. Allow gauging plunger to rest on thrust washer. Lock plunger in place with set screw.

GI

MA

EM


LC

EC

FE

CL

MT



- d. Use feeler gauge to measure gap between gauging plunger and gauging cylinder. This measurement should give you exact reverse clutch drum end play.

#### Reverse clutch drum end play "T<sub>2</sub>":

0.55 - 0.90 mm (0.0217 - 0.0354 in)


- If end play is out of specification, decrease or increase thickness of oil pump thrust washer as necessary.

#### Available oil pump thrust washer:

Refer to SDS, AT-205.

AT

### Assembly (2)



1. Install output shaft and parking gear.
  - a. Insert output shaft from rear of transmission case while slightly lifting front internal gear.
- **Do not force output shaft against front of transmission case.**

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




- b. Carefully push output shaft against front of transmission case. Install snap ring on front of output shaft.
- **Check to be sure output shaft cannot be removed in rear direction.**

BT

HA

EL


IDX




- c. Install needle bearing on transmission case.
- **Pay attention to its direction — Black side goes to rear.**
  - **Apply petroleum jelly to needle bearing.**

## ASSEMBLY

### Assembly (2) (Cont'd)




d. Install parking gear on transmission case.



e. Install snap ring on rear of output shaft.


- **Check to be sure output shaft cannot be removed in forward direction.**



2. Install rear extension or adapter case.

a. Install oil seal on rear extension or adapter case.


- **Apply ATF to oil seal.**



b. Install O-ring on revolution sensor.

- **Apply ATF to O-ring.**

c. Install revolution sensor on rear extension or adapter case.




d. Install rear extension gasket on transmission case.




# ASSEMBLY


## Assembly (2) (Cont'd)



e. Install parking rod on transmission case.




f. Install rear extension or adapter case on transmission case.



3. Install front side clutch and gear components.

a. Install rear sun gear on transmission case.

- Pay attention to its direction.



b. Make sure needle bearing is on front of front planetary carrier.

- Apply petroleum jelly to needle bearing.

c. Make sure needle bearing is on rear of front planetary carrier.

- Apply petroleum jelly to bearing.
- Pay attention to its direction — Black side goes to front.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

## ASSEMBLY


### Assembly (2) (Cont'd)




- d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.




- Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.



- e. Make sure bearing races are on front and rear of clutch pack.
- Apply petroleum jelly to bearing races.
  - Securely engage pawls of bearing races with holes in clutch pack.




- f. Install clutch pack into transmission case.




4. Install brake band and band strut.
- a. Install band strut on brake band.
- Apply petroleum jelly to band strut.

# ASSEMBLY


## Assembly (2) (Cont'd)




- b. Place brake band on periphery of reverse clutch drum, and insert band strut into end of band servo piston stem.




- c. Install anchor end bolt on transmission case. Then, tighten anchor end bolt just enough so that reverse clutch drum (clutch pack) will not tilt forward.



5. Install input shaft on transmission case.  
• **Pay attention to its direction — O-ring groove side is front.**  
6. Install gasket on transmission case.



7. Install oil pump assembly.  
a. Install needle bearing on oil pump assembly.  
• **Apply petroleum jelly to the needle bearing.**  
b. Install selected thrust washer on oil pump assembly.  
• **Apply petroleum jelly to thrust washer.**



- c. Carefully install seal rings into grooves and press them into the petroleum jelly so that they are a tight fit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

## ASSEMBLY


### Assembly (2) (Cont'd)




- d. Install O-ring on oil pump assembly.
- **Apply petroleum jelly to O-ring.**




- e. Apply petroleum jelly to mating surface of transmission case and oil pump assembly.



- f. Install oil pump assembly.
- **Install two converter housing securing bolts in bolt holes in oil pump assembly as guides.**








- **Insert oil pump assembly to the specified position in transmission, as shown at left.**



8. Install O-ring on input shaft.
- **Apply ATF to O-rings.**

## ASSEMBLY

### Assembly (2) (Cont'd)



9. Install converter housing.
  - a. Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to outer periphery of bolt holes in converter housing.
    - **Do not apply too much sealant.**

- b. Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to seating surfaces of bolts that secure front of converter housing.
    - c. Install converter housing on transmission case.

10. Adjust brake band.
  - a. Tighten anchor end bolt to specified torque.


**Anchor end bolt:**  
☑ : 4 - 6 N·m  
(0.4 - 0.6 kg-m, 35 - 52 in-lb)
  - b. Back off anchor end bolt two and a half turns.

- c. While holding anchor end pin, tighten lock nut.


11. Install terminal cord assembly.
  - a. Install O-ring on terminal cord assembly.
    - **Apply petroleum jelly to O-ring.**
  - b. Compress terminal cord assembly stopper and install terminal cord assembly on transmission case.

# ASSEMBLY


## Assembly (2) (Cont'd)




12. Install control valve assembly.
- a. Install accumulator piston return springs (B), (C) and (D).  
**Free length of return springs:  
Refer to SDS, AT-203.**




- b. Install manual valve on control valve.
- **Apply ATF to manual valve.**



- c. Place control valve assembly on transmission case. Connect solenoid connector for upper body.
- d. Install connector clip.




- e. Install control valve assembly on transmission case.
- f. Install connector tube brackets and tighten bolts (A) and (B).  
• **Check that terminal assembly does not catch.**

Bolt symbol	l mm (in)  l
(A)	33 (1.30)
(B)	45 (1.77)

## ASSEMBLY

### Assembly (2) (Cont'd)



- g. Install O-ring on oil strainer.
  - **Apply petroleum jelly to O-ring.**
- h. Install oil strainer on control valve.

GI

MA

EM

LC

EC

FE

CL

WT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL


IDX




- i. Securely fasten terminal harness with clips.



- j. Install torque converter clutch solenoid valve and fluid temperature sensor connectors.




- 13. Install oil pan.
  - a. Attach a magnet to oil pan.




- b. Install new oil pan gasket on transmission case.
- c. Install oil pan and bracket on transmission case.
  - **Always replace oil pan bolts as they are self-sealing bolts.**
  - **Before installing bolts, remove traces of sealant and oil from mating surface and thread holes.**
  - **Tighten four bolts in a criss-cross pattern to prevent dislocation of gasket.**
- d. Tighten drain plug.

## ASSEMBLY


### Assembly (2) (Cont'd)




14. Install inhibitor switch.
  - a. Check that manual shaft is in "1" position.
  - b. Temporarily install inhibitor switch on manual shaft.
  - c. Move manual shaft to "N".




- d. Tighten bolts while inserting 4.0 mm (0.157 in) dia. pin vertically into locating holes in inhibitor switch and manual shaft.



15. Install torque converter.
  - a. Pour ATF into torque converter.
    - **Approximately 2 liters (2-1/8 US qt, 1-3/4 Imp qt) of fluid are required for a new torque converter.**
    - **When reusing old torque converter, add the same amount of fluid as was drained.**



- b. Install torque converter while aligning notches and oil pump.





- c. Measure distance A to check that torque converter is in proper position.

**Distance "A":**  
**26.0 mm (1.024 in) or more**



## A/T Fluid Cooler



### REMOVAL AND INSTALLATION

1. Remove front radiator grill. Refer to BT section ("BODY END").
2. Disconnect fluid hoses from fluid cooler unit.
3. Remove fluid cooler unit.
4. Remove fluid cooler bracket.
5. Remove clips securing fluid hose (cooler unit to radiator) and loosen hose clamps, then remove the fluid hose.
6. Loosen clamps securing fluid hose (A/T assembly to fluid cooler), then remove the fluid hose.
7. Remove bolts securing fluid cooler tube bracket.
8. Remove fluid hose with bracket.
  - Reverse the removal procedure to install the A/T fluid cooler unit. Refer to the component drawing and specified tightening torque.
  - Check A/T fluid level and refill if necessary. Refer to MA section ("CHASSIS AND BODY MAINTENANCE").

# SERVICE DATA AND SPECIFICATIONS (SDS)

## General Specifications

Applied model	VG33E engine	
	2WD	4WD
Automatic transmission model	RE4R01A	
Transmission model code number	44X19	44X20
Stall torque ratio	2.0 : 1	
Transmission gear ratio		
1st	2.785	
2nd	1.545	
Top	1.000	
OD	0.694	
Reverse	2.272	
Recommended oil	Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada)*1	
Oil capacity ( US qt, Imp qt)	8.3 (8-3/4, 7-1/4)	8.5 (9, 7-1/2)

\*1: Refer to MA section ("Fluids and Lubricants", "RECOMMENDED FLUIDS AND LUBRICANTS").

## Specifications and Adjustment

### VEHICLE SPEED WHEN SHIFTING GEARS

#### 2WD, 4WD (Final gear ratio: 4.363) and 4WD (Final gear ratio: 4.636)

Throttle position	Vehicle speed km/h (MPH)						
	D <sub>1</sub> → D <sub>2</sub>	D <sub>2</sub> → D <sub>3</sub>	D <sub>3</sub> → D <sub>4</sub>	D <sub>4</sub> → D <sub>3</sub>	D <sub>3</sub> → D <sub>2</sub>	D <sub>2</sub> → D <sub>1</sub>	1 <sub>2</sub> → 1 <sub>1</sub>
Full throttle	48 - 52 (30 - 32)	93 - 101 (58 - 63)	148 - 158 (92 - 98)	143 - 153 (89 - 95)	88 - 96 (55 - 60)	43 - 47 (27 - 29)	44 - 48 (27 - 30)
Half throttle	35 - 39 (22 - 24)	61 - 67 (38 - 42)	134 - 142 (83 - 88)	85 - 93 (53 - 58)	32 - 38 (20 - 24)	10 - 14 (6 - 9)	44 - 48 (27 - 30)

### VEHICLE SPEED WHEN PERFORMING AND RELEASING LOCK-UP

#### 2WD, 4WD (Final gear ratio: 4.363) and 4WD (Final gear ratio: 4.636)

Throttle position	Overdrive control switch [Shift position]	Vehicle speed km/h (MPH)	
		Lock-up "ON"	Lock-up "OFF"
Full throttle	ON [D <sub>4</sub> ]	149 - 157 (93 - 98)	144 - 152 (89 - 94)
	OFF [D <sub>3</sub> ]	93 - 101 (58 - 63)	88 - 96 (55 - 60)
Half throttle	ON [D <sub>4</sub> ]	141 - 149 (88 - 93)	85 - 93 (53 - 58)
	OFF [D <sub>3</sub> ]	74 - 82 (46 - 51)	71 - 79 (44 - 49)

### STALL REVOLUTION

Stall revolution	rpm	2,440 - 2,690
------------------	-----	---------------

### LINE PRESSURE

Engine speed rpm	Line pressure kPa (kg/cm <sup>2</sup> , psi)	
	D, 2 and 1 positions	R position
Idle	422 - 461 (4.3 - 4.7, 61 - 67)	667 - 706 (6.8 - 7.2, 97 - 102)
Stall	1,020 - 1,098 (10.4 - 11.2, 148 - 159)	1,422 - 1,500 (14.5 - 15.3, 206 - 218)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## Specifications and Adjustment (Cont'd)

### RETURN SPRINGS

Unit: mm (in)

Parts		Item			
		Part No.	Free length	Outer diameter	
Control valve	Upper body	Torque converter relief valve spring	31742-41X23	38.0 (1.496)	9.0 (0.354)
		Pressure regulator valve spring	31742-41X24	44.02 (1.7331)	14.0 (0.551)
		Pressure modifier valve spring	31742-41X19	31.95 (1.2579)	6.8 (0.268)
		Accumulator control valve spring	—	—	—
		Shuttle shift valve D spring	31762-41X00	26.5 (1.043)	5.75 (0.2264)
		4-2 sequence valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve B spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
		4-2 relay valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve A spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
		Overrun clutch control valve spring	31762-41X03	23.6 (0.929)	7.0 (0.276)
		Overrun clutch reducing valve spring	31742-41X20	32.5 (1.280)	7.0 (0.276)
		Shuttle shift valve S spring	31762-41X04	51.0 (2.008)	5.65 (0.2224)
		Pilot valve spring	31742-41X13	25.7 (1.012)	9.0 (0.354)
	Lock-up control valve spring	31742-41X22	18.5 (0.728)	13.0 (0.512)	
		Lower body	Modifier accumulator valve spring	31742-27X70	31.4 (1.236)
	1st reducing valve spring		31756-41X05	25.4 (1.000)	6.75 (0.2657)
	3-2 timing valve spring		31742-41X06	23.0 (0.906)	6.7 (0.264)
	Servo charger valve spring		31742-41X06	23.0 (0.906)	6.7 (0.264)
Reverse clutch	16 pcs	31505-41X02	19.69 (0.7752)	11.6 (0.457)	
High clutch	16 pcs	31505-21X03	22.06 (0.8685)	11.6 (0.457)	
Forward clutch (Overrun clutch)	20 pcs	31521-41X00	35.77 (1.4083)	9.7 (0.382)	
Low & reverse brake	18 pcs	31505-41X05	22.3 (0.878)	11.6 (0.457)	
Band servo	Spring (A)	31605-41X05	45.6 (1.795)	34.3 (1.350)	
	Spring (B)	31605-41X00	53.8 (2.118)	40.3 (1.587)	
	Spring (C)	31605-41X01	29.7 (1.169)	27.6 (1.087)	
Accumulator	Accumulator (A)	31605-41X02	43.0 (1.693)	—	
	Accumulator (B)	31605-41X10	66.0 (2.598)	—	
	Accumulator (C)	31605-41X09	45.0 (1.772)	—	
	Accumulator (D)	31605-41X06	58.4 (2.299)	—	

### ACCUMULATOR O-RING

Accumulator	Diameter mm (in)			
	(A)	(B)	(C)	(D)
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## Specifications and Adjustment (Cont'd)

### CLUTCHES AND BRAKES

Code number		44X19	44X20
<b>Reverse clutch</b>			
Number of drive plates		2	
Number of driven plates		2	
Thickness of drive plate mm (in)	Standard	1.90 - 2.05 (0.0748 - 0.0807)	
	Wear limit	1.80 (0.0709)	
Clearance mm (in)	Standard	0.5 - 0.8 (0.020 - 0.031)	
	Allowable limit	1.2 (0.047)	
Thickness of retaining plate	Thickness mm (in)	Part number	
	4.8 (0.189)	31537-42X02	
	5.0 (0.197)	31537-42X03	
	5.2 (0.205)	31537-42X04	
	5.4 (0.213)	31537-42X05	
	5.6 (0.220)	31537-42X06	
	<b>High clutch</b>		
Number of drive plates		5	
Number of driven plates		5	
Thickness of drive plate mm (in)	Standard	1.52 - 1.67 (0.0598 - 0.0657)	
	Wear limit	1.40 (0.0551)	
Clearance mm (in)	Standard	1.8 - 2.2 (0.071 - 0.087)	
	Allowable limit	2.8 (0.110)	
Thickness of retaining plate	Thickness mm (in)	Part number	
	3.4 (0.134)	31537-41X71	
	3.6 (0.142)	31537-41X61	
	3.8 (0.150)	31537-41X62	
	4.0 (0.157)	31537-41X63	
	4.2 (0.165)	31537-41X64	
	4.4 (0.173)	31537-41X65	
	4.6 (0.181)	31537-41X66	
	4.8 (0.189)	31537-41X67	
	<b>Forward clutch</b>		
Number of drive plates		6	
Number of driven plates		6	
Thickness of drive plate mm (in)	Standard	1.90 - 2.05 (0.0748 - 0.0807)	
	Wear limit	1.80 (0.0709)	
Clearance mm (in)	Standard	0.45 - 0.85 (0.0177 - 0.0335)	
	Allowable limit	1.85 (0.0728)	
Thickness of retaining plate	Thickness mm (in)	Part number	
	8.0 (0.315)	31537-41X00	
	8.2 (0.323)	31537-41X01	
	8.4 (0.331)	31537-41X02	
	8.6 (0.339)	31537-41X03	
	8.8 (0.346)	31537-41X04	
	9.2 (0.362)	31537-41X06	

Code number		44X19	44X20
<b>Overrun clutch</b>			
Number of drive plates		3	
Number of driven plates		5	
Thickness of drive plate mm (in)	Standard	1.90 - 2.05 (0.0748 - 0.0807)	
	Wear limit	1.80 (0.0709)	
Clearance mm (in)	Standard	1.0 - 1.4 (0.039 - 0.055)	
	Allowable limit	2.0 (0.079)	
Thickness of retaining plate	Thickness mm (in)	Part number	
	4.2 (0.165)	31537-41X80	
	4.4 (0.173)	31537-41X81	
	4.6 (0.181)	31537-41X82	
	4.8 (0.189)	31537-41X83	
	5.0 (0.197)	31537-41X84	
<b>Low &amp; reverse brake</b>			
Number of drive plates		7	
Number of driven plates		7	
Thickness of drive plate mm (in)	Standard	1.90 - 2.05 (0.0748 - 0.0807)	
	Wear limit	1.80 (0.0709)	
Clearance mm (in)	Standard	0.7 - 1.1 (0.028 - 0.043)	
	Allowable limit	2.3 (0.091)	
Thickness of retaining plate	Thickness mm (in)	Part number	
	6.8 (0.268)	31667-41X11	
	7.0 (0.276)	31667-41X12	
	7.2 (0.283)	31667-41X13	
	7.4 (0.291)	31667-41X14	
	7.6 (0.299)	31667-41X07	
	7.8 (0.307)	31667-41X08	
	8.0 (0.315)	31667-41X00	
	8.2 (0.323)	31667-41X01	
	8.4 (0.331)	31667-41X02	
	8.6 (0.339)	31667-41X03	
	8.8 (0.346)	31667-41X04	
9.0 (0.354)	31667-41X05		
<b>Brake band</b>			
Anchor end bolt tightening torque		4 - 6 (0.4 - 0.6, 35 - 52)	
		N-m (kg-m, in-lb)	
Number of returning revolution for anchor end bolt		2.5	

# SERVICE DATA AND SPECIFICATIONS (SDS)

## Specifications and Adjustment (Cont'd)

### OIL PUMP AND LOW ONE-WAY CLUTCH

Oil pump clearance	mm (in)	
Cam ring — oil pump housing		
Standard		0.01 - 0.024 (0.0004 - 0.0009)
Rotor, vanes and control piston — oil pump housing		
Standard		0.03 - 0.044 (0.0012 - 0.0017)
Seal ring clearance	mm (in)	
Standard		0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit		0.25 (0.0098)

### TOTAL END PLAY

Total end play "T <sub>1</sub> "	0.25 - 0.55 mm (0.0098 - 0.0217 in)	
Thickness of oil pump cover bearing race	Thickness mm (in)	Part number
	0.8 (0.031)	31435-41X01
	1.0 (0.039)	31435-41X02
	1.2 (0.047)	31435-41X03
	1.4 (0.055)	31435-41X04
	1.6 (0.063)	31435-41X05
	1.8 (0.071)	31435-41X06
2.0 (0.079)	31435-41X07	

### REVERSE CLUTCH DRUM END PLAY

Reverse clutch drum end play "T <sub>2</sub> "	0.55 - 0.90 mm (0.0217 - 0.0354 in)	
Thickness of oil pump thrust washer	Thickness mm (in)	Part number
	0.9 (0.035)	31528-21X01
	1.1 (0.043)	31528-21X02
	1.3 (0.051)	31528-21X03
	1.5 (0.059)	31528-21X04
	1.7 (0.067)	31528-21X05
1.9 (0.075)	31528-21X06	

### REMOVAL AND INSTALLATION

Manual control linkage	
Number of returning revolutions for lock nut	2
Lock nut tightening torque N-m (kg-m, in-lb)	4.4 - 5.9 (0.45 - 0.60, 39.1 - 52.1)
Distance between end of clutch housing and torque converter mm (in)	26.0 (1.024) or more

GI

MA

EM

LC

FC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX