

## SECTION **EL**

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

## CONTENTS

<b>PRECAUTIONS</b> .....	2	Wiring Diagram (For USA) — H/LAMP — .....	42
Supplemental Restraint System (SRS) "AIR BAG" .....	2	Trouble Diagnoses (For USA) .....	43
<b>HARNESS CONNECTOR</b> .....	3	Daytime Light System/System Description (For Canada) .....	44
Description .....	3	Operation (Daytime light system for Canada) .....	45
<b>STANDARDIZED RELAY</b> .....	4	Schematic (For Canada) .....	46
Description .....	4	Wiring Diagram (For Canada) — DTRL — .....	47
<b>POWER SUPPLY ROUTING</b> .....	6	Trouble Diagnoses (For Canada) .....	50
Schematic .....	6	Bulb Replacement .....	51
Wiring Diagram — POWER — .....	7	Bulb Specifications .....	51
Fuse .....	18	Aiming Adjustment .....	51
Fusible Link .....	18	<b>EXTERIOR LAMP</b> .....	53
Circuit Breaker Inspection .....	18	Parking, License and Tail Lamps/Schematic .....	53
<b>GROUND DISTRIBUTION</b> .....	19	Parking, License and Tail Lamps/Wiring Diagram — TAIL/L — .....	54
<b>BATTERY</b> .....	22	Stop Lamp/Wiring Diagram — STOP/L — .....	57
How to Handle Battery .....	22	Back-up Lamp/Wiring Diagram — BACK/L — .....	59
Service Data and Specifications (SDS) .....	25	Front Fog Lamp/System Description .....	61
<b>STARTING SYSTEM</b> .....	26	Front Fog Lamp/Wiring Diagram — F/FOG — .....	62
System Description .....	26	Front Fog Lamp Aiming Adjustment .....	63
Wiring Diagram — START — .....	28	Bulb Specifications .....	63
Construction .....	31	Turn Signal and Hazard Warning Lamps/System Description .....	64
Removal and Installation .....	31	Turn Signal and Hazard Warning Lamps/Schematic .....	66
Pinion/Clutch Check .....	32	Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — .....	67
Service Data and Specifications (SDS) .....	32	Turn Signal and Hazard Warning Lamps/Trouble Diagnoses .....	70
<b>CHARGING SYSTEM</b> .....	33	Combination Flasher Unit Check .....	70
System Description .....	33	Bulb Specifications .....	71
Wiring Diagram — CHARGE — .....	34	<b>INTERIOR LAMP</b> .....	72
Trouble Diagnoses .....	35	Illumination/System Description .....	72
Construction .....	36	Illumination/Schematic .....	73
Removal and Installation .....	36	Illumination/Wiring Diagram — ILL — .....	74
Service Data and Specifications (SDS) .....	37	Interior, Spot and Luggage Room Lamps/System Description .....	78
<b>COMBINATION SWITCH</b> .....	38		
Combination Switch/Check .....	38		
Replacement .....	39		
Steering Switch/Check .....	40		
<b>HEADLAMP</b> .....	41		
System Description (For USA) .....	41		

# CONTENTS (Cont'd)

Bulb Specifications .....	78	Audio (With speaker amp.)/Wiring Diagram	
Interior, Spot and Luggage Room Lamps/ Schematic .....	79	— AUDIO — .....	140
Interior, Spot and Luggage Room Lamps/ Wiring Diagram — INT/L — .....	80	Audio (Without speaker amp.)/Wiring Diagram	
<b>METER AND GAUGES</b> .....	83	— AUDIO — .....	144
System Description .....	83	Audio (BOSE system)/Schematic .....	146
Combination Meter .....	84	Audio (BOSE system)/Wiring Diagram	
Combination Meter, Compass and Thermometer/Schematic .....	85	— AUDIO — .....	147
Combination Meter, Compass and Thermometer/Wiring Diagram — METER — .....	86	Power Antenna/System Description .....	151
Trouble Diagnoses .....	89	Power Antenna/Wiring Diagram — P/ANT — .....	152
<b>WARNING LAMPS</b> .....	95	Trouble Diagnoses .....	153
Warning Lamps/Schematic .....	95	Location of Antenna .....	155
Warning Lamps/Wiring Diagram — WARN — .....	96	Antenna Rod Replacement .....	156
Electrical Components Inspection .....	103	<b>POWER SUNROOF</b> .....	157
<b>WARNING BUZZER</b> .....	104	Wiring Diagram — SROOF — .....	157
Warning Buzzer/System Description .....	104	<b>DOOR MIRROR</b> .....	158
Warning Buzzer/Wiring Diagram — BUZZER — .....	105	Wiring Diagram — MIRROR — .....	158
Trouble Diagnoses .....	107	<b>POWER SEAT</b> .....	159
<b>WIPER AND WASHER</b> .....	111	Power Seat/Wiring Diagram — SEAT — .....	159
System Description .....	111	<b>HEATED SEAT</b> .....	161
Front Wiper and Washer/Wiring Diagram		Heated Seat/Wiring Diagram — HSEAT — .....	161
— WIPER — .....	113	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	162
Trouble Diagnoses .....	115	Component Parts and Harness Connector	
Wiper Installation and Adjustment .....	117	Location .....	162
Washer Nozzle Adjustment .....	117	System Description .....	163
Washer Tube Layout .....	118	Schematic .....	165
Wiper Linkage .....	118	Wiring Diagram — ASCD — .....	166
Rear Wiper and Washer/System Description .....	119	Trouble Diagnoses .....	171
Rear Wiper and Washer/Schematic .....	121	ASCD Wire Adjustment .....	181
Rear Wiper and Washer/Wiring Diagram		<b>POWER WINDOW</b> .....	182
— WIP/R — .....	122	System Description .....	182
Rear Wiper/Trouble Diagnoses .....	125	Schematic .....	184
Rear Wiper Installation and Adjustment .....	125	Wiring Diagram — WINDOW — .....	185
Rear Washer Nozzle Adjustment .....	126	Trouble Diagnoses .....	189
Washer Tube Layout .....	126	<b>POWER DOOR LOCK</b> .....	190
Check Valve (for rear washer) .....	126	System Description .....	190
<b>HORN AND CIGARETTE LIGHTER</b> .....	127	Schematic .....	192
Schematic .....	127	Wiring Diagram — D/LOCK — .....	193
Wiring Diagram — HORN — .....	128	Trouble Diagnoses .....	196
<b>REAR WINDOW DEFOGGER</b> .....	131	<b>MULTI-REMOTE CONTROL SYSTEM</b> .....	199
System Description .....	131	System Description .....	199
Wiring Diagram — DEF — .....	132	Schematic .....	201
Trouble Diagnoses .....	134	Wiring Diagram — MULTI — .....	202
Filament Check .....	135	Trouble Diagnoses .....	206
Filament Repair .....	136	Replacing Remote Controller or Control Unit .....	213
<b>AUDIO AND POWER ANTENNA</b> .....	138	<b>THEFT WARNING SYSTEM</b> .....	214
Audio/System Description .....	138	Component Parts and Harness Connector	
Audio (With speaker amp.)/Schematic .....	139	Location .....	214
		System Description .....	215
		Schematic .....	218
		Wiring Diagram — THEFT — .....	220
		Trouble Diagnoses .....	226
		<b>SMART ENTRANCE CONTROL UNIT</b> .....	239

# CONTENTS (Cont'd)

Description .....	239	Body Harness RH.....	257	CI
Schematic .....	240	Back Door Harness .....	258	
Input/Output Operation Signal .....	242	Engine and Transmission Harness.....	259	MA
<b>INTEGRATED HOMELINK TRANSMITTER</b> .....	243	Room Lamp .....	260	
Wiring Diagram — TRNSMT — .....	243	Air Bag Harness .....	261	
Trouble Diagnoses.....	244	Door Harness (LH side).....	262	EM
<b>LOCATION OF ELECTRICAL UNITS</b> .....	245	Door Harness (RH side).....	263	
Engine Compartment.....	245	<b>SUPER MULTIPLE JUNCTION (SMJ)</b> .....	Foldout	
Passenger Compartment.....	246	Terminal Arrangement.....	Foldout	LC
<b>HARNESS LAYOUT</b> .....	248	<b>FUSE BLOCK — Junction Box (J/B)</b> .....	Foldout	
Outline.....	248	Terminal Arrangement.....	Foldout	EC
How to Read Harness Layout .....	249	<b>FUSE AND FUSIBLE LINK BOX</b> .....	Foldout	
Main Harness.....	250	Terminal Arrangement.....	Foldout	FE
Engine Room Harness .....	252	<b>ELECTRICAL UNITS</b> .....	Foldout	
Engine Control Harness .....	254	Terminal Arrangement.....	Foldout	GL
Body Harness LH .....	256			

## WIRING DIAGRAM REFERENCE CHART

ECSS .....	EC SECTION	
A/T CONTROL, SHIFT LOCK CONTROL .....	AT SECTION	MT
ANTI-LOCK BRAKE SYSTEM .....	BR SECTION	
SRS "AIR BAG" .....	RS SECTION	
HEATER AND AIR CONDITIONER .....	HA SECTION	AT

TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA

**EL**

INDEX

## PRECAUTIONS

---

### Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

# HARNESS CONNECTOR

## Description


### HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

#### CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

SEL769D

EL


IDX

# STANDARDIZED RELAY

## Description

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

### TYPE OF STANDARDIZED RELAYS













1M ..... 1 Make      2M ..... 2 Make  
 1T ..... 1 Transfer      1M-1B ..... 1 Make 1 Break



SEL882H

# STANDARDIZED RELAY

## Description (Cont'd)


Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# POWER SUPPLY ROUTING

## Schematic







# POWER SUPPLY ROUTING

## Wiring Diagram — POWER —

EL-POWER-01





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-02





Refer to last page (Foldout page).

(E1) . (M1)

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-03





GI  
MA  
EV  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)


EL-POWER-04



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-05



Refer to last page (Foldout page).

- (E2)
- (E3)
- (M10)
- (M81)
- (M91)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


**EL**

IDX

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-06



Refer to last page (Foldout page).

(E2)

(E4)


(M10)

(M91)

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-07



Refer to last page (Foldout page).

(E4)

(M10)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


**EL**

IDX

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-08



Refer to last page (Foldout page).

E3


M10



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-09



Refer to last page (Foldout page).

- (E3)
- (E4)
- (M10)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

**EL**

IDX

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)



Refer to last page (Foldout page).

(E3)


(M10)

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-11

To EL-POWER-04



Refer to last page (Foldout page).

- (E3)
- (M10)
- (M91)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

**EL**


IDX

# POWER SUPPLY ROUTING



## Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




## Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

### CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



## Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Warning buzzer
- Power window & power door lock
- Power sunroof
- Power seat
- Multi-remote control system
- Theft warning system

# GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
M4/M66	A/C MODE SWITCH	M39	HA-A/C, A	GI
	ASCD CONTROL UNIT	M3	EL-ASCD	
	ASCD MAIN SWITCH	M18	EL-ASCD	
	CLUTCH INTERLOCK SWITCH	M28	EL-START	MA
	COMBINATION FLASHER UNIT	M15	EL-TURN	
	DOOR MIRROR REMOTE CONTROL SWITCH	M17	EL-MIRROR	
	FAN SWITCH	M43	EC-AC/SIG HA-HEATER	EM
	POWER ANTENNA	M69	EL-P/ANT	
	POWER WINDOW RELAY	M23	EL-SROOF EL-WINDOW	LC
	REAR WIPER SWITCH	M50	EL-WIP/R	
	REAR WINDOW DEFOGGER SWITCH	M36	EL-DEF	
	RECIRCULATION SWITCH	M42	HA-HEATER HA-A/C, M HA-A/C, A	EC
	DOOR LOCK AND UNLOCK SWITCH RH	D38	EL-D/LOCK	
	DOOR MIRROR DEFOGGER LH (Models without power window)	D1	EL-DEF	FE
	DOOR MIRROR DEFOGGER RH	D31	EL-DEF	
	FRONT DOOR KEY CYLINDER SWITCH RH	D39	EL-THEFT	CL
	AIR BAG DIAGNOSIS SENSOR UNIT	Z4	RS-SRS	
M4/M77	ABS ACTUATOR	M74	BR-ABS	
	A/C AUTO AMP.	M40	HA-A/C, A	MT
	COMBINATION METER (AIR BAG)	M26	RS-SRS EL-WARN	
	COMBINATION METER (CRUISE INDICATOR)	M26	EL-WARN EL-ASCD	
	COMBINATION METER (FUEL GAUGE)	M25	EL-METER	AT
	COMBINATION METER (4WD INDICATOR)	M26	EL-WARN	
	COMBINATION METER (HIGH BEAM INDICATOR)	M26	EL-H/LAMP EL-DTRL	TF
	COMBINATION METER (SPEEDOMETER)	M25	EC-VSS AT-A/T EL-METER EL-ASCD	
	COMBINATION METER (TACHOMETER)	M26	AT-A/T EL-METER	PD
	COMBINATION METER (TURN SIGNAL)	M26	EL-TURN	
	COMBINATION METER (WATER TEMPERATURE GAUGE)	M25	EL-METER	FA
	CIGARETTE LIGHTER SOCKET	M56	EL-HORN	
	DATA LINK CONNECTOR FOR CONSULT	M11	EC-MIL/DL AT-A/T	
	DATA LINK CONNECTOR FOR GST	M9	EC-MIL/DL	RA
	FAN CONTROL AMP.	M60	HA-A/C, A	
	FAN SWITCH	M43	HA-A/C, M HA-A/C, A	BR
	FRONT WIPER AMP.	M79	EL-WIPER	
	FRONT WIPER MOTOR	M78	EL-WIPER	
	FUSE BLOCK (BLOWER MOTOR RELAY)	M10	EL-POWER	ST
	HEATED SEAT SWITCH LH	M52	EL-HSEAT	
	HEATED SEAT SWITCH RH	M53	EL-HSEAT	
	ILLUMINATION CONTROL SWITCH	M19	EL-ILL	RS
	SMART ENTRANCE CONTROL UNIT	M16	EL-BUZZER EL-D/LOCK EL-MULTI EL-THEFT	
	COMPASS AND THERMOMETER	R4	EL-ILL EL-METER	BT
	INTEGRATED HOMELINK™ TRANSMITTER	R5	EL-TRNSMT	
	SPOT LAMP	R6	EL-INT/L	HA
	VANITY MIRROR LH (ILLUMINATION)	R5	EL-ILL	
	VANITY MIRROR RH (ILLUMINATION)	R3	EL-ILL	
	DOOR MIRROR DEFOGGER LH (Models with power window)	D1	EL-DEF	EL
	FRONT DOOR KEY CYLINDER SWITCH LH	D9	EL-THEFT	
	FRONT DOOR LOCK ACTUATOR LH	D7	EL-D/LOCK EL-MULTI EL-THEFT	
	FRONT DOOR LOCK ACTUATOR RH	D37	EL-D/LOCK EL-MULTI EL-THEFT	IDX

## GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE
M4/M77	POWER WINDOW MAIN SWITCH	D6	EL-WINDOW EL-D/LOCK
	ABS CONTROL UNIT	M54 M95	BR-ABS
	SHIELD WIRE (FRONT WHEEL SENSOR LH)	E14	BR-ABS
	SHIELD WIRE (FRONT WHEEL SENSOR RH)	E51	BR-ABS
	SHIELD WIRE (REAR WHEEL SENSOR LH)	B69	BR-ABS
	SHIELD WIRE (REAR WHEEL SENSOR RH)	B8	BR-ABS
E13/E41	AMBIENT AIR TEMPERATURE SWITCH	E34	EC-FICD HA-A/C, M HA-A/C, A
	ASCD HOLD RELAY	E22	EL-ASCD
	ATP RELAY	E86	EL-WARN
	BRAKE FLUID LEVEL SWITCH	E28	EL-WARN
	DAYTIME LIGHT CONTROL UNIT	E45	EL-DTRL
	FRONT FOG LAMP LH	E61	EL-F/FOG
	FRONT FOG LAMP RH	E62	EL-F/FOG
	FRONT FOG LAMP SWITCH	E63	EL-F/FOG
	FRONT TURN SIGNAL LAMP LH	E30	EL-TURN
	FRONT TURN SIGNAL LAMP RH	E39	EL-TURN
	FRONT WASHER MOTOR	E44	EL-WIPER
	FRONT WIPER SWITCH	E9	EL-WIPER
	HEADLAMP LH	E29	EL-H/LAMP EL-THEFT
	HEADLAMP RH	E38	EL-H/LAMP EL-DTRL EL-THEFT
	HOOD SWITCH	E31	EL-THEFT
	INHIBITOR RELAY	E56	EL-PNP/SW EL-START
	PARKING LAMP LH	E12	EL-TAIL/L
	PARKING LAMP RH	E40	EL-TAIL/L
	PARK/NEUTRAL POSITION SWITCH	E24	EL-ASCD
	POWER SOCKET RELAY	E21	EL-HORN
THEFT WARNING HORN RELAY	E23	EL-THEFT	
WASHER LEVEL SWITCH	E24	EL-WARN	
E101	ALTERNATOR	E105 E106 E107	EL-CHARGE
	POWER STEERING OIL PRESSURE SWITCH	E110	EC-PST/SW
F20/F25	A/T CONTROL UNIT	M13	AT-A/T
	DATA LINK CONNECTOR FOR GST	M9	EC-MIL/DL
	CONDENSER	F19	EC-IGN/SG
	CRANKSHAFT POSITION SENSOR (OBD)	F110	EC-CKPS
	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	DISTRIBUTOR (IGNITION)	F7	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	F24	EC-MAIN
	EVAP CONTROL SYSTEM PRESSURE SENSOR	B102	EC-PRE/SE
	REAR HEATED OXYGEN SENSOR LH	F3	EC-RRO2LH EC-RO2H-L
	REAR HEATED OXYGEN SENSOR RH	F1	EC-RRO2RH EC-RO2H-R
	SHIELD WIRE (ABSOLUTE PRESSURE SENSOR)	E88	EC-AP/SEN
	SHIELD WIRE (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (OBD)]	F110	EC-CKPS
	SHIELD WIRE (EVAP CONTROL SYSTEM PRESSURE SENSOR)	B102	EC-PRE/SE
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR LH)	F4	EC-FRO2LH EC-FO2H-L EC-FUELLH
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR RH)	F2	EC-FRO2RH EC-FO2H-R EC-FUELRH
	SHIELD WIRE (KNOCK SENSOR)	F102	EC-KS
SHIELD WIRE (MASS AIR FLOW SENSOR)	F10	EC-MAFS	

# GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
F20/F25	SHIELD WIRE (REAR HEATED OXYGEN SENSOR LH)	F3	EC-RRO2LH EC-RO2H-L	GI
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR RH)	F1	EC-RRO2RH EC-RO2H-R	MA
	SHIELD WIRE (THROTTLE POSITION SENSOR)	F8	EC-TPS AT-A/T	
B11/B22/D210	FUEL PUMP	B13	EC-F/PUMP	EM
	FUEL TANK GAUGE UNIT	B12	EC-TFTS EL-METER EL-WARN	
	FRONT DOOR SWITCH LH	B9	RS-SRS EL-BUZZER EL-THEFT	LC
	HEATED SEAT LH	B5	EL-HSEAT	EC
	POWER SEAT LH	B7	EL-SEAT	FE
	POWER SOCKET	B41	EL-HORN	CL
	REAR COMBINATION LAMP LH (BACK-UP LAMP LH)	B26	EL-BACK/L	
	REAR COMBINATION LAMP LH (REAR TURN SIGNAL LAMP LH)	B26	EL-TURN	FE
	REAR COMBINATION LAMP LH (STOP LAMP LH)	B26	EL-STOP/L	
	REAR COMBINATION LAMP LH (TAIL LAMP LH)	B26	EL-TAIL/L	CL
	REAR WIPER AMP.	B14	EL-WIP/R	
	SEAT BELT BUCKLE SWITCH	B6	EL-WARN EL-BUZZER	MT
	SPEAKER AMP.	B20	EL-AUDIO	
	BACK DOOR KEY CYLINDER SWITCH	D201	EL-THEFT	AT
	BACK DOOR SWITCH	D208	EL-INT/L EL-MULTI EL-THEFT	
	GLASS HATCH SWITCH	D209	EL-WIP/R	TF
	HIGH-MOUNTED STOP LAMP	D302	EL-STOP/L	
	LICENSE PLATE LAMP (Models with spare tire carrier)	D203	EL-TAIL/L	PD
	LICENSE PLATE LAMP LH (Models without spare tire carrier)	D202	EL-TAIL/L	
	LICENSE PLATE LAMP RH (Models without spare tire carrier)	D211	EL-TAIL/L	FA
LUGGAGE ROOM LAMP	D103	EL-INT/L		
REAR DOOR LOCK ACTUATOR LH	D54	EL-D/LOCK EL-MULTI EL-THEFT	RA	
REAR WIPER MOTOR	D212	EL-WIP/R		
B55/B75	A/T DEVICE (PARK POSITION SWITCH and OVERDRIVE CONTROL SWITCH)	B59	AT-SHIFT AT-A/T	BR
	ASHTRAY (ILLUMINATION)	B60 B76	EL-ILL	
	HEATED SEAT RH	B56	EL-HSEAT	ST
	NEUTRAL POSITION SWITCH	B203	EC-PNP/SW	RS
	REAR COMBINATION LAMP RH (BACK-UP LAMP RH)	B74	EL-BACK/L	
	REAR COMBINATION LAMP RH (REAR TURN SIGNAL LAMP RH)	B74	EL-TURN	BT
	REAR COMBINATION LAMP RH (STOP LAMP RH)	B74	EL-STOP/L	
	REAR COMBINATION LAMP RH (TAIL LAMP RH)	B74	EL-TAIL/L	HA
	POWER SEAT RH	B57	EL-SEAT	
	TIRE CARRIER SWITCH	B301	EL-WARN	
REAR DOOR LOCK ACTUATOR RH	D74	EL-D/LOCK EL-MULTI EL-THEFT		




**EL**

IDX

# BATTERY

## CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



## How to Handle Battery

### METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)
- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

### CHECKING ELECTROLYTE LEVEL

#### WARNING:



Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.



# BATTERY

## How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



### SULPHATION


A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.

### SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## BATTERY

### How to Handle Battery (Cont'd)

2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.

#### Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

### CHARGING THE BATTERY

#### CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

#### Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

# BATTERY

## How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

## Service Data and Specifications (SDS)

Applied area	USA		Canada
	Standard	Option	Standard
Type	55D23R	75D31R	
Capacity	V-AH	12-60	12-70
Cold cranking current (For reference value)	A	356	447

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## System Description

### M/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 40A fusible link (letter [a], located in the fuse and fusible link box).

With the ignition switch in the START position, power is supplied

- to clutch interlock relay terminal ②
- through 7.5A fuse [No. [12], located in the fuse block (J/B)].

### For models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- to theft warning relay terminal ①
- through 7.5A fuse [No. [12], located in the fuse block (J/B)].
- to clutch interlock relay terminal ③
- through ignition switch terminal ⑤ .

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and ground to the clutch interlock relay terminal ① is interrupted.

When the theft warning system is not operating, ground is supplied

- through theft warning relay terminal ③
- to clutch interlock relay terminal ① .

### For models without theft warning system

With the ignition switch in the START position, power is supplied

- through terminal ⑤ of the ignition switch
- to clutch interlock relay terminal ③ .

Ground is supplied to clutch interlock relay terminal ① , when the clutch pedal is depressed through the clutch interlock switch and body grounds (M4) and (M66) .

The clutch interlock relay is energized and power is supplied

- from terminal ⑤ of the clutch interlock relay
- to terminal ② of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

# STARTING SYSTEM

## System Description (Cont'd)

### A/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 40A fusible link (letter [B], located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to inhibitor switch terminal ② .
- through 10A fuse [No. [B], located in the fuse block (J/B)].

Ground is supplied

- to inhibitor relay terminal ②
- through body grounds (E13) and (E41)

### Models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. [2], located in the fuse block (J/B)]
- to theft warning relay terminal ① .

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the inhibitor relay terminal ① is interrupted.

When the theft warning system is not operating, power is supplied with ignition switch in the START position

- through inhibitor switch terminal ① ,
- to theft warning relay terminal ③ ,
- through theft warning relay terminal ④ ,
- to inhibitor relay terminal ① , with the selector lever in the P or N position.

Then inhibitor relay is energized and power is supplied

- through ignition switch terminal ⑤ ,
- to inhibitor relay terminal ③ ,
- through inhibitor relay terminal ⑤ ,
- to terminal ② of the starter motor windings.

### Models without theft warning system

With the ignition switch in the START position, power is supplied

- through inhibitor switch terminal ① ,
- to inhibitor relay terminal ① , with selector lever in the P or N position.

Then inhibitor relay is energized and power is supplied

- from ignition switch terminal ⑤
- to inhibitor relay terminal ③
- through inhibitor relay terminal ⑤
- to terminal ② of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX



# STARTING SYSTEM

## Wiring Diagram — START — (Cont'd)

EL-START-02



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX



Refer to last page (Foldout page).

E1, M1

E3

EL


IDX



# STARTING SYSTEM

## Wiring Diagram — START — (Cont'd)


A/T MODELS



EL-START-03

Refer to EL-POWER.


Refer to last page (Foldout page).






# STARTING SYSTEM

## Construction



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## Removal and Installation



# STARTING SYSTEM

## Pinion/Clutch Check

1. Inspect pinion teeth.
  - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
  - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
  - If it locks or rotates in both directions, or unusual resistance is evident, replace.

## Service Data and Specifications (SDS)

### STARTER

Type		MOT60181
		MITSUBISHI make
		Reduction gear type
System voltage	V	12
No-load		
Terminal voltage	V	11.0
Current	A	Less than 90
Revolution	rpm	More than 2,500
Minimum diameter of commutator	mm (in)	28.8 (1.134)
Minimum length of brush	mm (in)	7.0 (0.276)
Brush spring tension	N (kg, lb)	11.778 - 23.537 (1.201 - 2.400, 2.648 - 5.292)
Clearance between pinion front edge and pinion stopper	mm (in)	—

# CHARGING SYSTEM

## System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal ⑤ through:

- 100A fusible link (letter [a], located in the fuse and fusible link box), and
- 7.5A fuse (No. 65), located in the fuse and fusible link box).

Terminal ⑥ supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal ⑤ detecting the input voltage. The charging circuit is protected by the 100A fusible link.

Terminal ⑦ of the alternator supplies ground through body ground (E10).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 7], located in the fuse block (J/B)]
- to combination meter terminal ⑬ for the charge warning lamp.

Ground is supplied to terminal ⑭ of the combination meter through terminal ① of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX



# CHARGING SYSTEM

## Wiring Diagram — CHARGE —

EL-CHARGE-01



Refer to EL-POWER.



Refer to last page (Foldout page).

(E1), (M1)

(E60)

(M10)


# CHARGING SYSTEM

## Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

### WITH IC REGULATOR



Warning lamp: "CHARGE" warning lamp in combination meter

★: When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

### MALFUNCTION INDICATOR


The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- B terminal is disconnected.
- S terminal is disconnected or related circuit is open.
- Field circuit is open.
- Excessive voltage is produced.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# CHARGING SYSTEM

## Construction



## Removal and Installation



# CHARGING SYSTEM

## Service Data and Specifications (SDS)

### ALTERNATOR

Type		LR190-729
		HITACHI make
Nominal rating	V-A	12-90
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000
Hot output current (When 13.5 volts is applied)	A/rpm	More than 23/1,300 More than 65/2,500 More than 87/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.471 - 3.432 (150 - 350, 5.29 - 12.34)
Slip ring minimum outer diameter	mm (in)	26.0 (1.024)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

# COMBINATION SWITCH

## Combination Switch/Check




**LIGHTING SWITCH**

	OFF			1			2		
	A	B	C	A	B	C	A	B	C
5			○				○	○	○
6			○				○	○	○
7							○	○	○
8			○				○	○	○
9							○	○	○
10							○	○	○
11			○				○	○	○
12			○				○	○	○

**WIPER SWITCH**

	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○	○		
15		○			
16				○	
17			○	○	○
18					○



**FOG LAMP SWITCH**




	OFF	ON
31		○
32		○

**TURN SIGNAL SWITCH**

	L	N	R
1	○		○
2			○
3	○		○



# COMBINATION SWITCH



## Replacement

For removal and installation of spiral cable, refer to RS section ["Installation — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the turn signal cancel tab with the notch of combination switch.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

**EL**

IDX

# COMBINATION SWITCH

## Steering Switch/Check



# HEADLAMP

## System Description (For USA)

The headlamps are controlled by the lighting switch which is built into the combination switch.

Power is supplied at all times

- to lighting switch terminal ⑤
- through 15A fuse (No. ⑤9 , located in the fuse and fusible link box), and
- to lighting switch terminal ⑧
- through 15A fuse (No. ⑥0 , located in the fuse and fusible link box).

### Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to terminal ② of the LH headlamp, and
- from lighting switch terminal ⑦
- to terminal ② of the RH headlamp.

Terminal ③ of each headlamp supplies ground through body grounds ①3 and ①4.

With power and ground supplied, the headlamp(s) will illuminate.

### High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ① of each RH headlamp, and
- from lighting switch terminal ⑨
- to terminal ① of each LH headlamp, and
- to combination meter terminal ④3 for the high beam indicator.

Ground is supplied to terminal ③5 of the combination meter through body grounds ①4 and ①7.

Terminal ③ of each headlamp supplies ground through body grounds ①3 and ①4.

With power and ground supplied, the high beams and the high beam indicator illuminate.

### Theft warning system

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-215).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA





EL

IDX

# HEADLAMP

## Wiring Diagram (For USA) — H/LAMP —

EL-H/LAMP-01



Refer to last page (Foldout page).

(E1), (M1)

# HEADLAMP

## Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Grounds (E13) and (E41)</li> <li>15A fuse</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check grounds (E13) and (E41).</li> <li>Check 15A fuse (No. 60), located in fuse and fusible link box). Verify battery positive voltage is present at terminal (8) of lighting switch.</li> <li>Check lighting switch.</li> </ol>
RH headlamps do not operate.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Grounds (E13) and (E41)</li> <li>15A fuse</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check grounds (E13) and (E41).</li> <li>Check 15A fuse (No. 59), located in fuse and fusible link box). Verify battery positive voltage is present at terminal (5) of lighting switch.</li> <li>Check lighting switch.</li> </ol>
LH high beams do not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>Bulbs</li> <li>Open in LH high beams circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulbs.</li> <li>Check R/L wire between lighting switch and LH headlamps for an open circuit.</li> <li>Check lighting switch.</li> </ol>
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in LH low beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check R/G wire between lighting switch and LH headlamp for an open circuit.</li> <li>Check lighting switch.</li> </ol>
RH high beams do not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>Bulbs</li> <li>Open in RH high beams circuit</li> <li>Lighting switch.</li> </ol>	<ol style="list-style-type: none"> <li>Check bulbs.</li> <li>Check R/W wire between lighting switch and RH headlamps for an open circuit.</li> <li>Check lighting switch.</li> </ol>
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in RH low beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check R/B wire between lighting switch and RH headlamp for an open circuit.</li> <li>Check lighting switch.</li> </ol>
High beam indicator does not work.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Grounds (M4) and (M7)</li> <li>Open in high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb in combination meter.</li> <li>Check grounds (M4) and (M7).</li> <li>Check R/L wire between lighting switch and combination meter for an open circuit.</li> </ol>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## Daytime Light System/System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 60), located in the fuse and fusible link box)
- to daytime light control unit terminal ③ and
- to lighting switch terminal ⑧.

Power is also supplied at all times

- through 15A fuse (No. 59), located in the fuse and fusible link box)
- to daytime light control unit terminal ② and
- to lighting switch terminal ⑤.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12], located in the fuse block (J/B)]
- to daytime light control unit terminal ⑫.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 26], located in the fuse block (J/B)]
- to daytime light control unit terminal ①.

Ground is supplied to daytime light control unit terminal ⑨ through body grounds E13 and E41.

### HEADLAMP OPERATION

#### Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑦
- to RH headlamp terminal ②
- to daytime light control unit terminal ④.

Ground is supplied to RH headlamp terminal ③ through body grounds E13 and E41.

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to LH headlamp terminal ②.

Ground is supplied

- to LH headlamp terminal ③
- from daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑨
- through body grounds E13 and E41.

With power and ground supplied, the low beam headlamps illuminate.

#### High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ① of RH headlamp.

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal ⑨
- to daytime light control terminal ⑤
- to combination meter terminal ④③ for the high beam indicator
- through daytime light control terminal ⑥
- to terminal ① of LH headlamp.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to terminal ③⑤ of the combination meter through body grounds M4 and M77.

With power and ground supplied, the high beam headlamps and HI BEAM indicator illuminate.

# HEADLAMP

## Daytime Light System/System Description (For Canada) (Cont'd)

### DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- to daytime light control unit terminal ③
- through daytime light control unit terminal ⑥
- to terminal ① of LH headlamp
- through terminal ③ of LH headlamp
- to daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑧
- to terminal ① of RH headlamp.

Ground is supplied to terminal ③ of RH headlamp through body grounds (E13) and (E4).

Because the high beam headlamps are now wired in series, they operate at half illumination.

### Operation (Daytime light system for Canada)

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	○	X
Clearance and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

○ : Lamp "ON"

X : Lamp "OFF"

△ : Lamp dims.

□ : Added functions


\* : When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
FA  
EL  
IDX

# HEADLAMP

## Schematic (For Canada)






# HEADLAMP

## Wiring Diagram (For Canada) — DTRL —

EL-DTRL-01





Refer to EL-POWER.

Next page

Next page

Next page



Refer to last page (Foldout page).



E1, M1

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# HEADLAMP

## Wiring Diagram (For Canada) — DTRL — (Cont'd)

EL-DTRL-02








Refer to last page (Foldout page).  
(E3)

# HEADLAMP

## Wiring Diagram (For Canada) — DTRL — (Cont'd)

EL-DTRL-03



Refer to last page (Foldout page).

- (E1) , (M1)
- (M2) , (B1)
- (M10)











- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

# HEADLAMP

## Trouble Diagnoses (For Canada)









### DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE


(Data are reference values.)

Terminal No.	Item	Condition		Judgement standard
1	Start signal		When turning ignition switch to "ST"	Battery positive voltage
			When turning ignition switch to "ON" from "ST"	1V or less
			When turning ignition switch to "OFF"	1V or less
2	Power source		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "OFF"	Battery positive voltage
3	Power source		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "OFF"	Battery positive voltage
4	Lighting switch (Lo beam)		When turning lighting switch to "HEAD" (2nd position)	Battery positive voltage
5	Lighting switch (Hi beam)		When turning lighting switch to "HI BEAM"	Battery positive voltage
			When turning lighting switch to "FLASH TO PASS"	Battery positive voltage
6	LH hi beam		When turning lighting switch to "HI BEAM"	Battery positive voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Battery positive voltage
7	LH headlamp control (ground)		When lighting switch is turned to "HEAD"	1V or less
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
8	RH hi beam		When turning lighting switch to "HI BEAM"	Battery positive voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage

# HEADLAMP

## Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition	Judgement standard
9	Ground	—	—
10	Parking brake switch	 When parking brake is released	Battery positive voltage
		 When parking brake is set	1.5V or less
11	Alternator	 When turning ignition switch to "ON"	1V or less
		 When engine is running	Battery positive voltage
		 When turning ignition switch to "OFF"	1V or less
12	Power source	 When turning ignition switch to "ON"	Battery positive voltage
		 When turning ignition switch to "ST"	Battery positive voltage
		 When turning ignition switch to "OFF"	1V or less



### Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

#### CAUTION:

- **Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**

### Bulb Specifications

Item	Wattage (W)
Headlamp (Semi-sealed beam) High/Low	65/45 (HB1)

### Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# HEADLAMP

## Aiming Adjustment (Cont'd)

For details, refer to the regulations in your own country.

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).




### AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.


#### Adjustment value for mechanical aimer

	Mechanical aimer level
Horizontal side	-4 to 4
Vertical side	-4 to 4



### LOW BEAM

- Turn headlamp low beam on.
  - Use adjusting screws to perform aiming adjustment.
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.




- Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.
- Dotted lines in illustration show center of headlamp.

"H": Horizontal center line of headlamps

"W<sub>L</sub>": Distance between each headlamp center

# EXTERIOR LAMP

## Parking, License and Tail Lamps/Schematic




- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

# EXTERIOR LAMP

## Parking, License and Tail Lamps/Wiring Diagram — TAIL/L —

EL-TAIL/L-01



Refer to last page (Foldout page).







# EXTERIOR LAMP

## Parking, License and Tail Lamps/Wiring Diagram — TAIL/L — (Cont'd)


EL-TAIL/L-02



**TW** : Models with theft warning system  
**OT** : Models without theft warning system



Refer to last page (Foldout page).




GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
**EL**  
 IDX

# EXTERIOR LAMP

## Parking, License and Tail Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-03









BD : Models with spare tire carrier  
 OD : Models without spare tire carrier

Preceding page

Preceding page

Refer to last page (Foldout page).



M10










# EXTERIOR LAMP


## Back-up Lamp/Wiring Diagram — BACK/L —

A/T MODELS

EL-BACK/L-01



Refer to last page (Foldout page).







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# EXTERIOR LAMP


## Back-up Lamp/Wiring Diagram — BACK/L — (Cont'd)

M/T MODELS

EL-BACK/L-02



Refer to last page (Foldout page).



# EXTERIOR LAMP

## Front Fog Lamp/System Description

Power is supplied at all times to fog lamp relay terminal ③ through:

- 15A fuse (No. 53 , located in the fuse and fusible link box)

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 15A fuse (No. 59 , located in the fuse and fusible link box)
- to lighting switch terminal ⑤
- through terminal ⑦ of the lighting switch
- to fog lamp relay terminal ① .

### Fog lamp operation

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position:

- ground is supplied to fog lamp relay terminal ② through the fog lamp switch and body grounds (E13) and (E41) .

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal ⑤
- to terminal ① of each fog lamp.

Ground is supplied to terminal ② of each fog lamp through body grounds (E13) and (E4) .

With power and ground supplied, the fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

# EXTERIOR LAMP




## Front Fog Lamp/Wiring Diagram — F/FOG —

EL-F/FOG-01





# EXTERIOR LAMP



## Front Fog Lamp Aiming Adjustment

Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.

Loosen the front fog lamp bolts and adjust the vertical aiming by moving the front fog lamp assembly.

- Set the distance between the screen and the center of the fog lamp lens as shown at left.
- Turn front fog lamps ON.

- Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.

- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.
- Tighten the front fog lamp bolts.

## Bulb Specifications

Item	Wattage (W)
Front fog lamp	55

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/ System Description

#### TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11], located in the fuse block (J/B)
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds M4 and M66.

#### LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front turn signal lamp LH terminal ②
- combination meter terminal 13
- rear combination lamp LH terminal ⑤.

Ground is supplied to the front turn signal lamp LH terminal ① through body grounds E13 and E41.

Ground is supplied to the rear combination lamp LH terminal ⑥ through body grounds B11, B22 and D210.

Ground is supplied to combination meter terminal 35 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

#### RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front turn signal lamp RH terminal ②
- combination meter terminal ④
- rear combination lamp RH terminal ⑤.

Ground is supplied to the front turn signal lamp RH terminal ① through body grounds E13 and E41.

Ground is supplied to the rear combination lamp RH terminal ⑥ through body grounds B55 and B75.

Ground is supplied to combination meter terminal 35 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

#### HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 15A fuse [No. 14, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds M4 and M66.

Power is supplied through terminal ⑤ of the hazard switch to

- front turn signal lamp LH terminal ②
- combination meter terminal 13
- rear combination lamp LH terminal ⑤.

Power is supplied through terminal ⑥ of the hazard switch to

- front turn signal lamp RH terminal ②
- combination meter terminal ④
- rear combination lamp RH terminal ⑤.

Ground is supplied to terminal ① of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal ⑥ of the rear combination lamp LH through body grounds B11, B22 and D210.

Ground is supplied to terminal ⑥ of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 35 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/ System Description (Cont'd)

#### WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

- through 15A fuse [No. 14], located in the fuse block (J/B)
- to multi-remote control relay-1 terminals ①, ③ and ⑥.

Ground is supplied to multi-remote control relay-1 terminal ②, when the multi-remote control system is triggered through the smart entrance control unit.

Refer to "MULTI-REMOTE CONTROL SYSTEM", EL-199.

The multi-remote control relay-1 is energized.

Power is supplied through terminal ⑦ of the multi-remote control relay-1

- to front turn signal lamp LH terminal ②
- to combination meter terminal ⑬
- to rear combination lamp LH terminal ⑤.

Power is supplied through terminal ⑤ of the multi-remote control relay-1

- to front turn signal lamp RH terminal ②
- to combination meter terminal ④
- to rear combination lamp RH terminal ⑤.

Ground is supplied to terminal ① of each front turn signal lamp through body grounds (E13) and (E41).

Ground is supplied to terminal ⑥ of the rear combination lamp LH through body grounds (B11), (B22) and (D210).

Ground is supplied to terminal ⑥ of the rear combination lamp RH through body grounds (B55) and (B75).

Ground is supplied to combination meter terminal ⑮ through body grounds (M4) and (M77).

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX





# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Schematic



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN —



Refer to last page (Foldout page).


(M10)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX






# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

EL-TURN-02





Refer to last page (Foldout page).



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

EL-TURN-03




Refer to last page (Foldout page).  
E1, M1

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/ Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Hazard switch</li> <li>3. Turn signal switch</li> <li>4. Open in turn signal switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 11], located in fuse block (J/B). Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check turn signal switch.</li> <li>4. Check G wire between combination flasher unit and turn signal switch for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse [No. 14], located in fuse block (J/B). Verify battery positive voltage is present at terminal ③ of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check G wire between combination flasher unit and hazard switch for open circuit.</li> </ol>
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E13) and (E41)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E13) and (E41).</li> </ol>
Rear turn signal lamp LH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (B11), (B22) and (D210)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (B11), (B22) and (D210).</li> </ol>
Rear turn signal lamp RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (B55) and (B75)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (B55) and (B75).</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds (M4) and (M77).</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> </ol>



### Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.



# EXTERIOR LAMP

## Bulb Specifications

Item	Wattage (W)	
Headlamp (Semi-sealed beam)		GI
High/Low	65/45 (HB1)	MA
Front fog lamp	55	
Front turn signal lamp	27	EM
Parking lamp	7	
Rear combination lamp		LC
Turn signal lamp	27	
Stop/Tail lamp	27/8	
Back-up lamp	27	EC
License plate lamp	10	
High-mounted stop lamp	5	FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

**EL**

IDX

## INTERIOR LAMP

### Illumination/System Description

Power is supplied at all times

- through 10A fuse [No. 61], located in the fuse block (J/B)
- to lighting switch terminal ⑩.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.


The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M19	①	③
Combination meter	M24, M25	⑩	⑫
Cigarette lighter	M57	③	④
Rear wiper switch	M50	⑩	⑪
Compass and thermo meter	R4	⑤	②
ASCD main switch	M18	⑤	⑥
Rear window defogger switch	M36	⑤	⑥
Power window main switch	D6	④	⑬
Audio	M48	⑧	⑦
Hazard switch	M35	⑦	⑧
A/C switch	M45	②	①
A/T indicator	B59	③	④
Ashtray	B60, M76	①	②
Vanity mirror	R3, R5	①	②

The ground for all of the components except for ashtray and vanity mirror are controlled through terminals ② and ③ of the illumination control switch and body grounds ④ and ⑦.

# INTERIOR LAMP



## Illumination/Schematic



# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL —

EL-ILL-01



Refer to last page (Foldout page).




M10  
E3

# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-02

AS : Models with ASCD



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA



**EL**






IDX

# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-03

 : A/T models  
 : Models with power window




Refer to last page (Foldout page).

(M10)

# INTERIOR LAMP

## Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-04




Refer to EL-POWER.

(MT) : M/T model  
 (AT) : A/T model  
 (VA) : Models with vanity mirror illumination

Refer to last page (Foldout page).

(M10)



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

## INTERIOR LAMP

### Interior, Spot and Luggage Room Lamps/ System Description

Power is supplied at all times

- through 7.5A fuse [No. 15], located in the fuse block (J/B)]
- to interior lamp terminal ① ,
- to spot lamp terminal ① and
- to luggage room lamp terminal ① .

#### INTERIOR LAMP

With interior lamp switch ON, ground is supplied to turn interior lamp ON.

When a door switch is opened with interior lamp switch in DOOR, ground is supplied

- to interior lamp terminal ②
- through diode (M65) terminal ① (Models with theft warning system)
- to diode (M65) terminal ② (Models with theft warning system)
- through front door switch LH terminal ③ or
- through front door switch RH terminal ① or
- through rear door switch LH terminal ① or
- through rear door switch RH terminal ① or
- through back door switch terminal ②
- through body ground.

#### LUGGAGE ROOM LAMP

The luggage room lamp will turn on in the same manner as interior lamp.

#### SPOT LAMP

With the spot lamp switch in the ON position, ground is supplied

- to spot lamp terminal ②
- through body grounds (M4) and (M77).

With power and ground supplied, the spot lamp turns ON.


#### Bulb Specifications

Item	Wattage (W)
Interior lamp	10
Spot lamp	10
Luggage room lamp	10



# INTERIOR LAMP

## Interior, Spot and Luggage Room Lamps/ Schematic






- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

# INTERIOR LAMP

## Interior, Spot and Luggage Room Lamps/ Wiring Diagram — INT/L —

EL-INT/L-01



Refer to last page (Foldout page).

M2, B1






M10

M91

# INTERIOR LAMP

## Interior, Spot and Luggage Room Lamps/ Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-02



Refer to last page (Foldout page).




M2, B1

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# INTERIOR LAMP

## Interior, Spot and Luggage Room Lamps/ Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-03



## System Description

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 7], located in the fuse block (J/B)
- to combination meter terminal ⑮.

Ground is supplied

- to combination meter terminals ⑳ and ㉓
- through body grounds (M4) and (M77).

## WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal ㉗ of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

## TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal ③ of the ECM (ECCS control module)
- to combination meter terminal ㉚ for the tachometer.

## FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal ⑥ for the fuel gauge
- from terminal ③ of the fuel tank gauge unit
- through terminal ② of the fuel tank gauge unit and
- through body grounds (B11), (B22) and (D210).


## SPEEDOMETER

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals ⑧ and ⑫ for the speedometer
- from terminals ② and ① of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.



## COMPASS AND THERMOMETER

This unit is a display unit which possesses the following functions:

- Function to measure earth magnetism and indicate heading direction of vehicle.
- Function to indicate outside air temperature.
- Function to indicate caution for frozen road surfaces.

### Outside temperature display

Push the switch when the ignition key is in the "ACC" or "ON" position. The outside temperature will be displayed in "°F".

- Selecting the indication range  
Push the switch to change from "°F" to "°C".
- When the outside temperature drops below freezing point, [ICE] is displayed on the unit.
- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F).
- When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "---" though it is operating. This is not a problem.

### Direction display

Push the switch when the ignition key is in the "ACC" or "ON" position. The direction will be displayed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

# METER AND GAUGES

## Combination Meter



1	8
2	9
3	10
4	11
5	12
6	13
7	14
15	16

M24


17	23
18	24
19	25
20	26
21	27
22	28
29	30

M25


31	32	33	34	35	36	37	38	39
40	41	42	43	44	45	46		

M26

- Ⓒ : For Canada
- Ⓓ : Models with spare tire carrier
- Ⓔ : 4WD model
- Ⓕ : 4WD A/T model
- Ⓖ : A/T model
- Ⓖ : Models with ASCD system



Combination Meter, Compass and Thermometer/Schematic



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT





HA

**EL**

IDX

Combination Meter, Compass and Thermometer/Wiring Diagram — METER —

EL-METER-01



Refer to last page (Foldout page).

(M10)


(F24)




# METER AND GAUGES

## Combination Meter, Compass and Thermometer/Wiring Diagram — METER — (Cont'd)

EL-METER-02







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX




Refer to last page (Foldout page).  
M2, B1





## Trouble Diagnoses

### INSPECTION/FUEL GAUGE AND/OR WATER TEMPERATURE GAUGE






(Go to Ⓐ on next page.)






CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# METER AND GAUGES

## Trouble Diagnoses (Cont'd)








### INSPECTION/TACHOMETER



# METER AND GAUGES

## Trouble Diagnoses (Cont'd)

### INSPECTION/SPEEDOMETER AND VEHICLE SPEED SENSOR



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


# METER AND GAUGES

## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION


#### Fuel tank gauge unit check

- For removal, refer to FE section.
- Check the resistance between terminals ① and ③.



Ohmmeter		Float position mm (in)		Resistance value ( $\Omega$ )
(+)	(-)			
①	③	*1	Full	96 (3.78)
		*2	1/2	188 (7.40)
		*3	Empty	257 (10.12)


\*1 and \*3: When float rod is in contact with stopper.



#### Thermal transmitter check

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 $\Omega$
100°C (212°F)	Approx. 21 - 24 $\Omega$



#### Vehicle speed sensor signal check

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage across (a) and (b).

# METER AND GAUGES

## Trouble Diagnoses (Cont'd)


### INSPECTION/COMPASS AND THERMOMETER

Symptom	Possible causes	Repair order	
No display at all	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Ground circuit</li> <li>Compass and thermometer</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse [No. 27], located in fuse block (J/B). Turn the ignition switch ON and verify that battery positive voltage is at terminal ⑦ of compass and thermometer.</li> <li>Check ground circuit for compass and thermometer.</li> <li>Replace compass and thermometer.</li> </ol>	GI MA
Forward direction indication slips off the mark or incorrect.	<ol style="list-style-type: none"> <li>In manual correction mode (Bar and display vanish.)</li> <li>Zone variation change is not done.</li> </ol>	<ol style="list-style-type: none"> <li>Drive the vehicle and turn at an angle of 90°.</li> <li>Perform the zone variation change.</li> </ol>	EM
Compass reading remains unchanged.	<ol style="list-style-type: none"> <li>Vehicle speed sensor is not entered.</li> <li>Compass and thermometer</li> </ol>	<ol style="list-style-type: none"> <li>Check harness for open or short between combination meter terminal ⑩ and compass and thermometer terminal ①.</li> <li>Replace compass and thermometer.</li> </ol>	LC
Displays wrong temperature when ambient temperature is between -30°C (-20°F) and 55°C (130°F). (See NOTE)	<ol style="list-style-type: none"> <li>Check operation</li> <li>Ambient sensor circuit</li> <li>Vehicle speed sensor is not entered.</li> <li>Ambient sensor</li> <li>Compass and thermometer</li> </ol>	<ol style="list-style-type: none"> <li>Perform preliminary check shown below.</li> <li>Check harness for open or short between ambient sensor and compass and thermometer.</li> <li>Check harness for open or short between combination meter terminal ⑩ and compass and thermometer terminal ①.</li> <li>Replace ambient sensor.</li> <li>Replace compass and thermometer.</li> </ol>	EC FE CL

#### NOTE:

- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F). When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "----".
- While the vehicle is being driven, the indicated temperature on the thermometer changes only when the following condition (a), (b) and/or (c) is met.
  - The temperature detected by the ambient sensor is lower than the indicated temperature on the thermometer.
  - The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds. In other words, when the temperature rise is too rapid, the indicated temperature will not change.
  - The ignition key has been turned to the "OFF" position for more than 4 hours.

#### PRELIMINARY CHECK FOR THERMOMETER



★1: Check the system following "INSPECTION/COMPASS AND THERMOMETER".


## METER AND GAUGES

### Trouble Diagnoses (Cont'd)

#### CALIBRATION PROCEDURE FOR COMPASS

The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.

Zone Variation Chart



1. Determine your location on the zone map. Record your zone number.


2. Turn the ignition switch to ACC or ON position.

3. Push the "Mode" switch continuously for five seconds until the current zone entry number is displayed.

4. Press the "Mode" switch repeatedly until the desired zone number is displayed.

Once the desired zone number is displayed, stop pressing the "Mode" switch and the display will show compass direction after a few seconds.

SEL738UA



#### CORRECTION FUNCTIONS OF COMPASS

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

#### INITIAL CORRECTION PROCEDURE FOR COMPASS

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The direction bar starts blinking.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.


#### NOTE:

In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.



# WARNING LAMPS

## Warning Lamps/Schematic









GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# WARNING LAMPS

## Warning Lamps/Wiring Diagram — WARN —

EL-WARN-01



Refer to last page (Foldout page).


- (E1), (M1)
- (M10)
- (F24)

# WARNING LAMPS


## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-02

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



TC : Models with spare tire carrier









Refer to last page (Foldout page).

M2, B1

# WARNING LAMPS

## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



Refer to last page (Foldout page).


E1, M1

M2, B1



# WARNING LAMPS

## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-04



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IOX



Refer to last page (Foldout page).

(E1), (M1)


(M13)

(M54)





# WARNING LAMPS

## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-05



Refer to last page (Foldout page).




(M1) . (E1)  
(M10)





# WARNING LAMPS

## Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-06



- : 4WD model
- : A/T 4WD model
- : M/T 4WD model



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX







# WARNING LAMPS

## Electrical Components Inspection

### FUEL WARNING LAMP SENSOR CHECK


- It will take a short time for the bulb to light.



### OIL PRESSURE SWITCH CHECK

	Oil pressure kPa (kg/cm <sup>2</sup> , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES


Check the continuity between the terminals of oil pressure switch and body ground.



### DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

**NOTE:** Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## Warning Buzzer/System Description

The warning buzzer is controlled by the smart entrance control unit.

Power is supplied at all times

- through 7.5A fuse [No. 24], located in the fuse block (J/B)
- to warning buzzer terminal ①
- to key switch terminal ① .

Power is supplied at all times

- through 10A fuse [No. 61], located in the fuse block (J/B)
- to lighting switch terminal ⑪ .

Power is supplied at all times

- through 40A fusible link (letter F), located in the fuse and fusible link box).
- to smart entrance control unit terminal ① .

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12], located in the fuse block (J/B)
- to smart entrance control unit terminal ⑪ .

Ground is supplied to smart entrance control unit terminal ⑩ through body grounds M4 and M77 .

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied

- through smart entrance control unit terminal 23
- to warning buzzer terminal ③ .

With power and ground supplied, the warning buzzer will sound.

### Ignition key warning buzzer

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning buzzer will sound. A battery positive voltage is supplied

- from key switch terminal ②
- to smart entrance control unit terminal 24 .

Ground is supplied

- from front door switch LH terminal ①
- to smart entrance control unit terminal 15 .

Front door switch LH terminal ② is grounded through body grounds B11 , B22 and D210 .

### Light warning buzzer

With ignition switch OFF or ACC, driver's door open, and lighting switch in 1ST or 2ND position, warning buzzer will sound. A battery positive voltage is supplied.

- from lighting switch terminal ⑫
- to smart entrance control unit terminal 25

Ground is supplied

- from front door switch LH terminal ①
- to smart entrance control unit terminal 15 .

Front door switch LH terminal ② is grounded through body grounds B11 , B22 and D210 .

### Seat belt warning buzzer

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning buzzer will sound for approximately 6 seconds.


Ground is supplied

- from seat belt switch terminal ①
- to smart entrance control unit terminal 21 .




Seat belt switch terminal ② is grounded through body grounds B11 , B22 and D210 .

# WARNING BUZZER


## Warning Buzzer/Wiring Diagram — BUZZER —



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX




Refer to last page (Foldout page).



# WARNING BUZZER







## Warning Buzzer/Wiring Diagram — BUZZER — (Cont'd)

EL-BUZZER-02



Refer to last page (Foldout page).

- (M2) (B1)
- (M10)
- (E3)




# WARNING BUZZER

## Trouble Diagnoses

### SYMPTOM CHART

REFERENCE PAGE	EL-107	EL-108	EL-108	EL-109	EL-109
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1	DIAGNOSTIC PROCEDURE 2	DIAGNOSTIC PROCEDURE 3	DIAGNOSTIC PROCEDURE 4
Light warning buzzer does not activate.	X	X			X
Ignition key warning buzzer does not activate.	X		X		X
Seat belt warning buzzer does not activate.	X			X	X
All warning buzzers do not activate.	X				X

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD




### POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Power supply for smart entrance control unit

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
②	Ground	0V	0V	Battery voltage

RA  
 BR  
 ST  
 RS



### Ground circuit check

Terminals	Continuity
② - Ground	Yes

BT  
 HA

EL


IDX

# WARNING BUZZER

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

#### (Lighting switch input signal check)



**A**


**CHECK LIGHTING SWITCH INPUT SIGNAL.**  
Check voltage between control unit terminal ② and ground.

Condition of lighting switch	Voltage [V]
1ST or 2ND	Approx. 12
OFF	0

- NG
- Check the following.
- 10A fuse (No. ⑥1), located in the fuse and fusible link box
  - Harness for open or short between control unit and lighting switch

OK

Go to Procedure 4.



### DIAGNOSTIC PROCEDURE 2

#### (Key switch input signal check)

**A**

**CHECK KEY SWITCH INPUT SIGNAL.**  
Check voltage between control unit terminal ④ and ground.

Condition of key switch	Voltage [V]
Key is inserted.	Approx. 12
Key is withdrawn.	0

- NG
- Check the following.
- Key switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-110).
  - 7.5A fuse [No. ②4], located in fuse block (J/B)]
  - Harness for open or short between key switch and fuse
  - Harness for open or short between control unit and key switch

OK


Go to Procedure 4.

# WARNING BUZZER

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

#### (Seat belt buckle switch input signal check)



**A**

**CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL.**

1. Turn ignition switch "ON".
2. Check voltage between control unit terminal ⑳ and ground.

Condition of seat belt buckle switch	Voltage [V]
Fastened	Approx. 12
Unfastened	0


NG

Check the following.

- Seat belt buckle switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-110).
- Seat belt buckle switch ground circuit
- Harness for open or short between control unit and seat belt buckle switch

OK

Go to Procedure 4.



### DIAGNOSTIC PROCEDURE 4

**A**

**CHECK DOOR SWITCH INPUT SIGNAL.**

Check voltage between control unit terminal ⑲ and ground.

Condition of driver's door	Voltage [V]
Driver side door is closed.	Approx. 12
Driver side door is open.	0

NG

Check the following.

- Driver side door switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-110).
- Door switch ground circuit
- Harness for open or short between control unit and door switch

OK

**B**


**CHECK BUZZER POWER SUPPLY.**

Measure voltage between warning buzzer terminal ① and ground.  
**Battery voltage should exist.**

NG

Check the following.

- 7.5A fuse [No. 24], located in fuse block (J/B)
- Harness for open or short between buzzer and fuse



**C**

**CHECK WARNING BUZZER.**


1. Disconnect warning buzzer connector.
2. Apply 12V direct current to warning buzzer and check operation.

NG

Replace warning buzzer.

OK

Check harness for open or short between control unit and warning buzzer.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# WARNING BUZZER


## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### Key switch (insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.


Terminal No.	Condition	Continuity
① - ②	Key is inserted	Yes
	Key is removed	No



#### Driver side door switch

Check continuity between terminals when door switch is pushed and released.


Terminal No.	Condition	Continuity
① - ②, ③ - ground	Door switch is pushed.	No
	Door switch is released.	Yes



#### Seat belt buckle switch

Check continuity between terminals when seat belt is fastened and unfastened.

Terminal No.	Condition	Continuity
① - ②	Seat belt is fastened.	No
	Seat belt is unfastened.	Yes





## System Description

### WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19], located in the fuse block (J/B)]
- to wiper motor terminal 6.

#### Low and high speed wiper operation

Ground is supplied to wiper switch terminal 17 through body grounds E13 and E41.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 1.

With power and ground supplied, the wiper motor operates at high speed.

#### Auto stop operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper amplifier terminal 2
- through terminal 7 of the wiper amplifier
- to wiper motor terminal 5
- through terminal 4 of the wiper motor, and
- through body grounds M4 and M77.

When wiper arms reach base of windshield, wiper motor terminals 4 and 6 are connected instead of terminals 4 and 5. Wiper motor will then stop wiper arms at the PARK position.

#### Intermittent operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal 1
- from wiper switch terminal 15
- through body grounds E13 and E41.
- to wiper motor terminal 2
- through the wiper switch terminal 14
- to wiper switch terminal 13
- through wiper amplifier terminal 2
- to wiper amplifier terminal 3
- through body grounds M4 and M77.

The desired interval time is input

- to wiper amplifier terminal 8
- from wiper switch terminal 19.

The wiper motor operates at low speed at the desired time interval.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## WIPER AND WASHER

### System Description (Cont'd)

---

#### WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19], located in the fuse block (J/B)]
- to washer motor terminal ①.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ②, and
- to wiper amplifier terminal ⑥
- from terminal ⑩ of the wiper switch
- through terminal ⑰ of the wiper switch, and
- through body grounds (E13) and (E41).




With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

# WIPER AND WASHER

## Front Wiper and Washer/Wiring Diagram — WIPER —

EL-WIPER-01



Refer to last page (Foldout page).



- (E1), (M1)
- (E4)
- (M10)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# WIPER AND WASHER

## Front Wiper and Washer/Wiring Diagram — WIPER — (Cont'd)





EL-WIPER-02



## Trouble Diagnoses

### DIAGNOSTIC PROCEDURE 1

**SYMPTOM: Intermittent wiper does not operate.**



Check whether wiper operates with the wiper switch at Lo position.

NG → Check the following.

- 20A fuse [No. 19], located in fuse block (J/B)]
- Wiper motor
- Wiper switch
- Harness for open or short

OK →

**A**

1) Turn front wiper switch to OFF.  
2) Disconnect wiper amp. connector.  
3) Check voltage between wiper amp. terminal ② and ground.  
**Battery voltage should exist.**

NG → Check the following.

- Wiper switch
- Harness for open or short between wiper amp. terminal ② and wiper switch terminal ⑬

OK →

**B**

**CHECK INTERMITTENT SWITCH INPUT SIGNAL.**  
Check harness continuity between wiper amp. terminal ① and ground.

Condition of wiper switch	Continuity
OFF	No
INT	Yes

NG → Check the following.

- Wiper switch
- Harness for open or short between wiper amp. terminal ① and wiper switch terminal ⑭
- Ground circuit for front wiper switch terminal ⑰

OK →

**C**

**CHECK WIPER AMP. POWER SUPPLY CIRCUIT.**  
Check voltage between wiper amp. terminal ⑤ and ground while ignition switch is "ACC".  
**Battery voltage should exist.**

NG → Check the following.

- 20A fuse [No. 19], located in fuse block (J/B)]
- Harness for open or short between wiper amp. and fuse

OK →

**D**

**CHECK WIPER AMP. GROUND CIRCUIT.**  
Check harness continuity between wiper amp. terminal ③ and body ground.  
**Continuity should exist.**

NG → Repair harness or connector.

OK →

Replace wiper amp.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# WIPER AND WASHER

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

**SYMPTOM:** Intermittent time of wiper cannot be adjusted.



**A**

**CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL.**


- 1) Disconnect wiper amp. connector.
- 2) Measure resistance between wiper amp. terminals ⑧ and ③ while turning intermittent wiper volume.

Position of wiper knob	Resistance [ $\Omega$ ]
S	0
L	Approx. 1 k

OK → Replace wiper amp.

NG

- Check the following.
- Intermittent wiper volume
  - Harness for open or short between wiper amp. terminal ⑧ and wiper switch terminal ⑬
  - Ground circuit for front wiper switch terminal ⑳



### DIAGNOSTIC PROCEDURE 3

**SYMPTOM:** Wiper and washer activate individually but not in combination.

**A**

**CHECK WASHER SWITCH INPUT SIGNAL.**


- 1) Turn ignition switch to "OFF".
- 2) Disconnect wiper amp. connector.
- 3) Check harness continuity between wiper amp. terminal ⑥ and ground.

Condition of washer switch	Continuity
OFF	No
ON	Yes

NG → Check harness for open or short between wiper amp. terminal ⑥ and wiper switch terminal ⑬.


OK

Go to DIAGNOSTIC PROCEDURE 1. NG → Replace wiper amp.




## Wiper Installation and Adjustment

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
  2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L<sub>1</sub>" & "L<sub>2</sub>" immediately before tightening nut.
  3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
  4. Ensure that wiper blades stop within clearance "L<sub>1</sub>" & "L<sub>2</sub>".
    - Clearance "L<sub>1</sub>": 34 mm (1.34 in)**
    - Clearance "L<sub>2</sub>": 37 mm (1.46 in)**
- Tighten wiper arm nuts to specified torque.
    - Front wiper: 17 - 23 N-m (1.7 - 2.3 kg-m, 12 - 17 ft-lb)**




- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



## Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.
  - Adjustable range: ±10°**




Unit: mm (in)			
*1	390 (15.35)	*5	145 (5.71)
*2	160 (6.30)	*6	143 (5.63)
*3	379 (14.92)	*7	225 (8.86)
*4	140 (5.51)	*8	535 (21.06)

\*: The diameters of these circles are less than 80 mm (3.15 in).


GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

## WIPER AND WASHER



### Washer Tube Layout

### Wiper Linkage



### REMOVAL

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

**Be careful not to break ball joint rubber boot.**

### INSTALLATION

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.



## Rear Wiper and Washer/System Description

### WIPER OPERATION

#### Power supply and ground

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 29], located in the fuse block (J/B)
- to rear wiper relay terminals ④ and ①.

When the glass hatch switch is CLOSED, power is supplied

- from rear wiper relay terminal ③
- to rear wiper amp. terminal ⑤,
- to rear washer motor terminal ① and
- to rear wiper motor terminal ⑥.

If the glass hatch switch is OPEN, ground is supplied

- to rear wiper relay terminal ②
- from glass hatch switch terminal ①.

Then rear wiper relay is energized and power to the rear wiper amp., washer motor and wiper motor is interrupted.

(If the glass hatch is opened, no function of rear wiper motor will operate.)

If the rear wiper switch is turned to the INT or ON position, when glass hatch is opened, rear wiper relay terminal ② is also grounded

- through rear wiper relay terminals ⑥ and ⑦
- from rear wiper switch terminal ⑧.

(The purpose of this circuit is to prevent an abrupt operation of the rear wiper when the hatch is closed with the ignition switch turned to ON or ACC, and with the rear wiper switch set to INT or ON.)

Ground is supplied

- to rear wiper amplifier terminal ③
- through body grounds B11, B22 and D210.
- to rear wiper switch terminal ③
- through body grounds M4 and M66.

#### Rising up operation

When the rear wiper switch is turned to the INT or ON position, ground is supplied

- through terminal ① of rear wiper switch
- to rear wiper amp. terminal ①.

Then wiper amp. is energized and power is supplied

- through rear wiper amp. terminal ④
- to rear wiper motor terminal ④.

Ground is supplied to rear wiper motor through rear wiper switch.

With power and ground supplied, rear wiper operates and rear wiper arm moves up.

Wiper does not return to resting position until wiper switch is turned to OFF position.

#### Low speed wiper operation

When the rear wiper switch is placed in the ON position, ground is supplied

- through terminal ⑤ of rear wiper switch
- to rear wiper motor terminal ③.

With power and ground supplied, the wiper motor operates at low speed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## WIPER AND WASHER

### Rear Wiper and Washer/System Description (Cont'd)

#### Auto stop operation

With rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arms reach rear wiper stopper.

When wiper arm is not located at rear wiper stopper with wiper switch OFF, ground is provided

- from terminal ⑤ of the rear wiper switch
- to wiper motor terminal ③, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal ④ of the rear wiper switch
- to rear wiper amplifier terminal ②
- through terminal ⑦ of the rear wiper amplifier
- to rear wiper motor terminal ⑦
- through terminal ⑧ of the wiper motor, and
- through body grounds (B11), (B22) and (D210).

When wiper arms reach rear wiper stopper, rear wiper motor terminals ⑦ and ⑥ are connected instead of terminals ⑦ and ⑧. Rear wiper motor will then stop wiper arms at the PARK position.

#### Intermittent operation

The rear wiper motor operates the wiper arms at low speed approximately every 7 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal ①
- from rear wiper switch terminal ①
- through body grounds (M4) and (M66).
- to wiper motor terminal ③
- through the rear wiper switch terminal ⑤
- to rear wiper switch terminal ④
- through wiper amplifier terminal ②
- to wiper amplifier terminal ③
- through body grounds (B11), (B22) and (D210).

The rear wiper motor operates at low speed intermittent.

#### WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 29), located in the fuse block)
- to rear washer motor terminal ①.

When the rear wiper switch is turned to WASH position, ground is supplied


- to rear washer motor terminal ②, and
- to rear wiper amplifier terminal ⑥
- from terminal ② of rear wiper switch
- through terminal ③ of rear wiper switch, and
- through body grounds (B11), (B22) and (D210).

With power and ground supplied, the rear washer motor operates.

When the rear wiper switch is turned to WASH position for one second or more, the rear wiper motor operates at low speed for approximately 3 seconds after the rear wiper switch is released. This feature is controlled by the rear wiper amplifier in the same manner as the intermittent operation.

# WIPER AND WASHER

## Rear Wiper and Washer/Schematic



(TW) : Models with theft warning system  
 (OT) : Models without theft warning system

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA










**EL**

IDX

# WIPER AND WASHER

## Rear Wiper and Washer/Wiring Diagram — WIP/R —

EL-WIP/R-01



Refer to last page (Foldout page).




(M91)

(M2), (B1)


# WIPER AND WASHER

## Rear Wiper and Washer/Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-02



Refer to last page (Foldout page).









GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# WIPER AND WASHER

## Rear Wiper and Washer/Wiring Diagram — WIP/R — (Cont'd)







EL-WIP/R-03




# WIPER AND WASHER

## Rear Wiper/Trouble Diagnoses


**REAR WIPER AMP. INSPECTION TABLE**  
(Data are reference values.)


Terminal No.	Item	Condition		Voltage (Approximate value)	
1	Amp. ON signal		Rear wiper switch	ON or INT	1V or less
				OFF	Approx. 12
2	Wiper amp. output		Rear wiper switch "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12
3	Ground	—		—	
4	Rear wiper motor		Rear wiper switch	ON, INT or WASH	Approx. 12
				OFF	1V or less
5	Power supply (See NOTE)		Rear glass hatch	OPENED	0V
				CLOSED	Approx. 12
6	Washer switch		Rear wiper switch	WASH	1V or less
				OFF	Approx. 12
7	Auto stop		Rear wiper switch "ON" or "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12

**NOTE:** Power to the rear wiper amp. will be interrupted when the rear glass hatch is opened. In that case, conduct the inspection of the rear wiper amp. with the rear glass hatch closed, unless otherwise indicated.




### Rear Wiper Installation and Adjustment

- Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
- Install wiper arm to portion (A) as in figure below and tighten wiper arm nut to specification.
- Then, set wiper arm to portion (B).  
: 13 - 18 N·m (1.3 - 1.8 kg-m, 9 - 13 ft-lb)




- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

# WIPER AND WASHER




## Rear Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.  
**Adjustable range:  $\pm 10^\circ$  (In any direction)**




## Washer Tube Layout



## Check Valve (for rear washer)


- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.





# HORN AND CIGARETTE LIGHTER

## Schematic



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA







**EL**

IDX

# HORN AND CIGARETTE LIGHTER

## Wiring Diagram — HORN —

EL-HORN-01




\* : This connector is not shown in " HARNESS LAYOUT".

Refer to last page (Foldout page).

E1 , M1

# HORN AND CIGARETTE LIGHTER



## Wiring Diagram — HORN — (Cont'd)



EL-HORN-02

Refer to EL-POWER.

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX








Refer to last page (Foldout page).

- (E1) (M1)
- (M10)

# HORN AND CIGARETTE LIGHTER

## Wiring Diagram — HORN — (Cont'd)

EL-HORN-03



Refer to last page (Foldout page).

(M2) (B1)

# REAR WINDOW DEFOGGER

## System Description

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal ③
- through 20A fuse (No. ⑤⑥, located in the fuse and fusible link box) and
- to rear window defogger relay terminal ⑥
- through 20A fuse (No. ⑤⑦, located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① and
- to smart entrance control unit terminal ⑩
- through 7.5A fuse [No. ⑫, located in the fuse block (J/B)].

Ground is supplied to terminal ① of the rear window defogger switch through body grounds ④④ and ④⑥.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal ② of the rear window defogger switch
- to smart entrance control unit terminal ⑫.

Terminal ④⑥ of the smart entrance control unit then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal ③ of the rear window defogger switch
- from terminal ⑤ of the rear window defogger relay.

Terminal ④ of the rear window defogger switch is grounded through body grounds ④④ and ④⑥.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

# REAR WINDOW DEFOGGER

## Wiring Diagram — DEF —

EL-DEF-01



24	25	26	27	28	29	30	31	32	33	34	35	36
11	12	13	14	15	16	17	18	19	20	21	22	23

6	7	8	9	10
1	2	3	4	5

2	6	1
4	3	5

1	2
5	7
3	6

1	D301	D303
	B	B

2	D304
	B

1	2
3	4
5	6

Refer to last page (Foldout page).

- (E1) (M1)
- (M2) (B1)
- (M10)


# REAR WINDOW DEFOGGER

## Wiring Diagram — DEF — (Cont'd)


EL-DEF-02

Refer to EL-POWER.

Preceding page



- : Models with door mirror defogger
- : Models with power window
- : Models without power window



Refer to last page (Foldout page).

- .
- .







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# REAR WINDOW DEFOGGER

## Trouble Diagnoses

### DIAGNOSTIC PROCEDURE

**SYMPTOM:** Rear window defogger does not activate, or does not go off after activating.






# REAR WINDOW DEFOGGER

## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### Rear window defogger relay


Check continuity between terminals ③ and ⑤, ⑥ and ⑦.



Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

#### Rear window defogger switch


Check continuity between terminals when rear window defogger switch is pushed and released.




Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

#### Filament Check

- Attach probe circuit tester (in volt range) to middle portion of each filament.



- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

## REAR WINDOW DEFOGGER

### Filament Check (Cont'd)



2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

### Filament Repair

#### REPAIR EQUIPMENT


1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

#### REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.



**Shake silver composition container before use.**

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



## REAR WINDOW DEFOGGER

### Filament Repair (Cont'd)



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

**Do not touch repaired area while test is being conducted.**

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## Audio/System Description

Refer to Owner's Manual for audio system operating instructions.

### MODELS WITH SPEAKER AMP.

Power is supplied at all times

- through 7.5A fuse [No. 24], located in the fuse block (J/B)]
- to audio terminal ⑥ and
- through 15A fuse [No. 4], located in the fuse block (J/B)]
- to speaker amp. terminals 72 and 74.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10], located in the fuse block (J/B)]
- to audio terminal ⑩.

Ground is supplied through the case of the audio.

Ground is supplied

- to speaker amp. terminals 71 and 73
- through body grounds B11, B22 and D210.

When the audio power knob is pushed to the ON position, power is supplied to speaker amp. terminal 79 from audio terminal ⑫ and audio signals are supplied

- through audio terminals ①, ②, ③, ④, 13, 14, 15 and 16
- to terminals 7, 8, 9, 10, 75, 76, 77, and 78 of the speaker amp.
- to tweeters and the front and rear speakers through terminals ①, ②, ⑤, ⑥, 81, 82, 85 and 86 of the speaker amp.

### MODELS WITHOUT SPEAKER AMP.

Power is supplied at all times

- through 7.5A fuse [No. 24], located in the fuse block (J/B)]
- to audio terminal ⑥.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10], located in the fuse block (J/B)]
- to audio terminal ⑩.

Ground is supplied through the case of the audio.

When the audio power knob is pushed to the ON position, audio signals are supplied

- through audio terminals ①, ②, ③, ④, 13, 14, 15 and 16
- to the front and rear speakers.

### BOSE SYSTEM

Power is supplied at all times

- through 15A fuse [No. 4], located in the fuse block (J/B)]
- to audio terminal ⑥,
- to audio amp. relay terminal ② and
- to rear speaker amp. terminal ⑪.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10], located in the fuse block (J/B)]
- to audio terminal ⑩.

Ground is supplied through the case of the audio.

Ground is supplied

- to audio amp. relay terminal ③,
- to front door speaker LH terminal ⑤ and
- to front door speaker RH terminal ⑤
- through body grounds M4 and M77
- to rear speaker amp. terminal 24
- through body grounds B11, B22 and D210.

When the radio POWER button is pressed, power is supplied to rear speaker amp. terminal ⑨ and audio amp. relay ① from audio terminal ⑫. Then audio amp. relay is energized and power is supplied


- to front door speaker LH terminal ④ and
- to front door speaker RH terminal ④.

Audio signals are supplied

- through audio terminals ①, ②, ③, ④, 13, 14, 15 and 16
- to terminals ② and ⑥ of the LH and RH front speakers and terminals ⑤, ⑦, 18 and 20 of the rear speaker amp.
- to LH and RH tweeters through terminals ① and ③ of the front speakers
- to rear LH and RH speakers through terminals ①, ②, 25 and 26 of the rear speaker amp.

# AUDIO AND POWER ANTENNA




## Audio (With speaker amp.)/Schematic




- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

## Audio (With speaker amp.)/Wiring Diagram — AUDIO —

EL-AUDIO-01



Refer to last page (Foldout page).





# AUDIO AND POWER ANTENNA

## Audio (With speaker amp.)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-02

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX







Refer to last page (Foldout page).  
M2, B1


# AUDIO AND POWER ANTENNA

## Audio (With speaker amp.)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-03



Refer to last page (Foldout page).








# AUDIO AND POWER ANTENNA

## Audio (With speaker amp.)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-04



GI  
MA  
EM  
LG  
EC  
FE  
GL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX






Refer to last page (Foldout page).  
M2, B1

# AUDIO AND POWER ANTENNA

## Audio (Without speaker amp.)/Wiring Diagram — AUDIO —

EL-AUDIO-05



Refer to last page (Foldout page).


M2, B1

M10

# AUDIO AND POWER ANTENNA





## Audio (Without speaker amp.)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-06



SE : 4WD A/T SE models without theft warning system  
ES : Except for 4WD A/T SE models without theft warning system


Refer to last page (Foldout page).



M2, B1



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## Audio (BOSE system)/Schematic



Audio (BOSE system)/Wiring Diagram  
— AUDIO —

EL-AUDIO-07



Refer to last page (Foldout page).



M10  
M81

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# AUDIO AND POWER ANTENNA

## Audio (BOSE system)/Wiring Diagram — AUDIO — (Cont'd)


EL-AUDIO-08



# AUDIO AND POWER ANTENNA

## Audio (BOSE system)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-09



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX







Refer to last page (Foldout page).  
M2 . B1



# AUDIO AND POWER ANTENNA

## Audio (BOSE system)/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-10



Refer to last page (Foldout page).

(M2), (B1)



## Power Antenna/System Description

Power is supplied at all times

- through 7.5A fuse (No. 24), located in the fuse block
- to power antenna terminal ⑥ .

Ground is supplied to the power antenna terminal ② through body grounds M4 and M66 .

When the audio is turned to the ON position, battery positive voltage is supplied

- through audio terminal ⑤
- to power antenna terminal ④ .

The antenna raises and is held in the extended position.

When the audio is turned to the OFF position, battery positive voltage is interrupted

- from audio terminal ⑤
- to power antenna terminal ④ .

The antenna retracts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA




**EL**

IDX

# AUDIO AND POWER ANTENNA

## Power Antenna/Wiring Diagram — P/ANT —

EL-P/ANT-01



Refer to last page (Foldout page).

M10

# AUDIO AND POWER ANTENNA

## Trouble Diagnoses

### RADIO

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Poor radio case ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse [No. 10], located in fuse block (J/B). Turn ignition switch ON and verify that battery positive voltage is present at terminal ⑩ of radio.</li> <li>Check radio case ground.</li> <li>Remove radio for repair.</li> </ol>
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> <li>7.5A fuse (except for BOSE system) 15A fuse (for BOSE system)</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 7.5/15A fuse [No. 24/4], located in fuse block (J/B) and verify that battery positive voltage is present at terminal ⑥ of radio.</li> <li>Remove radio for repair.</li> </ol>
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> <li>Antenna</li> <li>Poor radio ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check antenna.</li> <li>Check radio ground.</li> <li>Remove radio for repair.</li> </ol>
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> <li>Window antenna</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check window antenna.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Loose or missing ground bonding straps</li> <li>Ignition condenser or rear window defogger noise suppressor condenser</li> <li>Alternator</li> <li>Ignition coil or secondary wiring</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check ground bonding straps.</li> <li>Replace ignition condenser or rear window defogger noise suppressor condenser.</li> <li>Check alternator.</li> <li>Check ignition coil and secondary wiring.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Antenna</li> <li>Accessory ground</li> <li>Faulty accessory</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check antenna.</li> <li>Check accessory ground.</li> <li>Replace accessory.</li> </ol>

### MODELS WITH SPEAKER AMP.

Symptom	Possible causes	Repair order
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Speaker amp. ground circuit</li> <li>Speaker amp.</li> <li>Speaker amp. circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse [No. 4], located in fuse block (J/B). Verify that battery positive voltage is present at terminals ⑭ and ⑮ of speaker amp.</li> <li>Check speaker amp. ground circuit.</li> <li>Check speaker amp. voltages.</li> <li>Check wires for open or short between radio, speaker amp. and speakers.</li> <li>Remove radio for repair.</li> </ol>
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker</li> <li>Radio/amp. output</li> <li>Speaker circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker.</li> <li>Check radio/amp. output voltages.</li> <li>Check wires for open or short between radio/amp. and speaker.</li> <li>Remove radio for repair.</li> </ol>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# AUDIO AND POWER ANTENNA

## Trouble Diagnoses (Cont'd)

### MODELS WITHOUT SPEAKER AMP.

Symptom	Possible causes	Repair order
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>1. Speaker</li> <li>2. Radio output</li> <li>3. Speaker circuit</li> <li>4. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check speaker.</li> <li>2. Check radio output voltages.</li> <li>3. Check wires for open or short between radio and speaker.</li> <li>4. Remove radio for repair.</li> </ol>

### BOSE SYSTEM

Symptom	Possible causes	Repair order
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Audio amp. relay</li> <li>3. Audio amp. relay ground</li> <li>4. Amp. ON signal</li> <li>5. Radio output</li> <li>6. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse [No. 4], located in fuse block (J/B)]. Verify battery positive voltage is present at terminal ② of audio amp. relay.</li> <li>2. Check audio amp. relay.</li> <li>3. Check audio amp. relay ground (Terminal ③).</li> <li>4. Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal ① of audio amp. relay.</li> <li>5. Check radio output voltage (Terminal ②).</li> <li>6. Remove radio for repair.</li> </ol>
Individual front speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>1. Speaker ground</li> <li>2. Power supply</li> <li>3. Radio output</li> <li>4. Speaker</li> </ol>	<ol style="list-style-type: none"> <li>1. Check speaker ground (Terminal ⑤).</li> <li>2. Check power supply for speaker (Terminal ④).</li> <li>3. Check radio output voltage for speaker.</li> <li>4. Replace speaker.</li> </ol>
Both rear speakers are inoperative.	<ol style="list-style-type: none"> <li>1. Poor rear speaker amp. ground</li> <li>2. Power supply</li> <li>3. Amp. ON signal</li> <li>4. Rear speaker amp.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check rear speaker amp. ground circuit.</li> <li>2. Check power supply for rear speaker amp. (Terminal ⑩).</li> <li>3. Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal ⑨ of rear speaker amp.</li> <li>4. Remove rear speaker amp. for repair.</li> </ol>
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>1. Speaker</li> <li>2. Radio/amp. output</li> <li>3. Speaker circuit</li> <li>4. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check speaker</li> <li>2. Check radio/amp. output</li> <li>3. Check wires for open or short between radio/amp. and speakers.</li> <li>4. Remove radio for repair.</li> </ol>

### POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Radio signal</li> <li>3. Grounds (M4) and (M66)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 24], located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal ⑥ of power antenna.</li> <li>2. Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal ④ of power antenna.</li> <li>3. Check grounds (M4) and (M66).</li> </ol>

# AUDIO AND POWER ANTENNA

## Trouble Diagnoses (Cont'd)

### SPEAKER INSPECTION (Except for BOSE system)

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ② .
  - The resistance should be 2 - 4  $\Omega$ .
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ② .
  - A momentary hum or pop should be heard.

### ANTENNA INSPECTION


1. Using a jumper wire, clip an auxiliary ground between antenna and body.
  - If reception improves, check antenna ground (at body surface).
  - If reception does not improve, check main feeder cable for short circuit or open circuit.

### RADIO AND AMP INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amps. connected (If radio or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

### Location of Antenna



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX



# AUDIO AND POWER ANTENNA



## Antenna Rod Replacement

### REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



### INSTALLATION




1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

# POWER SUNROOF

## Wiring Diagram — SROOF —

EL-SROOF-01

Refer to EL-POWER.



Refer to last page (Foldout page).


(E1), (M1)  
(M10)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# DOOR MIRROR




## Wiring Diagram — MIRROR —

EL-MIRROR-01



Refer to last page (Foldout page).

M10






# POWER SEAT

## Power Seat/Wiring Diagram — SEAT —



EL-SEAT-01



POWER SEAT LH (B7)

Refer to last page (Foldout page).

(E1), (M1)  
(M2), (B1)





- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IOX

# POWER SEAT

## Power Seat/Wiring Diagram — SEAT — (Cont'd)


EL-SEAT-02




# HEATED SEAT

## Heated Seat/Wiring Diagram — HSEAT —


EL-HSEAT-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX





Refer to last page (Foldout page).



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Component Parts and Harness Connector Location



## System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 12], located in the fuse block (J/B)
- to ASCD main switch terminal ① and
- to ASCD hold relay terminal ⑦.

When ASCD main switch is in the ON position, power is supplied

- from terminal ② of the ASCD main switch
- to ASCD control unit terminal ④ and
- from terminal ③ of the ASCD main switch
- to ASCD hold relay terminal ①.

Ground is supplied

- to ASCD hold relay terminal ②
- through body grounds (E13) and (E41).

With power and ground supplied, the ASCD hold relay is activated, and power is supplied

- from terminal ⑥ of the ASCD hold relay
- through ASCD main switch terminals ② and ③
- to ASCD hold relay terminal ①.

Power remains supplied when the ASCD switch is released to the N (neutral) position

- from terminal ⑥ of ASCD hold relay
- to ASCD control unit terminal ④ and
- from terminal ③ of ASCD hold relay
- to ASCD clutch switch terminal ① (M/T models) or
- to park/neutral position relay terminal ③ (A/T models).

Ground is supplied

- to ASCD control unit terminal ③
- through body grounds (M4) and (M66).

### Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- ASCD clutch switch (M/T models) or
- park/neutral position relay (A/T models)
- ASCD brake switch.

A vehicle speed input is supplied

- to ASCD control unit terminal ⑦
- from terminal ⑩ of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal ①
- through 10A fuse [No. 20], located in the fuse block (J/B)].

When the brake pedal is depressed, power is supplied

- from terminal ② of the stop lamp switch
- to ASCD control unit terminal ⑪.

Power is supplied at all times

- through 10A fuse [No. 54], located in the fuse and fusible link box]
- to horn relay terminal ②
- through terminal ① of the horn relay
- to ASCD steering switch terminal ⑫).

When the SET/COAST switch is depressed, power is supplied

- from terminal ⑬ of the ASCD steering switch
- to ASCD control unit terminal ②.

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal ⑭ of the ASCD steering switch
- to ASCD control unit terminal ①.

When the system is activated, power is supplied

- to ASCD control unit terminal ⑤.

Power is interrupted when

- the clutch switch is depressed (M/T models),
- the selector lever is placed in P or N (A/T models) or

GI

MA

EM

LC

EC

FE

CL

MI

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## AUTOMATIC SPEED CONTROL DEVICE (ASCD)

### System Description (Cont'd)

- the ASCD brake switch is depressed.

#### Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal ⑧ of the ASCD control unit
- to ASCD pump terminal ① .

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control unit
- to ASCD pump terminal ② .

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control unit
- to ASCD pump terminal ③ .

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control unit
- to ASCD pump terminal ④ .

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ⑤ and
- to A/T control unit terminal ⑳ (A/T models).

Ground is supplied

- to combination meter terminal ⑳
- through body grounds (M4) and (M77) .

With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed on A/T models, a signal is sent


- from terminal ⑫ of the ASCD control unit
- to A/T control unit terminal ④ .

When this occurs, the A/T control unit cancels overdrive.

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Schematic








GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
**EL**  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD —

EL-ASCD-01



Refer to last page (Foldout page).

(E1) (M1)

(E3)


(M10)



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)


EL-ASCD-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
DX

Refer to last page (Foldout page).




E1 , M1  
M10




# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03



Refer to last page (Foldout page).





\* : This connector is not shown in "HARNES LAYOUT".

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04



Refer to last page (Foldout page).

(E1) (M1)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

**EL**

IDX



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)



## Trouble Diagnoses

### FAIL-SAFE SYSTEM

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

### Malfunction detection conditions

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> <li>● ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck.</li> <li>● Vacuum motor ground circuit or power circuit is open or shorted.</li> <li>● Air valve ground circuit or power circuit is open or shorted.</li> <li>● Release valve ground circuit or power circuit is open or shorted.</li> <li>● Vehicle speed sensor is faulty.</li> <li>● ASCD control unit internal circuit is malfunctioning.</li> </ul>	<ul style="list-style-type: none"> <li>● ASCD is deactivated.</li> <li>● Vehicle speed memory is canceled.</li> </ul>
<ul style="list-style-type: none"> <li>● ASCD brake switch or stop lamp switch is faulty.</li> </ul>	<ul style="list-style-type: none"> <li>● ASCD is deactivated.</li> <li>● Vehicle speed memory is not canceled.</li> </ul>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### Fail-safe system check



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### SYMPTOM CHART

PROCEDURE	Diagnostic procedure								
REFERENCE PAGE	EL-172	EL-174	EL-174	EL-175	EL-176	EL-177	EL-178	EL-178	EL-179
SYMPTOM	Fail-safe system check	DIAGNOSTIC PROCEDURE 1 (POWER SUPPLY AND GROUND CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)	DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CHECK)	DIAGNOSTIC PROCEDURE 4 (ASCD BRAKE/STOP LAMP SWITCH CHECK)	DIAGNOSTIC PROCEDURE 5 (ASCD STEERING SWITCH CHECK)	DIAGNOSTIC PROCEDURE 6 (VEHICLE SPEED SENSOR CHECK)	DIAGNOSTIC PROCEDURE 7 (ASCD PUMP CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 8 (ASCD ACTUATOR/PUMP CHECK)
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)		X	X	X		X	X		
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X				X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.						X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2						X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.						X			X
System is not released after CANCEL switch (steering) has been pressed.						X			X
Large difference between set speed and actual vehicle speed.									X
Deceleration is greatest immediately after ASCD has been set.									X

★1: It indicates that system is in fail-safe.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.



CI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 DX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

#### (POWER SUPPLY AND GROUND CIRCUIT CHECK)



1. Turn ignition switch ON.
2. Turn ASCD main switch "ON" to make sure indicators illuminate.

NG → Go to DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK).

OK

**A**

CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT.

1. Disconnect ASCD control unit connector.
  2. Turn ignition switch ON.
  3. Turn ASCD main switch "ON".
  4. Check voltage between control unit connector terminal ④ and ground.
- Battery voltage should exist.**

Refer to wiring diagram in EL-166.

NG → Go to DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CIRCUIT CHECK). Refer to EL-175.

OK

**B**

CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT.

Check continuity between ASCD control unit harness terminal ③ and body ground.

Refer to wiring diagram in EL-169.


NG → Repair harness.

OK

Go to next procedure.

### DIAGNOSTIC PROCEDURE 2

#### (ASCD MAIN SWITCH CHECK)



- A**
- CHECK POWER SUPPLY FOR ASCD MAIN SWITCH.
1. Disconnect main switch connector.
  2. Measure voltage between main switch terminals ① and ④.
- Battery voltage should exist.**

Refer to wiring diagram in EL-166.

NG → Check the following.

- 7.5A fuse (No. 12, located in the fuse block)
- Harness for open or short between fuse and ASCD main switch
- Ground circuit for ASCD main switch

OK

CHECK ASCD MAIN SWITCH.

Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-180).

NG → Replace ASCD main switch.

OK

Go to next procedure.







# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

#### (ASCD HOLD RELAY CHECK)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

**EL**



IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4

#### (ASCD BRAKE/STOP LAMP SWITCH CHECK)



**A**

**CHECK BRAKE/STOP LAMP CIRCUIT FOR ASCD CONTROL UNIT.**

1. Disconnect control unit connector.
2. Turn ignition switch ON.
3. Turn ASCD main switch "ON".
4. Check voltage between control unit connector terminal ⑤ and ground.

When brake pedal or clutch pedal (M/T) is depressed or A/T selector lever (A/T) is in "N" or "P" range:

**Approx. 0V**

When both brake pedal and clutch pedal (M/T) are released or A/T selector lever (A/T) is not in "N" or "P" range:

**Battery voltage should exist.**

Refer to wiring diagram in EL-167.

NG

Check the following.

- ASCD brake switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-180).
- ASCD clutch switch (M/T model)  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-180).
- Inhibitor switch (A/T model)  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-180).
- ASCD hold relay
- Harness for open or short

OK

**B**

**CHECK STOP LAMP SWITCH CIRCUIT.**

1. Disconnect control unit connector.
2. Check voltage between control unit terminal ⑪ and ground.

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

Refer to wiring diagram in EL-168.

NG

Check the following.

- 10A fuse [No. 20], located in the fuse block (J/B)]
- Harness for open or short between ASCD control unit and stop lamp switch
- Stop lamp switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-180).

OK



ASCD brake switch is OK.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

#### (ASCD STEERING SWITCH CHECK)



**A**

CHECK ASCDC STEERING SWITCH CIRCUIT FOR ASCDC CONTROL UNIT.

1. Disconnect control unit connector.
2. Check voltage between control unit harness terminals and ground.

	Terminal No.		Switch condition	
	⊕	⊖	Pressed	Released
SET/COAST SW	②	ground	12V	0V
RESUME/ACC SW	①	ground	12V	0V
CANCEL SW	②	ground	12V	0V
	①	ground	12V	0V

Refer to wiring diagram in EL-168.

OK → ASCDC steering switch is OK.

NG

CHECK POWER SUPPLY FOR ASCDC STEERING SWITCH.  
Does horn work?

NG → Check the following.

- 10A fuse (No. 54, located in the relay box)
- Horn relay
- Harness for open or short between horn and fuse

**B**

CHECK ASCDC STEERING SWITCH.

1. Disconnect ASCDC steering switch.
2. Check continuity between terminals by pushing each switch.

Switch	Terminal		
	①	②	③
RESUME/ACCEL	○	—	○
SET/COAST	○	○	
CANCEL	○	→ ○	○
	○	→ ○	○

NG → Replace ASCDC steering switch.

OK

Check harness for open or short between ASCDC steering switch and ASCDC control unit.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

#### (VEHICLE SPEED SENSOR CHECK)



**A**

#### CHECK VEHICLE SPEED SENSOR CIRCUIT.

1. Apply wheel chocks and jack up drive wheel.
2. Disconnect control unit connector.
3. Connect voltmeter between control unit terminal ⑦ and ground.
4. Slowly turn drive wheel.
5. Check deflection of voltmeter pointer.

Refer to wiring diagram in EL-170.

OK → Vehicle speed sensor is OK.


OK

Does speedometer operate normally?

No → Check speedometer and vehicle speed sensor circuit. Refer to EL-91.

Yes

Check harness for open or short between ASCD control unit terminal ⑦ and combination meter terminal ⑩.



### DIAGNOSTIC PROCEDURE 7

#### (ASCD PUMP CIRCUIT CHECK)

**A**

#### CHECK ASCD PUMP.

1. Disconnect ASCD pump connector.
2. Measure resistance between control unit harness terminals ① and ②, ③, ④.

Terminals	Resistance [Ω]	
①	④	Approx. 3
	②	Approx. 65
	③	Approx. 65

Refer to wiring diagram in EL-169.

NG → Replace ASCD pump.

OK




Check harness for open or short between ASCD pump and ASCD control unit.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8

#### (ASCD ACTUATOR/PUMP CHECK)



**A**  
**CHECK VACUUM HOSE.**  
 Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.

NG → Repair or replace hose.

OK ↓

**CHECK ASCD WIRE.**  
 Check wire for improper installation, rust formation or breaks.

NG → Repair or replace wire. Refer to "ASCD WIRE ADJUSTMENT" (EL-181).

OK ↓

**B**  
**CHECK ASCD ACTUATOR.**  
 1. Disconnect vacuum hose from ASCD actuator.  
 2. Apply -40 kPa (-0.41 kg/cm<sup>2</sup>, -5.8 psi) vacuum to ASCD actuator with hand vacuum pump.  
**ASCD wire should move to pull throttle drum.**  
 3. Wait 10 seconds and check for decrease in vacuum pressure.  
**Vacuum pressure decrease:  
 Less than 2.7 kPa (0.028 kg/cm<sup>2</sup>, 0.39 psi)**

NG → Replace ASCD actuator.

OK ↓

**C**  
**CHECK ASCD PUMP.**  
 1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.  
 2. If necessary remove ASCD pump.  
 3. Connect vacuum gauge to ASCD pump.  
 4. Apply 12V direct current to ASCD pump and check operation.

NG → Replace ASCD pump.

	12V direct current supply terminals		Operation
	⊕	⊖	
Air valve	①	③	Close
Release valve		④	Close
Vacuum motor		②	Operate

**A vacuum pressure of at least -35 kPa (-0.36 kg/cm<sup>2</sup>, -5.1 psi) should be generated.**

OK ↓

INSPECTION END

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENT CHECK

#### ASCD main switch

Check continuity between terminals by pushing switch to each position.


Switch position	Terminals					
	1	2	3	4	5	6
ON	○	○	○	○	ILL	
N		○	○	○	○ — (M) — ○	
OFF						



#### ASCD brake switch and stop lamp switch


Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.




#### ASCD clutch switch (For M/T models)

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes




#### Inhibitor switch (For A/T models)

Selector lever position	Continuity
	Between terminals ① and ②
"P"	Yes
"N"	Yes
Except "P" and "N"	No



## ASCD Wire Adjustment



### CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

- (1) Loosen lock nut and adjusting nut.
- (2) Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
- (3) Tighten adjusting nut just until throttle drum starts to move.
- (4) Loosen adjusting nut again 1/2 to 1 turn.
- (5) Tighten lock nut.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

DX

## System Description

Power is supplied at all times

- from 40A fusible link (letter [f], located in the fuse and fusible link box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to power window relay terminal ③ .

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to power window relay terminal ② .

Ground is supplied to power window relay terminal ①

- through body grounds (M4) and (M66) .

The power window relay is energized and power is supplied

- through power window relay terminal ⑤
- to power window main switch terminal ① ,
- to power window sub switch terminal ⑤ .

## MANUAL OPERATION

### Front door LH

Ground is supplied

- to power window main switch terminal ③
- through body grounds (M4) and (M77) .

### WINDOW UP

When the front LH switch in the power window main switch is pressed in the up position, power is supplied

- to front power window regulator LH terminal ②
- through power window main switch terminal ⑨ .

Ground is supplied

- to front power window regulator LH terminal ①
- through power window main switch terminal ⑧ .

Then, the motor raises the window until the switch is released.

### WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to front power window regulator LH terminal ①
- through power window main switch terminal ⑧ .

Ground is supplied

- to front power window regulator LH terminal ②
- through power window main switch terminal ⑨ .

Then, the motor lowers the window until the switch is released.

### Front door RH

Ground is supplied

- to power window main switch terminal ③
- through body grounds (M4) and (M77) .

### NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

### MAIN SWITCH OPERATION

Power is supplied

- through power window main switch (⑥ , ⑤ )
- to front power window sub-switch (③ , ④ ) .

The subsequent operation is the same as the sub-switch operation.

### SUB-SWITCH OPERATION

Power is supplied

- through front power window sub-switch (② , ① )
- to front power window regulator RH (② , ① ) .



# POWER WINDOW

## System Description (Cont'd)

Ground is supplied

- to front power window regulator RH (① , ② )
- through front power window sub-switch (① , ② )
- to front power window sub-switch (③ , ④ )
- through power window main switch (⑥ , ⑤ ).

Then, the motor raises or lowers the window until the switch is released.

### Rear door

Rear door windows will raise and lower in the same manner as front door RH window.

### AUTO OPERATION

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

The AUTO feature only operates on the driver's window downward movement.

### POWER WINDOW LOCK

The power window lock is designed to lock operation of all windows except for driver's door window.

When the lock switch is pressed to lock position, ground of the sub-switches in the power window main switch is disconnected. This prevents the power window motors from operating.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

# POWER WINDOW


## Schematic




# POWER WINDOW

## Wiring Diagram — WINDOW —

EL-WINDOW-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX




Refer to last page (Foldout page).  
 (E1), (M1)  
 (M2), (B1)  
 (M10)

# POWER WINDOW





## Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02

Preceding page W









POWER WINDOW MAIN SWITCH (D6)



# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03






GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX




# POWER WINDOW

## Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04



Refer to last page (Foldout page).  
(M2), (B1)



# POWER WINDOW

## Trouble Diagnoses

Symptom	Possible cause	Repair order	
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 7.5A fuse, 40A fusible link and (M21) circuit breaker</li> <li>2. Grounds (M4) and (M77)</li> <li>3. Power window relay</li> <li>4. Open/short in power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse (No. 12, located in fuse block [J/B]), 40A fusible link (letter F, located in fuse and fusible link box) and (M21) circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminal ① of power window main switch and terminal ⑤ of sub-switch.</li> <li>2. Check grounds (M4) and (M77).</li> <li>3. Check power window relay.</li> <li>4. Check W wire between power window relay and power window main switch for open/short circuit.</li> </ol>	GI MA EM LC
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> </ol>	EC FE
Passenger power window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switches</li> <li>2. Passenger side power window regulators</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check passenger side power window regulator.</li> <li>3. Check power window main switch.</li> <li>4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>	CL MT AT
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>	TF PD
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>	FA

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
**EL**  
 IDX

## System Description

Power is supplied at all times

- through 40A fusible link (letter **I**, located in the fuse and fusible link box)
- to circuit breaker terminal **①**
- through circuit breaker terminal **②**
- to smart entrance control unit terminal **①**.

Ground is supplied to smart entrance control unit terminal **⑩** through body grounds **(M4)** and **(M77)**.

### INPUT

When the door lock & unlock switch LH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑩**
- through door lock & unlock switch LH terminal **⑭**
- to door lock & unlock switch LH terminal **③**
- through body grounds **(M4)** and **(M77)**.

When the door lock & unlock switch RH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑩**
- through door lock & unlock switch RH terminal **①**
- to door lock & unlock switch RH terminal **②**
- through body grounds **(M4)** and **(M66)**.

When the door lock & unlock switch LH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑩**
- through door lock & unlock switch LH terminal **⑦**
- to door lock & unlock switch LH terminal **③**
- through body grounds **(M4)** and **(M77)**.

When the door lock & unlock switch RH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑩**
- through door lock & unlock switch RH terminal **③**
- to door lock & unlock switch RH terminal **②**
- through body grounds **(M4)** and **(M66)**.

### OUTPUT

#### Unlock

Ground is supplied

- to front door lock actuator LH terminal **③**
- to front door lock actuator RH terminal **③**
- to rear door lock actuator LH terminal **③**
- to rear door lock actuator RH terminal **③**
- to back door lock actuator terminal **②**
- through smart entrance control unit terminal **④**.

#### FRONT DOOR LH

Power is supplied

- to front door lock actuator LH terminal **①**
- through smart entrance control unit terminal **③**.

#### FRONT DOOR RH

Power is supplied

- to front door lock actuator RH terminal **①**,
- through smart entrance control unit terminal **②**.

#### REAR DOOR LH

Power is supplied

- to rear door lock actuator LH terminal **①**
- through smart entrance control unit terminal **②**.

#### REAR DOOR RH

Power is supplied

- to rear door lock actuator RH terminal **①**
- through smart entrance control unit terminal **②**.

#### BACK DOOR

Power is supplied

- to back door lock actuator terminal **①**
- through smart entrance control unit terminal **②**.



# POWER DOOR LOCK

## System Description (Cont'd)

Then, the doors are unlocked.

### Lock

Ground is supplied

- to front door lock actuator LH terminal ①
- through smart entrance control unit terminal ③ , and
- to front door lock actuator RH terminal ①
- to rear door lock actuator LH terminal ①
- to rear door lock actuator RH terminal ①
- to back door lock actuator ①
- through smart entrance control unit terminal ② .

Power is supplied

- to front door lock actuator LH terminal ③ ,
- to front door lock actuator RH terminal ③ ,
- to rear door lock actuator LH terminal ③
- to rear door lock actuator RH terminal ③
- to back door lock terminal ②
- through smart entrance control unit terminal ④ .

Then, the doors are locked.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

**EL**

IDX

# POWER DOOR LOCK



## Schematic



# POWER DOOR LOCK

## Wiring Diagram — D/LOCK —

EL-D/LOCK-01



Refer to last page (Foldout page).


(E1) (M1)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# POWER DOOR LOCK


## Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-02



Refer to last page (Foldout page).





(M2), (B1)



# POWER DOOR LOCK

## Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-03



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

# POWER DOOR LOCK

## Trouble Diagnoses

### SYMPTOM CHART


REFERENCE PAGE	EL-196	EL-197	EL-198
SYMPTOM	Main power supply and ground circuit check	Diagnostic procedure 1 (Door lock/unlock switch check)	Diagnostic procedure 2 (Door lock actuator check)
None of the doors lock/unlock when operating both door lock/unlock switch.	X		X
One or more doors are not locked and/or unlocked.			X
LH or RH lock/unlock switch does not operate.		X	



### MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Main power supply for smart entrance control unit (SECU)

Terminal		Ignition switch		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage



#### Ground circuit for smart entrance control unit




Terminals	Continuity
⑩ - Ground	Yes

# POWER DOOR LOCK

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

#### (Door lock/unlock switch check)



**A**

**CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL.**

1. Disconnect control unit connector.
2. Check continuity between control unit terminal ⑱ or ⑲ and ground.

Terminals	Door lock/unlock switch (LH or RH) condition	Continuity
⑱ - ground	Lock	Yes
	N and Unlock	No
⑲ - ground	Unlock	Yes
	N and Lock	No

Refer to wiring diagram in EL-193.

OK → Door lock/unlock switch is OK.

NG

**B C**

**CHECK DOOR LOCK/UNLOCK SWITCH.**

1. Disconnect door lock/unlock switch connector.
2. Check continuity between each door lock/unlock switch terminals.

**B** Power window main switch (Door lock/unlock switch driver side)

Condition	Terminals		
	3	14	7
Lock	○	○	
N	No continuity		
Unlock	○		○

**C** Door lock/unlock switch passenger side

Condition	Terminals		
	1	2	3
Lock	○	○	
N	No continuity		
Unlock		○	○

NG → Replace door lock/unlock switch.

OK

Check the following.

- Ground circuit for door lock/unlock switch
- Harness for open or short between door lock/unlock switch and control unit connector





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# POWER DOOR LOCK

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

#### (Door lock actuator check)



**A B**

**CHECK DOOR LOCK ACTUATOR CIRCUIT.**

Check voltage for door lock actuator.

**A** Door lock actuator front LH

Door lock/unlock switch condition	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	ground	Approx. 12
Unlock	③	ground	

**B** Door lock actuator front RH, rear and back

Door lock/unlock switch condition	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	ground	Approx. 12
Unlock	②	ground	

Refer to wiring diagram in EL-194.

NG

Replace smart entrance control unit. (Before replacing control unit, perform Diagnostic procedure 1.)

OK

**C D**

**CHECK DOOR LOCK ACTUATOR.**

1. Disconnect door lock actuator connector.

2. Apply 12V direct current to door lock actuator and check operation.

**C**

Door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	③	①
Locked → Unlocked	①	③

**D**

Back door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	②	①
Locked → Unlocked	①	②

NG

Replace door lock actuator.

OK

Check harness for open or short between control unit connector and door lock actuator.



## System Description

Power is supplied at all times

- to smart entrance control unit terminal ①
- through 40A fusible link (letter ①, located in the fuse and fusible link box).

Power is supplied at all times

- to interior lamp terminal ①
- through 7.5A fuse [No. ⑮], located in the fuse block (J/B)].

Power is supplied at all times

- to key switch terminal ①
- through 7.5A fuse [No. ⑳], located in the fuse block (J/B)].

Power is supplied at all times

- to multi-remote control relays-1 and 2 terminal ①
- through 15A fuse [No. ⑭], located in the fuse block (J/B)].

Terminal ⑩ of the smart entrance control unit is grounded through body grounds ④ and ⑦.

### INPUTS

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal ②
- to smart entrance control unit terminal ⑳.

When the front door switch LH is OPEN, ground is supplied

- to smart entrance control unit terminal ⑮
- through front door switch LH terminal ①
- to front door switch LH terminal ②
- through body grounds ①, ② and ⑩.

When the each door switch is OPEN, ground is supplied

- to smart entrance control unit terminal ⑯
- through each door switch body ground or ①, ② and ⑩.

When the front door lock actuator LH (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal ⑫
- through door lock actuator LH (door unlock sensor) terminal ④
- to door lock actuator LH (door unlock sensor) terminal ②
- through body grounds ④ and ⑦.

When the front door lock actuator RH (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal ⑬ in the same manner as front door lock actuator LH.

When the rear door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal ⑭ in the same manner as other door lock actuator.

Remote controller signal input

- through antenna
- to smart entrance control unit terminal ⑳.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard lamp
- ID code entry.

### OPERATED PROCEDURE

#### Power door lock operation

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

smart entrance control unit locks all the doors with input of LOCK signal from remote controller.

Smart entrance control unit unlocks the doors with input of UNLOCK signal from remote controller.

Refer to "Power Door Lock" (EL-190).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# MULTI-REMOTE CONTROL SYSTEM

## System Description (Cont'd)

### Interior lamp operation

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

For detailed description, refer to "Interior, Spot and Luggage Room Lamps" (EL-78).

### Panic alarm operation

When key switch is OFF (when ignition key is not inserted in key cylinder), multi-remote control system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from remote controller.

For detailed description, refer to "THEFT WARNING SYSTEM" (EL-215).

### Hazard lamp operation

When the following input signals are all supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);
- door lock actuator (door unlock sensor) LOCKED (when all the doors are locked);

multi-remote control system outputs the following ground signals with input of LOCK signal from remote controller:


- to multi-remote control relays-1 and 2 terminal ② ;
- through smart entrance control unit terminal ⑦ .

As a result, multi-remote control relay-1 and -2 are energized, and hazard warning lamps flash on and off.

For detailed description, refer to "Turn Signal and Hazard Warning Lamps" (EL-64).

# MULTI-REMOTE CONTROL SYSTEM

## Schematic




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# MULTI-REMOTE CONTROL SYSTEM


## Wiring Diagram — MULTI —

EL-MULTI-01



Refer to EL-POWER.

SMART ENTRANCE CONTROL UNIT (M16)






Refer to last page (Foldout page).

- (E1), (M1)
- (E3)
- (M10)

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-02



Refer to last page (Foldout page).


(M2) , (B1)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
HOX

# MULTI-REMOTE CONTROL SYSTEM


## Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03



Refer to last page (Foldout page).




(M2), (B1)



# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-04



Refer to last page (Foldout page).


- (E1) (M1)
- (M10)

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX


# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses TROUBLE SYMPTOM

- All functions of remote control system do not operate.



- Some functions of multi-remote controller do not operate.



- Note:**
- The unlock operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
  - The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder, or if one of the doors is opened.




# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

Check remote controller battery.



**A**


#### CHECK REMOTE CONTROLLER BATTERY.

Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.

Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal	Battery negative terminal	2.5 - 3.0V
⊕	⊖	

**Note:**

Remote controller does not function if battery is not set correctly.



### DIAGNOSTIC PROCEDURE 2

Check antenna of multi remote control system.

**A**

#### CHECK ANTENNA FEEDER CABLE.

- 1) Disconnect feeder cable connector from control unit.
- 2) Remove LH rear pillar garnish and disconnect feeder cable connector from antenna.
- 3) Check continuity between the feeder cable connectors.

**Continuity should exist.**

- 4) Check continuity between the feeder cable connector terminal and body ground.

**Continuity should not exist.**

Refer to wiring diagram in EL-205.

NG → Replace feeder cable.

OK ↓

**B**


#### CHECK ANTENNA.

- 1) Remove rear pillar garnish and disconnect feeder cable connector from antenna.
- 2) Visually check film antenna.

NG → Replace antenna.

OK ↓

Antenna of multi-remote control is OK.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL




DX

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

All remote controls do not function even if remote controller is operated properly.



**A**

**CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT.**

- 1) Disconnect connector from control unit.
- 2) Check voltage between control unit terminal ① and ground.

**Battery voltage should exist.**

Refer to wiring diagram in EL-202.

NG → Check the following.

- 40A fusible link (Letter **f**), located in fuse and fusible link box)
- (M21) circuit breaker
- Harness for open or short between control unit and circuit breaker

**B**

**CHECK GROUND CIRCUIT FOR CONTROL UNIT.**

Check continuity between terminal ⑩ and ground.

**Continuity should exist.**

Refer to wiring diagram in EL-202.

NG → Check ground harness.

**C**

**CHECK DOOR SWITCH CIRCUIT.**

Check voltage between control unit terminal ⑮ and ground, ⑯ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
Driver side door switch	⑮	ground	Open	0
			Close	Approx. 12
Other door switches	⑯	ground	Open	0
			Close	Approx. 12

Refer to wiring diagram in EL-203.

NG → Check the following.

- Door switch  
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-212).
- Door switch ground circuit (Driver side, back door) or door switch ground condition (Other door)
- Harness for open or short between control unit and door switch




OK →

Ⓐ

(Go to next page.)

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)



**D**

**CHECK UNLOCK SENSOR CIRCUIT.**  
Check voltage between control unit terminal ⑫ and ground.

	Terminals		Condi- tion	Voltage [V]
	⊕	⊖		
Front LH door	⑫	ground	Unlock	0
			Lock	Approx. 12
Front RH door	⑬	ground	Unlock	0
			Lock	Approx. 12
Rear door	⑭	ground	Unlock	0
			Lock	Approx. 12

Refer to wiring diagram in EL-204.

Check the following.

- Door unlock sensor
- Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-212).
- Door unlock sensor ground circuit
- Harness for open or short between control unit and unlock sensor

**E**

**CHECK IGNITION SWITCH "ACC" CIRCUIT.**

- 1) Disconnect control unit connector.
- 2) Check voltage between control unit terminal ⑰ and ground while ignition switch is "ACC".

**Battery voltage should exist.**

Refer to wiring diagram in EL-202.

Check the following.

- 10A fuse [No. ⑩], located in fuse block (J/B)
- Harness for open or short between control unit and fuse

**F**

**CHECK KEY SWITCH INPUT SIGNAL.**  
Check voltage between control unit terminal ⑳ and ground.

Condition	Voltage [V]
Key is inserted.	Approx. 12
Key is withdrawn.	0

Refer to wiring diagram in EL-202.

Check the following.

- 7.5A fuse [No. ⑳], located in fuse block (J/B)
- Key switch
- Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-212).
- Harness for open or short between key switch and fuse
- Harness for open or short between control unit and key switch

Check operation parts in multi-remote control system for function.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4

Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller. Everything else functions.



**A**

CHECK INTERIOR LAMP CIRCUIT. When interior lamp switch is "DOOR" position, check voltage across control unit terminal ⑨ and ground.

**Does battery voltage exist?**

No

Repair harness between control unit and interior lamp.

Refer to wiring diagram in EL-202.

Yes

**A**

Push unlock button of remote controller and check voltage across control unit terminal ⑨ and ground.

No

Replace smart entrance control unit.

Multi-remote controller button condition	Voltage (V)
Unlock button is pushed.	0
Unlock button is not pushed.	Battery voltage

Yes









Check system again.

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

Hazard indicator does not flash twice when pressing lock button of remote controller. Everything else functions.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# MULTI-REMOTE CONTROL SYSTEM


## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### Door switches

Check continuity between terminals when door switch is pushed and released.


	Terminal No.	Condition	Continuity
Front LH door switch	① - ② , ③ - ground	Closed	No
		Open	Yes
Back door switch	② - ①	Closed	No
		Open	Yes
Other door switches	① - ground	Closed	No
		Open	Yes



#### Door lock actuator (Door unlock sensor)

Check continuity between terminals when door is locked and unlocked.


Terminal No.	Condition	Continuity
④ - ②	Door is locked.	No
	Door is unlocked.	Yes



#### Key switch (insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Terminal No.	Condition	Continuity
① - ②	Key is inserted.	Yes
	Key is removed.	No



# MULTI-REMOTE CONTROL SYSTEM

## Replacing Remote Controller or Control Unit


Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

### ID Code Entry Procedure

To enter the ID code, follow the procedures below.

### PROCEDURE



### NOTE

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

# THEFT WARNING SYSTEM

## Component Parts and Harness Connector Location






## System Description

### DESCRIPTION

#### 1. Operation flow



#### 2. Setting the theft warning system

##### Initial condition

- (1) Close all doors.
- (2) Close hood and glass hatch.

##### Disarmed phase

The theft warning system is in the disarmed phase when any door(s), hood or glass hatch is opened. The security indicator lamp blinks every second.

##### Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when hood, glass hatch and all doors are closed and locked by key or multi-remote controller. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

#### 3. Canceling the set theft warning system

When the following (a) or (b) operation is performed, the armed phase is canceled.

- (a) Unlock the doors with the key or multi-remote controller.
- (b) Open the glass hatch with the key. When the glass hatch is closed after opening the glass hatch with the key, the system returns to the armed phase.

#### 4. Activating the alarm operation of the theft warning system

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When the following operation (a) or (b) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. (At the same time, the system disconnects the starting system circuit.)

- (a) Engine hood, glass hatch or any door is opened before unlocking door with key or multi-remote controller.
- (b) Door is unlocked without using key or multi-remote controller.

GI

MA

EM

LC

EC

FE

CL

MH

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

DX

## THEFT WARNING SYSTEM

### System Description (Cont'd)

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times

- through 7.5A fuse [No. 24], located in the fuse block (J/B)
- to security indicator lamp terminal ①.

Power is supplied at all times

- through 40A fusible link (letter f), located in the fuse and fusible link box)
- to smart entrance control unit terminal ①.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10], located in the fuse block (J/B)
- to smart entrance control unit terminal ⑰.

Ground is supplied

- to smart entrance control unit terminal ⑩
- through body grounds M4 and M77.

### THEFT WARNING SYSTEM ACTIVATION

The operation of the theft warning system is controlled by the doors, hood and glass hatch.

To activate the theft warning system, the smart entrance control unit must receive signals indicating the doors, hood and glass hatch are closed and the doors are locked.

When a door is open, smart entrance control unit terminal ⑮ or ⑯ receives a ground signal from each door switch.

When a door is unlocked, smart entrance control unit terminal ⑫, ⑬ or ⑭ receives a ground signal from terminal ④ of each door unlock sensor.

When the hood is open, smart entrance control unit terminal ⑲ receives a ground signal

- from terminal ① of the hood switch
- through body grounds E13 and E41.

When the glass hatch is open, smart entrance control unit terminal ⑳ receives a ground signal

- from terminal ① of the glass hatch switch
- through body grounds D210, B11 and B22.

When the doors are locked with key or multi-remote controller

If none of the described conditions exist, the theft warning system will automatically shift to armed phase.

### THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key is used to lock doors, terminal ⑳ receives a ground signal

- from terminal ③ of the key cylinder switch LH
- from terminal ① of the door key cylinder switch RH
- through body grounds M4 and M77 or M4 and M66
- from terminal ① of the back door key cylinder switch
- through body grounds B11, B22 and D210.

If this signal or lock signal from remote controller is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal ㉓ supplies ground to terminal ② of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

# THEFT WARNING SYSTEM

## System Description (Cont'd)

### THEFT WARNING SYSTEM ALARM OPERATION

The theft warning system is triggered by

- opening a door or the glass hatch without using the key
- opening the hood
- unlocking door.

Once the theft warning system is in armed phase, if the smart entrance control unit receives a ground signal at terminal ⑫, ⑬, ⑭ (door unlock sensor), ⑮, ⑯ (door switch), ⑰ (glass hatch switch) or ⑱ (hood switch), the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

Power is supplied at all times

- through 7.5A fuse [No. ⑫], located in the fuse block (J/B)].
- to theft warning relay terminal ①.

If the theft warning system is triggered, ground is supplied

- from terminal ⑳ of the smart entrance control unit
- to theft warning relay terminal ②.

With power and ground supplied, power to the clutch interlock relay (M/T models) or inhibitor switch (A/T models) is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 7.5A fuse (No. ⑫), located in fuse and fusible link box)
- to theft warning lamp relay terminal ① and
- to theft warning horn relay terminal ①.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ⑧ of the smart entrance control unit
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

### THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the glass hatch must be unlocked with the key or remote controller.

When the key is used to unlock the back door, smart entrance control unit terminal ⑳ receives a ground signal

- from terminal ① of the LH key cylinder switch
- from terminal ③ of the RH key cylinder switch
- from terminal ② of the back door key cylinder switch.

When the key is used to open the glass hatch, smart entrance control unit terminal ㉑ receives a ground signal from terminal ③ of the back door key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

### PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently.

- from smart entrance control unit terminal ⑧
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


# THEFT WARNING SYSTEM

## Schematic



# THEFT WARNING SYSTEM

## Schematic (Cont'd)



Ⓢ : For U.S.A.  
 Ⓢ : For Canada

GI  
 MA  
 EM  
 LG  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA



**EL**

IDX

# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT —

EL-THEFT-01




Refer to last page (Foldout page).

- E1, M1
- M2, B1
- M10

# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

Refer to last page (Foldout page).



(M2) (B1)



# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



Refer to last page (Foldout page).






(M2), (B1)



# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04



Refer to last page (Foldout page).


(M2), (B1)

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-05



Refer to EL-POWER.



MT : M/T model  
AT : A/T model

Next page

Next page

Refer to last page (Foldout page).


E1, M1  
E3



# THEFT WARNING SYSTEM

## Wiring Diagram — THEFT — (Cont'd)




EL-THEFT-06



Refer to EL-POWER.

- U : For U.S.A.
- C : For Canada
- DT : Models with daytime light control system
- OD : Models without daytime light control system

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA



**EL**


IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses

### PRELIMINARY CHECK

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



After performing preliminary check, go to symptom chart in next page.

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

Before starting trouble diagnoses below, perform preliminary check, EL-226.

Symptom numbers in the symptom chart correspond with those of preliminary check.

### SYMPTOM CHART

PROCEDURE		—	Power supply and ground circuit check		Diagnostic procedure								—
REFERENCE PAGE		EL-226	EL-228	EL-228	EL-229	EL-232	EL-233	EL-234	EL-235	EL-236	EL-237	EL-238	EL-206
SYMPTOM		Preliminary check	Power supply circuit check	Ground circuit check	Diagnostic Procedure 1 (Door, hood and glass hatch switch check)	Diagnostic Procedure 2 (Security indicator lamp check)	Diagnostic Procedure 3 (Door unlock sensor check)	Diagnostic Procedure 4 (Door key cylinder switch check)	Diagnostic Procedure 5 (Back door key cylinder switch check)	Diagnostic Procedure 6 (Theft warning horn alarm check)	Diagnostic Procedure 7 (Theft warning headlamp alarm check)	Diagnostic Procedure 8 (Starter interrupt system check)	Check "MULTI-REMOTE CONTROL" system.
1	Theft warning indicator does not turn "ON" or blinking.	X	X	X		X							
2	Theft warning system cannot be set by ...												
	All items	X	X	X	X		X						
	Door out side key	X	X	X				X					
3	Theft warning system does not alarm when ...												
	Any door is opened.	X	X	X	X								
4	*1 Theft warning system does not activate.												
	All function	X	X	X	X		X						
	Horn alarm	X	X	X						X			
	Headlamp alarm	X	X	X							X		
5	Theft warning system cannot be canceled by ...												
	Door out side key	X	X	X				X					
	Back door key	X	X	X					X				
	Multi-remote control	X	X	X									X

X : Applicable

\*1: Make sure the system is in the armed phase.

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA




IDX

# THEFT WARNING SYSTEM


## Trouble Diagnoses (Cont'd)

### POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
⑩	Ground	0V	0V	Battery voltage
⑰	Ground	0V	Battery voltage	Battery voltage




#### Ground circuit check

Terminals	Continuity
⑩ - Ground	Yes

# THEFT WARNING SYSTEM


## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1-(1) (Door switch check)



- 1) Turn ignition switch "OFF" and remove key from key cylinder.
- 2) Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off.
- 3) Open any passenger door or back door. "SECURITY" indicator lamp should blink every second.

OK → Door switch is OK.



- A**
- CHECK DOOR SWITCH INPUT SIGNAL.  
Check voltage between control unit terminals 15 or 16 and ground.

OK → Door switch is OK.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
Front LH door switch	15	ground	Open	0
			Closed	Approx. 12
Other door switches	16	ground	Open	0
			Closed	Approx. 12

Refer to wiring diagram in EL-221.

- B**
- CHECK DOOR SWITCH.
- 1) Disconnect door switch connector.
  - 2) Check continuity between door switch terminals.

NG → Replace door switch.

	Terminals	Condition	Continuity
Front LH door switch	① - ②, ③ - ground	Closed	No
		Open	Yes
Back door switch	② - ①	Closed	No
		Open	Yes
Other door switches	① - ground	Closed	No
		Open	Yes

- OK
- Check the following.
- Door switch ground circuit (Front LH, back door) or door switch ground condition
  - Harness for open or short between control unit and door switch


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
JDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1-(2)


#### (Hood switch check)



- 1) Turn ignition switch "OFF" and remove key from key cylinder.
- 2) Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off.
- 3) Open hood. "SECURITY" indicator lamp should blink every second.

OK → Hood switch is OK.

NG



Check hood switch and hood fitting condition.

NG → Adjust installation of hood switch or hood.

OK

**A**

**CHECK HOOD SWITCH INPUT SIGNAL.**  
Check voltage between control unit terminal ② and ground.

Condition	Voltage [V]
Hood is open.	0
Hood is closed.	Approx. 12

Refer to wiring diagram in EL-220.

OK → Hood switch is OK.

NG

**B**

**CHECK HOOD SWITCH.**  
1) Disconnect hood switch connector.  
2) Check continuity between hood switch terminals.

Terminals	Condition	Continuity
① - ②	Pushed	No
	Released	Yes

NG → Replace hood switch.

OK

- Check the following.
- Hood switch ground circuit
  - Harness for open or short between control unit and hood switch




# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)


### DIAGNOSTIC PROCEDURE 1-(3)

#### (Glass hatch switch check)



- 1) Turn ignition switch "OFF" and remove key from key cylinder.
- 2) Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off.
- 3) Open glass hatch. "SECURITY" indicator lamp should blink every second.

OK → Glass hatch switch is OK.



- A**
- CHECK GLASS HATCH SWITCH INPUT SIGNAL.
- Check voltage between control unit terminal ② and ground.

Condition	Voltage [V]
Glass hatch is open.	Approx. 0
Glass hatch is closed.	Approx. 12

Refer to wiring diagram in EL-220.

OK → Glass hatch switch is OK.

- B**
- CHECK GLASS HATCH SWITCH.
- 1) Disconnect glass hatch switch connector.
  - 2) Check continuity between glass hatch switch terminals.

Terminals	Condition	Continuity
① - ②	Closed	No
	Open	Yes

NG → Replace glass hatch switch.

- OK →
- Check the following.
- Glass hatch switch ground circuit
  - Harness for open or short between control unit and glass hatch switch

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

PA




**EL**

IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)



### DIAGNOSTIC PROCEDURE 2 (Security indicator lamp check)



# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3 (Door unlock sensor check)



**A**

**CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.**  
Check voltage between control unit terminals ⑫, ⑬ or ⑭ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
Front LH door	⑫	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	⑬	Ground	Locked	Approx. 12
			Unlocked	0
Rear door	⑭	Ground	Locked	Approx. 12
			Unlocked	0

Refer to wiring diagram in EL-222.

**B**

**CHECK DOOR UNLOCK SENSOR.**  
1) Disconnect door unlock sensor connector.  
2) Check continuity between door unlock sensor terminals.

Terminals	Condition	Continuity
④ - ②	Locked	No
	Unlocked	Yes

OK

Check the following.

- Door unlock sensor ground circuit
- Harness for open or short between control unit and door unlock sensor

OK → Door unlock sensor is OK.

NG → Replace door unlock sensor.

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4 (Door key cylinder switch check)



**A**


CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL).  
Check voltage between control unit terminals ③ or ④ and ground.

Terminals		Key position	Voltage [V]
⊕	⊖		
③	Ground	Neutral	Approx. 12
		Lock	0
④	Ground	Neutral	Approx. 12
		Unlock	0

Refer to wiring diagram in EL-223.

OK → Door key cylinder switch is OK.

NG



**B**

CHECK DOOR KEY CYLINDER SWITCH.

- 1) Disconnect door key cylinder switch connector.
- 2) Check continuity between door key cylinder switch terminals.

Terminals	Key position	Continuity
LH: ③ - ②	Neutral	No
RH: ① - ②	Lock	Yes
LH: ① - ②	Neutral	No
RH: ③ - ②	Unlock	Yes

OK → Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between control unit and door key cylinder switch


NG → Replace door key cylinder switch.

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

#### (Back door key cylinder switch check)



**A**

**CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL).**


Check voltage between control unit terminals ⑩, ⑪ or ⑫ and ground.

OK → Back door key cylinder switch is OK.

	Terminals		Key position	Voltage [V]
	⊕	⊖		
Back door	⑩	Ground	Neutral	Approx. 12
			Between neutral and lock	0
Back door	⑪	Ground	Neutral	Approx. 12
			Between neutral and unlock	0
Glass hatch	⑫	Ground	Neutral	Approx. 12
			Between lock and unlock	0

Refer to wiring diagram in EL-223.

NG



**B C**

**CHECK BACK DOOR KEY CYLINDER SWITCH.**

- 1) Disconnect back door key cylinder switch connector.
- 2) Check continuity between back door key cylinder switch terminals.


NG → Replace back door key cylinder switch.

Key position	Terminals			
	①	②	③	④
Between neutral and lock (Back door)	○			○
Between neutral and unlock (Back door)		○		○
Between lock (Back door) and unlock (glass hatch)			○	○

OK

Check the following.

- Back door key cylinder switch ground circuit
- Harness for open or short between control unit and back door key cylinder switch







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
DX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)




### DIAGNOSTIC PROCEDURE 6 (Theft warning horn alarm check)



# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7 (Theft warning headlamp alarm check)



**A**

CHECK THEFT WARNING HEADLAMP ALARM OPERATION.

1. Disconnect control unit connector.
2. Apply ground to control unit terminal ⑧.

**Does headlamp alarm activate?**

Refer to wiring diagram in EL-224.

Yes → Headlamp alarm is OK.

No

Does headlamp come on when turning lighting switch "ON"?

No → Check headlamp system. Refer to "HEADLAMP".

Yes

Check theft warning lamp relay.

NG → Replace.

OK

**B**

CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY.

1. Disconnect theft warning lamp relay connector.
2. Check voltage between terminal ① and ground.

**Positive battery voltage should exist.**

Refer to wiring diagram in EL-225.

NG → Check the following.

- 7.5A fuse (No. 52, located in the fuse and fusible link box)
- Harness for open or short between theft warning lamp relay and fuse

OK

**C**

CHECK THEFT WARNING LAMP RELAY CIRCUIT.

1. Disconnect theft warning lamp relay connector.
2. Check voltage between terminals ③ and ⑤.

**Positive battery voltage should exist.**

NG → Check harness for open or short.

3. Check voltage between terminals ⑥ and ⑦.

**Positive battery voltage should exist.**

OK

Check harness for open or short between theft warning lamp relay and ground.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

**EL**


IDX

# THEFT WARNING SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8

#### (Starter interrupt system check)



**A**

#### CHECK STARTER MOTOR CUT OUTPUT SIGNAL.

1. Turn ignition switch "ON".
2. Check voltage between control unit terminal ③② and ground.

Condition	Voltage [V]
Except starter killed phase	Approx. 12
Starter killed phase	0

Refer to wiring diagram in EL-224.

NG

Check the following.

- 7.5A fuse [No. 12], located in fuse block (J/B)]
- Harness for open or short between theft warning relay and fuse
- Harness for open or short between control unit and theft warning relay

OK

Check theft warning relay.

NG

Replace relay.

OK

CHECK THE CONNECTIONS AT EACH CONNECTOR.



# SMART ENTRANCE CONTROL UNIT

## Description

The following systems are controlled by the smart entrance control unit.

- Warning buzzer
- Rear window defogger timer
- Power door lock
- Multi-remote control system
- Theft warning system

For detailed description and wiring diagrams, refer to the relevant pages for the each system.

The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.

System	Input	Output
Power door lock	Door lock and unlock switch	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switch Door unlock sensor Antenna (remote controller signal)	Theft warning horn relay Theft warning lamp relay Interior lamp Multi-remote control relay 1 and 2 Door lock actuator
Warning buzzer	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch Front door switch LH	Warning buzzer
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Theft warning	Ignition switch (ACC, ON) Door switch Hood switch Glass hatch switch Door key cylinder switch (lock/unlock) Back door key cylinder switch (lock/unlock) Door unlock sensor	Theft warning horn relay Theft warning lamp relay Theft warning relay (Starter interrupt) Security indicator

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


# SMART ENTRANCE CONTROL UNIT

## Schematic



# SMART ENTRANCE CONTROL UNIT

## Schematic (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# SMART ENTRANCE CONTROL UNIT

## Input/Output Operation Signal



### SMART ENTRANCE CONTROL UNIT

Terminal No.	Connections	Operated condition	Voltage (V) (Approximate values)
1	Power source (C/B)	—	12V
2	Passenger door lock motor	Door lock & unlock switch	Unlocked
3	Driver door lock motor		Free
4	Driver and passenger door lock motors	Door lock & unlock switch	Locked
			Free
7	Multi-remote control relays -1 and 2	When doors are locked using remote controller	12V → 0V
8	Theft warning horn relay	When panic alarm is operated using remote controller	12V → 0V
9	Interior lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V
10	Ground	—	—
11	Ignition switch (ON)	Ignition key is in "ON" position	12V
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V
14	Rear door unlock sensor	Rear door LH & RH: Locked → Unlocked	12V → 0V
15	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V
16	Passenger door switch	OFF (Closed) → ON (Open)	12V → 0V
17	Ignition switch (ACC)	"ACC" position	12V
18	Door lock & unlock switches	Neutral → Locks	12V → 0V
19	Door lock & unlock switches	Neutral → Unlocks	12V → 0V
20	Rear window defogger switch	OFF → ON	12V → 0V
21	Seat belt switch	Unfasten → Fasten (Ignition key is in "ON" position)	0V → 12V
23	Warning buzzer	OFF → ON	12V → 0V
24	Ignition key switch (Insert)	IGN key inserted → IGN key removed from IGN key cylinder	12V → 0V
25	Headlamp switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V
26	Glass hatch switch	ON (Open) → OFF (Closed)	0V → 12V
27	Back door key unlock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
29	Hood open signal	ON (Open) → OFF (Closed)	0V → 12V
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	12V → 0V
31	Door key cylinder lock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
32	Theft warning relay (Starter cut)	OFF → ON (Ignition key is in "ON" position)	12V → 0V
33	Theft warning indicator	Goes off → Illuminates	12V → 0V
36	Rear defogger relay	OFF → ON (Ignition key is in "ON" position)	12V → 0V
37	Multi-remote antenna	—	—

# INTEGRATED HOMELINK TRANSMITTER

## Wiring Diagram — TRNSMT —

EL-TRNSMT-01



Refer to last page (Foldout page).

M10

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS




BT

HA

**EL**

IDX

# INTEGRATED HOMELINK TRANSMITTER




## Trouble Diagnoses

### DIAGNOSTIC PROCEDURE

**SYMPTOM: Transmitter does not activate receiver.**




Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.



\*For details, refer to Technical Service Bulletin.

# LOCATION OF ELECTRICAL UNITS



## Engine Compartment



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
BS  
BT  
HA  
EL  
IDX

# LOCATION OF ELECTRICAL UNITS


## Passenger Compartment





# LOCATION OF ELECTRICAL UNITS


## Passenger Compartment (Cont'd)



G  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# HARNES LAYOUT


## Outline



# HARNESS LAYOUT

## How to Read Harness Layout

Example:



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

### To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

### CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> <li>• Cavity: Less than 4</li> <li>• Relay connector</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: From 5 to 8</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: More than 9</li> </ul>	—	—		
<ul style="list-style-type: none"> <li>• Ground terminal etc.</li> </ul>	—			

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

# HARNESS LAYOUT

## Main Harness



★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
Do not disconnect these connectors except in the case of working  
according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.





# HARNESS LAYOUT

## Main Harness (Cont'd)

B4★	M1	SMJ	To E1	D1	M41	B/16	A/C auto amp. (For auto A/C)	A3	M81	B/2	Fuse block (J/B)
B4★	M2	SMJ	To B1	D1	M42	W/4	Recirculation switch	D2	M90	W/2	Diode
B4	M3	B/20	ASCD control unit	E1	M43	W/6	Fan switch	B3	M91	W/12	Fuse block (J/B)
A3	M4	—	Body ground	E1	M44	W/3	A/C switch	E3	M92	B/2	Audio option connector (Not used)
B4	M5	W/16	To D3	E1	M45	W/3	A/C switch illumination	D2	M93	W/4	Audio option connector (Not used)
A3	M6	W/10	To D4	E1	M46	BR/4	Thermo control amp.	D3★	M94	W/18	To F27
A3	M7	W/2	Diode	E1	M47	Y/12	To Z1	D4	M95	—	Body ground (For ABS)
B2	M8	BR/2	Tweeter LH	E3	M48	W/10	Audio	A4	M97	BR/4	To D11
C4	M9	W/16	Data link connector for GST	G3	M49	W/6	Audio	G2	M101	BR/6	To D45
B3★	M10	SMJ	Fuse block (J/B)	E4	M50	W/12	Rear wiper switch				
C4	M11	GY/14	Data link connector for CONSULT	E4	M52	L/4	Heated seat switch LH				
B3★	M12	SB/6	Diode	F4	M53	W/4	Heated seat switch RH				
B4★	M13	W/48	A/T control unit	E4	M54	BR/88	ABS control unit				
B4	M14	L/2	ASCD clutch switch	E3	M55	B/6	Air mix door motor				
C3	M15	B/3	Combination flasher unit	F4	M56	B/2	Cigarette lighter socket				
C2	M16	W/36	Smart entrance control unit	F4	M57	W/2	Cigarette lighter illumination				
C3	M17	GY/12	Door mirror remote control switch	E1	M58	B/2	Sunload sensor				
C4	M18	W/6	ASCD main switch	G2	M59	W/4	Intake door motor				
C4	M19	W/3	Illumination control switch	F2	M60	W/4	Fan control amp. (For auto A/C)				
C3	M20	W/4	Security indicator lamp (With theft warning system)	G3	M61	BR/4	Fan resistor				
B2	M21	W/2	Circuit breaker-1	F1	M62	W/6	To R1				
B2	M22	W/2	Circuit breaker-2 (With power seat)	F1	M63	W/6	To R2				
B2	M23	L/4	Power window relay	F1	M64	BR/2	Tweeter RH				
D1★	M24	W/16	Combination meter	F2	M65	W/2	Diode				
D1★	M25	W/14	Combination meter	G2	M66	—	Body ground				
D1	M26	BR/16	Combination meter	F2	M67	W/12	To D33				
C1	M27	W/3	Warning buzzer	F2	M68	W/6	To D34				
C3	M28	L/2	Clutch interlock switch (For M/T model)	F3	M69	W/3	Power antenna motor				
C3	M29	L/2	ASCD brake switch	F3★	M70	W/20	To B50				
C3	M31	B/2	Brake lamp switch	F3★	M71	W/24	To B51				
D3★	M32	W/24	To F23	F3★	M72	W/16	To B52				
D3★	M33	GY/16	To F22	G3	M73	W/2	Blower motor				
D3	M34	W/2	In-vehicle sensor (With auto A/C)	D5	M74	B/6	ABS actuator				
D2	M35	W/8	Hazard switch	D5	M75	GY/8	ABS actuator				
D3	M36	W/6	Rear window defogger switch	C5	M76	W/2	ABS actuator				
D4	M37	GY/6	Joint connector	C5	M77	—	Body ground				
E2	M39	BR/4	A/C mode switch	C5	M78	W/6	Front wiper motor				
F2	M40	B/12	A/C auto amp. } (For auto A/C)	C5	M79	W/8	Front wiper amp.				

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.


Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



- EL
- HA
- BT
- PG
- ST
- BR
- RA
- FA
- PD
- TF
- AT
- MT
- GL
- EC
- LC
- EM
- MA
- CI

# HARNES LAYOUT


## Engine Room Harness



# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.




★ E1	SMJ	: To (MT)	F2	GY/2	: Brake fluid level switch
E2	B/2	: Fuse block (J/B)	E4	B/3	: Headlamp LH
E3	W/16	: Fuse block (J/B)	D5	GY/2	: Front turn signal lamp LH
E4	W/6	: Fuse block (J/B)	D3	GY/2	: Hood switch
E5	W/2	: Key switch	C3	B/2	: Ambient sensor (With auto A/C)
★ E6	W/6	: Ignition switch	C4	B/2	: Ambient air temperature sensor (For thermometer)
E7	BR/4	: Combination switch (Lighting switch)	C4	GY/2	: Ambient air temperature switch
E8	BR/8	: Combination switch (Lighting & turn signal switch)	C3	B/1	: Horn (High)
E9	GY/8	: Combination switch (Front wiper switch)	B3	B/1	: Horn (Low)
E10	B/1	: Not used	B3	B/2	: Dual-pressure switch
★ E11	GY/2	: Intake air temperature sensor	A3	B/3	: Headlamp RH
E4	E12	: Side marker lamp LH	A4	GY/2	: Front turn signal lamp RH
E3	E13	: Body ground	A2	GY/2	: Side marker lamp RH
F4	E14	: Front wheel sensor LH	A2	—	: Body ground
E1	E15	: Multi remote control relay-2	B4	BR/2	: Washer level switch
E1	E16	: Multi remote control relay-1	B4	GY/2	: Rear washer motor
E1	E17	: Front fog lamp relay	B4	GY/2	: Front washer motor
F1	E18	: Theft warning lamp relay	B2	GY/8	: Daytime light control unit
F1	E20	: Theft warning relay	A2	GY/6	: Daytime light control unit
E1	E21	: Power socket relay	B1	★ E47	: Dropping resistor
E1	E22	: ASCD hold relay	B1	E48	: To (E102)
E1	E23	: Theft warning horn relay	C2	E49	: To (E104)
F1	E24	: Park/Neutral position relay	B2	E50	: Theft warning horn
F1	E25	: Horn relay	C3	E51	: Front wheel sensor RH
F1	E26	: A/C relay	D2	E52	: Battery
			C2	E53	: Battery
			B1	E54	: Fuel pump relay
			B1	E55	: Clutch interlock relay (For M/T model)
			B1	★ E56	: Inhibitor relay (For A/T model)
			B1	★ E57	: ECCS relay
			C2	E59	: ASCD pump
			C1	E60	: Fuse and fusible link box
			D5	E61	: Front fog lamp LH
			B4	E62	: Front fog lamp RH
			E63	W/3	: Front fog lamp switch
			F1	E68	: ATP relay (Relay box-1)
			E2	★ E87	: EVAP canister purge volume control valve
			E3	★ E88	: Absolute pressure sensor
			E3	★ E89	: EVAP canister purge control solenoid valve
			E3	★ E90	: MAP/BARO switch solenoid valve

CI  
 MA  
 FM  
 LC  
 FC  
 FU  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# HARNESS LAYOUT

## Engine Control Harness






# HARNES LAYOUT

## Engine Control Harness (Cont'd)

D1*	F1	GY/4	: Rear heated oxygen sensor RH
D1*	F2	GY/3	: Front heated oxygen sensor RH
D1*	F3	GY/4	: Rear heated oxygen sensor LH
D1*	F4	GY/3	: Front heated oxygen sensor LH
C2*	F5	GY/8	: To F100
C3*	F6	B/8	: To F101
C4*	F7	GY/6	: Distributor
E4*	F8	BR/3	: Throttle position sensor
F4*	F9	GY/3	: Throttle position switch
E3*	F10	BR/4	: Mass air flow sensor
C4*	F11	GY/2	: Ignition coil
C4*	F12	GY/2	: EGR temperature sensor
D5	F14	GY/2	: To F200
E4*	F15	B/2	: EGRC-solenoid valve
C3*	F16	GY/2	: Engine coolant temperature sensor
C3	F17	B/1	: Thermal transmitter
E1*	F18	B/2	: Resistor
E1	F19	W/2	: Condenser
E1*	F20	—	: Engine ground
F3	F21	L/12	: Joint connector
F2*	F22	GY/16	: To M33
F2*	F23	W/24	: To M32
F2*	F24	W/88	: ECM (ECCS control module)
E1*	F25	—	: Engine ground
F3	F26	W/2	: Diode
F2*	F27	W/18	: To M84
C2*	F100	GY/8	: To F5
C2*	F101	B/8	: To F6
E2*	F102	B/2	: Knock sensor
C3*	F103	B/2	: Injector No. 1
C4*	F104	B/2	: Injector No. 2
C3*	F105	B/2	: Injector No. 3
F4*	F106	B/2	: Injector No. 4
E2*	F107	B/2	: Injector No. 5
F3*	F108	B/2	: Injector No. 6
F2*	F109	BR/2	: IACV-AAC valve
F3*	F110	GY/2	: Crankshaft position sensor (OBD)
F3	F111	GY/2	: IACV-FICD solenoid valve
D5	F200	GY/2	: To F14
E4	F201	B/1	: Oil pressure switch
D4	F202	B/1	: Compressor (Air conditioner)

Diode (F26)




★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.**

GI  
 MA  
 EM  
 EC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
**EL**  
 IDX

# HARNESS LAYOUT

## Body Harness LH




- ★ B1 : SMJ : To M2
- B3 : Parking brake switch
- B4 : To B40
- B5 : Heated seat LH
- B6 : Seat belt buckle switch
- B7 : Power seat harness
- B8 : Rear wheel sensor LH
- B9 : Front door switch LH
- B10 : To D50
- B11 : Body ground
- B12 : Fuel tank gauge unit
- B13 : Fuel pump
- B14 : Rear wiper amp.
- B15 : Rear wiper relay
- B16 : Rear window defogger relay
- B18 : Rear door switch LH
- B20 : Speaker amp. (With 6-speaker audio system)
- B21 : Speaker amp. (With 6-speaker audio system)
- B22 : Body ground
- B23 : To D100
- B24 : To D101
- B25 : To D102
- B26 : Rear combination lamp LH
- B27 : Diode
- B40 : To B4
- B41 : Power socket
- B42 : Door mirror defogger relay
- B43 : To B101
- B44 : Smart entrance control unit
- B45 : Antenna (For smart entrance control unit)
- B46 : Speaker amp. (For BOSE system)
- B47 : Audio amp. relay
- ★ B101 : To B43
- B102 : EVAP control system pressure sensor
- ★ B103 : EVAP canister vent control valve
- ★ B104 : Vacuum cut valve bypass valve

- Diode (B27)
- Rear wiper relay
- Glass hatch switch

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

# HARNES LAYOUT

## Body Harness RH




- ★ B50 : W/20 : To M70
- ★ B51 : W/24 : To M71
- ★ B52 : W/16 : To M72
- ★ B55 : — : Body ground
- B56 : GY/3 : Heated seat RH
- B57 : W/2 : To power seat harness RH
- B58 : GY/2 : G sensor (For 4WD model with ABS)
- B59 : W/6 : A/T device
- B60 : W/2 : Ashtray (M/T model)
- ★ B61 : B/6 : To B200 (M/T model)
- B62 : B/4 : To B201 (4WD A/T model)
- B63 : GY/2 : Vehicle speed sensor
- ★ B64 : BR/8 : Terminal cord assembly
- ★ B65 : GY/8 : Inhibitor switch
- ★ B66 : GY/2 : Inhibitor switch
- ★ B67 : GY/3 : Revolution sensor
- B68 : BR/1 : Front door switch RH
- B69 : GY/2 : Rear wheel sensor RH
- B70 : W/10 : To D70
- B71 : BR/1 : Rear door switch RH
- B72 : GY/2 : To B300
- B74 : W/6 : Rear combination lamp RH
- ★ B75 : — : Body ground
- B76 : W/3 : Ashtray (A/T model)
- B77 : GY/2 : G sensor (For 4WD model with ABS)
- B80 : GY/2 : To B72
- B81 : B/3 : Tire carrier switch

★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
 HA  
 EL  
 IDX

# HARNESS LAYOUT

## Back Door Harness




- (D300) W/2 : To (D107)
- (D301) W/1 : To (D108)
- (D302) W/3 : High-mounted stop lamp
- (D303) B/1 : Rear window defogger
- (D304) B/1 : Rear window defogger
- (D305) — : Body ground

- (D201) W/6 : Back door key cylinder switch
- (D202) B/2 : License plate lamp LH (Without spare tire carrier)
- (D203) BR/2 : License plate lamp (With spare tire carrier)
- (D204) W/8 : To (D104)
- (D205) W/12 : To (D105)
- (D206) W/4 : To (D106)
- (D207) W/4 : Back door lock actuator
- (D208) W/2 : Back door switch
- (D209) W/2 : Glass hatch switch
- (D210) — : Body ground
- (D211) B/2 : License plate lamp RH (Without spare tire carrier)
- (D212) W/8 : Rear wiper motor

- (D100) W/12 : To (B23)
- (D101) W/6 : To (B24)
- (D102) W/4 : To (B25)
- (D103) W/3 : Luggage room lamp
- (D104) W/8 : To (D204)
- (D105) W/12 : To (D205)
- (D106) W/4 : To (D206)
- (D107) W/2 : To (D300)
- (D108) W/1 : To (D301)

# HARNESS LAYOUT

## Engine and Transmission Harness



- ★ (B200) : To (B61) (M/T model)
- (B201) : To (B62) (A/T model)
- (B202) : Back-up lamp switch (M/T model)
- ★ (B203) : Neutral position switch (M/T model)
- (B204) : Neutral position switch (4WD model)
- (B205) : Transfer switch (4WD model)


- (E100) : Battery
- (E101) : Body ground
- (E102) : To (E48)
- (E103) : Fuse and fusible link box
- (E104) : To (E49)
- (E105) : Alternator
- (E106) : Alternator
- (E107) : Alternator
- (E108) : Starter motor
- (E109) : Starter motor
- (E110) : Power steering oil pressure switch

★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
 Do not disconnect these connectors except in the case of working  
 according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 FA  
 RA  
 BR  
 ST  
 DS  
 BT  
 HA  
 EL  
 IDX


# HARNES LAYOUT

## Room Lamp



# HARNES LAYOUT

## Air Bag Harness



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

**EL**


IX

# HARNESS LAYOUT

## FRONT


## Door Harness (LH side)

- (D1) GY/5 : Door mirror defogger LH
- (D2) BR/3 : Door mirror LH
- (D3) W/16 : To (M5)
- (D4) W/10 : To (M6)
- (D5) B/2 : Front power window regulator LH
- (D6) W/16 : Front power window switch LH
- (D7) GY/4 : Front door lock actuator LH
- (D9) BR/3 : Front door key cylinder switch LH
- (D10) BR/2 : Front door speaker LH  
(Except for BOSE system)
- (D11) BR/4 : To (M97)
- (D12) W/6 : Front door speaker LH  
(For BOSE system)



MEL833G

## REAR



- (D50) W/10 : To (B10)
- (D51) B/2 : Rear power window regulator LH
- (D52) W/8 : Rear power window switch LH
- (D53) BR/2 : Rear door speaker LH
- (D54) GY/4 : Rear door lock actuator LH


MEL870F



# HARNESS LAYOUT

FRONT


## Door Harness (RH side)



- (D31) GY/5 : Door mirror defogger RH
- (D32) BR/3 : Door mirror RH
- (D33) W/12 : To (M67)
- (D34) W/6 : To (M68)
- (D35) B/2 : Power window regulator RH
- (D36) W/8 : Front power window switch RH
- (D37) GY/4 : Front door lock actuator RH
- (D38) W/3 : Door lock switch RH
- (D39) BR/3 : Front door key cylinder switch RH
- (D40) BR/2 : Front door speaker RH  
(Except for BOSE system)
- (D42) W/6 : Front door speaker RH  
(For BOSE system)
- (D45) BR/6 : To (M101)

MEL834G

REAR



- (D70) W/10 : To (B70)
- (D71) B/2 : Rear power window regulator RH
- (D72) W/8 : Rear power window switch RH
- (D73) BR/2 : Rear door speaker RH
- (D74) GY/4 : Rear door lock actuator RH

MEL873F

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX