

SECTION **EM**



CONTENTS

PRECAUTIONS	2	OIL SEAL REPLACEMENT	18	GL
Parts Requiring Angular Tightening	2	CYLINDER HEAD	20	
Liquid Gasket Application Procedure	2	Removal	21	WT
PREPARATION	3	Disassembly	23	
Special Service Tools	3	Inspection	24	
Commercial Service Tools	5	Assembly	29	AT
OUTER COMPONENT PARTS	6	Installation	30	
COMPRESSION PRESSURE	8	ENGINE REMOVAL	34	
Measurement of Compression Pressure	8	Removal	36	TF
OIL PAN	9	CYLINDER BLOCK	37	
Removal	9	Disassembly	38	PD
Installation	10	Inspection	38	
TIMING BELT	12	Assembly	45	
Removal	13	SERVICE DATA AND SPECIFICATIONS (SDS)	48	FA
Inspection	14	General Specifications	48	
Installation	15	Inspection and Adjustment	48	

PRECAUTIONS

Parts Requiring Angular Tightening

- Use an angle wrench for the final tightening of the following engine parts:
 - (1) Cylinder head bolts
 - (2) Main bearing cap bolts
 - (3) Connecting rod cap nuts
 - (4) Crankshaft pulley bolt
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.










Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also completely clean any oil stains from these portions.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) dia. (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) dia. (in areas except oil pan).
- Apply liquid gasket to inner surface around hole perimeter area (unless otherwise specified).
- Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST0501S000 (—) Engine stand assembly ① ST05011000 (—) Engine stand ② ST05012000 (—) Base		Disassembling and assembling NT042
KV10106500 (—) Engine stand shaft		NT028
KV10110001 (—) Engine sub-attachment		NT032
ST10120000 (J24239-01) Cylinder head bolt wrench		Loosening and tightening cylinder head bolt a: 13 (0.51) dia. b: 12 (0.47) c: 10 (0.39) Unit: mm (in) NT583
KV10112100 (BT8653-A) Angle wrench		Tightening bearing cap, cylinder head bolts, etc. NT014
KV10110600 (J33986) Valve spring compressor		Disassembling and assembling valve compo- nents NT033
KV10107501 (—) Valve oil seal drift		Installing valve oil seal NT025

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT







HA

EL

DX


PREPARATION

Special Service Tools (Cont'd)






Tool number (Kent-Moore No.) Tool name	Description
KV10110300 (—) Piston pin press stand assembly ① KV10110310 (—) Cap ② KV10110330 (—) Spacer ③ ST13030020 (—) Press stand ④ ST13030030 (—) Spring ⑤ KV10110340 (—) Drift ⑥ KV10110320 (—) Center shaft	 <p style="text-align: right;">Disassembling and assembling piston with connecting rod</p> <p style="text-align: left;">NT036</p>
EM03470000 (J8037) Piston ring compressor	 <p style="text-align: right;">Installing piston assembly into cylinder bore</p> <p style="text-align: left;">NT044</p>
ST16610001 (J23907) Pilot bushing puller	 <p style="text-align: right;">Removing crankshaft pilot bushing</p> <p style="text-align: left;">NT045</p>
KV10111100 (J37228) Seal cutter	 <p style="text-align: right;">Removing oil pan</p> <p style="text-align: left;">NT046</p>
WS39930000 (—) Tube presser	 <p style="text-align: right;">Pressing the tube of liquid gasket</p> <p style="text-align: left;">NT052</p>
KV10117100 (J3647-A) Heated oxygen sensor wrench	 <p style="text-align: right;">Loosening or tightening heated oxygen sensor</p> <p style="text-align: left;">NT379</p> <p style="text-align: right;">For 22 mm (0.87 in) hexagon nut</p>

PREPARATION

Special Service Tools (Cont'd)


Tool number (Kent-Moore No.) Tool name	Description	
KV10114400 (J38365) Heated oxygen sensor wrench		Loosening or tightening rear heated oxygen sensor (For right bank)
	NT636	a: 22 mm (0.87 in)

Commercial Service Tools

Tool name	Description													
Spark plug wrench		Removing and installing spark plug												
	NT047													
Pulley holder		Holding camshaft pulley while tightening or loosening camshaft bolt												
	NT035													
Valve seat cutter set		Finishing valve seat dimensions												
	NT048													
Piston ring expander		Removing and installing piston ring												
	NT030													
Valve guide drift		Removing and installing valve guide												
	NT015	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Diameter</th> <th colspan="2" style="text-align: center;">mm (in)</th> </tr> <tr> <td></td> <th style="width: 35%;">Intake</th> <th style="width: 35%;">Exhaust</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">a</td> <td colspan="2" style="text-align: center;">10.5 (0.413)</td> </tr> <tr> <td style="text-align: center;">b</td> <td colspan="2" style="text-align: center;">6.6 (0.260)</td> </tr> </tbody> </table>	Diameter	mm (in)			Intake	Exhaust	a	10.5 (0.413)		b	6.6 (0.260)	
Diameter	mm (in)													
	Intake	Exhaust												
a	10.5 (0.413)													
b	6.6 (0.260)													
Valve guide reamer		Reaming valve guide ① or hole for over-size valve guide ②												
	NT016	<p>Intake:</p> <p>$d_1 = 7.0 \text{ mm (0.276 in) dia.}$</p> <p>$d_2 = 11.2 \text{ mm (0.441 in) dia.}$</p> <p>Exhaust:</p> <p>$d_1 = 8.0 \text{ mm (0.315 in) dia.}$</p> <p>$d_2 = 12.2 \text{ mm (0.480 in) dia.}$</p>												

OUTER COMPONENT PARTS

SEC. 140-208



⊗ : N·m (kg-m, in-lb)

⊙ : N·m (kg-m, ft-lb)

★ : ⊗ 24.5 - 29.4 (2.5 - 3.0, 18.1 - 21.7)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IX

Measurement of Compression Pressure

1. Warm up engine.
2. Turn ignition switch off.
3. Release fuel pressure.
Refer to "Releasing Fuel Pressure" in EC section.
4. Remove all spark plugs.
5. Disconnect distributor center cable.
6. Attach a compression tester to No. 1 cylinder.
7. Depress accelerator pedal fully to keep throttle valve wide open.
8. Crank engine and record highest gauge indication.
9. Repeat the measurement on each cylinder as shown above.
 - **Always use a fully-charged battery to obtain specified engine speed.**
Compression pressure: kPa (kg/cm², psi)/300 rpm
Standard
1,196 (12.2, 173)
Minimum
883 (9.0, 128)
Difference limit between cylinders
98 (1.0, 14)
10. If cylinder compression in one or more cylinders is low, pour a small amount of engine oil into cylinders through spark plug holes and retest compression.
 - **If adding oil improves cylinder compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
 - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to SDS.) If valve or valve seat is damaged excessively, replace them.**
 - **If compression in any two adjacent cylinders is low and if adding oil does not improve compression, there is leakage past the gasket surface. If so, replace cylinder head gasket.**



OIL PAN

Removal

Removal order and points		Applied model	
		2WD	4WD
1	Remove undercover.	○	○
2	Drain engine oil.	○	○
3	Remove stabilizer bracket bolts (RH & LH).	○	○
4	Remove front propeller shaft from front differential carrier.	—	○
5	Remove front drive shaft fixing bolts (RH & LH).	—	○
6	Remove front differential carrier bleeder hose.	—	○
7	Remove front suspension crossmember.	○	○
8	Remove differential front mounting bolts (RH & LH) and rear mounting bolts.	—	○
9	Remove front differential carrier.	—	○


Removal order and points		Applied model	
		2WD	4WD
10	Remove front differential carrier mounting bracket.	—	○
11	Remove starter motor.	○	○
12	Remove transmission to rear engine mounting bracket nuts (RH & LH).	○	○
13	Remove engine mounting bolts or nuts (RH & LH).	○	○
14	Remove power steering mounting brackets (RH & LH).	○	○
15	Lift up engine. If necessary, disconnect exhaust tube.	○	○
16	Remove oil pan.	○	○

WARNING:

- Place vehicle on a flat and solid surface.
- Place chocks at front and rear of rear wheels.
- You should not remove oil pan until exhaust system and cooling system have completely cooled off. Otherwise, you may burn yourself and/or fire may break out in the fuel line.
- When remove front and/or rear engine mounting bolts or nuts, lift up slightly engine for safety work.

CAUTION:


- In lifting engine, be careful not to hit against adjacent parts, especially against accelerator wire casing end, brake tube and brake master cylinder.
- For tightening torque, refer to AT, MT and PD sections.



- Remove oil pan bolts.

OIL PAN


Removal (Cont'd)




2. Remove oil pan.

(1) Insert Tool between cylinder block and oil pan.

- Do not drive seal cutter into oil pump or rear oil seal retainer portion, or aluminum mating face will be damaged.
- Do not insert screwdriver, or oil pan flange will be deformed.




(2) Slide Tool by tapping its side with a hammer, and remove oil pan.




Installation

1. Before installing oil pan, remove all traces of liquid gasket from mating surface using a scraper.

- Also remove traces of liquid gasket from mating surface of cylinder block.



2. Apply sealant to oil pump gasket and rear oil seal retainer gasket.





3. Apply a continuous bead of liquid gasket to mating surface of oil pan.

- Use Genuine Liquid Gasket or equivalent.

OIL PAN

Installation (Cont'd)



- Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide.
- 4. Apply liquid gasket to inner sealing surface as shown in figure.
- **Attaching should be done within 5 minutes after coating.**
- 5. Install oil pan.
- **Install bolts/nuts in their reverse order of removal.**
- **Wait at least 30 minutes before refilling engine oil.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

TIMING BELT

CAUTION:

- Do not bend or twist timing belt.
- After removing timing belt, do not turn crankshaft and camshaft separately because valves will strike piston heads.
- Make sure that timing belt, camshaft sprocket, crankshaft sprocket and belt tensioner are clean and free from oil and water.
- Installation should be carried out when engine is cold.

SEC. 120•130•135






- : N·m (kg-m, in-lb)
- : N·m (kg-m, ft-lb)
- : Lubricate with new engine oil

SEM311FA

TIMING BELT

Removal

1. Remove engine under cover.
 2. Drain engine coolant from radiator.
- Be careful not to spill coolant on drive belts.**
3. Remove radiator. (Refer to LC section.)
 4. Remove engine cooling fan and water pump pulley.
 5. Remove the following belts.
 - Power steering pump drive belt
 - Compressor drive belt
 - Alternator drive belt
 6. Remove all spark plugs.
 7. Remove distributor protector.
 8. Remove compressor drive belt idler bracket.
 9. Remove fresh-air intake tube for rocker cover.
 10. Remove water hose for thermostat housing.
 11. Remove crankshaft pulley bolt.
 12. Remove crankshaft pulley with a suitable puller.
 13. Remove front upper and lower belt covers.
 14. Set No. 1 piston at TDC on its compression stroke by rotating crankshaft.



15. Loosen timing belt tensioner nut, turn tensioner, then remove timing belt.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA





EL

DX

TIMING BELT

Inspection

Visually check the condition of timing belt.
Replace if any abnormality is found.


Item to check	Problem	Cause
Tooth is broken/tooth root is cracked.	 <p style="text-align: right;">SEM394A</p>	<ul style="list-style-type: none"> ● Camshaft jamming ● Distributor jamming ● Damaged camshaft/crankshaft oil seal
Back surface is cracked/worn.	 <p style="text-align: right;">SEM395A</p>	<ul style="list-style-type: none"> ● Tensioner jamming ● Overheated engine ● Interference with belt cover
Side surface is worn.	 <p style="text-align: right;">SEM396A</p> <ul style="list-style-type: none"> ● Belt corners are worn and round. ● Wicks are frayed and coming out. 	<ul style="list-style-type: none"> ● Improper installation of belt ● Malfunctioning crankshaft pulley plate/timing belt plate
Teeth are worn.	 <p style="text-align: center;">Rotating direction</p> <p style="text-align: right;">SEM397A</p> <ul style="list-style-type: none"> ● Canvas on tooth face is worn down. ● Canvas on tooth is fluffy, rubber layer is worn down and faded white, or weft is worn down and invisible. 	<ul style="list-style-type: none"> ● Poor belt cover sealing ● Coolant leakage at water pump ● Camshaft not functioning properly ● Distributor not functioning properly ● Excessive belt tension
Oil/Coolant or water is stuck to belt.	—	<ul style="list-style-type: none"> ● Poor oil sealing of each oil seal ● Coolant leakage at water pump ● Poor belt cover sealing

TIMING BELT

Inspection (Cont'd)

BELT TENSIONER AND TENSIONER SPRING


1. Check belt tensioner for smooth turning.
2. Check condition of tensioner spring.



SEM558

Installation


1. Confirm that No. 1 piston is set at TDC on its compression stroke.



SEM510EA


2. Install tensioner and tensioner spring.

If stud is once removed, apply locking sealant to threads of stud on cylinder block side before installing.



SEM243A

3. Turn tensioner fully outward with hexagon wrench, and temporarily tighten lock nut.



SEM829A


4. Set timing belt when engine is cold.

(1) Align white lines on timing belt with punchmarks on camshaft sprockets and crankshaft sprocket.

(2) Point arrow on timing belt toward front belt cover.

Number of teeth (reference):

Number of timing belt teeth		133
Number of teeth between timing marks	Between LH and RH camshaft sprockets	40
	Between LH camshaft sprocket and crankshaft timing sprocket	43



SEM511EA

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


FA

EL


IDX

TIMING BELT


Installation (Cont'd)




5. Loosen tensioner lock nut, keeping tensioner steady with hexagon wrench.
6. Turn tensioner 70 to 80 degrees clockwise with hexagon wrench, and temporarily tighten lock nut.
7. Turn crankshaft clockwise at least 2 times, then slowly set No. 1 piston at TDC on its compression stroke.



8. Push middle of timing belt between RH camshaft sprocket and tensioner pulley with force of 98 N (10 kg, 22 lb).
9. Loosen tensioner lock nut, keeping tensioner steady with hexagon wrench.










10. Set feeler gauge as shown in figure which is 0.35 mm (0.0138 in) thick and 12.7 mm (0.500 in) wide.




11. Turn crankshaft clockwise until feeler gauge is positioned as shown in figure.
 - Timing belt will move about 2.5 teeth.
12. Tighten tensioner lock nut, keeping tensioner steady with hexagon wrench.
13. Turn crankshaft clockwise or counterclockwise, and remove feeler gauge.
14. Turn crankshaft clockwise at least 2 times, then slowly set No. 1 piston at TDC on its compression stroke.
15. Install lower and upper belt covers.

TIMING BELT Installation (Cont'd)



No.	Tightened parts	No.	Tightened parts		
①	 Bolt Rubber washer Front upper belt cover Welded nut	8 pcs.	④	 Bolt Rubber washer Front lower belt cover	1 pc.
②	 Hexagon bolt with washer Rear belt cover	4 pcs.	⑤	 Bolt Rubber washer Front lower belt cover	1 pc.
③	 Bolt Rubber washer Front lower belt cover	4 pcs.	⑥	 Bolt Front lower belt cover Lock spring washer	1 pc.

SEM313F




BELT TENSION CHECK

1. Set No. 1 piston at TDC on its compression stroke.
2. Measure deflection of timing belt midway between camshaft pulleys while pushing with 98 N (10 kg, 22 lb) force.



**Belt deflection when engine is cold (Reference value):
13 - 15 mm (0.51 - 0.59 in)/98 N (10 kg, 22 lb)**

OIL SEAL REPLACEMENT




VALVE OIL SEAL

1. Remove rocker cover.
2. Remove rocker shaft assembly and valve lifters with valve lifter guide.
3. Remove valve springs and valve oil seal.
 - Piston concerned should be set at TDC to prevent valve from falling.
 - When removing intake side valve oil seal, use Tool or suitable tool.
 - When removing exhaust side valve oil seal, pull it out with suitable tool.
4. Apply engine oil to new valve oil seal and install it.
 - Before installing valve oil seal, install inner valve spring seat.
 - When installing intake side valve oil seal, use Tool.
 - When installing exhaust side valve oil seal, set it by hand.




OIL SEAL INSTALLING DIRECTION




CAMSHAFT OIL SEAL

1. Remove timing belt.
 2. Remove camshaft sprocket.
 3. Remove camshaft.
 4. Remove camshaft oil seal.
- Be careful not to scratch camshaft.**
5. Apply engine oil to new camshaft oil seal.



OIL SEAL REPLACEMENT



FRONT OIL SEAL


1. Remove timing belt and crankshaft sprocket.
2. Remove oil pump assembly.
3. Remove front oil seal from oil pump body.
4. Apply engine oil to new oil seal and install it using suitable tool.

GI

MA

EM

LC



REAR OIL SEAL

1. Remove flywheel or drive plate.
2. Remove rear oil seal retainer.
3. Remove rear oil seal from retainer.
4. Apply engine oil to new oil seal and install it using suitable tool.
5. Install rear oil seal retainer with a new gasket to cylinder block.

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

CYLINDER HEAD

SEC. 102•111•130



: N·m (kg-m, in-lb)

: N·m (kg-m, ft-lb)

: Lubricate with new engine oil

CYLINDER HEAD

CAUTION:

- When installing sliding parts such as rocker arms, camshaft and oil seal, be sure to apply new engine oil on their sliding surfaces.
- When tightening cylinder head bolts and rocker shaft bolts, apply new engine oil to thread portions and seat surfaces of bolts.

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX



99



- If hydraulic valve lifter is kept on its side, there is a risk of air entering it. After removal, always set hydraulic valve lifter straight up, or when laying it on its side, have it soak in new engine oil.
- Do not disassemble hydraulic valve lifter.
- Attach tags to valve lifters so as not to mix them up.


Removal

1. Release fuel pressure.
Refer to "Releasing Fuel Pressure" in EC section.
2. Remove timing belt.
Refer to "TIMING BELT — Removal" (EM-13).
3. Drain coolant by removing drain plugs from both sides of cylinder block.




CYLINDER HEAD


Removal (Cont'd)




4. Separate ASCD and accelerator control wire from intake manifold collector.
5. Remove intake manifold collector from engine. The following parts should be disconnected to remove intake manifold collector.
 - a. Harness connectors for: IACV-AAC valve, Throttle position sensor, Throttle position switch, Ignition coil, Power transistor, EGRC-solenoid valve, and EGR temperature sensor.
 - b. Water hoses from collector
 - c. Heater hoses
 - d. PCV hose from RH rocker cover
 - e. Vacuum hoses for: EVAP canister, Master brake cylinder and Pressure regulator.
 - f. Purge hose from EVAP canister
 - g. EGR tube
 - h. Earth harnesses
 - i. Air duct hose



6. Remove fuel feed and fuel return hoses from injector fuel tube assembly.
7. Disconnect all injector harness connectors.
8. Remove injector fuel tube assembly.



9. Remove intake manifold from engine. The following parts should be disconnected to remove intake manifold.
 - a. Engine coolant temperature switch harness connector
 - b. Thermal transmitter harness connector
 - c. Water hose from thermostat housing




10. Remove both camshaft sprockets.
11. Remove rear timing belt cover.
12. Remove distributor and ignition wires.

After pulling out distributor from cylinder head, do not rotate distributor rotor.


13. Remove harness clamp from RH rocker cover.
14. Remove front exhaust tube from exhaust manifold.

CYLINDER HEAD


Removal (Cont'd)



15. Remove compressor and power steering pump.
16. Remove alternator.
17. Remove compressor and alternator bracket.




18. Remove both rocker covers.




19. Remove cylinder head with exhaust manifold.

- **A warped or cracked cylinder head could result from removing in incorrect order.**
- **Cylinder head bolts should be loosened in two or three steps.**



Disassembly

1. Remove exhaust manifolds from cylinder head.



2. Remove rocker shafts with rocker arms.
3. Remove hydraulic valve lifters and lifter guide.
 - **Hold hydraulic valve lifters with wire so that they will not drop from lifter guide.**
4. Remove oil seal and camshaft.
 - **Before removing camshaft, measure camshaft end play.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

EA

RA

BR

ST

RS

BT

HA



EL

IDX

CYLINDER HEAD

Disassembly (Cont'd)

5. Remove valve components with Tool.
6. Remove valve oil seals with Tool or suitable tool.



Inspection

CYLINDER HEAD DISTORTION

Head surface flatness:

Less than 0.1 mm (0.004 in)

If beyond the specified limit, resurface it or replace it.

Resurfacing limit:

The resurfacing limit of cylinder head is determined by the cylinder block resurfacing in an engine.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$


After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

Nominal cylinder head height:

106.8 - 107.2 mm (4.205 - 4.220 in)

CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.




CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):

Limit 0.1 mm (0.004 in)

2. If it exceeds the limit, replace camshaft.



CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

Standard cam height:

Intake: 39.242 - 39.432 mm (1.5450 - 1.5524 in)

Exhaust: 38.943 - 39.133 mm (1.5332 - 1.5407 in)

Cam wear limit:






0.15 mm (0.0059 in)

2. If wear is beyond the limit, replace camshaft.

CYLINDER HEAD

Inspection (Cont'd)

CAMSHAFT JOURNAL CLEARANCE



1. Measure inner diameter of camshaft bearing.

Standard inner diameter:

- A 47.000 - 47.025 mm (1.8504 - 1.8514 in)
- B 42.500 - 42.525 mm (1.6732 - 1.6742 in)
- C 48.000 - 48.025 mm (1.8898 - 1.8907 in)

2. Measure outer diameter of camshaft journal.

Standard outer diameter:

- A 46.920 - 46.940 mm (1.8472 - 1.8480 in)
- B 42.420 - 42.440 mm (1.6701 - 1.6709 in)
- C 47.920 - 47.940 mm (1.8866 - 1.8874 in)

3. If clearance exceeds the limit, replace camshaft and/or cylinder head.

Camshaft journal clearance limit:

0.15 mm (0.0059 in)

CAMSHAFT END PLAY

1. Install camshaft and locate plate in cylinder head.
2. Measure camshaft end play.

Camshaft end play:

Standard 0.03 - 0.06 mm (0.0012 - 0.0024 in)

3. If it is out of the specified range, select thickness of camshaft locate plate to obtain standard specified end play.

Example:

When camshaft end play is 0.08 mm (0.0031 in) with camshaft locate plate ②, replace camshaft locate plate ② with camshaft locate plate ③ to set the end play at 0.05 mm (0.0020 in).

GI

MA

EM

LC

EC

PE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

CYLINDER HEAD

Inspection (Cont'd)



CAMSHAFT SPROCKET RUNOUT

1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.
Runout (Total indicator reading):
Limit 0.1 mm (0.004 in)
3. If it exceeds the limit, replace camshaft sprocket.




VALVE GUIDE CLEARANCE

1. Measure valve deflection in a right-angled direction with camshaft. (Valve and valve guide mostly wear in this direction.)
Valve deflection limit (Dial gauge reading):
0.20 mm (0.0079 in)
2. If it exceeds the limit, check valve to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.
Valve to valve guide clearance:
Intake
0.020 - 0.053 mm (0.0008 - 0.0021 in)
Exhaust
0.040 - 0.049 mm (0.0016 - 0.0019 in)
Limit
0.10 mm (0.0039 in)
 - c. If it exceeds the limit, replace valve or valve guide.








VALVE GUIDE REPLACEMENT

1. To remove valve guide, heat cylinder head to 150 to 160°C (302 to 320°F) by soaking in heated oil.



CYLINDER HEAD

Inspection (Cont'd)



2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.

3. Ream cylinder head valve guide hole.

**Valve guide hole diameter
(for service parts):**

Intake

11.175 - 11.196 mm (0.4400 - 0.4408 in)

Exhaust

12.175 - 12.196 mm (0.4793 - 0.4802 in)

4. Heat cylinder head to 150 to 160°C (302 to 320°F) and press service valve guide onto cylinder head.

Projection "L":

13.2 - 13.4 mm (0.520 - 0.528 in)

5. Ream valve guide.

Finished size:

Intake

7.000 - 7.018 mm (0.2756 - 0.2763 in)

Exhaust

8.000 - 8.011 mm (0.3150 - 0.3154 in)

VALVE SEATS

Check valve seats for any evidence of pitting at valve contact surface, and reseat or replace if it has worn out excessively.

- Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.
- Use both hands to cut uniformly.

REPLACING VALVE SEAT FOR SERVICE PARTS

1. Bore out old seat until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the seat recess in cylinder head.
2. Ream cylinder head recess.

Reaming bore for service valve seat

Oversize [0.5 mm (0.020 in)]:

Intake

44.500 - 44.516 mm (1.7520 - 1.7526 in)

Exhaust


37.500 - 37.516 mm (1.4764 - 1.4770 in)

CYLINDER HEAD

Inspection (Cont'd)


Reaming should be done in circles concentric to the valve guide center so that valve seat will have the correct fit.

- Heat cylinder head to 150 to 160°C (302 to 320°F) by soaking in heated oil.
- Press fit valve seat until it seats on the bottom.



- Cut or grind valve seat using suitable tool at the specified dimensions as shown in SDS (EM-49).
- After cutting, lap valve seat with abrasive compound.
- Check valve seating condition.


		Intake	Exhaust
Seat face angle "α"	degree	45	45
Contacting width "W"	mm (in)	1.75 (0.0689)	1.7 (0.067)



VALVE DIMENSIONS

Check dimensions in each valve. For dimensions, refer to SDS. When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.



VALVE SPRING

Squareness

- Measure "S" dimension.

Out-of-square:


Outer

Less than 2.2 mm (0.087 in)

Inner

Less than 1.9 mm (0.075 in)

- If it exceeds the limit, replace spring.



Pressure

Check valve spring pressure.

Standard pressure: N (kg, lb) at height mm (in)

Outer: 523.7 (53.4, 117.7) at 30.0 (1.181)

Inner: 255.0 (26.0, 57.3) at 25.0 (0.984)

Limit pressure: N (kg, lb) at height mm (in)

Outer: More than 228.5 (23.3, 51.4) at 25.0 (0.984)

Inner: More than 225.6 (23.0, 50.7) at 25.0 (0.984)

If it exceeds the limit, replace spring.

EM-28

CYLINDER HEAD


Inspection (Cont'd)

ROCKER SHAFT AND ROCKER ARM

1. Check rocker shafts for scratches, seizure and wear.
2. Check outer diameter of rocker shaft.

Diameter:

17.979 - 18.000 mm (0.7078 - 0.7087 in)



3. Check inner diameter of rocker arm.


Diameter:

18.007 - 18.028 mm (0.7089 - 0.7098 in)

Rocker arm to shaft clearance:

0.007 - 0.049 mm (0.0003 - 0.0019 in)

- Keep rocker arm with hydraulic valve lifter standing to prevent air from entering hydraulic valve lifter when checking.




HYDRAULIC VALVE LIFTER

1. Check contact and sliding surfaces for wear or scratches.
2. Check diameter of valve lifter.

Outer diameter:

15.947 - 15.957 mm (0.6278 - 0.6282 in)




3. Check valve lifter guide inner diameter.

Inner diameter:

16.000 - 16.013 mm (0.6299 - 0.6304 in)


Standard clearance between valve lifter and lifter guide:

0.043 - 0.066 mm (0.0017 - 0.0026 in)



Assembly

1. Install valve component parts.
 - Always use new valve oil seal. Refer to OIL SEAL REPLACEMENT (EM-18).
 - Before installing valve oil seal, install inner valve spring seat.
 - Install outer valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side.
 - After installing valve component parts, use plastic hammer to lightly tap valve stem tip to assure a proper fit.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


EA

EL


DX

CYLINDER HEAD


Assembly (Cont'd)



2. Install camshafts, locate plates and cylinder head rear covers.
 - **Set knock pin of camshaft at the top.**




3. Install valve lifters into valve lifter guide.
 - **Assemble valve lifters to their original position and hold all valve lifters with wire to prevent lifters from falling off.**
 - **After installing, remove the wire.**




4. Install rocker shafts with rocker arms.
 - **Tighten bolts gradually in two or three stages.**
 - **Before tightening, be sure to set camshaft the lobe at the position where lobe is not lifted.**
 - a. Set No. 1 piston at TDC on its compression stroke and tighten rocker shaft bolts for No. 2, No. 4 and No. 6 cylinders.
 - b. Set No. 4 piston at TDC on its compression stroke and tighten rocker shaft bolts for No. 1, No. 3 and No. 5 cylinders.
5. Install exhaust manifold to cylinder head in reverse order of removal.

Installation





1. Set No. 1 piston at TDC on its compression stroke as follows:
 - a. Align crankshaft sprocket aligning mark with mark on oil pump body.
 - b. Confirm that knock pin on camshaft is set at the top.




2. Install both drain plugs.
 - **Apply sealant to drain plug threads.**

CYLINDER HEAD

Installation (Cont'd)




3. Install exhaust manifolds to cylinder head.



4. Install cylinder head with new gasket.

- Be sure to install washers between bolts and cylinder head.
- Do not rotate crankshaft and camshaft separately, or valves will hit piston heads.



5. Tighten cylinder head bolts in numerical order using angle wrench [ST10120000 (J24239-01)].

Apply engine oil to threads and seating surfaces of cylinder head bolts before installing them.


- Tightening procedure:
 - (1) Tighten all bolts to 29 N·m (3.0 kg·m, 22 ft·lb).
 - (2) Tighten all bolts to 59 N·m (6.0 kg·m, 43 ft·lb).
 - (3) Loosen all bolts completely.
 - (4) Tighten all bolts to 29 N·m (3.0 kg·m, 22 ft·lb).
 - (5) Turn all bolts 60 to 65 degrees clockwise.

If an angle wrench is not available, tighten all bolts to 54 to 64 N·m (5.5 to 6.5 kg·m, 40 to 47 ft·lb).
- Bolts for ④, ⑦, ⑨ and ⑫ are longer than the others.
 - L_1 : 127 mm (5.00 in) for ④, ⑦, ⑨ and ⑫
 - L_2 : 106 mm (4.17 in) for others


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CYLINDER HEAD


Installation (Cont'd)



6. Install both rocker covers.



7. Install compressor and alternator bracket.
8. Install alternator.
9. Install compressor and power steering pump.
10. Install exhaust front tube to exhaust manifold.




11. Install rear belt cover and camshaft sprocket.

- **RH camshaft sprocket and LH camshaft sprocket are different parts. Be sure to install them in the correct location.**


	Identification mark	θ
RH camshaft sprocket	R3	$0^{\circ}53'$
LH camshaft sprocket	L3	$-3^{\circ}27'$

12. Install timing belt and adjust belt tension.
Refer to "TIMING BELT — Installation" (EM-15).



13. Install distributor.




- (1) Align mark on shaft with protruding mark on housing.



- (2) After installing, confirm that distributor rotor head is set as shown in figure.

CYLINDER HEAD

Installation (Cont'd)



14. Install intake manifold.
Install all parts which were removed in step 9 under "CYLINDER HEAD — Removal" (EM-21).

- **Tightening procedure**

- (1) Tighten all bolts to 3 to 5 N·m (0.3 to 0.5 kg-m, 2.2 to 3.6 ft-lb).

Tighten all nuts to 3 to 5 N·m (0.3 to 0.5 kg-m, 2.2 to 3.6 ft-lb).

- (2) Tighten all bolts to 18 to 22 N·m (1.8 to 2.2 kg-m, 13 to 16 ft-lb).

Tighten all nuts to 18 to 22 N·m (1.8 to 2.2 kg-m, 13 to 16 ft-lb).

15. Install injector fuel tube assembly.

16. Connect all injector harness connectors.

17. Install fuel feed and fuel return hoses to injector fuel tube assembly.

18. Install intake manifold collector.

Install all parts which were removed in step 5 under "CYLINDER HEAD — Removal" (EM-21).

19. Install ASCD and accelerator control wire.

20. Check hydraulic valve lifter.

- a. Push plunger forcefully with your finger.

- **Be sure to check it with rocker arm in its free position (not on the lobe).**

- b. If valve lifter moves more than 1 mm (0.04 in), air may be inside it.

- c. Bleed air off by running engine at 1,000 rpm under no load for about 10 minutes.

- d. If hydraulic valve lifters are still noisy, replace them and bleed air off again in the same manner as in step 20 (c).

GI

MA

EM

LC

EC

FE

GL

MT

AT

TE

PD

FA

RA

BR

ST

RS

BT

PA


EL

HXX

ENGINE REMOVAL

FRONT ENGINE MOUNTING

SEC. 112




\square : N·m (kg-m, ft-lb)

SEM320F

ENGINE REMOVAL

REAR ENGINE MOUNTING




WARNING:

- Situate vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off. Otherwise, you may burn yourself and/or fire may break out in fuel line.
- For safety during subsequent steps, the tension of wires should be slackened against the engine.
- Before disconnecting fuel hose, release fuel pressure from fuel line.
Refer to "Releasing Fuel Pressure" in EC section.
- Before removing front axle from transmission, place safety stands under designated front supporting points. Refer to GI section for lifting points and towing.
- Be sure to hoist engine and transmission in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.


CAUTION:

- When lifting engine, be careful not to strike adjacent parts, especially accelerator wire casing, brake lines, and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- Before separating engine and transmission, remove crankshaft position sensor (OBD) from the assembly.
- Always take extra care not to damage edge of crankshaft position sensor (OBD), or ring gear teeth.

ENGINE REMOVAL



- Do not loosen front engine mounting insulator cover securing nuts.
When cover is removed, damper oil flows out and mounting insulator will not function.
For tightening torque, refer to AT, MT and PD sections.
For 4WD model, sealant should be applied between engine and transmission.
Refer to "Installation" in MT section.



Removal

1. Remove engine undercover and hood.
2. Drain engine coolant.
3. Remove vacuum hoses, fuel tubes, wires, harnesses and connectors and so on.
4. Remove radiator with shroud and cooling fan.
5. Remove drive belts.
6. Remove power steering oil pump and air conditioner compressor.
7. Remove front exhaust tube.
8. Remove transmission from vehicle.


Refer to "Removal" in MT and AT sections.

9. Install engine slingers.

Slinger bolts:


: 20 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)

10. Hoist engine with engine slingers and remove engine mounting nuts from both sides.
11. Remove engine from vehicle.



CYLINDER BLOCK

SEC. 110•120•150•313



CI

MA

EM

LC

FC

FE

CL

MT

AT

TF

PD

FA

PA

BR

ST

RS

BT

HA

EL

DX

CYLINDER BLOCK





CAUTION:

- When installing sliding parts such as bearings and pistons, be sure to apply engine oil on the sliding surfaces.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When installing connecting rod bolts and main bearing cap bolts, apply new engine oil to threads and seating surfaces.
- Do not allow any magnetic materials to contact the ring gear teeth on flywheel or drive plate and rear plate.

Disassembly

PISTON AND CRANKSHAFT

1. Place engine on a work stand.
 2. Drain coolant and oil.
 3. Remove oil pan and oil pump.
 4. Remove timing belt.
 5. Remove water pump.
 6. Remove cylinder head.
 7. Remove pistons with connecting rods.
 - When disassembling piston and connecting rod, remove snap ring first, then heat piston to 60 to 70°C (140 to 158°F) or use piston pin press stand at room temperature.
- CAUTION:**
- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
 - When replacing piston rings, if there is no punchmark, install with either side up.
8. Remove bearing cap and crankshaft.
 - Before removing bearing cap, measure crankshaft end play.
 - Bolts should be loosened in two or three steps.




Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".
Standard diameter "dp":
20.969 - 20.981 mm (0.8255 - 0.8260 in)

CYLINDER BLOCK

Inspection (Cont'd)



2. Measure outer diameter of piston pin "Dp".

Standard diameter "Dp":

20.971 - 20.983 mm (0.8256 - 0.8261 in)

3. Calculate piston pin clearance.

$dp - Dp = 0 - 0.004$ mm (0 - 0.0002 in)

If it exceeds the above value, replace piston assembly with pin.

GI

MA

EM

LC

PISTON RING SIDE CLEARANCE

Side clearance:

Top ring: 0.024 - 0.076 mm (0.0009 - 0.0030 in)

2nd ring: 0.030 - 0.070 mm (0.0012 - 0.0028 in)

Max. limit of side clearance:

Top ring: 0.11 mm (0.0043 in)

2nd ring: 0.1 mm (0.004 in)


If out of specification, replace piston and/or piston ring assembly.

EC

FE

CL

MT



PISTON RING END GAP

End gap:

Top ring: 0.21 - 0.40 mm (0.0083 - 0.0157 in)

2nd ring: 0.50 - 0.69 mm (0.0197 - 0.0272 in)

Oil ring: 0.20 - 0.69 mm (0.0079 - 0.0272 in)

Max. limit of ring gap:

Top ring: 0.54 mm (0.0213 in)

2nd ring: 0.80 mm (0.0315 in)

Oil ring: 0.95 mm (0.0374 in)

If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, rebore cylinder and use oversized piston and piston rings.

AT

TF

PD

FA

RA

BR

ST


FS

BT

HA

EL

IDX



Refer to SDS (EM-51).

- When replacing the piston, check the cylinder block surface for scratches or seizure. If scratches or seizure are found, hone or replace the cylinder block.

CONNECTING ROD BEND AND TORSION

Bend:

Limit 0.15 mm (0.0059 in)


per 100 mm (3.94 in) length

Torsion:

Limit 0.30 mm (0.0118 in)



per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.



CYLINDER BLOCK

Inspection (Cont'd)



CYLINDER BLOCK DISTORTION AND WEAR

1. Clean upper face of cylinder block and measure the distortion.
Limit:

0.10 mm (0.0039 in)

2. If out of specification, resurface it.
The resurfacing limit is determined by cylinder head resurfacing in engine.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

A + B = 0.2 mm (0.008 in)

**Nominal cylinder block height
from crankshaft center:**

227.60 - 227.70 mm (8.9606 - 8.9645 in)

3. If necessary, replace cylinder block.

PISTON-TO-BORE CLEARANCE

1. Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Standard inner diameter:

91.500 - 91.530 mm (3.6024 - 3.6035 in)

Refer to "CYLINDER BLOCK" in SDS.

Wear limit:

0.20 mm (0.0079 in)

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.



Out-of-round (X - Y) standard:

0.015 mm (0.0006 in)

Taper (A - B or A - C) standard:




0.015 mm (0.0006 in)

2. Check for scratches and seizure. If seizure is found, hone it.



CYLINDER BLOCK

Inspection (Cont'd)



- If both cylinder block and piston are replaced with new ones, select piston of the same grade number according to the following table. These numbers are punched on cylinder block and piston in either Arabic or Roman numerals.

Combination of grade number for cylinder bore and piston

Cylinder bore grade No.	For No. 3 and 4 cylinders						Except for No. 3 and 4 cylinders		
	1	2	3	4	5	6	1	2	3
Piston grade No.	2-1	3-2	3-3	4-4	4-5	5-6	1	2	3

3. Measure piston skirt diameter.
Piston diameter "A":
Refer to SDS (EM-51).
Measuring point "a" (Distance from the top):
49.0 mm (1.929 in)
4. Check that piston-to-bore clearance is within specification.
Piston-to-bore clearance "B":
0.015 - 0.025 mm (0.0006 - 0.0010 in) for No. 3 and 4 cylinders
0.025 - 0.045 mm (0.0010 - 0.0018 in) except for No. 3 and 4 cylinders
5. Determine piston oversize according to amount of cylinder wear.

Oversize pistons are available for service. Refer to SDS (EM-51).

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation:

$$D = A + B - C$$

where,

D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)


7. Install main bearing caps, and tighten to the specified torque to prevent distortion of cylinder bores in final assembly.
8. Cut cylinder bores.
 - **When any cylinder needs boring, all other cylinders must also be bored.**
 - **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**
- 9.hone cylinders to obtain specified piston-to-bore clearance.
10. Measure finished cylinder bore for out-of-round and taper.
 - **Measurement should be done after cylinder bore cools down.**

GI
MA
EM
LC
EC
FE
CL
WT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
ICX

CYLINDER BLOCK

Inspection (Cont'd)

CRANKSHAFT




1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):

Less than 0.005 mm (0.0002 in)

Taper (A - B):


Less than 0.005 mm (0.0002 in)



3. Measure crankshaft runout.

Runout (Total indicator reading):

Less than 0.10 mm (0.0039 in)




BEARING CLEARANCE

- Either of the following two methods may be used, however, method A gives more reliable results and is preferable.

Method A (Using bore gauge & micrometer)

Main bearing


1. Set main bearings in their proper positions on cylinder block and main bearing cap.



2. Install main bearing cap to cylinder block.

Tighten all bolts in correct order in two or three stages.

3. Measure inner diameter "A" of each main bearing.



4. Measure outer diameter "Dm" of each crankshaft main journal.
5. Calculate main bearing clearance.

Main bearing clearance (A - Dm):

Standard

0.028 - 0.055 mm (0.0011 - 0.0022 in)


Limit

0.090 mm (0.0035 in)


6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

CYLINDER BLOCK

Inspection (Cont'd)




- a. When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.
"L": 0.1 mm (0.004 in)
- b. Refer to SDS for grinding crankshaft and available service parts.



8. If crankshaft is reused, measure main bearing clearances and select thickness of main bearings.

If crankshaft is replaced with a new one, it is necessary to select thickness of main bearings as follows:

- a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.




- b. Grade number of each crankshaft main journal is punched on the respective crankshaft. These numbers are punched in either Arabic or Roman numerals.
- c. Select main bearing with suitable thickness according to the following example or table.

For example:

$$\begin{aligned} \text{Main journal grade number: } & 1 \\ \text{Crankshaft journal grade number: } & 2 \\ \text{Main bearing grade number} & = 1 + 2 \\ & = 3 \text{ (Yellow)} \end{aligned}$$

Main bearing grade number (Identification color):

		Main journal grade number		
		"0"	"1" or "I"	"2" or "II"
Crankshaft journal grade number	"0"	0 (Black)	1 (Brown)	2 (Green)
	"1" or "I"	1 (Brown)	2 (Green)	3 (Yellow)
	"2" or "II"	2 (Green)	3 (Yellow)	4 (Blue)



Connecting rod bearing (Big end)


1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of each bearing.

CYLINDER BLOCK

Inspection (Cont'd)



4. Measure outer diameter "Dp" of each crankshaft pin journal.
5. Calculate connecting rod bearing clearance.

Connecting rod bearing clearance (C - Dp):

Standard

0.014 - 0.054 mm (0.0006 - 0.0021 in)

Limit


0.090 mm (0.0035 in)

6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing. Refer to step 7 of "BEARING CLEARANCE — Main bearing" (EM-41).

Method B (Using plastigage)

CAUTION:

- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. Then if excessive bearing clearance exists, use a thicker main bearing or undersized bearing so that the specified bearing clearance is obtained.



CONNECTING ROD BUSHING CLEARANCE (Small end)


1. Measure inner diameter "C" of bushing.
2. Measure outer diameter "Dp" of piston pin.
3. Calculate connecting rod bushing clearance.

Connecting rod bushing clearance = C - Dp

Standard: 0.005 - 0.017 mm (0.0002 - 0.0007 in)

Limit: 0.023 mm (0.0009 in)

If it exceeds the limit, replace connecting rod assembly or connecting rod bushing and/or piston set with pin.



REPLACEMENT OF CONNECTING ROD BUSHING (Small end)

1. Drive in small end bushing until it is flush with end surface of rod.

Be sure to align the oil holes.

2. After driving in small end bushing, ream the bushing so that clearance between connecting rod bushing and piston pin is the specified value.

Clearance between connecting rod bushing and piston pin:

0.005 - 0.017 mm (0.0002 - 0.0007 in)

FLYWHEEL/DRIVE PLATE RUNOUT

Runout (Total indicator reading):

Flywheel (M/T model)


Less than 0.15 mm (0.0059 in)


Drive plate (A/T model)

Less than 0.15 mm (0.0059 in)

CAUTION:

- Be careful not to damage the ring gear teeth.
- Check the drive plate for deformation or cracks.
- Do not allow any magnetic materials to contact the ring gear teeth.
- Do not surface flywheel. Replace as necessary.







Assembly

PISTON

1. Install new snap ring on one side of piston pin hole.
2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.
 - **Align the direction of piston and connecting rod.**
 - **Numbers stamped on connecting rod and cap correspond to each cylinder.**
 - **After assembly, make sure connecting rod swings smoothly.**




3. Set piston rings as shown.




CRANKSHAFT

1. Set main bearings in their proper positions on cylinder block and main bearing cap.
 - **Confirm that correct main bearings are used.**
- Refer to "Inspection" in this section (EM-42).



2. Install crankshaft and main bearing caps and tighten bolts to the specified torque.
 - **Prior to tightening bearing cap bolts, place bearing cap in its proper position by shifting crankshaft in the axial direction.**
 - **Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward sequentially.**
 - **After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.**
 - **Lubricate threads and seat surfaces of the bolts with new engine oil.**



3. Measure crankshaft end play.

Crankshaft end play:

Standard

0.050 - 0.170 mm (0.0020 - 0.0067 in)






Limit

0.30 mm (0.0118 in)

If beyond the limit, replace bearing with a new one.

CYLINDER BLOCK

Assembly (Cont'd)



4. Install connecting rod bearings in connecting rods and connecting rod caps.
 - **Confirm that correct bearings are used.****Refer to "Inspection".**
 - Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.

5. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - **Be careful not to scratch cylinder wall by connecting rod.**
 - **Arrange so that front mark on piston head faces toward front of engine.**

- b. Install connecting rod bearing caps.
 - **Lubricate threads and seat surfaces with new engine oil.**Tighten connecting rod bearing cap nuts to the specified torque.

 **Connecting rod bearing nut**

(1) Tighten to 14 to 16 N·m (1.4 to 1.6 kg-m, 10 to 12 ft-lb).

(2) Turn nuts 60 to 65 degrees clockwise.

If an angle wrench is not available, tighten nuts to 38 to 44 N·m (3.9 to 4.5 kg-m, 28 to 33 ft-lb).

6. Measure connecting rod side clearance.

Connecting rod side clearance:

Standard

0.20 - 0.35 mm (0.0079 - 0.0138 in)

Limit

0.40 mm (0.0157 in)

If beyond the limit, replace connecting rod and/or crankshaft.



7. Install rear oil seal retainer.

CYLINDER BLOCK

Assembly (Cont'd)

REPLACING PILOT BUSHING (M/T) OR PILOT CONVERTER (A/T)

1. Remove pilot bushing (M/T) or pilot converter (A/T).



2. Install pilot bushing (M/T) or pilot converter (A/T).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

FA

EL

DX

SERVICE DATA AND SPECIFICATIONS (SDS)


General Specifications

Cylinder arrangement	V-6	
Displacement	cm ³ (cu in)	3,275 (199.84)
Bore and stroke	mm (in)	91.5 x 83 (3.602 x 3.27)
Valve arrangement	OHC	
Firing order	1-2-3-4-5-6	
Number of piston rings		
Compression	2	
Oil	1	
Number of main bearings	4	
Compression ratio	8.9	

Unit: kPa (kg/cm², psi)/300 rpm


Compression pressure		
Standard	1,196 (12.2, 173)	
Minimum	883 (9.0, 128)	
Differential limit between cylinders	98 (1.0, 14)	

Cylinder number



SEM713A

Valve timing



EM120
Unit: degree


a	b	c	d	e	f
240	244	4	60	9	51

Inspection and Adjustment

CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Head surface distortion	Less than 0.03 (0.0012)	0.1 (0.004)




SEM082B

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

VALVE

Unit: mm (in)



SEM188

Valve head diameter "D"	
Intake	41.95 - 42.25 (1.6516 - 1.6634)
Exhaust	35.0 - 35.2 (1.378 - 1.386)
Valve length "L"	
Intake	125.3 - 125.9 (4.933 - 4.957)
Exhaust	124.2 - 124.8 (4.890 - 4.913)
Valve stem diameter "d"	
Intake	6.965 - 6.980 (0.2742 - 0.2748)
Exhaust	7.962 - 7.970 (0.3135 - 0.3138)
Valve seat angle "α"	
Intake	45°15' - 45°45'
Exhaust	
Valve margin "T"	
Intake	1.15 - 1.45 (0.0453 - 0.0571)
Exhaust	1.35 - 1.65 (0.0531 - 0.0650)
Valve margin "T" limit	More than 0.5 (0.020)
Valve stem end surface grinding limit	Less than 0.2 (0.008)
Valve clearance	
Intake	0 (0)
Exhaust	0 (0)

Valve spring

Free height	mm (in)	Outer	51.2 (2.016)
		Inner	44.1 (1.736)
Pressure N (kg, lb) at height mm (in)		Outer	523.7 (53.4, 117.7) at 30.0 (1.181)
		Inner	255.0 (26.0, 57.3) at 25.0 (0.984)
Out-of-square	mm (in)	Outer	2.2 (0.087)
		Inner	1.9 (0.075)

Hydraulic valve lifter

Unit: mm (in)

Lifter outside diameter	15.947 - 15.957 (0.6278 - 0.6282)
Lifter guide inside diameter	16.000 - 16.013 (0.6299 - 0.6304)
Clearance between lifter and lifter guide	0.043 - 0.066 (0.0017 - 0.0026)

Valve guide

Unit: mm (in)

		Standard	Service
Valve guide			
Outer diameter	Intake	11.023 - 11.034 (0.4340 - 0.4344)	11.223 - 11.234 (0.4418 - 0.4423)
	Exhaust	12.023 - 12.034 (0.4733 - 0.4738)	12.223 - 12.234 (0.4812 - 0.4817)
Valve guide			
Inner diameter (Finished size)	Intake	7.000 - 7.018 (0.2756 - 0.2763)	
	Exhaust	8.000 - 8.011 (0.3150 - 0.3154)	
Cylinder head valve guide hole diameter	Intake	10.975 - 10.996 (0.4321 - 0.4329)	11.175 - 11.196 (0.4400 - 0.4408)
	Exhaust	11.975 - 11.996 (0.4715 - 0.4723)	12.175 - 12.196 (0.4793 - 0.4802)
Interference fit of valve guide	Intake	0.027 - 0.059 (0.0011 - 0.0023)	
	Exhaust		
		Standard	Max. tolerance
Stem to guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.10 (0.0039)
	Exhaust	0.040 - 0.049 (0.0016 - 0.0019)	
Valve deflection limit		—	0.20 (0.0079)

Rocker shaft and rocker arm

Unit: mm (in)

Rocker shaft	
Outer diameter	17.979 - 18.000 (0.7078 - 0.7087)
Rocker arm	
Inner diameter	18.007 - 18.028 (0.7089 - 0.7098)
Clearance between rocker arm and rocker shaft	0.007 - 0.049 (0.0003 - 0.0019)


SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)


CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)

Intake valve seat




Oversize [0.5 (0.020)]




Unit: mm (in)

SEM755A



SEM893BA

	Standard	Max. tolerance
Camshaft journal to bearing clearance	0.060 - 0.105 (0.0024 - 0.0041)	0.15 (0.0059)
Inner diameter of camshaft bearing	(A): 47.000 - 47.025 (1.8504 - 1.8514) (B): 42.500 - 42.525 (1.6732 - 1.6742) (C): 48.000 - 48.025 (1.8898 - 1.8907)	—
Outer diameter of camshaft journal	(A): 46.920 - 46.940 (1.8472 - 1.8480) (B): 42.420 - 42.440 (1.6701 - 1.6709) (C): 47.920 - 47.940 (1.8866 - 1.8874)	—
Camshaft runout [TIR*]	Less than 0.04 (0.0016)	0.1 (0.004)
Camshaft end play	0.03 - 0.06 (0.0012 - 0.0024)	—




EM671


Cam height "A"	
Intake	39.242 - 39.432 (1.5450 - 1.5524)
Exhaust	38.943 - 39.133 (1.5332 - 1.5407)
Wear limit of cam height	0.15 (0.0059)

*Total indicator reading

Exhaust valve seat



Oversize [0.5 (0.020)]



Unit: mm (in)


SEM346F

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CYLINDER BLOCK

Unit: mm (in)



SEM321A

Surface flatness	
Standard	Less than 0.03 (0.0012)
Limit	0.10 (0.0039)
Cylinder bore	
Inner diameter	
Standard (for No. 3 and 4 cylinders)	
Grade No. 1	91.500 - 91.505 (3.6024 - 3.6026)
Grade No. 2	91.506 - 91.510 (3.6026 - 3.6027)
Grade No. 3	91.511 - 91.515 (3.6028 - 3.6029)
Grade No. 4	91.516 - 91.520 (3.6030 - 3.6031)
Grade No. 5	91.521 - 91.525 (3.6032 - 3.6033)
Grade No. 6	91.526 - 91.530 (3.6034 - 3.6035)
Standard (except for No. 3 and 4 cylinders)	
Grade No. 1	91.500 - 91.510 (3.6024 - 3.6027)
Grade No. 2	91.511 - 91.520 (3.6028 - 3.6031)
Grade No. 3	91.521 - 91.530 (3.6032 - 3.6035)
Wear limit	0.20 (0.0079)
Out-of-round (X - Y)	Less than 0.015 (0.0006)
Taper (A - B or A - C)	Less than 0.015 (0.0006)
Main journal inner diameter	
Grade No. 0	66.645 - 66.654 (2.6238 - 2.6242)
Grade No. 1	66.654 - 66.663 (2.6242 - 2.6245)
Grade No. 2	66.663 - 66.672 (2.6245 - 2.6249)
Difference in inner diameter between cylinders	
Standard	Less than 0.05 (0.0020)

CONNECTING ROD

Unit: mm (in)


Center distance	154.1 - 154.2 (6.067 - 6.071)
Bend, torsion [per 100 (3.94)]	
Limit	Bend: 0.15 (0.0059) Torsion: 0.30 (0.0118)
Piston pin bushing inner diameter*	20.982 - 20.994 (0.8261 - 0.8265)
Connecting rod big end inner diameter	53.000 - 53.013 (2.0866 - 2.0871)
Side clearance	
Standard	0.20 - 0.35 (0.0079 - 0.0138)
Limit	0.40 (0.0157)

*After installing in connecting rod

PISTON, PISTON RING AND PISTON PIN

Available piston

Unit: mm (in)



SEM882E

Piston skirt diameter "A"

Standard (for No. 3 and 4 cylinders)

Grade No. 2-1	91.480 - 91.485 (3.6016 - 3.6018)
Grade No. 3-2	91.486 - 91.490 (3.6018 - 3.6020)
Grade No. 3-3	91.491 - 91.495 (3.6020 - 3.6022)
Grade No. 4-4	91.496 - 91.500 (3.6022 - 3.6024)
Grade No. 4-5	91.501 - 91.505 (3.6024 - 3.6026)
Grade No. 5-6	91.506 - 91.510 (3.6026 - 3.6027)

Standard (except for No. 3 and 4 cylinders)

Grade No. 1	91.465 - 91.475 (3.6010 - 3.6014)
Grade No. 2	91.476 - 91.485 (3.6014 - 3.6018)
Grade No. 3	91.486 - 91.495 (3.6018 - 3.6022)
0.25 (0.0098) oversize (Service)	91.715 - 91.745 (3.6108 - 3.6120)
0.50 (0.0197) oversize (Service)	91.965 - 91.995 (3.6207 - 3.6218)

"a" dimension	49.0 (1.929)
Piston pin hole diameter	20.969 - 20.981 (0.8255 - 0.8260)
Piston clearance to cylinder block	
Standard	
For No. 3 and 4 cylinders	0.015 - 0.025 (0.0006 - 0.0010)
Except for No. 3 and 4 cylinders	0.025 - 0.045 (0.0010 - 0.0018)

Piston ring

Unit: mm (in)

	Standard	Limit
Side clearance		
Top	0.024 - 0.076 (0.0009 - 0.0030)	0.11 (0.0043)
2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.10 (0.004)
Oil	0.015 - 0.185 (0.0006 - 0.0073)	—
Ring gap		
Top	0.21 - 0.40 (0.0083 - 0.0157)	0.54 (0.0213)
2nd	0.50 - 0.69 (0.0197 - 0.0272)	0.80 (0.0315)
Oil (rail ring)	0.20 - 0.69 (0.0079 - 0.0272)	0.95 (0.0374)

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

Piston pin

Unit: mm (in)


Piston pin outer diameter	20.971 - 20.983 (0.8256 - 0.8261)
Interference fit of piston pin to piston	0 - 0.004 (0 - 0.0002)
Piston pin to connecting rod bushing clearance	0.005 - 0.017 (0.0002 - 0.0007)

*Values measured at ambient temperature of 20°C (68°F)

CRANKSHAFT


Unit: mm (in)

Main journal dia. "Dm"	
Grade No. 0	62.967 - 62.975 (2.4790 - 2.4793)
Grade No. 1	62.959 - 62.967 (2.4787 - 2.4790)
Grade No. 2	62.951 - 62.959 (2.4784 - 2.4787)
Pin journal dia. "Dp"	49.955 - 49.974 (1.9667 - 1.9675)
Center distance "r"	41.5 (1.634)
Out-of-round (X - Y)	
Standard	Less than 0.005 (0.0002)
Taper (A - B)	
Standard	Less than 0.005 (0.0002)
Runout [TIR]	
Standard	Less than 0.025 (0.0010)
Limit	Less than 0.10 (0.0039)
Free end play	
Standard	0.050 - 0.170 (0.0020 - 0.0067)
Limit	0.30 (0.0118)




SEM645

Out-of-round (X) - (Y)
Taper (A) - (B)



EM715

AVAILABLE MAIN BEARING



SEM327A

No. 1 main bearing

Grade number	Thickness "T" mm (in)	Width "W" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)		Black
1	1.821 - 1.825 (0.0717 - 0.0719)		Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	22.4 - 22.6 (0.882 - 0.890)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)		Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)		Blue

No. 2 and 3 main bearing

Grade number	Thickness "T" mm (in)	Width "W" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)		Black
1	1.821 - 1.825 (0.0717 - 0.0719)		Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	18.9 - 19.1 (0.744 - 0.752)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)		Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)		Blue

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

No. 4 main bearing

Grade number	Thickness "T" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)	Black
1	1.821 - 1.825 (0.0717 - 0.0719)	Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)	Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)	Blue

Main bearing 0.25 mm (0.0098 in) undersize

Unit: mm (in)

Thickness "T"	1.948 - 1.956 (0.0767 - 0.0770)
---------------	---------------------------------

AVAILABLE CONNECTING ROD BEARING

Connecting rod bearing undersize

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
Standard	1.502 - 1.506 (0.0591 - 0.0593)	49.955 - 49.974 (1.9667 - 1.9675)
Undersize		Grind so that bearing clearance is the specified value.
0.08 (0.0031)	1.542 - 1.546 (0.0607 - 0.0609)	
0.12 (0.0047)	1.562 - 1.566 (0.0615 - 0.0617)	
0.25 (0.0098)	1.627 - 1.631 (0.0641 - 0.0642)	

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Flywheel/Drive plate	
Runout [TIR]	Less than 0.15 (0.0059)

Bearing clearance

Unit: mm (in)

Main bearing clearance	
Standard	0.028 - 0.055 (0.0011 - 0.0022)
Limit	0.090 (0.0035)
Connecting rod bearing clearance	
Standard	0.014 - 0.051 (0.0006 - 0.0021)
Limit	0.090 (0.0035)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

DX