

## SECTION **EL**

### CONTENTS

<b>PRECAUTIONS</b> .....	2	<b>FRONT FOG LAMP</b> .....	39
Supplemental Restraint System (SRS) "AIR BAG" .....	2	System Description .....	39
Wiring Diagrams and Trouble Diagnosis .....	2	Wiring Diagram — F/FOG — .....	40
<b>HARNESS CONNECTOR</b> .....	3	Aiming Adjustment .....	41
Description .....	3	<b>TURN SIGNAL AND HAZARD WARNING LAMPS</b> .....	42
<b>STANDARDIZED RELAY</b> .....	4	System Description .....	42
Description .....	4	Wiring Diagram — TURN — .....	44
<b>POWER SUPPLY ROUTING</b> .....	6	Trouble Diagnoses .....	46
Schematic .....	6	Electrical Components Inspection .....	46
Wiring Diagram — POWER — .....	7	<b>ILLUMINATION</b> .....	47
Inspection .....	13	System Description .....	47
<b>GROUND</b> .....	14	Schematic .....	48
Ground Distribution .....	14	Wiring Diagram — ILL — .....	49
<b>COMBINATION SWITCH</b> .....	18	<b>INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS</b> .....	53
Check .....	18	System Description .....	53
Replacement .....	19	Schematic .....	54
<b>STEERING SWITCH</b> .....	20	Wiring Diagram — INT/L — .....	55
Check .....	20	<b>METER AND GAUGES</b> .....	59
<b>HEADLAMP (FOR USA)</b> .....	21	Component Parts and Harness Connector .....	59
System Description .....	21	Location .....	59
Wiring Diagram — H/LAMP — .....	22	System Description .....	59
Trouble Diagnoses .....	23	Combination Meter .....	61
Bulb Replacement .....	23	Wiring Diagram — METER — .....	62
Aiming Adjustment .....	24	Meter/Gauge Operation and Odo/Trip Meter .....	63
<b>HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM</b> — .....	26	Segment Check in Diagnosis Mode .....	63
System Description .....	26	Flexible Print Circuit (FPC) .....	64
Schematic .....	28	Trouble Diagnoses .....	65
Wiring Diagram — DTRL — .....	29	Electrical Components Inspection .....	70
Trouble Diagnoses .....	32	<b>COMPASS AND THERMOMETER</b> .....	72
Bulb Replacement .....	33	System Description .....	72
Aiming Adjustment .....	33	Wiring Diagram — COMPAS — .....	73
<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	34	Trouble Diagnoses .....	74
Wiring Diagram — TAIL/L — .....	34	Calibration Procedure for Compass .....	75
<b>STOP LAMP</b> .....	36	<b>WARNING LAMPS</b> .....	76
Wiring Diagram — STOP/L — .....	36	Schematic .....	76
<b>BACK-UP LAMP</b> .....	38	Wiring Diagram — WARN — .....	77
Wiring Diagram — BACK/L — .....	38	Electrical Components Inspection .....	84
		<b>WARNING CHIME</b> .....	85

# CONTENTS (Cont'd)

Component Parts and Harness Connector		Wiring Diagram — SEAT —	137
Location	85	<b>HEATED SEAT</b>	139
System Description	85	Wiring Diagram — HSEAT —	139
Wiring Diagram — CHIME —	87	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b>	140
Trouble Diagnoses	89	Component Parts and Harness Connector	
<b>FRONT WIPER AND WASHER</b>	93	Location	140
System Description	93	System Description	141
Wiring Diagram — WIPER —	95	Schematic/M/T Models	143
Trouble Diagnoses	97	Schematic/A/T Models	144
Removal and Installation	99	Wiring Diagram — ASCD —	145
Washer Nozzle Adjustment	100	Fail-safe System	150
Washer Tube Layout	101	Trouble Diagnoses	151
<b>REAR WIPER AND WASHER</b>	102	Electrical Component Inspection	160
System Description	102	ASCD Wire Adjustment	161
Schematic	104	<b>POWER WINDOW</b>	162
Wiring Diagram — WIP/R —	105	System Description	162
Trouble Diagnoses	108	Schematic	164
Removal and Installation	108	Wiring Diagram — WINDOW —	165
Washer Nozzle Adjustment	109	Trouble Diagnoses	169
Washer Tube Layout	109	<b>POWER DOOR LOCK</b>	170
Check Valve	109	Component Parts and Harness Connector	
<b>HORN</b>	110	Location	170
Wiring Diagram — HORN —	110	System Description	170
<b>CIGARETTE LIGHTER</b>	111	Schematic	172
Wiring Diagram — CIGAR —	111	Wiring Diagram — D/LOCK —	173
<b>REAR WINDOW DEFOGGER</b>	112	Trouble Diagnoses	176
Component Parts and Harness Connector		<b>MULTI-REMOTE CONTROL SYSTEM</b>	179
Location	112	Component Parts and Harness Connector	
System Description	112	Location	179
Wiring Diagram — DEF —	114	System Description	179
Trouble Diagnoses	116	Schematic	181
Electrical Components Inspection	118	Wiring Diagram — MULTI —	182
Filament Check	118	Trouble Diagnoses	186
Filament Repair	119	ID Code Entry Procedure	194
<b>AUDIO</b>	121	Remote Controller Battery Replacement	195
System Description	121	<b>THEFT WARNING SYSTEM</b>	196
Wiring Diagram — AUDIO —/Base System	122	Component Parts and Harness Connector	
Schematic/BOSE System	124	Location	196
Wiring Diagram — AUDIO —/BOSE System	125	System Description	197
Trouble Diagnoses	129	Schematic	200
Inspection	130	Wiring Diagram — THEFT —	202
<b>AUDIO ANTENNA</b>	131	Trouble Diagnoses	208
System Description	131	<b>SMART ENTRANCE CONTROL UNIT</b>	221
Wiring Diagram — P/ANT —	132	Description	221
Trouble Diagnoses	133	Schematic	222
Location of Antenna	133	Smart Entrance Control Unit Inspection Table	224
Antenna Rod Replacement	133	<b>INTEGRATED HOMELINK TRANSMITTER</b>	225
<b>POWER SUNROOF</b>	135	Wiring Diagram — TRNSMT —	225
Wiring Diagram — SROOF —	135	Trouble Diagnoses	226
<b>DOOR MIRROR</b>	136	<b>ELECTRICAL UNITS LOCATION</b>	227
Wiring Diagram — MIRROR —	136	Engine Compartment	227
<b>POWER SEAT</b>	137	Passenger Compartment	228

# CONTENTS (Cont'd)

<b>HARNESS LAYOUT</b> .....	230	<b>BULB SPECIFICATIONS</b> .....	246
How to Read Harness Layout.....	230	Headlamp.....	246
Outline.....	231	Exterior Lamp.....	246
Main Harness.....	232	Interior Lamp.....	246
Engine Room Harness.....	234	<b>WIRING DIAGRAM CODES (CELL CODES)</b> .....	247
Engine Control Harness.....	236	<b>SUPER MULTIPLE JUNCTION (SMJ)</b> .....	Foldout
Body Harness LH.....	238	Installation.....	Foldout
Body Harness RH.....	239	Terminal Arrangement.....	Foldout
Back Door Harness.....	240	<b>FUSE BLOCK — JUNCTION BOX (J/B)</b> .....	Foldout
Engine and Transmission Harness.....	241	Terminal Arrangement.....	Foldout
Room Lamp.....	242	<b>FUSE AND FUSIBLE LINK BOX</b> .....	Foldout
Air Bag Harness.....	243	Terminal Arrangement.....	Foldout
Front Door Harness.....	244	<b>ELECTRICAL UNITS</b> .....	Foldout
Rear Door Harness.....	245	Terminal Arrangement.....	Foldout

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG"

## Supplemental Restraint System (SRS) "AIR BAG"

NAEL0001

The Supplemental Restraint System "AIR BAG", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

## Wiring Diagrams and Trouble Diagnosis

NAEL0002

When you read wiring diagrams, refer to the followings:

- "HOW TO READ WIRING DIAGRAMS" in GI section
- "POWER SUPPLY ROUTING" for power distribution circuit in EL section

When you perform trouble diagnosis, refer to the followings:

- "HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS" in GI section
- "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section

Check for any Service bulletins before servicing the vehicle.

## Description


### HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

**CAUTION:**

**Do not pull the harness when disconnecting the connector.**

[Example]



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# STANDARDIZED RELAY

Description


## Description

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NAEL0004

NAEL0004S01




SEL881H

### TYPE OF STANDARDIZED RELAYS

NAEL0004S02













1M	1 Make	2M	2 Make
1T	1 Transfer	1M-1B	1 Make 1 Break



SEL882H

# STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

SEL661TA






**Wiring Diagram — POWER —**  
**BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION**



NAEL0006

NAEL006S01


EL-POWER-01



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX






Refer to last page (Foldout page).



# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02







Refer to last page (Foldout page).

(M1) (E1)

# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

## EL-POWER-03



MEL550H



# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


## ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

NAEL000502

EL-POWER-04



Refer to last page (Foldout page).





# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


## IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

NAEL0006S03

EL-POWER-05



Refer to last page (Foldout page).





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL552H

# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


EL-POWER-06



Refer to last page (Foldout page).

M10, E3, E4				
1	2		4	
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
		22		
24	25	26		
		28	29	


MEL553H



## Inspection

### FUSE

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




### FUSIBLE LINK

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

#### CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



### CIRCUIT BREAKER

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Warning chime
- Power window & power door lock
- Power sunroof
- Power seat
- Multi-remote control system
- Theft warning system

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# GROUND

Ground Distribution

## Ground Distribution

NAEL0008

EARTH	CONNECT TO	CONN. NO.	GELL CODE
M4/M66	A/C MODE SWITCH	M39	HA-A/C, A
	ASCD CONTROL UNIT	M3	EL-ASCD
	ASCD MAIN SWITCH	M18	EL-ASCD
	CLUTCH INTERLOCK SWITCH	M28	SC-START
	COMBINATION FLASHER UNIT	M15	EL-TURN
	DOOR MIRROR REMOTE CONTROL SWITCH	M17	EL-MIRROR
	POWER ANTENNA	M69	EL-P/ANT
	POWER WINDOW RELAY	M23	EL-SROOF EL-WINDOW
	REAR WIPER SWITCH	M50	EL-WIP/R
	REAR WINDOW DEFOGGER SWITCH	M36	EL-DEF
	RECIRCULATION SWITCH	M42	HA-A/C, A
	DOOR LOCK AND UNLOCK SWITCH RH	D38	EL-D/LOCK
	DOOR MIRROR DEFOGGER RH	D31	EL-DEF
	FRONT DOOR KEY CYLINDER SWITCH RH	D39	EL-THEFT
	AIR BAG DIAGNOSIS SENSOR UNIT	Z4	RS-SRS
	M4/M77	SHIELD WIRE (FRONT DOOR SPEAKER LH)	D12
SHIELD WIRE (TWEETER LH)		M8	EL-AUDIO
ABS RELAY UNIT (SOLENOID VALVE RELAY)		M74	BR-ABS
A/C AUTO AMP.		M40	HA-A/C, A
COMBINATION METER (AIR BAG)		M24	RS-SRS EL-WARN
COMBINATION METER (CRUISE INDICATOR)		M25	EL-ASCD
COMBINATION METER (FUEL GAUGE)		M24	EL-METER
COMBINATION METER (4WD INDICATOR)		M25	EL-WARN
COMBINATION METER (HIGH BEAM INDICATOR)		M25	EL-H/LAMP EL-DTRL
COMBINATION METER (SPEEDOMETER)		M24	EC-VSS AT-A/T EL-METER EL-ASCD
COMBINATION METER (TACHOMETER)		M26	AT-A/T EL-METER
COMBINATION METER (TURN SIGNAL)		M25	EL-TURN
COMBINATION METER (WATER TEMPERATURE GAUGE)		M24	EL-METER
CIGARETTE LIGHTER SOCKET		M56	EL-CIGAR
DATA LINK CONNECTOR FOR CONSULT		M11	EC-MIL/DL AT-NONDTC
DATA LINK CONNECTOR FOR GST		M9	EC-MIL/DL
FAN CONTROL AMP.		M60	HA-A/C, A
FAN SWITCH		M43	HA-A/C, M HA-A/C, A
FRONT WIPER AMP.		M79	EL-WIPER
FRONT WIPER MOTOR		M78	EL-WIPER
FUSE BLOCK (ACCESSORY RELAY, IGNITION RELAY AND BLOWER MOTOR RELAY)	M10	EL-POWER	



# GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
M4/M77	HEATED SEAT SWITCH LH	M52	EL-HSEAT	GI
	HEATED SEAT SWITCH RH	M53	EL-HSEAT	MA
	ILLUMINATION CONTROL SWITCH	M19	EL-ILL	EM
	SMART ENTRANCE CONTROL UNIT	M16	EL-CHIME EL-D/LOCK EL-MULTI EL-THEFT EL-DEF	EC
	COMPASS AND THERMOMETER	R4	EL-ILL EL-COMPAS	EC
	INTEGRATED HOMELINK <sup>®</sup> TRANSMITTER	R5	EL-TRNSMT	FE
	SPOT LAMP	R6	EL-INT/L	CL
	VANITY MIRROR LH (ILLUMINATION)	R5	EL-ILL	MT
	VANITY MIRROR RH (ILLUMINATION)	R3	EL-ILL	AT
	DOOR MIRROR DEFOGGER LH	D1	EL-DEF	TF
	FRONT DOOR KEY CYLINDER SWITCH LH	D9	EL-THEFT	PD
	FRONT DOOR LOCK ACTUATOR LH	D7	EL-MULTI EL-THEFT	AX
	FRONT DOOR LOCK ACTUATOR RH	D37	EL-MULTI EL-THEFT	SU
	POWER WINDOW MAIN SWITCH	D6	EL-WINDOW EL-D/LOCK	BR
	ABS CONTROL UNIT	M54	BR-ABS	ST
	SHIELD WIRE (FRONT WHEEL SENSOR LH)	E14	BR-ABS	RS
	SHIELD WIRE (FRONT WHEEL SENSOR RH)	E51	BR-ABS	BT
	SHIELD WIRE (REAR WHEEL SENSOR LH)	B69	BR-ABS	HA
	SHIELD WIRE (REAR WHEEL SENSOR RH)	B8	BR-ABS	SC
	SHIELD WIRE (TWEETER RH)	M64	EL-AUDIO	EL
	FRONT DOOR SPEAKER LH	D12	EL-AUDIO	EL
	SHIELD WIRE (FRONT DOOR SPEAKER LH)	D12	EL-AUDIO	EL
	SHIELD WIRE (FRONT DOOR SPEAKER RH)	D42	EL-AUDIO	EL
FRONT DOOR SPEAKER RH	D42	EL-AUDIO	EL	
AUDIO AMP. RELAY	B47	EL-AUDIO	EL	
E13/E41	AMBIENT AIR TEMPERATURE SWITCH	E34	EC-FICD HA-A/C, A	EL
	ASCD HOLD RELAY	E22	EL-ASCD	EL
	ATP RELAY	E86	EL-WARN	EL
	BRAKE FLUID LEVEL SWITCH	E28	EL-WARN	EL
	DAYTIME LIGHT CONTROL UNIT	E45	EL-DTRL	EL
	FRONT FOG LAMP LH	E61	EL-F/FOG	EL
	FRONT FOG LAMP RH	E62	EL-F/FOG	EL
	FRONT FOG LAMP SWITCH	E63	EL-F/FOG	EL
	FRONT TURN SIGNAL LAMP LH	E30	EL-TURN	EL
	FRONT TURN SIGNAL LAMP RH	E39	EL-TURN	EL
FRONT WIPER SWITCH	E9	EL-WIPER	EL	

# GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE
E13/E41	HEADLAMP LH	E29	EL-H/LAMP EL-THEFT
	HEADLAMP RH	E38	EL-H/LAMP EL-DTRL EL-THEFT
	HOOD SWITCH	E31	EL-THEFT
	INHIBITOR RELAY	E56	EC-PNP/SW SC-START
	PARKING LAMP LH	E12	EL-TAIL/L
	PARKING LAMP RH	E40	EL-TAIL/L
	POWER SOCKET RELAY	E21	EL-CIGAR
	THEFT WARNING HORN RELAY	E23	EL-THEFT
	WASHER LEVEL SWITCH	E42	EL-WARN
E101	ALTERNATOR	E105 E106 E107	SC-CHARGE
	POWER STEERING OIL PRESSURE SWITCH	E110	EC-PST/SW
F20/F25	TCM (TRANSMISSION CONTROL MODULE)	M13	AT-MAIN
	DATA LINK CONNECTOR FOR GST	M9	EC-MIL/DL
	CONDENSER	F19	EC-IGN/SG
	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	DISTRIBUTOR (IGNITION)	F7	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	F24	EC-MAIN
	REAR HEATED OXYGEN SENSOR LH	F3	EC-RRO2LH EC-RO2H-L
	REAR HEATED OXYGEN SENSOR RH	F1	EC-RRO2RH EC-RO2H-R
	SHIELD WIRE (ABSOLUTE PRESSURE SENSOR)	E88	EC-AP/SEN
	SHIELD WIRE (CAMSHAFT POSITION SENSOR)	F7	EC-CMPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (OBD)]	F110	EC-CKPS
	SHIELD WIRE (EVAP CONTROL SYSTEM PRESSURE SENSOR)	B102	EC-PRE/SE
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR LH)	F4	EC-FRO2LH EC-FO2H-L EC-FUELLH
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR RH)	F2	EC-FRO2RH EC-FO2H-R EC-FUELRH
	SHIELD WIRE (KNOCK SENSOR)	F102	EC-KS
	SHIELD WIRE (MASS AIR FLOW SENSOR)	F10	EC-MAFS
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR LH)	F3	EC-RRO2LH EC-RO2H-L
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR RH)	F1	EC-RRO2RH EC-RO2H-R
	SHIELD WIRE (THROTTLE POSITION SENSOR)	F8	EC-TPS AT-TPS
	B11/B22/D210	FUEL PUMP	B13
FUEL TANK GAUGE UNIT		B12	EC-TFTS EL-METER EL-WARN
FRONT DOOR SWITCH LH		B9	RS-SRS EL-CHIME EL-THEFT
HEATED SEAT LH		B5	EL-HSEAT

# GROUND

Ground Distribution (Cont'd)

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
B11/B22/D210	POWER SEAT LH	B7	EL-SEAT	GI
	POWER SOCKET	B41	EL-CIGAR	MA
	REAR COMBINATION LAMP LH (BACK-UP LAMP LH)	B26	EL-BACK/L	EM
	REAR COMBINATION LAMP LH (REAR TURN SIGNAL LAMP LH)	B26	EL-TURN	LC
	REAR COMBINATION LAMP LH (STOP LAMP LH)	B26	EL-STOP/L	EC
	REAR COMBINATION LAMP LH (TAIL LAMP LH)	B26	EL-TAIL/L	FE
	REAR WIPER AMP.	B14	EL-WIP/R	CL
	SEAT BELT BUCKLE SWITCH	B6	EL-WARN EL-CHIME	MT
	SPEAKER AMP.	B20	EL-AUDIO	AT
	REAR SPEAKER AMP.	B46	EL-AUDIO	TF
	BACK DOOR KEY CYLINDER SWITCH	D201	EL-THEFT	PD
	BACK DOOR SWITCH	D208	EL-INT/L EL-MULTI EL-THEFT	AX
	GLASS HATCH SWITCH	D209	EL-WIP/R EL-THEFT	SU
	HIGH-MOUNTED STOP LAMP	D302	EL-STOP/L	BR
	LICENSE PLATE LAMP (With spare tire carrier)	D203	EL-TAIL/L	ST
	LICENSE PLATE LAMP LH (Without spare tire carrier)	D202	EL-TAIL/L	RS
	LICENSE PLATE LAMP RH (Without spare tire carrier)	D211	EL-TAIL/L	BT
	LUGGAGE ROOM LAMP	D103	EL-INT/L	HA
	REAR DOOR LOCK ACTUATOR LH	D54	EL-D/LOCK EL-MULTI EL-THEFT	SC
	REAR WIPER MOTOR	D212	EL-WIP/R	
B55/B75	A/T DEVICE (PARK POSITION SWITCH and OVER-DRIVE CONTROL SWITCH)	B59	AT-SHIFT AT-NONDTC	
	ASHTRAY (ILLUMINATION)	B60 B76	EL-ILL	
	HEATED SEAT RH	B56	EL-HSEAT	
	NEUTRAL POSITION SWITCH	B203	EC-PNP/SW	
	REAR COMBINATION LAMP RH (BACK-UP LAMP RH)	B74	EL-BACK/L	
	REAR COMBINATION LAMP RH (REAR TURN SIGNAL LAMP RH)	B74	EL-TURN	
	REAR COMBINATION LAMP RH (STOP LAMP RH)	B74	EL-STOP/L	
	REAR COMBINATION LAMP RH (TAIL LAMP RH)	B74	EL-TAIL/L	
	POWER SEAT RH	B57	EL-SEAT	
	TIRE CARRIER SWITCH	B301	EL-WARN	
	REAR DOOR LOCK ACTUATOR RH	D74	EL-D/LOCK EL-MULTI EL-THEFT	
D305	REAR WINDOW DEFOGGER	D304	EL-DEF	

EL



IDX

# COMBINATION SWITCH

Check

## Check

NAEL0009




LIGHTING SWITCH

	OFF			1			2		
	A	B	C	A	B	C	A	B	C
5			○			○	○	○	○
6			○			○	○	○	○
7							○	○	○
8			○			○	○	○	○
9			○			○	○	○	○
10							○	○	○
11							○	○	○
12							○	○	○

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○			
14	○		○		
15		○			
16				○	
17		○	○		○
18					○






FOG LAMP SWITCH

	OFF	ON
31		○
32		○

TURN SIGNAL SWITCH

	L	N	R
1	○		○
2		○	
3	○		



## Replacement

For removal and installation of spiral cable, refer to RS section <sup>NAEL0010</sup> ["Installation — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.



CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# STEERING SWITCH

Check

Check

NAEL0011



MEL779H

## System Description

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 5
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to lighting switch terminal 8
- through 15A fuse (No. 60, located in the fuse and fusible link box).

### LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 2 of the LH headlamp, and
- from lighting switch terminal 7
- to terminal 2 of the RH headlamp.

Terminal 3 of each headlamp supplies ground through body grounds E13 and E41. With power and ground supplied, the headlamp(s) will illuminate.

### HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal 6
- to terminal 1 of each RH headlamp, and
- from lighting switch terminal 9
- to terminal 1 of each LH headlamp, and
- to combination meter terminal 33 for the high beam indicator.

Ground is supplied to terminal 19 of the combination meter through body grounds M4 and M77.

Terminal 3 of each headlamp supplies ground through body grounds E13 and E41.

With power and ground supplied, the high beams and the high beam indicator illuminate.

### THEFT WARNING SYSTEM

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-197).

GI  
 MA  
 EM  
 LG  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX


# HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP —

## Wiring Diagram — H/LAMP —




NAEL0013

EL-H/LAMP-01



Refer to last page (Foldout page).

(E1) (M1)






## Trouble Diagnoses

NAEL0014

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds E13 and E41</li> <li>3. 15A fuse</li> <li>4. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds E13 and E41.</li> <li>3. Check 15A fuse (No. 60, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch.</li> <li>4. Check lighting switch.</li> </ol>
RH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds E13 and E41</li> <li>3. 15A fuse</li> <li>4. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds E13 and E41.</li> <li>3. Check 15A fuse (No. 59, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch.</li> <li>4. Check lighting switch.</li> </ol>
LH high beams do not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulbs</li> <li>2. Open in LH high beams circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulbs.</li> <li>2. Check R/L wire between lighting switch and LH headlamps for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in LH low beam circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/G wire between lighting switch and LH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
RH high beams do not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulbs</li> <li>2. Open in RH high beams circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulbs.</li> <li>2. Check R/W wire between lighting switch and RH headlamps for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in RH low beam circuit</li> <li>3. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check R/B wire between lighting switch and RH headlamp for an open circuit.</li> <li>3. Check lighting switch.</li> </ol>
High beam indicator does not work.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds M4 and M77</li> <li>3. Open in high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> <li>2. Check grounds M4 and M77.</li> <li>3. Check R/L wire between lighting switch and combination meter for an open circuit.</li> </ol>



### Bulb Replacement

NAEL0015

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.

# HEADLAMP (FOR USA)

4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

**CAUTION:**

**Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**

## Aiming Adjustment


NAEL0016

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

**For details, refer to the regulations in your own country.**

- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle and tester on one and same flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).




### AIMER ADJUSTMENT MARK

NAEL0016S01

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

#### Adjustment value for mechanical aimer

	Mechanical aimer level
Horizontal side	-4 to 4
Vertical side	-4 to 4




### LOW BEAM

NAEL0016S02

1. Turn headlamp low beam on.
2. Use adjusting screws to perform aiming adjustment.
  - **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**

# HEADLAMP (FOR USA)

Aiming Adjustment (Cont'd)



- Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.
  - Dotted lines in illustration show center of headlamp.
- "H": Horizontal center line of headlamps  
 "W<sub>L</sub>": Distance between each headlamp center

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description

## System Description

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied. NAEL0017

Power is supplied at all times

- through 15A fuse (No. 60, located in the fuse and fusible link box)
- to daytime light control unit terminal 3 and
- to lighting switch terminal 8.

Power is also supplied at all times

- through 15A fuse (No. 59, located in the fuse and fusible link box)
- to daytime light control unit terminal 2 and
- to lighting switch terminal 5.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to daytime light control unit terminal 12.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 26, located in the fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied to daytime light control unit terminal 9 through body grounds E13 and E41.

## HEADLAMP OPERATION

### Low Beam Operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied NAEL0017S01

- from lighting switch terminal 7
- to RH headlamp terminal 2
- to daytime light control unit terminal 4.

Ground is supplied to RH headlamp terminal 3 through body grounds E13 and E41.

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied NAEL0017S0101

- from lighting switch terminal 10
- to LH headlamp terminal 2.

Ground is supplied

- to LH headlamp terminal 3
- from daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through body grounds E13 and E41.

With power and ground supplied, the low beam headlamps illuminate.

### High Beam Operation/Flash-to-pass Operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied NAEL0017S0102

- from lighting switch terminal 6
- to terminal 1 of RH headlamp.

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal 9
- to daytime light control terminal 5
- to combination meter terminal 33 for the high beam indicator
- through daytime light control terminal 6
- to terminal 1 of LH headlamp.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to terminal 19 of the combination meter through body grounds M4 and M77.

With power and ground supplied, the high beam headlamps and HI BEAM indicator illuminate.

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

## DAYTIME LIGHT OPERATION

NAEL0017S02

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- to daytime light control unit terminal 3
- through daytime light control unit terminal 6
- to terminal 1 of LH headlamp
- through terminal 3 of LH headlamp
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to terminal 1 of RH headlamp.

Ground is supplied to terminal 3 of RH headlamp through body grounds E13 and E41.

Because the high beam headlamps are now wired in series, they operate at half illumination.

## OPERATION

NAEL0017S03

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	△*	△*	O	△*	△*	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

A: "HIGH BEAM" position

B: "LOW BEAM" position

C: "FLASH TO PASS" position

O : Lamp "ON"


X : Lamp "OFF"

△ : Lamp dims. (Added functions)

\*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

## Schematic



TW : With theft warning system

HEADLAMP LO RH  
HEADLAMP HI RH  
HEADLAMP LO LH  
HEADLAMP HI LH

HIGH BEAM INDICATOR

PARKING BRAKE SWITCH

DAYTIME LIGHT CONTROL UNIT

LIGHTING SWITCH	1ST	2ND
OFF		
A	○	○
B	○	○
C	○	○
A	○	○
B	○	○
C	○	○
A	○	○
B	○	○
C	○	○
A	○	○
B	○	○
C	○	○
A	○	○
B	○	○
C	○	○




# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

## Wiring Diagram — DTRL —

NAEL0020

EL-DTRL-01



Refer to last page (Foldout page).  
(E1) . (M1)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL558H

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).




(E3)




# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



Refer to last page (Foldout page).



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —











Trouble Diagnoses

## Trouble Diagnoses

NAEL0021








### DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NAEL0021S01

Terminal No.	Item	Condition	Voltage (Approximate values)
1	Start signal	 When turning ignition switch to "ST"	Battery voltage
		 When turning ignition switch to "ON" from "ST"	Less than 1V
		 When turning ignition switch to "OFF"	Less than 1V
2	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
3	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
4	Lighting switch (Lo beam)	When turning lighting switch to the 2ND position with "LOW BEAM" position	Battery voltage
5	Lighting switch (Hi beam)	When turning lighting switch to "HI BEAM"	Battery voltage
		When turning lighting switch to "FLASH TO PASS"	Battery voltage
6	LH hi beam	When turning lighting switch to "HI BEAM"	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Battery voltage
7	LH headlamp control (ground)	When lighting switch is turned to the 2ND position with "LOW BEAM" position	Less than 1V
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
8	RH hi beam	When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
9	Ground	---	---

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Terminal No.	Item	Condition		Voltage (Approximate values)	
10	Parking brake switch		When parking brake is released	Battery voltage	GI
			When parking brake is set	Less than 1.5V	MA
11	Alternator		When turning ignition switch to "ON"	Less than 1V	EM
			When engine is running	Battery voltage	LC
			When turning ignition switch to "OFF"	Less than 1V	EC
12	Power source		When turning ignition switch to "ON"	Battery voltage	FE
			When turning ignition switch to "ST"	Battery voltage	CL
			When turning ignition switch to "OFF"	Less than 1V	MT

AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
DX

## Bulb Replacement

Refer to "HEADLAMP (FOR USA)" (EL-23).

NAEL0022

## Aiming Adjustment

Refer to "HEADLAMP (FOR USA)" (EL-24).

NAEL0023




# PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —


## Wiring Diagram — TAIL/L —

NAEL0024

EL-TAIL/L-01




Refer to last page (Foldout page).



# PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)


## EL-TAIL/L-02



- ⬡ TW : With theft warning system
- ⬡ OT : Without theft warning system
- ⬡ BD : With spare tire carrier
- ⬡ OD : Without spare tire carrier

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

Refer to last page (Foldout page).



(M9)

MEL563H



# STOP LAMP

Wiring Diagram — STOP/L —


## Wiring Diagram — STOP/L —

NAEL0025

EL-STOP/L-01









Refer to last page (Foldout page).



# STOP LAMP

Wiring Diagram — STOP/L — (Cont'd)

EL-STOP/L-02



CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

**EL**

MEL550F

IDX


# BACK-UP LAMP

Wiring Diagram — BACK/L —


## Wiring Diagram — BACK/L —

NAEL0026

EL-BACK/L-01



(M) : With M/T  
 (A) : With A/T



Refer to last page (Foldout page).

(M2), (B1)  
 (M10)



## System Description

NAEL0027

GI

Power is supplied at all times to fog lamp relay terminal 3 through:

- 15A fuse (No. 53, located in the fuse and fusible link box).

MA

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 15A fuse (No. 59, located in the fuse and fusible link box)
- to lighting switch terminal 5
- through terminal 7 of the lighting switch
- to fog lamp relay terminal 1.

EM

LC

### FOG LAMP OPERATION

NAEL0027S01

EC

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position:

- ground is supplied to fog lamp relay terminal 2 through the fog lamp switch and body grounds E13 and E41.

FE

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal 5
- to terminal 1 of each fog lamp.

GL

Ground is supplied to terminal 2 of each fog lamp through body grounds E13 and E41.

MT

With power and ground supplied, the fog lamps illuminate.

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



# FRONT FOG LAMP

Wiring Diagram — F/FOG —

## Wiring Diagram — F/FOG —


NAEL0028

EL-F/FOG-01



MEL364I

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




## Aiming Adjustment


Before performing aiming adjustment, make sure of the following. NAEL0029

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Loosen the front fog lamp bolts and adjust the vertical aiming by moving the front fog lamp assembly.



1. Set the distance between the screen and the center of the fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.

- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.
4. Tighten the front fog lamp bolts.

# TURN SIGNAL AND HAZARD WARNING LAMPS

System Description

## System Description

NAEL0030

### TURN SIGNAL OPERATION

NAEL0030S01

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4 and M66.

### LH Turn

NAEL0030S0101

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 2
- combination meter terminal 34
- rear combination lamp LH terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp LH terminal 6 through body grounds B11, B22 and D210.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

### RH Turn

NAEL0030S0102

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 2
- combination meter terminal 32
- rear combination lamp RH terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp RH terminal 6 through body grounds B55 and B75.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

### HAZARD LAMP OPERATION

NAEL0030S02

Power is supplied at all times to hazard switch terminal 3 through:

- 15A fuse [No. 20, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4 and M66.

Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 2
- combination meter terminal 34.
- rear combination lamp LH terminal 5.

Power is supplied through terminal 6 of the hazard switch to

- front turn signal lamp RH terminal 2
- combination meter terminal 32
- rear combination lamp RH terminal 5.

# TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.  
Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.  
Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.  
Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.  
With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

## MULTI-REMOTE CONTROL SYSTEM OPERATION

NAEL0030S03

Power is supplied at all times

- through 15A fuse [No. 20, located in the fuse block (J/B)]
- to multi-remote control relay terminals 1, 3 and 6.

Ground is supplied to multi-remote control relay terminal 2, when the multi-remote control system is triggered through the smart entrance control unit.

Refer to "MULTI-REMOTE CONTROL SYSTEM", EL-179.

The multi-remote control relay is energized.

Power is supplied through terminal 7 of the multi-remote control relay

- to front turn signal lamp LH terminal 2
- to combination meter terminal 34
- to rear combination lamp LH terminal 5.

Power is supplied through terminal 5 of the multi-remote control relay

- to front turn signal lamp RH terminal 2
- to combination meter terminal 32
- to rear combination lamp RH terminal 5.

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.

Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 19 through body grounds M4 and M77.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

## Wiring Diagram — TURN —

NAEL0032

EL-TURN-01




Refer to last page (Foldout page).

M10



# TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)


EL-TURN-02



MR : With multi-remote control system



Refer to last page (Foldout page).



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL3651


# TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

## Trouble Diagnoses

NAEL0033

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Hazard switch</li> <li>3. Turn signal switch</li> <li>4. Open in turn signal switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 12, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check turn signal switch.</li> <li>4. Check G wire between combination flasher unit and turn signal switch for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse [No. 20, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check G wire between combination flasher unit and hazard switch for open circuit.</li> </ol>
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds E13 and E41</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds E13 and E41.</li> </ol>
Rear turn signal lamp LH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds B11, B22 and D210</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds B11, B22 and D210.</li> </ol>
Rear turn signal lamp RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds B55 and B75</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds B55 and B75.</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds M4 and M77.</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> </ol>



## Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NAEL0034

NAEL0034S01

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.



## System Description

NAEL0035

Power is supplied at all times

- through 10A fuse [No. 61, located in the fuse block (J/B)]
- to lighting switch terminal 11.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M19	1	3
Combination meter	M25, M26	37	29
Cigarette lighter	M57	3	4
Rear wiper switch	M50	10	11
Compass and thermometer	R4	5	2
ASCD main switch	M18	5	6
Rear window defogger switch	M36	5	6
Power window main switch	D6	4	13
Audio	M48	8	7
Hazard switch	M35	7	8
CD player	M92, M93	3	5
A/C switch	M45	2	1
A/T indicator	B59	3	4
Ashtray	B60, B76	1	2


The ground for all of the components except for compass and thermometer and ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M4 and M77.

# ILLUMINATION

Schematic

NAEL0036

## Schematic






MEL572H

Wiring Diagram — ILL —

NAEL0037

EL-ILL-01



Refer to last page (Foldout page).

M10

E3




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02

AS : Models with ASCD



MEL564F

# ILLUMINATION



Wiring Diagram — ILL — (Cont'd)

EL-ILL-03

**A** : With A/T

**PW** : With power window


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
DX



Refer to last page (Foldout page).  
**M10**





MEL574H

# ILLUMINATION



Refer to last page (Foldout page).

(M91)



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description

## System Description

### INTERIOR LAMP

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)]
- to interior lamp terminal 1,

With interior lamp switch ON, ground is supplied to turn interior lamp ON.

When any of following door switches are opened with interior lamp switch in DOOR, ground is supplied to interior lamp terminal 2 through door switch.

- front door switch LH
- front door switch RH
- rear door switch LH
- rear door switch RH
- back door switch

With power and ground supplied, the interior room lamp turns ON.

### LUGGAGE ROOM LAMP

The luggage room lamp will turn on in the same manner as interior lamp.

### SPOT LAMP

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)].

With the spot lamp switch in the ON position, ground is supplied

- to spot lamp terminal 2
- through body grounds M4 and M77.

With power and ground supplied, the spot lamp turns ON.

### VANITY MIRROR LAMP

Power is supplied at all times

- through 7.5A fuse [No. 15, located in the fuse block (J/B)]
- to vanity mirror lamp terminal 1.

With the vanity mirror lamp switch in the ON position, the vanity mirror lamp turns ON.

### DOOR WARNING LAMP

With ignition switch in the ON position and any of following door switches opened, DOOR warning lamp (in combination meter) turns ON.

- front door switch LH
- front door switch RH
- rear door switch LH
- rear door switch RH
- back door switch
- glass hatch switch

NAEL0038

GI

NAEL0038S01

MA

EM

LC

EC

FE

NAEL0038S02

CL

NAEL0038S03

MT

AT

TF

NAEL0038S04

PD

AX

NAEL0038S05

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Schematic

## Schematic

NAEL0039



MEL1231




# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L —

## Wiring Diagram — INT/L —


NAEL0040

EL-INT/L-01



Refer to EL-POWER.

- ⬡ TW : With theft warning system
- ⬡ OT : Without theft warning system
- ⬡ VA : With vanity mirror illumination



Refer to last page (Foldout page).

- ⬡ M2 , ⬡ B1
- ⬡ M10
- ⬡ M91


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL577H





# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-02



⊠TW : With theft warning system  
 ⊠OT : Without theft warning system








Refer to last page (Foldout page).

⊠M10  
 ⊠M2, ⊠B1

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-03



Refer to last page (Foldout page).

M2 , B1



MEL1281

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-04



MEL3871

## Component Parts and Harness Connector Location



NAEL0041

SEL290V

## System Description

### UNIFIED CONTROL METER


- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit combined with speedometer.
- Digital meter is adopted for odo/trip meter.\*  
\*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

NAEL0042

NAEL0042S06

### HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NAEL0042S07



SEL253V

#### NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

# METER AND GAUGES

System Description (Cont'd)

## POWER SUPPLY AND GROUND CIRCUIT

NAEL0042S08

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to combination meter terminal 3.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 12.

Ground is supplied

- to combination meter terminal 2
- through body grounds M4 and M77.

## WATER TEMPERATURE GAUGE

NAEL0042S01

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 6 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

## TACHOMETER

NAEL0042S02

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 15 for the tachometer.

## FUEL GAUGE

NAEL0042S03

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 7 for the fuel gauge
- from terminal 3 of the fuel tank gauge unit
- through terminal 2 of the fuel tank gauge unit and
- through body grounds B11, B22 and D210.

## SPEEDOMETER

NAEL0042S04

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 16 and 14 for the speedometer
- from terminals 2 and 1 of the vehicle speed sensor.



The speedometer converts the voltage into the vehicle speed displayed.

# METER AND GAUGES


Combination Meter

## Combination Meter

NAEL0043



- U : For USA
- C : For Canada
- TC : With spare tire carrier
- 4W : With 4-wheel drive
- A4 : With 4-wheel drive and A/T
- AT : With A/T
- AS : With ASCD



MEL1271









# METER AND GAUGES

Wiring Diagram — METER —

## Wiring Diagram — METER —

NAL0045

EL-METER-01



Refer to last page (Foldout page).





# METER AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode


## Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

### DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

### HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.




6. All odo/trip meter segments should be turned on.

#### NOTE:

If some segments are not turned on, speedometer (unified meter control unit) with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.



7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

#### NOTE:

It takes about 1 minute for indication of fuel gauge to become stable.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

## Flexible Print Circuit (FPC)

=NAEL0152


Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.



### DISCONNECT

NAEL0152S01

1. Open connector cover.
2. Release connector lock by holding both ends of it and pulling it up.
3. Disconnect FPC by pulling it up.



### CONNECT

NAEL0152S02

1. Insert FPC into connector and lock connector pushing FPC downward.
2. Check secure connection of FPC.
3. Check continuity of check land terminal for secure connection of FPC.


**Resistance: 0Ω**

4. Close connector cover.

## Trouble Diagnoses PRELIMINARY CHECK

NAEL0046

NAEL0046S04



- \*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-63)
- \*2: METER/GAUGE RESISTANCE CHECK (EL-70)

- \*3: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-67)
- \*4: Flexible Print Circuit (FPC) (EL-64)

- \*5: Symptom Chart 1 (EL-66)
- \*6: Symptom Chart 2 (EL-66)

MEL474H

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# METER AND GAUGES

Trouble Diagnoses (Cont'd)

## SYMPTOM CHART

### Symptom Chart 1 (Malfunction is Indicated in Diagnosis Mode)

NAEL0046S05

NAEL0046S0501


Symptom	Possible causes	Repair order
Speedometer and/or odo/trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Speedometer (Unified meter control unit)</li> </ul>	<ul style="list-style-type: none"> <li>● Replace speedometer (unified meter control unit).</li> </ul>
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Meter/Gauge</li> <li>● Speedometer (Unified meter control unit)</li> </ul>	<ol style="list-style-type: none"> <li>1. Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-70.</li> <li>2. If the resistance is OK, replace speedometer (unified meter control unit).</li> </ol>

### Symptom Chart 2 (No Malfunction is Indicated in Diagnosis Mode)

NAEL0046S0502

Symptom	Possible causes	Repair order
Speedometer and odo/trip meter are malfunctioning.	<ol style="list-style-type: none"> <li>1. Sensor                             <ul style="list-style-type: none"> <li>- Speedometer, Odo/Trip meter</li> </ul> </li> <li>2. FPC connector</li> <li>3. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-68.)</li> <li>2. Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-64.</li> <li>3. Replace speedometer (unified meter control unit).</li> </ol>
Multiple meter/gauge are malfunctioning. (except speedometer, odo/trip meter)	<ol style="list-style-type: none"> <li>1. FPC connector</li> <li>2. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-64.</li> <li>2. Replace speedometer (unified meter control unit).</li> </ol>
One of tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> <li>1. Sensor/Engine revolution signal                             <ul style="list-style-type: none"> <li>- Tachometer</li> <li>- Fuel gauge</li> <li>- Water temp. gauge</li> </ul> </li> <li>2. FPC connector</li> <li>3. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-68.) INSPECTION/FUEL TANK GAUGE UNIT (Refer to EL-69.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-69.)</li> <li>2. Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-64.</li> <li>3. Replace speedometer (unified meter control unit).</li> </ol>

Before starting trouble diagnoses above, perform PRELIMINARY CHECK, EL-65.



## POWER SUPPLY AND GROUND CIRCUIT CHECK

-NAEL0046S07


### Power Supply Circuit Check

NAEL0046S0701

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
3	Ground	Battery volt- age	Battery volt- age	Battery volt- age
12	Ground	0V	0V	Battery volt- age

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 10A fuse [No. 8, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter



### Ground Circuit Check

NAEL0046S0702

Terminals	Continuity
2 - Ground	Yes

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# METER AND GAUGES

Trouble Diagnoses (Cont'd)

## INSPECTION/VEHICLE SPEED SENSOR

=NAEL0046S03

<b>1</b>	<b>CHECK VEHICLE SPEED SENSOR OUTPUT</b>
<p>1. Remove vehicle speed sensor from transmission.                  2. Check voltage between combination meter terminals 14 and 16 while quickly turning speed sensor pinion.  <b>Voltage: Approx. 0.5V</b></p>	
<p>Vehicle speed sensor</p> <p>Vehicle speed sensor pinion</p> <p>DISCONNECT H.S. Combination meter connector (M24)</p> <p>G/Y SB</p> <p>NOTE: Vehicle speed sensor connector should remain connected.</p> <p>SEL293V</p>	
<b>OK or NG</b>	
OK	▶ Vehicle speed sensor is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK VEHICLE SPEED SENSOR</b>
<p>Check resistance between vehicle speed sensor terminals 1 and 2.  <b>Resistance: Approx. 250Ω</b></p>	
<p>DISCONNECT T.S. Vehicle speed sensor connector (B63)</p> <p>1 2</p> <p>SEL344V</p>	
<b>OK or NG</b>	
OK	▶ Check harness or connector between speedometer and vehicle speed sensor.
NG	▶ Replace vehicle speed sensor.

## INSPECTION/ENGINE REVOLUTION SIGNAL

NAEL0046S02

<b>1</b>	<b>CHECK ECM OUTPUT</b>
<p>1. Start engine.                  2. Check voltage between combination meter terminal 15 and ground at idle and 2,000 rpm.  <b>Higher rpm = Higher voltage</b>  <b>Lower rpm = Lower voltage</b>  <b>Voltage should change with rpm.</b></p>	
<p>Combination meter connector (M24)</p> <p>15</p> <p>W/B</p> <p>CONNECT H.S.</p> <p>SEL294V</p>	
<b>OK or NG</b>	
OK	▶ Engine revolution signal is OK.
NG	▶ Harness for open or short between ECM and combination meter

## INSPECTION/FUEL TANK GAUGE UNIT

NAEL0046S08

<b>1</b>	<b>CHECK GROUND CIRCUIT FOR FUEL TANK GAUGE UNIT</b>
<p>Check harness continuity between fuel tank gauge unit terminal 2 and ground.</p>	
<p>Fuel tank gauge unit connector (B12)</p> <p>MEL839G</p>	
Does continuity exist?	
Yes	▶ GO TO 2.
No	▶ Repair harness or connector.

<b>2</b>	<b>CHECK GAUGE UNITS</b>
<p>Refer to "FUEL TANK GAUGE UNIT CHECK" (EL-70).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ Replace fuel tank gauge unit.

<b>3</b>	<b>CHECK HARNESS FOR OPEN OR SHORT</b>
<ol style="list-style-type: none"> <li>1. Disconnect combination meter connector and fuel tank gauge unit connector.</li> <li>2. Check continuity between combination meter terminal 7 and fuel tank gauge unit terminal 3. <b>Continuity should exist.</b></li> <li>3. Check continuity between combination meter terminal 7 and ground. <b>Continuity should not exist.</b></li> </ol>	
<p>Combination meter connector (M24)</p> <p>Fuel tank gauge unit connector (B12)</p> <p>SEL295V</p>	
OK or NG	
OK	▶ Fuel tank gauge unit is OK.
NG	▶ Repair harness or connector.

## INSPECTION/THERMAL TRANSMITTER

NAEL0046S09

<b>1</b>	<b>CHECK THERMAL TRANSMITTER</b>
<p>Refer to "THERMAL TRANSMITTER CHECK" (EL-71).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Replace.

<b>2</b>	<b>CHECK HARNESS FOR OPEN OR SHORT</b>
<ol style="list-style-type: none"> <li>1. Disconnect combination meter connector and thermal transmitter connector.</li> <li>2. Check continuity between combination meter terminal 6 and thermal transmitter terminal 1. <b>Continuity should exist.</b></li> <li>3. Check continuity between combination meter terminal 6 and ground. <b>Continuity should not exist.</b></li> </ol>	
<p>Combination meter connector (M24)</p> <p>Thermal transmitter connector (F17)</p> <p>SEL296V</p>	
OK or NG	
OK	▶ Thermal transmitter is OK.
NG	▶ Repair harness or connector.

# METER AND GAUGES

## Electrical Components Inspection


NAEL0047

### METER/GAUGE RESISTANCE CHECK


NAEL0047S04

1. Disconnect FPC connector. Refer to "Flexible Print Circuit (FPC)" (EL-64).
2. Check resistance between installation screws of meter/gauge.

Screws		Resistance Ω
Tachometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 70 - Approx. 140
B - D	B - C	Approx. 90 - Approx. 170



SEL310V



MEL827F

### FUEL TANK GAUGE UNIT CHECK

NAEL0047S01

- For removal, refer to FE section.

Check the resistance between terminals 3 and 2.


Ohmmeter		Float position		mm (in)	Resistance value (Ω)
(+)	(-)				
3	2	*1	Full	96 (3.78)	Approx. 4 - 6
		*2	1/2	188 (7.40)	
		*3	Empty	257 (10.12)	

\*1 and \*3: When float rod is in contact with stopper.



# METER AND GAUGES

Electrical Components Inspection (Cont'd)




## THERMAL TRANSMITTER CHECK

NAEL0047S02

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω

GI  
MA  
EM  
LC



## VEHICLE SPEED SENSOR SIGNAL CHECK

NAEL0047S03

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage across a and b.


EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

IDX

## System Description

NAEL0153



This unit displays the following items:

- Earth magnetism and heading direction of vehicle.
- Outside air temperature.
- Caution for frozen road surfaces.

### OUTSIDE TEMPERATURE DISPLAY

NAEL0153S01

Push the switch when the ignition key is in the "ACC" or "ON" position. The outside temperature will be displayed in "°F".

- Selecting the indication range  
Push the switch to change from "°F" to "°C".
- When the outside temperature drops below freezing point, ICE is displayed on the unit.
- When the outside temperature is between 55°C (131°F) and 70°C (158°F), the display shows 55°C (131°F).
- When the outside temperature is lower than -30°C (-22°F) or higher than 70°C (158°F), the display shows only "---" though it is operating. This is not a problem.
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
  - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
  - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds.  
(This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
  - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

### DIRECTION DISPLAY



NAEL0153S02

Push the switch when the ignition key is in the "ACC" or "ON" position. The direction will be displayed.


## Wiring Diagram — COMPAS —

NAEL0154

### EL-COMPAS-01



Refer to last page (Foldout page).



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# COMPASS AND THERMOMETER

Trouble Diagnoses

## Trouble Diagnoses PRELIMINARY CHECK FOR THERMOMETER

NAEL004B

NAEL0048S02

1 COOL DOWN CHECK	
1. Turn the ignition key switch to the "ACC" position. 2. Cool down the ambient air temperature sensor with water or ice, so that the indicated temperature falls.	
<b>Does the indicated temperature fall?</b>	
Yes	▶ GO TO 2.
No	▶ The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

2 WARM UP CHECK	
1. Leave the vehicle for 10 minutes, so that the indicated temperature rises. 2. With the ignition key in the "ACC" position, disconnect and reconnect the ambient air temperature sensor connector.	
<b>Does the indicated temperature rise?</b>	
Yes	▶ The system is OK.
No	▶ The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

### NOTE:

- When the outside temperature is between 55°C (131°F) and 70°C (158°F), the display shows 55°C (131°F). When the outside temperature is lower than -30°C (-22°F) or higher than 70°C (158°F), the display shows only "—".
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
  - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
  - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds. (This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
  - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

## INSPECTION/COMPASS AND THERMOMETER

NAEL0048S01

Symptom	Possible causes	Repair order
No display at all	1. 10A fuse 2. Ground circuit 3. Compass and thermometer	1. Check 10A fuse [No. 9, located in fuse block (J/B)]. Turn the ignition switch ON and verify that battery positive voltage is at terminal 7 of compass and thermometer. 2. Check ground circuit for compass and thermometer. 3. Replace compass and thermometer.
Forward direction indication slips off the mark or incorrect.	1. In manual correction mode (Bar and display vanish.) 2. Zone variation change is not done.	1. Drive the vehicle and turn at an angle of 90°. 2. Perform the zone variation change.
Compass reading remains unchanged.	1. Vehicle speed sensor is not entered. 2. Compass and thermometer	1. Check harness for open or short between combination meter terminal 36 and compass and thermometer terminal 1. 2. Replace compass and thermometer.
Displays wrong temperature when ambient temperature is between -30°C (-22°F) and 55°C (131°F). (See NOTE above)	1. Check operation 2. Ambient air temperature sensor circuit 3. Vehicle speed sensor is not entered. 4. Ambient air temperature sensor 5. Compass and thermometer	1. Perform preliminary check shown above. 2. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 3. Check harness for open or short between combination meter terminal 36 and compass and thermometer terminal 1. 4. Replace ambient air temperature sensor. 5. Replace compass and thermometer.

## Calibration Procedure for Compass

NAELO155


The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.

Zone Variation Chart

1. Determine your location on the zone map. Record your zone number.
2. Turn the ignition switch to ACC or ON position.
3. Push the "Mode" switch continuously for five seconds until the current zone entry number is displayed.
4. Press the "Mode" switch repeatedly until the desired zone number is displayed.

Once the desired zone number is displayed, stop pressing the "Mode" switch and the display will show compass direction after a few seconds.

SEL738UA



### CORRECTION FUNCTIONS OF COMPASS

NAELO155S01

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

### INITIAL CORRECTION PROCEDURE FOR COMPASS

NAELO155S02

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The direction bar starts blinking.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.

#### NOTE:

In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# WARNING LAMPS

Schematic

NAEL0049

## Schematic









# WARNING LAMPS

Wiring Diagram — WARN —

## Wiring Diagram — WARN —

NAEL0050

### EL-WARN-01



Refer to last page (Foldout page).

- (E1), (M1)
- (M10)
- (F24)

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS

EL





MEL583H

IDX

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02




Refer to last page (Foldout page).  
M2, B1



# WARNING LAMPS


Wiring Diagram — WARN — (Cont'd)



EL-WARN-03

COMBINATION METER (M24), (M26)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



Refer to last page (Foldout page).




(E1), (M1)  
(M2), (B1)

MEL585H

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-04









Refer to last page (Foldout page).

- (E1) , (M1)
- (M13)
- (M54)

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

## EL-WARN-05



Refer to last page (Foldout page).

(M1), (E1)

(M10)

MEL587H


EL

IDX





# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-06



- : With 4-wheel drive
- : With A/T and 4-wheel drive
- : With M/T and 4-wheel drive



MEL588H




# WARNING LAMPS

## Electrical Components Inspection FUEL WARNING LAMP SENSOR CHECK

NAEL0051

NAEL0051S01


- It will take a short time for the bulb to light.



MEL240H

## OIL PRESSURE SWITCH CHECK

NAEL0051S02



MEL425F

Check the continuity between the terminals of oil pressure switch and body ground.

## DIODE CHECK


NAEL0051S03

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

### NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.

- Diodes for warning lamps are built into the combination meter printed circuit.
- For diode location, refer to Combination Meter, EL-61.




SEL901F

# WARNING CHIME

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0052



SEL297V

### System Description

NAEL0053

The warning chime is controlled by the smart entrance control unit.

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to warning chime terminal 1
- to key switch terminal 1.

Power is supplied at all times

- through 10A fuse [No. 61, located in the fuse block (J/B)]
- to lighting switch terminal 11.

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box).
- to smart entrance control unit terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 11.

Ground is supplied to smart entrance control unit terminal 10 through body grounds M4 and M77.

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied

- through smart entrance control unit terminal 23
- to warning chime terminal 3.

With power and ground supplied, the warning chime will sound.

# WARNING CHIME

System Description (Cont'd)

## IGNITION KEY WARNING CHIME

NAEL0053S01

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning chime will sound. A battery positive voltage is supplied

- from key switch terminal 2
- to smart entrance control unit terminal 24.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 15.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

## LIGHT WARNING CHIME

NAEL0053S02

With ignition switch OFF or ACC, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. A battery positive voltage is supplied.

- from lighting switch terminal 12
- to smart entrance control unit terminal 25.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 15.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

## SEAT BELT WARNING CHIME

NAEL0053S03

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied

- from seat belt switch terminal 1
- to smart entrance control unit terminal 21.

Seat belt switch terminal 2 is grounded through body grounds B11, B22 and D210.





# WARNING CHIME

Wiring Diagram — CHIME —

## Wiring Diagram — CHIME —

NAEL0054

### EL-CHIME-01




MEL590H

# WARNING CHIME






Wiring Diagram — CHIME — (Cont'd)

EL-CHIME-02



Refer to last page (Foldout page).

(M2) (B1)



# WARNING CHIME


Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0055

NAEL0055S01

REFERENCE PAGE (EL- )	89	90	90	91	91	92
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	LIGHTING SWITCH CHECK	KEY SWITCH (INSERT) CHECK	SEAT BELT BUCKLE SWITCH CHECK	DRIVER SIDE DOOR SWITCH CHECK	WARNING CHIME CHECK
Light warning chime does not activate.	X	X			X	X
Ignition key warning chime does not activate.	X		X		X	X
Seat belt warning chime does not activate.	X			X		X
All warning chimes do not activate.	X				X	X




### POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check

NAEL0055S02

NAEL0055S0201

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage
11	Ground	0V	0V	Battery voltage



### Ground Circuit Check

NAEL0055S0202

Terminals	Continuity
10 - Ground	Yes

# WARNING CHIME

Trouble Diagnoses (Cont'd)

## LIGHTING SWITCH INPUT SIGNAL CHECK

-NAEL0055S03

<b>1</b>	<b>CHECK LIGHTING SWITCH INPUT SIGNAL</b>
<p>Check voltage between control unit terminal 25 and ground.  <b>Voltage [V]:</b>  <b>Condition of lighting switch: 1ST or 2ND</b>  <b>Approx. 12</b>  <b>Condition of lighting switch: OFF</b>  <b>0</b></p>	
<p style="text-align: right;">SEL232V</p>	
<b>OK or NG</b>	
OK	▶ Lighting switch is OK.
NG	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 10A fuse (No. 61, located in the fuse and fusible link box)</li> <li>● Harness for open or short between control unit and lighting switch</li> </ul>

## KEY SWITCH (INSERT) CHECK

NAEL0055S04

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>
<p>Check voltage between control unit terminal 24 and ground.  <b>Voltage [V]:</b>  <b>Condition of key switch: Key is inserted.</b>  <b>Approx. 12</b>  <b>Condition of key switch: Key is withdrawn.</b>  <b>0</b></p>	
<p style="text-align: right;">SEL234V</p>	
<b>OK or NG</b>	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK KEY SWITCH (INSERT)</b>
<p>Check continuity between terminals 1 and 2.  <b>Continuity:</b>  <b>Condition of key switch: Key is inserted.</b>  <b>Yes</b>  <b>Condition of key switch: Key is withdrawn.</b>  <b>No</b></p>	
<p style="text-align: right;">SEL249V</p>	
<b>OK or NG</b>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between control unit and key switch</li> </ul>
NG	▶ Replace key switch.

## SEAT BELT BUCKLE SWITCH CHECK

-NAEL0055S05

<b>1</b>	<b>CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL</b>
<p>1. Turn ignition switch "ON".                  2. Check voltage between control unit terminal 21 and ground.</p> <p><b>Voltage [V]:</b>                  Condition of seat belt buckle switch: Fastened                  Approx. 12                  Condition of seat belt buckle switch: Unfastened                  0</p> <p>Smart entrance control unit connector (M16)</p> <p style="text-align: right;">SEL235V</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Seat belt buckle switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK SEAT BELT BUCKLE SWITCH</b>
<p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.</p> <p><b>Continuity:</b>                  Seat belt is fastened.                  No                  Seat belt is unfastened.                  Yes</p> <p>Seat belt buckle switch connector (BB)</p> <p style="text-align: right;">SEL298V</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• Seat belt buckle switch ground circuit</li> <li>• Harness for open or short between control unit and seat belt buckle switch</li> </ul>
NG	▶ Replace seat belt buckle switch.

## DRIVER SIDE DOOR SWITCH CHECK

NAEL0055S06

<b>1</b>	<b>CHECK DOOR SWITCH INPUT SIGNAL</b>
<p>Check voltage between control unit terminal 15 and ground.</p> <p><b>Voltage [V]:</b>                  Condition of driver's door: CLOSED                  Approx. 12                  Condition of driver's door: OPENED                  0</p> <p>Smart entrance control unit connector (M16)</p> <p style="text-align: right;">SEL236V</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Driver side door switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK DRIVER SIDE DOOR SWITCH</b>
<p>Check continuity between terminals 1 and 2, 3 and ground.</p> <p><b>Continuity:</b>                  Door switch is pushed.                  No                  Door switch is released.                  Yes</p> <p>Door switch LH connector (B9)</p> <p style="text-align: right;">SEL237V</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• Door switch ground circuit</li> <li>• Harness for open or short between control unit and door switch</li> </ul>
NG	▶ Replace driver side door switch.

# WARNING CHIME

Trouble Diagnoses (Cont'd)

## WARNING CHIME CHECK

=NAEL0055S07

<b>1</b>	<b>CHECK CHIME POWER SUPPLY</b>
<p>Check voltage between warning chime terminal 1 and ground.</p> <p style="text-align: center;">Chime connector (M27)</p> <p style="text-align: right;">SEL770UA</p>	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 2.
No	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>• Harness for open or short between chime and fuse</li> </ul>

<b>2</b>	<b>CHECK WARNING CHIME</b>
<p>1. Disconnect warning chime connector. 2. Apply 12V direct current to warning chime and check operation.</p> <p style="text-align: center;">Chime connector (M27)</p> <p style="text-align: right;">SEL408V</p>	
<b>Does warning chime sound?</b>	
Yes	▶ Check harness for open or short between control unit and warning chime.
No	▶ Replace warning chime.

## System Description

### WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to wiper motor terminal 6.

### Low and High Speed Wiper Operation

Ground is supplied to wiper switch terminal 17 through body grounds E13 and E41.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 1.

With power and ground supplied, the wiper motor operates at high speed.

### Auto Stop Operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper amplifier terminal 2
- through terminal 7 of the wiper amplifier
- to wiper motor terminal 5
- through terminal 4 of the wiper motor, and
- through body grounds M4 and M77.

When wiper arms reach base of windshield, wiper motor terminals 5 and 6 are connected instead of terminals 4 and 5. Wiper motor will then stop wiper arms at the PARK position.

### Intermittent Operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal 1
- from wiper switch terminal 15
- through body grounds E13 and E41.
- to wiper motor terminal 2
- through the wiper switch terminal 14
- to wiper switch terminal 13
- through wiper amplifier terminal 2
- to wiper amplifier terminal 3
- through body grounds M4 and M77.

The desired interval time is input

- to wiper amplifier terminal 8
- from wiper switch terminal 19.

The wiper motor operates at low speed at the desired time interval.

NAEL0057

NAEL0057S01

NAEL0057S0101

NAEL0057S0102

NAEL0057S0103

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# FRONT WIPER AND WASHER

*System Description (Cont'd)*

---

## **WASHER OPERATION**

NAEL0057S02

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal 2, and
- to wiper amplifier terminal 6
- from terminal 18 of the wiper switch
- through terminal 17 of the wiper switch, and
- through body grounds E13 and E41.

With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.






# FRONT WIPER AND WASHER

Wiring Diagram — WIPER —

## Wiring Diagram — WIPER —

EL-WIPER-01

NAEL0038



Refer to last page (Foldout page).

- (E1), (M1)
- (E4)
- (M10)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL592H

# FRONT WIPER AND WASHER

Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-02



MEL554H


## Trouble Diagnoses DIAGNOSTIC PROCEDURE 1


NAEL0059


NAEL0059S01

**SYMPTOM: Intermittent wiper does not operate.**

<b>1</b>	<b>CHECK WIPER OPERATION</b>
Check whether wiper operates with the wiper switch at Lo position.	
<b>Does wiper operate at Lo speed?</b>	
Yes	▶ GO TO 2.
No	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 20A fuse [No. 19, located in fuse block (J/B)]</li> <li>● Wiper motor</li> <li>● Wiper switch</li> <li>● Harness for open or short</li> </ul>

<b>2</b>	<b>CHECK WIPER AMP. OUTPUT</b>
<p>1. Turn front wiper switch to OFF. 2. Disconnect wiper amp. connector. 3. Check voltage between wiper amp. terminal 2 and ground.</p>	
<p>Wiper amp. connector (M79)</p>  <p style="text-align: right;">SEL226V</p>	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 3.
No	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Wiper switch</li> <li>● Harness for open or short between wiper amp. terminal 2 and wiper switch terminal 13</li> </ul>

<b>3</b>	<b>CHECK INTERMITTENT SWITCH INPUT SIGNAL</b>
Check harness continuity between wiper amp. terminal 1 and ground.	
<p><b>Continuity:</b></p> <p><b>Condition of wiper switch: OFF</b> No</p> <p><b>Condition of wiper switch: INT</b> Yes</p>	
<p>Wiper amp. connector (M79)</p>  <p style="text-align: right;">SEL227V</p>	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Wiper switch</li> <li>● Harness for open or short between wiper amp. terminal 1 and wiper switch terminal 15</li> <li>● Ground circuit for front wiper switch terminal 17</li> </ul>

<b>4</b>	<b>CHECK WIPER AMP. POWER SUPPLY CIRCUIT</b>
Check voltage between wiper amp. terminal 5 and ground while ignition switch is "ACC".	
<p>Wiper amp. connector (M79)</p>  <p style="text-align: right;">SEL228V</p>	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 5.
No	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 20A fuse [No. 19, located in fuse block (J/B)]</li> <li>● Harness for open or short between wiper amp. and fuse</li> </ul>

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# FRONT WIPER AND WASHER

Trouble Diagnoses (Cont'd)

<b>5</b>	<b>CHECK WIPER AMP. GROUND CIRCUIT</b>	
<p>Check harness continuity between wiper amp. terminal 3 and body ground.</p>		
<p style="text-align: right;">SEL229V</p>		
<b>Does continuity exist?</b>		
Yes	▶	Replace wiper amp.
No	▶	Repair harness or connector.

## DIAGNOSTIC PROCEDURE 2

**SYMPTOM:** Intermittent time of wiper cannot be adjusted. NAEL0059S02


<b>1</b>	<b>CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL</b>	
<p>1. Disconnect wiper amp. connector.                  2. Measure resistance between wiper amp. terminals 8 and 3 while turning intermittent wiper volume.  <b>Resistance [Ω]:</b>                  Position of wiper knob: S                  0                  Position of wiper knob: L                  Approx. 1 k</p>		
<p style="text-align: right;">SEL230V</p>		
<b>OK or NG</b>		
OK	▶	Replace wiper amp.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Intermittent wiper volume</li> <li>● Harness for open or short between wiper amp. terminal 8 and wiper switch terminal 19</li> <li>● Ground circuit for front wiper switch terminal 20</li> </ul>

## DIAGNOSTIC PROCEDURE 3

-NAEL0059S03

**SYMPTOM:** Wiper and washer activate individually but not in combination.

<b>1</b>	<b>CHECK WASHER SWITCH INPUT SIGNAL</b>
<p>1. Turn ignition switch to "OFF".                  2. Disconnect wiper amp. connector.                  3. Check harness continuity between wiper amp. terminal 6 and ground.</p> <p><b>Continuity:</b>  <b>Condition of washer switch: OFF</b>                  No  <b>Condition of washer switch: ON</b>                  Yes</p> <p style="text-align: center;">Wiper amp. connector (M79)</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Go to DIAGNOSTIC PROCEDURE 1.
NG	▶ Check harness for open or short between wiper amp. terminal 6 and wiper switch terminal 18.



## Removal and Installation WIPER ARMS

NAEL0060


NAEL0060S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
  2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L<sub>1</sub>" & "L<sub>2</sub>" immediately before tightening nut.
  3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
  4. Ensure that wiper blades stop within clearance "L<sub>1</sub>" & "L<sub>2</sub>".
    - Clearance "L<sub>1</sub>": 34 mm (1.34 in)**
    - Clearance "L<sub>2</sub>": 37 mm (1.46 in)**
- Tighten wiper arm nuts to specified torque.
    - Front wiper: 17 - 23 N·m (1.7 - 2.3 kg-m, 12 - 17 ft-lb)**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# FRONT WIPER AND WASHER

Removal and Installation (Cont'd)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

## WIPER LINKAGE



### Removal

NAEL0060S0201

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

**Be careful not to break ball joint rubber boot.**

### Installation

NAEL0060S0202


- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

### Washer Nozzle Adjustment

NAEL0061


- Adjust washer nozzle with suitable tool as shown in the figure at left.

**Adjustable range:  $\pm 10^\circ$**



# FRONT WIPER AND WASHER


Washer Nozzle Adjustment (Cont'd)



SEL544T

Unit: mm (in)			
*1	390 (15.35)	*5	145 (5.71)
*2	160 (6.30)	*6	143 (5.63)
*3	379 (14.92)	*7	225 (8.86)
*4	140 (5.51)	*8	535 (21.06)

\*: The diameters of these circles are less than 80 mm (3.15 in).



MEL839F

## Washer Tube Layout

NAEL0062

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# REAR WIPER AND WASHER

System Description

## System Description

NAEL0063

NAEL0063S01

NAEL0063S0101

### WIPER OPERATION

#### Power Supply and Ground

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 29, located in the fuse block (J/B)]
- to rear wiper relay terminals 4 and 1.

When the glass hatch switch is CLOSED, power is supplied

- from rear wiper relay terminal 3
- to rear wiper amp. terminal 5,
- to rear washer motor terminal 1 and
- to rear wiper motor terminal 6.

If the glass hatch switch is OPEN, ground is supplied

- to rear wiper relay terminal 2
- from glass hatch switch terminal 1.

Then rear wiper relay is energized and power to the rear wiper amp., washer motor and wiper motor is interrupted.

(If the glass hatch is opened, no function of rear wiper motor will operate.)

If the rear wiper switch is turned to the INT or ON position, when glass hatch is opened, rear wiper relay terminal 2 is also grounded

- through rear wiper relay terminals 6 and 7
- from rear wiper switch terminal 8.

(The purpose of this circuit is to prevent an abrupt operation of the rear wiper when the hatch is closed with the ignition switch turned to ON or ACC, and with the rear wiper switch set to INT or ON.)

Ground is supplied

- to rear wiper amplifier terminal 3
- through body grounds B11, B22 and D210.
- to rear wiper switch terminal 3
- through body grounds M4 and M66.

#### Rising Up Operation

When the rear wiper switch is turned to the INT or ON position, ground is supplied

- through terminal 1 of rear wiper switch
- to rear wiper amp. terminal 1.

Then wiper amp. is energized and power is supplied

- through rear wiper amp. terminal 4
- to rear wiper motor terminal 4.

Ground is supplied to rear wiper motor through rear wiper switch.

With power and ground supplied, rear wiper operates and rear wiper arm moves up.

Wiper does not return to resting position until wiper switch is turned to OFF position.

NAEL0063S0102

#### Low Speed Wiper Operation

When the rear wiper switch is placed in the ON position, ground is supplied

- through terminal 5 of rear wiper switch
- to rear wiper motor terminal 3.

With power and ground supplied, the wiper motor operates at low speed.

NAEL0063S0103

#### Auto Stop Operation

With rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arms reach rear wiper stopper.

When wiper arm is not located at rear wiper stopper with wiper switch OFF, ground is provided

- from terminal 5 of the rear wiper switch
- to wiper motor terminal 3, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 4 of the rear wiper switch

NAEL0063S0104



- to rear wiper amplifier terminal 2
- through terminal 7 of the rear wiper amplifier
- to rear wiper motor terminal 7
- through terminal 8 of the wiper motor, and
- through body grounds B11, B22 and D210.

When wiper arms reach rear wiper stopper, rear wiper motor terminals 7 and 6 are connected instead of terminals 7 and 8. Rear wiper motor will then stop wiper arms at the PARK position.

### Intermittent Operation

The rear wiper motor operates the wiper arms at low speed approximately every 7 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal 1
- from rear wiper switch terminal 1
- through body grounds M4 and M66.
- to wiper motor terminal 3
- through the rear wiper switch terminal 5
- to rear wiper switch terminal 4
- through wiper amplifier terminal 2
- to wiper amplifier terminal 3
- through body grounds B11, B22 and D210.

The rear wiper motor operates at low speed intermittent.

### WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 29, located in the fuse block)
- to rear washer motor terminal 1.

When the rear wiper switch is turned to WASH position, ground is supplied

- to rear washer motor terminal 2, and
- to rear wiper amplifier terminal 6
- from terminal 2 of rear wiper switch
- through terminal 3 of rear wiper switch, and
- through body grounds M4 and M66.

With power and ground supplied, the rear washer motor operates.

When the rear wiper switch is turned to WASH position for one second or more, the rear wiper motor operates at low speed for approximately 3 seconds after the rear wiper switch is released. This feature is controlled by the rear wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

NAEL0063S0105

LG

EC

FE

CL

MT

AT

NAEL0063S02

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX





# REAR WIPER AND WASHER

Wiring Diagram — WIP/R —

## Wiring Diagram — WIP/R —

NAEL0065

### EL-WIP/R-01



Refer to last page (Foldout page).

- M91
- M2
- B1



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL593H


# REAR WIPER AND WASHER

Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-02




Refer to last page (Foldout page).



# REAR WIPER AND WASHER





Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-03



Preceding page

Preceding page



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL777G

# REAR WIPER AND WASHER

Trouble Diagnoses







## Trouble Diagnoses

NAEL0066

NAEL0066S01


### REAR WIPER AMP. INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition		Voltage (Approximate value)	
1	Amp. ON signal		Rear wiper switch	ON or INT	1V or less
				OFF	Approx. 12V
2	Wiper amp. output		Rear wiper switch "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12V
3	Ground	—		—	
4	Rear wiper motor		Rear wiper switch	ON, INT or WASH	Approx. 12V
				OFF	1V or less
5	Power supply (See NOTE)		Rear glass hatch	OPENED	0V
				CLOSED	Approx. 12V
6	Washer switch		Rear wiper switch	WASH	1V or less
				OFF	Approx. 12V
7	Auto stop		Rear wiper switch "ON" or "INT"	Wiper is moving	1V or less
				Wiper stop	Approx. 12V

#### NOTE:

Power to the rear wiper amp. will be interrupted when the rear glass hatch is opened. In that case, conduct the inspection of the rear wiper amp. with the rear glass hatch closed, unless otherwise indicated.




## Removal and Installation

NAEL0067


### WIPER ARMS


NAEL0067S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Install wiper arm to portion A as in figure below and tighten wiper arm nut to specification.
3. Then, set wiper arm to portion B.

 : 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.







## Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range:  $\pm 10^\circ$  (In any direction)




## Washer Tube Layout



## Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# HORN

Wiring Diagram — HORN —

## Wiring Diagram — HORN —

NAEL0071

EL-HORN-01



AS : With ASCD  
 OA : Without ASCD

Refer to EL-POWER.

Refer to last page (Foldout page).



\* : This connector is not shown in "HARNES LAYOUT".

E1 . M1










# CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

## Wiring Diagram — CIGAR —

NAEL0156

EL-CIGAR-01



Refer to last page (Foldout page).

M2 , B1

E1 , M1

M10

MEL597H


G!  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL00/2



SEL299V

## System Description

NAEL0073

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 20A fuse (No. 56, located in the fuse and fusible link box) and
- to rear window defogger relay terminal 6
- through 20A fuse (No. 57, located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal 1 and
- to smart entrance control unit terminal 11
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

Ground is supplied to terminal 1 of the rear window defogger switch through body grounds M4 and M66.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal 2 of the rear window defogger switch
- to smart entrance control unit terminal 20.

Terminal 36 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay

# REAR WINDOW DEFOGGER

System Description (Cont'd)

- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch
- from terminal 5 of the rear window defogger relay.

Terminal 4 of the rear window defogger switch is grounded through body grounds M4 and M66.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX



# REAR WINDOW DEFOGGER

Wiring Diagram — DEF —


## Wiring Diagram — DEF —

NAEL0074

EL-DEF-01




Refer to last page (Foldout page).




# REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



Refer to last page (Foldout page).  
 E1, M1  
 M2, B1

MEL600H

# REAR WINDOW DEFOGGER


Trouble Diagnoses


## Trouble Diagnoses DIAGNOSTIC PROCEDURE

NAEL0075

NAEL0075S01

**SYMPTOM:** Rear window defogger does not activate, or does not go off after activating.

<b>1</b>	<b>CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL</b>
<p>1. Turn ignition switch to ON position. 2. Check voltage between control unit harness terminal 36 and ground.</p> <p><b>Voltage [V]:</b> Rear window defogger switch is "OFF". Approx. 12 Rear window defogger switch is "ON". 0</p>  <p style="text-align: right;">SEL620U</p>	
OK or NG	
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Rear window defogger relay (Refer to EL-118.)</li> <li>● Rear window defogger circuit</li> <li>● Rear window defogger filament (Refer to EL-118.)</li> </ul>
NG	<p>▶ GO TO 2.</p>

<b>2</b>	<b>CHECK DEFOGGER RELAY COIL SIDE CIRCUIT</b>
<p>1. Disconnect control unit connector. 2. Turn ignition switch to ON position. 3. Check voltage between control unit terminal 36 and ground.</p>  <p style="text-align: right;">SEL735U</p>	
Does battery voltage exist?	
Yes	<p>▶ GO TO 3.</p>
No	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in the fuse block (J/B)]</li> <li>● Rear window defogger relay</li> <li>● Harness for open or short between rear window defogger relay and control unit</li> </ul>

# REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL</b>
<p>Check continuity between control unit terminal 20 and ground.</p> <p><b>Continuity:</b>  Rear window defogger switch is pushed.  Yes  Rear window defogger switch is released.  No</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>20</p> <p>OR</p> <p>Ω</p> <p>SEL345V</p>	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• Rear window defogger switch (Refer to EL-118.)</li> <li>• Harness for open or short between control unit and rear window defogger switch</li> <li>• Rear window defogger switch ground circuit</li> </ul>


<b>4</b>	<b>CHECK IGNITION INPUT SIGNAL</b>
<p>Check voltage between control unit terminal 11 and ground.</p> <p><b>Voltage [V]:</b>  Ignition switch is "ON".  Approx. 12  Ignition switch is "OFF".  0</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>11</p> <p>w/B</p> <p>V</p> <p>SEL424TB</p>	
<b>OK or NG</b>	
OK	▶ GO TO 5.
NG	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• 7.5A fuse [No. 11, located in the fuse block (J/B)]</li> <li>• Harness for open or short between control unit and fuse</li> </ul>

<b>5</b>	<b>CHECK CONTROL UNIT GROUND CIRCUIT</b>
<p>Check continuity between control unit terminal 10 and ground.</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>10</p> <p>B</p> <p>Ω</p> <p>SEL363TB</p>	
<b>Does continuity exist?</b>	
Yes	▶ Replace control unit.
No	▶ Repair harness or connectors.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REAR WINDOW DEFOGGER

Electrical Components Inspection



SEC202B

## Electrical Components Inspection


NAEL0076

### REAR WINDOW DEFOGGER RELAY

NAEL0076S01

Check continuity between terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No




SEL430TB

## REAR WINDOW DEFOGGER SWITCH

NAEL0076S02

Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No




SEL263

## Filament Check

NAEL0077



1. Attach probe circuit tester (in volt range) to middle portion of each filament.



SEL122R

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.






2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

## Filament Repair

### REPAIR EQUIPMENT

- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth



### REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.


**Shake silver composition container before use.**

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

Gj  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# REAR WINDOW DEFOGGER

## Filament Repair (Cont'd)



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

**Do not touch repaired area while test is being conducted.**



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

## System Description

Refer to Owner's Manual for audio system operating instructions.

NAEL0079

CI

### BASE SYSTEM

NAEL0079S01

MA

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio terminal 6.

EM

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 15, located in the fuse block (J/B)]
- to audio terminal 10.

LC

Ground is supplied through the case of the audio.

When the audio power knob is pushed to the ON position, audio signals are supplied

- through audio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

EC

FE

### BOSE SYSTEM

NAEL0079S02

CL

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio terminal 6,
- to audio amp. relay terminal 2 and
- to rear speaker amp. terminal 11.

MT

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio terminal 10.

AT

Ground is supplied through the case of the audio.

Ground is supplied

- to audio amp. relay terminal 3,
- to front door speaker LH terminal 5 and
- to front door speaker RH terminal 5
- through body grounds M4 and M77
- to rear speaker amp. terminal 24
- through body grounds B11, B22 and D210.

TF

PD

AX

SU

When the radio POWER button is pressed, power is supplied to rear speaker amp. terminal 9 and audio amp. relay terminal 1 from audio terminal 12. Then audio amp. relay is energized and power is supplied

- to front door speaker LH terminal 4 and
- to front door speaker RH terminal 4.

BR

Audio signals are supplied

- through audio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 2 and 6 of the LH and RH front speakers and terminals 5, 7, 18 and 20 of the rear speaker amp.
- to LH and RH tweeters through terminals 1 and 3 of the front speakers
- to rear LH and RH speakers through terminals 1, 2, 25 and 26 of the rear speaker amp.

ST

RS

BT

HA

SC

**EL**

IDX


# AUDIO

Wiring Diagram — AUDIO —/Base System

## Wiring Diagram — AUDIO —/Base System


NAEL0157

EL-AUDIO-01



Refer to last page (Foldout page).






(M10) (M81)



# AUDIO

Wiring Diagram — AUDIO —/Base System (Cont'd)

EL-AUDIO-02



Refer to last page (Foldout page).


(M2), (B1)

MEL602H

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

Schematic/BOSE System


NAEL0080



Wiring Diagram — AUDIO —/BOSE System

NAEL0091


EL-AUDIO-03



Refer to EL-POWER.

Next page

Refer to last page (Foldout page).





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

EL-AUDIO-04







MEL605H



# AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

EL-AUDIO-05



Refer to last page (Foldout page).  
(M2), (B1)







MEL606H

EL

# AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

EL-AUDIO-06



Refer to last page (Foldout page).

(M2) (B1)

## Trouble Diagnoses

### RADIO

NAEL0082

NAEL0082S01

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Poor radio case ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse [No. 10, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of radio.</li> <li>Check radio case ground.</li> <li>Remove radio for repair.</li> </ol>
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse [No. 4, located in fuse block (J/B)] and verify that battery positive voltage is present at terminal 6 of radio.</li> <li>Remove radio for repair.</li> </ol>
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> <li>Antenna</li> <li>Poor radio ground</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check antenna.</li> <li>Check radio ground.</li> <li>Remove radio for repair.</li> </ol>
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> <li>Window antenna</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check window antenna.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Loose or missing ground bonding straps</li> <li>Ignition condenser or rear window defogger noise suppressor condenser</li> <li>Alternator</li> <li>Ignition coil or secondary wiring</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check ground bonding straps.</li> <li>Replace ignition condenser or rear window defogger noise suppressor condenser.</li> <li>Check alternator.</li> <li>Check ignition coil and secondary wiring.</li> <li>Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> <li>Poor radio ground</li> <li>Antenna</li> <li>Accessory ground</li> <li>Faulty accessory</li> </ol>	<ol style="list-style-type: none"> <li>Check radio ground.</li> <li>Check antenna.</li> <li>Check accessory ground.</li> <li>Replace accessory.</li> </ol>

### BASE SYSTEM

NAEL0082S02

Symptom	Possible causes	Repair order
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker</li> <li>Radio output</li> <li>Speaker circuit</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker.</li> <li>Check radio output voltages.</li> <li>Check wires for open or short between radio and speaker.</li> <li>Remove radio for repair.</li> </ol>

### BOSE SYSTEM

NAEL0082S03

Symptom	Possible causes	Repair order
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Radio output</li> <li>Radio</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse [No. 4, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 2 of audio amp. relay.</li> <li>Check radio output voltage (Terminal 12).</li> <li>Remove radio for repair.</li> </ol>
All front speakers are inoperative.	<ol style="list-style-type: none"> <li>Audio amp. relay</li> <li>Audio amp. relay ground</li> <li>Amp. ON signal</li> </ol>	<ol style="list-style-type: none"> <li>Check audio amp. relay.</li> <li>Check audio amp. relay ground (Terminal 3).</li> <li>Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal 1 of audio amp. relay.</li> </ol>
Individual front speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker ground</li> <li>Power supply</li> <li>Radio output</li> <li>Speaker</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker ground (Terminal 5).</li> <li>Check power supply for speaker (Terminal 4).</li> <li>Check radio output voltage for speaker.</li> <li>Replace speaker.</li> </ol>

# AUDIO

## Trouble Diagnoses (Cont'd)

Symptom	Possible causes	Repair order
Both rear speakers are inoperative.	<ol style="list-style-type: none"> <li>1. Poor rear speaker amp. ground</li> <li>2. Power supply</li> <li>3. Amp. ON signal</li> <li>4. Rear speaker amp.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check rear speaker amp. ground circuit.</li> <li>2. Check power supply for rear speaker amp. (Terminal 11).</li> <li>3. Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal 9 of rear speaker amp.</li> <li>4. Remove rear speaker amp. for repair.</li> </ol>
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>1. Speaker</li> <li>2. Radio/amp. output</li> <li>3. Speaker circuit</li> <li>4. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check speaker.</li> <li>2. Check radio/amp. output.</li> <li>3. Check wires for open or short between radio/amp. and speakers.</li> <li>4. Remove radio for repair.</li> </ol>

## Inspection

### SPEAKER (FOR BASE SYSTEM)

NAEL0083

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals 1 and 2.
  - The resistance should be 2 - 4Ω.
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals 1 and 2.
  - A momentary hum or pop should be heard.

NAEL0683S03

### RADIO AND AMP.

NAEL0083S01

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amps. connected (If radio or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

### ANTENNA

NAEL0083S02

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
  - If reception improves, check antenna ground (at body surface).
  - If reception does not improve, check main feeder cable for short circuit or open circuit.

## System Description

NAEL0084

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to power antenna terminal 6.

Ground is supplied to the power antenna terminal 2 through body grounds M4 and M66.

When the audio is turned to the ON position, battery positive voltage is supplied

- through audio terminal 5
- to power antenna terminal 4.

The antenna raises and is held in the extended position.

When the audio is turned to the OFF position, battery positive voltage is interrupted

- from audio terminal 5
- to power antenna terminal 4.

The antenna retracts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX




# AUDIO ANTENNA

Wiring Diagram — P/ANT —

## Wiring Diagram — P/ANT —

NAE10085

EL-P/ANT-01



Refer to last page (Foldout page).

(M10)

## Trouble Diagnoses

### POWER ANTENNA



NAEL0086

NAEL0086S01

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> <li>7.5A fuse</li> <li>Radio signal</li> <li>Grounds M4 and M66</li> </ol>	<ol style="list-style-type: none"> <li>Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal 6 of power antenna.</li> <li>Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal 4 of power antenna.</li> <li>Check grounds M4 and M66.</li> </ol>

### Location of Antenna

NAEL0087



### Antenna Rod Replacement REMOVAL


- Remove antenna nut and antenna base.

NAEL0088


NAEL0088S01

# AUDIO ANTENNA

## Antenna Rod Replacement (Cont'd)



2. Withdraw antenna rod while raising it by operating antenna motor.



## INSTALLATION

NAEL0088S02

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.




# POWER SUNROOF

Wiring Diagram — SROOF —

## Wiring Diagram — SROOF —

NAEL0089



EL-SROOF-01



Refer to EL-POWER.

To EL-THEFT

Refer to last page (Foldout page).



- (M1) (E1)
- (M10)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
3T  
HA  
SC  
EL  
IDX

MEL609H


# DOOR MIRROR

Wiring Diagram — MIRROR —

## Wiring Diagram — MIRROR —



NAEL0090

EL-MIRROR-01



Refer to last page (Foldout page).

(M10)




# POWER SEAT

Wiring Diagram — SEAT —

## Wiring Diagram — SEAT —

NAEL0092



EL-SEAT-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL794G

# POWER SEAT






# HEATED SEAT

Wiring Diagram — HSEAT —

## Wiring Diagram — HSEAT —

EL-HSEAT-01

NAEL0093



Refer to last page (Foldout page).

M2, B1

M91



MEL612H

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0094



SEL301V

## System Description

Refer to Owner's Manual for ASCD operating instructions.

NAEL0095

### POWER SUPPLY AND GROUND

When ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to ASCD hold relay terminal 3 (M/T models), 7 (A/T models) and
- to ASCD main switch terminal 1.

When ASCD main switch is in ON position, power is supplied

- from ASCD main switch terminal 3
- from ASCD hold relay terminal 2 (M/T models), 1 (A/T models).

Ground is supplied

- to ASCD hold relay terminal 1 (M/T models), 2 (A/T models).
- through body grounds E5 and E30.

With power and ground is supplied, ASCD hold relay is energized. And then power is supplied

- from ASCD hold relay terminal 5 (M/T models), 6 (A/T models)
- to ASCD control unit terminal 4 and
- to ASCD main switch terminal 2.

After the ASCD main switch is released, power remains supplied

- to the coil circuit of ASCD hold relay
- through ASCD main switch terminals 2 and 3.

This power supply continues until any of following things happen.

- Ignition switch is returned to the ACC or OFF position.
- ASCD main switch is turned to OFF position.

While ASCD hold relay is energized power is also supplied to ASCD control unit terminal 5

- through ASCD brake switch and ASCD clutch switch (M/T models) or
- through ASCD brake switch, ASCD hold relay and park/neutral position relay (A/T models).

Ground is supplied

- to ASCD control unit terminal 3
- through body grounds M4 and M66.

### INPUTS

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- ASCD clutch switch (M/T models) or
- inhibitor relay (A/T models)
- ASCD brake switch.

A vehicle speed input is supplied

- to ASCD control unit terminal 7
- from terminal 36 of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal 1
- through 10A fuse [No. 14, located in the fuse block (J/B)].

When the brake pedal is depressed, power is supplied

- from terminal 2 of the stop lamp switch
- to ASCD control unit terminal 11.

Power is supplied at all times

- through 10A fuse [No. 54, located in the fuse and fusible link box]
- to horn relay terminal 2
- through terminal 1 of the horn relay

GI

NAEL0095S03

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

AX

NAEL0095S01

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## System Description (Cont'd)

---

- to ASCD steering switch terminal 21.

When the SET/COAST switch is depressed, power is supplied

- from terminal 22 of the ASCD steering switch
- to ASCD control unit terminal 2.

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal 23 of the ASCD steering switch
- to ASCD control unit terminal 1.

When the system is activated, power is supplied

- to ASCD control unit terminal 5.

Power is interrupted when

- the clutch switch is depressed (M/T models),
- the selector lever is placed in P or N (A/T models) or
- the ASCD brake switch is depressed.

## OUTPUTS

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. NAEL0095502  
The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal 8 of the ASCD control unit
- to ASCD pump terminal 1.

Ground is supplied to the vacuum motor

- from terminal 9 of the ASCD control unit
- to ASCD pump terminal 2.

Ground is supplied to the air valve

- from terminal 10 of the ASCD control unit
- to ASCD pump terminal 3.

Ground is supplied to the release valve

- from terminal 14 of the ASCD control unit
- to ASCD pump terminal 4.

When the system is activated, power is supplied

- from terminal 13 of the ASCD control unit
- to combination meter terminal 9 and
- to TCM (Transmission Control Module) terminal 37 (A/T models).

Ground is supplied

- to combination meter terminal 19
- through body grounds M4 and M77.

With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed on A/T models, a signal is sent

- from terminal 12 of the ASCD control unit
- to TCM (Transmission Control Module) terminal 40.

When this occurs, the TCM (Transmission Control Module) cancels overdrive.

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.




# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic/M/T Models

## Schematic/M/T Models

NAEL0096



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

**EL**

MEL1251


IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic/A/T Models

## Schematic/A/T Models

NAEL0158




MEL126I

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —

FIG. 1




EL-ASCD-01

Refer to EL-POWER.

NAEL0097  
NAEL0097S01

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



Refer to last page (Foldout page).

M1, E1  
M10, E3





# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)


**FIG. 3**

NAEL0097903

**EL-ASCD-03**



Refer to last page (Foldout page).



\* : This connector is not shown in "HARNESS LAYOUT".

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

**FIG. 4**

NAEL0097S04

EL-ASCD-04



Refer to last page (Foldout page).




MEL800G



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Fail-safe System



## Fail-safe System

### DESCRIPTION

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

NAEL0098

NAEL0098S01

### MALFUNCTION DETECTION CONDITIONS

NAEL0098S02

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> <li>• ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck.</li> <li>• Vacuum motor ground circuit or power circuit is open or shorted.</li> <li>• Air valve ground circuit or power circuit is open or shorted.</li> <li>• Release valve ground circuit or power circuit is open or shorted.</li> <li>• Vehicle speed sensor is faulty.</li> <li>• ASCD control unit internal circuit is malfunctioning.</li> </ul>	<ul style="list-style-type: none"> <li>• ASCD is deactivated.</li> <li>• Vehicle speed memory is canceled.</li> </ul>
<ul style="list-style-type: none"> <li>• ASCD brake switch or stop lamp switch is faulty.</li> </ul>	<ul style="list-style-type: none"> <li>• ASCD is deactivated.</li> <li>• Vehicle speed memory is not canceled.</li> </ul>



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0099

NAEL0099S01

REFERENCE PAGE (EL- )	152	153	154	155	156	157	158	158	159
SYMPTOM	FAIL-SAFE SYSTEM CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	ASCD MAIN SWITCH CHECK	ASCD HOLD RELAY CHECK	ASCD BRAKE/STOP LAMP SWITCH CHECK	ASCD STEERING SWITCH CHECK	VEHICLE SPEED SENSOR CHECK	ASCD PUMP CIRCUIT CHECK	ASCD ACTUATOR/PUMP CHECK
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)		X	X	X		X	X		
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X				X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.						X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2						X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.						X			X
System is not released after CAN-CEL switch (steering) has been pressed.						X			X
Large difference between set speed and actual vehicle speed.									X
Deceleration is greatest immediately after ASCD has been set.									X


★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "FAIL-SAFE SYSTEM CHECK" (EL-152) to verify repairs.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




## FAIL-SAFE SYSTEM CHECK

-NAEL0099S02

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the "cruise indicator" blinks.

**If the indicator lamp blinks, check the following.**


- ASCD steering switch. Refer to EL-157.



3. Drive the vehicle at more than 48 km/h (30 MPH) and push SET/COAST switch.

**If the indicator lamp blinks, check the following.**

- Vehicle speed sensor. Refer to EL-158.
- ASCD pump circuit. Refer to EL-158.
- Replace control unit.



4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

**If the indicator lamp blinks, check the following.**

- ASCD brake/stop lamp switch. Refer to EL-156.

5. END. (System is OK.)

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## POWER SUPPLY AND GROUND CIRCUIT CHECK

-NAEL0099S03

<b>1</b>	<b>OPERATION CHECK</b>	
1. Turn ignition switch ON. 2. Turn ASCD main switch "ON".  <p style="text-align: center;"><b>Does ASCD indicator illuminate?</b></p>		
Yes	▶	GO TO 2.
No	▶	Go to ASCD MAIN SWITCH CHECK. Refer to EL-154.

<b>2</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT</b>	
1. Disconnect ASCD control unit connector. 2. Turn ignition switch ON. 3. Turn ASCD main switch "ON". 4. Check voltage between control unit connector terminal 4 and ground.		
<p style="text-align: center;">Refer to wiring diagram in EL-146.</p> <p style="text-align: right;">SEL289UD</p>		
<b>Does battery voltage exist?</b>		
Yes	▶	GO TO 3.
No	▶	Go to ASCD HOLD RELAY CHECK. Refer to EL-155.

<b>3</b>	<b>CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT</b>	
Check continuity between ASCD control unit harness terminal 3 and body ground.		
<p style="text-align: right;">SEL764U</p>		
Refer to wiring diagram in EL-148.		
<b>Does continuity exist?</b>		
Yes	▶	Power supply and ground circuit is OK.
No	▶	Repair harness.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD MAIN SWITCH CHECK

-NAEL0099S04

1	<b>CHECK POWER SUPPLY FOR ASCD MAIN SWITCH</b>
<p>1. Disconnect main switch connector. 2. Check voltage between main switch terminals 1 and 4.</p> <div style="text-align: center;">  <p>ASCD main switch connector (M18)</p> </div> <p style="text-align: right;">MEL842F</p> <p>Refer to wiring diagram in EL-145.</p> <p style="text-align: center;"><b>Does battery voltage exist?</b></p>	
Yes	▶ GO TO 2.
No	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse (No. 11, located in the fuse block)</li> <li>● Harness for open or short between fuse and ASCD main switch</li> <li>● Ground circuit for ASCD main switch</li> </ul>

2	<b>CHECK ASCD MAIN SWITCH</b>
<p>Refer to "Electrical Component Inspection" (EL-160).</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Go to ASCD HOLD RELAY CHECK. Refer to EL-155.
NG	▶ Replace ASCD main switch.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD HOLD RELAY CHECK

-NAEL0099305

<b>1</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR ASCD HOLD RELAY</b>
<p>1. Disconnect ASCD hold relay                  2. Check voltage between ASCD hold relay terminal 3 (M/T), 7 (A/T) and body ground.</p> <p>ASCD hold relay connector</p> <p>M/T models (E27)    A/T models (E22)</p> <p style="text-align: right;">SEL348V</p> <p>Refer to wiring diagram in EL-145.</p> <p style="text-align: center;"><b>Does battery voltage exist?</b></p>	
Yes	▶ GO TO 2.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• 7.5A fuse (No. 11, located in the fuse block)</li> <li>• Harness for open or short between fuse and ASCD hold relay</li> </ul>

<b>2</b>	<b>CHECK GROUND CIRCUIT FOR ASCD HOLD RELAY</b>
<p>Check continuity between ASCD hold relay terminal 1 (M/T), 2 (A/T) and ground.</p> <p>ASCD hold relay connector</p> <p>M/T models (E27)    A/T models (E22)</p> <p style="text-align: right;">SEL349V</p> <p style="text-align: center;"><b>Does continuity exist?</b></p>	
Yes	▶ GO TO 3.
No	▶ Repair harness.

<b>3</b>	<b>CHECK ASCD HOLD RELAY</b>
<p>Check ASCD hold relay.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 4.
NG	▶ Replace ASCD hold relay.

<b>4</b>	<b>CHECK ASCD MAIN SWITCH</b>
<p>Refer to "Electrical Component Inspection" (EL-160).</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Go to next procedure.
NG	▶ Replace ASCD main switch.

<b>5</b>	<b>CHECK ASCD HOLD RELAY OPEN OR SHORT CIRCUIT</b>
<p>1. Connect ASCD main switch.                  2. Check continuity between ASCD hold relay terminals 2 and 5 (M/T), 1 and 6 (A/T).  <b>Continuity should exist.</b></p> <p>ASCD hold relay connector</p> <p>M/T models (E27)    A/T models (E22)</p> <p style="text-align: right;">SEL350V</p> <p>3. Check continuity between ASCD hold relay terminal 1 and ground.  <b>Continuity should not exist.</b></p> <p>ASCD hold relay connector</p> <p>M/T models (E27)    A/T models (E22)</p> <p style="text-align: right;">SEL351V</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ ASCD hold relay is OK.
NG	▶ Repair harness.


CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD BRAKE/STOP LAMP SWITCH CHECK

=NAEL0099S06

1 CHECK ASCD BRAKE SWITCH CIRCUIT	
<p>1. Disconnect control unit connector.                      2. Turn ignition switch ON.                      3. Turn ASCD main switch "ON".                      4. Check voltage between control unit connector terminal 5 and ground.                      When brake pedal is depressed, clutch pedal is depressed (M/T) or A/T selector lever is in "N" or "P" range (A/T):  <b>Approx. 0V</b>                      When both brake pedal is released and clutch pedal is released (M/T) or A/T selector lever is not in "N" or "P" range (A/T):  <b>Battery voltage should exist.</b></p>  <p style="text-align: right;">SEL765U</p>	
Refer to wiring diagram in EL-146.	
<b>OK or NG</b>	
OK	▶ GO TO 2.
NG	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● ASCD brake switch, ASCD clutch switch (M/T models), Inhibitor switch (A/T models) Refer to "Electrical Components Inspection" (EL-160).</li> <li>● ASCD hold relay</li> <li>● Harness for open or short</li> </ul>

2 CHECK STOP LAMP SWITCH CIRCUIT	
<p>1. Disconnect control unit connector.                      2. Check voltage between control unit terminal 11 and ground.  <b>Voltage [V]:</b>  <b>Stop lamp switch: Depressed</b>  <b>Approx. 12</b>  <b>Stop lamp switch: Released</b>  <b>0</b></p>  <p style="text-align: right;">SEL759U</p>	
Refer to wiring diagram in EL-147.	
<b>OK or NG</b>	
OK	▶ ASCD brake/stop lamp switch is OK.
NG	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 10A fuse [No. 14, located in the fuse block (J/B)]</li> <li>● Harness for open or short between ASCD control unit and stop lamp switch</li> <li>● Stop lamp switch Refer to "Electrical Components Inspection" (EL-160).</li> </ul>

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD STEERING SWITCH CHECK

=NAEL009S07

**1 CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT**

1. Disconnect control unit connector.  
2. Check voltage between control unit harness terminals and ground.

	Terminal No.		Switch condition	
	(+)	(-)	Pressed	Released
SET/COAST SW	2	ground	12V	0V
RESUME/ACC SW	1	ground	12V	0V
CANCEL SW	2	ground	12V	0V
	1	ground	12V	0V

MTBL0002

ASCD control unit connector (M3)

SEL760U

Refer to wiring diagram in EL-147.

**OK or NG**

OK	▶	ASCD steering switch is OK.
NG	▶	GO TO 2.

**2 CHECK POWER SUPPLY FOR ASCD STEERING SWITCH**

Does horn work?

Yes	▶	GO TO 3.
No	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>10A fuse (No. 54, located in the relay box)</li> <li>Horn relay</li> <li>Harness for open or short between horn and fuse</li> </ul>

**3 CHECK ASCD STEERING SWITCH**

1. Disconnect ASCD steering switch.  
2. Check continuity between terminals by pushing each switch.

Switch	Terminal		
	21	22	23
RESUME/ACCEL	○	○	○
SET/COAST	○	○	○
CANCEL	○	▶	○
	○	▶	○

MTBL0003

ASCD steering switch (EL2)

SEL409V

**OK or NG**

OK	▶	Check harness for open or short between ASCD steering switch and ASCD control unit.
NG	▶	Replace ASCD steering switch.

GI  
MA  
EM  
LC  
EC  
FE  
GL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## VEHICLE SPEED SENSOR CHECK

-NAEL0099S06

<b>1</b>	<b>CHECK SPEEDOMETER OPERATION</b>	
Refer to wiring diagram in EL-149.		
<b>Does speedometer operate normally?</b>		
Yes	▶	GO TO 2.
No	▶	Check speedometer and vehicle speed sensor circuit. Refer to EL-65.

<b>2</b>	<b>CHECK VEHICLE SPEED INPUT</b>	
<ol style="list-style-type: none"> <li>1. Apply wheel chocks and jack up drive wheels.</li> <li>2. Disconnect control unit connector.</li> <li>3. Check voltage between control unit terminal 7 and ground with turning drive wheels slowly.</li> </ol>		
SEL347V		
<b>Does voltmeter pointer deflect?</b>		
Yes	▶	Vehicle speed sensor is OK.
No	▶	Check harness for open or short between ASCD control unit terminal 7 and combination meter terminal 36.

## ASCD PUMP CIRCUIT CHECK

NAEL0099S09

<b>1</b>	<b>CHECK ASCD PUMP</b>										
<ol style="list-style-type: none"> <li>1. Disconnect ASCD pump connector.</li> <li>2. Measure resistance between ASCD pump terminals 1 and 2, 3, 4.</li> </ol>											
<table border="1"> <thead> <tr> <th>Terminals</th> <th>Resistance [<math>\Omega</math>]</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">1</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Approx. 3</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approx. 65</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Approx. 65</td> </tr> </tbody> </table>			Terminals	Resistance [ $\Omega$ ]	1	2	Approx. 3	3	Approx. 65	4	Approx. 65
Terminals	Resistance [ $\Omega$ ]										
1	2	Approx. 3									
	3	Approx. 65									
	4	Approx. 65									
MTBL0068											
<p>ASCD pump connector (F59)</p>											
MEL243H											
Refer to wiring diagram in EL-148.											
<b>OK or NG</b>											
OK	▶	Check harness for open or short between ASCD pump and ASCD control unit.									
NG	▶	Replace ASCD pump.									




# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)



## ASCD ACTUATOR/PUMP CHECK

-NAEL0098S10

<b>1</b>	<b>CHECK VACUUM HOSE</b>
Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks and fracture.	
	
MEL402G	
<b>OK or NG</b>	
OK	▶ GO TO 2.
NG	▶ Repair or replace hose.


<b>2</b>	<b>CHECK ASCD WIRE</b>
Check wire for improper installation, rust formation and breaks.	
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-161).

<b>3</b>	<b>CHECK ASCD ACTUATOR</b>
<ol style="list-style-type: none"> <li>1. Disconnect vacuum hose from ASCD actuator.</li> <li>2. Apply <math>-40 \text{ kPa}</math> (<math>-0.41 \text{ kg/cm}^2</math>, <math>-5.8 \text{ psi}</math>) vacuum to ASCD actuator with hand vacuum pump. <b>ASCD wire should move to pull throttle drum.</b></li> <li>3. Wait 10 seconds and check for decrease in vacuum pressure.</li> </ol>	
<p><b>Vacuum pressure decrease:</b> Less than <math>2.7 \text{ kPa}</math> (<math>0.028 \text{ kg/cm}^2</math>, <math>0.39 \text{ psi}</math>)</p>	
	
MEL403G	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ Replace ASCD actuator.

<b>4</b>	<b>CHECK ASCD PUMP</b>																		
<ol style="list-style-type: none"> <li>1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.</li> <li>2. If necessary remove ASCD pump.</li> <li>3. Connect vacuum gauge to ASCD pump.</li> <li>4. Apply 12V direct current to ASCD pump and check operation.</li> </ol>																			
<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">12V direct current supply terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Air valve</td> <td></td> <td>3</td> <td>Close</td> </tr> <tr> <td>Release valve</td> <td>1</td> <td>4</td> <td>Close</td> </tr> <tr> <td>Vacuum motor</td> <td></td> <td>2</td> <td>Operate</td> </tr> </tbody> </table>			12V direct current supply terminals		Operation	(+)	(-)	Air valve		3	Close	Release valve	1	4	Close	Vacuum motor		2	Operate
	12V direct current supply terminals		Operation																
	(+)	(-)																	
Air valve		3	Close																
Release valve	1	4	Close																
Vacuum motor		2	Operate																
MTBL0004																			
<p>A vacuum pressure of at least <math>-40 \text{ kPa}</math> (<math>-0.41 \text{ kg/cm}^2</math>, <math>-5.8 \text{ psi}</math>) should be generated.</p>																			
																			
																			
MEL844G																			
<b>OK or NG</b>																			
OK	▶ ASCD actuator/pump is OK.																		
NG	▶ Replace ASCD pump.																		

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Electrical Component Inspection



## Electrical Component Inspection


NAEL0100

### ASCD MAIN SWITCH

NAEL0100S01

Check continuity between terminals by pushing switch to each position.

Switch position	Terminals	Illumination
ON	1 - 2 - 3 - 4	5 - 6
N	2 - 3 - 4	
OFF		




### ASCD BRAKE SWITCH AND STOP LAMP SWITCH

NAEL0100S02

Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


Check each switch after adjusting brake pedal — refer to BR section.



### ASCD CLUTCH SWITCH (FOR M/T MODELS)

NAEL0100S04

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes




### INHIBITOR SWITCH (FOR A/T MODELS)

NAEL0100S03

Selector lever position	Continuity
	Between terminals 1 and 2
"P"	Yes
"N"	Yes
Except "P" and "N"	No

## ASCD Wire Adjustment

NAEL0101



MEL849F

### CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
3. Tighten adjusting nut just until throttle drum starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## System Description

NAEL0102

Power is supplied at all times

- from 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3.

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to power window relay terminal 2.

Ground is supplied to power window relay terminal 1

- through body grounds M4 and M66.

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to power window main switch terminal 1,
- to power window sub switch terminal 5.

## MANUAL OPERATION

### Front Door LH

NAEL0102S01

Ground is supplied

- to power window main switch terminal 3
- through body grounds M4 and M77.

### WINDOW UP

When the front LH switch in the power window main switch is pressed in the up position, power is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

Ground is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

Then, the motor raises the window until the switch is released.

### WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

Ground is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

Then, the motor lowers the window until the switch is released.

### Front Door RH

NAEL0102S0102

Ground is supplied

- to power window main switch terminal 3
- through body grounds M4 and M77.

### NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

### MAIN SWITCH OPERATION

Power is supplied

- through power window main switch (5, 6)
- to front power window sub-switch (4, 3).

The subsequent operation is the same as the sub-switch operation.

### SUB-SWITCH OPERATION

Power is supplied

- through front power window sub-switch (2, 1)

- to front power window regulator RH (2, 1).

GI

Ground is supplied

- to front power window regulator RH (1, 2)
- through front power window sub-switch (1, 2)
- to front power window sub-switch (3, 4)
- through power window main switch (6, 5).

MA

EM

Then, the motor raises or lowers the window until the switch is released.

## Rear Door

NAEL0102S0103

LC

Rear door windows will raise and lower in the same manner as front door RH window.

## AUTO OPERATION

NAEL0102S02

EC

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

The AUTO feature only operates on the driver's window downward movement.

FE

## POWER WINDOW LOCK

NAEL0102S03

CL

The power window lock is designed to lock operation of all windows except for driver's door window.

When the lock switch is pressed to lock position, ground of the sub-switches in the power window main switch is disconnected. This prevents the power window motors from operating.

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# POWER WINDOW

Schematic

NAEL0103


## Schematic



Wiring Diagram — WINDOW —

EL-WINDOW-01

NAEL0104




Refer to EL-POWER.

Next page

To EL-WINDOW-03

To EL-WINDOW-04



Refer to last page (Foldout page).





- (M1), (E1)
- (M2), (B1)
- (M10)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02











# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

## EL-WINDOW-03






GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL611F




# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04



Refer to last page (Foldout page).  
(M2), (B1)



# POWER WINDOW

Trouble Diagnoses

## Trouble Diagnoses

NAEL0105

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 7.5A fuse, 40A fusible link and M21 circuit breaker</li> <li>2. Grounds M4 and M77</li> <li>3. Power window relay</li> <li>4. Open/short in power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse (No. 11, located in fuse block [J/B]), 40A fusible link (letter f, located in fuse and fusible link box) and M21 circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminal 1 of power window main switch and terminal 5 of sub-switch.</li> <li>2. Check grounds M4 and M77.</li> <li>3. Check power window relay.</li> <li>4. Check W wire between power window relay and power window main switch for open/short circuit.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> </ol>
Passenger power window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switches</li> <li>2. Passenger side power window regulators</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check passenger side power window regulator.</li> <li>3. Check power window main switch.</li> <li>4. Check the following. <ol style="list-style-type: none"> <li>a. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>b. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol> </li> </ol>
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# POWER DOOR LOCK

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0106



SEL353V

## System Description

NAEL0107

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to smart entrance control unit terminal 1.

Ground is supplied to smart entrance control unit terminal 10 through body grounds M4 and M77.

### INPUT

When the door lock & unlock switch LH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal 18
- through door lock & unlock switch LH terminal 7
- to door lock & unlock switch LH terminal 3
- through body grounds M4 and M77.

When the door lock & unlock switch RH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal 18
- through door lock & unlock switch RH terminal 3
- to door lock & unlock switch RH terminal 2
- through body grounds M4 and M66.

When the door lock & unlock switch LH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal 19
- through door lock & unlock switch LH terminal 14
- to door lock & unlock switch LH terminal 3
- through body grounds M4 and M77.

When the door lock & unlock switch RH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal 19
- through door lock & unlock switch RH terminal 1
- to door lock & unlock switch RH terminal 2
- through body grounds M4 and M66.

NAEL0107S01

## OUTPUT

### Unlock

NAEL0107S02

GI

NAEL0107S0201

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

NAEL0107S0202

BR

ST

RS

BT

HA

SC

EL

IDX

Ground is supplied

- to front door lock actuator LH terminal 3
- to front door lock actuator RH terminal 3
- to rear door lock actuator LH terminal 3
- to rear door lock actuator RH terminal 3
- to back door lock actuator terminal 2
- through smart entrance control unit terminal 4.

### FRONT DOOR LH

Power is supplied

- to front door lock actuator LH terminal 1
- through smart entrance control unit terminal 3.

### FRONT DOOR RH

Power is supplied

- to front door lock actuator RH terminal 1,
- through smart entrance control unit terminal 2.

### REAR DOOR LH

Power is supplied

- to rear door lock actuator LH terminal 1
- through smart entrance control unit terminal 2.

### REAR DOOR RH

Power is supplied

- to rear door lock actuator RH terminal 1
- through smart entrance control unit terminal 2.

### BACK DOOR

Power is supplied

- to back door lock actuator terminal 1
- through smart entrance control unit terminal 2.

Then, the doors are unlocked.

### Lock

Ground is supplied

- to front door lock actuator LH terminal 1
- through smart entrance control unit terminal 3, and
- to front door lock actuator RH terminal 1
- to rear door lock actuator LH terminal 1
- to rear door lock actuator RH terminal 1
- to back door lock actuator 1
- through smart entrance control unit terminal 2.

Power is supplied

- to front door lock actuator LH terminal 3,
- to front door lock actuator RH terminal 3,
- to rear door lock actuator LH terminal 3
- to rear door lock actuator RH terminal 3
- to back door lock terminal 2
- through smart entrance control unit terminal 4.


Then, the doors are locked.

# POWER DOOR LOCK

Schematic

## Schematic

NAEL0108



MEL804G




# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 2


NAEL0109S02

EL-D/LOCK-02



Refer to last page (Foldout page).

(M2), (B1)









# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 3

NAEL0109S03

EL-D/LOCK-03



CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL3661

# POWER DOOR LOCK


Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0110

NAEL0110S01

REFERENCE PAGE (EL- )	176	177	178
SYMPTOM	Main power supply and ground circuit check	Door lock/unlock switch check	Door lock actuator check
None of the doors lock/unlock when operating both door lock/unlock switch.	X		X
One or more doors are not locked and/or unlocked.			X
LH or RH lock/unlock switch does not operate.		X	




### MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main Power Supply Circuit Check

NAEL0110S02

NAEL0110S0201

Terminal		Ignition switch		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage



### Ground Circuit Check

NAEL0110S0202

Terminals	Continuity
10 - Ground	Yes

## DOOR LOCK/UNLOCK SWITCH CHECK

-NAEL0110S03

CI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

**1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL**

1. Disconnect control unit connector.
2. Check continuity between control unit terminal 18 or 19 and ground.

Terminals	Door lock/unlock switch (LH or RH) condition	Continuity
18 - ground	Lock	Yes
	N and Unlock	No
19 - ground	Unlock	Yes
	N and Lock	No

MTBL0005

Smart entrance control unit connector (M16)

DISCONNECT H.S. OFF

Refer to wiring diagram in EL-173.

SEL785UB

**OK or NG**

OK	▶	Door lock/unlock switch is OK.
NG	▶	GO TO 2.

**2 CHECK DOOR LOCK/UNLOCK SWITCH**

1. Disconnect door lock/unlock switch connector.
2. Check continuity between each door lock/unlock switch terminals.

- Power window main switch (Door lock/unlock switch driver side)

Condition	Terminals		
	3	14	7
Lock	○	○	○
N	No continuity		
Unlock	○	○	○

MTBL0045

Door lock/unlock switch driver side

DISCONNECT T.S.

P/W main switch connector (D6)

- Door lock/unlock switch passenger side

Condition	Terminals		
	1	2	3
Lock	○	○	○
N	No continuity		
Unlock	○	○	○

MTBL0046

Door lock/unlock switch passenger side

DISCONNECT T.S.

Door lock/unlock switch passenger side connector (D38)

**OK or NG**

OK	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>• Ground circuit for door lock/unlock switch</li> <li>• Harness for open or short between door lock/unlock switch and control unit connector</li> </ul>
NG	▶	Replace door lock/unlock switch.

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## DOOR LOCK ACTUATOR CHECK

-NAEL0110S04

1	CHECK DOOR LOCK ACTUATOR CIRCUIT													
<p>Check voltage for door lock actuator.</p> <ul style="list-style-type: none"> <li>Door lock actuator front LH</li> </ul>														
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Door lock/unlock switch condition</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage (V)</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td>4</td> <td>ground</td> <td rowspan="2">Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>3</td> <td>ground</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0006</p>		Door lock/unlock switch condition	Terminal No.		Voltage (V)	(+)	(-)	Lock	4	ground	Approx. 12	Unlock	3	ground
Door lock/unlock switch condition	Terminal No.		Voltage (V)											
	(+)	(-)												
Lock	4	ground	Approx. 12											
Unlock	3	ground												
<p style="text-align: right;">SEL786U</p>														
<ul style="list-style-type: none"> <li>Door lock actuator front RH, rear and back</li> </ul>														
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Door lock/unlock switch condition</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage (V)</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td>4</td> <td>ground</td> <td rowspan="2">Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>2</td> <td>ground</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0007</p>		Door lock/unlock switch condition	Terminal No.		Voltage (V)	(+)	(-)	Lock	4	ground	Approx. 12	Unlock	2	ground
Door lock/unlock switch condition	Terminal No.		Voltage (V)											
	(+)	(-)												
Lock	4	ground	Approx. 12											
Unlock	2	ground												
<p style="text-align: right;">SEL787UB</p>														
<p>Refer to wiring diagram in EL-174.</p> <p style="text-align: center;"><b>OK or NG</b></p>														
OK	▶	GO TO 2.												
NG	▶	Replace smart entrance control unit. (Before replacing control unit, perform "DOOR LOCK/UNLOCK SWITCH CHECK".)												


2	CHECK DOOR LOCK ACTUATOR	
<ol style="list-style-type: none"> <li>Disconnect door lock actuator connector.</li> <li>Apply 12V direct current to door lock actuator and check operation.</li> </ol>		
<ul style="list-style-type: none"> <li>Door lock actuator operation:                     <ul style="list-style-type: none"> <li>Terminals between (+): 3 and (-): 1 Unlocked → Locked</li> <li>Terminals between (+): 1 and (-): 3 Locked → Unlocked</li> </ul> </li> </ul>		
<p style="text-align: right;">SEL736U</p>		
<ul style="list-style-type: none"> <li>Back door lock actuator operation:                     <ul style="list-style-type: none"> <li>Terminals between (+): 2 and (-): 1 Unlocked → Locked</li> <li>Terminals between (+): 1 and (-): 2 Locked → Unlocked</li> </ul> </li> </ul>		
<p style="text-align: right;">SEL737U</p>		
<p><b>OK or NG</b></p>		
OK	▶	Check harness for open or short between control unit connector and door lock actuator.
NG	▶	Replace door lock actuator.

# MULTI-REMOTE CONTROL SYSTEM

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0111



SEL303V

## System Description

### INPUTS

Power is supplied at all times

- to key switch terminal 1
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 24.

When the front door switch LH is OPEN, ground is supplied

- to smart entrance control unit terminal 15
- through front door switch LH terminal 1
- to front door switch LH terminal 2
- through body grounds B11, B22 and D210.

When the each door switch is OPEN, ground is supplied

- to smart entrance control unit terminal 16
- through each door switch body ground or B11, B22 and D210.

When the front door lock actuator LH (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal 12
- through door lock actuator LH (door unlock sensor) terminal 4
- to door lock actuator LH (door unlock sensor) terminal 2

NAEL0112

NAEL0112501

GI  
MA  
EW  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# MULTI-REMOTE CONTROL SYSTEM

## System Description (Cont'd)

- through body grounds M4 and M77.

When the front door lock actuator RH (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 13 in the same manner as front door lock actuator LH.

When the rear or back door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 14 in the same manner as other door lock actuator.

Remote controller signal input

- through antenna
- to smart entrance control unit terminal 37.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard reminder

## OPERATED PROCEDURE

### Power Door Lock Operation

NAEL0112S02

NAEL0112S0201

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder)
- door switch CLOSED (when all the doors are closed)

The two above signals are already input into smart entrance control unit. At this point, smart entrance control unit receives a LOCK signal from remote controller. Smart entrance control unit locks all doors with input of LOCK signal from remote controller.

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from remote controller again within 5 seconds, all other door will be unlocked.

### Hazard Reminder

NAEL0112S0204

Power is supplied at all times

- to multi-remote control relay terminal 1
- through 15A fuse [No. 20, located in the fuse block (J/B)].

When smart entrance control unit receives a LOCK signal from remote controller, ground is supplied

- to multi-remote control relay terminal 2
- through smart entrance control unit terminal 7.

Multi-remote control relays are now energized, and hazard warning lamp flash twice as a reminder. For detailed description, refer to "TURN SIGNAL AND HAZARD WARNING LAMPS" (EL-42).

### Interior Lamp Operation

NAEL0112S0202

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder)
- door switch CLOSED (when all the doors are closed)

Multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

For detailed description, refer to "INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS" (EL-53).

### Panic Alarm Operation

NAEL0112S0203

When key switch is OFF (when ignition key is not inserted in key cylinder), multi-remote control system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from remote controller.


For detailed description, refer to "THEFT WARNING SYSTEM" (EL-197).

# MULTI-REMOTE CONTROL SYSTEM

Schematic

## Schematic

NAEL0113



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IX

MEL3861

# MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —


## Wiring Diagram — MULTI —

NAEL0114




NAEL0114S01

EL-MULTI-01

FIG. 1



Refer to last page (Foldout page).






# MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 2





NAEL0114502

EL-MULTI-02



Refer to last page (Foldout page).

(M2), (B1)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL809G



# MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

NAEL0114503

EL-MULTI-03

FIG. 3



Refer to last page (Foldout page).

M2, B1




# MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 4

NAEL0114S04

EL-MULTI-04



Refer to last page (Foldout page).

M1, E1  
M10

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL627H

# MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0115

NAEL0115S01

Symptom	Diagnoses/service procedure	Reference page (EL- )
All function of multi-remote control system do not operate.	1. Remote controller battery check	187
	2. Multi-remote control antenna check	187
	3. Key switch (insert) check	190
	4. Door switch check	189
	5. Power supply and ground circuit for control unit check	188
	6. Replace remote controller. Refer to ID Code Entry Procedure.	194
The new ID of remote controller cannot entered.	1. Remote controller battery check	187
	2. Multi-remote control antenna check	187
	3. Key switch (insert) check	190
	4. Door switch check	189
	5. Door unlock sensor check	191
	6. Power supply and ground circuit for control unit check	188
	7. Replace remote controller. Refer to ID Code Entry Procedure.	194
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to EL-176.)	1. Key switch (insert) input signal check	190
	2. Door switch check	189
	3. Door unlock sensor check	191
	4. Replace remote controller. Refer to ID Code Entry Procedure.	194
Hazard indicator does not flash twice when pressing lock button of remote controller.	1. Harzard reminder check	192
	2. Replace remote controller. Refer to ID Code Entry Procedure.	194
Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller.	1. Interior room lamp operation check	193
	2. Replace remote controller. Refer to ID Code Entry Procedure.	194
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed more than 1.5 seconds.	1. Theft warning operation check. Refer to "PRELIMINALY CHECK" in "THEFT WARNING SYSTEM".	208
	2. Replace remote controller. Refer to ID Code Entry Procedure.	194


### NOTE:

- The unlock and panic alarm operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
- The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder or if one of the doors is opened.

## REMOTE CONTROLLER BATTERY CHECK


=NAEL0115S02


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK REMOTE CONTROLLER BATTERY</b>
<p>Remove battery (refer to EL-195) and measure voltage across battery positive and negative terminals, (+) and (-).  <b>Voltage [V]:</b>                  2.5 - 3.0</p> <p>NOTE:                  Remote controller does not function if battery is not set correctly.</p>	
	
SEL277V	
<b>OK or NG</b>	
OK	▶ Check remote controller battery terminals for corrosion or damage.
NG	▶ Replace battery.

## MULTI-REMOTE CONTROL ANTENNA CHECK

NAEL0115S03

<b>1</b>	<b>CHECK ANTENNA FEEDER CABLE</b>
<ol style="list-style-type: none"> <li>1. Disconnect feeder cable connector from control unit.</li> <li>2. Remove LH rear pillar garnish and disconnect feeder cable connector from antenna.</li> <li>3. Check continuity between the feeder cable connectors. <b>Continuity should exist.</b></li> <li>4. Check continuity between the feeder cable connector terminal 37 and body ground. <b>Continuity should not exist.</b></li> </ol>	
	
MEL040GB	
<b>OK or NG</b>	
OK	▶ GO TO 2.
NG	▶ Replace feeder cable.

<b>2</b>	<b>CHECK ANTENNA</b>
<ol style="list-style-type: none"> <li>1. Remove rear pillar garnish and disconnect feeder cable connector from antenna.</li> <li>2. Visually check film antenna.</li> </ol>	
	
SEL712U	
<b>OK or NG</b>	
OK	▶ Antenna of multi-remote control is OK.
NG	▶ Replace antenna.

# MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

## POWER SUPPLY AND GROUND CIRCUIT CHECK

-NAEL0115S04

<b>1</b>	<b>CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT</b>
<p>1. Disconnect connector from control unit. 2. Check voltage between control unit terminal 1 and ground.</p>	
SEL744U	
Refer to wiring diagram in EL-182.	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 2.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 40A fusible link (letter f, located in fuse and fusible link box)</li> <li>● M21 circuit breaker</li> <li>● Harness for open or short between control unit and circuit breaker</li> </ul>

<b>2</b>	<b>CHECK IGNITION SWITCH "ACC" CIRCUIT</b>
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 17 and ground while ignition switch is "ACC".</p>	
MEL245H	
Refer to wiring diagram in EL-182.	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 3.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 10A fuse [No. 10, located in fuse block (J/B)]</li> <li>● Harness for open or short between control unit and fuse</li> </ul>

<b>3</b>	<b>CHECK GROUND CIRCUIT FOR CONTROL UNIT</b>
Check continuity between terminal 10 and ground.	
SEL363TB	
Refer to wiring diagram in EL-182.	
<b>Does continuity exist?</b>	
Yes	▶ Power supply and ground circuits are OK.
No	▶ Check ground harness.

## DOOR SWITCH CHECK

-NAEL0115S05

1
CHECK DOOR SWITCH INPUT SIGNAL

Check voltage between control unit terminals 15 or 16 and ground.

	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door switch	15	ground	Open	0
			Closed	Approx. 12
All door switches	16	ground	Open	0
			Closed	Approx. 12

MTBL0069

Smart entrance control unit connector (M16)

C/U CONNECTOR

15 16

G/R R/L

V

SEL606U

Refer to wiring diagram in EL-183.

OK or NG

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

2
CHECK DOOR SWITCH

1. Disconnect door switch connector.
2. Check continuity between door switch terminals.

	Terminals	Condition	Continuity
Front LH door switch	1 - 2, 3 - ground	Closed	No
		Open	Yes
Back door switch	2 - 1	Closed	No
		Open	Yes
Rear and front RH door switch	1 - ground	Closed	No
		Open	Yes

MTBL0070

DISCONNECT

T.S. E

Door switch LH connector (B9)

3 1 2

SEL607U

DISCONNECT

T.S. E

Back door switch (D208)

2 1

SEL607U

DISCONNECT

T.S. E

Door switch connector

Front RH : (B68)

Rear LH : (B18)

Rear RH : (B71)

1

SEL607U

OK or NG

OK	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>Door switch ground circuit (Front LH, back door) or door switch ground condition</li> <li>Harness for open or short between control unit and door switch</li> </ul>
NG	▶	Replace door switch.

GI  
 MA  
 EV  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IX

# MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

## KEY SWITCH (INSERT) CHECK

=NAEL0115S07

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>
<p>Check voltage between control unit terminal 24 and ground.  <b>Voltage [V]:</b>  <b>Condition of key switch: Key is inserted.</b>                      Approx. 12  <b>Condition of key switch: Key is withdrawn.</b>                      0</p> <p>Smart entrance control unit connector (M18)</p> <p style="text-align: right;">SEL234V</p>	
Refer to wiring diagram in EL-182.	
<b>OK or NG</b>	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK KEY SWITCH (INSERT)</b>
<p>Check continuity between terminals 1 and 2.  <b>Continuity:</b>  <b>Condition of key switch: Key is inserted.</b>                      Yes  <b>Condition of key switch: Key is withdrawn.</b>                      No</p> <p>Key switch connector (E5)</p> <p style="text-align: right;">SEL249V</p>	
<b>OK or NG</b>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between control unit and key switch</li> </ul>
NG	▶ Replace key switch.



## DOOR UNLOCK SENSOR CHECK

-NAEL0115S06

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK DOOR UNLOCK SENSOR INPUT SIGNAL</b>
----------	--

Check voltage between control unit terminals 12, 13 or 14 and ground.

	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door	12	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	13	Ground	Locked	Approx. 12
			Unlocked	0
Rear and back door	14	Ground	Locked	Approx. 12
			Unlocked	0

MTBL0071

Smart entrance control unit connector (M16)

C/U CONNECTOR

12 13 14

Y/G Y/L V/R

V

CONNECT

DISCONNECT

OFF

SEL246V

Refer to wiring diagram in EL-184.

**OK or NG**

OK	▶	Door unlock sensor is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK DOOR UNLOCK SENSOR</b>
----------	---------------------------------

1. Disconnect door unlock sensor connector.
2. Check continuity between door unlock sensor terminals.

**Continuity:**

**Condition: Locked**  
No

**Condition: Unlocked**  
Yes

Door lock actuator connectors  
 Front LH : (D7)    Rear LH : (D54)  
 Front RH : (D37)    Rear RH : (D74)

SEL247V

Back door lock actuator connector (D207)

SEL352V

**OK or NG**

OK	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>• Door unlock sensor ground circuit</li> <li>• Harness for open or short between control unit and door unlock sensor</li> </ul>
NG	▶	Replace door unlock sensor.

# MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

## HAZARD REMINDER CHECK

=NACLO115G08

<b>1</b>	<b>CHECK HAZARD INDICATOR</b>
Check if hazard indicator flashes with hazard switch.	
<b>Does hazard indicator operate?</b>	
Yes	▶ GO TO 2.
No	▶ Check "hazard indicator" circuit.

<b>2</b>	<b>CHECK HAZARD REMINDER OPERATION</b>
1. Disconnect control unit connector. 2. Apply ground to control unit terminal 7.	
<p style="text-align: right;">SEL243V</p>	
Refer to wiring diagram in EL-185.	
<b>Does hazard indicator illuminate?</b>	
Yes	▶ Hazard reminder is OK.
No	▶ GO TO 3.

<b>3</b>	<b>CHECK MULTI-REMOTE CONTROL RELAY</b>
Check multi-remote control relay.	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ Replace.

<b>4</b>	<b>CHECK POWER SUPPLY FOR MULTI-REMOTE CONTROL RELAY</b>
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminal 1 and ground.	
<p style="text-align: right;">SEL244V</p>	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 5.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• 15A fuse [No. 20, located in fuse block (J/B)]</li> <li>• Harness for open or short between multi-remote control relay and fuse</li> </ul>

<b>5</b>	<b>CHECK MULTI-REMOTE CONTROL RELAY CIRCUIT</b>
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminals 3 and 5. <b>Battery voltage should exist.</b> 3. Check voltage between terminals 6 and 7. <b>Battery voltage should exist.</b>	
<p style="text-align: right;">SEL245V</p>	
<b>OK or NG</b>	
OK	▶ Check harness for open or short between control unit and multi-remote control relay.
NG	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• Harness for open or short between multi-remote control relay and fuse</li> <li>• Harness for open or short between multi-remote control relay and turn signal lamps</li> </ul>

## INTERIOR ROOM LAMP OPERATION CHECK

-NAEL0115S09

<b>1</b>	<b>CHECK INTERIOR ROOM LAMP</b>	
Check if the interior room lamp switch is in the "DOOR" position and the lamp illuminates when a door is open.		
<b>Does interior room lamp illuminate?</b>		
Yes	▶	GO TO 2.
No	▶	Check "Interior room lamp" circuit.

<b>2</b>	<b>CHECK INTERIOR ROOM LAMP CIRCUIT</b>	
When interior room lamp switch is "DOOR" position, check voltage across control unit terminal 9 and ground.		
Refer to wiring diagram in EL-182.		
<b>Does battery voltage exist?</b>		
Yes	▶	GO TO 3.
No	▶	Repair harness between control unit and interior room lamp.

<b>3</b>	<b>CHECK CONTROL UNIT OUTPUT</b>	
Push unlock button of remote controller and check voltage across control unit terminal 9 and ground.		
<b>Voltage [V]:</b>		
Unlock button is pushed. 0 (For approx. 30 seconds.)		
Unlock button is not pushed. Battery voltage		
<b>OK or NG</b>		
OK	▶	Check system again.
NG	▶	Replace smart entrance control unit.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# MULTI-REMOTE CONTROL SYSTEM

## ID Code Entry Procedure

Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

To enter the ID code, follow the procedures below.



### NOTE:

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.


# MULTI-REMOTE CONTROL SYSTEM

Remote Controller Battery Replacement

## Remote Controller Battery Replacement


NAEL0118

1.




Open the lid using a coin.

2.




Remove the battery.

3.



Insert the new battery.  
Recommended battery: CR2025 or equivalent.

4.



Close the lid securely.

SEL126V

GI

MA

EM

LG

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

# THEFT WARNING SYSTEM

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0119



SEL302V



# THEFT WARNING SYSTEM

## System Description (Cont'd)

---

- to smart entrance control unit terminal 1.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 17.

Ground is supplied

- to smart entrance control unit terminal 10
- through body grounds M4 and M77.

### INITIAL CONDITION TO ACTIVATE THE SYSTEM

NAEL0120S02

The operation of the theft warning system is controlled by the doors, hood and glass hatch.

To activate the theft warning system, the smart entrance control unit must receive signals indicating the doors, hood and glass hatch are closed and the doors are locked.

When a door is open, smart entrance control unit terminal 15 or 16 receives a ground signal from each door switch.

When a door is unlocked, smart entrance control unit terminal 12, 13 or 14 receives a ground signal from terminal 4 of each door unlock sensor or terminal 3 of back door unlock sensor.

When the hood is open, smart entrance control unit terminal 29 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E13 and E41.

When the glass hatch is open, smart entrance control unit terminal 26 receives a ground signal

- from terminal 1 of the glass hatch switch
- through body grounds D210, B11 and B22.

When the doors are locked with key or multi-remote controller and none of the described conditions exist, the theft warning system will automatically shift to armed phase.

### THEFT WARNING SYSTEM ACTIVATION (WITH KEY OR REMOTE CONTROLLER USED TO LOCK DOORS)

NAEL0120S03

If the key is used to lock doors, terminal 30 receives a ground signal

- from terminal 3 of the key cylinder switch LH
- from terminal 1 of the door key cylinder switch RH
- through body grounds M4 and M77 or M4 and M66
- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

If this signal or lock signal from remote controller is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal 33 supplies ground to terminal 2 of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

### THEFT WARNING SYSTEM ALARM OPERATION

NAEL0120S04

The theft warning system is triggered by

- opening a door without using the key
- opening the hood or the glass hatch
- unlocking door.

Once the theft warning system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 12, 13, 14 (door unlock sensor), 15, 16 (door switch), 26 (glass hatch switch) or 29 (hood switch), the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

Power is supplied at all times

- through 10A fuse [No. 18, located in the fuse block (J/B)].
- to theft warning relay terminal 1.

If the theft warning system is triggered, ground is supplied

- from terminal 32 of the smart entrance control unit
- to theft warning relay terminal 2.



# THEFT WARNING SYSTEM

System Description (Cont'd)

With power and ground supplied, starter motor circuit is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 7.5A fuse (No. 52, located in fuse and fusible link box)
- to theft warning lamp relay terminal 1 and
- to theft warning horn relay terminal 1.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal 8 of the smart entrance control unit
- to theft warning lamp relay terminal 2 and
- to theft warning horn relay terminal 2.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

## THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door, the back door or the glass hatch must be unlocked with the key or remote controller.

When the key is used to unlock the door, smart entrance control unit terminal 31 receives a ground signal

- from terminal 1 of the LH key cylinder switch
- from terminal 3 of the RH key cylinder switch
- from terminal 2 of the back door key cylinder switch.

When the key is used to open the glass hatch, smart entrance control unit terminal 27 receives a ground signal from terminal 3 of the back door key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

## PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required. When the multi-remote control system is triggered, ground is supplied intermittently.

- from smart entrance control unit terminal 8
- to theft warning lamp relay terminal 2 and
- to theft warning horn relay terminal 2.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# THEFT WARNING SYSTEM

Schematic

## Schematic


MAEL0121



MEL628H

# THEFT WARNING SYSTEM

Schematic (Cont'd)









# THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

**FIG. 3**

NAEL0122503

**EL-THEFT-03**



Refer to last page (Foldout page).

(M2), (B1)

MEL3681











# THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

**FIG. 4**

NAEL0122S04

## EL-THEFT-04



Refer to last page (Foldout page).



MEL817G


# THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

**FIG. 5**

NAEL0122S05

**EL-THEFT-05**



Refer to EL-POWER.

⬡ M : With M/T  
⬡ A : With A/T


Next page

Next page

Refer to last page (Foldout page).

⬡ M1   ⬡ E1  
⬡ E3

24	25	26	27	28	29	30	31	32	33	34	35	36	6	7	8	9	10	⬡ M16 W
11	12	13	14	15	16	17	18	19	20	21	22	23	1	2	3	4	5	









# THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

FIG. 6

NAEL0122506

EL-THEFT-06



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
ID

MEL6111


# THEFT WARNING SYSTEM

## Trouble Diagnoses PRELIMINARY CHECK

NAEL0123

NAEL0123S01

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



MEL447H

After performing preliminary check, go to symptom chart in next page.

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

## SYMPTOM CHART

NAEL0123502

REFERENCE PAGE (EL- )	208	210	211	214	215	216	217	218	219	220	186
SYMPTOM	PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND GLASS HATCH SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR UNLOCK SENSOR CHECK	DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	THEFT WARNING HORN ALARM CHECK	THEFT WARNING HEADLAMP ALARM CHECK	STARTER INTERRUPT SYSTEM CHECK	Check "MULTI-REMOTE CONTROL" system.
1	X	X		X							
2	X	X	X		X						
	X	X				X					
	X	X					X				
	X	X									X
3	X	X	X								
	X	X			X						
4	X	X	X		X						
	X	X						X			
	X	X							X		
	X	X									X
5	X	X				X					
	X	X					X				
	X	X									X

X : Applicable


\*1: Make sure the system is in the armed phase.

**Before starting trouble diagnoses above, perform preliminary check, EL-208.**

Symptom numbers in the symptom chart correspond with those of preliminary check.

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




## POWER SUPPLY AND GROUND CIRCUIT CHECK

NAEL0123S03

### Power Supply Circuit Check

NAEL0123S0301

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage
11	Ground	0V	0V	Battery voltage
17	Ground	0V	Battery voltage	Battery voltage



### Ground Circuit Check

NAEL0123S0302

Terminals	Continuity
10 - Ground	Yes

## DOOR, HOOD AND GLASS HATCH SWITCH CHECK

-NAEL0123S04

### Door Switch Check

NAEL0123S0401

<b>1</b>	<b>PRELIMINARY CHECK</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF" and remove key from key cylinder.</li> <li>2. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off.</li> <li>3. Open any passenger door or back door. "SECURITY" indicator lamp should blink every second.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Door switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK DOOR SWITCH INPUT SIGNAL</b>																					
<p>Check voltage between control unit terminals 15 or 16 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">15</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">All door switches</td> <td rowspan="2">16</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 50px;">MTBL0069</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 50px;">SEL606U</p> <p>Refer to wiring diagram in EL-203.</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door switch	15	ground	Open	0	Closed	Approx. 12	All door switches	16	ground	Open	0	Closed	Approx. 12
	Terminals		Condition	Voltage [V]																		
	(+)	(-)																				
Front LH door switch	15	ground	Open	0																		
			Closed	Approx. 12																		
All door switches	16	ground	Open	0																		
			Closed	Approx. 12																		
OK	▶ Door switch is OK.																					
NG	▶ GO TO 3.																					

<b>3</b>	<b>CHECK DOOR SWITCH</b>																						
<ol style="list-style-type: none"> <li>1. Disconnect door switch connector.</li> <li>2. Check continuity between door switch terminals.</li> </ol>																							
<table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">1 - 2, 3 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Back door switch</td> <td rowspan="2">2 - 1</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Rear and front RH door switch</td> <td rowspan="2">1 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 50px;">MTBL0070</p> <div style="margin: 10px 0;"> </div> <div style="margin: 10px 0;"> </div> <div style="margin: 10px 0;"> </div> <p style="text-align: right; margin-right: 50px;">SEL607U</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminals	Condition	Continuity	Front LH door switch	1 - 2, 3 - ground	Closed	No	Open	Yes	Back door switch	2 - 1	Closed	No	Open	Yes	Rear and front RH door switch	1 - ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity																				
Front LH door switch	1 - 2, 3 - ground	Closed	No																				
		Open	Yes																				
Back door switch	2 - 1	Closed	No																				
		Open	Yes																				
Rear and front RH door switch	1 - ground	Closed	No																				
		Open	Yes																				
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• Door switch ground circuit (Front LH, back door) or door switch ground condition</li> <li>• Harness for open or short between control unit and door switch</li> </ul>																						
NG	▶ Replace door switch.																						

# THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)


## Hood Switch Check

=NAEL0123S0402

<b>1</b>	<b>PRELIMINARY CHECK</b>
1. Turn ignition switch "OFF" and remove key from key cylinder. 2. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off. 3. Open hood. "SECURITY" indicator lamp should blink every second. <p style="text-align: center;">OK or NG</p>	
OK	▶ Hood switch is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK HOOD SWITCH FITTING CONDITION</b>
OK or NG	
OK	▶ GO TO 3.
NG	▶ Adjust installation of hood switch or hood.

<b>3</b>	<b>CHECK HOOD SWITCH INPUT SIGNAL</b>
Check voltage between control unit terminal 29 and ground. <b>Voltage [V]:</b> Hood is open. 0 Hood is closed. Approx. 12 <div style="text-align: center;">  <p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>29</p> <p>Y/B</p> <p>V</p> </div> <p style="text-align: right;">SEL608U</p> <p>Refer to wiring diagram in EL-202.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Hood switch is OK.
NG	▶ GO TO 4.

<b>4</b>	<b>CHECK HOOD SWITCH</b>
1. Disconnect hood switch connector. 2. Check continuity between hood switch terminals 1 and 2. <b>Continuity:</b> Condition: Pushed No Condition: Released Yes <div style="text-align: center;">  <p>Hood switch connector (E31)</p> <p>DISCONNECT</p> <p>1 2</p> <p>T.S.</p> <p>Ω</p> </div> <p style="text-align: right;">SEL397TB</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• Hood switch ground circuit</li> <li>• Harness for open or short between control unit and hood switch</li> </ul>
NG	▶ Replace hood switch.

## Glass Hatch Switch Check

-NAEL012350403

<b>1</b>	<b>PRELIMINARY CHECK</b>	<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF" and remove key from key cylinder.</li> <li>2. Close all doors, hood and glass hatch. "SECURITY" indicator lamp should turn off.</li> <li>3. Open glass hatch. "SECURITY" indicator lamp should blink every second.</li> </ol> <p style="text-align: center;">OK or NG</p>
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK GLASS HATCH SWITCH INPUT SIGNAL</b>	<p>Check voltage between control unit terminal 26 and ground.</p> <p><b>Voltage [V]:</b></p> <p><b>Glass hatch is open.</b> Approx. 0</p> <p><b>Glass hatch is closed.</b> Approx. 12</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL622U</p> <p>Refer to wiring diagram in EL-202.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 3.

<b>3</b>	<b>CHECK GLASS HATCH SWITCH</b>	<ol style="list-style-type: none"> <li>1. Disconnect glass hatch switch connector.</li> <li>2. Check continuity between glass hatch switch terminals 1 and 2.</li> </ol> <p><b>Continuity:</b></p> <p><b>Condition: Closed</b> No</p> <p><b>Condition: Open</b> Yes</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL609U</p> <p style="text-align: center;">OK or NG</p>
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• Glass hatch switch ground circuit</li> <li>• Harness for open or short between control unit and glass hatch switch</li> </ul>
NG	▶	Replace glass hatch switch.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

## SECURITY INDICATOR LAMP CHECK

-NAEL0123S05

<b>1</b>	<b>CHECK INDICATOR LAMP OUTPUT SIGNAL</b>
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 33 and ground.</p>	
SEL250V	
<p>Refer to wiring diagram in EL-202.</p> <p style="text-align: center;"><b>Does battery voltage exist?</b></p>	
Yes	▶ Security indicator lamp is OK.
No	▶ GO TO 2.

<b>2</b>	<b>CHECK INDICATOR LAMP</b>
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Replace indicator lamp.

<b>3</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP</b>
<p>1. Disconnect security lamp connector. 2. Check voltage between indicator lamp terminal 1 and ground.</p>	
SEL251V	
<b>Does battery voltage exist?</b>	
Yes	▶ Check harness for open or short between security indicator lamp and control unit.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between security indicator lamp and fuse</li> </ul>



## DOOR UNLOCK SENSOR CHECK

=NAEL0123S06

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK DOOR UNLOCK SENSOR INPUT SIGNAL</b>			
Check voltage between control unit terminals 12, 13 or 14 and ground.				
	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door	12	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	13	Ground	Locked	Approx. 12
			Unlocked	0
Rear and back door	14	Ground	Locked	Approx. 12
			Unlocked	0

MTBL0071

Smart entrance control unit connector (M16)

C/U CONNECTOR

12 13 14

Y/G Y/L Y/R

V

CONNECT

H.S.

E

SEL246V

Refer to wiring diagram in EL-204.

**OK or NG**

OK	▶	Door unlock sensor is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK DOOR UNLOCK SENSOR</b>			
1. Disconnect door unlock sensor connector.				
2. Check continuity between door unlock sensor terminals.				
<b>Continuity:</b>				
<b>Condition: Locked</b>				
No				
<b>Condition: Unlocked</b>				
Yes				
Door lock actuator connectors				
Front LH : (D7)    Rear LH : (D54)				
Front RH : (D37)    Rear RH : (D74)				
SEL247V				
Back door lock actuator connector (D207)				
SEL352V				
<b>OK or NG</b>				
OK	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>Door unlock sensor ground circuit</li> <li>Harness for open or short between control unit and door unlock sensor</li> </ul>		
NG	▶	Replace door unlock sensor.		

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

## DOOR KEY CYLINDER SWITCH CHECK

-NAEL0123507

<b>1</b>	<b>CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)</b>																		
Check voltage between control unit terminals 30 or 31 and ground.																			
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">30</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Lock</td> <td>0</td> </tr> <tr> <td rowspan="2">31</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>0</td> </tr> </tbody> </table>		Terminals		Key position	Voltage [V]	(+)	(-)	30	Ground	Neutral	Approx. 12	Lock	0	31	Ground	Neutral	Approx. 12	Unlock	0
Terminals		Key position	Voltage [V]																
(+)	(-)																		
30	Ground	Neutral	Approx. 12																
		Lock	0																
31	Ground	Neutral	Approx. 12																
		Unlock	0																
MTBL0041																			
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>30 31 LG</p> <p>V</p> <p>Neutral</p> <p>Lock Unlock</p> <p>Driver's side</p> <p>Neutral</p> <p>Unlock Lock</p> <p>Passenger side</p>																			
SEL614UB																			
Refer to wiring diagram in EL-205.																			
<b>OK or NG</b>																			
OK	▶ Door key cylinder switch is OK.																		
NG	▶ GO TO 2.																		

<b>2</b>	<b>CHECK DOOR KEY CYLINDER SWITCH</b>															
<ol style="list-style-type: none"> <li>Disconnect door key cylinder switch connector.</li> <li>Check continuity between door key cylinder switch terminals.</li> </ol>																
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>LH: 3 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>RH: 1 - 2</td> <td>Lock</td> <td>Yes</td> </tr> <tr> <td>LH: 1 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>RH: 3 - 2</td> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table>		Terminals	Key position	Continuity	LH: 3 - 2	Neutral	No	RH: 1 - 2	Lock	Yes	LH: 1 - 2	Neutral	No	RH: 3 - 2	Unlock	Yes
Terminals	Key position	Continuity														
LH: 3 - 2	Neutral	No														
RH: 1 - 2	Lock	Yes														
LH: 1 - 2	Neutral	No														
RH: 3 - 2	Unlock	Yes														
MTBL0042																
<p>DISCONNECT</p> <p>T.S.</p> <p>Door key cylinder switch connector</p> <p>LH : (D9) RH : (D39)</p> <p>3 2 1</p> <p>Ω</p>																
<ol style="list-style-type: none"> <li>Door unlock switch terminal (LH) Door lock switch terminal (RH)</li> <li>Ground terminal</li> <li>Door lock switch terminal (LH) Door unlock switch terminal (RH)</li> </ol>																
SEL880U																
<b>OK or NG</b>																
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>Door key cylinder switch ground circuit</li> <li>Harness for open or short between control unit and door key cylinder switch</li> </ul>															
NG	▶ Replace door key cylinder switch.															

## BACK DOOR KEY CYLINDER SWITCH CHECK

=NAEL0123S08

<b>1</b>	<b>CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)</b>																																	
<p>Check voltage between control unit terminals 30, 31 or 27 and ground.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="4" style="text-align: center;">Back door</td> <td rowspan="2" style="text-align: center;">30</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between neutral and lock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">31</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between neutral and unlock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">Glass hatch</td> <td rowspan="2" style="text-align: center;">27</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Between lock and unlock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 5px;">MTBL0016</p> <div style="text-align: center; margin-top: 20px;"> <p style="margin-top: 10px;">Smart entrance control unit connector (M16)</p> </div> <p style="text-align: right; margin-top: 10px;">MEL101GA</p> <p>Refer to wiring diagram in EL-205.</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>Back door key cylinder switch is OK.</td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>GO TO 2.</td> </tr> </table>			Terminals		Key position	Voltage [V]	(+)	(-)	Back door	30	Ground	Neutral	Approx. 12	Between neutral and lock	0	31	Ground	Neutral	Approx. 12	Between neutral and unlock	0	Glass hatch	27	Ground	Neutral	Approx. 12	Between lock and unlock	0	OK	▶	Back door key cylinder switch is OK.	NG	▶	GO TO 2.
	Terminals		Key position	Voltage [V]																														
	(+)	(-)																																
Back door	30	Ground	Neutral	Approx. 12																														
			Between neutral and lock	0																														
	31	Ground	Neutral	Approx. 12																														
			Between neutral and unlock	0																														
Glass hatch	27	Ground	Neutral	Approx. 12																														
			Between lock and unlock	0																														
OK	▶	Back door key cylinder switch is OK.																																
NG	▶	GO TO 2.																																

<b>2</b>	<b>CHECK BACK DOOR KEY CYLINDER SWITCH</b>																														
<p>1. Disconnect back door key cylinder switch connector.</p> <p>2. Check continuity between back door key cylinder switch terminals.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="4">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">Between lock (Back door) and unlock (glass hatch)</td> <td></td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 5px;">MTBL0043</p> <div style="text-align: center; margin-top: 20px;"> <p style="margin-top: 10px;">Back door key cylinder switch (D201)</p> <p style="text-align: right; margin-top: 10px;">SEL616U</p> </div> <div style="text-align: center; margin-top: 20px;"> <p style="margin-top: 10px;">Back door key cylinder switch (D201)</p> <p style="text-align: right; margin-top: 10px;">SEL613U</p> </div> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 15%; text-align: center;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td> <p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Back door key cylinder switch ground circuit</li> <li>● Harness for open or short between control unit and back door key cylinder switch</li> </ul> </td> </tr> <tr> <td style="text-align: center;">NG</td> <td style="text-align: center;">▶</td> <td>Replace back door key cylinder switch.</td> </tr> </table>		Key position	Terminals				1	2	3	4	Between neutral and lock (Back door)	○			○	Between neutral and unlock (Back door)		○		○	Between lock (Back door) and unlock (glass hatch)			○	○	OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Back door key cylinder switch ground circuit</li> <li>● Harness for open or short between control unit and back door key cylinder switch</li> </ul>	NG	▶	Replace back door key cylinder switch.
Key position	Terminals																														
	1	2	3	4																											
Between neutral and lock (Back door)	○			○																											
Between neutral and unlock (Back door)		○		○																											
Between lock (Back door) and unlock (glass hatch)			○	○																											
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Back door key cylinder switch ground circuit</li> <li>● Harness for open or short between control unit and back door key cylinder switch</li> </ul>																													
NG	▶	Replace back door key cylinder switch.																													

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

## THEFT WARNING HORN ALARM CHECK

-NAEL0123609

<b>1</b>	<b>CHECK THEFT WARNING HORN ALARM OPERATION</b>
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 8.</p>	
<p>Smart entrance control unit connector (M16)</p>	
SEL529UA	
Refer to wiring diagram in EL-206.	
<b>Does horn alarm activate?</b>	
Yes	▶ Horn alarm is OK.
No	▶ GO TO 2.

<b>2</b>	<b>CHECK THEFT WARNING HORN RELAY</b>
Check theft warning horn relay.	
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Replace.

<b>3</b>	<b>CHECK POWER SUPPLY FOR THEFT WARNING HORN RELAY</b>
<p>1. Disconnect theft warning horn relay connector. 2. Check voltage between terminal 1 and ground.</p>	
<p>Theft warning horn relay connector (E23)</p>	
SEL755UB	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 4.
No	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>• 7.5A fuse (No. 52, located in the fuse and fusible link box)</li> <li>• Harness for open or short between theft warning horn relay and fuse</li> </ul>

<b>4</b>	<b>CHECK THEFT WARNING HORN RELAY CIRCUIT</b>
<p>1. Disconnect theft warning horn relay connector. 2. Check voltage between terminals 3 and 5. <b>Battery voltage should exist.</b> 3. Check voltage between terminals 6 and 7. <b>Battery voltage should exist.</b></p>	
<p>Theft warning horn relay connector (E23)</p>	
SEL756UB	
<b>OK or NG</b>	
OK	▶ Check harness for open or short between theft warning horn relay and control unit.
NG	▶ Check harness for open or short.

## THEFT WARNING HEADLAMP ALARM CHECK

-NAEL0123S10

<b>1</b>	<b>CHECK THEFT WARNING HEADLAMP ALARM OPERATION</b>
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 8.</p>	
<p>Smart entrance control unit connector (M16)</p> <p>C/U CONNECTOR</p> <p>Y/G</p> <p>8</p>	
SEL529UA	
<b>Does headlamp alarm activate?</b>	
Yes	▶ Headlamp alarm is OK.
No	▶ GO TO 2.

<b>2</b>	<b>CHECK HEADLAMP OPERATION</b>
<b>Does headlamp come on when turning lighting switch "ON"?</b>	
Yes	▶ GO TO 3.
No	▶ Check headlamp system. Refer to "HEADLAMP".

<b>3</b>	<b>CHECK THEFT WARNING LAMP RELAY</b>
Check theft warning lamp relay.	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ Replace.

<b>4</b>	<b>CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY</b>
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminal 1 and ground.</p>	
<p>Theft warning lamp relay connector (E18)</p> <p>G/B</p> <p>1</p> <p>V</p>	
SEL757U	
<b>Does battery voltage exist?</b>	
Yes	▶ GO TO 5.
No	▶ <b>Check the following.</b>
<ul style="list-style-type: none"> <li>• 7.5A fuse (No. 52, located in the fuse and fusible link box)</li> <li>• Harness for open or short between theft warning lamp relay and fuse</li> </ul>	

<b>5</b>	<b>CHECK THEFT WARNING LAMP RELAY CIRCUIT</b>
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminals 3 and 5. <b>Battery voltage should exist.</b> 3. Check voltage between terminals 6 and 7. <b>Battery voltage should exist.</b></p>	
<p>Theft warning lamp relay connector (E18)</p> <p>R/L</p> <p>R/W</p> <p>5</p> <p>3</p> <p>6</p> <p>7</p> <p>R</p> <p>R/Y</p> <p>V</p> <p>V</p>	
SEL758U	
<b>OK or NG</b>	
OK	▶ Check harness for open or short between theft warning lamp relay and control unit.
NG	▶ <b>Check the following.</b>
<ul style="list-style-type: none"> <li>• Harness for open or short between fuse and theft warning lamp relay</li> <li>• Harness for open or short between theft warning lamp relay and headlamps</li> </ul>	


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

## STARTER INTERRUPT SYSTEM CHECK

-NAEL0123S11

<b>1</b>	<b>CHECK STARTER MOTOR INTERRUPT SIGNAL</b>
<p>1. Turn ignition switch "ON".</p> <p>2. Check voltage between control unit terminal 32 and ground.</p> <p><b>Voltage [V]:</b>                  Except starter interrupted phase                  Approx. 12                  Starter interrupted phase                  0</p>  <p style="text-align: right;">SEL624U</p> <p>Refer to wiring diagram in EL-206.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 2.
NG	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 10A fuse [No. 18, located in fuse block (J/B)]</li> <li>● Harness for open or short between theft warning relay and fuse</li> <li>● Harness for open or short between control unit and theft warning relay</li> </ul>

<b>2</b>	<b>CHECK THEFT WARNING RELAY</b>
<p>Check theft warning relay.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Check system again.
NG	▶ Replace relay.

# SMART ENTRANCE CONTROL UNIT

Description

## Description

NAEL0124

The following systems are controlled by the smart entrance control unit.

- Warning chime
- Rear window defogger timer
- Power door lock
- Multi-remote control system
- Theft warning system

For detailed description and wiring diagrams, refer to the relevant pages for the each system.

The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.

System	Input	Output
Power door lock	Door lock and unlock switch	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switch Door unlock sensor Antenna (remote controller signal)	Theft warning horn relay Theft warning lamp relay Interior lamp Multi-remote control relay Door lock actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch Front door switch LH	Warning chime
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Theft warning	Ignition switch (ACC, ON) Door switch Hood switch Glass hatch switch Door key cylinder switch (lock/unlock) Back door key cylinder switch (lock/unlock/glass hatch unlock) Door unlock sensor	Theft warning horn relay Theft warning lamp relay Theft warning relay (Starter interrupt) Security indicator

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# SMART ENTRANCE CONTROL UNIT

Schematic

NAEL0125

## Schematic




SMART ENTRANCE CONTROL UNIT

MEL631H



# SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL632H

# SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

## Smart Entrance Control Unit Inspection Table

NAEL0125

Terminal No.	Connections	Operated condition	Voltage (Approximate values)
1	Power source (C/B)	—	12V
2	Passenger door lock actuator	Door lock & unlock switch	Unlocked
3	Driver door lock actuator		Free
4	Driver and passenger door lock actuators	Door lock & unlock switch	Locked
			Free
7	Multi-remote control relay	When doors are locked using remote controller	12V → 0V
8	Theft warning horn/lamp relay	When panic alarm is operated using remote controller	12V → 0V
9	Interior lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V
10	Ground	—	—
11	Ignition switch (ON)	Ignition key is in "ON" position	12V
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V
14	Rear and back door unlock sensors	All doors are locked → One or more doors are unlocked	12V → 0V
15	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V
16	Passenger door switch	OFF (Closed) → ON (Open)	12V → 0V
17	Ignition switch (ACC)	"ACC" position	12V
18	Door lock & unlock switches	Neutral → Locks	12V → 0V
19	Door lock & unlock switches	Neutral → Unlocks	12V → 0V
20	Rear window defogger switch	OFF → ON	12V → 0V
21	Seat belt buckle switch	Unfasten → Fasten (Ignition key is in "ON" position)	0V → 12V
23	Warning chime	OFF → ON	12V → 0V
24	Ignition key switch (Insert)	Key inserted → Key removed from IGN key cylinder	12V → 0V
25	Lighting switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V
26	Glass hatch switch	ON (Open) → OFF (Closed)	0V → 12V
27	Back door key unlock switch	OFF (Neutral) → ON (Unlock)	12V → 0V
29	Hood switch	ON (Open) → OFF (Closed)	0V → 12V
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	12V → 0V
31	Door key cylinder lock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
32	Theft warning relay (Starter cut)	OFF → ON (Ignition key is in "ON" position)	12V → 0V
33	Theft warning indicator	Goes off → Illuminates	12V → 0V
36	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)	12V → 0V
37	Multi-remote control antenna	—	—



# INTEGRATED HOMELINK TRANSMITTER

Wiring Diagram — TRNSMT —

## Wiring Diagram — TRNSMT —

NAEL0127

### EL-TRNSMT-01



Refer to last page (Foldout page).

M10

MEL4711

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTEGRATED HOMELINK TRANSMITTER

## Trouble Diagnoses DIAGNOSTIC PROCEDURE

NAFI 0128  
NAELO128S01

**SYMPTOM: Transmitter does not activate receiver.**

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

1 PRELIMINARY CHECK	
1. Turn ignition switch "OFF". 2. Does red light (LED) of transmitter illuminate when any button is pressed?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2 CHECK TRANSMITTER FUNCTION	
Check transmitter with Tool. For details, refer to Technical Service Bulletin.	
OK or NG	
OK	▶ Receiver or handheld transmitter fault, not vehicle related.
NG	▶ Replace transmitter with sun visor assembly.

3 CHECK POWER SUPPLY	
1. Disconnect transmitter connector. 2. Turn ignition switch "OFF". 3. Check voltage between terminal 1 and body ground.	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check fuse (7.5A) and repair harness.




4 CHECK GROUND CIRCUIT	
Check continuity between terminal 2 and ground.	
Does continuity exist?	
Yes	▶ Replace transmitter with sun visor assembly.
No	▶ Repair harness.

# ELECTRICAL UNITS LOCATION

Engine Compartment

## Engine Compartment

NAEL0129



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

MEL3901



IDX

# ELECTRICAL UNITS LOCATION

Passenger Compartment

## Passenger Compartment


NAEL0130



MEL781H

# ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


MEL782H

# HARNES LAYOUT

How to Read Harness Layout

## How to Read Harness Layout

NAEL0131



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

### TO USE THE GRID REFERENCE

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

NAEL0131S01

### CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

NAEL0131S02

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> <li>• Cavity: Less than 4</li> <li>• Relay connector</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: From 5 to 8</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: More than 9</li> </ul>	—	—		
<ul style="list-style-type: none"> <li>• Ground terminal etc.</li> </ul>	—			




# HARNESS LAYOUT

Outline

## Outline

NAEL0132



MEL856F


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Main Harness

## Main Harness

NAEL0133






# HARNESS LAYOUT

Main Harness (Cont'd)

B4★	M1	SMJ	To E1	D1	M41	B/16	A/C auto amp. (For auto A/C)	A3	M81	B/2	Fuse block (J/B)
B4★	M2	SMJ	To B1	D1	M42	W/4	Recirculation switch	D2	M90	W/2	Diode
B4	M3	B/20	ASCD control unit	E1	M43	W/6	Fan switch	B3	M91	W/12	Fuse block (J/B)
A3	M4	—	Body ground	E1	M44	W/3	A/C switch	D4	M92	B/2	CD player
B4	M5	W/16	To D3	E1	M45	W/3	A/C switch illumination	D2	M93	W/4	CD player
A3	M6	W/10	To D4	E1	M46	BR/4	PTC	D3★	M94	W/18	To F27
A3	M7	W/2	Diode	E1	M47	W/12	To Z1	D4	M95	—	Body ground (For ABS)
B2	M8	BR/2	Tweeter LH	E3	M48	W/10	Audio	A4	M97	BR/4	To D11
C4	M9	GY/16	Data link connector for GST	G3	M49	W/6	Audio	G2	M101	BR/6	To D45
B3★	M10	SMJ	Fuse block (J/B)	E4	M50	W/12	Rear wiper switch	A3	M102	W/2	Diode
C4	M11	GY/14	Data link connector for CONSULT	E4	M52	L/4	Heated seat switch LH				
B3★	M12	SB/6	Diode	F4	M53	W/4	Heated seat switch RH				
B4★	M13	SMJ	TCM (Transmission control module)	E4	M54	SMJ	ABS control unit				
B4	M14	L/2	ASCD clutch switch	E3	M55	B/6	Air mix door motor				
C3	M15	B/3	Combination flasher unit	F4	M56	B/2	Cigarette lighter socket				
C2	M16	W/36	Smart entrance control unit	F4	M57	W/2	Cigarette lighter illumination				
C3	M17	GY/12	Door mirror remote control switch	E1	M58	B/2	Sunload sensor				
C4	M18	W/6	ASCD main switch	G2	M59	W/4	Intake door motor				
C4	M19	W/3	Illumination control switch	F2	M60	W/4	Fan control amp. (For auto A/C)				
C3	M20	W/4	Security indicator lamp (With theft warning system)	G3	M61	BR/4	Fan resistor				
B2	M21	W/2	Circuit breaker-1	F1	M62	W/6	To R1				
B2	M22	W/2	Circuit breaker-2 (With power seat)	F1	M63	W/6	To R2				
B2	M23	L/4	Power window relay	F1	M64	BR/2	Tweeter RH				
D1★	M24	W/16	Combination meter	F2	M65	W/2	Diode				
D1★	M25	W/14	Combination meter	G2	M66	—	Body ground				
D1	M26	BR/16	Combination meter	F2	M67	W/12	To D33				
C1	M27	W/3	Warning chime	F2	M68	W/6	To D34				
C3	M28	L/2	Clutch interlock switch (For M/T model)	F3	M69	W/3	Power antenna				
C3	M29	L/2	ASCD brake switch	F3★	M70	W/20	To B50				
C3	M31	B/2	Stop lamp switch	F3★	M71	W/24	To B51				
D3★	M32	W/24	To F23	F3★	M72	W/16	To B52				
D3★	M33	GY/16	To F22	G3	M73	W/2	Blower motor				
D3	M34	W/2	In-vehicle sensor (With auto A/C)	D5	M74	B/8	ABS relay unit				
D2	M35	W/8	Hazard switch	D5	M75	GY/8	ABS actuator				
D3	M36	W/6	Rear window defogger switch	C5	M76	B/2	ABS relay unit				
D4	M37	GY/6	Joint connector	C5	M77	—	Body ground				
E2	M38	BR/4	A/C mode switch	C5	M78	W/6	Front wiper motor				
F2	M40	B/12	A/C auto amp. } (For auto A/C)	C5	M79	B/8	Front wiper amp.				

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.

Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
FA  
SC  
EL  
IDX


MEL636H

# HARNESS LAYOUT

Engine Room Harness

## Engine Room Harness

NAEL0134




MEL637H

# HARNESS LAYOUT

Engine Room Harness (Cont'd)

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



F2	E28	GY/2	: Brake fluid level switch
E4	E29	B/3	: Headlamp LH
D5	E30	GY/2	: Front turn signal lamp LH
D3	E31	GY/2	: Hood switch
C3	E32	B/2	: Ambient sensor (With auto A/C)
C4	E33	B/2	: Ambient air temperature sensor (For thermometer)
C4	E34	GY/2	: Ambient air temperature switch
C3	E35	B/1	: Horn (High)
B3	E36	B/1	: Horn (Low)
B3	E37	B/2	: Dual-pressure switch
A3	E38	B/3	: Headlamp RH
A4	E39	GY/2	: Front turn signal lamp RH
A2	E40	GY/2	: Parking lamp RH
A2	E41	—	: Body ground
B4	E42	BR/2	: Washer level switch
B4	E43	GY/2	: Rear washer motor
B4	E44	GY/2	: Front washer motor
B2	E46	GY/8	: Daytime light control unit
A2	E46	GY/6	: Daytime light control unit
B1	E47	GY/2	: Dropping resistor
B1	E48	GY/4	: To (E102)
C2	E49	GY/1	: To (E104)
B2	E50	B/1	: Theft warning horn
C3	E51	GY/2	: Front wheel sensor RH
D2	E52	B/1	: Battery
C2	E53	B/1	: Battery
B1	E54	L/4	: Fuel pump relay
B1	E55	L/4	: Clutch interlock relay (With M/T)
B1	E56	GY/6	: Park/Neutral position relay (With A/T and ASCD)
A1	E57	BR/6	: ECCS relay
B1	E58	L/4	: Inhibitor relay (With A/T and without ASCD)
C2	E59	GY/4	: ASCD pump
C1	E60	—	: Fuse and fusible link box
D5	E61	BR/2	: Front fog lamp LH
B4	E62	BR/2	: Front fog lamp RH
	E63	W/3	: Front fog lamp switch
E3	E88	GY/3	: Absolute pressure sensor
E3	E90	B/2	: MAP/BARO switch solenoid valve

★	E1	SMJ	: To (MT)
	E2	B/2	: Fuse block (J/B)
	E3	W/16	: Fuse block (J/B)
	E4	W/4	: Fuse block (J/B)
	E5	W/2	: Key switch
★	E6	W/6	: Ignition switch
	E7	BR/4	: Combination switch (Lighting switch)
	E8	BR/8	: Combination switch (Lighting & turn signal switch)
	E9	GY/8	: Combination switch (Front wiper switch)
★	E11	GY/2	: Intake air temperature sensor
E4	E12	GY/2	: Parking lamp LH
E3	E13	—	: Body ground
F4	E14	BR/2	: Front wheel sensor LH
E1	E16	L/4	: Front fog lamp relay
E1	E17	BR/6	: Multi-remote control relay
E1	E18	BR/6	: Theft warning lamp relay
F1	E20	B/5	: Theft warning relay
D1	E21	L/4	: Power socket relay
E1	E22	BR/6	: ASCD hold relay (With A/T)
E1	E23	BR/6	: Theft warning horn relay
E1	E24	B/5	: ATP relay
F1	E25	W/3	: Horn relay
F1	E26	L/4	: A/C relay
E1	E27	L/4	: ASCD hold relay (With M/T)

MEL638H


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Engine Control Harness


## Engine Control Harness

NAELQ135



MEL639H

D1★	(F1)	GY/4	: Rear heated oxygen sensor RH
D1★	(F2)	GY/3	: Front heated oxygen sensor RH
D1★	(F3)	GY/4	: Rear heated oxygen sensor LH
D1★	(F4)	GY/3	: Front heated oxygen sensor LH
C2★	(F5)	GY/8	: To (F100)
C3★	(F6)	B/8	: To (F101)
C4★	(F7)	GY/6	: Distributor
E4★	(F8)	BR/3	: Throttle position sensor
F4★	(F9)	GY/3	: Throttle position switch
E3★	(F10)	BR/4	: Mass air flow sensor
C4★	(F11)	GY/2	: Distributor
C4★	(F12)	GY/2	: EGR temperature sensor
D5	(F14)	GY/2	: To (F200)
E4★	(F15)	G/2	: EGRC-solenoid valve
C3	(F17)	B/1	: Thermal transmitter
E1★	(F18)	GY/2	: Resistor
E1★	(F20)	—	: Engine ground
F3	(F21)	L/12	: Joint connector
F2★	(F22)	GY/16	: To (M33)
F2★	(F23)	W/24	: To (M32)
F2★	(F24)	SMJ	: ECM (ECCS control module)
E1★	(F25)	—	: Engine ground
F3	(F26)	W/2	: Diode
F2★	(F27)	W/18	: To (M94)
C2★	(F28)	B/4	: To (F113)
C2★	(F100)	GY/8	: To (F5)
C2★	(F101)	B/8	: To (F6)
E2★	(F102)	B/2	: Knock sensor
C3★	(F103)	B/2	: Injector No. 1
C4★	(F104)	B/2	: Injector No. 2
C3★	(F105)	B/2	: Injector No. 3
F4★	(F106)	B/2	: Injector No. 4
E2★	(F107)	B/2	: Injector No. 5
F3★	(F108)	B/2	: Injector No. 6
F2★	(F109)	BR/2	: IACV-AAC valve
F3★	(F110)	GY/2	: Crankshaft position sensor (OBD)
F3	(F111)	GY/2	: IACV-FICD solenoid valve
D3	(F112)	GY/2	: Engine coolant temperature sensor
C2	(F113)	B/4	: To (F28)
E3	(F114)	L/2	: EVAP canister purge control solenoid valve
D5	(F200)	GY/2	: To (F14)
E4	(F201)	B/1	: Oil pressure switch
D4	(F202)	B/1	: Compressor (Air conditioner)



★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
SC  
BT  
HA  
SC  
EL  
IDX





## Body Harness RH

NAE1 0137



- ★ (B50) W/20 : To (M70)
- ★ (B51) W/24 : To (M71)
- ★ (B52) W/16 : To (M72)
- ★ (B55) — : Body ground
- (B56) W/3 : Heated seat RH
- (B57) W/2 : Power seat RH
- (B58) GY/2 : G sensor (For 4WD model with ABS)
- (B59) W/6 : A/T device
- (B60) W/2 : Ashtray (With M/T)
- ★ (B61) B/6 : To (B200) (With M/T)
- (B62) B/4 : To (B201) (With A/T and 4-wheel drive)
- ★ (B63) GY/2 : Vehicle speed sensor
- ★ (B64) BR/8 : Terminal cord assembly
- ★ (B65) GY/8 : Inhibitor switch
- ★ (B66) GY/2 : Inhibitor switch
- ★ (B67) GY/3 : Revolution sensor
- (B68) BR/1 : Front door switch RH
- (B69) GY/2 : Rear wheel sensor RH
- (B70) W/10 : To (D70)
- (B71) BR/1 : Rear door switch RH
- (B72) GY/2 : To (B300)
- (B74) W/6 : Rear combination lamp RH
- ★ (B75) — : Body ground
- (B76) W/3 : Ashtray (With A/T)
- (B81) GY/2 : G sensor (For 4WD model with ABS)
- (B300) GY/2 : To (B72)
- (B301) B/3 : Tire carrier switch

(A/T model)

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Back Door Harness

## Back Door Harness

NAEL0138



- D300 : To D107
- D301 : To D108
- D302 : High-mounted stop lamp
- D303 : Rear window defogger
- D304 : Rear window defogger
- D305 : Body ground

- D201 : Back door key cylinder switch
- D202 : License plate lamp LH (Without spare tire carrier)
- D203 : License plate lamp (With spare tire carrier)
- D204 : To D104
- D205 : To D105
- D206 : To D106
- D207 : Back door lock actuator
- D208 : Back door switch
- D209 : Glass hatch switch
- D210 : Body ground
- D211 : License plate lamp RH (Without spare tire carrier)
- D212 : Rear wiper motor

- D100 : W/12 : To B23
- D101 : W/6 : To B24
- D102 : W/4 : To B25
- D103 : W/3 : Luggage room lamp
- D104 : W/8 : To D204
- D105 : W/12 : To D205
- D106 : W/4 : To D206
- D107 : W/2 : To D300
- D108 : W/1 : To D301

MEL830G



# HARNESS LAYOUT

Engine and Transmission Harness

## Engine and Transmission Harness

NAEL0139

- ★ **B200** : To **B61** (With M/T)
- B201** : To **B62** (With A/T)
- B202** : Back-up lamp switch (With M/T)
- ★ **B203** : Neutral position switch (With A/T)
- B204** : Neutral position switch (With 4-wheel drive)
- B205** : 4WD switch (With 4-wheel drive)



Body ground

- E100** : Battery
- E101** : Body ground
- E102** : To **E48**
- E103** : Fuse and fusible link box
- E104** : To **E49**
- E105** : Alternator
- E106** : Alternator
- E107** : Alternator
- E108** : Starter motor
- E109** : Starter motor
- E110** : Power steering oil pressure switch

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNES LAYOUT

Room Lamp

## Room Lamp


NAEL0140



MEL866FB

## Air Bag Harness

NAEL0141



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT


Front Door Harness

NAEL0142

## Front Door Harness


### LH side

- D1** GY/5 : Door mirror defogger LH
- D2** BR/3 : Door mirror LH
- D3** W/16 : To **M5**
- D4** W/10 : To **M6**
- D5** B/2 : Front power window regulator LH
- D6** W/16 : Power window main switch
- D7** GY/4 : Front door lock actuator LH
- D9** BR/3 : Front door key cylinder switch LH
- D10** BR/2 : Front door speaker LH  
(Except for BOSE system)
- D11** BR/4 : To **M97**
- D12** W/6 : Front door speaker LH  
(For BOSE system)



### RH side

- D31** GY/5 : Door mirror defogger RH
- D32** BR/3 : Door mirror RH
- D33** W/12 : To **M67**
- D34** W/6 : To **M68**
- D35** B/2 : Front power window regulator RH
- D36** W/8 : Front power window sub-switch
- D37** GY/4 : Front door lock actuator RH
- D38** W/3 : Door lock and unlock switch RH
- D39** BR/3 : Front door key cylinder switch RH
- D40** BR/2 : Front door speaker RH  
(Except for BOSE system)
- D42** W/6 : Front door speaker RH  
(For BOSE system)
- D45** BR/6 : To **M101**




MEL645H

## Rear Door Harness

NAEL0143


LH side



- (D50) W/10 : To (B10)
- (D51) B/2 : Rear power window regulator LH
- (D52) W/8 : Rear power window sub-switch LH
- (D53) BR/2 : Rear door speaker LH
- (D54) GY/4 : Rear door lock actuator LH

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

RH side



- (D70) W/10 : To (B70)
- (D71) B/2 : Rear power window regulator RH
- (D72) W/8 : Rear power window sub-switch RH
- (D73) BR/2 : Rear door speaker RH
- (D74) GY/4 : Rear door lock actuator RH

MEL646H

**BULB SPECIFICATIONS***Headlamp*

<b>Headlamp</b>	
<small>NAEL0144S03</small>	
Item	Wattage (W)
High/Low (Semi-sealed beam)	65/45 (HB1)

**Exterior Lamp**

<b>Exterior Lamp</b>		
<small>NAEL0144S01</small>		
Item	Wattage (W)	
Front fog lamp	55	
Front turn signal lamp	27	
Parking lamp	7	
Rear combination lamp	Turn signal lamp	27
	Stop/Tail lamp	27/8
Back-up lamp	27	
License plate lamp	10, 5 (With spare tire carrier)	
High-mounted stop lamp	5	

**Interior Lamp**

<b>Interior Lamp</b>	
<small>NAEL0144S02</small>	
Item	Wattage (W)
Interior lamp	10
Spot lamp	8
Luggage room lamp	10



# WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C, A	HA	Auto Air Conditioner
A/C, M	HA	Manual Air Conditioner
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device
AT/C	EC	A/T Control
ATDIAG	EC	A/T Diagnosis Communication Line
AUDIO	EL	Audio
BA/FIS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Solenoid Valve
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor (OBD)
CMPS	EC	Camshaft Position Sensor
COMPAS	EL	Compass and Thermometer
D/LOCK	EL	Power Door Lock
DEF	EL	Rear Window Defogger
DTRL	EL	Headlamp — With Daytime Light System —
ECTS	EC	Engine Coolant Temperature Sensor
EGR/TS	EC	EGR Temperature Sensor
EGRC/V	EC	EGRC-solenoid Valve
EGRC1	EC	EGR Function
ENGSS	AT	Engine Speed Signal
F/FOG	EL	Front Fog Lamp

Code	Section	Wiring Diagram Name
F/PUMP	EC	Fuel Pump Control
FICD	EC	IACV-FICD Solenoid Valve
FO2H-L	EC	Front Heated Oxygen Sensor Heater (Left Bank)
FO2H-R	EC	Front Heated Oxygen Sensor Heater (Right Bank)
FRO2LH	EC	Front Heated Oxygen Sensor (Front HO2S) (Left Bank)
FRO2RH	EC	Front Heated Oxygen Sensor (Front HO2S) (Right Bank)
FTS	AT	A/T Fluid Temperature Sensor
FUELLH	EC	Fuel Injection System Function (Left Bank)
FUELRH	EC	Fuel Injection System Function (Right Bank)
HEATER	HA	Heater System
H/LAMP	EL	Headlamp
HSEAT	EL	Heated Seat
HORN	EL	Horn
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INH/SW	AT	Inhibitor Switch
INJECT	EC	Injector
INT/L	EL	Interior, Spot, Vanity Mirror, and Luggage Room Lamps
KS	EC	Knock Sensor
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil, and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Door Mirror
MULTI	EL	Multi-remote Control System
NONDTC	AT	Non-detectable Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna

## WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PST/SW	EC	Power Steering Oil Pressure Switch
RO2H-L	EC	Rear Heated Oxygen Sensor Heater LH
RO2H-R	EC	Rear Heated Oxygen Sensor Heater RH
RRO2LH	EC	Rear Heated Oxygen Sensor LH
RRO2RH	EC	Rear Heated Oxygen Sensor RH
S/SIG	EC	Start Signal
SEAT	EL	Power Seat
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop lamp
SW/V	EC	MAP/BARO Switch Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock up)
TCV	AT	Torque Converter Clutch Solenoid Valve
TFTS	EC	Tank Fuel Temperature Sensor
THEFT	EL	Theft Warning System
TLID	EL	Glass Hatch Opener
TP/SW	EC	Throttle Position Switch
TPS	AT	Throttle Position Sensor
TPS	EC	Throttle Position Sensor
TRNSMT	EL	Integrated HOMELINK <sup>®</sup> Transmitter
TURN	EL	Turn Signal and Hazard Warning Lamps
VENT/V	EC	EVAP Canister Vent Control Valve
VSS	EC	Vehicle Speed Sensor

Code	Section	Wiring Diagram Name
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIP/R	EL	Rear Wiper and Washer
WIPER	EL	Front Wiper and Washer