

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

<p>PRECAUTIONS 4</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4</p> <p>Precautions When Using CONSULT-II 4</p> <p style="padding-left: 20px;">CHECK POINTS FOR USING CONSULT-II 4</p> <p>Precautions For Trouble Diagnosis 4</p> <p style="padding-left: 20px;">CAN SYSTEM 4</p> <p>Precautions For Harness Repair 5</p> <p style="padding-left: 20px;">CAN SYSTEM 5</p> <p>TROUBLE DIAGNOSES WORK FLOW 6</p> <p>When Displaying CAN Communication System Errors 6</p> <p style="padding-left: 20px;">WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM 6</p> <p style="padding-left: 20px;">WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM 6</p> <p style="padding-left: 20px;">TROUBLE DIAGNOSIS FLOW CHART 7</p> <p>Diagnosis Procedure 8</p> <p style="padding-left: 20px;">SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) 8</p> <p style="padding-left: 20px;">ACQUISITION OF DATA BY CONSULT-II 9</p> <p style="padding-left: 20px;">HOW TO USE CHECK SHEET TABLE 10</p> <p>CAN Diagnostic Support Monitor 17</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM 17</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM 18</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM 18</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TRANSFER CONTROL UNIT 19</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DRIVER SEAT CONTROL UNIT 20</p> <p style="padding-left: 20px;">DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND</p>	<p>ELECTRIC UNIT (CONTROL UNIT) 21</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R 22</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DISPLAY CONTROL UNIT 23</p> <p>CAN COMMUNICATION 24</p> <p style="padding-left: 20px;">System Description 24</p> <p style="padding-left: 20px;">CAN Communication Unit 24</p> <p style="padding-left: 40px;">TYPE 1/ TYPE 2/ TYPE 3/ TYPE 4 25</p> <p style="padding-left: 40px;">TYPE 5/ TYPE 6 28</p> <p style="padding-left: 40px;">TYPE 7/TYPE 8 31</p> <p>CAN SYSTEM (TYPE 1) 34</p> <p style="padding-left: 20px;">System Description 34</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 34</p> <p style="padding-left: 20px;">Schematic 35</p> <p style="padding-left: 20px;">Wiring Diagram - CAN - 36</p> <p style="padding-left: 20px;">CHECK SHEET 39</p> <p style="padding-left: 40px;">CHECK SHEET RESULTS (EXAMPLE) 41</p> <p style="padding-left: 20px;">Inspection Between TCM and Data Link Connector Circuit 51</p> <p style="padding-left: 20px;">Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit 52</p> <p style="padding-left: 20px;">ECM Circuit Inspection 53</p> <p style="padding-left: 20px;">TCM Circuit Inspection 54</p> <p style="padding-left: 20px;">Steering Angle Sensor Circuit Inspection 54</p> <p style="padding-left: 20px;">Data Link Connector Circuit Inspection 55</p> <p style="padding-left: 20px;">BCM Circuit Inspection 55</p> <p style="padding-left: 20px;">Combination Meter Circuit Inspection 56</p> <p style="padding-left: 20px;">ABS Actuator and Electric Unit (Control Unit) Circuit Inspection 56</p> <p style="padding-left: 20px;">IPDM E/R Circuit Inspection 57</p> <p style="padding-left: 20px;">CAN Communication Circuit Inspection 58</p> <p style="padding-left: 20px;">IPDM E/R Ignition Relay Circuit Inspection 62</p> <p>CAN SYSTEM (TYPE 2) 63</p> <p style="padding-left: 20px;">System Description 63</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 63</p> <p style="padding-left: 20px;">Schematic 64</p> <p style="padding-left: 20px;">Wiring Diagram - CAN - 65</p> <p style="padding-left: 20px;">CHECK SHEET 68</p>
---	--

F
G
H
I
J



L
M

CHECK SHEET RESULTS (EXAMPLE)	70	Combination Meter Circuit Inspection	151
Inspection Between TCM and Data Link Connector Circuit	80	Driver Seat Control Unit Circuit Inspection	152
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	81	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	152
ECM Circuit Inspection	82	IPDM E/R Circuit Inspection	153
TCM Circuit Inspection	83	CAN Communication Circuit Inspection	154
Steering Angle Sensor Circuit Inspection	83	IPDM E/R Ignition Relay Circuit Inspection	160
Data Link Connector Circuit Inspection	84	CAN SYSTEM (TYPE 5)	161
BCM Circuit Inspection	84	System Description	161
Combination Meter Circuit Inspection	85	Component Parts and Harness Connector Location	161
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	85	Schematic	162
IPDM E/R Circuit Inspection	86	Wiring Diagram - CAN -	163
CAN Communication Circuit Inspection	87	CHECK SHEET	166
IPDM E/R Ignition Relay Circuit Inspection	91	CHECK SHEET RESULTS (EXAMPLE)	168
CAN SYSTEM (TYPE 3)	92	Inspection Between TCM and Data Link Connector Circuit	179
System Description	92	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	180
Component Parts and Harness Connector Location	92	ECM Circuit Inspection	181
Schematic	93	TCM Circuit Inspection	182
Wiring Diagram - CAN -	94	Steering Angle Sensor Circuit Inspection	182
CHECK SHEET	97	Data Link Connector Circuit Inspection	183
CHECK SHEET RESULTS (EXAMPLE)	99	BCM Circuit Inspection	183
Inspection Between TCM and Data Link Connector Circuit	110	Combination Meter Circuit Inspection	184
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	111	Transfer Control Unit Circuit Inspection	184
ECM Circuit Inspection	112	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	185
TCM Circuit Inspection	113	IPDM E/R Circuit Inspection	185
Steering Angle Sensor Circuit Inspection	113	CAN Communication Circuit Inspection	186
Data Link Connector Circuit Inspection	114	IPDM E/R Ignition Relay Circuit Inspection	190
BCM Circuit Inspection	114	CAN SYSTEM (TYPE 6)	191
Combination Meter Circuit Inspection	115	System Description	191
Driver Seat Control Unit Circuit Inspection	115	Component Parts and Harness Connector Location	191
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	116	Schematic	192
IPDM E/R Circuit Inspection	116	Wiring Diagram - CAN -	193
CAN Communication Circuit Inspection	117	CHECK SHEET	196
IPDM E/R Ignition Relay Circuit Inspection	123	CHECK SHEET RESULTS (EXAMPLE)	198
CAN SYSTEM (TYPE 4)	124	Inspection Between TCM and Data Link Connector Circuit	209
System Description	124	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	210
Component Parts and Harness Connector Location	124	ECM Circuit Inspection	211
Schematic	125	TCM Circuit Inspection	212
Wiring Diagram - CAN -	126	Steering Angle Sensor Circuit Inspection	212
CHECK SHEET	129	Data Link Connector Circuit Inspection	213
CHECK SHEET RESULTS (EXAMPLE)	131	BCM Circuit Inspection	213
Inspection Between TCM and Display Control Unit Circuit	145	Combination Meter Circuit Inspection	214
Inspection Between Display Control Unit and Data Link Connector Circuit	147	Transfer Control Unit Circuit Inspection	214
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	147	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	215
ECM Circuit Inspection	148	IPDM E/R Circuit Inspection	215
TCM Circuit Inspection	148	CAN Communication Circuit Inspection	216
Display Control Unit Circuit Inspection	149	IPDM E/R Ignition Relay Circuit Inspection	221
Front Air Control Circuit Inspection	149	CAN SYSTEM (TYPE 7)	222
Steering Angle Sensor Circuit Inspection	150	System Description	222
Data Link Connector Circuit Inspection	150	Component Parts and Harness Connector Location	222
BCM Circuit Inspection	151	Schematic	223
		Wiring Diagram - CAN -	224
		CHECK SHEET	227

CHECK SHEET RESULTS (EXAMPLE)	229	CHECK SHEET	261	
Inspection Between TCM and Data Link Connector Circuit	241	CHECK SHEET RESULTS (EXAMPLE)	263	A
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ..	242	Inspection Between TCM and Display Control Unit Circuit	278	B
ECM Circuit Inspection	243	Inspection Between Display Control Unit and Data Link Connector Circuit	280	C
TCM Circuit Inspection	244	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ..	280	D
Steering Angle Sensor Circuit Inspection	244	ECM Circuit Inspection	281	E
Data Link Connector Circuit Inspection	245	TCM Circuit Inspection	281	F
BCM Circuit Inspection	245	Display Control Unit Circuit Inspection	282	G
Combination Meter Circuit Inspection	246	Front Air Control Circuit Inspection	282	H
Transfer Control Unit Circuit Inspection	246	Steering Angle Sensor Circuit Inspection	283	I
Driver Seat Control Unit Circuit Inspection	247	Data Link Connector Circuit Inspection	283	J
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	247	BCM Circuit Inspection	284	
IPDM E/R Circuit Inspection	248	Combination Meter Circuit Inspection	284	
CAN Communication Circuit Inspection	249	Transfer Control Unit Circuit Inspection	285	
IPDM E/R Ignition Relay Circuit Inspection	255	Driver Seat Control Unit Circuit Inspection	285	
CAN SYSTEM (TYPE 8)	256	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	286	
System Description	256	IPDM E/R Circuit Inspection	286	
Component Parts and Harness Connector Location	256	CAN Communication Circuit Inspection	287	
Schematic	257	IPDM E/R Ignition Relay Circuit Inspection	294	
Wiring Diagram - CAN -	258			

LAN

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS0017I

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS0017J

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM

UKS0017K

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


PRECAUTIONS

[CAN]


UKS0017L

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

PF0:00004

When Displaying CAN Communication System Errors

WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM


UKS003GH

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts : When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage : If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

TROUBLE DIAGNOSIS FLOW CHART



- Step 1 : Refer to [LAN-8, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2 : Refer to [LAN-9, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3 : Refer to [LAN-10, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4 : Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5 : Check and repair according to system diagnosis.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003G1

Diagnosis Procedure

SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Wagon/4WD (All-mode)/VQ40DE/AT/VDC/With automatic air conditioner/With automatic drive positioner/With navigation system

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Wagon							
Axle	2WD			4WD(Part time)		4WD(All-mode)		
Engine	VQ40DE							
Transmission	A/T							
Brake control	VDC							
Automatic air conditioner		x	x	x		x	x	x
Automatic drive positioner			x	x			x	x
Navigation system				x				x
CAN system type	1	2	3	4	5	6	7	8
CAN system trouble diagnosis	XXXX	XX:XX	XX:XX	XX:XX	X:XX	XX:XX	XX:XX	XX:XX

Check basic specification of the vehicle.

→ Select "x" if it is model with automatic air conditioner.

→ Select "x" if it is model with automatic drive positioner.

→ Select "x" if it is model with navigation system.

Which number is selected when sequentially selecting from the top of the specification table?
The number is "CAN system type" of the applicable vehicle.

x: Applicable

In the case of this example:
It corresponds to type 8.

SKIB3225E

TROUBLE DIAGNOSES WORK FLOW

[CAN]

ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.(For display control unit, transfer the data from the display screen of the vehicle to the CAN diagnosis support monitor check sheet [AV-139, "CAN Communication Line Check"](#) .)

Copy "SELECT SYSTEM" screen of CONSULT-II.

SELECT SYSTEM		SELECT SYSTEM	
ENGINE		AIR BAG	
A/T		IPDM E/R	
ABS		BCM	
AIR BAG		AUTO DRIVE POS.	
IPDM E/R		METER	
BCM		ALL MODE AWD/4WD	
Page Down		Page Up	
BACK	LIGHT	COPY	

AV section
Copy CAN diagnosis support monitor check sheet of CAN communication check.

Diagnosis Item	Screen display	Diagnosis Item	Screen display		
CANCOMM	OK	NG	CAN_CRIC_5	OK	UNKWN
CAN_CRIC_1	OK	UNKWN	CAN_CRIC_6	OK	UNKWN
CAN_CRIC_2	OK	UNKWN	CAN_CRIC_7	OK	UNKWN
CAN_CRIC_3	OK	UNKWN	CAN_CRIC_8	OK	UNKWN
CAN_CRIC_4	OK	UNKWN	CAN_CRIC_9	OK	UNKWN

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	ECM	TCM	Front air control	STRG	BCM	METER/M&A	AWD/4WD	ICCS	IPDM E/R		
ENGINE	---	NG	UNKWN	---	UNKWN	---	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1011)
A/T	---	NG	UNKWN	---	UNKWN	---	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	---	---
Display control unit	---	NG	UNKWN	---	UNKWN	---	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	---
BCM	---	No indicator	UNKWN	---	UNKWN	---	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	---	---
METER	---	No indicator	---	---	---	---	---	---	---	---	---	CAN COMM CIRCUIT (U1000)	---
ALL MODE AWD/4WD	---	No indicator	---	---	---	---	---	---	---	---	---	CAN COMM CIRCUIT (U1000)	---
AUTO DRIVE POS.	---	No indicator	---	---	---	---	---	---	---	---	---	CAN COMM CIRCUIT (U1000)	---
ABS	---	No indicator	---	---	---	---	---	---	---	---	---	CAN COMM CIRCUIT (U1000)	---
IPDM E/R	---	No indicator	---	---	---	---	---	---	---	---	---	CAN COMM CIRCUIT (U1000)	---

Symptoms :

Attach copy of SELECT SYSTEM

Attach copy of SELECT SYSTEM

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CRIC 5	METER&A
CAN CRIC 1	Transmit diagnosis	CAN CRIC 6	---
CAN CRIC 2	---	CAN CRIC 7	IPDM E/R
CAN CRIC 3	---	CAN CRIC 8	---
CAN CRIC 4	---	CAN CRIC 9	---

Attach copy of display control unit CAN DIAG SUPPORT MONITOR check sheet

Copy "SELF-DIAG RESULTS" screen of CONSULT-II.

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE	PRINT
MODE	BACK LIGHT COPY

Attach copy of ENGINE SELF-DIAG RESULTS

Attach copy of A/T SELF-DIAG RESULTS

Attach copy of BCM SELF-DIAG RESULTS

Attach copy of METER SELF-DIAG RESULTS

Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS

Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

Attach copy of IPDM E/R SELF-DIAG RESULTS

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT-II.

CAN DIAG SUPPORT MNTR		
ENGINE		
PRSN		
INITIAL DIAG	OK	
TRANSMIT DIAG	OK	
TCM	OK	
VDC/TCS/ABS	UNKWN	
METER&A	UNKWN	
ICC	UNKWN	
BCM/SEC	UNKWN	
IPDM E/R	UNKWN	
AWD/4WD	UNKWN	
PRINT		Scroll Down
MODE	BACK	LIGHT COPY

CAN DIAG SUPPORT MNTR		
ABS		
PRSN		
INITIAL DIAG	OK	
TRANSMIT DIAG	OK	
ECM	UNKWN	
TCM	UNKWN	
METER&A	UNKWN	
STRG	OK	
ICC	UNKWN	
AWD/4WD	OK	
PRINT		
MODE	BACK	LIGHT COPY

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of A/T CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR

Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

Attach copy of CAN DIAG SUPPORT MNTR

TROUBLE DIAGNOSES WORK FLOW

[CAN]

HOW TO USE CHECK SHEET TABLE

Use when the initial conditions are reproduced													Use when the initial conditions are not reproduced	
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

① ② ③ ④ ⑤

SK1B3227E

- Unit names displayed on CONSULT-II
- “No indication” : Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)
“—” : Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
- “NG” : Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.
“—” : Column not used (Initial diagnosis is not performed.)
- “UNKWN” : Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
- “UNKWN” : Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (It is not necessary for CAN communication trouble diagnosis.)

NOTE:

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#).
- when the initial conditions are not reproduced. Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Reproduced

The diagram illustrates the process of filling a check sheet table. It shows three 'CAN DIAG SUPPORT MNTR' screens, two 'SELECT SYSTEM' screens, and a 'Check sheet table'. Arrows indicate the flow of information from the support screens to the check sheet table.

CAN DIAG SUPPORT MNTR (ENGINE)

ENGINE	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	UNKWN
METER/M&A	UNKWN
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	UNKWN
AWD/4WD/e4WD	UNKWN
PRINT	Scroll Down
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR (A/T)

A/T	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	UNKWN
METER/M&A	UNKWN
ICC/e4WD	UNKWN
AWD/4WD	UNKWN
PRINT	
MODE	BACK LIGHT COPY

SELECT SYSTEM (ENGINE)

ENGINE	
A/T	
ABS	
AIR BAG	
IPDM E/R	
BCM	
Page Down	
BACK	LIGHT COPY

SELECT SYSTEM (AIR BAG)

AIR BAG	
IPDM E/R	
BCM	
AUTO DRIVE POS.	
METER	
ALL MODE AWD/4WD	
Page Up	
BACK	LIGHT COPY

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis													
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R					
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
METER	No indication	-	-	-	-	-	-	-	-	-	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ALL MODE AWD/4WD	No indication	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	-	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-

SKIB3228E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

NOTE:

Do not put a check mark on items in the column of "No indication" on the check sheet when displaying all items on "SELECT SYSTEM" screen.

- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

NOTE:

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "VDC/TCS/ABS", "METER/M&A", "ICC", "BCM/SEC", "IPDM E/R" and "AWD/4WD/e4WD". But put a check mark to "VDC/TCS/ABS", "METER/M&A", "BCM/SEC", "IPDM E/R" and "AWD/4WD/e4WD" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.


- Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "A/T" as well as "ENGINE". And then, put a check mark to the check sheet table.

NOTE:

- For "A/T", "UNKWN" is displayed on "VDC/TCS/ABS", "METER/M&A", "ICC/e4WD" and "AWD/4WD". But put a check mark to "VDC/TCS/ABS", "METER/M&A" and "AWD/4WD" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]




- Display control unit reads the CAN diagnosis support monitor check sheet (B) [AV-139, "CAN Communication Line Check"](#) transferred from the display screen (A). The transferred CAN diagnosis support monitor check sheet is copied to the Check sheet, and conversed according to the Display control unit Translation Sheet. And then put a check mark to the check sheet table.

NOTE:

In the CAN diagnosis support monitor check sheet (B), check marks are put to "CAN CIRC 3", "CAN CIRC 6", "CAN CIRC 8" and "CAN CIRC 9". But, in the column of the check sheet table indication in Display control unit Translation Sheet (C), "ECM" is listed only for "CAN CIRC 3". Therefore, put a check mark to "ECM" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]




5. Confirm the unit name that “UNKWN” is displayed on the copy of “CAN DIAG SUPPORT MNTR” screen of “BCM” and “ABS” as well as “ENGINE”. And then, put a check mark to the check sheet table.

NOTE:

- For “BCM”, “UNKWN” is displayed on “ECM”. Put a check mark to it.
- For “ALL MODE AWD/4WD”, “UNKWN” is displayed on “ECM” and “TCM”. Put a check mark to it.
- For “AUTO DRIVE POS.”, “UNKWN” is displayed on “TCM”. Put a check mark to it.
- For “ABS”, “UNKWN” is displayed on “ECM” and “TCM”. Put a check mark to it.
- For “IPDM E/R”, “UNKWN” is displayed on “ECM”. Put a check mark to it.

CAUTION:

“ALL MODE AWD/4WD” puts a check mark on the check sheet when “Present” is “UNKWN” and “Past” is “0”.



TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis													
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /eAWD	VDC/TC/ABS	IPDM E/R					
ENGINE	—	NG	UNKWVN	—	UNKWVN	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWVN	UNKWVN	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWVN	UNKWVN	—	UNKWVN	—	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWVN	—	UNKWVN	—	—	UNKWVN	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	


Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 1

Check harness between TCM and display control unit circuit.

Check sheet results (example)

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis													
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /eAWD	VDC/TC/ABS	IPDM E/R					
ENGINE	—	NG	UNKWVN	—	UNKWVN	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWVN	UNKWVN	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWVN	UNKWVN	—	UNKWVN	—	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	—	—	—	UNKWVN	—	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWVN	—	UNKWVN	—	—	UNKWVN	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	



SKIB3231E

NOTE:

There is a case that some of “CAN DIAG SUPPORT MNTR” and “SELF-DIAG RESULTS” are not needed for diagnosis. In the case, “UNKWVN” and “CAN COMM CIRCUIT(U1000)” in “Check sheet results (example)” change to “—”. Then, ignore check marks on the Check sheet table.

6. Perform system diagnosis for possible causes identified.
7. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-24, "CAN Communication Unit"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

<p>SYSTEM ENGINE</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>CAN COMM CIRCUIT [U1001] 1t</p>	<p>SYSTEM A/T</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS</p> <p>CAN COMM CIRCUIT [U1000]</p>	<p>SYSTEM BCM</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p>	<p>SYSTEM METER A/C AMP</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>CAN COMM CIRCUIT [U1000] 2</p>
<p>SYSTEM ALL MODE AWD/4WD</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS</p> <p>CAN COMM CIRCUIT [U1000]</p>	<p>SYSTEM AUTO DRIVE POS.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>CAN COMM CIRCUIT [U1000] PAST</p>	<p>SYSTEM ABS</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>CAN COMM CIRCUIT [U1000] 2</p>	<p>SYSTEM IPDM E/R</p> <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;">SELF-DIAG RESULTS</div> <p>DTC RESULTS TIME</p> <p>CAN COMM CIRCUIT [U1000] PAST</p>

SKIB3232E

- See “SELF-DIAG RESULTS” of all units attached to the check sheet. If “CAN COMM CIRCUIT”, “CAN COMM CIRCUIT [U1000]” or “CAN COMM CIRCUIT [U1001]” is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

NOTE:

- For “ENGINE”, “CAN COMM CIRCUIT [U1001]” are displayed. Put a check mark to it.
- For “A/T”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “BCM”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “METER”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “ALL MODE AWD/4WD”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “AUTO DRIVE POS.”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “ABS”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “IPDM E/R”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transfer diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M/A	AWD/4WD	DOCTS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
BCM	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
METER	No indicator	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	No indicator	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
AUTO DRIVE POS.	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indicator	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-

When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 1



Check harness between TCM and display control unit circuit.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transfer diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M/A	AWD/4WD	DOCTS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
BCM	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
METER	No indicator	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	No indicator	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
AUTO DRIVE POS.	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indicator	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-

Case 2

Check harness between display control unit and data link connector circuit.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transfer diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M/A	AWD/4WD	DOCTS /ABS	IPDM E/R				
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1000]
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
BCM	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
METER	No indicator	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	No indicator	-	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
AUTO DRIVE POS.	No indicator	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indicator	-	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT [U1000]	-



SKIB3233E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT[U1000]" in "Check sheet results (example)" change to "-". Then, ignore check marks on the Check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS003GJ

CAN Diagnostic Support Monitor DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR	CAN DIAG SUPPORT MNTR																																																				
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: right;">Scroll Down</td></tr> <tr><td>MODE</td><td style="text-align: right;">BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE	BACK LIGHT COPY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>EPS</td><td style="text-align: right;">UNKWN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: right;">Scroll Up</td></tr> <tr><td>MODE</td><td style="text-align: right;">BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	EPS	UNKWN	PRINT	Scroll Up	MODE	BACK LIGHT COPY
ENGINE																																																						
	PRSNT																																																					
INITIAL DIAG	OK																																																					
TRANSMIT DIAG	OK																																																					
TCM	OK																																																					
VDC/TCS/ABS	OK																																																					
METER/M&A	OK																																																					
ICC	UNKWN																																																					
BCM/SEC	OK																																																					
IPDM E/R	OK																																																					
AWD/4WD/e4WD	UNKWN																																																					
PRINT	Scroll Down																																																					
MODE	BACK LIGHT COPY																																																					
ENGINE																																																						
	PRSNT																																																					
TRANSMIT DIAG	OK																																																					
TCM	OK																																																					
VDC/TCS/ABS	OK																																																					
METER/M&A	OK																																																					
ICC	UNKWN																																																					
BCM/SEC	OK																																																					
IPDM E/R	OK																																																					
AWD/4WD/e4WD	UNKWN																																																					
EPS	UNKWN																																																					
PRINT	Scroll Up																																																					
MODE	BACK LIGHT COPY																																																					
		SKIB0591E																																																				

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN
EPS	EPS is not diagnosed.	UNKWN	

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example) CAN DIAG SUPPORT MNTR

A/T	
PRSN	T
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC/e4WD	UNKW
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKW
	ECM	Make sure of normal reception from ECM.	OK/UNKW
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKW
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKW
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKW
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKW

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKW : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example) CAN DIAG SUPPORT MNTR

BCM	
PRSN	T
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
IPDM E/R	OK
METER/M&A	UNKW
I-KEY	OK
PRINT	
MODE	BACK LIGHT COPY

SKIB0593E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKW
	ECM	Make sure of normal reception from ECM.	OK/UNKW
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKW
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKW
	I-KEY	I-KEY is not diagnosed.	OK

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKW : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TRANSFER CONTROL UNIT

All-mode 4WD models

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
	PRSNT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
VDC/TCS/ABS	OK	OK	
TCM	OK	OK	
STRG	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

PKIB5220E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
ALL MODE AWD/4WD	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1~39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/-	
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN/-	
	TCM	Make sure of normal reception from TCM.	OK/UNKWN/-	
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWN/-	

Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

CAUTION:

“UNKWN” is indicated by erasing the self-diagnosis result when any malfunction was detected in past.

- - : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.
- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- - : Undiagnosed

CAUTION:

- “UNKWN” is indicated in “Present” and “0” is indicated in “Past” when any malfunction is detected at present.
- “UNKWN” is indicated in “Present” and “1~39” is indicated in “Past” when any malfunction was detected in past.

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
	PRSNT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	UNKWN	0	
VDC/TCS/ABS	UNKWN	39	
TCM	UNKWN	0	
STRG	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB3246E

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Part time 4WD models

(Example) CAN DIAG SUPPORT MNTR

ALL MODE AWD/4WD			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
VDC/TCS/ABS	OK		
TCM	UNKWN		
METER/M&A	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB5232E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/ 4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DRIVER SEAT CONTROL UNIT

(Example) CAN DIAG SUPPORT MNTR

AUTO DRIVE POS.			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
BCM/SEC	OK		
METER/M&A	OK		
TCM	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB6076E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
AUTO DRIVE POS.	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	BCM	Make sure of normal reception from BCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSENT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
METER/M&A	UNKWVN		
STRG	OK		
ICC	UNKWVN		
AWD/4WD	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB6078E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	TCM	Make sure of normal reception from TCM.	OK/UNKWVN
	METER/M&A	METER/M&A is not diagnosed.	UNKWVN
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWVN
	ICC	ICC is not diagnosed.	UNKWVN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWVN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example)

CAN DIAG SUPPORT MNTR			
IPDM E/R			
	PRSNT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/-	OK/0/1~39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/-	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/-	

Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- - : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.
- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- - : Undiagnosed

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DISPLAY CONTROL UNIT

(Example)

CAN DIAG SUPPORT MONITOR			
CAN_COMM	OK	0	<input type="button" value="Delete"/>
CAN_CIRC_1	OK	0	
CAN_CIRC_2	OK	0	
CAN_CIRC_3	OK	0	
CAN_CIRC_4	UNKWN	1	
CAN_CIRC_5	UNKWN	1	
CAN_CIRC_6	UNKWN	1	
CAN_CIRC_7	OK	0	
CAN_CIRC_8	OK	0	
CAN_CIRC_9	OK	0	

SKIB0645E

Unit name	Diagnosis item	Description	“CAN DIAG SUPPORT MONITOR” screen	Error counter (Reference)
Display control unit	CAN COMM	Make sure that microcomputer in ECU works normally.	OK/NG	0/1~50
	CAN CIRC 1	Make sure of normal transmission.	OK/UNKWN	
	CAN CIRC 2	Make sure of normal reception from BCM.	OK/UNKWN	
	CAN CIRC 3	Make sure of normal reception from ECM.	OK/UNKWN	
	CAN CIRC 4	Make sure of normal reception from front air control.	OK/UNKWN	
	CAN CIRC 5	Make sure of normal reception from combination meter.	OK/UNKWN	
	CAN CIRC 6	CAN CIRC 6 is not diagnosed.	UNKWN	
	CAN CIRC 7	Make sure of normal reception from IPDM E/R.	OK/UNKWN	
	CAN CIRC 8	CAN CIRC 8 is not diagnosed.	UNKWN	
	CAN CIRC 9	CAN CIRC 9 is not diagnosed.	UNKWN	

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- – : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

Display Results : Error Counter (Reference)

- 0 : It is normal now.
- 1 ~ 50 : Displays when it finds malfunction in the past even if it is normal or there is a malfunction at present. Also, displays when diagnosis is not performed. It increase like 0→1→2...49→50 after returning to the normal condition whenever IGN OFF→ON. If it is over 50, it is fixed to 50 until the self-diagnostic results are erased. Keep this condition until resetting it.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN COMMUNICATION

System Description

UKS000NU

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

UKS000NV

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon							
Axle	2WD			4WD(Part time)			4WD(All-mode)	
Engine	VQ40DE							
Transmission	A/T							
Brake control	VDC							
Automatic air conditioner		×	×	×		×	×	×
Automatic drive positioner			×	×			×	×
Navigation system				×				×
CAN system type	1	2	3	4	5	6	7	8
CAN system trouble diagnosis	LAN-34	LAN-63	LAN-92	LAN-124	LAN-161	LAN-191	LAN-222	LAN-256

×: Applicable


NOTE:

Confirming the presence of the following items helps to identify CAN system type.

- With automatic air conditioner




- With automatic drive positioner



CAN COMMUNICATION


[CAN]

- With navigation system




TYPE 1/ TYPE 2/ TYPE 3/ TYPE 4 System diagram

- Type 1



- Type 2



A
B
C
D
E
F
G
H
I
J


LAN

L
M

CAN COMMUNICATION


[CAN]

● Type 3



SKIB2452E

● Type 4



SKIB2453E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R	R			R		R	
Engine status signal	T					R				
Engine coolant temperature signal	T			R			R			
Accelerator pedal position signal	T	R							R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Battery voltage signal	T	R								
A/T self-diagnosis signal	R	T								
Turbine revolution signal	R	T								

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Output shaft revolution signal	R	T								
A/C switch signal	R			R		T				
A/C compressor request signal	T									R
Blower fan motor switch signal	R					T				
Cooling fan speed request signal	T									R
A/C switch/indicator signal			T	R						
			R	T						
Low beam request signal						T				R
Low beam status signal	R									T
High beam request signal						T	R			R
High beam status signal	R									T
Position light request signal						T	R			R
Front fog light request signal						T	R			R
Day time running light request signal						T	R			R
Sleep wake up signal						T	R	R		R
Door switch signal			R			T	R	R		R
Seat belt buckle switch signal						R	T			
System setting signal			T			R		R		
			R			T		T		
Ignition switch signal						T		R		
Key switch signal						T		R		
Key fob ID signal						T		R		
Key fob door unlock signal						T		R		
Theft warning horn request signal						T				R
Horn chirp signal						T				R
Front wiper request signal						T				R
Front wiper stop position signal						R				T
Rear window defogger switch signal				R		T				R
Rear window defogger control signal	R			R						T
Buzzer output signal						T	R			
Tire pressure signal			R			T	R			
Tire pressure data signal			R			T				
Fuel consumption monitor signal	T						R			
			R				T			
Fuel level sensor signal	R						T			
Fuel level low warning signal			R				T			
Distance to empty signal			R				T			
Turn indicator signal						T	R			
Brake warning lamp signal							R		T	
ABS warning lamp signal							R		T	

A
B
C
D
E
F
G
H
I
J

LAN

L
M


CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
VDC OFF indicator lamp signal							R		T	
SLIP indicator lamp signal							R		T	
Malfunction indicator lamp signal	T						R			
ASCD CRUISE lamp signal	T						R			
ASCD SET lamp signal	T						R			
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T fluid temperature sensor signal		T					R			
A/T position indicator lamp signal		T					R			
P range signal		T					R	R	R	
O/D OFF indicator signal		T					R			
Overdrive control switch signal		R					T			
1st position switch signal		R					T			
Stop lamp switch signal		R					T			
Vehicle speed signal				R			R		T	
	R	R	R	R		R	T	R		
Steering angle sensor signal					T				R	

TYPE 5/ TYPE 6 System diagram


- Type 5



CAN COMMUNICATION

[CAN]

● Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Front air control	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R			R	R	R	
Engine status signal	T				R				
Engine coolant temperature signal	T		R			R			
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
A/T self-diagnosis signal	R	T							
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T					R		
A/C switch signal	R		R		T				
A/C compressor request signal	T								R
Blower fan motor switch signal	R				T				
Cooling fan speed request signal	T								R
Low beam request signal					T				R
Low beam status signal	R								T
High beam request signal					T	R			R
High beam status signal	R								T
Position light request signal					T	R			R
Front fog light request signal					T	R			R
Day time running light request signal					T	R			R
Sleep wake up signal					T	R			R
Door switch signal					T	R			R
Seat belt buckle switch signal					R	T			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Front air control	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Ignition switch signal					T				R
Theft warning horn request signal					T				R
Horn chirp signal					T				R
Front wiper request signal					T				R
Front wiper stop position signal					R				T
Rear window defogger switch signal			R		T				R
Rear window defogger control signal	R		R						T
Buzzer output signal					T	R			
Tire pressure signal					T	R			
Fuel consumption monitor signal	T					R			
Fuel level sensor signal	R					T			
Turn indicator signal					T	R			
Brake warning lamp signal						R		T	
ABS warning lamp signal						R		T	
VDC OFF indicator lamp signal						R		T	
SLIP indicator lamp signal						R		T	
HDC indicator lamp signal						R		T	
Malfunction indicator lamp signal	T					R			
ASCD CRUISE lamp signal	T					R			
ASCD SET lamp signal	T					R			
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
A/T fluid temperature sensor signal		T				R			
A/T position indicator lamp signal		T				R	R		
O/D OFF indicator signal		T				R			
Overdrive control switch signal		R				T			
1st position switch signal		R				T			
Stop lamp switch signal		R				T			
							R	T	
Vehicle speed signal			R			R	R	T	
	R	R	R		R	T			
Steering angle sensor signal				T				R	


CAN COMMUNICATION

[CAN]


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Transfer control unit	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R	R			R	R		R	
Engine status signal	T					R					
Engine coolant temperature signal	T			R			R				
Accelerator pedal position signal	T	R						R		R	
Closed throttle position signal	T	R									
Wide open throttle position signal	T	R									

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Transfer control unit	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Battery voltage signal	T	R									
A/T self-diagnosis signal	R	T									
Turbine revolution signal	R	T									
Output shaft revolution signal	R	T						R			
A/C switch signal	R			R		T					
A/C compressor request signal	T										R
Blower fan motor switch signal	R					T					
Cooling fan speed request signal	T										R
A/C switch/indicator signal			T	R							
			R	T							
Low beam request signal						T					R
Low beam status signal	R										T
High beam request signal						T	R				R
High beam status signal	R										T
Position light request signal						T	R				R
Front fog light request signal						T	R				R
Day time running light request signal						T	R				R
Sleep wake up signal						T	R		R		R
Door switch signal			R			T	R		R		R
Seat belt buckle switch signal						R	T				
System setting signal			T			R			R		
			R			T			T		
Ignition switch signal						T			R		
Key switch signal						T			R		
Key fob ID signal						T			R		
Key fob door unlock signal						T			R		
Theft warning horn request signal						T					R
Horn chirp signal						T					R
Front wiper request signal						T					R
Front wiper stop position signal						R					T
Rear window defogger switch signal				R		T					R
Rear window defogger control signal	R			R							T
Buzzer output signal						T	R				
Tire pressure signal			R			T	R				
Tire pressure data signal			R			T					
Fuel consumption monitor signal	T						R				
			R				T				
Fuel level sensor signal	R						T				

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit	Front air control	Steering angle sensor	BCM	Combination meter	Transfer control unit	Driver seat control unit	ABS actuator and electric unit (control unit)	IPDM E/R	A B C D E F G H I J LAN L M
Fuel level low warning signal			R				T					
Distance to empty signal			R				T					
Turn indicator signal						T	R					
Brake warning lamp signal							R			T		
ABS warning lamp signal							R			T		
VDC OFF indicator lamp signal							R			T		
SLIP indicator lamp signal							R			T		
Malfunction indicator lamp signal	T						R					
ASCD CRUISE lamp signal	T						R					
ASCD SET lamp signal	T						R					
ASCD operation signal	T	R										
ASCD OD cancel request	T	R										
A/T fluid temperature sensor signal		T					R					
A/T position indicator lamp signal		T					R	R				
P range signal		T					R		R	R		
O/D OFF indicator signal		T					R					
Overdrive control switch signal		R					T					
1st position switch signal		R					T					
Stop lamp switch signal		R					T					
Vehicle speed signal				R			R	R		T		
	R	R	R	R		R	T		R			
Steering angle sensor signal					T					R		

CAN SYSTEM (TYPE 1)

PF2:23710


System Description

UKS003G0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003G1




CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS003G2



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0605E

CAN SYSTEM (TYPE 1)



[CAN]

Wiring Diagram - CAN -

UKS003G3

LAN-CAN-01

▬ : DATA LINE



REFER TO THE FOLLOWING.


(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0368E


CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02







A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0606E

▬ : DATA LINE



BKWA0370E

CAN SYSTEM (TYPE 1)

[CAN]

UKS003G4

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table												
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5017E

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-51, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5083E



PKIB5200E

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-52, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5084E



PKIB5201E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-53, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB5085E



CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-54, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5086E



PKIB5203E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-54, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5087E



PKIB5204E

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-55, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5088E




PKIB5205E

Case 7

Check BCM circuit. Refer to [LAN-55, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5089E



CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-56, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UN ✓ KN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UN ✓ KN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UN ✓ KN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5090E




PKIB5207E

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-56, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	✓	✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5091E




Case 10

Check IPDM E/R circuit. Refer to [LAN-57, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5092E



Case 11

Check CAN communication circuit. Refer to [LAN-58, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5093E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-62, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB5094E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-62, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB5095E

Inspection Between TCM and Data Link Connector Circuit

UKS003G5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003G6

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003G7

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003G8

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003G9

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003GC

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003GD

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003GE

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.




4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J
LAN
L
M


7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

- 2 (L) – Ground : Continuity should not exist.**
- 3 (P) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 8.
- NG >> Repair harness between harness connector E5 and harness connector E152.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

- 6 (L) – 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 9.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between data link connector and harness connector M31
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91




9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

- 6 (L) – Ground : Continuity should not exist.**
- 14 (P) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 10.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between data link connector and harness connector M31
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003GG

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 2)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location




CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS003FL



BKWA0607E

CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram - CAN -


UKS003FM

LAN-CAN-04

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M





REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0372E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-05






BKWA0608E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-06

— : DATA LINE



BKWA0374E

CAN SYSTEM (TYPE 2)

[CAN]

UKS003FN

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table													
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :


Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5016E

CAN SYSTEM (TYPE 2)

[CAN]



A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB5017E

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-80, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5083E



PKIB5210E

CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-81, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit" .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5084E



PKIB5211E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-82, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB5085E



PKIB5212E

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-83, "TCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5086E



CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-83, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5087E



PKIB5214E

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-84, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5088E



PKIB5215E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-84, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5089E



PKIB5216E

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-85, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5090E



PKIB5217E

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-85, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5091E



PKIB5218E

CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-86, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5092E



Case 11

Check CAN communication circuit. Refer to [LAN-87, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5093E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-91, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB5094E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-91, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB5095E

Inspection Between TCM and Data Link Connector Circuit

UKS003FO

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003FP

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

UKS003FQ

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003FR

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003FS

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Data Link Connector Circuit Inspection

UKS003FT

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

UKS003FU

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003FV

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003FW

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003FX

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E2.




4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
- Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect harness connector E152.
- Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Front air control connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



A
B
C
D
E
F
G
H
I
J
LAN
L
M

9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003FZ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 3)


System Description

UKS003F0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003F1




BKIA0111E

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS003F2



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0609E

CAN SYSTEM (TYPE 3)



[CAN]

UKS003F3

Wiring Diagram - CAN -

LAN-CAN-07

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0376E

CAN SYSTEM (TYPE 3)


[CAN]

LAN-CAN-08

— : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0610E

LAN-CAN-09



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91) W
(B37) W

37	38	39	40	41	42
43	44	45	46	47	48

(E122) W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125) B

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

(P2) * W

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

CAN SYSTEM (TYPE 3)

[CAN]

UKS003F4

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5018E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5019E

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-110, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKW	—	UNKW	—	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5096E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-111, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5097E



PKIB5222E

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-112, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIB5098E



PKIB5223E

CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-113, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5099E




PKIB5224E

Case 5

Check steering angle sensor circuit. Refer to [LAN-113, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5100E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-114, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5101E




PKIB5226E

Case 7

Check BCM circuit. Refer to [LAN-114, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5102E




Case 8

Check combination meter circuit. Refer to [LAN-115, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	✓	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5103E




PKIB5228E

Case 9

Check driver seat control unit circuit. Refer to [LAN-115, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5104E




Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-116, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5105E




Case 11

Check IPDM E/R circuit. Refer to [LAN-116, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5106E



Case 12

Check CAN communication circuit. Refer to [LAN-117, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5107E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-123, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5108E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-123, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5109E

Inspection Between TCM and Data Link Connector Circuit

UKS003F5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).

52G (L) – 6 (L) : Continuity should exist.
51G (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003F6

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003F7


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003F8

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003FA

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Data Link Connector Circuit Inspection

UKS003FB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

UKS003FC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003FD

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003FE

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003FF

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003FG

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003FH

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and driver seat control unit

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Front air control connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Harness connector M40
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91




10. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Driver seat control unit connector
 - Harness connector P1
- Check continuity between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 11.
 NG >> Repair harness between driver seat control unit and harness connector P1.



11. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and ground.

3 (L) – Ground : Continuity should not exist.

19 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 12.
 NG >> Repair harness between driver seat control unit and harness connector P1.




12. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B37 terminals 15 (L) and 14 (P).

15 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 13.
 NG >> Repair harness between harness connector B37 and harness connector B69.



13. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B37 terminals 15 (L), 14 (P) and ground.

15 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 14.
 NG >> Repair harness between harness connector B37 and harness connector B69.



14. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 15.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



15. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 16.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



16. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 17.

NG >> Replace ECM and/or IPDM E/R.



17. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 18.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

18. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003FI

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

LAN

CAN SYSTEM (TYPE 4)


System Description

UKS003EF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003EG




BKIA0112E

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS003EH



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0611E

CAN SYSTEM (TYPE 4)



[CAN]

UKS003E1

Wiring Diagram - CAN -

LAN-CAN-10

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)



BKWA0380E

CAN SYSTEM (TYPE 4)

[CAN]


LAN-CAN-11

— : DATA LINE



BKWA0612E

LAN-CAN-12



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(M91)	(B37)
W	W

37	38	39	40	41	42
43	44	45	46	47	48

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

CAN SYSTEM (TYPE 4)

[CAN]

UKS003EJ

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.			
Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	Front air control	CAN CIRC 9	—

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

PKIB5020E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5019E

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and display control unit circuit. Refer to [LAN-145, "Inspection Between TCM and Display Control Unit Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5110E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between display control unit and data link connector circuit. Refer to [LAN-147, "Inspection Between Display Control Unit and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB5111E



PKIB5234E

CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-147, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5112E




PKIB5235E

Case 4

Check ECM circuit. Refer to [LAN-148, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
Display control unit	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5113E



CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-148, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UN✓W	—	—	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKW	UN✓W	—	—	—	—	UN✓W	UN✓W	—	CAN COMM CIRCUIT (U100) ✓	—
Display control unit	—	NG	UNKW	UNKW	—	UNKW	—	UNKW	UNKW	—	UNKW	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UN✓W	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKW	UNKW	UN✓W	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5114E



CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check display control unit circuit. Refer to [LAN-149, "Display Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5115E



CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check Front air control circuit. Refer to [LAN-149, "Front Air Control Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5116E




Case 8

Check steering angle sensor circuit. Refer to [LAN-150, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB5117E



PKIB5240E

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-150, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5118E



CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check BCM circuit. Refer to [LAN-151, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5119E



CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check combination meter circuit. Refer to [LAN-151, "Combination Meter Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5120E



PKIB5243E

CAN SYSTEM (TYPE 4)


[CAN]

Case 12

Check driver seat control unit circuit. Refer to [LAN-152, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5121E




PKIB5244E

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-152, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	✓	—	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5122E




Case 14

Check IPDM E/R circuit. Refer to [LAN-153, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5123E



Case 15

Check CAN communication circuit. Refer to [LAN-154, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5124E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-160, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	—	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5125E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-160, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5126E

Inspection Between TCM and Display Control Unit Circuit

UKS003EK

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check continuity between harness connector M31 terminals 52G (L), 51G (P) and display control unit harness connector M95 terminals 25 (L), 26 (P).

52G (L) – 25 (L) : Continuity should exist.
51G (P) – 26 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness.



Inspection Between Display Control Unit and Data Link Connector Circuit


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and display control unit connector.
4. Check continuity between display control unit harness connector M95 terminals 25 (L), 26 (P) and data link connector M22 terminals 6 (L), 14 (P).

25 (L) – 6 (L) : Continuity should exist.
26 (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J

LAN

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



UKS003EN

ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

OK >> Replace ECM.

NG >> Repair harness between ECM and A/T assembly.



UKS003EO

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003EP

Display Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

25 (L) – 26 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and harness connector M31.



UKS003EQ

Front Air Control Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 41 (L) and 42 (P).

41 (L) – 42 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



UKS003ER

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



WKIA4162E

UKS003ES

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS003EV

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and data link connector.



UKS003EW

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003EX

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Display control unit
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and driver seat control unit

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness between ECM and harness connector E2.




4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
- NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J
LAN
L
M

7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.

- Display control unit connector
- Front air control connector
- Steering angle sensor connector
- BCM connector
- Combination meter connector
- Harness connector M40
- Harness connector M91

2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and display control unit
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and display control unit
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - Driver seat control unit connector
 - Harness connector P1
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector P1.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and ground.


3 (L) – Ground : Continuity should not exist.

19 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector P1.



12. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B37 terminals 15 (L) and 14 (P).

15 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between harness connector B37 and harness connector B69.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B37 terminals 15 (L), 14 (P) and ground.


15 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between harness connector B37 and harness connector B69.



14. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 15.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



15. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 16.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



16. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 17.

NG >> Replace ECM and/or IPDM E/R.



17. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 18.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

18. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Display control unit
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003EZ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 5)

PFP:23710


System Description

UKS003DX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003DY



BKIA0113E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

UKS003DZ



BKWA0613E

CAN SYSTEM (TYPE 5)


[CAN]

Wiring Diagram - CAN -


UKS003E0

LAN-CAN-13

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0384E

LAN-CAN-14




BKWA0614E

CAN SYSTEM (TYPE 5)

[CAN]

LAN-CAN-15

▬ : DATA LINE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91)
W

37	38	39	40	41	42
43	44	45	46	47	48

(E122)
W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125)
B

LAN

BKWA0386E

CAN SYSTEM (TYPE 5)

[CAN]

UKS003E1

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5021E

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-179, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	✓	✓	✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5127E



SKIB2848E

CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-180, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5128E



SKIB2849E

CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-181, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB5129E



SKIB2850E

CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-182, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	✓	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	✓	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5130E



CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-182, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5131E



SKIB2852E

CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-183, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5132E



CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-183, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5133E




SKIB2854E

Case 8

Check combination meter circuit. Refer to [LAN-184, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	✓	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	✓	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5134E



CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check transfer control unit circuit. Refer to [LAN-184, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5135E




SKIB2856E

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-185, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5136E



CAN SYSTEM (TYPE 5)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-185, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5137E



Case 12

Check CAN communication circuit. Refer to [LAN-186, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5138E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5139E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-190, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5140E

Inspection Between TCM and Data Link Connector Circuit

UKS003E2

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003E3

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003E4

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003E5

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003E6

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Data Link Connector Circuit Inspection

UKS003E7

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

UKS003E8

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003E9

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003EA

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003EB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003EC

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003ED

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
- Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and transfer control unit
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003EE

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 6)


System Description

UKS003DE

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003DF



BKIA0114E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 6)

[CAN]

Schematic

UKS003DG



BKWA0615E

CAN SYSTEM (TYPE 6)


[CAN]

Wiring Diagram - CAN -


UKS003DH

LAN-CAN-16

■ : DATA LINE





A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0388E

LAN-CAN-17




BKWA0616E

CAN SYSTEM (TYPE 6)

[CAN]

LAN-CAN-18

— : DATA LINE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91)
W

37	38	39	40	41	42
43	44	45	46	47	48

(E122)
W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125)
B

LAN

BKWA0390E

CAN SYSTEM (TYPE 6)

[CAN]

UKS003DI

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5021E

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-209, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	✓	✓	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5127E



CAN SYSTEM (TYPE 6)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-210, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5128E



SKIB2836E

CAN SYSTEM (TYPE 6)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-211, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U000) ✓	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB5129E



SKIB2837E

CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-212, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN KN W N	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UN KN W N	—	—	—	UN KN W N	UN KN W N	UN KN W N	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UN KN W N	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UN KN W N	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5130E



SKIB2838E

CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-212, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5131E



SKIB2839E

CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-213, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5132E



CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-213, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5133E



SKIB2841E

CAN SYSTEM (TYPE 6)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-214, "Combination Meter Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5134E



CAN SYSTEM (TYPE 6)


[CAN]

Case 9

Check transfer control unit circuit. Refer to [LAN-214, "Transfer Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5135E




SKIB2843E

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-215, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5136E



CAN SYSTEM (TYPE 6)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-215, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5137E



Case 12

Check CAN communication circuit. Refer to [LAN-216, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	✓	✓	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	✓	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	✓	✓	✓	✓	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5138E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-221, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5139E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-221, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5140E

Inspection Between TCM and Data Link Connector Circuit

UKS003DJ

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003DK

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS003DL

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003DM

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003DO

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003DR

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003DS

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003DT

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS003DU

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003DV

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) - 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



A
B
C
D
E
F
G
H
I
J
LAN
L
M


6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Front air control connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF. A
2. Disconnect the battery cable from the negative terminal. B
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.) C
6. Make sure that the same symptom is reproduced. D
 - TCM
 - Front air control
 - Steering angle sensor E
 - BCM
 - Combination meter
 - Transfer control unit F
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R G

Inspection results

Reproduced>>Install removed unit, and then check the other unit. H

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003DW

Check the following. If no malfunction is found, replace the IPDM E/R. I

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#). J
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

LAN

L

M

CAN SYSTEM (TYPE 7)

PF:23710


System Description

UKS003CT

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003CU




BKIA0115E

CAN SYSTEM (TYPE 7)

[CAN]

Schematic

UKS003CV



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0617E

CAN SYSTEM (TYPE 7)



[CAN]

UKS003CW

Wiring Diagram - CAN -

LAN-CAN-19

▬ : DATA LINE



REFER TO THE FOLLOWING.


(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0392E

CAN SYSTEM (TYPE 7)


[CAN]

LAN-CAN-20





A
B
C
D
E
F
G
H
I
J
K
L
M

LAN



BKWA0618E

LAN-CAN-21



REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

BKWA0394E

CAN SYSTEM (TYPE 7)

[CAN]

UKS003CX

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB5023E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5024E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-241, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5141E



CAN SYSTEM (TYPE 7)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-242, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R				
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5142E



SKIB2823E

CAN SYSTEM (TYPE 7)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-243, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB5143E



CAN SYSTEM (TYPE 7)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-244, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UN KN W N	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UN KN W N	—	—	—	UN KN W N	UN KN W N	UN KN W N	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UN KN W N	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN KN W N	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UN KN W N	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5144E



SKIB2825E

CAN SYSTEM (TYPE 7)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-244, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5145E



CAN SYSTEM (TYPE 7)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-245, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5146E



SKIB2827E

CAN SYSTEM (TYPE 7)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-245, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5147E



CAN SYSTEM (TYPE 7)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-246, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5148E



CAN SYSTEM (TYPE 7)


[CAN]

Case 9

Check transfer control unit circuit. Refer to [LAN-246, "Transfer Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5149E



CAN SYSTEM (TYPE 7)


[CAN]

Case 10

Check driver seat control unit circuit. Refer to [LAN-247, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5150E



SKIB2831E

CAN SYSTEM (TYPE 7)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-247, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5151E



CAN SYSTEM (TYPE 7)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-248, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5152E



Case 13

Check CAN communication circuit. Refer to [LAN-249, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5153E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-255, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5154E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-255, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5155E

Inspection Between TCM and Data Link Connector Circuit

UKS003CY

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and Data Link Connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003D0

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).

11 (L) – 11 (L) : Continuity should exist.
10 (P) – 15 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS003D2

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS003D4

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS003D5

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS003D6

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS003D7

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS003D8

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 7 (L) and 8 (P).

7 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS003D9

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and data link connector.



UKS003DA

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and driver seat control unit

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E2.




4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - A/T assembly connector
 - Harness connector F14
- Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.

8 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between A/T assembly and harness connector F32
 - Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect harness connector E152.
- Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Front air control connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M40
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - Driver seat control unit connector
 - Harness connector P1
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector P1.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and ground.


3 (L) – Ground : Continuity should not exist.

19 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector P1.



12. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B37 terminals 15 (L) and 14 (P).

15 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between harness connector B37 and harness connector B69.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B37 terminals 15 (L), 14 (P) and ground.


15 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between harness connector B37 and harness connector B69.



14. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 15.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



A
B
C
D
E
F
G
H
I
J
LAN
L
M

15. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 16.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



16. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 - 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 - 132 Ω

OK or NG

OK >> GO TO 17.

NG >> Replace ECM and/or IPDM E/R.



17. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 18.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

18. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF. A
2. Disconnect the battery cable from the negative terminal. B
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.) C
6. Make sure that the same symptom is reproduced. D
 - TCM
 - Front air control
 - Steering angle sensor E
 - BCM
 - Combination meter
 - Transfer control unit F
 - Driver seat control unit
 - ABS actuator and electric unit (control unit) G
 - ECM
 - IPDM E/R

Inspection results H

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection UKS003DD I

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) . J
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

LAN

L

M

CAN SYSTEM (TYPE 8)


System Description

UKS003B5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS003B6




CAN SYSTEM (TYPE 8)

[CAN]

Schematic

UKS003B7



A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0619E

CAN SYSTEM (TYPE 8)



[CAN]

UKS003B8

Wiring Diagram - CAN -

LAN-CAN-22

▬ : DATA LINE




REFER TO THE FOLLOWING.

M31 - SUPER MULTIPLE JUNCTION (SMJ)



BKWA0354E

- (A4) : 4 A/T
 - (A5) : 5 A/T
 - (AD) : WITH AUTOMATIC DRIVE POSITIONER
 - (CD) : WITH COLOR DISPLAY
 - (MC) : WITH MONOCHROME DISPLAY
 - (WV) : WITH VDC
 - (XV) : WITHOUT VDC
- * 1 (WV) : 7 (XV) : 20
 - * 2 (WV) : 9 (XV) : 23
 - * 3 (A4) : 5 (A5) : 3
 - * 4 (A4) : 6 (A5) : 4





A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0620E

LAN-CAN-24



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0356E

CAN SYSTEM (TYPE 8)

[CAN]

UKS003B9

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	—	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKW	UNKW	—	UNKW	—	UNKW	UNKW	—	—	UNKW	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKW	UNKW	UNKW	—	UNKW	—	—	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	Front air control	CAN CIRC 9	—

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

PKIB5025E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5024E

CAN SYSTEM (TYPE 8)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and display control unit circuit. Refer to [LAN-278, "Inspection Between TCM and Display Control Unit Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2643E



SKIB2661E

CAN SYSTEM (TYPE 8)


[CAN]

Case 2

Check harness between display control unit and data link connector circuit. Refer to [LAN-280, "Inspection Between Display Control Unit and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

SKIB2644E



SKIB2662E

CAN SYSTEM (TYPE 8)

[CAN]


Case 3

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-280, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2645E



CAN SYSTEM (TYPE 8)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-281, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—	

SKIB2646E



SKIB2646E

CAN SYSTEM (TYPE 8)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-281, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2647E



CAN SYSTEM (TYPE 8)


[CAN]

Case 6

Check display control unit circuit. Refer to [LAN-282, "Display Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2648E



SKIB2666E

CAN SYSTEM (TYPE 8)


[CAN]

Case 7

Check Front air control circuit. Refer to [LAN-282, "Front Air Control Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

SKIB2649E



CAN SYSTEM (TYPE 8)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-283, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2650E



SKIB2668E

CAN SYSTEM (TYPE 8)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-283, "Data Link Connector Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

SKIB2651E



CAN SYSTEM (TYPE 8)


[CAN]

Case 10

Check BCM circuit. Refer to [LAN-284, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

SKIB2652E



SKIB2670E

CAN SYSTEM (TYPE 8)


[CAN]

Case 11

Check combination meter circuit. Refer to [LAN-284, "Combination Meter Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

SKIB2653E



SKIB2671E

CAN SYSTEM (TYPE 8)


[CAN]

Case 12

Check transfer control unit circuit. Refer to [LAN-285, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	✓	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

SKIB2654E



SKIB2672E

CAN SYSTEM (TYPE 8)


[CAN]

Case 13

Check driver seat control unit circuit. Refer to [LAN-285, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2655E



CAN SYSTEM (TYPE 8)


[CAN]

Case 14

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-286, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2656E



SKIB2674E

CAN SYSTEM (TYPE 8)


[CAN]

Case 15

Check IPDM E/R circuit. Refer to [LAN-286, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKW	UNKW	—	UNKW	—	UNKW	UNKW	—	—	UNKW	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKW	UNKW	UNKW	—	UNKW	—	—	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2657E



Case 16

Check CAN communication circuit. Refer to [LAN-287, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
			ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKW	UNKW	—	UNKW	—	UNKW	UNKW	—	—	UNKW	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKW	UNKW	UNKW	—	UNKW	—	—	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2658E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-294, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2659E

Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-294, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	Front air control	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB2660E

Inspection Between TCM and Display Control Unit Circuit

UKS003BB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).

3 (L) – 2 (L) : Continuity should exist.
8 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).

2 (L) – 52G (L) : Continuity should exist.
3 (P) – 51G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check continuity between harness connector M31 terminals 52G (L), 51G (P) and display control unit harness connector M95 terminals 25 (L), 26 (P).

52G (L) – 25 (L) : Continuity should exist.
51G (P) – 26 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Inspection Between Display Control Unit and Data Link Connector Circuit

UKS003BC


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and display control unit connector.
4. Check continuity between display control unit harness connector M95 terminals 25 (L), 26 (P) and data link connector M22 terminals 6 (L), 14 (P).

25 (L) – 6 (L) : Continuity should exist.
26 (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS003BD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).

11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



UKS003BE

ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and A/T assembly.



UKS003BF

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



Display Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

25 (L) – 26 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and harness connector M31.



Front Air Control Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 41 (L) and 42 (P).

41 (L) – 42 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



UKS003BI

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS003BJ

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



SKIA6868E

UKS003BK

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



SKIA6869E

UKS003BL

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS003BM

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 7 (L) and 8 (P).

7 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS003BN

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS003B0

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS003BP

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS003B0

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Display control unit
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R
 - Between ECM and driver seat control unit

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector E2
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.

- A/T assembly connector
- Harness connector F14

2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Display control unit connector
 - Front air control connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M40
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and display control unit
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and display control unit
- Harness between data link connector and front air control
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M40
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - Driver seat control unit connector
 - Harness connector P1
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) – 19 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Repair harness between driver seat control unit and harness connector P1.



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and ground.


3 (L) – Ground : Continuity should not exist.

19 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Repair harness between driver seat control unit and harness connector P1.



12. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B37 terminals 15 (L) and 14 (P).

15 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between harness connector B37 and harness connector B69.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B37 terminals 15 (L), 14 (P) and ground.


15 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between harness connector B37 and harness connector B69.



14. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 15.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



15. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 16.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



16. ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 17.

NG >> Replace ECM and/or IPDM E/R.



17. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 18.

NG >> Refer to [LAN-15, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

A
B
C
D
E
F
G
H
I
J
L
M

LAN

18. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Display control unit
 - Front air control
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - Driver seat control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS003BS

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .