

SECTION **LAN**
LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

CONTENTS

| CAN FUNDAMENTAL | CAN |
|-------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| PRECAUTIONS 3 | INDEX FOR DTC 40 |
| Precautions When Using CONSULT-II 3 | DTC No. Index 40 |
| Precautions for Trouble Diagnosis 3 | HOW TO USE THIS SECTION 41 |
| Precautions for Harness Repair 3 | Caution 41 |
| SYSTEM DESCRIPTION 4 | Abbreviation List 41 |
| CAN Communication System 4 | PRECAUTIONS 42 |
| SYSTEM DIAGRAM 4 | Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 42 |
| CAN COMMUNICATION CONTROL CIRCUIT 5 | Precautions When Using CONSULT-II 42 |
| Diag on CAN 6 | Precautions for Trouble Diagnosis 42 |
| DESCRIPTION 6 | Precautions for Harness Repair 42 |
| SYSTEM DIAGRAM 6 | TROUBLE DIAGNOSIS 44 |
| TROUBLE DIAGNOSIS 7 | CAN Diagnostic Support Monitor 44 |
| Condition of Error Detection 7 | MONITOR ITEM LIST (CONSULT-II) 44 |
| CAN COMMUNICATION SYSTEM ERROR 7 | MONITOR ITEM LIST (ON-BOARD DIAGNOSIS) 48 |
| WHEN INDICATED "U1000" OR "U1001" IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL 7 | CAN System Specification Chart 49 |
| Symptom When Error Occurs in CAN Communication System 8 | VEHICLE EQUIPMENT IDENTIFICATION INFORMATION 49 |
| ERROR EXAMPLE 8 | CAN Communication Signal Chart 50 |
| Self-Diagnosis 12 | TYPE 1/TYPE 2/TYPE 3/TYPE 4 50 |
| CAN Diagnostic Support Monitor 13 | TYPE 5/TYPE 6 51 |
| MONITOR ITEM (CONSULT-II) 13 | TYPE 7/TYPE 8/TYPE 9/TYPE 10 53 |
| MONITOR ITEM (ON-BOARD DIAGNOSIS) 14 | Schematic 56 |
| TROUBLE DIAGNOSES WORK FLOW 15 | Wiring Diagram — CAN — 57 |
| Information Needed for Trouble Diagnosis 15 | Interview Sheet 60 |
| How to Use CAN Communication Signal Chart 15 | Data Sheet 61 |
| Trouble Diagnosis Flow Chart 16 | CONSULT-II DATA ATTACHMENT SHEET 61 |
| Trouble Diagnosis Procedure 17 | ON-BOARD DIAGNOSIS COPY SHEET 63 |
| INTERVIEW WITH CUSTOMER 17 | CAN System (Type 1) 64 |
| INSPECTION OF VEHICLE CONDITION 18 | DIAGNOSIS SHEET 64 |
| CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART).. 19 | CAN System (Type 2) 65 |
| CREATE INTERVIEW SHEET 21 | DIAGNOSIS SHEET 65 |
| CREATE DATA SHEET 22 | CAN System (Type 3) 66 |
| CREATE DIAGNOSIS SHEET 24 | DIAGNOSIS SHEET 66 |
| DETECT THE ROOT CAUSE 25 | CAN System (Type 4) 67 |
| | DIAGNOSIS SHEET 67 |
| | CAN System (Type 5) 68 |

LAN

| | | | |
|-------------------------------------------------|----|---------------------------------------------------------------------------------|----|
| DIAGNOSIS SHEET | 68 | Actuator and Electric Unit | 77 |
| CAN System (Type 6) | 69 | Main Line Between Data Link Connector and Display Control Unit | 78 |
| DIAGNOSIS SHEET | 69 | Main Line Between Display Control unit and ABS Actuator and Electric Unit | 79 |
| CAN System (Type 7) | 70 | ECM Branch Line Circuit | 80 |
| DIAGNOSIS SHEET | 70 | TCM Branch Line Circuit | 80 |
| CAN System (Type 8) | 71 | Transfer Control Unit Branch Line Circuit | 81 |
| DIAGNOSIS SHEET | 71 | Driver Seat Control Unit Branch Line Circuit | 82 |
| CAN System (Type 9) | 72 | BCM Branch Line Circuit | 83 |
| DIAGNOSIS SHEET | 72 | Data Link Connector Branch Line Circuit | 83 |
| CAN System (Type 10) | 73 | Front Air Control Branch Line Circuit | 84 |
| DIAGNOSIS SHEET | 73 | Combination Meter Branch Line Circuit | 85 |
| Component Parts Location | 74 | Steering Angle Sensor Branch Line Circuit | 85 |
| Harness Layout | 74 | Display Control Unit Branch Line Circuit | 86 |
| Malfunction Area Chart | 75 | ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit | 87 |
| MAIN LINE | 75 | IPDM E/R Branch Line Circuit | 87 |
| BRANCH LINE | 75 | CAN Communication Circuit | 88 |
| SHORT CIRCUIT | 75 | | |
| Main Line Between TCM and Data Link Connector.. | 76 | | |
| Main Line Between Data Link Connector and ABS | | | |

PRECAUTIONS

PFP:00001

Precautions When Using CONSULT-II

UKS006H2

Use CONSULT-II CONVERTER when connecting CONSULT-II to data link connector.

CAUTION:

CAN communication does not function properly if CONSULT-II is used without connecting CONSULT-II CONVERTER.

Precautions for Trouble Diagnosis

UKS006H3

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

UKS006H4

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SYSTEM DESCRIPTION


PFP:00000

CAN Communication System

UKS006H5

- CAN communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with two communication lines (CAN-H and CAN-L).
- Control units on the CAN network transmit signals using the CAN communication control circuit. They receive only necessary signals from other control units to operate various functions.
- CAN communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.


SYSTEM DIAGRAM



Each control unit passes an electric current to the termination circuits when transmitting CAN communication signal. The termination circuits produce an electrical potential difference between CAN-H and CAN-L. CAN communication system transmits and receives CAN communication signals by the potential difference.

| Component | Description |
|---------------------|-----------------------------------------------------------------------|
| Main line | CAN communication line between splices |
| Branch line | CAN communication line between splice and a control unit |
| Splice | A point connecting a branch line with a main line |
| Termination circuit | Refer to LAN-5, "CAN COMMUNICATION CONTROL CIRCUIT" . |

CAN COMMUNICATION CONTROL CIRCUIT



| Component | System description |
|-------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| CAN controller | It controls CAN communication signal transmission and reception, error detection, etc. |
| Transceiver IC | It converts digital signal into CAN communication signal, and CAN communication signal into digital signal. |
| Noise filter | It eliminates noise of CAN communication signal. |
| Termination circuit* (Resistance of approx. 120 Ω) | It produces potential difference. |

*: These are the only control units wired with both ends of CAN communication system.


A
B
C
D
E
F
G
H
I
J
L
M

LAN

Diag on CAN DESCRIPTION

“Diag on CAN” is a diagnosis using CAN communication instead of previous DDL1 and DDL2 communication line, between control unit and diagnosis unit.

SYSTEM DIAGRAM



| Name | Harness | Description |
|-------------|----------------|------------------------------------------------------------------------------|
| DDL1 | Tx Rx | It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling) |
| DDL2 | K-LINE | It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling) |
| Diag on CAN | CAN-H CAN-L | It is used for trouble diagnosis and control. |

TROUBLE DIAGNOSIS

PFP:00004

Condition of Error Detection

UKS006H7

“U1000” or “U1001” is indicated on SELF-DIAG RESULTS on CONSULT-II if CAN communication signal is not transmitted or received between units for 2 seconds or more.

CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

WHEN INDICATED “U1000” OR “U1001” IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- CONSULT-II CONVERTER not connected: Error may be detected by the self-diagnosis when not using CONSULT-II CONVERTER (Depending on the control unit which carries out CAN communication).
- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

NOTE:

CAN communication system is normal if “U1000” or “U1001” is indicated on SELF-DIAG RESULTS of CONSULT-II under the above conditions. Erase the memory of the self-diagnosis of each unit.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

Symptom When Error Occurs in CAN Communication System


In CAN communication system, multiple units mutually transmit and receive signals. Each unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

ERROR EXAMPLE

NOTE:

- Each vehicle differs in symptom of each unit under fail-safe mode and CAN communication line wiring.
- Refer to [LAN-41, "Abbreviation List"](#) for the unit abbreviation.


Example: TCM branch line open circuit



SKIB6738E

| Unit name | Symptom |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| ECM | Engine torque limiting is affected, and shift harshness increases. |
| BCM | Reverse warning chime does not sound. |
| EPS control unit | Normal operation. |
| Combination meter | <ul style="list-style-type: none"> ● Shift position indicator and OD OFF indicator turn OFF. ● Warning lamps turn ON. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | Normal operation. |

Example: Data link connector branch line open circuit



| Unit name | Symptom |
|-----------------------------------------------|-------------------|
| ECM | Normal operation. |
| BCM | |
| EPS control unit | |
| Combination meter | |
| ABS actuator and electric unit (control unit) | |
| TCM | |
| IPDM E/R | |

NOTE:

- When data link connector branch line is open, transmission and reception of CAN communication signals is not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.
- When data link connector branch line is open, the screen-display of the CONSULT-II "SELECT SYSTEM" screen may be the same as when the CAN communication line has short-circuit. However, symptoms differ depending on the case. See below chart for the differences.

| | SELECT SYSTEM (CONSULT-II) | Difference of symptom |
|----------------------------------------------|------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Data link connector branch line open circuit | All Diag on CAN units are not indicated. | Normal operation. |
| CAN-H, CAN-L harness short-circuit | | Most the units which are connected to the CAN communication system enter fail-safe mode or are deactivated. |

A
B
C
D
E
F
G
H
I
J


LAN

L
M

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit




| Unit name | Symptom |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ECM | Engine torque limiting is affected, and shift harshness increases. |
| BCM | <ul style="list-style-type: none"> ● Reverse warning chime does not sound. ● The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. |
| EPS control unit | The steering effort increases. |
| Combination meter | <ul style="list-style-type: none"> ● The shift position indicator and OD OFF indicator turn OFF. ● The speedometer is inoperative. ● The odo/trip meter stops. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | When the ignition switch is ON, <ul style="list-style-type: none"> ● The headlamps (Lo) turn ON. ● The cooling fan continues to rotate. |

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

Example: CAN-H, CAN-L Harness Short Circuit



| Unit name | Symptom |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ECM | <ul style="list-style-type: none"> ● Engine torque limiting is affected, and shift harshness increases. ● Engine speed drops. |
| BCM | <ul style="list-style-type: none"> ● Reverse warning chime does not sound. ● The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. ● The room lamp does not turn ON. ● The engine does not start (if an error or malfunction occurs while turning the ignition switch is OFF.) ● The steering lock does not release (if an error or malfunction occurs while turning the ignition switch is OFF.) |
| EPS control unit | The steering effort increases. |
| Combination meter | <ul style="list-style-type: none"> ● The tachometer and the speedometer do not move. ● Warning lamps turn ON. ● Indicator lamps do not turn ON. |
| ABS actuator and electric unit (control unit) | Normal operation. |
| TCM | No impact on operation. |
| IPDM E/R | When the ignition switch is ON, <ul style="list-style-type: none"> ● The headlamps (Lo) turn ON. ● The cooling fan continues to rotate. |

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

Self-Diagnosis

UKS006H9

| DTC | Self-diagnosis item (CONSULT-II indication) | DTC detection condition | Inspection/Action |
|-------|------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| U1000 | CAN COMM CIRCUIT | When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more. | Refer to LAN-15 . "TROUBLE DIAG- NOSES WORK FLOW" . |
| | | When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more. | |
| U1001 | CAN COMM CIRCUIT | When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more. | |
| U1002 | SYSTEM COMM | When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less. | Start the inspection. Refer to the applicable section of the indicated control unit. |
| U1010 | CONTROL UNIT [CAN] | When an error is detected during the initial diagnosis for CAN controller of each control unit. | Replace the control unit indicating "U1010". |

CAN Diagnostic Support Monitor

CONSULT-II and CAN diagnostic support monitor (on-board diagnosis function) are used for detecting root cause.

MONITOR ITEM (CONSULT-II)

Example: CAN DIAG SUPPORT MNTR indication

| Without PAST | | | With PAST | | |
|---------------|--------|-------|---------------|--------|------------|
| SYSTEM | ENGINE | | SYSTEM | ENGINE | |
| DATE | | | DATE | | |
| P/# | | | P/# | | |
| | | PRSNT | | | PRSNT PAST |
| INITIAL DIAG | | OK | TRANSMIT DIAG | | OK OK |
| TRANSMIT DIAG | | OK | VDC/TCS/ABS | | - - |
| TCM | | OK | METER/M&A | | OK OK |
| VDC/TCS/ABS | | UNKWN | BCM/SEC | | OK OK |
| METER/M&A | | OK | ICC | | - - |
| ICC | | UNKWN | HVAC | | - - |
| BCM/SEC | | OK | TCM | | OK OK |
| IPDM E/R | | OK | EPS | | - - |
| | | | IPDM E/R | | OK OK |
| | | | e4WD | | - - |
| | | | AWD/4WD | | OK OK |

SKIB8742E

Without PAST

| Item | PRSNT | Description |
|--------------------------------------------|-------|------------------------------------------------------------------------------|
| Initial diagnosis | OK | Normal at present |
| | NG | Control unit error (Except for some control units) |
| Transmission diagnosis | OK | Normal at present |
| | UNKWN | Unable to transmit signals for 2 seconds or more. Diagnosis not performed |
| Control unit name (Reception diagnosis) | OK | Normal at present |
| | UNKWN | Unable to receive signals for 2 seconds or more. Diagnosis not performed |
| | UNKWN | No control unit for receiving signals. (No applicable optional parts) |

With PAST

| Item | PRSNT | PAST | Description |
|--------------------------------------------|-------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Transmission diagnosis | OK | OK | Normal at present and in the past |
| | | 1 – 39 | Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.) |
| | UNKWN | 0 | Unable to transmit signals for 2 seconds or more at present. |
| Control unit name (Reception diagnosis) | OK | OK | Normal at present and in the past |
| | | 1 – 39 | Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.) |
| | UNKWN | 0 | Unable to receive signals for 2 seconds or more at present |
| | - | - | Diagnosis not performed. No control unit for receiving signals. (No applicable optional parts) |

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

MONITOR ITEM (ON-BOARD DIAGNOSIS)

NOTE:

- For some models, CAN communication diagnosis result is received from the vehicle monitor. (CONSULT-II is not available.)
- Refer to [LAN-48, "MONITOR ITEM LIST \(ON-BOARD DIAGNOSIS\)"](#) for the details.

Example: Vehicle Display

| Item | Result indicated | Error counter | Description |
|------------------------------------------------------|------------------|---------------|-----------------------------------------------------------------------------------------------------------------------|
| CAN_COMM (Initial diagnosis) | OK | 0 | Normal at present |
| | NG | 1 – 50 | Control unit error (The number indicates how many times diagnosis has been run.) |
| CAN_CIRC_1 (Transmission diagnosis) | OK | 0 | Normal at present |
| | UNKWN | 1 – 50 | Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.) |
| CAN_CIRC_2 – 9 (Reception diagnosis of each unit) | OK | 0 | Normal at present |
| | UNKWN | 1 – 50 | Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.) |
| | | | Diagnosis not performed. |
| | | | No control unit for receiving signals. (No applicable optional parts) |

TROUBLE DIAGNOSES WORK FLOW

PFP:00004

Information Needed for Trouble Diagnosis

UKS006HB

CAN communication system performs trouble diagnosis with the following tools.

| Tool | Usage |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Interview sheet | For filling in vehicle information and interview with customer. |
| Data sheet | For attaching CONSULT-II data or on-board diagnosis data. |
| Diagnosis sheet | For detecting the root cause. (Diagnosis sheet includes system diagram for every CAN system type) |
| SELECT SYSTEM (CONSULT-II) | For checking the condition of control units and the status of CAN communication. |
| SELF-DIAG RESULTS (CONSULT-II) | |
| CAN DIAG SUPPORT MNTR (CONSULT-II) | |
| CAN communication signal chart | For converting information received from a customer into CAN communication signal transmission and reception. This information can be used to judge whether a circuit between control units is normal or abnormal. |
| Abbreviation list | For checking abbreviations in CAN communication signal chart and diagnosis sheet. |

How to Use CAN Communication Signal Chart

UKS006HC

The CAN communication signal chart lists the signals needed for trouble diagnosis. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.

Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive


| Signal name/Connecting unit | ECM | BCM | M&A | STRG | ABS | IPDM-E |
|------------------------------------|-----|-----|-----|------|-----|--------|
| A/C compressor feedback signal | T | | R | | | |
| A/C compressor request signal | T | | | | | R |
| Accelerator pedal position signal | T | | | | R | |
| Cooling fan motor operation signal | T | | | | | R |
| Engine coolant temperature signal | T | | R | | | |
| Engine speed signal | T | | R | | R | |
| Fuel consumption monitor signal | T | | R | | | |
| Malfunction indicator lamp signal | T | | R | | | |
| A/C switch signal | R | T | | | | |
| Ignition switch signal | | T | | | | R |
| Sleep/wake up signal | | T | R | | | R |

It indicates that an error occurs between ECM and M&A (Shaded area).

SKIB8715E

Trouble Diagnosis Flow Chart

UKS006HD



SKIB8716E

Trouble Diagnosis Procedure

INTERVIEW WITH CUSTOMER


Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment
- Result: Symptom

NOTE:

- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.
- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.
- Indication of the combination meter is important to detect the root cause because it is the most obvious from the customer, and it performs CAN communication with many units.



TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

INSPECTION OF VEHICLE CONDITION

- Check whether or not “U1000” or “U1001” is indicated on “SELF-DIAG RESULTS” by CONSULT-II.

NOTE:

Root cause cannot be detected using the procedure in this section if “U1000” or “U1001” is not indicated.

- Check whether the symptom is reproduced or not.

NOTE:

- Never turn the ignition switch OFF or disconnect the battery cable while the reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.

- The procedures for present errors differ from the procedures for past errors. Refer to [LAN-25](#).
"DETECT THE ROOT CAUSE".

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment. Then choose the correct diagnosis sheet.

NOTE:

There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.

CAN System Type Specification Chart (Style A)

NOTE:

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:

Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)

CAN System Specification Chart

Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

| | | | | | | |
|--------------------------------|------------------------|---------|------------------------|---------|------------------------|---------|
| Body type | Wagon | | | | | |
| Axle | 2WD | | | AWD | | |
| Engine | QR25DE | | VQ35DE | | | |
| Transmission | A/T | | CVT | | | |
| Brake control | ABS | | | VDC | | |
| Intelligent Key system | | X | | X | | X |
| CAN system type | 1 | 2 | 3 | 4 | 5 | 6 |
| Diagnosis sheet | (XX-XX) | (XX-XX) | (XX-XX) | (XX-XX) | (XX-XX) | (XX-XX) |
| CAN communication signal chart | XX-XX. "TYPE 1/TYPE 2" | | XX-XX. "TYPE 3/TYPE 4" | | XX-XX. "TYPE 5/TYPE 6" | |

X : Applicable

Check the vehicle equipment with the vehicle identification number plate.


Check the vehicle equipment.

The number indicates the CAN system type of the vehicle.

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.



- In the above example,
 - Checking VDC OFF switch leads to judge whether or not VDC is equipped.
 - Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.

For the above case, CAN system type is "6".

SKIB888E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

CAN System Type Specification Chart (Style B)

NOTE:

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:

Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

CAN System Specification Chart

Refer to the specification as shown in the chart.

| | | | |
|---------------------|----------------------------|----------------------------|----------------------------|
| Body type | Sedan | | |
| Axle | 2WD | | AWD |
| Engine | HR15DE | MR20DE | HR15DE |
| Transmission | A/T | CVT | A/T |
| Brake control | ABS | | |
| Specification chart | AAA. SPECIFICATION CHART A | YYX. SPECIFICATION CHART B | AAA. SPECIFICATION CHART C |

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

Select the applicable vehicle equipment. Refer to the specification chart.

x: Applicable

SPECIFICATION CHART B

Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

| | | | | | | | | | | | | |
|--------------------------------|--------------------------------------------------------------------------------------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| Body type | Sedan | | | | | | | | | | | |
| Axle | 2WD | | | | | | | | | | | |
| Engine | MR20DE | | | | | | | | | | | |
| Transmission | CVT | | | | | | | | | | | |
| Brake control | ABS | | | | | | | | | | | |
| Active AFS | | x | | | x | x | | | x | x | x | x |
| Intelligent Key system | | | x | | x | | x | x | x | x | x | x |
| Navigation system | | | | x | | x | x | | x | | x | |
| Automatic drive positioner | | | | | | | | x | | x | x | |
| CAN system type | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| Diagnosis sheet | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX | AA: XX |
| CAN communication signal chart | XX:XX. TYPE 9TYPE 10TYPE 11TYPE 12TYPE 13TYPE 14TYPE 15TYPE 16TYPE 17TYPE 18TYPE 19TYPE 20 | | | | | | | | | | | |

Check the vehicle equipment.





The number indicates the CAN system type of the vehicle.

x: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.

| | |
|---------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| With active AFS  | With Intelligent Key system  |
| With navigation system  | With automatic drive positioner  |

In the above example,

- Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
- Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
- Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

[For the above case, CAN system type is "20".]

SKIB889E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

Interview Sheet (Example)

| CAN Communication System Diagnosis Interview Sheet | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Date received: | 3, Feb. 2005 |
| Type: | DBA-KG11 |
| VIN No.: | KG11-005040 |
| Model: | BDRARGZ397EDA-E-J- |
| First registration: | 10, Jan. 2005 |
| Mileage: | 952 km |
| CAN system type: | Type 19 |
| Symptom (Results from interview with customer) | |
| <ul style="list-style-type: none">• Headlamps suddenly turn ON while driving the vehicle.• The engine does not restart after stopping the vehicle and turning the ignition switch OFF.• The cooling fan continues rotating while turning the ignition switch ON. | |
| Condition at inspection | |
| Error Symptom: <u>Present</u> / Past | |
| The engine does not start. While turning the ignition switch ON, <ul style="list-style-type: none">• The headlamps (Lo) turn ON, and the cooling fan continues rotating.• The interior lamp does not turn ON. On CONSULT-II screen, <ul style="list-style-type: none">• IPDM E/R is not indicated on SELECT SYSTEM.• ENGINE: U1001• BCM, ADAPTIVE LIGHT: U1000 | |

SKIB8890E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

CREATE DATA SHEET


Create CONSULT-II Data Attachment Sheet

Print out the following CONSULT-II screens, and attach them to the CONSULT-II data attachment sheet.

- SELECT SYSTEM
- SELF-DIAG RESULTS
- CAN DIAG SUPPORT MNTR

NOTE:

Some items may not be needed depending on CAN system type of vehicle.



SKIB8721E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

Create On-board Diagnosis Copy Sheet

Display the trouble diagnosis result of CAN communication with the on-board diagnosis function on the vehicle monitor, etc. Copy them on the on-board diagnosis copy sheet.


NOTE:

- For some models, CAN communication diagnosis result is received from the vehicle monitor. (CONSULT-II is not available.)
- For the details, refer to [LAN-63, "ON-BOARD DIAGNOSIS COPY SHEET"](#).

Example: Copy the diagnosis result of CAN communication from the vehicle monitor.

Vehicle monitor indication

| CAN DIAG SUPPORT MONITOR | | | |
|--------------------------|-------|----|--------|
| CAN_COMM | OK | 0 | Delete |
| CAN_CIRC_1 | OK | 0 | |
| CAN_CIRC_2 | UNKWN | 12 | |
| CAN_CIRC_3 | UNKWN | 12 | |
| CAN_CIRC_4 | UNKWN | 0 | |
| CAN_CIRC_5 | OK | 0 | |
| CAN_CIRC_6 | UNKWN | 0 | |
| CAN_CIRC_7 | OK | 0 | |
| CAN_CIRC_8 | UNKWN | 0 | |
| CAN_CIRC_9 | UNKWN | 50 | |



Vehicle monitor (Display control unit) CAN DIAG SUPPORT MONITOR copy sheet

| Indication item (Diagnosis item) | Vehicle monitor | | Indication item (Diagnosis item) | Vehicle monitor | |
|------------------------------------------|------------------|---------------|--------------------------------------------------------------------|------------------|---------------|
| | Result indicated | Error counter | | Result indicated | Error counter |
| CAN_COMM (Initial diagnosis) | OK | 0 | CAN_CIRC_5 (Receive diagnosis of Unified meter and A/C amp.) | OK | 0 |
| CAN_CIRC_1 (Transmit diagnosis) | OK | 0 | CAN_CIRC_6 | Not available | |
| CAN_CIRC_2 (Receive diagnosis of BCM) | UNKWN | 12 | CAN_CIRC_7 (Receive diagnosis of IPDM E/R) | OK | 0 |
| CAN_CIRC_3 (Receive diagnosis of ECM) | UNKWN | 12 | CAN_CIRC_8 | Not available | |
| CAN_CIRC_4 | Not available | | CAN_CIRC_9 | Not available | |

Result indicated: Fill in the indication (OK, NG or UNKWN).
Error counter: Fill in the indicated number.

SKIB8722E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

CREATE DIAGNOSIS SHEET

NOTE:

Be sure to use the diagnosis sheet for the correct CAN system type.


Print Diagnosis Sheet

Print the diagnosis sheet for the applicable CAN system type.

Check of Received Data

Check the created data sheet for missing information.

- For abbreviations, refer to [LAN-41, "Abbreviation List"](#).



DETECT THE ROOT CAUSE

Identify the root cause using the created diagnosis sheet.

Identifying the root cause

- Draw a line on the diagnosis sheet to indicate the possible cause. Narrow the search.

NOTE:

- Color-code when drawing lines.
- Do not draw a line onto an existing line.
- Drawing a line is not necessary if the circuit is shorted. Refer to [LAN-32, "Present Error — Short Circuit —"](#), [LAN-39, "Past Error — Short Circuit —"](#).

Refer to the following for details of the trouble diagnosis procedure.

- [LAN-26, "Present Error — Open Circuit —"](#)
- [LAN-32, "Present Error — Short Circuit —"](#)
- [LAN-33, "Past Error — Open Circuit —"](#)
- [LAN-39, "Past Error — Short Circuit —"](#)

NOTE:

When the root cause appears to be a branch line or short circuit, be sure to check the control unit as well as the communication line.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

Present Error — Open Circuit —

Identify the error circuit using information from the “SELECT SYSTEM” and “CAN DIAG SUPPORT MNTR” screens.

1. SELECT SYSTEM: Check the items indicated in “SELECT SYSTEM”. Draw a line on the diagnosis sheet to indicate the error circuit.

NOTE:


CAN communication line has no error if units other than Diag on CAN units are indicated. An error may be on the power supply of the control unit, DDL1 line or DDL2 line.

- a. “TRANSMISSION” which is Diag on CAN unit, is not indicated on “SELECT SYSTEM” screen. This indicates that DLC is not receiving a signal from TCM. Draw a line to indicate an error between DLC and TCM (line 1-a in the figure).

NOTE:

- Diag on CAN units are not indicated on the “SELECT SYSTEM” screen when the CAN line between Diag on CAN unit and the data link connector is open.
- For a description of Diag on CAN, refer to [LAN-6, "Diag on CAN"](#).

(Example)



SKIB8892E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

2. CAN DIAG SUPPORT MNTR: Check each item on "CAN DIAG SUPPORT MNTR". Draw a line on the diagnosis sheet to indicate the error circuit.
 - a. Reception item of "ENGINE": On "TCM", "UNKWN" is indicated. This means ECM cannot receive the signal from TCM. Draw a line to indicate an error between ECM and TCM (line 2-a in the figure).


NOTE:

If "UNKWN" is indicated on "TRANSMIT DIAG", then the control unit cannot transmit CAN communication signal to each unit. Draw a line between the control unit and the splice.

- b. Reception item of "ADAPTIVE LIGHT": On "TCM", "UNKWN" is indicated. This means AFS cannot receive the signal from TCM. Draw a line to indicate an error between AFS and TCM (line 2-b in the figure).
 - c. Reception item of "MULTI AV": "UNKWN" is not indicated. This indicates normal communication between AV and its receiving units. Do not draw any line.

(Example)

| SYSTEM | ENGINE | | SYSTEM | ADAPTIVE LIGHT | | SYSTEM | MULTI AV | |
|---------------|--------|------|---------------|----------------|------|---------------|----------|------|
| DATE | | | DATE | | | DATE | | |
| P/# | PRSNT | PAST | P/# | PRSNT | PAST | P/# | PRSNT | PAST |
| TRANSMIT DIAG | OK | OK | TRANSMIT DIAG | - | - | TRANSMIT DIAG | - | - |
| VDC/TCS/ABS | OK | OK | ECM | OK | OK | ECM | OK | OK |
| METER/M&A | - | - | METER/M&A | OK | OK | METER/M&A | OK | OK |
| BCM/SEC | OK | OK | TCM | UNKWN | 0 | BCM/SEC | - | - |
| ICC | - | - | STRG | OK | OK | HVAC | - | - |
| HVAC | - | - | EPS | - | - | IPDM E/R | - | - |
| TCM | UNKWN | 0 | IPDM E/R | OK | OK | TIRE-P | - | - |
| EPS | OK | OK | | | | | | |
| IPDM E/R | OK | OK | | | | | | |
| e4WD | - | - | | | | | | |
| AWD/4WD | - | - | | | | | | |



SKIB8725E


TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

- d. Reception item of "BCM": On "TCM", "UNKWN" is indicated. This means BCM cannot receive the signal from TCM. Draw a line to indicate an error between BCM and TCM (line 2-d in the figure).
- e. Reception item of "EPS" and "INTELLIGENT KEY": "UNKWN" is not indicated. This indicates normal communication between EPS and I-KEY and their receiving units. Do not draw any line.

NOTE:


On CAN DIAG SUPPORT MNTR (without PAST), "UNKWN" is indicated even though the item is not used in the trouble diagnosis. For the details of each item on CAN diagnostic support monitor, refer to [LAN-44, "CAN Diagnostic Support Monitor"](#) .



TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

- f. Reception item of "METER": On "TCM", "UNKWN" is indicated. This means M&A cannot receive the signal from TCM. Draw a line to indicate an error between M&A and TCM (line 2-f in the figure).
- g. Reception item of "AUTO DRIVE POS.": On "TCM", "UNKWN" is indicated. This means ADP cannot receive the signal from TCM. Draw a line to indicate an error between ADP and TCM (line 2-g in the figure).
- h. Reception item of "ABS": "UNKWN" is not indicated. This indicates normal communication between ABS and its receiving units. Do not draw any line.




TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

- i. Reception item of "IPDM E/R": "UNKWN" is not indicated. This indicates normal communication between IPDM-E and its receiving units. Do not draw any line.
3. Based on information received from "CAN DIAG SUPPORT MNTR", place a check mark on the known good CAN communication line between ECM and IPDM-E.
 - a. Through the previous procedure, the circuit between ADP splice and TCM has the most amount of lines (shade 3-a in the figure).
 - b. Place a check mark on the known good lines to establish the error circuit. Reception item of "IPDM E/R": On "ECM", "OK" is indicated. IPDM-E communicates normally with ECM. Put a check mark on the normal circuit between ECM and IPDM-E (check mark 3-b in the figure).

(Example)

| SYSTEM | IPDM E/R | |
|---------------|----------|------|
| DATE | PRSENT | PAST |
| TRANSMIT DIAG | OK | OK |
| ECM | OK | OK |
| BCM/SEC | OK | OK |



SKIB8728E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]


4. Through the above procedure, the error is detected in the TCM branch line (shaded in the figure).

NOTE:

For abbreviations, refer to [LAN-41, "Abbreviation List"](#).

5. Perform the inspection for the detected error circuit. For the inspection procedure, refer to [LAN-75, "Malfunction Area Chart"](#).

(Example)



▲ :Diag on CAN unit

< CONSULT-II printout checklist >

| | Item | Check box |
|----|------------------------------|-------------------------------------|
| 1 | SELECT SYSTEM | <input checked="" type="checkbox"/> |
| 2 | ENGINE | <input checked="" type="checkbox"/> |
| 3 | ADAPTIVE LIGHT [▲] | <input checked="" type="checkbox"/> |
| 4 | MULTI AV [▲] | <input checked="" type="checkbox"/> |
| 5 | BCM [▲] | <input checked="" type="checkbox"/> |
| 6 | EPS [▲] | <input checked="" type="checkbox"/> |
| 7 | INTELLIGENT KEY [▲] | <input checked="" type="checkbox"/> |
| 8 | METER [▲] | <input checked="" type="checkbox"/> |
| 9 | AUTO DRIVE POS. [▲] | <input checked="" type="checkbox"/> |
| 10 | ABS | <input checked="" type="checkbox"/> |
| 11 | TRANSMISSION [▲] | N-IDC |
| 12 | IPDM E/R [▲] | <input checked="" type="checkbox"/> |

Possible root cause

· Error between TCM and splice.
· Error in TCM.

Inspection result

SKIB8893E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

Past Error — Open Circuit —

Review CAN communication signal chart based on information received from the interview with the customer and on past error information from SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR.

- SELF-DIAG RESULTS: Inspect the control units indicating "U1000" or "U1001" on SELF-DIAG RESULTS.

(Example)

| | | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>SYSTEM ENGINE DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p style="border: 1px dashed black; padding: 2px;">CAN COMM CIRCUIT 1t [U1001]</p> | <p>SYSTEM ADAPTIVE LIGHT DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | <p>SYSTEM MULTI AV DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | <p>SYSTEM BCM DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> |
| <p>SYSTEM EPS DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p style="border: 1px dashed black; padding: 2px;">CAN COMM CIRCUIT PAST [U1000]</p> | <p>SYSTEM INTELLIGENT KEY DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | <p>SYSTEM METER DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p style="border: 1px dashed black; padding: 2px;">CAN COMM CIRCUIT 3 [U1000]</p> | <p>SYSTEM AUTO DRIVE POS. DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> |
| <p>SYSTEM ABS DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p style="border: 1px dashed black; padding: 2px;">CAN COMM CIRCUIT 3 [U1000]</p> | <p>SYSTEM TRANSMISSION DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p style="border: 1px dashed black; padding: 2px;">CAN COMM CIRCUIT 3 [U1000]</p> | <p>SYSTEM IPDM E/R DATE P/#</p> <p style="text-align: center; border: 1px solid black; padding: 5px;">SELF-DIAG RESULTS</p> <p>DTC RESULTS TIME</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p> | |

SKIB8731E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

2. CAN DIAG SUPPORT MNTR (with PAST): Check the CAN DIAG SUPPORT MNTR (with PAST) of units indicating "U1000" or "U1001" on SELF-DIAG RESULTS. Draw a line on the diagnosis sheet to indicate the possible error circuit.


NOTE:

For the details of each indication on CAN DIAG SUPPORT MNTR, refer to [LAN-44, "CAN Diagnostic Support Monitor"](#).

- a. Reception item of "ENGINE": "VDC/TCS/ABS", "3" is indicated in the "PAST". This means ECM could not receive the signal from ABS in the past. Draw a line between ECM and ABS (line 2-a in the figure).
- b. Reception item of "METER": "VDC/TCS/ABS", "3" is indicated in the "PAST". This means M&A could not receive the signal from ABS in the past. Draw a line between M&A and ABS (line 2-b in the figure).
- c. Reception item of "TRANSMISSION": "VDC/TCS/ABS", "3" is indicated in the "PAST". This means TCM could not receive the signal from ABS in the past. Draw a line between TCM and ABS (line 2-c in the figure).

(Example)

| SYSTEM ENGINE | | | SYSTEM METER | | | SYSTEM TRANSMISSION | | |
|---------------|--------|------|---------------|--------|------|---------------------|--------|------|
| DATE | | | DATE | | | DATE | | |
| P/# | PRSENT | PAST | P/# | PRSENT | PAST | P/# | PRSENT | PAST |
| TRANSMIT DIAG | OK | OK | TRANSMIT DIAG | OK | OK | TRANSMIT DIAG | OK | OK |
| VDC/TCS/ABS | OK | 3 | ECM | OK | OK | VDC/TCS/ABS | OK | 3 |
| METER/M&A | - | - | TCM | OK | OK | METER/M&A | OK | OK |
| BCM/SEC | OK | OK | BCM/SEC | OK | OK | BCM/SEC | OK | OK |
| ICC | - | - | VDC/TCS/ABS | OK | 3 | ICC | - | - |
| HVAC | - | - | IPDM E/R | - | - | e4WD | - | - |
| TCM | OK | OK | DISPLAY | - | - | AWD/4WD | - | - |
| EPS | OK | OK | I-KEY | OK | OK | | | |
| IPDM E/R | OK | OK | EPS | OK | OK | | | |
| e4WD | - | - | AWD/4WD | - | - | | | |
| AWD/4WD | - | - | e4WD | - | - | | | |
| | | | ICC | - | - | | | |
| | | | LANE KEEP | - | - | | | |
| | | | TIRE-P | - | - | | | |



SK1B8732E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]


3. CAN DIAG SUPPORT MNTR (without PAST): Check the CAN DIAG SUPPORT MNTR (without PAST) of units indicating "U1000" or "U1001" on SELF-DIAG RESULTS. Draw a line on the diagnosis sheet to indicate the possible error circuit.

NOTE:

- While an error occurred in the past according to SELF-DIAG RESULTS, it is unclear which signal is not received. Assume that errors were detected from all reception items.
 - Draw a single line among the unit and all reception items. (Work flow differs from CAN DIAG SUPPORT MNTR (with PAST).)
- a. Reception item of "EPS": Assume that the unit could not receive the signals from ECM, ABS, and M&A. Draw a line among EPS, ECM, ABS, and M&A (line 3-a in the figure).
- b. Reception item of "ABS": Assume that the unit could not receive the signal from ECM. Draw a line between ABS and ECM (line 3-b in the figure).

(Example)

| SYSTEM | EPS | SYSTEM | ABS |
|---------------|-------|---------------|-------|
| DATE | | DATE | |
| P/# | PRSNT | P/# | PRSNT |
| TRANSMIT DIAG | OK | INITIAL DIAG | OK |
| ECM | OK | TRANSMIT DIAG | OK |
| VDC/TCS/ABS | OK | ECM | OK |
| METER/M&A | OK | | |



SKIB8733E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

4. Search for the possible cause using CAN communication signal chart using information from the interview with the customer.

NOTE:

For the details of CAN communication signal, refer to [LAN-50, "CAN Communication Signal Chart"](#) .

- a. ABS warning lamp turned ON and speedometer did not move: This means that “ABS warning lamp signal” and “Vehicle speed signal” could not communicate between M&A and ABS (4-a in the figure).
- b. The tachometer moved normally: This means that “Engine speed signal” could communicate normally between ECM and M&A (4-b in the figure).

(Example)


First registration:

CAN system type:

Symptom (Results from interview with customer)

While driving,

- ABS warning lamp turned ON.
- Speedometer did not move.
- Tachometer moved normally.



CAN Communication Signal Chart

T: Transmit R: Receive

| Signal name/Connecting unit | ECM | AFS ¹ | AV ² | BCM | EPS | I-KEY ³ | M&A | STRG ¹ | ADP ⁴ | ABS | TCM | IPDM-E |
|------------------------------------------|--------|------------------|-----------------|----------------|-----|--------------------|-----|-------------------|------------------|-----|--------|--------|
| A/C compressor request signal | T | | | | | | | | | | | R |
| Accelerator pedal position signal | T | | | | | | | | | | R | |
| Closed throttle position signal | T | | | | | | | | | | R | |
| Cooling fan speed request signal | T | | | | | | | | | | | R |
| Engine and CVT integrated control signal | T R | | | | | | | | | | R T | |
| Engine coolant temperature signal | T | | | | | | R | | | | R | |
| 4-b Engine speed signal | T | | | | | | R | | | | R | |
| Engine status signal | T | | R | | R | | | | | | | |
| Fuel consumption monitor signal | T | | R | | | | R | | | | | |
| MI signal | T | | | | | | R | | | | | |
| Wide open throttle position signal | T | | | | | | | | | | R | |
| 4-a ABS warning lamp signal | | | | | | | R | | | T | | |
| Brake warning lamp signal | | | | | | | R | | | T | | |
| Steering angle sensor signal | | R | | | | | | T | | | | |
| Vehicle speed signal | R | | | | R | | R | | | T | R | |
| Input shaft revolution signal | R | | R | | R | R | T | | R | | | T |
| Output shaft revolution signal | R | | | | | | | | | | | T |
| Shift position indicator signal | R | R | R | R ⁵ | | | R | | R ⁶ | | | T |
| Second position indicator signal | | | | | | | R | | | | | T |
| Front wiper stop position signal | | | | R | | | | | | | | T |
| High beam status signal | R | R | | | | | | | | | | T |
| Low beam status signal | R | R | | | | | | | | | | T |


SKIB8895E

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]

5. Fill out the diagnosis sheet based on information from step 4.
 - a. The ABS warning lamp turned ON and speedometer did not move: Assume that a possible cause is no communication between M&A and ABS. Draw a line between M&A and ABS. (Line 5-a in the figure).
 - b. The tachometer moved normally: Put check marks between ECM and M&A. The circuit between ECM and M&A is functioning properly (check marks 5-b in the figure).

(Example)



A
B
C
D
E
F
G
H
I
J

LAN

L
M

TROUBLE DIAGNOSES WORK FLOW

[CAN FUNDAMENTAL]


6. The circuit which has the most amount of lines are the possible cause. Error is detected from ABS actuator and electric unit (control unit) branch line (shaded in the figure).

NOTE:

For abbreviations, refer to [LAN-41, "Abbreviation List"](#) .

7. Perform the inspection procedure for the possible cause. Refer to [LAN-75, "Malfunction Area Chart"](#) .

(Example)



< CONSULT-II printout checklist >

| | Item | Check box |
|----|------------------------------|-------------------------------------|
| 1 | SELECT SYSTEM | <input checked="" type="checkbox"/> |
| 2 | ENGINE | <input checked="" type="checkbox"/> |
| 3 | ADAPTIVE LIGHT [▲] | <input checked="" type="checkbox"/> |
| 4 | MULTI AV [▲] | <input checked="" type="checkbox"/> |
| 5 | BCM [▲] | <input checked="" type="checkbox"/> |
| 6 | EPS [▲] | <input checked="" type="checkbox"/> |
| 7 | INTELLIGENT KEY [▲] | <input checked="" type="checkbox"/> |
| 8 | METER [▲] | <input checked="" type="checkbox"/> |
| 9 | AUTO DRIVE POS. [▲] | <input checked="" type="checkbox"/> |
| 10 | ABS | <input checked="" type="checkbox"/> |
| 11 | TRANSMISSION [▲] | <input checked="" type="checkbox"/> |
| 12 | IPDM E/R [▲] | <input checked="" type="checkbox"/> |

Possible root cause

- Error between ABS actuator and electric unit (control unit) and splice.
- Error in ABS actuator and electric unit (control unit).

Inspection result

SKIB8896E

INDEX FOR DTC

[CAN]

INDEX FOR DTC

PFP:00004

DTC No. Index

UKS006HF

| DTC | Self-diagnosis item (CONSULT-II indication) | DTC detection condition | Inspection |
|-------|------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| U1000 | CAN COMM CIRCUIT | When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more. | Refer to LAN-41. "HOW TO USE THIS SECTION" . |
| | | When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more. | |
| U1001 | CAN COMM CIRCUIT | When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more. | |
| U1002 | SYSTEM COMM | When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less. | Start the inspection. Refer to the applicable section of the indicated control unit. |
| U1010 | CONTROL UNIT [CAN] | When an error is detected during the initial diagnosis for CAN controller of each control unit. | Replace the control unit indicating "U1010". |

HOW TO USE THIS SECTION

PFP:00008

Caution

UKS006HG

- This section describes information peculiar to a vehicle, sheets for trouble diagnosis, and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Procedure"](#).

Abbreviation List

UKS006HH

Abbreviations in CAN communication signal chart, and the diagnosis sheet are as per the following list.

| Abbreviation | Unit name | SELECT SYSTEM (CONSULT-II) | CAN DIAG SUPPORT MNTR (CONSULT-II) |
|--------------|-----------------------------------------------|-------------------------------|---------------------------------------|
| 4WD | Transfer control unit | ALL MODE AWD/4WD | AWD/4WD |
| A-BAG | Air bag diagnosis sensor unit | AIR BAG | — |
| ABS | ABS actuator and electric unit (control unit) | ABS | VDC/TCS/ABS |
| ADP | Driver seat control unit | AUTO DRIVE POS. | — |
| BCM | BCM | BCM | BCM/SEC |
| DISP | Display control unit | — | — |
| DLC | Data link connector | — | — |
| ECM | ECM | ENGINE | ECM |
| HVAC | Front air control | — | — |
| IPDM-E | IPDM E/R | IPDM E/R | IPDM E/R |
| M&A | Combination meter | METER | METER/M&A |
| STRG | Steering angle sensor | — | STRG |
| TCM | TCM | A/T | TCM |

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS006HI

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS006HJ

Use CONSULT-II CONVERTER when connecting CONSULT-II to data link connector.

CAUTION:

CAN communication does not function properly if CONSULT-II is used without connecting CONSULT-II CONVERTER.

Precautions for Trouble Diagnosis

UKS006HK

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

UKS006HL

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).




PRECAUTIONS

[CAN]

- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSIS

[CAN]

PFP:00004

UKS006HM

TROUBLE DIAGNOSIS

CAN Diagnostic Support Monitor

Use "CAN DIAG SUPPORT MNTR" for detecting the root cause.

MONITOR ITEM LIST (CONSULT-II)

ECM

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | | Error | |
|---------------|--------------------------------------------------------|--------------------------------------------------------------------------------|---------------------|---------------------|-------|------|
| | | | PRSNT | PAST | PRSNT | PAST |
| ENGINE | TRANSMIT DIAG | Signal transmission status | OK | OK or 1 – 39* | UNKWN | 0 |
| | VDC/TCS/ABS | Signal receiving status from the ABS actuator and electric unit (control unit) | | | | |
| | METER/M&A | Signal receiving status from the combination meter | | | | |
| | BCM/SEC | Signal receiving status from the BCM | | | | |
| | ICC | Not used even though indicated | | | | |
| | HVAC | | | | | |
| | TCM | Signal receiving status from the TCM | OK | OK or 1 – 39* | UNKWN | 0 |
| | EPS | Not used even though indicated | | | | |
| | IPDM E/R | Signal receiving status from the IPDM E/R | OK | OK or 1 – 39* | UNKWN | 0 |
| | e4WD | Not used even though indicated | | | | |
| AWD/4WD | Signal receiving status from the transfer control unit | OK | OK or 1 – 39* | UNKWN | 0 | |

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

TCM

NOTE:

Replace the unit when "NG" is indicated on the "INITIAL DIAG".

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | Error |
|---------------|-----------------------|--------------------------------------------------------------------------------|--------|-------|
| | | | PRSNT | |
| A/T | INITIAL DIAG | Status of CAN controller | OK | NG |
| | TRANSMIT DIAG | Signal transmission status | | |
| | ECM | Signal receiving status from the ECM | | |
| | VDC/TCS/ABS | Signal receiving status from the ABS actuator and electric unit (control unit) | | |
| | METER/M&A | Signal receiving status from the combination meter | | |
| | ICC/e4WD | Not used even though indicated | | |
| | AWD/4WD | Signal receiving status from the transfer control unit | OK | UNKWN |

TROUBLE DIAGNOSIS

[CAN]

Transfer Control Unit (Part Time 4WD Models)

NOTE:

Replace the unit when “NG” is indicated on the “INITIAL DIAG”.

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | Error |
|------------------|-----------------------|--------------------------------------------------------------------------------|--------|-------|
| | | | PRSNT | |
| ALL MODE AWD/4WD | INITIAL DIAG | Status of CAN controller | OK | NG |
| | TRANSMIT DIAG | Signal transmission status | | UNKWN |
| | ECM | Signal receiving status from the ECM | | |
| | VDC/TCS/ABS | Signal receiving status from the ABS actuator and electric unit (control unit) | | |
| | TCM | Signal receiving status from the TCM | | |
| | METER/M&A | Signal receiving status from the combination meter | | |

Transfer Control Unit (All-mode 4WD Models)

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | | Error | |
|------------------|-----------------------|--------------------------------------------------------------------------------|--------|---------------|-------|------|
| | | | PRSNT | PAST | PRSNT | PAST |
| ALL MODE AWD/4WD | TRANSMIT DIAG | Signal transmission status | OK | OK or 1 – 39* | UNKWN | 0 |
| | ECM | Signal receiving status from the ECM | | | | |
| | VDC/TCS/ABS | Signal receiving status from the ABS actuator and electric unit (control unit) | | | | |
| | TCM | Signal receiving status from the TCM | | | | |
| | STRG | Signal receiving status from the steering angle sensor | | | | |

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

Driver Seat Control Unit

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | | Error | |
|-----------------|-----------------------|----------------------------------------------------|--------|---------------|-------|------|
| | | | PRSNT | PAST | PRSNT | PAST |
| AUTO DRIVE POS. | TRANSMIT DIAG | Not used even though indicated | | | | |
| | METER/M&A | Signal receiving status from the combination meter | OK | OK or 1 – 39* | UNKWN | 0 |
| | BCM/SEC | Signal receiving status from the BCM | | | | |
| | TCM | Signal receiving status from the TCM | | | | |

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

TROUBLE DIAGNOSIS

[CAN]

BCM

NOTE:

Replace the unit when “NG” is indicated on the “INITIAL DIAG”.

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | Error |
|---------------|-----------------------|----------------------------------------------------|--------|-------|
| | | | PRSNT | |
| BCM | INITIAL DIAG | Status of CAN controller | OK | NG |
| | TRANSMIT DIAG | Signal transmission status | | UNKWN |
| | ECM | Signal receiving status from the ECM | | |
| | IPDM E/R | Signal receiving status from the IPDM E/R | | |
| | METER/M&A | Signal receiving status from the combination meter | | |
| | I-KEY | Not used even though indicated | | |

Combination Meter

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | | Error | |
|---------------|-----------------------|--------------------------------------------------------------------------------|--------|---------------------|-------|------|
| | | | PRSNT | PAST | PRSNT | PAST |
| METER | TRANSMIT DIAG | Signal transmission status | OK | OK or 1 – 39* | UNKWN | 0 |
| | ECM | Signal receiving status from the ECM | | | | |
| | TCM | Signal receiving status from the TCM | | | | |
| | BCM/SEC | Signal receiving status from the BCM | | | | |
| | VDC/TCS/ABS | Signal receiving status from the ABS actuator and electric unit (control unit) | | | | |
| | IPDM E/R | Signal receiving status from the IPDM E/R | | | | |
| | I-KEY | Not used even though indicated | | | | |
| | EPS | | | | | |
| | AWD/4WD | | | | | |
| | e4WD | | | | | |
| | ICC | | | | | |
| | LANE KEEP | | | | | |
| | TIRE-P | | | | | |

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

ABS Actuator and Electric Unit (Control Unit)

| SELECT SYSTEM | CAN DIAG SUPPORT MNTR | Description | Normal | Error |
|---------------|-----------------------|--------------------------------------------------------|--------|-----------------------|
| | | | PRSNT | |
| ABS | INITIAL DIAG | Status of CAN controller | OK | NG ^{Caution} |
| | TRANSMIT DIAG | Signal transmission status | | UNKWN |
| | ECM | Signal receiving status from the ECM | | |
| | TCM | Signal receiving status from the TCM | | |
| | METER/M&A | Not used even though indicated | | |
| | STRG | Signal receiving status from the steering angle sensor | OK | UNKWN |
| | ICC | Not used even though indicated | | |
| | AWD/4WD | Signal receiving status from the transfer control unit | OK | UNKWN |

CAUTION:

Never replace the unit even when “NG” is indicated on the “INITIAL DIAG” at this stage. Follow the trouble diagnosis procedures.

TROUBLE DIAGNOSIS

[CAN]

IPDM E/R

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

| SELECT SYS- TEM | CAN DIAG SUP- PORT MNTR | Description | Normal | | Error | |
|--------------------|----------------------------|--------------------------------------|--------|---------------------|-------|------|
| | | | PRSNT | PAST | PRSNT | PAST |
| IPDM E/R | TRANSMIT DIAG | Signal transmission status | OK | OK or 1 – 39* | UNKWN | 0 |
| | ECM | Signal receiving status from the ECM | | | | |
| | BCM/SEC | Signal receiving status from the BCM | | | | |

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSIS

[CAN]

MONITOR ITEM LIST (ON-BOARD DIAGNOSIS)

Display Control Unit

NOTE:

CAN diagnostic support monitor of the display control unit is indicated on the vehicle display. Refer to [AV-104](#), "[Self-Diagnosis Mode \(DCU\)](#)".

(Example)

| CAN DIAG SUPPORT MONITOR | | | |
|--------------------------|-------|---|---------------------------------------|
| CAN_COMM | OK | 0 | <input type="button" value="Delete"/> |
| CAN_CIRC_1 | OK | 0 | |
| CAN_CIRC_2 | OK | 0 | |
| CAN_CIRC_3 | OK | 0 | |
| CAN_CIRC_4 | OK | 0 | |
| CAN_CIRC_5 | OK | 0 | |
| CAN_CIRC_6 | UNKWN | 1 | |
| CAN_CIRC_7 | OK | 0 | |
| CAN_CIRC_8 | UNKWN | 1 | |
| CAN_CIRC_9 | UNKWN | 1 | |

PKIC6981E

| Unit name | Diagnosis item | Description | Indicated items on CAN DIAG SUPPORT MONITOR | | | |
|----------------------|----------------|----------------------------------------------------|---------------------------------------------|---------------------------|------------------|---------------------------|
| | | | Normal | | Error | |
| | | | Result indicated | Error counter (Reference) | Result indicated | Error counter (Reference) |
| Display control unit | CAN_COMM | Status of CAN controller | OK | 0 or 1 – 50* | NG | 1 – 50* |
| | CAN_CIRC_1 | Signal transmission status | | | | |
| | CAN_CIRC_2 | Signal receiving status from the BCM | | | | |
| | CAN_CIRC_3 | Signal receiving status from the ECM | | | | |
| | CAN_CIRC_4 | Signal receiving status from the front air control | | | | |
| | CAN_CIRC_5 | Signal receiving status from the combination meter | | | | |
| | CAN_CIRC_6 | Not used even though indicated | | | | |
| | CAN_CIRC_7 | Signal receiving status from the IPDM E/R | OK | 0 or 1 – 50* | UNKWN | 1 – 50* |
| | CAN_CIRC_8 | Not used even though indicated | | | | |
| CAN_CIRC_9 | | | | | | |

*: The error counter stops counting when it reaches "50" and holds "50" until it is deleted.

CAN System Specification Chart

Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

NOTE:

Refer to [LAN-19, "CHECK OF CAN SYSTEM TYPE \(HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART\)"](#) for how to use CAN system specification chart.





| | | | | | | | | | | |
|--------------------------------|-------------------------------------------------------|------------------------|------------------------|------------------------|-----------------------------------------|------------------------|------------------------|--------------------------------------------------------|------------------------|------------------------|
| Body type | Wagon | | | | | | | | | |
| Axle | 2WD | | | 4WD(Part time) | | | 4WD(All-mode) | | | |
| Engine | VQ40DE | | | | | | | | | |
| Transmission | A/T | | | | | | | | | |
| Brake control | VDC | | | | | | | | | |
| Automatic drive positioner | | | × | × | | | | | × | × |
| Navigation system | | | | × | | | | | | × |
| Automatic air conditioner | | × | × | × | | × | | × | × | × |
| CAN system type | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| Diagnosis sheet | LAN-64 | LAN-65 | LAN-66 | LAN-67 | LAN-68 | LAN-69 | LAN-70 | LAN-71 | LAN-72 | LAN-73 |
| CAN communication signal chart | LAN-50, "TYPE 1/TYPE 2/TYPE 3/TYPE 4" | | | | LAN-51, "TYPE 5/TYPE 6" | | | LAN-53, "TYPE 7/TYPE 8/TYPE 9/TYPE 10" | | |

×: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.

| | |
|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>With All-mode 4WD</p>  | <p>With automatic drive positioner</p>  <p style="text-align: center;">Seat memory switch</p> |
| <p>With navigation system</p>  | <p>With automatic air conditioner</p> <p style="text-align: center;">Front air control (with auto A/C)</p>  |

BKIA0220E

TROUBLE DIAGNOSIS

[CAN]

UKS006HO

CAN Communication Signal Chart

Refer to [LAN-15, "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

TYPE 1/TYPE 2/TYPE 3/TYPE 4

NOTE:

Refer to [LAN-41, "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

| Signal name/Connecting unit | ECM | TCM | ADP ^{*1} | BCM | HVAC ^{*2} | M&A | STRG | DISP ^{*3} | ABS | IPDM-E |
|---------------------------------------|-----|-----|-------------------|-----|--------------------|-----|------|--------------------|-----|--------|
| A/C compressor request signal | T | | | | | | | | | R |
| Accelerator pedal position signal | T | R | | | | | | | R | |
| ASCD CRUISE lamp signal | T | | | | | R | | | | |
| ASCD OD cancel request | T | R | | | | | | | | |
| ASCD operation signal | T | R | | | | | | | | |
| ASCD SET lamp signal | T | | | | | R | | | | |
| Battery voltage signal | T | R | | | | | | | | |
| Closed throttle position signal | T | R | | | | | | | | |
| Cooling fan speed request signal | T | | | | | | | | | R |
| Engine coolant temperature signal | T | | | | R | R | | | | |
| Engine speed signal | T | R | | | R | R | | R | R | |
| Engine status signal | T | | | R | | | | | | |
| Fuel consumption monitor signal | T | | | | | R | | | | |
| | | | | | | T | | R | | |
| Malfunction indicator lamp signal | T | | | | | R | | | | |
| Power generation command value signal | T | | | | | | | | | R |
| Wide open throttle position signal | T | R | | | | | | | | |
| A/T fluid temperature sensor signal | | T | | | | R | | | | |
| A/T position indicator lamp signal | | T | | | | R | | | | |
| A/T self-diagnosis signal | R | T | | | | | | | | |
| O/D OFF indicator signal | | T | | | | R | | | | |
| Output shaft revolution signal | R | T | | | | | | | | |
| P range signal | | T | R | | | R | | | R | |
| Turbine revolution signal | R | T | | | | | | | | |
| System setting signal | | | R | R | | | | T | | |
| | | | T | T | | | | R | | |
| A/C switch signal | R | | | T | R | | | | | |
| Blower fan motor switch signal | R | | | T | | | | | | |
| Buzzer output signal | | | | T | | R | | | | |
| Day time running light request signal | | | | T | | R | | | | R |
| Door switch signal | | | R | T | | R | | R | | R |
| Front fog light request signal | | | | T | | R | | | | R |
| Front wiper request signal | | | | T | | | | | | R |
| High beam request signal | | | | T | | R | | | | R |
| Horn chirp signal | | | | T | | | | | | R |
| Ignition switch signal | | | R | T | | | | | | |

TROUBLE DIAGNOSIS

[CAN]

| Signal name/Connecting unit | ECM | TCM | ADP*1 | BCM | HVAC*2 | M&A | STRG | DISP*3 | ABS | IPDM-E | |
|-------------------------------------|-----|-----|-------|-----|--------|-----|------|--------|-----|--------|-----|
| Key fob door unlock signal | | | R | T | | | | | | | A |
| Key fob ID signal | | | R | T | | | | | | | B |
| Key switch signal | | | R | T | | | | | | | |
| Low beam request signal | | | | T | | | | | | R | C |
| Position light request signal | | | | T | | R | | | | R | |
| Rear window defogger switch signal | | | | T | R | | | | | R | |
| Sleep wake up signal | | | R | T | | R | | | | R | D |
| Theft warning horn request signal | | | | T | | | | | | R | |
| Tire pressure data signal | | | | T | | | | R | | | E |
| Tire pressure signal | | | | T | | R | | R | | | |
| Turn indicator signal | | | | T | | R | | | | | |
| A/C switch/indicator signal | | | | | R | | | T | | | F |
| | | | | | T | | | R | | | |
| 1st position switch signal | | R | | | | T | | | | | G |
| Distance to empty signal | | | | | | T | | R | | | |
| Fuel level low warning signal | | | | | | T | | R | | | |
| Fuel level sensor signal | R | | | | | T | | | | | H |
| Overdrive control switch signal | | R | | | | T | | | | | |
| Seat belt buckle switch signal | | | | R | | T | | | | | I |
| Stop lamp switch signal | | R | | | | T | | | | | |
| Vehicle speed signal | | | | | R | R | | | T | | J |
| | R | R | R | R | R | T | | R | | | |
| Steering angle sensor signal | | | | | | | T | | R | | |
| ABS warning lamp signal | | | | | | R | | | T | | LAN |
| Brake warning lamp signal | | | | | | R | | | T | | |
| SLIP indicator lamp signal | | | | | | R | | | T | | |
| VDC OFF indicator lamp signal | | | | | | R | | | T | | L |
| Front wiper stop position signal | | | | R | | | | | | T | |
| High beam status signal | R | | | | | | | | | T | M |
| Low beam status signal | R | | | | | | | | | T | |
| Rear window defogger control signal | R | | | | R | | | | | T | |

- *1: Models with automatic drive positioner
- *2: Models with automatic air conditioner
- *3: Models with navigation system

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

TYPE 5/TYPER 6

NOTE:

Refer to [LAN-41, "Abbreviation List"](#) for the abbreviations of the connecting units.

TROUBLE DIAGNOSIS

[CAN]

T: Transmit R: Receive

| Signal name/Connecting unit | ECM | TCM | 4WD | BCM | HVAC*1 | M&A | STRG | ABS | IPDM-E |
|---------------------------------------|-----|-----|-----|-----|--------|-----|------|-----|--------|
| A/C compressor request signal | T | | | | | | | | R |
| Accelerator pedal position signal | T | R | | | | | | R | |
| ASCD CRUISE lamp signal | T | | | | | R | | | |
| ASCD OD cancel request | T | R | | | | | | | |
| ASCD operation signal | T | R | | | | | | | |
| ASCD SET lamp signal | T | | | | | R | | | |
| Battery voltage signal | T | R | | | | | | | |
| Closed throttle position signal | T | R | | | | | | | |
| Cooling fan speed request signal | T | | | | | | | | R |
| Engine coolant temperature signal | T | | | | R | R | | | |
| Engine speed signal | T | R | R | | R | R | | R | |
| Engine status signal | T | | | R | | | | | |
| Fuel consumption monitor signal | T | | | | | R | | | |
| Malfunction indicator lamp signal | T | | | | | R | | | |
| Power generation command value signal | T | | | | | | | | R |
| Wide open throttle position signal | T | R | | | | | | | |
| A/T fluid temperature sensor signal | | T | | | | R | | | |
| A/T position indicator lamp signal | | T | R | | | R | | | |
| A/T self-diagnosis signal | R | T | | | | | | | |
| O/D OFF indicator signal | | T | | | | R | | | |
| Output shaft revolution signal | R | T | R | | | | | | |
| P range signal | | T | | | | R | | R | |
| Turbine revolution signal | R | T | | | | | | | |
| A/C switch signal | R | | | T | R | | | | |
| Blower fan motor switch signal | R | | | T | | | | | |
| Buzzer output signal | | | | T | | R | | | |
| Day time running light request signal | | | | T | | R | | | R |
| Door switch signal | | | | T | | R | | | R |
| Front fog light request signal | | | | T | | R | | | R |
| Front wiper request signal | | | | T | | | | | R |
| High beam request signal | | | | T | | R | | | R |
| Horn chirp signal | | | | T | | | | | R |
| Ignition switch signal | | | | T | | | | | R |
| Low beam request signal | | | | T | | | | | R |
| Position light request signal | | | | T | | R | | | R |
| Rear window defogger switch signal | | | | T | R | | | | R |
| Sleep wake up signal | | | | T | | R | | | R |
| Theft warning horn request signal | | | | T | | | | | R |
| Tire pressure signal | | | | T | | R | | | |
| Turn indicator signal | | | | T | | R | | | |
| 1st position switch signal | | R | | | | T | | | |
| Fuel level sensor signal | R | | | | | T | | | |

TROUBLE DIAGNOSIS

[CAN]

| Signal name/Connecting unit | ECM | TCM | 4WD | BCM | HVAC*1 | M&A | STRG | ABS | IPDM-E |
|-------------------------------------|-----|-----|-----|-----|--------|-----|------|-----|--------|
| Overdrive control switch signal | | R | | | | T | | | |
| Seat belt buckle switch signal | | | | R | | T | | | |
| Stop lamp switch signal | | R | | | | T | | | |
| | | | R | | | | | T | |
| Vehicle speed signal | | | R | | R | R | | T | |
| | R | R | | R | R | T | | | |
| Steering angle sensor signal | | | | | | | T | R | |
| ABS warning lamp signal | | | | | | R | | T | |
| Brake warning lamp signal | | | | | | R | | T | |
| HDC indicator lamp signal*2 | | | | | | R | | T | |
| SLIP indicator lamp signal | | | | | | R | | T | |
| VDC OFF indicator lamp signal | | | | | | R | | T | |
| Front wiper stop position signal | | | | R | | | | | T |
| High beam status signal | R | | | | | | | | T |
| Low beam status signal | R | | | | | | | | T |
| Rear window defogger control signal | R | | | | R | | | | T |

● *1: Models with automatic air conditioner

● *2: Models with HDC

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

TYPE 7/TYPER 8/TYPER 9/TYPER 10

NOTE:

Refer to [LAN-41, "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

| Signal name/Connecting unit | ECM | TCM | 4WD | ADP*1 | BCM | HVAC*2 | M&A | STRG | DISP*3 | ABS | IPDM-E |
|---------------------------------------|-----|-----|-----|-------|-----|--------|-----|------|--------|-----|--------|
| A/C compressor request signal | T | | | | | | | | | | R |
| Accelerator pedal position signal | T | R | R | | | | | | | R | |
| ASCD CRUISE lamp signal | T | | | | | | R | | | | |
| ASCD OD cancel request | T | R | | | | | | | | | |
| ASCD operation signal | T | R | | | | | | | | | |
| ASCD SET lamp signal | T | | | | | | R | | | | |
| Battery voltage signal | T | R | | | | | | | | | |
| Closed throttle position signal | T | R | | | | | | | | | |
| Cooling fan speed request signal | T | | | | | | | | | | R |
| Engine coolant temperature signal | T | | | | | R | R | | | | |
| Engine speed signal | T | R | R | | | R | R | | R | R | |
| Engine status signal | T | | | | R | | | | | | |
| Fuel consumption monitor signal | T | | | | | | R | | | | |
| | | | | | | | T | | R | | |
| Malfunction indicator lamp signal | T | | | | | | R | | | | |
| Power generation command value signal | T | | | | | | | | | | R |
| Wide open throttle position signal | T | R | | | | | | | | | |

TROUBLE DIAGNOSIS

[CAN]

| Signal name/Connecting unit | ECM | TCM | 4WD | ADP*1 | BCM | HVAC*2 | M&A | STRG | DISP*3 | ABS | IPDM-E |
|---------------------------------------|-----|-----|-----|-------|-----|--------|-----|------|--------|-----|--------|
| A/T fluid temperature sensor signal | | T | | | | | R | | | | |
| A/T position indicator lamp signal | | T | R | | | | R | | | | |
| A/T self-diagnosis signal | R | T | | | | | | | | | |
| O/D OFF indicator signal | | T | | | | | R | | | | |
| Output shaft revolution signal | R | T | R | | | | | | | | |
| P range signal | | T | | R | | | R | | | R | |
| Turbine revolution signal | R | T | | | | | | | | | |
| System setting signal | | | | R | R | | | | T | | |
| | | | | T | T | | | | R | | |
| A/C switch signal | R | | | | T | R | | | | | |
| Blower fan motor switch signal | R | | | | T | | | | | | |
| Buzzer output signal | | | | | T | | R | | | | |
| Day time running light request signal | | | | | T | | R | | | | R |
| Door switch signal | | | | R | T | | R | | R | | R |
| Front fog light request signal | | | | | T | | R | | | | R |
| Front wiper request signal | | | | | T | | | | | | R |
| High beam request signal | | | | | T | | R | | | | R |
| Horn chirp signal | | | | | T | | | | | | R |
| Ignition switch signal | | | | R | T | | | | | | |
| Key fob door unlock signal | | | | R | T | | | | | | |
| Key fob ID signal | | | | R | T | | | | | | |
| Key switch signal | | | | R | T | | | | | | |
| Low beam request signal | | | | | T | | | | | | R |
| Position light request signal | | | | | T | | R | | | | R |
| Rear window defogger switch signal | | | | | T | R | | | | | R |
| Sleep wake up signal | | | | R | T | | R | | | | R |
| Theft warning horn request signal | | | | | T | | | | | | R |
| Tire pressure data signal | | | | | T | | | | R | | |
| Tire pressure signal | | | | | T | | R | | R | | |
| Turn indicator signal | | | | | T | | R | | | | |
| A/C switch/indicator signal | | | | | | R | | | T | | |
| | | | | | | T | | | R | | |
| 1st position switch signal | | R | | | | | T | | | | |
| Distance to empty signal | | | | | | | T | | R | | |
| Fuel level low warning signal | | | | | | | T | | R | | |
| Fuel level sensor signal | R | | | | | | T | | | | |
| Overdrive control switch signal | | R | | | | | T | | | | |
| Seat belt buckle switch signal | | | | | R | | T | | | | |
| Stop lamp switch signal | | R | | | | | T | | | | |
| Vehicle speed signal | | | R | | | R | R | | | T | |
| | R | R | | R | R | R | T | | R | | |
| Steering angle sensor signal | | | | | | | | T | | R | |
| ABS warning lamp signal | | | | | | | R | | | T | |

TROUBLE DIAGNOSIS

[CAN]

| Signal name/Connecting unit | ECM | TCM | 4WD | ADP*1 | BCM | HVAC*2 | M&A | STRG | DISP*3 | ABS | IPDM-E |
|-------------------------------------|-----|-----|-----|-------|-----|--------|-----|------|--------|-----|--------|
| Brake warning lamp signal | | | | | | | R | | | T | |
| HDC indicator lamp signal*4 | | | | | | | R | | | T | |
| SLIP indicator lamp signal | | | | | | | R | | | T | |
| VDC OFF indicator lamp signal | | | | | | | R | | | T | |
| Front wiper stop position signal | | | | | R | | | | | | T |
| High beam status signal | R | | | | | | | | | | T |
| Low beam status signal | R | | | | | | | | | | T |
| Rear window defogger control signal | R | | | | | R | | | | | T |

- *1: Models with automatic drive positioner
- *2: Models with automatic air conditioner
- *3: Models with navigation system
- *4: Models with HDC

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


TROUBLE DIAGNOSIS

[CAN]

Schematic

UKS006HP

- (4W) : WITH 4-WHEEL DRIVE
- (AA) : WITH AUTO A/C
- (AC) : WITH AUTOMATIC DRIVE POSITIONER
- (AM) : ALL-MODE 4WD SYSTEM
- (NV) : WITH NAVI
- (PT) : PART TIME 4WD SYSTEM
- (AM)/7
- (PT)/1
- (AM)/8
- (PT)/2




BKWA0715E

Wiring Diagram — CAN —


UKS006HQ

LAN-CAN-01

- : DATA LINE
- 4W : WITH 4-WHEEL DRIVE
- AM : ALL MODE 4WD SYSTEM
- PT : PART TIME 4WD SYSTEM
- *1 AM : 7
PT : 1
- *2 AM : 8
PT : 2



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0743E

TROUBLE DIAGNOSIS

[CAN]



LAN-CAN-02

— : DATA LINE


4W : WITH 4-WHEEL DRIVE

AA : WITH AUTO A/C


AD : WITH AUTOMATIC DRIVE POSITIONER



REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE JUNCTION (SMJ)




M24 W



M35 Y




M47 W



M50 W

B37 W



P2 W

* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.



BKWA0716E

TROUBLE DIAGNOSIS

[CAN]

LAN-CAN-03

— : DATA LINE
 ◊NV : WITH NAVI



BKWA0717E

Interview Sheet

UKS006HR

CAN Communication System Diagnosis Interview Sheet

Date received:

Type:

VIN No.:

Model:

First registration:

Mileage:

CAN system type:

Symptom (Results from interview with customer)

Condition at inspection

Error symptom : Present / Past

SKIB8898E

TROUBLE DIAGNOSIS

[CAN]

Data Sheet CONSULT-II DATA ATTACHMENT SHEET

UKS006HS

A
B
C
D
E
F
G
H
I
J
LAN
L
M

| |
|---------------------------------------------------------------------------------------------|
| Attach printout of ALL MODE AWD/4WD SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR |
| Attach printout of A/T SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR |
| Attach printout of ENGINE SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR |
| Attach printout of SELECT SYSTEM |

PKID0617E

TROUBLE DIAGNOSIS

[CAN]

Attach printout of
ABS
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR

Attach printout of
METER
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR


Attach printout of
BCM
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR

Attach printout of
AUTO DRIVE POS.
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR

PKID0657E

TROUBLE DIAGNOSIS

[CAN]



A
B
C
D
E
F
G
H
I
J
L
M

ON-BOARD DIAGNOSIS COPY SHEET

NOTE:

CAN diagnostic support monitor of the display control unit is indicated on the vehicle display. Refer to [AV-104](#), "[Self-Diagnosis Mode \(DCU\)](#)".

Vehicle monitor (Display control unit) CAN DIAG SUPPORT MONITOR copy sheet

| Indication item (Diagnosis item) | Vehicle monitor | | Indication item (Diagnosis item) | Vehicle monitor | |
|--------------------------------------------------------|------------------|---------------|--------------------------------------------------------|------------------|---------------|
| | Result indicated | Error counter | | Result indicated | Error counter |
| CAN_COMM (Initial diagnosis) | | | CAN_CIRC_5 (Receive diagnosis of Combination meter) | | |
| CAN_CIRC_1 (Transmit diagnosis) | | | CAN_CIRC_6 | Not available | |
| CAN_CIRC_2 (Receive diagnosis of BCM) | | | CAN_CIRC_7 (Receive diagnosis of IPDM E/R) | | |
| CAN_CIRC_3 (Receive diagnosis of ECM) | | | CAN_CIRC_8 | Not available | |
| CAN_CIRC_4 (Receive diagnosis of Front air control) | | | CAN_CIRC_9 | Not available | |

SKIB8771E


LAN

TROUBLE DIAGNOSIS

[CAN]

CAN System (Type 1) DIAGNOSIS SHEET

UKS006HT



PKID0630E


TROUBLE DIAGNOSIS

[CAN]

UKS006HU

CAN System (Type 2) DIAGNOSIS SHEET

A
B
C
D
E
F
G
H
I
J
LAN
L
M




PKID0665E

TROUBLE DIAGNOSIS

[CAN]

CAN System (Type 3) DIAGNOSIS SHEET

UKS006HV



PKID0664E


TROUBLE DIAGNOSIS

[CAN]

UKS006HW

CAN System (Type 4) DIAGNOSIS SHEET

A
B
C
D
E
F
G
H
I
J
LAN
L
M




PKID0663E

TROUBLE DIAGNOSIS

[CAN]

UKS006HX

CAN System (Type 5) DIAGNOSIS SHEET



PKID0620E


TROUBLE DIAGNOSIS

[CAN]

UKS006HY

CAN System (Type 6) DIAGNOSIS SHEET

A
B
C
D
E
F
G
H
I
J
LAN
L
M




PKID0662E

TROUBLE DIAGNOSIS

[CAN]

UKS0061F

CAN System (Type 7) DIAGNOSIS SHEET



PKID0661E


TROUBLE DIAGNOSIS

[CAN]

UKS0061G

CAN System (Type 8) DIAGNOSIS SHEET

A
B
C
D
E
F
G
H
I
J
LAN
L
M




PKID0660E

TROUBLE DIAGNOSIS

[CAN]

UKS0061H

CAN System (Type 9) DIAGNOSIS SHEET



PKID0659E


TROUBLE DIAGNOSIS

[CAN]

UKS00611

CAN System (Type 10) DIAGNOSIS SHEET


A
B
C
D
E
F
G
H
I
J
LAN
L
M



PKID0658E

Component Parts Location

UKS006HZ



BKIA0199E

- | | | |
|---------------------------------|---------------------------------------|-------------------------------------------------------|
| 1. IPDM E/R E122 | 2. ECM E16 | 3. Display control unit M95 |
| 4. Combination meter M24 | 5. BCM M18 | 6. ABS actuator and electric unit (control unit) E125 |
| 7. Transfer control unit M152 | 8. Data link connector M22 | 9. Steering angle sensor M47 |
| 10. Driver seat control unit P2 | 11. Air bag diagnosis sensor unit M35 | 12. A/T assembly F9 |
| 13. Front air control M50 | | |

Harness Layout

UKS006I0

Refer to [PG-43, "Harness Layout"](#) .

TROUBLE DIAGNOSIS

[CAN]

UKS0061

Malfunction Area Chart

MAIN LINE

| Malfunction Area | Reference |
|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Main line between TCM and data link connector | LAN-76, "Main Line Between TCM and Data Link Connector" |
| Main line between data link connector and ABS actuator and electric unit (control unit) | LAN-77, "Main Line Between Data Link Connector and ABS Actuator and Electric Unit" |
| Main line between data link connector and display control unit | LAN-78, "Main Line Between Data Link Connector and Display Control Unit" |
| Main line between display control unit and ABS actuator and electric unit (control unit) | LAN-79, "Main Line Between Display Control unit and ABS Actuator and Electric Unit" |

BRANCH LINE

| Malfunction Area | Reference |
|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| ECM branch line circuit | LAN-80, "ECM Branch Line Circuit" |
| TCM branch line circuit | LAN-80, "TCM Branch Line Circuit" |
| Transfer control unit branch line circuit | LAN-81, "Transfer Control Unit Branch Line Circuit" |
| Driver seat control branch line circuit | LAN-82, "Driver Seat Control Unit Branch Line Circuit" |
| BCM branch line circuit | LAN-83, "BCM Branch Line Circuit" |
| Data link connector branch line circuit | LAN-83, "Data Link Connector Branch Line Circuit" |
| Front air control branch line circuit | LAN-84, "Front Air Control Branch Line Circuit" |
| Combination meter branch line circuit | LAN-85, "Combination Meter Branch Line Circuit" |
| Steering angle sensor branch line circuit | LAN-85, "Steering Angle Sensor Branch Line Circuit" |
| Display control unit branch line circuit | LAN-86, "Display Control Unit Branch Line Circuit" |
| ABS actuator and electric unit (control unit) branch line circuit | LAN-87, "ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit" |
| IPDM E/R branch line circuit | LAN-87, "IPDM E/R Branch Line Circuit" |

SHORT CIRCUIT

| Malfunction Area | Reference |
|---------------------------|-----------------------------------------------------|
| CAN communication circuit | LAN-88, "CAN Communication Circuit" |

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Main Line Between TCM and Data Link Connector

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - A/T assembly connector
 - Harness connector F14 and E5
2. Check the continuity between the A/T assembly harness connector and the harness connector.

| A/T assembly harness connector | | Harness connector | | Continuity |
|--------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| F9 | 3 | F14 | 2 | Yes |
| | 8 | | 3 | Yes |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the A/T assembly and the harness connector F14.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors E152 and M31.
2. Check the continuity between harness connectors.

| Harness connector | | Harness connector | | Continuity |
|-------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E5 | 2 | E152 | 52G | Yes |
| | 3 | | 51G | Yes |

OK or NG

- OK >> GO TO 4.
 NG >> Repair the main line between the harness connector E5 and the harness connector E152.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

| Harness connector | | Data link connector | | Continuity |
|-------------------|--------------|---------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M31 | 52G | M22 | 6 | Yes |
| | 51G | | 14 | Yes |

OK or NG

- OK >> ● Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the A/T assembly and the data link connector.

NG >> Repair the main line between the harness connector M31 and the data link connector.

Main Line Between Data Link Connector and ABS Actuator and Electric Unit

UKS00613

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M91 and E26.
2. Check the continuity between the data link connector and the harness connector.

| Data link connector | | Harness connector | | Continuity |
|---------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M91 | 11 | Yes |
| | 14 | | 10 | Yes |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the data link connector and the harness connector M91.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the continuity between the harness connector and the ABS actuator and electric unit (control unit) harness connector.

| Harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|-------------------|--------------|-----------------------------------------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E26 | 11 | E125 | 11 | Yes |
| | 10 | | 15 | Yes |

OK or NG

- OK** >> ● Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the data link connector and the ABS actuator and electric unit (control unit).
- NG** >> Repair the main line between the harness connector E26 and the ABS actuator and electric unit (control unit).

Main Line Between Data Link Connector and Display Control Unit

UKS006J

INSPECTION PROCEDURE

1. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and display control unit connector.
4. Check the continuity between the data link connector and the display control unit harness connector.

| Data link connector | | Display control unit harness connector | | Continuity |
|---------------------|--------------|----------------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M22 | 6 | M95 | 25 | Yes |
| | 14 | | 26 | Yes |

OK or NG

- OK** >> ● Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the data link connector and the display control unit.
- NG** >> Repair the main line between the data link connector and the display control unit.

Main Line Between Display Control unit and ABS Actuator and Electric Unit UKS006IK

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Display control unit connector
 - Harness connector M91 and E26
2. Check the continuity between the display control unit harness connector and the harness connector.

| Display control unit harness connector | | Harness connector | | Continuity |
|----------------------------------------|--------------|-------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| M95 | 25 | M91 | 11 | Yes |
| | 26 | | 10 | Yes |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the display control unit and the harness connector M91.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the continuity between the harness connector and the ABS actuator and electric unit (control unit) harness connector.

| Harness connector | | ABS actuator and electric unit (control unit) harness connector | | Continuity |
|-------------------|--------------|-----------------------------------------------------------------|--------------|------------|
| Connector No. | Terminal No. | Connector No. | Terminal No. | |
| E26 | 11 | E125 | 11 | Yes |
| | 10 | | 15 | Yes |

OK or NG

- OK >> ● Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the display control unit and the ABS actuator and electric unit (control unit).
- NG >> Repair the main line between the harness connector E26 and the ABS actuator and electric unit (control unit).

ECM Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

| ECM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| E16 | 94 | 86 | Approx. 108 – 132 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the ECM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-146, "POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> ● Present error: Replace the ECM. Refer to [EC-76, "Procedure After Replacing ECM"](#) .
 ● Past error: Error was detected in the ECM branch line.
 NG >> Repair the power supply and the ground circuit.

TCM Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/T assembly for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

| A/T assembly harness connector | | | Resistance (Ω) |
|--------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| F9 | 3 | 8 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
- NG >> Repair the TCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [AT-167, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> ● Present error: Replace the control valve with the TCM. Refer to [AT-228, "CONTROL VALVE WITH TCM REMOVAL AND INSTALLATION"](#) .
- Past error: Error was detected in the TCM branch line.
- NG >> Repair the power supply and the ground circuit.

Transfer Control Unit Branch Line Circuit

UKS00616

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the transfer control unit for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of transfer control unit.
2. Check the resistance between the transfer control unit harness connector terminals.

- Part time 4WD models

| Transfer control unit harness connector | | | Resistance (Ω) |
|-----------------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M152 | 1 | 2 | Approx. 54 – 66 |

- All-mode 4WD models

| Transfer control unit harness connector | | | Resistance (Ω) |
|-----------------------------------------|--------------|---|-----------------|
| Connector No. | Terminal No. | | |
| M152 | 7 | 8 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
- NG >> Repair the transfer control unit branch line.

A
B
C
D
E
F
G
H
I
J
L
M



3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the transfer control unit. Refer to [TF-222, "Power Supply Circuit For Transfer Control Unit"](#) (Part time 4WD models) or [TF-56, "Power Supply Circuit For Transfer Control Unit"](#) (All-mode 4WD models).

OK or NG

- OK >> ● Present error: Replace the transfer control unit. Refer to [TF-268, "TRANSFER CONTROL UNIT"](#) (Part time 4WD models) or [TF-132, "TRANSFER CONTROL UNIT"](#) (All-mode 4WD models).
- Past error: Error was detected in the transfer control unit branch line.
- NG >> Repair the power supply and the ground circuit.

Driver Seat Control Unit Branch Line Circuit

UKS0061L

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

| Driver seat control unit harness connector | | | Resistance (Ω) |
|--------------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| P2 | 3 | 19 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
- NG >> Repair the driver seat control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [SE-30, "POWER SUPPLY AND GROUND CIRCUIT INSPECTION"](#) .

OK or NG

- OK >> ● Present error: Replace the driver seat control unit. Refer to [SE-11, "Component Parts And Harness Connector Location"](#) .
- Past error: Error was detected in the driver seat control unit branch line.
- NG >> Repair the power supply and the ground circuit.

BCM Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

| BCM harness connector | | | Resistance (Ω) |
|-----------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M18 | 39 | 40 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#).

OK or NG

- OK >> ● Present error: Replace the BCM. Refer to [BCS-25, "Removal and Installation"](#).
 ● Past error: Error was detected in the BCM branch line.
 NG >> Repair the power supply and the ground circuit.

Data Link Connector Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

A
B
C
D
E
F
G
H
I
J

LAN

L
M

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

| Data link connector | | | Resistance (Ω) |
|---------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | Approx. 54 – 66 |

OK or NG

- OK >> ● Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the data link connector branch line circuit.
- NG >> Repair the data link connector branch line.

Front Air Control Branch Line Circuit

UKS00618

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the front air control for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of front air control.
2. Check the resistance between the front air control harness connector terminals.

| Front air control harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-----------------|
| Connector No. | Terminal No. | | |
| M50 | 41 | 42 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the front air control branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the front air control. Refer to [ATC-55, "Power Supply and Ground Circuit for Front Air Control"](#) .

OK or NG

- OK >> ● Present error: Replace the front air control. Refer to [ATC-131, "Removal and Installation"](#) .
 ● Past error: Error was detected in the front air control branch line.
- NG >> Repair the power supply and the ground circuit.

Combination Meter Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

| Combination meter harness connector | | | Resistance (Ω) |
|-------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M24 | 12 | 11 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [DI-18, "Power Supply and Ground Circuit Inspection"](#).

OK or NG

- OK >> ● Present error: Replace the combination meter. Refer to [DI-23, "Removal and Installation"](#).
 ● Past error: Error was detected in the combination meter branch line.
 NG >> Repair the power supply and the ground circuit.

Steering Angle Sensor Branch Line Circuit

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

A
B
C
D
E
F
G

H

I

J

LAN

L

M

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

| Steering angle sensor harness connector | | | Resistance (Ω) |
|-----------------------------------------|--------------|---|-------------------------|
| Connector No. | Terminal No. | | |
| M47 | 4 | 5 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the steering angle sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-16, "Schematic"](#) (VDC/TCS/ABS) or [BRC-78, "Schematic"](#) (HDC/HSA/VDC/TCS/ABS).

OK or NG

- OK >> ● Present error: Replace the steering angle sensor. Refer to [BRC-63, "Removal and Installation"](#) (VDC/TCS/ABS) or [BRC-132, "Removal and Installation"](#) (HDC/HSA/VDC/TCS/ABS).
 ● Past error: Error was detected in the steering angle sensor branch line.
- NG >> Repair the power supply and the ground circuit.

Display Control Unit Branch Line Circuit

UKS0061M

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

| Display control unit harness connector | | | Resistance (Ω) |
|----------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| M95 | 25 | 26 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the display control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-117, "Power Supply and Ground Circuit Check for Display Control Unit"](#).

OK or NG

- OK >> ● Present error: Replace the display control unit. Refer to [AV-153, "DISPLAY CONTROL UNIT"](#).
 ● Past error: Error was detected in the display control unit branch line.
- NG >> Repair the power supply and the ground circuit.

ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit

UKS0061C

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

| ABS actuator and electric unit (control unit) harness connector | | | Resistance (Ω) |
|-----------------------------------------------------------------|--------------|----|-------------------------|
| Connector No. | Terminal No. | | |
| E125 | 11 | 15 | Approx. 54 – 66 |

OK or NG

- OK >> GO TO 3.
 NG >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-16, "Schematic"](#) (VDC/TCS/ABS) or [BRC-78, "Schematic"](#) (HDC/HSA/VDC/TCS/ABS).

OK or NG

- OK >> ● Present error: Replace the ABS actuator and electric unit (control unit). Refer to [BRC-61, "Removal and Installation"](#) (VDC/TCS/ABS) or [BRC-130, "Removal and Installation"](#) (HDC/HSA/VDC/TCS/ABS).
- Past error: Error was detected in the ABS actuator and electric unit (control unit) branch line.
- NG >> Repair the power supply and the ground circuit.

IPDM E/R Branch Line Circuit

UKS0061D

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

| IPDM E/R harness connector | | | Resistance (Ω) |
|----------------------------|--------------|----|-------------------|
| Connector No. | Terminal No. | | |
| E122 | 39 | 40 | Approx. 108 – 132 |

OK or NG

- OK >> GO TO 3.
- NG >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#).

OK or NG

- OK >>
 - Present error: Replace the IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).
 - Past error: Error was detected in the IPDM E/R branch line.
- NG >> Repair the power supply and the ground circuit.

CAN Communication Circuit

UKS006IE

INSPECTION PROCEDURE

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

| Data link connector | | | Continuity |
|---------------------|--------------|----|------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | 14 | No |

OK or NG

- OK >> GO TO 3.
- NG >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

| Data link connector | | Ground | Continuity |
|---------------------|--------------|--------|------------|
| Connector No. | Terminal No. | | |
| M22 | 6 | | No |
| | 14 | | No |

OK or NG

- OK >> GO TO 4.
- NG >> Check the harness and repair the root cause.


4. CHECK ECM AND IPDM E/R TERMINATION CIRCUIT

1. Remove the ECM and the IPDM E/R.
2. Check the resistance between the ECM terminals.

| ECM | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 94 | 86 | Approx. 108 – 132 |

3. Check the resistance between the IPDM E/R terminals.

| IPDM E/R | | Resistance (Ω) |
|--------------|----|-------------------|
| Terminal No. | | |
| 39 | 40 | Approx. 108 – 132 |



OK or NG

- OK >> GO TO 5.
- NG >> Replace the ECM and/or the IPDM E/R.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
- Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.

NOTE:

ECM and IPDM E/R have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

- Reproduced>>Connect the connector. Check other units as per the above procedure.
- Non-reproduced>>Replace the unit whose connector was disconnected.

