

LT  
**SECTION**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

**CONTENTS**

<b>PRECAUTIONS</b> .....	<b>4</b>	LOW BEAM AND HIGH BEAM .....	<b>24</b>
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	Bulb Replacement .....	25
General precautions for service operations .....	4	HEADLAMP BULB .....	25
<b>HEADLAMP (FOR USA)</b> .....	<b>5</b>	FRONT TURN SIGNAL/PARKING LAMP .....	25
Component Parts and Harness Connector Location .....	5	FRONT SIDE MARKER LAMP .....	25
System Description .....	5	Removal and Installation .....	25
OUTLINE .....	5	FRONT COMBINATION LAMP .....	25
BATTERY SAVER CONTROL .....	6	Disassembly and Assembly .....	26
AUTO LIGHT OPERATION .....	6	FRONT COMBINATION LAMP .....	26
VEHICLE SECURITY SYSTEM (PANIC ALARM) .....	6	<b>HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -</b> .....	<b>27</b>
CAN Communication System Description .....	6	Component Parts and Harness Connector Location .....	27
Schematic .....	7	System Description .....	27
Wiring Diagram — H/LAMP — .....	8	OUTLINE .....	28
Terminals and Reference Values for BCM .....	12	DAYTIME LIGHT OPERATION .....	29
Terminals and Reference Values for IPDM E/R .....	12	COMBINATION SWITCH READING FUNCTION .....	29
How to Proceed With Trouble Diagnosis .....	12	AUTO LIGHT OPERATION .....	29
Preliminary Check .....	12	CAN Communication System Description .....	29
CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM .....	12	Schematic .....	30
CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R .....	12	Wiring Diagram — DTRL — .....	31
CONSULT-II Function (BCM) .....	12	Terminals and Reference Values for BCM .....	35
CONSULT-II START PROCEDURE .....	12	Terminals and Reference Values for IPDM E/R .....	35
WORK SUPPORT .....	12	How to Proceed With Trouble Diagnosis .....	35
DATA MONITOR .....	12	Preliminary Check .....	35
ACTIVE TEST .....	13	CHECK BCM CONFIGURATION .....	35
SELF-DIAGNOSTIC RESULTS .....	13	CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM .....	35
CONSULT-II Function (IPDM E/R) .....	13	CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R .....	35
CONSULT-II START PROCEDURE .....	14	INSPECTION PARKING BRAKE SWITCH CIRCUIT .....	35
DATA MONITOR .....	14	CONSULT-II Function (BCM) .....	36
ACTIVE TEST .....	14	CONSULT-II Function (IPDM E/R) .....	36
Headlamp HI Does Not Illuminate (Both Sides) .....	14	Daytime Light Control Does Not Operate Properly (Normal Headlamps Operate Properly) .....	36
Headlamp HI Does Not Illuminate (One Side) .....	17	Aiming Adjustment .....	37
High Beam Indicator Lamp Does Not Illuminate .....	18	Bulb Replacement .....	37
Headlamp LO Does Not Illuminate (Both Sides) .....	18	Removal and Installation .....	37
Headlamp LO Does Not Illuminate (One Side) .....	20	Disassembly and Assembly .....	37
Headlamps Do Not Turn OFF .....	22	<b>AUTO LIGHT SYSTEM</b> .....	<b>38</b>
Aiming Adjustment .....	23		

Component Parts and Harness Connector Location..	38	Component Parts and Harness Connector Location..	60
System Description .....	39	System Description .....	60
OUTLINE .....	39	OUTLINE .....	60
COMBINATION SWITCH READING FUNCTION..	39	TURN SIGNAL OPERATION .....	60
EXTERIOR LAMP BATTERY SAVER CONTROL..	39	HAZARD LAMP OPERATION .....	61
DELAY TIMER FUNCTION .....	39	REMOTE KEYLESS ENTRY SYSTEM OPERA-	
CAN Communication System Description .....	39	TION .....	61
Major Components and Functions .....	40	COMBINATION SWITCH READING FUNCTION..	62
Schematic .....	41	CAN Communication System Description .....	62
Wiring Diagram — AUTO/L — .....	42	Wiring Diagram — TURN — .....	63
Terminals and Reference Values for BCM .....	45	Terminals and Reference Values for BCM .....	65
Terminals and Reference Values for IPDM E/R .....	45	How to Proceed With Trouble Diagnosis .....	65
How to Proceed With Trouble Diagnosis .....	45	Preliminary Check .....	65
Preliminary Check .....	45	CHECK POWER SUPPLY AND GROUND CIR-	
SETTING CHANGE FUNCTIONS .....	45	CUIT FOR BCM .....	65
CHECK BCM CONFIGURATION .....	45	CONSULT-II Function (BCM) .....	65
CHECK POWER SUPPLY AND GROUND CIR-		CONSULT-II START PROCEDURE .....	65
CUIT FOR BCM .....	45	DATA MONITOR .....	65
CHECK POWER SUPPLY AND GROUND CIR-		ACTIVE TEST .....	65
CUIT FOR IPDM E/R .....	45	Turn Signal Lamps Do Not Operate .....	65
CONSULT-II Function (BCM) .....	45	Front Turn Signal Lamps Do Not Operate .....	66
CONSULT-II START PROCEDURE .....	45	Rear Turn Signal Lamp Does Not Operate .....	66
WORK SUPPORT .....	45	Hazard Warning Lamp Does Not Operate But Turn	
DATA MONITOR .....	46	Signal Lamps Operate .....	67
ACTIVE TEST .....	46	Turn Signal Indicator Lamp Does Not Operate .....	69
CONSULT-II Function (IPDM E/R) .....	46	Bulb Replacement .....	70
CONSULT-II START PROCEDURE .....	46	FRONT TURN SIGNAL LAMP .....	70
DATA MONITOR .....	47	REAR TURN SIGNAL LAMP .....	70
ACTIVE TEST .....	47	Removal and Installation .....	70
Trouble Diagnosis Chart by Symptom .....	47	FRONT TURN SIGNAL LAMP .....	70
Lighting Switch Inspection .....	48	REAR TURN SIGNAL LAMP .....	70
Optical Sensor System Inspection .....	48	<b>LIGHTING AND TURN SIGNAL SWITCH .....</b>	<b>71</b>
Removal and Installation .....	50	Removal and Installation .....	71
OPTICAL SENSOR .....	50	REMOVAL .....	71
<b>FRONT FOG LAMP .....</b>	<b>51</b>	INSTALLATION .....	71
Component Parts and Harness Connector Location..	51	<b>HAZARD SWITCH .....</b>	<b>72</b>
System Description .....	51	Removal and Installation .....	72
OUTLINE .....	51	REMOVAL .....	72
COMBINATION SWITCH READING FUNCTION..	52	INSTALLATION .....	72
EXTERIOR LAMP BATTERY SAVER CONTROL..	52	<b>COMBINATION SWITCH .....</b>	<b>73</b>
CAN Communication System Description .....	52	Wiring Diagram — COMBSW — .....	73
Wiring Diagram — F/FOG — .....	53	Combination Switch Reading Function .....	74
Terminals and Reference Values for BCM .....	55	CONSULT-II Function (BCM) .....	74
Terminals and Reference Values for IPDM E/R .....	55	CONSULT-II START PROCEDURE .....	74
How to Proceed With Trouble Diagnosis .....	55	DATA MONITOR .....	74
Preliminary Check .....	55	Combination Switch Inspection .....	75
CHECK POWER SUPPLY AND GROUND CIR-		Removal and Installation .....	77
CUIT FOR BCM .....	55	Switch Circuit Inspection .....	77
CHECK POWER SUPPLY AND GROUND CIR-		<b>STOP LAMP .....</b>	<b>78</b>
CUIT FOR IPDM E/R .....	55	System Description .....	78
CONSULT-II Function (BCM) .....	55	Wiring Diagram — STOP/L — .....	79
CONSULT-II Function (IPDM E/R) .....	55	High-Mounted Stop Lamp .....	80
Front Fog Lamps Do Not Illuminate (Both Sides) ...	55	BULB REPLACEMENT .....	80
Front Fog Lamp Does Not Illuminate (One Side) ...	56	REMOVAL AND INSTALLATION .....	80
Aiming Adjustment .....	58	Stop Lamp .....	80
Bulb Replacement .....	59	BULB REPLACEMENT .....	80
Removal and Installation .....	59	REMOVAL AND INSTALLATION .....	80
FRONT FOG LAMP .....	59	<b>BACK-UP LAMP .....</b>	<b>81</b>
<b>TURN SIGNAL AND HAZARD WARNING LAMPS..</b>	<b>60</b>	Wiring Diagram — BACK/L — .....	81

Bulb Replacement .....	82	TRAILER POWER SUPPLY OPERATION .....	100	
Removal and Installation .....	82	Schematic .....	102	A
<b>PARKING, LICENSE PLATE AND TAIL LAMPS ....</b>	<b>83</b>	Wiring Diagram — T/TOW — .....	103	
Component Parts and Harness Connector Location .....	83	<b>INTERIOR ROOM LAMP .....</b>	<b>108</b>	B
System Description .....	83	Component Parts and Harness Connector Location .....	108	
OPERATION BY LIGHTING SWITCH .....	83	System Description .....	109	C
COMBINATION SWITCH READING FUNCTION .....	84	POWER SUPPLY AND GROUND .....	109	
EXTERIOR LAMP BATTERY SAVER CONTROL .....	84	SWITCH OPERATION .....	110	
CAN Communication System Description .....	84	ROOM LAMP TIMER OPERATION .....	110	
Schematic .....	85	INTERIOR LAMP BATTERY SAVER CONTROL .....	111	
Wiring Diagram — TAIL/L — .....	86	Schematic .....	112	D
Terminals and Reference Values for BCM .....	90	Wiring Diagram — INT/L — .....	114	
Terminals and Reference Values for IPDM E/R .....	90	Terminals and Reference Values for BCM .....	119	E
How to Proceed With Trouble Diagnosis .....	90	How to Proceed With Trouble Diagnosis .....	119	
Preliminary Check .....	90	Preliminary Check .....	119	
CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM .....	90	INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT FOR BCM .....	119	F
CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R .....	90	CONSULT-II Function (BCM) .....	119	
CONSULT-II Function (BCM) .....	90	CONSULT-II START PROCEDURE .....	119	
CONSULT-II Function (IPDM E/R) .....	90	WORK SUPPORT .....	119	
Parking, Side Marker, License Plate and/or Tail Lamps Do Not Illuminate .....	90	DATA MONITOR .....	119	G
Parking, Side Marker, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes) .....	97	ACTIVE TEST .....	120	
Bulb Replacement .....	97	Room/Map Lamp Control Does Not Operate .....	120	H
FRONT PARKING LAMP .....	97	Personal Lamp Control Does Not Operate (Room/Map Lamps Operate) .....	122	
TAIL LAMP .....	97	All Interior Room Lamps Do Not Operate .....	123	
LICENSE PLATE LAMP .....	97	Ignition Keyhole Illumination Control Does Not Operate .....	123	I
Removal and Installation .....	97	<b>ILLUMINATION .....</b>	<b>126</b>	
LICENSE PLATE LAMP .....	97	Component Parts and Harness Connector Location .....	126	J
<b>REAR COMBINATION LAMP .....</b>	<b>98</b>	System Description .....	126	
Bulb Replacement .....	98	ILLUMINATION OPERATION BY LIGHTING SWITCH .....	127	
REMOVAL .....	98	EXTERIOR LAMP BATTERY SAVER CONTROL .....	128	
INSTALLATION .....	98	CAN Communication System Description .....	128	LT
Removal and Installation .....	98	Schematic .....	129	
REMOVAL .....	98	Wiring Diagram — ILL — .....	132	
INSTALLATION .....	98	Removal and Installation .....	141	L
<b>TRAILER TOW .....</b>	<b>99</b>	ILLUMINATION CONTROL SWITCH .....	141	
Component Parts and Harness Connector Location .....	99	<b>BULB SPECIFICATIONS .....</b>	<b>142</b>	
System Description .....	99	Headlamp .....	142	M
TRAILER TAIL LAMP OPERATION .....	100	Exterior Lamp .....	142	
TRAILER STOP, TURN SIGNAL AND HAZARD LAMP OPERATION .....	100	Interior Lamp/Illumination .....	142	

# PRECAUTIONS

## PRECAUTIONS

PF0:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00FTW

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### General precautions for service operations

EKS00FTX

- Never work with wet hands.
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.


# HEADLAMP (FOR USA)

## HEADLAMP (FOR USA)

PFP:26010

### Component Parts and Harness Connector Location

EKS00FTZ



WKIA4957E

- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121,<br>E122, E123, E124 | 2. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) | 3. Combination Switch (lighting switch)<br>M28 |
| 4. Combination meter<br>M24                                |  |  |

## System Description

EKS00FU0

Control of the front headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, the BCM (body control module) receives input requesting the headlamps (and tail lamps) illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the front headlamp high and front headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.

## OUTLINE

Power is supplied at all times

- to ignition relay, located in the IPDM E/R,
- to headlamp high relay, located in the IPDM E/R,
- to headlamp low relay, located in the IPDM E/R,
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM terminal 70.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59
- through grounds E9, E15 and E24.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- through 15A fuse (No. 41, located in the IPDM E/R)
- through IPDM E/R terminal 54
- to front headlamp RH terminal 3, and
- through 15A fuse (No. 40, located in the IPDM E/R)
- through IPDM E/R terminal 52
- to front headlamp LH terminal 3.

Ground is supplied

- to front headlamp LH and RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, low beam headlamps illuminate.

## High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- through 10A fuse (No. 34, located in the IPDM E/R)
- through IPDM E/R terminal 56
- to front headlamp RH terminal 1, and
- through 10A fuse (No. 35, located in the IPDM E/R)
- through IPDM E/R terminal 55
- to front headlamp LH terminal 1.

Ground is supplied

- to front headlamp LH and RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, the high beam headlamps illuminate.

## BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

## AUTO LIGHT OPERATION

Refer to [LT-39, "System Description"](#) .

## VEHICLE SECURITY SYSTEM (PANIC ALARM)

The vehicle security system (panic alarm) will flash the high beams if the system is triggered. Refer to [BL-42, "Panic Alarm Operation"](#) .

## CAN Communication System Description


Refer to [LAN-4, "CAN Communication System"](#) .

EKS00FU1

# HEADLAMP (FOR USA)

## Schematic

EKS00FU2



\*: THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

WKWA5434E





# HEADLAMP (FOR USA)

EKS00FU3

## Wiring Diagram — H/LAMP —

LT-H/LAMP-01



— : DATA LINE



WKWA5435E

# HEADLAMP (FOR USA)


LT-H/LAMP-02



WKWA2018E

# HEADLAMP (FOR USA)

LT-H/LAMP-03



WKWA2019E



# HEADLAMP (FOR USA)

## Terminals and Reference Values for BCM

EKS00FU4

Refer to [BCS-12, "Terminals and Reference Values for BCM"](#) .

## Terminals and Reference Values for IPDM E/R

EKS00FU5

Refer to [PG-27, "Terminals and Reference Values for IPDM E/R"](#) .

## How to Proceed With Trouble Diagnosis

EKS00FU6

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-5, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-12, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS00FU7

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R

Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#) .

## CONSULT-II Function (BCM)

EKS00FU8

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between ON/OFF.	ON	×
		OFF	—

### DATA MONITOR

#### Display Item List

Monitor item	Contents
IGN ON SW	"ON/OFF" Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW	"ON/OFF" Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW	"ON/OFF" Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.

## HEADLAMP (FOR USA)

Monitor item	Contents
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW-DR "ON/OFF"	Displays status of the front door LH as judged from the front door switch LH signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-AS "ON/OFF"	Displays status of the front door RH as judged from the front door switch RH signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RR "ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RL "ON/OFF"	Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW "ON/OFF"	Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW "ON/OFF"	Displays status of cargo lamp switch.
OPTICAL SENSOR [0 - 5V]	Displays "ambient light (close to 5V when dark/close to 0V when light)" judged from optical sensor signal.

### ACTIVE TEST

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay (HI, LO) to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP	Not used.
CARGO LAMP	Allows cargo lamp to operate by switching ON-OFF.

### SELF-DIAGNOSTIC RESULTS

#### Display Item List

Monitored item	CONSULT-II display	Description
CAN communication	CAN communication [U1000]	Malfunction is detected in CAN communication.
CAN communication system	CAN communication system 1 to 6 [U1000]	Malfunction is detected in CAN system.

### CONSULT-II Function (IPDM E/R)

EKS00FU9

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

IPDM E/R diagnostic mode	Description
SELF-DIAG RESULTS	Displays IPDM E/R self-diagnosis results.
DATA MONITOR	Displays IPDM E/R input/output data in real time.

# HEADLAMP (FOR USA)

IPDM E/R diagnostic mode	Description
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

## DATA MONITOR

### All Items, Main Items, Select Item Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Parking, license plate and tail lamps request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Daytime lights request	DTRL REQ	ON/OFF	×	–	×	Signal status input from BCM
Front fog lamps request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

## ACTIVE TEST

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI, LO) at your option (Headlamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay (FOG) output		Allows fog lamp relay (FOG) to operate by switching operation ON-OFF at your option.

## Headlamp HI Does Not Illuminate (Both Sides)

EKS00FUA

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in HIGH position : HI BEAM SW ON**

#### OK or NG

OK >> GO TO 2.

NG >> Check lighting switch. Refer to [LT-75, "Combination Switch Inspection"](#) .

DATA MONITOR	
MONITOR	
HI BEAM SW	ON

SKIA4193E

# HEADLAMP (FOR USA)

## 2. HEADLAMP ACTIVE TEST

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" on "ACTIVE TEST" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.

ACTIVE TEST			
EXTERNAL LAMPS		OFF	
		TAIL	
LO		HI	
FOG			
MODE	BACK	LIGHT	COPY

WKIA1438E

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HIGH position.

**When lighting switch is in HIGH position : HL LO REQ ON  
: HL HI REQ ON**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
HL HI REQ		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5775E

## 4. HEADLAMP HIGH FUSE INSPECTION

Inspect 10A fuse No. 34 RH and fuse No. 35 LH (located in IPDM E/R).

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness and replace fuse.

## 5. BULB INSPECTION

Inspect inoperative headlamp bulbs.

OK or NG


- OK >> GO TO 6.
- NG >> Replace headlamp bulb. [LT-25, "HEADLAMP BULB"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## 6. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front headlamp RH and LH connectors.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
6. Touch "HI" on "ACTIVE TEST" screen.
7. When headlamp high beam is operating, check voltage between front headlamp RH and LH harness connector and ground.



Front headlamp		Terminal	(-)	Voltage
(+)				
Connector				
RH	E107	1	Ground	Battery voltage
LH	E11			

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 7.


## 7. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E123 terminal 56 and front headlamp RH harness connector E107 terminal 1.

**56 - 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E123 terminal 55 and front headlamp LH harness connector E11 terminal 1.

**55 - 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) .  
 NG >> Repair harness or connector.

## 8. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front headlamp RH harness connector E107 terminal 2 and ground.


**2 - Ground : Continuity should exist.**

3. Check continuity between front headlamp LH harness connector E11 terminal 2 and ground.

**2 - Ground : Continuity should exist.**

OK or NG

- OK >> Check front headlamp connector for damage or poor connection. Repair as necessary.  
 NG >> Repair harness or connector.



# HEADLAMP (FOR USA)

EKS00FUB

## Headlamp HI Does Not Illuminate (One Side)

### 1. HEADLAMP HIGH FUSE INSPECTION

Inspect 10A fuse No. 34 RH or fuse No. 35 LH (located in IPDM E/R).

OK or NG

OK >> GO TO 2.

NG >> Repair headlamp high power supply circuits.

### 2. BULB INSPECTION

Inspect inoperative headlamp bulb.

OK or NG

OK >> GO TO 3.

NG >> Replace headlamp bulb. Refer to [LT-25, "HEADLAMP BULB"](#).

### 3. CHECK POWER TO HEADLAMP


1. Disconnect inoperative headlamp connector.
2. Turn the high beam headlamps ON.
3. Check voltage between inoperative headlamp terminal and ground.

Front headlamp		Terminal	(-)	Voltage (Approx.)
(+)				
Connector		1	Ground	Battery voltage
RH	E107			
LH	E11			

OK or NG

OK >> GO TO 4.

NG >> GO TO 5.



### 4. CHECK HEADLAMP GROUND


1. Turn the high beam headlamps OFF.
2. Check continuity between inoperative headlamp connector and ground.

Front headlamp		Terminal	Ground	Continuity
Connector				
RH	E107	2	Ground	Yes
LH	E11			

OK or NG

OK >> Check front headlamp connector for damage or poor connection. Repair as necessary.

NG >> Repair open circuit in harness between inoperative headlamp and ground.





# HEADLAMP (FOR USA)


## 4. HEADLAMP ACTIVE TEST

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "LO" on "ACTIVE TEST" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 6.




## 5. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is in 2ND position : HL LO REQ ON**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) .  
 NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#) .




## 6. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front headlamp RH and LH connectors.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
6. Touch "LO" on "ACTIVE TEST" screen.
7. When headlamp low beam is operating, check voltage between front headlamp RH and LH harness connector and ground.

Front headlamp		Terminal	(-)	Voltage
(+) Connector				
RH	E107	3	Ground	Battery voltage
LH	E11			

OK or NG

- OK >> GO TO 8.  
 NG >> GO TO 7.



# HEADLAMP (FOR USA)


## 7. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E123 terminal 54 and front headlamp RH harness connector E107 terminal 3.

**54 - 3 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E123 terminal 52 and front headlamp LH harness connector E11 terminal 3.

**52 - 3 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.

## 8. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front headlamp RH harness connector E107 terminal 2 and ground.


**2 - Ground : Continuity should exist.**

3. Check continuity between front headlamp LH harness connector E11 terminal 2 and ground.

**2 - Ground : Continuity should exist.**

OK or NG

- OK >> Check front headlamp connector for damage or poor connection. Repair as necessary.
- NG >> Repair harness or connector.



## Headlamp LO Does Not Illuminate (One Side)

EKS00FUE

### 1. HEADLAMP LOW FUSE INSPECTION

Inspect 15A fuse No. 40 LH and fuse No. 41 RH (located in IPDM E/R).

OK or NG

- OK >> Go to 2.
- NG >> Repair headlamp low power supply circuits.

### 2. BULB INSPECTION

Inspect inoperative headlamp bulb.

OK or NG

- OK >> GO TO 3.
- NG >> Replace headlamp bulb. Refer to [LT-25, "HEADLAMP BULB"](#).

# HEADLAMP (FOR USA)


## 3. CHECK POWER TO HEADLAMP

1. Disconnect inoperative headlamp connector.
2. Turn the low beam headlamps ON.
3. Check voltage between inoperative headlamp connector terminal and ground.

Front headlamp		Terminal	(-)	Voltage (Approx.)
(+)				
Connector				
RH	E107	3	Ground	Battery voltage
LH	E11			

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 5.




## 4. CHECK HEADLAMP GROUND

1. Turn the low beam headlamps OFF.
2. Check continuity between inoperative headlamp connector terminal and ground.

Front headlamp		Terminal	Ground	Continuity
Connector				
RH	E107	2	Ground	Yes
LH	E11			

OK or NG

- OK >> Check front headlamp and IPDM E/R connector. Repair as necessary.  
 NG >> Repair harness between inoperative headlamp and ground.




## 5. INSPECTION BETWEEN IPDM E/R AND HEADLAMPS

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector terminals of IPDM E/R harness connector terminals of inoperative headlamp.

IPDM E/R		Front headlamp		Continuity
Connector	Terminal	Connector	Terminal	
E123	54	RH	E107	Yes
	52	LH	E11	

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).  
 NG >> Check harness between IPDM E/R and headlamps. Repair as necessary.






# HEADLAMP (FOR USA)

## Aiming Adjustment

EKS00FUG



**For details, refer to the regulations in your area.**

### NOTE:


If vehicle front body has been repaired and /or the headlamp assembly has been replaced, check headlamp aiming.

- Before performing aiming adjustment, check the following:
  - Confirm headlamp aiming switch is set to "0" (zero) position.
  - Ensure all tires are inflated to correct pressure.
  - Place vehicle and screen on level surface.
  - Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant and engine oil filled to correct level, and fuel tank full.
  - Confirm spare tire, jack and tools are properly stowed.
  - Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.
  - Use adjusting screw to perform aiming adjustment

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## LOW BEAM AND HIGH BEAM



WKIA4885E

1	Adjustment screen	2	Headlamp bulb center (HV point)	A	Minimum acceptable vertical aim dimension (see aiming chart)
B	Maximum acceptable vertical aim dimension (see aiming chart)	C	H-V point	D	Distance of headlamp aiming screen from vehicle 7.62 m (25 ft.)
E	Maximum aim evaluation distance from vertical center on aiming screen 399mm (3° R).	F	Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R)	G	Aim evaluation area
H	Horizontal aiming evaluation line.	⇒	Right		

### Aiming Chart

<b>A (Minimum acceptable vertical aim dimension)</b>	<b>-3.3 mm (0.13 in)</b>	<b>0.025° up</b>
<b>B (Maximum acceptable vertical aim dimension)</b>	<b>36.6 mm (1.44 in)</b>	<b>0.275° down</b>

### NOTE:

- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
  - Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.
1. Use adjustment screw to perform aiming adjustment.

- **Cover the opposite lamp and ensure fog lamps, if equipped, are turned off.**

### CAUTION:

**Do not tighten adjustment screw beyond specified torque or damage may occur.**

**Adjustment torque**                      **1.67 N.m (17 kg-cm, 14.8 in-lb)**

2. Adjust beam pattern until cut-off line (top edge of illumination area) is positioned at the specified height off ground. Measure cut-off line within distance J on H-line. See aiming chart.

# HEADLAMP (FOR USA)

EKS00FUH

## Bulb Replacement

### HEADLAMP BULB

#### Removal

##### NOTE:

Reach through engine room for bulb replacement access.

##### CAUTION:

**Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Turn front headlamp switch OFF.
2. Disconnect the electrical connector.
3. Rotate the headlamp bulb retaining ring counterclockwise and remove.
4. Pull the headlamp bulb straight out from the headlamp assembly.

##### NOTE:

Remove the headlamp bulb from the headlamp assembly just before a replacement bulb is installed. Dust, moisture, foreign materials, etc. entering headlamp body may affect performance.

#### Installation

Installation is in the reverse order of removal.

### FRONT TURN SIGNAL/PARKING LAMP

#### Removal

##### NOTE:

Reach through engine room for bulb replacement access.

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

#### Installation

Installation is in the reverse order of removal.

##### CAUTION:

**After installing the bulb, be sure to install the bulb socket securely for watertightness.**

### FRONT SIDE MARKER LAMP

#### Removal

##### NOTE:

Reach through engine room for bulb replacement access.

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

#### Installation

Installation is in the reverse order of removal.

##### CAUTION:

**After installing the bulb, be sure to install the bulb socket securely for watertightness.**

### Removal and Installation

#### FRONT COMBINATION LAMP

#### Removal

1. Remove front portion of front fender protector. Refer to [EI-20, "FENDER PROTECTOR"](#) .
2. Remove the front bumper. Refer to [EI-14, "Removal and Installation"](#) .

EKS00FUI

A

B

C

D

E

F

G

H

I

J


LT

L

M

# HEADLAMP (FOR USA)

3. Remove the front combination lamp bolts.



4. Disconnect the front combination lamp connector and remove front combination lamp.


## Installation

Installation is in the reverse order of removal.

: 6.0 N·m (0.61 kg·m, 53 in·lb)

## Disassembly and Assembly FRONT COMBINATION LAMP

EKS00FUJ



1. Headlamp assembly

2. Headlamp bulb

3. Headlamp bulb retaining ring

4. Wiring harness assembly

5. Front side marker lamp bulb

6. Front turn signal/parking lamp bulb


# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

PF2:26010

### Component Parts and Harness Connector Location

EKS00FUK



WKIA4958E

- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121, E122,<br>E123, E124 | 2. Parking brake switch<br>E53                 | 3. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) |
| 4. ECM<br>E16<br>(view with ECM cover removed)             | 5. Generator<br>E205                           | 6. Daytime light relay 1   |
| 7. Daytime Light Relay 2                                   | 8. Combination switch (lighting switch)<br>M28 | 9. Combination meter<br>M24  |

## System Description

EKS00FUL

Daytime light system turns on daytime light lamps while driving. Daytime light lamps are not turned on if engine is activated with parking brake on. Take off parking brake to turn on daytime light lamps. The lamps turn off when lighting switch is in the 2ND position or AUTO position (Headlamp is "ON") and when lighting switch is in the PASSING position. (Daytime light lamps are not turned off only by parking brake itself.)

A parking brake signal and engine run or stop signal are sent to BCM (body control module) by CAN communication line.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

---

## OUTLINE

Power is supplied at all times

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 3, and
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU (central processing unit) of IPDM E/R (intelligent power distribution module engine room), and
- to headlamp high relay, located in the IPDM E/R, and
- to headlamp low relay, located in the IPDM E/R, and
- through 50A fusible link (letter **g** , located in the fuse and fusible link box)
- to BCM terminal 70, and
- through 10A fuse (No. 45, located in the IPDM E/R)
- to daytime light relay 1 terminals 2 and 5.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 16, and
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67 and
- to combination meter terminals 13 and 23
- through grounds M57, M61 and M79.

## Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- through 15A fuse (No. 41, located in the IPDM E/R)
- through IPDM E/R terminal 54
- to front headlamp RH terminal 3, and
- through 15A fuse (No. 40, located in the IPDM E/R)
- through IPDM E/R terminal 52
- to daytime light relay 2 terminals 2 and 5, and
- through daytime light relay 2 terminal 3
- to front headlamp LH terminal 3.

Ground is supplied

- to front headlamp RH terminal 2
- to daytime light relay 1 terminal 4
- to daytime light relay 2 terminal 1
- through grounds E9, E15 and E24.

When the CPU of the IPDM E/R energizes the headlamp low relay, it de-energizes daytime relay 1. When de-energized, this relay supplies ground

- to front headlamp LH terminal 2
- through daytime light relay 1 terminal 3.

With power and ground supplied, low beam headlamps illuminate.

## High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R across the CAN com-

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

munication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- through 10A fuse (No. 34, located in the IPDM E/R)
- through IPDM E/R terminal 56
- to front headlamp RH terminal 1, and
- through 10A fuse (No. 35, located in the IPDM E/R)
- through IPDM E/R terminal 55
- to front headlamp LH terminal 1.

Ground is supplied

- to front headlamp RH terminal 2,
- to daytime light relay 1 terminal 4, and
- to daytime light relay 2 terminal 1
- through grounds E9, E15 and E24.

When the CPU of the IPDM E/R energizes the headlamp high relay, it de-energizes daytime relay 1. When de-energized, this relay supplies ground

- to front headlamp LH terminal 2
- through daytime light relay 1 terminal 3.

With power and ground supplied, the high beam headlamps illuminate.

## DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, the IPDM E/R receives input requesting the daytime lights illuminate. This input is communicated across the CAN communication lines. The CPU of the IPDM E/R controls daytime light relay 1 coil. When energized, this relay directs power

- through daytime light relay 1 terminal 3
- through front headlamp LH terminal 2
- through front headlamp LH terminal 1
- through IPDM E/R terminal 55
- through 10A fuse (No. 35, located in the IPDM E/R)
- through 10A fuse (No. 34, located in the IPDM E/R)
- through IPDM E/R terminal 56
- to front headlamp RH terminal 1.

Ground is supplied

- to combination lamp RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, the daytime lights illuminate. The high beam headlamps are now wired in series and illuminate at a reduced intensity.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## AUTO LIGHT OPERATION

For auto light operation, refer to [LT-39, "System Description"](#) .

## CAN Communication System Description

Refer to [LAN-4, "CAN Communication System"](#) .

EKS00FUM





# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Wiring Diagram — DTRL —

EKS00FU0

LT-DTRL-01






REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA4223E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-02

— : DATA LINE



REFER TO THE FOLLOWING.


(E16) - ELECTRICAL UNITS

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


WKWA5437E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-03





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



WKWA4225E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-04



WKWA3081E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Terminals and Reference Values for BCM

EKS00FUP

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

A

## Terminals and Reference Values for IPDM E/R

EKS00FUQ

Refer to [PG-27, "Terminals and Reference Values for IPDM E/R"](#) .

B

## How to Proceed With Trouble Diagnosis

EKS00FUR

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-27, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-35, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the daytime light system operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

C

D

E

## Preliminary Check

EKS00FUS

### CHECK BCM CONFIGURATION

#### 1. CHECK BCM CONFIGURATION

F

Confirm BCM configuration for "DTRL" is set to "WITH". Refer to [BCS-19, "READ CONFIGURATION PROCEDURE"](#) .

G

OK or NG

- OK >> Continue preliminary check. Refer to [LT-35, "CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM"](#) .
- NG >> Change BCM configuration for "DTRL" to "WITH". Refer to [BCS-21, "WRITE CONFIGURATION PROCEDURE"](#) .

H

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

I

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R

J

Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#) .

## INSPECTION PARKING BRAKE SWITCH CIRCUIT

#### 1. CHECK BRAKE INDICATOR

LT

1. Turn ignition switch ON.
2. Apply parking brake.
3. Release parking brake.

L

**Brake indicator in combination meter should illuminate when parking brake is applied and turn OFF when released.**

M

OK or NG

- OK >> Inspection End.
- NG >> GO TO 2.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 2. CHECK PARKING BRAKE SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Turn ignition switch ON.
4. Check voltage between parking brake switch harness connector E53 terminal 1 and ground.

**1 - Ground : Battery voltage should exist.**

OK or NG

- OK >> Replace parking brake switch.  
NG >> GO TO 3.




## 3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M24 terminal 31 and parking brake switch harness connector E53 terminal 1.

**1 - 31 : Continuity should exist.**

OK or NG

- OK >> Replace combination meter. Refer to [IP-14, "COMBINATION METER"](#) .  
NG >> Repair harness or connector.



## CONSULT-II Function (BCM)

EKS00FUT

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II Function (IPDM E/R)

EKS00KDZ

Refer to [LT-13, "CONSULT-II Function \(IPDM E/R\)"](#) .

## Daytime Light Control Does Not Operate Properly (Normal Headlamps Operate Properly)

EKS00FUU


### 1. CHECK DAYTIME LIGHT RELAY 1 POWER SUPPLY CIRCUIT

1. Remove daytime light relay 1.
2. Check voltage between daytime light relay 1 harness connector E103 terminals 2, 5 and ground.

**2, 5 - Ground : Battery voltage should exist.**

OK or NG

- OK >> GO TO 2.  
NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 2. CHECK DAYTIME LIGHT RELAY 1

1. Apply battery voltage to daytime light relay 1 terminal 2 and ground terminal 1.
2. Check continuity between terminals 3 and 5.

**3 - 5 : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Replace daytime light relay 1.




## 3. CHECK INPUT SIGNAL

1. Connect daytime light relay 1.
2. Start engine and release parking brake. Headlamp switch OFF.
3. Select "IPDM E/R" on CONSULT-II. With data monitor, make sure "DTRL REQ" turns ON-OFF linked with operation of parking brake switch.

**Parking brake ON : DTRL REQ ON**  
**Parking brake OFF : DTRL REQ OFF**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) .  
 NG >> GO TO 4.




## 4. CHECKING CAN COMMUNICATIONS

Select "BCM" on CONSULT-II and perform self-diagnosis for BCM.

Displayed self-diagnosis results

- NO DTC>>Replace BCM. Refer to [BCS-25, "Removal and Installation"](#) .  
 CAN COMM CIRCUIT>> Check BCM CAN communication system. Refer to [BCS-18, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .



### Aiming Adjustment

Refer to [LT-23, "Aiming Adjustment"](#) .

### Bulb Replacement

Refer to [LT-26, "Disassembly and Assembly"](#) .

### Removal and Installation

Refer to [LT-25, "Removal and Installation"](#) .

### Disassembly and Assembly

Refer to [LT-26, "Disassembly and Assembly"](#) .


# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PF2:28491

### Component Parts and Harness Connector Location

EKS00FUZ



WKIA4959E

- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121,<br>E122, E123, E124 | 2. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) | 3. Combination switch (lighting switch)<br>M28 |
| 4. Combination meter<br>M24                                | 5. Rear door switch LH<br>B18<br>Rear door switch RH<br>B116             | 6. Optical sensor<br>M145                      |
| 7. Back door switch<br>D502                                | 7. Front door switch LH<br>B8<br>Front door switch RH<br>B108            |  |

# AUTO LIGHT SYSTEM

EKS00FV0

## System Description

Automatically turns on/off the parking lamps and the headlamps in accordance with ambient light. Timing for when the lamps turn on/off can be selected using four modes.

### OUTLINE

The auto light control system uses an optical sensor that detects outside brightness.

When the lighting switch is in "AUTO" position, it automatically turns on/off the parking lamps and the headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, refer to [LT-45, "SETTING CHANGE FUNCTIONS"](#).

Optical sensor ground is supplied

- to optical sensor terminal 3
- through BCM (body control module) terminal 18.

When ignition switch is turned to "ON" position and when outside brightness is darker than prescribed level, input is supplied

- to BCM terminal 58
- from optical sensor terminal 4.

The headlamps will then illuminate. For a description of headlamp operation, refer to [LT-5, "System Description"](#).

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the AUTO position, and the ignition switch is turned from ON or ACC to OFF, and one of the front doors is opened, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

### DELAY TIMER FUNCTION

When the ignition switch is ON and auto light switch is ON, the BCM turns on/off the headlamps. In delay timer function, ignition is OFF, auto light sensor power source is OFF and the headlamps are not turned on/off by the BCM. On condition that:

- when the state of ignition switch ON or ACC is ON and output judgment by auto light function is headlamp ON changes to ignition switch and ACC are OFF and any door switch is ON, output judgment by BCM should be headlamp ON for 5 minutes by timer. After time out, output judgment by BCM should be headlamp OFF.
- when the state of any door switch is turned to ON from OFF while 45 second or 5 minute timer is counting, timer stops, and restarts counting for 5 minutes, then BCM judges output as headlamp ON. After time out, BCM judges output as headlamp OFF.
- when the state of front door switch LH, front door switch RH, rear door switch LH, rear door switch RH or back door latch (door ajar switch) is ON turns to all door switches are OFF while 45 second or 5 minute timer is counting, timer stops, and restarts counting for 45 seconds, then BCM judges output as headlamp ON. After timer out, BCM judges output as headlamp OFF.
- when the state is ignition switch ON or ACC is ON or auto light switch OFF while timer is counting, timer stops counting and BCM turns on/off lamps according to headlamp function, front fog lamp function, auto light function and headlamp battery save function.

Delay timer control mode can be changed by the function setting of CONSULT-II or with the display (with NAVI).

## CAN Communication System Description

EKS00FV1

Refer to [LAN-4, "CAN Communication System"](#).

# AUTO LIGHT SYSTEM

## Major Components and Functions


EKS00FV2

Components	Functions
BCM	<ul style="list-style-type: none"><li>● Turns on/off circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), front door switch LH, front door switch RH, rear door switches, back door switch, and ignition switch (ON, OFF).</li></ul>
Optical sensor	<ul style="list-style-type: none"><li>● Converts ambient light (lux) to voltage, and sends it to BCM. (Detects lightness of 50 to 1,300 lux)</li></ul>

# AUTO LIGHT SYSTEM

## Schematic

EKS00FV3



\*: THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM).

WKWA5438E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

## Wiring Diagram — AUTO/L —

EKS00FV4

LT-AUTO/L-01





WKWA5439E



# AUTO LIGHT SYSTEM

LT-AUTO/L-03



WKWA4306E

# AUTO LIGHT SYSTEM

## Terminals and Reference Values for BCM

EKS00FV5

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

## Terminals and Reference Values for IPDM E/R

EKS00FV6

Refer to [PG-27, "Terminals and Reference Values for IPDM E/R"](#) .

## How to Proceed With Trouble Diagnosis

EKS00FV7

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-39, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-45, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction. Refer to [LT-47, "Trouble Diagnosis Chart by Symptom"](#) .
5. Does the auto light system operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS00FV8

### SETTING CHANGE FUNCTIONS

- Sensitivity of auto light system can be adjusted using CONSULT-II or with display (with NAVI). Refer to [LT-45, "WORK SUPPORT"](#) .

### CHECK BCM CONFIGURATION

#### 1. CHECK BCM CONFIGURATION

Confirm BCM configuration for "AUTO LIGHT" is set to "WITH". Refer to [BCS-19, "READ CONFIGURATION PROCEDURE"](#) .

OK or NG

- OK >> Continue preliminary check. Refer to [LT-45, "CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM"](#) .
- NG >> Change BCM configuration for "AUTO LIGHT" to "WITH". Refer to [BCS-21, "WRITE CONFIGURATION PROCEDURE"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R

Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#) .

## CONSULT-II Function (BCM)

EKS00FV9

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

### CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

## WORK SUPPORT

### Work Support Setting Item

- Sensitivity of auto light can be selected and set from four modes.

Work item	Description
CUSTOM ALIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. <ul style="list-style-type: none"><li>● MODE 1 (Normal-default)/ MODE 2 (Desensitized)/MODE 3 (Sensitive)/MODE4 (Insensitive)</li></ul>
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. <ul style="list-style-type: none"><li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)</li></ul>

# AUTO LIGHT SYSTEM

## DATA MONITOR Display Item List

Monitor item	Contents
IGN ON SW                    "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW                    "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW                    "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1              "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
HEAD LAMP SW 2              "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST                "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW                "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW                    "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW                    "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW-DR                  "ON/OFF"	Displays status of the front door LH as judged from the front door switch LH signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-AS                  "ON/OFF"	Displays status of the front door RH as judged from the front door switch RH signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RR                  "ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RL                  "ON/OFF"	Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW                "ON/OFF"	Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R                "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L                "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW                "ON/OFF"	Displays status of cargo lamp.
OPTICAL SENSOR                [0 - 5V]	Displays "ambient light (close to 5V when dark/close to 0V when light)" judged from optical sensor signal.

## ACTIVE TEST Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay (HI, LO) to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CARGO LAMP	Allows cargo lamp to operate by switching ON-OFF.

## CONSULT-II Function (IPDM E/R)

EKS00FVA

Refer to [LT-13, "CONSULT-II Function \(IPDM E/R\)"](#) .

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

# AUTO LIGHT SYSTEM

## DATA MONITOR

### All Items, Main Items, Select Item Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Parking, license plate and tail lamps request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lamps request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

### ACTIVE TEST

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI, LO) at your option (Headlamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.

## Trouble Diagnosis Chart by Symptom

EKS00FVB

Trouble phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1st position and 2nd position operate normally.)</li> <li>● Parking lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1st position and 2nd position operate normally.)</li> <li>● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-45, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-48, "Lighting Switch Inspection"</a> .</li> <li>● Refer to <a href="#">LT-48, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM. Refer to <a href="#">BCS-25, "Removal and Installation"</a> .</p>
Parking lamps illuminate when outside of the vehicle becomes dark, but headlamps stay off. (Lighting switch 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-45, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-48, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM. Refer to <a href="#">BCS-25, "Removal and Installation"</a> .</p>
Auto light adjustment system will not operate. (Lighting switch AUTO, 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-48, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above system is normal, replace BCM. Refer to <a href="#">BCS-25, "Removal and Installation"</a> .</p>
Auto light adjustment system will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line to BCM inspection. Refer to <a href="#">BCS-18, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> </ul>
Shut off delay feature will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-18, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> <li>● Refer to <a href="#">BL-27, "Door Switch Check"</a> .</li> </ul> <p>If above system is normal, replace BCM. Refer to <a href="#">BCS-25, "Removal and Installation"</a> .</p>

# AUTO LIGHT SYSTEM

EKS00FVC

## Lighting Switch Inspection

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in AUTO position : AUTO LIGHT SW ON**

⊗ Without CONSULT-II

Refer to [LT-75, "Combination Switch Inspection"](#).

OK or NG

OK >> Inspection End.

NG >> Check lighting switch. Refer to [LT-75, "Combination Switch Inspection"](#).

DATA MONITOR	
MONITOR	
AUTO LIGHT SW	ON

SKIA4196E

## Optical Sensor System Inspection

EKS00FVD

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "OPTICAL SENSOR" data monitor, check difference in the voltage when the optical sensor is illuminated and not illuminated.

**Illuminated**

**OPTICAL SENSOR : 3.1V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6V or less**

#### NOTE:

Optical sensor must be completely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.

⊗ Without CONSULT-II

GO TO 2.

OK or NG

OK >> Inspection End.

NG >> GO TO 2.

DATA MONITOR	
MONITOR	
OPTICAL SENSOR	XXXV

WKIA0486E

### 2. CHECK OPTICAL SENSOR SIGNAL GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M18 terminal 18 and optical sensor harness connector M145 terminal 3.

**18 - 3 : Continuity should exist.**


4. Check continuity (short circuit) between BCM harness connector M18 terminal 18 and ground.

**18 - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# AUTO LIGHT SYSTEM

## 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M20 terminal 58 and optical sensor harness connector M145 terminal 4.


**58 - 4 : Continuity should exist.**

2. Check continuity (short circuit) between BCM harness connector M20 terminal 58 and ground.

**58 - Ground : Continuity should not exist.**

### OK or NG

- OK >> Replace optical sensor. Refer to [LT-50, "Removal and Installation"](#) . Recheck sensor output with CONSULT-II.  
If NG, replace BCM. Refer to [BCS-25, "Removal and Installation"](#) .
- NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# AUTO LIGHT SYSTEM

## Removal and Installation OPTICAL SENSOR

EKS00EVE

### Removal

1. Using a thin blade screwdriver, gently pry upward to release optical sensor from defrost grille.
2. Disconnect optical sensor connector.



### Installation

Installation is in the reverse order of removal.


# FRONT FOG LAMP

PFP:26150

## FRONT FOG LAMP

### Component Parts and Harness Connector Location

EKS00FVF



WKIA4960E

- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121,<br>E122, E123, E124 | 2. BCM<br>M18, M19, M20<br>(view with instrument lower panel RH removed) | 3. Combination switch (lighting switch)<br>M28 |
| 4. Combination meter<br>M24                                |  |  |

### System Description

EKS00FVG

Control of the fog lamps is dependent upon the position of the combination switch (lighting switch). The lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) for front fog lamp operation. When the lighting switch is placed in the fog lamp position, the BCM (body control module) receives input signal requesting the fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the front fog lamp relay coil. When activated, this relay directs power to the front fog lamps.

### OUTLINE

Power is supplied at all times

- to ignition relay, located in the IPDM E/R, and
- to front fog lamp relay, located in the IPDM E/R, and
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM terminal 70.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59
- through grounds E9, E15 and E24.

### FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the fog lamp switch must be ON for fog lamp operation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## FRONT FOG LAMP

---

With the fog lamp switch in the ON position, the CPU of the IPDM E/R grounds the coil side of the fog lamp relay. The fog lamp relay then directs power

- through 20A fuse (No. 56, located in the IPDM E/R)
- through IPDM E/R terminal 50
- to front fog lamp LH terminal 1, and
- through IPDM E/R terminal 51
- to front fog lamp RH terminal 1.

Ground is supplied

- to front fog lamp LH and RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, the front fog lamps illuminate.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), the fog lamp switch is ON, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the fog lamps (and headlamps) remain illuminated for 5 minutes, then the fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

### CAN Communication System Description


EKS00FVH

Refer to [LAN-4, "CAN Communication System"](#) .




# FRONT FOG LAMP

LT-F/FOG-02



PRECEDING PAGE



WKWA3082E

# FRONT FOG LAMP

## Terminals and Reference Values for BCM

EKS00FVJ

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

A

## Terminals and Reference Values for IPDM E/R

EKS00FVK

Refer to [PG-27, "Terminals and Reference Values for IPDM E/R"](#) .

B

## How to Proceed With Trouble Diagnosis

EKS00FVL

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-51, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-55, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the front fog lamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

C

D

E

## Preliminary Check

EKS00FVM

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

F

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R

Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#) .

G

## CONSULT-II Function (BCM)

EKS00FVN

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II Function (IPDM E/R)

EKS00KE0

Refer to [LT-13, "CONSULT-II Function \(IPDM E/R\)"](#) .

H

## Front Fog Lamps Do Not Illuminate (Both Sides)

EKS00FVO

### 1. INSPECT FOG LAMP FUSE

Inspect fog lamp 20A fuse (No. 56, located in IPDM E/R).

OK or NG

- OK >> GO TO 2.
- NG >> Repair fog lamp power supply circuit.

J

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in FOG position : FR FOG SW ON**

OK or NG

- OK >> GO TO 3.
- NG >> Check lighting switch. Refer to [LT-75, "Combination Switch Inspection"](#) .

L

M

DATA MONITOR	
MONITOR	
FR FOG SW	ON

SKIA5897E

LT

# FRONT FOG LAMP


## 3. FOG LAMP ACTIVE TEST

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" on "ACTIVE TEST" screen.
4. Make sure fog lamps operate.

**Fog lamps should operate.**

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 5.




## 4. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is in FOG position : FR FOG REQ ON**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) .
- NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#) .




## 5. IPDM E/R INSPECTION

1. Disconnect fog lamp LH and RH.
2. Start auto active test. Refer to [PG-23, "Auto Active Test"](#) . When front fog lamp relay is operating, check voltage between left/right front fog lamp connector terminals and ground.

Front fog lamp		(-)	Voltage (Approx.)
( + )			
Connector	Terminal	Ground	Battery voltage
LH	E101		
RH	E102		

OK or NG

- OK >> Check front fog lamp bulbs and replace as necessary. Refer to [LT-59, "Bulb Replacement"](#) .
- NG >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) .



## Front Fog Lamp Does Not Illuminate (One Side)

EKS00FVP

### 1. BULB INSPECTION

Inspect bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace lamp bulb. Refer to [LT-59, "Bulb Replacement"](#) .

# FRONT FOG LAMP


## 2. INSPECTION BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Disconnect IPDM E/R connector and inoperative front fog lamp connector.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminal of front fog lamps.

IPDM E/R		Front fog lamp		Continuity	
Connector	Terminal	Connector	Terminal		
E123	50	LH	E101	1	Yes
	51	RH	E102		

### OK or NG

- OK >> Check ground circuit. If OK, replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#) . If NG, repair harness or connector.
- NG >> Check harness between IPDM E/R and front fog lamps.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

## Aiming Adjustment

EKS00FVQ


The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.


Adjust aiming in the vertical direction by turning the adjustment screw.

### NOTE:


Use a Phillips screwdriver to adjust. Turn screw clockwise to raise pattern and counterclockwise to lower pattern.



1. Set the distance between the screen and the center of the fog lamp lens as shown.



2. Turn front fog lamps ON.
  3. Remove front portion of fender protector(s) for adjustment screw access. Refer to [EI-21, "Removal and Installation of Front Fender Protector"](#)
  4. Adjust front fog lamps using adjustment screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



# FRONT FOG LAMP


EKS00FVR

## Bulb Replacement

1. Remove front portion of fender protector. Refer to [EI-21, "Removal and Installation of Front Fender Protector"](#)
2. Disconnect fog lamp connector.
3. Turn the bulb counterclockwise to remove it.

### CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of fog lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of fog lamp. When replacing bulb, be sure to replace it with new one.



## Removal and Installation FRONT FOG LAMP

EKS00FVS


The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

### CAUTION:

- Do not leave fog lamp assembly without bulb for a long period of time. Dust, moisture, smoke, etc. entering the fog lamp body may affect the performance. Remove the bulb from the headlamp assembly just before replacement bulb is installed.
- Grasp only the plastic base when handling the bulb. Never touch the glass envelope. Touching the glass could significantly affect the bulb life and/or fog lamp performance.

### Removal

1. Remove front portion of fender protector. Refer to [EI-21, "Removal and Installation of Front Fender Protector"](#)
2. Disconnect fog lamp connector.
3. Remove fog lamp screws and pull fog lamp rearward out of front bumper.



### Installation

Installation is in the reverse order of removal.


# TURN SIGNAL AND HAZARD WARNING LAMPS

## TURN SIGNAL AND HAZARD WARNING LAMPS

PF2:26120

### Component Parts and Harness Connector Location

EKS00FVT



WKIA4961E

1. BCM  
M18, M19, M20  
(view with instrument lower panel RH removed)
2. Combination switch (lighting switch)  
M28
3. Combination meter  
M24
4. Hazard switch

### System Description OUTLINE

EKS00FVU

Power is supplied at all times

- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM (body control module) terminal 70, and
- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 3.

### TURN SIGNAL OPERATION

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38, and
- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 16.

Ground is supplied

- to BCM terminal 67 and
- to combination meter terminals 13 and 23
- through grounds M57, M61 and M79.

### LH Turn

When the turn signal switch is moved to the left position, the BCM, interpreting it as turn signal is ON, outputs turn signal from BCM terminal 60.

The BCM supplies power

- through BCM terminal 60
- to front turn signal lamp LH terminal 1
- through front turn signal lamp LH terminal 3
- to grounds E9, E15 and E24, and
- to rear combination lamp LH (turn signal) terminal 4
- through rear combination lamp LH (turn signal) terminal 5
- to grounds B7 and B19.

# TURN SIGNAL AND HAZARD WARNING LAMPS

BCM sends signal to combination meter through CAN communication lines and turns on turn signal indicator lamp within combination meter.

## RH Turn

When the turn signal switch is moved to the right position, the BCM, interpreting it as turn signal is ON, outputs turn signal from BCM terminal 61.

The BCM supplies power

- through BCM terminal 61
- to front turn signal lamp RH terminal 1
- through front turn signal lamp RH terminal 3
- to grounds E9, E15 and E24, and
- to rear combination lamp RH (turn signal) terminal 4
- through rear combination lamp RH (turn signal) terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamp within combination meter.

## HAZARD LAMP OPERATION

Power is supplied at all times

- through 50A fusible link (letter **g** , located in the fuse and fusible link box)
- to BCM terminal 70, and
- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 3.

Ground is supplied

- to BCM terminal 67 and
- to combination meter terminals 13 and 23
- through grounds M57, M61 and M79.

When the hazard switch is depressed, ground is supplied

- to BCM terminal 29
- through hazard switch terminal 2
- through hazard switch terminal 1
- through grounds M57, M61 and M79.

When the hazard switch is depressed, the BCM, interpreting it as hazard warning lamps are ON, outputs turn signal from BCM terminals 60 and 61.

The BCM supplies power

- through BCM terminals 60 and 61
- to front turn signal lamp LH and RH terminal 1
- through front turn signal lamp LH and RH terminal 3
- to grounds E9, E15 and E24, and
- to rear combination lamp LH (turn signal) terminal 4
- through rear combination lamp LH (turn signal) terminal 5
- to grounds B7 and B19, and
- to rear combination lamp RH (turn signal) terminal 4
- through rear combination lamp RH (turn signal) terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines and turns on turn signal indicator lamps within combination meter.

## REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- through 50A fusible link (letter **g** , located in the fuse and fusible link box)
- to BCM terminal 70, and

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

## TURN SIGNAL AND HAZARD WARNING LAMPS

---

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 3.

Ground is supplied

- to BCM terminal 67 and
- to combination meter terminals 13 and 23
- through grounds M57, M61 and M79.

When the remote keyless entry system is triggered by input from the keyfob, the BCM, interpreting it as turn signal is ON, outputs turn signal from BCM terminals 60 and 61.

The BCM supplies power

- through BCM terminals 60 and 61
- to front turn signal lamp LH and RH terminal 1
- through front turn signal lamp LH and RH terminal 3
- to grounds E9, E15 and E24, and
- to rear combination lamp LH (turn signal) terminal 4
- through rear combination lamp LH (turn signal) terminal 5
- to grounds B7 and B19, and
- to rear combination lamp RH (turn signal) terminal 4
- through rear combination lamp RH (turn signal) terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamps within combination meter.

With power and input supplied, the BCM controls the flashing of the hazard warning lamps when keyfob is used to activate the remote keyless entry system.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### CAN Communication System Description

Refer to [LAN-4, "CAN Communication System"](#) .





EKS00FVV

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —

EKS00FVW



LT-TURN-01



WKWA5441E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



REFER TO THE FOLLOWING.  
 (M31), (M36), (M40) - SUPER  
 MULTIPLE JUNCTION (SMJ)

WKWA4307E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Terminals and Reference Values for BCM

EKS00FVX

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

## How to Proceed With Trouble Diagnosis

EKS00FVY

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-60, "System Description"](#) .
3. Perform preliminary check. Refer to [LT-65, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Do turn signal and hazard warning lamps operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS00FVZ

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

## CONSULT-II Function (BCM)

EKS00FW0

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

## DATA MONITOR

### Display Item List

Monitor item	Contents
IGN ON SW	"ON/OFF" Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
HAZARD SW	"ON/OFF" Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R	"ON/OFF" Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.
BRAKE SW	"ON/OFF" Displays status of stop lamp switch.

## ACTIVE TEST

### Display Item List

Test item	Description
FLASHER (RH)	Turn signal lamp (right) can be operated by any ON-OFF operations.
FLASHER (LH)	Turn signal lamp (left) can be operated by any ON-OFF operations.

## Turn Signal Lamps Do Not Operate

EKS00FW1

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in : TURN SIGNAL R ON  
TURN RH position**

**When lighting switch is in : TURN SIGNAL L ON  
TURN LH position**

☒ Without CONSULT-II

Refer to [LT-75, "Combination Switch Inspection"](#) .

OK or NG

OK >> Replace the BCM. Refer to [BCS-25, "Removal and Installation"](#) .

NG >> Check lighting switch. Refer to [LT-75, "Combination Switch Inspection"](#) .

DATA MONITOR	
MONITOR	
TURN SIGNAL R	ON
TURN SIGNAL L	ON

SKIA4499E

# TURN SIGNAL AND HAZARD WARNING LAMPS

EKS00KMR

## Front Turn Signal Lamps Do Not Operate

### 1. CHECK BULB

Check bulb standard of each turn signal lamp is correct. Refer to [LT-142, "Exterior Lamp"](#) .


OK or NG

OK >> GO TO 2.

NG >> Replace turn signal lamp bulb. Refer to [LT-25, "FRONT TURN SIGNAL/PARKING LAMP"](#) .

### 2. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and front turn signal lamp LH and RH connectors.
3. Check continuity between BCM harness connector M20 terminal 60 and front turn signal lamp LH harness connector E27 terminal 1.  
**60 - 1 : Continuity should exist.**
4. Check continuity between BCM harness connector M20 terminal 61 and front turn signal lamp RH harness connector E111 terminal 1.  
**61 - 1 : Continuity should exist.**




OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

### 3. CHECK GROUND

1. Check continuity between front turn signal lamp LH harness connector E27 terminal 3 and ground.  
**3 - Ground : Continuity should exist.**
2. Check continuity between front turn signal lamp RH harness connector E111 terminal 3 and ground.  
**3 - Ground : Continuity should exist.**



OK or NG

OK >> Inspect connection at front combination lamp.

NG >> Repair harness or connector.

## Rear Turn Signal Lamp Does Not Operate

EKS00FW2

### 1. CHECK TAIL LAMPS AND STOP LAMPS

Check bulb standard of each turn signal lamp is correct. Refer to [LT-142, "Exterior Lamp"](#) .

OK or NG

OK >> GO TO 2.

NG >> Replace turn signal lamp bulb. Refer to [LT-98, "Bulb Replacement"](#) .

# TURN SIGNAL AND HAZARD WARNING LAMPS


## 2. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect BCM connector and rear combination lamp connector.
2. Check continuity between BCM harness connector M20 terminal 61 and rear combination lamp RH harness connector B105 terminal 4.

**61 - 4** : Continuity should exist.

3. Check continuity between BCM harness connector M20 terminal 60 and rear combination lamp LH harness connector B35 terminal 4.

**60 - 4** : Continuity should exist.



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

## 3. CHECK GROUND CIRCUIT


Check continuity between rear combination lamp harness connector B35 (LH) and B105 (RH) terminal 5 and ground.

**5 - Ground** : Continuity should exist.

OK or NG

OK >> Check rear combination lamp connector for proper connection. Repair as necessary.

NG >> Repair harness or connector.



## Hazard Warning Lamp Does Not Operate But Turn Signal Lamps Operate

EKS00FW3

### 1. CHECK BULB

Make sure bulb standard of each turn signal lamp is correct. Refer to [LT-142, "Exterior Lamp"](#).

OK or NG

OK >> GO TO 2.


NG >> Replace turn signal lamp bulb. Refer to [LT-25, "FRONT TURN SIGNAL/PARKING LAMP"](#) for front turn signal bulb. Refer to [LT-98, "Bulb Replacement"](#) for rear turn signal bulb.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 2. CHECK HAZARD SWITCH INPUT SIGNAL

☑ With CONSULT-II  
 Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.

**When hazard switch is in ON position : HAZARD SW ON**




☒ Without CONSULT-II  
 Check voltage between BCM harness connector M18 terminal 29 and ground.

BCM (+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M18	29	Ground	Hazard switch is ON	0V
			Hazard switch is OFF	5V

OK or NG

- OK >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).
- NG >> GO TO 3.




## 3. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity between BCM harness connector M18 terminal 29 and hazard switch harness connector M55 terminal 2.

**29 - 2 : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.




## 4. CHECK GROUND

Check continuity between hazard switch harness connector M55 terminal 1 and ground.

**1 - Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 5. CHECK HAZARD SWITCH


1. Disconnect hazard switch connector.
2. Check continuity of hazard switch.

Hazard switch		Condition	Continuity
Terminal			
2	1	Hazard switch is ON	Yes
		Hazard switch is OFF	No

### OK or NG

OK >> Replace BCM if hazard warning lamps do not work after setting the connector again. Refer to [BCS-25, "Removal and Installation"](#) .

NG >> Replace hazard switch. Refer to [LT-72, "Removal and Installation"](#) .



## Turn Signal Indicator Lamp Does Not Operate

EKS00FW4

### 1. CHECK CAN COMMUNICATION SYSTEM

Check CAN communication. Refer to [LAN-4, "CAN Communication System"](#) .

### OK or NG

OK >> Replace combination meter. Refer to [IP-14, "COMBINATION METER"](#) .

NG >> Repair as necessary.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

LT

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

## **Bulb Replacement**

EKS00FW5

### **FRONT TURN SIGNAL LAMP**

Refer to [LT-25, "FRONT TURN SIGNAL/PARKING LAMP"](#) .

### **REAR TURN SIGNAL LAMP**

Refer to [LT-98, "Bulb Replacement"](#) .

## **Removal and Installation**

EKS00FW7

### **FRONT TURN SIGNAL LAMP**

Refer to [LT-25, "Removal and Installation"](#) .

### **REAR TURN SIGNAL LAMP**

Refer to [LT-98, "Removal and Installation"](#) .

# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PF25540

### Removal and Installation

EKS00FW9

#### REMOVAL

1. Remove instrument lower cover LH. Refer to [IP-14, "LOWER INSTRUMENT PANEL LH"](#) .
2. Remove steering column cover.
3. Disconnect the lighting and turn signal switch connector.
4. While pressing tabs, pull lighting and turn signal switch toward driver door and release from the steering column.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HAZARD SWITCH

PFP:25290


## HAZARD SWITCH

### Removal and Installation

EKS00FWA

#### REMOVAL

1. Remove cluster lid C. Refer to [IP-11, "CLUSTER LID C -WITHOUT NAVIGATION SYSTEM"](#) .
2. Disconnect the hazard switch connector.
3. Remove the screws and remove the hazard switch.



#### INSTALLATION

Installation is in the reverse order of removal.

# COMBINATION SWITCH

PF2:25567





## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

EKS00FWB

## LT-COMBSW-01

DATA LINE



WKWA5442E

# COMBINATION SWITCH

## Combination Switch Reading Function

EKS00FWC

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CONSULT-II Function (BCM)

EKS00FWD

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

## DATA MONITOR

### Display Item List

Monitor item name "OPERATION OR UNIT"	Contents
TURN SIGNAL R "ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Other: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays "Headlamp switch 1 (ON)/Other (OFF)" status, determined from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Other: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1st position: ON/Other: OFF) of lighting switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Other: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays "Auto light switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR FOG SW "ON/OFF"	Displays "Front fog lamp switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR WIPER HI "ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT "ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WASHER SW "ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME [1 - 7]	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
RR WIPER ON "ON/OFF"	Displays "Rear Wiper (ON)/(OFF)" status, determined from wiper switch signal.
RR WIPER INT "ON/OFF"	Displays "Rear Wiper INT (ON)/(OFF)" status, determined from wiper switch signal.
RR WASHER SW "ON/OFF"	Displays "Rear Washer (ON)/(OFF)" status, determined from wiper switch signal.

# COMBINATION SWITCH

EKS00FWE

## Combination Switch Inspection

### 1. SYSTEM CHECK

Referring to table below, check to which system the malfunctioning switch belongs.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	TAIL LAMP
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> GO TO 2.

### 2. SYSTEM CHECK

 With CONSULT-II

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

1. Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START", and confirm that other switches in malfunctioning system operate normally.

Example: When auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR	
MONITOR	
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
HIBEAM SW	OFF
HEAD LAMP SW1	OFF
HEAD LAMP SW2	OFF
LIGHT SW 1ST	OFF
PASSING SW	OFF
AUTO LIGHT SW	OFF
FR FOG SW	OFF
	Page Down
	RECORD
MODE	BACK
LIGHT	COPY

SKIA7075E

 Without CONSULT-II

Operate combination switch, and confirm that other switches in malfunctioning system operate normally.

Example: When auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, operate normally.

#### Check results

Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.


Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. HARNESS INSPECTION

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check for continuity between BCM harness connector of the suspect system and the corresponding combination switch connector terminals.

Suspect system	A		B		Continuity	
	BCM connector	Terminal	Combination switch connector	Terminal		
1	M18	Input 1	6	M28	6	Yes
		Output 1	36		1	
2		Input 2	5		7	
		Output 2	35		2	
3		Input 3	4		10	
		Output 3	34		3	
4		Input 4	3		9	
		Output 4	33		4	
5		Input 5	2		8	
		Output 5	32		5	



4. Check for continuity between each terminal of BCM harness connector in suspect malfunctioning system and ground.

Suspect system	A			Continuity	
	BCM connector	Terminal			
1	A: M18	Input 1	6	Ground	No
		Output 1	36		
2		Input 2	5		
		Output 2	35		
3		Input 3	4		
		Output 3	34		
4		Input 4	3		
		Output 4	33		
5		Input 5	2		
		Output 5	32		

OK or NG

OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH


## 4. BCM OUTPUT TERMINAL INSPECTION

1. Connect BCM and combination switch connectors.
2. Turn lighting switch and wiper switch to OFF.
3. Set wiper dial to position 4.
4. Turn ignition switch ON, and check combination switch input (BCM output) terminal voltage waveform of suspect malfunctioning system.

Suspect system	Combination switch		
	(+)		
	Connector	Terminal	
1	M28	Input 1	1
2		Input 2	2
3		Input 3	3
4		Input 4	4
5		Input 5	5

### OK or NG

- OK >> Open circuit in combination switch, GO TO 5.  
 NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).



## 5. COMBINATION SWITCH INSPECTION

Referring to table below, perform combination switch inspection.

Procedure									
1	2		3	4		5	6		7
Replace lighting switch.	Confirm check results.	OK	INSPECTION END	Confirm check results.	OK	INSPECTION END	Confirm check results.	OK	INSPECTION END
		NG	Replace wiper switch.		NG	Replace switch base.		NG	Confirm symptom again.

>> Inspection End.

### Removal and Installation

For details, refer to [LT-71, "Removal and Installation"](#).

### Switch Circuit Inspection

For details, refer to [LT-75, "Combination Switch Inspection"](#).

# STOP LAMP

---

## STOP LAMP

PF2:26550

### System Description

EKS00FWH

Power is supplied at all times

- through 10A fuse [No. 20, located in fuse block (J/B)]
- to stop lamp switch terminal 1, and
- to stop lamp relay terminals 2 and 3 (with hill descent control and hill start assist).

When the brake pedal is pressed, the stop lamp switch is closed and power is supplied

- through stop lamp switch terminal 2
- to rear combination lamp LH and RH terminal 2
- to high-mounted stop lamp terminal 1
- to ABS actuator and electric unit (control unit) terminal 41.

Ground is supplied

- to rear combination lamp LH terminal 5
- through grounds B7 and B19, and
- to high-mounted stop lamp terminal 2
- through grounds D406 and D504, and
- to rear combination lamp RH terminal 5
- through grounds B117 and B132.

With power and ground supplied, the stop lamps illuminate.



# STOP LAMP

## High-Mounted Stop Lamp BULB REPLACEMENT


EKS00FWJ

The high-mounted stop lamp bulbs are not serviceable.

### REMOVAL AND INSTALLATION

#### Removal

1. Remove back door window garnish.
2. Disconnect high-mounted stop lamp connector.
3. Remove nuts and remove high-mounted stop lamp.



#### Installation

Installation is in the reverse order of removal.

## Stop Lamp BULB REPLACEMENT

EKS00FWK

Refer to [LT-98, "Bulb Replacement"](#) .

### REMOVAL AND INSTALLATION

Refer to [LT-98, "Removal and Installation"](#) .

# BACK-UP LAMP

PF2:26550



EKS00FWL

## BACK-UP LAMP

### Wiring Diagram — BACK/L —

## LT-BACK/L-01

⬡ NV : WITH NAVI



REFER TO THE FOLLOWING.  
 (M31), (M36), (M40) - SUPER MULTIPLE JUNCTION (SMJ)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

WKWA5345E

# BACK-UP LAMP

---

## **Bulb Replacement**

*EKS00FWM*

Refer to [LT-98, "Bulb Replacement"](#) .

## **Removal and Installation**

*EKS00FWM*

Refer to [LT-98, "Removal and Installation"](#) .


# PARKING, LICENSE PLATE AND TAIL LAMPS

## PARKING, LICENSE PLATE AND TAIL LAMPS

PF26550

### Component Parts and Harness Connector Location

EKS00FWO



WKIA4963E

- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121,<br>E122, E123, E124 | 2. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) | 3. Combination switch (lighting switch)<br>M28 |
| 4. Combination meter<br>M24                                |  |  |

### System Description

EKS00FWP

Control of the parking, front side marker, license plate, and tail lamp operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST position, the BCM (body control module) receives input signal requesting the parking, front side marker, license plate and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the parking, front side marker, license plate and tail lamps, which then illuminate.

Power is supplied at all times

- to ignition relay, located in the IPDM E/R,
- to tail lamp relay, located in the IPDM E/R,
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM terminal 70.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R.
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38 and

Ground is supplied

- to BCM terminal 67
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59
- through grounds E9, E15 and E24.

### OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input signal requesting the parking, front side marker, license plate and tail lamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU in the IPDM E/R controls the tail lamp relay coil, which when energized, directs power

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## PARKING, LICENSE PLATE AND TAIL LAMPS

---

- through 10A fuse (No. 37, located in the IPDM E/R)
- through IPDM E/R terminal 57
- to license plate lamp LH and RH terminal 1
- to rear combination lamp LH and RH (tail/side marker) terminal 1, and
- through 10A fuse (No. 36, located in the IPDM E/R)
- through IPDM E/R terminals 28 and 49
- to front side marker lamp LH and RH terminal 1
- to front parking lamp LH and RH terminal 2.

Ground is supplied

- to front side marker lamp LH and RH terminal 2
- to front parking lamp LH and RH terminal 3
- through grounds E9, E15 and E24, and
- to license plate lamp LH and RH terminal 2
- through grounds D406 and D504, and
- to rear combination lamp LH (tail/side marker) terminal 5
- through grounds B7 and B19, and
- to rear combination lamp RH (tail/side marker) terminal 5
- through grounds B117 and B132.

With power and ground supplied, the parking, side marker, license plate and tail lamps illuminate.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the parking, front side marker, license and tail lamps remain illuminated for 5 minutes, then the parking, front side marker, license plate and tail lamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

### CAN Communication System Description


EKS00FWQ

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

EKS00FWR



\*: THIS RELAY IS BUILT INTO THE IPDM/E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

WKWA5443E




# PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00FWS

## Wiring Diagram — TAIL/L —

### LT-TAIL/L-01

— : DATA LINE




REFER TO THE FOLLOWING.

M31 - SUPER MULTIPLE JUNCTION (SMJ)


WKWA5444E

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



WKWA3087E

# PARKING, LICENSE PLATE AND TAIL LAMPS


LT-TAIL/L-03



WKWA2039E


# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-04



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT



REFER TO THE FOLLOWING.  
(M31), (M36) - SUPER  
MULTIPLE JUNCTION (SMJ)

WKWA4342E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

EKS00FWT

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

## Terminals and Reference Values for IPDM E/R

EKS00FWU

Refer to [PG-27, "Terminals and Reference Values for IPDM E/R"](#) .

## How to Proceed With Trouble Diagnosis

EKS00FWV

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-83, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-90, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Do the parking, front side marker, license and tail lamps operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS00FWW

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT FOR IPDM E/R

Refer to [PG-29, "IPDM E/R Power/Ground Circuit Inspection"](#) .

## CONSULT-II Function (BCM)

EKS00FWX

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II Function (IPDM E/R)

EKS00KOM

Refer to [LT-13, "CONSULT-II Function \(IPDM E/R\)"](#) .

## Parking, Side Marker, License Plate and/or Tail Lamps Do Not Illuminate

EKS00FWY

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓟ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "LIGHT SW 1ST" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in 1ST position : LIGHT SW 1ST ON**

Ⓧ Without CONSULT-II

Refer to [LT-75, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check lighting switch. Refer to [LT-75, "Combination Switch Inspection"](#) .

DATA MONITOR	
MONITOR	
LIGHT SW 1ST	ON

SKIA5956E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 2. ACTIVE TEST

Ⓜ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "EXTERNAL LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "TAIL" on "ACTIVE TEST" screen.
4. Make sure parking, front side marker, license plate and tail lamp operation.

**Parking, front side marker, license plate and tail lamp should operate**

ACTIVE TEST			
EXTERNAL LAMPS		OFF	
		TAIL	
LO		HI	
FOG			
MODE	BACK	LIGHT	COPY

WKIA1438E

Ⓧ Without CONSULT-II

1. Start auto active test. Refer to [PG-23, "Auto Active Test"](#).
2. Make sure parking, front side marker, license plate and tail lamp operation.

**Parking, front side marker, license plate and tail lamp should operate**

OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 4.

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "TAIL&CLR REQ" turns ON when lighting switch is in 1ST position.

**When lighting switch is in 1ST position : TAIL&CLR REQ ON**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).

DATA MONITOR			
MONITOR			
TAIL&CLR REQ		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5958E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK INPUT SIGNAL


④ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front parking lamp, front side marker lamp, license plate lamp and rear combination lamp connectors.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
6. Touch "ON" on "ACTIVE TEST" screen.
7. When tail lamp is operating, check voltage between front parking lamp, front side marker lamp, license plate lamp, rear combination lamp harness connector and ground.


⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-23, "Auto Active Test"](#).
2. When tail lamp is operating, check voltage between front side marker lamp, front parking lamp, license plate lamp, rear combination lamp harness connector and ground.


Front side marker lamp		Terminal	(-)	Voltage
(+) Connector				
LH	E17	1	Ground	Battery voltage
RH	E108			



Front parking lamp		Terminal	(-)	Voltage
(+) Connector				
LH	E27	2	Ground	Battery voltage
RH	E111			



License plate lamp		Terminal	(-)	Voltage
(+) Connector				
LH	D506	1	Ground	Battery voltage
RH	D507			




# PARKING, LICENSE PLATE AND TAIL LAMPS

Rear combination lamp		Terminal	(-)	Voltage
(+)				
Connector		1	Ground	Battery voltage
LH	B35			
RH	B105			

**OK or NG**

OK >> GO TO 6.  
 NG >> GO TO 5.




A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 LT  
 L  
 M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK PARKING, SIDE MARKER, LICENSE PLATE AND TAIL LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
E121	28	LH	E17	Yes
E123	49	RH	E108	



4. Check continuity between IPDM E/R harness connector and front parking lamp harness connector.


IPDM E/R		Front parking lamp		Continuity
Connector	Terminal	Connector	Terminal	
E121	28	LH	E27	Yes
E123	49	RH	E111	



# PARKING, LICENSE PLATE AND TAIL LAMPS


5. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity	
Connector	Terminal	Connector	Terminal		
E124	57	LH	D506	1	Yes
		RH	D507		



6. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
E124	57	LH	B35	1	Yes
		RH	B105		



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-32, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 6. CHECK GROUND


1. Turn ignition switch OFF.
2. Check continuity between front side marker lamp harness connector and ground.

Front side marker lamp		Terminal	Ground	Continuity
Connector				
LH	E17	2	Ground	Yes
RH	E108			




3. Check continuity between front parking lamp harness connector and ground.

Front parking lamp		Terminal	Ground	Continuity
Connector				
LH	E27	3	Ground	Yes
RH	E111			




4. Check continuity between license plate lamp harness connector and ground.

License plate lamp		Terminal	Ground	Continuity
Connector				
LH	D506	2	Ground	Yes
RH	D507			



5. Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp		Terminal	Ground	Continuity
Connector				
LH	B35	5	Ground	Yes
RH	B105			



### OK or NG

- OK >> Check bulbs.  
 NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Parking, Side Marker, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

EKS00FWZ

### 1. CHECK IPDM E/R

1. Turn ignition switch ON. Turn the combination switch (lighting switch) to the OFF position. Turn ignition switch OFF.
2. Verify that the parking, front side marker, license plate and tail lamps turn on and off after approximately 10 minutes.

#### OK or NG

- OK >> Ignition relay malfunction. Refer to [PG-19, "Function of Detecting Ignition Relay Malfunction"](#) .  
NG >> Inspection End.

## Bulb Replacement FRONT PARKING LAMP

EKS00FX0

Refer to [LT-25, "FRONT TURN SIGNAL/PARKING LAMP"](#) .

### TAIL LAMP

For bulb replacement, refer to [LT-98, "Bulb Replacement"](#) .

### LICENSE PLATE LAMP

#### Removal

1. Remove back door finisher. Refer to [EI-36, "BACK DOOR TRIM"](#) .
2. Turn bulb socket counterclockwise and remove bulb socket.
3. Remove license plate lamp bulb.

#### Installation

Installation is in the reverse order of removal.

## Removal and Installation LICENSE PLATE LAMP

EKS00HJU

#### Removal

1. Remove license lamp finisher. Refer to [EI-19, "LICENSE LAMP FINISHER"](#) .
2. Disconnect license plate lamp harness connector.
3. Remove license plate lamp screw and remove license plate lamp.

#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# REAR COMBINATION LAMP


## REAR COMBINATION LAMP

PF2P:26554

### Bulb Replacement REMOVAL

EKS00FX2

1. Remove rear combination lamp bolts.
2. Pull rear combination lamp to remove from the vehicle.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb.



### INSTALLATION

Installation is in the reverse order of removal.

### Removal and Installation REMOVAL

EKS00FX3

1. Remove rear combination lamp bolts.
2. Pull rear combination lamp to remove from the vehicle.
3. Disconnect rear combination lamp connector.

### INSTALLATION

Installation is in the reverse order of removal.


# TRAILER TOW

PFP:93020

EKS00FX4

## TRAILER TOW

### Component Parts and Harness Connector Location



- |  |  |  |
|--|--|--|
| 1. IPDM E/R<br>E118, E119, E120, E121,<br>E122, E123, E124 | 2. Trailer tow relays<br>E140, E148            | 3. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) |
| 4. Electric brake (pre-wiring)<br>M76                      | 5. Combination switch (lighting switch)<br>M28 | 6. Combination meter<br>M24  |
| 7. Trailer connector<br>C126                               |  |  |

WKIA4962E

### System Description

EKS00FX5

Power is supplied at all times

- to ignition relay, located in the IPDM E/R (intelligent power distribution module engine room),
- to tail lamp relay, located in the IPDM E/R,
- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM (body control module) terminal 70,
- to 15A fuse (No. 60, located in the fuse and relay box),
- to trailer turn relay RH and LH terminal 5,
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU of the IPDM E/R,
- through 10A fuse (No. 32, located in the IPDM E/R)
- to IPDM E/R terminal 61
- to trailer tow relay 1 terminal 3,
- through 30A fusible link (letter **m**, located in the fuse and fusible link box)
- to trailer tow relay 2 terminals 3 and 6, and
- through 30A fusible link (letter **h**, located in the fuse and fusible link box)
- to electric brake (pre-wiring) terminal 5.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TRAILER TOW

---

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38, and
- through 10A fuse (No. 38, located in the IPDM E/R)
- to IPDM E/R terminal 27, and
- to trailer tow relay 2 terminal 1.

Ground is supplied

- to BCM terminal 67 and
- to electric brake (pre-wiring) terminal 1
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59
- to trailer tow relay 1 terminal 2
- to trailer tow relay 2 terminal 2
- to trailer connector terminal 1 (trailer tow 7 pin) or terminal 4 (trailer tow 4 pin), and
- to trailer turn relay RH and LH terminal 2
- through grounds E9, E15 and E24.

## TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow relay 1.

With the lighting switch in the parking and tail lamp ON (1ST) position, AUTO position (and the auto light system is activated) or headlamp ON (2ND) position, power is supplied from the tail lamp relay

- through 10A fuse (No. 37, located in the IPDM E/R)
- through IPDM E/R terminal 29
- to trailer tow relay 1 terminal 1.

When energized, trailer tow relay 1 tail lamp power is supplied

- through trailer tow relay 1 terminal 5
- to trailer connector terminal 3.

## TRAILER STOP, TURN SIGNAL AND HAZARD LAMP OPERATION

The trailer stop, turn signal and hazard lamps are controlled by the BCM. If either turn signal or the hazard lamps are turned on, the BCM supplies voltage to the trailer turn relay RH or LH to make them flash. If the BCM receives stop lamp switch signal, the BCM supplies voltage to the trailer turn relay RH and LH to make them illuminate.

Left stop, turn signal and hazard lamp output is supplied

- through BCM terminal 52
- to trailer turn relay LH terminal 1

When energized, trailer turn relay LH supplies power to the left stop, turn signal, and hazard lamp

- through trailer turn relay LH terminal 3
- to trailer connector terminal 2 (trailer tow 7 pin) or terminal 1 (trailer tow 4 pin).

Right stop, turn signal and hazard lamp output is supplied

- through BCM terminal 51
- to trailer turn relay RH terminal 1

When energized, trailer turn relay RH supplies power to the right stop, turn signal, and hazard lamp

- through trailer turn relay RH terminal 3
- to trailer connector terminal 5 (trailer tow 7 pin) or terminal 2 (trailer tow 4 pin).

## TRAILER POWER SUPPLY OPERATION

The trailer power supply (trailer tow 7 pin connector only) is controlled by trailer tow relay 2.

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse (No. 38, located in the IPDM E/R)
- through IPDM E/R terminal 27

## TRAILER TOW

---

- to trailer tow relay 2 terminal 1.
- When energized, trailer tow relay 2 power is supplied
- through trailer tow relay 2 terminals 5 and 7
  - to trailer connector terminal 4.

A

B

C

D

E

F

G

H

I

J

**LT**

L


M

# TRAILER TOW

## Schematic

EKS00FX6

(T4) : TRAILER TOW 4-PIN  
(TT) : TRAILER TOW 7-PIN



\*: THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

WKWA5445E




# TRAILER TOW

## Wiring Diagram — T/TOW —

EKS00FX7

### LT-T/TOW-01

▬ : DATA LINE




WKWA5446E

# TRAILER TOW

LT-T/TOW-02


▬ : DATA LINE



REFER TO "PG-POWER".


PRE-CEDING PAGE

TO LT-T/TOW-05



WKWA4234E

# TRAILER TOW






LT-T/TOW-03

ⓉⓉ: TRAILER TOW 7 PIN

REFER TO "PG-POWER".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA5346E






# INTERIOR ROOM LAMP

PF2:26410

## INTERIOR ROOM LAMP

### Component Parts and Harness Connector Location

EKS00FX8



WKIA4971E

- |   |  |   |
|---|--|---|
| 1. BCM<br>M18, M19, M20<br>(view with instrument lower panel<br>LH removed) | 2. Key switch<br>M27<br>(view with instrument lower panel LH<br>removed)           | 3. Steering column assembly                                     |
| 4. Glass hatch ajar switch<br>D506  | 5. Front door switch LH<br>B8<br>Front door switch RH<br>B108                      | 6. Rear door switch LH<br>B18<br>Rear door switch RH<br>B116    |
| 7. Back door switch<br>D502   | 8. Room lamp 2nd row<br>(without map lamps)<br>R12<br>(with rear map lamps)<br>R10 | 9. Front room/map lamp assembly<br>(with front map lamps)<br>R9 |
| 10. Vanity lamps (with vanity lamps)<br>LH B80<br>Vanity lamps<br>RH B81    | 11. Ignition keyhole illumination<br>M150  | 12. Cargo lamp<br>R11   |

# INTERIOR ROOM LAMP

EKS00FX9

## System Description

When room lamp and personal lamp switch is in DOOR position, room lamp and personal lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch LH, unlock signal from keyfob, door lock and unlock switch, key cylinder switch, ignition switch and glass hatch ajar switch.

When room/map lamp and personal lamp turns ON, there is a gradual brightening over 1 second. When room/map lamp and personal lamp turns OFF, there is a gradual dimming over 1 second.

The room/map lamp and personal lamp timer is controlled by the BCM (body control module).

Room/map lamp and personal lamp timer control settings can be changed with CONSULT-II.

Ignition keyhole illumination turns ON when front door LH is opened (door switch ON) or key is removed from key cylinder. Illumination turns OFF when front door LH is closed (door switch OFF).

## POWER SUPPLY AND GROUND

Power is supplied at all times

- through 10A fuse (No. 25, located in the fuse and fusible link box)
- to key switch terminal 2,
- through 10A fuse [No. 18, located in the fuse block (J/B)]
- to BCM terminal 57, and
- through 50A fusible link (letter **g**, located in the fuse and fusible link box)
- to BCM terminal 70.

When the key is inserted in key switch, power is supplied

- through the key switch terminal 1
- to BCM terminal 37.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67
- through grounds M57, M61 and M79.

When the front door LH is opened, ground is supplied

- to BCM terminal 47
- through front door switch LH terminal 2
- through case ground of front door switch LH.

When the front door RH is opened, ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- through case ground of front door switch RH.

When the rear door LH is opened, ground is supplied

- to BCM terminal 48
- through rear door switch LH terminal 2
- through case ground of rear door switch LH.

When the rear door RH is opened, ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 2
- through case ground of rear door switch RH.

When the glass hatch is opened, ground is supplied

- to BCM terminal 42
- through glass hatch ajar switch terminal 1
- through case ground of glass hatch ajar switch.

When the liftgate is opened, ground is supplied

- to BCM terminal 43
- through back door switch terminal 3

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

# INTERIOR ROOM LAMP

---

- through back door switch terminal 1
- through grounds D406 and D504.

When the front door LH is unlocked by the key, the main power window and door lock/unlock switch receives ground signal

- to main power window and door lock/unlock switch terminal 6
- through front door lock assembly LH (key cylinder switch) terminal 3
- through front door lock assembly LH (key cylinder switch) terminal 4
- through grounds M57, M61 and M79.

The BCM receives the unlock signal as serial data

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 14.

When a signal, or combination of signals is received by BCM, ground is supplied

- to front room/map lamp assembly terminal 2
- to personal lamp 2nd row terminal 2 (with rear map lamps)
- to room lamp 2nd row terminal 1
- through BCM terminal 63, and
- to cargo lamp terminal 1
- through BCM terminal 49.

With power and ground supplied, the lamps illuminate.

## SWITCH OPERATION

When any door switch is ON (door is opened), ground is supplied

- to front room/map lamp assembly terminal 2
- to personal lamp 2nd row terminal 2 (with rear map lamps)
- to room lamp 2nd row terminal 1
- through BCM terminal 63, and
- to ignition keyhole illumination terminal 2
- through BCM terminal 1.

And power is supplied

- through BCM terminal 56
- to ignition keyhole illumination terminal 1
- to front room/map lamp assembly terminal 1
- to vanity lamp LH and RH terminal 1 (if equipped)
- to personal lamp 2nd row terminal 1 (with rear map lamps)
- to room lamp 2nd row terminal 2
- to cargo lamp terminal 2.

When front room/map lamp switch is ON, ground is supplied

- to front room/map lamp assembly terminal 3
- through grounds M57, M61 and M79.

When vanity lamp (LH and RH) (if equipped) is ON, ground is supplied

- to vanity lamp (LH and RH) terminal 2
- through grounds B7 and B19.

When personal lamp 2nd row (with rear map lamps) is ON, ground is supplied

- to personal lamp 2nd row terminal 3
- through grounds M57, M61 and M79.

When room lamp 2nd row is ON, ground is supplied through room lamp case ground.

When cargo lamp switch is ON, ground is supplied through cargo lamp case ground.

## ROOM LAMP TIMER OPERATION

When lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for interior room lamp and map lamp ON/OFF.

# INTERIOR ROOM LAMP

Power is supplied

- through 10A fuse [No. 25, located in the fuse block (J/B)]
- to key switch terminal 2.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37. Ground is supplied

- to BCM terminal 46
- through main power window and door lock/unlock switch terminal 11.

At the time that front door LH is opened, BCM detects that front door LH is unlocked. It determines that interior room lamp and map lamp timer operation conditions are met, and turns the interior room lamps ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), power is supplied

- through key switch terminal 1
- to BCM terminal 37.

When key is removed from key switch and key lock solenoid (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that interior room lamp and map lamp timer conditions are met, and turns the interior room lamps ON for 30 seconds.

When front door LH opens → closes, and the key is not inserted in the key switch (key switch OFF), BCM terminal 47 changes between 0V (door open) → 12V (door closed). The BCM determines that conditions for interior room lamp operation are met and turns the interior room lamp ON for 30 seconds.

Timer control is canceled under the following conditions

- Front door LH is locked [when locked by keyfob, main power window and door lock/unlock switch, or front door lock assembly LH (key cylinder switch)]
- Front door LH is opened (front door switch LH turns ON)
- Ignition switch ON.

## INTERIOR LAMP BATTERY SAVER CONTROL

If interior lamp is left ON, it will not be turned off even when door is closed.

BCM turns off interior lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior lamps listed below:

- Vanity lamp (if equipped)
- Front room/map lamp
- Cargo lamp
- Personal lamp 2nd row (with rear map lamps)
- Room lamp 2nd row
- Ignition keyhole illumination

After lamps turn OFF by the battery saver system, the lamps illuminate again when

- signal received from keyfob, main power window and door lock/unlock switch or front door lock assembly LH (key cylinder switch) is locked or unlocked
- door is opened or closed
- key is removed from ignition key cylinder or inserted in ignition key cylinder.


Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# INTERIOR ROOM LAMP

## Schematic

EKS00FXA



# INTERIOR ROOM LAMP



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

WKWA3092E


# INTERIOR ROOM LAMP

## Wiring Diagram — INT/L —

EKS00FXB


### LT-INT/L-01

■ : DATA LINE



REFER TO "PG-POWER".

BCM (BODY CONTROL MODULE)  
(M18), (M20)





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA4238E

# INTERIOR ROOM LAMP

LT-INT/L-02





REFER TO THE FOLLOWING.  
 (M36), (M40) - SUPER  
 MULTIPLE JUNCTION (SMJ)

WKWA4343E

# INTERIOR ROOM LAMP

LT-INT/L-03





WKWA5348E

# INTERIOR ROOM LAMP

**LT-INT/L-04**



(VN) : WITH VANITY LAMPS



# INTERIOR ROOM LAMP

LT-INT/L-05

 : WITH REAR MAP LAMPS



WKWA3094E

# INTERIOR ROOM LAMP

## Terminals and Reference Values for BCM

EKS00FXC

Refer to [LT-12, "Terminals and Reference Values for BCM"](#) .

## How to Proceed With Trouble Diagnosis

EKS00FXD

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-109, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-119, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the interior room lamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS00FXE

### INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT FOR BCM

Refer to [BCS-16, "BCM Power Supply and Ground Circuit Check"](#) .

## CONSULT-II Function (BCM)

EKS00FXF

Refer to [LT-12, "CONSULT-II Function \(BCM\)"](#) .

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

## WORK SUPPORT

### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds operating function of the interior room lamps and the ignition keyhole illumination can be selected when front door LH is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when the interior room lamps and the ignition keyhole illumination is turned on.	MODE 1 - 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when the interior room lamps and the ignition keyhole illumination is turned off.	MODE 1 - 7

Reference between "MODE" and "TIME" for "TURN ON/OFF".

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

## DATA MONITOR

### Display Item List

Monitored Item	Description
IGN ON SW	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
KEY ON SW	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key switch signal.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
BACK DOOR SW	Indicates [ON/OFF] condition of back door switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
KEYLESS PANIC	Indicates [ON/OFF] condition of panic signal from keyfob.
KEYLESS UNLOCK	Indicates [ON/OFF] condition of unlock signal from keyfob.

# INTERIOR ROOM LAMP

KEYLESS LOCK	Indicates [ON/OFF] condition of lock signal from keyfob.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from door key cylinder switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from lock/unlock switch.
RKE LCK-UNLCK	Indicates [ON/OFF] condition of lock/unlock signal at the same time from keyfob.
RKE KEEP UNLK	Indicates [ON/OFF] condition of unlock signal from keyfob.

## ACTIVE TEST

### Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition keyhole illumination can be operated by ON-OFF operation.

## Room/Map Lamp Control Does Not Operate

EKS00FXG

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-119, "Display Item List"](#) for switches and their functions.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E

### 2. ACTIVE TEST

- Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
- When switch is in DOOR position, use active test to make sure interior room lamp operates.

**Room lamps should turn on.**

#### OK or NG

- OK >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).  
 NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
	OFF

LKIA0092E


### 3. CHECK INTERIOR ROOM LAMP INPUT

- Turn ignition switch OFF.
- Check voltage between front room/map lamp assembly harness connector R9 terminal 1 and ground.

**1 - Ground : Battery voltage should exist.**

#### OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 5.



# INTERIOR ROOM LAMP


## 4. CHECK INTERIOR ROOM LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M20 terminal 63 and front room/map lamp assembly harness connector R9 terminal 2.

**63 - 2** : Continuity should exist.

OK or NG

- OK >> Replace BCM if interior lamp does not work after setting the connector again. Refer to [BCS-25, "Removal and Installation"](#).
- NG >> Repair harness or connector.




## 5. CHECK INTERIOR ROOM LAMP CIRCUIT

1. Disconnect BCM connector and front room/map lamp assembly connector.
2. Check continuity between BCM harness connector M20 terminal 56 and front room/map lamp assembly harness connector R9 terminal 1.

**56 - 1** : Continuity should exist.

OK or NG

- OK >> Replace BCM if interior lamp does not work after setting the connector again. Refer to [BCS-25, "Removal and Installation"](#).
- NG >> Repair harness or connector between BCM and room/map lamp.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

## Personal Lamp Control Does Not Operate (Room/Map Lamps Operate)

EKS00FXH

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-110, "SWITCH OPERATION"](#) for switches and their function.

#### OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning door switch.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E


### 2. CHECK PERSONAL LAMP OUTPUT

1. Turn ignition switch OFF.
2. Confirm lamp switch is in the DOOR position.
3. Disconnect personal lamp 2nd row connector.
4. Open any door.
5. Check voltage between personal lamp 2nd row harness connector R10 terminal 1 and ground.

**1 - Ground : Battery voltage should exist.**

#### OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.




### 3. CHECK PERSONAL LAMP CONTROL CIRCUIT

1. Disconnect front room/map lamp assembly connector.
2. Check continuity between front room/map lamp assembly harness connector R9 terminal 3 and personal lamp 2nd row harness connector R10 terminal 3.

**3 - 3 : Continuity should exist.**

#### OK or NG

- OK >> Replace personal lamp 2nd row.
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## All Interior Room Lamps Do Not Operate

EKS00FXI

### 1. CHECK POWER SUPPLY CIRCUIT


1. All interior room lamp switches are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M20 terminal 56 and ground.

**56 - Ground** : **Battery voltage should exist.**

#### OK or NG

OK >> Repair harness or connector. To prevent making a short circuit, be sure to disconnect battery negative cable after repairing harness, and then reconnect.

NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).



## Ignition Keyhole Illumination Control Does Not Operate

EKS00FXJ

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-119, "Display Item List"](#) for switches and their functions.

#### OK or NG

OK >> GO TO 2.

NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E

### 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP".
2. Select "IGN ILLUM" active test to make sure lamp operates.

#### OK or NG

OK >> Replace BCM. Refer to [BCS-25, "Removal and Installation"](#).

NG >> GO TO 3.

ACTIVE TEST	
IGN ILLUM	ON
	OFF

SKIA3992E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP


## 3. CHECK IGNITION KEYHOLE ILLUMINATION POWER SUPPLY INPUT

1. Check voltage between ignition keyhole illumination harness connector M150 terminal 1 and ground.

Terminals		(-)	Voltage (Approx.)
(+)			
Ignition keyhole illumination connector	Terminal		
M150	1	Ground	Battery voltage

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 6.



WKIA5801E


## 4. CHECK IGNITION KEYHOLE ILLUMINATION BULB

1. Turn ignition switch OFF.
2. Disconnect ignition keyhole illumination connector.
3. Check continuity between ignition keyhole illumination terminals 1 and 2.

Terminals		Continuity
Ignition keyhole illumination terminal		
1	2	Yes

OK or NG

- OK >> GO TO 5.  
 NG >> Replace ignition keyhole illumination bulb.



WKIA5802E


## 5. CHECK IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M18 (A) terminal 1 and ignition keyhole illumination harness connector M150 (B) terminal 2.

A		B		Continuity
BCM connector	Terminal	Ignition keyhole illumination connector	Terminal	
M18	1	M150	2	Yes

OK or NG

- OK >> Replace BCM if ignition keyhole illumination does not work after setting the connector again. Refer to [BCS-25, "Removal and Installation"](#) .  
 NG >> Repair harness or connector.




WKIA5803E

# INTERIOR ROOM LAMP

## 6. CHECK IGNITION KEYHOLE ILLUMINATION POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and ignition keyhole illumination connector.
3. Check continuity between BCM harness connector M20 (A) terminal 56 and ignition keyhole illumination harness connector M150 (B) terminal 1.

A		B		Continuity
BCM connector	Terminal	Ignition keyhole illumination connector	Terminal	
M20	56	M150	1	Yes



### OK or NG

- OK >> Replace BCM if ignition keyhole illumination does not work after setting the connector again.  
Refer to [BCS-25, "Removal and Installation"](#).
- NG >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# ILLUMINATION

## ILLUMINATION

PF2:27545

### Component Parts and Harness Connector Location

EKS00FXK



WKIA4973E

- |  |  |                             |
|--|--|-----------------------------|
| 1. IPDM E/R<br>E118, E119, E120, E121, E122,<br>E123, E124       | 2. Combination switch (lighting switch)<br>M28                           | 3. Combination meter<br>M24 |
| 4. Illumination control switch<br>(built into combination meter) | 5. BCM<br>M18, M19, M20<br>(view with instrument lower panel LH removed) |                             |

## System Description

EKS00FXL

Control of the illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the illumination lamps, which then illuminate. Power is supplied at all times

- to ignition relay, located in the IPDM E/R,
- to tail lamp relay, located in the IPDM E/R,
- through 50A fusible link (letter **g** , located in the fuse and fusible link box)
- to BCM terminal 70,
- through 20A fuse (No. 53, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- through 10A fuse [No.19, located in fuse block (J/B)]
- to combination meter terminal 3.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 1, located in the fuse block (J/B)]

# ILLUMINATION

- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67 and
- to combination meter terminals 13 and 23
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59
- through grounds E9, E15 and E24.

## ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the tail lamp relay coil, which, when energized, directs power

- through 10A fuse (No. 37, located in the IPDM E/R)
- through IPDM E/R terminal 57
- to AV switch terminal 3 (with NAVI)
- to hazard switch terminal 3
- to audio unit terminal 8
- to main power window and door lock/unlock switch terminal 16 (early production)
- to power window and door lock/unlock switch RH terminal 5 (early production)
- to glove box lamp terminal 1
- to display control unit terminal 14 (with NAVI)
- to 4WD shift switch terminal 7 (with 4-wheel drive)
- to front air control terminal 8
- to DVD player terminal 12 (with DVD entertainment system)
- to NAVI control unit terminal 61 (with NAVI)
- to rear air control terminal 1 (with auto A/C)
- to pedal adjusting switch terminal 5 (with adjustable pedals)
- to door mirror remote control switch terminal 16
- to electric brake (pre-wiring) terminal 4 (with trailer tow 7 pin)
- to A/T device terminal 3
- to front heated seat switch LH and RH terminal 5 (with heated seats)
- to VDC OFF switch terminal 3 and
- to HDC switch terminal 5 (with hill descent control and hill start assist).

Illumination ground is controlled

- through combination meter terminal 22
- to AV switch terminal 4 (with NAVI)
- to hazard switch terminal 4
- to audio unit terminal 7
- to main power window and door lock/unlock switch terminal 12 (early production)
- to power window and door lock/unlock switch RH terminal 1 (early production)
- to 4WD switch terminal 8 (with 4-wheel drive)
- to front air control terminal 9
- to DVD player terminal 10 (with DVD entertainment system)
- to pedal adjusting switch terminal 6 (with adjustable pedals)
- to door mirror remote control switch terminal 15
- to A/T device terminal 5
- to front heated seat switch LH and RH terminal 6 (with heated seats)
- to VDC OFF switch terminal 4 and
- to HDC switch terminal 6 (with hill descent control and hill start assist).

# ILLUMINATION

---

Ground is supplied

- to glove box lamp terminal 2
- to display control unit terminal 3 (with NAVI)
- to electric brake (pre-wiring) terminal 1 (with trailer tow 7 pin) and
- to rear air control terminal 3 (with auto A/C)
- through grounds M57, M61 and M79, and
- to NAVI control unit terminal 1 (with NAVI)
- through grounds B117 and B132.

With power and ground supplied, illumination lamps illuminate.

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST or 2ND position (or if auto light system is activated), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated. Under this condition, the illumination lamps remain illuminated for 5 minutes, then the illumination lamps are turned off.

When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps are turned off by the battery saver control, the illumination lamps illuminate again.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description


EKS00FXM

Refer to [LAN-4, "CAN Communication System"](#) .

# ILLUMINATION

## Schematic

EKS00FXN




\* : THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM).


▶▶ NEXT PAGE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# ILLUMINATION



# ILLUMINATION



- (AP) : WITH ADJUSTABLE PEDALS WITHOUT MEMORY
- (HS) : WITH HEATED SEATS
- (DC) : WITH HILL DESCENT CONTROL AND HILL START ASSIST
- (TT) : TRAILER TOW 7 PIN
- (EP) : EARLY PRODUCTION

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

WKWA5352E




# ILLUMINATION

## Wiring Diagram — ILL —

EKS00FX0

LT-ILL-01



▬ : DATA LINE



WKWA5447E

# ILLUMINATION

LT-ILL-02





WKWA2077E

# ILLUMINATION

LT-ILL-03

 : WITH NAVI  
 : DATA LINE




REFER TO THE FOLLOWING.  
 - SUPER MULTIPLE JUNCTION (SMJ)

WKWA4243E


# ILLUMINATION

LT-ILL-04

EP : EARLY PRODUCTION



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





WKWA5353E

# ILLUMINATION

LT-ILL-05

 : WITH 4-WHEEL DRIVE  
 : WITH NAVI





WKWA2080E

# ILLUMINATION


LT-ILL-06

-  : WITH NAVI
-  : WITH DVD ENTERTAINMENT SYSTEM
-  : WITH AUTO A/C



REFER TO THE FOLLOWING.

 - SUPER MULTIPLE JUNCTION (SMJ)




WKWA4244E

# ILLUMINATION

## LT-ILL-07

⬡AP⬡ : WITH ADJUSTABLE PEDALS WITHOUT MEMORY

⬡TT⬡ : TRAILER TOW 7 PIN





WKWA5354E

# ILLUMINATION

## LT-ILL-08





HS : WITH HEATED SEATS  
DC : WITH HILL DESCENT CONTROL AND HILL START ASSIST



A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
**LT**  
 L  
 M

# ILLUMINATION

LT-ILL-09



REFER TO THE FOLLOWING.  
(M36), (M40) - SUPER  
MULTIPLE JUNCTION (SMJ)

WKWA5355E


# ILLUMINATION

## Removal and Installation

### ILLUMINATION CONTROL SWITCH

The illumination control switch is a function of the combination meter, and not serviced separately. For replacement, refer to [IP-14, "COMBINATION METER"](#)

EKS00FXP



A

B

C

D

E

F

G

H

I

J

LT

L

M

# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PFP:26297

### Headlamp

EKS00FXQ

Item	Wattage (W)*
Low/High	65/55 (HB5)

\*: Always check with the Parts Department for the latest parts information.

### Exterior Lamp

EKS00FXR

Item	Wattage (W)*	
Front combination lamp	Turn signal lamp/parking lamp	28/8
	Side marker	3.8
Rear combination lamp	Stop/Tail lamp	27/8
	Turn signal lamp	27
	Back-up lamp	18
Front fog lamp	55	
License plate lamp	5	
High-mounted stop lamp	*	

\*: Always check with the Parts Department for the latest parts information.

### Interior Lamp/Illumination

EKS00FXS

Item	Wattage (W)*
Glove box lamp	3.4
Room/Map lamp	8
A/T device lamp	3
Cargo lamp	8
Vanity lamp	*
Personal lamp	8

\*: Always check with the Parts Department for the latest parts information.