

ENGINE FUEL AND EMISSION CONTROL SYSTEM

SECTION EF & EC

CONTENTS

PRECAUTIONS	2	Carbon Canister.....	16
PREPARATION	4	Fuel Filter.....	16
Special Service Tool	4	ENGINE AND EMISSION CONTROL SYSTEM	
ENGINE AND EMISSION CONTROL OVERALL		DESCRIPTION	17
SYSTEM	5	Multiport Fuel Injection (MFI) System.....	17
ECM (ECCS) Component Parts Location	5	Distributor Ignition (DI) System.....	20
System Diagram	6	Idle Speed Control.....	22
System Chart	7	Fuel Pump Control.....	23
Vacuum Hose Drawing	8	Idle Air Control (IAC) Valve-Air Regulator	
Circuit Diagram	9	Control.....	23
ENGINE AND EMISSION CONTROL PARTS		Exhaust Gas Recirculation (EGR) System.....	24
DESCRIPTION	10	Acceleration Cut Control.....	24
Engine Control Module (ECM)-ECCS Control		Cooling Fan Control.....	25
Module	10	Fail-safe System	26
Camshaft Position (CMP) Sensor.....	10	IDLE SPEED/IGNITION TIMING/IDLE MIXTURE	
Mass Air Flow (MAF) Sensor.....	10	RATIO INSPECTION	28
Engine Coolant Temperature (ECT) Sensor.....	11	TROUBLE DIAGNOSES	33
Throttle Position (TP) Sensor & Soft/Hard		How to Perform Trouble Diagnoses for Quick	
Closed Throttle Position Switch.....	11	and Accurate Repair	33
Fuel Injector	12	Introduction	33
Fuel Pressure Regulator.....	12	Work Flow.....	34
Power Steering Pressure (PSP) Switch	12	Diagnostic Worksheet.....	35
Heated Oxygen Sensor (HO2S).....	12	Worksheet sample.....	35
Fuel Pump.....	13	Intermittent Problem Simulation	36
Inertia Fuel Shutoff Switch.....	13	On-board Diagnostic System.....	37
Power Transistor & Ignition Coil	13	On-board Diagnostic System — On-board	
Idle Air Control (IAC) Valve-Air Regulator	14	Diagnostic Test Mode I	40
Idle Air Adjusting (IAA) Unit	14	On-board Diagnostic System — On-board	
Idle Air Control (IAC) Valve-Auxiliary Air		Diagnostic Test Mode II (Self-diagnostic	
Control (AAC) Valve.....	14	results)	41
Vehicle Speed Sensor (VSS).....	14	How To Erase On-Board Diagnostic Test	
Knock Sensor (KS)	14	Mode II (Self-diagnostic results).....	43
Exhaust Gas Recirculation (EGR) Valve	15	On-board Diagnostic System — On-board	
EGR Control-BPT Valve.....	15	Diagnostic Test Mode II (Heated oxygen	
EGR Control-Solenoid Valve	15	sensor monitor)	43
EGR Temperature Sensor	15	How To Check Heated Oxygen Sensor	43
Data Link Connector (DLC) for CONSULT.....	15	CONSULT	44
ECM On-Board Diagnostic System Connector	16	CONSULT Inspection Procedure.....	44

GI

MA

EM

LG

EF & EC

FE

AT

FA

RA

BR

ST










BF

HA

EL

IDX

CONTENTS (Cont'd.)

Definition Of CONSULT Functions	45	Diagnostic Procedure 22	92
ECCS Component Parts Application	45	Main Power Supply And Ground Circuit	
Work Support Diagnostic Test Mode	46	(Not self-diagnostic item).....	92
Self-Diagnostic Results Diagnostic Test		Camshaft Position Sensor (Diagnostic	
Mode	47	trouble code No. 11).....	95
Data Monitor Diagnostic Test Mode	48	Mass Air Flow Sensor (Diagnostic trouble	
Active Test Diagnostic Test Mode	50	code No. 12)  (Malfunction Indicator	
Function Test Diagnostic Test Mode	51	Lamp Item)	98
Diagnostic Precautions	53	Engine Coolant Temperature Sensor	
Basic Inspection.....	55	(Diagnostic trouble code No. 13)	
Diagnostic Procedure 1 — High Idling after		 (Malfunction Indicator Lamp Item).....	101
Warm-up.....	58	Vehicle Speed Sensor (Diagnostic trouble	
Diagnostic Procedure 2 — Hunting	59	code No. 14)  (Malfunction Indicator	
Diagnostic Procedure 3 — Unstable Idle	61	Lamp Item)	103
Diagnostic Procedure 4 — Hard to Start or		Ignition Signal (Diagnostic trouble code No.	
Impossible to Start when the Engine is Cold	64	21).....	106
Diagnostic Procedure 5 — Hard to Start or		ECM (ECCS Control Module) (Diagnostic	
Impossible to Start when the Engine is Hot.....	66	trouble code No. 31)  (Malfunction	
Diagnostic Procedure 6 — Hard to Start or		Indicator Lamp Item)	109
Impossible to Start under Normal Conditions.....	68	EGR Function (Diagnostic trouble code No.	
Diagnostic Procedure 7 — Hesitation when		32)  (Malfunction Indicator Lamp	
the Engine is Hot	70	Item).....	110
Diagnostic Procedure 8 — Hesitation when		Heated Oxygen Sensor (Diagnostic trouble	
the Engine is Cold	71	code No. 33).....	114
Diagnostic Procedure 9 — Hesitation under		Knock Sensor (Diagnostic trouble code No.	
Normal Conditions	72	34).....	117
Diagnostic Procedure 10 — Engine Stalls		EGR Temperature Sensor (Diagnostic	
when Turning	73	trouble code No. 35)  (Malfunction	
Diagnostic Procedure 11 — Engine Stalls		Indicator Lamp Item)	119
when the Engine is Hot	75	Throttle Position Sensor (Diagnostic trouble	
Diagnostic Procedure 12 — Engine Stalls		code No. 43)  (Malfunction Indicator	
when the Engine is Cold.....	77	Lamp Item)	122
Diagnostic Procedure 13 — Engine Stalls		Injector Leak (Code No. 45)	
when Accelerator is Momentarily Pressed and		 (Malfunction Indicator Lamp Item).....	125
Released	79	Injector Circuit (Diagnostic trouble code No.	
Diagnostic Procedure 14 — Engine Stalls after		51)  (Malfunction Indicator Lamp	
Decelerating.....	81	Item).....	127
Diagnostic Procedure 15 — Engine Stalls		Non-Self-Diagnosis Items	
when Accelerating or when Driving at		Fuel Pump Control	130
Constant Speed	84	Closed Throttle Position Switch.....	133
Diagnostic Procedure 16 — Engine Stalls		Start Signal	136
when the Electrical Load is Heavy	86	IAC Valve-Air Regulator.....	138
Diagnostic Procedure 17 — Lack of Power		IAC Valve-AAC Valve	140
and Stumble.....	88	IAC Valve-FICD Solenoid Valve And Air	
Diagnostic Procedure 18 — Knock	89	Conditioning System Input	142
Diagnostic Procedure 19 — Surge.....	90	Cooling Fan Control	146
Diagnostic Procedure 20 — Backfire through		Power Steering Pressure Switch.....	154
the Intake	91	A/T Control Unit (Neutral Signal) Circuit	156
Diagnostic Procedure 21 — Backfire through		Electrical Components Inspection	158
the Exhaust on Deceleration	91	ECM Input/Output Signal Inspection	158

CONTENTS (Cont'd.)

ECM Harness Connector Terminal Layout.....	158	Fuel Injector.....	169	GI
ECM Inspection table.....	159	Heated Oxygen Sensor (HO2S).....	169	
Camshaft Position Sensor.....	163	ECM Relay, Fuel Pump Relay, Air		
Mass Air Flow Sensor.....	163	Conditioning Relay, IAC Relay-FICD Relay		MA
Engine Coolant Temperature (ECT) Sensor..	164	And Cooling Fan Relays.....	169	
Ignition Coil.....	164	Resistor.....	170	EM
Power Transistor.....	164	Power Steering Pressure (PSP) Switch.....	170	
Fuel Pump.....	165	High Pressure Switch-2.....	170	
EGR Control-Solenoid Valve And Pressure		Cooling Fan Motor.....	170	LC
Regulator Control Solenoid Valve.....	165	MULTIPOINT FUEL INJECTION (MFI) SYSTEM		
Inertia Fuel Shutoff Switch.....	165	INSPECTION.....	171	
EGR Valve.....	165	Releasing Fuel Pressure.....	171	EF & EC
EGRC-Bpt Valve.....	166	Fuel Pressure Check.....	171	
EGR Temperature Sensor.....	166	Fuel Pressure Regulator Check.....	172	FE
Throttle Position (TP) Sensor.....	166	Injector Removal.....	173	
Closed Throttle Position Switch.....	166	EVAPORATIVE EMISSION (EVAP) SYSTEM.....	174	
Adjustment For Throttle Position (TP)		Description.....	174	AT
Sensor And Closed Throttle Position Switch..	167	Inspection.....	174	
IAC Valve-AAC Valve.....	167	CRANKCASE EMISSION CONTROL SYSTEM....	176	
IAC Valve-FICD Solenoid Valve.....	168	Description.....	176	FA
IAC Valve-Air Regulator.....	168	Inspection.....	176	
Knock Sensor.....	168	SERVICE DATA AND SPECIFICATIONS (SDS) ...	177	RA

Note: Refer to Foldout page for "ECCS WIRING DIAGRAM".

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX

PRECAUTIONS



Precautions for Supplemental Restraint System Supplemental "AIR BAG"

The Supplemental Restraint System Supplemental "Air Bag", used along with seat belts, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of a supplemental air bag module (located in the center of the steering wheel), sensors, a diagnosis (control) unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS Supplemental "Air Bag".

PRECAUTIONS

Engine Fuel & Emission Control System

ECM (ECCS Control Module)

- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

INJECTOR

- Do not disconnect injector harness connectors with engine running.
- Do not apply battery power directly to injectors.

ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IAC valve-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.



BATTERY


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far as possible away from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

ECM HARNESS HANDLING

- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

AEC370



PREPARATION

Special Service Tool

Tool number (Kent-Moore No.) Tool name	Description
(J34267)	2.5 k Ω resistor CO checking procedure

ENGINE AND EMISSION CONTROL OVERALL SYSTEM


ECM (ECCS) Component Parts Location



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM


System Diagram




AEC366

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart



Vacuum Hose Drawing



AEC367


- ① Fuel pressure regulator to intake manifold collector
- ② EGR valve to EGR control-solenoid valve

- ③ EGR control-solenoid valve to throttle body
- ④ Carbon canister (purge port) to intake manifold collector

- ⑤ Carbon canister (vacuum port) to throttle body
- ⑥ EGR control-solenoid valve to air duct


ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram




G
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 PA
 BR
 ST
 BF
 HA
 FL
 IDX

ENGINE AND EMISSION CONTROL PARTS DESCRIPTION



Engine Control Module (ECM)-ECCS Control Module


The ECM controls the engine using a microcomputer. It uses input signals from various sensors and components to control output devices. The ECM also has an on-board diagnostic test mode selector, an inspection lamp, and connectors for signal input and output, and for power supply. For diagnosis, refer to EF & EC-158.




Camshaft Position (CMP) Sensor

The Camshaft Position (CMP) sensor is a basic component of the entire ECCS. It monitors engine speed and piston position, and sends signals to the ECM to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for 1° signal and 6 slits for 120° signal. Light Emitting Diodes (LED) and photo diodes are built in the wave-forming circuit.





When the rotor plate passes between the LED and the photo diode, the slits in the rotor plate continually cut the light being transmitted to the photo diode from the LED. This generates rough-shaped pulses which are converted into on-off pulses by the wave-forming circuit, which are sent to the ECM. For diagnosis, refer to EF & EC-163.



Mass Air Flow (MAF) Sensor


The Mass Air Flow (MAF) sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film resistor that is supplied with electric current from the ECM. The temperature of the hot film resistor is controlled by the ECM a certain amount. The heat generated by the hot film resistor is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film resistor as air flow increases. The ECM detects the air flow by means of this current change. For diagnosis, refer to EF & EC-163.





Engine Coolant Temperature (ECT) Sensor


The Engine Coolant Temperature (ECT) sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the ECT input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases. For diagnosis, refer to EF & EC-164.




Throttle Position (TP) Sensor & Soft/Hard Closed Throttle Position Switch

The Throttle Position (TP) sensor is located on the throttle body. It monitors accelerator pedal movement using a potentiometer. The potentiometer changes the throttle valve position into an output voltage. The throttle position sensor also detects the opening and closing speed of the throttle valve. These signals are sent to the ECM.


The ECM detects closed throttle valve position using the voltage from the throttle position sensor. This system is called "soft closed throttle position". This signal is used to control engine operations such as fuel cut. Also built into the throttle position sensor is "hard closed throttle position switch". This signal is used for engine control only when the soft closed throttle position switch is malfunctioning. For diagnosis, refer to EF & EC-166.






Fuel Injector

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs. For diagnosis, refer to EF & EC-169.




Fuel Pressure Regulator

The fuel pressure regulator adjusts the fuel pressure to the fuel injector depending upon engine load. When intake manifold vacuum is high, fuel pressure to the injector will be lowered. When intake manifold vacuum is low, fuel pressure to the injector will be raised. For diagnosis, refer to EF & EC-171.




Power Steering Pressure (PSP) Switch


The Power Steering Pressure (PSP) switch is attached to the power steering high-pressure tube and detects the power steering load, sending the load signal to the ECM. The ECM then sends the idle-up signal to the IAC valve-AAC valve to increase the idle speed and adjust for the increased load. For diagnosis, refer to EF & EC-170.



Heated Oxygen Sensor (HO2S)


The Heated Oxygen Sensor (HO2S) is located in the exhaust tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V. A heater is used to activate the sensor. For diagnosis, refer to EF & EC-114.





Fuel Pump

The fuel pump is located in the fuel tank. It consists of a motor, pump, fuel damper and a relief valve. For diagnosis, refer to EF & EC-165.




Inertia Fuel Shutoff Switch

The inertia fuel shutoff switch automatically stops the flow of fuel to the engine when the vehicle is involved in a collision. The impact does not have to be great to trigger the switch. Minor parking lot bumping and severe road impacts (such as potholes) may trigger the switch.

Once the switch is triggered, it must be reset manually before starting the vehicle. Reset the switch by pressing the red button located on the top of the switch.


The inertia fuel shutoff switch is located near the driver's door frame below the hood release handle. For diagnosis, refer to EF & EC-165.



Power Transistor & Ignition Coil

The ignition signal from the ECM is amplified by the power transistor, which turns the ignition coil primary circuit on and off, inducing the proper high voltage in the secondary circuit. The ignition coil is a small, molded type. For diagnosis, refer to EF & EC-164.


GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX



Idle Air Control (IAC) Valve-Air Regulator


The IAC valve-air regulator provides an air by-pass when the engine is cold for a fast idle during warm-up.

A bimetal, heater and rotary shutter are built into the IAC valve-air regulator. When the bimetal temperature is low, the air by-pass port opens. As the engine starts and electric current flows through a heater, the bimetal begins to turn the shutter to close the by-pass port. The air passage remains closed until the engine stops and the bimetal temperature drops. For diagnosis, refer to EF & EC-168.




Idle Air Adjusting (IAA) Unit

The IAA unit is made up of the IAC valve-AAC valve, IAC valve-FICD solenoid valve and idle adjusting screw. It receives the signal from the ECM and controls the idle speed at the preset value. The IAC valve-FICD solenoid valve compensates for changes in idle speed caused by the operation of the air conditioning compressor. For diagnosis, refer to EF & EC-168.



Idle Air Control (IAC) Valve-Auxiliary Air Control (AAC) Valve


The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed. For diagnosis, refer to EF & EC-167.



Vehicle Speed Sensor (VSS)

The Vehicle Speed Sensor (VSS) provides a vehicle speed signal to the speedometer and the speedometer sends a signal to the ECM.


The speed sensor consists of a pulse generator, which is installed in the speedometer unit in the transaxle. For diagnosis, refer to EF & EC-103.



Knock Sensor (KS)


The Knock Sensor (KS) is attached to the cylinder block and senses engine knocking conditions.

A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. This vibrational pressure is then converted into a voltage signal which is delivered as output. For diagnosis, refer to EF & EC-168.




Exhaust Gas Recirculation (EGR) Valve

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve. For diagnosis, refer to EF & EC-165.




EGR Control-BPT Valve

The EGR control-BPT valve controls the amount of vacuum applied to the EGR valve. A diaphragm adjusts the vacuum in response to exhaust system pressure. This helps control the amount of recirculated exhaust gas based on EGR valve position. For diagnosis, refer to EF & EC-166.




EGR Control-Solenoid Valve

The EGR system is controlled only by the ECM. At both low- and high-speed revolutions of engine, the solenoid valve turns on and the EGR valve cuts the exhaust gas leading to the intake manifold accordingly. For diagnosis, refer to EF & EC-165.



EGR Temperature Sensor


The EGR temperature sensor detects temperature changes in the EGR passage way. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passage way changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. For diagnosis, refer to EF & EC-166.



Data Link Connector (DLC) for CONSULT


The data link connector for CONSULT is located in the instrument lower panel, at the bottom of the fuse panel.

GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX



ECM On-Board Diagnostic System Connector


This connector is used to retrieve self-diagnosis codes and monitor Heated Oxygen Sensor (HO2S) operation. For diagnosis, refer to EF & EC-37.



Carbon Canister

The carbon canister is filled with activated charcoal to absorb evaporative gases that are produced in the fuel tank. The gases are delivered to the intake manifold by manifold vacuum for combustion.

The vacuum in the air duct upstream from the throttle body increases with the amount of intake air flow. When this vacuum is greater than a preset value, a second purge control valve on the carbon canister opens. The absorbed gases are delivered to the intake air flow by the vacuum. For diagnosis, refer to EF & EC-174.




Fuel Filter

The specially designed fuel filter has a metal case in order to withstand high fuel pressure.

Multipoint Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL LINE



BASIC MULTIPOINT FUEL INJECTION (MFI) SYSTEM

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.

⟨Fuel increase⟩


- 1) During warm-up
- 2) When starting the engine
- 3) During acceleration
- 4) Hot-engine operation
- 5) When selector lever is moved from "N" to "D"

⟨Fuel decrease⟩

- 1) During deceleration
- 2) During high engine speed operation

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd) MIXTURE RATIO FEEDBACK CONTROL



Mixture ratio feedback system is used for precise control of the air-fuel ratio to the stoichiometric point. The three-way catalyst can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor in the exhaust tube to monitor the air-fuel ratio. The ECM adjusts the injection pulse width according to the sensor voltage signal. This maintains the mixture ratio within the range of the stoichiometric (ideal air-fuel mixture). This stage is referred to as the closed loop control condition.

OPEN LOOP CONTROL

The open loop control condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- 1) Deceleration
- 2) High-load, high-speed operation
- 3) Engine idling
- 4) Malfunction of heated oxygen sensor or its circuit
- 5) Insufficient activation of heated oxygen sensor at low engine coolant temperature
- 6) Engine starting


MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. This is due to manufacturing differences (e.g., mass air flow sensor hot film) and changes during operation (injector clogging, etc.) of ECCS parts which directly affect the mixture ratio.

Accordingly, a difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "fuel injection duration" to automatically compensate for the difference between the two ratios.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd) FUEL INJECTION TIMING



Two types of fuel injection are used — simultaneous multiport fuel injection and sequential multiport fuel injection.

In the simultaneous multiport fuel injection system, fuel is injected into all six cylinders simultaneously twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM to the six injectors two times for each engine cycle.

In the sequential multiport fuel injection system, fuel is injected into each cylinder during each engine cycle according to the firing order.

When the engine is being started and/or if the fail-safe system (CPU) is operating, simultaneous multiport fuel injection system is used. When the engine is running, sequential multiport fuel injection system is used.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high engine speed.

GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

Distributor Ignition (DI) System

INPUT/OUTPUT SIGNAL LINE



ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Distributor Ignition (DI) System (Cont'd)

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine.

The ignition timing data is stored in the ECM. This data forms the map shown below.


The ECM detects information such as the injection pulse width and camshaft position sensor signal. Responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions the ignition timing is revised by the ECM according to the other data stored in the ECM.

- 1) At starting
- 2) During warm-up
- 3) At idle
- 4) At low battery positive voltage




The knock sensor retard system is designed only for emergencies. The basic ignition timing is pre-programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.

If engine knocking occurs, the knock sensor monitors the condition and the signal is transmitted to the ECM (ECCS control module). The ECM retards the ignition timing to eliminate the knocking condition.

Idle Speed Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IAC valve-AAC valve. The IAC valve-AAC valve repeats ON/OFF operation according to the signal sent by the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IAC valve-AAC valve so that engine speed matches the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking various engine conditions into consideration such as warming up and during deceleration, fuel consumption, and engine load (air conditioning, electrical load).

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fuel Pump Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

The ECM activates the fuel pump for several seconds after the ignition switch is turned on. This occurs to improve engine start-up. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and activates the pump. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents the battery from discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1.5 seconds
Except as shown above	Stops

Idle Air Control (IAC) Valve-Air Regulator Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

The IAC valve-air regulator is controlled by the ECM at the same time as fuel pump ON-OFF control.

Condition	IAC valve-air regulator operation
Ignition switch is turned to ON	Operates for 5 seconds
While engine is running and cranking	Operates
When engine is stopped	OFF in 1.5 seconds
Except as shown above	OFF

Exhaust Gas Recirculation (EGR) System

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

A system is provided which precisely cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGR control-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve causing the port vacuum to be discharged into the atmosphere. The EGR valve remains closed.

- 1) Low engine coolant temperature
- 2) Engine starting
- 3) High-speed engine operation
- 4) Engine idling
- 5) Camshaft position sensor malfunction
- 6) ECM (ECCS control module) malfunction

Acceleration Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

When the accelerator pedal is fully depressed or the engine is running at high speed, the air conditioning is turned off for a few seconds. This system improves acceleration when the air conditioning is used.

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Cooling Fan Control

INPUT/OUTPUT SIGNAL LINE



The ECM performs ON/OFF control and LOW/HIGH speed control of the cooling fan corresponding to the vehicle speed, engine coolant temperature, air conditioning ON signal, and air conditioning pressure.

Operation

Air conditioning switch is "OFF"

Engine coolant temperature °C (°F)	Cooling fans	Remarks
94 (201) or less	OFF	
Between 95 (203) and 99 (210)	LOW	
Between 100 (212) and 104 (219)	LOW	Vehicle speed is 19 km/h (12 MPH) or less
	HIGH	Vehicle speed is 20 km/h (12 MPH) or more
105 (221) or more	HIGH	

Air conditioning switch is "ON" (Any mode except "OFF"), high pressure switch is "OFF".

Engine coolant temperature °C (°F)	Cooling fans	Remarks
94 (201) or less	OFF	Vehicle speed is 110 km/h (68 MPH) or more
	LOW	Vehicle speed is 109 km/h (68 MPH) or less
Between 95 (203) and 104 (219)	LOW	Vehicle speed is 19 km/h (12 MPH) or less
	HIGH	Vehicle speed is 20 km/h (12 MPH) or more
105 (221) or more	HIGH	

Air conditioning switch is "ON" (Any mode except "OFF"), high pressure switch is "ON".


Engine coolant temperature °C (°F)	Cooling fans	Remarks
All	HIGH	

- The cooling fan operates at HIGH if the self-diagnosing engine coolant temperature sensor system or ECM results in "NG".
- A/C compressor clutch will not engage if A/C system low side pressure is below 331 kPa (3.38 kg/cm², 48 psi). Therefore, the A/C compressor clutch will not engage in cold temperatures [below 10°C (50°F)].

Fail-safe System

CPU MALFUNCTION OF ECM

Powertrain input/control signal line



Outline

The fail-safe system makes engine starting possible if there is something malfunctioning in the ECM's CPU circuit. In former models, engine starting was difficult under the conditions mentioned above. But with the provisions provided in this fail-safe system, it is possible to start the engine.

Fail-safe system activating condition when ECM is malfunctioning

The fail-safe mode operates when the ECM is judged to be malfunctioning. When a malfunction is detected in the CPU of the ECM, the fail-safe system activates. The MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.

Engine control with fail-safe system operating

When the fail-safe system is operating, fuel injection, ignition timing, engine idle speed, and EGR operation are controlled under certain limitations

Cancellation of fail-safe system when ECM is malfunctioning

Activation of the fail-safe system is canceled each time the ignition switch is turned "OFF". The system is reactivated if all of the activating conditions are satisfied after turning the ignition switch from "OFF" to "ON".

Operation

	Operation
Fuel injection	Simultaneous multiport fuel injection
Ignition timing	Ignition timing is fixed at the preset value.
Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.
EGR control-solenoid valve	ON (EGR cut)
Cooling fan	Cooling fan operates at high speed

CAMSHAFT POSITION SENSOR MALFUNCTION

The fail-safe mode operation starts immediately after all of the following conditions have been satisfied for several seconds.

- (1) No pulse of 120° signal (reference signal) detected for several seconds, or 1° signal (position signal) is equivalent to 0 rpm.
- (2) Ignition switch in "START".
- (3) Battery positive voltage is greater than 10 volts with ignition switch "ON".
- (4) The park/neutral position switch is "ON", or the inhibitor switch is in the "P" or "N" position.
- (5) When ignition switch is in "START", battery positive voltage is at least 1 volt lower than when ignition switch is "ON".

ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION

Fail-safe System (Cont'd)

MASS AIR FLOW (MAF) SENSOR MALFUNCTION

If the mass air flow sensor output voltage is below the specified value, the ECM senses an mass air flow sensor malfunction. In case of a malfunction, the throttle position sensor substitutes for the mass air flow sensor.

Though the mass air flow sensor is malfunctioning, it is possible to start the engine and drive the vehicle. However, engine speed will not rise more than 2,000 rpm in order to inform the driver of fail-safe system operation while driving.

GI

KA

EM

Operation

Engine condition	Starter switch	Fail-safe system	Fail-safe functioning
Stopped	ANY	Does not operate	—
Cranking	ON	Operates	Engine will be started by a pre-determined injection pulse on ECM
Running	OFF		Engine speed will not rise above 2,000 rpm

LC

EF & EC

FE

ENGINE COOLANT TEMPERATURE (ECT) SENSOR MALFUNCTION

When engine coolant temperature sensor output voltage is below or above the specified value, water temperature is fixed at the preset value as follows:

KNOCK SENSOR MALFUNCTION

When the output signal of the knock sensor is abnormal, the ECM judges it to be malfunctioning. When knock sensor is malfunctioning, ignition timing will retard according to operating conditions.

AT

FA

Operation

Condition	Engine coolant temperature decided
Just as ignition switch is turned ON or Start	20°C (68°F)
More than 6 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)

THROTTLE POSITION (TP) SENSOR MALFUNCTION

When the output signal of the throttle position sensor is abnormal, the ECM judges it as a malfunctioning of the throttle position sensor. The ECM does not use the throttle position sensor signal but uses a closed throttle position switch signal.

RA

BR

ST

BF

HA

EL

IDX

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION

PREPARATION


1. Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system (Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - EGR valve operation
 - Throttle valve
2. On air conditioning equipped models, checks should be carried out while the air conditioning is "OFF".
3. When checking idle rpm, ignition timing

- and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.


WARNING:

- a. Before selector lever is shifted to "D" position, apply parking brake and block both front and rear wheels with chocks.
- b. Depress brake pedal while racing the engine to prevent forward surge of vehicle.
- c. After the adjustment has been made, shift the lever to the "N" or "P" position and remove wheel chocks.

Overall inspection sequence




IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION




IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION

GI
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX



IDLE SPEED/IGNITION TIMING/IDLE MIXTURE RATIO INSPECTION



*ECM (ECCS control module) may be the cause of a problem, but this is rarely the case.

TROUBLE DIAGNOSES

Fail-safe System

How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The engine has an ECM (ECCS control module) to control major systems such as fuel control, ignition control, idle speed control, etc. The ECM accepts powertrain input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.


It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by either poor electrical connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.


Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.


1. Verify the complaint.
2. Isolate the cause.
3. Repair.
4. Recheck and be sure no new symptoms have been caused.



SEF232G



SEF233G



SEF234G

CI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



*1: If the self-diagnosis cannot be performed, check main power supply and ground circuit. (See Diagnostic Procedure 22. Refer to EF & EC-92)

*2: If the trouble is not duplicated, see INTERMITTENT PROBLEM SIMULATION. Refer to EF & EC-36.


TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

INTERMITTENT PROBLEM SIMULATION

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.


Perform the activity listed under Service procedure and note the result.



	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Camshaft position sensor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3	Mixture ratio feedback control	Heated oxygen sensor	Suspended	Disconnect heated oxygen sensor harness connector.
		ECM	Operation check	Perform on-board diagnostic test mode II (Self-diagnostic results) at 2,000 rpm.
4	Idle speed	IAC valve-AAC valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electrical connection (Electric continuity)	Harness connectors and wires	Poor electrical connection or improper wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	ECM	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioning, rear defogger, etc.
9	Closed throttle position switch condition	ECM	ON-OFF switching	Rotate throttle position sensor body.
10	Ignition spark	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition coil adapter (SST).

- Select the "Variable factor" when the symptom occurs. Perform the "Service procedure" to try to simulate the intermittent problem.

TROUBLE DIAGNOSES





On-board Diagnostic System

MALFUNCTION INDICATOR LAMP (MIL)

A malfunction indicator lamp has been adopted on all models. For a list of conditions that turn the lamp on, refer to EF & EC-40.

GI
MA
EM
LC

ON-BOARD DIAGNOSTIC SYSTEM MODES

Condition		On-board Diagnostic Test Mode I	On-board Diagnostic Test Mode II
Ignition switch in "ON" position	Engine stopped 	MALFUNCTION INDICATOR LAMP CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	HEATED OXYGEN SENSOR MONITOR

EF & EC





FE
AT
FA
RA

- Refer to the next page for on-board diagnostic procedures (without CONSULT) or EF & EC-44 (with CONSULT).



BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

On-board Diagnostic System (Cont'd) HOW TO SWITCH ON-BOARD DIAGNOSTIC TEST MODES (Without CONSULT)



Disconnect harness connectors **E30** and **F28** and connect **A** and **B** terminals with a suitable jumper wire.




Remove jumper wire and reconnect harness connectors **E30** and **F28**.

B

TROUBLE DIAGNOSES

On-board Diagnostic System (Cont'd)



To erase stored codes it is necessary to disconnect harness connectors **(E30)** and **(F28)** and connect **(A)** and **(B)** terminals with a suitable jumper wire.

Remove jumper wire and reconnect harness connectors **(E30)** and **(F28)**.

- Switching the modes is not possible when the engine is running.
- When the ignition switch is turned off during diagnosis in each mode, and then turned back on again after power to the ECM has dropped off completely, the diagnosis mode will automatically return to On-board Diagnostic Test Mode I but stored codes will remain in memory unless the erasing procedure has been performed.

GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR

ST


BF

HA

EL

IDX

TROUBLE DIAGNOSES



On-board Diagnostic System — On-board Diagnostic Test Mode I

ON-BOARD DIAGNOSTIC TEST MODE I — MALFUNCTION INDICATOR LAMP CHECK

In this mode, the MALFUNCTION INDICATOR LAMP in the instrument panel stays “ON”.

If MALFUNCTION INDICATOR LAMP remains “OFF”, check the bulb in the MALFUNCTION INDICATOR LAMP.

ON-BOARD DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MALFUNCTION INDICATOR LAMP	Condition
ON	When the following malfunctions (malfunction indicator lamp item) are detected or the ECM's CPU or camshaft position sensor is malfunctioning.
OFF	OK

Diagnostic trouble code No.	Malfunction
12	Mass air flow sensor circuit
13	Engine coolant temperature sensor circuit
14	Vehicle speed sensor circuit
31	ECM (ECCS control module) CPU
32	EGR function
33	Heated oxygen sensor circuit
35	EGR temperature sensor circuit
43	Throttle position sensor circuit
45	Injector leak
51	Injector circuit


- These Diagnostic trouble code Numbers are clarified in On-board Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS. Refer to EF & EC-41.
- The MALFUNCTION INDICATOR LAMP will turn OFF when operation returns to normal. But, the On-board Diagnostic Test Mode II — SELF-DIAGNOSTIC RESULTS memory will hold the diagnostic trouble code until the memory is cleared. To clear SELF-DIAGNOSTIC RESULTS memory, refer to EF & EC-38 (Without CONSULT). To clear SELF-DIAGNOSTIC RESULTS memory (With CONSULT), refer to CONSULT Operation Manual — Engine.

TROUBLE DIAGNOSES

On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results)

DESCRIPTION

In this mode, a diagnostic trouble code is indicated by the number of flashes from the MALFUNCTION INDICATOR LAMP as shown below:



Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits.

For example, MALFUNCTION INDICATOR LAMP flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the mass air flow sensor. In this way, all the problems are classified by their diagnostic trouble code numbers.

The diagnostic results will remain in ECM memory.

Display diagnostic trouble code table

Diagnostic trouble code No.	Detected items	Diagnostic Procedure Page
11*	Camshaft position sensor circuit	EF & EC-95
12	Mass air flow sensor circuit	EF & EC-98
13	Engine coolant temperature sensor circuit	EF & EC-101
14	Vehicle speed sensor circuit	EF & EC-103
21*	Ignition signal circuit	EF & EC-106
31	ECM CPU	EF & EC-109
32	EGR function	EF & EC-110
33	Heated oxygen sensor circuit	EF & EC-114
34	Knock sensor circuit	EF & EC-117
35	EGR temperature sensor circuit	EF & EC-119
43	Throttle position sensor circuit	EF & EC-122
45	Injector leak	EF & EC-125
51	Injector circuit	EF & EC-127
55	No malfunction in the above circuits	EF & EC-34

: Malfunction indicator lamp item

*: Inspect items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 are displayed at the same time.

TROUBLE DIAGNOSES

On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)

Diagnostic trouble code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
*11	Camshaft position sensor circuit	<ul style="list-style-type: none"> ● Either 1° or 120° signal is not entered for the first few seconds during engine cranking. ● Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace camshaft position sensor.)
12	Mass air flow sensor circuit	<ul style="list-style-type: none"> ● The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
13	Engine coolant temperature sensor circuit	<ul style="list-style-type: none"> ● The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> ● The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor (pulse generator)
*21	Ignition signal circuit	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness and connector ● Power transistor unit
31	ECM CPU	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
32	EGR function	<ul style="list-style-type: none"> ● EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> ● EGR valve ● EGR control-solenoid valve
33	Heated oxygen sensor circuit	<ul style="list-style-type: none"> ● The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Heated oxygen sensor ● Fuel pressure ● Injectors ● Intake air leaks
34	Knock sensor circuit	<ul style="list-style-type: none"> ● The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Knock sensor
35	EGR temperature sensor circuit	<ul style="list-style-type: none"> ● The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● EGR temperature sensor
43	Throttle position sensor circuit	<ul style="list-style-type: none"> ● The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor
45	Injector leak	<ul style="list-style-type: none"> ● Fuel leaks from injector. 	<ul style="list-style-type: none"> ● Injector
51	Injector circuit	<ul style="list-style-type: none"> ● The injector circuit is open. 	<ul style="list-style-type: none"> ● Injector
55	None	<ul style="list-style-type: none"> ● None of the above items detected. 	Refer to EF & EC-34

*: Inspect items causing a malfunction of camshaft position sensor circuit first, if both diagnostic trouble code No. 11 and 21 come out at the same time.

TROUBLE DIAGNOSES

On-board Diagnostic System — On-board Diagnostic Test Mode II (Self-diagnostic results) (Cont'd)

HOW TO ERASE ON-BOARD DIAGNOSTIC TEST MODE II (Self-diagnostic results)



The diagnostic trouble code is erased from the backup memory on the ECM when the On-board diagnostic test mode is changed from On-board Diagnostic Test Mode II to On-board Diagnostic Test Mode I. (Refer to "HOW TO SWITCH ON-BOARD DIAGNOSTIC TEST MODES".) Refer to EF & EC-38.

- When the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- Before starting on-board diagnostic test mode II (self-diagnostic result), do not erase the stored memory.
- Refer to CONSULT Operation Manual — Engine.



On-board Diagnostic System — On-board Diagnostic Test Mode II (Heated oxygen sensor monitor)

DESCRIPTION

In this mode, the MALFUNCTION INDICATOR LAMP displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor.

MALFUNCTION INDICATOR LAMP	Fuel mixture condition in the exhaust gas	② Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
① Remains ON or OFF	Any condition	Open loop system


①: Maintains the mixture condition present just before switching to open loop.

② Refer to EF & EC-18 for description of mixture ratio feedback system and open loop system.

HOW TO CHECK HEATED OXYGEN SENSOR

1. Set On-board Diagnostic Test Mode II. (Refer to "HOW TO SWITCH ON-BOARD DIAGNOSTIC TEST MODES".) Refer to EF & EC-38.
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure MALFUNCTION INDICATOR LAMP goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.



TROUBLE DIAGNOSES




CONSULT

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect CONSULT to data link connector for CONSULT.
(Data link connector for CONSULT is located in lower side instrument panel.)



3. Turn on ignition switch.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to the inspection sheet as follows:

For further information, see the CONSULT Operation Manual — Engine.

TROUBLE DIAGNOSES

CONSULT (Cont'd)

DEFINITION OF CONSULT FUNCTIONS

Diagnostic test mode	Function	Page
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.	EF & EC-46
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	EF & EC-47
Data monitor	Input/Output data in the ECM can be read.	EF & EC-48
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the control modules and also shifts some parameters in a specified range.	EF & EC-50
ECM part number	ECM part number can be read.	—
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".	EF & EC-51

ECCS COMPONENT PARTS APPLICATION

ECCS COMPONENT PARTS		DIAGNOSTIC TEST MODE				
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
INPUT	Camshaft position sensor		X	X		
	Mass air flow sensor		X	X		
	Engine coolant temperature sensor		X	X	X	
	Heated oxygen sensor		X	X		X
	Vehicle speed sensor		X	X		X
	Throttle position sensor	X	X	X		X
	EGR temperature sensor		X	X		
	Knock sensor		X			
	Ignition switch (start signal)			X		X
	Air conditioning signal			X		
	Park/neutral position switch			X		X
	Battery			X		
	Power steering pressure switch			X		X
	Closed throttle position switch			X		X
OUT-PUT	Injectors		X	X	X	X
	Power transistor (ignition timing)		X (Ignition signal)	X	X	X
	IAC valve-AAC valve	X		X	X	X
	Fuel pump relay	X		X	X	X
	EGR control-solenoid valve			X	X	X
	Air conditioning relay			X		
	Cooling fan relay(s)			X	X	X

X: Applicable

TROUBLE DIAGNOSES

CONSULT (Cont'd)

WORK SUPPORT DIAGNOSTIC TEST MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITION. <ul style="list-style-type: none">● IGN SW "ON"● ENG NOT RUNNING● ACC PEDAL KEPT OFF	When adjusting throttle position sensor initial position. Refer to EF & EC-56.
IACV-AAC/V ADJ	SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITION. <ul style="list-style-type: none">● ENG WARMED UP ENOUGH● NO LOAD	When adjusting idle speed. Refer to EF & EC-56.
FUEL PRES RELEASE	<ul style="list-style-type: none">● FUEL PUMP WILL STOP BY TOUCHING START DURING IDLE CRANK A FEW TIMES AFTER ENGINE STALL.	When releasing fuel pressure. Refer to MA section.

TROUBLE DIAGNOSES

CONSULT (Cont'd)

SELF-DIAGNOSTIC RESULTS DIAGNOSTIC TEST MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CAMSHAFT POSITION SENSOR*	<ul style="list-style-type: none"> • Either 1° or 120° signal is not entered for the first few seconds during engine cranking. • Either 1° or 120° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace camshaft position sensor.)
MASS AIR FLOW SENSOR	<ul style="list-style-type: none"> • The mass air flow sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace mass air flow sensor.)
ENGINE COOLANT TEMPERATURE SENSOR	<ul style="list-style-type: none"> • The engine coolant temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
VEHICLE SPEED SENSOR	<ul style="list-style-type: none"> • The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (pulse generator)
IGN SIGNAL-PRIMARY*	<ul style="list-style-type: none"> • The ignition signal in primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> • Harness and connector • Power transistor unit
ECM	<ul style="list-style-type: none"> • ECM calculation function is malfunctioning. 	[Replace ECM (ECCS control module).]
EGR SYSTEM	<ul style="list-style-type: none"> • EGR valve does not operate. (EGR valve spring does not lift.) 	<ul style="list-style-type: none"> • EGR valve • EGR control-solenoid valve
HEATED OXYGEN SENSOR	<ul style="list-style-type: none"> • The heated oxygen sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Heated oxygen sensor • Fuel pressure • Injectors • Intake air leaks
KNOCK SENSOR	<ul style="list-style-type: none"> • The knock sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Knock sensor
EGR TEMP SENSOR	<ul style="list-style-type: none"> • The EGR temperature sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • EGR temperature sensor
THROTTLE POSITION SENSOR	<ul style="list-style-type: none"> • The throttle position sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor
INJECTOR LEAK	<ul style="list-style-type: none"> • Fuel leaks from injector. 	<ul style="list-style-type: none"> • Injector
INJECTOR OPEN	<ul style="list-style-type: none"> • The injector circuit is open. 	<ul style="list-style-type: none"> • Injector

*: Inspect items causing a malfunction of camshaft position sensor circuit first, if both "CAMSHAFT POSITION SENSOR" and "IGN SIGNAL-PRIMARY" come out at the same time.

- **Sensor failures which set a self-diagnosis code are listed as due to an open or short circuit.**
- **A sensor sending a signal which is inaccurate but not open or short will NOT set a self-diagnosis code.**
- **If a driveability symptom is present, but no self-diagnosis code is set, perform further inspections using DATA MONITOR.**

TROUBLE DIAGNOSES

CONSULT (Cont'd)

DATA MONITOR DIAGNOSTIC TEST MODE

Remarks : ● Specification data are reference values.

● Specification data are output/input values which are detected or supplied by ECM at the connector.

*Specification data may not be directly related to their components signals/values/operations.

ie. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing being not adjusted to the specification data. This IGN TIMING monitors the calculated data by ECM according to the input signals from camshaft position sensor and other ignition timing related sensors.

● If the real-time diagnosis results are NG and the on-board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

● If the A/F ALPHA is below 100, the ECM is compensating for a rich signal from the heated oxygen sensor. If it is above 100, the ECM is compensating for a lean signal from the heated oxygen sensor.

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CMPS · RPM (POS)	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.	<ul style="list-style-type: none"> Harness and connector Camshaft position sensor
MAS AIR/FL SE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine A/C switch "OFF" Shift lever "N" 	Idle	1.0 - 1.7V	<ul style="list-style-type: none"> Harness and connector Mass air flow sensor
		2,000 rpm	1.4 - 2.2V	
COOLAN TEMP/S	<ul style="list-style-type: none"> Engine: After warming up 		More than 70°C (158°F)	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor
O2 SEN	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 ↔ Approx. 1.5V	<ul style="list-style-type: none"> Harness and connector Heated oxygen sensor Intake air leaks Injectors
M/R F/C MNT			LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
VHCL SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value	<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor
BATTERY VOLT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) 		11 - 14V	<ul style="list-style-type: none"> Battery ECM power supply circuit
THRTL POS SEN	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) 	Throttle valve fully closed	0.3 - 0.7V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment
		Throttle valve fully opened	Approx. 4.0V	
EGR TEMP SEN	<ul style="list-style-type: none"> Engine: After warming up 		Less than 4.5V	<ul style="list-style-type: none"> Harness and connector EGR temperature sensor
START SIGNAL	<ul style="list-style-type: none"> Ignition switch: "ON" → "START" 		OFF → ON	<ul style="list-style-type: none"> Harness and connector Starter switch
CLOSED TH/POS	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) 	Throttle valve: Idle position	ON	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	A/C switch "OFF"	OFF	<ul style="list-style-type: none"> Harness and connector Air conditioning switch
		A/C switch "ON" (1)	ON	
NEUT POSI SW	<ul style="list-style-type: none"> Ignition switch: "ON" 	Shift lever "P" or "N"	ON	<ul style="list-style-type: none"> Harness and connector Park/neutral position switch
		Except above	OFF	

(1): Any mode except "OFF", ambient temperature above 10°C (50°F).

TROUBLE DIAGNOSES

CONSULT (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.	
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF	● Harness and connector ● Power steering pressure switch
		The steering wheel is turned	ON	
INJ PULSE	● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load	Idle	2.4 - 3.5 msec.	● Harness and connector ● Injector ● Mass air flow sensor ● Intake air system
		2,000 rpm	2.3 - 3.2 msec.	
IGN TIMING	ditto	Idle	15° BTDC	● Harness and connector ● Camshaft position sensor
		2,000 rpm	More than 25° BTDC	
IACV-AAC V	ditto	Idle	15 - 40%	● Harness and connector ● IAC valve-AAC valve
		2,000 rpm	—	
AIR COND RLY	● Air conditioning switch OFF → ON ⁽¹⁾	OFF → ON	● Harness and connector ● Air conditioning switch ● Air conditioning relay	
EGRC SOLV	● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load	Idle	ON	● Harness and connector ● EGR control-solenoid valve
		2,000 rpm	OFF	
FUEL PUMP RLY	● Ignition switch is turned to "ON" (Operates for 5 seconds) ● Engine running and cranking ● When engine is stopped (stops in 1.5 seconds) Except as shown above		ON	● Harness and connector ● Fuel pump relay
			OFF	
COOLING FAN	● After warming up engine, idle the engine. ● A/C switch "OFF"	Engine coolant temperature is 94°C (201°F) or less	OFF	● Harness and connector ● Cooling fan relays ● Cooling fan
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F).	LOW	
		Engine coolant temperature is 105°C (221°F) or more	HIGH	
A/F ALPHA	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	75 - 125%	● Harness and connector ● Injectors ● Mass air flow sensor ● Heated oxygen sensor ● Canister purge line ● Intake air system

(1): Any mode except "OFF", ambient temperature above 10°C (50°F).

TROUBLE DIAGNOSES

CONSULT (Cont'd)

ACTIVE TEST DIAGNOSTIC TEST MODE

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL INJECTION TEST	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the amount of fuel injection with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel injectors ● Heated oxygen sensor
IAC VALVE-AAC VALVE OPENING TEST	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Change the IAC valve-AAC valve opening percent with the CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● IAC valve-AAC valve
ENG COOLANT TEMP TEST	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor ● Fuel injectors
IGNITION TIMING TEST	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing with the CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Adjust initial ignition timing
POWER BALANCE TEST	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time with the CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connector ● Compression ● Injectors ● Power transistor ● Spark plugs ● Ignition coils
COOLING FAN TEST	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Turn cooling fan "ON" and "OFF" with the CONSULT. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connector ● Cooling fan motor
FUEL PUMP RELAY TEST	<ul style="list-style-type: none"> ● Ignition switch: "ON" (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" with the CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
EGRC SOLENOID VALVE TEST	<ul style="list-style-type: none"> ● Ignition switch: "ON" ● Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound. 	EGR control-solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
SELF-LEARNING CONT TEST	<ul style="list-style-type: none"> ● In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		

TROUBLE DIAGNOSES

CONSULT (Cont'd)

FUNCTION TEST DIAGNOSTIC TEST MODE






FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) Displays the results of on-board diagnostic system. 	—		Objective system	CI MA
CLOSED THROTTLE POSI (CLOSED THROTTLE POSITION SWITCH CIRCUIT)	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) Closed throttle position switch circuit is tested when throttle is opened and closed fully. ("CLOSED THROTTLE POSI" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> Harness and connector Throttle position sensor (Closed throttle position switch) Throttle position sensor (Closed throttle position switch) adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	EM LC
		Throttle valve: closed	ON		EF & EC
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	AT FA
NEUTRAL POSI SW CKT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) Park/neutral position switch circuit is tested when shift lever is manipulated. 	OUT OF N/P-RANGE	OFF	<ul style="list-style-type: none"> Harness and connector Park/neutral position switch/Inhibitor switch Linkage + Inhibitor switch adjustment 	RA
		IN N-RANGE	ON		BR
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose. The relay makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level 	ST BF
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine stopped) EGR control-solenoid valve circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector EGR control-solenoid valve 	HA EL
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> Ignition switch "ON" (Engine stopped) Cooling fan circuit is tested by checking cooling fan operation. 	The cooling fan rotates and stops every 3 seconds.		<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay 	IDX
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: "ON" → "START" Start signal circuit is tested when engine is started by operating the starter. Battery positive voltage and water temperature before cranking, and average battery positive voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed. 	Start signal: "OFF" → "ON"		<ul style="list-style-type: none"> Harness and connector Ignition switch 	

TROUBLE DIAGNOSES

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: "ON" (Engine running) Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> Harness and connector Power steering pressure switch Power steering oil pump
		Neutral position	OFF	
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor powertrain input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor Electric speedometer
IGN TIMING ADJ	<ul style="list-style-type: none"> After warming up, idle the engine. Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> Adjust ignition timing (by moving camshaft position sensor or distributor) Camshaft position sensor drive mechanism
MIXTURE RATIO TEST	<ul style="list-style-type: none"> Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the heated oxygen sensor output at 2,000 rpm under non-loaded state. 	<ul style="list-style-type: none"> HEATED OXYGEN SENSOR COUNT: More than 5 times during 10 seconds 		<ul style="list-style-type: none"> INJECTION SYS (Injector, fuel pressure regulator, harness or connector) IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) VACUUM SYS (Intake air leaks) Heated oxygen sensor circuit Heated oxygen sensor operation Fuel pressure high or low Mass air flow sensor
POWER BALANCE	<ul style="list-style-type: none"> After warming up, idle the engine. Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multiport fuel injection system is used.) 	Difference in engine rpm is greater than 25 rpm before and after cutting off the injector of each cylinder.		<ul style="list-style-type: none"> Injector circuit (Injector, harness or connector) Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) Compression Valve timing
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> After warming up, idle the engine. IAC valve-AAC valve system is tested by detecting change in engine rpm when IAC valve-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine rpm is greater than 150 rpm between when valve opening is at 80%(102 steps) and at 20%(25 steps).		<ul style="list-style-type: none"> Harness and connector IAC valve-AAC valve Air passage restriction between air inlet and IAC valve-AAC valve IAS (Idle adjusting screw) adjustment

TROUBLE DIAGNOSES



Diagnostic Precautions

CAUTION:

1. Before connecting or disconnecting the ECM harness connector to or from any ECM, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage ECM as battery positive voltage is applied to ECM even if ignition switch is turned off. Failure to do so may damage the ECM.
2. When connecting ECM harness connector, tighten securing bolt until red projection is in line with connector face.
3. When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
5. Before replacing ECM, perform ECM input/output signal inspection and make sure whether ECM functions properly or not. Refer to EF & EC-158.
6. After reviewing the above items, perform On-board Diagnostic Test Mode II (Self-diagnostic results) and driving test.

GI

WA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA

EL


IDX

TROUBLE DIAGNOSES

Diagnostic Precautions (Cont'd)





7. When measuring ECM controlled components supply voltage with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the ECM power transistor.



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Basic Inspection



1

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for proper connections
 - Vacuum hoses for splits, kinks, and proper connections
 - Wiring for proper connections, pinches, and cuts

2

CONNECT CONSULT TO THE VEHICLE

Connect CONSULT to the data link connector for CONSULT and select "ENGINE" from the menu. Refer to EF & EC-44.

3

DOES ENGINE START?

No → Go to **6**

Yes →

4

CHECK IGNITION TIMING.

Warm up engine sufficiently and check ignition timing at idle using timing light. Refer to EF & EC-28.

Ignition timing:
15°±2° BTDC

NG → Adjust ignition timing by turning camshaft position sensor.

OK →

(Go to **A** on next page.)

TROUBLE DIAGNOSES

Basic Inspection (Cont'd)

5


■ IACV-AAC/V ADJ ■

SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITION

- ENG WARMED UP
- NO LOAD

START

SEF260M



6

■ THRTL POS SEN ADJ ■

*** ADJ MONITOR ***


THRTL POS SEN 0.42V

=== MONITOR ===

CMPS•RPM (POS) 0rpm

CLOSED TH/POS ON

AEC381



(A)

5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.

No → Adjust engine rpm by turning idle adjusting screw.

1. Select "IACV-AAC/V ADJ" in "WORK SUPPORT" mode.

2. When touching "START", does engine rpm fall to 700 ± 50 rpm (in "N" position)?

OR

3. When disconnecting IAC valve-AAC valve sub-harness connector (F106), does engine rpm fall to 700 ± 50 rpm (in "N" position)?

Yes

6

CHECK THROTTLE POSITION SENSOR IDLE POSITION.

NG → 1. Adjust output voltage by rotating throttle position sensor body.

2. Disconnect throttle position sensor harness connector for a few seconds and then reconnect it.

3. Confirm that "CLOSED TH/POS" stays "ON".

1. Perform "THRTL POS SEN ADJ" in "WORK SUPPORT" mode.

2. Check that output voltage of throttle position sensor is 0.3 to 0.7V. (Throttle valve fully closes.) and "IDLE POSITION" stays "ON".

OR

3. Measure output voltage of throttle position sensor using voltmeter, and check that it is 0.3 to 0.7V. (Throttle valve fully closed.)

OK

(Go to (B) on next page.)

TROUBLE DIAGNOSES


Basic Inspection (Cont'd)

7

☆ MONITOR ☆ NO FAIL	<input type="checkbox"/>
START SIGNAL	OFF
CLOSED TH/POS	ON
AIR COND SIG	OFF
NEUT POSI SW	ON
PW/ST SIGNAL	OFF

RECORD

AEC213





8

■ SELF-DIAG RESULTS ■	<input type="checkbox"/>
FAILURE DETECTED	TIME
• NO SELF DIAGNOSTIC FAILURE INDICATED.	
FURTHER TESTING MAY BE REQUIRED **	

ERASE PRINT


SEF227L



C
 MA
 EM
 LG
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 DX

TROUBLE DIAGNOSES

Diagnostic Procedure 1 — High Idling after Warm-up




1

CHECK IAC VALVE-AIR REGULATOR.
When pinching the IAC valve-air regulator hose, does the engine speed drop?

Yes

Check IAC valve-air regulator and circuit. Refer to EF & EC-138.

No



2

CHECK INTAKE AIR LEAK.



1. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.
2. Clear the self-learning control coefficient by touching "CLEAR".
3. Does the engine speed drop?

Yes


Discover air leak location and repair.

OR



1. Disconnect heated oxygen sensor harness connector.
2. After racing engine at 1,500 rpm under no load for about 30 seconds, does the engine speed drop?

No



3


CHECK THROTTLE LINKAGE.

1. Check that throttle linkage moves smoothly.
2. Confirm that throttle valve fully opens and fully closes.

NG

Repair throttle linkage or sticking of throttle valve.


OK



INSPECTION END

TROUBLE DIAGNOSES


Diagnostic Procedure 2 — Hunting



1

CHECK HEATED OXYGEN SENSOR.
When disconnecting heated oxygen sensor harness connector, is the hunting fixed?

Yes → Check heated oxygen sensor. Refer to EF & EC-114.



2

PERFORM POWER BALANCE TEST.


1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.

2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 4 .

OR

Disconnect each ignition wire from spark plug and ground it, one at a time, is there any cylinder which does not produce a momentary engine speed drop?




Yes

3

CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).






OK

(Go to (A) on next page.)







GI
MA
EM
LG
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
DX

TROUBLE DIAGNOSES

Diagnostic Procedure 2 — Hunting (Cont'd)



Diagnostic Procedure 3 — Unstable Idle



GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle (Cont'd)




5

CHECK INJECTOR.

1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON". (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No → Check injector(s) and circuit(s). Refer to EF & EC-127.




6

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. Refer to EF & EC-171.
2. Install fuel pressure gauge and check fuel pressure.

At idle:
Approx. 235 kPa
(2.4 kg/cm², 34 psi)

NG → Check fuel pump and circuit. Refer to EF & EC-130.



7


CHECK HEATED OXYGEN SENSOR.

1. See "M/R F/C MNT" in "Data monitor" mode.
2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →
1 time 2 times
LEAN → RICH.....

OR

NG → Replace heated oxygen sensor.








1. Set "Heated oxygen sensor monitor" in the On-board Diagnostic Test Mode II. Refer to EF & EC-38.
2. Maintaining engine at 2,000 rpm under no-load, check to make sure that malfunction indicator lamp goes ON and OFF more than 5 times during 10 seconds.

(Go to **B** on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 3 — Unstable Idle (Cont'd)



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold




1
CHECK BATTERY AND STARTER.
 Check battery and starter condition. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("Trouble Diagnoses", "STARTING SYSTEM").

NG → Repair or replace.




2
CHECK FUEL PRESSURE.
 1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. Refer to EF & EC-130.




3
CHECK IAC VALVE-AIR REGULATOR AND IAC VALVE-AAC VALVE.
 When pressing accelerator pedal 1/4 open, can you start the engine.

Yes → Check IAC valve-AAC valve, IAC valve-air regulator and circuits. Refer to EF & EC-138 and EF & EC-140.



4
CHECK IGNITION SPARK.
 1. Disconnect ignition wire from spark plug.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

NG → Check ignition coil, power transistor unit and their circuits. Refer to EF & EC-106.




5
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).

OK → (Go to **A** on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)



6

(A)

CHECK INJECTOR.

1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON". (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No

Check injector(s) and circuit(s). Refer to EF & EC-127.

Yes

CHECK ECM HARNESS CONNECTOR.

Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-158.

NG

Repair or replace.

OK

Reconnect ECM harness connector and retest.

Trouble is not fixed.

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Refer to EF & EC-92.

NG

Repair or replace.

OK

TRY A KNOWN GOOD ECM.

INSPECTION END

GI

WA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot




1

CHECK FUEL PRESSURE.

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. Refer to EF & EC-130.




2

CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Can you start engine?

Yes → Check fuel properties.




3

CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.



4

CHECK INJECTOR.


1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON". (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No → Check injector(s) and circuit(s). Refer to EF & EC-127.

Yes → (Go to **A** on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot (Cont'd)



GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX


TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions




1
CHECK BATTERY AND STARTER.
 Check battery and starter operation. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("Trouble Diagnoses", "CHARGING SYSTEM").

NG → Repair or replace.




2
CHECK FUEL PRESSURE.
 1. Pinch fuel feed hose with fingers.
 2. When cranking the engine, is there any pressure on the fuel feed hose?

No → Check fuel pump and circuit. Refer to EF & EC-130.




3
CHECK IGNITION SPARK.
 1. Disconnect ignition wire from spark plug.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.



4
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).






5
CHECK INJECTOR FOR LEAKAGE.
 When pressing accelerator pedal fully, can you start the engine.

Yes → Check injector(s) for leakage. Refer to EF & EC-125.

(Go to **A** on next page.)




TROUBLE DIAGNOSES

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)



CI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES



Diagnostic Procedure 7 — Hesitation when the Engine is Hot

1

CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check fuel properties.

No

2

CHECK CANISTER PURGE.

1. Disconnect canister purge line hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check purge and vacuum line. Refer to EF & EC-174.

No

3

CHECK FOR INTAKE AIR LEAK.

- When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?



Yes

Discover air leak location and repair.


No

INSPECTION END

TROUBLE DIAGNOSES




Diagnostic Procedure 8 — Hesitation when the Engine is Cold




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 9 — Hesitation under Normal Conditions




SEF156I




AEC386




AEC379




AEC019








AEC385






Diagnostic Procedure 10 — Engine Stalls when Turning



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)



5

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. Refer to EF & EC-171.
2. Install fuel pressure gauge and check fuel pressure.

At idle:

Approx. 235 kPa
(2.4 kg/cm², 34 psi)

The moment throttle valve
is fully open:

Approx. 294 kPa
(3.0 kg/cm², 43 psi)

NG

Check fuel pressure regulator diaphragm. Refer to EF & EC-171.

OK

CHECK ECM HARNESS CONNECTOR.

Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-158.

NG

Repair or replace.

OK

Reconnect ECM harness connector and retest.

Trouble is not fixed.

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Refer to EF & EC-92.





NG

Repair or replace.


OK

TRY A KNOWN GOOD ECM.

INSPECTION END






Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)




TROUBLE DIAGNOSES



Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold

1
CHECK IAC VALVE-AIR REGULATOR AND IAC VALVE-AAC VALVE.
 When the engine is cold, can you start the engine when pressing accelerator pedal 1/4 open?


NG → Check IAC valve-AAC valve, IAC valve-air regulator and circuits. Refer to EF & EC-138 and EF & EC-140.



2
PERFORM POWER BALANCE TEST.
 1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
 2. Is there any cylinder which does not produce a momentary engine speed drop?


NG → Go to **6**.

OR
 Disconnect each ignition wire from spark plug and ground it, one at a time, is there any cylinder which does not produce a momentary engine speed drop?




3
CHECK IGNITION SPARK.
 1. Disconnect ignition wire from spark plug.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against a suitable ground and crank engine.
 4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.



4
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).






(Go to **A** on next page.)

GI
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)



CI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST







BF

HA

EL




IDX

Diagnostic Procedure 13 — Engine Stalls when Accelerator is Momentarily Pressed and Released








TROUBLE DIAGNOSES

Diagnostic Procedure 13 — Engine Stalls when Accelerator is Momentarily Pressed and Released (Cont'd)









Diagnostic Procedure 14 — Engine Stalls after Decelerating



GI
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)


7

* MONITOR	* NO FAIL	<input type="checkbox"/>
CMPS•RPM (POS)	2000rpm	
M/R F/C MNT	RICH	

RECORD

AEC386


7



CHECK ENGINE

Malfunction indicator lamp


AEC379



GI
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed



1

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.


2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**

OR

2. Disconnect each ignition wire from spark plug and ground it, one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes



2

CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.


2. Connect a known good spark plug to the ignition wire.

3. Place end of spark plug against a suitable ground and crank engine.

4. Check for spark.

No → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

Yes



3

CHECK INJECTOR.


1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)

2. Turn ignition switch "ON". (Do not start engine.)

3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No → Check injector(s) and circuit(s). Refer to EF & EC-127.




Yes



(Go to **A** on next page.)

TROUBLE DIAGNOSES


Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed (Cont'd)



GI
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy



1
CHECK BATTERY AND GENERATOR.
Check battery and generator condition. Refer to EL section ("SPECIFIC GRAVITY CHECK", "BATTERY") and ("Trouble Diagnoses", "CHARGING SYSTEM").

NG → Repair or replace.

OK




2
PERFORM POWER BALANCE TEST.
1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to 5.

OR
3. Disconnect each ignition wire from spark plug and ground it, one at a time, is there any cylinder which does not produce a momentary engine speed drop?


Yes



3
CHECK IGNITION SPARK.
1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

NG → Check ignition coil, power transistor unit and circuits. Refer to EF & EC-106.

OK




4
CHECK INJECTOR.
1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON". (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No → Check injector(s) and circuit(s). Refer to EF & EC-127.


Yes

(Go to A on next page.)



TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)



5

CHECK FUEL PRESSURE.
 1. Release fuel pressure to zero. Refer to EF & EC-171.
 2. Install fuel pressure gauge and check fuel pressure.
At idle:
 Approx. 235 kPa
 (2.4 kg/cm², 34 psi)
The moment throttle valve is fully open:
 Approx. 294 kPa
 (3.0 kg/cm², 43 psi)

NG → Check fuel pressure regulator diaphragm. Refer to EF & EC-171.

OK

CHECK ECM HARNESS CONNECTOR.
 Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC-158.

NG → Repair or replace.

OK

Reconnect ECM harness connector and retest.

Trouble is not fixed.

CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.
 Refer to EF & EC-92.

NG → Repair or replace.

OK

TRY A KNOWN GOOD ECM.

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST



BF

HA

EL

IDX

TROUBLE DIAGNOSES



Diagnostic Procedure 17 — Lack of Power and Stumble

1

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. Refer to EF & EC-171.
2. Install fuel pressure gauge and check fuel pressure.

At idle:

Approx. 235 kPa
(2.4 kg/cm², 34 psi)

The moment throttle valve
is fully open:

Approx. 294 kPa
(3.0 kg/cm², 43 psi)

NG

Check fuel pressure regulator diaphragm. Refer to EF & EC-171.

OK

2

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes

Discover air leak location and repair.

No

CHECK TIMING BELT FOR PROPER INSTALLATION.







NG

Properly install new timing belt. Refer to EM section ("Installation", "TIMING BELT").

OK

INSPECTION END

Diagnostic Procedure 18 — Knock



G1

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 19 — Surge

1

* MONITOR	* NO FAIL	<input type="checkbox"/>
CMPS•RPM (POS)	2000rpm	
M/R F/C MNT	RICH	

RECORD


AEC386

1

CHECK ENGINE

Malfunction indicator lamp

AEC379



1

CHECK HEATED OXYGEN SENSOR.

1. See "M/R F/C MNT" in "DATA MONITOR" mode.

2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently.), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH→LEAN→RICH→
1 time 2 times
LEAN→RICH.....

OR

1. Set "Heated oxygen sensor monitor" in the On-board Diagnostic Test Mode II. Refer to EF & EC-38.

2. Maintaining engine at 2,000 rpm under no load, check that malfunction indicator lamp goes ON and OFF more than 5 times during 10 seconds.

NG → Replace heated oxygen sensor.

OK ↓

2

CHECK EGR VALVE.
Check EGR valve for sticking.

NG → Repair or replace.

OK ↓

CHECK ECM HARNESS CONNECTOR.
Check the ECM pin terminals for damage or poor connection of ECM harness connector. Refer to EF & EC- 158.

OK ↓


Reconnect ECM harness connector and retest.

Trouble is not fixed. ↓

TRY A KNOWN GOOD ECM.

INSPECTION END

TROUBLE DIAGNOSES




Diagnostic Procedure 20 — Backfire through the Intake

1

CHECK SPARK PLUGS AND DISTRIBUTOR CAP.
Remove the spark plugs and check for fouling, etc. Remove and check distributor cap for carbon tracking.

NG → Repair or replace spark plug(s) or distributor cap.

OK



2


CHECK INTAKE AIR LEAK.
When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes → Discover air leak location and repair.

No

CHECK FOR INTAKE VALVE DEPOSITS.
If there are deposits on intake valves, remove them.

INSPECTION END



Diagnostic Procedure 21 — Backfire through the Exhaust on Deceleration

1

CHECK ENGINE COOLANT TEMPERATURE SENSOR.
Check engine coolant temperature sensor and its circuit. Refer to EF & EC-101.

NG → Replace or repair.

OK

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

YA


EL

IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)









Harness layout



TROUBLE DIAGNOSES


Diagnostic Procedure 22 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 22 (Cont'd)




F

CHECK GROUND CIRCUIT.
1) Check harness continuity between ECM terminals (39), (48) and engine ground.
Continuity should exist.

NG → Repair harness or connectors.

OK




G

CHECK OUTPUT SIGNAL CIRCUIT.
1) Check harness continuity between ECM terminal (4) and terminal (2).
Continuity should exist.

NG → Check the following.
• Harness connectors (F1), (E1)
• Harness continuity between ECM and ECM relay
If NG, repair harness or connectors.

OK



H

CHECK INPUT SIGNAL CIRCUIT.
1) Turn ignition switch "ON".
2) Check voltage between ECM terminal (36) and ground.
Voltage: Battery positive voltage

NG → Check the following.
• Harness connectors (F51), (M64)
• "10A" fuse
• Harness continuity between ECM and ignition switch
If NG, repair harness or connectors.

OK

CHECK COMPONENT (ECM relay).
Refer to EF & EC-169.

NG → Replace ECM relay.

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158. Reconnect ECM harness connector and retest.

INSPECTION END




TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11

CAMSHAFT POSITION SENSOR (Diagnostic trouble code No. 11)







Harness layout



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES


Diagnostic Procedure For Trouble Code 11 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 11 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.



GI

MA

EM

LC

**EF &
EC**

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES


Diagnostic Procedure For Trouble Code 12

MASS AIR FLOW SENSOR (Diagnostic trouble code No. 12) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)




AEC347


Harness layout



AEC020



AEC028








AEC399

EF & EC-98

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 12 (Cont'd)




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 12 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.




TROUBLE DIAGNOSES



Diagnostic Procedure For Trouble Code 13

ENGINE COOLANT TEMPERATURE SENSOR (Diagnostic trouble code No. 13) (MALFUNCTION INDICATOR LAMP ITEM)

CHECK ENGINE







Harness layout




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 13 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.






TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 14

VEHICLE SPEED SENSOR (Diagnostic trouble code No. 14) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)



Harness layout



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 14 (Cont'd)

A ■ VEHICLE SPEED SEN CKT ■

AFTER TOUCH START,
DRIVE VEHICLE
AT 10 km/h (6 mph) OR
(MORE WITHIN 15 sec.)

NEXT START



SEF233M

A ☆ MONITOR ☆ NO FAIL

VHCL SPEED SE 10mph

RECORD


SEF234M



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 14 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX




TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21

IGNITION SIGNAL (Diagnostic trouble code No. 21)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21 (Cont'd)



INSPECTION START

A
CHECK POWER SUPPLY.
1) Disconnect ignition coil harness connector.
2) Turn ignition switch "ON".
3) Check voltage between terminal (a) and ground.
Voltage: Battery positive voltage

NG → Check the following.
• Harness connectors (F28), (E30)
• Harness continuity between ignition coil and ignition switch
If NG, repair harness or connectors.

OK →
B CHECK GROUND CIRCUIT.
1) Turn ignition switch "OFF".
2) Disconnect resistor and condenser harness connector.
3) Disconnect power transistor harness connector.
4) Check harness continuity between terminal (b) and (d), (i).
Continuity should exist.
C 5) Check harness continuity between terminal (h) and engine ground.
Continuity should exist.

NG → Repair harness or connectors.

OK →
D CHECK INPUT SIGNAL CIRCUIT.
1) Disconnect ECM harness connector.
2) Check harness continuity between terminal (c) and ECM terminal (3).
Continuity should exist.

NG → Repair harness or connectors.

OK →
E CHECK OUTPUT SIGNAL CIRCUIT.
1) Check harness continuity between terminal (g) and ECM terminal (1).
Continuity should exist.

NG → Repair harness or connectors.

OK →
CHECK COMPONENTS (Ignition coil, resistor and condenser, power transistor).
Refer to EF & EC-164, EF & EC-164, EF & EC-170.

NG → Replace malfunctioning component(s).

OK → Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158.
Reconnect ECM harness connector and retest.

GI
MA
EM
LG
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
DX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 21 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.




TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 31

ECM (ECCS CONTROL MODULE) (Diagnostic trouble code No. 31)
(MALFUNCTION INDICATOR LAMP ITEM)

CHECK
ENGINE



GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32

EGR FUNCTION (Diagnostic trouble code No. 32) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)



INSPECTION START

A

CHECK VACUUM SOURCE TO EGR VALVE.

- 1) Start engine and warm it up sufficiently.
- 2) Perform On-board Diagnostic Test Mode II (Self-diagnostic results). Make sure that diagnostic trouble code No. 12 is not displayed. Make sure that both camshaft position sensor and ECM's CPU are not in "fail-safe" state.
- 3) Keep engine speed at 2,000 rpm.
- 4) Disconnect vacuum hose to EGR valve.
- 5) Make sure that vacuum exists. **Vacuum should exist.**

OK → CHECK COMPONENTS (EGR valve, EGRC-BPT valve and EGR temperature sensor). Refer to EF & EC-165, 166.

NG

Replace malfunctioning component(s).

NG

B

CHECK CONTROL FUNCTION.

- 1) Check voltage between ECM terminal (102) and ground under the following conditions.

Voltage:

Engine speed is about 2,000 rpm
Battery positive voltage

Engine speed is about 4,000 rpm
0.8 - 0.9V

OK → **C**

CHECK VACUUM HOSE.

- 1) Check vacuum hose for clogging, cracks and proper connection.

NG

D

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect EGR control-solenoid valve harness connector.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal (a) and ground.

Voltage: Battery positive voltage

NG → Check the following.

- Harness connectors (F28, E30)
- Harness continuity between EGR control-solenoid valve and ignition switch

If NG, repair harness or connectors.

OK

E

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal (102) and terminal (b).

Continuity should exist.

NG → Repair harness or connectors.

OK

(A)

GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)

F

■ EGRC SOL/V CIRCUIT ■

DOES THE SOLENOID VALVE MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

MEF330C

F

■ ACTIVE TEST ■


EGRC SOL/V ON

=== MONITOR ===

CMPS•RPM (POS) 0rpm

ON ON/OFF OFF

AEC402



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 32 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.

G

ROAD TEST
Test condition

Drive vehicle under the following conditions with a suitable shift position.

- Engine speed: 2,150±450 rpm
- Intake manifold vacuum: -32.0±6.7 kPa (-240±50 mmHg, -9.45±1.97 inHg)

Driving mode


① Start engine and warm it up sufficiently.
② Turn off ignition switch and keep it off more than 10 seconds.
③ Start engine and make sure that air conditioning switch and rear defogger are turned "OFF" during driving test.
④ Keep engine running for at least 4 minutes.
⑤ Shift to suitable gear position and drive in "Test condition" for at least 21 seconds.
⑥ Decrease engine revolution to idle speed.
⑦ Repeat steps ⑤ through ⑥ at least 1 time.

AEC175

H

CHECK ENGINE

AEC015



GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX




TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 33

HEATED OXYGEN SENSOR (Diagnostic trouble code No. 33)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 33 (Cont'd)



INSPECTION START

Loosen and retighten ground screws.

A

CHECK HEATED OXYGEN SENSOR CIRCUIT.

- 1) Start engine and warm it up sufficiently.
- 2) Perform "MIXTURE RATIO TEST" in "FUNCTION TEST" mode with CONSULT.

OR

- 2) Make sure that "M/R F/C MNT" in "DATA MONITOR" mode indicates "RICH" and "LEAN" periodically more than 5 times during 10 seconds at 2,000 rpm.

OR

- 2) Run engine at about 2,000 rpm for about 2 minutes under no-load.
- 3) Set ECM diagnosis mode to On-board Diagnostic Test Mode II. Refer to EF & EC-38.
- 4) Keep engine speed at 2,000 rpm and make sure that malfunction indicator lamp goes on and off more than 5 times during 10 seconds.

OK INSPECTION END

NG

B

CHECK POWER SUPPLY.

- 1) Stop engine.
- 2) Disconnect heated oxygen sensor harness connector.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal (c) and ground.

Voltage: Battery positive voltage

NG

Check the following.

- Harness connectors (E44, M9)
- 10A fuse
- Harness continuity between heated oxygen sensor and fuse

If NG, repair harness or connectors.

OK

C

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect ECM harness connector.
- 3) Check harness continuity between ECM terminal (106) and terminal (a).

Continuity should exist.

NG

Check the following.

- Harness connectors (F2, E2)



If NG, repair harness or connectors.

OK


A

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 33 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.






TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 34

KNOCK SENSOR (Diagnostic trouble code No. 34)




Harness layout



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 34 (Cont'd)



INSPECTION START

Loosen and retighten ground screws.

A
CHECK INPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector and knock sensor sub-harness connector.
 2) Check harness continuity between terminal (a) and ECM terminal (27).
Continuity should exist.

NG → Repair harness or connectors.

OK
CHECK COMPONENT
 (Knock sensor).
 Refer to EF & EC-168.

NG → Replace knock sensor.

OK
 Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.
 Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158. Reconnect ECM harness connector and retest.

Perform FINAL CHECK by the following procedure after repair is completed.

FINAL CHECK

Erase the On-board Diagnostic Test Mode II (self-diagnostic results) memory. Refer to EF & EC-43.

Perform test drive.

Perform On-board Diagnostic Test Mode II (Self-diagnostic results) again. Refer to EF & EC-37.

NG → Recheck ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158.


OK
 INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35


EGR TEMPERATURE SENSOR (Diagnostic trouble code No. 35) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)

CI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX




AEC354

Harness layout






AEC020



AEC042

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Start engine and warm it up sufficiently.
- 2) Read EGR temperature sensor signal in "DATA MONITOR" mode with CONSULT.

Voltage:
Less than 4.5V (at idle)

OR

- 1) Disconnect EGR temperature sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal **(a)** and ground.

Voltage:
Approximately 5V

NG → Repair harness, connectors or check EGR temperature sensor.

NG → Check the following.

- Harness connectors **(F7, F102)**
- Harness continuity between ECM and EGR temperature sensor

If NG, repair harness or connectors.

B

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Check harness continuity between terminal **(b)** and engine ground.

Continuity should exist.

NG → Check the following.

- Harness connectors **(F7, F102)**
- Harness continuity between ECM and EGR temperature sensor

If NG, repair harness or connectors.

CHECK COMPONENT
(EGR temperature sensor).
Refer to EF & EC-166.

NG → Replace EGR temperature sensor.

OK → Disconnect and reconnect harness connectors in the circuit, and retest.


Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158. Reconnect ECM harness connector and retest.

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 35 (Cont'd)


Perform **FINAL CHECK** by the following procedure after repair is completed.






TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43

THROTTLE POSITION SENSOR (Diagnostic trouble code No. 43) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)








Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Disconnect throttle position sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal (c) and ground.

Voltage: Approximately 5V

NG → Repair harness or connectors.

B

CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Loosen and retighten ground screws.
- 3) Check harness continuity between terminal (a) and engine ground.

Continuity should exist.

NG → Repair harness or connectors.

C

CHECK INPUT SIGNAL CIRCUIT.

- 1) Reconnect throttle position sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Perform "THROTTLE POSI SEN CKT" in "FUNCTION TEST" mode with CONSULT.

NG → Repair harness or connectors.

OR

- 3) Read throttle position sensor output voltage in "WORK SUPPORT" mode with CONSULT.

Throttle valve fully closed:
0.4 - 0.5V

Smoothly and gradually increasing until throttle valve fully open:
Approx. 4.0V

OR

- 1) Disconnect ECM harness connector.
- 2) Check harness continuity between ECM terminal (20) and terminal (b).

Continuity should exist.

OK

CHECK COMPONENT
(Throttle position sensor).
Refer to EF & EC-166.

NG → Replace throttle position sensor.

OK

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158.
Reconnect ECM harness connector and retest.

GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
DX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 43 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.



A

■ ACTIVE TEST ■ □

SELF-LEARN CONTROL 100%

= = = MONITOR = = =

CMPS•RPM (POS) 800rpm
 COOLAN TEMP/S 88°C
 O2 SEN 1.17V
 A/F ALPHA 98%

CLEAR

AEC405

B

ROAD TEST

Test condition

Drive vehicle under the following conditions with suitable gear position.

- (1) Engine speed: 2550 ± 650 rpm
- (2) Intake manifold vacuum: -46.7 ± 6.7 kPa (-350 ± 50 mmHg, -13.78 ± 1.97 inHg)

Driving mode

Ⓐ: 13 minutes
 Ⓑ: 15 minutes at idle speed
 Ⓒ: 5 minutes at test condition
 Ⓓ: 2 minutes at idle speed

Until red LED goes off.


- ① Start engine and warm it up sufficiently.
- ② Turn off ignition switch and keep it off until red LED goes off.
- ③ Start engine and keep it running for 13 minutes.
- ④ Turn off ignition switch and keep it off until red LED goes off.
- ⑤ Repeat steps ③ through ④ a total of 3 times.
- ⑥ Start engine and keep it at idle speed for at least 15 minutes.
 If engine stalls or ignition is turned off within 13 minutes of engine starting, return to step ②. If after 13 minutes, restart step ⑥.
- ⑦ Shift to suitable gear position and drive in "Test condition" for at least 5 minutes.
 If the following conditions occur during step ⑦, return to step ⑥.
 - Engine races over 4,000 rpm or hardly accelerates for more than 10 seconds.
 - Engine stalls or ignition is turned off.
- ⑧ Keep engine at idle speed for more than 2 minutes.

AEC406

Diagnostic Procedure For Trouble Code 45

INJECTOR LEAK (Code No. 45)


(MALFUNCTION INDICATOR LAMP ITEM)




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 45 (Cont'd)




Perform FINAL CHECK by the following procedure after repair is completed.





TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 51

INJECTOR CIRCUIT (Diagnostic trouble code No. 51) CHECK ENGINE (MALFUNCTION INDICATOR LAMP ITEM)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 51 (Cont'd)



INSPECTION START

CHECK POWER SUPPLY.

- 1) Disconnect sub-harness connectors (F6), (F101) for No. 1, No. 3, No. 5 cylinders.
- A** 2) Check voltage between terminal (c) and ground.
Voltage: Battery positive voltage
- 3) Disconnect injector harness connectors for No. 2, No. 4, No. 6 cylinders.
- B** 4) Check voltage between terminal (a) and ground.
Voltage: Battery positive voltage
- 5) Turn ignition switch "ON".
- C** 6) Check voltage between ECM terminal (109) and ground.
Voltage: Battery positive voltage

NG

Check the following.

- Harness connectors (F28), (E30)
- Harness connectors (F1), (E1)
- 25A fusible link
- Harness continuity between battery and ECM
- Harness continuity between ECM relay and ECM

If NG, repair harness or connectors.

OK

CHECK OUTPUT SIGNAL CIRCUIT.

- 1) Turn ignition switch "OFF".
- D** 2) Check harness continuity between terminal (a) and ECM terminal (101), terminal (b) and ECM terminal (103), (e) and ECM terminal (105).
Continuity should exist.
- E** 3) Check harness continuity between terminal (b) and ECM terminals (110), (112), (114).
Continuity should exist.

NG

Repair harness and connectors.

OK

CHECK COMPONENT (Injector).
Refer to EF & EC-169.

NG

Replace injector. Refer to EF & EC-172.

OK

Disconnect and reconnect harness connectors in the circuit, and retest.



Trouble is not fixed.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158.
Reconnect ECM harness connector and retest.

TROUBLE DIAGNOSES

Diagnostic Procedure For Trouble Code 51 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.



GI

MA

EM

LC

**EF &
EC**

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES





Diagnostic Procedure 23

FUEL PUMP CONTROL (Not self-diagnostic item)







AEC369

Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 23 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF








HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 23 (Cont'd)



Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.


Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158. Reconnect ECM harness connector and retest.

INSPECTION END



TROUBLE DIAGNOSES

Diagnostic Procedure 24

CLOSED THROTTLE POSITION SWITCH (Not self-diagnostic item)







Harness layout



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 24 (Cont'd)



INSPECTION START

A

CHECK OVERALL FUNCTION.

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF".
- 3) Disconnect throttle position sensor harness connector.
- 4) Turn ignition switch "ON".
- 5) Perform "CLOSED THROTTLE POSI" in "FUNCTION TEST" mode with CONSULT.

OR

OK → INSPECTION END

5) Check closed throttle position switch signal in "DATA MONITOR" mode with CONSULT.

CLOSED TH/POS:
 Accelerator pedal is released ... ON
 Accelerator pedal is depressed .. OFF

OR

3) Turn ignition switch "ON".

4) Check voltage between ECM terminal ③ and ground under the following conditions.

Voltage:
 Accelerator pedal is released
 Approximately 8 - 10V
 Accelerator pedal is depressed
 Approximately 0V

NG

B

CHECK POWER SUPPLY.

- 1) Turn ignition switch "OFF".
- 2) Disconnect closed throttle position switch harness connector.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminal ② and ground.

Voltage:
 Approximately 8 - 10V



NG → Repair harness or connectors.

OK

Ⓐ

TROUBLE DIAGNOSES

Diagnostic Procedure 24 (Cont'd)




GI
VA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
DX



TROUBLE DIAGNOSES

Diagnostic Procedure 25

START SIGNAL (Not self-diagnostic item)



Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 25 (Cont'd)

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE. SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY.

NEXT START

SEF191L




A

☆ MONITOR ☆ NO FAIL

START SIGNAL OFF

RECORD

AEC445




GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES



Diagnostic Procedure 26

IAC VALVE-AIR REGULATOR (Not self-diagnostic item)







AEC359

Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)



CI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX




TROUBLE DIAGNOSES

Diagnostic Procedure 27

IAC VALVE-AAC VALVE (Not self-diagnostic item)









Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 27 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES




Diagnostic Procedure 28

IAC VALVE-FICD SOLENOID VALVE (Not self-diagnostic item) AND AIR CONDITIONING SYSTEM INPUT (Not self-diagnostic item)





AEC361

Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 28 (Cont'd)



IAC valve-FICD solenoid valve

INSPECTION START

CHECK OVERALL FUNCTION.

- 1) Start engine and warm it up sufficiently.
- 2) Check idle speed.
750 ± 50 rpm
If NG, adjust idle speed.
- 3) Turn both air conditioning switch and blower fan switch "ON", any mode except "OFF", ambient temperature above 10°C (50°F), then recheck idle speed.
800 ± 50 rpm

OK → INSPECTION END

NG → Check if air conditioning compressor functions normally.

NG → Refer to HA section.

OK → CHECK POWER SUPPLY.

- 1) Turn ignition switch "OFF".
- 2) Disconnect IAC relay-FICD relay.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ②, ⑤ and ground.
Voltage: Battery positive voltage

NG → Check the following.

- Harness connectors (E44), (M9)
- 10A fuse
- Harness continuity between fuse and IAC relay-FICD relay

If NG, repair harness or connectors.

OK → CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
- 2) Disconnect IAC valve-FICD solenoid valve harness connector.
- 3) Check harness continuity between terminal (b) and body ground, terminal (a) and terminal (3).
Continuity should exist.

NG → Check the following.

- Harness connectors (F52), (M65)
- Harness connectors (F7), (F102)
- Harness connectors (F1), (E1)
- Harness continuity between IAC valve-FICD solenoid valve and body ground
- Harness continuity between IAC valve-FICD solenoid valve and IAC relay-FICD relay

If NG, repair harness or connectors.

OK → A

CI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF



HA

EL

IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 28 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 28 (Cont'd)



Air conditioning (A/C) switch

INSPECTION START

D CHECK OVERALL FUNCTION.

1) Start engine.
2) Check A/C switch signal in "DATA MONITOR" mode with CONSULT.

With air conditioning switch "ON" and fan switch in any position and any mode except "OFF", ambient temperature above 10°C (50°F):
ON

With air conditioning switch "OFF":
OFF

OR

1) Start engine.
2) Check voltage between ECM terminal ④1 and ground.

Voltage:
With air conditioning switch "ON" and fan switch in any position and any mode except "OFF", ambient temperature above 10°C (50°F)
Less than 2.3V

With air conditioning switch "OFF"
Battery positive voltage

NG Check harness continuity between A/C system and ECM terminal ④1. Refer to HA section. If NG, repair harness or connectors.

OK


INSPECTION END

GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX





TROUBLE DIAGNOSES

Diagnostic Procedure 29

COOLING FAN CONTROL (Not self-diagnostic item)




Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



Cooling fan


INSPECTION START



A CHECK COOLING FAN LOW SPEED OPERATION.

- 1) Start engine.
- 2) Keep engine speed at about 2,000 rpm until engine is warmed up sufficiently.
- 3) Make sure that cooling fan begins to operate at low speed during warm-up.

NG → Check cooling fan low speed control circuit. (Go to **PROCEDURE A**.) Refer to EF & EC-153.



OK ↓

A CHECK COOLING FAN HIGH SPEED OPERATION.

- 1) Stop engine.
- B** 2) Disconnect radiator fan relay-LO and cooling fan relay-H1.
- 3) Disconnect engine coolant temperature sensor harness connector.
- 4) Connect 150 Ω resistor to engine coolant temperature sensor harness connector.
- 5) Restart engine. Make sure that cooling fan operates at high speed.
- 6) Stop engine.
- C** 7) Reconnect cooling fan relay-H1 and disconnect cooling fan relay-H2.
- 8) Restart engine. Make sure that cooling fan operates at high speed.

NG → Check cooling fan high speed control circuit. (Go to **PROCEDURE B**.) Refer to EF & EC-150.

OK ↓

INSPECTION END

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF




HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



PROCEDURE A

INSPECTION START

D
CHECK POWER SUPPLY.
 1) Stop engine.
 2) Disconnect cooling fan relay-LO.
 3) Turn ignition switch "ON".
 4) Check voltage between terminals ②, ③ and ground.
Voltage: Battery positive voltage

NG → Check the following.
 • Harness connectors
 E44, M9
 • 10A fuse
 • 65A fusible link
 • 120A fusible link
 • Harness continuity between cooling fan relay-LO and fuse
 • Harness continuity between cooling fan relay-LO and battery
 If NG, repair harness or connectors.

OK ↓

E
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Disconnect cooling fan motor harness connectors.
 3) Check harness continuity between terminal ⑤ and terminal ⑥, terminal ⑦ and body ground.
Continuity should exist.

NG → Repair harness or connectors.

OK ↓

F
CHECK OUTPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector.
 2) Check harness continuity between ECM terminal ⑨ and terminal ①.
Continuity should exist.

NG → Check the following.
 • Harness connectors
 F1, E1
 • Harness continuity between cooling fan relay-LO and ECM
 If NG, repair harness or connectors.

OK ↓



CHECK COMPONENT
 (Cooling fan relay-LO).
 Refer to EF & EC-169.

NG → Replace cooling fan relay-LO.

OK ↓
 (A)

TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR

ST

BF




HA

EL

IDX

TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



PROCEDURE B

INSPECTION START

H

CHECK POWER SUPPLY 1.

- 1) Stop engine.
- 2) Disconnect radiator fan relay-H1.
- 3) Turn ignition switch "ON".
- 4) Check voltage between terminals ②, ③ and ground.

Voltage: Battery positive voltage

NG

Check the following.

- Harness continuity between cooling fan relay-H1 and harness connector (E44)
- Harness continuity between cooling fan relay-H1 and fusible link (E27)

If NG, repair harness or connectors.

OK

I

CHECK POWER SUPPLY 2.

- 1) Turn ignition switch "OFF".
- 2) Disconnect cooling fan relay-H2.
- 3) Check harness continuity between terminals ② and terminal ②, terminal ③ and terminal ③.

Continuity should exist.

NG

Repair harness or connectors.

OK

J

CHECK GROUND CIRCUIT 1.

- 1) Disconnect cooling fan motor harness connectors.
- 2) Check harness continuity between terminal (a) and cooling fan relay-H1 terminal (5).

Continuity should exist.

NG





Repair harness or connectors.

OK

➔ (A)

TROUBLE DIAGNOSES



Diagnostic Procedure 29 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 29 (Cont'd)



High pressure switch-2 box

INSPECTION START

O
CHECK GROUND CIRCUIT.
 1) Disconnect high pressure switch-2 harness connector.
 2) Check harness continuity between terminal (b) and engine ground.
Continuity should exist.

NG → Repair harness or connectors.

P
CHECK INPUT SIGNAL CIRCUIT.
 1) Disconnect ECM harness connector.
 2) Check harness continuity between ECM terminal (45) and terminal (d).
Continuity should exist.

NG → Repair harness or connectors.

CHECK COMPONENT
 (High pressure switch-2).
 Refer to EF & EC-170.

NG → Replace high pressure switch.

Check ECM pin terminals for damage or the connection of ECM harness connector. Refer to EF & EC-158.


INSPECTION END

G
 MA
 EM
 LC
EF & EC
 FE
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 DX



TROUBLE DIAGNOSES

Diagnostic Procedure 30

POWER STEERING PRESSURE SWITCH (Not self-diagnostic item)







Harness layout



TROUBLE DIAGNOSES

Diagnostic Procedure 30 (Cont'd)



INSPECTION START

A

CHECK CONTROL FUNCTION.

- 1) Start engine and warm it up sufficiently.
- 2) Check power steering pressure switch signal in "DATA MONITOR" mode with CONSULT.

Steering is neutral: OFF
Steering is turned: ON

OR

2) Check voltage between ECM terminal ⑫ and ground.

Voltage:
When steering wheel is turned quickly.
Approximately 0V
Except above
Approximately 5V

B

CHECK GROUND CIRCUIT.

- 1) Stop engine.
- 2) Disconnect power steering pressure switch harness connector.
- 3) Check harness continuity between terminal ⑬ and engine ground.

Continuity should exist.

C

CHECK INPUT SIGNAL CIRCUIT.

- 1) Disconnect ECM harness connector.
- 2) Check harness continuity between ECM terminal ⑫ and terminal ①.

Continuity should exist.

CHECK COMPONENT (Power steering pressure switch). Refer to EF & EC-170.

Disconnect and reconnect harness connectors in the circuit, and retest.

Trouble is not fixed.

Check ECM pin terminals for damage or the connection of the ECM harness connector. Refer to EF & EC-158. Reconnect ECM harness connector and retest.

INSPECTION END

OK → INSPECTION END

NG →

NG → Repair harness or connectors.

NG → Repair harness or connectors.

NG → Replace power steering pressure switch.

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX



TROUBLE DIAGNOSES

Diagnostic Procedure 31

A/T CONTROL UNIT (NEUTRAL SIGNAL) CIRCUIT (Not self-diagnostic item)








Harness layout






TROUBLE DIAGNOSES

Diagnostic Procedure 31 (Cont'd)



GI
MA
EM
LC
EF & EC
FE
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TROUBLE DIAGNOSES



Electrical Components Inspection

ECM INPUT/OUTPUT SIGNAL INSPECTION

- ECM is located behind the glove box. For this inspection:
 - Remove glove box bucket.
 - Remove lower finisher panel by reaching through the glove box and releasing the spring clips.
- Remove ECM harness protector.
- Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.

ECM HARNESS CONNECTOR TERMINAL LAYOUT

101	102	103	104	105	106	107	108	1	2	3	4	5	6	7	15	16	17	18	19	20	21	22	31	32	33	34	36	36	37	38	39
109	110	112	113	114	116	8	9	10	11	12	13	14	23	24	27	28	29	30	40	41	44	45	46	47	48						



AEC431

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

ECM Inspection table

TERMI- NAL NO.	ITEM	CONDITION	DATA	CI MA EM LC EF & EC FE AT FA RA BR ST BF HA EL IDX
1	Ignition signal	Engine is running. └ Idle speed	0.4 - 0.6V	
		Engine is running. └ Engine speed is 2,000 rpm.	1.1 - 1.3V	
2	Tachometer	Engine is running. └ Idle speed	Approximately 1.0V	
		Engine is running. └ Engine speed is 2,000 rpm.	3.2 - 3.6V	
3	Ignition check	Engine is running. └ Idle speed	9 - 12V	
4	ECM power source (Self-shutoff)	Engine is running. └ Idle speed	0 - 1V	
		Engine is running. └ For a few seconds after turning ignition switch "OFF"	BATTERY POSITIVE VOLTAGE (11 - 14V)	
8	EGR temperature sensor	Engine is running. (Warm-up condition) └ Idle speed	1.0V or more	
		Engine is running. (Warm-up condition) └ EGR system is operating.	0 - 1.0V	
9	Cooling fan (Low speed)	Engine is running. └ Cooling fan is not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	
		Engine is running. └ Cooling fan is operating at low speed.	0.7 - 0.8V	
10	Cooling fan (High speed)	Engine is running. └ Cooling fan is not operating.	BATTERY POSITIVE VOLTAGE (11 - 14V)	
		Engine is running. └ Cooling fan is operating at high speed.	0.7 - 0.8V	
11	Air conditioning relay	Engine is running. └ Both A/C switch and blower switch are "ON". (1)	Approximately 0V	
		Engine is running. └ A/C switch is "OFF".	BATTERY POSITIVE VOLTAGE (11 - 14V)	

(1) Any mode except "OFF", ambient temperature above 10°C (50°F).

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

TERMI- NAL NO.	ITEM	CONDITION	DATA
12	Power steering pressure switch	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Steering wheel is being turned.	Approximately 0V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Steering wheel is not being turned.	Approximately 5V
16	Mass air flow sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div>	1.0 - 3.0V Voltage varies with engine speed.
18	Engine coolant temperature sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div>	0 - 5.0V Voltage varies with engine coolant temperature
19	Heated oxygen sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ After warming up sufficiently	0 - Approximately 1.0V
20	Throttle position sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	0.4 - Approximately 4V Voltage varies with the throttle valve opening angle.
22 30	Crankshaft position sensor (Reference signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> Do not run engine at high speed under no-load.	0.2 - 0.5V
27	Knock sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	Approximately 2.5V
28	Throttle opening signal	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	0.3 - Approximately 3V Voltage varies with the throttle valve opening angle
31 40	Crankshaft position sensor (Position signal)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> Do not run engine at high speed under no-load.	2.0 - 3.0V
32	Vehicle speed sensor	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Engine stopped and gear position is "Neutral". └ While rotating front wheel by hand	Varies from 0 to 5V
33	Closed throttle position switch (Idle position)	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Throttle valve: Idle position	Approximately 8 - 10V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Throttle valve: Any position except idle position	0V
34	Start signal	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "START"</div>	8 - 12V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div>	Approximately 0V

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

TERMI- NAL NO.	ITEM	CONDITION	DATA	CI
35	A/T control unit (Park/neutral position)	Ignition switch "ON" └ Neutral/Parking	0V	MA
		Ignition switch "ON" └ Except the above gear position	4 - 6V	EM
36	Ignition switch	Ignition switch "OFF"	0V	LC
		Ignition switch "ON"	BATTERY POSITIVE VOLTAGE (11 - 14V)	EF & EC
37	Power source for sensors	Ignition switch "ON"	Approximately 5V	FE
38 47	Power supply for ECM	Ignition switch "ON"	BATTERY POSITIVE VOLTAGE	AT
41	Air conditioning signal	Engine is running. └ Both air conditioning switch and blower switch are "ON".	2.0 - 2.5V	FA
		Engine is running. └ Air conditioning switch is "OFF".	BATTERY POSITIVE VOLTAGE (11 - 14V)	RA
44	Power source for closed throttle position switch	Ignition switch "ON" └ Throttle valve: Idle position	Approximately 8 - 9V	BR
		Ignition switch "ON" └ Throttle valve: Except idle position	BATTERY POSITIVE VOLTAGE (11 - 14V)	ST
46	Power supply (Back-up)	Ignition switch "OFF"	BATTERY POSITIVE VOLTAGE (11 - 14V)	BF
101	Injector No. 1	Engine is running.	BATTERY POSITIVE VOLTAGE (11 - 14V)	HA
103	Injector No. 3			
105	Injector No. 5			
110	Injector No. 2			
112	Injector No. 4			
114	Injector No. 6			EL
102	EGR control-solenoid valve	Engine is running. (Warm-up condition) └ Engine speed is below 3,200 rpm.	BATTERY POSITIVE VOLTAGE (11 - 14V)	IDX
		Engine is running. (Warm-up condition) └ Engine speed is above 3,200 rpm.	0.8 - 0.9V	


TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

TERMI- NAL NO.	ITEM	CONDITION	DATA
104	Fuel pump relay	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ For 5 seconds after turning ignition switch "ON"	0.7 - 0.9V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div>	
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Ignition switch "ON"</div> └ Within 5 seconds after turning ignition switch "ON"	BATTERY POSITIVE VOLTAGE (11 - 14V)
113	IAC valve-AAC valve	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Idle speed	8 - 11V
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">Engine is running.</div> └ Steering wheel is being turned. └ Air conditioning is operating. └ Rear defogger is "ON". └ Headlamps are in high position.	4 - 7V

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd) CAMSHAFT POSITION SENSOR



1. Remove distributor from engine. (Camshaft position sensor harness connector should remain connected.)
2. Turn ignition switch "ON".
3. Rotate distributor shaft slowly by hand and check voltage between terminals ③, ④ and ground.

Terminal	Voltage
③ (120° signal)	Tester's pointer fluctuates between 5V and 0V.
④ (1° signal)	

If NG, replace distributor assembly with camshaft position sensor.

GF

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR


ST

BF


HA

EL

IDX




4. Visually check signal plate for damage or dust.



MASS AIR FLOW SENSOR

1. Peel mass air flow sensor harness connector rubber if the harness connector is connected.
2. Turn ignition switch "ON".
3. Start engine and warm it up sufficiently.
4. Check voltage between terminal ① and ground.


Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 0.5
Idle (Engine is warm-up sufficiently.)	Approximately 1.0 - 1.7



5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd) ENGINE COOLANT TEMPERATURE (ECT) SENSOR




1. Disconnect engine coolant temperature sensor harness connector.
2. Check resistance as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
80 (176)	0.30 - 0.33

If NG, replace engine coolant temperature sensor.

IGNITION COIL




1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.

Terminal	Resistance
① - ②	Approximately 1.0Ω
① - ③	Approximately 10 kΩ

If NG, replace ignition coil.

POWER TRANSISTOR



1. Disconnect power transistor harness connector.
 2. Check power transistor continuity between terminals with a digital tester as shown in the figure.
- The digital tester must have a diode check position to perform this test.

⊕ Terminal side	⊖ Terminal side					
	Terminal (a)		Terminal (b)		Terminal (c)	
	Resistance Ω	Result	Resistance Ω	Result	Resistance Ω	Result
Terminal (a)	—	—	∞	OK	∞	OK
	—	—	Not ∞ or 0	NG	Not ∞ or 0	NG
	—	—	0	NG	0	NG
Terminal (b)	∞	NG	—	—	∞	NG
	Not ∞ or 0	OK	—	—	Not ∞ or 0	OK
	0	NG	—	—	0	NG
Terminal (c)	∞	NG	∞	NG	—	—
	Not ∞ or 0	OK	Not ∞ or 0	OK	—	—
	0	NG	0	NG	—	—


∞: Infinity resistance

If NG, replace power transistor.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)


FUEL PUMP



1. Disconnect fuel pump harness connector.
2. Check resistance between terminals (a) and (b).
Resistance: Approximately 0.7Ω
If NG, replace fuel pump.

GI
MA
EM
LC

EGR CONTROL-SOLENOID VALVE AND PRESSURE REGULATOR CONTROL SOLENOID VALVE




1. Disconnect EGR control-solenoid valve harness connector.
2. Check solenoid valve, following the table as shown below:

Conditions	Air passage continuity between (A) and (B)	Air passage continuity between (B) and (C)
Supply 12V direct current between terminals (1) and (2)	Yes	No
No current supply	No	Yes

EF & EC
FE
AT
FA

If NG, replace EGR control-solenoid valve.

RA
BR
ST




INERTIA FUEL SHUTOFF SWITCH

1. Disconnect inertia fuel shutoff switch harness connector.
2. Check inertia fuel shutoff switch, following the table as shown below:

Conditions	Continuity between terminals (a) and (b)
Switch open (tripped)	No
Switch closed (set)	Yes

BF
HA
EL
IDX

EGR VALVE




- Apply vacuum to EGR vacuum port with a hand vacuum pump.
EGR valve spring should lift.
If NG, replace EGR valve.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

EGRC-BPT VALVE

Plug one of two ports of EGRC-BPT valve.
Apply a pressure above 0.490 kPa (50 mmH₂O, 1.97 inH₂O) to check for leakage. If a leak is noted, replace valve.



EGR TEMPERATURE SENSOR


Check resistance change and resistance value at 100°C (212°F).

- Resistance should decrease in response to temperature increase.

Resistance: 100°C (212°F)

85.3±8.53 kΩ

If NG, replace EGR temperature sensor.




THROTTLE POSITION (TP) SENSOR

- Disconnect throttle position sensor harness connector.
- Make sure that resistance between terminals (b) and (c) changes when opening throttle valve manually.

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
While moving	(smoothly) 1 - 9
Completely depressed	Approximately 9

If NG, replace throttle position sensor, adjust as instructed below.




CLOSED THROTTLE POSITION SWITCH

- Disconnect closed throttle position switch harness connector.
- Check continuity between terminals (a) and (b).

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

If NG, replace closed throttle position switch, adjust as instructed below.



TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd) ADJUSTMENT FOR THROTTLE POSITION (TP) SENSOR AND CLOSED THROTTLE POSITION SWITCH

If throttle position sensor or closed throttle position switch is replaced or removed, it is necessary to install it in the proper position, by the procedure below:

1. Install throttle position sensor on throttle body. Do not tighten bolts. Leave bolts loose.
2. Connect throttle position sensor and closed throttle position switch harness connectors.
3. Start engine and warm it up sufficiently.
4. Disconnect closed throttle position switch harness connector and IAC valve-AAC valve sub-harness connector.
5. Check closed throttle position switch "OFF" → "ON" speed with circuit tester, closing throttle valve manually.

Closed throttle position switch OFF → ON speed:
Idle speed $\begin{matrix} +400 \\ +100 \end{matrix}$ rpm in "N" position.

GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR


ST

BF

HA

EL

IDX




IAC VALVE-AAC VALVE

1. Disconnect IAC valve-AAC valve sub-harness connector **(F106)**.
2. Check IAC valve-AAC valve resistance at sub-harness connector.

Resistance:

Approximately 10Ω


- If NG check resistance of IAC valve-AAC valve and sub-harness separately.



- Check IAC valve-AAC valve resistance.

Resistance:

Approximately 10Ω





- Check plunger for seizing or sticking.
- Check for broken spring.

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

IAC VALVE-FICD SOLENOID VALVE


- Check for clicking sound when applying 12V direct current to terminals.



- Check plunger for seizing or sticking.
- Check for broken spring.

IAC VALVE-AIR REGULATOR

- Check IAC valve-air regulator resistance.
Resistance:
Approximately 70 - 80Ω
- Check IAC valve-air regulator for clogging.



KNOCK SENSOR


1. Disconnect knock sensor sub-harness connector (F102).
2. Check continuity between terminal ③ and ground.

Continuity should exist.

- It is necessary to use an ohmmeter which can measure more than 10 MΩ.

CAUTION:

Discard any knock sensor which has been dropped or undergone shocks; use a new one.



TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

FUEL INJECTOR

No. 2, No. 4 and No. 6 cylinders

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: 10 - 14Ω

If NG, replace injector.

No. 1, No. 3 and No. 5 cylinders



1. Disconnect sub-harness connector (F101) for injectors.
2. Check resistance between terminals, following the table as shown below:

Cylinder	Terminal No.	Resistance
No. 1	(a) - (c)	10 - 14Ω
No. 3	(a) - (b)	
No. 5	(a) - (e)	

If NG, replace injector.

HEATED OXYGEN SENSOR (HO2S)

Perform "Diagnostic Procedure For Trouble Code 33".
Refer to EF & EC-114.



ECM RELAY, FUEL PUMP RELAY, AIR CONDITIONING RELAY, IAC RELAY-FICD RELAY AND COOLING FAN RELAYS

Check continuity between terminals (3) and (5).


Conditions	Continuity between terminals (3) and (5)
12V (fused) direct current supply between terminals (1) and (2)	Yes
No current supply	No

If NG, replace relay.

TROUBLE DIAGNOSES


Electrical Components Inspection (Cont'd)

RESISTOR



1. Disconnect resistor harness connector.
2. Check resistance between terminal (a) and (b).
Resistance: Approximately 2.2kΩ
If NG, replace resistor.

POWER STEERING PRESSURE (PSP) SWITCH




1. Disconnect power steering pressure switch harness connector.
2. Start engine.
3. Check continuity between terminals (a) and (b).

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

If NG, replace power steering pressure switch.


HIGH PRESSURE SWITCH-2

Check continuity between terminals (b) and (d).



High-pressure side line pressure	kPa (kg/cm ² , psi)	Operation	Continuity
Increasing to	2,246 (22.9, 326)	Fan OFF	Does not exist
Decreasing to	1,824 (18.6, 264)	Fan ON	Exists

COOLING FAN MOTOR



1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery positive voltage and check operation.


	Speed	Terminals	
		(⊕)	(⊖)
Cooling fan motor	Low	(a)	(c)
	High	(b)	(d)

Cooling fan motor should operate.

If NG, replace cooling fan motor.

MULTIPOINT FUEL INJECTION (MFI) SYSTEM INSPECTION

INJECTION (MFI) SYSTEM INSPECTION



Releasing Fuel Pressure

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.



1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR


ST

BF


HA

EL

IDX



1. Remove fuel pump fuse.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



Fuel Pressure Check


- a. When reconnecting fuel line, always use new clamps.
- b. Make sure that clamp screw does not contact adjacent parts.
- c. Use a torque driver to tighten clamps.
- d. Use Pressure Gauge to check fuel pressure.
- e. Do not perform fuel pressure check while fuel pressure regulator control system is operating; otherwise, fuel pressure gauge might indicate incorrect readings.

1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.

MULTIPOINT FUEL INJECTION (MFI) SYSTEM INSPECTION

INJECTION (MFI) SYSTEM INSPECTION

Fuel Pressure Check (Cont'd)



5. Read the indication of fuel pressure gauge.

At idling:

When fuel pressure regulator valve vacuum hose is connected.

Approximately 235 kPa
(2.4 kg/cm², 34 psi)


When fuel pressure regulator valve vacuum hose is disconnected.

Approximately 294 kPa
(3.0 kg/cm², 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check.

Fuel Pressure Regulator Check


1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a rubber cap.
3. Connect variable vacuum source to fuel pressure regulator.



4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.

MULTIPOINT FUEL INJECTION (MFI) SYSTEM INSPECTION



Injector Removal

1. Release fuel pressure to zero.
2. Separate ASCD and accelerator control wire from intake manifold collector.
3. Remove intake manifold collector from engine.

The following parts should be disconnected or removed.

- (1) Harness connectors for
 - IAC valve-AAC valve
 - IAC valve-FICD solenoid valve
 - Closed throttle position switch
 - Throttle position sensor
 - IAC valve-air regulator
 - EGR control-solenoid valve
 - EGR temperature sensor
 - Ground harness
- (2) PCV hoses
- (3) Vacuum hoses for
 - Master brake cylinder
 - EGR control-solenoid valve
 - Fuel pressure regulator
 - Carbon canister
 - EGRC-BPT valve
- (4) Air hoses from
 - Air duct
 - IAC valve-AAC valve
 - IAC valve-air regulator
- (5) Water hoses for
 - Throttle body
 - Air relief plug
- (6) Carbon canister purge hose
- (7) EGR flare tube

GI

MA

EM

LC

EF &
EC

FE

AT

FA

RA

BR


ST

BF


HA

EL

IDX



4. Remove injector fuel tube assembly.
- The following parts should be disconnected or removed.
- Vacuum hose for fuel pressure regulator
 - Fuel feed and return hose
 - All injectors harness connectors




5. Remove any malfunctioning injector from injector fuel tube.
 6. Replace or clean injector as necessary.
- Always replace O-rings and insulators with new ones.**
7. Connect injector to injector fuel tube.
 8. Reinstall any part removed in reverse order of removal.

CAUTION:

After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage.

EVAPORATIVE EMISSION (EVAP) SYSTEM

Description




The evaporative emission (EVAP) system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the carbon canister.

The fuel vapor from the sealed fuel tank is led into the canister which contains activated carbon and the vapor is stored there when the engine is not running.

The canister retains the fuel vapor until the canister is purged by the air drawn through the bottom of the canister to the intake manifold when the engine is running. When the engine runs at idle, the purge control valve is closed.

Only a small amount of stored vapor flows into the intake manifold through the constant purge orifice. As the engine speed increases, and the throttle vacuum rises higher, the purge control valve opens and the vapor is sucked into the intake manifold through both the main purge orifice and the constant purge orifice.



Inspection

CARBON CANISTER


Check carbon canister as follows:

1. Blow air in port **(A)** and ensure that there is no leakage.
2. ● Apply vacuum to port **(A)**.
● Cover port **(D)** with hand.
● Blow air in port **(C)** and ensure free flow out of port **(B)**.

EVAPORATIVE EMISSION (EVAP) SYSTEM

Inspection (Cont'd)

FUEL TANK VACUUM RELIEF VALVE



1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air through fuel tank side to ensure continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR


ST

BF

HA

EL

IDX




FUEL CHECK VALVE (With rollover valve)

1. Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow should be directed toward the canister side.
2. Blow air through connector on canister side. Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

Rollover valve operation

Ensure that continuity of air passage does not exist when the installed rollover valve is tilted to 90° or 180°.

CRANKCASE EMISSION CONTROL SYSTEM



Description

This system returns blow-by gas to both the intake manifold and air inlet tubes.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.



During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes, through the hose connecting air inlet tubes to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by some of the flow will go through the hose connection to the air inlet tubes under all conditions.



Inspection

PCV (Positive Crankcase Ventilation)

With engine running at idle, remove ventilation hose from PCV valve; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

PRESSURE REGULATOR Regulated pressure kPa (kg/cm ² , psi)	
Vacuum hose is connected	235 (2.4, 34)
Vacuum hose is disconnected	294 (3.0, 43)

Inspection and Adjustment

idle speed*1	rpm	
No-load*2 (in "N" position)		750±50 (700)*3
Air conditioning: ON (in "N" position)		800±50
Ignition timing	degree	15°±2° BTDC
Closed throttle position switch touch speed ("OFF" to "ON") rpm (in "N" position)		Idle speed + 400 *3 + 100

*1: Feedback controlled and needs no adjustments

*2: Under the following conditions:

- Air conditioning switch: OFF
- Steering wheel: Kept straight
- Electric load: OFF (Lights, heater, fan & rear defogger)

*3: (): Disconnect IAC valve-AAC valve sub-harness connector.

IGNITION COIL

Primary voltage	V	12
Primary resistance [at 20°C (68°F)]	Ω	Approximately 1.0
Secondary resistance [at 20°C (68°F)]	kΩ	Approximately 10

MASS AIR FLOW SENSOR

Supply voltage	V	Battery positive voltage (11 - 14)
Output voltage	V	Approximately 1.0 - 1.7*

*: Engine is warmed up sufficiently and idling under no-load.

ENGINE COOLANT TEMPERATURE SENSOR

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
80 (176)	0.30 - 0.33

FUEL PUMP

Resistance	Ω	Approximately 0.7
------------	---	-------------------

EGR TEMPERATURE SENSOR

Resistance [at 100°C (212°F)]	kΩ	85.3±8.53
----------------------------------	----	-----------

IAC VALVE-AAC VALVE

Resistance	Ω	Approximately 10.0
------------	---	--------------------

INJECTOR

Resistance	Ω	10 - 14
------------	---	---------

RESISTOR

Resistance	kΩ	Approximately 2.2
------------	----	-------------------

THROTTLE POSITION SENSOR

Accelerator pedal conditions	Resistance kΩ
Completely released	Approximately 1
Partially released	1 - 9
Completely depressed	Approximately 9

IGNITION WIRE

Resistance	kΩ/m (kΩ/ft)	Less than 30 (9.1)
------------	--------------	--------------------