

SECTION **RSU**  
 REAR SUSPENSION

A  
B  
C  
D

RSU

CONTENTS

<b>PRECAUTIONS</b> .....	<b>2</b>	<b>INSTALLATION</b> .....	<b>12</b>	<b>F</b>
Precautions .....	2	Inspection .....	12	
<b>PREPARATION</b> .....	<b>3</b>	<b>RADIUS ROD</b> .....	<b>13</b>	<b>G</b>
Special Service Tools .....	3	Removal and Installation .....	13	
Commercial Service Tools .....	3	REMOVAL .....	13	
<b>NOISE, VIBRATION, AND HARSHNESS (NVH)</b>		INSTALLATION .....	13	
<b>TROUBLESHOOTING</b> .....	<b>4</b>	Inspection .....	13	<b>H</b>
NVH Troubleshooting Chart .....	4	<b>FRONT LOWER LINK</b> .....	<b>14</b>	
<b>REAR SUSPENSION ASSEMBLY</b> .....	<b>5</b>	Removal and Installation .....	14	
Components .....	5	REMOVAL .....	14	
On-vehicle Service .....	6	INSTALLATION .....	14	<b>I</b>
Rear Wheel Alignment .....	6	Inspection .....	14	
PRELIMINARY INSPECTION .....	6	<b>REAR LOWER LINK AND COIL SPRING</b> .....	<b>15</b>	<b>J</b>
CAMBER .....	6	Removal and Installation .....	15	
TOE-IN .....	7	REMOVAL .....	15	
<b>REAR SUSPENSION MEMBER</b> .....	<b>9</b>	INSTALLATION .....	15	
Removal and Installation .....	9	Inspection .....	16	<b>K</b>
REMOVAL .....	10	<b>STABILIZER BAR</b> .....	<b>17</b>	
INSTALLATION .....	10	Removal and Installation .....	17	
<b>SHOCK ABSORBER</b> .....	<b>11</b>	REMOVAL .....	17	
Removal and Installation .....	11	INSTALLATION .....	17	<b>L</b>
REMOVAL .....	11	Inspection .....	17	
INSTALLATION .....	11	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>18</b>	<b>M</b>
Inspection .....	11	General Specifications (Rear) .....	18	
<b>SUSPENSION ARM</b> .....	<b>12</b>	Rear Wheel Alignment (Unladen*) .....	18	
Removal and Installation .....	12	Ball Joint .....	18	
REMOVAL .....	12	Wheelarch Height (Unladen*) .....	19	

# PRECAUTIONS


## PRECAUTIONS

PFP:00001

### Precautions

EES00009

- When installing each rubber part, final tightening must be carried out under unladen condition\* with tires on ground. Oil will shorten the life of rubber bushings. Be sure to wipe off any spilled oil.  
\*: Fuel, engine coolant, and engine oil are full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment.
- Do not jack up at the trailing arm and lateral link.
- Always torque brake lines when installing.
- Lock nuts are not reusable parts; always use new ones. When replacing, do not wipe the oil off of the new lock nut before tightening.



# PREPARATION

## PREPARATION


PFP:00002

### Special Service Tools

EES0016T

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
HT72520000 (J-25730-A) Ball joint remover	Removing suspension arm ball joint




NT146


### Commercial Service Tools

EES0000A

Tool name	Description
1. Flare nut crowfoot 2. Torque wrench	Removing and installing brake piping <b>a: 10 mm (0.39 in)</b>
Power tool	Loosening bolts and nuts



S-NT360



PBIC0190E

A  
B  
C  
D  
RSU  
F  
G  
H  
I  
J  
K  
L  
M

# NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

## NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PF0:00003

### NVH Troubleshooting Chart

EES0000B

Use the following chart to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page			<a href="#">RSU-5</a>	<a href="#">RSU-11</a>	<a href="#">RSU-5</a>	<a href="#">RSU-5</a>	<a href="#">RSU-16</a>	<a href="#">RSU-5</a>	<a href="#">RSU-6</a>	<a href="#">RSU-17</a>	<a href="#">FAX-4, "NVH Troubleshooting Chart"</a>	<a href="#">RAX-4, "NVH Troubleshooting Chart"</a>	<a href="#">WT-3, "NVH Troubleshooting Chart"</a>	<a href="#">WT-3, "NVH Troubleshooting Chart"</a>	<a href="#">BR-5, "NVH Troubleshooting Chart"</a>	<a href="#">PS-5, "NVH Troubleshooting Chart"</a>
Possible cause and SUSPECTED PARTS			Improper installation, looseness	Shock absorber deformation, damage or deflection	Bushing or mounting	Parts interference	Spring fatigue	Suspension looseness	Incorrect wheel alignment	Stabilizer bar fatigue	DRIVE SHAFT	AXLE	TIRES	ROAD WHEEL	BRAKES	STEERING
Symptom	Noise	x	x	x	x	x	x	x			x	x	x	x	x	x
	Shake	x	x	x	x			x			x	x	x	x	x	x
	Vibration	x	x	x	x	x					x	x	x			x
	Shimmy	x	x	x	x				x			x	x	x	x	x
	Shudder	x	x	x								x	x	x	x	x
	Poor quality ride or handling	x	x	x	x	x			x	x		x	x	x		

x: Applicable

# REAR SUSPENSION ASSEMBLY


## REAR SUSPENSION ASSEMBLY

### Components

PFP:55020

EES0000C

A  
B  
C  
D  
RSU  
F  
G  
H  
I  
J  
K  
L  
M



WEIA0110E


# REAR SUSPENSION ASSEMBLY

- |                           |                          |                                    |
|---------------------------|--------------------------|------------------------------------|
| 1. Rear suspension member | 2. Stabilizer bar        | 3. Stabilizer bar bushing          |
| 4. Stabilizer bar clamp   | 5. Connecting rod        | 6. Member stay                     |
| 7. Member stopper         | 8. Radius rod            | 9. Adjusting bolt cam              |
| 10. Front lower link      | 11. Bushing              | 12. Wheel hub and spindle assembly |
| 13. Rear lower link       | 14. Suspension arm       | 15. Lower rubber seat              |
| 16. Coil spring           | 17. Upper rubber seat    | 18. Shock absorber                 |
| 19. Bound bumper cover    | 20. Bound bumper         | 21. Lower bushing                  |
| 22. Upper bracket         | 23. Upper bracket sleeve | 24. Gasket                         |
| 25. Upper bushing         | 26. Washer               |                                    |

## On-vehicle Service

EES0000D

- Check suspension parts for excessive play, cracks, wear or damage. Shake each rear wheel to check for excessive play.
- Retighten all nuts and bolts to the specified torque. Refer to [RSU-5, "Components"](#).
- Make sure that the suspension arm cotter pin is inserted.
- Check the shock absorber for any oil leakage or other damage.
- Check wheelarch height. Refer to [RSU-19, "Wheelarch Height \(Unladen\\*\)"](#).
- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage.



## Rear Wheel Alignment

EES0000E

Before checking rear wheel alignment, be sure to make a preliminary inspection.

### PRELIMINARY INSPECTION


- Check tires for wear and for improper inflation.
- Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout. Refer to [WT-4, "Inspection"](#).
- Check rear wheel bearings for looseness.
- Check rear suspension for looseness.
- Check that rear shock absorber works properly.
- Check wheelarch height (unladen\*). Refer to [RSU-19, "Wheelarch Height \(Unladen\\*\)"](#).

### CAMBER

- Measure camber of both right and left wheels with a suitable alignment gauge and adjust in accordance with the following procedures.

**Camber** : Refer to [RSU-18, "Rear Wheel Alignment \(Unladen\\*\)"](#).

- If camber is not within specification, adjust by turning the adjusting bolts in the same direction.





# REAR SUSPENSION ASSEMBLY

1. Turn the adjusting bolts in the same direction to calibrate.

**NOTE:**

Camber changes about 5' minutes with each graduation of the adjusting bolt.



2. Tighten adjusting bolt nuts to specification. Refer to [RSU-5, "Components"](#).


**TOE-IN**

Measure toe-in using following procedure. If out of specification, inspect and replace any damaged or worn rear suspension parts.

**WARNING:**


- Always perform the following procedure on a flat surface.
- Make sure that no person is in front of the vehicle before pushing it.

1. Bounce rear of vehicle up and down to stabilize the posture.
2. Push the vehicle straight ahead about 5 m (16 ft).
3. Put a mark on base line of the tread (rear side) of both tires at the same height of hub center. This mark is a measuring point.



4. Measure distance "A" (rear side).
5. Push the vehicle slowly ahead to rotate the wheels 180° degrees (1/2 turn).  
If the wheels have rotated more than 180° degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.
6. Measure distance "B" (front side).

**Total toe-in** : Refer to [RSU-18, "Rear Wheel Alignment \(Unladen\\*\)"](#).





## REAR SUSPENSION ASSEMBLY

- Adjust toe-in by turning the adjusting bolts.

**NOTE:**

Toe changes about 1.5 mm (0.059 in) [one side] with each graduation of the adjusting bolt.



- Tighten the adjusting bolt nuts to specification. Refer to [RSU-5, "Components"](#).



# REAR SUSPENSION MEMBER


## REAR SUSPENSION MEMBER

PFP:55501

### Removal and Installation

EES000S3

#### Rear Suspension Assembly



A  
B  
C  
D  
RSU  
F  
G  
H  
I  
J  
K  
L  
M

# REAR SUSPENSION MEMBER


- |                           |                          |                                    |
|---------------------------|--------------------------|------------------------------------|
| 1. Rear suspension member | 2. Stabilizer bar        | 3. Stabilizer bar bushing          |
| 4. Stabilizer bar clamp   | 5. Connecting rod        | 6. Member stay                     |
| 7. Member stopper         | 8. Radius rod            | 9. Adjusting bolt cam              |
| 10. Front lower link      | 11. Bushing              | 12. Wheel hub and spindle assembly |
| 13. Rear lower link       | 14. Suspension arm       | 15. Lower rubber seat              |
| 16. Coil spring           | 17. Upper rubber seat    | 18. Shock absorber                 |
| 19. Bound bumper cover    | 20. Bound bumper         | 21. Lower bushing                  |
| 22. Upper bracket         | 23. Upper bracket sleeve | 24. Gasket                         |
| 25. Upper bushing         | 26. Washer               |                                    |

## REMOVAL


### CAUTION:

**Before removing the rear suspension assembly, disconnect the ABS wheel sensors from the assembly. Failure to do so may result in damage to the sensor wires and the sensors becoming inoperative.**

1. Remove the center exhaust tube with mufflers using power tool. Refer to [EX-3, "Removal and Installation"](#).
2. Disconnect the parking brake cable assemblies from the front cable. Refer to [PB-3, "Removal and Installation"](#).
3. Remove the brake caliper assemblies from the rear wheel hub and spindle assemblies without disconnecting the brake lines, using power tool. Position the brake caliper assemblies aside using suitable wire. Refer to [BR-33, "Removal and Installation of Caliper Assembly and Disc Rotor"](#).
  - Leave the brake line connected to the brake caliper.
  - Do not depress the brake pedal, or the piston will pop out.
  - Do not pull or twist the brake hose.
4. Remove the shock absorber upper end nuts using power tool.



5. Disconnect the LH and RH ABS sensor harness connectors, and disconnect the ABS sensor harness from the rear suspension member.
6. Remove the LH and RH member stay bolts using power tool.
7. Use a support jack or suitable tool, to support the rear suspension member.
8. Remove the rear suspension member mounting nuts using power tool. Then lower the rear suspension member assembly using the support jack.



## INSTALLATION

Installation is in the reverse order of removal.

# SHOCK ABSORBER

PFP:56210

## SHOCK ABSORBER

### Removal and Installation

EES000S4


1. Remove the wheel and tire assembly using power tool. Refer to [WT-5, "ROAD WHEEL TIRE ASSEMBLY"](#)

2. Set a transmission jack or suitable tool, under the rear lower link to relieve the coil spring tension, then remove the shock absorber lower end bolt using power tool.


**NOTE:**

The rear brake rotor has been removed for clarity only.

3. Remove the transmission jack supporting the rear lower link.



4. Remove the shock absorber upper end nuts using power tool.




### INSTALLATION

Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#) .

### Inspection

EES000S5

- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage on welded or gland packing portions.
- Check piston rod for cracks, deformation or other damage and replace if necessary.



# SUSPENSION ARM

## SUSPENSION ARM

PFP:55501

### Removal and Installation

EES000S6

#### REMOVAL

1. Remove the rear suspension member assembly using power tool. Refer to [RSU-9, "Removal and Installation"](#) .
2. Disconnect the connecting rod upper joint from the suspension arm using power tool.
3. Remove the suspension arm nuts and bolts on the suspension member side using power tool.
4. Remove the suspension arm cotter pin and lock nut on the wheel hub and spindle assembly side using power tool.
5. Disconnect the suspension arm from the wheel hub and spindle assembly using Tool.

**Tool number** : HT72520000 (J-25730-A)

#### CAUTION:

- Do not damage ball joint with Tool.
- While using Tool, temporarily tighten the lock nut so as not to damage the ball joint stud threads.

#### INSTALLATION


Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#) .

- After installing the suspension arm, check the wheel alignment and adjust if necessary. Refer to [RSU-6, "Rear Wheel Alignment"](#) .

#### Inspection

EES000S7

- Check suspension arm for damage, cracks, deformation and replace if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace suspension arm assembly if necessary.
- Check ball joint. Replace suspension arm assembly if any of the following exists:
  - Ball stud is worn.
  - Joint is hard to swing.
  - Play in axial direction is excessive.
- Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.



SFA858A

**Swinging force "A"** : Refer to [RSU-18, "Ball Joint"](#) .

**Turning force "B"** : Refer to [RSU-18, "Ball Joint"](#) .

**Vertical end play "C"** : Refer to [RSU-18, "Ball Joint"](#) .

# RADIUS ROD

PFP:55110


## RADIUS ROD

### Removal and Installation


EES000S8

#### REMOVAL

1. Remove the wheel and tire assembly using power tool. Refer to [WT-5, "ROAD WHEEL TIRE ASSEMBLY"](#).
2. Set a transmission jack or suitable tool, to relieve the coil spring tension and support the radius rod.
3. Disconnect the radius rod from the rear suspension member using power tool.



4. Disconnect the radius rod nut and bolt from the wheel hub and spindle assembly using power tool, then remove the radius rod.



#### INSTALLATION

Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#).

- After installing the radius rod, check the wheel alignment and adjust if necessary. Refer to [RSU-6, "Rear Wheel Alignment"](#).

#### Inspection

EES000S9

- Check radius rod for any deformation, cracks, or damage and replace if necessary.

# FRONT LOWER LINK


PFP:55110

## FRONT LOWER LINK


### Removal and Installation REMOVAL

EES000SA


1. Remove the wheel and tire assembly using power tool. Refer to [WT-5, "ROAD WHEEL TIRE ASSEMBLY"](#)
2. Set a transmission jack or suitable tool, to relieve the coil spring tension and support the front lower link.
3. Disconnect the shock absorber lower end bolt using power tool.



4. Remove the front lower link adjusting bolt using power tool.



5. Disconnect the front lower link nut and bolt from the wheel hub and spindle assembly using power tool, then remove front lower link.



### INSTALLATION

Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#) .

- After installing the front lower link, check the wheel alignment and adjust if necessary. Refer to [RSU-6, "Rear Wheel Alignment"](#) .

### Inspection

EES000SB

Check front lower link for any deformation, cracks, or damage and replace if necessary.

# REAR LOWER LINK AND COIL SPRING

PDF:551B0


## REAR LOWER LINK AND COIL SPRING

### Removal and Installation


EES000SC

#### REMOVAL


1. Remove the wheel and tire assembly using power tool. Refer to [WT-5, "ROAD WHEEL TIRE ASSEMBLY"](#).
2. Set a transmission jack or suitable tool, to relieve the coil spring tension and support the rear lower link.
3. Loosen the rear lower link adjusting bolt and nut connected to the rear suspension member, using power tool.



4. Remove the rear lower link bolt and nut from the wheel hub and spindle assembly using power tool.



5. Slowly lower the transmission jack to release the coil spring tension. Then remove upper rubber seat, coil spring and lower rubber seat from the rear lower link.
6. Remove the rear lower link adjusting bolt and nut from the rear suspension member using power tool, then remove the rear lower link.




#### INSTALLATION

Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#).

## REAR LOWER LINK AND COIL SPRING

- Check that the projecting part inside the upper seat and the flange part of bracket are attached as shown.
- Check that the projection part outside the upper seat directs to vehicle front.
- Position the hollow of the rubber seat with the groove part of rear lower link to install.
- Install coil spring with the side of two paint markers directing to lower side.
- After installing the rear lower link and coil spring, check the wheel alignment and adjust if necessary. Refer to [RSU-6, "Rear Wheel Alignment"](#) .



### Inspection

Check for deformation, cracks, or other damage and replace if necessary.

EES000SD



# STABILIZER BAR


PF5:54611

## STABILIZER BAR


### Removal and Installation

EES000SE

1. Disconnect the stabilizer bar ends from the connecting rods using power tool.




2. Remove the stabilizer bar clamps using power tool, and remove the stabilizer bar bushings.
3. Remove the stabilizer bar.



### INSTALLATION

Installation is in the reverse order of removal. Refer to [RSU-5, "Components"](#).

- Install the stabilizer bar bushing and clamp so they are positioned inside of the crimp ring on the stabilizer bar.



### Inspection

EES000SF

- Check stabilizer bar for any deformation, cracks, or damage and replace if necessary.
- Check rubber bushings for deterioration, or cracks and replace if necessary.

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

### General Specifications (Rear)


EES0000H

Suspension type	Independent multi-link suspension
Shock absorber type	Double-acting hydraulic

### Rear Wheel Alignment (Unladen\*)

EES0000I

Camber Degree minute (Decimal degree)	Minimum	-1°3' (-1.05°)
	Nominal	-0°33' (-0.55°)
	Maximum	-0°3' (-0.05°)




Total toe-in	Distance ("A" - "B") mm (in)	Minimum	1.6 (0.063)
		Nominal	3.2 (0.126)
		Maximum	4.8 (0.189)
	Difference between LH, RH	Minimum	-0.2 (-0.008)
		Nominal	0 (0)
		Maximum	0.2 (0.008)
	Angle (left plus right) Degree minute (Decimal degree)	Minimum	0° 5' (0.06°)
		Nominal	0° 8' (0.13°)
		Maximum	0° 12' (0.20°)

\*: Fuel, engine coolant, and engine oil are full. Spare tire, jack, hand tools and mats in designated positions.

### Ball Joint

EES0000J




Swinging force "A" (measuring point: cotter pin hole of ball stud)	7.8 - 54.9 N (0.8 - 5.6 kg-f, 1.8 - 12.3 lb-f)
Turning torque "B"	0.49 - 3.43 N-m (5.0 - 35.0 kg-cm, 4.3 - 30.4 in-lb)
Vertical end play "C"	0 mm (0 in)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## Wheelarch Height (Unladen\*)

EES0000K

Unit: mm (in)



WEIA0030E

Tire	P225/65R16	P225/60R17
Front (Hf)	740 (29.13)	740 (29.13)
Rear (Hr)	749 (29.49)	749 (29.49)

\*: Fuel, engine coolant, and engine oil are full. Spare tire, jack, hand tools and mats in designated positions.

A  
B  
C  
D  
RSU  
F  
G  
H  
I  
J  
K  
L  
M

## SERVICE DATA AND SPECIFICATIONS (SDS)

---