

SECTION **SB**
SEAT BELTS

A
B
C
D
E
F
G
SB
I
J
K
L
M

CONTENTS

PRECAUTIONS	2	COMPONENTS	8
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	REMOVAL AND INSTALLATION OF OUT-BOARD SEAT BELT RETRACTOR	9
Precaution for Seat Belt Service	2	REMOVAL AND INSTALLATION OF CENTER SEAT BELT RETRACTOR	9
AFTER A COLLISION	3	REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE	9
SEAT BELTS	4	Seat Belt Inspection	11
Front Seat Belt	4	AFTER A COLLISION	11
COMPONENTS	4	PRELIMINARY CHECKS	11
REMOVAL AND INSTALLATION OF SEAT BELT RETRACTOR	5	SEAT BELT RETRACTOR ON-VEHICLE CHECK	12
REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE	5	SEAT BELT RETRACTOR OFF-VEHICLE CHECK	12
Second Row Seat Belt	6	LATCH (LOWER ANCHORS AND TETHER FOR CHILDREN) SYSTEM	14
COMPONENTS	6	Removal and Installation	14
REMOVAL AND INSTALLATION OF SEAT BELT RETRACTOR	6	TOP TETHER STRAP CHILD RESTRAINT	15
REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE	7	Removal and Installation	15
Third Row Seat Belt	8		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EHS00008

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Seat Belt Service

EHS00009

CAUTION:

- Before removing the seat belt pre-tensioner assembly, turn the ignition switch off, disconnect the battery ground cable and wait at least 3 minutes.
- Do not use electrical test equipment for seat belt pre-tensioner connector.
- After replacing or reinstalling seat belt pre-tensioner assembly, or reconnecting seat belt pre-tensioner connector, check the system function. Refer to [SRS-20, "SRS Operation Check"](#) .
- Do not use disassembled buckle or seat belt assembly.
- Replace anchor bolts if they are deformed or worn out.
- Never oil tongue and buckle.
- If any component of seat belt assembly is questionable, do not repair. Replace the whole seat belt assembly.
- If webbing is cut, frayed, or damaged, replace seat belt assembly.
- When replacing seat belt assembly, use a genuine NISSAN seat belt assembly.

PRECAUTIONS

AFTER A COLLISION

WARNING:

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

A
B
C
D
E
F
G
I
J
K
L
M

SB

SEAT BELTS


PF:86884

EHS0000A

SEAT BELTS

Front Seat Belt COMPONENTS

SEC. 868



- | | | |
|--------------------------------------|--|------------------------------------|
| 1. Center pillar upper trim | 2. Seat belt height adjuster | 3. Center pillar |
| 4. Seat belt pre-tensioner connector | 5. Seat belt retractor and belt assembly | 6. Seat belt buckle |
| 7. Center pillar lower trim | 8. Seat belt anchor cover | 9. Seat belt guide |
| 10. Assist handle | 11. Assist handle bolt covers | 12. Center pillar upper bolt cover |

LHIA0028E


SEAT BELTS

REMOVAL AND INSTALLATION OF SEAT BELT RETRACTOR

Removal

CAUTION:


- Before servicing SRS, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.
1. Remove the center pillar upper/lower trim. Refer to [EI-32, "Removal and Installation"](#) .
 2. Separate the seat belt guide from the center pillar.
 3. Remove the seat belt retractor anchor bolts and assembly.
 - On RH side, disconnect the seat belt tension sensor.



4. Disconnect the seat belt pre-tensioner connector.

CAUTION:

- For installing/removing seat belt pre-tensioner connector, insert a thin screwdriver wrapped in tape into the notch, lift the lock and remove the connector.
- Install the connector with the lock raised, and push the lock into the connector.




Installation

Installation is in the reverse order of removal.

REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE

Removal

1. Remove the front seat. Refer to [SE-89, "Removal and Installation"](#) .
2. Remove the screws and seat cushion inner finisher.
3. Remove the anchor bolt and buckle.



Installation

Installation is in the reverse order of removal.


SEAT BELTS

Second Row Seat Belt COMPONENTS

EHS0000B

Second Row

SEC. 869



 N·m (kg·m, ft·lb)

LHIA0030E

- | | | |
|------------------------------|--------------------|--|
| 1. Seat belt height adjuster | 2. Seat belt guide | 3. Seat belt retractor and belt assembly |
| 4. Seat belt lower anchor | 5. D-ring anchor | 6. D-ring anchor bolt cover |

REMOVAL AND INSTALLATION OF SEAT BELT RETRACTOR

Removal

1. Remove seat belt lower anchor bolt.
2. Remove the D-ring anchor bolt cover and D-ring anchor bolt.
3. Remove the upper luggage area trim. Refer to [EI-32. "Removal and Installation"](#).
4. Remove the seat belt guide bolt.
5. Remove seat belt retractor anchor bolt and the assembly.

SEAT BELTS

6. Remove the height adjuster assembly.


Installation

Installation is in the reverse order of removal.

REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE

Removal

1. Remove the seat back recliner handle.
2. Remove the screws and seat cushion finisher.
3. Remove the seat belt buckle anchor bolt and seat belt buckle.



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
SB
I
J
K
L
M


SEAT BELTS

Third Row Seat Belt COMPONENTS

EHS000PN

Third Row Outboard

SEC. 869




 N-m (kg-m, ft-lb)

- | | | |
|----------------------------|-------------------------------|--|
| 1. D-ring mounting bracket | 2. Retractor mounting bracket | 3. Seat belt retractor and belt assembly |
| 4. Seat belt lower anchor | 5. D-ring anchor bolt cover | 6. D-ring anchor |

LHIA0029E

SEAT BELTS

Third Row Center



A
B
C
D
E
F
G

SB

I
J
K
L
M

REMOVAL AND INSTALLATION OF OUTBOARD SEAT BELT RETRACTOR

Removal

1. Remove the upper anchor bolt cover.
2. Remove the D-ring anchor bolt cover and D-ring anchor bolt.
3. Remove the seat belt lower anchor.
4. Remove the upper luggage area trim. Refer to [EI-32, "Removal and Installation"](#).
5. Remove the seat belt retractor anchor bolt and retractor assembly.

Installation

Installation is in the reverse order of removal.

REMOVAL AND INSTALLATION OF CENTER SEAT BELT RETRACTOR

Removal

1. Remove the upper luggage area trim. Refer to [EI-32, "Removal and Installation"](#).
2. Lower the rear portion of the headliner.
3. Remove the seat belt retractor anchor bolts and retractor assembly.

Installation

Installation is in the reverse order of removal.

REMOVAL AND INSTALLATION OF SEAT BELT BUCKLE

Removal

1. Rotate third row seat assembly rearward to expose underside.
2. Release seat cushion trim cover locking strip.
3. Remove the seat belt buckle anchor bolt and seat belt buckle.

Installation

Installation is in the reverse order of removal.

SEAT BELTS

Seat belt buckle anchor bolt : 49 N-m (5.0 kg-m, 36 ft-lb)

SEAT BELTS

EHS0000C

Seat Belt Inspection AFTER A COLLISION

WARNING:

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioners should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

PRELIMINARY CHECKS

1. Check the seat belt warning lamp/chime for proper operation as follows:
 - a. Switch ignition ON. The seat belt warning lamp should illuminate. Also, the seat belt warning chime should sound for about seven seconds.
 - b. Fasten driver's seat belt. The seat belt warning lamp should go out and the chime (if sounding) should stop.
2. If the air bag warning lamp is blinking, conduct self-diagnosis using CONSULT-II, and air bag warning lamp. Refer to [SRS-20, "SRS Operation Check"](#).
3. Check that the seat belt retractor, seat belt anchor and buckle bolts are securely attached.
4. Check the shoulder seat belt guide and shoulder belt height adjuster for front seats. Ensure guide swivels freely and that belt lays flat and does not bind in guide. Ensure height adjuster operates properly and holds securely.
5. Check retractor operation:
 - a. Fully extend the seat belt webbing and check for twists, tears or other damage.
 - b. Allow the seat belt to retract. Ensure that belt returns smoothly and completely into the retractor. If the seat belt does not return smoothly, wipe the inside of the loops with a clean paper cloth, because dirt built up in the loops of the upper anchors can cause the seat belts to retract slowly.
 - c. Fasten the seat belt. Check the seat belt returns smoothly and completely to the retractor. If the belt does not return smoothly, the cause may be an accumulation of dust or dirt. Use the "SEAT BELT TAPE SET" and perform the following steps.

Inspect the front seat belt through-anchor:

1. Pull the seat belt out to a length of 500 mm (19.69 in) or more.
2. Use a clip or other device to hold the seat belt at the center pillar belt opening.
3. Pass a thin wire through the through-anchor belt opening. Hold both ends of the wire and pull taut while moving it up and down several times along the belt opening surface to remove dirt.
4. Any dirt that cannot be removed with the wire can be removed by cleaning the opening with a clean cloth.
5. Apply tape at the point where the belt contacts the through-anchor belt opening.

NOTE:

- Apply the tape so that there is no looseness or wrinkling.
6. Remove the clip holding the seat belt and check that the belt returns smoothly.
7. Repeat steps above as necessary to check the other seat belts.

SEAT BELTS

SEAT BELT RETRACTOR ON-VEHICLE CHECK

Emergency Locking Retractors (ELR) and Automatic Locking Retractors (ALR)

NOTE:

All seat belt retractors are of the Emergency Locking Retractors (ELR) type. In an emergency (sudden stop) the retractor will lock and prevent the belt from extending any further. All 3-point type seat belt retractors except the driver's seat belt also have an Automatic Locking Retractors (ALR) mode. The ALR mode (also called child restraint mode) is used when installing child seats. The ALR mode is activated when the seat belt is fully extended. When the belt is then retracted partially, the ALR mode automatically locks the seat belt in a specific position so the belt cannot be extended any further. To cancel the ALR mode, allow the seat belt to fully wind back into the retractor.

Check the seat belt retractors using the following test(s) to determine if a retractor assembly is operating properly.

ELR Function Stationary Check

Grasp the shoulder belt and pull forward quickly. The retractor should lock and prevent the belt from extending further.

ALR Function Stationary Check

1. Pull out entire length of seat belt from retractor until a click is heard.
2. Retract the belt partially. A clicking noise should be heard as the belt retracts indicating that the retractor is in the Automatic Locking Retractor (ALR) mode.
3. Grasp the seat belt and try to pull out the retractor. The belt must lock and not extend any further. If necessary replace the retractor assembly.
4. Allow the entire length of the belt to retract to cancel the automatic locking mode.

ELR Function Moving Check

WARNING:

Perform the following test in a safe, open area clear of other vehicles and obstructions (for example, a large, empty parking lot). Road surface must be paved and dry. DO NOT perform the following test on wet or gravel roads or on public streets and highways. This could result in an accident and serious personal injury. The driver and passenger must be prepared to brace themselves in the event the retractor does not lock.

1. Fasten driver's seat belt. Buckle a passenger into the seat for the belt that is to be tested.
2. Proceed to the designated safe area.
3. Drive the vehicle at approximately 16 km/h (10 MPH). Notify any passengers of a pending sudden stop. The driver and passenger must be prepared to brace themselves in the event the retractor does not lock. Apply brakes firmly and make a very hard stop.


During stop, seat belts should lock and not be extended. If the seat belt retractor assembly does not lock, perform the retractor off-vehicle check.

SEAT BELT RETRACTOR OFF-VEHICLE CHECK

1. Remove the seat belt retractor assembly.
2. Slowly pull out belt while tilting the retractor assembly forward from the mounted position without twisting the retractor assembly as shown in the illustration.


SEAT BELTS

Front seat belt




Tilt the seat belt retractor forward from the mounted position without twisting the retractor.

Rear seat belt Outer seat belt



Center seat belt



PHIA0257E

15 degrees or less tilt : Belt can be pulled out.

35 degrees or more tilt : Belt locks and cannot be pulled out.

If NG, replace the retractor assembly.

A
B
C
D
E
F
G
SB
I
J
K
L
M

LATCH (LOWER ANCHORS AND TETHER FOR CHILDREN) SYSTEM

LATCH (LOWER ANCHORS AND TETHER FOR CHILDREN) SYSTEM

PF:75466

Removal and Installation

EHS0000D

NOTE:

The LATCH (Lower Anchors and Tether for Children) system is not serviceable.

TOP TETHER STRAP CHILD RESTRAINT

TOP TETHER STRAP CHILD RESTRAINT

PFP:88000

Removal and Installation

EHS0000E

NOTE:

The top tether strap child restraint is not serviceable.

A

B

C

D

E

F

G

SB

I

J

K

L

M

TOP TETHER STRAP CHILD RESTRAINT
